CAT® CLASSIC™ PARTS PRODUCT BOOK

2016



CAT®

Table of Contents

Section Page

Cat Classic Parts Overview....3
Articulated Trucks....5
Backhoe Loaders....121
Engines....257
Excavators....935
Material Handlers....1695
Motor Graders....1725
Pipelayers....2129
Scrapers....2215
Skid Steer Loaders....3013
Track Loaders....3029
Track-Type Tractors....3183
Wheel Dozers....4459
Wheel Loaders....4513
Literature References....5297
Part Cross-Reference....5299

Cat® Classic™ Parts

Cat Classic Parts provide owners of older Cat equipment with low cost replacement parts that offer quality and convenience that can be trusted. Cat machines and engines have long, productive lives. As. the equipment ages, maintenance costs often need to be re-evaluated, taking the remaining market value into consideration. Cat Classic Parts are lower-cost, genuine Cat parts that provide acceptable service life for older Cat equipment. Not all Cat original parts have a Classic Parts option. The Classic Parts Line generally contains parts that have a greater impact on the overall Repair costs. Together with Cat original and remanufactured parts, Cat Classic Parts help Caterpillar offer value-priced Repair alternatives over the entire product life cycle.

Benefits

- Lower owning and operating costs for older Cat equipment
- Standard Caterpillar parts warranty
- One stop shopping for all parts needs
- Quality controlled parts: Cat Classic parts approved by Caterpillar engineers, ensuRing the part will meet form, fit, or function. Quality control procedures in place at parts locations to ensure highest quality parts are delivered.
- Parts provided from the name you can trust - Cat

Cat Classic Parts Overview

Cat Classic Parts Product Book

This Cat Classic Parts Product Book contains the Line of Classic Parts available for Cat machines and engines. The Classic Parts Overview section of this manual provides you with detailed information to help your customer make an informed decision on which Type of part to purchase. The next nine sections contain a cross reference between Cat Classic part numbers and Cat original part numbers categorized by product family and models. This section is further broken down into the model numbers of specific Cat machines and engines. The Literature Reference section provides a reference of available promotional material for Cat Classic Parts information. The Part Cross-Reference section at the End of the catalog details the available parts in numerical order.

Warranty

Cat Classic Parts are backed by the standard Caterpillar parts warranty. This warranty covers the parts for a six month time period. The warranty statement should be referenced for general information on the overall warranty terms. Dealers should reference the relevant parts warranty bulletin for additional specific details about Classic Parts warranty.

Undercarriage Assurance (3 years/4,000 hours) is now offered for Cat Classic Major moving undercarriage parts. Enrollment requirements will be the same As. for Cat premium undercarriage products.

Additional Information

For more information on the Cat Classic Parts product Line, customers should visit the Classic Parts section of www.cat.com.

Dealers, please use your CWS ID to access the global Classic Parts websites. They are contained within the Product Support area of your Cat regional internet websites under Parts Products. Types of information that can be found on these pages include the following: advertising/promotional material, cost comparisons, presentations, a video explaining Classic parts, and appropriate Cat Classic parts contacts.

- NACD - https://nacd.cat.com
- APD - https://apdnet.cat.com
- LACD - https://lacdlive.cat.com
- EAME - https://eame.cat.com

Contact Information

Classic Parts Email Address:
Classic_Parts_Support@cat.com

Customer Interaction Center:
USA: 1-877-CAT-CICO (228-2420)
International: 309-578-7372
Email: cic@cat.com

Sales Model 725

AFX		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone - Roller Brg	380-7504
1S-7057	Gasket	420-6384
1T-0679	Roller-Freewheel	384-4797
1T-0762	Race - Thrust	384-4803
1T-1078	Bearing - Thrust	384-4802
1T-1278	Bearing - Thrust	370-8370
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1T-1401	Ring-Seal	384-4799
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2K-5073	Bushing	299-1989
2S-7931	Bearing - Sleeve	387-2904
2V-5715	Bushing	299-1987
2V-7092	Plate - Retainer	374-6510
3L-9409	Cup - Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone - Roller Brg	399-4433
3S-1404	Bearing - Outer	417-4508
4F-2041	Cup - Roller Brg	418-9609
4N-2514	Gear - Flywheel	421-7283
4N-2572	Spider As.-Fan	451-9027

AFX		
Original Part Number	Part Name	Classic Part Number
4P-3754	Core As.-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4T-8054	Seal As.	472-8010
4V-0094	Shaft-Planet	380-1486
4V-4852	Piston	433-0452
4V-7545	Gear - Ring	394-9823
5L-2031	Cup - Roller Brg	384-5927
5M-0578	Bearing	419-7775
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-3489	Race-Brg Outer	396-9905
5P-7802	Bearing-Aligning	420-2496
5P-9505	Cone - Roller Brg	420-6540
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
6T-0248	Ring-Seal	295-6440
6V-3831	Seal-O-Ring	436-2657
6V-5003	Bearing-Aligning	420-2498
6Y-2027	Disc-Friction	377-7441
6Y-4457	Bearing-Aligning	420-2504
6Y-9960	Mount As..	376-3639
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7K-5448	Cup-Bearing	415-1922
7N-0113	Core As.-Oclr	388-0564
7N-9146	Gear-Fly Starter	279-4995
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8H-9789	Bearing-Ball	374-8342
8N-0111	Mount As.	374-1452
8S-9151	Cup-Spl Tapered	374-8348
9M-1328	Bearing-Aligning	325-6018

AFX		
Original Part Number	Part Name	Classic Part Number
9M-1990	Dowel-Reaction	386-4963
9S-5279	Bearing-Inner	453-3661
9S-8597	Spring	399-8561
9W-7925	Cone - Roller Brg	422-6491
9W-7926	Cup - Roller Brg	421-2554
9Y-7215	Sleeve-Isolator	425-3646
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As.-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As.-Ui Rocker	433-0446
115-9403	Shaft As.	434-7259
116-1102	Sleeve-Injector	451-9024
128-3935	Bearing-Race	396-9897
138-2317	Wheel	396-9948
147-3781	Kit-Gasket (Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
155-6648	Cone Spl Rol Brg	418-9599
176-4168	Bridge As.-Valve	419-4727
176-4172	Bridge As.-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As.-Cyl	438-2022
190-0649	Tightener-Belt	434-1407

Sales Model 725 (Cont'd.)

AFX		
Original Part Number	**Part Name**	**Classic Part Number**
197-9251	Pin As..-Piston	454-6110
216-4781	Gasket Kit	437-8144
237-2859	Bearing-Rlr	368-0125

AFX		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

AFX		
Original Part Number	**Part Name**	**Classic Part Number**
319-3607	Kit-Gasket (Rs)	438-0137
352-2077	Pump Gp-Water -B	434-6108

B1L, WWA		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone - Roller Brg	380-7504
1S-7057	Gasket	420-6384
1T-0679	Roller-Freewheel	384-4797
1T-0762	Race - Thrust	384-4803
1T-1078	Bearing - Thrust	384-4802
1T-1278	Bearing - Thrust	370-8370
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1T-1401	Ring-Seal	384-4799
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2K-5073	Bushing	299-1989
2S-7931	Bearing - Sleeve	387-2904
2V-5715	Bushing	299-1987
2V-7092	Plate - Retainer	374-6510
3L-9409	Cup - Roller Brg	399-4436

B1L, WWA		
Original Part Number	**Part Name**	**Classic Part Number**
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone - Roller Brg	399-4433
3S-1404	Bearing - Outer	417-4508
4F-2041	Cup - Roller Brg	418-9609
4N-2514	Gear - Flywheel	421-7283
4T-8054	Seal As.	472-8010
4V-0094	Shaft-Planet	380-1486
4V-4852	Piston	433-0452
4V-7545	Gear - Ring	394-9823
5L-2031	Cup - Roller Brg	384-5927
5M-0578	Bearing	419-7775
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-3489	Race-Brg Outer	396-9905
5P-7802	Bearing-Aligning	420-2496
5P-9505	Cone - Roller Brg	420-6540
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
6T-0248	Ring-Seal	295-6440
6V-5003	Bearing-Aligning	420-2498
6Y-2027	Disc-Friction	377-7441
6Y-4457	Bearing-Aligning	420-2504
6Y-9960	Mount As..	376-3639

B1L, WWA		
Original Part Number	**Part Name**	**Classic Part Number**
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7K-5448	Cup-Bearing	415-1922
7N-0113	Core As.-Oclr	388-0564
7N-9146	Gear-Fly Starter	279-4995
7T-8816	Bearing-Spl Ball	420-2491
8H-9789	Bearing-Ball	374-8342
8N-0111	Mount As.	374-1452
8S-9151	Cup-Spl Tapered	374-8348
9M-1990	Dowel-Reaction	386-4963
9S-5279	Bearing-Inner	453-3661
9S-8597	Spring	399-8561
9W-7925	Cone - Roller Brg	422-6491
9W-7926	Cup - Roller Brg	421-2554
100-8010	Valve	423-5583
128-3935	Bearing-Race	396-9897
138-2317	Wheel	396-9948
155-6648	Cone Spl Rol Brg	418-9599
237-2859	Bearing-Rlr	368-0125
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
B1L		
9M-1328	Bearing-Aligning	325-6018

Sales Model 725C

2L6, 2T3		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1P-1367	Plunger-Valve	432-8913
1T-0679	Roller-Freewheel	384-4797
1T-0762	Race - Thrust	384-4803
1T-1078	Bearing - Thrust	384-4802
1T-1278	Bearing - Thrust	370-8370
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1T-1401	Ring-Seal	384-4799
2B-0941	Spacer	418-1955
2S-7931	Bearing - Sleeve	387-2904
2V-5715	Bushing	299-1987
2V-7092	Plate - Retainer	374-6510
3L-9409	Cup - Roller Brg	399-4436
3P-1210	Cone - Roller Brg	399-4433
3S-1404	Bearing - Outer	417-4508
4N-2514	Gear - Flywheel	421-7283
4T-8054	Seal As.	472-8010

2L6, 2T3		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8538	Gear - Ring	288-8720
5L-2031	Cup - Roller Brg	384-5927
5M-0578	Bearing	419-7775
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-3489	Race-Brg Outer	396-9905
5P-7802	Bearing-Aligning	420-2496
5P-9505	Cone - Roller Brg	420-6540
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
6T-0248	Ring-Seal	295-6440
6V-3831	Seal-O-Ring	436-2657
6V-5003	Bearing-Aligning	420-2498
6Y-2027	Disc-Friction	377-7441
6Y-2539	Cone - Roller Brg	464-4050
6Y-2540	Cup - Roller Brg	434-8985
6Y-4457	Bearing-Aligning	420-2504
6Y-9960	Mount As..	376-3639
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017

2L6, 2T3		
Original Part Number	**Part Name**	**Classic Part Number**
7K-5448	Cup-Bearing	415-1922
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8S-9151	Cup-Spl Tapered	374-8348
9M-1990	Dowel-Reaction	386-4963
9S-5279	Bearing-Inner	453-3661
9W-7925	Cone - Roller Brg	422-6491
9W-7926	Cup - Roller Brg	421-2554
9Y-2988	Breather As.	361-1716
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
128-3935	Bearing-Race	396-9897
147-1740	Gear-Planet	377-7466
155-6648	Cone Spl Rol Brg	418-9599
161-3411	Gasket	394-0896
237-2859	Bearing-Rlr	368-0125
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

LFB, TFB		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone - Roller Brg	380-7504
1T-0679	Roller-Freewheel	384-4797
1T-0762	Race - Thrust	384-4803

LFB, TFB		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1078	Bearing - Thrust	384-4802
1T-1278	Bearing - Thrust	370-8370
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1T-1401	Ring-Seal	384-4799
2B-0941	Spacer	418-1955
2K-5066	Cone - Roller Brg	396-4142

LFB, TFB		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5069	Cup - Roller Brg	374-8346
2S-7931	Bearing - Sleeve	387-2904
2V-5715	Bushing	299-1987
2V-7092	Plate - Retainer	374-6510
3L-9409	Cup - Roller Brg	399-4436
3P-1210	Cone - Roller Brg	399-4433

Articulated Trucks

Sales Model 725C (Cont'd.)

LFB, TFB		
Original Part Number	**Part Name**	**Classic Part Number**
3S-1404	Bearing - Outer	417-4508
4F-2041	Cup - Roller Brg	418-9609
4N-2514	Gear - Flywheel	421-7283
4T-8054	Seal As.	472-8010
4V-4852	Piston	433-0452
4V-7545	Gear - Ring	394-9823
4V-8538	Gear - Ring	288-8720
5L-2031	Cup - Roller Brg	384-5927
5M-0578	Bearing	419-7775
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-3489	Race-Brg Outer	396-9905
5P-7802	Bearing-Aligning	420-2496
5P-9505	Cone - Roller Brg	420-6540
5T-5682	Driver	418-9579

LFB, TFB		
Original Part Number	**Part Name**	**Classic Part Number**
5V-1274	Spider	385-6110
6T-0248	Ring-Seal	295-6440
6V-3831	Seal-O-Ring	436-2657
6V-5003	Bearing-Aligning	420-2498
6Y-2027	Disc-Friction	377-7441
6Y-2539	Cone - Roller Brg	464-4050
6Y-2540	Cup - Roller Brg	434-8985
6Y-4457	Bearing-Aligning	420-2504
6Y-9960	Mount As..	376-3639
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7K-5448	Cup-Bearing	415-1922
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8S-9151	Cup-Spl Tapered	374-8348
9M-1990	Dowel-Reaction	386-4963

LFB, TFB		
Original Part Number	**Part Name**	**Classic Part Number**
9S-5279	Bearing-Inner	453-3661
9W-7925	Cone - Roller Brg	422-6491
9W-7926	Cup - Roller Brg	421-2554
9Y-2988	Breather As.	361-1716
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
128-3935	Bearing-Race	396-9897
147-1740	Gear-Planet	377-7466
155-6648	Cone Spl Rol Brg	418-9599
161-3411	Gasket	394-0896
237-2859	Bearing-Rlr	368-0125
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 730

AGF		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1S-7057	Gasket	420-6384
1T-0679	Roller-Freewheel	384-4797
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924

AGF		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1282	Race-Brg Thrust	373-1755
1T-1401	Ring-Seal	384-4799
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2S-7931	Bearing-Sleeve	387-2904
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2W-8494	Pulley-Alt	295-5692

AGF		
Original Part Number	**Part Name**	**Classic Part Number**
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3S-1404	Bearing-Outer	417-4508
4F-2041	Cup-Roller Brg	418-9609
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236

Sales Model 730 (Cont'd.)

AGF		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4V-8534	Shaft-Planet	281-1700
4V-8538	Gear-Ring	288-8720
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5L-2031	Cup-Roller Brg	384-5927
5M-0578	Bearing	419-7775
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-3489	Race-Brg Outer	396-9905
5P-7802	Bearing-Aligning	420-2496
5P-7807	Bearing-Ball	314-8502
5P-9505	Cone-Roller Brg	420-6540
5P-9514	Bearing-Ball	417-9467
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
6T-0248	Ring-Seal	295-6440
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-5003	Bearing-Aligning	420-2498
6Y-2027	Disc-Friction	377-7441
6Y-4457	Bearing-Aligning	420-2504
6Y-9960	Mount As.	376-3639
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7E-5816	Shaft-Fan	399-8552
7K-5448	Cup-Bearing	415-1922
7N-0113	Core As-Oclr	388-0564

AGF		
Original Part Number	Part Name	Classic Part Number
7N-9146	Gear-Fly Starter	279-4995
7W-5164	Gasket	420-8568
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8N-0111	Mount As	374-1452
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
9M-1328	Bearing-Aligning	325-6018
9M-1990	Dowel-Reaction	386-4963
9S-5279	Bearing-Inner	453-3661
9S-8597	Spring	399-8561
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9Y-7215	Sleeve-Isolator	425-3646
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446

AGF		
Original Part Number	Part Name	Classic Part Number
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
128-3935	Bearing-Race	396-9897
138-2317	Wheel	396-9948
147-1740	Gear-Planet	377-7466
147-3781	Kit-Gasket (Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
155-6648	Cone Spl Rol Brg	418-9599
160-9874	Kit-Gasket-Scl	386-3048
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
237-2859	Bearing-Rlr	368-0125
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2077	Pump Gp-Water -B	434-6108

B1M		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398

B1M		
Original Part Number	Part Name	Classic Part Number
1P-4694	Cone-Roller Brg	380-7504
1S-7057	Gasket	420-6384
1T-0679	Roller-Freewheel	384-4797
1T-0762	Race-Thrust	384-4803

B1M		
Original Part Number	Part Name	Classic Part Number
1T-1078	Bearing-Thrust	384-4802
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924

Sales Model 730 (Cont'd.)

B1M		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1282	Race-Brg Thrust	373-1755
1T-1401	Ring-Seal	384-4799
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2S-7931	Bearing-Sleeve	387-2904
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3S-1404	Bearing-Outer	417-4508
4F-2041	Cup-Roller Brg	418-9609
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0094	Shaft-Planet	380-1486
4V-4852	Piston	433-0452
4V-7545	Gear-Ring	394-9823

B1M		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8534	Shaft-Planet	281-1700
4V-8538	Gear-Ring	288-8720
5L-2031	Cup-Roller Brg	384-5927
5M-0578	Bearing	419-7775
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-3489	Race-Brg Outer	396-9905
5P-7802	Bearing-Aligning	420-2496
5P-9505	Cone-Roller Brg	420-6540
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
6T-0248	Ring-Seal	295-6440
6V-5003	Bearing-Aligning	420-2498
6Y-2027	Disc-Friction	377-7441
6Y-4457	Bearing-Aligning	420-2504
6Y-9960	Mount As.	376-3639
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7K-5448	Cup-Bearing	415-1922
7N-0113	Core As-Oclr	388-0564
7N-9146	Gear-Fly Starter	279-4995
7T-8816	Bearing-Spl Ball	420-2491

B1M		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8N-0111	Mount As	374-1452
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
9M-1328	Bearing-Aligning	325-6018
9M-1990	Dowel-Reaction	386-4963
9S-5279	Bearing-Inner	453-3661
9S-8597	Spring	399-8561
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
128-3935	Bearing-Race	396-9897
138-2317	Wheel	396-9948
147-1740	Gear-Planet	377-7466
155-6648	Cone Spl Rol Brg	418-9599
237-2859	Bearing-Rlr	368-0125
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

B1W		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1S-7057	Gasket	420-6384
1T-0679	Roller-Freewheel	384-4797
1T-0762	Race-Thrust	384-4803

B1W		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1078	Bearing-Thrust	384-4802
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1401	Ring-Seal	384-4799
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5066	Cone-Roller Brg	396-4142

B1W		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5069	Cup-Roller Brg	374-8346
2S-7931	Bearing-Sleeve	387-2904
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433

Sales Model 730 (Cont'd.)

B1W		
Original Part Number	**Part Name**	**Classic Part Number**
3S-1404	Bearing-Outer	417-4508
4F-2041	Cup-Roller Brg	418-9609
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4V-8534	Shaft-Planet	281-1700
4V-8538	Gear-Ring	288-8720
5L-2031	Cup-Roller Brg	384-5927
5M-0578	Bearing	419-7775
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-3489	Race-Brg Outer	396-9905
5P-7802	Bearing-Aligning	420-2496
5P-9505	Cone-Roller Brg	420-6540
5T-5682	Driver	418-9579

B1W		
Original Part Number	**Part Name**	**Classic Part Number**
5V-1274	Spider	385-6110
6T-0248	Ring-Seal	295-6440
6V-5003	Bearing-Aligning	420-2498
6Y-2027	Disc-Friction	377-7441
6Y-4457	Bearing-Aligning	420-2504
6Y-9960	Mount As.	376-3639
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7K-5448	Cup-Bearing	415-1922
7N-0113	Core As-Oclr	388-0564
7N-9146	Gear-Fly Starter	279-4995
7T-8816	Bearing-Spl Ball	420-2491
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348

B1W		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1990	Dowel-Reaction	386-4963
9S-5279	Bearing-Inner	453-3661
9S-8597	Spring	399-8561
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
108-1760	Bearing-Ball	417-9493
128-3935	Bearing-Race	396-9897
138-2317	Wheel	396-9948
147-1740	Gear-Planet	377-7466
155-6648	Cone Spl Rol Brg	418-9599
237-2859	Bearing-Rlr	368-0125
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

WWB		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1S-7057	Gasket	420-6384
1T-0679	Roller-Freewheel	384-4797
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1401	Ring-Seal	384-4799
2A-4429	Lock-Retainer	379-0174

WWB		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2S-7931	Bearing-Sleeve	387-2904
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3S-1404	Bearing-Outer	417-4508
4F-2041	Cup-Roller Brg	418-9609

WWB		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4V-8534	Shaft-Planet	281-1700
4V-8538	Gear-Ring	288-8720
5L-2031	Cup-Roller Brg	384-5927
5M-0578	Bearing	419-7775
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-3489	Race-Brg Outer	396-9905
5P-7802	Bearing-Aligning	420-2496
5P-9505	Cone-Roller Brg	420-6540
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110

Articulated Trucks

Sales Model 730 (Cont'd.)

WWB		
Original Part Number	**Part Name**	**Classic Part Number**
6T-0248	Ring-Seal	295-6440
6V-5003	Bearing-Aligning	420-2498
6Y-2027	Disc-Friction	377-7441
6Y-4457	Bearing-Aligning	420-2504
6Y-9960	Mount As.	376-3639
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7K-5448	Cup-Bearing	415-1922
7N-0113	Core As-Oclr	388-0564
7N-9146	Gear-Fly Starter	279-4995
7T-8816	Bearing-Spl Ball	420-2491

WWB		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8N-0111	Mount As	374-1452
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
9M-1990	Dowel-Reaction	386-4963
9S-5279	Bearing-Inner	453-3661
9S-8597	Spring	399-8561
9W-7925	Cone-Roller Brg	422-6491

WWB		
Original Part Number	**Part Name**	**Classic Part Number**
9W-7926	Cup-Roller Brg	421-2554
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
128-3935	Bearing-Race	396-9897
138-2317	Wheel	396-9948
147-1740	Gear-Planet	377-7466
155-6648	Cone Spl Rol Brg	418-9599
237-2859	Bearing-Rlr	368-0125
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 730C

2L7, 2L8, 2T4, 2T5		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1P-1367	Plunger-Valve	432-8913
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433

2L7, 2L8, 2T4, 2T5		
Original Part Number	**Part Name**	**Classic Part Number**
3S-1404	Bearing-Outer	417-4508
3T-2094	Bearing-Sleeve	388-0638
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-8538	Gear-Ring	288-8720
5L-2031	Cup-Roller Brg	384-5927
5M-0578	Bearing	419-7775
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7802	Bearing-Aligning	420-2496
5P-9505	Cone-Roller Brg	420-6540
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
6V-5003	Bearing-Aligning	420-2498
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985

2L7, 2L8, 2T4, 2T5		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-4457	Bearing-Aligning	420-2504
6Y-9960	Mount As.	376-3639
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7K-5448	Cup-Bearing	415-1922
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8S-9151	Cup-Spl Tapered	374-8348
9S-5279	Bearing-Inner	453-3661
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
128-3935	Bearing-Race	396-9897
147-1740	Gear-Planet	377-7466
155-6648	Cone Spl Rol Brg	418-9599

Sales Model 730C (Cont'd.)

2L7, 2L8, 2T4, 2T5		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028

2L7, 2L8, 2T4, 2T5		
Original Part Number	**Part Name**	**Classic Part Number**
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

2L7, 2L8, 2T4, 2T5		
Original Part Number	**Part Name**	**Classic Part Number**
2L7, 2L8		
7T-8816	Bearing-Spl Ball	420-2491

LFF, , LFH, TFF, TFH		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433

LFF, , LFH, TFF, TFH		
Original Part Number	**Part Name**	**Classic Part Number**
3S-1404	Bearing-Outer	417-4508
3T-2094	Bearing-Sleeve	388-0638
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4V-8538	Gear-Ring	288-8720
5L-2031	Cup-Roller Brg	384-5927
5M-0578	Bearing	419-7775
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7802	Bearing-Aligning	420-2496
5P-9505	Cone-Roller Brg	420-6540
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
6V-5003	Bearing-Aligning	420-2498
6Y-4457	Bearing-Aligning	420-2504
6Y-9960	Mount As.	376-3639
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7K-5448	Cup-Bearing	415-1922

LFF, , LFH, TFF, TFH		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
9S-5279	Bearing-Inner	453-3661
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
100-8010	Valve	423-5583
128-3935	Bearing-Race	396-9897
147-1740	Gear-Planet	377-7466
155-6648	Cone Spl Rol Brg	418-9599
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
LFF, , LFH		
7T-8816	Bearing-Spl Ball	420-2491

Sales Model 735

AWR		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1M-6573	Cup - Roller Brg	399-4438

AWR		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114

AWR		
Original Part Number	**Part Name**	**Classic Part Number**
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone - Roller Brg	380-7504

Sales Model 735 (Cont'd.)

AWR		
Original Part Number	Part Name	Classic Part Number
1T-0679	Roller-Freewheel	384-4797
1T-1278	Bearing - Thrust	370-8370
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1W-7238	Shaft As.-Pump Dr	379-0164
1W-7239	Shaft As.-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2S-7931	Bearing - Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate - Retainer	374-6510
3E-6772	Seal-Water	382-8017
3K-2511	Dowel-Reaction	383-2126
3K-4290	Rod End	374-1823
3L-9409	Cup - Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3S-3875	Screen-Suction	435-4849
4N-0362	Cover As.-Rgltr	419-4722
4N-0913	Screen As.-Bell	374-7489
4N-2514	Gear - Flywheel	421-7283

AWR		
Original Part Number	Part Name	Classic Part Number
4N-2572	Spider As.-Fan	451-9027
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4V-5392	Spider	377-7430
4W-2474	Rotocoil As.	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5L-2031	Cup - Roller Brg	384-5927
5M-0578	Bearing	419-7775
5P-3489	Race-Brg Outer	396-9905
5P-3930	Bearing As.-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9505	Cone - Roller Brg	420-6540
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
6I-1453	Crankshaft As.	368-5916
6I-2726	Bearing - Sleeve	419-4757
6N-1931	Plunger	379-0171
6T-0248	Ring-Seal	295-6440
6V-3831	Seal-O-Ring	436-2657
6V-5003	Bearing-Aligning	420-2498
6Y-9960	Mount As..	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As.-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7K-5448	Cup-Bearing	415-1922

AWR		
Original Part Number	Part Name	Classic Part Number
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing - Sleeve	380-7373
7N-7628	Gasket	419-1811
7W-2164	Core As.-Oclr	299-1996
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
8M-7166	Housing-Screen	297-7192
8N-2104	Bell As.-Suction	380-1521
8S-6511	Bearing - Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9L-5839	Coupling-Exhaust	374-7480
9M-1328	Bearing-Aligning	325-6018
9M-2744	Cone-Spl Tapered	380-1480
9S-7949	Cup - Roller Brg	420-6531
9S-8597	Spring	399-8561
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9W-7925	Cone - Roller Brg	422-6491
9W-7926	Cup - Roller Brg	421-2554
9W-9930	Mount As.	295-6437
9Y-2988	Breather As.	361-1716
9Y-6054	Rod As.-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-7930	Bearing As.	377-7463
127-6356	Cover As..-Pump	420-8566
128-2922	Kit-Gasket (WP)	386-3814
128-3935	Bearing-Race	396-9897

Sales Model 735 (Cont'd.)

AWR		
Original Part Number	Part Name	Classic Part Number
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing - Sleeve	422-6919
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As.-Idler	426-0035
146-2601	Cover	399-6054
147-1206	Gear Planet	418-9597
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599

AWR		
Original Part Number	Part Name	Classic Part Number
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As.	382-8019
173-0888	Univ Jt As.	394-0898
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As.	397-5055
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
202-3572	Shaft As.-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-WP	437-2003
216-5582	Bearing - Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735

AWR		
Original Part Number	Part Name	Classic Part Number
232-3679	Kit-Gasket (RS)	437-2039
237-2859	Bearing-Rlr	368-0125
253-1752	Plate-Thrust	379-0170
278-1365	Arm As.-Ul Rkr	433-7507
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As.-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

B1N		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1L-7205	Bearing-Ball	416-2167
1M-6573	Cup - Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone - Roller Brg	380-7504
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race - Thrust Brg	453-3651
1T-1278	Bearing - Thrust	370-8370
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1W-4738	Bearing - Sleeve	325-6020

B1N		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As.-Pump Dr	379-0164
1W-7239	Shaft As.-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2M-5685	Bearing-Needle	380-7469
2S-7931	Bearing - Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987

B1N		
Original Part Number	Part Name	Classic Part Number
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate - Retainer	374-6510
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3K-2511	Dowel-Reaction	383-2126
3K-4290	Rod End	374-1823
3L-9409	Cup - Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3S-3875	Screen-Suction	435-4849
4N-2514	Gear - Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4V-5392	Spider	377-7430

Sales Model 735 (Cont'd.)

B1N		
Original Part Number	Part Name	Classic Part Number
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5L-2031	Cup - Roller Brg	384-5927
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-3489	Race-Brg Outer	396-9905
5P-3930	Bearing As.-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9505	Cone - Roller Brg	420-6540
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
6N-1931	Plunger	379-0171
6P-7564	Carrier-Ring	384-3850
6P-7706	Carrier-Ring	388-6603
6T-0248	Ring-Seal	295-6440
6T-1996	Plate-Clutch	368-0117
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-3831	Seal-O-Ring	436-2657
6V-5003	Bearing-Aligning	420-2498
6Y-9960	Mount As..	376-3639
7C-0145	Core As.-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-3039	Core As.-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-7431	Piston-Selector	432-8911
7K-5448	Cup-Bearing	415-1922
7N-2156	Bearing - Sleeve	380-7373
7N-7628	Gasket	419-1811
7W-3145	Plate	422-7894

B1N		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8M-7166	Housing-Screen	297-7192
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing - Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9M-1328	Bearing-Aligning	325-6018
9M-1990	Dowel-Reaction	386-4963
9M-2744	Cone-Spl Tapered	380-1480
9N-3167	Plate-Block Bot	430-4468
9S-7949	Cup - Roller Brg	420-6531
9S-8597	Spring	399-8561
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9W-7925	Cone - Roller Brg	422-6491
9W-7926	Cup - Roller Brg	421-2554
9W-9930	Mount As.	295-6437
9Y-2988	Breather As.	361-1716
101-3125	Gasket	420-8567
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As.	377-7463
127-6356	Cover As..-Pump	420-8566
128-2922	Kit-Gasket (WP)	386-3814
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589
131-7123	Bearing - Sleeve	422-6919
131-8674	Gear As.-Drive	394-0911

B1N		
Original Part Number	Part Name	Classic Part Number
133-3359	Manifold-Exhaust	419-4730
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
147-1206	Gear Planet	418-9597
150-1916	Manifold-Exh	395-1322
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As.	382-8019
173-0888	Univ Jt As.	394-0898
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As.	397-5055
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
187-8979	Gear As.	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing - Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
232-3679	Kit-Gasket (RS)	437-2039
237-2859	Bearing-Rlr	368-0125
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As..	425-3444
278-1365	Arm As.-Ul Rkr	433-7507
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As.-V Rocker	433-0443

Sales Model 735B

E4R, GLG		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1L-7205	Bearing-Ball	416-2167
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1T-0807	Race-Thrust Brg	453-3651
1W-4738	Bearing-Sleeve	325-6020
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-9295	Bearing-Cone	422-6480
2S-7931	Bearing-Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3S-3875	Screen-Suction	435-4849
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4V-5392	Spider	377-7430
4W-5698	Bearing-Main	419-6323

E4R, GLG		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-9505	Cone-Roller Brg	420-6540
5T-5682	Driver	418-9579
6N-1931	Plunger	379-0171
6P-7564	Carrier-Ring	384-3850
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-5003	Bearing-Aligning	420-2498
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7N-2156	Bearing-Sleeve	380-7373
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9M-2744	Cone-Spl Tapered	380-1480
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9930	Mount As	295-6437
101-3125	Gasket	420-8567
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463

L4D		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347

E4R, GLG		
Original Part Number	**Part Name**	**Classic Part Number**
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
147-1206	Gear Planet	418-9597
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
173-0888	Univ Jt As	394-0898
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
GLG		
150-1916	Manifold-Exh	395-1322

Sales Model 735B (Cont'd.)

L4D		
Original Part Number	**Part Name**	**Classic Part Number**
1L-7205	Bearing-Ball	416-2167
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1T-0807	Race-Thrust Brg	453-3651
1W-4738	Bearing-Sleeve	325-6020
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-9295	Bearing-Cone	422-6480
2S-7931	Bearing-Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3S-3875	Screen-Suction	435-4849
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4V-5392	Spider	377-7430
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320

L4D		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5701	Bearing-Main	419-6333
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9505	Cone-Roller Brg	420-6540
5T-5682	Driver	418-9579
6N-1931	Plunger	379-0171
6P-7564	Carrier-Ring	384-3850
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-3831	Seal-O-Ring	436-2657
6V-5003	Bearing-Aligning	420-2498
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7N-2156	Bearing-Sleeve	380-7373
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9M-2744	Cone-Spl Tapered	380-1480
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566

L4D		
Original Part Number	**Part Name**	**Classic Part Number**
128-2922	Kit-Gasket (Wp)	386-3814
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
133-3359	Manifold-Exhaust	419-4730
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
147-1206	Gear Planet	418-9597
150-1916	Manifold-Exh	395-1322
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
173-0888	Univ Jt As	394-0898
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
232-3679	Kit-Gasket (Rs)	437-2039
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444

Sales Model 735B (Cont'd.)

T4P		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1L-7205	Bearing-Ball	416-2167
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1T-0807	Race-Thrust Brg	453-3651
1W-4738	Bearing-Sleeve	325-6020
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-9295	Bearing-Cone	422-6480
2S-7931	Bearing-Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3S-3875	Screen-Suction	435-4849
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4V-5392	Spider	377-7430
4W-5698	Bearing-Main	419-6323

T4P		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-9505	Cone-Roller Brg	420-6540
5T-5682	Driver	418-9579
6N-1931	Plunger	379-0171
6P-7564	Carrier-Ring	384-3850
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-5003	Bearing-Aligning	420-2498
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7N-2156	Bearing-Sleeve	380-7373
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9M-2744	Cone-Spl Tapered	380-1480
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9930	Mount As	295-6437
101-3125	Gasket	420-8567
106-7799	Bearing-Ball	396-9947

T4P		
Original Part Number	**Part Name**	**Classic Part Number**
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
147-1206	Gear Planet	418-9597
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
173-0888	Univ Jt As	394-0898
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170

Articulated Trucks

Sales Model 735C

LFJ, TFJ		
Original Part Number	**Part Name**	**Classic Part Number**
1M-6573	Cup - Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1T-0655	Bearing - Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race Brg Thrust	380-7464
1T-0762	Race - Thrust	384-4803
1T-0807	Race - Thrust Brg	453-3651
1T-1078	Bearing - Thrust	384-4802
1W-7238	Shaft As.-Pump Dr	379-0164
1W-7239	Shaft As.-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-5069	Cup - Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2V-5656	Ring-Snap	374-1454
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017

LFJ, TFJ		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone - Roller Brg	399-4433
4N-2514	Gear - Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4V-5392	Spider	377-7430
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-0578	Bearing	419-7775
5P-3930	Bearing As.-Rlr	419-6022
5T-5682	Driver	418-9579
6N-1931	Plunger	379-0171
6T-0248	Ring-Seal	295-6440
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-5003	Bearing-Aligning	420-2498
6Y-9960	Mount As..	376-3639
7C-0145	Core As.-Oclr	374-4720
7C-0307	Gasket	399-8571
7K-5448	Cup-Bearing	415-1922
7N-2156	Bearing - Sleeve	380-7373
8S-6511	Bearing - Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9M-2744	Cone-Spl Tapered	380-1480

LFJ, TFJ		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9930	Mount As.	295-6437
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
108-7930	Bearing As.	377-7463
110-8368	Bearing-Cup	416-2172
127-6356	Cover As..-Pump	420-8566
128-2922	Kit-Gasket (WP)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing - Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
147-1206	Gear Planet	418-9597
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
173-0888	Univ Jt As.	394-0898
186-2001	Rotocoil As.	397-5055
187-8979	Gear As.	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing - Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170

Sales Model 740

AXM		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347

AXM		
Original Part Number	**Part Name**	**Classic Part Number**
1L-7205	Bearing-Ball	416-2167
1M-6573	Cup-Roller Brg	399-4438

Sales Model 740 (Cont'd.)

AXM		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1T-0807	Race-Thrust Brg	453-3651
1W-4738	Bearing-Sleeve	325-6020
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2S-7931	Bearing-Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3K-4290	Rod End	374-1823
3S-3875	Screen-Suction	435-4849
4N-0362	Cover As-Rgltr	419-4722
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-5857	Cap-Bearing	376-9086

AXM		
Original Part Number	Part Name	Classic Part Number
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4V-5392	Spider	377-7430
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9505	Cone-Roller Brg	420-6540
5T-5682	Driver	418-9579
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
6P-7564	Carrier-Ring	384-3850
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-5003	Bearing-Aligning	420-2498
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-7431	Piston-Selector	432-8911
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7W-2164	Core As-Oclr	299-1996

AXM		
Original Part Number	Part Name	Classic Part Number
7W-3145	Plate	422-7894
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8M-7166	Housing-Screen	297-7192
8N-2104	Bell As-Suction	380-1521
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9L-5839	Coupling-Exhaust	374-7480
9M-1328	Bearing-Aligning	325-6018
9M-1990	Dowel-Reaction	386-4963
9M-2744	Cone-Spl Tapered	380-1480
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919

Sales Model 740 (Cont'd.)

AXM		
Original Part Number	**Part Name**	**Classic Part Number**
131-8674	Gear As-Drive	394-0911
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
147-1206	Gear Planet	418-9597
148-0885	Stator-Converter	379-0161
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054

AXM		
Original Part Number	**Part Name**	**Classic Part Number**
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
173-0888	Univ Jt As	394-0898
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735

AXM		
Original Part Number	**Part Name**	**Classic Part Number**
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
278-8781	Kit-Gasket (Sch)	437-8653
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
374-1849	Brg-Rlr-Cla	399-4442
430-7619	Adapter-Cla	438-1812

AZZ		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1L-7205	Bearing-Ball	416-2167
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1T-0807	Race-Thrust Brg	453-3651
1W-4738	Bearing-Sleeve	325-6020
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

AZZ		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2S-7931	Bearing-Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3K-4290	Rod End	374-1823
3S-3875	Screen-Suction	435-4849
4N-0362	Cover As-Rgltr	419-4722
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283

AZZ		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2572	Spider As-Fan	451-9027
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4V-5392	Spider	377-7430
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9505	Cone-Roller Brg	420-6540
5T-5682	Driver	418-9579

Sales Model 740 (Cont'd.)

AZZ		
Original Part Number	**Part Name**	**Classic Part Number**
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
6P-7564	Carrier-Ring	384-3850
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-3831	Seal-O-Ring	436-2657
6V-5003	Bearing-Aligning	420-2498
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-7431	Piston-Selector	432-8911
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8M-7166	Housing-Screen	297-7192
8N-2104	Bell As-Suction	380-1521
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612

AZZ		
Original Part Number	**Part Name**	**Classic Part Number**
8S-9076	Cup-Bearing	418-9613
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9M-2744	Cone-Spl Tapered	380-1480
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
147-1206	Gear Planet	418-9597

B1P, B1R		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347

AZZ		
Original Part Number	**Part Name**	**Classic Part Number**
148-0885	Stator-Converter	379-0161
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
173-0888	Univ Jt As	394-0898
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
374-1849	Brg-Rlr-Cla	399-4442
430-7619	Adapter-Cla	438-1812

Sales Model 740 (Cont'd.)

B1P, B1R		
Original Part Number	**Part Name**	**Classic Part Number**
1L-7205	Bearing-Ball	416-2167
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1T-0807	Race-Thrust Brg	453-3651
1W-4738	Bearing-Sleeve	325-6020
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2S-7931	Bearing-Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3K-4290	Rod End	374-1823
3S-3875	Screen-Suction	435-4849
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4V-5392	Spider	377-7430
4W-5698	Bearing-Main	419-6323

B1P, B1R		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9505	Cone-Roller Brg	420-6540
5T-5682	Driver	418-9579
6N-1931	Plunger	379-0171
6P-7564	Carrier-Ring	384-3850
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-3831	Seal-O-Ring	436-2657
6V-5003	Bearing-Aligning	420-2498
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-7431	Piston-Selector	432-8911
7N-2156	Bearing-Sleeve	380-7373
7W-3145	Plate	422-7894
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8M-7166	Housing-Screen	297-7192
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9M-1990	Dowel-Reaction	386-4963
9M-2744	Cone-Spl Tapered	380-1480

B1P, B1R		
Original Part Number	**Part Name**	**Classic Part Number**
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
133-3359	Manifold-Exhaust	419-4730
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
147-1206	Gear Planet	418-9597
148-0885	Stator-Converter	379-0161
150-1916	Manifold-Exh	395-1322
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
173-0888	Univ Jt As	394-0898
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055

Sales Model 740 (Cont'd.)

B1P, B1R		
Original Part Number	**Part Name**	**Classic Part Number**
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
232-3679	Kit-Gasket (Rs)	437-2039

B1P, B1R		
Original Part Number	**Part Name**	**Classic Part Number**
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

B1P, B1R		
Original Part Number	**Part Name**	**Classic Part Number**
308-1845	Seal-Wiper	472-8032
328-4240	Arm As-V Rocker	433-0443
374-1849	Brg-Rlr-Cla	399-4442
B1P		
9M-1328	Bearing-Aligning	325-6018

Sales Model 740B

E4S		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1L-7205	Bearing-Ball	416-2167
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1T-0807	Race-Thrust Brg	453-3651
1W-4738	Bearing-Sleeve	325-6020
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-9295	Bearing-Cone	422-6480
2S-7931	Bearing-Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510

E4S		
Original Part Number	**Part Name**	**Classic Part Number**
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3S-3875	Screen-Suction	435-4849
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4V-5392	Spider	377-7430
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-9505	Cone-Roller Brg	420-6540
5T-5682	Driver	418-9579
6N-1931	Plunger	379-0171
6P-7564	Carrier-Ring	384-3850
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-5003	Bearing-Aligning	420-2498

E4S		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7N-2156	Bearing-Sleeve	380-7373
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9M-2744	Cone-Spl Tapered	380-1480
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9930	Mount As	295-6437
101-3125	Gasket	420-8567
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

Sales Model 740B (Cont'd.)

E4S		
Original Part Number	**Part Name**	**Classic Part Number**
131-8674	Gear As-Drive	394-0911
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
147-1206	Gear Planet	418-9597
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107

E4S		
Original Part Number	**Part Name**	**Classic Part Number**
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
173-0888	Univ Jt As	394-0898
177-9024	Adapter-Damper	299-1956

E4S		
Original Part Number	**Part Name**	**Classic Part Number**
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170

GLH, L4E		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1L-7205	Bearing-Ball	416-2167
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1T-0807	Race-Thrust Brg	453-3651
1W-4738	Bearing-Sleeve	325-6020
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-9295	Bearing-Cone	422-6480
2S-7931	Bearing-Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
3B-4124	Cup-Spl Tapered	422-6481

GLH, L4E		
Original Part Number	**Part Name**	**Classic Part Number**
3E-6772	Seal-Water	382-8017
3S-3875	Screen-Suction	435-4849
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4V-5392	Spider	377-7430
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-9505	Cone-Roller Brg	420-6540
5T-5682	Driver	418-9579
6N-1931	Plunger	379-0171
6P-7564	Carrier-Ring	384-3850
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-3831	Seal-O-Ring	436-2657
6V-5003	Bearing-Aligning	420-2498

GLH, L4E		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7N-2156	Bearing-Sleeve	380-7373
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9M-2744	Cone-Spl Tapered	380-1480
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

Sales Model 740B (Cont'd.)

GLH, L4E		
Original Part Number	**Part Name**	**Classic Part Number**
131-8674	Gear As-Drive	394-0911
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
147-1206	Gear Planet	418-9597
150-1916	Manifold-Exh	395-1322
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107

GLH, L4E		
Original Part Number	**Part Name**	**Classic Part Number**
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
173-0888	Univ Jt As	394-0898
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055

GLH, L4E		
Original Part Number	**Part Name**	**Classic Part Number**
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170

L4F		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1L-7205	Bearing-Ball	416-2167
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1T-0807	Race-Thrust Brg	453-3651
1W-4738	Bearing-Sleeve	325-6020
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-9295	Bearing-Cone	422-6480
2S-7931	Bearing-Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510

L4F		
Original Part Number	**Part Name**	**Classic Part Number**
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3S-3875	Screen-Suction	435-4849
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4V-5392	Spider	377-7430
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-9505	Cone-Roller Brg	420-6540
5T-5682	Driver	418-9579
6N-1931	Plunger	379-0171
6P-7564	Carrier-Ring	384-3850
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-3831	Seal-O-Ring	436-2657

L4F		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7N-2156	Bearing-Sleeve	380-7373
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9M-2744	Cone-Spl Tapered	380-1480
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

Sales Model 740B (Cont'd.)

L4F		
Original Part Number	**Part Name**	**Classic Part Number**
131-8674	Gear As-Drive	394-0911
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
147-1206	Gear Planet	418-9597
150-1916	Manifold-Exh	395-1322
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107

L4F		
Original Part Number	**Part Name**	**Classic Part Number**
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
173-0888	Univ Jt As	394-0898
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656

L4F		
Original Part Number	**Part Name**	**Classic Part Number**
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

T4R		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1L-7205	Bearing-Ball	416-2167
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1T-0807	Race-Thrust Brg	453-3651
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-9295	Bearing-Cone	422-6480
2S-7931	Bearing-Sleeve	387-2904
2V-5656	Ring-Snap	374-1454

T4R		
Original Part Number	**Part Name**	**Classic Part Number**
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3S-3875	Screen-Suction	435-4849
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4V-5392	Spider	377-7430
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-9505	Cone-Roller Brg	420-6540
5T-5682	Driver	418-9579
6N-1931	Plunger	379-0171
6P-7564	Carrier-Ring	384-3850
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117

T4R		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-5003	Bearing-Aligning	420-2498
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7N-2156	Bearing-Sleeve	380-7373
8N-2104	Bell As-Suction	380-1521
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9M-2744	Cone-Spl Tapered	380-1480
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9930	Mount As	295-6437
101-3125	Gasket	420-8567
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814

Sales Model 740B (Cont'd.)

T4R		
Original Part Number	**Part Name**	**Classic Part Number**
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052

T4R		
Original Part Number	**Part Name**	**Classic Part Number**
147-1206	Gear Planet	418-9597
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
173-0888	Univ Jt As	394-0898

T4R		
Original Part Number	**Part Name**	**Classic Part Number**
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170

T4S		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1L-7205	Bearing-Ball	416-2167
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1T-0807	Race-Thrust Brg	453-3651
1W-4738	Bearing-Sleeve	325-6020
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-9295	Bearing-Cone	422-6480
2S-7931	Bearing-Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3S-3875	Screen-Suction	435-4849
4N-2514	Gear-Flywheel	421-7283

T4S		
Original Part Number	**Part Name**	**Classic Part Number**
4P-2383	Adapter-Inlet	438-1812
4V-5392	Spider	377-7430
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-9505	Cone-Roller Brg	420-6540
5T-5682	Driver	418-9579
6N-1931	Plunger	379-0171
6P-7564	Carrier-Ring	384-3850
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-5003	Bearing-Aligning	420-2498
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7N-2156	Bearing-Sleeve	380-7373
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612

T4S		
Original Part Number	**Part Name**	**Classic Part Number**
8S-9076	Cup-Bearing	418-9613
9M-2744	Cone-Spl Tapered	380-1480
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9930	Mount As	295-6437
101-3125	Gasket	420-8567
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
147-1206	Gear Planet	418-9597
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845

Articulated Trucks

Sales Model 740B (Cont'd.)

T4S		
Original Part Number	**Part Name**	**Classic Part Number**
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
173-0888	Univ Jt As	394-0898
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055

T4S		
Original Part Number	**Part Name**	**Classic Part Number**
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508

T4S		
Original Part Number	**Part Name**	**Classic Part Number**
253-1752	Plate-Thrust	379-0170
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 740C

LFN, TFN		
Original Part Number	**Part Name**	**Classic Part Number**
1M-6573	Cup - Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1T-0655	Bearing - Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race Brg Thrust	380-7464
1T-0762	Race - Thrust	384-4803
1T-0807	Race - Thrust Brg	453-3651
1T-1078	Bearing - Thrust	384-4802
1W-7238	Shaft As.-Pump Dr	379-0164
1W-7239	Shaft As.-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-5069	Cup - Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2V-5656	Ring-Snap	374-1454

LFN, TFN		
Original Part Number	**Part Name**	**Classic Part Number**
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
4N-2514	Gear - Flywheel	421-7283
4V-5392	Spider	377-7430
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-0578	Bearing	419-7775
5P-3930	Bearing As.-Rlr	419-6022
5T-5682	Driver	418-9579
6N-1931	Plunger	379-0171
6T-0248	Ring-Seal	295-6440
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-9960	Mount As..	376-3639
7C-0145	Core As.-Oclr	374-4720
7K-5448	Cup-Bearing	415-1922
7N-2156	Bearing - Sleeve	380-7373
8S-6511	Bearing - Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9M-2744	Cone-Spl Tapered	380-1480

LFN, TFN		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9930	Mount As.	295-6437
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
108-7930	Bearing As.	377-7463
110-8368	Bearing-Cup	416-2172
127-6356	Cover As..-Pump	420-8566
131-7123	Bearing - Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
138-9381	Plate-Spacer	424-7052
147-1206	Gear Planet	418-9597
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
173-0888	Univ Jt As.	394-0898
186-2001	Rotocoil As.	397-5055
211-0592	Bearing - Main	419-6368
216-5582	Bearing - Sleeve	390-0914
253-1752	Plate-Thrust	379-0170
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
LFN		
246-3130	Shaft-Water Pump	392-4508

Sales Model 745C

LFK, TFK		
Original Part Number	**Part Name**	**Classic Part Number**
1M-6573	Cup - Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1T-0655	Bearing - Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race Brg Thrust	380-7464
1T-0762	Race - Thrust	384-4803
1T-0807	Race - Thrust Brg	453-3651
1T-1078	Bearing - Thrust	384-4802
1W-7238	Shaft As.-Pump Dr	379-0164
1W-7239	Shaft As.-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-5069	Cup - Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480

LFK, TFK		
Original Part Number	**Part Name**	**Classic Part Number**
2V-5656	Ring-Snap	374-1454
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
4N-2514	Gear - Flywheel	421-7283
4V-5392	Spider	377-7430
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-0578	Bearing	419-7775
5P-3930	Bearing As.-Rlr	419-6022
5T-5682	Driver	418-9579
6N-1931	Plunger	379-0171
6T-0248	Ring-Seal	295-6440
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-9960	Mount As..	376-3639
7C-0145	Core As.-Oclr	374-4720
7K-5448	Cup-Bearing	415-1922
7N-2156	Bearing - Sleeve	380-7373
8S-6511	Bearing - Sleeve	380-7372

LFK, TFK		
Original Part Number	**Part Name**	**Classic Part Number**
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9M-2744	Cone-Spl Tapered	380-1480
9W-9930	Mount As.	295-6437
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
108-7930	Bearing As.	377-7463
110-8368	Bearing-Cup	416-2172
127-6356	Cover As..-Pump	420-8566
131-7123	Bearing - Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
138-9381	Plate-Spacer	424-7052
147-1206	Gear Planet	418-9597
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
173-0888	Univ Jt As.	394-0898
186-2001	Rotocoil As.	397-5055
211-0592	Bearing - Main	419-6368
216-5582	Bearing - Sleeve	390-0914
253-1752	Plate-Thrust	379-0170
LFK		
246-3130	Shaft-Water Pump	392-4508

Sales Model AD60

KNW		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4478	Pin	330-9272
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup - Roller Brg	420-6535
1P-4110	Disc-Friction	433-9858
1T-0782	Turbine-Conv	377-7410

KNW		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0807	Race - Thrust Brg	453-3651
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-6489	Race-Brg Outer	374-8350
2L-5271	Bearing-Ball	371-4305

KNW		
Original Part Number	**Part Name**	**Classic Part Number**
2M-5685	Bearing-Needle	380-7469
2S-4900	Shaft As.	384-4792
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As.-Idler	418-9582
3E-6772	Seal-Water	382-8017

Sales Model AD60 (Cont'd.)

KNW		
Original Part Number	**Part Name**	**Classic Part Number**
3G-6856	Pump Gp-Gr A	421-1556
3P-1210	Cone - Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3P-8186	Housing-Screen	390-5261
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing - Sleeve	425-8226
4B-9373	Cone - Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-0487	Valve As.-Check	375-4334
4E-2250	Housing	399-6043
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing - Sleeve	379-0191
4N-0913	Screen As.-Bell	374-7489
4N-2514	Gear - Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-6658	Bearing - Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219
5D-6298	Cup-Spl Tapered	399-6063
5F-7404	Nut-Bearing Lock	308-9878
5K-3968	Cage-Bearing	308-9804
5K-4079	Cage-Bearing	308-9805
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467

KNW		
Original Part Number	**Part Name**	**Classic Part Number**
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-1370	Bearing As.-Rlr	416-2164
5P-9769	Cone-Rlr Bearing	422-6486
5S-4442	Bearing-Spl Ball	419-6025
6N-0977	Bearing - Sleeve	417-4524
6P-7706	Carrier-Ring	388-6603
6P-8340	Sleeve	422-7895
6V-3831	Seal-O-Ring	436-2657
6Y-4689	Bearing-Aligning	420-6532
6Y-8675	Housing As.	418-9584
6Y-9885	Bearing-Rlr As.	396-9906
6Y-9960	Mount As..	376-3639
7C-0145	Core As.-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-5665	Elbow-90 Deg	399-8547
7J-1309	Bearing-Aligning	360-2275
7J-9346	Bearing - Sleeve	374-8357
7N-2156	Bearing - Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4497	Gear-CPLG & Sun	444-1842
7S-4523	Gear - Ring	419-8799
7S-8631	Shaft As.	275-5296
7W-3145	Plate	422-7894
8C-3111	Rod End-Spher	392-4523
8K-0067	Spacer	396-1569
8N-2104	Bell As.-Suction	380-1521
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing - Sleeve	380-7372

KNW		
Original Part Number	**Part Name**	**Classic Part Number**
8V-1540	Univ Jt As.	388-6574
9D-7924	Mount As.	360-2356
9K-5639	Pin	425-6451
9M-1990	Dowel-Reaction	386-4963
9M-1997	Bearing-Ball	384-5954
9V-7710	Univ Joint As.	394-8234
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As.	295-6437
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Cam-shaft Dr	376-9069
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As.	377-7463
117-9712	Shaft-Dr Idler	425-7754
124-0501	Cone-Spl Tapered	399-4441
124-0502	Cup-Spl Tapered	416-2161
124-0503	Cone-Spl Tapered	418-9604
126-2522	Cone-Spl Tapered	377-7397
127-6356	Cover As..-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing - Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
141-4109	Core As.-Oclr	416-5518
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As.	397-5055
211-0592	Bearing - Main	419-6368
216-5582	Bearing - Sleeve	390-0914
217-8938	Tightening-Belt	419-4735

Sales Model AD60 (Cont'd.)

KNW		
Original Part Number	Part Name	Classic Part Number
237-9849	Cage-Bearing	443-1201
253-1752	Plate-Thrust	379-0170

KNW		
Original Part Number	Part Name	Classic Part Number
321-5746	Bearing-Main	419-6367
352-0200	Pump Gp-Water -B	434-6109

KNW		
Original Part Number	Part Name	Classic Part Number
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420
443-1200	Brg-Rlr-Cla	377-7397

Sales Model D20D

9MG		
Original Part Number	Part Name	Classic Part Number
1L-7205	Bearing-Ball	416-2167
1S-7057	Gasket	420-6384
1S-9670	Univ Jt As.	443-2017
1T-0020	Wheel-Turbine	297-4862
1T-0576	Bearing - Sleeve	379-0186
1T-1981	Stator As.-Conv	377-7416
1W-4623	Muffler As.	360-9622
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915
2K-0535	Nut	299-2026
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2K-5073	Bushing	299-1989
2W-7213	Bearing - Sleeve	419-4667
3K-2511	Dowel-Reaction	383-2126
3P-3208	Flange-Joint	301-4647
4B-1455	Cap As.-Filler	361-1719
4F-2393	Bearing-Ball	380-1499
4M-3915	Bearing-Caged	377-7427
4M-5226	Bearing-Ball	399-6061
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As.-Arm	457-4596
4P-8577	Rod As.-Injector	455-5513
4T-8054	Seal As.	472-8010

9MG		
Original Part Number	Part Name	Classic Part Number
4V-0092	Hub As.	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-4852	Piston	433-0452
4V-7545	Gear - Ring	394-9823
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-7188	Core As.-Oclr	374-7501
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5K-3171	Plate-Coupling	417-9475
5L-2031	Cup - Roller Brg	384-5927
5M-6212	Tube	390-0996
5P-5045	Bearing-Spl Ball	415-1917
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9514	Bearing-Ball	417-9467
5S-4326	Housing-Screen	435-4790
5T-1362	Univ Joint As.-5C	325-6011
5V-1274	Spider	385-6110
6H-2577	Spider Gp-Brg&	333-4954
6I-1099	Manifold-Exh	424-6366
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As. - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6P-7704	Carrier-Ring	314-8658

9MG		
Original Part Number	Part Name	Classic Part Number
6P-7706	Carrier-Ring	388-6603
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-5003	Bearing-Aligning	420-2498
6Y-9960	Mount As..	376-3639
7C-3760	Tube As.-O Drain	375-5443
7C-5403	Tube As.	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As.-Injector	433-0449
7E-7302	Bracket	416-5497
7G-2830	Ring-Seal	295-6441
7G-3707	Piston-Clutch	302-2691
7G-5618	Manifold As.	283-5204
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As.	314-8721
7M-7219	Bearing - Thrust	384-4816
7T-2036	Cap As.-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As..	378-3986
7W-5095	Gear - Flywheel	425-9190
7W-5426	Camshaft As..	378-3987
7W-8064	Valve-Inlet	384-8705

Sales Model D20D (Cont'd.)

9MG		
Original Part Number	**Part Name**	**Classic Part Number**
7W-9027	Base-Oil Cooler	399-8545
8H-2810	Case As.-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8P-1919	Gear-Planet	300-2579
8P-1948	Gear - Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As.	325-6033
8T-0072	Cone-Rlr Brg	377-7448
8V-1537	Gear-Sun	446-3061
8V-3134	Pinion-Bevel	260-0788
9G-0280	Piston	283-5213
9J-3206	Bearing-Spher	360-2275
9P-8517	Case-XMSN	394-0909
9W-3605	Carrier-Ring	314-8662
9W-9930	Mount As.	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605

9MG		
Original Part Number	**Part Name**	**Classic Part Number**
100-2941	Gasket Kit	393-1020
100-6267	Plate As.-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As.-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3237	Precleaner As.	432-4220
126-5875	Flywheel As..	374-4694
136-0819	Valve-Exhaust	384-8697
138-2317	Wheel	396-9948
139-9175	Gasket Kit	377-7464
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388

9MG		
Original Part Number	**Part Name**	**Classic Part Number**
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
163-1387	Gear - Flywheel	374-4697
203-9726	Gasket Kit	434-7282
212-4893	Bearing - Thrust	419-6372
213-3193	Rod As.-Conn	379-8870
224-3973	Kit-Gasket-RS	437-8123
224-4323	Kit-Gasket-RS	393-3627
224-6638	Bearing-Rod	419-6371
229-5153	Bearing - Thrust	419-6370
229-5154	Bearing - Thrust	419-6369
264-6898	Kit-Gasket-Sch	382-5069
271-5658	Crankshaft As..	368-5912
277-7089	Shaft As.	380-7578
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2160	Pump Gp-Water -B	433-0789

Sales Model D250B

5WD		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup - Roller Brg	374-8345
1L-7205	Bearing-Ball	416-2167
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As.-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786

5WD		
Original Part Number	**Part Name**	**Classic Part Number**
1S-9670	Univ Jt As.	443-2017
1T-1278	Bearing - Thrust	370-8370
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

5WD		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As.	443-2659
1W-5912	Tappet As.-Guide &	325-6223
1W-6541	Plunger As.	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As.-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

Sales Model D250B (Cont'd.)

5WD		
Original Part Number	Part Name	Classic Part Number
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-5065	Cone - Roller Brg	416-2157
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2K-5073	Bushing	299-1989
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As.-Gear	296-1367
2P-1738	Plate As.-Oil Pan	325-6164
2P-1739	Tube As.-Pump	325-6229
2P-1751	Bell As.-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As.-Inlet	325-6230
2P-2697	Tube As.-Air Vent	382-6901
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As.-Pump	325-6197
2S-7931	Bearing - Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203

5WD		
Original Part Number	Part Name	Classic Part Number
2W-7458	Crankshaft As.	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2749	Cartridge Gp-RR	422-8125
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
4F-2393	Bearing-Ball	380-1499
4K-8225	Pin-Cylinder	297-7215
4M-3915	Bearing-Caged	377-7427
4M-5226	Bearing-Ball	399-6061
4N-0432	Bearing-Ball	417-4499
4N-4679	Pulley-Fan	394-9837
4N-7693	Crankshaft As.	269-8763
4P-3546	Valve As.-Relief	325-6236
4P-7688	Valve As.-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As.-Fuel Inj	279-4984
4P-9382	Line As.-Fuel Inj	279-4985
4P-9383	Line As.-Fuel Inj	279-4988
4P-9384	Line As.-Fuel Inj	279-4989
4P-9395	Line As.-Fuel Inj	383-3690
4P-9396	Line As.-Fuel Inj	383-3691
4S-8472	Hood As.-Preclnr	296-1355
4T-6869	Cartridge Gp	422-8104
4V-0092	Hub As.	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4V-7543	Retainer	281-1699

5WD		
Original Part Number	Part Name	Classic Part Number
4V-7545	Gear - Ring	394-9823
4W-0452	Seal As.-Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As.-Oclr	374-7501
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5K-3171	Plate-Coupling	417-9475
5L-2031	Cup - Roller Brg	384-5927
5L-7632	Support-Elbow	433-9854
5M-2051	Bearing-Caged	380-7467
5M-6212	Tube	390-0996
5P-2526	Cup-Rlr Bearing	380-7498
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As.	242-3437
5S-7630	Bearing - Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6H-2577	Spider Gp-Brg &	333-4954

Sales Model D250B (Cont'd.)

5WD		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As.-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As. - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-5003	Bearing-Aligning	420-2498
6V-5976	Kit-Gasket (RS)	393-5200
6Y-1690	Carrier-Ring	384-3849
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As.	283-5204
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As.	314-8721
7H-7628	Bearing	453-3655
7J-8893	Cone - Roller Brg	374-1846
7M-4046	Bearing - Sleeve	394-8206
7M-7219	Bearing - Thrust	384-4816
7N-0110	Core As.-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724

5WD		
Original Part Number	Part Name	Classic Part Number
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As.-Radiator	295-6417
7T-2036	Cap As.-Fuel	361-1721
7T-9542	Gear - Ring	384-4822
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As.-Pump Suc	378-3989
8H-2810	Case As.-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8N-0703	Bearing - Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As.-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing - Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As.-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing - Sleeve	394-8207

5WD		
Original Part Number	Part Name	Classic Part Number
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As.-Outlet	325-6232
8N-7782	Rotocoil As.	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-0961	Impeller-Conv	433-9204
8P-1919	Gear-Planet	300-2579
8P-1948	Gear - Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As.	325-6033
8S-0493	Shaft As.-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As.	242-3438
8S-3995	Gage As.-Level	430-8042
8S-6511	Bearing - Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-1537	Gear-Sun	446-3061
8V-3134	Pinion-Bevel	260-0788

Sales Model D250B (Cont'd.)

5WD		
Original Part Number	Part Name	Classic Part Number
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9J-3206	Bearing-Spher	360-2275
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9M-1328	Bearing-Aligning	325-6018
9P-8517	Case-XMSN	394-0909
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As.	325-6042
9T-5096	Flexplate	455-3271
9W-3605	Carrier-Ring	314-8662
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-7689	Yoke As.	422-7245
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As.-Head	279-4977
124-3237	Precleaner As.	432-4220
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296

5WD		
Original Part Number	Part Name	Classic Part Number
138-2317	Wheel	396-9948
139-9175	Gasket Kit	377-7464
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As.-Piston	477-7125
165-4262	Body As.-Piston	270-4351
165-4262	Body As.-Piston	270-4353
165-4262	Body As.-Piston	477-7126
167-8123	Damper As.	299-2006
168-4531	Body As.-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687

5WD		
Original Part Number	Part Name	Classic Part Number
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As.-Idler	364-5259
196-0029	Gear As.-Idler	374-4674
203-9726	Gasket Kit	434-7282
205-1098	Gasket Kit	434-7283
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As.-Cla	279-4988
296-1360	Line As.-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As.	242-3439

Sales Model D250D

6NG		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167
1P-3934	Cup - Roller Brg	420-6535

6NG		
Original Part Number	Part Name	Classic Part Number
1P-3935	Cone - Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1S-9670	Univ Jt As.	443-2017
1T-1278	Bearing - Thrust	370-8370

6NG		
Original Part Number	Part Name	Classic Part Number
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1W-4623	Muffler As.	360-9622
2D-9454	Cup - Roller Brg	415-1914

Sales Model D250D (Cont'd.)

6NG		
Original Part Number	Part Name	Classic Part Number
2D-9455	Cone - Roller Brg	415-1915
2K-0535	Nut	299-2026
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2K-5073	Bushing	299-1989
2M-5685	Bearing-Needle	380-7469
2S-7931	Bearing - Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate - Retainer	374-6510
2W-7213	Bearing - Sleeve	419-4667
3K-2511	Dowel-Reaction	383-2126
3P-3208	Flange-Joint	301-4647
4B-1455	Cap As.-Filler	361-1719
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup - Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4M-3915	Bearing-Caged	377-7427
4M-5226	Bearing-Ball	399-6061
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As.-Arm	457-4596
4P-8577	Rod As.-Injector	455-5513
4T-8054	Seal As.	472-8010
4V-0092	Hub As.	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-4852	Piston	433-0452
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7545	Gear - Ring	394-9823
4W-1203	Cup-Rlr Brg	418-9603

6NG		
Original Part Number	Part Name	Classic Part Number
4W-2042	Spacer	325-6217
4W-7188	Core As.-Oclr	374-7501
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5K-3171	Plate-Coupling	417-9475
5L-2031	Cup - Roller Brg	384-5927
5M-6212	Tube	390-0996
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9514	Bearing-Ball	417-9467
5S-4326	Housing-Screen	435-4790
5V-1274	Spider	385-6110
5V-5917	Pinion-Diff	297-7224
6C-3500	Shaft-Bev Pinion	384-4788
6H-2577	Spider Gp-Brg&	333-4954
6I-1099	Manifold-Exh	424-6366
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As. - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-5003	Bearing-Aligning	420-2498
6W-5119	Housing-Support	450-8051
6Y-1690	Carrier-Ring	384-3849
6Y-9960	Mount As..	376-3639
7C-3760	Tube As.-O Drain	375-5443
7C-5403	Tube As.	374-4673
7C-6976	Bearing-Conn Rod	419-6317

6NG		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As.-Injector	433-0449
7E-7302	Bracket	416-5497
7G-2830	Ring-Seal	295-6441
7G-3707	Piston-Clutch	302-2691
7G-5618	Manifold As.	283-5204
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As.	314-8721
7H-7628	Bearing	453-3655
7J-8893	Cone - Roller Brg	374-1846
7M-7219	Bearing - Thrust	384-4816
7T-2036	Cap As.-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As..	378-3986
7W-5095	Gear - Flywheel	425-9190
7W-5426	Camshaft As..	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8H-2810	Case As.-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8P-0953	Turbine-Conv	297-7269
8P-1919	Gear-Planet	300-2579
8P-1948	Gear - Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As.	325-6033
8T-0072	Cone-Rlr Brg	377-7448
8V-1537	Gear-Sun	446-3061
8V-3134	Pinion-Bevel	260-0788
9C-5852	Hub As.	297-7208

Sales Model D250D (Cont'd.)

6NG		
Original Part Number	Part Name	Classic Part Number
9C-8205	Gear-Bevel	319-8175
9G-0280	Piston	283-5213
9J-3206	Bearing-Spher	360-2275
9M-1328	Bearing-Aligning	325-6018
9P-8517	Case-XMSN	394-0909
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9W-3605	Carrier-Ring	314-8662
9W-9930	Mount As.	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2941	Gasket Kit	393-1020
100-6267	Plate As.-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-7689	Yoke As.	422-7245
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020

6NG		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
115-4204	Pulley As.-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3237	Precleaner As.	432-4220
126-5875	Flywheel As..	374-4694
136-0819	Valve-Exhaust	384-8697
136-7813	Bearing-Race	460-8296
138-2317	Wheel	396-9948
139-9175	Gasket Kit	377-7464
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
163-1387	Gear - Flywheel	374-4697

6NG		
Original Part Number	Part Name	Classic Part Number
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
203-9726	Gasket Kit	434-7282
212-4893	Bearing - Thrust	419-6372
213-3193	Rod As.-Conn	379-8870
224-3973	Kit-Gasket-RS	437-8123
224-4323	Kit-Gasket-RS	393-3627
224-6638	Bearing-Rod	419-6371
229-5153	Bearing - Thrust	419-6370
229-5154	Bearing - Thrust	419-6369
264-6898	Kit-Gasket-Sch	382-5069
271-5658	Crankshaft As..	368-5912
277-7089	Shaft As.	380-7578
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2160	Pump Gp-Water -B	433-0789

Sales Model D250E

4PS		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-2696	Cone-Bearing	374-1834
1P-3958	Bearing-Needle	434-6114

4PS		
Original Part Number	Part Name	Classic Part Number
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone - Roller Brg	380-7504
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9945	Bracket As.-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0655	Bearing - Thrust	377-7409

4PS		
Original Part Number	Part Name	Classic Part Number
1T-0686	Race Brg Thrust	380-7464
1T-0762	Race - Thrust	384-4803
1T-1078	Bearing - Thrust	384-4802
1T-1278	Bearing - Thrust	370-8370
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

Sales Model D250E (Cont'd.)

4PS		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As.	443-2659
1W-5912	Tappet As.-Guide &	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As.-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-9457	Cone-Spl Tapered	377-7418
2H-6489	Race-Brg Outer	374-8350
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2K-5073	Bushing	299-1989
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As.-Gear	296-1367
2P-1738	Plate As.-Oil Pan	325-6164
2P-1739	Tube As.-Pump	325-6229
2P-1751	Bell As.-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As.-Inlet	325-6230
2P-6245	Shaft As.-Pump	325-6197
2S-7931	Bearing - Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357

4PS		
Original Part Number	**Part Name**	**Classic Part Number**
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As.	242-3439
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup - Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone - Roller Brg	399-4433
3P-3208	Flange-Joint	301-4647
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As.-Filler	361-1719
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup - Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-8225	Pin-Cylinder	297-7215
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As.	269-8763
4P-3546	Valve As.-Relief	325-6236
4P-7688	Valve As.-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4T-8054	Seal As.	472-8010
4V-0094	Shaft-Planet	380-1486
4V-4852	Piston	433-0452
4V-7545	Gear - Ring	394-9823
4W-0452	Seal As. -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511

4PS		
Original Part Number	**Part Name**	**Classic Part Number**
5K-3171	Plate-Coupling	417-9475
5L-2031	Cup - Roller Brg	384-5927
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9505	Cone - Roller Brg	420-6540
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As.	242-3437
5S-7630	Bearing - Sleeve	394-0219
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
6B-7469	Spacer	417-4535
6E-6153	Plate-Port	346-5678
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As.-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436

Sales Model D250E (Cont'd.)

4PS		
Original Part Number	Part Name	Classic Part Number
6I-8510	Housing As. - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-5003	Bearing-Aligning	420-2498
6Y-1690	Carrier-Ring	384-3849
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As..	376-3639
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7G-3707	Piston-Clutch	302-2691
7G-5618	Manifold As.	283-5204
7G-7431	Piston-Selector	432-8911
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As.	314-8721
7H-7628	Bearing	453-3655
7J-8893	Cone - Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing - Sleeve	394-8206
7M-7219	Bearing - Thrust	384-4816
7N-0110	Core As.-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656

4PS		
Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As.-Radiator	295-6417
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As.-Pump Suc	378-3989
8H-2810	Case As.-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8M-7166	Housing-Screen	297-7192
8N-0703	Bearing - Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As.-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As.-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing - Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As.-Outlet	325-6232
8N-7782	Rotocoil As.	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

4PS		
Original Part Number	Part Name	Classic Part Number
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1919	Gear-Planet	300-2579
8P-1948	Gear - Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As.	325-6033
8S-0493	Shaft As.-Pump	325-6198
8S-3970	Chamber As.	242-3438
8S-6511	Bearing - Sleeve	380-7372
9G-0280	Piston	283-5213
9G-1499	Gear-Pump (Oil)	295-6424
9J-3206	Bearing-Spher	360-2275
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9P-8517	Case-XMSN	394-0909
9S-5279	Bearing-Inner	453-3661
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As.	325-6042
9W-3271	Body As.-Oil Pump	430-4553
9W-3605	Carrier-Ring	314-8662
9W-9930	Mount As.	295-6437
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
101-7689	Yoke As.	422-7245

Sales Model D250E (Cont'd.)

4PS		
Original Part Number	Part Name	Classic Part Number
106-7798	Bearing-Ball	417-9494
111-8015	Gasket As.-Head	279-4977
124-3237	Precleaner As.	432-4220
131-3815	Seal Gp-Basic	325-6193
131-8246	Yoke As. (8.5C)	430-5362
136-7813	Bearing-Race	460-8296
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As.-Piston	477-7125
165-4262	Body As.-Piston	270-4351
165-4262	Body As.-Piston	270-4353

4PS		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As.-Piston	477-7126
167-8123	Damper As.	299-2006
168-4531	Body As.-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835

4PS		
Original Part Number	Part Name	Classic Part Number
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As.-Idler	364-5259
196-0029	Gear As.-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As.	242-3439

5TN		
Original Part Number	Part Name	Classic Part Number
1L-7205	Bearing-Ball	416-2167
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-2696	Cone-Bearing	374-1834
1P-9945	Bracket As.-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-1278	Bearing - Thrust	370-8370
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006

5TN		
Original Part Number	Part Name	Classic Part Number
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As.	443-2659
1W-5912	Tappet As.-Guide &	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As.-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915
2K-0535	Nut	299-2026
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2K-5073	Bushing	299-1989

5TN		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As.-Gear	296-1367
2P-1738	Plate As.-Oil Pan	325-6164
2P-1739	Tube As.-Pump	325-6229
2P-1751	Bell As.-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As.-Inlet	325-6230
2P-6245	Shaft As.-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203

Sales Model D250E (Cont'd.)

5TN		
Original Part Number	Part Name	Classic Part Number
2W-7458	Crankshaft As.	242-3439
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As.-Filler	361-1719
4E-8534	Retainer-Seal	300-2588
4F-2393	Bearing-Ball	380-1499
4K-8225	Pin-Cylinder	297-7215
4M-3915	Bearing-Caged	377-7427
4M-5226	Bearing-Ball	399-6061
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As.	269-8763
4P-3546	Valve As.-Relief	325-6236
4P-7688	Valve As.-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4V-0092	Hub As.	396-9934
4V-0094	Shaft-Planet	380-1486
4V-4852	Piston	433-0452
4V-7545	Gear - Ring	394-9823
4W-0452	Seal As. -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As.-Oclr	374-7501
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5K-3171	Plate-Coupling	417-9475
5L-2031	Cup - Roller Brg	384-5927
5M-0578	Bearing	419-7775
5M-6212	Tube	390-0996
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529

5TN		
Original Part Number	Part Name	Classic Part Number
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As.	242-3437
5S-7630	Bearing - Sleeve	394-0219
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As.-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As. - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-5003	Bearing-Aligning	420-2498
6Y-1690	Carrier-Ring	384-3849
6Y-9960	Mount As..	376-3639
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7G-3707	Piston-Clutch	302-2691

5TN		
Original Part Number	Part Name	Classic Part Number
7G-5618	Manifold As.	283-5204
7G-7431	Piston-Selector	432-8911
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As.	314-8721
7H-7628	Bearing	453-3655
7J-8893	Cone - Roller Brg	374-1846
7M-4046	Bearing - Sleeve	394-8206
7M-7219	Bearing - Thrust	384-4816
7N-0110	Core As.-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As.-Radiator	295-6417
7T-2036	Cap As.-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As.-Pump Suc	378-3989
8H-2810	Case As.-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8M-7166	Housing-Screen	297-7192
8N-0703	Bearing - Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

Sales Model D250E (Cont'd.)

5TN		
Original Part Number	Part Name	Classic Part Number
8N-1721	Rod As.-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As.-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing - Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As.-Outlet	325-6232
8N-7782	Rotocoil As.	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1919	Gear-Planet	300-2579
8P-1948	Gear - Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As.	325-6033
8S-0493	Shaft As.-Pump	325-6198

5TN		
Original Part Number	Part Name	Classic Part Number
8S-3970	Chamber As.	242-3438
8S-6511	Bearing - Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-1499	Gear-Pump (Oil)	295-6424
9J-3206	Bearing-Spher	360-2275
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9P-8517	Case-XMSN	394-0909
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As.	325-6042
9W-3271	Body As.-Oil Pump	430-4553
9W-3605	Carrier-Ring	314-8662
9W-9930	Mount As.	295-6437
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
101-7689	Yoke As.	422-7245
111-8015	Gasket As.-Head	279-4977
124-3237	Precleaner As.	432-4220
130-1521	Gasket Kit - Sch	393-1030
131-3815	Seal Gp-Basic	325-6193
131-8246	Yoke As. (8.5C)	430-5362
134-3038	Gasket Kit	437-3228
136-7813	Bearing-Race	460-8296
138-2317	Wheel	396-9948
139-9175	Gasket Kit	377-7464
147-6170	Gasket Kit	437-4598
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As.-Piston	477-7125

5TN		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As.-Piston	477-7126
165-4262	Body As.-Piston	270-4351
165-4262	Body As.-Piston	270-4353
167-8123	Damper As.	299-2006
168-4531	Body As.-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As.-Idler	364-5259
196-0029	Gear As.-Idler	374-4674
205-1098	Gasket Kit	434-7283
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As.	242-3439

Sales Model D25C

9YC		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup - Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup - Roller Brg	420-6535
1P-3935	Cone - Roller Brg	377-7397
1P-9945	Bracket As.-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-9670	Univ Jt As.	443-2017
1T-1278	Bearing - Thrust	370-8370
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As.	443-2659
1W-5912	Tappet As.-Guide &	325-6223
1W-6541	Plunger As.	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As.-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup - Roller Brg	386-4944

9YC		
Original Part Number	Part Name	Classic Part Number
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As.-Gear	296-1367
2P-1738	Plate As.-Oil Pan	325-6164
2P-1739	Tube As.-Pump	325-6229
2P-1751	Bell As.-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As.-Inlet	325-6230
2P-2697	Tube As.-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As.-Pump	325-6197
2S-6097	Tang	375-9979
2S-7931	Bearing - Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate - Retainer	374-6510
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357

9YC		
Original Part Number	Part Name	Classic Part Number
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As.	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-7663	Cartridge Gp	422-8120
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3N-4892	Lever-Gov Cont	439-4542
3P-3208	Flange-Joint	301-4647
4B-1455	Cap As.-Filler	361-1719
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup - Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-8225	Pin-Cylinder	297-7215
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As.	269-8763
4P-3546	Valve As.-Relief	325-6236
4P-7688	Valve As.-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As.-Fuel Inj	279-4984
4P-9382	Line As.-Fuel Inj	279-4985
4P-9383	Line As.-Fuel Inj	279-4988
4P-9384	Line As.-Fuel Inj	279-4989
4P-9395	Line As.-Fuel Inj	383-3690
4P-9396	Line As.-Fuel Inj	383-3691
4S-8472	Hood As.-Preclnr	296-1355
4V-5213	Spindle	299-2060

Sales Model D25C (Cont'd.)

9YC		
Original Part Number	Part Name	Classic Part Number
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4W-0452	Seal As. -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As.-Oclr	374-7501
4W-9989	Gear As.-Idler	302-2677
5D-2989	Bearing	380-7511
5L-7632	Support-Elbow	433-9854
5M-2051	Bearing-Caged	380-7467
5M-6212	Tube	390-0996
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-6254	Bearing	420-2495
5P-7487	Bearing-Aligning	434-3300
5P-7802	Bearing-Aligning	420-2496
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As.	242-3437
5S-7630	Bearing - Sleeve	394-0219
5S-8543	Bearing - Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5U-0557	Pump Gp-VN Bsc-B	422-8175
5V-1274	Spider	385-6110
5V-5917	Pinion-Diff	297-7224

9YC		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3500	Shaft-Bev Pinion	384-4788
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As.-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As. -Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-5003	Bearing-Aligning	420-2498
6W-5119	Housing-Support	450-8051
6Y-1690	Carrier-Ring	384-3849
6Y-4457	Bearing-Aligning	420-2504
7B-7515	Bearing-Ball	399-6059
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As.	283-5204
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As.	314-8721
7H-7628	Bearing	453-3655
7J-8893	Cone - Roller Brg	374-1846
7M-4046	Bearing - Sleeve	394-8206

9YC		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing - Thrust	384-4816
7N-0110	Core As.-Oil Clr	319-3435
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As.-Radiator	295-6417
7T-9542	Gear - Ring	384-4822
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As.-Pump Suc	378-3989
8F-9365	Pin	319-3463
8H-2810	Case As.-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8N-0703	Bearing - Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As.-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing - Sleeve	417-4518
8N-2641	Sleeve	325-6210

Sales Model D25C (Cont'd.)

9YC		
Original Part Number	Part Name	Classic Part Number
8N-3251	Shaft As.-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing - Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As.-Outlet	325-6232
8N-7782	Rotocoil As.	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-0961	Impeller-Conv	433-9204
8P-1919	Gear-Planet	300-2579
8P-1948	Gear - Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As.	325-6033
8S-0493	Shaft As.-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501

9YC		
Original Part Number	Part Name	Classic Part Number
8S-3970	Chamber As.	242-3438
8S-3995	Gage As.-Level	430-8042
8S-6511	Bearing - Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8V-6390	Drum-Brake	377-7449
9C-5852	Hub As.	297-7208
9C-8205	Gear-Bevel	319-8175
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9P-8517	Case-XMSN	394-0909
9S-3581	Cup - Roller Brg	415-1923
9S-3582	Cone - Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-7949	Cup - Roller Brg	420-6531
9S-8679	Chamber As.	325-6042
9T-2200	Cartridgr Gp	422-8114
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-5160	Plunger Kt-Adj	385-7218
9W-3605	Carrier-Ring	314-8662
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-0155	Pipe As.-Exhaust	399-4427
101-7689	Yoke As.	422-7245
103-5961	Wheel	398-2963

9YC		
Original Part Number	Part Name	Classic Part Number
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As.-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
131-8246	Yoke As. (8.5C)	430-5362
131-8248	Yoke As.	434-6113
134-3068	Kit-Gasket(F)	393-3636
136-7813	Bearing-Race	460-8296
139-9175	Gasket Kit	377-7464
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As.-Piston	477-7125
165-4262	Body As.-Piston	270-4353
165-4262	Body As.-Piston	270-4351
165-4262	Body As.-Piston	477-7126
167-8123	Damper As.	299-2006
168-4531	Body As.-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698

Articulated Trucks

Sales Model D25C (Cont'd.)

9YC		
Original Part Number	**Part Name**	**Classic Part Number**
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As.-Idler	364-5259
196-0029	Gear As.-Idler	374-4674

9YC		
Original Part Number	**Part Name**	**Classic Part Number**
205-1098	Gasket Kit	434-7283
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

9YC		
Original Part Number	**Part Name**	**Classic Part Number**
296-1359	Line As.-Cla	279-4988
296-1360	Line As.-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As.	242-3439
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model D25D

1HK		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup - Roller Brg	420-6535
1P-3935	Cone - Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114
1P-9945	Bracket As.-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-9670	Univ Jt As.	443-2017
1T-0767	Bearing - Sleeve	383-2108
1T-1278	Bearing - Thrust	370-8370
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1T-1386	Yoke-Univ Joint	325-6239

1HK		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As.	443-2659
1W-5912	Tappet As.-Guide &	325-6223
1W-6541	Plunger As.	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As.-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0535	Nut	299-2026
2K-5065	Cone - Roller Brg	416-2157

1HK		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As.-Gear	296-1367
2P-1738	Plate As.-Oil Pan	325-6164
2P-1739	Tube As.-Pump	325-6229
2P-1751	Bell As.-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As.-Inlet	325-6230
2P-2697	Tube As.-Air Vent	382-6901
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As.-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912

Sales Model D25D (Cont'd.)

1HK		
Original Part Number	Part Name	Classic Part Number
2S-6097	Tang	375-9979
2S-7931	Bearing - Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate - Retainer	374-6510
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As.	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-7663	Cartridge Gp	422-8120
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3N-5869	Support-Elbow	375-9973
3P-3208	Flange-Joint	301-4647
3T-2094	Bearing - Sleeve	388-0638
3T-2145	Carrier As.	325-6041
3T-4384	Housing As.-Cl	435-2573
4B-1455	Cap As.-Filler	361-1719
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup - Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-7420	Retainer	297-7234
4K-8225	Pin-Cylinder	297-7215
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As.	269-8763
4P-3546	Valve As.-Relief	325-6236
4P-7688	Valve As.-Check	420-6216

1HK		
Original Part Number	Part Name	Classic Part Number
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As.-Fuel Inj	279-4984
4P-9382	Line As.-Fuel Inj	279-4985
4P-9383	Line As.-Fuel Inj	279-4988
4P-9384	Line As.-Fuel Inj	279-4989
4P-9395	Line As.-Fuel Inj	383-3690
4P-9396	Line As.-Fuel Inj	383-3691
4S-8472	Hood As.-Preclnr	296-1355
4V-4852	Piston	433-0452
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7543	Retainer	281-1699
4W-0452	Seal As. -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As.-Oclr	374-7501
5D-2989	Bearing	380-7511
5K-8591	Bearing - Outer	380-7502
5L-7632	Support-Elbow	433-9854
5M-2051	Bearing-Caged	380-7467
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As.-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5411	Race-Brg Outer	417-9481

1HK		
Original Part Number	Part Name	Classic Part Number
5P-6254	Bearing	420-2495
5P-7802	Bearing-Aligning	420-2496
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As.	242-3437
5S-7630	Bearing - Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5U-0557	Pump Gp-VN Bsc-B	422-8175
5V-1274	Spider	385-6110
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3500	Shaft-Bev Pinion	384-4788
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As.-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As. - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658

Sales Model D25D (Cont'd.)

1HK		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6V-5003	Bearing-Aligning	420-2498
6W-5119	Housing-Support	450-8051
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As..	376-3639
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As.	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As.	314-8721
7H-7628	Bearing	453-3655
7J-8893	Cone - Roller Brg	374-1846
7K-0449	Yoke As.	297-7271
7M-4046	Bearing - Sleeve	394-8206
7M-7219	Bearing - Thrust	384-4816
7N-0110	Core As.-Oil Clr	319-3435
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811

1HK		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As.-Radiator	295-6417
7T-3370	Yoke As.	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear - Ring	384-4822
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As.-Pump Suc	378-3989
8E-7569	Case-XMSN	394-0899
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8F-9365	Pin	319-3463
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone - Roller Brg	399-4442
8H-2810	Case As.-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8N-0703	Bearing - Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As.-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing - Sleeve	417-4518

1HK		
Original Part Number	**Part Name**	**Classic Part Number**
8N-2641	Sleeve	325-6210
8N-3251	Shaft As.-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing - Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As.-Outlet	325-6232
8N-7782	Rotocoil As.	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-0961	Impeller-Conv	433-9204
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear - Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212

Sales Model D25D (Cont'd.)

1HK		
Original Part Number	Part Name	Classic Part Number
8S-0248	Breather As.	325-6033
8S-0493	Shaft As.-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As.	242-3438
8S-3995	Gage As.-Level	430-8042
8S-6511	Bearing - Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8V-6390	Drum-Brake	377-7449
8V-7885	Housing-Support	297-7193
9C-5852	Hub As.	297-7208
9C-8205	Gear-Bevel	319-8175
9C-8218	Shaft-Bev Pinion	302-2697
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing - Sleeve	418-1931
9G-7412	Gear As.-Pump	297-7183
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear - Ring	373-5398
9P-8517	Case-XMSN	394-0909
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220

1HK		
Original Part Number	Part Name	Classic Part Number
9P-9507	Race - Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9S-3581	Cup - Roller Brg	415-1923
9S-3582	Cone - Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-7949	Cup - Roller Brg	420-6531
9S-8679	Chamber As.	325-6042
9T-2200	Cartridgr Gp	422-8114
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-5160	Plunger Kt-Adj	385-7218
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear - Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9W-9930	Mount As.	295-6437
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-0155	Pipe As.-Exhaust	399-4427
101-7689	Yoke As.	422-7245
103-5961	Wheel	398-2963
108-5680	Gage-Oil Level	378-4001
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As.-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
119-5727	Bearing-Spl Ball	417-9491
124-3237	Precleaner As.	432-4220
126-2522	Cone-Spl Tapered	377-7397
127-5537	Core As.-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
131-8246	Yoke As. (8.5C)	430-5362

1HK		
Original Part Number	Part Name	Classic Part Number
131-8248	Yoke As.	434-6113
134-3038	Gasket Kit	437-3228
136-7813	Bearing-Race	460-8296
139-9175	Gasket Kit	377-7464
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-1206	Gear Planet	418-9597
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As.-Piston	477-7125
165-4262	Body As.-Piston	270-4351
165-4262	Body As.-Piston	270-4353
165-4262	Body As.-Piston	477-7126
167-8123	Damper As.	299-2006
168-4531	Body As.-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698

Sales Model D25D (Cont'd.)

1HK		
Original Part Number	**Part Name**	**Classic Part Number**
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As.-Idler	364-5259
196-0029	Gear As.-Idler	374-4674
203-9726	Gasket Kit	434-7282

1HK		
Original Part Number	**Part Name**	**Classic Part Number**
205-1098	Gasket Kit	434-7283
206-6405	Bearing-Spl Ball	420-2503
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

1HK		
Original Part Number	**Part Name**	**Classic Part Number**
296-1359	Line As.-Cla	279-4988
296-1360	Line As.-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As.	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8256	Kit-Gasket (Sch)	447-8653
443-1200	Brg-Rlr-Cla	377-7397

Sales Model D300B

4SD		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup - Roller Brg	374-8345
1L-7205	Bearing-Ball	416-2167
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As.-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-9670	Univ Jt As.	443-2017
1T-1278	Bearing - Thrust	370-8370
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As.	443-2659

4SD		
Original Part Number	**Part Name**	**Classic Part Number**
1W-5912	Tappet As.-Guide &	325-6223
1W-6541	Plunger As.	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As.-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-5065	Cone - Roller Brg	416-2157
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2K-5073	Bushing	299-1989
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927

4SD		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1170	Shaft As.-Gear	296-1367
2P-1738	Plate As.-Oil Pan	325-6164
2P-1739	Tube As.-Pump	325-6229
2P-1751	Bell As.-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As.-Inlet	325-6230
2P-2697	Tube As.-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As.-Pump	325-6197
2S-7931	Bearing - Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203

Sales Model D300B (Cont'd.)

4SD		
Original Part Number	Part Name	Classic Part Number
2W-7458	Crankshaft As.	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2749	Cartridge Gp-RR	422-8125
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3N-4892	Lever-Gov Cont	439-4542
3P-3208	Flange-Joint	301-4647
4F-2393	Bearing-Ball	380-1499
4K-8225	Pin-Cylinder	297-7215
4M-3915	Bearing-Caged	377-7427
4M-5226	Bearing-Ball	399-6061
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As.	269-8763
4P-3546	Valve As.-Relief	325-6236
4P-7688	Valve As.-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As.-Fuel Inj	279-4984
4P-9382	Line As.-Fuel Inj	279-4985
4P-9383	Line As.-Fuel Inj	279-4988
4P-9384	Line As.-Fuel Inj	279-4989
4P-9395	Line As.-Fuel Inj	383-3690
4P-9396	Line As.-Fuel Inj	383-3691
4S-8472	Hood As.-Preclnr	296-1355
4T-6869	Cartridge Gp	422-8104
4V-0092	Hub As.	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4V-7543	Retainer	281-1699

4SD		
Original Part Number	Part Name	Classic Part Number
4V-7545	Gear - Ring	394-9823
4W-0452	Seal As. -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As.-Oclr	374-7501
4W-9989	Gear As.-Idler	302-2677
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5K-3171	Plate-Coupling	417-9475
5L-2031	Cup - Roller Brg	384-5927
5L-7632	Support-Elbow	433-9854
5M-2051	Bearing-Caged	380-7467
5M-6212	Tube	390-0996
5P-2526	Cup-Rlr Bearing	380-7498
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As.	242-3437
5S-7630	Bearing - Sleeve	394-0219
5S-8543	Bearing - Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
6B-7469	Spacer	417-4535

4SD		
Original Part Number	Part Name	Classic Part Number
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As.-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As. - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-5003	Bearing-Aligning	420-2498
6Y-1690	Carrier-Ring	384-3849
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As.	283-5204
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As.	314-8721
7H-7628	Bearing	453-3655
7J-8893	Cone - Roller Brg	374-1846
7M-4046	Bearing - Sleeve	394-8206
7M-7219	Bearing - Thrust	384-4816
7N-0110	Core As.-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686

Sales Model D300B (Cont'd.)

4SD		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7166	Race Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As.-Radiator	295-6417
7T-2036	Cap As.-Fuel	361-1721
7T-9542	Gear - Ring	384-4822
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As.	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As.-Pump Suc	378-3989
8H-2810	Case As.-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8N-0703	Bearing - Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As.-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing - Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As.-Rkr Arm	314-8711

4SD		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing - Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As.-Outlet	325-6232
8N-7782	Rotocoil As.	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-0961	Impeller-Conv	433-9204
8P-1919	Gear-Planet	300-2579
8P-1948	Gear - Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As.	325-6033
8S-0493	Shaft As.-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501

4SD		
Original Part Number	**Part Name**	**Classic Part Number**
8S-3970	Chamber As.	242-3438
8S-3995	Gage As.-Level	430-8042
8S-6511	Bearing - Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-1537	Gear-Sun	446-3061
8V-3134	Pinion-Bevel	260-0788
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9J-3206	Bearing-Spher	360-2275
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9P-8517	Case-XMSN	394-0909
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As.	325-6042
9T-5096	Flexplate	455-3271
9W-3605	Carrier-Ring	314-8662
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-7689	Yoke As.	422-7245
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As.-Head	279-4977
124-3237	Precleaner As.	432-4220
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
138-2317	Wheel	396-9948
139-9175	Gasket Kit	377-7464
144-0502	Ring Kit-Piston	395-1312

Sales Model D300B (Cont'd.)

4SD		
Original Part Number	Part Name	Classic Part Number
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As.-Piston	477-7125
165-4262	Body As.-Piston	270-4351
165-4262	Body As.-Piston	270-4353
165-4262	Body As.-Piston	477-7126
167-8123	Damper As.	299-2006
168-4531	Body As.-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

4SD		
Original Part Number	Part Name	Classic Part Number
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As.-Idler	364-5259
196-0029	Gear As.-Idler	374-4674
203-9726	Gasket Kit	434-7282

4SD		
Original Part Number	Part Name	Classic Part Number
205-1098	Gasket Kit	434-7283
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As.-Cla	279-4988
296-1360	Line As.-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As.	242-3439
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model D300D

5MG		
Original Part Number	Part Name	Classic Part Number
1L-7205	Bearing-Ball	416-2167
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As.-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-9670	Univ Jt As.	443-2017
1T-1278	Bearing - Thrust	370-8370
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1W-1669	Piston	325-6158

5MG		
Original Part Number	Part Name	Classic Part Number
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As.	443-2659
1W-5912	Tappet As.-Guide &	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As.-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513

5MG		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2K-5073	Bushing	299-1989
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As.-Gear	296-1367
2P-1738	Plate As.-Oil Pan	325-6164

Sales Model D300D (Cont'd.)

5MG		
Original Part Number	Part Name	Classic Part Number
2P-1739	Tube As.-Pump	325-6229
2P-1751	Bell As.-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As.-Inlet	325-6230
2P-6245	Shaft As.-Pump	325-6197
2S-7931	Bearing - Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As.	242-3439
2W-7678	Gear-Water Pump	325-6088
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
4F-2393	Bearing-Ball	380-1499
4K-8225	Pin-Cylinder	297-7215
4M-3915	Bearing-Caged	377-7427
4M-5226	Bearing-Ball	399-6061
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As.	269-8763
4P-3546	Valve As.-Relief	325-6236
4P-7688	Valve As.-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As.-Fuel Inj	279-4984
4P-9382	Line As.-Fuel Inj	279-4985

5MG		
Original Part Number	Part Name	Classic Part Number
4P-9383	Line As.-Fuel Inj	279-4988
4P-9384	Line As.-Fuel Inj	279-4989
4P-9395	Line As.-Fuel Inj	383-3690
4P-9396	Line As.-Fuel Inj	383-3691
4S-8472	Hood As.-Preclnr	296-1355
4V-0092	Hub As.	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-4852	Piston	433-0452
4V-7545	Gear - Ring	394-9823
4W-0452	Seal As. -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As.-Oclr	374-7501
5D-2989	Bearing	380-7511
5K-3171	Plate-Coupling	417-9475
5L-2031	Cup - Roller Brg	384-5927
5L-7632	Support-Elbow	433-9854
5M-6212	Tube	390-0996
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4326	Housing-Screen	435-4790
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

5MG		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As.	242-3437
5S-7630	Bearing - Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
6B-7469	Spacer	417-4535
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As.-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As. - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-5003	Bearing-Aligning	420-2498
6Y-1690	Carrier-Ring	384-3849
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-3707	Piston-Clutch	302-2691
7G-5618	Manifold As.	283-5204
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As.	314-8721
7H-7628	Bearing	453-3655
7J-8893	Cone - Roller Brg	374-1846
7M-4046	Bearing - Sleeve	394-8206
7M-7219	Bearing - Thrust	384-4816

Sales Model D300D (Cont'd.)

5MG		
Original Part Number	Part Name	Classic Part Number
7N-0110	Core As.-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As.-Radiator	295-6417
7T-2036	Cap As.-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As.	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As.-Pump Suc	378-3989
8H-2810	Case As.-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8N-0703	Bearing - Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As.-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing - Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As.-Rkr Arm	314-8711

5MG		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing - Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As.-Outlet	325-6232
8N-7782	Rotocoil As.	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1919	Gear-Planet	300-2579
8P-1948	Gear - Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As.	325-6033
8S-0493	Shaft As.-Pump	325-6198
8S-3970	Chamber As.	242-3438
8S-6511	Bearing - Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448

5MG		
Original Part Number	Part Name	Classic Part Number
8V-1537	Gear-Sun	446-3061
8V-3134	Pinion-Bevel	260-0788
9G-0280	Piston	283-5213
9J-3206	Bearing-Spher	360-2275
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9P-8517	Case-XMSN	394-0909
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As.	325-6042
9W-3605	Carrier-Ring	314-8662
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-7689	Yoke As.	422-7245
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As.-Head	279-4977
124-3237	Precleaner As.	432-4220
131-3815	Seal Gp-Basic	325-6193
131-8246	Yoke As. (8.5C)	430-5362
136-7813	Bearing-Race	460-8296
138-2317	Wheel	396-9948
139-9175	Gasket Kit	377-7464
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As.-Piston	477-7125

Sales Model D300D (Cont'd.)

5MG		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As.-Piston	270-4351
165-4262	Body As.-Piston	270-4353
165-4262	Body As.-Piston	477-7126
167-8123	Damper As.	299-2006
168-4531	Body As.-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

5MG		
Original Part Number	**Part Name**	**Classic Part Number**
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As.-Idler	364-5259
196-0029	Gear As.-Idler	374-4674
203-9726	Gasket Kit	434-7282
232-3233	Bearing-Main	376-9085

5MG		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As.-Cla	279-4988
296-1360	Line As.-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As.	242-3439

Sales Model D300E

5KS		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone - Roller Brg	380-7504
1P-9945	Bracket As.-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-1278	Bearing - Thrust	370-8370
1T-1281	Retainer - Brg	390-0924

5KS		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1282	Race Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As.	443-2659
1W-5912	Tappet As.-Guide &	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As.-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

5KS		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As.-Gear	296-1367
2P-1738	Plate As.-Oil Pan	325-6164
2P-1739	Tube As.-Pump	325-6229
2P-1751	Bell As.-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As.-Inlet	325-6230
2P-6245	Shaft As.-Pump	325-6197
2S-7931	Bearing - Sleeve	387-2904

Sales Model D300E (Cont'd.)

5KS		
Original Part Number	Part Name	Classic Part Number
2V-5715	Bushing	299-1987
2V-7092	Plate - Retainer	374-6510
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As.	242-3439
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup - Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone - Roller Brg	399-4433
3P-3208	Flange-Joint	301-4647
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As.-Filler	361-1719
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup - Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-8225	Pin-Cylinder	297-7215
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As.	269-8763
4P-3546	Valve As.-Relief	325-6236
4P-7688	Valve As.-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4T-8054	Seal As.	472-8010
4V-4852	Piston	433-0452
4V-7543	Retainer	281-1699

5KS		
Original Part Number	Part Name	Classic Part Number
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As.	423-9669
4V-8538	Gear - Ring	288-8720
4W-0452	Seal As. -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As.-Oclr	374-7501
5D-2989	Bearing	380-7511
5K-3171	Plate-Coupling	417-9475
5L-2031	Cup - Roller Brg	384-5927
5M-0578	Bearing	419-7775
5M-6212	Tube	390-0996
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-6254	Bearing	420-2495
5P-7802	Bearing-Aligning	420-2496
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9505	Cone - Roller Brg	420-6540
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As.	242-3437
5S-7630	Bearing - Sleeve	394-0219
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
6B-7469	Spacer	417-4535
6E-6153	Plate-Port	346-5678
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273

5KS		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As.-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As. - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-5003	Bearing-Aligning	420-2498
6Y-1690	Carrier-Ring	384-3849
6Y-9960	Mount As..	376-3639
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7G-3707	Piston-Clutch	302-2691
7G-5618	Manifold As.	283-5204
7G-7431	Piston-Selector	432-8911
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As.	314-8721
7H-7628	Bearing	453-3655
7J-8893	Cone - Roller Brg	374-1846
7M-4046	Bearing - Sleeve	394-8206
7M-7219	Bearing - Thrust	384-4816
7N-0110	Core As.-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin-Piston	295-6438

Sales Model D300E (Cont'd.)

5KS		
Original Part Number	**Part Name**	**Classic Part Number**
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As.-Radiator	295-6417
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As.-Pump Suc	378-3989
8H-2810	Case As.-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8L-8867	Pulley	434-1409
8M-7166	Housing-Screen	297-7192
8N-0703	Bearing - Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As.-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As.-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing - Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As.-Outlet	325-6232
8N-7782	Rotocoil As.	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

5KS		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1919	Gear-Planet	300-2579
8P-1948	Gear - Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As.	325-6033
8S-0493	Shaft As.-Pump	325-6198
8S-3970	Chamber As.	242-3438
8S-6511	Bearing - Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0280	Piston	283-5213
9G-1499	Gear-Pump (Oil)	295-6424
9J-3206	Bearing-Spher	360-2275
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9P-8517	Case-XMSN	394-0909
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As.	325-6042
9W-3271	Body As.-Oil Pump	430-4553

5KS		
Original Part Number	**Part Name**	**Classic Part Number**
9W-3605	Carrier-Ring	314-8662
9W-9930	Mount As.	295-6437
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
101-7689	Yoke As.	422-7245
111-8015	Gasket As.-Head	279-4977
124-3237	Precleaner As.	432-4220
131-3815	Seal Gp-Basic	325-6193
131-8246	Yoke As. (8.5C)	430-5362
136-7813	Bearing-Race	460-8296
138-2317	Wheel	396-9948
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As.-Piston	477-7125
165-4262	Body As.-Piston	270-4351
165-4262	Body As.-Piston	270-4353
165-4262	Body As.-Piston	477-7126
167-8123	Damper As.	299-2006
168-4531	Body As.-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835
187-0605	Gasket Kit - Cl	382-5055

Sales Model D300E (Cont'd.)

5KS		
Original Part Number	**Part Name**	**Classic Part Number**
196-0028	Gear As.-Idler	364-5259
196-0029	Gear As.-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	295-6438

5KS		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

5KS		
Original Part Number	**Part Name**	**Classic Part Number**
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As.	242-3439

7FN		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone - Roller Brg	380-7504
1P-9945	Bracket As.-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-1278	Bearing - Thrust	370-8370
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As.	443-2659
1W-5912	Tappet As.-Guide &	325-6223
1W-6810	Pipe-Outlet	472-8036

7FN		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6987	Valve As.-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As.-Gear	296-1367
2P-1738	Plate As.-Oil Pan	325-6164
2P-1739	Tube As.-Pump	325-6229
2P-1751	Bell As.-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As.-Inlet	325-6230
2P-6245	Shaft As.-Pump	325-6197
2S-7931	Bearing - Sleeve	387-2904
2V-5715	Bushing	299-1987
2V-7092	Plate - Retainer	374-6510
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203

7FN		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7458	Crankshaft As.	242-3439
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup - Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone - Roller Brg	399-4433
3P-3208	Flange-Joint	301-4647
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As.-Filler	361-1719
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup - Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-8225	Pin-Cylinder	297-7215
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As.	269-8763
4P-3546	Valve As.-Relief	325-6236
4P-7688	Valve As.-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4T-8054	Seal As.	472-8010
4V-4852	Piston	433-0452

Sales Model D300E (Cont'd.)

7FN		
Original Part Number	Part Name	Classic Part Number
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As.	423-9669
4V-8538	Gear - Ring	288-8720
4W-0452	Seal As. -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As.-Oclr	374-7501
5D-2989	Bearing	380-7511
5K-3171	Plate-Coupling	417-9475
5L-2031	Cup - Roller Brg	384-5927
5M-0578	Bearing	419-7775
5M-6212	Tube	390-0996
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-6254	Bearing	420-2495
5P-7802	Bearing-Aligning	420-2496
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9505	Cone - Roller Brg	420-6540
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As.	242-3437
5S-7630	Bearing - Sleeve	394-0219
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
6B-7469	Spacer	417-4535
6E-6153	Plate-Port	346-5678
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358

7FN		
Original Part Number	Part Name	Classic Part Number
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As.-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As. - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-5003	Bearing-Aligning	420-2498
6Y-1690	Carrier-Ring	384-3849
6Y-9960	Mount As..	376-3639
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7G-3707	Piston-Clutch	302-2691
7G-5618	Manifold As.	283-5204
7G-7431	Piston-Selector	432-8911
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As.	314-8721
7H-7628	Bearing	453-3655
7J-8893	Cone - Roller Brg	374-1846
7M-4046	Bearing - Sleeve	394-8206
7M-7219	Bearing - Thrust	384-4816
7N-0110	Core As.-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear - Flywheel	279-4994

7FN		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As.-Radiator	295-6417
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As.-Pump Suc	378-3989
8H-2810	Case As.-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8L-8867	Pulley	434-1409
8M-7166	Housing-Screen	297-7192
8N-0703	Bearing - Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As.-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As.-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing - Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As.-Outlet	325-6232
8N-7782	Rotocoil As.	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

Sales Model D300E (Cont'd.)

7FN		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1919	Gear-Planet	300-2579
8P-1948	Gear - Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As.	325-6033
8S-0493	Shaft As.-Pump	325-6198
8S-3970	Chamber As.	242-3438
8S-6511	Bearing - Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0280	Piston	283-5213
9G-1499	Gear-Pump (Oil)	295-6424
9J-3206	Bearing-Spher	360-2275
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9P-8517	Case-XMSN	394-0909
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As.	325-6042
9W-3271	Body As.-Oil Pump	430-4553

7FN		
Original Part Number	Part Name	Classic Part Number
9W-3605	Carrier-Ring	314-8662
9W-9930	Mount As.	295-6437
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
101-7689	Yoke As.	422-7245
111-8015	Gasket As.-Head	279-4977
124-3237	Precleaner As.	432-4220
131-3815	Seal Gp-Basic	325-6193
131-8246	Yoke As. (8.5C)	430-5362
136-7813	Bearing-Race	460-8296
138-2317	Wheel	396-9948
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As.-Piston	477-7125
165-4262	Body As.-Piston	270-4351
165-4262	Body As.-Piston	270-4353
165-4262	Body As.-Piston	477-7126
167-8123	Damper As.	299-2006
168-4531	Body As.-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835
187-0605	Gasket Kit - Cl	382-5055

7FN		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As.-Idler	364-5259
196-0029	Gear As.-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As.	242-3439
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-2696	Cone-Bearing	374-1834
1P-3934	Cup - Roller Brg	420-6535
1P-3935	Cone - Roller Brg	377-7397
1P-9945	Bracket As.-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-1278	Bearing - Thrust	370-8370
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

Sales Model D300E (Cont'd.)

7FN		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As.	443-2659
1W-5912	Tappet As.-Guide &	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As.-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915
2K-0535	Nut	299-2026
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As.-Gear	296-1367
2P-1738	Plate As.-Oil Pan	325-6164
2P-1739	Tube As.-Pump	325-6229
2P-1751	Bell As.-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As.-Inlet	325-6230
2P-6245	Shaft As.-Pump	325-6197
2V-5715	Bushing	299-1987
2V-7092	Plate - Retainer	374-6510
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203

7FN		
Original Part Number	Part Name	Classic Part Number
2W-7458	Crankshaft As.	242-3439
2W-8494	Pulley-Alt	295-5692
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As.-Filler	361-1719
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup - Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-8225	Pin-Cylinder	297-7215
4M-3915	Bearing-Caged	377-7427
4M-5226	Bearing-Ball	399-6061
4N-0432	Bearing-Ball	417-4499
4N-2514	Gear - Flywheel	421-7283
4N-7693	Crankshaft As.	269-8763
4P-3546	Valve As.-Relief	325-6236
4P-7688	Valve As.-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4V-4852	Piston	433-0452
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As.	423-9669
4V-8538	Gear - Ring	288-8720
4W-0452	Seal As. -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534

7FN		
Original Part Number	Part Name	Classic Part Number
4W-7188	Core As.-Oclr	374-7501
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5K-3171	Plate-Coupling	417-9475
5M-0578	Bearing	419-7775
5M-6212	Tube	390-0996
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As.	242-3437
5S-7630	Bearing - Sleeve	394-0219
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6C-3500	Shaft-Bev Pinion	384-4788
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As.-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As. - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603

Sales Model D300E (Cont'd.)

7FN		
Original Part Number	Part Name	Classic Part Number
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-5003	Bearing-Aligning	420-2498
6W-5119	Housing-Support	450-8051
6Y-1690	Carrier-Ring	384-3849
6Y-9960	Mount As..	376-3639
7E-5816	Shaft-Fan	399-8552
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7G-3707	Piston-Clutch	302-2691
7G-5618	Manifold As.	283-5204
7G-7431	Piston-Selector	432-8911
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As.	314-8721
7H-7628	Bearing	453-3655
7J-8893	Cone - Roller Brg	374-1846
7M-4046	Bearing - Sleeve	394-8206
7M-7219	Bearing - Thrust	384-4816
7N-0110	Core As.-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As.-Radiator	295-6417
7T-2036	Cap As.-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935

7FN		
Original Part Number	Part Name	Classic Part Number
7W-5164	Gasket	420-8568
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As.-Pump Suc	378-3989
8H-2810	Case As.-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8L-8867	Pulley	434-1409
8M-7166	Housing-Screen	297-7192
8N-0703	Bearing - Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As.-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As.-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing - Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As.-Outlet	325-6232
8N-7782	Rotocoil As.	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

7FN		
Original Part Number	Part Name	Classic Part Number
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1919	Gear-Planet	300-2579
8P-1948	Gear - Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As.	325-6033
8S-0493	Shaft As.-Pump	325-6198
8S-3970	Chamber As.	242-3438
8S-6511	Bearing - Sleeve	380-7372
9C-8205	Gear-Bevel	319-8175
9G-0280	Piston	283-5213
9G-1499	Gear-Pump (Oil)	295-6424
9J-3206	Bearing-Spher	360-2275
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9P-8517	Case-XMSN	394-0909
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As.	325-6042
9W-3271	Body As.-Oil Pump	430-4553
9W-3605	Carrier-Ring	314-8662
9W-9930	Mount As.	295-6437
9Y-1798	Seal-Water	379-0165
9Y-7215	Sleeve-Isolator	425-3646
100-7860	Valve-Inlet	270-4360
101-3125	Gasket	420-8567
101-7689	Yoke As.	422-7245
104-1706	Valve-Regulating	432-8281

Sales Model D300E (Cont'd.)

7FN		
Original Part Number	**Part Name**	**Classic Part Number**
111-2645	Valve-Pump Byp	441-1561
111-8015	Gasket As.-Head	279-4977
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As.-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As.-Ul Rocker	433-0446
115-9403	Shaft As.	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As..-Rglt	419-4719
124-3237	Precleaner As.	432-4220
131-3815	Seal Gp-Basic	325-6193
131-8246	Yoke As. (8.5C)	430-5362
134-3038	Gasket Kit	437-3228
136-7813	Bearing-Race	460-8296
138-2317	Wheel	396-9948
139-9175	Gasket Kit	377-7464
147-1740	Gear-Planet	377-7466
147-3781	Kit-Gasket (WP)	422-2484
148-2125	Liner-Cylinder	458-0154

7FN		
Original Part Number	**Part Name**	**Classic Part Number**
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
160-9874	Kit-Gasket-Scl	386-3048
164-6560	Body As.-Piston	477-7125
165-4262	Body As.-Piston	270-4351
165-4262	Body As.-Piston	270-4353
165-4262	Body As.-Piston	477-7126
167-8123	Damper As.	299-2006
168-4531	Body As.-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
176-4168	Bridge As.-Valve	419-4727

7FN		
Original Part Number	**Part Name**	**Classic Part Number**
176-4172	Bridge As.-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-0605	Gasket Kit - Cl	382-5055
187-3307	Gasket As.-Cyl	438-2022
196-0028	Gear As.-Idler	364-5259
196-0029	Gear As.-Idler	374-4674
197-9251	Pin As..-Piston	454-6110
205-1098	Gasket Kit	434-7283
216-4781	Gasket Kit	437-8144
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As.	242-3439
352-2077	Pump Gp-Water -B	434-6108

Sales Model D30C

05A, 7ZC		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup - Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167

05A, 7ZC		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup - Roller Brg	420-6535
1P-3935	Cone - Roller Brg	377-7397

05A, 7ZC		
Original Part Number	**Part Name**	**Classic Part Number**
1P-9945	Bracket As.-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-9670	Univ Jt As.	443-2017
1T-1278	Bearing - Thrust	370-8370

Sales Model D30C (Cont'd.)

05A, 7ZC		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As.	443-2659
1W-5912	Tappet As.-Guide &	325-6223
1W-6541	Plunger As.	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As.-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup - Roller Brg	386-4944
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As.-Gear	296-1367
2P-1738	Plate As.-Oil Pan	325-6164
2P-1739	Tube As.-Pump	325-6229
2P-1751	Bell As.-Suction	430-7624

05A, 7ZC		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As.-Inlet	325-6230
2P-2697	Tube As.-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As.-Pump	325-6197
2S-6097	Tang	375-9979
2S-7931	Bearing - Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate - Retainer	374-6510
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As.	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-7663	Cartridge Gp	422-8120
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3N-4892	Lever-Gov Cont	439-4542
3P-3208	Flange-Joint	301-4647
4B-1455	Cap As.-Filler	361-1719
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup - Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-8225	Pin-Cylinder	297-7215
4M-3915	Bearing-Caged	377-7427

05A, 7ZC		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As.	269-8763
4P-3546	Valve As.-Relief	325-6236
4P-7688	Valve As.-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As.-Fuel Inj	279-4984
4P-9382	Line As.-Fuel Inj	279-4985
4P-9383	Line As.-Fuel Inj	279-4988
4P-9384	Line As.-Fuel Inj	279-4989
4P-9395	Line As.-Fuel Inj	383-3690
4P-9396	Line As.-Fuel Inj	383-3691
4S-8472	Hood As.-Preclnr	296-1355
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4W-0452	Seal As. -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As.-Oclr	374-7501
4W-9989	Gear As.-Idler	302-2677
5D-2989	Bearing	380-7511
5L-7632	Support-Elbow	433-9854
5M-2051	Bearing-Caged	380-7467
5M-6212	Tube	390-0996
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-6254	Bearing	420-2495
5P-7487	Bearing-Aligning	434-3300
5P-7802	Bearing-Aligning	420-2496

Sales Model D30C (Cont'd.)

05A, 7ZC		
Original Part Number	**Part Name**	**Classic Part Number**
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As.	242-3437
5S-7630	Bearing - Sleeve	394-0219
5S-8543	Bearing - Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5U-0557	Pump Gp-VN Bsc-B	422-8175
5V-1274	Spider	385-6110
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3500	Shaft-Bev Pinion	384-4788
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As.-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As. - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574

05A, 7ZC		
Original Part Number	**Part Name**	**Classic Part Number**
6V-5003	Bearing-Aligning	420-2498
6W-5119	Housing-Support	450-8051
6Y-1690	Carrier-Ring	384-3849
6Y-4457	Bearing-Aligning	420-2504
7B-7515	Bearing-Ball	399-6059
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As.	283-5204
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As.	314-8721
7H-7628	Bearing	453-3655
7J-8893	Cone - Roller Brg	374-1846
7M-4046	Bearing - Sleeve	394-8206
7M-7219	Bearing - Thrust	384-4816
7N-0110	Core As.-Oil Clr	319-3435
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As.-Radiator	295-6417
7T-9542	Gear - Ring	384-4822
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041

05A, 7ZC		
Original Part Number	**Part Name**	**Classic Part Number**
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As.-Pump Suc	378-3989
8F-9365	Pin	319-3463
8H-2810	Case As.-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8N-0703	Bearing - Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As.-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing - Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As.-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing - Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As.-Outlet	325-6232
8N-7782	Rotocoil As.	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081

Sales Model D30C (Cont'd.)

05A, 7ZC		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-0961	Impeller-Conv	433-9204
8P-1919	Gear-Planet	300-2579
8P-1948	Gear - Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As.	325-6033
8S-0493	Shaft As.-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As.	242-3438
8S-3995	Gage As.-Level	430-8042
8S-6511	Bearing - Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8V-6390	Drum-Brake	377-7449
9C-5852	Hub As.	297-7208
9C-8205	Gear-Bevel	319-8175
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9P-8517	Case-XMSN	394-0909
9S-3581	Cup - Roller Brg	415-1923

05A, 7ZC		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3582	Cone - Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-7949	Cup - Roller Brg	420-6531
9S-8679	Chamber As.	325-6042
9T-2200	Cartridgr Gp	422-8114
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-5160	Plunger Kt-Adj	385-7218
9W-3605	Carrier-Ring	314-8662
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-0155	Pipe As.-Exhaust	399-4427
101-7689	Yoke As.	422-7245
103-5961	Wheel	398-2963
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As.-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
131-8246	Yoke As. (8.5C)	430-5362
131-8248	Yoke As.	434-6113
136-7813	Bearing-Race	460-8296
139-9175	Gasket Kit	377-7464
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As.-Piston	477-7125
165-4262	Body As.-Piston	477-7126
165-4262	Body As.-Piston	270-4351
165-4262	Body As.-Piston	270-4353

05A, 7ZC		
Original Part Number	**Part Name**	**Classic Part Number**
167-8123	Damper As.	299-2006
168-4531	Body As.-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As.-Idler	364-5259
196-0029	Gear As.-Idler	374-4674
205-1098	Gasket Kit	434-7283
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As.-Cla	279-4988
296-1360	Line As.-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349

Sales Model D30C (Cont'd.)

05A, 7ZC		
Original Part Number	**Part Name**	**Classic Part Number**
334-8389	Crankshaft As.	242-3439

05A, 7ZC		
Original Part Number	**Part Name**	**Classic Part Number**
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model D30D

1PK		
Original Part Number	**Part Name**	**Classic Part Number**
4S-8472	Hood As.-Preclnr	296-1355
124-3237	Precleaner As.	432-4220

3AJ		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup - Roller Brg	420-6535
1P-3935	Cone - Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114
1P-9945	Bracket As.-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-9670	Univ Jt As.	443-2017
1T-1278	Bearing - Thrust	370-8370
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

3AJ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As.	443-2659
1W-5912	Tappet As.-Guide &	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As.-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0535	Nut	299-2026
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927

3AJ		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1170	Shaft As.-Gear	296-1367
2P-1738	Plate As.-Oil Pan	325-6164
2P-1739	Tube As.-Pump	325-6229
2P-1751	Bell As.-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As.-Inlet	325-6230
2P-6245	Shaft As.-Pump	325-6197
2S-6097	Tang	375-9979
2S-7931	Bearing - Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate - Retainer	374-6510
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203

Sales Model D30D (Cont'd.)

3AJ		
Original Part Number	Part Name	Classic Part Number
2W-7458	Crankshaft As.	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-7663	Cartridge Gp	422-8120
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
4B-1455	Cap As.-Filler	361-1719
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup - Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-8225	Pin-Cylinder	297-7215
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As.	269-8763
4P-3546	Valve As.-Relief	325-6236
4P-7688	Valve As.-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As.-Fuel Inj	279-4984
4P-9382	Line As.-Fuel Inj	279-4985
4P-9383	Line As.-Fuel Inj	279-4988
4P-9384	Line As.-Fuel Inj	279-4989
4P-9395	Line As.-Fuel Inj	383-3690
4P-9396	Line As.-Fuel Inj	383-3691
4S-8472	Hood As.-Preclnr	296-1355
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4W-0452	Seal As. -Cshaft	325-6191

3AJ		
Original Part Number	Part Name	Classic Part Number
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As.-Oclr	374-7501
5D-2989	Bearing	380-7511
5L-7632	Support-Elbow	433-9854
5M-6212	Tube	390-0996
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-6254	Bearing	420-2495
5P-7802	Bearing-Aligning	420-2496
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As.	242-3437
5S-7630	Bearing - Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5U-0557	Pump Gp-VN Bsc-B	422-8175
5V-1274	Spider	385-6110
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3500	Shaft-Bev Pinion	384-4788
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As.-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

3AJ		
Original Part Number	Part Name	Classic Part Number
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As. - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-5003	Bearing-Aligning	420-2498
6W-5119	Housing-Support	450-8051
6Y-1690	Carrier-Ring	384-3849
6Y-4457	Bearing-Aligning	420-2504
6Y-9960	Mount As..	376-3639
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As.	283-5204
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As.	314-8721
7H-7628	Bearing	453-3655
7J-8893	Cone - Roller Brg	374-1846
7M-4046	Bearing - Sleeve	394-8206
7M-7219	Bearing - Thrust	384-4816
7N-0110	Core As.-Oil Clr	319-3435
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724

Sales Model D30D (Cont'd.)

3AJ		
Original Part Number	Part Name	Classic Part Number
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As.-Radiator	295-6417
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As.	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As.-Pump Suc	378-3989
8F-9365	Pin	319-3463
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone - Roller Brg	399-4442
8H-2810	Case As.-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8N-0703	Bearing - Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As.-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing - Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As.-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

3AJ		
Original Part Number	Part Name	Classic Part Number
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing - Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As.-Outlet	325-6232
8N-7782	Rotocoil As.	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1919	Gear-Planet	300-2579
8P-1948	Gear - Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As.	325-6033
8S-0493	Shaft As.-Pump	325-6198
8S-3970	Chamber As.	242-3438
8S-6511	Bearing - Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8V-6390	Drum-Brake	377-7449
8V-7885	Housing-Support	297-7193
9C-5852	Hub As.	297-7208

3AJ		
Original Part Number	Part Name	Classic Part Number
9C-8205	Gear-Bevel	319-8175
9C-8218	Shaft-Bev Pinion	302-2697
9G-0280	Piston	283-5213
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9P-8517	Case-XMSN	394-0909
9S-3581	Cup - Roller Brg	415-1923
9S-3582	Cone - Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-7949	Cup - Roller Brg	420-6531
9S-8679	Chamber As.	325-6042
9T-2200	Cartridgr Gp	422-8114
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-5160	Plunger Kt-Adj	385-7218
9W-3605	Carrier-Ring	314-8662
9W-9930	Mount As.	295-6437
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-0155	Pipe As.-Exhaust	399-4427
101-7689	Yoke As.	422-7245
103-5961	Wheel	398-2963
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As.-Head	279-4977
124-3237	Precleaner As.	432-4220
131-3815	Seal Gp-Basic	325-6193
131-8246	Yoke As. (8.5C)	430-5362
131-8248	Yoke As.	434-6113
136-7813	Bearing-Race	460-8296

Sales Model D30D (Cont'd.)

3AJ		
Original Part Number	Part Name	Classic Part Number
139-9175	Gasket Kit	377-7464
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-1206	Gear Planet	418-9597
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As.-Piston	477-7125
165-4262	Body As.-Piston	270-4351
165-4262	Body As.-Piston	270-4353
165-4262	Body As.-Piston	477-7126
167-8123	Damper As.	299-2006
168-4531	Body As.-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194

3AJ		
Original Part Number	Part Name	Classic Part Number
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261

3AJ		
Original Part Number	Part Name	Classic Part Number
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As.-Idler	364-5259
196-0029	Gear As.-Idler	374-4674
203-9726	Gasket Kit	434-7282
205-1098	Gasket Kit	434-7283
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As.-Cla	279-4988
296-1360	Line As.-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As.	242-3439
374-1849	Brg-Rlr-Cla	399-4442

Sales Model D350C

8XC		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup - Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup - Roller Brg	420-6535
1P-3935	Cone - Roller Brg	377-7397
1P-9945	Bracket As.-Fan	296-1344

8XC		
Original Part Number	Part Name	Classic Part Number
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-9670	Univ Jt As.	443-2017
1T-1278	Bearing - Thrust	370-8370
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006

8XC		
Original Part Number	Part Name	Classic Part Number
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As.	443-2659
1W-5912	Tappet As.-Guide &	325-6223
1W-6541	Plunger As.	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As.-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

Sales Model D350C (Cont'd.)

8XC		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup - Roller Brg	386-4944
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-5065	Cone - Roller Brg	416-2157
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As.-Gear	296-1367
2P-1738	Plate As.-Oil Pan	325-6164
2P-1739	Tube As.-Pump	325-6229
2P-1751	Bell As.-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As.-Inlet	325-6230
2P-2697	Tube As.-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As.-Pump	325-6197
2S-6097	Tang	375-9979
2S-7931	Bearing - Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate - Retainer	374-6510
2W-1707	Ring-Piston Top	270-4356

8XC		
Original Part Number	Part Name	Classic Part Number
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As.	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-7663	Cartridge Gp	422-8120
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3N-4892	Lever-Gov Cont	439-4542
3P-3208	Flange-Joint	301-4647
4B-1455	Cap As.-Filler	361-1719
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup - Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-8225	Pin-Cylinder	297-7215
4M-3915	Bearing-Caged	377-7427
4M-5226	Bearing-Ball	399-6061
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As.	269-8763
4P-3546	Valve As.-Relief	325-6236
4P-7688	Valve As.-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As.-Fuel Inj	279-4984
4P-9382	Line As.-Fuel Inj	279-4985
4P-9383	Line As.-Fuel Inj	279-4988
4P-9384	Line As.-Fuel Inj	279-4989
4P-9395	Line As.-Fuel Inj	383-3690
4P-9396	Line As.-Fuel Inj	383-3691
4S-8472	Hood As.-Preclnr	296-1355

8XC		
Original Part Number	Part Name	Classic Part Number
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4W-0452	Seal As. -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As.-Oclr	374-7501
4W-9989	Gear As.-Idler	302-2677
5B-9169	Plug-Drain	419-4736
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5L-7632	Support-Elbow	433-9854
5M-2051	Bearing-Caged	380-7467
5M-6212	Tube	390-0996
5P-2526	Cup-Rlr Bearing	380-7498
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-6254	Bearing	420-2495
5P-7802	Bearing-Aligning	420-2496
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As.	242-3437
5S-7630	Bearing - Sleeve	394-0219
5S-8543	Bearing - Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5U-0557	Pump Gp-VN Bsc-B	422-8175

Sales Model D350C (Cont'd.)

8XC		
Original Part Number	Part Name	Classic Part Number
5V-1274	Spider	385-6110
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3500	Shaft-Bev Pinion	384-4788
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As.-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As. - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-5003	Bearing-Aligning	420-2498
6W-5119	Housing-Support	450-8051
6Y-1690	Carrier-Ring	384-3849
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As.	283-5204
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As.	314-8721
7H-7628	Bearing	453-3655
7J-8893	Cone - Roller Brg	374-1846
7M-4046	Bearing - Sleeve	394-8206
7M-7219	Bearing - Thrust	384-4816

8XC		
Original Part Number	Part Name	Classic Part Number
7N-0110	Core As.-Oil Clr	319-3435
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As.-Radiator	295-6417
7T-2036	Cap As.-Fuel	361-1721
7T-9542	Gear - Ring	384-4822
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As.-Pump Suc	378-3989
8F-9365	Pin	319-3463
8H-2810	Case As.-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8N-0703	Bearing - Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As.-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing - Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As.-Rkr Arm	314-8711

8XC		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing - Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As.-Outlet	325-6232
8N-7782	Rotocoil As.	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-0961	Impeller-Conv	433-9204
8P-1919	Gear-Planet	300-2579
8P-1948	Gear - Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As.	325-6033
8S-0493	Shaft As.-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As.	242-3438
8S-3995	Gage As.-Level	430-8042
8S-6511	Bearing - Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448

Sales Model D350C (Cont'd.)

8XC		
Original Part Number	**Part Name**	**Classic Part Number**
8V-3134	Pinion-Bevel	260-0788
8V-6390	Drum-Brake	377-7449
9C-5852	Hub As.	297-7208
9C-8205	Gear-Bevel	319-8175
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9K-1171	Cup-Rlr Bearing	430-3339
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9P-8517	Case-XMSN	394-0909
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As.	325-6042
9T-2200	Cartridgr Gp	422-8114
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-5160	Plunger Kt-Adj	385-7218
9W-3605	Carrier-Ring	314-8662
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-0155	Pipe As.-Exhaust	399-4427
101-7689	Yoke As.	422-7245

8XC		
Original Part Number	**Part Name**	**Classic Part Number**
103-5961	Wheel	398-2963
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As.-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
131-8246	Yoke As. (8.5C)	430-5362
131-8248	Yoke As.	434-6113
136-7813	Bearing-Race	460-8296
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As.-Piston	477-7125
165-4262	Body As.-Piston	270-4351
165-4262	Body As.-Piston	270-4353
165-4262	Body As.-Piston	477-7126
167-8123	Damper As.	299-2006
168-4531	Body As.-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

8XC		
Original Part Number	**Part Name**	**Classic Part Number**
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As.-Idler	364-5259
196-0029	Gear As.-Idler	374-4674
205-1098	Gasket Kit	434-7283
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As.-Cla	279-4988
296-1360	Line As.-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As.	242-3439
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model D350D

9RF		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347

Sales Model D350D (Cont'd.)

9RF		
Original Part Number	Part Name	Classic Part Number
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup - Roller Brg	420-6535
1P-3935	Cone - Roller Brg	377-7397
1P-9945	Bracket As.-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-9670	Univ Jt As.	443-2017
1T-1278	Bearing - Thrust	370-8370
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As.	443-2659
1W-5912	Tappet As.-Guide &	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As.-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0535	Nut	299-2026

9RF		
Original Part Number	Part Name	Classic Part Number
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As.-Gear	296-1367
2P-1738	Plate As.-Oil Pan	325-6164
2P-1739	Tube As.-Pump	325-6229
2P-1751	Bell As.-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As.-Inlet	325-6230
2P-6245	Shaft As.-Pump	325-6197
2S-6097	Tang	375-9979
2S-7931	Bearing - Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate - Retainer	374-6510
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As.	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-7663	Cartridge Gp	422-8120
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356

9RF		
Original Part Number	Part Name	Classic Part Number
3P-3208	Flange-Joint	301-4647
4B-1455	Cap As.-Filler	361-1719
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup - Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-8225	Pin-Cylinder	297-7215
4M-3915	Bearing-Caged	377-7427
4M-5226	Bearing-Ball	399-6061
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As.	269-8763
4P-3546	Valve As.-Relief	325-6236
4P-7688	Valve As.-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As.-Fuel Inj	279-4984
4P-9382	Line As.-Fuel Inj	279-4985
4P-9383	Line As.-Fuel Inj	279-4988
4P-9384	Line As.-Fuel Inj	279-4989
4P-9395	Line As.-Fuel Inj	383-3690
4P-9396	Line As.-Fuel Inj	383-3691
4S-8472	Hood As.-Preclnr	296-1355
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4W-0452	Seal As. -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As.-Oclr	374-7501
5D-2989	Bearing	380-7511
5L-7632	Support-Elbow	433-9854

Sales Model D350D (Cont'd.)

9RF		
Original Part Number	Part Name	Classic Part Number
5M-6212	Tube	390-0996
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-6254	Bearing	420-2495
5P-7802	Bearing-Aligning	420-2496
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As.	242-3437
5S-7630	Bearing - Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5U-0557	Pump Gp-VN Bsc-B	422-8175
5V-1274	Spider	385-6110
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3500	Shaft-Bev Pinion	384-4788
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As.-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As. - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542

9RF		
Original Part Number	Part Name	Classic Part Number
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-5003	Bearing-Aligning	420-2498
6W-5119	Housing-Support	450-8051
6Y-1690	Carrier-Ring	384-3849
6Y-9960	Mount As..	376-3639
7C-0307	Gasket	399-8571
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As.	283-5204
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As.	314-8721
7H-7628	Bearing	453-3655
7J-8893	Cone - Roller Brg	374-1846
7M-4046	Bearing - Sleeve	394-8206
7M-7219	Bearing - Thrust	384-4816
7N-0110	Core As.-Oil Clr	319-3435
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin-Piston	295-6438

9RF		
Original Part Number	Part Name	Classic Part Number
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As.-Radiator	295-6417
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-5733	Gasket	421-7333
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As.	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As.-Pump Suc	378-3989
8F-9365	Pin	319-3463
8H-2810	Case As.-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8N-0703	Bearing - Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As.-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing - Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As.-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing - Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290

Sales Model D350D (Cont'd.)

9RF		
Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As.-Outlet	325-6232
8N-7782	Rotocoil As.	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1919	Gear-Planet	300-2579
8P-1948	Gear - Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As.	325-6033
8S-0493	Shaft As.-Pump	325-6198
8S-3970	Chamber As.	242-3438
8S-6511	Bearing - Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8V-6390	Drum-Brake	377-7449
9C-5852	Hub As.	297-7208
9C-8205	Gear-Bevel	319-8175
9G-0280	Piston	283-5213
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018

9RF		
Original Part Number	Part Name	Classic Part Number
9P-8517	Case-XMSN	394-0909
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As.	325-6042
9T-2200	Cartridgr Gp	422-8114
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-5160	Plunger Kt-Adj	385-7218
9W-3605	Carrier-Ring	314-8662
9W-9930	Mount As.	295-6437
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-0155	Pipe As.-Exhaust	399-4427
101-7689	Yoke As.	422-7245
103-5961	Wheel	398-2963
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As.-Head	279-4977
124-3237	Precleaner As.	432-4220
131-3815	Seal Gp-Basic	325-6193
131-8246	Yoke As. (8.5C)	430-5362
131-8248	Yoke As.	434-6113
136-7813	Bearing-Race	460-8296
139-9175	Gasket Kit	377-7464
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As.-Piston	477-7125
165-4262	Body As.-Piston	477-7126
165-4262	Body As.-Piston	270-4353
165-4262	Body As.-Piston	270-4351

9RF		
Original Part Number	Part Name	Classic Part Number
166-9142	Gasket	420-8546
167-8123	Damper As.	299-2006
168-4531	Body As.-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As.-Idler	364-5259
196-0029	Gear As.-Idler	374-4674
203-9726	Gasket Kit	434-7282
205-1098	Gasket Kit	434-7283
232-3233	Bearing-Main	376-9085
234-1874	Kit-Gasket-FS	437-8668
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

Articulated Trucks

Sales Model D350D (Cont'd.)

9RF		
Original Part Number	**Part Name**	**Classic Part Number**
296-1359	Line As.-Cla	279-4988
296-1360	Line As.-Cla	279-4989
308-1845	Seal-Wiper	472-8032

9RF		
Original Part Number	**Part Name**	**Classic Part Number**
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

9RF		
Original Part Number	**Part Name**	**Classic Part Number**
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As.	242-3439

Sales Model D350E

2XW		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167
1M-6573	Cup - Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone - Roller Brg	380-7504
1S-9209	Shaft-Tightener	374-6499
1T-0364	Flange-Joint	388-6567
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing - Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race - Thrust Brg	453-3651
1W-4738	Bearing - Sleeve	325-6020
1W-7238	Shaft As.-Pump Dr	379-0164
1W-7239	Shaft As.-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup - Roller Brg	415-1914

2XW		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9455	Cone - Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2F-8509	Cone - Roller Brg	399-4434
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2S-6150	Cover-Pulley	428-8817
2V-5656	Ring-Snap	374-1454
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate - Retainer	374-6510
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup - Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3735	Housing As.	391-9830
3P-3738	Housing As.	385-7196
3P-7489	Plate-Clutch	377-7423
3T-2139	Housing As.-Cl	394-2583

2XW		
Original Part Number	**Part Name**	**Classic Part Number**
4B-1455	Cap As.-Filler	361-1719
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup - Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4K-8225	Pin-Cylinder	297-7215
4N-0362	Cover As.-Rgltr	419-4722
4N-0733	Pump Gp-XX 1 Gr	374-7502
4N-0913	Screen As.-Bell	374-7489
4N-2514	Gear - Flywheel	421-7283
4N-2572	Spider As.-Fan	451-9027
4N-4942	Rod-Eye	421-8919
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4S-5367	Mount As.	375-9986
4S-8472	Hood As.-Preclnr	296-1355
4V-4852	Piston	433-0452
4V-5392	Spider	377-7430
4W-2474	Rotocoil As.	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5L-2031	Cup - Roller Brg	384-5927

Sales Model D350E (Cont'd.)

2XW		
Original Part Number	Part Name	Classic Part Number
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-6254	Bearing	420-2495
5P-7802	Bearing-Aligning	420-2496
5P-7807	Bearing-Ball	314-8502
5P-9505	Cone - Roller Brg	420-6540
5P-9514	Bearing-Ball	417-9467
5S-4326	Housing-Screen	435-4790
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
6I-1453	Crankshaft As.	368-5916
6I-2726	Bearing - Sleeve	419-4757
6N-1931	Plunger	379-0171
6N-3641	Pulley-Tightener	380-7536
6N-7653	Gage As.-O Level	428-7206
6P-6739	Shaft-Planet	308-9929
6T-3726	Carrier As.	390-5269
6T-5611	Spacer	435-8520
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-5003	Bearing-Aligning	420-2498
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-9960	Mount As..	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As.-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520

2XW		
Original Part Number	Part Name	Classic Part Number
7G-5749	Piston-Clutch	416-2132
7M-7219	Bearing - Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing - Sleeve	380-7373
7S-7809	Cap As.-Radiator	295-6417
7W-2164	Core As.-Oclr	299-1996
7W-3145	Plate	422-7894
7W-5733	Gasket	421-7333
8H-8175	Bearing - Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As.-Suction	380-1521
8N-5305	Spacer	363-7464
8P-4047	Shaft-Planet	373-5390
8S-6511	Bearing - Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-5852	Hub As.	297-7208
9G-1919	Gear-Planet	371-4307
9L-5839	Coupling-Exhaust	374-7480
9M-1328	Bearing-Aligning	325-6018
9M-1990	Dowel-Reaction	386-4963
9M-2744	Cone-Spl Tapered	380-1480
9N-0316	Bracket-Pulley	434-1993
9P-5531	Gear-Sun	417-9499
9S-7949	Cup - Roller Brg	420-6531
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9W-1572	Shaft-XMSN Input	419-1864
9W-2977	Hub As.	423-6985
9W-5768	Gear - Ring	380-7474
9W-7040	Piston-Clutch	377-7462
9W-9930	Mount As.	295-6437
9Y-6054	Rod As.-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665

2XW		
Original Part Number	Part Name	Classic Part Number
002-1212	Cup - Roller Brg	399-4446
101-3125	Gasket	420-8567
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
106-7798	Bearing-Ball	417-9494
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As.	377-7463
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
127-6356	Cover As..-Pump	420-8566
128-2922	Kit-Gasket (WP)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing - Sleeve	422-6919
131-8246	Yoke As. (8.5C)	430-5362
131-8248	Yoke As.	434-6113
131-8674	Gear As.-Drive	394-0911
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As.-Idler	426-0035
146-2601	Cover	399-6054
148-0885	Stator-Converter	379-0161
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048

Sales Model D350E (Cont'd.)

2XW		
Original Part Number	**Part Name**	**Classic Part Number**
164-4891	Plate As..	391-1093
166-9142	Gasket	420-8546
167-8126	Damper As.	382-8019
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As.	397-5055
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
202-3572	Shaft As.-Drive	426-0037
211-0592	Bearing - Main	419-6368

2XW		
Original Part Number	**Part Name**	**Classic Part Number**
216-5582	Bearing - Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
233-6984	Kit-Gasket (FS)	437-2045
233-9748	Disc-Friction	417-9502
253-1752	Plate-Thrust	379-0170
278-1365	Arm As.-Ul Rkr	433-7507
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

2XW		
Original Part Number	**Part Name**	**Classic Part Number**
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
325-2721	Kit-Gasket(T)	393-3662
328-4240	Arm As.-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
430-7619	Adapter-Cla	438-1812

9LR		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup - Roller Brg	420-6535
1P-3935	Cone - Roller Brg	377-7397
1T-0364	Flange-Joint	388-6567
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0807	Race - Thrust Brg	453-3651
1U-2666	Cartridge Gp	422-8115
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As.-Guide &	383-1569
1W-7238	Shaft As.-Pump Dr	379-0164
1W-7239	Shaft As.-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174

9LR		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2K-0535	Nut	299-2026
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2N-5842	Screw-Bridge Adj	418-1934
2P-8986	Cup-Rlr Bearing	415-1912
2S-6097	Tang	375-9979
2V-5656	Ring-Snap	374-1454
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate - Retainer	374-6510
2W-7455	Gear As.	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203

9LR		
Original Part Number	**Part Name**	**Classic Part Number**
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3735	Housing As.	391-9830
3P-3738	Housing As.	385-7196
3P-7489	Plate-Clutch	377-7423
3T-2139	Housing As.-Cl	394-2583
4B-1455	Cap As.-Filler	361-1719
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup - Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4K-8225	Pin-Cylinder	297-7215
4M-5226	Bearing-Ball	399-6061
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As.-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing - Sleeve	379-0191
4N-0733	Pump Gp-XX 1 Gr	374-7502
4N-0913	Screen As.-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear - Flywheel	421-7283

Sales Model D350E (Cont'd.)

9LR		
Original Part Number	Part Name	Classic Part Number
4N-2572	Spider As.-Fan	451-9027
4N-3714	Chamber As.	363-7450
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As.-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing - Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As.-Check	420-6216
4S-8472	Hood As.-Preclnr	296-1355
4V-4852	Piston	433-0452
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As.	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As.	373-1906
4W-5998	Rod-Valve Push	379-0168
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-6254	Bearing	420-2495
5P-7802	Bearing-Aligning	420-2496
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4326	Housing-Screen	435-4790
5T-5682	Driver	418-9579

9LR		
Original Part Number	Part Name	Classic Part Number
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3500	Shaft-Bev Pinion	384-4788
6I-1453	Crankshaft As.	368-5916
6I-2726	Bearing - Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As.	380-7556
6N-7653	Gage As.-O Level	428-7206
6P-6739	Shaft-Planet	308-9929
6T-3726	Carrier As.	390-5269
6T-5611	Spacer	435-8520
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-5003	Bearing-Aligning	420-2498
6W-5119	Housing-Support	450-8051
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-9960	Mount As..	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As.-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As.-Conn	379-8864
7E-6002	Bearing - Sleeve	417-4523
7E-6003	Bearing - Sleeve	417-4522
7E-6004	Bearing - Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857

9LR		
Original Part Number	Part Name	Classic Part Number
7G-5746	Housing-Clutch	392-4520
7G-5749	Piston-Clutch	416-2132
7H-7628	Bearing	453-3655
7M-7219	Bearing - Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing - Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-8957	Gear-Crankshaft	422-2652
7S-7809	Cap As.-Radiator	295-6417
7W-2164	Core As.-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing - Sleeve	416-5494
8H-8175	Bearing - Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As.-Conn	379-8866
8N-2104	Bell As.-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-5305	Spacer	363-7464
8N-8258	Bearing - Sleeve	452-1077
8P-4047	Shaft-Planet	373-5390
8S-6511	Bearing - Sleeve	380-7372
9C-5852	Hub As.	297-7208
9C-8205	Gear-Bevel	319-8175
9G-1919	Gear-Planet	371-4307
9L-5839	Coupling-Exhaust	374-7480
9M-1328	Bearing-Aligning	325-6018
9M-1990	Dowel-Reaction	386-4963
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race - Thrust	394-9205
9N-3668	Base As..-Coolant	419-4718

Sales Model D350E (Cont'd.)

9LR		
Original Part Number	**Part Name**	**Classic Part Number**
9P-5531	Gear-Sun	417-9499
9S-7949	Cup - Roller Brg	420-6531
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9W-1572	Shaft-XMSN Input	419-1864
9W-2977	Hub As.	423-6985
9W-5768	Gear - Ring	380-7474
9W-7040	Piston-Clutch	377-7462
9W-9930	Mount As.	295-6437
9Y-2988	Breather As.	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As.	378-4000
101-1816	Bridge As.-Intake	374-4689
101-1817	Bridge As..-Exh	374-4690
101-1818	Bridge As.-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
106-7798	Bearing-Ball	417-9494
108-2102	Bonnet-Valve	455-3274
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215

9LR		
Original Part Number	**Part Name**	**Classic Part Number**
108-7930	Bearing As.	377-7463
110-5096	Head As.-Cyl	394-0915
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As.	394-2587
127-6356	Cover As..-Pump	420-8566
128-2922	Kit-Gasket (WP)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing - Sleeve	422-6919
131-8246	Yoke As. (8.5C)	430-5362
131-8248	Yoke As.	434-6113
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
139-9170	Gasket Kit	447-0825
144-0482	Gasket	420-8547
145-8503	Shaft As.-Idler	426-0035
148-0885	Stator-Converter	379-0161
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-XX 1 Gr	374-7502
164-4891	Plate As..	391-1093
166-9142	Gasket	420-8546

9LR		
Original Part Number	**Part Name**	**Classic Part Number**
167-8126	Damper As.	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As.	380-1516
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
190-9861	Kit-GSKT-ACL	386-3812
191-7941	Line As.-Fuel Inj	378-4011
191-7942	Line As.-Fuel Inj	374-4699
191-7943	Line As.-Fuel Inj	374-4700
191-7944	Line As.-Fuel Inj	374-4701
191-7945	Line As.-Fuel Inj	378-4012
191-7946	Line As.-Fuel Inj	378-4013
202-3572	Shaft As.-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
220-3779	Kit-Gasket(F)	437-1998
233-9748	Disc-Friction	417-9502
234-1874	Kit-Gasket-FS	437-8668
253-1752	Plate-Thrust	379-0170
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

Sales Model D35C

2GD		
Original Part Number	Part Name	Classic Part Number
1B-3937	Cup - Roller Brg	377-7394
1B-4043	Cone - Roller Brg	377-7395
1H-5338	Cup - Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup - Roller Brg	420-6535
1P-3935	Cone - Roller Brg	377-7397
1P-9945	Bracket As.-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-9670	Univ Jt As.	443-2017
1T-1278	Bearing - Thrust	370-8370
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As.	443-2659
1W-5912	Tappet As.-Guide &	325-6223
1W-6541	Plunger As.	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As.-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup - Roller Brg	386-4944

2GD		
Original Part Number	Part Name	Classic Part Number
2D-9130	Washer-Thrust	308-9943
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As.-Gear	296-1367
2P-1738	Plate As.-Oil Pan	325-6164
2P-1739	Tube As.-Pump	325-6229
2P-1751	Bell As.-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As.-Inlet	325-6230
2P-2697	Tube As.-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As.-Pump	325-6197
2S-6097	Tang	375-9979
2S-7931	Bearing - Sleeve	387-2904
2V-3687	Gear-Diff Bevel	308-9849
2V-5656	Ring-Snap	374-1454
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate - Retainer	374-6510
2W-1707	Ring-Piston Top	270-4356

2GD		
Original Part Number	Part Name	Classic Part Number
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As.	242-3439
2W-7678	Gear-Water Pump	325-6088
3D-5315	Pinion-Dif Bevel	308-9856
3G-7663	Cartridge Gp	422-8120
3K-2511	Dowel-Reaction	383-2126
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3N-4892	Lever-Gov Cont	439-4542
3P-3208	Flange-Joint	301-4647
3V-3855	Housing-Brg Spt	375-9980
4B-1455	Cap As.-Filler	361-1719
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup - Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-8225	Pin-Cylinder	297-7215
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As.	269-8763
4P-3546	Valve As.-Relief	325-6236
4P-7688	Valve As.-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As.-Fuel Inj	279-4984
4P-9382	Line As.-Fuel Inj	279-4985
4P-9383	Line As.-Fuel Inj	279-4988
4P-9384	Line As.-Fuel Inj	279-4989

Sales Model D35C (Cont'd.)

2GD		
Original Part Number	Part Name	Classic Part Number
4P-9395	Line As.-Fuel Inj	383-3690
4P-9396	Line As.-Fuel Inj	383-3691
4S-8472	Hood As.-Preclnr	296-1355
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4W-0452	Seal As. -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As.-Oclr	374-7501
4W-9989	Gear As.-Idler	302-2677
5D-2989	Bearing	380-7511
5F-7404	Nut-Bearing Lock	308-9878
5L-7632	Support-Elbow	433-9854
5M-2051	Bearing-Caged	380-7467
5M-6212	Tube	390-0996
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-6254	Bearing	420-2495
5P-7802	Bearing-Aligning	420-2496
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As.	242-3437
5S-7630	Bearing - Sleeve	394-0219
5S-8543	Bearing - Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883

2GD		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
5U-0557	Pump Gp-VN Bsc-B	422-8175
5V-1274	Spider	385-6110
5V-5917	Pinion-Diff	297-7224
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3500	Shaft-Bev Pinion	384-4788
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As.-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As. -Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-5003	Bearing-Aligning	420-2498
6W-5119	Housing-Support	450-8051
6W-7290	Shaft-Planet	308-9930
6Y-1690	Carrier-Ring	384-3849
6Y-4689	Bearing-Aligning	420-6532
7B-7515	Bearing-Ball	399-6059
7D-8437	Cone - Roller Brg	380-1502
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441

2GD		
Original Part Number	Part Name	Classic Part Number
7G-5618	Manifold As.	283-5204
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As.	314-8721
7H-7628	Bearing	453-3655
7J-8893	Cone - Roller Brg	374-1846
7M-4046	Bearing - Sleeve	394-8206
7M-7219	Bearing - Thrust	384-4816
7N-0110	Core As.-Oil Clr	319-3435
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As.-Radiator	295-6417
7T-9542	Gear - Ring	384-4822
7V-6790	Shaft-Bev Pinion	308-9922
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As.-Pump Suc	378-3989
8F-9365	Pin	319-3463
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone - Roller Brg	399-4442
8H-2810	Case As.-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

Sales Model D35C (Cont'd.)

2GD		
Original Part Number	Part Name	Classic Part Number
8L-8867	Pulley	434-1409
8N-0703	Bearing - Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As.-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing - Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As.-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing - Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As.-Outlet	325-6232
8N-7782	Rotocoil As.	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-0961	Impeller-Conv	433-9204
8P-1919	Gear-Planet	300-2579
8P-1948	Gear - Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016

2GD		
Original Part Number	Part Name	Classic Part Number
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-7425	Retainer	308-9917
8S-0248	Breather As.	325-6033
8S-0493	Shaft As.-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As.	242-3438
8S-3995	Gage As.-Level	430-8042
8S-6511	Bearing - Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8V-6390	Drum-Brake	377-7449
9C-5852	Hub As.	297-7208
9C-8205	Gear-Bevel	319-8175
9C-8278	Case As.-Diff	423-6984
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9J-3206	Bearing-Spher	360-2275
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9P-8517	Case-XMSN	394-0909
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As.	325-6042
9T-2200	Cartridgr Gp	422-8114
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-5160	Plunger Kt-Adj	385-7218
9V-7710	Univ Joint As.	394-8234

2GD		
Original Part Number	Part Name	Classic Part Number
9W-3605	Carrier-Ring	314-8662
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-0155	Pipe As.-Exhaust	399-4427
101-7689	Yoke As.	422-7245
103-5961	Wheel	398-2963
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As.-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
139-9175	Gasket Kit	377-7464
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As.-Piston	477-7125
165-4262	Body As.-Piston	270-4351
165-4262	Body As.-Piston	270-4353
165-4262	Body As.-Piston	477-7126
167-8123	Damper As.	299-2006
168-4531	Body As.-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

Sales Model D35C (Cont'd.)

2GD		
Original Part Number	**Part Name**	**Classic Part Number**
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As.-Idler	364-5259

2GD		
Original Part Number	**Part Name**	**Classic Part Number**
196-0029	Gear As.-Idler	374-4674
205-1098	Gasket Kit	434-7283
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As.-Cla	279-4988

2GD		
Original Part Number	**Part Name**	**Classic Part Number**
296-1360	Line As.-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As.	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model D35-HP

3FD		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3937	Cup - Roller Brg	377-7394
1B-4043	Cone - Roller Brg	377-7395
1H-5338	Cup - Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup - Roller Brg	420-6535
1P-3935	Cone - Roller Brg	377-7397
1T-0364	Flange-Joint	388-6567
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing - Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race - Thrust Brg	453-3651
1U-2666	Cartridge Gp	422-8115
1W-1669	Piston	325-6158

3FD		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As.-Guide &	383-1569
1W-7238	Shaft As.-Pump Dr	379-0164
1W-7239	Shaft As.-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup - Roller Brg	386-4944
2D-9130	Washer-Thrust	308-9943
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2K-0535	Nut	299-2026
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469

3FD		
Original Part Number	**Part Name**	**Classic Part Number**
2N-5842	Screw-Bridge Adj	418-1934
2P-8986	Cup-Rlr Bearing	415-1912
2S-6097	Tang	375-9979
2V-3687	Gear-Diff Bevel	308-9849
2V-5656	Ring-Snap	374-1454
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate - Retainer	374-6510
2W-7455	Gear As.	396-9957
3B-4124	Cup-Spl Tapered	422-6481
3D-5315	Pinion-Dif Bevel	308-9856
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203

Sales Model D35-HP (Cont'd.)

3FD		
Original Part Number	Part Name	Classic Part Number
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3735	Housing As.	391-9830
3P-3738	Housing As.	385-7196
3P-7489	Plate-Clutch	377-7423
3T-2139	Housing As.-Cl	394-2583
3V-3855	Housing-Brg Spt	375-9980
4B-1455	Cap As.-Filler	361-1719
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup - Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4K-8225	Pin-Cylinder	297-7215
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As.-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing - Sleeve	379-0191
4N-0733	Pump Gp-XX 1 Gr	374-7502
4N-0913	Screen As.-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear - Flywheel	421-7283
4N-2572	Spider As.-Fan	451-9027
4N-3714	Chamber As.	363-7450
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As.-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing - Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As.-Check	420-6216

3FD		
Original Part Number	Part Name	Classic Part Number
4P-7731	Core Gp-O Clr	385-7228
4P-9961	Line As.-Fuel Inj	325-6115
4S-8472	Hood As.-Preclnr	296-1355
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As.	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As.	373-1906
4W-5998	Rod-Valve Push	379-0168
5F-7404	Nut-Bearing Lock	308-9878
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-6254	Bearing	420-2495
5P-7802	Bearing-Aligning	420-2496
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4326	Housing-Screen	435-4790
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-5917	Pinion-Diff	297-7224
6B-3223	Cup-Bearing	399-6065
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3500	Shaft-Bev Pinion	384-4788
6I-1453	Crankshaft As.	368-5916
6I-2726	Bearing - Sleeve	419-4757

3FD		
Original Part Number	Part Name	Classic Part Number
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As.	380-7556
6N-7653	Gage As.-O Level	428-7206
6P-6739	Shaft-Planet	308-9929
6T-3726	Carrier As.	390-5269
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-5003	Bearing-Aligning	420-2498
6W-5119	Housing-Support	450-8051
6W-7290	Shaft-Planet	308-9930
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4689	Bearing-Aligning	420-6532
6Y-5793	Ring-Seal	451-9028
6Y-9960	Mount As..	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As.-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7D-8437	Cone - Roller Brg	380-1502
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As.-Conn	379-8864
7E-6002	Bearing - Sleeve	417-4523
7E-6003	Bearing - Sleeve	417-4522
7E-6004	Bearing - Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7G-5749	Piston-Clutch	416-2132

Sales Model D35-HP (Cont'd.)

3FD		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing - Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing - Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-8828	Pulley	420-6395
7N-8957	Gear-Crankshaft	422-2652
7S-7809	Cap As.-Radiator	295-6417
7V-6790	Shaft-Bev Pinion	308-9922
7W-0140	Gear-Drive	399-8546
7W-2164	Core As.-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8C-4456	Gasket Kit - Sch	393-1029
8F-6058	Bearing - Sleeve	416-5494
8F-9365	Pin	319-3463
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone - Roller Brg	399-4442
8H-8175	Bearing - Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As.-Conn	379-8866
8N-2104	Bell As.-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-8258	Bearing - Sleeve	452-1077
8P-4047	Shaft-Planet	373-5390
8R-7425	Retainer	308-9917
8S-6511	Bearing - Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612

3FD		
Original Part Number	Part Name	Classic Part Number
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8V-6390	Drum-Brake	377-7449
9C-5852	Hub As.	297-7208
9C-8205	Gear-Bevel	319-8175
9C-8278	Case As.-Diff	423-6984
9G-1919	Gear-Planet	371-4307
9G-9543	Gear-Pump (Oil)	295-6426
9J-3206	Bearing-Spher	360-2275
9L-5839	Coupling-Exhaust	374-7480
9M-1328	Bearing-Aligning	325-6018
9M-1990	Dowel-Reaction	386-4963
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race - Thrust	394-9205
9N-3668	Base As..-Coolant	419-4718
9P-5531	Gear-Sun	417-9499
9S-7949	Cup - Roller Brg	420-6531
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-5160	Plunger Kt-Adj	385-7218
9V-7710	Univ Joint As.	394-8234
9W-1572	Shaft-XMSN Input	419-1864
9W-2977	Hub As.	423-6985
9W-5768	Gear - Ring	380-7474
9W-7040	Piston-Clutch	377-7462
9Y-2988	Breather As.	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As.	378-4000
101-0155	Pipe As.-Exhaust	399-4427

3FD		
Original Part Number	Part Name	Classic Part Number
101-1816	Bridge As.-Intake	374-4689
101-1817	Bridge As..-Exh	374-4690
101-1818	Bridge As.-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
103-5961	Wheel	398-2963
106-7798	Bearing-Ball	417-9494
108-2102	Bonnet-Valve	455-3274
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As.	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As.	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As.-Cyl	394-0915
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As.	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As..-Pump	420-8566
128-2922	Kit-Gasket (WP)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing - Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813

Sales Model D35-HP (Cont'd.)

3FD		
Original Part Number	Part Name	Classic Part Number
139-9170	Gasket Kit	447-0825
144-0482	Gasket	420-8547
145-8503	Shaft As.-Idler	426-0035
148-0885	Stator-Converter	379-0161
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-8178	Rod As.-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-XX 1 Gr	374-7502
164-4891	Plate As..	391-1093
166-9142	Gasket	420-8546
167-8126	Damper As.	382-8019
177-9024	Adapter-Damper	299-1956

3FD		
Original Part Number	Part Name	Classic Part Number
185-2831	Line As.	380-1516
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
190-9861	Kit-GSKT-ACL	386-3812
191-7941	Line As.-Fuel Inj	378-4011
191-7942	Line As.-Fuel Inj	374-4699
191-7943	Line As.-Fuel Inj	374-4700
191-7944	Line As.-Fuel Inj	374-4701
191-7945	Line As.-Fuel Inj	378-4012
191-7946	Line As.-Fuel Inj	378-4013
202-3572	Shaft As.-Drive	426-0037
211-0592	Bearing - Main	419-6368

3FD		
Original Part Number	Part Name	Classic Part Number
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3679	Kit-Gasket (RS)	437-2039
233-9748	Disc-Friction	417-9502
234-1874	Kit-Gasket-FS	437-8668
253-1752	Plate-Thrust	379-0170
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
374-1849	Brg-Rlr-Cla	399-4442
430-7619	Adapter-Cla	438-1812

Sales Model D400

1MD		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup - Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup - Roller Brg	420-6535
1P-3935	Cone - Roller Brg	377-7397
1T-0364	Flange-Joint	388-6567
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing - Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410

1MD		
Original Part Number	Part Name	Classic Part Number
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race - Thrust Brg	453-3651
1U-2666	Cartridge Gp	422-8115
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As.-Guide &	383-1569
1W-7238	Shaft As.-Pump Dr	379-0164
1W-7239	Shaft As.-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup - Roller Brg	386-4944

1MD		
Original Part Number	Part Name	Classic Part Number
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2K-0535	Nut	299-2026
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2N-5842	Screw-Bridge Adj	418-1934
2P-8986	Cup-Rlr Bearing	415-1912
2S-6097	Tang	375-9979
2V-5656	Ring-Snap	374-1454

Sales Model D400 (Cont'd.)

1MD		
Original Part Number	**Part Name**	**Classic Part Number**
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate - Retainer	374-6510
2W-7455	Gear As.	396-9957
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3735	Housing As.	391-9830
3P-3738	Housing As.	385-7196
3P-7489	Plate-Clutch	377-7423
3T-2139	Housing As.-Cl	394-2583
4B-1455	Cap As.-Filler	361-1719
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup - Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4K-8225	Pin-Cylinder	297-7215
4M-5226	Bearing-Ball	399-6061
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As.-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing - Sleeve	379-0191
4N-0733	Pump Gp-XX 1 Gr	374-7502
4N-0913	Screen As.-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177

1MD		
Original Part Number	**Part Name**	**Classic Part Number**
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear - Flywheel	421-7283
4N-2572	Spider As.-Fan	451-9027
4N-3714	Chamber As.	363-7450
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As.-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing - Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As.-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4P-9961	Line As.-Fuel Inj	325-6115
4S-8472	Hood As.-Preclnr	296-1355
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As.	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As.	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433

1MD		
Original Part Number	**Part Name**	**Classic Part Number**
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-6254	Bearing	420-2495
5P-7802	Bearing-Aligning	420-2496
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4326	Housing-Screen	435-4790
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-5917	Pinion-Diff	297-7224
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3500	Shaft-Bev Pinion	384-4788
6I-1453	Crankshaft As.	368-5916
6I-2726	Bearing - Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As.	380-7556
6N-7653	Gage As.-O Level	428-7206
6P-6739	Shaft-Planet	308-9929
6T-3726	Carrier As.	390-5269
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-5003	Bearing-Aligning	420-2498
6W-5119	Housing-Support	450-8051
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-9960	Mount As..	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As.-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303

Sales Model D400 (Cont'd.)

1MD		
Original Part Number	Part Name	Classic Part Number
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As.-Conn	379-8864
7E-6002	Bearing - Sleeve	417-4523
7E-6003	Bearing - Sleeve	417-4522
7E-6004	Bearing - Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7G-5749	Piston-Clutch	416-2132
7M-7219	Bearing - Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing - Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-8828	Pulley	420-6395
7N-8957	Gear-Crankshaft	422-2652
7S-7809	Cap As.-Radiator	295-6417
7W-0140	Gear-Drive	399-8546
7W-2164	Core As.-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8C-4456	Gasket Kit - Sch	393-1029
8F-6058	Bearing - Sleeve	416-5494
8F-9365	Pin	319-3463
8H-8175	Bearing - Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As.-Conn	379-8866
8N-2104	Bell As.-Suction	380-1521
8N-2641	Sleeve	325-6210

1MD		
Original Part Number	Part Name	Classic Part Number
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-8258	Bearing - Sleeve	452-1077
8P-4047	Shaft-Planet	373-5390
8S-6511	Bearing - Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8V-6390	Drum-Brake	377-7449
9C-5852	Hub As.	297-7208
9C-8205	Gear-Bevel	319-8175
9G-1919	Gear-Planet	371-4307
9G-9543	Gear-Pump (Oil)	295-6426
9L-5839	Coupling-Exhaust	374-7480
9M-1328	Bearing-Aligning	325-6018
9M-1990	Dowel-Reaction	386-4963
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race - Thrust	394-9205
9N-3668	Base As..-Coolant	419-4718
9P-5531	Gear-Sun	417-9499
9S-7949	Cup - Roller Brg	420-6531
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-5160	Plunger Kt-Adj	385-7218
9W-1572	Shaft-XMSN Input	419-1864
9W-2977	Hub As.	423-6985
9W-5768	Gear - Ring	380-7474
9W-7040	Piston-Clutch	377-7462
9Y-2988	Breather As.	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552

1MD		
Original Part Number	Part Name	Classic Part Number
100-7408	Camshaft As.	378-4000
101-1816	Bridge As.-Intake	374-4689
101-1817	Bridge As..-Exh	374-4690
101-1818	Bridge As.-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
103-5961	Wheel	398-2963
106-7798	Bearing-Ball	417-9494
108-2102	Bonnet-Valve	455-3274
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As.	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As.	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As.-Cyl	394-0915
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As.	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As..-Pump	420-8566
128-2922	Kit-Gasket (WP)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193

Articulated Trucks

Sales Model D400 (Cont'd.)

1MD		
Original Part Number	**Part Name**	**Classic Part Number**
131-7123	Bearing - Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
139-9170	Gasket Kit	447-0825
144-0482	Gasket	420-8547
145-8503	Shaft As.-Idler	426-0035
148-0885	Stator-Converter	379-0161
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-8178	Rod As.-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-XX 1 Gr	374-7502
164-4891	Plate As..	391-1093

1MD		
Original Part Number	**Part Name**	**Classic Part Number**
166-9142	Gasket	420-8546
167-8126	Damper As.	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As.	380-1516
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
190-9861	Kit-GSKT-ACL	386-3812
191-7941	Line As.-Fuel Inj	378-4011
191-7942	Line As.-Fuel Inj	374-4699
191-7943	Line As.-Fuel Inj	374-4700
191-7944	Line As.-Fuel Inj	374-4701
191-7945	Line As.-Fuel Inj	378-4012
191-7946	Line As.-Fuel Inj	378-4013
202-3572	Shaft As.-Drive	426-0037

1MD		
Original Part Number	**Part Name**	**Classic Part Number**
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-6574	Kit-Gasket-RS	437-2034
233-9748	Disc-Friction	417-9502
234-1874	Kit-Gasket-FS	437-8668
253-1752	Plate-Thrust	379-0170
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

Sales Model D400D

4EJ		
Original Part Number	**Part Name**	**Classic Part Number**
1L-7205	Bearing-Ball	416-2167
2D-9457	Cone-Spl Tapered	377-7418
4F-2041	Cup - Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433

4EJ		
Original Part Number	**Part Name**	**Classic Part Number**
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-6254	Bearing	420-2495
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028

4EJ		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7949	Cup - Roller Brg	420-6531
106-7798	Bearing-Ball	417-9494
139-9170	Gasket Kit	447-0825
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
232-3679	Kit-Gasket (RS)	437-2039

8TF		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167

8TF		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup - Roller Brg	420-6535

8TF		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3935	Cone - Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114
1P-9945	Bracket As.-Fan	296-1344

Sales Model D400D (Cont'd.)

8TF		
Original Part Number	Part Name	Classic Part Number
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1S-9670	Univ Jt As.	443-2017
1T-0364	Flange-Joint	388-6567
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0807	Race - Thrust Brg	453-3651
1T-1278	Bearing - Thrust	370-8370
1T-1281	Retainer - Brg	390-0924
1T-1282	Race Brg Thrust	373-1755
1U-2666	Cartridge Gp	422-8115
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As.	443-2659
1W-5910	Tappet As.-Guide &	383-1569
1W-5912	Tappet As.-Guide &	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As.-Check	420-6221
1W-7238	Shaft As.-Pump Dr	379-0164
1W-7239	Shaft As.-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup - Roller Brg	415-1914

8TF		
Original Part Number	Part Name	Classic Part Number
2D-9455	Cone - Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0535	Nut	299-2026
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As.-Gear	296-1367
2P-1738	Plate As.-Oil Pan	325-6164
2P-1739	Tube As.-Pump	325-6229
2P-1751	Bell As.-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As.-Inlet	325-6230
2P-6245	Shaft As.-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2S-6097	Tang	375-9979
2S-7931	Bearing - Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate - Retainer	374-6510
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357

8TF		
Original Part Number	Part Name	Classic Part Number
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7455	Gear As.	396-9957
2W-7458	Crankshaft As.	242-3439
2W-7678	Gear-Water Pump	325-6088
3E-6772	Seal-Water	382-8017
3G-7663	Cartridge Gp	422-8120
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3208	Flange-Joint	301-4647
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3735	Housing As.	391-9830
3P-3738	Housing As.	385-7196
3P-7489	Plate-Clutch	377-7423
3T-2139	Housing As.-Cl	394-2583
4B-1455	Cap As.-Filler	361-1719
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup - Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-7463	Seal-Lip Type	472-8007
4K-8225	Pin-Cylinder	297-7215
4M-3915	Bearing-Caged	377-7427
4M-5226	Bearing-Ball	399-6061
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As.-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing - Sleeve	379-0191
4N-0733	Pump Gp-XX 1 Gr	374-7502

Sales Model D400D (Cont'd.)

8TF		
Original Part Number	Part Name	Classic Part Number
4N-0913	Screen As.-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear - Flywheel	421-7283
4N-2572	Spider As.-Fan	451-9027
4N-3714	Chamber As.	363-7450
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As.-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing - Sleeve	373-1885
4N-7693	Crankshaft As.	269-8763
4P-2383	Adapter-Inlet	438-1812
4P-3546	Valve As.-Relief	325-6236
4P-7688	Valve As.-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As.-Fuel Inj	279-4984
4P-9382	Line As.-Fuel Inj	279-4985
4P-9383	Line As.-Fuel Inj	279-4988
4P-9384	Line As.-Fuel Inj	279-4989
4P-9395	Line As.-Fuel Inj	383-3690
4P-9396	Line As.-Fuel Inj	383-3691
4P-9961	Line As.-Fuel Inj	325-6115
4S-8472	Hood As.-Preclnr	296-1355

8TF		
Original Part Number	Part Name	Classic Part Number
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4W-0452	Seal As. -Cshaft	325-6191
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As.	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As.	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As.-Oclr	374-7501
5D-2989	Bearing	380-7511
5L-7632	Support-Elbow	433-9854
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-6254	Bearing	420-2495
5P-7802	Bearing-Aligning	420-2496
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4326	Housing-Screen	435-4790

8TF		
Original Part Number	Part Name	Classic Part Number
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As.	242-3437
5S-7630	Bearing - Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5U-0557	Pump Gp-VN Bsc-B	422-8175
5V-1274	Spider	385-6110
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3500	Shaft-Bev Pinion	384-4788
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As.-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1453	Crankshaft As.	368-5916
6I-2726	Bearing - Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As. - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1931	Plunger	379-0171
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As.	380-7556
6N-7174	Shield-Oil	314-8544
6N-7653	Gage As.-O Level	428-7206

Sales Model D400D (Cont'd.)

8TF		
Original Part Number	Part Name	Classic Part Number
6P-6739	Shaft-Planet	308-9929
6P-7704	Carrier-Ring	314-8658
6T-3726	Carrier As.	390-5269
6V-0538	Bearing-Spl Ball	398-2935
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-5003	Bearing-Aligning	420-2498
6W-5119	Housing-Support	450-8051
6Y-1690	Carrier-Ring	384-3849
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-9960	Mount As..	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As.-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As.-Conn	379-8864
7E-6002	Bearing - Sleeve	417-4523
7E-6003	Bearing - Sleeve	417-4522
7E-6004	Bearing - Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-5618	Manifold As.	283-5204
7G-5746	Housing-Clutch	392-4520
7G-5749	Piston-Clutch	416-2132
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As.	314-8721
7H-7628	Bearing	453-3655

8TF		
Original Part Number	Part Name	Classic Part Number
7J-8893	Cone - Roller Brg	374-1846
7M-4046	Bearing - Sleeve	394-8206
7M-7219	Bearing - Thrust	384-4816
7N-0110	Core As.-Oil Clr	319-3435
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing - Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8828	Pulley	420-6395
7N-8957	Gear-Crankshaft	422-2652
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As.-Radiator	295-6417
7W-0140	Gear-Drive	399-8546
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As.-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5692	Pulley-Cshaft	386-3041
7W-5733	Gasket	421-7333
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As.	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As.-Pump Suc	378-3989

8TF		
Original Part Number	Part Name	Classic Part Number
8F-6058	Bearing - Sleeve	416-5494
8F-9365	Pin	319-3463
8H-2810	Case As.-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing - Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8N-0703	Bearing - Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As.-Conn	269-5291
8N-1726	Rod As.-Conn	379-8866
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As.-Suction	380-1521
8N-2518	Bearing - Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As.-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing - Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As.-Outlet	325-6232
8N-7782	Rotocoil As.	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

Sales Model D400D (Cont'd.)

8TF		
Original Part Number	Part Name	Classic Part Number
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8258	Bearing - Sleeve	452-1077
8P-0953	Turbine-Conv	297-7269
8P-1919	Gear-Planet	300-2579
8P-1948	Gear - Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4047	Shaft-Planet	373-5390
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As.	325-6033
8S-0493	Shaft As.-Pump	325-6198
8S-3970	Chamber As.	242-3438
8S-6511	Bearing - Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8V-6390	Drum-Brake	377-7449
8V-7885	Housing-Support	297-7193
9C-5852	Hub As.	297-7208
9C-8205	Gear-Bevel	319-8175
9C-8218	Shaft-Bev Pinion	302-2697
9G-0280	Piston	283-5213
9G-1919	Gear-Planet	371-4307
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5839	Coupling-Exhaust	374-7480
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9M-1990	Dowel-Reaction	386-4963

8TF		
Original Part Number	Part Name	Classic Part Number
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race - Thrust	394-9205
9N-3668	Base As..-Coolant	419-4718
9P-5531	Gear-Sun	417-9499
9P-8517	Case-XMSN	394-0909
9S-7788	Ring-Piston	461-5124
9S-7949	Cup - Roller Brg	420-6531
9S-8679	Chamber As.	325-6042
9T-2200	Cartridgr Gp	422-8114
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-5160	Plunger Kt-Adj	385-7218
9W-1572	Shaft-XMSN Input	419-1864
9W-2977	Hub As.	423-6985
9W-3605	Carrier-Ring	314-8662
9W-5768	Gear - Ring	380-7474
9W-7040	Piston-Clutch	377-7462
9W-9930	Mount As.	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2988	Breather As.	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As.	378-4000
100-7860	Valve-Inlet	270-4360
101-0155	Pipe As.-Exhaust	399-4427
101-1816	Bridge As.-Intake	374-4689
101-1817	Bridge As..-Exh	374-4690
101-1818	Bridge As.-Exh	374-4691
101-7689	Yoke As.	422-7245
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513

8TF		
Original Part Number	Part Name	Classic Part Number
102-8608	Manifold-Exhaust	376-9062
103-5961	Wheel	398-2963
106-7798	Bearing-Ball	417-9494
108-2102	Bonnet-Valve	455-3274
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As.	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As.	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As.-Cyl	394-0915
111-8015	Gasket As.-Head	279-4977
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As.	394-2587
126-2522	Cone-Spl Tapered	377-7397
127-6356	Cover As..-Pump	420-8566
128-2922	Kit-Gasket (WP)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing - Sleeve	422-6919
131-8246	Yoke As. (8.5C)	430-5362
131-8248	Yoke As.	434-6113
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
136-7813	Bearing-Race	460-8296

Sales Model D400D (Cont'd.)

8TF		
Original Part Number	**Part Name**	**Classic Part Number**
139-9170	Gasket Kit	447-0825
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
145-8503	Shaft As.-Idler	426-0035
147-1206	Gear Planet	418-9597
148-0885	Stator-Converter	379-0161
148-7455	Valve - Exhaust	270-4361
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-8178	Rod As.-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-XX 1 Gr	374-7502
164-4891	Plate As..	391-1093
164-6560	Body As.-Piston	477-7125
165-4262	Body As.-Piston	270-4351
165-4262	Body As.-Piston	477-7126
165-4262	Body As.-Piston	270-4353
166-9142	Gasket	420-8546
167-8123	Damper As.	299-2006
167-8126	Damper As.	382-8019
168-4531	Body As.-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194

8TF		
Original Part Number	**Part Name**	**Classic Part Number**
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
177-9024	Adapter-Damper	299-1956
185-2831	Line As.	380-1516
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
190-9861	Kit-GSKT-ACL	386-3812
191-7941	Line As.-Fuel Inj	378-4011
191-7942	Line As.-Fuel Inj	374-4699
191-7943	Line As.-Fuel Inj	374-4700
191-7944	Line As.-Fuel Inj	374-4701
191-7945	Line As.-Fuel Inj	378-4012
191-7946	Line As.-Fuel Inj	378-4013
196-0028	Gear As.-Idler	364-5259
196-0029	Gear As.-Idler	374-4674
202-3572	Shaft As.-Drive	426-0037

8TF		
Original Part Number	**Part Name**	**Classic Part Number**
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3233	Bearing-Main	376-9085
232-3679	Kit-Gasket (RS)	437-2039
232-6574	Kit-Gasket-RS	437-2034
233-9748	Disc-Friction	417-9502
234-1874	Kit-Gasket-FS	437-8668
253-1752	Plate-Thrust	379-0170
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
290-2060	Kit-Gasket-Sch	438-0149
296-1359	Line As.-Cla	279-4988
296-1360	Line As.-Cla	279-4989
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
334-8389	Crankshaft As.	242-3439
430-7619	Adapter-Cla	438-1812
443-1200	Brg-Rlr-Cla	377-7397

2YR		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114
1T-0364	Flange-Joint	388-6567
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0807	Race-Thrust Brg	453-3651
1U-2666	Cartridge Gp	422-8115
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-8986	Cup-Rlr Bearing	415-1912
2S-6097	Tang	375-9979
2V-5656	Ring-Snap	374-1454

2YR		
Original Part Number	**Part Name**	**Classic Part Number**
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-7489	Plate-Clutch	377-7423
3T-2139	Housing As-Cl	394-2583
4B-1455	Cap As-Filler	361-1719
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4K-8225	Pin-Cylinder	297-7215
4M-5226	Bearing-Ball	399-6061
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027

2YR		
Original Part Number	**Part Name**	**Classic Part Number**
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355
4V-4852	Piston	433-0452
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-6254	Bearing	420-2495
5P-7802	Bearing-Aligning	420-2496
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4326	Housing-Screen	435-4790

Sales Model D400E (Cont'd.)

2YR		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6P-6739	Shaft-Planet	308-9929
6T-3726	Carrier As	390-5269
6T-5611	Spacer	435-8520
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-5003	Bearing-Aligning	420-2498
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7G-5749	Piston-Clutch	416-2132

2YR		
Original Part Number	Part Name	Classic Part Number
7H-7628	Bearing	453-3655
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-8828	Pulley	420-6395
7N-8957	Gear-Crankshaft	422-2652
7S-7809	Cap As-Radiator	295-6417
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8P-4047	Shaft-Planet	373-5390
8S-6511	Bearing-Sleeve	380-7372
9C-5852	Hub As	297-7208
9G-1919	Gear-Planet	371-4307
9L-5839	Coupling-Exhaust	374-7480
9M-1328	Bearing-Aligning	325-6018
9M-1990	Dowel-Reaction	386-4963

2YR		
Original Part Number	Part Name	Classic Part Number
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9P-5531	Gear-Sun	417-9499
9S-7949	Cup-Roller Brg	420-6531
9W-1572	Shaft-Xmsn Input	419-1864
9W-2977	Hub As	423-6985
9W-5768	Gear-Ring	380-7474
9W-7040	Piston-Clutch	377-7462
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
106-7798	Bearing-Ball	417-9494
108-2102	Bonnet-Valve	455-3274
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215

Sales Model D400E (Cont'd.)

2YR		
Original Part Number	Part Name	Classic Part Number
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
131-8246	Yoke As (8.5C)	430-5362
131-8248	Yoke As	434-6113
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
139-9170	Gasket Kit	447-0825

2YR		
Original Part Number	Part Name	Classic Part Number
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
147-1206	Gear Planet	418-9597
148-0885	Stator-Converter	379-0161
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
164-4891	Plate As.	391-1093
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700

2YR		
Original Part Number	Part Name	Classic Part Number
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
233-9748	Disc-Friction	417-9502
234-1874	Kit-Gasket-Fs	437-8668
253-1752	Plate-Thrust	379-0170
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

8PS		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1S-9209	Shaft-Tightener	374-6499
1T-0364	Flange-Joint	388-6567
1T-0679	Roller-Freewheel	384-4797

8PS		
Original Part Number	Part Name	Classic Part Number
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1W-4738	Bearing-Sleeve	325-6020
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059

8PS		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-8509	Cone-Roller Brg	399-4434
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2S-6150	Cover-Pulley	428-8817
2V-5656	Ring-Snap	374-1454

Sales Model D400E (Cont'd.)

8PS		
Original Part Number	Part Name	Classic Part Number
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4E-8534	Retainer-Seal	300-2588
4K-8225	Pin-Cylinder	297-7215
4N-0362	Cover As-Rgltr	419-4722
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-4942	Rod-Eye	421-8919
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4S-5367	Mount As	375-9986
4V-5392	Spider	377-7430
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-7802	Bearing-Aligning	420-2496
5P-7807	Bearing-Ball	314-8502
5P-9505	Cone-Roller Brg	420-6540
5P-9514	Bearing-Ball	417-9467
5S-4326	Housing-Screen	435-4790
5T-5682	Driver	418-9579
6I-1453	Crankshaft As	368-5916

8PS		
Original Part Number	Part Name	Classic Part Number
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
6N-3641	Pulley-Tightener	380-7536
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-5003	Bearing-Aligning	420-2498
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-7431	Piston-Selector	432-8911
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7S-7809	Cap As-Radiator	295-6417
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-5733	Gasket	421-7333
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9L-5839	Coupling-Exhaust	374-7480

8PS		
Original Part Number	Part Name	Classic Part Number
9M-1328	Bearing-Aligning	325-6018
9M-1990	Dowel-Reaction	386-4963
9M-2744	Cone-Spl Tapered	380-1480
9N-0316	Bracket-Pulley	434-1993
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
002-1212	Cup-Roller Brg	399-4446
101-3125	Gasket	420-8567
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
131-8246	Yoke As (8.5C)	430-5362
131-8248	Yoke As	434-6113
131-8674	Gear As-Drive	394-0911
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
147-1206	Gear Planet	418-9597
148-0885	Stator-Converter	379-0161
150-4637	Pan-Oil	377-5843

Sales Model D400E (Cont'd.)

8PS		
Original Part Number	**Part Name**	**Classic Part Number**
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055

8PS		
Original Part Number	**Part Name**	**Classic Part Number**
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
233-6984	Kit-Gasket (Fs)	437-2045
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
289-2935	Seal As-Buffer	472-8028

8PS		
Original Part Number	**Part Name**	**Classic Part Number**
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
325-2721	Kit-Gasket(T)	393-3662
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
430-7619	Adapter-Cla	438-1812

APF		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1S-9209	Shaft-Tightener	374-6499
1T-0364	Flange-Joint	388-6567
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1W-4738	Bearing-Sleeve	325-6020
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163

APF		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2S-6150	Cover-Pulley	428-8817
2V-5656	Ring-Snap	374-1454
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4E-8534	Retainer-Seal	300-2588
4K-8225	Pin-Cylinder	297-7215
4N-0362	Cover As-Rgltr	419-4722
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502

APF		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-4942	Rod-Eye	421-8919
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4S-5367	Mount As	375-9986
4V-5392	Spider	377-7430
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-7802	Bearing-Aligning	420-2496

Sales Model D400E (Cont'd.)

APF		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-9505	Cone-Roller Brg	420-6540
5P-9514	Bearing-Ball	417-9467
5S-4326	Housing-Screen	435-4790
5T-5682	Driver	418-9579
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-3641	Pulley-Tightener	380-7536
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-5003	Bearing-Aligning	420-2498
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-7431	Piston-Selector	432-8911
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7S-7809	Cap As-Radiator	295-6417

APF		
Original Part Number	Part Name	Classic Part Number
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-5733	Gasket	421-7333
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9M-2744	Cone-Spl Tapered	380-1480
9N-0316	Bracket-Pulley	434-1993
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
131-8246	Yoke As (8.5C)	430-5362
131-8248	Yoke As	434-6113
131-8674	Gear As-Drive	394-0911

APF		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
147-1206	Gear Planet	418-9597
148-0885	Stator-Converter	379-0161
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

2JJ		
Original Part Number	Part Name	Classic Part Number
1B-3937	Cup - Roller Brg	377-7394
1B-4043	Cone - Roller Brg	377-7395
1B-6577	Cone-Spl Tapered	374-1839
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup - Roller Brg	420-6535
1P-3935	Cone - Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114
1T-0364	Flange-Joint	388-6567
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0807	Race - Thrust Brg	453-3651
1U-2666	Cartridge Gp	422-8115
1V-8604	Gear - Ring	308-9853
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As.-Guide &	383-1569
1W-7238	Shaft As.-Pump Dr	379-0164
1W-7239	Shaft As.-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2D-9130	Washer-Thrust	308-9943
2D-9454	Cup - Roller Brg	415-1914
2D-9455	Cone - Roller Brg	415-1915

2JJ		
Original Part Number	Part Name	Classic Part Number
2D-9457	Cone-Spl Tapered	377-7418
2G-1034	Valve-Safety	380-7555
2J-2152	Cup - Roller Brg	374-1852
2K-5066	Cone - Roller Brg	396-4142
2K-5069	Cup - Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2N-5842	Screw-Bridge Adj	418-1934
2P-8986	Cup-Rlr Bearing	415-1912
2S-6097	Tang	375-9979
2V-3687	Gear-Diff Bevel	308-9849
2V-5656	Ring-Snap	374-1454
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate - Retainer	374-6510
2W-7455	Gear As.	396-9957
3D-5315	Pinion-Dif Bevel	308-9856
3E-6772	Seal-Water	382-8017
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3735	Housing As.	391-9830
3P-3738	Housing As.	385-7196
3P-7489	Plate-Clutch	377-7423
3T-2139	Housing As.-Cl	394-2583
4B-1455	Cap As.-Filler	361-1719

2JJ		
Original Part Number	Part Name	Classic Part Number
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup - Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4K-8225	Pin-Cylinder	297-7215
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As.-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing - Sleeve	379-0191
4N-0733	Pump Gp-XX 1 Gr	374-7502
4N-0913	Screen As.-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear - Flywheel	421-7283
4N-2572	Spider As.-Fan	451-9027
4N-3714	Chamber As.	363-7450
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As.-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing - Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As.-Check	420-6216
4P-9961	Line As.-Fuel Inj	325-6115
4S-8472	Hood As.-Preclnr	296-1355
4V-2057	Bearing-Spher	419-6019
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177

Sales Model D40D (Cont'd.)

2JJ		
Original Part Number	Part Name	Classic Part Number
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As.	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As.	373-1906
4W-5998	Rod-Valve Push	379-0168
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-6254	Bearing	420-2495
5P-7802	Bearing-Aligning	420-2496
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4326	Housing-Screen	435-4790
5T-5682	Driver	418-9579
5V-5917	Pinion-Diff	297-7224
6B-3223	Cup-Bearing	399-6065
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6I-1453	Crankshaft As.	368-5916
6I-2726	Bearing - Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-7751	Rod End-Spher	472-8015
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As.	380-7556
6N-7653	Gage As.-O Level	428-7206

2JJ		
Original Part Number	Part Name	Classic Part Number
6P-6739	Shaft-Planet	308-9929
6T-3726	Carrier As.	390-5269
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-5003	Bearing-Aligning	420-2498
6W-7290	Shaft-Planet	308-9930
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4689	Bearing-Aligning	420-6532
6Y-5793	Ring-Seal	451-9028
6Y-9960	Mount As..	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As.-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7D-8437	Cone - Roller Brg	380-1502
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As.-Conn	379-8864
7E-6002	Bearing - Sleeve	417-4523
7E-6003	Bearing - Sleeve	417-4522
7E-6004	Bearing - Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7G-5749	Piston-Clutch	416-2132
7H-7628	Bearing	453-3655
7M-7219	Bearing - Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing - Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race Brg Thrust	417-4531

2JJ		
Original Part Number	Part Name	Classic Part Number
7N-7628	Gasket	419-1811
7N-8828	Pulley	420-6395
7N-8957	Gear-Crankshaft	422-2652
7S-7809	Cap As.-Radiator	295-6417
7W-0140	Gear-Drive	399-8546
7W-2164	Core As.-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing - Sleeve	416-5494
8F-9365	Pin	319-3463
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone - Roller Brg	399-4442
8H-8175	Bearing - Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As.-Conn	379-8866
8N-2104	Bell As.-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-8258	Bearing - Sleeve	452-1077
8P-4047	Shaft-Planet	373-5390
8R-4821	Carrier-Planet	308-9837
8R-7425	Retainer	308-9917
8S-6511	Bearing - Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8V-6382	Hub As.	308-9868
8V-6384	Spacer As.	308-9935
8V-6390	Drum-Brake	377-7449
8V-7885	Housing-Support	297-7193
9C-5852	Hub As.	297-7208
9C-8074	Gear-Planet	308-9858
9C-8075	Gear-Sun	308-9864

Sales Model D40D (Cont'd.)

2JJ		
Original Part Number	Part Name	Classic Part Number
9C-8218	Shaft-Bev Pinion	302-2697
9C-8278	Case As.-Diff	423-6984
9G-1919	Gear-Planet	371-4307
9J-3206	Bearing-Spher	360-2275
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race - Thrust	394-9205
9N-3668	Base As..-Coolant	419-4718
9P-5531	Gear-Sun	417-9499
9S-7949	Cup - Roller Brg	420-6531
9T-2200	Cartridgr Gp	422-8114
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-5160	Plunger Kt-Adj	385-7218
9V-6526	Ring-Retaining	422-2485
9V-7710	Univ Joint As.	394-8234
9W-1572	Shaft-XMSN Input	419-1864
9W-2977	Hub As.	423-6985
9W-5768	Gear - Ring	380-7474
9W-7040	Piston-Clutch	377-7462
9W-9930	Mount As.	295-6437
9Y-2988	Breather As.	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As.	378-4000
101-1816	Bridge As.-Intake	374-4689
101-1817	Bridge As..-Exh	374-4690
101-1818	Bridge As.-Exh	374-4691

2JJ		
Original Part Number	Part Name	Classic Part Number
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
103-5961	Wheel	398-2963
106-7798	Bearing-Ball	417-9494
108-2102	Bonnet-Valve	455-3274
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As.	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As.	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As.-Cyl	394-0915
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As.	394-2587
126-2522	Cone-Spl Tapered	377-7397
127-6356	Cover As..-Pump	420-8566
128-2922	Kit-Gasket (WP)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing - Sleeve	422-6919
131-8246	Yoke As. (8.5C)	430-5362
131-8248	Yoke As.	434-6113
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813

2JJ		
Original Part Number	Part Name	Classic Part Number
139-9170	Gasket Kit	447-0825
144-0482	Gasket	420-8547
145-8503	Shaft As.-Idler	426-0035
147-1206	Gear Planet	418-9597
148-0885	Stator-Converter	379-0161
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-8178	Rod As.-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-XX 1 Gr	374-7502
164-4891	Plate As..	391-1093
166-9142	Gasket	420-8546
167-8126	Damper As.	382-8019
171-6696	DIAPHRAGM	384-4811
177-9024	Adapter-Damper	299-1956
185-2831	Line As.	380-1516
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
190-9861	Kit-GSKT-ACL	386-3812
191-7941	Line As.-Fuel Inj	378-4011
191-7942	Line As.-Fuel Inj	374-4699
191-7943	Line As.-Fuel Inj	374-4700
191-7944	Line As.-Fuel Inj	374-4701
191-7945	Line As.-Fuel Inj	378-4012
191-7946	Line As.-Fuel Inj	378-4013
202-3572	Shaft As.-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3679	Kit-Gasket (RS)	437-2039
232-6574	Kit-Gasket-RS	437-2034

Sales Model D40D (Cont'd.)

2JJ		
Original Part Number	Part Name	Classic Part Number
233-9748	Disc-Friction	417-9502
234-1874	Kit-Gasket-FS	437-8668
253-1752	Plate-Thrust	379-0170
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

2JJ		
Original Part Number	Part Name	Classic Part Number
290-2060	Kit-Gasket-Sch	438-0149
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387

2JJ		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
374-1849	Brg-Rlr-Cla	399-4442
430-7619	Adapter-Cla	438-1812
443-1200	Brg-Rlr-Cla	377-7397

Sales Model D44

2LD		
Original Part Number	Part Name	Classic Part Number
1B-3937	Cup - Roller Brg	377-7394
1B-4043	Cone - Roller Brg	377-7395
1H-5338	Cup - Roller Brg	374-8345
1M-8736	Cup - Roller Brg	423-7759
1P-1367	Plunger-Valve	432-8913
1P-7522	Yoke As.	382-6893
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1S-0057	Plate-Clutch	377-7404
1W-0156	Core As.-Oclr	416-5525
1W-5009	Crankshaft As.	398-2969
1W-6987	Valve As.-Check	420-6221
1W-7238	Shaft As.-Pump Dr	379-0164
1W-7239	Shaft As.-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2D-9130	Washer-Thrust	308-9943
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-6489	Race-Brg Outer	374-8350

2LD		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2S-6097	Tang	375-9979
2V-3687	Gear-Diff Bevel	308-9849
2W-7980	Camshaft As.	378-3972
3D-5315	Pinion-Dif Bevel	308-9856
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-6411	Cup-Rlr Bearing	423-7759
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3429	Cage-Bearing	452-0430
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As.	391-9830
3P-3738	Housing As.	385-7196

2LD		
Original Part Number	Part Name	Classic Part Number
3P-7489	Plate-Clutch	377-7423
3P-8186	Housing-Screen	390-5261
3S-1262	Retainer	308-9915
3T-2139	Housing As.-Cl	394-2583
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350
3V-4046	Plate-PRESSURE	380-7470
4B-7255	Cone-Bearing	386-4951
4E-0079	Cage-Bearing	434-4387
4F-2041	Cup - Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As.-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing - Sleeve	379-0191
4N-0913	Screen As.-Bell	374-7489
4N-1015	Bearing - Sleeve	417-4525
4N-1098	Shaft As.	374-1455
4N-1106	Shaft As.-Rocker	377-5837
4N-1116	Shaft As.-Pump	374-7473

Sales Model D44 (Cont'd.)

2LD		
Original Part Number	Part Name	Classic Part Number
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1675	Manifold-Exhaust	443-2015
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear - Flywheel	421-7283
4N-3714	Chamber As.	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As.-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing - Sleeve	373-1885
4P-7688	Valve As.-Check	420-6216
4W-0419	Core As.-Oclr	379-0182
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As.-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5F-7404	Nut-Bearing Lock	308-9878
5F-8651	Bearing-Ball	420-3223
5G-3612	Cap Gp-Protn	295-6419
5J-9451	Bearing	374-8338
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-9738	Coupling-Exhaust	311-9380

2LD		
Original Part Number	Part Name	Classic Part Number
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6I-1032	Line As.-Fuel Inj	390-0931
6I-1035	Line As.-Fuel Inj	390-0921
6I-1036	Line As.-Fuel Inj	390-0922
6I-1038	Line As.-Fuel Inj	390-0923
6I-4613	Plate-Spacer	380-7405
6N-1931	Plunger	379-0171
6N-4597	Coupling-Exhaust	369-9489
6N-5354	Pipe-Extension	430-8130
6N-6490	Bracket As.-Fan	420-8569
6N-7154	Rotocoil As.	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As.	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing - Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-2923	Yoke As.	382-6891
6P-6739	Shaft-Planet	308-9929
6T-3726	Carrier As.	390-5269
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-5003	Bearing-Aligning	420-2498

2LD		
Original Part Number	Part Name	Classic Part Number
6W-7290	Shaft-Planet	308-9930
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-3039	Core As.-Oclr	363-7451
7E-5085	Bushing	377-5829
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7G-5749	Piston-Clutch	416-2132
7M-7219	Bearing - Thrust	384-4816
7N-2156	Bearing - Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5218	Manifold-Exhaust	435-4786
7N-5219	Manifold-Exhaust	425-2362
7S-4000	Piston	416-2143
7S-7809	Cap As.-Radiator	295-6417
7T-2036	Cap As.-Fuel	361-1721
7W-0182	Plunger & Bbl As.	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As.-Oclr	299-1996
8F-6058	Bearing - Sleeve	416-5494
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone - Roller Brg	399-4442
8H-8175	Bearing - Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As.-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886

Sales Model D44 (Cont'd.)

2LD		
Original Part Number	Part Name	Classic Part Number
8N-2104	Bell As.-Suction	380-1521
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8P-0514	Yoke As.	308-9947
8P-4047	Shaft-Planet	373-5390
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing - Sleeve	380-7372
9C-8278	Case As.-Diff	423-6984
9G-1919	Gear-Planet	371-4307
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9M-1990	Dowel-Reaction	386-4963
9N-1161	Line As.-Fuel Inj	383-3705
9N-3668	Base As..-Coolant	419-4718
9N-3970	Line As.-Fuel Inj	390-1005
9N-5529	Body-F Inj Valve	378-3993
9P-5531	Gear-Sun	417-9499
9S-7949	Cup - Roller Brg	420-6531
9V-7710	Univ Joint As.	394-8234
9W-1572	Shaft-XMSN Input	419-1864
9W-2977	Hub As.	423-6985
9W-5768	Gear - Ring	380-7474
9W-7040	Piston-Clutch	377-7462

2LD		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As.	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
101-1816	Bridge As.-Intake	374-4689
101-1817	Bridge As..-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Cam-shaft Dr	376-9069
102-4563	Gear-Transfer	399-4430
102-8608	Manifold-Exhaust	376-9062
106-7798	Bearing-Ball	417-9494
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As.	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As..-Pump	420-8566

2LD		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing - Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
141-4109	Core As.-Oclr	416-5518
145-8503	Shaft As.-Idler	426-0035
160-8178	Rod As.-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
164-4891	Plate As..	391-1093
202-3572	Shaft As.-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
217-0586	Bearing-Rod	419-7266
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As..	425-3444
283-5666	Gasket-Cyl Head	388-6565
307-1303	Muffler As..	361-6574
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
374-1849	Brg-Rlr-Cla	399-4442

Sales Model D44B

8SD		
Original Part Number	Part Name	Classic Part Number
1B-3937	Cup - Roller Brg	377-7394
1B-4043	Cone - Roller Brg	377-7395

8SD		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup - Roller Brg	423-7759
1P-1367	Plunger-Valve	432-8913

8SD		
Original Part Number	Part Name	Classic Part Number
1P-7522	Yoke As.	382-6893
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399

Sales Model D44B (Cont'd.)

8SD		
Original Part Number	Part Name	Classic Part Number
1S-0057	Plate-Clutch	377-7404
1W-5009	Crankshaft As.	398-2969
1W-6987	Valve As.-Check	420-6221
1W-7238	Shaft As.-Pump Dr	379-0164
1W-7239	Shaft As.-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2D-9130	Washer-Thrust	308-9943
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-6489	Race-Brg Outer	374-8350
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2V-3687	Gear-Diff Bevel	308-9849
2W-4087	Gear As.-Idler	418-9582
2W-7980	Camshaft As.	378-3972
3D-5315	Pinion-Dif Bevel	308-9856
3E-6772	Seal-Water	382-8017
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3N-6411	Cup-Rlr Bearing	423-7759
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3429	Cage-Bearing	452-0430

8SD		
Original Part Number	Part Name	Classic Part Number
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As.	391-9830
3P-3738	Housing As.	385-7196
3P-7489	Plate-Clutch	377-7423
3P-8186	Housing-Screen	390-5261
3S-1262	Retainer	308-9915
3T-2139	Housing As.-Cl	394-2583
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350
3V-3855	Housing-Brg Spt	375-9980
3V-4046	Plate-PRESSURE	380-7470
4B-7255	Cone-Bearing	386-4951
4E-0079	Cage-Bearing	434-4387
4F-2041	Cup - Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As.-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing - Sleeve	379-0191
4N-0913	Screen As.-Bell	374-7489
4N-1015	Bearing - Sleeve	417-4525
4N-1098	Shaft As.	374-1455
4N-1106	Shaft As.-Rocker	377-5837
4N-1116	Shaft As.-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-2514	Gear - Flywheel	421-7283
4N-3714	Chamber As.	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As.-Rocker	374-4710

8SD		
Original Part Number	Part Name	Classic Part Number
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing - Sleeve	373-1885
4P-7688	Valve As.-Check	420-6216
4W-0419	Core As.-Oclr	379-0182
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As.-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5F-7404	Nut-Bearing Lock	308-9878
5G-3612	Cap Gp-Protn	295-6419
5J-9451	Bearing	374-8338
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6C-0570	Pump Gp-Mtrg Bsc	374-5380

Sales Model D44B (Cont'd.)

8SD		
Original Part Number	Part Name	Classic Part Number
6I-0031	Line As.-Fuel Inj	374-4713
6I-0032	Line As.-Fuel Inj	374-4714
6I-0033	Line As.-Fuel Inj	374-4715
6I-0034	Line As.-Fuel Inj	375-2262
6I-0035	Line As.-Fuel Inj	374-4716
6I-0036	Line As.-Fuel Inj	374-4717
6I-0037	Line As.-Fuel Inj	374-4718
6I-0038	Line As.-Fuel Inj	374-4719
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing - Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-5354	Pipe-Extension	430-8130
6N-6490	Bracket As.-Fan	420-8569
6N-7154	Rotocoil As.	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As.	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing - Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-2923	Yoke As.	382-6891
6P-6739	Shaft-Planet	308-9929
6T-3726	Carrier As.	390-5269
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-7290	Shaft-Planet	308-9930
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4689	Bearing-Aligning	420-6532
6Y-5793	Ring-Seal	451-9028
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571

8SD		
Original Part Number	Part Name	Classic Part Number
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As.-Oclr	363-7451
7D-8437	Cone - Roller Brg	380-1502
7E-5085	Bushing	377-5829
7E-5996	Rod As.-Conn	379-8864
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7G-5749	Piston-Clutch	416-2132
7M-7219	Bearing - Thrust	384-4816
7N-2156	Bearing - Sleeve	380-7373
7S-4000	Piston	416-2143
7T-2036	Cap As.-Fuel	361-1721
7V-6790	Shaft-Bev Pinion	308-9922
7W-0182	Plunger & Bbl As.	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As.-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
8F-6058	Bearing - Sleeve	416-5494
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone - Roller Brg	399-4442
8H-8175	Bearing - Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As.-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-2104	Bell As.-Suction	380-1521
8N-3666	Repair Kt-Major	377-5842

8SD		
Original Part Number	Part Name	Classic Part Number
8N-5305	Spacer	363-7464
8P-0514	Yoke As.	308-9947
8P-4047	Shaft-Planet	373-5390
8R-7425	Retainer	308-9917
8S-6511	Bearing - Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-8278	Case As.-Diff	423-6984
9G-1919	Gear-Planet	371-4307
9J-3206	Bearing-Spher	360-2275
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9M-1990	Dowel-Reaction	386-4963
9N-3668	Base As..-Coolant	419-4718
9P-5531	Gear-Sun	417-9499
9S-7949	Cup - Roller Brg	420-6531
9V-7710	Univ Joint As.	394-8234
9W-1572	Shaft-XMSN Input	419-1864
9W-2977	Hub As.	423-6985
9W-5768	Gear - Ring	380-7474
9W-7040	Piston-Clutch	377-7462
9Y-2988	Breather As.	361-1716
9Y-3969	Line As.-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As.-Intake	374-4689
101-1817	Bridge As..-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Cam-shaft Dr	376-9069
102-4563	Gear-Transfer	399-4430
102-8608	Manifold-Exhaust	376-9062

Sales Model D44B (Cont'd.)

8SD		
Original Part Number	**Part Name**	**Classic Part Number**
106-7798	Bearing-Ball	417-9494
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As.	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504

8SD		
Original Part Number	**Part Name**	**Classic Part Number**
127-6356	Cover As..-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing - Sleeve	422-6919
135-3225	Shaft As.	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As..	397-5053
141-4109	Core As.-Oclr	416-5518
145-8503	Shaft As.-Idler	426-0035
160-8178	Rod As.-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
164-4891	Plate As..	391-1093
202-3572	Shaft As.-Drive	426-0037

8SD		
Original Part Number	**Part Name**	**Classic Part Number**
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
217-0586	Bearing-Rod	419-7266
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As..	425-3444
283-5666	Gasket-Cyl Head	388-6565
307-1303	Muffler As..	361-6574
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
374-1849	Brg-Rlr-Cla	399-4442

Sales Model D550

4RD		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3937	Cup - Roller Brg	377-7394
1B-4043	Cone - Roller Brg	377-7395
1H-5338	Cup - Roller Brg	374-8345
1M-8736	Cup - Roller Brg	423-7759
1P-1367	Plunger-Valve	432-8913
1P-7522	Yoke As.	382-6893
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1S-0057	Plate-Clutch	377-7404
1W-0156	Core As.-Oclr	416-5525
1W-5009	Crankshaft As.	398-2969
1W-6987	Valve As.-Check	420-6221

4RD		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7238	Shaft As.-Pump Dr	379-0164
1W-7239	Shaft As.-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2D-9130	Washer-Thrust	308-9943
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-6489	Race-Brg Outer	374-8350
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532

4RD		
Original Part Number	**Part Name**	**Classic Part Number**
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2S-6097	Tang	375-9979
2V-3687	Gear-Diff Bevel	308-9849
2W-7980	Camshaft As.	378-3972
3D-5315	Pinion-Dif Bevel	308-9856
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-6411	Cup-Rlr Bearing	423-7759
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-3059	Gear-Sun	308-9861

Sales Model D550 (Cont'd.)

4RD		
Original Part Number	Part Name	Classic Part Number
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3429	Cage-Bearing	452-0430
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As.	391-9830
3P-3738	Housing As.	385-7196
3P-7489	Plate-Clutch	377-7423
3P-8186	Housing-Screen	390-5261
3S-1262	Retainer	308-9915
3T-2139	Housing As.-Cl	394-2583
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350
3V-4046	Plate-PRESSURE	380-7470
4B-7255	Cone-Bearing	386-4951
4E-0079	Cage-Bearing	434-4387
4F-2041	Cup - Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As.-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing - Sleeve	379-0191
4N-0913	Screen As.-Bell	374-7489
4N-1015	Bearing - Sleeve	417-4525
4N-1098	Shaft As.	374-1455
4N-1106	Shaft As.-Rocker	377-5837
4N-1116	Shaft As.-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1675	Manifold-Exhaust	443-2015
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear - Flywheel	421-7283
4N-3714	Chamber As.	363-7450

4RD		
Original Part Number	Part Name	Classic Part Number
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As.-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing - Sleeve	373-1885
4P-7688	Valve As.-Check	420-6216
4W-0419	Core As.-Oclr	379-0182
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As.-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5F-7404	Nut-Bearing Lock	308-9878
5F-8651	Bearing-Ball	420-3223
5G-3612	Cap Gp-Protn	295-6419
5J-9451	Bearing	374-8338
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-9738	Coupling-Exhaust	311-9380
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883

4RD		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
6I-1032	Line As.-Fuel Inj	390-0931
6I-1035	Line As.-Fuel Inj	390-0921
6I-1036	Line As.-Fuel Inj	390-0922
6I-1038	Line As.-Fuel Inj	390-0923
6I-4613	Plate-Spacer	380-7405
6N-1931	Plunger	379-0171
6N-4597	Coupling-Exhaust	369-9489
6N-5354	Pipe-Extension	430-8130
6N-6490	Bracket As.-Fan	420-8569
6N-7154	Rotocoil As.	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As.	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing - Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-2923	Yoke As.	382-6891
6P-6739	Shaft-Planet	308-9929
6T-3726	Carrier As.	390-5269
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-5003	Bearing-Aligning	420-2498
6W-7290	Shaft-Planet	308-9930
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-3039	Core As.-Oclr	363-7451
7E-5085	Bushing	377-5829
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520

Sales Model D550 (Cont'd.)

4RD		
Original Part Number	Part Name	Classic Part Number
7G-5749	Piston-Clutch	416-2132
7M-7219	Bearing - Thrust	384-4816
7N-2156	Bearing - Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5218	Manifold-Exhaust	435-4786
7N-5219	Manifold-Exhaust	425-2362
7S-4000	Piston	416-2143
7S-7809	Cap As.-Radiator	295-6417
7T-2036	Cap As.-Fuel	361-1721
7W-0182	Plunger & Bbl As.	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As.-Oclr	299-1996
8F-6058	Bearing - Sleeve	416-5494
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone - Roller Brg	399-4442
8H-8175	Bearing - Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As.-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-2104	Bell As.-Suction	380-1521
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8P-0514	Yoke As.	308-9947
8P-4047	Shaft-Planet	373-5390
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing - Sleeve	380-7372

4RD		
Original Part Number	Part Name	Classic Part Number
9C-8278	Case As.-Diff	423-6984
9G-1919	Gear-Planet	371-4307
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9M-1990	Dowel-Reaction	386-4963
9N-1161	Line As.-Fuel Inj	383-3705
9N-3668	Base As..-Coolant	419-4718
9N-3970	Line As.-Fuel Inj	390-1005
9N-5529	Body-F Inj Valve	378-3993
9P-5531	Gear-Sun	417-9499
9S-7949	Cup - Roller Brg	420-6531
9V-7710	Univ Joint As.	394-8234
9W-1572	Shaft-XMSN Input	419-1864
9W-2977	Hub As.	423-6985
9W-5768	Gear - Ring	380-7474
9W-7040	Piston-Clutch	377-7462
9Y-2988	Breather As.	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
101-1816	Bridge As.-Intake	374-4689
101-1817	Bridge As..-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Cam-shaft Dr	376-9069
102-4563	Gear-Transfer	399-4430
102-8608	Manifold-Exhaust	376-9062
106-7798	Bearing-Ball	417-9494
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476

4RD		
Original Part Number	Part Name	Classic Part Number
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As.	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As..-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing - Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
141-4109	Core As.-Oclr	416-5518
145-8503	Shaft As.-Idler	426-0035
160-8178	Rod As.-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
164-4891	Plate As..	391-1093
202-3572	Shaft As.-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
217-0586	Bearing-Rod	419-7266
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As..	425-3444
283-5666	Gasket-Cyl Head	388-6565
307-1303	Muffler As..	361-6574
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
374-1849	Brg-Rlr-Cla	399-4442

Sales Model D550B

5ND		
Original Part Number	Part Name	Classic Part Number
1B-3937	Cup - Roller Brg	377-7394
1B-4043	Cone - Roller Brg	377-7395
1M-8736	Cup - Roller Brg	423-7759
1P-1367	Plunger-Valve	432-8913
1P-7522	Yoke As.	382-6893
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1S-0057	Plate-Clutch	377-7404
1W-5009	Crankshaft As.	398-2969
1W-6987	Valve As.-Check	420-6221
1W-7238	Shaft As.-Pump Dr	379-0164
1W-7239	Shaft As.-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2D-9130	Washer-Thrust	308-9943
2D-9455	Cone - Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-6489	Race-Brg Outer	374-8350
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2V-3687	Gear-Diff Bevel	308-9849
2W-4087	Gear As.-Idler	418-9582
2W-7980	Camshaft As.	378-3972
3D-5315	Pinion-Dif Bevel	308-9856
3E-6772	Seal-Water	382-8017

5ND		
Original Part Number	Part Name	Classic Part Number
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3N-6411	Cup-Rlr Bearing	423-7759
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3429	Cage-Bearing	452-0430
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As.	391-9830
3P-3738	Housing As.	385-7196
3P-7489	Plate-Clutch	377-7423
3P-8186	Housing-Screen	390-5261
3S-1262	Retainer	308-9915
3T-2139	Housing As.-Cl	394-2583
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350
3V-3855	Housing-Brg Spt	375-9980
3V-4046	Plate-PRESSURE	380-7470
4B-7255	Cone-Bearing	386-4951
4E-0079	Cage-Bearing	434-4387
4F-2041	Cup - Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4M-5226	Bearing-Ball	399-6061
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As.-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing - Sleeve	379-0191

5ND		
Original Part Number	Part Name	Classic Part Number
4N-0913	Screen As.-Bell	374-7489
4N-1015	Bearing - Sleeve	417-4525
4N-1098	Shaft As.	374-1455
4N-1106	Shaft As.-Rocker	377-5837
4N-1116	Shaft As.-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-2514	Gear - Flywheel	421-7283
4N-3714	Chamber As.	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As.-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing - Sleeve	373-1885
4P-7688	Valve As.-Check	420-6216
4W-0419	Core As.-Oclr	379-0182
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As.-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5F-7404	Nut-Bearing Lock	308-9878
5G-3612	Cap Gp-Protn	295-6419
5J-9451	Bearing	374-8338
5L-7632	Support-Elbow	433-9854

Sales Model D550B (Cont'd.)

5ND		
Original Part Number	Part Name	Classic Part Number
5L-7634	Elbow-Turbo Exh	380-1555
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6I-0031	Line As.-Fuel Inj	374-4713
6I-0032	Line As.-Fuel Inj	374-4714
6I-0033	Line As.-Fuel Inj	374-4715
6I-0034	Line As.-Fuel Inj	375-2262
6I-0035	Line As.-Fuel Inj	374-4716
6I-0036	Line As.-Fuel Inj	374-4717
6I-0037	Line As.-Fuel Inj	374-4718
6I-0038	Line As.-Fuel Inj	374-4719
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing - Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-5354	Pipe-Extension	430-8130
6N-6490	Bracket As.-Fan	420-8569
6N-7154	Rotocoil As.	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As.	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing - Sleeve	380-7371

5ND		
Original Part Number	Part Name	Classic Part Number
6N-9133	Gasket-Plate	398-2959
6P-2923	Yoke As.	382-6891
6P-6739	Shaft-Planet	308-9929
6T-3726	Carrier As.	390-5269
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-7290	Shaft-Planet	308-9930
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4689	Bearing-Aligning	420-6532
6Y-5793	Ring-Seal	451-9028
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As.-Oclr	363-7451
7D-8437	Cone - Roller Brg	380-1502
7E-5085	Bushing	377-5829
7E-5996	Rod As.-Conn	379-8864
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7G-5749	Piston-Clutch	416-2132
7M-7219	Bearing - Thrust	384-4816
7N-2156	Bearing - Sleeve	380-7373
7S-4000	Piston	416-2143
7T-2036	Cap As.-Fuel	361-1721
7V-6790	Shaft-Bev Pinion	308-9922
7W-0182	Plunger & Bbl As.	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As.-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493

5ND		
Original Part Number	Part Name	Classic Part Number
8F-6058	Bearing - Sleeve	416-5494
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone - Roller Brg	399-4442
8H-8175	Bearing - Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As.-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-2104	Bell As.-Suction	380-1521
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8P-0514	Yoke As.	308-9947
8P-4047	Shaft-Planet	373-5390
8R-7425	Retainer	308-9917
8S-6511	Bearing - Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1540	Univ Jt As.	388-6574
9C-8278	Case As.-Diff	423-6984
9G-1919	Gear-Planet	371-4307
9J-3206	Bearing-Spher	360-2275
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9M-1990	Dowel-Reaction	386-4963
9N-3668	Base As..-Coolant	419-4718
9P-5531	Gear-Sun	417-9499
9S-7949	Cup - Roller Brg	420-6531
9V-7710	Univ Joint As.	394-8234
9W-1572	Shaft-XMSN Input	419-1864
9W-2977	Hub As.	423-6985
9W-5768	Gear - Ring	380-7474

Sales Model D550B (Cont'd.)

5ND		
Original Part Number	**Part Name**	**Classic Part Number**
9W-7040	Piston-Clutch	377-7462
9Y-2988	Breather As.	361-1716
9Y-3969	Line As.-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As.-Intake	374-4689
101-1817	Bridge As..-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Cam-shaft Dr	376-9069
102-4563	Gear-Transfer	399-4430
102-8608	Manifold-Exhaust	376-9062
106-7798	Bearing-Ball	417-9494
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166

5ND		
Original Part Number	**Part Name**	**Classic Part Number**
108-7930	Bearing As.	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As..-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing - Sleeve	422-6919
135-3225	Shaft As.	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As..	397-5053
141-4109	Core As.-Oclr	416-5518

5ND		
Original Part Number	**Part Name**	**Classic Part Number**
145-8503	Shaft As.-Idler	426-0035
160-8178	Rod As.-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
164-4891	Plate As..	391-1093
202-3572	Shaft As.-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
217-0586	Bearing-Rod	419-7266
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As..	425-3444
283-5666	Gasket-Cyl Head	388-6565
307-1303	Muffler As..	361-6574
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
374-1849	Brg-Rlr-Cla	399-4442

Cat Classic Parts for Backhoe Loaders

Cat backhoe loaders are designed for maximum performance and durability in any application. Caterpillar has been deliveRing industry-leading digging forces with this product Line since its introduction. However, As. with any aging equipment, maintenance costs need to be re-evaluated over time to ensure that maximum profitability is maintained. Cat Classic Parts are offered As. another solution to help keep these maintenance costs down for Caterpillar equipment. They are released for several models of backhoe loaders As. a competitively priced alternative to aftermarket parts.

Cat Classic Parts provide owners of older Caterpillar products with low cost Repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic Parts coverage for backhoe loaders includes:

- Engine
- Final Drive
- Hydraulics
- SteeRing
- Transmission
- ...and many more.

Sales Model 414E

ELB, TMS		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
3E-4924	Mounting As.	391-9812
3P-1210	Cone - Roller Brg	399-4433
6D-1734	Cup - Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As.	360-2353
9T-3948	Rod As.	393-0940
9W-9931	Mount As..	360-2354
005-0469	Cup-Rlr Bearing	418-9610

ELB, TMS		
Original Part Number	**Part Name**	**Classic Part Number**
005-0471	Cone-Spl Tapered	415-1924
005-8639	Bearing-Aligning	415-1925
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As.	416-2139
130-5451	Pin	394-9816
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As.	396-9901

ELB, TMS		
Original Part Number	**Part Name**	**Classic Part Number**
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
274-4553	Disc-Clutch	416-2153
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915
ELB		
126-5984	Ring-Backup	419-4654

Sales Model 415F

HWA		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955

Sales Model 415F (Cont'd.)

HWA		
Original Part Number	Part Name	Classic Part Number
6D-1734	Cup - Roller Brg	416-2171
6Y-9930	Mount As.	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As..	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
130-1637	Shaft	347-0471

HWA		
Original Part Number	Part Name	Classic Part Number
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As.-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As.	396-9901

HWA		
Original Part Number	Part Name	Classic Part Number
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing - Sleeve	394-0194
274-4274	Bearing - Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

PF4		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
6D-1734	Cup - Roller Brg	416-2171
6Y-9930	Mount As.	360-2353
9W-9931	Mount As..	360-2354

PF4		
Original Part Number	Part Name	Classic Part Number
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
178-8608	Cone	422-6479

PF4		
Original Part Number	Part Name	Classic Part Number
209-9886	Tie Rod As.	396-9901
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 416

5PC		
Original Part Number	PartName	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup - Roller Brg	423-7759
1P-7115	Mount As.	418-1936
1S-7057	Gasket	420-6384
2A-4576	Cup - Roller Brg	386-4944
2B-0941	Spacer	418-1955
2S-0479	Bearing-Cone	380-7506
4T-8054	Seal As.	472-8010
5J-7010	Seal As.	472-8011
5L-9656	Cone-Bearing	399-4448
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7K-5448	Cup-Bearing	415-1922

5PC		
Original Part Number	PartName	Classic Part Number
7T-3038	Gear-Reverse	445-1097
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
7T-3194	Yoke	346-5681
7T-5426	Cone - Roller Brg	453-3657
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As.-Rlr	384-4823
7W-5164	Gasket	420-8568
7W-5194	Muffler As..	346-5682
8E-2043	Yoke As.	385-6115
8S-9151	Cup-Spl Tapered	374-8348
9K-5639	Pin	425-6451
9L-2685	Rod End	419-1866
9R-0080	Coupling	346-5683
9R-0097	Pin	346-5684

5PC		
Original Part Number	PartName	Classic Part Number
9R-0313	Hub As.	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As.-Front	388-6604
9R-1725	Bearing - Sleeve	425-6446
9R-1917	Bearing - Sleeve	418-1958
9R-2410	Retainer As..	346-5688
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2476	Disc-Bk Rear	346-5691
9R-2477	Disc As.	346-5692
9R-2480	Case As.	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-2601	Rod Gp-Tie	385-6133

Sales Model 416 (Cont'd.)

5PC		
Original Part Number	PartName	Classic Part Number
9R-2842	Rod-Tie	385-6134
9R-2843	Rod-Tie	385-6135
9R-2846	Pin	346-5694
9R-2857	Rod-Piston	418-9588
9R-3527	Carrier-Planet	396-9892
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-6475	Pad As.	346-5702
9R-8199	Joint-Double	384-4813
9R-8714	Fork	390-0929
9R-8715	Spider As.-Brg&	346-5716
9R-8718	Yoke As.	364-5258
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9S-3581	Cup - Roller Brg	415-1923

5PC		
Original Part Number	PartName	Classic Part Number
9S-3582	Cone - Roller Brg	396-4144
9S-7949	Cup - Roller Brg	420-6531
9T-3948	Rod As.	393-0940
9Y-9431	Precleaner As.	361-1718
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
054-2213	Spider & Brg As.	347-0464
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As.	384-5959

5PC		
Original Part Number	PartName	Classic Part Number
055-1260	Housing Bk-Outer	347-0479
101-3125	Gasket	420-8567
118-5839	Seal-Lip Type	435-8517
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
130-1637	Shaft	347-0471
160-1014	Pin As.	347-0473
166-7870	Pad As.-Street	416-5515
186-4117	Carrier As.	394-8235
186-4118	Gear-Planet	347-0483
226-8202	Seal-Wiper	472-8024
274-4553	Disc-Clutch	416-2153
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 416B

8SG, 8ZK		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
1S-7057	Gasket	420-6384
2A-4576	Cup - Roller Brg	386-4944
2B-0941	Spacer	418-1955
2S-0479	Bearing-Cone	380-7506
3E-4903	Mount As.	396-7274
3P-1210	Cone - Roller Brg	399-4433
4T-8054	Seal As.	472-8010
5L-9656	Cone-Bearing	399-4448
6E-0775	Head	425-9373
6E-6153	Plate-Port	346-5678
6E-6163	Shaft	346-5679
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555

8SG, 8ZK		
Original Part Number	Part Name	Classic Part Number
7C-4349	Mount As.	383-2117
7K-5448	Cup-Bearing	415-1922
7T-3038	Gear-Reverse	445-1097
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
7T-3194	Yoke	346-5681
7T-5426	Cone - Roller Brg	453-3657
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As.-Rlr	384-4823
7W-5164	Gasket	420-8568
8E-2043	Yoke As.	385-6115
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0313	Hub As.	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As.-Front	388-6604

8SG, 8ZK		
Original Part Number	Part Name	Classic Part Number
9R-1725	Bearing - Sleeve	425-6446
9R-1917	Bearing - Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As.	346-5692
9R-2480	Case As.	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-2601	Rod Gp-Tie	385-6133
9R-2842	Rod-Tie	385-6134
9R-2843	Rod-Tie	385-6135
9R-2846	Pin	346-5694
9R-2857	Rod-Piston	418-9588
9R-3527	Carrier-Planet	396-9892
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701

Sales Model 416B (Cont'd.)

8SG, 8ZK		
Original Part Number	**Part Name**	**Classic Part Number**
9R-7696	Pin	346-5705
9R-8199	Joint-Double	384-4813
9R-8231	Pad As.	397-5066
9R-8235	Pad As.	383-2106
9R-8579	Pin	346-5711
9R-8580	Pin As.	418-1932
9R-8663	Pin	365-8831
9R-8714	Fork	390-0929
9R-8715	Spider As.-Brg&	346-5716
9R-8718	Yoke As.	364-5258
9R-9190	Rod Gp-Tie	346-5718
9R-9400	Case As.	346-5719
9R-9402	Seal-Rax	347-0476
9R-9403	Pinion	347-0477
9R-9475	Bearing - Sleeve	380-7377
9R-9505	Bearing - Sleeve	453-6516
9R-9812	Pin	347-0468
9S-3581	Cup - Roller Brg	415-1923
9S-3582	Cone - Roller Brg	396-4144
9S-7949	Cup - Roller Brg	420-6531
9T-3948	Rod As.	393-0940
9Y-9431	Precleaner As.	361-1718
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

8SG, 8ZK		
Original Part Number	**Part Name**	**Classic Part Number**
030-1957	Cone-Bearing	420-2502
054-2213	Spider & Brg As.	347-0464
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As.	384-5959
101-3125	Gasket	420-8567
101-4020	Pin As.	396-7285
102-4560	Bearing - Sleeve	347-0469
107-3950	Head	383-1588
110-0013	Cup-Rlr Brg	384-5960
112-1773	Piston	347-0462
118-5839	Seal-Lip Type	435-8517
126-5984	Ring-Backup	419-4654
127-8592	Muffler As.	347-0463
127-8594	Muffler As.-Turbo	390-0981
128-4128	Rod Gp-Tie	385-6136
130-0479	Pin As.	415-1907
130-0485	Pin	396-7286
130-1637	Shaft	347-0471
134-2659	Rod As.	388-6568
135-8167	Pipe-Extension	395-1305
154-5279	Pin	392-4529
159-0961	Pin	396-7287
160-1014	Pin As.	347-0473
164-7174	Cyl Gp-0076-1067	423-7865
166-2142	Hub Gp-Shaft	394-8238
166-7870	Pad As.-Street	416-5515

8SG, 8ZK		
Original Part Number	**Part Name**	**Classic Part Number**
174-7432	Head	388-0660
186-4117	Carrier As.	394-8235
186-4118	Gear-Planet	347-0483
206-0502	Cylinder As..	423-7866
206-0503	Cyl Gp-0114-0695	426-0038
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing - Sleeve	453-6501
237-0944	Bearing - Sleeve	394-0194
237-2252	Bearing - Sleeve	347-0474
239-9956	Brake Disc	347-0485
251-7319	Bearing - Sleeve	425-6450
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing - Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As..	394-9813
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
8ZK		
4B-7270	Cone-Bearing	399-4439
6B-3223	Cup-Bearing	399-6065
6V-0347	Cone-Spl Tapered	420-6537

Sales Model 416C

1WR		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2G-7309	Shaft	393-3682
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812

1WR		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269

1WR		
Original Part Number	**Part Name**	**Classic Part Number**
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306

Sales Model 416C (Cont'd.)

1WR		
Original Part Number	Part Name	Classic Part Number
6D-1734	Cup-Roller Brg	416-2171
6F-6992	Cap-Ballsocket	297-7160
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
8D-7086	Bearing	330-9251
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8S-9151	Cup-Spl Tapered	374-8348
9M-1328	Bearing-Aligning	325-6018
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604
9R-1917	Bearing-Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693

1WR		
Original Part Number	Part Name	Classic Part Number
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8580	Pin As	418-1932
9R-8663	Pin	365-8831
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-3948	Rod As	393-0940
9T-5729	Cyl Gp-0038 0158	422-2486
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
107-8375	Shaft As	439-1134
111-4332	Plate	396-7290

1WR		
Original Part Number	Part Name	Classic Part Number
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
130-0479	Pin As	415-1907
130-0485	Pin	396-7286
130-1637	Shaft	347-0471
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0961	Pin	396-7287
160-1014	Pin As	347-0473
163-3749	Bearing-Sleeve	433-7505

Sales Model 416C (Cont'd.)

1WR		
Original Part Number	**Part Name**	**Classic Part Number**
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
172-2349	Cylinder As (Lh)	430-5958
173-1926	Cyl Gp-0102-0541	399-8576
173-1927	Cyl Gp-0102-0541	426-0036
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
184-9843	Head	347-0461
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957

1WR		
Original Part Number	**Part Name**	**Classic Part Number**
199-0760	Bearing-Roller	465-8981
206-0502	Cylinder As.	423-7866
206-0503	Cyl Gp-0114-0695	426-0038
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485

1WR		
Original Part Number	**Part Name**	**Classic Part Number**
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

1XR		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2G-7309	Shaft	393-3682
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6F-6992	Cap-Ballsocket	297-7160

1XR		
Original Part Number	**Part Name**	**Classic Part Number**
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
8D-7086	Bearing	330-9251
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384

1XR		
Original Part Number	**Part Name**	**Classic Part Number**
8D-9159	Bearing-Sleeve	472-8019
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604
9R-1917	Bearing-Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943

Sales Model 416C (Cont'd.)

1XR		
Original Part Number	Part Name	Classic Part Number
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8580	Pin As	418-1932
9R-8663	Pin	365-8831
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-3948	Rod As	393-0940
9T-5729	Cyl Gp-0038 0158	422-2486
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
107-8375	Shaft As	439-1134
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272

1XR		
Original Part Number	Part Name	Classic Part Number
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
130-0479	Pin As	415-1907
130-0485	Pin	396-7286
130-1637	Shaft	347-0471
130-1918	Pin As	393-0933
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0961	Pin	396-7287
160-1014	Pin As	347-0473
163-3749	Bearing-Sleeve	433-7505
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515

1XR		
Original Part Number	Part Name	Classic Part Number
168-0444	Pin	393-3687
172-2349	Cylinder As (Lh)	430-5958
173-1926	Cyl Gp-0102-0541	399-8576
173-1927	Cyl Gp-0102-0541	426-0036
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
184-9843	Head	347-0461
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
206-0502	Cylinder As.	423-7866
206-0503	Cyl Gp-0114-0695	426-0038
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153

Sales Model 416C (Cont'd.)

1XR		
Original Part Number	**Part Name**	**Classic Part Number**
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813

1XR		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

1XR		
Original Part Number	**Part Name**	**Classic Part Number**
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

4ZN		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2G-7309	Shaft	393-3682
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6D-1734	Cup-Roller Brg	416-2171
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8D-7086	Bearing	330-9251
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8S-9151	Cup-Spl Tapered	374-8348
9M-1328	Bearing-Aligning	325-6018

4ZN		
Original Part Number	**Part Name**	**Classic Part Number**
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604
9R-1917	Bearing-Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8580	Pin As	418-1932
9R-8663	Pin	365-8831
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-3948	Rod As	393-0940
9T-5729	Cyl Gp-0038 0158	422-2486

4ZN		
Original Part Number	**Part Name**	**Classic Part Number**
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
107-8375	Shaft As	439-1134
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
130-0479	Pin As	415-1907
130-0485	Pin	396-7286
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
134-2659	Rod As	388-6568

Sales Model 416C (Cont'd.)

4ZN		
Original Part Number	**Part Name**	**Classic Part Number**
135-8167	Pipe-Extension	395-1305
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0961	Pin	396-7287
160-1014	Pin As	347-0473
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
172-2349	Cylinder As (Lh)	430-5958
173-1926	Cyl Gp-0102-0541	399-8576
173-1927	Cyl Gp-0102-0541	426-0036
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
184-9843	Head	347-0461

4ZN		
Original Part Number	**Part Name**	**Classic Part Number**
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
199-0760	Bearing-Roller	465-8981
206-0502	Cylinder As.	423-7866
206-0503	Cyl Gp-0114-0695	426-0038
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194

4ZN		
Original Part Number	**Part Name**	**Classic Part Number**
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

5YN		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2G-7309	Shaft	393-3682
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654

5YN		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8D-7086	Bearing	330-9251
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320

5YN		
Original Part Number	**Part Name**	**Classic Part Number**
9R-1572	Wheel As-Front	388-6604
9R-1917	Bearing-Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8580	Pin As	418-1932

Sales Model 416C (Cont'd.)

5YN		
Original Part Number	**Part Name**	**Classic Part Number**
9R-8663	Pin	365-8831
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-3948	Rod As	393-0940
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
107-8375	Shaft As	439-1134
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481

5YN		
Original Part Number	**Part Name**	**Classic Part Number**
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
130-0479	Pin As	415-1907
130-0485	Pin	396-7286
130-1637	Shaft	347-0471
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0961	Pin	396-7287
160-1014	Pin As	347-0473
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
172-2349	Cylinder As (Lh)	430-5958
173-1926	Cyl Gp-0102-0541	399-8576
173-1927	Cyl Gp-0102-0541	426-0036
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
184-9843	Head	347-0461
186-4117	Carrier As	394-8235

5YN		
Original Part Number	**Part Name**	**Classic Part Number**
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
206-0502	Cylinder As.	423-7866
206-0503	Cyl Gp-0114-0695	426-0038
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

Sales Model 416D

B2D		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4576	Cup-Roller Brg	386-4944

Sales Model 416D (Cont'd.)

B2D		
Original Part Number	Part Name	Classic Part Number
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3G-2797	Bearing-Sleeve	360-2329
4T-8054	Seal As	472-8010
5F-8651	Bearing-Ball	420-3223
5L-9656	Cone-Bearing	399-4448
6D-1734	Cup-Roller Brg	416-2171
6Y-7652	Cup-Rlr Brg	399-6067
7J-8893	Cone-Roller Brg	374-1846
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377

B2D		
Original Part Number	Part Name	Classic Part Number
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9T-3948	Rod As	393-0940
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
112-1773	Piston	347-0462
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-5451	Pin	394-9816
135-8167	Pipe-Extension	395-1305
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-9843	Head	347-0461

B2D		
Original Part Number	Part Name	Classic Part Number
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
199-0760	Bearing-Roller	465-8981
206-0502	Cylinder As.	423-7866
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

BFP		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
2A-4576	Cup-Roller Brg	386-4944
2S-0479	Bearing-Cone	380-7506

BFP		
Original Part Number	Part Name	Classic Part Number
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448

BFP		
Original Part Number	Part Name	Classic Part Number
5P-9439	Bearing-Spl Ball	371-4306
6D-1734	Cup-Roller Brg	416-2171
6S-3051	Cup-Rlr Brg	415-1928

Sales Model 416D (Cont'd.)

BFP		
Original Part Number	Part Name	Classic Part Number
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8S-9151	Cup-Spl Tapered	374-8348
9J-5875	Bearing-Sleeve	308-9830
9M-1328	Bearing-Aligning	325-6018
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-0424	Pin	346-5686
9R-1917	Bearing-Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-3948	Rod As	393-0940
9T-5729	Cyl Gp-0038 0158	422-2486
005-0469	Cup-Rlr Bearing	418-9610

BFP		
Original Part Number	Part Name	Classic Part Number
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
130-0485	Pin	396-7286
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0961	Pin	396-7287
160-1014	Pin As	347-0473
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
183-2358	Bearing	425-3588

BFP		
Original Part Number	Part Name	Classic Part Number
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
199-0760	Bearing-Roller	465-8981
206-0502	Cylinder As.	423-7866
206-0503	Cyl Gp-0114-0695	426-0038
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 416D (Cont'd.)

BGJ, BKG		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6D-1734	Cup-Roller Brg	416-2171
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-0424	Pin	346-5686
9R-1917	Bearing-Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468

BGJ, BKG		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-3948	Rod As	393-0940
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
130-0485	Pin	396-7286
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0961	Pin	396-7287

BGJ, BKG		
Original Part Number	Part Name	Classic Part Number
160-1014	Pin As	347-0473
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
199-0760	Bearing-Roller	465-8981
206-0502	Cylinder As.	423-7866
206-0503	Cyl Gp-0114-0695	426-0038
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813

Sales Model 416D (Cont'd.)

BGJ, BKG		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

BGJ, BKG		
Original Part Number	**Part Name**	**Classic Part Number**
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915
BGJ		

BGJ, BKG		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7929	Disc-Friction	456-0555
9R-0437	Pin	389-6320

CHW, CKN		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9T-3948	Rod As	393-0940
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
122-1881	Plate-Clutch	347-0475

CHW, CKN		
Original Part Number	**Part Name**	**Classic Part Number**
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-5451	Pin	394-9816
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
199-0760	Bearing-Roller	465-8981
206-0502	Cylinder As.	423-7866
206-0503	Cyl Gp-0114-0695	426-0038

CHW, CKN		
Original Part Number	**Part Name**	**Classic Part Number**
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

CXP		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4576	Cup-Roller Brg	386-4944
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812

CXP		
Original Part Number	**Part Name**	**Classic Part Number**
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6D-1734	Cup-Roller Brg	416-2171

CXP		
Original Part Number	**Part Name**	**Classic Part Number**
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
7T-6652	Cone-Rlr Bearing	416-2124

Sales Model 416D (Cont'd.)

CXP		
Original Part Number	Part Name	Classic Part Number
7T-7621	Bearing As-Rlr	384-4823
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-9403	Pinion	347-0477
9T-3948	Rod As	393-0940
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502

CXP		
Original Part Number	Part Name	Classic Part Number
055-1986	Seal-Lip Type	347-0465
102-4560	Bearing-Sleeve	347-0469
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482

CXP		
Original Part Number	Part Name	Classic Part Number
135-8167	Pipe-Extension	395-1305
178-8608	Cone	422-6479
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
209-9886	Tie Rod As	396-9901
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
239-9956	Brake Disc	347-0485
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 416E

BWC		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9T-3948	Rod As	393-0940
9W-9931	Mount As.	360-2354

BWC		
Original Part Number	Part Name	Classic Part Number
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469
110-1337	Ring Kit-Pstn	377-5834
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
130-5451	Pin	394-9816
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513

BWC		
Original Part Number	Part Name	Classic Part Number
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 416E (Cont'd.)

CBD		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
3G-2797	Bearing-Sleeve	360-2329
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
5F-8651	Bearing-Ball	420-3223
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
8N-3666	Repair Kt-Major	377-5842
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-8579	Pin	346-5711
9R-9505	Bearing-Sleeve	453-6516
9T-3948	Rod As	393-0940
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610

CBD		
Original Part Number	Part Name	Classic Part Number
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
102-4560	Bearing-Sleeve	347-0469
110-1337	Ring Kit-Pstn	377-5834
112-1773	Piston	347-0462
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-5451	Pin	394-9816
135-8167	Pipe-Extension	395-1305
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479

CBD		
Original Part Number	Part Name	Classic Part Number
184-9843	Head	347-0461
187-3827	Pad As.	397-5057
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

LMS		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9T-3948	Rod As	393-0940

LMS		
Original Part Number	Part Name	Classic Part Number
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469
110-1337	Ring Kit-Pstn	377-5834
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
130-5451	Pin	394-9816
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515

LMS		
Original Part Number	Part Name	Classic Part Number
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813

Sales Model 416E (Cont'd.)

LMS		
Original Part Number	Part Name	Classic Part Number
331-8538	Seal-Wheel	391-9874

LMS		
Original Part Number	Part Name	Classic Part Number
392-6301	Kit-Spider & Brg	390-0915

MFG		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-9505	Bearing-Sleeve	453-6516
9T-3948	Rod As	393-0940
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610

MFG		
Original Part Number	Part Name	Classic Part Number
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
102-4560	Bearing-Sleeve	347-0469
110-1337	Ring Kit-Pstn	377-5834
112-1773	Piston	347-0462
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
130-5451	Pin	394-9816
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513

MFG		
Original Part Number	Part Name	Classic Part Number
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

NBE		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9T-3948	Rod As	393-0940
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610

NBE		
Original Part Number	Part Name	Classic Part Number
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
130-5451	Pin	394-9816
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
178-8608	Cone	422-6479

NBE		
Original Part Number	Part Name	Classic Part Number
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
237-0944	Bearing-Sleeve	394-0194
262-7044	Bearing	418-1948
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 416E (Cont'd.)

SHA		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-8579	Pin	346-5711
9R-9505	Bearing-Sleeve	453-6516
9T-3948	Rod As	393-0940
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

SHA		
Original Part Number	**Part Name**	**Classic Part Number**
100-6267	Plate As-Idler	375-9983
102-4560	Bearing-Sleeve	347-0469
110-1337	Ring Kit-Pstn	377-5834
112-1773	Piston	347-0462
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-5451	Pin	394-9816
135-8167	Pipe-Extension	395-1305
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513

SHA		
Original Part Number	**Part Name**	**Classic Part Number**
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 416F

HWB		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
6D-1734	Cup-Roller Brg	416-2171
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

HWB		
Original Part Number	**Part Name**	**Classic Part Number**
130-1637	Shaft	347-0471
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981

HWB		
Original Part Number	**Part Name**	**Classic Part Number**
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

KSF		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955

Sales Model 416F (Cont'd.)

KSF		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471

KSF		
Original Part Number	Part Name	Classic Part Number
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194

KSF		
Original Part Number	Part Name	Classic Part Number
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

LBF		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
4T-0732	Bracket	314-8627
6D-1734	Cup-Roller Brg	416-2171
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610

LBF		
Original Part Number	Part Name	Classic Part Number
005-0471	Cone-Spl Tapered	415-1924
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687

LBF		
Original Part Number	Part Name	Classic Part Number
179-6152	Bearing	361-1704
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
392-6301	Kit-Spider & Brg	390-0915

LWT		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
122-6787	Yoke As	416-2139

LWT		
Original Part Number	Part Name	Classic Part Number
130-1637	Shaft	347-0471
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024

LWT		
Original Part Number	Part Name	Classic Part Number
237-0944	Bearing-Sleeve	394-0194
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 416F (Cont'd.)

LYA		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
6D-1734	Cup-Roller Brg	416-2171
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

LYA		
Original Part Number	**Part Name**	**Classic Part Number**
130-1637	Shaft	347-0471
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981

LYA		
Original Part Number	**Part Name**	**Classic Part Number**
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 420D

BKC		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2G-7309	Shaft	393-3682
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6D-1734	Cup-Roller Brg	416-2171
6F-6992	Cap-Ballsocket	297-7160
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8D-7086	Bearing	330-9251
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384

BKC		
Original Part Number	**Part Name**	**Classic Part Number**
8D-9159	Bearing-Sleeve	472-8019
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1917	Bearing-Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468

BKC		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
107-8375	Shaft As	439-1134
112-1773	Piston	347-0462
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139

Sales Model 420D (Cont'd.)

BKC		
Original Part Number	Part Name	Classic Part Number
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
130-0485	Pin	396-7286
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0961	Pin	396-7287
160-1014	Pin As	347-0473
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513

BKC		
Original Part Number	Part Name	Classic Part Number
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
184-9843	Head	347-0461
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
199-0760	Bearing-Roller	465-8981
206-0502	Cylinder As.	423-7866
206-0503	Cyl Gp-0114-0695	426-0038
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501

BKC		
Original Part Number	Part Name	Classic Part Number
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

BLN, BMC		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3E-6772	Seal-Water	382-8017
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4T-8054	Seal As	472-8010
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5J-7010	Seal As	472-8011

BLN, BMC		
Original Part Number	Part Name	Classic Part Number
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6D-1734	Cup-Roller Brg	416-2171
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7C-0307	Gasket	399-8571
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488

BLN, BMC		
Original Part Number	Part Name	Classic Part Number
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
7W-1713	Core Gp-O Clr	438-2010
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
9F-3212	Bearing-Ball	384-5953
9N-3167	Plate-Block Bot	430-4468

Sales Model 420D (Cont'd.)

BLN, BMC		
Original Part Number	Part Name	Classic Part Number
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-0424	Pin	346-5686
9R-1917	Bearing-Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-3125	Gasket	420-8567
101-4020	Pin As	396-7285
101-9640	Gear-Air Compr	398-2966
102-4560	Bearing-Sleeve	347-0469
108-7930	Bearing As	377-7463
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462

BLN, BMC		
Original Part Number	Part Name	Classic Part Number
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
128-4128	Rod Gp-Tie	385-6136
129-9907	Impeller-Pump	383-1589
130-0485	Pin	396-7286
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
134-2659	Rod As	388-6568
135-4928	Shaft-Water Pump	386-3813
135-8167	Pipe-Extension	395-1305
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
148-2593	Head	383-1591
151-5349	Head	383-1592
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0961	Pin	396-7287

BLN, BMC		
Original Part Number	Part Name	Classic Part Number
160-1014	Pin As	347-0473
160-9874	Kit-Gasket-Scl	386-3048
164-7174	Cyl Gp-0076-1067	423-7865
166-6352	Tube As.	432-4223
166-7870	Pad As-Street	416-5515
167-8126	Damper As	382-8019
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
186-2001	Rotocoil As	397-5055
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
187-8979	Gear As	393-3656
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
199-0760	Bearing-Roller	465-8981
202-3572	Shaft As-Drive	426-0037
206-0502	Cylinder As.	423-7866
206-0503	Cyl Gp-0114-0695	426-0038
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.- Track	347-0486
229-2950	Rod As.- Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
243-6718	Kit-Brg(Main)	469-1690
251-7319	Bearing-Sleeve	425-6450
253-1752	Plate-Thrust	379-0170

Sales Model 420D (Cont'd.)

BLN, BMC		
Original Part Number	**Part Name**	**Classic Part Number**
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1365	Arm As-Ui Rkr	433-7507
278-1972	Cylinder As.	394-9813

BLN, BMC		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
331-8538	Seal-Wheel	391-9874

BLN, BMC		
Original Part Number	**Part Name**	**Classic Part Number**
392-6301	Kit-Spider & Brg	390-0915
430-7619	Adapter-Cla	438-1812
BLN		
1S-7056	Bearing-Ball	422-6483
9T-5729	Cyl Gp-0038 0158	422-2486
BMC		
9R-0437	Pin	389-6320
130-1918	Pin As	393-0933

C2C, C8A		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4924	Mounting As	391-9812
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
112-1773	Piston	347-0462
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286
130-1637	Shaft	347-0471

C2C, C8A		
Original Part Number	**Part Name**	**Classic Part Number**
130-2533	Pin	396-7265
130-5451	Pin	394-9816
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
199-0760	Bearing-Roller	465-8981
206-0502	Cylinder As.	423-7866
206-0503	Cyl Gp-0114-0695	426-0038
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658

C2C, C8A		
Original Part Number	**Part Name**	**Classic Part Number**
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915
C8A		
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
125-1037	Pin As	375-9985
148-2593	Head	383-1591

FDP		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483

Sales Model 420D (Cont'd.)

FDP		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2G-7309	Shaft	393-3682
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6D-1734	Cup-Roller Brg	416-2171
6F-6992	Cap-Ballsocket	297-7160
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7J-5131	Trunnion	296-1371
7K-0078	Bearing-Sleeve	308-9825
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8D-7086	Bearing	330-9251
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8S-9151	Cup-Spl Tapered	374-8348
9J-5875	Bearing-Sleeve	308-9830
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-0424	Pin	346-5686
9R-1917	Bearing-Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505

FDP		
Original Part Number	Part Name	Classic Part Number
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
107-8375	Shaft As	439-1134
112-1773	Piston	347-0462
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
130-0485	Pin	396-7286
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
134-2659	Rod As	388-6568

FDP		
Original Part Number	Part Name	Classic Part Number
135-8167	Pipe-Extension	395-1305
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0961	Pin	396-7287
160-1014	Pin As	347-0473
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
184-9843	Head	347-0461
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
199-0760	Bearing-Roller	465-8981
206-0502	Cylinder As.	423-7866
206-0503	Cyl Gp-0114-0695	426-0038
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.- Track	347-0486
229-2950	Rod As.- Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896

Sales Model 420D (Cont'd.)

FDP		
Original Part Number	**Part Name**	**Classic Part Number**
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813

FDP		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

FDP		
Original Part Number	**Part Name**	**Classic Part Number**
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

MBH		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3E-6772	Seal-Water	382-8017
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5L-9656	Cone-Bearing	399-4448
6D-1734	Cup-Roller Brg	416-2171
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7C-0307	Gasket	399-8571
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7T-6652	Cone-Rlr Bearing	416-2124

MBH		
Original Part Number	**Part Name**	**Classic Part Number**
7T-7621	Bearing As-Rlr	384-4823
7W-1713	Core Gp-O Clr	438-2010
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
9F-3212	Bearing-Ball	384-5953
9N-3167	Plate-Block Bot	430-4468
9R-0424	Pin	346-5686
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-1957	Cone-Bearing	420-2502
101-3125	Gasket	420-8567
101-4020	Pin As	396-7285
101-9640	Gear-Air Compr	398-2966
102-4560	Bearing-Sleeve	347-0469
108-7930	Bearing As	377-7463
111-4332	Plate	396-7290
111-4340	Pin	451-1512

MBH		
Original Part Number	**Part Name**	**Classic Part Number**
111-4343	Pin	390-5272
112-1773	Piston	347-0462
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-0485	Pin	396-7286
130-5451	Pin	394-9816
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0961	Pin	396-7287
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
166-7870	Pad As-Street	416-5515
167-8126	Damper As	382-8019
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956

Sales Model 420D (Cont'd.)

MBH		
Original Part Number	**Part Name**	**Classic Part Number**
178-8608	Cone	422-6479
186-2001	Rotocoil As	397-5055
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
206-0502	Cylinder As.	423-7866
209-9886	Tie Rod As	396-9901
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501

MBH		
Original Part Number	**Part Name**	**Classic Part Number**
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
243-6718	Kit-Brg(Main)	469-1690
251-7319	Bearing-Sleeve	425-6450
253-1752	Plate-Thrust	379-0170
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554

MBH		
Original Part Number	**Part Name**	**Classic Part Number**
278-1365	Arm As-Ui Rkr	433-7507
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915
430-7619	Adapter-Cla	438-1812

Sales Model 420E

DAN		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469

DAN		
Original Part Number	**Part Name**	**Classic Part Number**
110-1337	Ring Kit-Pstn	377-5834
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
130-1637	Shaft	347-0471
130-5451	Pin	394-9816
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981

DJL		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955

DAN		
Original Part Number	**Part Name**	**Classic Part Number**
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 420E (Cont'd.)

DJL		
Original Part Number	Part Name	Classic Part Number
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469

DJL		
Original Part Number	Part Name	Classic Part Number
110-1337	Ring Kit-Pstn	377-5834
112-1773	Piston	347-0462
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
130-5451	Pin	394-9816
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952

DJL		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

GAN		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
102-4560	Bearing-Sleeve	347-0469
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272

GAN		
Original Part Number	Part Name	Classic Part Number
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
130-5451	Pin	394-9816
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194

GAN		
Original Part Number	Part Name	Classic Part Number
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

GEK		
Original Part Number	Part Name	Classic Part Number
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353

GEK		
Original Part Number	Part Name	Classic Part Number
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354

GEK		
Original Part Number	Part Name	Classic Part Number
102-4560	Bearing-Sleeve	347-0469
110-1337	Ring Kit-Pstn	377-5834
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272

Sales Model 420E (Cont'd.)

GEK		
Original Part Number	Part Name	Classic Part Number
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
130-5451	Pin	394-9816
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901

GEK		
Original Part Number	Part Name	Classic Part Number
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153

GEK		
Original Part Number	Part Name	Classic Part Number
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

HLS		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-8579	Pin	346-5711
9R-9505	Bearing-Sleeve	453-6516
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983

HLS		
Original Part Number	Part Name	Classic Part Number
102-4560	Bearing-Sleeve	347-0469
110-1337	Ring Kit-Pstn	377-5834
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-5451	Pin	394-9816
135-8167	Pipe-Extension	395-1305
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687

HLS		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

KMW		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433

KMW		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353

KMW		
Original Part Number	Part Name	Classic Part Number
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842

Sales Model 420E (Cont'd.)

KMW		
Original Part Number	Part Name	Classic Part Number
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-8579	Pin	346-5711
9R-9505	Bearing-Sleeve	453-6516
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
102-4560	Bearing-Sleeve	347-0469
110-1337	Ring Kit-Pstn	377-5834
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693

KMW		
Original Part Number	Part Name	Classic Part Number
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-5451	Pin	394-9816
135-8167	Pipe-Extension	395-1305
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952

KMW		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

PHC		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469

PHC		
Original Part Number	Part Name	Classic Part Number
110-1337	Ring Kit-Pstn	377-5834
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
130-1637	Shaft	347-0471
130-5451	Pin	394-9816
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981

PHC		
Original Part Number	Part Name	Classic Part Number
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Backhoe Loaders

Sales Model 420E (Cont'd.)

PRA		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

PRA		
Original Part Number	Part Name	Classic Part Number
102-4560	Bearing-Sleeve	347-0469
110-1337	Ring Kit-Pstn	377-5834
112-1773	Piston	347-0462
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
130-5451	Pin	394-9816
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901

PRA		
Original Part Number	Part Name	Classic Part Number
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 420F

HWC		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

HWC		
Original Part Number	Part Name	Classic Part Number
102-4560	Bearing-Sleeve	347-0469
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981

HWC		
Original Part Number	Part Name	Classic Part Number
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

HWD		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433
6D-1734	Cup-Roller Brg	416-2171

HWD		
Original Part Number	Part Name	Classic Part Number
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354

HWD		
Original Part Number	Part Name	Classic Part Number
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469

Sales Model 420F (Cont'd.)

HWD		
Original Part Number	Part Name	Classic Part Number
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515

HWD		
Original Part Number	Part Name	Classic Part Number
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024

HWD		
Original Part Number	Part Name	Classic Part Number
237-0944	Bearing-Sleeve	394-0194
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

JWJ		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

JWJ		
Original Part Number	Part Name	Classic Part Number
102-4560	Bearing-Sleeve	347-0469
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981

JWJ		
Original Part Number	Part Name	Classic Part Number
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

LBS		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433
4T-0732	Bracket	314-8627
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610

LBS		
Original Part Number	Part Name	Classic Part Number
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515

LBS		
Original Part Number	Part Name	Classic Part Number
179-6152	Bearing	361-1704
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
392-6301	Kit-Spider & Brg	390-0915

LKH		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
4T-8054	Seal As	472-8010

LKH		
Original Part Number	Part Name	Classic Part Number
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555

LKH		
Original Part Number	Part Name	Classic Part Number
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686

Sales Model 420F (Cont'd.)

LKH		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
154-5278	Pin	393-3685

LKH		
Original Part Number	**Part Name**	**Classic Part Number**
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952

LKH		
Original Part Number	**Part Name**	**Classic Part Number**
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

LTG		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469

LTG		
Original Part Number	**Part Name**	**Classic Part Number**
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024

LTG		
Original Part Number	**Part Name**	**Classic Part Number**
237-0944	Bearing-Sleeve	394-0194
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

LYB		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

LYB		
Original Part Number	**Part Name**	**Classic Part Number**
102-4560	Bearing-Sleeve	347-0469
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981

LYB		
Original Part Number	**Part Name**	**Classic Part Number**
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 420F (Cont'd.)

LYC		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

LYC		
Original Part Number	Part Name	Classic Part Number
102-4560	Bearing-Sleeve	347-0469
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981

LYC		
Original Part Number	Part Name	Classic Part Number
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

SKR		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469

SKR		
Original Part Number	Part Name	Classic Part Number
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024

SKR		
Original Part Number	Part Name	Classic Part Number
237-0944	Bearing-Sleeve	394-0194
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 422E

DSK		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555

DSK		
Original Part Number	Part Name	Classic Part Number
6Y-9930	Mount As	360-2353
9R-0437	Pin	389-6320
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9T-3948	Rod As	393-0940
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

DSK		
Original Part Number	Part Name	Classic Part Number
102-4560	Bearing-Sleeve	347-0469
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
130-5451	Pin	394-9816
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868

Sales Model 422E (Cont'd.)

DSK		
Original Part Number	**Part Name**	**Classic Part Number**
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981

DSK		
Original Part Number	**Part Name**	**Classic Part Number**
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660

DSK		
Original Part Number	**Part Name**	**Classic Part Number**
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

HBE		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842
9R-0097	Pin	346-5684
9R-0437	Pin	389-6320
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9T-3948	Rod As	393-0940
9W-9931	Mount As.	360-2354

HBE		
Original Part Number	**Part Name**	**Classic Part Number**
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469
110-1337	Ring Kit-Pstn	377-5834
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
130-5451	Pin	394-9816
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496

HBE		
Original Part Number	**Part Name**	**Classic Part Number**
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

MAW		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9T-3948	Rod As	393-0940
9W-9931	Mount As.	360-2354

MAW		
Original Part Number	**Part Name**	**Classic Part Number**
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515

MAW		
Original Part Number	**Part Name**	**Classic Part Number**
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
269-0381	Cyl Gp-100 254 X	393-3660

Sales Model 422E (Cont'd.)

MAW		
Original Part Number	Part Name	Classic Part Number
274-4274	Bearing-Sleeve	391-9896

MAW		
Original Part Number	Part Name	Classic Part Number
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874

MAW		
Original Part Number	Part Name	Classic Part Number
392-6301	Kit-Spider & Brg	390-0915

Sales Model 422F

LRH		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
6D-1734	Cup - Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As.	360-2353
9W-9931	Mount As..	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
122-6787	Yoke As.	416-2139

LRH		
Original Part Number	Part Name	Classic Part Number
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As.-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As.	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981

LRH		
Original Part Number	Part Name	Classic Part Number
209-9886	Tie Rod As.	396-9901
210-7305	Shaft	396-9952
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing - Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

LYF		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
6D-1734	Cup - Roller Brg	416-2171
6Y-9930	Mount As.	360-2353
9W-9931	Mount As..	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
154-5279	Pin	392-4529

LYF		
Original Part Number	Part Name	Classic Part Number
154-5280	Pin	391-9868
166-7870	Pad As.-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As.	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981

LYF		
Original Part Number	Part Name	Classic Part Number
209-9886	Tie Rod As.	396-9901
210-7305	Shaft	396-9952
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing - Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 424

JRB		
Original Part Number	Part Name	Classic Part Number
3E-4924	Mounting As.	391-9812
5J-7010	Seal As.	472-8011
6D-1734	Cup - Roller Brg	416-2171
9R-0097	Pin	346-5684

JRB		
Original Part Number	Part Name	Classic Part Number
9R-0313	Hub As.	388-6591
9R-1917	Bearing - Sleeve	418-1958
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711

JRB		
Original Part Number	Part Name	Classic Part Number
9R-8663	Pin	365-8831
9R-9475	Bearing - Sleeve	380-7377
9R-9505	Bearing - Sleeve	453-6516

Sales Model 424 (Cont'd.)

JRB		
Original Part Number	Part Name	Classic Part Number
9R-9812	Pin	347-0468
9S-3581	Cup - Roller Brg	415-1923
9S-3582	Cone - Roller Brg	396-4144
9S-7949	Cup - Roller Brg	420-6531
9T-3948	Rod As.	393-0940
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing - Sleeve	347-0469
112-1773	Piston	347-0462
112-5089	Muffler As.-NA	390-0982
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As.	416-2139
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
130-0485	Pin	396-7286

JRB		
Original Part Number	Part Name	Classic Part Number
130-5451	Pin	394-9816
134-2659	Rod As.	388-6568
135-8167	Pipe-Extension	395-1305
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0961	Pin	396-7287
160-1014	Pin As.	347-0473
174-7432	Head	388-0660
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
184-1413	Pin As.	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
199-0760	Bearing-Roller	465-8981
209-6188	Plate	393-1053
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024

JRB		
Original Part Number	Part Name	Classic Part Number
235-9832	Head	419-4658
236-8183	Bearing - Sleeve	453-6501
237-0944	Bearing - Sleeve	394-0194
237-2252	Bearing - Sleeve	347-0474
251-7319	Bearing - Sleeve	425-6450
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing - Sleeve	391-9896
278-1972	Cylinder As..	394-9813
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 424B

JRC		
Original Part Number	Part Name	Classic Part Number
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
6D-1734	Cup-Roller Brg	416-2171
9R-0313	Hub As	388-6591
9R-1917	Bearing-Sleeve	418-1958
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9475	Bearing-Sleeve	380-7377
9R-9812	Pin	347-0468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

JRC		
Original Part Number	Part Name	Classic Part Number
9S-7949	Cup-Roller Brg	420-6531
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
054-2213	Spider & Brg As	347-0464
102-4560	Bearing-Sleeve	347-0469
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
130-0485	Pin	396-7286
130-5451	Pin	394-9816
151-5349	Head	383-1592
154-5278	Pin	393-3685

JRC		
Original Part Number	Part Name	Classic Part Number
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0961	Pin	396-7287
160-1014	Pin As	347-0473
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981
209-6188	Plate	393-1053
210-7305	Shaft	396-9952
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
251-7319	Bearing-Sleeve	425-6450

Sales Model 424B (Cont'd.)

JRC		
Original Part Number	Part Name	Classic Part Number
274-4274	Bearing-Sleeve	391-9896

JRC		
Original Part Number	Part Name	Classic Part Number
331-8538	Seal-Wheel	391-9874

JRC		
Original Part Number	Part Name	Classic Part Number
392-6301	Kit-Spider & Brg	390-0915

JRN		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
9R-8663	Pin	365-8831
9R-9475	Bearing-Sleeve	380-7377
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

JRN		
Original Part Number	Part Name	Classic Part Number
9S-7949	Cup-Roller Brg	420-6531
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
054-2213	Spider & Brg As	347-0464
130-5451	Pin	394-9816

JRN		
Original Part Number	Part Name	Classic Part Number
154-5279	Pin	392-4529
154-5280	Pin	391-9868
183-2358	Bearing	425-3588
236-8183	Bearing-Sleeve	453-6501
237-2252	Bearing-Sleeve	347-0474
331-8538	Seal-Wheel	391-9874

JRY		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
9R-8663	Pin	365-8831
9R-9475	Bearing-Sleeve	380-7377
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531

JRY		
Original Part Number	Part Name	Classic Part Number
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
054-2213	Spider & Brg As	347-0464
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
130-5451	Pin	394-9816
154-5279	Pin	392-4529

JRY		
Original Part Number	Part Name	Classic Part Number
154-5280	Pin	391-9868
183-2358	Bearing	425-3588
236-8183	Bearing-Sleeve	453-6501
237-2252	Bearing-Sleeve	347-0474
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 424D

BGP		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448

BGP		
Original Part Number	Part Name	Classic Part Number
5P-9439	Bearing-Spl Ball	371-4306
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823

BGP		
Original Part Number	Part Name	Classic Part Number
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-1917	Bearing-Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690

Sales Model 424D (Cont'd.)

BGP		
Original Part Number	Part Name	Classic Part Number
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-3948	Rod As	393-0940
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574

BGP		
Original Part Number	Part Name	Classic Part Number
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
130-0485	Pin	396-7286
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
160-1014	Pin As	347-0473
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
184-1413	Pin As	393-1050
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054

BGP		
Original Part Number	Part Name	Classic Part Number
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
251-7319	Bearing-Sleeve	425-6450
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

BKR		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2S-0479	Bearing-Cone	380-7506

BKR		
Original Part Number	Part Name	Classic Part Number
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448

BKR		
Original Part Number	Part Name	Classic Part Number
5P-9439	Bearing-Spl Ball	371-4306
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654

Sales Model 424D (Cont'd.)

BKR		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-1917	Bearing-Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-3948	Rod As	393-0940
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

BKR		
Original Part Number	Part Name	Classic Part Number
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
130-0485	Pin	396-7286
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
160-1014	Pin As	347-0473
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513

BKR		
Original Part Number	Part Name	Classic Part Number
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
184-1413	Pin As	393-1050
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
251-7319	Bearing-Sleeve	425-6450
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

Sales Model 424D (Cont'd.)

CJZ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3E-6772	Seal-Water	382-8017
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4T-8054	Seal As	472-8010
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
6D-1734	Cup-Roller Brg	416-2171
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724

CJZ		
Original Part Number	**Part Name**	**Classic Part Number**
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
7W-1713	Core Gp-O Clr	438-2010
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
9F-3212	Bearing-Ball	384-5953
9N-3167	Plate-Block Bot	430-4468
9R-0097	Pin	346-5684
9R-0437	Pin	389-6320
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9T-3948	Rod As	393-0940
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
101-3125	Gasket	420-8567
101-4020	Pin As	396-7285
101-9640	Gear-Air Compr	398-2966

CJZ		
Original Part Number	**Part Name**	**Classic Part Number**
102-4560	Bearing-Sleeve	347-0469
108-7930	Bearing As	377-7463
112-1773	Piston	347-0462
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-0485	Pin	396-7286
130-5451	Pin	394-9816
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
134-2659	Rod As	388-6568
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
151-5349	Head	383-1592
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
160-9874	Kit-Gasket-Scl	386-3048
164-7174	Cyl Gp-0076-1067	423-7865

Sales Model 424D (Cont'd.)

CJZ		
Original Part Number	Part Name	Classic Part Number
166-6352	Tube As.	432-4223
166-7870	Pad As-Street	416-5515
167-8126	Damper As	382-8019
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
186-2001	Rotocoil As	397-5055
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
187-8979	Gear As	393-3656
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
202-3572	Shaft As-Drive	426-0037

CJZ		
Original Part Number	Part Name	Classic Part Number
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
243-6718	Kit-Brg(Main)	469-1690
251-7319	Bearing-Sleeve	425-6450
253-1752	Plate-Thrust	379-0170
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896

CJZ		
Original Part Number	Part Name	Classic Part Number
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1365	Arm As-Ui Rkr	433-7507
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915
430-7619	Adapter-Cla	438-1812

RXA		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
6D-1734	Cup-Roller Brg	416-2171
6Y-7652	Cup-Rlr Brg	399-6067
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0437	Pin	389-6320

RXA		
Original Part Number	Part Name	Classic Part Number
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9T-3948	Rod As	393-0940

RXA		
Original Part Number	Part Name	Classic Part Number
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
112-1773	Piston	347-0462
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286
130-5451	Pin	394-9816

Sales Model 424D (Cont'd.)

RXA		
Original Part Number	Part Name	Classic Part Number
134-2659	Rod As	388-6568
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054

RXA		
Original Part Number	Part Name	Classic Part Number
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485

RXA		
Original Part Number	Part Name	Classic Part Number
251-7319	Bearing-Sleeve	425-6450
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

S5A		
Original Part Number	Part Name	Classic Part Number
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
6D-1734	Cup-Roller Brg	416-2171
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9T-3948	Rod As	393-0940
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469

S5A		
Original Part Number	Part Name	Classic Part Number
107-3950	Head	383-1588
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286
130-2533	Pin	396-7265
130-5451	Pin	394-9816
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479

S5A		
Original Part Number	Part Name	Classic Part Number
184-1413	Pin As	393-1050
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
199-0760	Bearing-Roller	465-8981
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660

Sales Model 424D (Cont'd.)

S5A		
Original Part Number	Part Name	Classic Part Number
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813

S5A		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

S5A		
Original Part Number	Part Name	Classic Part Number
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 426

7BC		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup - Roller Brg	423-7759
1P-7115	Mount As.	418-1936
1S-7057	Gasket	420-6384
2A-4576	Cup - Roller Brg	386-4944
2B-0941	Spacer	418-1955
2S-0479	Bearing-Cone	380-7506
3E-6772	Seal-Water	382-8017
4T-8054	Seal As.	472-8010
5J-7010	Seal As.	472-8011
5L-9656	Cone-Bearing	399-4448
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7K-5448	Cup-Bearing	415-1922
7T-3038	Gear-Reverse	445-1097
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
7T-3194	Yoke	346-5681
7T-5426	Cone - Roller Brg	453-3657
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As.-Rlr	384-4823
7W-5164	Gasket	420-8568
7W-5194	Muffler As..	346-5682
8E-2043	Yoke As.	385-6115
8S-9151	Cup-Spl Tapered	374-8348

7BC		
Original Part Number	Part Name	Classic Part Number
9K-5639	Pin	425-6451
9L-2685	Rod End	419-1866
9R-0080	Coupling	346-5683
9R-0097	Pin	346-5684
9R-0313	Hub As.	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As.-Front	388-6604
9R-1725	Bearing - Sleeve	425-6446
9R-1917	Bearing - Sleeve	418-1958
9R-2410	Retainer As..	346-5688
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2476	Disc-Bk Rear	346-5691
9R-2477	Disc As.	346-5692
9R-2480	Case As.	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-2601	Rod Gp-Tie	385-6133
9R-2842	Rod-Tie	385-6134
9R-2843	Rod-Tie	385-6135
9R-2846	Pin	346-5694
9R-2857	Rod-Piston	418-9588
9R-3527	Carrier-Planet	396-9892
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-6475	Pad As.	346-5702
9R-8199	Joint-Double	384-4813
9R-8714	Fork	390-0929

7BC		
Original Part Number	Part Name	Classic Part Number
9R-8715	Spider As.-Brg&	346-5716
9R-8718	Yoke As.	364-5258
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9S-3581	Cup - Roller Brg	415-1923
9S-3582	Cone - Roller Brg	396-4144
9S-7949	Cup - Roller Brg	420-6531
9Y-9431	Precleaner As.	361-1718
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
054-2213	Spider & Brg As.	347-0464
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As.	384-5959
055-1260	Housing Bk-Outer	347-0479
101-3125	Gasket	420-8567
118-5839	Seal-Lip Type	435-8517
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
130-1637	Shaft	347-0471
160-1014	Pin As.	347-0473
166-7870	Pad As.-Street	416-5515
186-4117	Carrier As.	394-8235

Sales Model 426 (Cont'd.)

7BC		
Original Part Number	**Part Name**	**Classic Part Number**
186-4118	Gear-Planet	347-0483
226-8202	Seal-Wiper	472-8024

7BC		
Original Part Number	**Part Name**	**Classic Part Number**
274-4553	Disc-Clutch	416-2153
289-2935	Seal As.-Buffer	472-8028

7BC		
Original Part Number	**Part Name**	**Classic Part Number**
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 426B

5YJ		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
1S-7057	Gasket	420-6384
2A-4576	Cup - Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9191	Cone - Roller Brg	374-1837
2S-0479	Bearing-Cone	380-7506
3E-4903	Mount As.	396-7274
3P-1210	Cone - Roller Brg	399-4433
4T-8054	Seal As.	472-8010
5L-9656	Cone-Bearing	399-4448
6E-0775	Head	425-9373
6E-6153	Plate-Port	346-5678
6E-6163	Shaft	346-5679
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7C-4349	Mount As.	383-2117
7K-5448	Cup-Bearing	415-1922
7T-3038	Gear-Reverse	445-1097
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
7T-3194	Yoke	346-5681
7T-5426	Cone - Roller Brg	453-3657
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As.-Rlr	384-4823
7W-5164	Gasket	420-8568

5YJ		
Original Part Number	**Part Name**	**Classic Part Number**
8E-2043	Yoke As.	385-6115
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0313	Hub As.	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As.-Front	388-6604
9R-1725	Bearing - Sleeve	425-6446
9R-1917	Bearing - Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As.	346-5692
9R-2480	Case As.	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-2601	Rod Gp-Tie	385-6133
9R-2842	Rod-Tie	385-6134
9R-2843	Rod-Tie	385-6135
9R-2846	Pin	346-5694
9R-2857	Rod-Piston	418-9588
9R-3527	Carrier-Planet	396-9892
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8199	Joint-Double	384-4813
9R-8231	Pad As.	397-5066
9R-8235	Pad As.	383-2106
9R-8579	Pin	346-5711
9R-8709	Pin	346-5715
9R-8714	Fork	390-0929

5YJ		
Original Part Number	**Part Name**	**Classic Part Number**
9R-8715	Spider As.-Brg&	346-5716
9R-8718	Yoke As.	364-5258
9R-9190	Rod Gp-Tie	346-5718
9R-9400	Case As.	346-5719
9R-9402	Seal-Rax	347-0476
9R-9403	Pinion	347-0477
9R-9505	Bearing - Sleeve	453-6516
9S-3581	Cup - Roller Brg	415-1923
9S-3582	Cone - Roller Brg	396-4144
9S-7949	Cup - Roller Brg	420-6531
9Y-9431	Precleaner As.	361-1718
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
054-2213	Spider & Brg As.	347-0464
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As.	384-5959
101-3125	Gasket	420-8567
102-4560	Bearing - Sleeve	347-0469
110-0013	Cup-Rlr Brg	384-5960
110-0840	Track Rod As..	391-1097
112-1773	Piston	347-0462
118-5839	Seal-Lip Type	435-8517
126-5984	Ring-Backup	419-4654

Sales Model 426B (Cont'd.)

5YJ		
Original Part Number	**Part Name**	**Classic Part Number**
127-8592	Muffler As.	347-0463
127-8594	Muffler As.-Turbo	390-0981
128-4128	Rod Gp-Tie	385-6136
130-0479	Pin As.	415-1907
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
135-8167	Pipe-Extension	395-1305
154-5279	Pin	392-4529
160-1014	Pin As.	347-0473

5YJ		
Original Part Number	**Part Name**	**Classic Part Number**
166-2142	Hub Gp-Shaft	394-8238
166-7870	Pad As.-Street	416-5515
186-4117	Carrier As.	394-8235
186-4118	Gear-Planet	347-0483
226-8202	Seal-Wiper	472-8024
236-8183	Bearing - Sleeve	453-6501
239-9956	Brake Disc	347-0485
269-0381	Cyl Gp-100 254 X	393-3660

5YJ		
Original Part Number	**Part Name**	**Classic Part Number**
274-4274	Bearing - Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As..	394-9813
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

6KL		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
1S-7057	Gasket	420-6384
2A-4576	Cup - Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9191	Cone - Roller Brg	374-1837
2S-0479	Bearing-Cone	380-7506
3E-4903	Mount As.	396-7274
3P-1210	Cone - Roller Brg	399-4433
4T-8054	Seal As.	472-8010
5L-9656	Cone-Bearing	399-4448
6E-0775	Head	425-9373
6E-6153	Plate-Port	346-5678
6E-6163	Shaft	346-5679
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7C-4349	Mount As.	383-2117
7K-5448	Cup-Bearing	415-1922
7T-3038	Gear-Reverse	445-1097
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
7T-3194	Yoke	346-5681
7T-5426	Cone - Roller Brg	453-3657

6KL		
Original Part Number	**Part Name**	**Classic Part Number**
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As.-Rlr	384-4823
7W-5164	Gasket	420-8568
8E-2043	Yoke As.	385-6115
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0313	Hub As.	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As.-Front	388-6604
9R-1725	Bearing - Sleeve	425-6446
9R-1917	Bearing - Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As.	346-5692
9R-2480	Case As.	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-2601	Rod Gp-Tie	385-6133
9R-2842	Rod-Tie	385-6134
9R-2843	Rod-Tie	385-6135
9R-2846	Pin	346-5694
9R-2857	Rod-Piston	418-9588
9R-3527	Carrier-Planet	396-9892

6KL		
Original Part Number	**Part Name**	**Classic Part Number**
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8199	Joint-Double	384-4813
9R-8231	Pad As.	397-5066
9R-8235	Pad As.	383-2106
9R-8579	Pin	346-5711
9R-8709	Pin	346-5715
9R-8714	Fork	390-0929
9R-8715	Spider As.-Brg&	346-5716
9R-8718	Yoke As.	364-5258
9R-9190	Rod Gp-Tie	346-5718
9R-9400	Case As.	346-5719
9R-9402	Seal-Rax	347-0476
9R-9403	Pinion	347-0477
9R-9505	Bearing - Sleeve	453-6516
9S-3581	Cup - Roller Brg	415-1923
9S-3582	Cone - Roller Brg	396-4144
9S-7949	Cup - Roller Brg	420-6531
9Y-9431	Precleaner As.	361-1718
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502

Sales Model 426B (Cont'd.)

6KL		
Original Part Number	**Part Name**	**Classic Part Number**
054-2213	Spider & Brg As.	347-0464
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As.	384-5959
101-3125	Gasket	420-8567
102-4560	Bearing - Sleeve	347-0469
110-0013	Cup-Rlr Brg	384-5960
110-0840	Track Rod As..	391-1097
112-1773	Piston	347-0462
118-5839	Seal-Lip Type	435-8517
126-5984	Ring-Backup	419-4654
127-8592	Muffler As.	347-0463

6KL		
Original Part Number	**Part Name**	**Classic Part Number**
127-8594	Muffler As.-Turbo	390-0981
128-4128	Rod Gp-Tie	385-6136
130-0479	Pin As.	415-1907
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
135-8167	Pipe-Extension	395-1305
154-5279	Pin	392-4529
160-1014	Pin As.	347-0473
166-2142	Hub Gp-Shaft	394-8238
166-7870	Pad As.-Street	416-5515
186-4117	Carrier As.	394-8235
186-4118	Gear-Planet	347-0483
226-8202	Seal-Wiper	472-8024

6KL		
Original Part Number	**Part Name**	**Classic Part Number**
236-8183	Bearing - Sleeve	453-6501
239-9956	Brake Disc	347-0485
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing - Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As..	394-9813
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 426C

1CR		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2G-7309	Shaft	393-3682
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067

1CR		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8D-7086	Bearing	330-9251
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692

1CR		
Original Part Number	**Part Name**	**Classic Part Number**
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8709	Pin	346-5715
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9505	Bearing-Sleeve	453-6516
9T-5729	Cyl Gp-0038 0158	422-2486
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465

Sales Model 426C (Cont'd.)

1CR		
Original Part Number	**Part Name**	**Classic Part Number**
102-4560	Bearing-Sleeve	347-0469
107-8375	Shaft As	439-1134
110-0840	Track Rod As.	391-1097
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
130-0479	Pin As	415-1907
130-1637	Shaft	347-0471

1CR		
Original Part Number	**Part Name**	**Classic Part Number**
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
135-8167	Pipe-Extension	395-1305
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5279	Pin	392-4529
166-7870	Pad As-Street	416-5515
172-2349	Cylinder As (Lh)	430-5958
173-1926	Cyl Gp-0102-0541	399-8576
173-1927	Cyl Gp-0102-0541	426-0036
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-9843	Head	347-0461
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3827	Pad As.	397-5057

1CR		
Original Part Number	**Part Name**	**Classic Part Number**
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
236-8183	Bearing-Sleeve	453-6501
239-9956	Brake Disc	347-0485
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

1ER		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6E-0775	Head	425-9373
6S-3051	Cup-Rlr Brg	415-1928

1ER		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689

1ER		
Original Part Number	**Part Name**	**Classic Part Number**
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8709	Pin	346-5715
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9505	Bearing-Sleeve	453-6516

Sales Model 426C (Cont'd.)

1ER		
Original Part Number	Part Name	Classic Part Number
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
102-4560	Bearing-Sleeve	347-0469
110-0840	Track Rod As.	391-1097
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654

1ER		
Original Part Number	Part Name	Classic Part Number
128-4128	Rod Gp-Tie	385-6136
130-0479	Pin As	415-1907
130-1637	Shaft	347-0471
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
135-8167	Pipe-Extension	395-1305
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
172-2349	Cylinder As (Lh)	430-5958
173-1926	Cyl Gp-0102-0541	399-8576
173-1927	Cyl Gp-0102-0541	426-0036
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
186-4117	Carrier As	394-8235

1ER		
Original Part Number	Part Name	Classic Part Number
186-4118	Gear-Planet	347-0483
187-3827	Pad As.	397-5057
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
236-8183	Bearing-Sleeve	453-6501
239-9956	Brake Disc	347-0485
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

1MR		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2G-7309	Shaft	393-3682
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269

1MR		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6F-6992	Cap-Ballsocket	297-7160
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124

1MR		
Original Part Number	Part Name	Classic Part Number
7T-7621	Bearing As-Rlr	384-4823
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
8D-7086	Bearing	330-9251
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019

Sales Model 426C (Cont'd.)

1MR		
Original Part Number	Part Name	Classic Part Number
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8709	Pin	346-5715
9R-9403	Pinion	347-0477
9R-9505	Bearing-Sleeve	453-6516
9T-5729	Cyl Gp-0038 0158	422-2486
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655

1MR		
Original Part Number	Part Name	Classic Part Number
102-4560	Bearing-Sleeve	347-0469
107-8375	Shaft As	439-1134
110-0840	Track Rod As.	391-1097
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
130-0479	Pin As	415-1907
130-1637	Shaft	347-0471
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
135-8167	Pipe-Extension	395-1305
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
148-2593	Head	383-1591
154-5279	Pin	392-4529
163-3749	Bearing-Sleeve	433-7505

1MR		
Original Part Number	Part Name	Classic Part Number
166-7870	Pad As-Street	416-5515
172-2349	Cylinder As (Lh)	430-5958
173-1926	Cyl Gp-0102-0541	399-8576
173-1927	Cyl Gp-0102-0541	426-0036
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-9843	Head	347-0461
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3827	Pad As.	397-5057
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
236-8183	Bearing-Sleeve	453-6501
239-9956	Brake Disc	347-0485
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

Sales Model 426C (Cont'd.)

1NR		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4T-8054	Seal As	472-8010
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690

1NR		
Original Part Number	Part Name	Classic Part Number
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8709	Pin	346-5715
9R-9403	Pinion	347-0477
9R-9505	Bearing-Sleeve	453-6516
9T-5729	Cyl Gp-0038 0158	422-2486
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655
102-4560	Bearing-Sleeve	347-0469
110-0840	Track Rod As.	391-1097
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517

1NR		
Original Part Number	Part Name	Classic Part Number
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
130-0479	Pin As	415-1907
130-1637	Shaft	347-0471
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
135-8167	Pipe-Extension	395-1305
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
148-2593	Head	383-1591
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
163-3749	Bearing-Sleeve	433-7505
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
172-2349	Cylinder As (Lh)	430-5958
173-1926	Cyl Gp-0102-0541	399-8576
173-1927	Cyl Gp-0102-0541	426-0036
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3827	Pad As.	397-5057
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322

Sales Model 426C (Cont'd.)

1NR		
Original Part Number	**Part Name**	**Classic Part Number**
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
236-8183	Bearing-Sleeve	453-6501
239-9956	Brake Disc	347-0485
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351

1NR		
Original Part Number	**Part Name**	**Classic Part Number**
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153

1NR		
Original Part Number	**Part Name**	**Classic Part Number**
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

1YR		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2G-7309	Shaft	393-3682
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6D-1734	Cup-Roller Brg	416-2171
6F-6992	Cap-Ballsocket	297-7160
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124

1YR		
Original Part Number	**Part Name**	**Classic Part Number**
7T-7621	Bearing As-Rlr	384-4823
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
8D-7086	Bearing	330-9251
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604
9R-1917	Bearing-Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943

1YR		
Original Part Number	**Part Name**	**Classic Part Number**
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8709	Pin	346-5715
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9505	Bearing-Sleeve	453-6516
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655

Sales Model 426C (Cont'd.)

1YR		
Original Part Number	**Part Name**	**Classic Part Number**
102-4560	Bearing-Sleeve	347-0469
107-8375	Shaft As	439-1134
110-0840	Track Rod As.	391-1097
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
130-0479	Pin As	415-1907
130-1637	Shaft	347-0471
130-1918	Pin As	393-0933
130-2533	Pin	396-7265

1YR		
Original Part Number	**Part Name**	**Classic Part Number**
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
135-8167	Pipe-Extension	395-1305
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
160-1014	Pin As	347-0473
163-3749	Bearing-Sleeve	433-7505
166-7870	Pad As-Street	416-5515
172-2349	Cylinder As (Lh)	430-5958
173-1926	Cyl Gp-0102-0541	399-8576
173-1927	Cyl Gp-0102-0541	426-0036
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
184-9843	Head	347-0461
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3827	Pad As.	397-5057

1YR		
Original Part Number	**Part Name**	**Classic Part Number**
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
236-8183	Bearing-Sleeve	453-6501
239-9956	Brake Disc	347-0485
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

1ZR		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433

1ZR		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306

1ZR		
Original Part Number	**Part Name**	**Classic Part Number**
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823

Sales Model 426C (Cont'd.)

1ZR		
Original Part Number	Part Name	Classic Part Number
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604
9R-1917	Bearing-Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8709	Pin	346-5715
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9505	Bearing-Sleeve	453-6516
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

1ZR		
Original Part Number	Part Name	Classic Part Number
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655
102-4560	Bearing-Sleeve	347-0469
110-0840	Track Rod As.	391-1097
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
130-0479	Pin As	415-1907
130-1637	Shaft	347-0471
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816

1ZR		
Original Part Number	Part Name	Classic Part Number
130-6879	Seal	347-0482
135-8167	Pipe-Extension	395-1305
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
160-1014	Pin As	347-0473
163-3749	Bearing-Sleeve	433-7505
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
172-2349	Cylinder As (Lh)	430-5958
173-1926	Cyl Gp-0102-0541	399-8576
173-1927	Cyl Gp-0102-0541	426-0036
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3827	Pad As.	397-5057
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
236-8183	Bearing-Sleeve	453-6501
239-9956	Brake Disc	347-0485
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153

Sales Model 426C (Cont'd.)

1ZR		
Original Part Number	**Part Name**	**Classic Part Number**
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813

1ZR		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

1ZR		
Original Part Number	**Part Name**	**Classic Part Number**
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

6XN		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2G-7309	Shaft	393-3682
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6D-1734	Cup-Roller Brg	416-2171
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8D-7086	Bearing	330-9251
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8S-9151	Cup-Spl Tapered	374-8348

6XN		
Original Part Number	**Part Name**	**Classic Part Number**
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604
9R-1917	Bearing-Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8709	Pin	346-5715
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9505	Bearing-Sleeve	453-6516
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502

6XN		
Original Part Number	**Part Name**	**Classic Part Number**
055-1986	Seal-Lip Type	347-0465
102-4560	Bearing-Sleeve	347-0469
107-8375	Shaft As	439-1134
110-0840	Track Rod As.	391-1097
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
130-0479	Pin As	415-1907
130-1637	Shaft	347-0471
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
135-8167	Pipe-Extension	395-1305
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
160-1014	Pin As	347-0473

Sales Model 426C (Cont'd.)

6XN		
Original Part Number	Part Name	Classic Part Number
166-7870	Pad As-Street	416-5515
172-2349	Cylinder As (Lh)	430-5958
173-1926	Cyl Gp-0102-0541	399-8576
173-1927	Cyl Gp-0102-0541	426-0036
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
184-9843	Head	347-0461
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3827	Pad As.	397-5057

6XN		
Original Part Number	Part Name	Classic Part Number
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
236-8183	Bearing-Sleeve	453-6501
239-9956	Brake Disc	347-0485
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664

6XN		
Original Part Number	Part Name	Classic Part Number
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

7WN		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6E-0775	Head	425-9373
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8S-9151	Cup-Spl Tapered	374-8348

7WN		
Original Part Number	Part Name	Classic Part Number
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604
9R-1917	Bearing-Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8709	Pin	346-5715
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9505	Bearing-Sleeve	453-6516
9S-3581	Cup-Roller Brg	415-1923

7WN		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
102-4560	Bearing-Sleeve	347-0469
110-0840	Track Rod As.	391-1097
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475

Sales Model 426C (Cont'd.)

7WN		
Original Part Number	Part Name	Classic Part Number
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
130-0479	Pin As	415-1907
130-1637	Shaft	347-0471
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
135-8167	Pipe-Extension	395-1305
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
160-1014	Pin As	347-0473

7WN		
Original Part Number	Part Name	Classic Part Number
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
172-2349	Cylinder As (Lh)	430-5958
173-1926	Cyl Gp-0102-0541	399-8576
173-1927	Cyl Gp-0102-0541	426-0036
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3827	Pad As.	397-5057
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487

7WN		
Original Part Number	Part Name	Classic Part Number
236-8183	Bearing-Sleeve	453-6501
239-9956	Brake Disc	347-0485
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

Sales Model 427F

HWK		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3P-1210	Cone - Roller Brg	399-4433
6D-1734	Cup - Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As.	360-2353
9W-9931	Mount As..	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

HWK		
Original Part Number	Part Name	Classic Part Number
122-6787	Yoke As.	416-2139
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As.-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As.	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981

HWK		
Original Part Number	Part Name	Classic Part Number
209-9886	Tie Rod As.	396-9901
210-7305	Shaft	396-9952
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing - Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 428

6TC		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849

Sales Model 428 (Cont'd.)

6TC		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup - Roller Brg	423-7759
1P-7115	Mount As.	418-1936
1S-7057	Gasket	420-6384
2A-4576	Cup - Roller Brg	386-4944
2B-0941	Spacer	418-1955
2S-0479	Bearing-Cone	380-7506
3E-6772	Seal-Water	382-8017
4T-8054	Seal As.	472-8010
5J-7010	Seal As.	472-8011
5L-9656	Cone-Bearing	399-4448
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7K-5448	Cup-Bearing	415-1922
7T-3038	Gear-Reverse	445-1097
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
7T-3194	Yoke	346-5681
7T-5426	Cone - Roller Brg	453-3657
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As.-Rlr	384-4823
7W-5164	Gasket	420-8568
7W-5194	Muffler As..	346-5682
8E-2043	Yoke As.	385-6115
8S-9151	Cup-Spl Tapered	374-8348
9L-2685	Rod End	419-1866
9R-0080	Coupling	346-5683
9R-0097	Pin	346-5684
9R-0313	Hub As.	388-6591
9R-0424	Pin	346-5686

6TC		
Original Part Number	Part Name	Classic Part Number
9R-0437	Pin	389-6320
9R-1572	Wheel As.-Front	388-6604
9R-1725	Bearing - Sleeve	425-6446
9R-1917	Bearing - Sleeve	418-1958
9R-2410	Retainer As..	346-5688
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2476	Disc-Bk Rear	346-5691
9R-2477	Disc As.	346-5692
9R-2480	Case As.	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-2601	Rod Gp-Tie	385-6133
9R-2842	Rod-Tie	385-6134
9R-2843	Rod-Tie	385-6135
9R-2846	Pin	346-5694
9R-2857	Rod-Piston	418-9588
9R-3527	Carrier-Planet	396-9892
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-6475	Pad As.	346-5702
9R-6545	Pin	346-5703
9R-7092	Bar	364-5272
9R-8199	Joint-Double	384-4813
9R-8714	Fork	390-0929
9R-8715	Spider As.-Brg&	346-5716
9R-8718	Yoke As.	364-5258
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9S-3581	Cup - Roller Brg	415-1923
9S-3582	Cone - Roller Brg	396-4144

6TC		
Original Part Number	Part Name	Classic Part Number
9S-7949	Cup - Roller Brg	420-6531
9Y-9431	Precleaner As.	361-1718
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
054-2213	Spider & Brg As.	347-0464
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As.	384-5959
055-1260	Housing Bk-Outer	347-0479
101-3125	Gasket	420-8567
118-5839	Seal-Lip Type	435-8517
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
151-5349	Head	383-1592
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-1014	Pin As.	347-0473
160-9874	Kit-Gasket-Scl	386-3048
166-7870	Pad As.-Street	416-5515
186-4117	Carrier As.	394-8235
186-4118	Gear-Planet	347-0483
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
232-6574	Kit-Gasket-RS	437-2034
274-4553	Disc-Clutch	416-2153
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 428B

7EJ		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849

Sales Model 428B (Cont'd.)

7EJ		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1S-7057	Gasket	420-6384
2A-4576	Cup - Roller Brg	386-4944
2B-0941	Spacer	418-1955
2S-0479	Bearing-Cone	380-7506
3E-4903	Mount As.	396-7274
3P-1210	Cone - Roller Brg	399-4433
4T-8054	Seal As.	472-8010
5J-7010	Seal As.	472-8011
5L-9656	Cone-Bearing	399-4448
6E-0775	Head	425-9373
6E-6153	Plate-Port	346-5678
6E-6163	Shaft	346-5679
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7C-4349	Mount As.	383-2117
7K-5448	Cup-Bearing	415-1922
7T-3038	Gear-Reverse	445-1097
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
7T-3194	Yoke	346-5681
7T-5426	Cone - Roller Brg	453-3657
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As.-Rlr	384-4823
7W-5164	Gasket	420-8568
8E-2043	Yoke As.	385-6115
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0313	Hub As.	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As.-Front	388-6604
9R-1725	Bearing - Sleeve	425-6446
9R-1917	Bearing - Sleeve	418-1958

7EJ		
Original Part Number	Part Name	Classic Part Number
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As.	346-5692
9R-2480	Case As.	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-2601	Rod Gp-Tie	385-6133
9R-2842	Rod-Tie	385-6134
9R-2843	Rod-Tie	385-6135
9R-2846	Pin	346-5694
9R-2857	Rod-Piston	418-9588
9R-3527	Carrier-Planet	396-9892
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-6545	Pin	346-5703
9R-7092	Bar	364-5272
9R-7696	Pin	346-5705
9R-8199	Joint-Double	384-4813
9R-8231	Pad As.	397-5066
9R-8235	Pad As.	383-2106
9R-8579	Pin	346-5711
9R-8580	Pin As.	418-1932
9R-8663	Pin	365-8831
9R-8709	Pin	346-5715
9R-8714	Fork	390-0929
9R-8715	Spider As.-Brg&	346-5716
9R-8718	Yoke As.	364-5258
9R-9190	Rod Gp-Tie	346-5718
9R-9400	Case As.	346-5719
9R-9402	Seal-Rax	347-0476
9R-9403	Pinion	347-0477
9R-9475	Bearing - Sleeve	380-7377
9R-9505	Bearing - Sleeve	453-6516
9R-9812	Pin	347-0468
9S-3581	Cup - Roller Brg	415-1923
9S-3582	Cone - Roller Brg	396-4144
9S-7949	Cup - Roller Brg	420-6531
9Y-9431	Precleaner As.	361-1718

7EJ		
Original Part Number	Part Name	Classic Part Number
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
054-2213	Spider & Brg As.	347-0464
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As.	384-5959
101-3125	Gasket	420-8567
101-4020	Pin As.	396-7285
102-4560	Bearing - Sleeve	347-0469
107-3950	Head	383-1588
110-0013	Cup-Rlr Brg	384-5960
112-1773	Piston	347-0462
118-5839	Seal-Lip Type	435-8517
126-5984	Ring-Backup	419-4654
127-8592	Muffler As.	347-0463
127-8594	Muffler As.-Turbo	390-0981
128-4128	Rod Gp-Tie	385-6136
130-0479	Pin As.	415-1907
130-0485	Pin	396-7286
130-2533	Pin	396-7265
134-2659	Rod As.	388-6568
135-8167	Pipe-Extension	395-1305
151-5349	Head	383-1592
154-5279	Pin	392-4529
159-0959	Pin As.	418-9578
159-0961	Pin	396-7287
160-1014	Pin As.	347-0473
164-7174	Cyl Gp-0076-1067	423-7865
166-2142	Hub Gp-Shaft	394-8238
166-7870	Pad As.-Street	416-5515
174-7432	Head	388-0660
184-1413	Pin As.	393-1050
186-4117	Carrier As.	394-8235
186-4118	Gear-Planet	347-0483
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495

Sales Model 428B (Cont'd.)

7EJ		
Original Part Number	Part Name	Classic Part Number
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing - Sleeve	453-6501
237-0944	Bearing - Sleeve	394-0194
237-2252	Bearing - Sleeve	347-0474

7EJ		
Original Part Number	Part Name	Classic Part Number
239-9956	Brake Disc	347-0485
251-7319	Bearing - Sleeve	425-6450
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing - Sleeve	391-9896
274-4553	Disc-Clutch	416-2153

7EJ		
Original Part Number	Part Name	Classic Part Number
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As..	394-9813
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 428C

2CR		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup - Roller Brg	386-4944
2B-0941	Spacer	418-1955
2G-7309	Shaft	393-3682
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As.	391-9812
3P-1210	Cone - Roller Brg	399-4433
4I-0453	Bearing - Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As.	480-8268
4I-4812	Pin As.	480-8269
4T-8054	Seal As.	472-8010
5J-7010	Seal As.	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing - Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124

2CR		
Original Part Number	Part Name	Classic Part Number
7T-7621	Bearing As.-Rlr	384-4823
7Y-2395	Bearing - Sleeve	314-8646
7Y-2396	Bearing - Sleeve	314-8634
7Y-3427	Bearing - Sleeve	314-8635
7Y-3428	Bearing - Sleeve	314-8647
8D-7086	Bearing	330-9251
8D-8168	Bearing	453-6511
8D-8572	Bearing - Sleeve	380-7384
8D-9159	Bearing - Sleeve	472-8019
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0313	Hub As.	388-6591
9R-0437	Pin	389-6320
9R-1572	Wheel As.-Front	388-6604
9R-1917	Bearing - Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As.	346-5692
9R-2480	Case As.	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693

2CR		
Original Part Number	Part Name	Classic Part Number
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-6545	Pin	346-5703
9R-7092	Bar	364-5272
9R-7696	Pin	346-5705
9R-8231	Pad As.	397-5066
9R-8235	Pad As.	383-2106
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9475	Bearing - Sleeve	380-7377
9R-9505	Bearing - Sleeve	453-6516
9R-9812	Pin	347-0468
9S-3581	Cup - Roller Brg	415-1923
9S-3582	Cone - Roller Brg	396-4144
9S-7949	Cup - Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465

Sales Model 428C (Cont'd.)

2CR		
Original Part Number	**Part Name**	**Classic Part Number**
087-5802	Link-RH	301-7964
087-5803	Link As.	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
096-7911	Bearing - Sleeve	314-8653
096-7912	Bearing - Sleeve	314-8654
096-7913	Bearing - Sleeve	314-8655
101-4020	Pin As.	396-7285
102-4560	Bearing - Sleeve	347-0469
107-3950	Head	383-1588
107-8375	Shaft As.	439-1134
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As.-NA	390-0982
113-1149	Shaft As.-AWD	418-9574
113-1150	Shaft As.-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As.	416-2139
125-1037	Pin As.	375-9985
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
128-9863	Bearing - Sleeve	314-8630
128-9882	Bearing - Sleeve	314-8642
128-9884	Bearing - Sleeve	360-2315

2CR		
Original Part Number	**Part Name**	**Classic Part Number**
130-0485	Pin	396-7286
130-1918	Pin As.	393-0933
130-3013	Shaft As.	391-9865
130-3014	Shaft As.	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
134-2659	Rod As.	388-6568
135-8167	Pipe-Extension	395-1305
137-2819	Bearing - Sleeve	360-2317
137-2919	Bearing - Sleeve	360-2319
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As.	418-9578
159-0961	Pin	396-7287
160-1014	Pin As.	347-0473
163-3749	Bearing - Sleeve	433-7505
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As.-Street	416-5515
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
184-1413	Pin As.	393-1050
184-9843	Head	347-0461
186-4117	Carrier As.	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As..	397-5054
187-3827	Pad As..	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As..	430-5957

2CR		
Original Part Number	**Part Name**	**Classic Part Number**
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
227-6789	Bearing - Sleeve	360-2322
229-2949	Rod As..-Track	347-0486
229-2950	Rod As..-Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing - Sleeve	453-6501
237-0944	Bearing - Sleeve	394-0194
237-2252	Bearing - Sleeve	347-0474
239-9956	Brake Disc	347-0485
250-2398	Pin As.	382-8047
250-2402	Pin As.	360-2351
251-7319	Bearing - Sleeve	425-6450
262-7044	Bearing	418-1948
264-2769	Bearing As..-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing - Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As..	394-9813
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

8RN		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4576	Cup - Roller Brg	386-4944
2B-0941	Spacer	418-1955

8RN		
Original Part Number	**Part Name**	**Classic Part Number**
2G-7309	Shaft	393-3682
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As.	391-9812

8RN		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone - Roller Brg	399-4433
4T-8054	Seal As.	472-8010

Sales Model 428C (Cont'd.)

8RN		
Original Part Number	Part Name	Classic Part Number
5J-7010	Seal As.	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing - Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As.-Rlr	384-4823
8D-7086	Bearing	330-9251
8D-8168	Bearing	453-6511
8D-8572	Bearing - Sleeve	380-7384
8D-9159	Bearing - Sleeve	472-8019
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0313	Hub As.	388-6591
9R-0437	Pin	389-6320
9R-1572	Wheel As.-Front	388-6604
9R-1917	Bearing - Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As.	346-5692
9R-2480	Case As.	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-6545	Pin	346-5703
9R-7092	Bar	364-5272
9R-7696	Pin	346-5705
9R-8231	Pad As.	397-5066

8RN		
Original Part Number	Part Name	Classic Part Number
9R-8235	Pad As.	383-2106
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9475	Bearing - Sleeve	380-7377
9R-9505	Bearing - Sleeve	453-6516
9R-9812	Pin	347-0468
9S-3581	Cup - Roller Brg	415-1923
9S-3582	Cone - Roller Brg	396-4144
9S-7949	Cup - Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-4020	Pin As.	396-7285
102-4560	Bearing - Sleeve	347-0469
107-3950	Head	383-1588
107-8375	Shaft As.	439-1134
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As.-NA	390-0982
113-1149	Shaft As.-AWD	418-9574
113-1150	Shaft As.-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As.	416-2139
125-1037	Pin As.	375-9985
126-5984	Ring-Backup	419-4654

8RN		
Original Part Number	Part Name	Classic Part Number
128-4128	Rod Gp-Tie	385-6136
130-0485	Pin	396-7286
130-1918	Pin As.	393-0933
130-3013	Shaft As.	391-9865
130-3014	Shaft As.	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
134-2659	Rod As.	388-6568
135-8167	Pipe-Extension	395-1305
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As.	418-9578
159-0961	Pin	396-7287
160-1014	Pin As.	347-0473
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As.-Street	416-5515
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
184-1413	Pin As.	393-1050
184-9843	Head	347-0461
186-4117	Carrier As.	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As..	397-5054
187-3827	Pad As..	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As..	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
229-2949	Rod As..-Track	347-0486
229-2950	Rod As..-Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing - Sleeve	453-6501

Sales Model 428C (Cont'd.)

8RN		
Original Part Number	**Part Name**	**Classic Part Number**
237-0944	Bearing - Sleeve	394-0194
237-2252	Bearing - Sleeve	347-0474
239-9956	Brake Disc	347-0485
251-7319	Bearing - Sleeve	425-6450
262-7044	Bearing	418-1948

8RN		
Original Part Number	**Part Name**	**Classic Part Number**
264-2769	Bearing As..-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing - Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554

8RN		
Original Part Number	**Part Name**	**Classic Part Number**
278-1972	Cylinder As..	394-9813
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

Sales Model 428D

BLL		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-1572	Wheel As-Front	388-6604
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881

BLL		
Original Part Number	**Part Name**	**Classic Part Number**
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670

BLL		
Original Part Number	**Part Name**	**Classic Part Number**
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479

Sales Model 428D (Cont'd.)

BLL		
Original Part Number	Part Name	Classic Part Number
184-1413	Pin As	393-1050
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.-Track	347-0486

BLL		
Original Part Number	Part Name	Classic Part Number
229-2950	Rod As.-Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
251-7319	Bearing-Sleeve	425-6450
264-2769	Bearing As.-Spl	419-8664

BLL		
Original Part Number	Part Name	Classic Part Number
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

BMT		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692

BMT		
Original Part Number	Part Name	Classic Part Number
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272

BMT		
Original Part Number	Part Name	Classic Part Number
112-1773	Piston	347-0462
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287

Sales Model 428D (Cont'd.)

BMT		
Original Part Number	**Part Name**	**Classic Part Number**
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496

BMT		
Original Part Number	**Part Name**	**Classic Part Number**
193-1684	Pad	396-0645
193-1688	Pad	416-5495
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
251-7319	Bearing-Sleeve	425-6450

BMT		
Original Part Number	**Part Name**	**Classic Part Number**
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

BNB		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-1572	Wheel As-Front	388-6604
9R-2419	Kit-Bearing	383-2137

BNB		
Original Part Number	**Part Name**	**Classic Part Number**
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-4020	Pin As	396-7285

BNB		
Original Part Number	**Part Name**	**Classic Part Number**
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
134-2659	Rod As	388-6568

Sales Model 428D (Cont'd.)

BNB		
Original Part Number	Part Name	Classic Part Number
135-8167	Pipe-Extension	395-1305
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483

BNB		
Original Part Number	Part Name	Classic Part Number
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474

BNB		
Original Part Number	Part Name	Classic Part Number
239-9956	Brake Disc	347-0485
251-7319	Bearing-Sleeve	425-6450
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

BNS		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8S-9151	Cup-Spl Tapered	374-8348

BNS		
Original Part Number	Part Name	Classic Part Number
9R-0097	Pin	346-5684
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
005-0469	Cup-Rlr Bearing	418-9610

BNS		
Original Part Number	Part Name	Classic Part Number
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139

Sales Model 428D (Cont'd.)

BNS		
Original Part Number	Part Name	Classic Part Number
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687

BNS		
Original Part Number	Part Name	Classic Part Number
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501

BNS		
Original Part Number	Part Name	Classic Part Number
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
251-7319	Bearing-Sleeve	425-6450
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

BXC		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
6D-1734	Cup-Roller Brg	416-2171
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0437	Pin	389-6320

BXC		
Original Part Number	Part Name	Classic Part Number
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
005-0469	Cup-Rlr Bearing	418-9610

BXC		
Original Part Number	Part Name	Classic Part Number
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286

Sales Model 428D (Cont'd.)

BXC		
Original Part Number	Part Name	Classic Part Number
130-1918	Pin As	393-0933
130-5451	Pin	394-9816
134-2659	Rod As	388-6568
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483

BXC		
Original Part Number	Part Name	Classic Part Number
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485

BXC		
Original Part Number	Part Name	Classic Part Number
251-7319	Bearing-Sleeve	425-6450
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

DSX		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
6D-1734	Cup-Roller Brg	416-2171
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0437	Pin	389-6320
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690

DSX		
Original Part Number	Part Name	Classic Part Number
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
111-4332	Plate	396-7290

DSX		
Original Part Number	Part Name	Classic Part Number
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-5451	Pin	394-9816
134-2659	Rod As	388-6568
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515

Sales Model 428D (Cont'd.)

DSX		
Original Part Number	**Part Name**	**Classic Part Number**
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495

DSX		
Original Part Number	**Part Name**	**Classic Part Number**
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
251-7319	Bearing-Sleeve	425-6450
269-0381	Cyl Gp-100 254 X	393-3660

DSX		
Original Part Number	**Part Name**	**Classic Part Number**
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

MBM		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4576	Cup-Roller Brg	386-4944
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
6D-1734	Cup-Roller Brg	416-2171
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0437	Pin	389-6320
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505

MBM		
Original Part Number	**Part Name**	**Classic Part Number**
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
112-1773	Piston	347-0462
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286

MBM		
Original Part Number	**Part Name**	**Classic Part Number**
130-1918	Pin As	393-0933
130-5451	Pin	394-9816
134-2659	Rod As	388-6568
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901
226-8202	Seal-Wiper	472-8024

Sales Model 428D (Cont'd.)

MBM		
Original Part Number	Part Name	Classic Part Number
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485

MBM		
Original Part Number	Part Name	Classic Part Number
251-7319	Bearing-Sleeve	425-6450
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554

MBM		
Original Part Number	Part Name	Classic Part Number
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

S1K		
Original Part Number	Part Name	Classic Part Number
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
112-1773	Piston	347-0462
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139

S1K		
Original Part Number	Part Name	Classic Part Number
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286
130-2533	Pin	396-7265
130-5451	Pin	394-9816
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495

S1K		
Original Part Number	Part Name	Classic Part Number
199-0760	Bearing-Roller	465-8981
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

S9D		
Original Part Number	Part Name	Classic Part Number
3E-4924	Mounting As	391-9812

Sales Model 428D (Cont'd.)

S9D		
Original Part Number	**Part Name**	**Classic Part Number**
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139

S9D		
Original Part Number	**Part Name**	**Classic Part Number**
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-5451	Pin	394-9816
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645

S9D		
Original Part Number	**Part Name**	**Classic Part Number**
193-1688	Pad	416-5495
199-0760	Bearing-Roller	465-8981
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 428E

DPH		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354

DPH		
Original Part Number	**Part Name**	**Classic Part Number**
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
111-4332	Plate	396-7290
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
154-5279	Pin	392-4529
154-5280	Pin	391-9868

DPH		
Original Part Number	**Part Name**	**Classic Part Number**
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981

Sales Model 428E (Cont'd.)

DPH		
Original Part Number	Part Name	Classic Part Number
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
269-0381	Cyl Gp-100 254 X	393-3660

DPH		
Original Part Number	Part Name	Classic Part Number
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153

DPH		
Original Part Number	Part Name	Classic Part Number
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

DXC		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0437	Pin	389-6320
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469

DXC		
Original Part Number	Part Name	Classic Part Number
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
130-1918	Pin As	393-0933
130-5451	Pin	394-9816
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981

DXC		
Original Part Number	Part Name	Classic Part Number
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

SNL		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842

SNL		
Original Part Number	Part Name	Classic Part Number
9R-0097	Pin	346-5684
9R-0437	Pin	389-6320
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9T-3948	Rod As	393-0940
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469
110-1337	Ring Kit-Pstn	377-5834
111-4332	Plate	396-7290
111-4340	Pin	451-1512

SNL		
Original Part Number	Part Name	Classic Part Number
111-4343	Pin	390-5272
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
130-1918	Pin As	393-0933
130-5451	Pin	394-9816
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479

Backhoe Loaders

Sales Model 428E (Cont'd.)

SNL		
Original Part Number	**Part Name**	**Classic Part Number**
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024

SNL		
Original Part Number	**Part Name**	**Classic Part Number**
237-0944	Bearing-Sleeve	394-0194
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813

SNL		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 428F

HWN		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

HWN		
Original Part Number	**Part Name**	**Classic Part Number**
122-6787	Yoke As	416-2139
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981

HWN		
Original Part Number	**Part Name**	**Classic Part Number**
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

LBH		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
122-6787	Yoke As	416-2139

LBH		
Original Part Number	**Part Name**	**Classic Part Number**
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981

LBH		
Original Part Number	**Part Name**	**Classic Part Number**
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

LYG		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955

Sales Model 428F (Cont'd.)

LYG		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

LYG		
Original Part Number	**Part Name**	**Classic Part Number**
122-6787	Yoke As	416-2139
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981

LYG		
Original Part Number	**Part Name**	**Classic Part Number**
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

RAK		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
122-6787	Yoke As	416-2139

RAK		
Original Part Number	**Part Name**	**Classic Part Number**
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981

RAK		
Original Part Number	**Part Name**	**Classic Part Number**
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

SJW		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
122-6787	Yoke As	416-2139

SJW		
Original Part Number	**Part Name**	**Classic Part Number**
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981

SJW		
Original Part Number	**Part Name**	**Classic Part Number**
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

BML		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3E-6772	Seal-Water	382-8017
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4T-8054	Seal As	472-8010
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6D-1734	Cup-Roller Brg	416-2171
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7C-0307	Gasket	399-8571
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257

BML		
Original Part Number	Part Name	Classic Part Number
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
7W-1713	Core Gp-O Clr	438-2010
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
9F-3212	Bearing-Ball	384-5953
9M-1328	Bearing-Aligning	325-6018
9N-3167	Plate-Block Bot	430-4468
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-0424	Pin	346-5686
9R-1917	Bearing-Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-8579	Pin	346-5711
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9505	Bearing-Sleeve	453-6516

BML		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-4560	Bearing-Sleeve	347-0469
108-7930	Bearing As	377-7463
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
128-4128	Rod Gp-Tie	385-6136
129-9907	Impeller-Pump	383-1589
130-1637	Shaft	347-0471
130-1918	Pin As	393-0933

Sales Model 430D (Cont'd.)

BML		
Original Part Number	Part Name	Classic Part Number
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
135-8167	Pipe-Extension	395-1305
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
148-2593	Head	383-1591
151-5349	Head	383-1592
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
160-1014	Pin As	347-0473
160-9874	Kit-Gasket-Scl	386-3048

BML		
Original Part Number	Part Name	Classic Part Number
166-6352	Tube As.	432-4223
166-7870	Pad As-Street	416-5515
167-8126	Damper As	382-8019
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
186-2001	Rotocoil As	397-5055
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3827	Pad As.	397-5057
187-8979	Gear As	393-3656
199-0760	Bearing-Roller	465-8981
202-3572	Shaft As-Drive	426-0037
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
236-8183	Bearing-Sleeve	453-6501

BML		
Original Part Number	Part Name	Classic Part Number
239-9956	Brake Disc	347-0485
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1365	Arm As-Ui Rkr	433-7507
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915
430-7619	Adapter-Cla	438-1812

BNK		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
2A-4576	Cup-Roller Brg	386-4944
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306

BNK		
Original Part Number	Part Name	Classic Part Number
6D-1734	Cup-Roller Brg	416-2171
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823

BNK		
Original Part Number	Part Name	Classic Part Number
8S-9151	Cup-Spl Tapered	374-8348
9M-1328	Bearing-Aligning	325-6018
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1917	Bearing-Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137

Sales Model 430D (Cont'd.)

BNK		
Original Part Number	**Part Name**	**Classic Part Number**
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-8579	Pin	346-5711
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9505	Bearing-Sleeve	453-6516
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
102-4560	Bearing-Sleeve	347-0469

BNK		
Original Part Number	**Part Name**	**Classic Part Number**
112-1773	Piston	347-0462
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
135-8167	Pipe-Extension	395-1305
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
160-1014	Pin As	347-0473
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
183-2358	Bearing	425-3588

BNK		
Original Part Number	**Part Name**	**Classic Part Number**
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3827	Pad As.	397-5057
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
236-8183	Bearing-Sleeve	453-6501
239-9956	Brake Disc	347-0485
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

C3J		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4924	Mounting As	391-9812
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-8579	Pin	346-5711
9R-9505	Bearing-Sleeve	453-6516

C3J		
Original Part Number	**Part Name**	**Classic Part Number**
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469
112-1773	Piston	347-0462
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
130-1637	Shaft	347-0471

C3J		
Original Part Number	**Part Name**	**Classic Part Number**
130-2533	Pin	396-7265
130-5451	Pin	394-9816
135-8167	Pipe-Extension	395-1305
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479

Sales Model 430D (Cont'd.)

C3J		
Original Part Number	Part Name	Classic Part Number
187-3827	Pad As.	397-5057
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
236-8183	Bearing-Sleeve	453-6501

C3J		
Original Part Number	Part Name	Classic Part Number
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813

C3J		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

C5B		
Original Part Number	Part Name	Classic Part Number
3E-4924	Mounting As	391-9812
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-8579	Pin	346-5711
9R-9505	Bearing-Sleeve	453-6516
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272

C5B		
Original Part Number	Part Name	Classic Part Number
112-1773	Piston	347-0462
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-5451	Pin	394-9816
135-8167	Pipe-Extension	395-1305
148-2593	Head	383-1591
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
187-3827	Pad As.	397-5057
199-0760	Bearing-Roller	465-8981

C5B		
Original Part Number	Part Name	Classic Part Number
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
236-8183	Bearing-Sleeve	453-6501
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

C7E		
Original Part Number	Part Name	Classic Part Number
3E-4924	Mounting As	391-9812
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-8579	Pin	346-5711

C7E		
Original Part Number	Part Name	Classic Part Number
9R-9505	Bearing-Sleeve	453-6516
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469
112-1773	Piston	347-0462
122-1881	Plate-Clutch	347-0475

C7E		
Original Part Number	Part Name	Classic Part Number
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-5451	Pin	394-9816
135-8167	Pipe-Extension	395-1305
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868

Sales Model 430D (Cont'd.)

C7E		
Original Part Number	**Part Name**	**Classic Part Number**
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
187-3827	Pad As.	397-5057
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901

C7E		
Original Part Number	**Part Name**	**Classic Part Number**
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
236-8183	Bearing-Sleeve	453-6501
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896

C7E		
Original Part Number	**Part Name**	**Classic Part Number**
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

C9P		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4924	Mounting As	391-9812
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-8579	Pin	346-5711
9R-9505	Bearing-Sleeve	453-6516
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272

C9P		
Original Part Number	**Part Name**	**Classic Part Number**
112-1773	Piston	347-0462
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-5451	Pin	394-9816
135-8167	Pipe-Extension	395-1305
148-2593	Head	383-1591
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
187-3827	Pad As.	397-5057
199-0760	Bearing-Roller	465-8981

C9P		
Original Part Number	**Part Name**	**Classic Part Number**
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
236-8183	Bearing-Sleeve	453-6501
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 430E

DDT		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010

DDT		
Original Part Number	**Part Name**	**Classic Part Number**
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847

DDT		
Original Part Number	**Part Name**	**Classic Part Number**
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686

Sales Model 430E (Cont'd.)

DDT		
Original Part Number	Part Name	Classic Part Number
9R-8579	Pin	346-5711
9R-9505	Bearing-Sleeve	453-6516
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
102-4560	Bearing-Sleeve	347-0469
110-1337	Ring Kit-Pstn	377-5834
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693

DDT		
Original Part Number	Part Name	Classic Part Number
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-5451	Pin	394-9816
135-8167	Pipe-Extension	395-1305
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981

DDT		
Original Part Number	Part Name	Classic Part Number
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
236-8183	Bearing-Sleeve	453-6501
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

EAT		
Original Part Number	Part Name	Classic Part Number
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-8579	Pin	346-5711
9R-9505	Bearing-Sleeve	453-6516
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983

EAT		
Original Part Number	Part Name	Classic Part Number
102-4560	Bearing-Sleeve	347-0469
110-1337	Ring Kit-Pstn	377-5834
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-5451	Pin	394-9816
135-8167	Pipe-Extension	395-1305
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515

EAT		
Original Part Number	Part Name	Classic Part Number
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
236-8183	Bearing-Sleeve	453-6501
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 430E (Cont'd.)

MXB		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4924	Mounting As	391-9812
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469
110-1337	Ring Kit-Pstn	377-5834

MXB		
Original Part Number	**Part Name**	**Classic Part Number**
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-5451	Pin	394-9816
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901

MXB		
Original Part Number	**Part Name**	**Classic Part Number**
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

RLN		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4924	Mounting As	391-9812
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469

RLN		
Original Part Number	**Part Name**	**Classic Part Number**
110-1337	Ring Kit-Pstn	377-5834
112-1773	Piston	347-0462
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-5451	Pin	394-9816
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901

RLN		
Original Part Number	**Part Name**	**Classic Part Number**
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

SCD		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171

SCD		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847

SCD		
Original Part Number	**Part Name**	**Classic Part Number**
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842

Sales Model 430E (Cont'd.)

SCD		
Original Part Number	**Part Name**	**Classic Part Number**
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469
110-1337	Ring Kit-Pstn	377-5834
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985

SCD		
Original Part Number	**Part Name**	**Classic Part Number**
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-5451	Pin	394-9816
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194

SCD		
Original Part Number	**Part Name**	**Classic Part Number**
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

SWC		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4924	Mounting As	391-9812
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469

SWC		
Original Part Number	**Part Name**	**Classic Part Number**
110-1337	Ring Kit-Pstn	377-5834
112-1773	Piston	347-0462
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-5451	Pin	394-9816
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901

SWC		
Original Part Number	**Part Name**	**Classic Part Number**
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 430F

HWE		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433

Sales Model 430F (Cont'd.)

HWE		
Original Part Number	**Part Name**	**Classic Part Number**
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

HWE		
Original Part Number	**Part Name**	**Classic Part Number**
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479

HWE		
Original Part Number	**Part Name**	**Classic Part Number**
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

HWG		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610

HWG		
Original Part Number	**Part Name**	**Classic Part Number**
005-0471	Cone-Spl Tapered	415-1924
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687

HWG		
Original Part Number	**Part Name**	**Classic Part Number**
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

LDY		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471

LDY		
Original Part Number	**Part Name**	**Classic Part Number**
130-2533	Pin	396-7265
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024

LDY		
Original Part Number	**Part Name**	**Classic Part Number**
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 430F (Cont'd.)

LNH		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

LNH		
Original Part Number	**Part Name**	**Classic Part Number**
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981

LNH		
Original Part Number	**Part Name**	**Classic Part Number**
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

LYD		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610

LYD		
Original Part Number	**Part Name**	**Classic Part Number**
005-0471	Cone-Spl Tapered	415-1924
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687

LYD		
Original Part Number	**Part Name**	**Classic Part Number**
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

LYE		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610

LYE		
Original Part Number	**Part Name**	**Classic Part Number**
005-0471	Cone-Spl Tapered	415-1924
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687

LYE		
Original Part Number	**Part Name**	**Classic Part Number**
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

RDF		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955

Sales Model 430F (Cont'd.)

RDF		
Original Part Number	**Part Name**	**Classic Part Number**
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
130-2533	Pin	396-7265

RDF		
Original Part Number	**Part Name**	**Classic Part Number**
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
269-0381	Cyl Gp-100 254 X	393-3660

RDF		
Original Part Number	**Part Name**	**Classic Part Number**
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

RGS		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0424	Pin	346-5686
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

RGS		
Original Part Number	**Part Name**	**Classic Part Number**
122-6787	Yoke As	416-2139
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981

RGS		
Original Part Number	**Part Name**	**Classic Part Number**
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 432D

BLD		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2S-0479	Bearing-Cone	380-7506

BLD		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4924	Mounting As	391-9812
3E-6772	Seal-Water	382-8017
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4T-8054	Seal As	472-8010
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

BLD		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6I-2726	Bearing-Sleeve	419-4757

Sales Model 432D (Cont'd.)

BLD		
Original Part Number	Part Name	Classic Part Number
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7C-0307	Gasket	399-8571
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
7W-1713	Core Gp-O Clr	438-2010
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
9F-3212	Bearing-Ball	384-5953
9N-3167	Plate-Block Bot	430-4468
9R-0097	Pin	346-5684
9R-1572	Wheel As-Front	388-6604
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701

BLD		
Original Part Number	Part Name	Classic Part Number
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-3125	Gasket	420-8567
101-4020	Pin As	396-7285
101-9640	Gear-Air Compr	398-2966
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
108-7930	Bearing As	377-7463
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589

BLD		
Original Part Number	Part Name	Classic Part Number
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
134-2659	Rod As	388-6568
135-4928	Shaft-Water Pump	386-3813
135-8167	Pipe-Extension	395-1305
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
148-2593	Head	383-1591
151-5349	Head	383-1592
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
160-9874	Kit-Gasket-Scl	386-3048
164-7174	Cyl Gp-0076-1067	423-7865
166-6352	Tube As.	432-4223
166-7870	Pad As-Street	416-5515
167-8126	Damper As	382-8019
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
178-8608	Cone	422-6479
184-1413	Pin As	393-1050

Sales Model 432D (Cont'd.)

BLD		
Original Part Number	**Part Name**	**Classic Part Number**
186-2001	Rotocoil As	397-5055
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
187-8979	Gear As	393-3656
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
202-3572	Shaft As-Drive	426-0037
209-6188	Plate	393-1053
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
226-8202	Seal-Wiper	472-8024

BLD		
Original Part Number	**Part Name**	**Classic Part Number**
229-2949	Rod As.-Track	347-0486
229-2950	Rod As.-Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
243-6718	Kit-Brg(Main)	469-1690
251-7319	Bearing-Sleeve	425-6450
253-1752	Plate-Thrust	379-0170
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896

BLD		
Original Part Number	**Part Name**	**Classic Part Number**
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1365	Arm As-Ui Rkr	433-7507
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
392-6301	Kit-Spider & Brg	390-0915
430-7619	Adapter-Cla	438-1812

S6B		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

S6B		
Original Part Number	**Part Name**	**Classic Part Number**
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-5451	Pin	394-9816
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529

S6B		
Original Part Number	**Part Name**	**Classic Part Number**
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
199-0760	Bearing-Roller	465-8981
209-6188	Plate	393-1053

Sales Model 432D (Cont'd.)

S6B		
Original Part Number	Part Name	Classic Part Number
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474

S6B		
Original Part Number	Part Name	Classic Part Number
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813

S6B		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

S6H		
Original Part Number	Part Name	Classic Part Number
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
122-1881	Plate-Clutch	347-0475

S6H		
Original Part Number	Part Name	Classic Part Number
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-5451	Pin	394-9816
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496

S6H		
Original Part Number	Part Name	Classic Part Number
193-1684	Pad	396-0645
193-1688	Pad	416-5495
199-0760	Bearing-Roller	465-8981
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 432D (Cont'd.)

TDR		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3E-6772	Seal-Water	382-8017
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4T-8054	Seal As	472-8010
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
6D-1734	Cup-Roller Brg	416-2171
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7C-0307	Gasket	399-8571
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190

TDR		
Original Part Number	Part Name	Classic Part Number
7N-7435	Kit-Major Repair	374-4724
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
7W-1713	Core Gp-O Clr	438-2010
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
9F-3212	Bearing-Ball	384-5953
9N-3167	Plate-Block Bot	430-4468
9R-0097	Pin	346-5684
9R-0437	Pin	389-6320
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
101-3125	Gasket	420-8567
101-4020	Pin As	396-7285

TDR		
Original Part Number	Part Name	Classic Part Number
101-9640	Gear-Air Compr	398-2966
102-4560	Bearing-Sleeve	347-0469
108-7930	Bearing As	377-7463
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-5451	Pin	394-9816
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
134-2659	Rod As	388-6568
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
151-5349	Head	383-1592
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
154-5278	Pin	393-3685

Sales Model 432D (Cont'd.)

TDR		
Original Part Number	Part Name	Classic Part Number
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
160-9874	Kit-Gasket-Scl	386-3048
164-7174	Cyl Gp-0076-1067	423-7865
166-6352	Tube As.	432-4223
166-7870	Pad As-Street	416-5515
167-8126	Damper As	382-8019
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
186-2001	Rotocoil As	397-5055
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
187-8979	Gear As	393-3656
191-7725	Cyl Gp-0076-1067	423-7867

TDR		
Original Part Number	Part Name	Classic Part Number
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
202-3572	Shaft As-Drive	426-0037
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
243-6718	Kit-Brg(Main)	469-1690
251-7319	Bearing-Sleeve	425-6450
253-1752	Plate-Thrust	379-0170

TDR		
Original Part Number	Part Name	Classic Part Number
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1365	Arm As-Ui Rkr	433-7507
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915
430-7619	Adapter-Cla	438-1812

WEP		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3E-6772	Seal-Water	382-8017
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4T-8054	Seal As	472-8010
4W-2474	Rotocoil As	388-6571

WEP		
Original Part Number	Part Name	Classic Part Number
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
6D-1734	Cup-Roller Brg	416-2171
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555

WEP		
Original Part Number	Part Name	Classic Part Number
7C-0307	Gasket	399-8571
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
7W-1713	Core Gp-O Clr	438-2010

Sales Model 432D (Cont'd.)

WEP		
Original Part Number	Part Name	Classic Part Number
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
9F-3212	Bearing-Ball	384-5953
9N-3167	Plate-Block Bot	430-4468
9R-0097	Pin	346-5684
9R-0437	Pin	389-6320
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
101-3125	Gasket	420-8567
101-4020	Pin As	396-7285
101-9640	Gear-Air Compr	398-2966
102-4560	Bearing-Sleeve	347-0469
108-7930	Bearing As	377-7463
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272

WEP		
Original Part Number	Part Name	Classic Part Number
112-1773	Piston	347-0462
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-5451	Pin	394-9816
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
134-2659	Rod As	388-6568
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
151-5349	Head	383-1592
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
160-9874	Kit-Gasket-Scl	386-3048
164-7174	Cyl Gp-0076-1067	423-7865

WEP		
Original Part Number	Part Name	Classic Part Number
166-6352	Tube As.	432-4223
166-7870	Pad As-Street	416-5515
167-8126	Damper As	382-8019
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
186-2001	Rotocoil As	397-5055
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
187-8979	Gear As	393-3656
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
202-3572	Shaft As-Drive	426-0037
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
243-6718	Kit-Brg(Main)	469-1690
251-7319	Bearing-Sleeve	425-6450
253-1752	Plate-Thrust	379-0170
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153

Sales Model 432D (Cont'd.)

WEP		
Original Part Number	Part Name	Classic Part Number
278-0223	Housing-Brake	456-0554
278-1365	Arm As-Ui Rkr	433-7507
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

WEP		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387

WEP		
Original Part Number	Part Name	Classic Part Number
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915
430-7619	Adapter-Cla	438-1812

Sales Model 432E

BXE		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842
9R-0097	Pin	346-5684
9R-0437	Pin	389-6320
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9T-3948	Rod As	393-0940
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

BXE		
Original Part Number	Part Name	Classic Part Number
100-6267	Plate As-Idler	375-9983
102-4560	Bearing-Sleeve	347-0469
110-1337	Ring Kit-Pstn	377-5834
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
130-1918	Pin As	393-0933
130-5451	Pin	394-9816
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479

BXE		
Original Part Number	Part Name	Classic Part Number
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

JBA		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353

JBA		
Original Part Number	Part Name	Classic Part Number
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610

JBA		
Original Part Number	Part Name	Classic Part Number
005-0471	Cone-Spl Tapered	415-1924
111-4332	Plate	396-7290
122-1881	Plate-Clutch	347-0475

Sales Model 432E (Cont'd.)

JBA		
Original Part Number	**Part Name**	**Classic Part Number**
122-6787	Yoke As	416-2139
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050

JBA		
Original Part Number	**Part Name**	**Classic Part Number**
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
269-0381	Cyl Gp-100 254 X	393-3660

JBA		
Original Part Number	**Part Name**	**Classic Part Number**
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

RXS		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0437	Pin	389-6320
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469
111-4332	Plate	396-7290
111-4340	Pin	451-1512

RXS		
Original Part Number	**Part Name**	**Classic Part Number**
111-4343	Pin	390-5272
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
130-1918	Pin As	393-0933
130-5451	Pin	394-9816
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901

RXS		
Original Part Number	**Part Name**	**Classic Part Number**
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 432F

HWP		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610

HWP		
Original Part Number	**Part Name**	**Classic Part Number**
005-0471	Cone-Spl Tapered	415-1924
122-6787	Yoke As	416-2139
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496

HWP		
Original Part Number	**Part Name**	**Classic Part Number**
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153

Sales Model 432F (Cont'd.)

HWP		
Original Part Number	Part Name	Classic Part Number
331-8538	Seal-Wheel	391-9874

HWP		
Original Part Number	Part Name	Classic Part Number
392-6301	Kit-Spider & Brg	390-0915

LNR		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
122-6787	Yoke As	416-2139

LNR		
Original Part Number	Part Name	Classic Part Number
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901

LNR		
Original Part Number	Part Name	Classic Part Number
210-7305	Shaft	396-9952
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

LYJ		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

LYJ		
Original Part Number	Part Name	Classic Part Number
122-6787	Yoke As	416-2139
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981

LYJ		
Original Part Number	Part Name	Classic Part Number
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

PXR		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
122-6787	Yoke As	416-2139

PXR		
Original Part Number	Part Name	Classic Part Number
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901

PXR		
Original Part Number	Part Name	Classic Part Number
210-7305	Shaft	396-9952
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 432F (Cont'd.)

SEJ		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
122-6787	Yoke As	416-2139

SEJ		
Original Part Number	**Part Name**	**Classic Part Number**
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901

SEJ		
Original Part Number	**Part Name**	**Classic Part Number**
210-7305	Shaft	396-9952
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 434E

FSH		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842
9R-0437	Pin	389-6320
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

FSH		
Original Part Number	**Part Name**	**Classic Part Number**
100-6267	Plate As-Idler	375-9983
102-4560	Bearing-Sleeve	347-0469
110-1337	Ring Kit-Pstn	377-5834
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645

FSH		
Original Part Number	**Part Name**	**Classic Part Number**
199-0760	Bearing-Roller	465-8981
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

SEF		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433
6D-1734	Cup-Roller Brg	416-2171

SEF		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610

SEF		
Original Part Number	**Part Name**	**Classic Part Number**
005-0471	Cone-Spl Tapered	415-1924
122-6787	Yoke As	416-2139
154-5279	Pin	392-4529

Sales Model 434E (Cont'd.)

SEF		
Original Part Number	Part Name	Classic Part Number
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645

SEF		
Original Part Number	Part Name	Classic Part Number
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896

SEF		
Original Part Number	Part Name	Classic Part Number
274-4553	Disc-Clutch	416-2153
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

SJL		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
122-6787	Yoke As	416-2139
154-5279	Pin	392-4529
154-5280	Pin	391-9868

SJL		
Original Part Number	Part Name	Classic Part Number
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981
269-0381	Cyl Gp-100 254 X	393-3660

SJL		
Original Part Number	Part Name	Classic Part Number
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

SXB		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0437	Pin	389-6320
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9W-9931	Mount As.	360-2354
102-4560	Bearing-Sleeve	347-0469
122-6787	Yoke As	416-2139

SXB		
Original Part Number	Part Name	Classic Part Number
126-5984	Ring-Backup	419-4654
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024

SXB		
Original Part Number	Part Name	Classic Part Number
237-0944	Bearing-Sleeve	394-0194
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 434F

FLY		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703

Sales Model 434F (Cont'd.)

FLY		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6D-1734	Cup-Roller Brg	416-2171
6V-3831	Seal-O-Ring	436-2657
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
9W-9931	Mount As.	360-2354
9Y-2988	Breather As	361-1716
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

FLY		
Original Part Number	**Part Name**	**Classic Part Number**
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
122-6787	Yoke As	416-2139
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-5279	Pin	392-4529
154-5280	Pin	391-9868
154-8030	Gasket	394-0894
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645

FLY		
Original Part Number	**Part Name**	**Classic Part Number**
199-0760	Bearing-Roller	465-8981
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
269-0381	Cyl Gp-100 254 X	393-3660
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
347-6081	Gauge As	360-2348
392-6301	Kit-Spider & Brg	390-0915
441-9566	Gear-Flywheel	374-4703

HWR		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

HWR		
Original Part Number	**Part Name**	**Classic Part Number**
122-6787	Yoke As	416-2139
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981

HWR		
Original Part Number	**Part Name**	**Classic Part Number**
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

LDH		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353

LDH		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

LDH		
Original Part Number	**Part Name**	**Classic Part Number**
122-6787	Yoke As	416-2139
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515

Sales Model 434F (Cont'd.)

LDH		
Original Part Number	Part Name	Classic Part Number
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645

LDH		
Original Part Number	Part Name	Classic Part Number
199-0760	Bearing-Roller	465-8981
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896

LDH		
Original Part Number	Part Name	Classic Part Number
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

LYK		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

LYK		
Original Part Number	Part Name	Classic Part Number
122-6787	Yoke As	416-2139
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981

LYK		
Original Part Number	Part Name	Classic Part Number
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

MTR		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

MTR		
Original Part Number	Part Name	Classic Part Number
122-6787	Yoke As	416-2139
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645

MTR		
Original Part Number	Part Name	Classic Part Number
199-0760	Bearing-Roller	465-8981
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 436

5KF		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup - Roller Brg	423-7759
1P-7115	Mount As.	418-1936
1S-7057	Gasket	420-6384
2A-4576	Cup - Roller Brg	386-4944

5KF		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2S-0479	Bearing-Cone	380-7506
3E-6772	Seal-Water	382-8017
4T-8054	Seal As.	472-8010
5L-9656	Cone-Bearing	399-4448

5KF		
Original Part Number	Part Name	Classic Part Number
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7K-5448	Cup-Bearing	415-1922

Sales Model 436 (Cont'd.)

5KF		
Original Part Number	**Part Name**	**Classic Part Number**
7T-3038	Gear-Reverse	445-1097
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
7T-3194	Yoke	346-5681
7T-5426	Cone - Roller Brg	453-3657
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As.-Rlr	384-4823
7W-5164	Gasket	420-8568
7W-5194	Muffler As..	346-5682
8E-2043	Yoke As.	385-6115
8S-9151	Cup-Spl Tapered	374-8348
9L-2685	Rod End	419-1866
9R-0080	Coupling	346-5683
9R-0097	Pin	346-5684
9R-0313	Hub As.	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As.-Front	388-6604
9R-1725	Bearing - Sleeve	425-6446
9R-1917	Bearing - Sleeve	418-1958
9R-2410	Retainer As..	346-5688
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690

5KF		
Original Part Number	**Part Name**	**Classic Part Number**
9R-2476	Disc-Bk Rear	346-5691
9R-2477	Disc As.	346-5692
9R-2480	Case As.	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-2601	Rod Gp-Tie	385-6133
9R-2842	Rod-Tie	385-6134
9R-2843	Rod-Tie	385-6135
9R-2846	Pin	346-5694
9R-2857	Rod-Piston	418-9588
9R-3527	Carrier-Planet	396-9892
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-6475	Pad As.	346-5702
9R-8199	Joint-Double	384-4813
9R-8714	Fork	390-0929
9R-8715	Spider As.-Brg&	346-5716
9R-8718	Yoke As.	364-5258
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9S-3581	Cup - Roller Brg	415-1923
9S-3582	Cone - Roller Brg	396-4144
9S-7949	Cup - Roller Brg	420-6531
9Y-9431	Precleaner As.	361-1718

5KF		
Original Part Number	**Part Name**	**Classic Part Number**
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
054-2213	Spider & Brg As.	347-0464
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As.	384-5959
055-1260	Housing Bk-Outer	347-0479
101-3125	Gasket	420-8567
118-5839	Seal-Lip Type	435-8517
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
130-1637	Shaft	347-0471
160-1014	Pin As.	347-0473
166-7870	Pad As.-Street	416-5515
186-4117	Carrier As.	394-8235
186-4118	Gear-Planet	347-0483
226-8202	Seal-Wiper	472-8024
274-4553	Disc-Clutch	416-2153
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 436B

6MJ		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
1S-7057	Gasket	420-6384
2A-4576	Cup - Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9191	Cone - Roller Brg	374-1837

6MJ		
Original Part Number	**Part Name**	**Classic Part Number**
2S-0479	Bearing-Cone	380-7506
3E-4903	Mount As.	396-7274
3P-1210	Cone - Roller Brg	399-4433
4T-8054	Seal As.	472-8010
5J-7010	Seal As.	472-8011
5L-9656	Cone-Bearing	399-4448

6MJ		
Original Part Number	**Part Name**	**Classic Part Number**
6E-0775	Head	425-9373
6E-6153	Plate-Port	346-5678
6E-6163	Shaft	346-5679
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555

Sales Model 436B (Cont'd.)

6MJ		
Original Part Number	Part Name	Classic Part Number
7C-4349	Mount As.	383-2117
7K-5448	Cup-Bearing	415-1922
7T-3038	Gear-Reverse	445-1097
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
7T-3194	Yoke	346-5681
7T-5426	Cone - Roller Brg	453-3657
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As.-Rlr	384-4823
7W-5164	Gasket	420-8568
8E-2043	Yoke As.	385-6115
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0313	Hub As.	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As.-Front	388-6604
9R-1725	Bearing - Sleeve	425-6446
9R-1917	Bearing - Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As.	346-5692
9R-2480	Case As.	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-2601	Rod Gp-Tie	385-6133
9R-2842	Rod-Tie	385-6134
9R-2843	Rod-Tie	385-6135
9R-2846	Pin	346-5694
9R-2857	Rod-Piston	418-9588
9R-3527	Carrier-Planet	396-9892
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-6545	Pin	346-5703
9R-7092	Bar	364-5272
9R-7696	Pin	346-5705
9R-8199	Joint-Double	384-4813

6MJ		
Original Part Number	Part Name	Classic Part Number
9R-8231	Pad As.	397-5066
9R-8235	Pad As.	383-2106
9R-8579	Pin	346-5711
9R-8580	Pin As.	418-1932
9R-8663	Pin	365-8831
9R-8709	Pin	346-5715
9R-8714	Fork	390-0929
9R-8715	Spider As.-Brg&	346-5716
9R-8718	Yoke As.	364-5258
9R-9190	Rod Gp-Tie	346-5718
9R-9400	Case As.	346-5719
9R-9402	Seal-Rax	347-0476
9R-9403	Pinion	347-0477
9R-9475	Bearing - Sleeve	380-7377
9R-9505	Bearing - Sleeve	453-6516
9R-9812	Pin	347-0468
9S-3581	Cup - Roller Brg	415-1923
9S-3582	Cone - Roller Brg	396-4144
9S-7949	Cup - Roller Brg	420-6531
9Y-9431	Precleaner As.	361-1718
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
054-2213	Spider & Brg As.	347-0464
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As.	384-5959
101-3125	Gasket	420-8567
101-4020	Pin As.	396-7285
102-4560	Bearing - Sleeve	347-0469
107-3950	Head	383-1588
110-0013	Cup-Rlr Brg	384-5960
110-0840	Track Rod As..	391-1097
112-1773	Piston	347-0462
118-5839	Seal-Lip Type	435-8517

6MJ		
Original Part Number	Part Name	Classic Part Number
126-5984	Ring-Backup	419-4654
127-8592	Muffler As.	347-0463
127-8594	Muffler As.-Turbo	390-0981
128-4128	Rod Gp-Tie	385-6136
130-0479	Pin As.	415-1907
130-0485	Pin	396-7286
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
134-2659	Rod As.	388-6568
135-8167	Pipe-Extension	395-1305
151-5349	Head	383-1592
154-5279	Pin	392-4529
159-0961	Pin	396-7287
160-1014	Pin As.	347-0473
166-2142	Hub Gp-Shaft	394-8238
166-7870	Pad As.-Street	416-5515
174-7432	Head	388-0660
184-1413	Pin As.	393-1050
186-4117	Carrier As.	394-8235
186-4118	Gear-Planet	347-0483
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing - Sleeve	453-6501
237-0944	Bearing - Sleeve	394-0194
237-2252	Bearing - Sleeve	347-0474
239-9956	Brake Disc	347-0485
251-7319	Bearing - Sleeve	425-6450
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing - Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As..	394-9813
289-2935	Seal As.-Buffer	472-8028

Sales Model 436B (Cont'd.)

6MJ		
Original Part Number	**Part Name**	**Classic Part Number**
289-2946	Seal-U-Cup	472-8030

6MJ		
Original Part Number	**Part Name**	**Classic Part Number**
308-1845	Seal-Wiper	472-8032

7FL		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
1S-7057	Gasket	420-6384
2A-4576	Cup - Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9191	Cone - Roller Brg	374-1837
2S-0479	Bearing-Cone	380-7506
3E-4903	Mount As.	396-7274
3P-1210	Cone - Roller Brg	399-4433
4T-8054	Seal As.	472-8010
5L-9656	Cone-Bearing	399-4448
6E-0775	Head	425-9373
6E-6153	Plate-Port	346-5678
6E-6163	Shaft	346-5679
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7C-4349	Mount As.	383-2117
7K-5448	Cup-Bearing	415-1922
7T-3038	Gear-Reverse	445-1097
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
7T-3194	Yoke	346-5681
7T-5426	Cone - Roller Brg	453-3657
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As.-Rlr	384-4823
7W-5164	Gasket	420-8568
8E-2043	Yoke As.	385-6115
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0313	Hub As.	388-6591

7FL		
Original Part Number	**Part Name**	**Classic Part Number**
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As.-Front	388-6604
9R-1725	Bearing - Sleeve	425-6446
9R-1917	Bearing - Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As.	346-5692
9R-2480	Case As.	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-2601	Rod Gp-Tie	385-6133
9R-2842	Rod-Tie	385-6134
9R-2843	Rod-Tie	385-6135
9R-2846	Pin	346-5694
9R-2857	Rod-Piston	418-9588
9R-3527	Carrier-Planet	396-9892
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8199	Joint-Double	384-4813
9R-8231	Pad As.	397-5066
9R-8235	Pad As.	383-2106
9R-8579	Pin	346-5711
9R-8709	Pin	346-5715
9R-8714	Fork	390-0929
9R-8715	Spider As.-Brg&	346-5716
9R-8718	Yoke As.	364-5258
9R-9190	Rod Gp-Tie	346-5718
9R-9400	Case As.	346-5719
9R-9402	Seal-Rax	347-0476
9R-9403	Pinion	347-0477
9R-9505	Bearing - Sleeve	453-6516
9S-3581	Cup - Roller Brg	415-1923

7FL		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3582	Cone - Roller Brg	396-4144
9S-7949	Cup - Roller Brg	420-6531
9Y-9431	Precleaner As.	361-1718
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
054-2213	Spider & Brg As.	347-0464
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As.	384-5959
101-3125	Gasket	420-8567
102-4560	Bearing - Sleeve	347-0469
110-0013	Cup-Rlr Brg	384-5960
110-0840	Track Rod As..	391-1097
112-1773	Piston	347-0462
118-5839	Seal-Lip Type	435-8517
126-5984	Ring-Backup	419-4654
127-8592	Muffler As.	347-0463
127-8594	Muffler As.-Turbo	390-0981
128-4128	Rod Gp-Tie	385-6136
130-0479	Pin As.	415-1907
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
135-8167	Pipe-Extension	395-1305
154-5279	Pin	392-4529
160-1014	Pin As.	347-0473
166-2142	Hub Gp-Shaft	394-8238
166-7870	Pad As.-Street	416-5515
186-4117	Carrier As.	394-8235
186-4118	Gear-Planet	347-0483

Sales Model 436B (Cont'd.)

7FL		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
236-8183	Bearing - Sleeve	453-6501
239-9956	Brake Disc	347-0485
269-0381	Cyl Gp-100 254 X	393-3660

7FL		
Original Part Number	Part Name	Classic Part Number
274-4274	Bearing - Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554

7FL		
Original Part Number	Part Name	Classic Part Number
278-1972	Cylinder As..	394-9813
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 436C

1FR		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2G-7309	Shaft	393-3682
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3E-6772	Seal-Water	382-8017
3P-1210	Cone-Roller Brg	399-4433
4N-0685	Bearing-Sleeve	379-0191
4N-6658	Bearing-Sleeve	373-1885
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-2726	Bearing-Sleeve	419-4757
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6V-3831	Seal-O-Ring	436-2657
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7C-0307	Gasket	399-8571
7M-7219	Bearing-Thrust	384-4816

1FR		
Original Part Number	Part Name	Classic Part Number
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8D-7086	Bearing	330-9251
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8709	Pin	346-5715
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477

1FR		
Original Part Number	Part Name	Classic Part Number
9R-9505	Bearing-Sleeve	453-6516
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
102-4560	Bearing-Sleeve	347-0469
107-8375	Shaft As	439-1134
110-0840	Track Rod As.	391-1097
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
130-0479	Pin As	415-1907
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
131-7123	Bearing-Sleeve	422-6919
135-8167	Pipe-Extension	395-1305

Sales Model 436C (Cont'd.)

1FR		
Original Part Number	**Part Name**	**Classic Part Number**
151-5349	Head	383-1592
154-5279	Pin	392-4529
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-7870	Pad As-Street	416-5515
166-9142	Gasket	420-8546
172-2349	Cylinder As (Lh)	430-5958
173-1926	Cyl Gp-0102-0541	399-8576
173-1927	Cyl Gp-0102-0541	426-0036
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-9843	Head	347-0461

1FR		
Original Part Number	**Part Name**	**Classic Part Number**
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3827	Pad As.	397-5057
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.- Track	347-0486
229-2950	Rod As.- Track	347-0487
236-8183	Bearing-Sleeve	453-6501
239-9956	Brake Disc	347-0485
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660

1FR		
Original Part Number	**Part Name**	**Classic Part Number**
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
392-6301	Kit-Spider & Brg	390-0915

1GR		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6E-0775	Head	425-9373
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320

1GR		
Original Part Number	**Part Name**	**Classic Part Number**
9R-1572	Wheel As-Front	388-6604
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8709	Pin	346-5715
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9505	Bearing-Sleeve	453-6516
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
102-4560	Bearing-Sleeve	347-0469

1GR		
Original Part Number	**Part Name**	**Classic Part Number**
110-0840	Track Rod As.	391-1097
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
130-0479	Pin As	415-1907
130-1637	Shaft	347-0471
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
135-8167	Pipe-Extension	395-1305
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
172-2349	Cylinder As (Lh)	430-5958

Sales Model 436C (Cont'd.)

1GR		
Original Part Number	Part Name	Classic Part Number
173-1926	Cyl Gp-0102-0541	399-8576
173-1927	Cyl Gp-0102-0541	426-0036
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3827	Pad As.	397-5057
226-8202	Seal-Wiper	472-8024

1GR		
Original Part Number	Part Name	Classic Part Number
229-2949	Rod As.- Track	347-0486
229-2950	Rod As.- Track	347-0487
236-8183	Bearing-Sleeve	453-6501
239-9956	Brake Disc	347-0485
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660

1GR		
Original Part Number	Part Name	Classic Part Number
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

1PR		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2G-7309	Shaft	393-3682
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4T-8054	Seal As	472-8010
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6F-6992	Cap-Ballsocket	297-7160
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634

1PR		
Original Part Number	Part Name	Classic Part Number
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
8D-7086	Bearing	330-9251
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8709	Pin	346-5715
9R-9403	Pinion	347-0477

1PR		
Original Part Number	Part Name	Classic Part Number
9R-9505	Bearing-Sleeve	453-6516
9T-5729	Cyl Gp-0038 0158	422-2486
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655
102-4560	Bearing-Sleeve	347-0469
107-8375	Shaft As	439-1134
110-0840	Track Rod As.	391-1097
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480

Sales Model 436C (Cont'd.)

1PR		
Original Part Number	Part Name	Classic Part Number
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
130-0479	Pin As	415-1907
130-1637	Shaft	347-0471
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
135-8167	Pipe-Extension	395-1305
137-2819	Bearing-Sleeve	360-2317

1PR		
Original Part Number	Part Name	Classic Part Number
137-2919	Bearing-Sleeve	360-2319
148-2593	Head	383-1591
154-5279	Pin	392-4529
163-3749	Bearing-Sleeve	433-7505
166-7870	Pad As-Street	416-5515
172-2349	Cylinder As (Lh)	430-5958
173-1926	Cyl Gp-0102-0541	399-8576
173-1927	Cyl Gp-0102-0541	426-0036
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-9843	Head	347-0461
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3827	Pad As.	397-5057
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322

1PR		
Original Part Number	Part Name	Classic Part Number
229-2949	Rod As.- Track	347-0486
229-2950	Rod As.- Track	347-0487
236-8183	Bearing-Sleeve	453-6501
239-9956	Brake Disc	347-0485
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

1RR		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4T-8054	Seal As	472-8010
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654

1RR		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604

1RR		
Original Part Number	Part Name	Classic Part Number
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8709	Pin	346-5715
9R-9403	Pinion	347-0477
9R-9505	Bearing-Sleeve	453-6516
9T-5729	Cyl Gp-0038 0158	422-2486

Sales Model 436C (Cont'd.)

1RR		
Original Part Number	Part Name	Classic Part Number
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655
102-4560	Bearing-Sleeve	347-0469
110-0840	Track Rod As.	391-1097
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139

1RR		
Original Part Number	Part Name	Classic Part Number
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
130-0479	Pin As	415-1907
130-1637	Shaft	347-0471
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
135-8167	Pipe-Extension	395-1305
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
148-2593	Head	383-1591
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
163-3749	Bearing-Sleeve	433-7505
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
172-2349	Cylinder As (Lh)	430-5958
173-1926	Cyl Gp-0102-0541	399-8576

1RR		
Original Part Number	Part Name	Classic Part Number
173-1927	Cyl Gp-0102-0541	426-0036
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3827	Pad As.	397-5057
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322
229-2949	Rod As.- Track	347-0486
229-2950	Rod As.- Track	347-0487
236-8183	Bearing-Sleeve	453-6501
239-9956	Brake Disc	347-0485
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

2AR		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2G-7309	Shaft	393-3682
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511

2AR		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6D-1734	Cup-Roller Brg	416-2171
6F-6992	Cap-Ballsocket	297-7160
6S-3051	Cup-Rlr Brg	415-1928

2AR		
Original Part Number	Part Name	Classic Part Number
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
7Y-2395	Bearing-Sleeve	314-8646

Sales Model 436C (Cont'd.)

2AR		
Original Part Number	Part Name	Classic Part Number
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
8D-7086	Bearing	330-9251
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604
9R-1917	Bearing-Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8709	Pin	346-5715
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9505	Bearing-Sleeve	453-6516
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486

2AR		
Original Part Number	Part Name	Classic Part Number
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655
102-4560	Bearing-Sleeve	347-0469
107-8375	Shaft As	439-1134
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
130-0479	Pin As	415-1907
130-1637	Shaft	347-0471
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864

2AR		
Original Part Number	Part Name	Classic Part Number
130-5451	Pin	394-9816
130-6879	Seal	347-0482
135-8167	Pipe-Extension	395-1305
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
160-1014	Pin As	347-0473
163-3749	Bearing-Sleeve	433-7505
166-7870	Pad As-Street	416-5515
172-2349	Cylinder As (Lh)	430-5958
173-1926	Cyl Gp-0102-0541	399-8576
173-1927	Cyl Gp-0102-0541	426-0036
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
184-9843	Head	347-0461
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3827	Pad As.	397-5057
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322
229-2949	Rod As.- Track	347-0486
229-2950	Rod As.- Track	347-0487
236-8183	Bearing-Sleeve	453-6501
239-9956	Brake Disc	347-0485
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896

Sales Model 436C (Cont'd.)

2AR		
Original Part Number	Part Name	Classic Part Number
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813

2AR		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

2AR		
Original Part Number	Part Name	Classic Part Number
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

2BR		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604

2BR		
Original Part Number	Part Name	Classic Part Number
9R-1917	Bearing-Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8709	Pin	346-5715
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9505	Bearing-Sleeve	453-6516
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
096-7911	Bearing-Sleeve	314-8653

2BR		
Original Part Number	Part Name	Classic Part Number
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655
102-4560	Bearing-Sleeve	347-0469
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
130-0479	Pin As	415-1907
130-1637	Shaft	347-0471
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
135-8167	Pipe-Extension	395-1305
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319

Sales Model 436C (Cont'd.)

2BR		
Original Part Number	Part Name	Classic Part Number
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
160-1014	Pin As	347-0473
163-3749	Bearing-Sleeve	433-7505
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
172-2349	Cylinder As (Lh)	430-5958
173-1926	Cyl Gp-0102-0541	399-8576
173-1927	Cyl Gp-0102-0541	426-0036

2BR		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3827	Pad As.	397-5057
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322
229-2949	Rod As.- Track	347-0486
229-2950	Rod As.- Track	347-0487
236-8183	Bearing-Sleeve	453-6501
239-9956	Brake Disc	347-0485
250-2398	Pin As	382-8047

2BR		
Original Part Number	Part Name	Classic Part Number
250-2402	Pin As	360-2351
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

8TN		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1W-1064	Gear-Flywheel	374-4703
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2G-7309	Shaft	393-3682
2N-1599	Gear	378-3970
2S-0479	Bearing-Cone	380-7506
2W-7213	Bearing-Sleeve	419-4667
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4B-7270	Cone-Bearing	399-4439
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603

8TN		
Original Part Number	Part Name	Classic Part Number
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6B-3223	Cup-Bearing	399-6065
6D-1734	Cup-Roller Brg	416-2171
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6H-3957	Bearing-Ball	311-9358
6I-4689	Gasket-Cyl Head	377-5840
6S-3051	Cup-Rlr Brg	415-1928
6V-0347	Cone-Spl Tapered	420-6537
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449

8TN		
Original Part Number	Part Name	Classic Part Number
7J-8210	Cone-Roller Brg	423-6987
7K-0084	Bearing-Sleeve	453-6508
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5164	Gasket	420-8568
7W-8064	Valve-Inlet	384-8705
8D-7086	Bearing	330-9251
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-0424	Pin	346-5686

Sales Model 436C (Cont'd.)

8TN		
Original Part Number	Part Name	Classic Part Number
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604
9R-1917	Bearing-Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-4067	Joint Gp-Univ	373-5399
9R-4208	Pin	425-3450
9R-6070	Pin As	393-3681
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-6950	Pinion-Planetary	391-9872
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8709	Pin	346-5715
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9505	Bearing-Sleeve	453-6516
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
9Y-9431	Precleaner As	361-1718
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
054-2213	Spider & Brg As	347-0464
055-1986	Seal-Lip Type	347-0465
100-6267	Plate As-Idler	375-9983

8TN		
Original Part Number	Part Name	Classic Part Number
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
101-3125	Gasket	420-8567
102-4560	Bearing-Sleeve	347-0469
105-2155	Pump Gp-Vn Bsc-A	422-8151
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
116-8539	Spider & Brg Kit	399-4399
118-5839	Seal-Lip Type	435-8517
119-2950	Gasket	433-8195
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
121-7627	Bearing-Roller	453-3653
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
130-0479	Pin As	415-1907
130-1637	Shaft	347-0471
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
135-8167	Pipe-Extension	395-1305
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
148-2593	Head	383-1591

8TN		
Original Part Number	Part Name	Classic Part Number
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
160-1014	Pin As	347-0473
166-7870	Pad As-Street	416-5515
172-2349	Cylinder As (Lh)	430-5958
173-1926	Cyl Gp-0102-0541	399-8576
173-1927	Cyl Gp-0102-0541	426-0036
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
184-9843	Head	347-0461
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3827	Pad As.	397-5057
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.- Track	347-0486
229-2950	Rod As.- Track	347-0487
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-8183	Bearing-Sleeve	453-6501
239-9956	Brake Disc	347-0485
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
271-5658	Crankshaft As.	368-5912
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
277-7089	Shaft As	380-7578
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
286-8903	Cyl Gp-Basic	425-9363

Sales Model 436C (Cont'd.)

8TN		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874

8TN		
Original Part Number	**Part Name**	**Classic Part Number**
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

8TN		
Original Part Number	**Part Name**	**Classic Part Number**
392-6301	Kit-Spider & Brg	390-0915
441-9566	Gear-Flywheel	374-4703

9JN		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1W-1064	Gear-Flywheel	374-4703
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2S-0479	Bearing-Cone	380-7506
2W-7213	Bearing-Sleeve	419-4667
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4B-7270	Cone-Bearing	399-4439
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6I-4689	Gasket-Cyl Head	377-5840
6S-3051	Cup-Rlr Brg	415-1928
6V-0347	Cone-Spl Tapered	420-6537

9JN		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7J-8210	Cone-Roller Brg	423-6987
7K-0084	Bearing-Sleeve	453-6508
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5164	Gasket	420-8568
7W-8064	Valve-Inlet	384-8705
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604
9R-1917	Bearing-Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137

9JN		
Original Part Number	**Part Name**	**Classic Part Number**
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-4067	Joint Gp-Univ	373-5399
9R-4208	Pin	425-3450
9R-6070	Pin As	393-3681
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-6950	Pinion-Planetary	391-9872
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8709	Pin	346-5715
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9505	Bearing-Sleeve	453-6516
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
9Y-9431	Precleaner As	361-1718
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
054-2213	Spider & Brg As	347-0464

Sales Model 436C (Cont'd.)

9JN		
Original Part Number	Part Name	Classic Part Number
055-1986	Seal-Lip Type	347-0465
100-6267	Plate As-Idler	375-9983
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
101-3125	Gasket	420-8567
102-4560	Bearing-Sleeve	347-0469
105-2155	Pump Gp-Vn Bsc-A	422-8151
107-7708	Bearing-Main	419-6381
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
116-8539	Spider & Brg Kit	399-4399
118-5839	Seal-Lip Type	435-8517
119-2950	Gasket	433-8195
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
121-7627	Bearing-Roller	453-3653
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
130-0479	Pin As	415-1907
130-1637	Shaft	347-0471

9JN		
Original Part Number	Part Name	Classic Part Number
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
135-8167	Pipe-Extension	395-1305
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
148-2593	Head	383-1591
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
160-1014	Pin As	347-0473
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
172-2349	Cylinder As (Lh)	430-5958
173-1926	Cyl Gp-0102-0541	399-8576
173-1927	Cyl Gp-0102-0541	426-0036
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
183-2358	Bearing	425-3588
184-9843	Head	347-0461
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3827	Pad As.	397-5057
212-4893	Bearing-Thrust	419-6372

9JN		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.- Track	347-0486
229-2950	Rod As.- Track	347-0487
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-8183	Bearing-Sleeve	453-6501
239-9956	Brake Disc	347-0485
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
271-5658	Crankshaft As.	368-5912
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
277-7089	Shaft As	380-7578
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
286-8903	Cyl Gp-Basic	425-9363
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
392-6301	Kit-Spider & Brg	390-0915
441-9566	Gear-Flywheel	374-4703

Sales Model 438

3DJ		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup - Roller Brg	423-7759
1S-7057	Gasket	420-6384

3DJ		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup - Roller Brg	386-4944
2B-0941	Spacer	418-1955
2S-0479	Bearing-Cone	380-7506

3DJ		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As.	472-8010
5J-7010	Seal As.	472-8011
5L-9656	Cone-Bearing	399-4448

Sales Model 438 (Cont'd.)

3DJ		
Original Part Number	**Part Name**	**Classic Part Number**
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7K-5448	Cup-Bearing	415-1922
7T-3038	Gear-Reverse	445-1097
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
7T-3194	Yoke	346-5681
7T-5426	Cone - Roller Brg	453-3657
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As.-Rlr	384-4823
7W-5164	Gasket	420-8568
8E-2043	Yoke As.	385-6115
8S-9151	Cup-Spl Tapered	374-8348
9L-2685	Rod End	419-1866
9R-0080	Coupling	346-5683
9R-0097	Pin	346-5684
9R-0313	Hub As.	388-6591
9R-0437	Pin	389-6320
9R-1572	Wheel As.-Front	388-6604
9R-1725	Bearing - Sleeve	425-6446
9R-1917	Bearing - Sleeve	418-1958
9R-2410	Retainer As..	346-5688
9R-2419	Kit-Bearing	383-2137

3DJ		
Original Part Number	**Part Name**	**Classic Part Number**
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2476	Disc-Bk Rear	346-5691
9R-2477	Disc As.	346-5692
9R-2480	Case As.	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-2601	Rod Gp-Tie	385-6133
9R-2842	Rod-Tie	385-6134
9R-2843	Rod-Tie	385-6135
9R-2846	Pin	346-5694
9R-2857	Rod-Piston	418-9588
9R-3527	Carrier-Planet	396-9892
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-6475	Pad As.	346-5702
9R-6545	Pin	346-5703
9R-7092	Bar	364-5272
9R-8199	Joint-Double	384-4813
9R-8714	Fork	390-0929
9R-8715	Spider As.-Brg&	346-5716
9R-8718	Yoke As.	364-5258
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9S-3581	Cup - Roller Brg	415-1923
9S-3582	Cone - Roller Brg	396-4144

3DJ		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7949	Cup - Roller Brg	420-6531
9Y-9431	Precleaner As.	361-1718
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
054-2213	Spider & Brg As.	347-0464
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As.	384-5959
055-1260	Housing Bk-Outer	347-0479
101-3125	Gasket	420-8567
118-5839	Seal-Lip Type	435-8517
126-5984	Ring-Backup	419-4654
151-5349	Head	383-1592
166-7870	Pad As.-Street	416-5515
186-4117	Carrier As.	394-8235
186-4118	Gear-Planet	347-0483
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
274-4553	Disc-Clutch	416-2153
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 438B

3KK		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
1S-7057	Gasket	420-6384
2A-4576	Cup - Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9191	Cone - Roller Brg	374-1837

3KK		
Original Part Number	**Part Name**	**Classic Part Number**
2S-0479	Bearing-Cone	380-7506
3E-4903	Mount As.	396-7274
3P-1210	Cone - Roller Brg	399-4433
4T-8054	Seal As.	472-8010
5J-7010	Seal As.	472-8011

3KK		
Original Part Number	**Part Name**	**Classic Part Number**
5L-9656	Cone-Bearing	399-4448
6E-0775	Head	425-9373
6E-6153	Plate-Port	346-5678
6E-6163	Shaft	346-5679
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654

Sales Model 438B (Cont'd.)

3KK		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7C-4349	Mount As.	383-2117
7K-5448	Cup-Bearing	415-1922
7T-3038	Gear-Reverse	445-1097
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
7T-3194	Yoke	346-5681
7T-5426	Cone - Roller Brg	453-3657
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As.-Rlr	384-4823
7W-5164	Gasket	420-8568
8E-2043	Yoke As.	385-6115
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0313	Hub As.	388-6591
9R-0437	Pin	389-6320
9R-1572	Wheel As.-Front	388-6604
9R-1725	Bearing - Sleeve	425-6446
9R-1917	Bearing - Sleeve	418-1958
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As.	346-5692
9R-2480	Case As.	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-2601	Rod Gp-Tie	385-6133
9R-2842	Rod-Tie	385-6134
9R-2843	Rod-Tie	385-6135
9R-2846	Pin	346-5694
9R-2857	Rod-Piston	418-9588
9R-3527	Carrier-Planet	396-9892
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-6545	Pin	346-5703
9R-7092	Bar	364-5272
9R-7696	Pin	346-5705

3KK		
Original Part Number	Part Name	Classic Part Number
9R-8199	Joint-Double	384-4813
9R-8231	Pad As.	397-5066
9R-8235	Pad As.	383-2106
9R-8579	Pin	346-5711
9R-8580	Pin As.	418-1932
9R-8663	Pin	365-8831
9R-8714	Fork	390-0929
9R-8715	Spider As.-Brg&	346-5716
9R-8718	Yoke As.	364-5258
9R-9190	Rod Gp-Tie	346-5718
9R-9400	Case As.	346-5719
9R-9402	Seal-Rax	347-0476
9R-9403	Pinion	347-0477
9R-9475	Bearing - Sleeve	380-7377
9R-9505	Bearing - Sleeve	453-6516
9R-9812	Pin	347-0468
9S-3581	Cup - Roller Brg	415-1923
9S-3582	Cone - Roller Brg	396-4144
9S-7949	Cup - Roller Brg	420-6531
9Y-9431	Precleaner As.	361-1718
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
054-2213	Spider & Brg As.	347-0464
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As.	384-5959
101-3125	Gasket	420-8567
101-4020	Pin As.	396-7285
102-4560	Bearing - Sleeve	347-0469
107-3950	Head	383-1588
110-0013	Cup-Rlr Brg	384-5960
110-0840	Track Rod As..	391-1097
112-1773	Piston	347-0462
118-5839	Seal-Lip Type	435-8517

3KK		
Original Part Number	Part Name	Classic Part Number
126-5984	Ring-Backup	419-4654
127-8592	Muffler As.	347-0463
127-8594	Muffler As.-Turbo	390-0981
128-4128	Rod Gp-Tie	385-6136
130-0479	Pin As.	415-1907
130-0485	Pin	396-7286
134-2659	Rod As.	388-6568
135-8167	Pipe-Extension	395-1305
151-5349	Head	383-1592
154-5279	Pin	392-4529
159-0959	Pin As.	418-9578
159-0961	Pin	396-7287
160-1014	Pin As.	347-0473
164-7174	Cyl Gp-0076-1067	423-7865
166-2142	Hub Gp-Shaft	394-8238
166-7870	Pad As.-Street	416-5515
174-7432	Head	388-0660
184-1413	Pin As.	393-1050
186-4117	Carrier As.	394-8235
186-4118	Gear-Planet	347-0483
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing - Sleeve	453-6501
237-0944	Bearing - Sleeve	394-0194
237-2252	Bearing - Sleeve	347-0474
239-9956	Brake Disc	347-0485
251-7319	Bearing - Sleeve	425-6450
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing - Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As..	394-9813
289-2935	Seal As.-Buffer	472-8028

Sales Model 438B (Cont'd.)

3KK		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030

3KK		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032

Sales Model 438C

1JR		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2G-7309	Shaft	393-3682
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6F-6992	Cap-Ballsocket	297-7160
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8D-7086	Bearing	330-9251
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689

1JR		
Original Part Number	Part Name	Classic Part Number
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-6545	Pin	346-5703
9R-7092	Bar	364-5272
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
107-8375	Shaft As	439-1134
110-0840	Track Rod As.	391-1097
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982

1JR		
Original Part Number	Part Name	Classic Part Number
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
184-9843	Head	347-0461
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867

Sales Model 438C (Cont'd.)

1JR		
Original Part Number	Part Name	Classic Part Number
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.- Track	347-0486
229-2950	Rod As.- Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501

1JR		
Original Part Number	Part Name	Classic Part Number
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660

1JR		
Original Part Number	Part Name	Classic Part Number
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

1TR		
Original Part Number	Part Name	Classic Part Number
193-1684	Pad	396-0645
193-1688	Pad	416-5495
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322
229-2949	Rod As.- Track	347-0486
229-2950	Rod As.- Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194

1TR		
Original Part Number	Part Name	Classic Part Number
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660

1TR		
Original Part Number	Part Name	Classic Part Number
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

2DR		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2G-7309	Shaft	393-3682
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4T-8054	Seal As	472-8010

2DR		
Original Part Number	Part Name	Classic Part Number
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823

2DR		
Original Part Number	Part Name	Classic Part Number
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
8D-7086	Bearing	330-9251
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8S-9151	Cup-Spl Tapered	374-8348

Sales Model 438C (Cont'd.)

2DR		
Original Part Number	Part Name	Classic Part Number
9R-0097	Pin	346-5684
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-6545	Pin	346-5703
9R-7092	Bar	364-5272
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9T-5729	Cyl Gp-0038 0158	422-2486
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469

2DR		
Original Part Number	Part Name	Classic Part Number
107-3950	Head	383-1588
107-8375	Shaft As	439-1134
110-0840	Track Rod As.	391-1097
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
163-3749	Bearing-Sleeve	433-7505
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687

2DR		
Original Part Number	Part Name	Classic Part Number
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
184-9843	Head	347-0461
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322
229-2949	Rod As.- Track	347-0486
229-2950	Rod As.- Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

Sales Model 438C (Cont'd.)

9KN		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2G-7309	Shaft	393-3682
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7M-7219	Bearing-Thrust	384-4816
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8D-7086	Bearing	330-9251
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943

9KN		
Original Part Number	Part Name	Classic Part Number
9R-6163	Pin	346-5701
9R-6545	Pin	346-5703
9R-7092	Bar	364-5272
9R-7696	Pin	346-5705
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
107-8375	Shaft As	439-1134
110-0840	Track Rod As.	391-1097
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
112-5089	Muffler As-Na	390-0982
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
134-2659	Rod As	388-6568

9KN		
Original Part Number	Part Name	Classic Part Number
135-8167	Pipe-Extension	395-1305
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
184-9843	Head	347-0461
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.- Track	347-0486
229-2950	Rod As.- Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153

Sales Model 438C (Cont'd.)

9KN		
Original Part Number	**Part Name**	**Classic Part Number**
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813

9KN		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

9KN		
Original Part Number	**Part Name**	**Classic Part Number**
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

Sales Model 438D

BPE		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4576	Cup-Roller Brg	386-4944
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377

BPE		
Original Part Number	**Part Name**	**Classic Part Number**
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
148-2593	Head	383-1591
151-5349	Head	383-1592

BPE		
Original Part Number	**Part Name**	**Classic Part Number**
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.- Track	347-0486
229-2950	Rod As.- Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
251-7319	Bearing-Sleeve	425-6450
264-2769	Bearing As.-Spl	419-8664

Sales Model 438D (Cont'd.)

BPE		
Original Part Number	**Part Name**	**Classic Part Number**
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153

BPE		
Original Part Number	**Part Name**	**Classic Part Number**
278-0223	Housing-Brake	456-0554
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

BPE		
Original Part Number	**Part Name**	**Classic Part Number**
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

BPN		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4576	Cup-Roller Brg	386-4944
2D-9191	Cone-Roller Brg	374-1837
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
8S-9151	Cup-Spl Tapered	374-8348
9R-0097	Pin	346-5684
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377

BPN		
Original Part Number	**Part Name**	**Classic Part Number**
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
110-0840	Track Rod As.	391-1097
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685

BPN		
Original Part Number	**Part Name**	**Classic Part Number**
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.- Track	347-0486
229-2950	Rod As.- Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
251-7319	Bearing-Sleeve	425-6450
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660

Sales Model 438D (Cont'd.)

BPN		
Original Part Number	**Part Name**	**Classic Part Number**
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554

BPN		
Original Part Number	**Part Name**	**Classic Part Number**
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

BPN		
Original Part Number	**Part Name**	**Classic Part Number**
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

S8J		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462

S8J		
Original Part Number	**Part Name**	**Classic Part Number**
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-5451	Pin	394-9816
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957

S8J		
Original Part Number	**Part Name**	**Classic Part Number**
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
199-0760	Bearing-Roller	465-8981
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

S8M		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555

S8M		
Original Part Number	**Part Name**	**Classic Part Number**
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701

S8M		
Original Part Number	**Part Name**	**Classic Part Number**
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9475	Bearing-Sleeve	380-7377

Sales Model 438D (Cont'd.)

S8M		
Original Part Number	Part Name	Classic Part Number
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-5451	Pin	394-9816
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305

S8M		
Original Part Number	Part Name	Classic Part Number
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
199-0760	Bearing-Roller	465-8981
209-6188	Plate	393-1053

S8M		
Original Part Number	Part Name	Classic Part Number
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 442D

BRG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2D-9191	Cone-Roller Brg	374-1837
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3E-6772	Seal-Water	382-8017
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4T-8054	Seal As	472-8010
4W-2474	Rotocoil As	388-6571

BRG		
Original Part Number	Part Name	Classic Part Number
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654

BRG		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7C-0307	Gasket	399-8571
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7T-6652	Cone-Rlr Bearing	416-2124

Sales Model 442D (Cont'd.)

BRG		
Original Part Number	Part Name	Classic Part Number
7T-7621	Bearing As-Rlr	384-4823
7W-1713	Core Gp-O Clr	438-2010
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
9F-3212	Bearing-Ball	384-5953
9N-3167	Plate-Block Bot	430-4468
9R-0097	Pin	346-5684
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-3125	Gasket	420-8567
101-4020	Pin As	396-7285
101-9640	Gear-Air Compr	398-2966
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
108-7930	Bearing As	377-7463

BRG		
Original Part Number	Part Name	Classic Part Number
110-0840	Track Rod As.	391-1097
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
134-2659	Rod As	388-6568
135-4928	Shaft-Water Pump	386-3813
135-8167	Pipe-Extension	395-1305
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
148-2593	Head	383-1591
151-5349	Head	383-1592
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
154-5278	Pin	393-3685
154-5279	Pin	392-4529

BRG		
Original Part Number	Part Name	Classic Part Number
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
160-9874	Kit-Gasket-Scl	386-3048
164-7174	Cyl Gp-0076-1067	423-7865
166-6352	Tube As.	432-4223
166-7870	Pad As-Street	416-5515
167-8126	Damper As	382-8019
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
186-2001	Rotocoil As	397-5055
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
187-8979	Gear As	393-3656
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
202-3572	Shaft As-Drive	426-0037
209-6188	Plate	393-1053
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
226-8202	Seal-Wiper	472-8024
229-2949	Rod As.- Track	347-0486
229-2950	Rod As.- Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
243-6718	Kit-Brg(Main)	469-1690
251-7319	Bearing-Sleeve	425-6450

Sales Model 442D (Cont'd.)

BRG		
Original Part Number	**Part Name**	**Classic Part Number**
253-1752	Plate-Thrust	379-0170
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554

BRG		
Original Part Number	**Part Name**	**Classic Part Number**
278-1365	Arm As-Ui Rkr	433-7507
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443

BRG		
Original Part Number	**Part Name**	**Classic Part Number**
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
392-6301	Kit-Spider & Brg	390-0915
430-7619	Adapter-Cla	438-1812

BRY		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2D-9191	Cone-Roller Brg	374-1837
2S-0479	Bearing-Cone	380-7506
3E-4924	Mounting As	391-9812
3E-6772	Seal-Water	382-8017
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4T-8054	Seal As	472-8010
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5J-7010	Seal As	472-8011
5L-9656	Cone-Bearing	399-4448
5P-9439	Bearing-Spl Ball	371-4306
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6S-3051	Cup-Rlr Brg	415-1928
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7929	Disc-Friction	456-0555
7C-0307	Gasket	399-8571

BRY		
Original Part Number	**Part Name**	**Classic Part Number**
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
7W-1713	Core Gp-O Clr	438-2010
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
9F-3212	Bearing-Ball	384-5953
9N-3167	Plate-Block Bot	430-4468
9R-0097	Pin	346-5684
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-6161	Pin	374-6505

BRY		
Original Part Number	**Part Name**	**Classic Part Number**
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-1957	Cone-Bearing	420-2502
055-1986	Seal-Lip Type	347-0465
101-3125	Gasket	420-8567
101-4020	Pin As	396-7285
101-9640	Gear-Air Compr	398-2966
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
108-7930	Bearing As	377-7463
110-0840	Track Rod As.	391-1097
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
118-5839	Seal-Lip Type	435-8517

Sales Model 442D (Cont'd.)

BRY		
Original Part Number	Part Name	Classic Part Number
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-5451	Pin	394-9816
130-6879	Seal	347-0482
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
134-2659	Rod As	388-6568
135-4928	Shaft-Water Pump	386-3813
135-8167	Pipe-Extension	395-1305
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
148-2593	Head	383-1591
151-5349	Head	383-1592
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117

BRY		
Original Part Number	Part Name	Classic Part Number
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
160-9874	Kit-Gasket-Scl	386-3048
164-7174	Cyl Gp-0076-1067	423-7865
166-6352	Tube As.	432-4223
166-7870	Pad As-Street	416-5515
167-8126	Damper As	382-8019
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
186-2001	Rotocoil As	397-5055
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
187-8979	Gear As	393-3656
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
202-3572	Shaft As-Drive	426-0037
209-6188	Plate	393-1053
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
226-8202	Seal-Wiper	472-8024

BRY		
Original Part Number	Part Name	Classic Part Number
229-2949	Rod As.- Track	347-0486
229-2950	Rod As.- Track	347-0487
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
239-9956	Brake Disc	347-0485
243-6718	Kit-Brg(Main)	469-1690
251-7319	Bearing-Sleeve	425-6450
253-1752	Plate-Thrust	379-0170
264-2769	Bearing As.-Spl	419-8664
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-0223	Housing-Brake	456-0554
278-1365	Arm As-Ui Rkr	433-7507
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
392-6301	Kit-Spider & Brg	390-0915
430-7619	Adapter-Cla	438-1812

S4T		
Original Part Number	Part Name	Classic Part Number
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555

S4T		
Original Part Number	Part Name	Classic Part Number
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701

S4T		
Original Part Number	Part Name	Classic Part Number
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9475	Bearing-Sleeve	380-7377

Sales Model 442D (Cont'd.)

S4T		
Original Part Number	Part Name	Classic Part Number
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-4020	Pin As	396-7285
102-4560	Bearing-Sleeve	347-0469
107-3950	Head	383-1588
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-5451	Pin	394-9816
134-2659	Rod As	388-6568
135-8167	Pipe-Extension	395-1305

S4T		
Original Part Number	Part Name	Classic Part Number
148-2593	Head	383-1591
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
164-7174	Cyl Gp-0076-1067	423-7865
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
174-7432	Head	388-0660
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
199-0760	Bearing-Roller	465-8981
209-6188	Plate	393-1053

S4T		
Original Part Number	Part Name	Classic Part Number
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
251-7319	Bearing-Sleeve	425-6450
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

SMJ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2D-9191	Cone-Roller Brg	374-1837
3E-4924	Mounting As	391-9812
3E-6772	Seal-Water	382-8017
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4T-8054	Seal As	472-8010
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5J-7010	Seal As	472-8011

SMJ		
Original Part Number	Part Name	Classic Part Number
6D-1734	Cup-Roller Brg	416-2171
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6S-3051	Cup-Rlr Brg	415-1928
6Y-7929	Disc-Friction	456-0555
7C-0307	Gasket	399-8571
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724

SMJ		
Original Part Number	Part Name	Classic Part Number
7W-1713	Core Gp-O Clr	438-2010
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
8S-6511	Bearing-Sleeve	380-7372
9F-3212	Bearing-Ball	384-5953
9N-3167	Plate-Block Bot	430-4468
9R-0097	Pin	346-5684
9R-0437	Pin	389-6320
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-7092	Bar	364-5272
9R-8579	Pin	346-5711
9R-8663	Pin	365-8831
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516

Sales Model 442D (Cont'd.)

SMJ		
Original Part Number	Part Name	Classic Part Number
9R-9812	Pin	347-0468
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-3125	Gasket	420-8567
101-4020	Pin As	396-7285
101-9640	Gear-Air Compr	398-2966
102-4560	Bearing-Sleeve	347-0469
108-7930	Bearing As	377-7463
110-0840	Track Rod As.	391-1097
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
112-1773	Piston	347-0462
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
126-5984	Ring-Backup	419-4654
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-0485	Pin	396-7286
130-1918	Pin As	393-0933
130-5451	Pin	394-9816
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
134-2659	Rod As	388-6568
135-4928	Shaft-Water Pump	386-3813

SMJ		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
151-5349	Head	383-1592
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
160-9874	Kit-Gasket-Scl	386-3048
164-7174	Cyl Gp-0076-1067	423-7865
166-6352	Tube As.	432-4223
166-7870	Pad As-Street	416-5515
167-8126	Damper As	382-8019
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
186-2001	Rotocoil As	397-5055
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
187-8979	Gear As	393-3656
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
202-3572	Shaft As-Drive	426-0037
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901

SMJ		
Original Part Number	Part Name	Classic Part Number
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
236-8183	Bearing-Sleeve	453-6501
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
243-6718	Kit-Brg(Main)	469-1690
251-7319	Bearing-Sleeve	425-6450
253-1752	Plate-Thrust	379-0170
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1365	Arm As-Ui Rkr	433-7507
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915
430-7619	Adapter-Cla	438-1812

Sales Model 442E

EME		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
111-4332	Plate	396-7290

EME		
Original Part Number	Part Name	Classic Part Number
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645

EME		
Original Part Number	Part Name	Classic Part Number
199-0760	Bearing-Roller	465-8981
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

GKZ		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
5J-7010	Seal As	472-8011
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842
9R-0437	Pin	389-6320
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983

GKZ		
Original Part Number	Part Name	Classic Part Number
102-4560	Bearing-Sleeve	347-0469
110-1337	Ring Kit-Pstn	377-5834
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-5451	Pin	394-9816
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513

GKZ		
Original Part Number	Part Name	Classic Part Number
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

PCR		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
5J-7010	Seal As	472-8011
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555

PCR		
Original Part Number	Part Name	Classic Part Number
6Y-9930	Mount As	360-2353
9R-0437	Pin	389-6320
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9W-9931	Mount As.	360-2354

PCR		
Original Part Number	Part Name	Classic Part Number
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
102-4560	Bearing-Sleeve	347-0469

Sales Model 442E (Cont'd.)

PCR		
Original Part Number	Part Name	Classic Part Number
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
125-1037	Pin As	375-9985
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-5451	Pin	394-9816
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868

PCR		
Original Part Number	Part Name	Classic Part Number
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901
210-7305	Shaft	396-9952
226-8202	Seal-Wiper	472-8024
262-7044	Bearing	418-1948

PCR		
Original Part Number	Part Name	Classic Part Number
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 444E

HXB		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9R-0437	Pin	389-6320
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9W-9931	Mount As.	360-2354
102-4560	Bearing-Sleeve	347-0469

HXB		
Original Part Number	Part Name	Classic Part Number
122-6787	Yoke As	416-2139
126-5984	Ring-Backup	419-4654
130-2533	Pin	396-7265
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645

HXB		
Original Part Number	Part Name	Classic Part Number
199-0760	Bearing-Roller	465-8981
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

LBE		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3E-4924	Mounting As	391-9812
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353

LBE		
Original Part Number	Part Name	Classic Part Number
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8N-3666	Repair Kt-Major	377-5842
9R-0437	Pin	389-6320
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610

LBE		
Original Part Number	Part Name	Classic Part Number
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
102-4560	Bearing-Sleeve	347-0469
110-1337	Ring Kit-Pstn	377-5834
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139

Sales Model 444E (Cont'd.)

LBE		
Original Part Number	Part Name	Classic Part Number
126-5984	Ring-Backup	419-4654
130-2533	Pin	396-7265
151-5349	Head	383-1592
154-5278	Pin	393-3685
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479

LBE		
Original Part Number	Part Name	Classic Part Number
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981
209-6188	Plate	393-1053
226-8202	Seal-Wiper	472-8024
262-7044	Bearing	418-1948
269-0381	Cyl Gp-100 254 X	393-3660

LBE		
Original Part Number	Part Name	Classic Part Number
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
278-1972	Cylinder As.	394-9813
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

NBA		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
4T-8054	Seal As	472-8010
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
122-6787	Yoke As	416-2139
154-5279	Pin	392-4529

NBA		
Original Part Number	Part Name	Classic Part Number
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981

NBA		
Original Part Number	Part Name	Classic Part Number
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 444F

FBN		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6D-1734	Cup-Roller Brg	416-2171
6V-3831	Seal-O-Ring	436-2657
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449

FBN		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
9W-9931	Mount As.	360-2354
9Y-2988	Breather As	361-1716
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
122-6787	Yoke As	416-2139
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

FBN		
Original Part Number	Part Name	Classic Part Number
154-5279	Pin	392-4529
154-5280	Pin	391-9868
154-8030	Gasket	394-0894
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

Sales Model 444F (Cont'd.)

FBN		
Original Part Number	**Part Name**	**Classic Part Number**
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
269-0381	Cyl Gp-100 254 X	393-3660

FBN		
Original Part Number	**Part Name**	**Classic Part Number**
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153

FBN		
Original Part Number	**Part Name**	**Classic Part Number**
331-8538	Seal-Wheel	391-9874
347-6081	Gauge As	360-2348
392-6301	Kit-Spider & Brg	390-0915
441-9566	Gear-Flywheel	374-4703

HWS		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
122-6787	Yoke As	416-2139

HWS		
Original Part Number	**Part Name**	**Classic Part Number**
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645

HWS		
Original Part Number	**Part Name**	**Classic Part Number**
199-0760	Bearing-Roller	465-8981
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

JXR		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
122-6787	Yoke As	416-2139
154-5279	Pin	392-4529
154-5280	Pin	391-9868

JXR		
Original Part Number	**Part Name**	**Classic Part Number**
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981
269-0381	Cyl Gp-100 254 X	393-3660

JXR		
Original Part Number	**Part Name**	**Classic Part Number**
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

LJJ		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
122-6787	Yoke As	416-2139
154-5279	Pin	392-4529
154-5280	Pin	391-9868

LJJ		
Original Part Number	**Part Name**	**Classic Part Number**
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645
199-0760	Bearing-Roller	465-8981
269-0381	Cyl Gp-100 254 X	393-3660

LJJ		
Original Part Number	**Part Name**	**Classic Part Number**
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 444F (Cont'd.)

LYL		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
122-6787	Yoke As	416-2139

LYL		
Original Part Number	Part Name	Classic Part Number
154-5279	Pin	392-4529
154-5280	Pin	391-9868
166-7870	Pad As-Street	416-5515
168-0444	Pin	393-3687
178-8608	Cone	422-6479
184-1413	Pin As	393-1050
193-1683	Pad	416-5496
193-1684	Pad	396-0645

LYL		
Original Part Number	Part Name	Classic Part Number
199-0760	Bearing-Roller	465-8981
269-0381	Cyl Gp-100 254 X	393-3660
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 446

6XF		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1P-2636	Cup - Roller Brg	396-4147
1P-2662	Cone - Roller Brg	374-1851
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1W-1064	Gear - Flywheel	374-4703
2A-4576	Cup - Roller Brg	386-4944
2N-1599	Gear	378-3970
2S-0479	Bearing-Cone	380-7506
2W-7213	Bearing - Sleeve	419-4667
3E-4924	Mounting As.	391-9812
4B-7270	Cone-Bearing	399-4439
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As.-Arm	457-4596
4P-8577	Rod As.-Injector	455-5513
4T-0998	Lever	314-8687
4T-8054	Seal As.	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5L-9656	Cone-Bearing	399-4448
6B-3223	Cup-Bearing	399-6065

6XF		
Original Part Number	Part Name	Classic Part Number
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6I-4689	Gasket-Cyl Head	377-5840
6S-3051	Cup-Rlr Brg	415-1928
6V-0347	Cone-Spl Tapered	420-6537
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7929	Disc-Friction	456-0555
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As.-Injector	433-0449
7E-7302	Bracket	416-5497
7J-8210	Cone - Roller Brg	423-6987
7K-5448	Cup-Bearing	415-1922
7T-3038	Gear-Reverse	445-1097
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
7T-3194	Yoke	346-5681
7T-5426	Cone - Roller Brg	453-3657
7T-7621	Bearing As.-Rlr	384-4823
7W-3773	Pulley-Cshaft	383-1583

6XF		
Original Part Number	Part Name	Classic Part Number
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As..	378-3986
7W-5164	Gasket	420-8568
7W-8064	Valve-Inlet	384-8705
8E-2043	Yoke As.	385-6115
8H-2810	Case As.-Filter	314-8512
8S-0248	Breather As.	325-6033
9R-0313	Hub As.	388-6591
9R-0424	Pin	346-5686
9R-1572	Wheel As.-Front	388-6604
9R-1725	Bearing - Sleeve	425-6446
9R-1917	Bearing - Sleeve	418-1958
9R-2480	Case As.	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-2601	Rod Gp-Tie	385-6133
9R-2842	Rod-Tie	385-6134
9R-2843	Rod-Tie	385-6135
9R-2846	Pin	346-5694
9R-2857	Rod-Piston	418-9588
9R-3527	Carrier-Planet	396-9892
9R-4067	Joint Gp-Univ	373-5399
9R-4208	Pin	425-3450
9R-6070	Pin As.	393-3681
9R-6163	Pin	346-5701
9R-6950	Pinion-Planetary	391-9872

Sales Model 446 (Cont'd.)

6XF		
Original Part Number	**Part Name**	**Classic Part Number**
9R-8199	Joint-Double	384-4813
9R-8231	Pad As.	397-5066
9R-8235	Pad As.	383-2106
9R-8714	Fork	390-0929
9R-8715	Spider As.-Brg&	346-5716
9R-8718	Yoke As.	364-5258
9R-9190	Rod Gp-Tie	346-5718
9R-9403	Pinion	347-0477
9R-9505	Bearing - Sleeve	453-6516
9S-3581	Cup - Roller Brg	415-1923
9S-3582	Cone - Roller Brg	396-4144
9S-7949	Cup - Roller Brg	420-6531
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
9Y-9431	Precleaner As.	361-1718
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
054-2213	Spider & Brg As.	347-0464
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As.	384-5959

6XF		
Original Part Number	**Part Name**	**Classic Part Number**
100-6267	Plate As.-Idler	375-9983
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
101-3125	Gasket	420-8567
105-2155	Pump Gp-VN Bsc-A	422-8151
107-7708	Bearing-Main	419-6381
112-1773	Piston	347-0462
113-6200	Gasket	438-2020
115-4204	Pulley As.-Idler	301-5219
115-4237	Pulley-Idler	374-4693
116-8539	Spider & Brg Kit	399-4399
119-2950	Gasket	433-8195
121-7627	Bearing-Roller	453-3653
126-5984	Ring-Backup	419-4654
128-4128	Rod Gp-Tie	385-6136
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388

6XF		
Original Part Number	**Part Name**	**Classic Part Number**
152-3952	Impeller-Pump	374-4696
160-1014	Pin As.	347-0473
166-7870	Pad As.-Street	416-5515
184-9843	Head	347-0461
187-3827	Pad As..	397-5057
212-4893	Bearing - Thrust	419-6372
213-3193	Rod As.-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing - Thrust	419-6370
229-5154	Bearing - Thrust	419-6369
271-5658	Crankshaft As..	368-5912
274-4274	Bearing - Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
277-7089	Shaft As.	380-7578
286-8903	Cyl Gp-Basic	425-9363
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear - Flywheel	374-4703

Sales Model 446B

5BL		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1P-2636	Cup - Roller Brg	396-4147
1P-2662	Cone - Roller Brg	374-1851
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294

5BL		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear - Flywheel	374-4703
2A-4576	Cup - Roller Brg	386-4944
2N-1599	Gear	378-3970
2S-0479	Bearing-Cone	380-7506
2W-7213	Bearing - Sleeve	419-4667

5BL		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4924	Mounting As.	391-9812
4B-7270	Cone-Bearing	399-4439
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As.-Arm	457-4596
4P-8577	Rod As.-Injector	455-5513

Sales Model 446B (Cont'd.)

5BL		
Original Part Number	Part Name	Classic Part Number
4T-0998	Lever	314-8687
4T-8054	Seal As.	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5L-9656	Cone-Bearing	399-4448
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6I-4689	Gasket-Cyl Head	377-5840
6S-3051	Cup-Rlr Brg	415-1928
6V-0347	Cone-Spl Tapered	420-6537
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7929	Disc-Friction	456-0555
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As.-Injector	433-0449
7E-7302	Bracket	416-5497
7J-8210	Cone - Roller Brg	423-6987
7K-0084	Bearing - Sleeve	453-6508
7K-5448	Cup-Bearing	415-1922
7T-7621	Bearing As.-Rlr	384-4823
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As..	378-3986
7W-5164	Gasket	420-8568
7W-8064	Valve-Inlet	384-8705
8H-2810	Case As.-Filter	314-8512
8S-0248	Breather As.	325-6033
9R-0424	Pin	346-5686
9R-1572	Wheel As.-Front	388-6604
9R-1917	Bearing - Sleeve	418-1958

5BL		
Original Part Number	Part Name	Classic Part Number
9R-2480	Case As.	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-4067	Joint Gp-Univ	373-5399
9R-4208	Pin	425-3450
9R-6070	Pin As.	393-3681
9R-6163	Pin	346-5701
9R-6950	Pinion-Planetary	391-9872
9R-8231	Pad As.	397-5066
9R-8235	Pad As.	383-2106
9R-9403	Pinion	347-0477
9R-9505	Bearing - Sleeve	453-6516
9S-3581	Cup - Roller Brg	415-1923
9S-3582	Cone - Roller Brg	396-4144
9S-7949	Cup - Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
9Y-9431	Precleaner As.	361-1718
054-2213	Spider & Brg As.	347-0464
100-6267	Plate As.-Idler	375-9983
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
101-3125	Gasket	420-8567
105-2155	Pump Gp-VN Bsc-A	422-8151
107-7708	Bearing-Main	419-6381
112-1773	Piston	347-0462
113-6200	Gasket	438-2020
115-4204	Pulley As.-Idler	301-5219
115-4237	Pulley-Idler	374-4693
116-8539	Spider & Brg Kit	399-4399

5BL		
Original Part Number	Part Name	Classic Part Number
119-2950	Gasket	433-8195
121-7627	Bearing-Roller	453-3653
126-5984	Ring-Backup	419-4654
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
166-7870	Pad As.-Street	416-5515
184-9843	Head	347-0461
187-3827	Pad As..	397-5057
212-4893	Bearing - Thrust	419-6372
213-3193	Rod As.-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing - Thrust	419-6370
229-5154	Bearing - Thrust	419-6369
271-5658	Crankshaft As..	368-5912
274-4274	Bearing - Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
277-7089	Shaft As.	380-7578
286-8903	Cyl Gp-Basic	425-9363
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear - Flywheel	374-4703

DBL		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1P-2636	Cup - Roller Brg	396-4147
1P-2662	Cone - Roller Brg	374-1851
1S-7057	Gasket	420-6384
1W-1064	Gear - Flywheel	374-4703
2A-4576	Cup - Roller Brg	386-4944
2N-1599	Gear	378-3970
2S-0479	Bearing-Cone	380-7506
2W-7213	Bearing - Sleeve	419-4667
3E-4924	Mounting As.	391-9812
4B-7270	Cone-Bearing	399-4439
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As.-Arm	457-4596
4P-8577	Rod As.-Injector	455-5513
4T-0998	Lever	314-8687
4T-8054	Seal As.	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5L-9656	Cone-Bearing	399-4448
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6I-4689	Gasket-Cyl Head	377-5840
6S-3051	Cup-Rlr Brg	415-1928
6V-0347	Cone-Spl Tapered	420-6537
6V-0832	Cone-Rlr Bearing	453-3654
6Y-7929	Disc-Friction	456-0555
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As.-Injector	433-0449

DBL		
Original Part Number	**Part Name**	**Classic Part Number**
7J-8210	Cone - Roller Brg	423-6987
7K-0084	Bearing - Sleeve	453-6508
7K-5448	Cup-Bearing	415-1922
7T-7621	Bearing As.-Rlr	384-4823
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As..	378-3986
7W-8064	Valve-Inlet	384-8705
8H-2810	Case As.-Filter	314-8512
8S-0248	Breather As.	325-6033
9R-1917	Bearing - Sleeve	418-1958
9R-2480	Case As.	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-4067	Joint Gp-Univ	373-5399
9R-4208	Pin	425-3450
9R-6070	Pin As.	393-3681
9R-6163	Pin	346-5701
9R-6950	Pinion-Planetary	391-9872
9R-8231	Pad As.	397-5066
9R-8235	Pad As.	383-2106
9R-9403	Pinion	347-0477
9R-9505	Bearing - Sleeve	453-6516
9S-3581	Cup - Roller Brg	415-1923
9S-3582	Cone - Roller Brg	396-4144
9S-7949	Cup - Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
9Y-9431	Precleaner As.	361-1718
054-2213	Spider & Brg As.	347-0464
100-6267	Plate As.-Idler	375-9983

DBL		
Original Part Number	**Part Name**	**Classic Part Number**
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
105-2155	Pump Gp-VN Bsc-A	422-8151
107-7708	Bearing-Main	419-6381
112-1773	Piston	347-0462
113-6200	Gasket	438-2020
115-4204	Pulley As.-Idler	301-5219
115-4237	Pulley-Idler	374-4693
116-8539	Spider & Brg Kit	399-4399
119-2950	Gasket	433-8195
121-7627	Bearing-Roller	453-3653
126-5984	Ring-Backup	419-4654
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
187-3827	Pad As..	397-5057
212-4893	Bearing - Thrust	419-6372
213-3193	Rod As.-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing - Thrust	419-6370
229-5154	Bearing - Thrust	419-6369
271-5658	Crankshaft As..	368-5912
274-4274	Bearing - Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
277-7089	Shaft As.	380-7578
286-8903	Cyl Gp-Basic	425-9363

Sales Model 446D (Cont'd.)

DBL		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As.-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

DBL		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107

DBL		
Original Part Number	Part Name	Classic Part Number
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear - Flywheel	374-4703

Sales Model 450E

EBL		
Original Part Number	Part Name	Classic Part Number
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
4W-7188	Core As-Oclr	374-7501
6D-1734	Cup-Roller Brg	416-2171
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353
7K-0084	Bearing-Sleeve	453-6508

EBL		
Original Part Number	Part Name	Classic Part Number
9W-9931	Mount As.	360-2354
122-6787	Yoke As	416-2139
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153

EBL		
Original Part Number	Part Name	Classic Part Number
286-8903	Cyl Gp-Basic	425-9363
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

LYR		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
4W-7188	Core As-Oclr	374-7501
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353

LYR		
Original Part Number	Part Name	Classic Part Number
9W-9931	Mount As.	360-2354
122-6787	Yoke As	416-2139
178-8608	Cone	422-6479
274-4274	Bearing-Sleeve	391-9896

LYR		
Original Part Number	Part Name	Classic Part Number
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

RBA		
Original Part Number	Part Name	Classic Part Number
3E-4924	Mounting As	391-9812
4T-8054	Seal As	472-8010
4W-7188	Core As-Oclr	374-7501
6D-1734	Cup-Roller Brg	416-2171
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6Y-7929	Disc-Friction	456-0555
6Y-9930	Mount As	360-2353

RBA		
Original Part Number	Part Name	Classic Part Number
9W-9931	Mount As.	360-2354
122-6787	Yoke As	416-2139
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
237-0944	Bearing-Sleeve	394-0194
274-4274	Bearing-Sleeve	391-9896

RBA		
Original Part Number	Part Name	Classic Part Number
274-4553	Disc-Clutch	416-2153
286-8903	Cyl Gp-Basic	425-9363
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model 450F

HJR		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433
6D-1734	Cup-Roller Brg	416-2171
6Y-7929	Disc-Friction	456-0555

HJR		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354
122-6787	Yoke As	416-2139
178-8608	Cone	422-6479
274-4274	Bearing-Sleeve	391-9896

HJR		
Original Part Number	**Part Name**	**Classic Part Number**
274-4553	Disc-Clutch	416-2153
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Cat Classic Parts for Older Engines



Cat Classic parts are available for the following Engine models: D353C/D/E; D379/B; D398/B; D399; G353D; G379; G398; G399. First produced by Caterpillar more than four decades ago, thousands of these engines are still heavily relied upon in a variety of petroleum, marine, and prime power applications. As. these engines age, maintenance costs sometimes need to be re-evaluated.

Cat Classic parts provide owners of older Cat products with low cost Repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts offeRings for engines include:

- Air, Manifold, & Outlet Elbows
- Cooler Core
- Cylinder Liner
- Front & Upper Manifolds
- Fuel Injection Lines & Pumps
- Fuel Transfer Pumps
- Gaskets
- Inlet & Exhaust Valves
- Pistons
- ...and many more.

Sales Model 1140

36B		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-8271	Arm As-Rocker	432-8912
5P-7807	Bearing-Ball	314-8502
5P-8545	Gasket Kit	437-8626
5S-5917	Screw-Rocker Adj	380-7537
7E-2888	Gear-Fuel Pump	397-5062

36B		
Original Part Number	**Part Name**	**Classic Part Number**
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7F-2742	Bearing-Ball	422-6488
7M-7219	Bearing-Thrust	384-4816
7W-2059	Gasket-Cyl Hd	380-1548
8N-0701	Bearing-Sleeve	419-4745
9L-7682	Valve-Inlet	385-9266

36B		
Original Part Number	**Part Name**	**Classic Part Number**
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
119-6772	Valve-Exhaust	384-8699
234-7989	Kit-Gasket-Sch	437-8122

Sales Model 1145

97B		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

97B		
Original Part Number	**Part Name**	**Classic Part Number**
2W-8271	Arm As-Rocker	432-8912
5P-7807	Bearing-Ball	314-8502

97B		
Original Part Number	**Part Name**	**Classic Part Number**
5P-8545	Gasket Kit	437-8626
5S-5917	Screw-Rocker Adj	380-7537

Sales Model 1145 (Cont'd.)

97B		
Original Part Number	Part Name	Classic Part Number
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7F-2742	Bearing-Ball	422-6488
7M-7219	Bearing-Thrust	384-4816

97B		
Original Part Number	Part Name	Classic Part Number
7W-2059	Gasket-Cyl Hd	380-1548
8N-0701	Bearing-Sleeve	419-4745
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772

97B		
Original Part Number	Part Name	Classic Part Number
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
119-6772	Valve-Exhaust	384-8699
234-7989	Kit-Gasket-Sch	437-8122

Sales Model 1150

96B		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-8271	Arm As-Rocker	432-8912
5P-7807	Bearing-Ball	314-8502
5P-8545	Gasket Kit	437-8626
5S-5917	Screw-Rocker Adj	380-7537
7E-2888	Gear-Fuel Pump	397-5062

96B		
Original Part Number	Part Name	Classic Part Number
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7F-2742	Bearing-Ball	422-6488
7M-7219	Bearing-Thrust	384-4816
7W-2059	Gasket-Cyl Hd	380-1548
8N-0701	Bearing-Sleeve	419-4745
9L-7682	Valve-Inlet	385-9266

96B		
Original Part Number	Part Name	Classic Part Number
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
119-6772	Valve-Exhaust	384-8699
234-7989	Kit-Gasket-Sch	437-8122

Sales Model 1160

57V		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2B-0941	Spacer	418-1955
2W-8271	Arm As-Rocker	432-8912
2W-8271	Arm As-Rocker	432-8912
4N-0209	Bonnet-Valve	378-3973
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059

57V		
Original Part Number	Part Name	Classic Part Number
4N-2954	Sleeve-Camshaft	299-2059
5P-7807	Bearing-Ball	314-8502
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5S-5917	Screw-Rocker Adj	380-7537
7E-2888	Gear-Fuel Pump	397-5062
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7E-7894	Bearing-Rod	419-7260
7M-7219	Bearing-Thrust	384-4816

57V		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7W-2059	Gasket-Cyl Hd	380-1548
7W-2059	Gasket-Cyl Hd	380-1548
8N-0701	Bearing-Sleeve	419-4745
8N-0701	Bearing-Sleeve	419-4745
9L-7682	Valve-Inlet	385-9266
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6221	Crankshaft As	368-5914

Sales Model 1160 (Cont'd.)

57V		
Original Part Number	Part Name	Classic Part Number
9N-6500	Rod-Valve Push	383-3706
9N-6500	Rod-Valve Push	383-3706
9Y-0231	Line As-F Inj	390-0932
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0232	Line As-F Inj	390-0933

57V		
Original Part Number	Part Name	Classic Part Number
9Y-0233	Line As-F Inj	390-0934
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937

57V		
Original Part Number	Part Name	Classic Part Number
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
9Y-0238	Line As-F Inj	390-0939
119-6772	Valve-Exhaust	384-8699
119-6772	Valve-Exhaust	384-8699

95B		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-8271	Arm As-Rocker	432-8912
4D-2619	Bearing	417-4494
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
5P-7807	Bearing-Ball	314-8502
5P-8545	Gasket Kit	437-8626
5S-5917	Screw-Rocker Adj	380-7537

95B		
Original Part Number	Part Name	Classic Part Number
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7F-2742	Bearing-Ball	422-6488
7M-7219	Bearing-Thrust	384-4816
7W-2059	Gasket-Cyl Hd	380-1548
8N-0701	Bearing-Sleeve	419-4745
9B-1320	Valve-Check	377-5832
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772

95B		
Original Part Number	Part Name	Classic Part Number
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
119-6772	Valve-Exhaust	384-8699
234-7989	Kit-Gasket-Sch	437-8122

Sales Model 1506

XGN		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
2W-8494	Pulley-Alt	295-5692
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603

XGN		
Original Part Number	Part Name	Classic Part Number
4W-2042	Spacer	325-6217
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6V-2202	Bearing-Spl Ball	380-1574
115-4072	Bearing	397-5069

XGN		
Original Part Number	Part Name	Classic Part Number
115-4237	Pulley-Idler	374-4693
161-3411	Gasket	394-0896
229-1490	Sleeve-Injector	393-3659

Sales Model 1670

61B		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
3S-9466	Bearing-Sleeve	314-8509
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
6B-6224	Ferrule	419-4738
6L-8968	Coupling-Exhaust	311-9381

61B		
Original Part Number	**Part Name**	**Classic Part Number**
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-4358	Manifold-Exhaust	261-0907
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7N-9805	Pin-Piston	295-6438
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512

61B		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-2685	Rod End	419-1866
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166
232-3233	Bearing-Main	376-9085

Sales Model 1673

70B		
Original Part Number	**Part Name**	**Classic Part Number**
1M-0090	Gasket-Manifold	445-7701
1S-5331	Cylinder-Adj	226-0214
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-7984	Yoke As-Idler	226-0220
2S-4015	Plunger As-Valve	311-9438
2S-6265	Rod Gp-Recoil	226-0197
3P-1459	Spring-Recoil	375-5448
3S-9466	Bearing-Sleeve	314-8509
4F-5004	Spring As-Arm	383-2128
5H-7071	Director-Water	388-0555
5L-7632	Support-Elbow	433-9854

70B		
Original Part Number	**Part Name**	**Classic Part Number**
5L-8856	Coupling-Exhaust	311-9379
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
6B-6224	Ferrule	419-4738
6L-4716	Gasket-Exhaust	398-2951
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207

70B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-9789	Bearing-Ball	374-8342
8M-6191	Sleeve-Bolt	226-0234
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377

Sales Model 1673 (Cont'd.)

70B		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8222	Bearing-Conn Rod	419-6322
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
9G-8303	Collar-Idler End	226-0242

70B		
Original Part Number	**Part Name**	**Classic Part Number**
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-2685	Rod End	419-1866
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934

70B		
Original Part Number	**Part Name**	**Classic Part Number**
108-5603	Screw-Adj Arm	379-0166
124-3237	Precleaner As	432-4220
169-4200	Gasket	472-8023
232-3233	Bearing-Main	376-9085

74B		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
3N-3368	Pipe-Exhaust	311-9434
3S-9466	Bearing-Sleeve	314-8509
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5S-1833	Chamber As	247-3298
6B-6224	Ferrule	419-4738
6L-4716	Gasket-Exhaust	398-2951

74B		
Original Part Number	**Part Name**	**Classic Part Number**
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7N-9805	Pin-Piston	295-6438
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860

74B		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-2685	Rod End	419-1866
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166
169-4200	Gasket	472-8023
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085

83B		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438

83B		
Original Part Number	**Part Name**	**Classic Part Number**
3S-9466	Bearing-Sleeve	314-8509
5H-7071	Director-Water	388-0555
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298

83B		
Original Part Number	**Part Name**	**Classic Part Number**
6B-6224	Ferrule	419-4738
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348

Sales Model 1673 (Cont'd.)

83B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7N-9805	Pin-Piston	295-6438
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342

83B		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084

83B		
Original Part Number	**Part Name**	**Classic Part Number**
9H-5797	Plunger As-Pump	391-9891
9L-2685	Rod End	419-1866
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166
169-4200	Gasket	472-8023
232-3233	Bearing-Main	376-9085

Sales Model 1673B

78B		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
3N-3368	Pipe-Exhaust	311-9434
3S-9466	Bearing-Sleeve	314-8509
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
6B-6224	Ferrule	419-4738

78B		
Original Part Number	**Part Name**	**Classic Part Number**
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7N-9805	Pin-Piston	295-6438
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342

78B		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-2685	Rod End	419-1866
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166
169-4200	Gasket	472-8023
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085

Sales Model 1673C

69D		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3574	Block Gp-Cyl	460-8298

Sales Model 1673C (Cont'd.)

69D		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-4303	Head As-Cylinder	242-3434
1P-5480	Cover As.-End	299-1998
1S-3062	Director-Water	418-9572
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-4015	Plunger As-Valve	311-9438
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7678	Gear-Water Pump	325-6088
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542

69D		
Original Part Number	Part Name	Classic Part Number
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4878	Pump Gp-F Tfr	390-0995
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9561	Gasket Kt-V G	437-8106
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-2820	Pump Gp-Eng Oil	415-1903

69D		
Original Part Number	Part Name	Classic Part Number
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-2202	Bearing-Spl Ball	380-1574
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2834	Kit-Repair	374-4723
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7765	Governor As	377-5841
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7043	Mount As	389-6332
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037

Sales Model 1673C (Cont'd.)

69D		
Original Part Number	**Part Name**	**Classic Part Number**
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033

69D		
Original Part Number	**Part Name**	**Classic Part Number**
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9L-5519	Manifold-Exhaust	392-4500
9L-5521	Manifold-Exhaust	396-9895
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126

69D		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

76R		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572

76R		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-6810	Pipe-Outlet	472-8036
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

76R		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214

Sales Model 1673C (Cont'd.)

76R		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4878	Pump Gp-F Tfr	390-0995
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4W-0452	Seal As -Cshaft	325-6191
4W-6805	Flywheel As	421-3325
4W-7188	Core As-Oclr	374-7501
4W-9989	Gear As-Idler	302-2677
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502

76R		
Original Part Number	Part Name	Classic Part Number
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9561	Gasket Kt-V G	437-8106
5P-9568	Gasket Kit	393-3625
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-2202	Bearing-Spl Ball	380-1574
6V-2580	Gasket Kt-V G	393-3637
6V-2983	Gasket Kt	437-3213
6V-5976	Kit-Gasket (Rs)	393-5200
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-2871	Line As-Fuel Inj	319-8172

76R		
Original Part Number	Part Name	Classic Part Number
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-5910	Impeller-Pump	314-8686
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232

Sales Model 1673C (Cont'd.)

76R		
Original Part Number	**Part Name**	**Classic Part Number**
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558

76R		
Original Part Number	**Part Name**	**Classic Part Number**
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
170-0560	Rebuild Kit-Pump	363-7458
170-0566	Kit-Rebuild-Pump	377-5835

76R		
Original Part Number	**Part Name**	**Classic Part Number**
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 1674

94B		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
2B-0941	Spacer	418-1955

94B		
Original Part Number	**Part Name**	**Classic Part Number**
2F-5721	Bearing-Ball	311-9354
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532

94B		
Original Part Number	**Part Name**	**Classic Part Number**
2S-4015	Plunger As-Valve	311-9438
2W-1707	Ring-Piston Top	270-4356

Sales Model 1674 (Cont'd.)

94B		
Original Part Number	Part Name	Classic Part Number
2W-1708	Ring-Piston	270-4357
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-4557	Bearing	311-9360
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381

94B		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7M-7219	Bearing-Thrust	384-4816
7N-9805	Pin-Piston	295-6438
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-8220	Bearing-Conn Rod	377-5860

94B		
Original Part Number	Part Name	Classic Part Number
8N-8221	Bearing-Conn Rod	419-6377
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9S-7788	Ring-Piston	461-5124
131-3815	Seal Gp-Basic	325-6193
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085

Sales Model 1676

02A		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3S-9466	Bearing-Sleeve	314-8509
5L-7520	Elbow-Exhaust	419-4711

02A		
Original Part Number	Part Name	Classic Part Number
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5M-2054	Bearing	380-7510
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574

02A		
Original Part Number	Part Name	Classic Part Number
7E-5085	Bushing	377-5829
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
214-6045	Bellows As	435-4846

54B		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384

54B		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354

54B		
Original Part Number	Part Name	Classic Part Number
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532

Sales Model 1676 (Cont'd.)

54B		
Original Part Number	Part Name	Classic Part Number
2S-4015	Plunger As-Valve	311-9438
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3S-9466	Bearing-Sleeve	314-8509
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5M-2054	Bearing	380-7510
5P-7807	Bearing-Ball	314-8502

54B		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7L-7508	Bearing-Ball	420-6536

54B		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
214-6045	Bellows As	435-4846

Sales Model 1693

27U		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-3839	Crankshaft As	398-2968
2S-4015	Plunger As-Valve	311-9438
5L-7632	Support-Elbow	433-9854
5L-9738	Coupling-Exhaust	311-9380
5M-3560	Bearing-Sleeve	392-4521

27U		
Original Part Number	Part Name	Classic Part Number
5P-8789	Gasket Kt	393-3620
7E-5085	Bushing	377-5829
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7S-3206	Seal-O-Ring	436-2656
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342

27U		
Original Part Number	Part Name	Classic Part Number
8N-3666	Repair Kt-Major	377-5842
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
9L-2685	Rod End	419-1866
9S-5746	Ferrule-Seal	392-4493
110-1337	Ring Kit-Pstn	377-5834
162-3904	Pump As-F Prm	391-1102

65B		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-7125	Governor As	383-3672
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533

65B		
Original Part Number	Part Name	Classic Part Number
2M-4209	Spacer-Timing	417-4532
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542

65B		
Original Part Number	Part Name	Classic Part Number
3S-9466	Bearing-Sleeve	314-8509
4M-9215	Gear-Pump Idler	311-9391
5L-2660	Bearing-Sleeve	311-9363
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555

Sales Model 1693 (Cont'd.)

65B		
Original Part Number	**Part Name**	**Classic Part Number**
5L-8856	Coupling-Exhaust	311-9379
5L-9738	Coupling-Exhaust	311-9380
5M-3560	Bearing-Sleeve	392-4521
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6L-3353	Rod End-Special	416-2134
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381

65B		
Original Part Number	**Part Name**	**Classic Part Number**
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7S-3206	Seal-O-Ring	436-2656
7W-1713	Core Gp-O Clr	438-2010
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342

65B		
Original Part Number	**Part Name**	**Classic Part Number**
8M-0874	Plunger As-Valve	311-9439
8N-3666	Repair Kt-Major	377-5842
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
9L-2685	Rod End	419-1866
9M-8395	Bearing-Sleeve	391-1103
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
110-1337	Ring Kit-Pstn	377-5834
162-3904	Pump As-F Prm	391-1102
214-6045	Bellows As	435-4846

Sales Model 2206A

TGL		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
3L-1425	Bearing-Ball	311-9356

TGL		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491

TGL		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
8N-5305	Spacer	363-7464

Sales Model 2206D

PTP, PTS, PXP, PXS		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
3L-1425	Bearing-Ball	311-9356

PTP, PTS, PXP, PXS		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491

PTP, PTS, PXP, PXS		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
8N-5305	Spacer	363-7464

Sales Model 2206F

PP3		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913

Sales Model 2206F (Cont'd.)

PP3		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
8H-9789	Bearing-Ball	374-8342

Sales Model 2306

C3P		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7N-2156	Bearing-Sleeve	380-7373

C3P		
Original Part Number	**Part Name**	**Classic Part Number**
7W-3145	Plate	422-7894
8S-6511	Bearing-Sleeve	380-7372
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-8178	Rod As-Conn	379-8869

C3P		
Original Part Number	**Part Name**	**Classic Part Number**
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
430-7619	Adapter-Cla	438-1812

Sales Model 2506A

MGL		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174

MGL		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812

MGL		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5P-7807	Bearing-Ball	314-8502

Sales Model 2506A (Cont'd.)

MGL		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
6N-1931	Plunger	379-0171
6V-2202	Bearing-Spl Ball	380-1574
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7N-2156	Bearing-Sleeve	380-7373
8H-9789	Bearing-Ball	374-8342
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
102-8501	Manifold-Exhaust	377-5853

MGL		
Original Part Number	Part Name	Classic Part Number
102-8608	Manifold-Exhaust	376-9062
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106

MGL		
Original Part Number	Part Name	Classic Part Number
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
170-4860	Bonnet-Oil Clr	430-5359
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443

Sales Model 2506D

PK5		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
7C-0307	Gasket	399-8571
7N-2156	Bearing-Sleeve	380-7373

PK5		
Original Part Number	Part Name	Classic Part Number
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9N-3167	Plate-Block Bot	430-4468
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8608	Manifold-Exhaust	376-9062
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

PK5		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443

Sales Model 2806

CDB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913

Sales Model 2806 (Cont'd.)

CDB		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7N-2156	Bearing-Sleeve	380-7373
7W-3145	Plate	422-7894

CDB		
Original Part Number	**Part Name**	**Classic Part Number**
8S-6511	Bearing-Sleeve	380-7372
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117

CDB		
Original Part Number	**Part Name**	**Classic Part Number**
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

Sales Model 2806-18

P5E		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171

P5E		
Original Part Number	**Part Name**	**Classic Part Number**
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7N-2156	Bearing-Sleeve	380-7373
8H-9789	Bearing-Ball	374-8342
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9N-3167	Plate-Block Bot	430-4468
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814

P5E		
Original Part Number	**Part Name**	**Classic Part Number**
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
170-4860	Bonnet-Oil Clr	430-5359
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914

Sales Model 2806-18 (Cont'd.)

P5E		
Original Part Number	Part Name	Classic Part Number
246-3130	Shaft-Water Pump	392-4508

P5E		
Original Part Number	Part Name	Classic Part Number
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507

P5E		
Original Part Number	Part Name	Classic Part Number
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443

P5G		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571

P5G		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
8H-9789	Bearing-Ball	374-8342
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9N-3167	Plate-Block Bot	430-4468
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813

P5G		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
170-4860	Bonnet-Oil Clr	430-5359
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443

P6E		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571

P6E		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
8H-9789	Bearing-Ball	374-8342
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9N-3167	Plate-Block Bot	430-4468
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813

P6E		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
170-4860	Bonnet-Oil Clr	430-5359
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443

Sales Model 2806-18 (Cont'd.)

P6H		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571

P6H		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
8H-9789	Bearing-Ball	374-8342
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9N-3167	Plate-Block Bot	430-4468
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813

P6H		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
170-4860	Bonnet-Oil Clr	430-5359
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443

Sales Model 2806A

JGN		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6N-1931	Plunger	379-0171
6V-2202	Bearing-Spl Ball	380-1574

JGN		
Original Part Number	Part Name	Classic Part Number
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7N-2156	Bearing-Sleeve	380-7373
7N-8828	Pulley	420-6395
8H-9789	Bearing-Ball	374-8342
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9N-3167	Plate-Block Bot	430-4468
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

JGN		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
170-4860	Bonnet-Oil Clr	430-5359
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443

Sales Model 2806C

SJF		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571

SJF		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9N-3167	Plate-Block Bot	430-4468
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813

SJF		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
170-4860	Bonnet-Oil Clr	430-5359
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443

Sales Model 2806D

PK8		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7N-2156	Bearing-Sleeve	380-7373

PK8		
Original Part Number	Part Name	Classic Part Number
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9N-3167	Plate-Block Bot	430-4468
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8608	Manifold-Exhaust	376-9062
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

PK8		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443

Engines

Sales Model 3011C

311, G1P		
Original Part Number	Part Name	Classic Part Number
4J-1641	Trunnion	314-8725

311, G1P		
Original Part Number	Part Name	Classic Part Number
4T-1504	Trunnion	314-8727
7J-5131	Trunnion	296-1371

Sales Model 3034

7EF		
Original Part Number	Part Name	Classic Part Number
1P-7115	Mount As	418-1936
1W-6005	Bearing-Sleeve	417-4521
1W-6356	Gasket	438-1795
2A-4429	Lock-Retainer	379-0174
2N-5842	Screw-Bridge Adj	418-1934

7EF		
Original Part Number	Part Name	Classic Part Number
2S-5100	Valve-Ball	386-3049
4N-1320	Gasket-Adapter	398-2928
7N-5089	Gasket	394-0890
7N-5449	Spool-Press Rlf	434-2450
7N-7628	Gasket	419-1811

7EF		
Original Part Number	Part Name	Classic Part Number
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
9Y-0635	Spacer	435-8519
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193

Sales Model 3054

5YS		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
8H-9789	Bearing-Ball	374-8342

6FK		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
6H-3957	Bearing-Ball	311-9358
8H-9789	Bearing-Ball	374-8342

Sales Model 3054B

5MF		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
8H-9789	Bearing-Ball	374-8342

Sales Model 3054C

330		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358

Sales Model 3054C (Cont'd.)

334		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255

334		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521

334		
Original Part Number	**Part Name**	**Classic Part Number**
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-7354	Manifold-Exhaust	386-3060
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554

Sales Model 3054C (Cont'd.)

334		
Original Part Number	**Part Name**	**Classic Part Number**
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011

334		
Original Part Number	**Part Name**	**Classic Part Number**
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368

334		
Original Part Number	**Part Name**	**Classic Part Number**
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

Sales Model 3054E

304		
Original Part Number	**Part Name**	**Classic Part Number**
6H-3957	Bearing-Ball	311-9358

Sales Model 3056

1ML		
Original Part Number	**Part Name**	**Classic Part Number**
2F-5721	Bearing-Ball	311-9354
6H-3957	Bearing-Ball	311-9358
8H-9789	Bearing-Ball	374-8342

7MS		
Original Part Number	**Part Name**	**Classic Part Number**
6H-3957	Bearing-Ball	311-9358
8H-9789	Bearing-Ball	374-8342

Sales Model 3056E

356		
Original Part Number	**Part Name**	**Classic Part Number**
6H-3957	Bearing-Ball	311-9358

Sales Model 3114

1ZG		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1M-7250	Bowl	360-2296
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3K-3124	Muffler-Trap	247-2673
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4N-4520	Guide	388-6600
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2541	Shaft-Gov Cont	399-8580
5L-9656	Cone-Bearing	399-4448
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065

1ZG		
Original Part Number	**Part Name**	**Classic Part Number**
6I-4689	Gasket-Cyl Head	377-5840
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-9918	Repair Kit-Major	388-0655
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8L-4282	Hub	444-0573
8S-0248	Breather As	325-6033
9Y-1403	Muffler As	393-0930
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983

1ZG		
Original Part Number	**Part Name**	**Classic Part Number**
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-1337	Ring Kit-Pstn	377-5834
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
121-7746	Pre-Cleaner As	360-2311
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

5EF		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1M-7250	Bowl	360-2296
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667

5EF		
Original Part Number	**Part Name**	**Classic Part Number**
3E-7461	Gasket Kit-Sch	437-4575
3K-3124	Muffler-Trap	247-2673
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4N-4520	Guide	388-6600
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513

5EF		
Original Part Number	**Part Name**	**Classic Part Number**
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2541	Shaft-Gov Cont	399-8580
5L-9656	Cone-Bearing	399-4448
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6I-4689	Gasket-Cyl Head	377-5840

Sales Model 3114 (Cont'd.)

5EF		
Original Part Number	**Part Name**	**Classic Part Number**
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-9918	Repair Kit-Major	388-0655
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190

5EF		
Original Part Number	**Part Name**	**Classic Part Number**
7W-8064	Valve-Inlet	384-8705
8H-2810	Case As-Filter	314-8512
8L-4282	Hub	444-0573
8S-0248	Breather As	325-6033
9X-2192	Gasket Kit-Sch	393-5189
9Y-1403	Muffler As	393-0930
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-1337	Ring Kit-Pstn	377-5834
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
121-7746	Pre-Cleaner As	360-2311
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697

5EF		
Original Part Number	**Part Name**	**Classic Part Number**
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
287-8465	Kit-Gasket-Fs	437-8627
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

5JG		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
2L-4238	Mount-Flexible	385-7222
2W-7213	Bearing-Sleeve	419-4667
3K-3124	Muffler-Trap	247-2673
3N-1968	Mount-Shock	397-5046
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
6I-4689	Gasket-Cyl Head	377-5840
6V-2983	Gasket Kt	437-3213

5JG		
Original Part Number	**Part Name**	**Classic Part Number**
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8L-4282	Hub	444-0573
8S-0248	Breather As	325-6033
9X-2192	Gasket Kit-Sch	393-5189
9Y-1403	Muffler As	393-0930
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

5JG		
Original Part Number	**Part Name**	**Classic Part Number**
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
121-7746	Pre-Cleaner As	360-2311
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

Sales Model 3114 (Cont'd.)

5JG		
Original Part Number	Part Name	Classic Part Number
352-2151	Pump Gp-Water -B	434-6107

5JG		
Original Part Number	Part Name	Classic Part Number
352-2160	Pump Gp-Water -B	433-0789

5YL		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
2W-7213	Bearing-Sleeve	419-4667
3E-7461	Gasket Kit-Sch	437-4575
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-7807	Bearing-Ball	314-8502
6I-4689	Gasket-Cyl Head	377-5840
6V-2202	Bearing-Spl Ball	380-1574
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

5YL		
Original Part Number	Part Name	Classic Part Number
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219

5YL		
Original Part Number	Part Name	Classic Part Number
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

6AF		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
2W-7213	Bearing-Sleeve	419-4667
3K-3124	Muffler-Trap	247-2673
4N-1320	Gasket-Adapter	398-2928
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-2541	Shaft-Gov Cont	399-8580
6I-4689	Gasket-Cyl Head	377-5840

6AF		
Original Part Number	Part Name	Classic Part Number
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7L-4302	Gasket	420-8570
7N-5089	Gasket	394-0890
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8L-4282	Hub	444-0573
8S-0248	Breather As	325-6033

6AF		
Original Part Number	Part Name	Classic Part Number
9X-2192	Gasket Kit-Sch	393-5189
9Y-1403	Muffler As	393-0930
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376

Sales Model 3114 (Cont'd.)

6AF		
Original Part Number	Part Name	Classic Part Number
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
152-5705	Gasket	447-0830
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
213-8467	Kit-Gasket (Wlg)	438-0143

6AF		
Original Part Number	Part Name	Classic Part Number
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
282-2065	Kit-Gasket-T	438-0184
305-2669	Kit-Gasket (Cl)	438-0183

6AF		
Original Part Number	Part Name	Classic Part Number
313-4914	Kit-Gasket(T)	438-0182
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
355-0763	Kit-Gasket (Sch)	438-0181

9LL		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
2W-7213	Bearing-Sleeve	419-4667
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-7807	Bearing-Ball	314-8502
6I-4689	Gasket-Cyl Head	377-5840
6V-2202	Bearing-Spl Ball	380-1574
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317

9LL		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020

9LL		
Original Part Number	Part Name	Classic Part Number
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

Sales Model 3116

160		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449

160		
Original Part Number	Part Name	Classic Part Number
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8S-0248	Breather As	325-6033
9Y-8534	Support-Shft	463-7671
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069

160		
Original Part Number	Part Name	Classic Part Number
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372

Sales Model 3116 (Cont'd.)

160		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371

160		
Original Part Number	Part Name	Classic Part Number
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

160		
Original Part Number	Part Name	Classic Part Number
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

1NJ		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
2L-4238	Mount-Flexible	385-7222
2W-7213	Bearing-Sleeve	419-4667
3N-1968	Mount-Shock	397-5046
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-2541	Shaft-Gov Cont	399-8580
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-7344	Muffler As	360-7886

1NJ		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7X-2522	Gasket Kit	437-8648
8L-4282	Hub	444-0573
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
106-2822	Gasket Kit	436-8376
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219

1NJ		
Original Part Number	Part Name	Classic Part Number
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

1SK		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3D-9126	Cup-Roller Brg	399-4435
3E-7496	Gasket Kit - Sch	437-8105
3N-6411	Cup-Rlr Bearing	423-7759

1SK		
Original Part Number	Part Name	Classic Part Number
4B-7255	Cone-Bearing	386-4951
4L-8473	Plate-Wear	419-0883
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
5B-9169	Plug-Drain	419-4736
5P-7807	Bearing-Ball	314-8502
6D-1734	Cup-Roller Brg	416-2171
6L-2279	Plug-Ptf	419-4739
6S-6031	Cup-Rlr Brg	415-1920

1SK		
Original Part Number	Part Name	Classic Part Number
6S-6032	Cone-Rlr Brg	415-1921
6Y-7652	Cup-Rlr Brg	399-6067
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986

Sales Model 3116 (Cont'd.)

1SK		
Original Part Number	**Part Name**	**Classic Part Number**
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8H-4320	Bearing-Ball	419-2301
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069

1SK		
Original Part Number	**Part Name**	**Classic Part Number**
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5911	Manifold As.-Exh	441-5604
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697

1SK		
Original Part Number	**Part Name**	**Classic Part Number**
163-5723	Gasket Kit - Sch	437-8641
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

2BK		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
2W-7213	Bearing-Sleeve	419-4667
3E-3339	Gasket Kit	393-3614
3E-7496	Gasket Kit - Sch	437-8105
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-7807	Bearing-Ball	314-8502
6I-1099	Manifold-Exh	424-6366
6V-2202	Bearing-Spl Ball	380-1574
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449

2BK		
Original Part Number	**Part Name**	**Classic Part Number**
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7X-2522	Gasket Kit	437-8648
8S-0248	Breather As	325-6033
9N-3668	Base As.-Coolant	419-4718
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-2951	Gasket-Kit Sch	447-8649
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-1337	Ring Kit-Pstn	377-5834
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219

2BK		
Original Part Number	**Part Name**	**Classic Part Number**
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
127-4953	Gasket Kit-Sch	437-8676
127-5022	Gasket Kit-Sch	437-8643
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
254-5676	Kit-Gasket-Sch	437-8649
264-6898	Kit-Gasket-Sch	382-5069
268-2932	Kit-Gasket-Sch	438-0153
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
281-2813	Kit-Gasket-Sch	387-2921
352-2160	Pump Gp-Water -B	433-0789

Sales Model 3116 (Cont'd.)

2CW		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
5P-7807	Bearing-Ball	314-8502
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-8926	Head Kt-Cyl	377-5847
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705

2CW		
Original Part Number	**Part Name**	**Classic Part Number**
8S-0248	Breather As	325-6033
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
132-7923	Gasket Kit-Sch	437-8642
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336

2CW		
Original Part Number	**Part Name**	**Classic Part Number**
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2160	Pump Gp-Water -B	433-0789

2FR		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-3900	Gasket	472-8006
2P-0220	Gasket-Pump	398-2927
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-7807	Bearing-Ball	314-8502
6I-1099	Manifold-Exh	424-6366
6V-2202	Bearing-Spl Ball	380-1574
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449

2FR		
Original Part Number	**Part Name**	**Classic Part Number**
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
127-4953	Gasket Kit-Sch	437-8676

2FR		
Original Part Number	**Part Name**	**Classic Part Number**
127-5022	Gasket Kit-Sch	437-8643
135-2151	Tensioner	419-4735
136-0819	Valve-Exhaust	384-8697
140-2246	Gasket Kit	383-3710
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2160	Pump Gp-Water -B	433-0789
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 3116 (Cont'd.)

2MR		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3N-3786	Rod-Thrt Cont	397-5051
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2541	Shaft-Gov Cont	399-8580
5L-9656	Cone-Bearing	399-4448
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6I-1099	Manifold-Exh	424-6366
6V-2202	Bearing-Spl Ball	380-1574

2MR		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-7344	Muffler As	360-7886
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7S-8443	Muffler	247-2675
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8H-2810	Case As-Filter	314-8512
8L-4282	Hub	444-0573
8S-0248	Breather As	325-6033
9N-3668	Base As.-Coolant	419-4718
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983

2MR		
Original Part Number	Part Name	Classic Part Number
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-1337	Ring Kit-Pstn	377-5834
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
265-9185	Kit-Gasket(Ocl)	437-8631
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703
460-5395	Kit-Gasket (Sch)	436-8395

2SG		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
2W-7213	Bearing-Sleeve	419-4667
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600

2SG		
Original Part Number	Part Name	Classic Part Number
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

2SG		
Original Part Number	Part Name	Classic Part Number
4W-2541	Shaft-Gov Cont	399-8580
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

Sales Model 3116 (Cont'd.)

2SG		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7C-7344	Muffler As	360-7886
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7X-2522	Gasket Kit	437-8648
8L-4282	Hub	444-0573
8S-0248	Breather As	325-6033

2SG		
Original Part Number	Part Name	Classic Part Number
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
106-2822	Gasket Kit	436-8376
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336

2SG		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

2WG		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1M-7250	Bowl	360-2296
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3E-3339	Gasket Kit	393-3614
3E-7496	Gasket Kit - Sch	437-8105
3N-3786	Rod-Thrt Cont	397-5051
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596

2WG		
Original Part Number	Part Name	Classic Part Number
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2541	Shaft-Gov Cont	399-8580
4W-7188	Core As-Oclr	374-7501
5L-9656	Cone-Bearing	399-4448
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6I-1099	Manifold-Exh	424-6366
6L-4716	Gasket-Exhaust	398-2951
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

2WG		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7C-7344	Muffler As	360-7886
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7S-8443	Muffler	247-2675
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7X-2754	Gasket Kit - F	437-3235
8H-2810	Case As-Filter	314-8512
8L-4282	Hub	444-0573
8L-8867	Pulley	434-1409
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756

Sales Model 3116 (Cont'd.)

2WG		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-8534	Support-Shft	463-7671
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
106-2822	Gasket Kit	436-8376
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-1337	Ring Kit-Pstn	377-5834
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002

2WG		
Original Part Number	**Part Name**	**Classic Part Number**
121-7746	Pre-Cleaner As	360-2311
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
127-4953	Gasket Kit-Sch	437-8676
136-0819	Valve-Exhaust	384-8697
140-1093	Gasket Kit-Sch	436-8394
144-0482	Gasket	420-8547
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5911	Manifold As.-Exh	441-5604
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-5723	Gasket Kit - Sch	437-8641

2WG		
Original Part Number	**Part Name**	**Classic Part Number**
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
264-6898	Kit-Gasket-Sch	382-5069
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

3AF		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2L-4238	Mount-Flexible	385-7222
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025

3AF		
Original Part Number	**Part Name**	**Classic Part Number**
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-9027	Base-Oil Cooler	399-8545
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-1337	Ring Kit-Pstn	377-5834
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069

3RJ		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384

3AF		
Original Part Number	**Part Name**	**Classic Part Number**
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
441-9566	Gear-Flywheel	374-4703

Sales Model 3116 (Cont'd.)

3RJ		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583

3RJ		
Original Part Number	Part Name	Classic Part Number
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694

3RJ		
Original Part Number	Part Name	Classic Part Number
127-5022	Gasket Kit-Sch	437-8643
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
441-9566	Gear-Flywheel	374-4703

4KG		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3D-9126	Cup-Roller Brg	399-4435
3E-3339	Gasket Kit	393-3614
3E-7496	Gasket Kit - Sch	437-8105
3N-6411	Cup-Rlr Bearing	423-7759
4B-7255	Cone-Bearing	386-4951
4L-8473	Plate-Wear	419-0883
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
5B-9169	Plug-Drain	419-4736

4KG		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
6D-1734	Cup-Roller Brg	416-2171
6L-2279	Plug-Ptf	419-4739
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6Y-7652	Cup-Rlr Brg	399-6067
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7X-2522	Gasket Kit	437-8648
8H-4320	Bearing-Ball	419-2301

4KG		
Original Part Number	Part Name	Classic Part Number
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
106-2822	Gasket Kit	436-8376
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
135-4928	Shaft-Water Pump	386-3813
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376

Sales Model 3116 (Cont'd.)

4KG		
Original Part Number	Part Name	Classic Part Number
145-0165	Bearing-Main	419-6388
151-5911	Manifold As.-Exh	441-5604
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-5723	Gasket Kit - Sch	437-8641

4KG		
Original Part Number	Part Name	Classic Part Number
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

4KG		
Original Part Number	Part Name	Classic Part Number
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

4PG		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1M-7250	Bowl	360-2296
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3E-3339	Gasket Kit	393-3614
3N-3786	Rod-Thrt Cont	397-5051
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2541	Shaft-Gov Cont	399-8580
5L-9656	Cone-Bearing	399-4448
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6I-1099	Manifold-Exh	424-6366

4PG		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-7344	Muffler As	360-7886
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7S-8443	Muffler	247-2675
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7X-2522	Gasket Kit	437-8648
8H-2810	Case As-Filter	314-8512
8L-4282	Hub	444-0573
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671

4PG		
Original Part Number	Part Name	Classic Part Number
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
106-2822	Gasket Kit	436-8376
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-1337	Ring Kit-Pstn	377-5834
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
140-1093	Gasket Kit-Sch	436-8394
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5911	Manifold As.-Exh	441-5604
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
264-6898	Kit-Gasket-Sch	382-5069
265-9185	Kit-Gasket(Ocl)	437-8631

Sales Model 3116 (Cont'd.)

4PG		
Original Part Number	Part Name	Classic Part Number
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

4PG		
Original Part Number	Part Name	Classic Part Number
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

4PG		
Original Part Number	Part Name	Classic Part Number
441-9566	Gear-Flywheel	374-4703

5EN		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1M-7250	Bowl	360-2296
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3N-3786	Rod-Thrt Cont	397-5051
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2541	Shaft-Gov Cont	399-8580
5L-9656	Cone-Bearing	399-4448
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6I-1099	Manifold-Exh	424-6366
6V-2202	Bearing-Spl Ball	380-1574

5EN		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-7344	Muffler As	360-7886
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7S-8443	Muffler	247-2675
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8H-2810	Case As-Filter	314-8512
8L-4282	Hub	444-0573
8L-8867	Pulley	434-1409
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

5EN		
Original Part Number	Part Name	Classic Part Number
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-1337	Ring Kit-Pstn	377-5834
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703
460-5395	Kit-Gasket (Sch)	436-8395

Sales Model 3116 (Cont'd.)

5JZ		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
2W-7213	Bearing-Sleeve	419-4667
3E-6772	Seal-Water	382-8017
4N-1320	Gasket-Adapter	398-2928
4P-3683	Pump Gp-Water -B	374-7498
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
6I-1099	Manifold-Exh	424-6366
7C-0307	Gasket	399-8571
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449

5JZ		
Original Part Number	**Part Name**	**Classic Part Number**
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693

5JZ		
Original Part Number	**Part Name**	**Classic Part Number**
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
293-3018	Kit-Gasket (Sch)	438-0145
352-2160	Pump Gp-Water -B	433-0789

5RM		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847

5RM		
Original Part Number	**Part Name**	**Classic Part Number**
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693

5RM		
Original Part Number	**Part Name**	**Classic Part Number**
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2160	Pump Gp-Water -B	433-0789

Sales Model 3116 (Cont'd.)

5TS		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449

5TS		
Original Part Number	**Part Name**	**Classic Part Number**
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5426	Camshaft As.	378-3987
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219

5TS		
Original Part Number	**Part Name**	**Classic Part Number**
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2160	Pump Gp-Water -B	433-0789

7AG		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551

7AG		
Original Part Number	**Part Name**	**Classic Part Number**
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694

7AG		
Original Part Number	**Part Name**	**Classic Part Number**
127-5022	Gasket Kit-Sch	437-8643
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

7HJ		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384

Sales Model 3116 (Cont'd.)

7HJ		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551

7HJ		
Original Part Number	Part Name	Classic Part Number
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693

7HJ		
Original Part Number	Part Name	Classic Part Number
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

7HS		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
5P-7807	Bearing-Ball	314-8502
6I-1099	Manifold-Exh	424-6366
6V-2202	Bearing-Spl Ball	380-1574
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449

7HS		
Original Part Number	Part Name	Classic Part Number
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219

7HS		
Original Part Number	Part Name	Classic Part Number
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2160	Pump Gp-Water -B	433-0789

7JL		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384

Sales Model 3116 (Cont'd.)

7JL		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6I-1099	Manifold-Exh	424-6366
6V-2202	Bearing-Spl Ball	380-1574
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847

7JL		
Original Part Number	**Part Name**	**Classic Part Number**
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8H-2810	Case As-Filter	314-8512
8L-8867	Pulley	434-1409
8S-0248	Breather As	325-6033
9N-3668	Base As.-Coolant	419-4718
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
127-5022	Gasket Kit-Sch	437-8643

7JL		
Original Part Number	**Part Name**	**Classic Part Number**
135-2151	Tensioner	419-4735
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
265-9185	Kit-Gasket(Ocl)	437-8631
266-5907	Kit-Gasket-Cl	438-0155
268-2932	Kit-Gasket-Sch	438-0153
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
281-2813	Kit-Gasket-Sch	387-2921
352-2160	Pump Gp-Water -B	433-0789

7SF		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
5P-7807	Bearing-Ball	314-8502
6I-1099	Manifold-Exh	424-6366
6V-2202	Bearing-Spl Ball	380-1574
7C-3760	Tube As-O Drain	375-5443

7SF		
Original Part Number	**Part Name**	**Classic Part Number**
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987

7SF		
Original Part Number	**Part Name**	**Classic Part Number**
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7X-2522	Gasket Kit	437-8648
8S-0248	Breather As	325-6033
9N-3668	Base As.-Coolant	419-4718
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896

Sales Model 3116 (Cont'd.)

7SF		
Original Part Number	**Part Name**	**Classic Part Number**
110-1337	Ring Kit-Pstn	377-5834
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380

7SF		
Original Part Number	**Part Name**	**Classic Part Number**
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371

7SF		
Original Part Number	**Part Name**	**Classic Part Number**
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
254-5676	Kit-Gasket-Sch	437-8649
264-6898	Kit-Gasket-Sch	382-5069
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2160	Pump Gp-Water -B	433-0789

7TM		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-5435	Compressor As	396-9942
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
6I-1240	Governor As	380-7538
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

7TM		
Original Part Number	**Part Name**	**Classic Part Number**
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069

7TM		
Original Part Number	**Part Name**	**Classic Part Number**
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

8WL		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498

8WL		
Original Part Number	**Part Name**	**Classic Part Number**
4P-5435	Compressor As	396-9942
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366

8WL		
Original Part Number	**Part Name**	**Classic Part Number**
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

Sales Model 3116 (Cont'd.)

8WL		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8S-0248	Breather As	325-6033
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692

8WL		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
132-7923	Gasket Kit-Sch	437-8642
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388

8WL		
Original Part Number	Part Name	Classic Part Number
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

9CJ		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847

9CJ		
Original Part Number	Part Name	Classic Part Number
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219

9CJ		
Original Part Number	Part Name	Classic Part Number
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

9GK		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
2W-7213	Bearing-Sleeve	419-4667
3E-3339	Gasket Kit	393-3614

9GK		
Original Part Number	Part Name	Classic Part Number
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-5435	Compressor As	396-9942

9GK		
Original Part Number	Part Name	Classic Part Number
4P-7688	Valve As-Check	420-6216
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513

Sales Model 3116 (Cont'd.)

9GK		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-7807	Bearing-Ball	314-8502
6I-1099	Manifold-Exh	424-6366
6V-2202	Bearing-Spl Ball	380-1574
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7E-9918	Repair Kit-Major	388-0655

9GK		
Original Part Number	Part Name	Classic Part Number
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8S-0248	Breather As	325-6033
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-2951	Gasket-Kit Sch	447-8649
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
106-2822	Gasket Kit	436-8376
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
108-2102	Bonnet-Valve	455-3274
108-6633	Pump Gp-Fuel Inj	420-6215
110-1337	Ring Kit-Pstn	377-5834
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219

9GK		
Original Part Number	Part Name	Classic Part Number
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
127-2194	Gasket Kit-Sch	437-8645
127-4953	Gasket Kit-Sch	437-8676
127-5022	Gasket Kit-Sch	437-8643
135-2151	Tensioner	419-4735
136-0819	Valve-Exhaust	384-8697
144-0482	Gasket	420-8547
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
268-2932	Kit-Gasket-Sch	438-0153
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
281-2813	Kit-Gasket-Sch	387-2921
287-8465	Kit-Gasket-Fs	437-8627
352-2160	Pump Gp-Water -B	433-0789

9LN		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
2W-7213	Bearing-Sleeve	419-4667
3E-3339	Gasket Kit	393-3614
4P-3683	Pump Gp-Water -B	374-7498
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673

9LN		
Original Part Number	Part Name	Classic Part Number
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8S-0248	Breather As	325-6033

9LN		
Original Part Number	Part Name	Classic Part Number
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693

Sales Model 3116 (Cont'd.)

9LN		
Original Part Number	**Part Name**	**Classic Part Number**
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
127-4953	Gasket Kit-Sch	437-8676
135-2151	Tensioner	419-4735
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388

9LN		
Original Part Number	**Part Name**	**Classic Part Number**
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
266-5907	Kit-Gasket-Cl	438-0155

9LN		
Original Part Number	**Part Name**	**Classic Part Number**
268-2932	Kit-Gasket-Sch	438-0153
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441
352-2160	Pump Gp-Water -B	433-0789

9YN		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
2W-7213	Bearing-Sleeve	419-4667
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
6I-1099	Manifold-Exh	424-6366
6V-3831	Seal-O-Ring	436-2657
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986

9YN		
Original Part Number	**Part Name**	**Classic Part Number**
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
127-2194	Gasket Kit-Sch	437-8645

9YN		
Original Part Number	**Part Name**	**Classic Part Number**
127-4953	Gasket Kit-Sch	437-8676
127-5022	Gasket Kit-Sch	437-8643
135-2151	Tensioner	419-4735
136-0819	Valve-Exhaust	384-8697
142-2535	Gasket Kit	437-4593
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
287-8465	Kit-Gasket-Fs	437-8627

BMN		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7213	Bearing-Sleeve	419-4667
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

BMN		
Original Part Number	**Part Name**	**Classic Part Number**
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190

BMN		
Original Part Number	**Part Name**	**Classic Part Number**
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069

Sales Model 3116 (Cont'd.)

BMN		
Original Part Number	**Part Name**	**Classic Part Number**
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376

BMN		
Original Part Number	**Part Name**	**Classic Part Number**
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371

BMN		
Original Part Number	**Part Name**	**Classic Part Number**
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

CSM		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551

CSM		
Original Part Number	**Part Name**	**Classic Part Number**
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693

CSM		
Original Part Number	**Part Name**	**Classic Part Number**
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2160	Pump Gp-Water -B	433-0789

RZR		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449

RZR		
Original Part Number	**Part Name**	**Classic Part Number**
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
8H-4320	Bearing-Ball	419-2301
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002

RZR		
Original Part Number	**Part Name**	**Classic Part Number**
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
151-5911	Manifold As.-Exh	441-5604
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912

Sales Model 3116 (Cont'd.)

RZR		
Original Part Number	Part Name	Classic Part Number
277-7089	Shaft As	380-7578

RZR		
Original Part Number	Part Name	Classic Part Number
441-9566	Gear-Flywheel	374-4703

Sales Model 3126

161		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449

161		
Original Part Number	Part Name	Classic Part Number
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

161		
Original Part Number	Part Name	Classic Part Number
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444

1BW		
Original Part Number	Part Name	Classic Part Number
1P-7125	Governor As	383-3672
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-4137	Shaft As.	378-3986

1BW		
Original Part Number	Part Name	Classic Part Number
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-9712	Shaft-Dr Idler	425-7754
119-2940	Gasket	378-4002
131-7123	Bearing-Sleeve	422-6919
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336

1BW		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441
441-9566	Gear-Flywheel	374-4703

1ED		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667

1ED		
Original Part Number	Part Name	Classic Part Number
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

1ED		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847

Sales Model 3126 (Cont'd.)

1ED		
Original Part Number	**Part Name**	**Classic Part Number**
7W-3773	Pulley-Cshaft	383-1583
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445

1ED		
Original Part Number	**Part Name**	**Classic Part Number**
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371

1ED		
Original Part Number	**Part Name**	**Classic Part Number**
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441

1WM		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
3E-6772	Seal-Water	382-8017
4P-3683	Pump Gp-Water -B	374-7498
4P-5435	Compressor As	396-9942
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8S-0248	Breather As	325-6033
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-3125	Gasket	420-8567
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381

1WM		
Original Part Number	**Part Name**	**Classic Part Number**
107-7750	Pulley	382-6896
108-7930	Bearing As	377-7463
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-9712	Shaft-Dr Idler	425-7754
119-2940	Gasket	378-4002
124-3684	Gasket Kit-Sch	437-8646
126-5875	Flywheel As.	374-4694
131-7123	Bearing-Sleeve	422-6919
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
136-0819	Valve-Exhaust	384-8697
138-6744	Rebuild Kit-Pump	363-7457
141-5787	Kit-Gasket(Ocl)	437-4611
142-2221	Gasket Kit - Sch	437-8127
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388

1WM		
Original Part Number	**Part Name**	**Classic Part Number**
152-3952	Impeller-Pump	374-4696
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
163-1387	Gear-Flywheel	374-4697
166-9142	Gasket	420-8546
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3675	Kit-Gasket-Rs	437-8670
232-3679	Kit-Gasket (Rs)	437-2039
237-6367	Kit - Gasket-Sch	437-8625
265-9185	Kit-Gasket(Ocl)	437-8631
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
287-8465	Kit-Gasket-Fs	437-8627
325-2721	Kit-Gasket(T)	393-3662
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model 3126 (Cont'd.)

1ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3D-9126	Cup-Roller Brg	399-4435
4B-7255	Cone-Bearing	386-4951
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
5B-9169	Plug-Drain	419-4736
5P-7807	Bearing-Ball	314-8502
6D-1734	Cup-Roller Brg	416-2171
6L-2279	Plug-Ptf	419-4739
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6Y-7652	Cup-Rlr Brg	399-6067

1ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-9027	Base-Oil Cooler	399-8545
8H-4320	Bearing-Ball	419-2301
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693

1ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
119-2940	Gasket	378-4002
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
151-5911	Manifold As.-Exh	441-5604
152-3952	Impeller-Pump	374-4696
210-7443	Gasket Kit - Sch	437-8125
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
265-9185	Kit-Gasket(Ocl)	437-8631
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
441-9566	Gear-Flywheel	374-4703

3TR		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4P-5435	Compressor As	396-9942
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-7807	Bearing-Ball	314-8502
6I-1099	Manifold-Exh	424-6366
6L-4716	Gasket-Exhaust	398-2951
6V-2202	Bearing-Spl Ball	380-1574
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025

3TR		
Original Part Number	**Part Name**	**Classic Part Number**
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
9N-3668	Base As.-Coolant	419-4718
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694

3TR		
Original Part Number	**Part Name**	**Classic Part Number**
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
237-6367	Kit - Gasket-Sch	437-8625
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

Sales Model 3126 (Cont'd.)

3TR		
Original Part Number	**Part Name**	**Classic Part Number**
287-8465	Kit-Gasket-Fs	437-8627

3TR		
Original Part Number	**Part Name**	**Classic Part Number**
352-2153	Pump As-Water	433-0444

3TR		
Original Part Number	**Part Name**	**Classic Part Number**
352-2157	Pump Gp-Water -B	433-0441

4ES		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4P-5435	Compressor As	396-9942
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449

4ES		
Original Part Number	**Part Name**	**Classic Part Number**
7E-8926	Head Kt-Cyl	377-5847
7W-4137	Shaft As.	378-3986
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
119-2940	Gasket	378-4002
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
142-2221	Gasket Kit - Sch	437-8127
145-0162	Bearing-Main	419-6380

4ES		
Original Part Number	**Part Name**	**Classic Part Number**
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
441-9566	Gear-Flywheel	374-4703

4EZ		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
6L-2279	Plug-Ptf	419-4739
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551

4EZ		
Original Part Number	**Part Name**	**Classic Part Number**
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-9027	Base-Oil Cooler	399-8545
8H-4320	Bearing-Ball	419-2301
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
133-4995	Gasket-Cyl Head	434-2445

4EZ		
Original Part Number	**Part Name**	**Classic Part Number**
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5911	Manifold As.-Exh	441-5604
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
441-9566	Gear-Flywheel	374-4703

6MK		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483

Sales Model 3126 (Cont'd.)

6MK		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3D-9126	Cup-Roller Brg	399-4435
4B-7255	Cone-Bearing	386-4951
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
5B-9169	Plug-Drain	419-4736
5P-7807	Bearing-Ball	314-8502
6D-1734	Cup-Roller Brg	416-2171
6L-2279	Plug-Ptf	419-4739
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6Y-7652	Cup-Rlr Brg	399-6067
7C-6976	Bearing-Conn Rod	419-6317

6MK		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-9027	Base-Oil Cooler	399-8545
8H-4320	Bearing-Ball	419-2301
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002

6MK		
Original Part Number	Part Name	Classic Part Number
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
151-5911	Manifold As.-Exh	441-5604
152-3952	Impeller-Pump	374-4696
210-7443	Gasket Kit - Sch	437-8125
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
265-9185	Kit-Gasket(Ocl)	437-8631
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
441-9566	Gear-Flywheel	374-4703

6MS		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2L-4238	Mount-Flexible	385-7222
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5L-9656	Cone-Bearing	399-4448
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6I-1099	Manifold-Exh	424-6366

6MS		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7S-8443	Muffler	247-2675
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190

6MS		
Original Part Number	Part Name	Classic Part Number
7W-9027	Base-Oil Cooler	399-8545
8L-8867	Pulley	434-1409
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
133-4995	Gasket-Cyl Head	434-2445

Sales Model 3126 (Cont'd.)

6MS		
Original Part Number	Part Name	Classic Part Number
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
166-2142	Hub Gp-Shaft	394-8238
212-4893	Bearing-Thrust	419-6372

6MS		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

6MS		
Original Part Number	Part Name	Classic Part Number
290-0187	Kit-Gasket-Sch	437-8116
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

6RW		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
2W-7213	Bearing-Sleeve	419-4667
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-4137	Shaft As.	378-3986

6RW		
Original Part Number	Part Name	Classic Part Number
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-9712	Shaft-Dr Idler	425-7754
119-2940	Gasket	378-4002
131-7123	Bearing-Sleeve	422-6919
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380

6RW		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444

6SR		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3D-9126	Cup-Roller Brg	399-4435
4B-7255	Cone-Bearing	386-4951
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
5B-9169	Plug-Drain	419-4736
5P-7807	Bearing-Ball	314-8502
6L-2279	Plug-Ptf	419-4739
6S-6031	Cup-Rlr Brg	415-1920

6SR		
Original Part Number	Part Name	Classic Part Number
6S-6032	Cone-Rlr Brg	415-1921
6Y-7652	Cup-Rlr Brg	399-6067
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-9027	Base-Oil Cooler	399-8545
8H-4320	Bearing-Ball	419-2301
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

6SR		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
151-5911	Manifold As.-Exh	441-5604
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370

Sales Model 3126 (Cont'd.)

6SR		
Original Part Number	Part Name	Classic Part Number
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912

6SR		
Original Part Number	Part Name	Classic Part Number
277-7089	Shaft As	380-7578
441-9566	Gear-Flywheel	374-4703

7LZ		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4P-5435	Compressor As	396-9942
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-4137	Shaft As.	378-3986

7LZ		
Original Part Number	Part Name	Classic Part Number
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

7LZ		
Original Part Number	Part Name	Classic Part Number
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
237-6367	Kit - Gasket-Sch	437-8625
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441

8HW		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4P-5435	Compressor As	396-9942
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-4137	Shaft As.	378-3986

8HW		
Original Part Number	Part Name	Classic Part Number
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

8HW		
Original Part Number	Part Name	Classic Part Number
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
237-6367	Kit - Gasket-Sch	437-8625
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441

Sales Model 3126 (Cont'd.)

8NM		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3D-9126	Cup-Roller Brg	399-4435
4B-7255	Cone-Bearing	386-4951
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
5B-9169	Plug-Drain	419-4736
5P-7807	Bearing-Ball	314-8502
6L-2279	Plug-Ptf	419-4739
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6Y-7652	Cup-Rlr Brg	399-6067
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

8NM		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8H-4320	Bearing-Ball	419-2301
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693

8NM		
Original Part Number	Part Name	Classic Part Number
119-2940	Gasket	378-4002
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5911	Manifold As.-Exh	441-5604
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
441-9566	Gear-Flywheel	374-4703

9ZR		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2L-4238	Mount-Flexible	385-7222
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3N-3786	Rod-Thrt Cont	397-5051
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4P-5433	Compressor As	419-4728
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596

9ZR		
Original Part Number	Part Name	Classic Part Number
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2541	Shaft-Gov Cont	399-8580
5L-9656	Cone-Bearing	399-4448
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065
6I-1099	Manifold-Exh	424-6366
6L-7751	Rod End-Spher	472-8015
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030

9ZR		
Original Part Number	Part Name	Classic Part Number
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7S-8443	Muffler	247-2675
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-9027	Base-Oil Cooler	399-8545

Sales Model 3126 (Cont'd.)

9ZR		
Original Part Number	Part Name	Classic Part Number
8L-4282	Hub	444-0573
8L-8867	Pulley	434-1409
9N-3668	Base As.-Coolant	419-4718
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-1337	Ring Kit-Pstn	377-5834

9ZR		
Original Part Number	Part Name	Classic Part Number
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
151-5911	Manifold As.-Exh	441-5604

9ZR		
Original Part Number	Part Name	Classic Part Number
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
290-0187	Kit-Gasket-Sch	437-8116
352-2151	Pump Gp-Water -B	434-6107
441-9566	Gear-Flywheel	374-4703

CKK		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3N-3786	Rod-Thrt Cont	397-5051
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-2541	Shaft-Gov Cont	399-8580
5B-9169	Plug-Drain	419-4736
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6V-2202	Bearing-Spl Ball	380-1574
7C-6976	Bearing-Conn Rod	419-6317

CKK		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-2731	Retainer	423-3541
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8L-4282	Hub	444-0573
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693

CKK		
Original Part Number	Part Name	Classic Part Number
119-2940	Gasket	378-4002
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
151-5911	Manifold As.-Exh	441-5604
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
265-9185	Kit-Gasket(Ocl)	437-8631
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
441-9566	Gear-Flywheel	374-4703

M26		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667

M26		
Original Part Number	Part Name	Classic Part Number
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-2042	Spacer	325-6217

M26		
Original Part Number	Part Name	Classic Part Number
6I-1099	Manifold-Exh	424-6366
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

Sales Model 3126 (Cont'd.)

M26		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-9027	Base-Oil Cooler	399-8545
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692

M26		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

M26		
Original Part Number	Part Name	Classic Part Number
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
441-9566	Gear-Flywheel	374-4703

NSW		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
6L-2279	Plug-Ptf	419-4739
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551

NSW		
Original Part Number	Part Name	Classic Part Number
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-9027	Base-Oil Cooler	399-8545
8H-4320	Bearing-Ball	419-2301
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
133-4995	Gasket-Cyl Head	434-2445

NSW		
Original Part Number	Part Name	Classic Part Number
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5911	Manifold As.-Exh	441-5604
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
441-9566	Gear-Flywheel	374-4703

RZS		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667

RZS		
Original Part Number	Part Name	Classic Part Number
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
5B-9169	Plug-Drain	419-4736
6L-2279	Plug-Ptf	419-4739

RZS		
Original Part Number	Part Name	Classic Part Number
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449

Sales Model 3126 (Cont'd.)

RZS		
Original Part Number	Part Name	Classic Part Number
7W-3145	Plate	422-7894
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
8H-4320	Bearing-Ball	419-2301
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381

RZS		
Original Part Number	Part Name	Classic Part Number
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
151-5911	Manifold As.-Exh	441-5604

RZS		
Original Part Number	Part Name	Classic Part Number
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
441-9566	Gear-Flywheel	374-4703

Sales Model 3126A

GKE		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
2W-7213	Bearing-Sleeve	419-4667
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
6I-1099	Manifold-Exh	424-6366
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583

GKE		
Original Part Number	Part Name	Classic Part Number
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693

GKE		
Original Part Number	Part Name	Classic Part Number
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

Sales Model 3126B

1AJ		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
7C-6976	Bearing-Conn Rod	419-6317

1AJ		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983

1AJ		
Original Part Number	Part Name	Classic Part Number
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449

Sales Model 3126B (Cont'd.)

1AJ		
Original Part Number	Part Name	Classic Part Number
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

1AJ		
Original Part Number	Part Name	Classic Part Number
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371

1AJ		
Original Part Number	Part Name	Classic Part Number
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
441-9566	Gear-Flywheel	374-4703

3GS		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2W-7213	Bearing-Sleeve	419-4667
3D-9126	Cup-Roller Brg	399-4435
5B-9169	Plug-Drain	419-4736
5P-7807	Bearing-Ball	314-8502
6L-2279	Plug-Ptf	419-4739
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
7C-6976	Bearing-Conn Rod	419-6317

3GS		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3145	Plate	422-7894
7W-5095	Gear-Flywheel	425-9190
8H-4320	Bearing-Ball	419-2301
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380

3GS		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
255-6863	Gasket	450-5024
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
441-9566	Gear-Flywheel	374-4703

5GL		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4P-5435	Compressor As	396-9942
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

5GL		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

5GL		
Original Part Number	Part Name	Classic Part Number
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441

Sales Model 3126B (Cont'd.)

6PZ		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381

6PZ		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870

6PZ		
Original Part Number	Part Name	Classic Part Number
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
262-7133	Kit-Gasket (Sch)	437-8633
266-4561	Kit-Gasket-Cl	437-8628
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441
441-9566	Gear-Flywheel	374-4703

6ZG		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

6ZG		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

6ZG		
Original Part Number	Part Name	Classic Part Number
163-1387	Gear-Flywheel	374-4697
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
265-9185	Kit-Gasket(Ocl)	437-8631
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441

7AS		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4P-5435	Compressor As	396-9942

7AS		
Original Part Number	Part Name	Classic Part Number
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449

7AS		
Original Part Number	Part Name	Classic Part Number
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381

Sales Model 3126B (Cont'd.)

7AS		
Original Part Number	**Part Name**	**Classic Part Number**
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-0162	Bearing-Main	419-6380

7AS		
Original Part Number	**Part Name**	**Classic Part Number**
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

7AS		
Original Part Number	**Part Name**	**Classic Part Number**
262-7133	Kit-Gasket (Sch)	437-8633
265-9185	Kit-Gasket(Ocl)	437-8631
266-5907	Kit-Gasket-Cl	438-0155
266-6621	Kit-Gasket(Cl)	438-0154
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
288-6375	Kit-Gasket(Fs)	437-8104
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441
352-2163	Pump As-Water	434-6106
441-9566	Gear-Flywheel	374-4703

7JZ		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381

7JZ		
Original Part Number	**Part Name**	**Classic Part Number**
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870

7JZ		
Original Part Number	**Part Name**	**Classic Part Number**
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
262-7133	Kit-Gasket (Sch)	437-8633
266-4561	Kit-Gasket-Cl	437-8628
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441
441-9566	Gear-Flywheel	374-4703

8SZ		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4P-5435	Compressor As	396-9942
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

8SZ		
Original Part Number	**Part Name**	**Classic Part Number**
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190

8SZ		
Original Part Number	**Part Name**	**Classic Part Number**
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219

Sales Model 3126B (Cont'd.)

8SZ		
Original Part Number	**Part Name**	**Classic Part Number**
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380

8SZ		
Original Part Number	**Part Name**	**Classic Part Number**
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371

8SZ		
Original Part Number	**Part Name**	**Classic Part Number**
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
265-9185	Kit-Gasket(Ocl)	437-8631
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441

8YL		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-5435	Compressor As	396-9942
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5S-8543	Bearing-Sleeve	376-3635
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7T-8816	Bearing-Spl Ball	420-2491
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
8H-9789	Bearing-Ball	374-8342

8YL		
Original Part Number	**Part Name**	**Classic Part Number**
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
218-4389	Kit-Gasket (Sch)	437-8124
224-6638	Bearing-Rod	419-6371

8YL		
Original Part Number	**Part Name**	**Classic Part Number**
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
262-5009	Kit-Gasket (Sch)	437-8635
262-5080	Kit-Gasket-Sch	437-8634
262-7133	Kit-Gasket (Sch)	437-8633
265-9185	Kit-Gasket(Ocl)	437-8631
266-4561	Kit-Gasket-Cl	437-8628
266-5907	Kit-Gasket-Cl	438-0155
266-6621	Kit-Gasket(Cl)	438-0154
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
288-6375	Kit-Gasket(Fs)	437-8104
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441
352-2160	Pump Gp-Water -B	433-0789
352-2163	Pump As-Water	434-6106
441-9566	Gear-Flywheel	374-4703

9SZ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913

Sales Model 3126B (Cont'd.)

9SZ		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-5435	Compressor As	396-9942
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5S-8543	Bearing-Sleeve	376-3635
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7T-8816	Bearing-Spl Ball	420-2491
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
8H-9789	Bearing-Ball	374-8342
100-6267	Plate As-Idler	375-9983

9SZ		
Original Part Number	Part Name	Classic Part Number
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
218-4389	Kit-Gasket (Sch)	437-8124
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370

9SZ		
Original Part Number	Part Name	Classic Part Number
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
262-5009	Kit-Gasket (Sch)	437-8635
262-5080	Kit-Gasket-Sch	437-8634
262-7133	Kit-Gasket (Sch)	437-8633
265-9185	Kit-Gasket(Ocl)	437-8631
266-4561	Kit-Gasket-Cl	437-8628
266-5907	Kit-Gasket-Cl	438-0155
266-6621	Kit-Gasket(Cl)	438-0154
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
288-6375	Kit-Gasket(Fs)	437-8104
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441
352-2160	Pump Gp-Water -B	433-0789
352-2163	Pump As-Water	434-6106
441-9566	Gear-Flywheel	374-4703

9ZF		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2W-7213	Bearing-Sleeve	419-4667
3D-9126	Cup-Roller Brg	399-4435
5B-9169	Plug-Drain	419-4736
5P-7807	Bearing-Ball	314-8502
6L-2279	Plug-Ptf	419-4739
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
7C-6976	Bearing-Conn Rod	419-6317

9ZF		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3145	Plate	422-7894
7W-5095	Gear-Flywheel	425-9190
8H-4320	Bearing-Ball	419-2301
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380

9ZF		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
255-6863	Gasket	450-5024
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
441-9566	Gear-Flywheel	374-4703

Sales Model 3126B (Cont'd.)

BDZ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-5095	Gear-Flywheel	425-9190
9W-9930	Mount As	295-6437
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

BDZ		
Original Part Number	**Part Name**	**Classic Part Number**
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
212-4893	Bearing-Thrust	419-6372

BDZ		
Original Part Number	**Part Name**	**Classic Part Number**
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441
441-9566	Gear-Flywheel	374-4703

BEJ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
2W-8494	Pulley-Alt	295-5692
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4S-8472	Hood As-Preclnr	296-1355
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5B-9169	Plug-Drain	419-4736
5L-9656	Cone-Bearing	399-4448
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-8543	Bearing-Sleeve	376-3635
6B-3223	Cup-Bearing	399-6065
6V-2202	Bearing-Spl Ball	380-1574

BEJ		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7N-7435	Kit-Major Repair	374-4724
7S-8443	Muffler	247-2675
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449

BEJ		
Original Part Number	**Part Name**	**Classic Part Number**
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
262-7133	Kit-Gasket (Sch)	437-8633
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710

Sales Model 3126B (Cont'd.)

BEJ		
Original Part Number	**Part Name**	**Classic Part Number**
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444

BEJ		
Original Part Number	**Part Name**	**Classic Part Number**
352-2157	Pump Gp-Water -B	433-0441

BEJ		
Original Part Number	**Part Name**	**Classic Part Number**
441-9566	Gear-Flywheel	374-4703

BES		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

BES		
Original Part Number	**Part Name**	**Classic Part Number**
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

BES		
Original Part Number	**Part Name**	**Classic Part Number**
154-8030	Gasket	394-0894
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441

BKD		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4P-5435	Compressor As	396-9942
5S-8543	Bearing-Sleeve	376-3635
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

BKD		
Original Part Number	**Part Name**	**Classic Part Number**
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372

BKD		
Original Part Number	**Part Name**	**Classic Part Number**
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
262-5080	Kit-Gasket-Sch	437-8634
262-7133	Kit-Gasket (Sch)	437-8633
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441
352-2163	Pump As-Water	434-6106
441-9566	Gear-Flywheel	374-4703

Sales Model 3126B (Cont'd.)

CKM		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4P-5435	Compressor As	396-9942
5S-8543	Bearing-Sleeve	376-3635
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069

CKM		
Original Part Number	Part Name	Classic Part Number
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
218-4389	Kit-Gasket (Sch)	437-8124
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370

CKM		
Original Part Number	Part Name	Classic Part Number
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
262-5009	Kit-Gasket (Sch)	437-8635
262-5080	Kit-Gasket-Sch	437-8634
262-7133	Kit-Gasket (Sch)	437-8633
265-9185	Kit-Gasket(Ocl)	437-8631
266-4561	Kit-Gasket-Cl	437-8628
266-5907	Kit-Gasket-Cl	438-0155
266-6621	Kit-Gasket(Cl)	438-0154
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
288-6375	Kit-Gasket(Fs)	437-8104
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441
352-2163	Pump As-Water	434-6106
441-9566	Gear-Flywheel	374-4703

DCD		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7S-8443	Muffler	247-2675
7W-5095	Gear-Flywheel	425-9190

DCD		
Original Part Number	Part Name	Classic Part Number
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

DCD		
Original Part Number	Part Name	Classic Part Number
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
441-9566	Gear-Flywheel	374-4703

DCS		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667

DCS		
Original Part Number	Part Name	Classic Part Number
2W-8494	Pulley-Alt	295-5692
4N-2572	Spider As-Fan	451-9027
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

DCS		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6V-2202	Bearing-Spl Ball	380-1574

Sales Model 3126B (Cont'd.)

DCS		
Original Part Number	Part Name	Classic Part Number
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381

DCS		
Original Part Number	Part Name	Classic Part Number
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449
124-3237	Precleaner As	432-4220
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
190-0649	Tightener-Belt	434-1407

DCS		
Original Part Number	Part Name	Classic Part Number
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441
441-9566	Gear-Flywheel	374-4703

Z2A		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
5B-9169	Plug-Drain	419-4736
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449

Z2A		
Original Part Number	Part Name	Classic Part Number
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
133-4995	Gasket-Cyl Head	434-2445

Z2A		
Original Part Number	Part Name	Classic Part Number
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912

Sales Model 3126E

1AJ		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

1AJ		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896

1AJ		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445

Sales Model 3126E (Cont'd.)

1AJ		
Original Part Number	Part Name	Classic Part Number
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

1AJ		
Original Part Number	Part Name	Classic Part Number
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370

1AJ		
Original Part Number	Part Name	Classic Part Number
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
441-9566	Gear-Flywheel	374-4703

3RW		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

3RW		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449
126-5875	Flywheel As.	374-4694
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

3RW		
Original Part Number	Part Name	Classic Part Number
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441

6ZG		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

6ZG		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

6ZG		
Original Part Number	Part Name	Classic Part Number
163-1387	Gear-Flywheel	374-4697
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
265-9185	Kit-Gasket(Ocl)	437-8631
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441

Sales Model 3126E (Cont'd.)

8SZ		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4P-5435	Compressor As	396-9942
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

8SZ		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

8SZ		
Original Part Number	Part Name	Classic Part Number
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
265-9185	Kit-Gasket(Ocl)	437-8631
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441

8YL		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-5435	Compressor As	396-9942
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5S-8543	Bearing-Sleeve	376-3635
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7T-8816	Bearing-Spl Ball	420-2491
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190

8YL		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735

8YL		
Original Part Number	Part Name	Classic Part Number
218-4389	Kit-Gasket (Sch)	437-8124
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
262-5009	Kit-Gasket (Sch)	437-8635
262-5080	Kit-Gasket-Sch	437-8634
262-7133	Kit-Gasket (Sch)	437-8633
265-9185	Kit-Gasket(Ocl)	437-8631
266-4561	Kit-Gasket-Cl	437-8628
266-5907	Kit-Gasket-Cl	438-0155
266-6621	Kit-Gasket(Cl)	438-0154
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
288-6375	Kit-Gasket(Fs)	437-8104
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441

Sales Model 3126E (Cont'd.)

8YL		
Original Part Number	**Part Name**	**Classic Part Number**
352-2160	Pump Gp-Water -B	433-0789

8YL		
Original Part Number	**Part Name**	**Classic Part Number**
352-2163	Pump As-Water	434-6106

8YL		
Original Part Number	**Part Name**	**Classic Part Number**
441-9566	Gear-Flywheel	374-4703

9SZ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-5435	Compressor As	396-9942
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5S-8543	Bearing-Sleeve	376-3635
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7T-8816	Bearing-Spl Ball	420-2491
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
8H-9789	Bearing-Ball	374-8342

9SZ		
Original Part Number	**Part Name**	**Classic Part Number**
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
218-4389	Kit-Gasket (Sch)	437-8124
224-6638	Bearing-Rod	419-6371

9SZ		
Original Part Number	**Part Name**	**Classic Part Number**
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
262-5009	Kit-Gasket (Sch)	437-8635
262-5080	Kit-Gasket-Sch	437-8634
262-7133	Kit-Gasket (Sch)	437-8633
265-9185	Kit-Gasket(Ocl)	437-8631
266-4561	Kit-Gasket-Cl	437-8628
266-5907	Kit-Gasket-Cl	438-0155
266-6621	Kit-Gasket(Cl)	438-0154
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
288-6375	Kit-Gasket(Fs)	437-8104
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441
352-2160	Pump Gp-Water -B	433-0789
352-2163	Pump As-Water	434-6106
441-9566	Gear-Flywheel	374-4703

BKD		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4P-5435	Compressor As	396-9942
5S-8543	Bearing-Sleeve	376-3635
7C-5403	Tube As	374-4673

BKD		
Original Part Number	**Part Name**	**Classic Part Number**
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190

BKD		
Original Part Number	**Part Name**	**Classic Part Number**
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449

Sales Model 3126E (Cont'd.)

BKD		
Original Part Number	**Part Name**	**Classic Part Number**
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697

BKD		
Original Part Number	**Part Name**	**Classic Part Number**
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
262-5080	Kit-Gasket-Sch	437-8634

BKD		
Original Part Number	**Part Name**	**Classic Part Number**
262-7133	Kit-Gasket (Sch)	437-8633
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441
352-2163	Pump As-Water	434-6106
441-9566	Gear-Flywheel	374-4703

BNG		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449

BNG		
Original Part Number	**Part Name**	**Classic Part Number**
7E-8926	Head Kt-Cyl	377-5847
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

BNG		
Original Part Number	**Part Name**	**Classic Part Number**
154-8030	Gasket	394-0894
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710

CKM		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4P-5435	Compressor As	396-9942
5S-8543	Bearing-Sleeve	376-3635
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583

CKM		
Original Part Number	**Part Name**	**Classic Part Number**
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380

CKM		
Original Part Number	**Part Name**	**Classic Part Number**
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
218-4389	Kit-Gasket (Sch)	437-8124
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
262-5009	Kit-Gasket (Sch)	437-8635

Sales Model 3126E (Cont'd.)

CKM		
Original Part Number	**Part Name**	**Classic Part Number**
262-5080	Kit-Gasket-Sch	437-8634
262-7133	Kit-Gasket (Sch)	437-8633
265-9185	Kit-Gasket(Ocl)	437-8631
266-4561	Kit-Gasket-Cl	437-8628
266-5907	Kit-Gasket-Cl	438-0155

CKM		
Original Part Number	**Part Name**	**Classic Part Number**
266-6621	Kit-Gasket(Cl)	438-0154
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
288-6375	Kit-Gasket(Fs)	437-8104
352-2153	Pump As-Water	433-0444

CKM		
Original Part Number	**Part Name**	**Classic Part Number**
352-2157	Pump Gp-Water -B	433-0441
352-2163	Pump As-Water	434-6106
441-9566	Gear-Flywheel	374-4703

CRP		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4P-5435	Compressor As	396-9942
5S-8543	Bearing-Sleeve	376-3635
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

CRP		
Original Part Number	**Part Name**	**Classic Part Number**
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372

CRP		
Original Part Number	**Part Name**	**Classic Part Number**
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
262-5009	Kit-Gasket (Sch)	437-8635
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441
352-2163	Pump As-Water	434-6106
441-9566	Gear-Flywheel	374-4703

DPF		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
5S-8543	Bearing-Sleeve	376-3635
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

DPF		
Original Part Number	**Part Name**	**Classic Part Number**
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693

DPF		
Original Part Number	**Part Name**	**Classic Part Number**
118-2089	Pulley	434-2449
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697

Sales Model 3126E (Cont'd.)

DPF		
Original Part Number	**Part Name**	**Classic Part Number**
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370

DPF		
Original Part Number	**Part Name**	**Classic Part Number**
229-5154	Bearing-Thrust	419-6369
262-5080	Kit-Gasket-Sch	437-8634
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578

DPF		
Original Part Number	**Part Name**	**Classic Part Number**
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441
441-9566	Gear-Flywheel	374-4703

FML		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

FML		
Original Part Number	**Part Name**	**Classic Part Number**
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697

FML		
Original Part Number	**Part Name**	**Classic Part Number**
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441
441-9566	Gear-Flywheel	374-4703

FMM		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

FMM		
Original Part Number	**Part Name**	**Classic Part Number**
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696

FMM		
Original Part Number	**Part Name**	**Classic Part Number**
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441
441-9566	Gear-Flywheel	374-4703

Sales Model 3126E (Cont'd.)

G3E		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

G3E		
Original Part Number	**Part Name**	**Classic Part Number**
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-2089	Pulley	434-2449
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

G3E		
Original Part Number	**Part Name**	**Classic Part Number**
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441
441-9566	Gear-Flywheel	374-4703

HEP		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4P-5435	Compressor As	396-9942
5S-8543	Bearing-Sleeve	376-3635
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7W-3773	Pulley-Cshaft	383-1583
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069

HEP		
Original Part Number	**Part Name**	**Classic Part Number**
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-9712	Shaft-Dr Idler	425-7754
118-2089	Pulley	434-2449
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
131-7123	Bearing-Sleeve	422-6919
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735

HEP		
Original Part Number	**Part Name**	**Classic Part Number**
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
265-9183	Kit-Gasket (Sch)	437-8632
265-9185	Kit-Gasket(Ocl)	437-8631
265-9186	Kit-Gasket (Sch)	437-8630
266-2540	Kit-Gasket (Sch)	437-8629
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
289-6232	Kit-Gasket (Sch)	437-8661
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441
352-2163	Pump As-Water	434-6106
441-9566	Gear-Flywheel	374-4703

Sales Model 3126E (Cont'd.)

LEF		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449

LEF		
Original Part Number	**Part Name**	**Classic Part Number**
7W-5095	Gear-Flywheel	425-9190
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

LEF		
Original Part Number	**Part Name**	**Classic Part Number**
154-8030	Gasket	394-0894
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
441-9566	Gear-Flywheel	374-4703

Sales Model 3145

65P		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
2A-4429	Lock-Retainer	379-0174
2N-1572	Muffler As-Exh	361-6575
2W-8271	Arm As-Rocker	432-8912
5P-7807	Bearing-Ball	314-8502
5P-8545	Gasket Kit	437-8626
5S-5917	Screw-Rocker Adj	380-7537

65P		
Original Part Number	**Part Name**	**Classic Part Number**
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7M-7219	Bearing-Thrust	384-4816
7W-2059	Gasket-Cyl Hd	380-1548
8H-2810	Case As-Filter	314-8512
8N-0701	Bearing-Sleeve	419-4745
9L-7682	Valve-Inlet	385-9266

65P		
Original Part Number	**Part Name**	**Classic Part Number**
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
119-6772	Valve-Exhaust	384-8699
234-7989	Kit-Gasket-Sch	437-8122

96M		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2N-1572	Muffler As-Exh	361-6575
2N-1599	Gear	378-3970
2N-2139	Cone-Roller Brg	415-1911
2W-8271	Arm As-Rocker	432-8912
3N-3368	Pipe-Exhaust	311-9434
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502

96M		
Original Part Number	**Part Name**	**Classic Part Number**
5P-8545	Gasket Kit	437-8626
5S-5917	Screw-Rocker Adj	380-7537
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7F-2742	Bearing-Ball	422-6488
7M-7219	Bearing-Thrust	384-4816
7W-2059	Gasket-Cyl Hd	380-1548

96M		
Original Part Number	**Part Name**	**Classic Part Number**
8H-2810	Case As-Filter	314-8512
8N-0701	Bearing-Sleeve	419-4745
9H-2256	Pump Gp-F Prm	311-9443
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
119-6772	Valve-Exhaust	384-8699
214-6045	Bellows As	435-4846
234-7989	Kit-Gasket-Sch	437-8122

Sales Model 3150

66P		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
2A-4429	Lock-Retainer	379-0174
2N-1572	Muffler As-Exh	361-6575
2W-8271	Arm As-Rocker	432-8912
5P-7807	Bearing-Ball	314-8502
5P-8545	Gasket Kit	437-8626
5S-5917	Screw-Rocker Adj	380-7537

66P		
Original Part Number	Part Name	Classic Part Number
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7M-7219	Bearing-Thrust	384-4816
7W-2059	Gasket-Cyl Hd	380-1548
8H-2810	Case As-Filter	314-8512
8N-0701	Bearing-Sleeve	419-4745
9L-7682	Valve-Inlet	385-9266

66P		
Original Part Number	Part Name	Classic Part Number
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
119-6772	Valve-Exhaust	384-8699
234-7989	Kit-Gasket-Sch	437-8122

97M		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-7125	Governor As	383-3672
1S-7056	Bearing-Ball	422-6483
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2N-1572	Muffler As-Exh	361-6575
2N-1599	Gear	378-3970
2N-2139	Cone-Roller Brg	415-1911
2W-8271	Arm As-Rocker	432-8912
3N-3368	Pipe-Exhaust	311-9434
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502

97M		
Original Part Number	Part Name	Classic Part Number
5P-8545	Gasket Kit	437-8626
5S-5917	Screw-Rocker Adj	380-7537
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7F-2742	Bearing-Ball	422-6488
7L-4302	Gasket	420-8570
7M-7219	Bearing-Thrust	384-4816
7W-2059	Gasket-Cyl Hd	380-1548

97M		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8N-0701	Bearing-Sleeve	419-4745
9H-2256	Pump Gp-F Prm	311-9443
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
119-6772	Valve-Exhaust	384-8699
214-6045	Bellows As	435-4846
234-7989	Kit-Gasket-Sch	437-8122
282-2065	Kit-Gasket-T	438-0184
313-4914	Kit-Gasket(T)	438-0182

Sales Model 3156B

GSA		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1W-6005	Bearing-Sleeve	417-4521
1W-6356	Gasket	438-1795
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-4444	Bearing	419-6029
2N-5842	Screw-Bridge Adj	418-1934

GSA		
Original Part Number	Part Name	Classic Part Number
2S-5100	Valve-Ball	386-3049
3N-1968	Mount-Shock	397-5046
3N-8463	Bearing-Roller	394-9193
4M-6107	Bearing-Roller	380-7507
4N-1320	Gasket-Adapter	398-2928
5N-2902	Seal-Oil	314-8540
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6L-2279	Plug-Ptf	419-4739

GSA		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
7N-5449	Spool-Press Rlf	434-2450
8T-0209	Race-Spl Rlr Brg	384-5951
9Y-0635	Spacer	435-8519
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
207-1332	Bellows As	444-0569

Sales Model 3160

57V		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2B-0941	Spacer	418-1955
2W-8271	Arm As-Rocker	432-8912
2W-8271	Arm As-Rocker	432-8912
4N-0209	Bonnet-Valve	378-3973
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-2954	Sleeve-Camshaft	299-2059
5P-7807	Bearing-Ball	314-8502
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5S-5917	Screw-Rocker Adj	380-7537

57V		
Original Part Number	Part Name	Classic Part Number
7E-2888	Gear-Fuel Pump	397-5062
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7E-7894	Bearing-Rod	419-7260
7M-7219	Bearing-Thrust	384-4816
7M-7219	Bearing-Thrust	384-4816
7W-2059	Gasket-Cyl Hd	380-1548
7W-2059	Gasket-Cyl Hd	380-1548
8N-0701	Bearing-Sleeve	419-4745
8N-0701	Bearing-Sleeve	419-4745
9L-7682	Valve-Inlet	385-9266
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914

57V		
Original Part Number	Part Name	Classic Part Number
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9N-6500	Rod-Valve Push	383-3706
9Y-0231	Line As-F Inj	390-0932
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
9Y-0238	Line As-F Inj	390-0939
119-6772	Valve-Exhaust	384-8699
119-6772	Valve-Exhaust	384-8699

67P		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
2A-4429	Lock-Retainer	379-0174
2N-1572	Muffler As-Exh	361-6575
2W-8271	Arm As-Rocker	432-8912
5P-7807	Bearing-Ball	314-8502
5P-8545	Gasket Kit	437-8626
5S-5917	Screw-Rocker Adj	380-7537

67P		
Original Part Number	Part Name	Classic Part Number
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7M-7219	Bearing-Thrust	384-4816
7W-2059	Gasket-Cyl Hd	380-1548
8H-2810	Case As-Filter	314-8512
8N-0701	Bearing-Sleeve	419-4745
9L-7682	Valve-Inlet	385-9266

67P		
Original Part Number	Part Name	Classic Part Number
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
119-6772	Valve-Exhaust	384-8699
234-7989	Kit-Gasket-Sch	437-8122

68P		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354

68P		
Original Part Number	Part Name	Classic Part Number
2N-1599	Gear	378-3970
2W-8271	Arm As-Rocker	432-8912
3D-9126	Cup-Roller Brg	399-4435
3N-6411	Cup-Rlr Bearing	423-7759

68P		
Original Part Number	Part Name	Classic Part Number
4D-2619	Bearing	417-4494
4L-8473	Plate-Wear	419-0883
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915

Sales Model 3160 (Cont'd.)

68P		
Original Part Number	Part Name	Classic Part Number
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
5P-7807	Bearing-Ball	314-8502
5P-8545	Gasket Kit	437-8626
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
6D-1734	Cup-Roller Brg	416-2171
6L-2279	Plug-Ptf	419-4739
6V-2202	Bearing-Spl Ball	380-1574
7E-2888	Gear-Fuel Pump	397-5062

68P		
Original Part Number	Part Name	Classic Part Number
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7M-7219	Bearing-Thrust	384-4816
7W-2059	Gasket-Cyl Hd	380-1548
7W-2731	Retainer	423-3541
8H-2810	Case As-Filter	314-8512
8N-0701	Bearing-Sleeve	419-4745
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607

68P		
Original Part Number	Part Name	Classic Part Number
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
119-6772	Valve-Exhaust	384-8699
234-7989	Kit-Gasket-Sch	437-8122
234-7991	Kit-Gasket-Mch	437-8121

98M		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2N-1572	Muffler As-Exh	361-6575
2N-1599	Gear	378-3970
2N-2139	Cone-Roller Brg	415-1911
2W-8271	Arm As-Rocker	432-8912
3N-3368	Pipe-Exhaust	311-9434
4D-2619	Bearing	417-4494
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379

98M		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8545	Gasket Kit	437-8626
5S-5917	Screw-Rocker Adj	380-7537
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7F-2742	Bearing-Ball	422-6488
7M-7219	Bearing-Thrust	384-4816
7W-2059	Gasket-Cyl Hd	380-1548
8H-2810	Case As-Filter	314-8512
8N-0701	Bearing-Sleeve	419-4745
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443

98M		
Original Part Number	Part Name	Classic Part Number
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
119-6772	Valve-Exhaust	384-8699
214-6045	Bellows As	435-4846
234-7989	Kit-Gasket-Sch	437-8122

Sales Model 3176

2YG		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
4N-1119	Gear-Tfr Pump	373-1884
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657

2YG		
Original Part Number	**Part Name**	**Classic Part Number**
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
8H-9789	Bearing-Ball	374-8342
8N-3666	Repair Kt-Major	377-5842
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
110-1337	Ring Kit-Pstn	377-5834
111-2645	Valve-Pump Byp	441-1561

2YG		
Original Part Number	**Part Name**	**Classic Part Number**
116-1102	Sleeve-Injector	451-9024
133-3545	Tightener-Belt	434-1407
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
190-0649	Tightener-Belt	434-1407
223-8228	Kit-Gasket (Sch)	437-8142

5XN		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847

5XN		
Original Part Number	**Part Name**	**Classic Part Number**
7F-2742	Bearing-Ball	422-6488
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8N-3666	Repair Kt-Major	377-5842
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
110-1337	Ring Kit-Pstn	377-5834
111-2645	Valve-Pump Byp	441-1561

5XN		
Original Part Number	**Part Name**	**Classic Part Number**
116-1102	Sleeve-Injector	451-9024
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600

7LG		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
3E-3322	Gasket Kit - F	437-8114
3E-3332	Kit-Gasket(Ocl)	437-8113
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041

7LG		
Original Part Number	**Part Name**	**Classic Part Number**
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
5S-8543	Bearing-Sleeve	376-3635
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724

7LG		
Original Part Number	**Part Name**	**Classic Part Number**
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
8H-9789	Bearing-Ball	374-8342
8N-3666	Repair Kt-Major	377-5842
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
110-1337	Ring Kit-Pstn	377-5834
111-2645	Valve-Pump Byp	441-1561

Sales Model 3176 (Cont'd.)

7LG		
Original Part Number	Part Name	Classic Part Number
113-6200	Gasket	438-2020
116-1102	Sleeve-Injector	451-9024
119-2940	Gasket	378-4002
133-3545	Tightener-Belt	434-1407
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312

7LG		
Original Part Number	Part Name	Classic Part Number
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600

7LG		
Original Part Number	Part Name	Classic Part Number
190-0649	Tightener-Belt	434-1407
221-0859	Kit-Gasket-T	437-8135
223-8228	Kit-Gasket (Sch)	437-8142
312-5931	Kit-Gasket (Sch)	438-0140

LZD		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
6V-3831	Seal-O-Ring	436-2657
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646

LZD		
Original Part Number	Part Name	Classic Part Number
101-3125	Gasket	420-8567
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

LZD		
Original Part Number	Part Name	Classic Part Number
118-2800	Housing As.-Rglt	419-4719
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
176-4168	Bridge As-Valve	419-4727
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
216-4781	Gasket Kit	437-8144

Sales Model 3176B

3LZ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650

3LZ		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8N-3666	Repair Kt-Major	377-5842
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
110-1337	Ring Kit-Pstn	377-5834
111-2645	Valve-Pump Byp	441-1561
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446

3LZ		
Original Part Number	Part Name	Classic Part Number
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
216-4781	Gasket Kit	437-8144

Sales Model 3176B (Cont'd.)

3NL		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2W-5539	Core As-Rad	374-7492
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
3E-3332	Kit-Gasket(Ocl)	437-8113
3N-3017	Adapter As	433-2031
4B-7270	Cone-Bearing	399-4439
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6805	Flywheel As	421-3325
5F-8651	Bearing-Ball	420-3223

3NL		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-8543	Bearing-Sleeve	376-3635
6B-3223	Cup-Bearing	399-6065
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-9146	Gear-Fly Starter	279-4995
7W-0205	Core As-Oclr	379-0183
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
8D-0983	Mounting	384-3470
8N-3666	Repair Kt-Major	377-5842
9S-7148	Cap As-Rain	378-3994
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281

3NL		
Original Part Number	Part Name	Classic Part Number
110-1337	Ring Kit-Pstn	377-5834
111-2645	Valve-Pump Byp	441-1561
116-1102	Sleeve-Injector	451-9024
133-3545	Tightener-Belt	434-1407
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
190-0649	Tightener-Belt	434-1407
216-7957	U-Joint	367-6069
221-0859	Kit-Gasket-T	437-8135
223-7811	Kit-Gasket (Sch)	437-8636
223-8228	Kit-Gasket (Sch)	437-8142
255-6863	Gasket	450-5024
312-5931	Kit-Gasket (Sch)	438-0140
352-2077	Pump Gp-Water -B	434-6108

9CK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
3E-3332	Kit-Gasket(Ocl)	437-8113
3E-4329	Kit-Gasket(Ocl)	437-8110
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
5S-8543	Bearing-Sleeve	376-3635
6V-2202	Bearing-Spl Ball	380-1574

9CK		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
8H-9789	Bearing-Ball	374-8342
8N-3666	Repair Kt-Major	377-5842
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281

9CK		
Original Part Number	Part Name	Classic Part Number
110-1337	Ring Kit-Pstn	377-5834
111-2645	Valve-Pump Byp	441-1561
116-1102	Sleeve-Injector	451-9024
133-3545	Tightener-Belt	434-1407
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573

Sales Model 3176B (Cont'd.)

9CK		
Original Part Number	Part Name	Classic Part Number
176-6998	Impeller-Wtr Pmp	425-9367
190-0649	Tightener-Belt	434-1407
221-0859	Kit-Gasket-T	437-8135

9CK		
Original Part Number	Part Name	Classic Part Number
223-7811	Kit-Gasket (Sch)	437-8636
223-8228	Kit-Gasket (Sch)	437-8142

9CK		
Original Part Number	Part Name	Classic Part Number
312-5931	Kit-Gasket (Sch)	438-0140
352-2077	Pump Gp-Water -B	434-6108

9WK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
3N-3017	Adapter As	433-2031
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
5F-8651	Bearing-Ball	420-3223
5P-7807	Bearing-Ball	314-8502
6L-2279	Plug-Ptf	419-4739
6V-3831	Seal-O-Ring	436-2657
7S-4411	Cap As-Rain	373-1912

9WK		
Original Part Number	Part Name	Classic Part Number
7W-3145	Plate	422-7894
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
116-1102	Sleeve-Injector	451-9024
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154

9WK		
Original Part Number	Part Name	Classic Part Number
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
219-7975	Kit-Gasket (Sch)	437-1999
252-7955	Kit-Gasket(Cl)	437-8654
255-6863	Gasket	450-5024
352-2077	Pump Gp-Water -B	434-6108

Sales Model 3176C

2AW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4P-9942	Seal-End Tank	385-7217

2AW		
Original Part Number	Part Name	Classic Part Number
4P-9943	Seal-End Tank	385-7216
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-7188	Core As-Oclr	374-7501
4W-9822	Core Gp-O Clr	374-4711
5F-8651	Bearing-Ball	420-3223
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-8543	Bearing-Sleeve	376-3635
6B-3223	Cup-Bearing	399-6065
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657

2AW		
Original Part Number	Part Name	Classic Part Number
7C-5665	Elbow-90 Deg	399-8547
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-2731	Retainer	423-3541
7W-3145	Plate	422-7894
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
9S-7148	Cap As-Rain	378-3994
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646

Sales Model 3176C (Cont'd.)

2AW		
Original Part Number	**Part Name**	**Classic Part Number**
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446

2AW		
Original Part Number	**Part Name**	**Classic Part Number**
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
133-3545	Tightener-Belt	434-1407
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
166-6352	Tube As.	432-4223
176-4168	Bridge As-Valve	419-4727

2AW		
Original Part Number	**Part Name**	**Classic Part Number**
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
255-6863	Gasket	450-5024
316-4396	Kit-Gasket (Sch)	393-3661
352-2077	Pump Gp-Water -B	434-6108

6BW		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
3N-3017	Adapter As	433-2031
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
5F-8651	Bearing-Ball	420-3223
5P-7807	Bearing-Ball	314-8502
6L-2279	Plug-Ptf	419-4739
6V-3831	Seal-O-Ring	436-2657
7S-4411	Cap As-Rain	373-1912
7W-2731	Retainer	423-3541
7W-3145	Plate	422-7894
7W-5844	Bearing-Conn Rod	419-4650

6BW		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

6BW		
Original Part Number	**Part Name**	**Classic Part Number**
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
219-7975	Kit-Gasket (Sch)	437-1999
252-7955	Kit-Gasket(Cl)	437-8654
255-6863	Gasket	450-5024
352-2077	Pump Gp-Water -B	434-6108

LSD		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174

LSD		
Original Part Number	**Part Name**	**Classic Part Number**
2W-8494	Pulley-Alt	295-5692
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4W-1203	Cup-Rlr Brg	418-9603

LSD		
Original Part Number	**Part Name**	**Classic Part Number**
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
6V-3831	Seal-O-Ring	436-2657
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488

Sales Model 3176C (Cont'd.)

LSD		
Original Part Number	Part Name	Classic Part Number
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8H-9789	Bearing-Ball	374-8342
9L-5908	Gasket	433-8196
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635

LSD		
Original Part Number	Part Name	Classic Part Number
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554

LSD		
Original Part Number	Part Name	Classic Part Number
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
166-6352	Tube As.	432-4223
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
216-4781	Gasket Kit	437-8144

Sales Model 3196

1DW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-7188	Core As-Oclr	374-7501
4W-9822	Core Gp-O Clr	374-4711
5F-8651	Bearing-Ball	420-3223
5P-7807	Bearing-Ball	314-8502

1DW		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5S-8543	Bearing-Sleeve	376-3635
6B-3223	Cup-Bearing	399-6065
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-5665	Elbow-90 Deg	399-8547
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-2731	Retainer	423-3541
7W-3145	Plate	422-7894
7W-5164	Gasket	420-8568
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
9S-7148	Cap As-Rain	378-3994
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281

1DW		
Original Part Number	Part Name	Classic Part Number
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
133-3545	Tightener-Belt	434-1407
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
176-4168	Bridge As-Valve	419-4727

Sales Model 3196 (Cont'd.)

1DW		
Original Part Number	**Part Name**	**Classic Part Number**
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367

1DW		
Original Part Number	**Part Name**	**Classic Part Number**
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110

1DW		
Original Part Number	**Part Name**	**Classic Part Number**
216-4781	Gasket Kit	437-8144
255-6863	Gasket	450-5024
352-2077	Pump Gp-Water -B	434-6108

2XR		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2W-9978	Core As-Oclr	279-4983
3N-3017	Adapter As	433-2031
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
5F-8651	Bearing-Ball	420-3223
5P-7807	Bearing-Ball	314-8502
6L-2279	Plug-Ptf	419-4739
6V-3831	Seal-O-Ring	436-2657
7S-4411	Cap As-Rain	373-1912
7W-2731	Retainer	423-3541
7W-3145	Plate	422-7894
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
8H-9789	Bearing-Ball	374-8342

2XR		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8608	Manifold-Exhaust	376-9062
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
147-3781	Kit-Gasket(Wp)	422-2484

2XR		
Original Part Number	**Part Name**	**Classic Part Number**
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
219-7975	Kit-Gasket (Sch)	437-1999
252-7955	Kit-Gasket(Cl)	437-8654
255-6863	Gasket	450-5024
352-2077	Pump Gp-Water -B	434-6108

LSG		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568

LSG		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
111-2645	Valve-Pump Byp	441-1561
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

LSG		
Original Part Number	**Part Name**	**Classic Part Number**
118-2800	Housing As.-Rglt	419-4719
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
166-6352	Tube As.	432-4223
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367

Sales Model 3196 (Cont'd.)

LSG		
Original Part Number	**Part Name**	**Classic Part Number**
187-3307	Gasket As-Cyl	438-2022

LSG		
Original Part Number	**Part Name**	**Classic Part Number**
197-9251	Pin As.-Piston	454-6110

LSG		
Original Part Number	**Part Name**	**Classic Part Number**
216-4781	Gasket Kit	437-8144

RA6		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
6V-3831	Seal-O-Ring	436-2657
7W-5164	Gasket	420-8568
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567

RA6		
Original Part Number	**Part Name**	**Classic Part Number**
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719

RA6		
Original Part Number	**Part Name**	**Classic Part Number**
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144

Sales Model 3204

163		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558

163		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
5S-5917	Screw-Rocker Adj	380-7537
7C-7955	Gasket-Cover	382-6899
7W-2059	Gasket-Cyl Hd	380-1548
8N-0701	Bearing-Sleeve	419-4745

163		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
119-6772	Valve-Exhaust	384-8699

2TB		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076

2TB		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3822	Bearing-Conn Rod	376-9077
1P-7125	Governor As	383-3672
1W-0311	Bearing-Main	376-9078

2TB		
Original Part Number	**Part Name**	**Classic Part Number**
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900

Sales Model 3204 (Cont'd.)

2TB		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2N-1599	Gear	378-3970
2P-1757	Hub-Fan Pulley	296-1357
2W-1223	Pump Gp-Water	385-7197
2W-8271	Arm As-Rocker	432-8912
3L-1425	Bearing-Ball	311-9356
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600

2TB		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7688	Valve As-Check	420-6216
4W-2541	Shaft-Gov Cont	399-8580
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
6N-1553	Coupling-Exhaust	295-6422
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
7C-7955	Gasket-Cover	382-6899
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-7166	Race-Brg Thrust	417-4531
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935

2TB		
Original Part Number	**Part Name**	**Classic Part Number**
7W-2059	Gasket-Cyl Hd	380-1548
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9Y-5168	Manifold-Exhaust	374-7483
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699

3PC		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513

3PC		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2N-1599	Gear	378-3970
2W-1223	Pump Gp-Water	385-7197
2W-8271	Arm As-Rocker	432-8912
4N-0432	Bearing-Ball	417-4499
4P-7688	Valve As-Check	420-6216
4W-6869	Spacer-Fuel Pump	417-4534
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
6V-6896	Rebuild Kit	390-1006
7C-7955	Gasket-Cover	382-6899
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-7166	Race-Brg Thrust	417-4531

3PC		
Original Part Number	**Part Name**	**Classic Part Number**
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9Y-5168	Manifold-Exhaust	374-7483
119-6772	Valve-Exhaust	384-8699

Sales Model 3204 (Cont'd.)

6DC		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513

6DC		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2N-1599	Gear	378-3970
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3N-4892	Lever-Gov Cont	439-4542
4N-0432	Bearing-Ball	417-4499
4P-7688	Valve As-Check	420-6216
4W-6869	Spacer-Fuel Pump	417-4534
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
6V-6896	Rebuild Kit	390-1006
7C-7955	Gasket-Cover	382-6899
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983

6DC		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7166	Race-Brg Thrust	417-4531
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9Y-5168	Manifold-Exhaust	374-7483
119-6772	Valve-Exhaust	384-8699

7EB		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-7125	Governor As	383-3672
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513

7EB		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2N-1599	Gear	378-3970
2P-1757	Hub-Fan Pulley	296-1357
2W-1223	Pump Gp-Water	385-7197
2W-8271	Arm As-Rocker	432-8912
3L-1425	Bearing-Ball	311-9356
3N-4892	Lever-Gov Cont	439-4542
4N-0432	Bearing-Ball	417-4499
4P-7688	Valve As-Check	420-6216
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006

7EB		
Original Part Number	**Part Name**	**Classic Part Number**
7C-7955	Gasket-Cover	382-6899
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-7166	Race-Brg Thrust	417-4531
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772

Sales Model 3204 (Cont'd.)

7EB		
Original Part Number	**Part Name**	**Classic Part Number**
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706

7EB		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-5168	Manifold-Exhaust	374-7483

7EB		
Original Part Number	**Part Name**	**Classic Part Number**
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699

Sales Model 3208

01Z		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3165	Plunger-Rlf V	373-1883
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-6987	Valve As-Check	420-6221
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
3B-8845	Bearing-Inner	417-4509
3D-9126	Cup-Roller Brg	399-4435
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-6411	Cup-Rlr Bearing	423-7759
4L-8473	Plate-Wear	419-0883
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1157	Coupling-Exhaust	379-0177
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4P-7688	Valve As-Check	420-6216
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711

01Z		
Original Part Number	**Part Name**	**Classic Part Number**
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5S-4557	Bearing	311-9360
5S-5917	Screw-Rocker Adj	380-7537
6D-1734	Cup-Roller Brg	416-2171
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-2909	Gasket Kit - F	388-0652
6V-6894	Rebuild Kt-Pump	383-3696
6V-9729	Gasket Kit - F	393-5195
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7M-7219	Bearing-Thrust	384-4816
7S-4411	Cap As-Rain	373-1912
7W-2059	Gasket-Cyl Hd	380-1548
7W-2731	Retainer	423-3541
8H-4320	Bearing-Ball	419-2301
8N-0701	Bearing-Sleeve	419-4745

01Z		
Original Part Number	**Part Name**	**Classic Part Number**
9B-1320	Valve-Check	377-5832
9L-5839	Coupling-Exhaust	374-7480
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
119-6772	Valve-Exhaust	384-8699
167-8123	Damper As	299-2006
214-6045	Bellows As	435-4846
234-7999	Kit-Gasket-Sch	437-8119
234-8001	Kit-Gasket-Mch	437-8118
242-9834	Kit-Gasket-Mch	387-2923
242-9847	Kit-Gasket-Mch	438-0129
242-9857	Kit-Gasket-Mch	437-8637
255-6863	Gasket	450-5024

02Z		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3165	Plunger-Rlf V	373-1883

Sales Model 3208 (Cont'd.)

02Z		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
1W-4623	Muffler As	360-9622
1W-6987	Valve As-Check	420-6221
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2N-1599	Gear	378-3970
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4P-7688	Valve As-Check	420-6216
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5917	Screw-Rocker Adj	380-7537
6V-2202	Bearing-Spl Ball	380-1574

02Z		
Original Part Number	Part Name	Classic Part Number
6V-2909	Gasket Kit - F	388-0652
6V-6894	Rebuild Kt-Pump	383-3696
6V-9729	Gasket Kit - F	393-5195
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7E-8926	Head Kt-Cyl	377-5847
7M-7219	Bearing-Thrust	384-4816
7N-7435	Kit-Major Repair	374-4724
7W-2059	Gasket-Cyl Hd	380-1548
7W-2731	Retainer	423-3541
7W-5095	Gear-Flywheel	425-9190
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0701	Bearing-Sleeve	419-4745
8N-3666	Repair Kt-Major	377-5842
8S-0248	Breather As	325-6033
8T-3383	Kit-Gasket-Mch	447-8648
9L-7682	Valve-Inlet	385-9266
9N-3345	Pulley As-Idler	398-8341

02Z		
Original Part Number	Part Name	Classic Part Number
9N-3668	Base As.-Coolant	419-4718
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
234-7998	Kit-Gasket-Mch	437-8640
234-7999	Kit-Gasket-Sch	437-8119
234-8019	Kit-Gasket-Sch	437-8639
242-9834	Kit-Gasket-Mch	387-2923

03Z		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-7056	Bearing-Ball	422-6483
1W-6987	Valve As-Check	420-6221
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2N-1599	Gear	378-3970
2N-2139	Cone-Roller Brg	415-1911
2P-1757	Hub-Fan Pulley	296-1357

03Z		
Original Part Number	Part Name	Classic Part Number
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
3L-1425	Bearing-Ball	311-9356
3N-3368	Pipe-Exhaust	311-9434
4B-7255	Cone-Bearing	386-4951
4L-8473	Plate-Wear	419-0883
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1157	Coupling-Exhaust	379-0177
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4P-7688	Valve As-Check	420-6216

03Z		
Original Part Number	Part Name	Classic Part Number
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9656	Cone-Bearing	399-4448
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883

Sales Model 3208 (Cont'd.)

03Z		
Original Part Number	Part Name	Classic Part Number
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
6V-2909	Gasket Kit - F	388-0652
6V-6894	Rebuild Kt-Pump	383-3696
6V-9729	Gasket Kit - F	393-5195
6Y-7652	Cup-Rlr Brg	399-6067
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7E-8926	Head Kt-Cyl	377-5847
7M-7219	Bearing-Thrust	384-4816
7N-7435	Kit-Major Repair	374-4724
7W-2059	Gasket-Cyl Hd	380-1548
7W-2731	Retainer	423-3541
7W-5095	Gear-Flywheel	425-9190
8H-9789	Bearing-Ball	374-8342

03Z		
Original Part Number	Part Name	Classic Part Number
8N-0701	Bearing-Sleeve	419-4745
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8T-3383	Kit-Gasket-Mch	447-8648
9L-5839	Coupling-Exhaust	374-7480
9L-6371	Rod-Eye	363-7459
9L-7682	Valve-Inlet	385-9266
9N-3345	Pulley As-Idler	398-8341
9N-3668	Base As.-Coolant	419-4718
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9S-7148	Cap As-Rain	378-3994
9S-9328	Muffler	395-1308
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934

03Z		
Original Part Number	Part Name	Classic Part Number
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
214-6045	Bellows As	435-4846
234-7998	Kit-Gasket-Mch	437-8640
234-7999	Kit-Gasket-Sch	437-8119
234-8001	Kit-Gasket-Mch	437-8118
234-8019	Kit-Gasket-Sch	437-8639
242-9834	Kit-Gasket-Mch	387-2923
255-6863	Gasket	450-5024

164		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260

164		
Original Part Number	Part Name	Classic Part Number
7W-2059	Gasket-Cyl Hd	380-1548
8N-0701	Bearing-Sleeve	419-4745
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772

164		
Original Part Number	Part Name	Classic Part Number
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
119-6772	Valve-Exhaust	384-8699

29A		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-6987	Valve As-Check	420-6221
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

29A		
Original Part Number	Part Name	Classic Part Number
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
3K-3124	Muffler-Trap	247-2673
3N-1968	Mount-Shock	397-5046
3N-3368	Pipe-Exhaust	311-9434
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903

29A		
Original Part Number	Part Name	Classic Part Number
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4P-7688	Valve As-Check	420-6216
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854

Sales Model 3208 (Cont'd.)

29A		
Original Part Number	**Part Name**	**Classic Part Number**
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
6V-2909	Gasket Kit - F	388-0652
6V-6894	Rebuild Kt-Pump	383-3696
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260

29A		
Original Part Number	**Part Name**	**Classic Part Number**
7M-7219	Bearing-Thrust	384-4816
7N-8018	Seal-Water	418-1964
7T-2036	Cap As-Fuel	361-1721
7W-2059	Gasket-Cyl Hd	380-1548
8N-0701	Bearing-Sleeve	419-4745
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9S-7534	Pipe-Exh Ext	398-2950
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934

29A		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
9Y-1798	Seal-Water	379-0165
111-8015	Gasket As-Head	279-4977
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
124-3237	Precleaner As	432-4220
214-6045	Bellows As	435-4846
234-7998	Kit-Gasket-Mch	437-8640
234-7999	Kit-Gasket-Sch	437-8119

30A		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3165	Plunger-Rlf V	373-1883
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-6987	Valve As-Check	420-6221
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
3N-1968	Mount-Shock	397-5046
3N-3368	Pipe-Exhaust	311-9434
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4P-7688	Valve As-Check	420-6216
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502

30A		
Original Part Number	**Part Name**	**Classic Part Number**
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5917	Screw-Rocker Adj	380-7537
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
6V-2909	Gasket Kit - F	388-0652
6V-6894	Rebuild Kt-Pump	383-3696
6V-9729	Gasket Kit - F	393-5195
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
7W-2059	Gasket-Cyl Hd	380-1548
8N-0701	Bearing-Sleeve	419-4745
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772

30A		
Original Part Number	**Part Name**	**Classic Part Number**
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9S-9328	Muffler	395-1308
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
119-6772	Valve-Exhaust	384-8699
124-3237	Precleaner As	432-4220
214-6045	Bellows As	435-4846
234-7998	Kit-Gasket-Mch	437-8640
234-7999	Kit-Gasket-Sch	437-8119
234-8019	Kit-Gasket-Sch	437-8639
242-9834	Kit-Gasket-Mch	387-2923

Sales Model 3208 (Cont'd.)

32Y		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-6987	Valve As-Check	420-6221
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2N-1599	Gear	378-3970
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1225	Pump Gp-Water	380-7532
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
2W-8271	Arm As-Rocker	432-8912
3N-5869	Support-Elbow	375-9973
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716

32Y		
Original Part Number	Part Name	Classic Part Number
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572
4N-9944	Line As-Fuel Inj	380-1565
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8545	Gasket Kit	437-8626
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544

32Y		
Original Part Number	Part Name	Classic Part Number
6N-7263	Gasket-Cyl Head	380-7386
6V-2202	Bearing-Spl Ball	380-1574
6V-2909	Gasket Kit - F	388-0652
6V-6894	Rebuild Kt-Pump	383-3696
6V-9729	Gasket Kit - F	393-5195
7C-3862	Camshaft	458-0151
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3536	Gear-Fuel	279-4993
7N-7435	Kit-Major Repair	374-4724
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-2059	Gasket-Cyl Hd	380-1548
7W-5095	Gear-Flywheel	425-9190
7W-5692	Pulley-Cshaft	386-3041
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0081	Trunnion	393-5196

Sales Model 3208 (Cont'd.)

32Y		
Original Part Number	Part Name	Classic Part Number
8N-0701	Bearing-Sleeve	419-4745
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033

32Y		
Original Part Number	Part Name	Classic Part Number
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9L-6371	Rod-Eye	363-7459
9L-7682	Valve-Inlet	385-9266
9M-5477	Bearing-Sleeve	374-6517
9N-3345	Pulley As-Idler	398-8341
9N-3668	Base As.-Coolant	419-4718
9N-5246	Bearing-Camshaft	384-4772
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9N-5786	Lifter-Valve	457-6607
9N-5920	Bearing-Conn Rod	419-6383
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939

32Y		
Original Part Number	Part Name	Classic Part Number
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
167-8123	Damper As	299-2006
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-7989	Kit-Gasket-Sch	437-8122
234-7991	Kit-Gasket-Mch	437-8121
234-7994	Kit-Gasket-Sch	437-8120
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
242-9834	Kit-Gasket-Mch	387-2923
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

40S		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883

40S		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913

Sales Model 3208 (Cont'd.)

40S		
Original Part Number	Part Name	Classic Part Number
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-6987	Valve As-Check	420-6221
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2N-1599	Gear	378-3970
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1225	Pump Gp-Water	380-7532
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
2W-8271	Arm As-Rocker	432-8912
3N-5869	Support-Elbow	375-9973
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763

40S		
Original Part Number	Part Name	Classic Part Number
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572
4N-9944	Line As-Fuel Inj	380-1565
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8545	Gasket Kit	437-8626
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-2202	Bearing-Spl Ball	380-1574

40S		
Original Part Number	Part Name	Classic Part Number
6V-2909	Gasket Kit - F	388-0652
6V-6894	Rebuild Kt-Pump	383-3696
6V-9729	Gasket Kit - F	393-5195
7C-3862	Camshaft	458-0151
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3536	Gear-Fuel	279-4993
7N-7435	Kit-Major Repair	374-4724
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-2059	Gasket-Cyl Hd	380-1548
7W-5095	Gear-Flywheel	425-9190
7W-5692	Pulley-Cshaft	386-3041
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0081	Trunnion	393-5196
8N-0701	Bearing-Sleeve	419-4745
8N-0703	Bearing-Sleeve	472-8037

Sales Model 3208 (Cont'd.)

40S		
Original Part Number	Part Name	Classic Part Number
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831

40S		
Original Part Number	Part Name	Classic Part Number
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9L-6371	Rod-Eye	363-7459
9L-7682	Valve-Inlet	385-9266
9M-5477	Bearing-Sleeve	374-6517
9N-3345	Pulley As-Idler	398-8341
9N-3668	Base As.-Coolant	419-4718
9N-5246	Bearing-Camshaft	384-4772
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9N-5786	Lifter-Valve	457-6607
9N-5920	Bearing-Conn Rod	419-6383
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
9Y-1798	Seal-Water	379-0165

40S		
Original Part Number	Part Name	Classic Part Number
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
167-8123	Damper As	299-2006
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-7989	Kit-Gasket-Sch	437-8122
234-7991	Kit-Gasket-Mch	437-8121
234-7994	Kit-Gasket-Sch	437-8120
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
242-9834	Kit-Gasket-Mch	387-2923
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

5YF		
Original Part Number	Part Name	Classic Part Number
1N-3165	Plunger-Rlf V	373-1883
1W-3900	Gasket	472-8006

5YF		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
2A-4429	Lock-Retainer	379-0174

5YF		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
2W-1225	Pump Gp-Water	380-7532

Sales Model 3208 (Cont'd.)

5YF		
Original Part Number	Part Name	Classic Part Number
2W-8271	Arm As-Rocker	432-8912
3N-1968	Mount-Shock	397-5046
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4P-7688	Valve As-Check	420-6216
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
6L-4716	Gasket-Exhaust	398-2951
6V-6894	Rebuild Kt-Pump	383-3696

5YF		
Original Part Number	Part Name	Classic Part Number
6V-9729	Gasket Kit - F	393-5195
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
7W-2059	Gasket-Cyl Hd	380-1548
8N-0701	Bearing-Sleeve	419-4745
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706

5YF		
Original Part Number	Part Name	Classic Part Number
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
119-6772	Valve-Exhaust	384-8699
131-3815	Seal Gp-Basic	325-6193
234-8019	Kit-Gasket-Sch	437-8639

51Z		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-6987	Valve As-Check	420-6221
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2N-1599	Gear	378-3970
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214

51Z		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1225	Pump Gp-Water	380-7532
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
2W-8271	Arm As-Rocker	432-8912
3N-5869	Support-Elbow	375-9973
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563

51Z		
Original Part Number	Part Name	Classic Part Number
4N-9943	Line As-Fuel Inj	380-1572
4N-9944	Line As-Fuel Inj	380-1565
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8545	Gasket Kit	437-8626
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

Sales Model 3208 (Cont'd.)

51Z		
Original Part Number	**Part Name**	**Classic Part Number**
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-2202	Bearing-Spl Ball	380-1574
6V-2909	Gasket Kit - F	388-0652
6V-6894	Rebuild Kt-Pump	383-3696
6V-9729	Gasket Kit - F	393-5195
7C-3862	Camshaft	458-0151
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3536	Gear-Fuel	279-4993
7N-7435	Kit-Major Repair	374-4724
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497

51Z		
Original Part Number	**Part Name**	**Classic Part Number**
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-2059	Gasket-Cyl Hd	380-1548
7W-5095	Gear-Flywheel	425-9190
7W-5692	Pulley-Cshaft	386-3041
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0081	Trunnion	393-5196
8N-0701	Bearing-Sleeve	419-4745
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

51Z		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9L-6371	Rod-Eye	363-7459
9L-7682	Valve-Inlet	385-9266
9M-5477	Bearing-Sleeve	374-6517
9N-3345	Pulley As-Idler	398-8341
9N-3668	Base As.-Coolant	419-4718
9N-5246	Bearing-Camshaft	384-4772
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9N-5786	Lifter-Valve	457-6607
9N-5920	Bearing-Conn Rod	419-6383
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939

Sales Model 3208 (Cont'd.)

51Z		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554

51Z		
Original Part Number	**Part Name**	**Classic Part Number**
167-8123	Damper As	299-2006
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085

51Z		
Original Part Number	**Part Name**	**Classic Part Number**
234-7989	Kit-Gasket-Sch	437-8122
234-7991	Kit-Gasket-Mch	437-8121
234-7994	Kit-Gasket-Sch	437-8120
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
242-9834	Kit-Gasket-Mch	387-2923
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

5CD		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3165	Plunger-Rlf V	373-1883
1N-3165	Plunger-Rlf V	373-1883
1W-6987	Valve As-Check	420-6221
1W-6987	Valve As-Check	420-6221
2A-4429	Lock-Retainer	379-0174
2A-4429	Lock-Retainer	379-0174
2W-1225	Pump Gp-Water	380-7532
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
2W-8271	Arm As-Rocker	432-8912
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-2954	Sleeve-Camshaft	299-2059
4P-7688	Valve As-Check	420-6216

5CD		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7688	Valve As-Check	420-6216
5P-7807	Bearing-Ball	314-8502
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5S-5917	Screw-Rocker Adj	380-7537
6V-6894	Rebuild Kt-Pump	383-3696
6V-6894	Rebuild Kt-Pump	383-3696
7E-2888	Gear-Fuel Pump	397-5062
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7E-7894	Bearing-Rod	419-7260
7M-7219	Bearing-Thrust	384-4816
7M-7219	Bearing-Thrust	384-4816
7W-2059	Gasket-Cyl Hd	380-1548
7W-2059	Gasket-Cyl Hd	380-1548
8N-0701	Bearing-Sleeve	419-4745

5CD		
Original Part Number	**Part Name**	**Classic Part Number**
8N-0701	Bearing-Sleeve	419-4745
8S-0248	Breather As	325-6033
9L-7682	Valve-Inlet	385-9266
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9N-6500	Rod-Valve Push	383-3706
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
119-6772	Valve-Exhaust	384-8699
119-6772	Valve-Exhaust	384-8699

Sales Model 3208 (Cont'd.)

62W		
Original Part Number	Part Name	Classic Part Number
1N-3165	Plunger-Rlf V	373-1883
1N-3165	Plunger-Rlf V	373-1883
1W-6987	Valve As-Check	420-6221
2A-4429	Lock-Retainer	379-0174
2A-4429	Lock-Retainer	379-0174
2W-8271	Arm As-Rocker	432-8912
2W-8271	Arm As-Rocker	432-8912
4N-0209	Bonnet-Valve	378-3973
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-2954	Sleeve-Camshaft	299-2059
4P-7688	Valve As-Check	420-6216
5P-7807	Bearing-Ball	314-8502
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5S-5917	Screw-Rocker Adj	380-7537

62W		
Original Part Number	Part Name	Classic Part Number
7E-2888	Gear-Fuel Pump	397-5062
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7E-7894	Bearing-Rod	419-7260
7M-7219	Bearing-Thrust	384-4816
7M-7219	Bearing-Thrust	384-4816
7W-2059	Gasket-Cyl Hd	380-1548
7W-2059	Gasket-Cyl Hd	380-1548
8N-0701	Bearing-Sleeve	419-4745
8N-0701	Bearing-Sleeve	419-4745
8S-0248	Breather As	325-6033
8S-0248	Breather As	325-6033
9B-1320	Valve-Check	377-5832
9B-1320	Valve-Check	377-5832
9L-7682	Valve-Inlet	385-9266
9L-7682	Valve-Inlet	385-9266
9N-3345	Pulley As-Idler	398-8341
9N-5246	Bearing-Camshaft	384-4772
9N-5246	Bearing-Camshaft	384-4772

62W		
Original Part Number	Part Name	Classic Part Number
9N-5786	Lifter-Valve	457-6607
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9N-6500	Rod-Valve Push	383-3706
9Y-0231	Line As-F Inj	390-0932
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
9Y-0238	Line As-F Inj	390-0939
119-6772	Valve-Exhaust	384-8699
119-6772	Valve-Exhaust	384-8699

6SF		
Original Part Number	Part Name	Classic Part Number
1N-3165	Plunger-Rlf V	373-1883
1W-6987	Valve As-Check	420-6221
2A-4429	Lock-Retainer	379-0174
2N-1599	Gear	378-3970
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4P-7688	Valve As-Check	420-6216

6SF		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5S-4557	Bearing	311-9360
5S-5917	Screw-Rocker Adj	380-7537
6V-6894	Rebuild Kt-Pump	383-3696
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7E-8926	Head Kt-Cyl	377-5847
7M-7219	Bearing-Thrust	384-4816
7N-7435	Kit-Major Repair	374-4724

6SF		
Original Part Number	Part Name	Classic Part Number
7W-2059	Gasket-Cyl Hd	380-1548
8H-9789	Bearing-Ball	374-8342
8N-0701	Bearing-Sleeve	419-4745
8N-3666	Repair Kt-Major	377-5842
9L-7682	Valve-Inlet	385-9266
9N-3345	Pulley As-Idler	398-8341
9N-5246	Bearing-Camshaft	384-4772
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699

Sales Model 3208 (Cont'd.)

6SF		
Original Part Number	Part Name	Classic Part Number
144-0502	Ring Kit-Piston	395-1312

6SF		
Original Part Number	Part Name	Classic Part Number
144-0503	Piston & Ring Kt	380-1554

75V		
Original Part Number	Part Name	Classic Part Number
1N-3165	Plunger-Rlf V	373-1883
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-6987	Valve As-Check	420-6221
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
3D-9126	Cup-Roller Brg	399-4435
3N-3368	Pipe-Exhaust	311-9434
3N-6411	Cup-Rlr Bearing	423-7759
4L-8473	Plate-Wear	419-0883
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1157	Coupling-Exhaust	379-0177
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4P-7688	Valve As-Check	420-6216
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711

75V		
Original Part Number	Part Name	Classic Part Number
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5S-4557	Bearing	311-9360
5S-5917	Screw-Rocker Adj	380-7537
6D-1734	Cup-Roller Brg	416-2171
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2909	Gasket Kit - F	388-0652
6V-6894	Rebuild Kt-Pump	383-3696
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7M-7219	Bearing-Thrust	384-4816
7W-2059	Gasket-Cyl Hd	380-1548
7W-2731	Retainer	423-3541
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8N-0701	Bearing-Sleeve	419-4745
9B-1320	Valve-Check	377-5832
9L-5839	Coupling-Exhaust	374-7480

75V		
Original Part Number	Part Name	Classic Part Number
9L-7682	Valve-Inlet	385-9266
9N-3668	Base As.-Coolant	419-4718
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-5920	Bearing-Conn Rod	419-6383
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
119-6772	Valve-Exhaust	384-8699
214-6045	Bellows As	435-4846
234-7989	Kit-Gasket-Sch	437-8122
234-7991	Kit-Gasket-Mch	437-8121
234-7999	Kit-Gasket-Sch	437-8119
234-8001	Kit-Gasket-Mch	437-8118
255-6863	Gasket	450-5024

90N		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1P-1367	Plunger-Valve	432-8913
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-7056	Bearing-Ball	422-6483

90N		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2N-1572	Muffler As-Exh	361-6575

90N		
Original Part Number	Part Name	Classic Part Number
2N-1599	Gear	378-3970
2N-2139	Cone-Roller Brg	415-1911
2P-1757	Hub-Fan Pulley	296-1357
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912

Sales Model 3208 (Cont'd.)

90N		
Original Part Number	Part Name	Classic Part Number
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3N-3368	Pipe-Exhaust	311-9434
4B-7255	Cone-Bearing	386-4951
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2572	Spider As-Fan	451-9027
4N-2954	Sleeve-Camshaft	299-2059
4P-7688	Valve As-Check	420-6216
5B-9169	Plug-Drain	419-4736
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9656	Cone-Bearing	399-4448
5P-7807	Bearing-Ball	314-8502
5P-8545	Gasket Kit	437-8626
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381

90N		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6V-2909	Gasket Kit - F	388-0652
6V-6894	Rebuild Kt-Pump	383-3696
6V-9729	Gasket Kit - F	393-5195
6Y-7652	Cup-Rlr Brg	399-6067
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7M-7219	Bearing-Thrust	384-4816
7N-7435	Kit-Major Repair	374-4724
7N-8018	Seal-Water	418-1964
7W-2059	Gasket-Cyl Hd	380-1548
7W-2731	Retainer	423-3541
7W-5095	Gear-Flywheel	425-9190
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8N-0701	Bearing-Sleeve	419-4745
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
9B-1320	Valve-Check	377-5832
9L-7682	Valve-Inlet	385-9266
9N-3345	Pulley As-Idler	398-8341
9N-3668	Base As.-Coolant	419-4718
9N-5246	Bearing-Camshaft	384-4772

90N		
Original Part Number	Part Name	Classic Part Number
9N-5786	Lifter-Valve	457-6607
9N-5920	Bearing-Conn Rod	419-6383
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9S-7148	Cap As-Rain	378-3994
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
9Y-1798	Seal-Water	379-0165
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
214-6045	Bellows As	435-4846
234-7989	Kit-Gasket-Sch	437-8122
234-7991	Kit-Gasket-Mch	437-8121
234-7994	Kit-Gasket-Sch	437-8120
234-7998	Kit-Gasket-Mch	437-8640
234-7999	Kit-Gasket-Sch	437-8119
234-8019	Kit-Gasket-Sch	437-8639
242-9834	Kit-Gasket-Mch	387-2923

90S		
Original Part Number	Part Name	Classic Part Number
1N-3165	Plunger-Rlf V	373-1883
2A-4429	Lock-Retainer	379-0174
2N-1599	Gear	378-3970
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903

90S		
Original Part Number	Part Name	Classic Part Number
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537

90S		
Original Part Number	Part Name	Classic Part Number
6V-6894	Rebuild Kt-Pump	383-3696
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7M-7219	Bearing-Thrust	384-4816
7W-2059	Gasket-Cyl Hd	380-1548

Sales Model 3208 (Cont'd.)

90S		
Original Part Number	**Part Name**	**Classic Part Number**
8H-2810	Case As-Filter	314-8512
8N-0701	Bearing-Sleeve	419-4745
9B-1320	Valve-Check	377-5832
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607

90S		
Original Part Number	**Part Name**	**Classic Part Number**
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935

90S		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
119-6772	Valve-Exhaust	384-8699

93Z		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3165	Plunger-Rlf V	373-1883
1N-3165	Plunger-Rlf V	373-1883
1W-6987	Valve As-Check	420-6221
1W-6987	Valve As-Check	420-6221
2A-4429	Lock-Retainer	379-0174
2A-4429	Lock-Retainer	379-0174
2W-1225	Pump Gp-Water	380-7532
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
2W-8271	Arm As-Rocker	432-8912
4N-0209	Bonnet-Valve	378-3973
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-2954	Sleeve-Camshaft	299-2059
4P-7688	Valve As-Check	420-6216
4P-7688	Valve As-Check	420-6216
5P-7807	Bearing-Ball	314-8502

93Z		
Original Part Number	**Part Name**	**Classic Part Number**
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5S-5917	Screw-Rocker Adj	380-7537
6V-6894	Rebuild Kt-Pump	383-3696
6V-6894	Rebuild Kt-Pump	383-3696
7E-2888	Gear-Fuel Pump	397-5062
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7E-7894	Bearing-Rod	419-7260
7M-7219	Bearing-Thrust	384-4816
7M-7219	Bearing-Thrust	384-4816
7W-2059	Gasket-Cyl Hd	380-1548
7W-2059	Gasket-Cyl Hd	380-1548
8N-0701	Bearing-Sleeve	419-4745
8N-0701	Bearing-Sleeve	419-4745
9B-1320	Valve-Check	377-5832
9B-1320	Valve-Check	377-5832
9L-7682	Valve-Inlet	385-9266
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772

93Z		
Original Part Number	**Part Name**	**Classic Part Number**
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9N-6500	Rod-Valve Push	383-3706
9Y-0231	Line As-F Inj	390-0932
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
9Y-0238	Line As-F Inj	390-0939
119-6772	Valve-Exhaust	384-8699
119-6772	Valve-Exhaust	384-8699

99R		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3165	Plunger-Rlf V	373-1883

Sales Model 3208 (Cont'd.)

99R		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
6V-6894	Rebuild Kt-Pump	383-3696

99R		
Original Part Number	**Part Name**	**Classic Part Number**
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7M-7219	Bearing-Thrust	384-4816
7W-2059	Gasket-Cyl Hd	380-1548
8N-0701	Bearing-Sleeve	419-4745
8S-0248	Breather As	325-6033
9B-1320	Valve-Check	377-5832
9L-7682	Valve-Inlet	385-9266
9N-3345	Pulley As-Idler	398-8341
9N-5246	Bearing-Camshaft	384-4772

99R		
Original Part Number	**Part Name**	**Classic Part Number**
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
119-6772	Valve-Exhaust	384-8699

9WC		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3165	Plunger-Rlf V	373-1883
1N-3165	Plunger-Rlf V	373-1883
1W-6987	Valve As-Check	420-6221
1W-6987	Valve As-Check	420-6221
2A-4429	Lock-Retainer	379-0174
2A-4429	Lock-Retainer	379-0174
2W-1225	Pump Gp-Water	380-7532
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
2W-8271	Arm As-Rocker	432-8912
4N-0406	Gear-Tfr Pump	373-1903
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-2954	Sleeve-Camshaft	299-2059

9WC		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7688	Valve As-Check	420-6216
4P-7688	Valve As-Check	420-6216
5P-7807	Bearing-Ball	314-8502
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5S-5917	Screw-Rocker Adj	380-7537
6V-6894	Rebuild Kt-Pump	383-3696
6V-6894	Rebuild Kt-Pump	383-3696
7E-2888	Gear-Fuel Pump	397-5062
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7E-7894	Bearing-Rod	419-7260
7M-7219	Bearing-Thrust	384-4816

9WC		
Original Part Number	**Part Name**	**Classic Part Number**
7M-7219	Bearing-Thrust	384-4816
7W-2059	Gasket-Cyl Hd	380-1548
7W-2059	Gasket-Cyl Hd	380-1548
8N-0701	Bearing-Sleeve	419-4745
8N-0701	Bearing-Sleeve	419-4745
9L-7682	Valve-Inlet	385-9266
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5246	Bearing-Camshaft	384-4772
9N-6221	Crankshaft As	368-5914
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9N-6500	Rod-Valve Push	383-3706
119-6772	Valve-Exhaust	384-8699
119-6772	Valve-Exhaust	384-8699

Sales Model 3304

02B		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1U-2668	Cartridge Gp	422-8117
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-6810	Pipe-Outlet	472-8036
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2W-1707	Ring-Piston Top	270-4356

02B		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3B-8845	Bearing-Inner	417-4509
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-4878	Pump Gp-F Tfr	390-0995
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-9941	Line As-Fuel Inj	380-1562

02B		
Original Part Number	**Part Name**	**Classic Part Number**
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572
4N-9944	Line As-Fuel Inj	380-1565
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-7188	Core As-Oclr	374-7501
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951

Sales Model 3304 (Cont'd.)

02B		
Original Part Number	Part Name	Classic Part Number
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6V-0600	Gasket Kit	437-4583
6V-0611	Kit-Gasket-Fs	437-4581
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6V-2246	Gasket Kit	391-1091
6V-2523	Gasket Kit	437-3209
6V-2983	Gasket Kt	437-3213
6Y-7652	Cup-Rlr Brg	399-6067
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-7435	Kit-Major Repair	374-4724
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497

02B		
Original Part Number	Part Name	Classic Part Number
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7043	Mount As	389-6332
7S-7070	Head As-Cylinder	325-6107
7S-8443	Muffler	247-2675
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5687	Hub-Cshft	314-8684
7W-5692	Pulley-Cshaft	386-3041
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556

02B		
Original Part Number	Part Name	Classic Part Number
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-3668	Base As.-Coolant	419-4718

Sales Model 3304 (Cont'd.)

02B		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-9328	Muffler	395-1308
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351

02B		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
169-1750	Seal Gp-Basic	472-8022
170-0556	Kit-Rebuild-Pump	383-3712
170-0558	Kit-Rebuild-Pump	390-1001
170-0560	Rebuild Kit-Pump	363-7458
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

02B		
Original Part Number	Part Name	Classic Part Number
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

04B		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483

04B		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-6810	Pipe-Outlet	472-8036
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357

04B		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2S-4015	Plunger As-Valve	311-9438
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055

Sales Model 3304 (Cont'd.)

04B		
Original Part Number	Part Name	Classic Part Number
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-5869	Support-Elbow	375-9973
3S-5017	Elbow-Exhaust	369-9498
3S-9466	Bearing-Sleeve	314-8509
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4M-9215	Gear-Pump Idler	311-9391
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-4864	Pump Gp-F Tfr	242-3442
4N-4878	Pump Gp-F Tfr	390-0995
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710

04B		
Original Part Number	Part Name	Classic Part Number
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572
4N-9944	Line As-Fuel Inj	380-1565
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-7188	Core As-Oclr	374-7501
4W-9989	Gear As-Idler	302-2677
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475

04B		
Original Part Number	Part Name	Classic Part Number
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6V-0600	Gasket Kit	437-4583
6V-0611	Kit-Gasket-Fs	437-4581
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6V-2246	Gasket Kit	391-1091
6V-2523	Gasket Kit	437-3209
6V-2983	Gasket Kt	437-3213
6Y-7652	Cup-Rlr Brg	399-6067
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519

Sales Model 3304 (Cont'd.)

04B		
Original Part Number	Part Name	Classic Part Number
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8M-0874	Plunger As-Valve	311-9439
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623

04B		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-3668	Base As.-Coolant	419-4718
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124

04B		
Original Part Number	Part Name	Classic Part Number
9S-8597	Spring	399-8561
9S-9328	Muffler	395-1308
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-8711	Elbow-Exhaust	383-3709
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
169-1750	Seal Gp-Basic	472-8022
170-0556	Kit-Rebuild-Pump	383-3712
170-0558	Kit-Rebuild-Pump	390-1001
170-0560	Rebuild Kit-Pump	363-7458
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

Sales Model 3304 (Cont'd.)

04B		
Original Part Number	**Part Name**	**Classic Part Number**
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314

04B		
Original Part Number	**Part Name**	**Classic Part Number**
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438

04B		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

05B		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-6810	Pipe-Outlet	472-8036
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

05B		
Original Part Number	**Part Name**	**Classic Part Number**
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7678	Gear-Water Pump	325-6088
3D-9126	Cup-Roller Brg	399-4435
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
4L-8473	Plate-Wear	419-0883
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4878	Pump Gp-F Tfr	390-0995
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710

05B		
Original Part Number	**Part Name**	**Classic Part Number**
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572
4N-9944	Line As-Fuel Inj	380-1565
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

Sales Model 3304 (Cont'd.)

05B		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6V-0611	Kit-Gasket-Fs	437-4581
6V-2202	Bearing-Spl Ball	380-1574
6V-2246	Gasket Kit	391-1091
6V-2523	Gasket Kit	437-3209
6V-2983	Gasket Kt	437-3213
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7L-7508	Bearing-Ball	420-6536
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985

05B		
Original Part Number	Part Name	Classic Part Number
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

05B		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-3668	Base As.-Coolant	419-4718
9N-5251	Piston Gp-Bsc	250-6557
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
169-1750	Seal Gp-Basic	472-8022
170-0556	Kit-Rebuild-Pump	383-3712
170-0560	Rebuild Kit-Pump	363-7458

Sales Model 3304 (Cont'd.)

05B		
Original Part Number	Part Name	Classic Part Number
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365

05B		
Original Part Number	Part Name	Classic Part Number
172-7771	Pump Gp-Water -B	419-4646
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892

05B		
Original Part Number	Part Name	Classic Part Number
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

10E		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173

10E		
Original Part Number	Part Name	Classic Part Number
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-8912	Elbow-Exhaust	398-2957
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088

10E		
Original Part Number	Part Name	Classic Part Number
2W-9094	Adapter-Exhaust	299-2534
2W-9978	Core As-Oclr	279-4983
3E-8905	Gasket Kit	393-3617
3L-1425	Bearing-Ball	311-9356
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3P-0114	Elbow-Exhaust	314-8516
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984

Sales Model 3304 (Cont'd.)

10E		
Original Part Number	Part Name	Classic Part Number
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
4W-9989	Gear As-Idler	302-2677
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065

10E		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-2983	Gasket Kt	437-3213
6V-7459	Gasket Kit	391-1095
6Y-7652	Cup-Rlr Brg	399-6067
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995

10E		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842

Sales Model 3304 (Cont'd.)

10E		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1606	Kit-Gskt-Sch	386-3046
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042

10E		
Original Part Number	Part Name	Classic Part Number
9S-9328	Muffler	395-1308
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-8711	Elbow-Exhaust	383-3709
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
140-2246	Gasket Kit	383-3710
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0564	Rebuild Kit-Pump	380-7576

10E		
Original Part Number	Part Name	Classic Part Number
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
234-8013	Kit-Gasket-Sch	437-8650
234-8020	Kit-Gasket-Sch	437-8660
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

13E		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770

13E		
Original Part Number	Part Name	Classic Part Number
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

13E		
Original Part Number	Part Name	Classic Part Number
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659

Sales Model 3304 (Cont'd.)

13E		
Original Part Number	Part Name	Classic Part Number
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3D-9126	Cup-Roller Brg	399-4435
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
4L-8473	Plate-Wear	419-0883
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710

13E		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544

13E		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6V-7459	Gasket Kit	391-1095
6V-8041	Gasket Kit	437-3191
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196

Sales Model 3304 (Cont'd.)

13E		
Original Part Number	**Part Name**	**Classic Part Number**
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033

13E		
Original Part Number	**Part Name**	**Classic Part Number**
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
141-7955	Gasket Kit	437-4609
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127

13E		
Original Part Number	**Part Name**	**Classic Part Number**
169-1750	Seal Gp-Basic	472-8022
170-0560	Rebuild Kit-Pump	363-7458
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

165		
Original Part Number	**Part Name**	**Classic Part Number**
1N-4304	Head Gp-Cyl -A	269-8761
1S-3062	Director-Water	418-9572
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-6245	Shaft As-Pump	325-6197

165		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
4N-7692	Crankshaft As	269-8764
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

165		
Original Part Number	**Part Name**	**Classic Part Number**
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6I-1345	Shaft As-O Pump	374-7475
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
7C-3862	Camshaft	458-0151
7M-4046	Bearing-Sleeve	394-8206

Sales Model 3304 (Cont'd.)

165		
Original Part Number	**Part Name**	**Classic Part Number**
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

165		
Original Part Number	**Part Name**	**Classic Part Number**
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9S-7788	Ring-Piston	461-5124
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032

165		
Original Part Number	**Part Name**	**Classic Part Number**
100-7860	Valve-Inlet	270-4360
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
170-7502	Shaft-Dr Idler	374-7484
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

3TC		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716

3TC		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-4238	Mount-Flexible	385-7222
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357

3TC		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046

Sales Model 3304 (Cont'd.)

3TC		
Original Part Number	Part Name	Classic Part Number
3N-3786	Rod-Thrt Cont	397-5051
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5L-7632	Support-Elbow	433-9854
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247

3TC		
Original Part Number	Part Name	Classic Part Number
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-7459	Gasket Kit	391-1095
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351

3TC		
Original Part Number	Part Name	Classic Part Number
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

Sales Model 3304 (Cont'd.)

3TC		
Original Part Number	Part Name	Classic Part Number
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-9328	Muffler	395-1308
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977

3TC		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0564	Rebuild Kit-Pump	380-7576
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687

3TC		
Original Part Number	Part Name	Classic Part Number
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-8020	Kit-Gasket-Sch	437-8660
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

4PC		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

4PC		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046

4PC		
Original Part Number	Part Name	Classic Part Number
3N-3017	Adapter As	433-2031
3N-3786	Rod-Thrt Cont	397-5051
4N-4520	Guide	388-6600
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
5P-8768	Kit-Gasket (Scl)	393-1024
5S-1211	Cover-Valve	314-8665

Sales Model 3304 (Cont'd.)

4PC		
Original Part Number	Part Name	Classic Part Number
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2466	Kit-Gasket-Fs	437-3211
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7M-4046	Bearing-Sleeve	394-8206
7N-0165	Core As-O Clr	295-5670
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-8443	Muffler	247-2675
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-5687	Hub-Cshft	314-8684
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0703	Bearing-Sleeve	472-8037

4PC		
Original Part Number	Part Name	Classic Part Number
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-9486	Gasket Kt	393-5197
9N-5251	Piston Gp-Bsc	250-6557

4XB		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158

4PC		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-7788	Ring-Piston	461-5124
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6557	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

Sales Model 3304 (Cont'd.)

4XB		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

4XB		
Original Part Number	Part Name	Classic Part Number
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3L-1425	Bearing-Ball	311-9356
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

4XB		
Original Part Number	Part Name	Classic Part Number
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5L-7632	Support-Elbow	433-9854
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-7459	Gasket Kit	391-1095
6Y-7652	Cup-Rlr Brg	399-6067
7C-2880	Bell As-Suction	380-1520

Sales Model 3304 (Cont'd.)

4XB		
Original Part Number	Part Name	Classic Part Number
7C-3862	Camshaft	458-0151
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

4XB		
Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9N-3668	Base As.-Coolant	419-4718

4XB		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-9328	Muffler	395-1308
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646

Sales Model 3304 (Cont'd.)

4XB		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-8013	Kit-Gasket-Sch	437-8650
234-8020	Kit-Gasket-Sch	437-8660
241-3381	Valve Kit-Cla	247-6892

4XB		
Original Part Number	Part Name	Classic Part Number
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988

4XB		
Original Part Number	Part Name	Classic Part Number
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

6YB		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488

6YB		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3786	Rod-Thrt Cont	397-5051
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763

6YB		
Original Part Number	Part Name	Classic Part Number
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882

Sales Model 3304 (Cont'd.)

6YB		
Original Part Number	Part Name	Classic Part Number
5P-8768	Kit-Gasket (Scl)	393-1024
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6V-0600	Gasket Kit	437-4583
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985

6YB		
Original Part Number	Part Name	Classic Part Number
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-8443	Muffler	247-2675
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860

6YB		
Original Part Number	Part Name	Classic Part Number
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126

Sales Model 3304 (Cont'd.)

6YB		
Original Part Number	Part Name	Classic Part Number
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

6YB		
Original Part Number	Part Name	Classic Part Number
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438

6YB		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

83Z		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5910	Tappet As-Guide&	383-1569

83Z		
Original Part Number	Part Name	Classic Part Number
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356

83Z		
Original Part Number	Part Name	Classic Part Number
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7455	Gear As	396-9957
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9094	Adapter-Exhaust	299-2534
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3P-0114	Elbow-Exhaust	314-8516
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177

Sales Model 3304 (Cont'd.)

83Z		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4679	Pulley-Fan	394-9837
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-2383	Adapter-Inlet	438-1812
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4W-0452	Seal As -Cshaft	325-6191
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580

83Z		
Original Part Number	Part Name	Classic Part Number
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4W-9989	Gear As-Idler	302-2677
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1453	Crankshaft As	368-5916

83Z		
Original Part Number	Part Name	Classic Part Number
6I-1647	Arm Gp-V Rocker	433-0451
6I-1650	Arm Gp-V Rocker	433-0450
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-2983	Gasket Kt	437-3213
6V-3831	Seal-O-Ring	436-2657
6V-7459	Gasket Kit	391-1095
6V-8041	Gasket Kit	437-3191
7C-0307	Gasket	399-8571
7C-2880	Bell As-Suction	380-1520
7C-3039	Core As-Oclr	363-7451
7C-3862	Camshaft	458-0151
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222

Sales Model 3304 (Cont'd.)

83Z		
Original Part Number	Part Name	Classic Part Number
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5692	Pulley-Cshaft	386-3041
7W-5733	Gasket	421-7333
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895

83Z		
Original Part Number	Part Name	Classic Part Number
7W-7546	Gasket-Plate	433-8187
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1726	Rod As-Conn	379-8866
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377

83Z		
Original Part Number	Part Name	Classic Part Number
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8258	Bearing-Sleeve	452-1077
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-9328	Muffler	395-1308
9Y-1798	Seal-Water	379-0165
9Y-2988	Breather As	361-1716
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-7860	Valve-Inlet	270-4360
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062

Sales Model 3304 (Cont'd.)

83Z		
Original Part Number	Part Name	Classic Part Number
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
121-7746	Pre-Cleaner As	360-2311
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
140-2246	Gasket Kit	383-3710
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
145-8503	Shaft As-Idler	426-0035
148-7455	Valve - Exhaust	270-4361
148-8861	Gasket Kit	437-4596
150-4637	Pan-Oil	377-5843

83Z		
Original Part Number	Part Name	Classic Part Number
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
166-9142	Gasket	420-8546
167-8123	Damper As	299-2006
167-8126	Damper As	382-8019
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0560	Rebuild Kit-Pump	363-7458
170-0564	Rebuild Kit-Pump	380-7576
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011

83Z		
Original Part Number	Part Name	Classic Part Number
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3233	Bearing-Main	376-9085
234-8013	Kit-Gasket-Sch	437-8650
234-8020	Kit-Gasket-Sch	437-8660
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
253-1752	Plate-Thrust	379-0170
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
321-5746	Bearing-Main	419-6367
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955
430-7619	Adapter-Cla	438-1812

Sales Model 3304 (Cont'd.)

8XL		
Original Part Number	Part Name	Classic Part Number
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203

8XL		
Original Part Number	Part Name	Classic Part Number
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
4L-8473	Plate-Wear	419-0883
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5B-9169	Plug-Drain	419-4736
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9568	Gasket Kit	393-3625
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739

8XL		
Original Part Number	Part Name	Classic Part Number
6L-4716	Gasket-Exhaust	398-2951
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

Sales Model 3304 (Cont'd.)

8XL		
Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033

8XL		
Original Part Number	Part Name	Classic Part Number
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

8XL		
Original Part Number	Part Name	Classic Part Number
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 3304B

10E		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770

10E		
Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715

10E		
Original Part Number	Part Name	Classic Part Number
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221

Sales Model 3304B (Cont'd.)

10E		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-8912	Elbow-Exhaust	398-2957
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9094	Adapter-Exhaust	299-2534
2W-9978	Core As-Oclr	279-4983
3E-8905	Gasket Kit	393-3617
3L-1425	Bearing-Ball	311-9356
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3P-0114	Elbow-Exhaust	314-8516
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600

10E		
Original Part Number	Part Name	Classic Part Number
4N-4679	Pulley-Fan	394-9837
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
4W-9989	Gear As-Idler	302-2677
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502

10E		
Original Part Number	Part Name	Classic Part Number
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-2983	Gasket Kt	437-3213
6V-7459	Gasket Kit	391-1095
6Y-7652	Cup-Rlr Brg	399-6067
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816

Sales Model 3304B (Cont'd.)

10E		
Original Part Number	Part Name	Classic Part Number
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436

10E		
Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1606	Kit-Gskt-Sch	386-3046
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905

10E		
Original Part Number	Part Name	Classic Part Number
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-9328	Muffler	395-1308
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-8711	Elbow-Exhaust	383-3709
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
140-2246	Gasket Kit	383-3710
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0564	Rebuild Kit-Pump	380-7576
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

Sales Model 3304B (Cont'd.)

10E		
Original Part Number	Part Name	Classic Part Number
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

10E		
Original Part Number	Part Name	Classic Part Number
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
234-8013	Kit-Gasket-Sch	437-8650
234-8020	Kit-Gasket-Sch	437-8660
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357

10E		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

13E		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944

13E		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3D-9126	Cup-Roller Brg	399-4435
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
4L-8473	Plate-Wear	419-0883
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709

13E		
Original Part Number	Part Name	Classic Part Number
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

Sales Model 3304B (Cont'd.)

13E		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-7459	Gasket Kit	391-1095
6V-8041	Gasket Kit	437-3191
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342

13E		
Original Part Number	Part Name	Classic Part Number
8L-4282	Hub	444-0573
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438

13E		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
141-7955	Gasket Kit	437-4609
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0560	Rebuild Kit-Pump	363-7458
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

Sales Model 3304B (Cont'd.)

13E		
Original Part Number	Part Name	Classic Part Number
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893

13E		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438

13E		
Original Part Number	Part Name	Classic Part Number
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

1NS		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-4238	Mount-Flexible	385-7222
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

1NS		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3786	Rod-Thrt Cont	397-5051
4B-7270	Cone-Bearing	399-4439
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580

1NS		
Original Part Number	Part Name	Classic Part Number
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-4716	Gasket-Exhaust	398-2951
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-8041	Gasket Kit	437-3191
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496

Sales Model 3304B (Cont'd.)

1NS		
Original Part Number	Part Name	Classic Part Number
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623

1PS		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158

1NS		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361

1NS		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0560	Rebuild Kit-Pump	363-7458
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 3304B (Cont'd.)

1PS		
Original Part Number	Part Name	Classic Part Number
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-4238	Mount-Flexible	385-7222
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892

1PS		
Original Part Number	Part Name	Classic Part Number
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3786	Rod-Thrt Cont	397-5051
4B-7270	Cone-Bearing	399-4439
4N-0432	Bearing-Ball	417-4499
4N-2514	Gear-Flywheel	421-7283
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5F-8651	Bearing-Ball	420-3223
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-3223	Cup-Bearing	399-6065

1PS		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-4716	Gasket-Exhaust	398-2951
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-8041	Gasket Kit	437-3191
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

Sales Model 3304B (Cont'd.)

1PS		
Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081

1PS		
Original Part Number	Part Name	Classic Part Number
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
141-7955	Gasket Kit	437-4609
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

1PS		
Original Part Number	Part Name	Classic Part Number
170-0560	Rebuild Kit-Pump	363-7458
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
256-9653	Flywheel As.	425-3444
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

1YF		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913

1YF		
Original Part Number	Part Name	Classic Part Number
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

1YF		
Original Part Number	Part Name	Classic Part Number
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

Sales Model 3304B (Cont'd.)

1YF		
Original Part Number	Part Name	Classic Part Number
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3H-1996	Bearing-Ball	380-1498
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3786	Rod-Thrt Cont	397-5051
4N-0432	Bearing-Ball	417-4499
4N-4520	Guide	388-6600
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270

1YF		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5P-8768	Kit-Gasket (Scl)	393-1024
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358

1YF		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-8443	Muffler	247-2675
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196

Sales Model 3304B (Cont'd.)

1YF		
Original Part Number	Part Name	Classic Part Number
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084

1YF		
Original Part Number	Part Name	Classic Part Number
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1606	Kit-Gskt-Sch	386-3046
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

1YF		
Original Part Number	Part Name	Classic Part Number
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

2KK		
Original Part Number	Part Name	Classic Part Number
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

2KK		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

2KK		
Original Part Number	Part Name	Classic Part Number
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

Sales Model 3304B (Cont'd.)

2KK		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
4L-8473	Plate-Wear	419-0883
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

2KK		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291

2KK		
Original Part Number	Part Name	Classic Part Number
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977

Sales Model 3304B (Cont'd.)

2KK		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127

2KK		
Original Part Number	Part Name	Classic Part Number
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646

2KK		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

3TC		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221

3TC		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-4238	Mount-Flexible	385-7222
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3786	Rod-Thrt Cont	397-5051
4N-0432	Bearing-Ball	417-4499

3TC		
Original Part Number	Part Name	Classic Part Number
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777

Sales Model 3304B (Cont'd.)

3TC		
Original Part Number	Part Name	Classic Part Number
4P-9964	Line As-Fuel Inj	298-2778
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5L-7632	Support-Elbow	433-9854
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-7459	Gasket Kit	391-1095
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519

3TC		
Original Part Number	Part Name	Classic Part Number
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207

3TC		
Original Part Number	Part Name	Classic Part Number
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-9328	Muffler	395-1308
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

Sales Model 3304B (Cont'd.)

3TC		
Original Part Number	Part Name	Classic Part Number
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0564	Rebuild Kit-Pump	380-7576
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687

3TC		
Original Part Number	Part Name	Classic Part Number
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-8020	Kit-Gasket-Sch	437-8660
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	295-6438

3TC		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

4XB		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173

4XB		
Original Part Number	Part Name	Classic Part Number
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3L-1425	Bearing-Ball	311-9356

4XB		
Original Part Number	Part Name	Classic Part Number
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

Sales Model 3304B (Cont'd.)

4XB		
Original Part Number	Part Name	Classic Part Number
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5L-7632	Support-Elbow	433-9854
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-7459	Gasket Kit	391-1095
6Y-7652	Cup-Rlr Brg	399-6067
7C-2880	Bell As-Suction	380-1520

4XB		
Original Part Number	Part Name	Classic Part Number
7C-3862	Camshaft	458-0151
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

4XB		
Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9N-3668	Base As.-Coolant	419-4718

Sales Model 3304B (Cont'd.)

4XB		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-9328	Muffler	395-1308
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046

4XB		
Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698

4XB		
Original Part Number	Part Name	Classic Part Number
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-8013	Kit-Gasket-Sch	437-8650
234-8020	Kit-Gasket-Sch	437-8660
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

83Z		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

83Z		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5910	Tappet As-Guide&	383-1569
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164

83Z		
Original Part Number	Part Name	Classic Part Number
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

Sales Model 3304B (Cont'd.)

83Z		
Original Part Number	Part Name	Classic Part Number
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7455	Gear As	396-9957
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9094	Adapter-Exhaust	299-2534
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3P-0114	Elbow-Exhaust	314-8516
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4679	Pulley-Fan	394-9837
4N-5614	Arm As-Rocker	374-4710

83Z		
Original Part Number	Part Name	Classic Part Number
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-2383	Adapter-Inlet	438-1812
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4W-0452	Seal As -Cshaft	325-6191
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255

83Z		
Original Part Number	Part Name	Classic Part Number
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4W-9989	Gear As-Idler	302-2677
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1453	Crankshaft As	368-5916
6I-1647	Arm Gp-V Rocker	433-0451
6I-1650	Arm Gp-V Rocker	433-0450
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518

Sales Model 3304B (Cont'd.)

83Z		
Original Part Number	Part Name	Classic Part Number
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-2983	Gasket Kt	437-3213
6V-3831	Seal-O-Ring	436-2657
6V-7459	Gasket Kit	391-1095
6V-8041	Gasket Kit	437-3191
7C-0307	Gasket	399-8571
7C-2880	Bell As-Suction	380-1520
7C-3039	Core As-Oclr	363-7451
7C-3862	Camshaft	458-0151
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994

83Z		
Original Part Number	Part Name	Classic Part Number
7N-0165	Core As-O Clr	295-5670
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5692	Pulley-Cshaft	386-3041
7W-5733	Gasket	421-7333
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889

83Z		
Original Part Number	Part Name	Classic Part Number
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1726	Rod As-Conn	379-8866
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

Sales Model 3304B (Cont'd.)

83Z		
Original Part Number	Part Name	Classic Part Number
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8258	Bearing-Sleeve	452-1077
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-9328	Muffler	395-1308
9Y-1798	Seal-Water	379-0165
9Y-2988	Breather As	361-1716
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-7860	Valve-Inlet	270-4360
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744

83Z		
Original Part Number	Part Name	Classic Part Number
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
121-7746	Pre-Cleaner As	360-2311
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
140-2246	Gasket Kit	383-3710
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
145-8503	Shaft As-Idler	426-0035
148-7455	Valve - Exhaust	270-4361
148-8861	Gasket Kit	437-4596
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

83Z		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
166-9142	Gasket	420-8546
167-8123	Damper As	299-2006
167-8126	Damper As	382-8019
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0560	Rebuild Kit-Pump	363-7458
170-0564	Rebuild Kit-Pump	380-7576
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846

Sales Model 3304B (Cont'd.)

83Z		
Original Part Number	Part Name	Classic Part Number
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3233	Bearing-Main	376-9085
234-8013	Kit-Gasket-Sch	437-8650
234-8020	Kit-Gasket-Sch	437-8660
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
253-1752	Plate-Thrust	379-0170
270-4353	Kit-Liner-Cla	270-4357

83Z		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
321-5746	Bearing-Main	419-6367
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-4665

83Z		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955
430-7619	Adapter-Cla	438-1812

8XL		
Original Part Number	Part Name	Classic Part Number
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

8XL		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
4L-8473	Plate-Wear	419-0883
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838

8XL		
Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5B-9169	Plug-Drain	419-4736
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9568	Gasket Kit	393-3625
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851

Sales Model 3304B (Cont'd.)

8XL		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

8XL		
Original Part Number	Part Name	Classic Part Number
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193

8XL		
Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

9HK		
Original Part Number	Part Name	Classic Part Number
1N-3574	Block Gp-Cyl	460-8298

Sales Model 3304B (Cont'd.)

9HK		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892

9HK		
Original Part Number	Part Name	Classic Part Number
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
3N-3786	Rod-Thrt Cont	397-5051
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882

9HK		
Original Part Number	Part Name	Classic Part Number
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-3955	Bearing-Ball	417-9485
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351

Sales Model 3304B (Cont'd.)

9HK		
Original Part Number	Part Name	Classic Part Number
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464

9HK		
Original Part Number	Part Name	Classic Part Number
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1606	Kit-Gskt-Sch	386-3046
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125

9HK		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 3306

09A		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167

09A		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158

09A		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978

Sales Model 3306 (Cont'd.)

09A		
Original Part Number	Part Name	Classic Part Number
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3062	Retainer As	311-9445
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-8606	Valve-Inlet	443-1204
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

09A		
Original Part Number	Part Name	Classic Part Number
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-3767	Tube-Disposal	377-5850
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7830	Pump Gp	314-8533
2S-4015	Plunger As-Valve	311-9438
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-5869	Support-Elbow	375-9973

09A		
Original Part Number	Part Name	Classic Part Number
3S-5017	Elbow-Exhaust	369-9498
3S-9466	Bearing-Sleeve	314-8509
4B-7270	Cone-Bearing	399-4439
4D-2619	Bearing	417-4494
4L-8473	Plate-Wear	419-0883
4M-9215	Gear-Pump Idler	311-9391
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2572	Spider As-Fan	451-9027
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4577	Muffler As.	308-9877
4N-4679	Pulley-Fan	394-9837
4N-4864	Pump Gp-F Tfr	242-3442
4N-4878	Pump Gp-F Tfr	390-0995
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4N-9213	Elbow-Exhaust	330-9270
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572
4N-9944	Line As-Fuel Inj	380-1565
4P-3546	Valve As-Relief	325-6236

Sales Model 3306 (Cont'd.)

09A		
Original Part Number	Part Name	Classic Part Number
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9989	Gear As-Idler	302-2677
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024

09A		
Original Part Number	Part Name	Classic Part Number
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5P-9561	Gasket Kt-V G	437-8106
5P-9568	Gasket Kit	393-3625
5S-1757	Insert-Seat	311-9401
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-0714	Pulley-Alt	264-5884
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386

09A		
Original Part Number	Part Name	Classic Part Number
6V-0611	Kit-Gasket-Fs	437-4581
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
6V-2529	Gasket Kit	437-3208
6V-2983	Gasket Kt	437-3213
6V-5976	Kit-Gasket (Rs)	393-5200
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7K-2135	Bearing-Roller	417-4492
7L-7508	Bearing-Ball	420-6536
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5511	Gear As-Idler	233-2180
7N-5645	Tube As-Outlet	378-3984
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759

Sales Model 3306 (Cont'd.)

09A		
Original Part Number	Part Name	Classic Part Number
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7639	Rotator-Valve	383-1582
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-4411	Cap As-Rain	373-1912
7S-8443	Muffler	247-2675
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5687	Hub-Cshft	314-8684
7W-5692	Pulley-Cshaft	386-3041
7W-5696	Hub-Cshft	424-5887
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-0983	Mounting	384-3470
8D-9973	Housing	391-9825
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212

09A		
Original Part Number	Part Name	Classic Part Number
8L-8867	Pulley	434-1409
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

09A		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8T-2466	Gasket Kit	393-5199
8W-3589	Link As-Spring	380-7389
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9N-3668	Base As.-Coolant	419-4718
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888

Sales Model 3306 (Cont'd.)

09A		
Original Part Number	Part Name	Classic Part Number
9S-2355	Manifold-Exhaust	261-0891
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-7148	Cap As-Rain	378-3994
9S-7534	Pipe-Exh Ext	398-2950
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
102-1561	Lifter As-Valve	311-9402
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351

09A		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
170-0558	Kit-Rebuild-Pump	390-1001
170-0560	Rebuild Kit-Pump	363-7458
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698

09A		
Original Part Number	Part Name	Classic Part Number
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7772	Pump Gp-Water -B	438-2009
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
255-6863	Gasket	450-5024
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

166		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1S-3062	Director-Water	418-9572
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2P-1170	Shaft As-Gear	296-1367

166		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439

166		
Original Part Number	Part Name	Classic Part Number
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247

Sales Model 3306 (Cont'd.)

166		
Original Part Number	**Part Name**	**Classic Part Number**
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6I-1345	Shaft As-O Pump	374-7475
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-7546	Gasket-Plate	433-8187
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196

166		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-6796	Head Gp-Cyl -A	269-5290
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558

166		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
170-7502	Shaft-Dr Idler	374-7484
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

1DG		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659

1DG		
Original Part Number	**Part Name**	**Classic Part Number**
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

1DG		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850

Sales Model 3306 (Cont'd.)

1DG		
Original Part Number	Part Name	Classic Part Number
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3786	Rod-Thrt Cont	397-5051
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
5P-8768	Kit-Gasket (Scl)	393-1024
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

1DG		
Original Part Number	Part Name	Classic Part Number
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0703	Bearing-Sleeve	472-8037

1DG		
Original Part Number	Part Name	Classic Part Number
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050

Sales Model 3306 (Cont'd.)

1DG		
Original Part Number	Part Name	Classic Part Number
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353

1DG		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

1DG		
Original Part Number	Part Name	Classic Part Number
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

1RD		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-7458	Crankshaft As	242-3439
4N-0432	Bearing-Ball	417-4499

1RD		
Original Part Number	Part Name	Classic Part Number
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5P-8768	Kit-Gasket (Scl)	393-1024
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206

1RD		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-7166	Race-Brg Thrust	417-4531
7N-8018	Seal-Water	418-1964
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377

Sales Model 3306 (Cont'd.)

1RD		
Original Part Number	Part Name	Classic Part Number
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0493	Shaft As-Pump	325-6198
8S-6511	Bearing-Sleeve	380-7372
9Y-1798	Seal-Water	379-0165
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

1RD		
Original Part Number	Part Name	Classic Part Number
167-8123	Damper As	299-2006
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
456-2503	Kit-Ovhl-Cla	380-7537
456-2503	Kit-Ovhl-Cla	270-4360
456-2503	Kit-Ovhl-Cla	270-4361
456-2503	Kit-Ovhl-Cla	311-9356
456-2503	Kit-Ovhl-Cla	325-6236
456-2503	Kit-Ovhl-Cla	379-0174
456-2503	Kit-Ovhl-Cla	383-1575
456-2503	Kit-Ovhl-Cla	398-2927

1RD		
Original Part Number	Part Name	Classic Part Number
456-2503	Kit-Ovhl-Cla	419-6349
456-2503	Kit-Ovhl-Cla	374-8342
456-2505	Kit-Ovhl-Cla	380-7372
456-2505	Kit-Ovhl-Cla	398-2927
456-2505	Kit-Ovhl-Cla	394-8207
456-2505	Kit-Ovhl-Cla	394-8206
456-2505	Kit-Ovhl-Cla	383-1575
456-2505	Kit-Ovhl-Cla	419-6349
456-2505	Kit-Ovhl-Cla	374-8342
456-2505	Kit-Ovhl-Cla	380-7537
456-2505	Kit-Ovhl-Cla	379-0174
456-2505	Kit-Ovhl-Cla	376-9085
456-2505	Kit-Ovhl-Cla	270-4360
456-2505	Kit-Ovhl-Cla	270-4361
456-2505	Kit-Ovhl-Cla	311-9356
456-2505	Kit-Ovhl-Cla	325-6236
456-2508	Kit-Gasket-Cla	325-6223
456-2508	Kit-Gasket-Cla	417-4499
456-2508	Kit-Gasket-Cla	325-6158
456-2508	Kit-Gasket-Cla	384-4816
456-2508	Kit-Gasket-Cla	325-6210
456-2508	Kit-Gasket-Cla	417-4531

23C		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1N-3165	Plunger-Rlf V	373-1883
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659

23C		
Original Part Number	Part Name	Classic Part Number
1W-6810	Pipe-Outlet	472-8036
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

23C		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2W-1225	Pump Gp-Water	380-7532
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439

Sales Model 3306 (Cont'd.)

23C		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7678	Gear-Water Pump	325-6088
2W-8271	Arm As-Rocker	432-8912
3L-1425	Bearing-Ball	311-9356
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
4D-2619	Bearing	417-4494
4L-8473	Plate-Wear	419-0883
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-4864	Pump Gp-F Tfr	242-3442
4N-4878	Pump Gp-F Tfr	390-0995
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572
4N-9944	Line As-Fuel Inj	380-1565
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-7188	Core As-Oclr	374-7501
4W-9989	Gear As-Idler	302-2677
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-5553	Screw-Tappet Adj	311-9451
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379

23C		
Original Part Number	**Part Name**	**Classic Part Number**
5L-9371	Connector-Inlet	311-9375
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5P-9568	Gasket Kit	393-3625
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6N-8992	Adapter-Fan	394-9810
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
6V-2580	Gasket Kt-V G	393-3637
6V-2983	Gasket Kt	437-3213
6V-4785	Gasket Kit - Fs	388-0661
6V-6894	Rebuild Kt-Pump	383-3696
7C-3862	Camshaft	458-0151

23C		
Original Part Number	**Part Name**	**Classic Part Number**
7C-4297	Seal As-Cshaft	325-6192
7E-4728	Rod As-Conn	379-8863
7E-5085	Bushing	377-5829
7E-7894	Bearing-Rod	419-7260
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7W-2731	Retainer	423-3541
7W-5687	Hub-Cshft	314-8684
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989

Sales Model 3306 (Cont'd.)

23C		
Original Part Number	Part Name	Classic Part Number
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8M-0874	Plunger As-Valve	311-9439
8N-0081	Trunnion	393-5196
8N-0701	Bearing-Sleeve	419-4745
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349

23C		
Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-7682	Valve-Inlet	385-9266
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-3668	Base As.-Coolant	419-4718
9N-5246	Bearing-Camshaft	384-4772
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124

23C		
Original Part Number	Part Name	Classic Part Number
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
119-6772	Valve-Exhaust	384-8699
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
167-8123	Damper As	299-2006
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
170-0558	Kit-Rebuild-Pump	390-1001
170-0560	Rebuild Kit-Pump	363-7458
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687

Sales Model 3306 (Cont'd.)

23C		
Original Part Number	**Part Name**	**Classic Part Number**
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942

23C		
Original Part Number	**Part Name**	**Classic Part Number**
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893

23C		
Original Part Number	**Part Name**	**Classic Part Number**
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

28M		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-3900	Gasket	472-8006
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357

28M		
Original Part Number	**Part Name**	**Classic Part Number**
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
3S-5017	Elbow-Exhaust	369-9498
4N-4878	Pump Gp-F Tfr	390-0995
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4W-0452	Seal As -Cshaft	325-6191
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816

28M		
Original Part Number	**Part Name**	**Classic Part Number**
7N-0110	Core As-Oil Clr	319-3435
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5692	Pulley-Cshaft	386-3041
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4529	Pulley-Alt	264-5889
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349

Sales Model 3306 (Cont'd.)

28M		
Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438

28M		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165

28M		
Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
167-8123	Damper As	299-2006
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

2ZC		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

2ZC		
Original Part Number	Part Name	Classic Part Number
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3786	Rod-Thrt Cont	397-5051
4N-4520	Guide	388-6600
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580

2ZC		
Original Part Number	Part Name	Classic Part Number
4W-6805	Flywheel As	421-3325
5P-8768	Kit-Gasket (Scl)	393-1024
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206

Sales Model 3306 (Cont'd.)

2ZC		
Original Part Number	Part Name	Classic Part Number
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-9020	Bell As-Pump Suc	378-3989
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349

2ZC		
Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
9N-5251	Piston Gp-Bsc	250-6557
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124

2ZC		
Original Part Number	Part Name	Classic Part Number
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
167-8123	Damper As	299-2006
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
250-6557	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

49S		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-6810	Pipe-Outlet	472-8036

49S		
Original Part Number	Part Name	Classic Part Number
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214

49S		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203

Sales Model 3306 (Cont'd.)

49S		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7458	Crankshaft As	242-3439
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572
4N-9944	Line As-Fuel Inj	380-1565
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
5L-7632	Support-Elbow	433-9854
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851

49S		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-9789	Bearing-Ball	374-8342
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207

49S		
Original Part Number	**Part Name**	**Classic Part Number**
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
167-8123	Damper As	299-2006
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484

Sales Model 3306 (Cont'd.)

49S		
Original Part Number	**Part Name**	**Classic Part Number**
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

49S		
Original Part Number	**Part Name**	**Classic Part Number**
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085

49S		
Original Part Number	**Part Name**	**Classic Part Number**
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

4WB		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-7936	Spider As-Fan	383-3673
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1W-3900	Gasket	472-8006
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203

4WB		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-6805	Flywheel As	421-3325
5P-8768	Kit-Gasket (Scl)	393-1024
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544

4WB		
Original Part Number	**Part Name**	**Classic Part Number**
6N-7263	Gasket-Cyl Head	380-7386
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-9020	Bell As-Pump Suc	378-3989
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291

Sales Model 3306 (Cont'd.)

4WB		
Original Part Number	Part Name	Classic Part Number
8N-1849	Bearing-Conn Rod	379-0196
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

4WB		
Original Part Number	Part Name	Classic Part Number
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193

4WB		
Original Part Number	Part Name	Classic Part Number
167-8123	Damper As	299-2006
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
250-6557	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

5JC		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

5JC		
Original Part Number	Part Name	Classic Part Number
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-4238	Mount-Flexible	385-7222
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850

5JC		
Original Part Number	Part Name	Classic Part Number
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3786	Rod-Thrt Cont	397-5051
3N-5869	Support-Elbow	375-9973
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236

Sales Model 3306 (Cont'd.)

5JC		
Original Part Number	Part Name	Classic Part Number
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991

5JC		
Original Part Number	Part Name	Classic Part Number
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

5JC		
Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193

Sales Model 3306 (Cont'd.)

5JC		
Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

5JC		
Original Part Number	Part Name	Classic Part Number
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259

5JC		
Original Part Number	Part Name	Classic Part Number
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-8014	Kit-Gasket-Sch	437-8662
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

5KD		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357

5KD		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3L-1425	Bearing-Ball	311-9356
3N-4892	Lever-Gov Cont	439-4542
3N-5869	Support-Elbow	375-9973
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984

5KD		
Original Part Number	Part Name	Classic Part Number
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-9989	Gear As-Idler	302-2677
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

Sales Model 3306 (Cont'd.)

5KD		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200
7C-2880	Bell As-Suction	380-1520
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-5928	Pump Gp-F Inj -B	432-8277

5KD		
Original Part Number	Part Name	Classic Part Number
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033

5KD		
Original Part Number	Part Name	Classic Part Number
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8T-1622	Gasket Kit - Sch	436-8388
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9X-6560	Gasket Kit	382-5073
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

Sales Model 3306 (Cont'd.)

5KD		
Original Part Number	**Part Name**	**Classic Part Number**
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365

5KD		
Original Part Number	**Part Name**	**Classic Part Number**
172-7771	Pump Gp-Water -B	419-4646
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356

5KD		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

63Z		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356

63Z		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191

63Z		
Original Part Number	**Part Name**	**Classic Part Number**
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9989	Gear As-Idler	302-2677
5L-7632	Support-Elbow	433-9854
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5P-9568	Gasket Kit	393-3625
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200

Sales Model 3306 (Cont'd.)

63Z		
Original Part Number	Part Name	Classic Part Number
7C-2880	Bell As-Suction	380-1520
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

63Z		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1622	Gasket Kit - Sch	436-8388
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9X-6560	Gasket Kit	382-5073
9Y-1798	Seal-Water	379-0165

63Z		
Original Part Number	Part Name	Classic Part Number
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-6170	Gasket Kit	437-4598
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0560	Rebuild Kit-Pump	363-7458
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646

Sales Model 3306 (Cont'd.)

63Z		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
232-3233	Bearing-Main	376-9085
234-8011	Kit-Gasket-Sch	437-8664

63Z		
Original Part Number	Part Name	Classic Part Number
234-8016	Kit-Gasket-Sch	393-0919
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988

63Z		
Original Part Number	Part Name	Classic Part Number
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

66D		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3062	Retainer As	311-9445
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-8606	Valve-Inlet	443-1204
1W-9171	Bonnet-Valve	374-4707

66D		
Original Part Number	Part Name	Classic Part Number
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-3767	Tube-Disposal	377-5850
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7830	Pump Gp	314-8533
2S-4015	Plunger As-Valve	311-9438
2S-6150	Cover-Pulley	428-8817

66D		
Original Part Number	Part Name	Classic Part Number
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-5869	Support-Elbow	375-9973
3S-5017	Elbow-Exhaust	369-9498
3S-9466	Bearing-Sleeve	314-8509
4B-7270	Cone-Bearing	399-4439
4D-2619	Bearing	417-4494
4L-8473	Plate-Wear	419-0883
4M-9215	Gear-Pump Idler	311-9391
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903

Sales Model 3306 (Cont'd.)

66D		
Original Part Number	Part Name	Classic Part Number
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2572	Spider As-Fan	451-9027
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4577	Muffler As.	308-9877
4N-4679	Pulley-Fan	394-9837
4N-4864	Pump Gp-F Tfr	242-3442
4N-4878	Pump Gp-F Tfr	390-0995
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4N-9213	Elbow-Exhaust	330-9270
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572
4N-9944	Line As-Fuel Inj	380-1565
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985

66D		
Original Part Number	Part Name	Classic Part Number
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9989	Gear As-Idler	302-2677
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5P-9561	Gasket Kt-V G	437-8106
5P-9568	Gasket Kit	393-3625
5S-1757	Insert-Seat	311-9401
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437

66D		
Original Part Number	Part Name	Classic Part Number
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-0714	Pulley-Alt	264-5884
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-0611	Kit-Gasket-Fs	437-4581
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
6V-2529	Gasket Kit	437-3208
6V-2983	Gasket Kt	437-3213
6V-5976	Kit-Gasket (Rs)	393-5200
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847

Sales Model 3306 (Cont'd.)

66D		
Original Part Number	**Part Name**	**Classic Part Number**
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7K-2135	Bearing-Roller	417-4492
7L-7508	Bearing-Ball	420-6536
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5511	Gear As-Idler	233-2180
7N-5645	Tube As-Outlet	378-3984
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7639	Rotator-Valve	383-1582
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994

66D		
Original Part Number	**Part Name**	**Classic Part Number**
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-4411	Cap As-Rain	373-1912
7S-8443	Muffler	247-2675
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5687	Hub-Cshft	314-8684
7W-5692	Pulley-Cshaft	386-3041
7W-5696	Hub-Cshft	424-5887
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-0983	Mounting	384-3470
8D-9973	Housing	391-9825
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436

66D		
Original Part Number	**Part Name**	**Classic Part Number**
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198

Sales Model 3306 (Cont'd.)

66D		
Original Part Number	Part Name	Classic Part Number
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8T-2466	Gasket Kit	393-5199
8W-3589	Link As-Spring	380-7389
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9N-3668	Base As.-Coolant	419-4718
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-7148	Cap As-Rain	378-3994
9S-7534	Pipe-Exh Ext	398-2950
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042

66D		
Original Part Number	Part Name	Classic Part Number
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
102-1561	Lifter As-Valve	311-9402
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
170-0558	Kit-Rebuild-Pump	390-1001
170-0560	Rebuild Kit-Pump	363-7458
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484

66D		
Original Part Number	Part Name	Classic Part Number
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7772	Pump Gp-Water -B	438-2009
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
255-6863	Gasket	450-5024
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 3306 (Cont'd.)

67D		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-6810	Pipe-Outlet	472-8036
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439

67D		
Original Part Number	Part Name	Classic Part Number
2W-7678	Gear-Water Pump	325-6088
3B-8845	Bearing-Inner	417-4509
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
4L-8473	Plate-Wear	419-0883
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4878	Pump Gp-F Tfr	390-0995
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572
4N-9944	Line As-Fuel Inj	380-1565
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024

67D		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5P-9568	Gasket Kit	393-3625
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-0611	Kit-Gasket-Fs	437-4581
6V-2202	Bearing-Spl Ball	380-1574
6V-2529	Gasket Kit	437-3208
6V-2983	Gasket Kt	437-3213
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7L-7508	Bearing-Ball	420-6536
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-3536	Gear-Fuel	279-4993

Sales Model 3306 (Cont'd.)

67D		
Original Part Number	Part Name	Classic Part Number
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7S-7070	Head As-Cylinder	325-6107
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623

67D		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-5908	Gasket	433-8196
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-3668	Base As.-Coolant	419-4718
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561

67D		
Original Part Number	Part Name	Classic Part Number
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
167-8123	Damper As	299-2006
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
170-0560	Rebuild Kit-Pump	363-7458
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
255-6863	Gasket	450-5024
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 3306 (Cont'd.)

68D		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-3062	Retainer As	311-9445
1W-8606	Valve-Inlet	443-1204
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-4238	Mount-Flexible	385-7222
2P-6245	Shaft As-Pump	325-6197
3B-1142	Retainer-Spring	391-1099
3N-1968	Mount-Shock	397-5046
3N-3368	Pipe-Exhaust	311-9434
4B-7270	Cone-Bearing	399-4439
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-7693	Crankshaft As	269-8763
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-8768	Kit-Gasket (Scl)	393-1024

68D		
Original Part Number	Part Name	Classic Part Number
5S-1757	Insert-Seat	311-9401
5S-5917	Screw-Rocker Adj	380-7537
5S-7630	Bearing-Sleeve	394-0219
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6I-1345	Shaft As-O Pump	374-7475
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-2820	Pump Gp-Eng Oil	415-1903
6N-7263	Gasket-Cyl Head	380-7386
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-7639	Rotator-Valve	383-1582
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7S-3161	Lifter-Valve	279-4996
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8N-1984	Rod As-Conn	242-3441

68D		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0493	Shaft As-Pump	325-6198
8S-6511	Bearing-Sleeve	380-7372
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9S-7148	Cap As-Rain	378-3994
9Y-1798	Seal-Water	379-0165
102-1561	Lifter As-Valve	311-9402
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
167-8123	Damper As	299-2006
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
328-5572	Bearing-Rod	419-6349

69D		
Original Part Number	Part Name	Classic Part Number
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913

69D		
Original Part Number	Part Name	Classic Part Number
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-4303	Head As-Cylinder	242-3434
1P-5480	Cover As.-End	299-1998
1S-3062	Director-Water	418-9572

69D		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

Sales Model 3306 (Cont'd.)

69D		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-4015	Plunger As-Valve	311-9438
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7678	Gear-Water Pump	325-6088
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4878	Pump Gp-F Tfr	390-0995
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191

69D		
Original Part Number	Part Name	Classic Part Number
4W-2061	Pan As-Oil Sump	416-5519
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9561	Gasket Kt-V G	437-8106
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-2202	Bearing-Spl Ball	380-1574
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816

69D		
Original Part Number	Part Name	Classic Part Number
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2834	Kit-Repair	374-4723
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7765	Governor As	377-5841
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7043	Mount As	389-6332
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

Sales Model 3306 (Cont'd.)

69D		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9L-5519	Manifold-Exhaust	392-4500

69D		
Original Part Number	Part Name	Classic Part Number
9L-5521	Manifold-Exhaust	396-9895
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
169-1750	Seal Gp-Basic	472-8022

69D		
Original Part Number	Part Name	Classic Part Number
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6557	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

70R		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344

70R		
Original Part Number	Part Name	Classic Part Number
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3062	Retainer As	311-9445
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981

70R		
Original Part Number	Part Name	Classic Part Number
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-8606	Valve-Inlet	443-1204
1W-9171	Bonnet-Valve	374-4707

Sales Model 3306 (Cont'd.)

70R		
Original Part Number	Part Name	Classic Part Number
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-3767	Tube-Disposal	377-5850
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7830	Pump Gp	314-8533
2S-4015	Plunger As-Valve	311-9438
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439

70R		
Original Part Number	Part Name	Classic Part Number
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-5869	Support-Elbow	375-9973
3S-5017	Elbow-Exhaust	369-9498
3S-9466	Bearing-Sleeve	314-8509
4B-7270	Cone-Bearing	399-4439
4D-2619	Bearing	417-4494
4L-8473	Plate-Wear	419-0883
4M-9215	Gear-Pump Idler	311-9391
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2572	Spider As-Fan	451-9027
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4577	Muffler As.	308-9877
4N-4679	Pulley-Fan	394-9837
4N-4864	Pump Gp-F Tfr	242-3442
4N-4878	Pump Gp-F Tfr	390-0995

70R		
Original Part Number	Part Name	Classic Part Number
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4N-9213	Elbow-Exhaust	330-9270
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572
4N-9944	Line As-Fuel Inj	380-1565
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9989	Gear As-Idler	302-2677

Sales Model 3306 (Cont'd.)

70R		
Original Part Number	**Part Name**	**Classic Part Number**
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5P-9561	Gasket Kt-V G	437-8106
5P-9568	Gasket Kit	393-3625
5S-1757	Insert-Seat	311-9401
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542

70R		
Original Part Number	**Part Name**	**Classic Part Number**
6L-8968	Coupling-Exhaust	311-9381
6N-0714	Pulley-Alt	264-5884
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-0611	Kit-Gasket-Fs	437-4581
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
6V-2529	Gasket Kit	437-3208
6V-2983	Gasket Kt	437-3213
6V-5976	Kit-Gasket (Rs)	393-5200
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7K-2135	Bearing-Roller	417-4492
7L-7508	Bearing-Ball	420-6536
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779

70R		
Original Part Number	**Part Name**	**Classic Part Number**
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5511	Gear As-Idler	233-2180
7N-5645	Tube As-Outlet	378-3984
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7639	Rotator-Valve	383-1582
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-4411	Cap As-Rain	373-1912
7S-8443	Muffler	247-2675
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5687	Hub-Cshft	314-8684
7W-5692	Pulley-Cshaft	386-3041
7W-5696	Hub-Cshft	424-5887
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8A-2251	Liner-Cylinder	376-9068

Sales Model 3306 (Cont'd.)

70R		
Original Part Number	Part Name	Classic Part Number
8A-2305	Repair Kt-Major	386-3042
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-0983	Mounting	384-3470
8D-9973	Housing	391-9825
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

70R		
Original Part Number	Part Name	Classic Part Number
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8T-2466	Gasket Kit	393-5199
8W-3589	Link As-Spring	380-7389
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-5519	Manifold-Exhaust	392-4500

70R		
Original Part Number	Part Name	Classic Part Number
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9N-3668	Base As.-Coolant	419-4718
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-7148	Cap As-Rain	378-3994
9S-7534	Pipe-Exh Ext	398-2950
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
102-1561	Lifter As-Valve	311-9402
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046

Sales Model 3306 (Cont'd.)

70R		
Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
170-0558	Kit-Rebuild-Pump	390-1001
170-0560	Rebuild Kit-Pump	363-7458
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835

70R		
Original Part Number	Part Name	Classic Part Number
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7772	Pump Gp-Water -B	438-2009
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314

70R		
Original Part Number	Part Name	Classic Part Number
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
255-6863	Gasket	450-5024
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

76R		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-6810	Pipe-Outlet	472-8036
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354

76R		
Original Part Number	Part Name	Classic Part Number
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439

76R		
Original Part Number	Part Name	Classic Part Number
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364

Sales Model 3306 (Cont'd.)

76R		
Original Part Number	**Part Name**	**Classic Part Number**
4N-3284	Line As-Fuel Inj	247-3365
4N-4878	Pump Gp-F Tfr	390-0995
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4W-0452	Seal As -Cshaft	325-6191
4W-6805	Flywheel As	421-3325
4W-7188	Core As-Oclr	374-7501
4W-9989	Gear As-Idler	302-2677
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9561	Gasket Kt-V G	437-8106
5P-9568	Gasket Kit	393-3625
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386

76R		
Original Part Number	**Part Name**	**Classic Part Number**
6V-2202	Bearing-Spl Ball	380-1574
6V-2580	Gasket Kt-V G	393-3637
6V-2983	Gasket Kt	437-3213
6V-5976	Kit-Gasket (Rs)	393-5200
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-5910	Impeller-Pump	314-8686
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

76R		
Original Part Number	**Part Name**	**Classic Part Number**
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895

Sales Model 3306 (Cont'd.)

76R		
Original Part Number	Part Name	Classic Part Number
9L-5908	Gasket	433-8196
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126

76R		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
170-0560	Rebuild Kit-Pump	363-7458
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698

76R		
Original Part Number	Part Name	Classic Part Number
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

7HB		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173

7HB		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357

7HB		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356

Sales Model 3306 (Cont'd.)

7HB		
Original Part Number	Part Name	Classic Part Number
3N-1968	Mount-Shock	397-5046
3N-3786	Rod-Thrt Cont	397-5051
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
5L-6326	Bearing-Ball	420-3222
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437

7HB		
Original Part Number	Part Name	Classic Part Number
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-2202	Bearing-Spl Ball	380-1574
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989

7HB		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831

Sales Model 3306 (Cont'd.)

7HB		
Original Part Number	**Part Name**	**Classic Part Number**
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
9B-1320	Valve-Check	377-5832
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977

7HB		
Original Part Number	**Part Name**	**Classic Part Number**
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

7HB		
Original Part Number	**Part Name**	**Classic Part Number**
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
250-6557	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

84Z		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221

84Z		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454

84Z		
Original Part Number	**Part Name**	**Classic Part Number**
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3B-8845	Bearing-Inner	417-4509
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
4L-8473	Plate-Wear	419-0883
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600

Sales Model 3306 (Cont'd.)

84Z		
Original Part Number	Part Name	Classic Part Number
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1647	Arm Gp-V Rocker	433-0451
6I-1650	Arm Gp-V Rocker	433-0450
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015

84Z		
Original Part Number	Part Name	Classic Part Number
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-2983	Gasket Kt	437-3213
6V-4785	Gasket Kit - Fs	388-0661
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858

84Z		
Original Part Number	Part Name	Classic Part Number
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125

Sales Model 3306 (Cont'd.)

84Z		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0560	Rebuild Kit-Pump	363-7458
170-0570	Rebuild Kit-Pump	380-7577

84Z		
Original Part Number	Part Name	Classic Part Number
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

84Z		
Original Part Number	Part Name	Classic Part Number
196-9534	Bearing Kt-Main	468-8667
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
234-8014	Kit-Gasket-Sch	437-8662
255-6863	Gasket	450-5024
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

85Z		
Original Part Number	Part Name	Classic Part Number
1L-7205	Bearing-Ball	416-2167
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5910	Tappet As-Guide&	383-1569
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221

85Z		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

85Z		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7455	Gear As	396-9957
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3E-6772	Seal-Water	382-8017
3F-3049	Cone-Roller Brg	418-9600
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542

Sales Model 3306 (Cont'd.)

85Z		
Original Part Number	Part Name	Classic Part Number
3N-5869	Support-Elbow	375-9973
3P-2582	Bearing-Spl Ball	417-9478
4B-7270	Cone-Bearing	399-4439
4F-2041	Cup-Roller Brg	418-9609
4L-8473	Plate-Wear	419-0883
4M-5858	Bearing-Spl Ball	417-4495
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4679	Pulley-Fan	394-9837
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-7693	Crankshaft As	269-8763
4P-2383	Adapter-Inlet	438-1812
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988

85Z		
Original Part Number	Part Name	Classic Part Number
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355
4W-0452	Seal As -Cshaft	325-6191
4W-0456	Muffler As-Eject	360-7879
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-5044	Race-Brg Outer	417-9479

85Z		
Original Part Number	Part Name	Classic Part Number
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5P-9568	Gasket Kit	393-3625
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1453	Crankshaft As	368-5916
6I-1647	Arm Gp-V Rocker	433-0451
6I-1650	Arm Gp-V Rocker	433-0450
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-9808	Bearing-Ball	417-9484
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-1931	Plunger	379-0171

Sales Model 3306 (Cont'd.)

85Z		
Original Part Number	Part Name	Classic Part Number
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-2983	Gasket Kt	437-3213
6V-3831	Seal-O-Ring	436-2657
6V-4785	Gasket Kit - Fs	388-0661
6Y-3484	Bearing-Spl Ball	416-2166
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724

85Z		
Original Part Number	Part Name	Classic Part Number
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5692	Pulley-Cshaft	386-3041
7W-5733	Gasket	421-7333
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1726	Rod As-Conn	379-8866

85Z		
Original Part Number	Part Name	Classic Part Number
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8258	Bearing-Sleeve	452-1077
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894

Sales Model 3306 (Cont'd.)

85Z		
Original Part Number	Part Name	Classic Part Number
8S-7718	Manifold-Exhaust	295-0416
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6147	Body As	369-9499
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9S-9328	Muffler	395-1308
9W-9930	Mount As	295-6437
9W-9931	Mount As.	360-2354
9X-6560	Gasket Kit	382-5073
9Y-1798	Seal-Water	379-0165
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-7860	Valve-Inlet	270-4360
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-3014	Gasket Kit	388-0656
106-7798	Bearing-Ball	417-9494
106-7799	Bearing-Ball	396-9947
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276

85Z		
Original Part Number	Part Name	Classic Part Number
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
111-8015	Gasket As-Head	279-4977
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
145-8503	Shaft As-Idler	426-0035
148-7455	Valve - Exhaust	270-4361
150-4637	Pan-Oil	377-5843
155-1379	Gasket Kit - Sch	386-3815
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353

85Z		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
166-9142	Gasket	420-8546
167-8123	Damper As	299-2006
167-8126	Damper As	382-8019
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0560	Rebuild Kit-Pump	363-7458
170-0566	Kit-Rebuild-Pump	377-5835
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
187-0605	Gasket Kit - Cl	382-5055
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013

Sales Model 3306 (Cont'd.)

85Z		
Original Part Number	**Part Name**	**Classic Part Number**
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
202-3572	Shaft As-Drive	426-0037
204-4458	Gasket Kit - Acl	437-8151
204-4462	Gasket Kit - Sch	437-2005
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266

85Z		
Original Part Number	**Part Name**	**Classic Part Number**
232-3233	Bearing-Main	376-9085
234-8011	Kit-Gasket-Sch	437-8664
234-8014	Kit-Gasket-Sch	437-8662
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
321-5746	Bearing-Main	419-6367

85Z		
Original Part Number	**Part Name**	**Classic Part Number**
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653
430-7619	Adapter-Cla	438-1812

9SL		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

9SL		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
4L-8473	Plate-Wear	419-0883
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580

9SL		
Original Part Number	**Part Name**	**Classic Part Number**
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
5B-9169	Plug-Drain	419-4736
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816

Sales Model 3306 (Cont'd.)

9SL		
Original Part Number	Part Name	Classic Part Number
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207

9SL		
Original Part Number	Part Name	Classic Part Number
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

9SL		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
255-6863	Gasket	450-5024
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

R8Z		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-7125	Governor As	383-3672

R8Z		
Original Part Number	Part Name	Classic Part Number
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

R8Z		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

Sales Model 3306 (Cont'd.)

R8Z		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

R8Z		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5P-8768	Kit-Gasket (Scl)	393-1024
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-1152	Pulley-Fan	333-4951
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438

R8Z		
Original Part Number	**Part Name**	**Classic Part Number**
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5779	Coupling-Exhaust	325-6047
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

Sales Model 3306 (Cont'd.)

R8Z		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196

R8Z		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

R8Z		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

T9R		
Original Part Number	Part Name	Classic Part Number
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020

T9R		
Original Part Number	Part Name	Classic Part Number
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

T9R		
Original Part Number	Part Name	Classic Part Number
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088

Sales Model 3306 (Cont'd.)

T9R		
Original Part Number	Part Name	Classic Part Number
2W-9978	Core As-Oclr	279-4983
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
7C-4297	Seal As-Cshaft	325-6192
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655

T9R		
Original Part Number	Part Name	Classic Part Number
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5696	Hub-Cshft	424-5887
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0081	Trunnion	393-5196
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349

T9R		
Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
109-4848	Pulley-Cshaft	416-5507
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
134-4200	Manifold-Exhaust	443-2060
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351

Sales Model 3306 (Cont'd.)

T9R		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

T9R		
Original Part Number	**Part Name**	**Classic Part Number**
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438

T9R		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005

Sales Model 3306B

1BM		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

1BM		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
3N-4892	Lever-Gov Cont	439-4542
3N-5869	Support-Elbow	375-9973
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984

1BM		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535

Sales Model 3306B (Cont'd.)

1BM		
Original Part Number	**Part Name**	**Classic Part Number**
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

1BM		
Original Part Number	**Part Name**	**Classic Part Number**
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977

1BM		
Original Part Number	**Part Name**	**Classic Part Number**
131-3815	Seal Gp-Basic	325-6193
140-2246	Gasket Kit	383-3710
148-7455	Valve - Exhaust	270-4361
155-1378	Gasket Kit - Sch	437-8152
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

1DG		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978

Sales Model 3306B (Cont'd.)

1DG		
Original Part Number	Part Name	Classic Part Number
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892

1DG		
Original Part Number	Part Name	Classic Part Number
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3786	Rod-Thrt Cont	397-5051
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
5P-8768	Kit-Gasket (Scl)	393-1024
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535

1DG		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196

Sales Model 3306B (Cont'd.)

1DG		
Original Part Number	Part Name	Classic Part Number
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084

1DG		
Original Part Number	Part Name	Classic Part Number
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353

1DG		
Original Part Number	Part Name	Classic Part Number
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

1RD		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

1RD		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-7458	Crankshaft As	242-3439

1RD		
Original Part Number	Part Name	Classic Part Number
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5P-8768	Kit-Gasket (Scl)	393-1024
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247

Sales Model 3306B (Cont'd.)

1RD		
Original Part Number	Part Name	Classic Part Number
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-7166	Race-Brg Thrust	417-4531
7N-8018	Seal-Water	418-1964
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623

1RD		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0493	Shaft As-Pump	325-6198
8S-6511	Bearing-Sleeve	380-7372
9Y-1798	Seal-Water	379-0165
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
232-3233	Bearing-Main	376-9085

1RD		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
456-2503	Kit-Ovhl-Cla	398-2927
456-2503	Kit-Ovhl-Cla	383-1575
456-2503	Kit-Ovhl-Cla	380-7537
456-2503	Kit-Ovhl-Cla	379-0174
456-2503	Kit-Ovhl-Cla	374-8342
456-2503	Kit-Ovhl-Cla	325-6236
456-2503	Kit-Ovhl-Cla	419-6349
456-2503	Kit-Ovhl-Cla	311-9356
456-2503	Kit-Ovhl-Cla	270-4361
456-2503	Kit-Ovhl-Cla	270-4360
456-2505	Kit-Ovhl-Cla	394-8206
456-2505	Kit-Ovhl-Cla	383-1575
456-2505	Kit-Ovhl-Cla	398-2927
456-2505	Kit-Ovhl-Cla	394-8207
456-2505	Kit-Ovhl-Cla	380-7372
456-2505	Kit-Ovhl-Cla	270-4361
456-2505	Kit-Ovhl-Cla	270-4360
456-2505	Kit-Ovhl-Cla	325-6236
456-2505	Kit-Ovhl-Cla	376-9085
456-2505	Kit-Ovhl-Cla	379-0174
456-2505	Kit-Ovhl-Cla	419-6349
456-2505	Kit-Ovhl-Cla	311-9356
456-2505	Kit-Ovhl-Cla	380-7537
456-2505	Kit-Ovhl-Cla	374-8342
456-2508	Kit-Gasket-Cla	417-4531
456-2508	Kit-Gasket-Cla	417-4499
456-2508	Kit-Gasket-Cla	384-4816
456-2508	Kit-Gasket-Cla	325-6223
456-2508	Kit-Gasket-Cla	325-6210
456-2508	Kit-Gasket-Cla	325-6158

1RS		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483

1RS		
Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006

1RS		
Original Part Number	Part Name	Classic Part Number
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

Sales Model 3306B (Cont'd.)

1RS		
Original Part Number	Part Name	Classic Part Number
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-4238	Mount-Flexible	385-7222
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3N-3786	Rod-Thrt Cont	397-5051
4B-7270	Cone-Bearing	399-4439
4N-0432	Bearing-Ball	417-4499
4N-2514	Gear-Flywheel	421-7283
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

1RS		
Original Part Number	Part Name	Classic Part Number
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
5F-8651	Bearing-Ball	420-3223
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2983	Gasket Kt	437-3213
6Y-3955	Bearing-Ball	417-9485
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996

1RS		
Original Part Number	Part Name	Classic Part Number
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

Sales Model 3306B (Cont'd.)

1RS		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
104-3014	Gasket Kit	388-0656
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361

1RS		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

1RS		
Original Part Number	Part Name	Classic Part Number
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
232-3233	Bearing-Main	376-9085
234-8014	Kit-Gasket-Sch	437-8662
255-6863	Gasket	450-5024
256-9653	Flywheel As.	425-3444
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

2AJ		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221

2AJ		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454

2AJ		
Original Part Number	Part Name	Classic Part Number
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3786	Rod-Thrt Cont	397-5051
3N-5869	Support-Elbow	375-9973
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572

Sales Model 3306B (Cont'd.)

2AJ		
Original Part Number	Part Name	Classic Part Number
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-8768	Kit-Gasket (Scl)	393-1024
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991

2AJ		
Original Part Number	Part Name	Classic Part Number
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6V-2983	Gasket Kt	437-3213
6V-5976	Kit-Gasket (Rs)	393-5200
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210

2AJ		
Original Part Number	Part Name	Classic Part Number
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
9L-5908	Gasket	433-8196
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977

Sales Model 3306B (Cont'd.)

2AJ		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
140-2246	Gasket Kit	383-3710
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127

2AJ		
Original Part Number	Part Name	Classic Part Number
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0564	Rebuild Kit-Pump	380-7576
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365

2AJ		
Original Part Number	Part Name	Classic Part Number
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

2TM		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229

2TM		
Original Part Number	Part Name	Classic Part Number
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
3N-3786	Rod-Thrt Cont	397-5051
3N-5869	Support-Elbow	375-9973
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236

2TM		
Original Part Number	Part Name	Classic Part Number
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-8768	Kit-Gasket (Scl)	393-1024

Sales Model 3306B (Cont'd.)

2TM		
Original Part Number	Part Name	Classic Part Number
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889

2TM		
Original Part Number	Part Name	Classic Part Number
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
9N-5769	Cover-Housing	325-6050

2TM		
Original Part Number	Part Name	Classic Part Number
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9930	Mount As	295-6437
9X-6560	Gasket Kit	382-5073
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
232-3233	Bearing-Main	376-9085
234-8015	Kit-Gasket-Sch	437-8674
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351

Sales Model 3306B (Cont'd.)

2TM		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988

2TM		
Original Part Number	Part Name	Classic Part Number
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349

2TM		
Original Part Number	Part Name	Classic Part Number
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

3RG		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203

3RG		
Original Part Number	Part Name	Classic Part Number
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3786	Rod-Thrt Cont	397-5051
4N-4520	Guide	388-6600
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
5P-8768	Kit-Gasket (Scl)	393-1024
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6V-2983	Gasket Kt	437-3213
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951

3RG		
Original Part Number	Part Name	Classic Part Number
7N-5910	Impeller-Pump	314-8686
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

Sales Model 3306B (Cont'd.)

3RG		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042

3RG		
Original Part Number	Part Name	Classic Part Number
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

3RG		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-8014	Kit-Gasket-Sch	437-8662
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

5GZ		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221

5GZ		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

5GZ		
Original Part Number	Part Name	Classic Part Number
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-5869	Support-Elbow	375-9973
4B-7270	Cone-Bearing	399-4439

Sales Model 3306B (Cont'd.)

5GZ		
Original Part Number	Part Name	Classic Part Number
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4W-0452	Seal As -Cshaft	325-6191
4W-0456	Muffler As-Eject	360-7879
4W-2541	Shaft-Gov Cont	399-8580
4W-5363	Core Gp-O Clr	380-7531
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5F-8651	Bearing-Ball	420-3223
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5N-1932	Shaft-Clutch	425-0216
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247

5GZ		
Original Part Number	Part Name	Classic Part Number
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041

5GZ		
Original Part Number	Part Name	Classic Part Number
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438

Sales Model 3306B (Cont'd.)

5GZ		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125

5GZ		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574

5GZ		
Original Part Number	Part Name	Classic Part Number
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

5JC		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

5JC		
Original Part Number	Part Name	Classic Part Number
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-4238	Mount-Flexible	385-7222
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850

5JC		
Original Part Number	Part Name	Classic Part Number
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3786	Rod-Thrt Cont	397-5051
3N-5869	Support-Elbow	375-9973
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236

Sales Model 3306B (Cont'd.)

5JC		
Original Part Number	Part Name	Classic Part Number
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991

5JC		
Original Part Number	Part Name	Classic Part Number
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

5JC		
Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193

Sales Model 3306B (Cont'd.)

5JC		
Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

5JC		
Original Part Number	Part Name	Classic Part Number
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259

5JC		
Original Part Number	Part Name	Classic Part Number
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-8014	Kit-Gasket-Sch	437-8662
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

5KD		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357

5KD		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3L-1425	Bearing-Ball	311-9356
3N-4892	Lever-Gov Cont	439-4542
3N-5869	Support-Elbow	375-9973
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984

5KD		
Original Part Number	Part Name	Classic Part Number
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-9989	Gear As-Idler	302-2677
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

Sales Model 3306B (Cont'd.)

5KD		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200
7C-2880	Bell As-Suction	380-1520
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-5928	Pump Gp-F Inj -B	432-8277

5KD		
Original Part Number	Part Name	Classic Part Number
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033

5KD		
Original Part Number	Part Name	Classic Part Number
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8T-1622	Gasket Kit - Sch	436-8388
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9X-6560	Gasket Kit	382-5073
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

Sales Model 3306B (Cont'd.)

5KD		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365

5KD		
Original Part Number	Part Name	Classic Part Number
172-7771	Pump Gp-Water -B	419-4646
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356

5KD		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

63Z		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356

63Z		
Original Part Number	Part Name	Classic Part Number
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191

63Z		
Original Part Number	Part Name	Classic Part Number
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9989	Gear As-Idler	302-2677
5L-7632	Support-Elbow	433-9854
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5P-9568	Gasket Kit	393-3625
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200

Sales Model 3306B (Cont'd.)

63Z		
Original Part Number	Part Name	Classic Part Number
7C-2880	Bell As-Suction	380-1520
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

63Z		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1622	Gasket Kit - Sch	436-8388
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9X-6560	Gasket Kit	382-5073
9Y-1798	Seal-Water	379-0165

63Z		
Original Part Number	Part Name	Classic Part Number
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-6170	Gasket Kit	437-4598
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0560	Rebuild Kit-Pump	363-7458
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646

Sales Model 3306B (Cont'd.)

63Z		
Original Part Number	**Part Name**	**Classic Part Number**
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
232-3233	Bearing-Main	376-9085
234-8011	Kit-Gasket-Sch	437-8664

63Z		
Original Part Number	**Part Name**	**Classic Part Number**
234-8016	Kit-Gasket-Sch	393-0919
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988

63Z		
Original Part Number	**Part Name**	**Classic Part Number**
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

64Z		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036

64Z		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2L-6744	Plunger	426-0030
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-3767	Tube-Disposal	377-5850
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055

64Z		
Original Part Number	**Part Name**	**Classic Part Number**
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9094	Adapter-Exhaust	299-2534
2W-9978	Core As-Oclr	279-4983
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-5869	Support-Elbow	375-9973
3S-5017	Elbow-Exhaust	369-9498
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-4782	Pulley	325-6176
4N-4942	Rod-Eye	421-8919
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270

Sales Model 3306B (Cont'd.)

64Z		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-6548	Muffler As	360-7878
4P-6589	Pipe As	382-6898
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8472	Hood As-Preclnr	296-1355
4W-0452	Seal As -Cshaft	325-6191
4W-0456	Muffler As-Eject	360-7879
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-2541	Shaft-Gov Cont	399-8580
4W-5363	Core Gp-O Clr	380-7531
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534

64Z		
Original Part Number	Part Name	Classic Part Number
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
4W-9989	Gear As-Idler	302-2677
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9656	Cone-Bearing	399-4448
5N-1932	Shaft-Clutch	425-0216
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5P-9568	Gasket Kit	393-3625
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381

64Z		
Original Part Number	Part Name	Classic Part Number
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-2983	Gasket Kt	437-3213
6V-4785	Gasket Kit - Fs	388-0661
6V-5976	Kit-Gasket (Rs)	393-5200
7C-2880	Bell As-Suction	380-1520
7C-3729	Pulley	376-9066
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7C-6628	Pulley-Alt	396-9894
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-5645	Tube As-Outlet	378-3984
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497

Sales Model 3306B (Cont'd.)

64Z		
Original Part Number	Part Name	Classic Part Number
7N-8022	Gasket-Cyl Head	378-3985
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5687	Hub-Cshft	314-8684
7W-5692	Pulley-Cshaft	386-3041
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196

64Z		
Original Part Number	Part Name	Classic Part Number
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586

64Z		
Original Part Number	Part Name	Classic Part Number
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8T-1622	Gasket Kit - Sch	436-8388
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-9328	Muffler	395-1308
9W-9930	Mount As	295-6437
9X-6560	Gasket Kit	382-5073
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
101-8740	Muffler As	360-7878
104-3014	Gasket Kit	388-0656
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
128-3132	Gasket Kit	437-4566
130-1521	Gasket Kit - Sch	393-1030
131-3815	Seal Gp-Basic	325-6193
134-3038	Gasket Kit	437-3228
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
141-7277	Kit-Gasket-Fs	437-4610

Sales Model 3306B (Cont'd.)

64Z		
Original Part Number	Part Name	Classic Part Number
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-6170	Gasket Kit	437-4598
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0560	Rebuild Kit-Pump	363-7458
170-0564	Rebuild Kit-Pump	380-7576

64Z		
Original Part Number	Part Name	Classic Part Number
170-0566	Kit-Rebuild-Pump	377-5835
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7772	Pump Gp-Water -B	438-2009
187-0605	Gasket Kit - Cl	382-5055
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259

64Z		
Original Part Number	Part Name	Classic Part Number
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
234-7988	Kit-Gasket-Sch	387-2925
234-8002	Kit-Gasket-Sch	386-3817
234-8011	Kit-Gasket-Sch	437-8664
234-8014	Kit-Gasket-Sch	437-8662
234-8015	Kit-Gasket-Sch	437-8674
234-8016	Kit-Gasket-Sch	393-0919
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
255-6863	Gasket	450-5024
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
360-7863	Muffler-Cla	360-7878
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

7JB		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981

7JB		
Original Part Number	Part Name	Classic Part Number
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222

7JB		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197

Sales Model 3306B (Cont'd.)

7JB		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3L-1425	Bearing-Ball	311-9356
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-5869	Support-Elbow	375-9973
4B-7270	Cone-Bearing	399-4439
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691

7JB		
Original Part Number	Part Name	Classic Part Number
4S-8472	Hood As-Preclnr	296-1355
4W-0452	Seal As -Cshaft	325-6191
4W-0456	Muffler As-Eject	360-7879
4W-2446	Damper As	279-4990
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9989	Gear As-Idler	302-2677
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-9656	Cone-Bearing	399-4448
5N-1932	Shaft-Clutch	425-0216
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5P-9568	Gasket Kit	393-3625
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-4716	Gasket-Exhaust	398-2951

7JB		
Original Part Number	Part Name	Classic Part Number
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-2983	Gasket Kt	437-3213
7C-3729	Pulley	376-9066
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5687	Hub-Cshft	314-8684
7W-5692	Pulley-Cshaft	386-3041
7W-5696	Hub-Cshft	424-5887
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187

Sales Model 3306B (Cont'd.)

7JB		
Original Part Number	Part Name	Classic Part Number
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-8867	Pulley	434-1409
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

7JB		
Original Part Number	Part Name	Classic Part Number
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-9328	Muffler	395-1308
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
134-3038	Gasket Kit	437-3228
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046

7JB		
Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-7988	Kit-Gasket-Sch	387-2925
234-8014	Kit-Gasket-Sch	437-8662
234-8015	Kit-Gasket-Sch	437-8674
255-6863	Gasket	450-5024
270-4353	Kit-Liner-Cla	270-4356

Sales Model 3306B (Cont'd.)

7JB		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988

7JB		
Original Part Number	**Part Name**	**Classic Part Number**
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005

7JB		
Original Part Number	**Part Name**	**Classic Part Number**
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

84Z		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214

84Z		
Original Part Number	**Part Name**	**Classic Part Number**
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3B-8845	Bearing-Inner	417-4509
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
4L-8473	Plate-Wear	419-0883
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501

84Z		
Original Part Number	**Part Name**	**Classic Part Number**
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1647	Arm Gp-V Rocker	433-0451
6I-1650	Arm Gp-V Rocker	433-0450
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544

Sales Model 3306B (Cont'd.)

84Z		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6V-2983	Gasket Kt	437-3213
6V-4785	Gasket Kit - Fs	388-0661
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

84Z		
Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125

84Z		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0560	Rebuild Kit-Pump	363-7458
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
234-8014	Kit-Gasket-Sch	437-8662
255-6863	Gasket	450-5024
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model 3306B (Cont'd.)

85Z		
Original Part Number	Part Name	Classic Part Number
1L-7205	Bearing-Ball	416-2167
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5910	Tappet As-Guide&	383-1569
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

85Z		
Original Part Number	Part Name	Classic Part Number
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7455	Gear As	396-9957
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3E-6772	Seal-Water	382-8017
3F-3049	Cone-Roller Brg	418-9600
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-5869	Support-Elbow	375-9973
3P-2582	Bearing-Spl Ball	417-9478
4B-7270	Cone-Bearing	399-4439
4F-2041	Cup-Roller Brg	418-9609
4L-8473	Plate-Wear	419-0883
4M-5858	Bearing-Spl Ball	417-4495
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722

85Z		
Original Part Number	Part Name	Classic Part Number
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4679	Pulley-Fan	394-9837
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-7693	Crankshaft As	269-8763
4P-2383	Adapter-Inlet	438-1812
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355
4W-0452	Seal As -Cshaft	325-6191

Sales Model 3306B (Cont'd.)

85Z		
Original Part Number	Part Name	Classic Part Number
4W-0456	Muffler As-Eject	360-7879
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-5044	Race-Brg Outer	417-9479
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5P-9568	Gasket Kit	393-3625
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

85Z		
Original Part Number	Part Name	Classic Part Number
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1453	Crankshaft As	368-5916
6I-1647	Arm Gp-V Rocker	433-0451
6I-1650	Arm Gp-V Rocker	433-0450
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-9808	Bearing-Ball	417-9484
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-1931	Plunger	379-0171
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-2983	Gasket Kt	437-3213
6V-3831	Seal-O-Ring	436-2657
6V-4785	Gasket Kit - Fs	388-0661
6Y-3484	Bearing-Spl Ball	416-2166

85Z		
Original Part Number	Part Name	Classic Part Number
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7T-2036	Cap As-Fuel	361-1721

Sales Model 3306B (Cont'd.)

85Z		
Original Part Number	Part Name	Classic Part Number
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5692	Pulley-Cshaft	386-3041
7W-5733	Gasket	421-7333
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1726	Rod As-Conn	379-8866
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

85Z		
Original Part Number	Part Name	Classic Part Number
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8258	Bearing-Sleeve	452-1077
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6147	Body As	369-9499
9S-7148	Cap As-Rain	378-3994

85Z		
Original Part Number	Part Name	Classic Part Number
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9S-9328	Muffler	395-1308
9W-9930	Mount As	295-6437
9W-9931	Mount As.	360-2354
9X-6560	Gasket Kit	382-5073
9Y-1798	Seal-Water	379-0165
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-7860	Valve-Inlet	270-4360
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-3014	Gasket Kit	388-0656
106-7798	Bearing-Ball	417-9494
106-7799	Bearing-Ball	396-9947
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
111-8015	Gasket As-Head	279-4977
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698

Sales Model 3306B (Cont'd.)

85Z		
Original Part Number	Part Name	Classic Part Number
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
145-8503	Shaft As-Idler	426-0035
148-7455	Valve - Exhaust	270-4361
150-4637	Pan-Oil	377-5843
155-1379	Gasket Kit - Sch	386-3815
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
166-9142	Gasket	420-8546

85Z		
Original Part Number	Part Name	Classic Part Number
167-8123	Damper As	299-2006
167-8126	Damper As	382-8019
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0560	Rebuild Kit-Pump	363-7458
170-0566	Kit-Rebuild-Pump	377-5835
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
187-0605	Gasket Kit - Cl	382-5055
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701

85Z		
Original Part Number	Part Name	Classic Part Number
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
202-3572	Shaft As-Drive	426-0037
204-4458	Gasket Kit - Acl	437-8151
204-4462	Gasket Kit - Sch	437-2005
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3233	Bearing-Main	376-9085
234-8011	Kit-Gasket-Sch	437-8664
234-8014	Kit-Gasket-Sch	437-8662
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
321-5746	Bearing-Main	419-6367
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653
430-7619	Adapter-Cla	438-1812

8JJ		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572

8JJ		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

8JJ		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006

Sales Model 3306B (Cont'd.)

8JJ		
Original Part Number	Part Name	Classic Part Number
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
3N-3786	Rod-Thrt Cont	397-5051
3N-5869	Support-Elbow	375-9973
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

8JJ		
Original Part Number	Part Name	Classic Part Number
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487

8JJ		
Original Part Number	Part Name	Classic Part Number
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-3955	Bearing-Ball	417-9485
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210

Sales Model 3306B (Cont'd.)

8JJ		
Original Part Number	Part Name	Classic Part Number
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415

8JJ		
Original Part Number	Part Name	Classic Part Number
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
141-7277	Kit-Gasket-Fs	437-4610
147-6170	Gasket Kit	437-4598
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

8JJ		
Original Part Number	Part Name	Classic Part Number
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0564	Rebuild Kit-Pump	380-7576
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

8KR		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

8KR		
Original Part Number	Part Name	Classic Part Number
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-6245	Shaft As-Pump	325-6197

8KR		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-7458	Crankshaft As	242-3439
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4W-0452	Seal As -Cshaft	325-6191

Sales Model 3306B (Cont'd.)

8KR		
Original Part Number	Part Name	Classic Part Number
4W-6869	Spacer-Fuel Pump	417-4534
5P-8768	Kit-Gasket (Scl)	393-1024
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-7166	Race-Brg Thrust	417-4531
7N-8018	Seal-Water	418-1964
7N-9805	Pin-Piston	295-6438

8KR		
Original Part Number	Part Name	Classic Part Number
7S-3161	Lifter-Valve	279-4996
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

8KR		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0493	Shaft As-Pump	325-6198
8S-6511	Bearing-Sleeve	380-7372
9Y-1798	Seal-Water	379-0165
111-8015	Gasket As-Head	279-4977
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

9DS		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173

9DS		
Original Part Number	Part Name	Classic Part Number
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

9DS		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3L-1425	Bearing-Ball	311-9356
3N-3786	Rod-Thrt Cont	397-5051
3N-5869	Support-Elbow	375-9973

Sales Model 3306B (Cont'd.)

9DS		
Original Part Number	Part Name	Classic Part Number
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
5B-9169	Plug-Drain	419-4736
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437

9DS		
Original Part Number	Part Name	Classic Part Number
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-5003	Cap As-Rain	379-0184
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932

9DS		
Original Part Number	Part Name	Classic Part Number
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438

Sales Model 3306B (Cont'd.)

9DS		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-3014	Gasket Kit	388-0656
111-8015	Gasket As-Head	279-4977
130-1521	Gasket Kit - Sch	393-1030
131-3815	Seal Gp-Basic	325-6193
140-2246	Gasket Kit	383-3710
141-7277	Kit-Gasket-Fs	437-4610
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361

9DS		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0564	Rebuild Kit-Pump	380-7576
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

9DS		
Original Part Number	Part Name	Classic Part Number
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

9NR		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

9NR		
Original Part Number	Part Name	Classic Part Number
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357

9NR		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3E-6772	Seal-Water	382-8017

Sales Model 3306B (Cont'd.)

9NR		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-5869	Support-Elbow	375-9973
4L-8473	Plate-Wear	419-0883
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4W-0452	Seal As -Cshaft	325-6191
4W-0456	Muffler As-Eject	360-7879
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555

9NR		
Original Part Number	Part Name	Classic Part Number
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1647	Arm Gp-V Rocker	433-0451
6I-1650	Arm Gp-V Rocker	433-0450
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488

9NR		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196

Sales Model 3306B (Cont'd.)

9NR		
Original Part Number	Part Name	Classic Part Number
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
9L-5908	Gasket	433-8196

9NR		
Original Part Number	Part Name	Classic Part Number
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-6147	Body As	369-9499
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
111-8015	Gasket As-Head	279-4977
130-1521	Gasket Kit - Sch	393-1030
131-3815	Seal Gp-Basic	325-6193
134-3068	Kit-Gasket(F)	393-3636
140-2246	Gasket Kit	383-3710
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-6170	Gasket Kit	437-4598
148-7455	Valve - Exhaust	270-4361
155-1378	Gasket Kit - Sch	437-8152
155-1379	Gasket Kit - Sch	386-3815
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

9NR		
Original Part Number	Part Name	Classic Part Number
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0564	Rebuild Kit-Pump	380-7576
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
232-3233	Bearing-Main	376-9085
255-6863	Gasket	450-5024
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
290-2060	Kit-Gasket-Sch	438-0149
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

9SL		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978

Sales Model 3306B (Cont'd.)

9SL		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
4L-8473	Plate-Wear	419-0883

9SL		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
5B-9169	Plug-Drain	419-4736
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-5910	Impeller-Pump	314-8686

9SL		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

Sales Model 3306B (Cont'd.)

9SL		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361

9SL		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

9SL		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
255-6863	Gasket	450-5024
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

BME		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

BME		
Original Part Number	Part Name	Classic Part Number
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892

BME		
Original Part Number	Part Name	Classic Part Number
2W-5240	Pipe-Pump Outlet	376-9055
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3L-1425	Bearing-Ball	311-9356
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988

Sales Model 3306B (Cont'd.)

BME		
Original Part Number	Part Name	Classic Part Number
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-9989	Gear As-Idler	302-2677
5P-8768	Kit-Gasket (Scl)	393-1024
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-7166	Race-Brg Thrust	417-4531

BME		
Original Part Number	Part Name	Classic Part Number
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-9789	Bearing-Ball	374-8342
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377

BME		
Original Part Number	Part Name	Classic Part Number
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
111-8015	Gasket As-Head	279-4977
134-4200	Manifold-Exhaust	443-2060
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

Sales Model 3306B (Cont'd.)

BME		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484

BME		
Original Part Number	**Part Name**	**Classic Part Number**
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357

BME		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005

LSA		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357

LSA		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3L-1425	Bearing-Ball	311-9356
3N-4892	Lever-Gov Cont	439-4542
3N-5869	Support-Elbow	375-9973
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984

LSA		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475

Sales Model 3306B (Cont'd.)

LSA		
Original Part Number	Part Name	Classic Part Number
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-3486	Manifold-Exhaust	261-0899
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-5698	Pulley-Cshaft	295-5679
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

LSA		
Original Part Number	Part Name	Classic Part Number
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891

LSA		
Original Part Number	Part Name	Classic Part Number
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

Sales Model 3306C

2AZ		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087

2AZ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453

2AZ		
Original Part Number	Part Name	Classic Part Number
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158

Sales Model 3306C (Cont'd.)

2AZ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3N-4892	Lever-Gov Cont	439-4542
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988

2AZ		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9384	Line As-Fuel Inj	279-4989
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
7C-2880	Bell As-Suction	380-1520
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351

2AZ		
Original Part Number	**Part Name**	**Classic Part Number**
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9N-5769	Cover-Housing	325-6050

Sales Model 3306C (Cont'd.)

2AZ		
Original Part Number	Part Name	Classic Part Number
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
142-0228	Gasket Kit - Sch	393-1035
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

2AZ		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574

2AZ		
Original Part Number	Part Name	Classic Part Number
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8256	Kit-Gasket (Sch)	447-8653

3KS		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354

3KS		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3N-4892	Lever-Gov Cont	439-4542
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009

3KS		
Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As -Cshaft	325-6191
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544

Sales Model 3306C (Cont'd.)

3KS		
Original Part Number	**Part Name**	**Classic Part Number**
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

3KS		
Original Part Number	**Part Name**	**Classic Part Number**
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
148-7455	Valve - Exhaust	270-4361

3KS		
Original Part Number	**Part Name**	**Classic Part Number**
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
190-0649	Tightener-Belt	434-1407
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

7RJ		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

7RJ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

7RJ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2P-0220	Gasket-Pump	398-2927

Sales Model 3306C (Cont'd.)

7RJ		
Original Part Number	Part Name	Classic Part Number
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9989	Gear As-Idler	302-2677
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

7RJ		
Original Part Number	Part Name	Classic Part Number
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-5976	Kit-Gasket (Rs)	393-5200
7C-2880	Bell As-Suction	380-1520
7C-4297	Seal As-Cshaft	325-6192
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5089	Gasket	394-0890
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0081	Trunnion	393-5196

7RJ		
Original Part Number	Part Name	Classic Part Number
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-6371	Rod-Eye	363-7459
9N-3668	Base As.-Coolant	419-4718

Sales Model 3306C (Cont'd.)

7RJ		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9X-6560	Gasket Kit	382-5073
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351

7RJ		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835

7RJ		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
232-3233	Bearing-Main	376-9085
234-7988	Kit-Gasket-Sch	387-2925
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

9TL		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164

9TL		
Original Part Number	Part Name	Classic Part Number
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008

9TL		
Original Part Number	Part Name	Classic Part Number
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4W-0452	Seal As -Cshaft	325-6191
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9989	Gear As-Idler	302-2677
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9568	Gasket Kit	393-3625
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635

Sales Model 3306C (Cont'd.)

9TL		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200
7C-2880	Bell As-Suction	380-1520
7C-4297	Seal As-Cshaft	325-6192
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-1035	Mount	383-2118
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037

9TL		
Original Part Number	Part Name	Classic Part Number
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-6371	Rod-Eye	363-7459
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050

9TL		
Original Part Number	Part Name	Classic Part Number
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9X-6560	Gasket Kit	382-5073
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
104-3014	Gasket Kit	388-0656
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
140-2246	Gasket Kit	383-3710
142-0226	Kit-Gasket-Fs	393-1034
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-6170	Gasket Kit	437-4598
148-7455	Valve - Exhaust	270-4361
155-1378	Gasket Kit - Sch	437-8152
155-1379	Gasket Kit - Sch	386-3815
164-2138	Gasket Kit - Sch	437-2016
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0560	Rebuild Kit-Pump	363-7458
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

Sales Model 3306C (Cont'd.)

9TL		
Original Part Number	**Part Name**	**Classic Part Number**
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

9TL		
Original Part Number	**Part Name**	**Classic Part Number**
232-3233	Bearing-Main	376-9085
234-7988	Kit-Gasket-Sch	387-2925
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438

9TL		
Original Part Number	**Part Name**	**Classic Part Number**
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model 3406

172		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-5910	Tappet As-Guide&	383-1569
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-1106	Shaft As-Rocker	377-5837
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333

172		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-7154	Rotocoil As	380-7556
7C-0307	Gasket	399-8571
7C-6697	Shaft - Idler	425-9370
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8N-1726	Rod As-Conn	379-8866
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563

172		
Original Part Number	**Part Name**	**Classic Part Number**
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665

Sales Model 3406 (Cont'd.)

172		
Original Part Number	**Part Name**	**Classic Part Number**
328-5574	Bearing-Rod	419-7266

172		
Original Part Number	**Part Name**	**Classic Part Number**
430-7619	Adapter-Cla	438-1812

4FD		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2W-5540	Core As-Radiator	363-7452
2W-7455	Gear As	396-9957
3E-4326	Gasket Kit	437-8111
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3786	Rod-Thrt Cont	397-5051
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891

4FD		
Original Part Number	**Part Name**	**Classic Part Number**
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5N-1841	Flange-Pipe	426-0029
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-3353	Rod End-Special	416-2134

4FD		
Original Part Number	**Part Name**	**Classic Part Number**
6L-6490	Sleeve-O-Ring	398-8346
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-1726	Rod As-Conn	379-8866

Sales Model 3406 (Cont'd.)

4FD		
Original Part Number	**Part Name**	**Classic Part Number**
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-6371	Rod-Eye	363-7459
9S-7148	Cap As-Rain	378-3994
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-8644	Kit-Gasket (Ocl)	436-8416
108-5603	Screw-Adj Arm	379-0166

4FD		
Original Part Number	**Part Name**	**Classic Part Number**
108-7930	Bearing As	377-7463
109-6928	Gasket Kit	436-8413
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572
117-0456	Crankshaft As	394-2587
124-3237	Precleaner As	432-4220
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554

4FD		
Original Part Number	**Part Name**	**Classic Part Number**
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-8780	Kit-Gasket (Ocl)	437-2013
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

5HZ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059

5HZ		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2W-5540	Core As-Radiator	363-7452
2W-7455	Gear As	396-9957
3E-4326	Gasket Kit	437-8111
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356

5HZ		
Original Part Number	**Part Name**	**Classic Part Number**
3N-1968	Mount-Shock	397-5046
3N-3786	Rod-Thrt Cont	397-5051
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3092	Spider As-Fan	363-7465

Sales Model 3406 (Cont'd.)

5HZ		
Original Part Number	Part Name	Classic Part Number
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5N-1841	Flange-Pipe	426-0029
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-3353	Rod End-Special	416-2134
6L-6490	Sleeve-O-Ring	398-8346
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171

5HZ		
Original Part Number	Part Name	Classic Part Number
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077

5HZ		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
9L-6371	Rod-Eye	363-7459
9S-7148	Cap As-Rain	378-3994
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-8644	Kit-Gasket (Ocl)	436-8416
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
109-6928	Gasket Kit	436-8413
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572
117-0456	Crankshaft As	394-2587
124-3237	Precleaner As	432-4220
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
144-0502	Ring Kit-Piston	395-1312

Sales Model 3406 (Cont'd.)

5HZ		
Original Part Number	Part Name	Classic Part Number
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019

5HZ		
Original Part Number	Part Name	Classic Part Number
171-8780	Kit-Gasket (Ocl)	437-2013
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034

5HZ		
Original Part Number	Part Name	Classic Part Number
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

6H6		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320

6H6		
Original Part Number	Part Name	Classic Part Number
4W-5701	Bearing-Main	419-6333
4W-5998	Rod-Valve Push	379-0168
6I-1453	Crankshaft As	368-5916
6I-2981	Plate-Block	374-7495
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7W-2164	Core As-Oclr	299-1996
7W-5733	Gasket	421-7333
8N-2104	Bell As-Suction	380-1521
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
101-1816	Bridge As-Intake	374-4689

6H6		
Original Part Number	Part Name	Classic Part Number
101-1818	Bridge As-Exh	374-4691
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665

Sales Model 3406 (Cont'd.)

75Z		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2W-3391	Body As-F Inj V	383-3687
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
4B-7255	Cone-Bearing	386-4951
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716

75Z		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502

75Z		
Original Part Number	**Part Name**	**Classic Part Number**
5P-8053	Kit-Gasket (Sch)	415-1901
5P-8054	Gasket Kit	437-8109
5P-9514	Bearing-Ball	417-9467
5P-9538	Bearing-Roller	421-8183
5S-4557	Bearing	311-9360
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0425	Coupling-Exhaust	394-9836
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7L-7508	Bearing-Ball	420-6536

Sales Model 3406 (Cont'd.)

75Z		
Original Part Number	**Part Name**	**Classic Part Number**
7M-7219	Bearing-Thrust	384-4816
7N-1220	Plunger As-Pump	419-4743
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7N-8371	Line As-Fuel Inj	373-1901
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-1184	Elbow-Exhaust	392-4497
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9N-0316	Bracket-Pulley	434-1993

75Z		
Original Part Number	**Part Name**	**Classic Part Number**
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843

75Z		
Original Part Number	**Part Name**	**Classic Part Number**
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-0560	Rebuild Kit-Pump	363-7458
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-6574	Kit-Gasket-Rs	437-2034
233-7083	Kit-Gasket-Fs	387-2919
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

Sales Model 3406 (Cont'd.)

8SB		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2W-3391	Body As-F Inj V	383-3687
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906

8SB		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5998	Rod-Valve Push	379-0168
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5S-4557	Bearing	311-9360
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7M-7219	Bearing-Thrust	384-4816
7N-1220	Plunger As-Pump	419-4743
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-8371	Line As-Fuel Inj	373-1901
7W-0182	Plunger & Bbl As	391-9893
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-3580	Bracket-Mtg	418-1939
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-1726	Rod As-Conn	379-8866

8SB		
Original Part Number	**Part Name**	**Classic Part Number**
8N-2104	Bell As-Suction	380-1521
8N-3666	Repair Kt-Major	377-5842
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019

Sales Model 3406 (Cont'd.)

8SB		
Original Part Number	**Part Name**	**Classic Part Number**
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665

8SB		
Original Part Number	**Part Name**	**Classic Part Number**
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387

8SB		
Original Part Number	**Part Name**	**Classic Part Number**
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

90U		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-7125	Governor As	383-3672
1S-7056	Bearing-Ball	422-6483
1W-0156	Core As-Oclr	416-5525
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-2719	Pipe-Oil Filler	363-7454
2P-8986	Cup-Rlr Bearing	415-1912
2W-3391	Body As-F Inj V	383-3687
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051

90U		
Original Part Number	**Part Name**	**Classic Part Number**
3N-4892	Lever-Gov Cont	439-4542
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-2954	Sleeve-Camshaft	299-2059
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710

90U		
Original Part Number	**Part Name**	**Classic Part Number**
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355
4W-0456	Muffler As-Eject	360-7879
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-7382	Core As-Oclr	380-1514
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854

Sales Model 3406 (Cont'd.)

90U		
Original Part Number	Part Name	Classic Part Number
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5P-7807	Bearing-Ball	314-8502
5P-8053	Kit-Gasket (Sch)	415-1901
5P-8054	Gasket Kit	437-8109
5P-8366	Gasket Kit - Sch	387-2911
5P-9514	Bearing-Ball	417-9467
5P-9538	Bearing-Roller	421-8183
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0425	Coupling-Exhaust	394-9836
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-5482	Plate-Friction	376-3637
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571

90U		
Original Part Number	Part Name	Classic Part Number
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1220	Plunger As-Pump	419-4743
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-8371	Line As-Fuel Inj	373-1901
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7T-2036	Cap As-Fuel	361-1721
7W-0140	Gear-Drive	399-8546
7W-0182	Plunger & Bbl As	391-9893
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333

90U		
Original Part Number	Part Name	Classic Part Number
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-1184	Elbow-Exhaust	392-4497
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9L-5839	Coupling-Exhaust	374-7480
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-5529	Body-F Inj Valve	378-3993
9S-7148	Cap As-Rain	378-3994
9S-8597	Spring	399-8561
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552

Sales Model 3406 (Cont'd.)

90U		
Original Part Number	Part Name	Classic Part Number
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455

90U		
Original Part Number	Part Name	Classic Part Number
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-0560	Rebuild Kit-Pump	363-7458
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011

90U		
Original Part Number	Part Name	Classic Part Number
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-6574	Kit-Gasket-Rs	437-2034
233-7083	Kit-Gasket-Fs	387-2919
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
256-9653	Flywheel As.	425-3444
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

91U		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163

91U		
Original Part Number	Part Name	Classic Part Number
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532

91U		
Original Part Number	Part Name	Classic Part Number
2N-5842	Screw-Bridge Adj	418-1934
2W-3391	Body As-F Inj V	383-3687
2W-7455	Gear As	396-9957
3B-8845	Bearing-Inner	417-4509
3E-6772	Seal-Water	382-8017
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542

Sales Model 3406 (Cont'd.)

91U		
Original Part Number	**Part Name**	**Classic Part Number**
4B-7255	Cone-Bearing	386-4951
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223

91U		
Original Part Number	**Part Name**	**Classic Part Number**
5L-5772	Race & Roller As	394-9200
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9656	Cone-Bearing	399-4448
5P-7807	Bearing-Ball	314-8502
5P-8053	Kit-Gasket (Sch)	415-1901
5P-8054	Gasket Kit	437-8109
5P-9514	Bearing-Ball	417-9467
5P-9538	Bearing-Roller	421-8183
5S-4557	Bearing	311-9360
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522

91U		
Original Part Number	**Part Name**	**Classic Part Number**
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-1220	Plunger As-Pump	419-4743
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7N-8371	Line As-Fuel Inj	373-1901
7S-4411	Cap As-Rain	373-1912
7W-0182	Plunger & Bbl As	391-9893
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
9H-2256	Pump Gp-F Prm	311-9443
9K-1171	Cup-Rlr Bearing	430-3339
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-5529	Body-F Inj Valve	378-3993

Sales Model 3406 (Cont'd.)

91U		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814

91U		
Original Part Number	**Part Name**	**Classic Part Number**
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700

91U		
Original Part Number	**Part Name**	**Classic Part Number**
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-6574	Kit-Gasket-Rs	437-2034
233-7083	Kit-Gasket-Fs	387-2919
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

92U		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-7125	Governor As	383-3672
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059

92U		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-2519	Tube As-Inlet	325-6230
2P-2719	Pipe-Oil Filler	363-7454

92U		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-3391	Body As-F Inj V	383-3687
2W-7455	Gear As	396-9957
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974

Sales Model 3406 (Cont'd.)

92U		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0362	Cover As-Rgltr	419-4722
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-7693	Crankshaft As	269-8763
4P-2383	Adapter-Inlet	438-1812
4P-3546	Valve As-Relief	325-6236
4P-7731	Core Gp-O Clr	385-7228
4W-0452	Seal As -Cshaft	325-6191
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333

92U		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5F-8651	Bearing-Ball	420-3223
5L-7632	Support-Elbow	433-9854
5P-7807	Bearing-Ball	314-8502
5P-8053	Kit-Gasket (Sch)	415-1901
5P-8054	Gasket Kit	437-8109
5P-8366	Gasket Kit - Sch	387-2911
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1032	Line As-Fuel Inj	390-0931
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922
6I-1038	Line As-Fuel Inj	390-0923
6I-1453	Crankshaft As	368-5916
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-8968	Coupling-Exhaust	311-9381
6N-0425	Coupling-Exhaust	394-9836
6N-1931	Plunger	379-0171
6N-5482	Plate-Friction	376-3637

92U		
Original Part Number	**Part Name**	**Classic Part Number**
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7263	Gasket-Cyl Head	380-7386
6N-7653	Gage As-O Level	428-7206
6N-9133	Gasket-Plate	398-2959
6V-0233	Kit-Gasket-T	437-4586
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-9221	Gasket Kit	391-1092
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1183	Plunger As-Fuel	419-4742
7N-1220	Plunger As-Pump	419-4743
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781

Sales Model 3406 (Cont'd.)

92U		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7435	Kit-Major Repair	374-4724
7N-8018	Seal-Water	418-1964
7N-8371	Line As-Fuel Inj	373-1901
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-5003	Cap As-Rain	379-0184
7W-0182	Plunger & Bbl As	391-9893
7W-1713	Core Gp-O Clr	438-2010
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-3580	Bracket-Mtg	418-1939
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1184	Elbow-Exhaust	392-4497
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1726	Rod As-Conn	379-8866
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585

92U		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-2389	Body-Fuel Valve	377-5831
8S-3653	Bonnet-Valve	374-4728
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5836	Coupling-Exhaust	385-7212
9L-5839	Coupling-Exhaust	374-7480
9L-6371	Rod-Eye	363-7459
9M-5477	Bearing-Sleeve	374-6517
9N-0316	Bracket-Pulley	434-1993
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5529	Body-F Inj Valve	378-3993
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042

92U		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-1798	Seal-Water	379-0165
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
114-4787	Kit-Gasket (Ocl)	388-0657
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546

Sales Model 3406 (Cont'd.)

92U		
Original Part Number	Part Name	Classic Part Number
167-8123	Damper As	299-2006
167-8126	Damper As	382-8019
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
177-9024	Adapter-Damper	299-1956
190-9861	Kit-Gskt-Acl	386-3812

92U		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3233	Bearing-Main	376-9085
232-6574	Kit-Gasket-Rs	437-2034
233-7083	Kit-Gasket-Fs	387-2919
243-6718	Kit-Brg(Main)	469-1690
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
253-1752	Plate-Thrust	379-0170

92U		
Original Part Number	Part Name	Classic Part Number
256-9653	Flywheel As.	425-3444
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
430-7619	Adapter-Cla	438-1812

Sales Model 3406B

2EK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-4325	Kit-Gasket (F)	437-8112
3E-4326	Gasket Kit	437-8111
3E-6772	Seal-Water	382-8017
3R-8530	Boss	425-3454
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722

2EK		
Original Part Number	Part Name	Classic Part Number
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320

2EK		
Original Part Number	Part Name	Classic Part Number
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571

Sales Model 3406B (Cont'd.)

2EK		
Original Part Number	Part Name	Classic Part Number
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7W-0140	Gear-Drive	399-8546
7W-1713	Core Gp-O Clr	438-2010
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7X-7954	Gasket Kit	393-5204
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842

2EK		
Original Part Number	Part Name	Classic Part Number
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-2937	Kit-Gasket (Ocl)	436-8417
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704

2EK		
Original Part Number	Part Name	Classic Part Number
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
231-0649	Kit-Gasket (Sch)	437-8673
232-2922	Kit-Gasket-Rs	437-8671

Sales Model 3406B (Cont'd.)

2EK		
Original Part Number	Part Name	Classic Part Number
232-6574	Kit-Gasket-Rs	437-2034
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170

2EK		
Original Part Number	Part Name	Classic Part Number
256-9653	Flywheel As.	425-3444
290-2060	Kit-Gasket-Sch	438-0149
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665

2EK		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

2RJ		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-3714	Chamber As	363-7450
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320

2RJ		
Original Part Number	Part Name	Classic Part Number
4W-5701	Bearing-Main	419-6333
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8N-1726	Rod As-Conn	379-8866
8N-2641	Sleeve	325-6210

2RJ		
Original Part Number	Part Name	Classic Part Number
8N-3666	Repair Kt-Major	377-5842
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9N-1545	Race-Thrust	394-9205
9Y-7735	Bearing-Rod	419-4665
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1818	Bridge As-Exh	374-4691
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547

Sales Model 3406B (Cont'd.)

2RJ		
Original Part Number	Part Name	Classic Part Number
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699

2RJ		
Original Part Number	Part Name	Classic Part Number
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
232-3679	Kit-Gasket (Rs)	437-2039
234-1874	Kit-Gasket-Fs	437-8668

2RJ		
Original Part Number	Part Name	Classic Part Number
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812
448-7015	Kit-Ovhl-Cla	386-3812
448-7017	Kit-Ovhl-Cla	379-0171
448-7018	Kit-Gasket-F-Cla	383-1569

2WB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-4087	Gear As-Idler	418-9582
2W-5540	Core As-Radiator	363-7452
2W-7455	Gear As	396-9957
3E-3322	Gasket Kit - F	437-8114
3E-4326	Gasket Kit	437-8111
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031

2WB		
Original Part Number	Part Name	Classic Part Number
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
4B-7255	Cone-Bearing	386-4951
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3714	Chamber As	363-7450
4N-4161	Mount As	374-1448
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4539	Sleeve	314-8720

2WB		
Original Part Number	Part Name	Classic Part Number
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906

Sales Model 3406B (Cont'd.)

2WB		
Original Part Number	Part Name	Classic Part Number
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-2448	Bearing-Ball	399-6064
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9538	Bearing-Roller	421-8183
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0425	Coupling-Exhaust	394-9836
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-9221	Gasket Kit	391-1092
6V-9725	Kit-Gasket (F)	437-3200
6V-9736	Kit-Gasket (F)	437-3202
6Y-7652	Cup-Rlr Brg	399-6067

2WB		
Original Part Number	Part Name	Classic Part Number
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7T-2036	Cap As-Fuel	361-1721
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-1184	Elbow-Exhaust	392-4497
8N-1726	Rod As-Conn	379-8866

2WB		
Original Part Number	Part Name	Classic Part Number
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-7148	Cap As-Rain	378-3994
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-2937	Kit-Gasket (Ocl)	436-8417
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3374	Gear-Camshaft Dr	376-9069
101-8644	Kit-Gasket (Ocl)	436-8416
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215

Sales Model 3406B (Cont'd.)

2WB		
Original Part Number	**Part Name**	**Classic Part Number**
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
114-4787	Kit-Gasket (Ocl)	388-0657
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572
117-0456	Crankshaft As	394-2587
117-7899	Gasket Kit - Sch	436-8409
117-7901	Kit-Gasket (F)	436-8397
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
138-4338	Kit-Gasket-T	393-1032

2WB		
Original Part Number	**Part Name**	**Classic Part Number**
138-6744	Rebuild Kit-Pump	363-7457
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-4229	Gasket Kit - Sch	437-4599
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
163-5636	Kit-Gasket(Ocl)	437-2017
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012

2WB		
Original Part Number	**Part Name**	**Classic Part Number**
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
223-3345	Kit-Gasket-Sch	437-8130
226-2018	Kit-Gasket-Acl	393-0921
232-2922	Kit-Gasket-Rs	437-8671
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
232-6599	Kit-Gasket (Mch)	437-2033
232-6642	Kit-Gasket (Sch)	437-2020
233-9474	Kit-Gasket (Sch)	437-2024
233-9480	Kit-Gasket-Sch	437-2023
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
290-2060	Kit-Gasket-Sch	438-0149
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

3SF		
Original Part Number	**Part Name**	**Classic Part Number**
155-5619	Gasket	382-5054
232-3679	Kit-Gasket (Rs)	437-2039

3ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846

3ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163

3ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354

Sales Model 3406B (Cont'd.)

3ZJ		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-4326	Gasket Kit	437-8111
3E-6772	Seal-Water	382-8017
3R-8530	Boss	425-3454
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360

3ZJ		
Original Part Number	Part Name	Classic Part Number
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7W-0140	Gear-Drive	399-8546
7W-1713	Core Gp-O Clr	438-2010
7W-2164	Core As-Oclr	299-1996

3ZJ		
Original Part Number	Part Name	Classic Part Number
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7X-7954	Gasket Kit	393-5204
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9F-3212	Bearing-Ball	384-5953
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-2930	Gasket Kit - F	393-1026
100-2937	Kit-Gasket (Ocl)	436-8417
100-5953	Gasket Kit - F	437-4573
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060

Sales Model 3406B (Cont'd.)

3ZJ		
Original Part Number	Part Name	Classic Part Number
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
112-7993	Gasket Kit	437-3231
113-4610	Gasket Kit	436-8410
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
122-8900	Kit-Gasket(F)	437-3230
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456

3ZJ		
Original Part Number	Part Name	Classic Part Number
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
141-5787	Kit-Gasket(Ocl)	437-4611
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
149-0629	Gasket Kit - Sch	437-4594
150-1914	Manifold-Exh	434-6111
150-1916	Manifold-Exh	395-1322
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699

3ZJ		
Original Part Number	Part Name	Classic Part Number
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
219-3501	Kit - Gasket	437-8129
231-0649	Kit-Gasket (Sch)	437-8673
232-2922	Kit-Gasket-Rs	437-8671
232-3675	Kit-Gasket-Rs	437-8670
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
233-6728	Kit-Gasket-Fs	437-2032
233-9198	Kit-Gasket-Sch	437-2029
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
290-2060	Kit-Gasket-Sch	438-0149
321-5746	Bearing-Main	419-6367
325-2721	Kit-Gasket(T)	393-3662
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

4CK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569

4CK		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-5271	Bearing-Ball	371-4305

4CK		
Original Part Number	Part Name	Classic Part Number
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-4325	Kit-Gasket (F)	437-8112
3E-4326	Gasket Kit	437-8111
3E-6772	Seal-Water	382-8017
3R-8530	Boss	425-3454

Sales Model 3406B (Cont'd.)

4CK		
Original Part Number	Part Name	Classic Part Number
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5P-7807	Bearing-Ball	314-8502
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206

4CK		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7W-0140	Gear-Drive	399-8546
7W-1713	Core Gp-O Clr	438-2010
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7X-7954	Gasket Kit	393-5204
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842

4CK		
Original Part Number	Part Name	Classic Part Number
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-2930	Gasket Kit - F	393-1026
100-2937	Kit-Gasket (Ocl)	436-8417
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
112-7993	Gasket Kit	437-3231
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572

Sales Model 3406B (Cont'd.)

4CK		
Original Part Number	Part Name	Classic Part Number
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
140-9631	Kit-Gasket(F)	437-3217
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-4229	Gasket Kit - Sch	437-4599

4CK		
Original Part Number	Part Name	Classic Part Number
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037

4CK		
Original Part Number	Part Name	Classic Part Number
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
219-3501	Kit - Gasket	437-8129
231-0649	Kit-Gasket (Sch)	437-8673
232-2922	Kit-Gasket-Rs	437-8671
232-3675	Kit-Gasket-Rs	437-8670
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
290-2060	Kit-Gasket-Sch	438-0149
321-5746	Bearing-Main	419-6367
325-2721	Kit-Gasket(T)	393-3662
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

4JK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356

4JK		
Original Part Number	Part Name	Classic Part Number
3N-3786	Rod-Thrt Cont	397-5051
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572

4JK		
Original Part Number	Part Name	Classic Part Number
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323

Sales Model 3406B (Cont'd.)

4JK		
Original Part Number	Part Name	Classic Part Number
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-3955	Bearing-Ball	417-9485
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854

4JK		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7N-8828	Pulley	420-6395
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9N-1545	Race-Thrust	394-9205
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276

4JK		
Original Part Number	Part Name	Classic Part Number
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-1987	Gasket Kit - F	437-3238
138-4338	Kit-Gasket-T	393-1032
138-6744	Rebuild Kit-Pump	363-7457
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
149-0625	Kit-Gasket(F)	437-4595
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700

Sales Model 3406B (Cont'd.)

4JK		
Original Part Number	Part Name	Classic Part Number
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368

4JK		
Original Part Number	Part Name	Classic Part Number
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
223-3343	Kit-Gasket-Acl	437-8131
223-3345	Kit-Gasket-Sch	437-8130
232-2922	Kit-Gasket-Rs	437-8671
233-9473	Kit-Gasket-Sch	437-2025
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690

4JK		
Original Part Number	Part Name	Classic Part Number
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

4MG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-6005	Bearing-Sleeve	417-4521
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-4326	Gasket Kit	437-8111
3E-6772	Seal-Water	382-8017
3R-8530	Boss	425-3454
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177

4MG		
Original Part Number	Part Name	Classic Part Number
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5F-8651	Bearing-Ball	420-3223
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467

4MG		
Original Part Number	Part Name	Classic Part Number
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-9221	Gasket Kit	391-1092
6V-9725	Kit-Gasket (F)	437-3200
6V-9921	Gasket Kit	437-3236
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-7955	Gasket-Cover	382-6899
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222

Sales Model 3406B (Cont'd.)

4MG		
Original Part Number	Part Name	Classic Part Number
7F-2742	Bearing-Ball	422-6488
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-5449	Spool-Press Rlf	434-2450
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7W-0140	Gear-Drive	399-8546
7W-1713	Core Gp-O Clr	438-2010
7W-2059	Gasket-Cyl Hd	380-1548
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7X-2754	Gasket Kit - F	437-3235
7X-7954	Gasket Kit	393-5204
8C-4455	Gasket Kit	436-8392
8C-5704	Gasket Kit - Sch	393-1027
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205

4MG		
Original Part Number	Part Name	Classic Part Number
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-2930	Gasket Kit - F	393-1026
100-2937	Kit-Gasket (Ocl)	436-8417
100-5953	Gasket Kit - F	437-4573
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
114-4787	Kit-Gasket (Ocl)	388-0657
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566

4MG		
Original Part Number	Part Name	Classic Part Number
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-4229	Gasket Kit - Sch	437-4599
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
171-8780	Kit-Gasket (Ocl)	437-2013
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368

Sales Model 3406B (Cont'd.)

4MG		
Original Part Number	Part Name	Classic Part Number
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
226-2018	Kit-Gasket-Acl	393-0921
231-0649	Kit-Gasket (Sch)	437-8673
232-2922	Kit-Gasket-Rs	437-8671
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034

4MG		
Original Part Number	Part Name	Classic Part Number
233-9474	Kit-Gasket (Sch)	437-2024
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
290-2060	Kit-Gasket-Sch	438-0149
321-5746	Bearing-Main	419-6367

4MG		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

4PM		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3786	Rod-Thrt Cont	397-5051
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928

4PM		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854

4PM		
Original Part Number	Part Name	Classic Part Number
5L-7634	Elbow-Turbo Exh	380-1555
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854

Sales Model 3406B (Cont'd.)

4PM		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7S-4411	Cap As-Rain	373-1912
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9N-1545	Race-Thrust	394-9205
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691

4PM		
Original Part Number	Part Name	Classic Part Number
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
109-6928	Gasket Kit	436-8413
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572
117-0456	Crankshaft As	394-2587
117-7899	Gasket Kit - Sch	436-8409
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054

4PM		
Original Part Number	Part Name	Classic Part Number
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-2922	Kit-Gasket-Rs	437-8671
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

4RG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846

4RG		
Original Part Number	Part Name	Classic Part Number
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163

4RG		
Original Part Number	Part Name	Classic Part Number
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934

Sales Model 3406B (Cont'd.)

4RG		
Original Part Number	Part Name	Classic Part Number
2W-7455	Gear As	396-9957
3E-3322	Gasket Kit - F	437-8114
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3786	Rod-Thrt Cont	397-5051
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318

4RG		
Original Part Number	Part Name	Classic Part Number
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7S-5003	Cap As-Rain	379-0184
7T-2036	Cap As-Fuel	361-1721
7W-2164	Core As-Oclr	299-1996

4RG		
Original Part Number	Part Name	Classic Part Number
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9N-1545	Race-Thrust	394-9205
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704

Sales Model 3406B (Cont'd.)

4RG		
Original Part Number	Part Name	Classic Part Number
115-3657	Kit-Gasket-Ocl	437-4572
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
146-4229	Gasket Kit - Sch	437-4599
150-4637	Pan-Oil	377-5843

4RG		
Original Part Number	Part Name	Classic Part Number
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012

4RG		
Original Part Number	Part Name	Classic Part Number
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-6574	Kit-Gasket-Rs	437-2034
233-9474	Kit-Gasket (Sch)	437-2024
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

4T7		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3N-3017	Adapter As	433-2031
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499

4T7		
Original Part Number	Part Name	Classic Part Number
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323

4T7		
Original Part Number	Part Name	Classic Part Number
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5P-7807	Bearing-Ball	314-8502
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206

Sales Model 3406B (Cont'd.)

4T7		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7S-4411	Cap As-Rain	373-1912
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8L-4282	Hub	444-0573
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372

4T7		
Original Part Number	Part Name	Classic Part Number
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547

4T7		
Original Part Number	Part Name	Classic Part Number
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

4TB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158

4TB		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569

4TB		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059

Sales Model 3406B (Cont'd.)

4TB		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-5842	Screw-Bridge Adj	418-1934
2W-3391	Body As-F Inj V	383-3687
2W-7455	Gear As	396-9957
3B-8845	Bearing-Inner	417-4509
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
4B-7255	Cone-Bearing	386-4951
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550

4TB		
Original Part Number	Part Name	Classic Part Number
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-5772	Race & Roller As	394-9200
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9538	Bearing-Roller	421-8183
5S-4557	Bearing	311-9360
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-9221	Gasket Kit	391-1092
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370

4TB		
Original Part Number	Part Name	Classic Part Number
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-1220	Plunger As-Pump	419-4743
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-8371	Line As-Fuel Inj	373-1901
7S-4411	Cap As-Rain	373-1912
7W-0140	Gear-Drive	399-8546
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210

Sales Model 3406B (Cont'd.)

4TB		
Original Part Number	Part Name	Classic Part Number
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9K-1171	Cup-Rlr Bearing	430-3339
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-7148	Cap As-Rain	378-3994
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-2930	Gasket Kit - F	393-1026
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834

4TB		
Original Part Number	Part Name	Classic Part Number
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
117-7899	Gasket Kit - Sch	436-8409
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956

4TB		
Original Part Number	Part Name	Classic Part Number
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
222-7974	Kit - Gasket	437-2044
222-7987	Kit - Gasket	437-2043
222-8662	Kit-Gasket(F)	437-8134
223-3345	Kit-Gasket-Sch	437-8130
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
233-6728	Kit-Gasket-Fs	437-2032
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

5KJ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846

5KJ		
Original Part Number	Part Name	Classic Part Number
1W-5910	Tappet As-Guide&	383-1569
1W-6005	Bearing-Sleeve	417-4521
1W-7238	Shaft As-Pump Dr	379-0164

5KJ		
Original Part Number	Part Name	Classic Part Number
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354

Sales Model 3406B (Cont'd.)

5KJ		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-4326	Gasket Kit	437-8111
3E-6772	Seal-Water	382-8017
3R-8530	Boss	425-3454
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255

5KJ		
Original Part Number	Part Name	Classic Part Number
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5F-8651	Bearing-Ball	420-3223
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-9221	Gasket Kit	391-1092
6V-9725	Kit-Gasket (F)	437-3200
6V-9921	Gasket Kit	437-3236
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-7955	Gasket-Cover	382-6899
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133

5KJ		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-5449	Spool-Press Rlf	434-2450
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7W-0140	Gear-Drive	399-8546
7W-1713	Core Gp-O Clr	438-2010
7W-2059	Gasket-Cyl Hd	380-1548
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7X-2754	Gasket Kit - F	437-3235
7X-7954	Gasket Kit	393-5204
8C-4455	Gasket Kit	436-8392
8C-5704	Gasket Kit - Sch	393-1027
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665

Sales Model 3406B (Cont'd.)

5KJ		
Original Part Number	Part Name	Classic Part Number
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-2930	Gasket Kit - F	393-1026
100-2937	Kit-Gasket (Ocl)	436-8417
100-5953	Gasket Kit - F	437-4573
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
114-4787	Kit-Gasket (Ocl)	388-0657
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704

5KJ		
Original Part Number	Part Name	Classic Part Number
115-3657	Kit-Gasket-Ocl	437-4572
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-4229	Gasket Kit - Sch	437-4599
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
171-8780	Kit-Gasket (Ocl)	437-2013
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516

5KJ		
Original Part Number	Part Name	Classic Part Number
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
226-2018	Kit-Gasket-Acl	393-0921
231-0649	Kit-Gasket (Sch)	437-8673
232-2922	Kit-Gasket-Rs	437-8671
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
233-9474	Kit-Gasket (Sch)	437-2024
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
290-2060	Kit-Gasket-Sch	438-0149
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

5YG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846

5YG		
Original Part Number	Part Name	Classic Part Number
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059

5YG		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934

Sales Model 3406B (Cont'd.)

5YG		
Original Part Number	Part Name	Classic Part Number
2W-7455	Gear As	396-9957
3E-4325	Kit-Gasket (F)	437-8112
3E-4326	Gasket Kit	437-8111
3E-6772	Seal-Water	382-8017
3R-8530	Boss	425-3454
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495

5YG		
Original Part Number	Part Name	Classic Part Number
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7W-0140	Gear-Drive	399-8546
7W-1713	Core Gp-O Clr	438-2010
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333

5YG		
Original Part Number	Part Name	Classic Part Number
7X-7954	Gasket Kit	393-5204
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-7354	Manifold-Exhaust	386-3060
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915

Sales Model 3406B (Cont'd.)

5YG		
Original Part Number	Part Name	Classic Part Number
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035

5YG		
Original Part Number	Part Name	Classic Part Number
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012

5YG		
Original Part Number	Part Name	Classic Part Number
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-6574	Kit-Gasket-Rs	437-2034
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
290-2060	Kit-Gasket-Sch	438-0149
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

6TB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2489	Muffler As	360-7870
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934

6TB		
Original Part Number	Part Name	Classic Part Number
2P-1757	Hub-Fan Pulley	296-1357
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-8986	Cup-Rlr Bearing	415-1912
2W-5540	Core As-Radiator	363-7452
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191

6TB		
Original Part Number	Part Name	Classic Part Number
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495

Sales Model 3406B (Cont'd.)

6TB		
Original Part Number	Part Name	Classic Part Number
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161
5F-8651	Bearing-Ball	420-3223
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9538	Bearing-Roller	421-8183
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757

6TB		
Original Part Number	Part Name	Classic Part Number
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0425	Coupling-Exhaust	394-9836
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-5978	Coupling-Exhaust	369-9487
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-9221	Gasket Kit	391-1092
6V-9725	Kit-Gasket (F)	437-3200
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816

6TB		
Original Part Number	Part Name	Classic Part Number
7N-1220	Plunger As-Pump	419-4743
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8018	Seal-Water	418-1964
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7W-0140	Gear-Drive	399-8546
7W-0182	Plunger & Bbl As	391-9893
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7W-7546	Gasket-Plate	433-8187
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0788	Cover	440-0849
8N-1184	Elbow-Exhaust	392-4497
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077

Sales Model 3406B (Cont'd.)

6TB		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-7148	Cap As-Rain	378-3994
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-2930	Gasket Kit - F	393-1026
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-8644	Kit-Gasket (Ocl)	436-8416
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915

6TB		
Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As-Head	279-4977
114-4787	Kit-Gasket (Ocl)	388-0657
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572
117-0456	Crankshaft As	394-2587
117-7899	Gasket Kit - Sch	436-8409
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
141-4617	Kit-Gasket(Acl)	393-0917
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-4229	Gasket Kit - Sch	437-4599
150-4637	Pan-Oil	377-5843
155-1379	Gasket Kit - Sch	386-3815
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
163-5636	Kit-Gasket(Ocl)	437-2017
166-9142	Gasket	420-8546

6TB		
Original Part Number	Part Name	Classic Part Number
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
187-8979	Gear As	393-3656
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
223-3343	Kit-Gasket-Acl	437-8131
231-0649	Kit-Gasket (Sch)	437-8673
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
232-6599	Kit-Gasket (Mch)	437-2033
232-6642	Kit-Gasket (Sch)	437-2020
233-9474	Kit-Gasket (Sch)	437-2024
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
290-2060	Kit-Gasket-Sch	438-0149
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387

Sales Model 3406B (Cont'd.)

6TB		
Original Part Number	Part Name	Classic Part Number
328-5574	Bearing-Rod	419-7266

6TB		
Original Part Number	Part Name	Classic Part Number
430-7619	Adapter-Cla	438-1812

7FB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-6005	Bearing-Sleeve	417-4521
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-4326	Gasket Kit	437-8111
3E-6772	Seal-Water	382-8017
3R-8530	Boss	425-3454
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710

7FB		
Original Part Number	Part Name	Classic Part Number
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5F-8651	Bearing-Ball	420-3223
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657

7FB		
Original Part Number	Part Name	Classic Part Number
6V-9221	Gasket Kit	391-1092
6V-9725	Kit-Gasket (F)	437-3200
6V-9921	Gasket Kit	437-3236
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-7955	Gasket-Cover	382-6899
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-5449	Spool-Press Rlf	434-2450
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7W-0140	Gear-Drive	399-8546
7W-1713	Core Gp-O Clr	438-2010
7W-2059	Gasket-Cyl Hd	380-1548
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894

Sales Model 3406B (Cont'd.)

7FB		
Original Part Number	Part Name	Classic Part Number
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7X-2754	Gasket Kit - F	437-3235
7X-7954	Gasket Kit	393-5204
8C-4455	Gasket Kit	436-8392
8C-5704	Gasket Kit - Sch	393-1027
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-2930	Gasket Kit - F	393-1026
100-2937	Kit-Gasket (Ocl)	436-8417
100-5953	Gasket Kit - F	437-4573
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060

7FB		
Original Part Number	Part Name	Classic Part Number
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
114-4787	Kit-Gasket (Ocl)	388-0657
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-4229	Gasket Kit - Sch	437-4599
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054

7FB		
Original Part Number	Part Name	Classic Part Number
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
171-8780	Kit-Gasket (Ocl)	437-2013
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
226-2018	Kit-Gasket-Acl	393-0921
231-0649	Kit-Gasket (Sch)	437-8673
232-2922	Kit-Gasket-Rs	437-8671
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
233-9474	Kit-Gasket (Sch)	437-2024
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
290-2060	Kit-Gasket-Sch	438-0149
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387

Sales Model 3406B (Cont'd.)

7FB		
Original Part Number	**Part Name**	**Classic Part Number**
328-5574	Bearing-Rod	419-7266

7FB		
Original Part Number	**Part Name**	**Classic Part Number**
430-7619	Adapter-Cla	438-1812

7T2		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2489	Muffler As	360-7870
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3786	Rod-Thrt Cont	397-5051
4B-7270	Cone-Bearing	399-4439
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885

7T2		
Original Part Number	**Part Name**	**Classic Part Number**
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
6B-3223	Cup-Bearing	399-6065
6I-1453	Crankshaft As	368-5916
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370

7T2		
Original Part Number	**Part Name**	**Classic Part Number**
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-1184	Elbow-Exhaust	392-4497
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372

Sales Model 3406B (Cont'd.)

7T2		
Original Part Number	**Part Name**	**Classic Part Number**
9L-5839	Coupling-Exhaust	374-7480
9L-6371	Rod-Eye	363-7459
9N-1545	Race-Thrust	394-9205
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587

7T2		
Original Part Number	**Part Name**	**Classic Part Number**
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
187-8979	Gear As	393-3656
191-7941	Line As-Fuel Inj	378-4011

7T2		
Original Part Number	**Part Name**	**Classic Part Number**
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3679	Kit-Gasket (Rs)	437-2039
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

7XC		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-5271	Bearing-Ball	371-4305

7XC		
Original Part Number	**Part Name**	**Classic Part Number**
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177

7XC		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550

Sales Model 3406B (Cont'd.)

7XC		
Original Part Number	Part Name	Classic Part Number
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5P-7807	Bearing-Ball	314-8502
5S-4557	Bearing	311-9360
5S-5917	Screw-Rocker Adj	380-7537
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-4728	Rod As-Conn	379-8863
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-7894	Bearing-Rod	419-7260
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488

7XC		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7W-0140	Gear-Drive	399-8546
7W-2059	Gasket-Cyl Hd	380-1548
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8N-0701	Bearing-Sleeve	419-4745
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-7682	Valve-Inlet	385-9266
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9N-5246	Bearing-Camshaft	384-4772
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057

7XC		
Original Part Number	Part Name	Classic Part Number
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-7354	Manifold-Exhaust	386-3060
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
119-6772	Valve-Exhaust	384-8699
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054

Sales Model 3406B (Cont'd.)

7XC		
Original Part Number	**Part Name**	**Classic Part Number**
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699

7XC		
Original Part Number	**Part Name**	**Classic Part Number**
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266

7XC		
Original Part Number	**Part Name**	**Classic Part Number**
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

8TC		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-4325	Kit-Gasket (F)	437-8112
3E-6772	Seal-Water	382-8017
3R-8530	Boss	425-3454
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450

8TC		
Original Part Number	**Part Name**	**Classic Part Number**
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360

8TC		
Original Part Number	**Part Name**	**Classic Part Number**
5S-9080	Pulley-Alt Drive	264-5883
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847

Sales Model 3406B (Cont'd.)

8TC		
Original Part Number	Part Name	Classic Part Number
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7W-0140	Gear-Drive	399-8546
7W-1713	Core Gp-O Clr	438-2010
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7X-7954	Gasket Kit	393-5204
8C-5704	Gasket Kit - Sch	393-1027
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665

8TC		
Original Part Number	Part Name	Classic Part Number
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-2937	Kit-Gasket (Ocl)	436-8417
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919

8TC		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-4229	Gasket Kit - Sch	437-4599
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-2922	Kit-Gasket-Rs	437-8671
232-6574	Kit-Gasket-Rs	437-2034
233-9474	Kit-Gasket (Sch)	437-2024
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
290-2060	Kit-Gasket-Sch	438-0149
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387

Sales Model 3406B (Cont'd.)

8TC		
Original Part Number	**Part Name**	**Classic Part Number**
328-5573	Bearing-Conn Rod	419-4665

8TC		
Original Part Number	**Part Name**	**Classic Part Number**
328-5574	Bearing-Rod	419-7266

8TC		
Original Part Number	**Part Name**	**Classic Part Number**
430-7619	Adapter-Cla	438-1812

9PL		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550

9PL		
Original Part Number	**Part Name**	**Classic Part Number**
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-3831	Seal-O-Ring	436-2657
6Y-3955	Bearing-Ball	417-9485
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222

9PL		
Original Part Number	**Part Name**	**Classic Part Number**
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9N-1545	Race-Thrust	394-9205
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587

Sales Model 3406B (Cont'd.)

9PL		
Original Part Number	Part Name	Classic Part Number
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869

9PL		
Original Part Number	Part Name	Classic Part Number
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012

9PL		
Original Part Number	Part Name	Classic Part Number
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

WJA		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2489	Muffler As	360-7870
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850

WJA		
Original Part Number	Part Name	Classic Part Number
2P-8986	Cup-Rlr Bearing	415-1912
2W-5540	Core As-Radiator	363-7452
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177

WJA		
Original Part Number	Part Name	Classic Part Number
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355

Sales Model 3406B (Cont'd.)

WJA		
Original Part Number	Part Name	Classic Part Number
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161
5F-8651	Bearing-Ball	420-3223
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9538	Bearing-Roller	421-8183
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381

WJA		
Original Part Number	Part Name	Classic Part Number
6N-0425	Coupling-Exhaust	394-9836
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-5978	Coupling-Exhaust	369-9487
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-9221	Gasket Kit	391-1092
6V-9725	Kit-Gasket (F)	437-3200
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-1220	Plunger As-Pump	419-4743
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724

WJA		
Original Part Number	Part Name	Classic Part Number
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8018	Seal-Water	418-1964
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7W-0140	Gear-Drive	399-8546
7W-0182	Plunger & Bbl As	391-9893
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7W-7546	Gasket-Plate	433-8187
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0788	Cover	440-0849
8N-1184	Elbow-Exhaust	392-4497
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-7148	Cap As-Rain	378-3994

Sales Model 3406B (Cont'd.)

WJA		
Original Part Number	Part Name	Classic Part Number
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-2930	Gasket Kit - F	393-1026
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-8644	Kit-Gasket (Ocl)	436-8416
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
111-8015	Gasket As-Head	279-4977
114-4787	Kit-Gasket (Ocl)	388-0657
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572
117-0456	Crankshaft As	394-2587

WJA		
Original Part Number	Part Name	Classic Part Number
117-7899	Gasket Kit - Sch	436-8409
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
141-4617	Kit-Gasket(Acl)	393-0917
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-4229	Gasket Kit - Sch	437-4599
150-4637	Pan-Oil	377-5843
155-1379	Gasket Kit - Sch	386-3815
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
163-5636	Kit-Gasket(Ocl)	437-2017
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
187-8979	Gear As	393-3656
190-9861	Kit-Gskt-Acl	386-3812

WJA		
Original Part Number	Part Name	Classic Part Number
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
223-3343	Kit-Gasket-Acl	437-8131
231-0649	Kit-Gasket (Sch)	437-8673
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
232-6599	Kit-Gasket (Mch)	437-2033
232-6642	Kit-Gasket (Sch)	437-2020
233-9474	Kit-Gasket (Sch)	437-2024
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
290-2060	Kit-Gasket-Sch	438-0149
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

Sales Model 3406C

1LS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3N-3786	Rod-Thrt Cont	397-5051
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600

1LS		
Original Part Number	Part Name	Classic Part Number
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9538	Bearing-Roller	421-8183
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739

1LS		
Original Part Number	Part Name	Classic Part Number
6N-0425	Coupling-Exhaust	394-9836
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7T-2036	Cap As-Fuel	361-1721
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470

Sales Model 3406C (Cont'd.)

1LS		
Original Part Number	Part Name	Classic Part Number
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-1184	Elbow-Exhaust	392-4497
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-7148	Cap As-Rain	378-3994
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062

1LS		
Original Part Number	Part Name	Classic Part Number
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-1987	Gasket Kit - F	437-3238
138-4338	Kit-Gasket-T	393-1032
138-6744	Rebuild Kit-Pump	363-7457
138-7025	Kit-Gasket(F)	437-3222
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048

1LS		
Original Part Number	Part Name	Classic Part Number
161-4111	Pump Gp-Xx 1 Gr	374-7502
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
223-3343	Kit-Gasket-Acl	437-8131
223-3345	Kit-Gasket-Sch	437-8130
232-2922	Kit-Gasket-Rs	437-8671
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

1SS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356

1SS		
Original Part Number	Part Name	Classic Part Number
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569

1SS		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163

Sales Model 3406C (Cont'd.)

1SS		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3N-3786	Rod-Thrt Cont	397-5051
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550

1SS		
Original Part Number	**Part Name**	**Classic Part Number**
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-3831	Seal-O-Ring	436-2657
6Y-3955	Bearing-Ball	417-9485
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222

1SS		
Original Part Number	**Part Name**	**Classic Part Number**
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9N-1545	Race-Thrust	394-9205
9S-7148	Cap As-Rain	378-3994
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691

Sales Model 3406C (Cont'd.)

1SS		
Original Part Number	Part Name	Classic Part Number
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-4338	Kit-Gasket-T	393-1032

1SS		
Original Part Number	Part Name	Classic Part Number
138-6744	Rebuild Kit-Pump	363-7457
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
163-5636	Kit-Gasket(Ocl)	437-2017
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701

1SS		
Original Part Number	Part Name	Classic Part Number
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
223-3343	Kit-Gasket-Acl	437-8131
223-3344	Kit-Gasket(Ocl)	437-2040
223-3345	Kit-Gasket-Sch	437-8130
232-3679	Kit-Gasket (Rs)	437-2039
233-9480	Kit-Gasket-Sch	437-2023
234-1874	Kit-Gasket-Fs	437-8668
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

1WW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-7125	Governor As	383-3672
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

1WW		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177

1WW		
Original Part Number	Part Name	Classic Part Number
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2954	Sleeve-Camshaft	299-2059
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115

Sales Model 3406C (Cont'd.)

1WW		
Original Part Number	**Part Name**	**Classic Part Number**
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5S-4557	Bearing	311-9360
6I-1240	Governor As	380-7538
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-8968	Coupling-Exhaust	311-9381
6N-1931	Plunger	379-0171
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6N-9743	Support-Muffler	308-9940
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222

1WW		
Original Part Number	**Part Name**	**Classic Part Number**
7F-2742	Bearing-Ball	422-6488
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0788	Cover	440-0849
8N-1184	Elbow-Exhaust	392-4497
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9L-5839	Coupling-Exhaust	374-7480
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9S-8597	Spring	399-8561
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690

1WW		
Original Part Number	**Part Name**	**Classic Part Number**
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956

Sales Model 3406C (Cont'd.)

1WW		
Original Part Number	**Part Name**	**Classic Part Number**
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701

1WW		
Original Part Number	**Part Name**	**Classic Part Number**
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
197-5510	Support As	419-0880
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-3294	Gage As-O Level	398-2930

1WW		
Original Part Number	**Part Name**	**Classic Part Number**
217-0578	Bearing-Rod	419-4665
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812

2AM		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904

2AM		
Original Part Number	**Part Name**	**Classic Part Number**
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206

2AM		
Original Part Number	**Part Name**	**Classic Part Number**
6V-3831	Seal-O-Ring	436-2657
6Y-3955	Bearing-Ball	417-9485
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7L-7508	Bearing-Ball	420-6536
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210

Sales Model 3406C (Cont'd.)

2AM		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9N-1545	Race-Thrust	394-9205
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700

2AM		
Original Part Number	**Part Name**	**Classic Part Number**
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011

2AM		
Original Part Number	**Part Name**	**Classic Part Number**
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

2MZ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3N-3786	Rod-Thrt Cont	397-5051

2MZ		
Original Part Number	**Part Name**	**Classic Part Number**
3N-4892	Lever-Gov Cont	439-4542
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271

2MZ		
Original Part Number	**Part Name**	**Classic Part Number**
4N-5614	Arm As-Rocker	374-4710
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168

Sales Model 3406C (Cont'd.)

2MZ		
Original Part Number	Part Name	Classic Part Number
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8L-4282	Hub	444-0573
8N-1184	Elbow-Exhaust	392-4497
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521

2MZ		
Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814

2RJ		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483

2MZ		
Original Part Number	Part Name	Classic Part Number
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
430-7619	Adapter-Cla	438-1812

Sales Model 3406C (Cont'd.)

2RJ		
Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-3714	Chamber As	363-7450
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518

2RJ		
Original Part Number	Part Name	Classic Part Number
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8N-1726	Rod As-Conn	379-8866
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9N-1545	Race-Thrust	394-9205
9Y-7735	Bearing-Rod	419-4665
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1818	Bridge As-Exh	374-4691
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215

2RJ		
Original Part Number	Part Name	Classic Part Number
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
232-3679	Kit-Gasket (Rs)	437-2039
234-1874	Kit-Gasket-Fs	437-8668
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665

Sales Model 3406C (Cont'd.)

2RJ		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812
448-7015	Kit-Ovhl-Cla	379-0171
448-7015	Kit-Ovhl-Cla	379-0174
448-7015	Kit-Ovhl-Cla	384-8700
448-7015	Kit-Ovhl-Cla	384-8704
448-7015	Kit-Ovhl-Cla	386-3048
448-7015	Kit-Ovhl-Cla	386-3812
448-7015	Kit-Ovhl-Cla	386-3814
448-7015	Kit-Ovhl-Cla	388-6571
448-7015	Kit-Ovhl-Cla	311-9356
448-7015	Kit-Ovhl-Cla	361-1716
448-7015	Kit-Ovhl-Cla	379-0166
448-7015	Kit-Ovhl-Cla	363-7455
448-7015	Kit-Ovhl-Cla	374-8342

2RJ		
Original Part Number	Part Name	Classic Part Number
448-7017	Kit-Ovhl-Cla	386-3812
448-7017	Kit-Ovhl-Cla	363-7455
448-7017	Kit-Ovhl-Cla	422-6919
448-7017	Kit-Ovhl-Cla	311-9356
448-7017	Kit-Ovhl-Cla	373-1885
448-7017	Kit-Ovhl-Cla	361-1716
448-7017	Kit-Ovhl-Cla	419-6367
448-7017	Kit-Ovhl-Cla	386-3814
448-7017	Kit-Ovhl-Cla	386-3048
448-7017	Kit-Ovhl-Cla	384-8704
448-7017	Kit-Ovhl-Cla	384-8700
448-7017	Kit-Ovhl-Cla	379-0191
448-7017	Kit-Ovhl-Cla	379-0177
448-7017	Kit-Ovhl-Cla	379-0174
448-7017	Kit-Ovhl-Cla	379-0171
448-7017	Kit-Ovhl-Cla	379-0166

2RJ		
Original Part Number	Part Name	Classic Part Number
448-7017	Kit-Ovhl-Cla	375-9974
448-7017	Kit-Ovhl-Cla	374-8342
448-7017	Kit-Ovhl-Cla	388-6571
448-7017	Kit-Ovhl-Cla	379-0170
448-7018	Kit-Gasket-F-Cla	417-4499
448-7018	Kit-Gasket-F-Cla	325-6158
448-7018	Kit-Gasket-F-Cla	325-6210
448-7018	Kit-Gasket-F-Cla	383-1569
448-7018	Kit-Gasket-F-Cla	384-4816
448-7018	Kit-Gasket-F-Cla	399-4423

2WB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-4087	Gear As-Idler	418-9582
2W-5540	Core As-Radiator	363-7452
2W-7455	Gear As	396-9957
3E-3322	Gasket Kit - F	437-8114
3E-4326	Gasket Kit	437-8111
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356

2WB		
Original Part Number	Part Name	Classic Part Number
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
4B-7255	Cone-Bearing	386-4951
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3714	Chamber As	363-7450
4N-4161	Mount As	374-1448

2WB		
Original Part Number	Part Name	Classic Part Number
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4539	Sleeve	314-8720
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320

Sales Model 3406C (Cont'd.)

2WB		
Original Part Number	Part Name	Classic Part Number
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-2448	Bearing-Ball	399-6064
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9538	Bearing-Roller	421-8183
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0425	Coupling-Exhaust	394-9836
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574

2WB		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
6V-9221	Gasket Kit	391-1092
6V-9725	Kit-Gasket (F)	437-3200
6V-9736	Kit-Gasket (F)	437-3202
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7T-2036	Cap As-Fuel	361-1721
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494

2WB		
Original Part Number	Part Name	Classic Part Number
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-1184	Elbow-Exhaust	392-4497
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-7148	Cap As-Rain	378-3994
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-2937	Kit-Gasket (Ocl)	436-8417
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3374	Gear-Camshaft Dr	376-9069
101-8644	Kit-Gasket (Ocl)	436-8416
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166

Sales Model 3406C (Cont'd.)

2WB		
Original Part Number	Part Name	Classic Part Number
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
114-4787	Kit-Gasket (Ocl)	388-0657
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572
117-0456	Crankshaft As	394-2587
117-7899	Gasket Kit - Sch	436-8409
117-7901	Kit-Gasket (F)	436-8397
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423

2WB		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
138-4338	Kit-Gasket-T	393-1032
138-6744	Rebuild Kit-Pump	363-7457
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-4229	Gasket Kit - Sch	437-4599
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
163-5636	Kit-Gasket(Ocl)	437-2017
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701

2WB		
Original Part Number	Part Name	Classic Part Number
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
223-3345	Kit-Gasket-Sch	437-8130
226-2018	Kit-Gasket-Acl	393-0921
232-2922	Kit-Gasket-Rs	437-8671
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
232-6599	Kit-Gasket (Mch)	437-2033
232-6642	Kit-Gasket (Sch)	437-2020
233-9474	Kit-Gasket (Sch)	437-2024
233-9480	Kit-Gasket-Sch	437-2023
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
290-2060	Kit-Gasket-Sch	438-0149
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

3ER		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1S-9209	Shaft-Tightener	374-6499
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846

3ER		
Original Part Number	Part Name	Classic Part Number
1W-2489	Muffler As	360-7870
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163

3ER		
Original Part Number	Part Name	Classic Part Number
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-5842	Screw-Bridge Adj	418-1934

Sales Model 3406C (Cont'd.)

3ER		
Original Part Number	Part Name	Classic Part Number
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-8986	Cup-Rlr Bearing	415-1912
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3R-8530	Boss	425-3454
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1106	Shaft As-Rocker	377-5837
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3092	Spider As-Fan	363-7465
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904

3ER		
Original Part Number	Part Name	Classic Part Number
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4S-5367	Mount As	375-9986
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9538	Bearing-Roller	421-8183
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6N-0425	Coupling-Exhaust	394-9836

3ER		
Original Part Number	Part Name	Classic Part Number
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-5978	Coupling-Exhaust	369-9487
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475

Sales Model 3406C (Cont'd.)

3ER		
Original Part Number	Part Name	Classic Part Number
7W-2731	Retainer	423-3541
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0788	Cover	440-0849
8N-1184	Elbow-Exhaust	392-4497
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-7148	Cap As-Rain	378-3994
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689

3ER		
Original Part Number	Part Name	Classic Part Number
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-7354	Manifold-Exhaust	386-3060
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-7025	Kit-Gasket(F)	437-3222
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054

3ER		
Original Part Number	Part Name	Classic Part Number
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-8780	Kit-Gasket (Ocl)	437-2013
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-3294	Gage As-O Level	398-2930
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
226-2018	Kit-Gasket-Acl	393-0921
232-3679	Kit-Gasket (Rs)	437-2039
234-1874	Kit-Gasket-Fs	437-8668
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
256-9653	Flywheel As.	425-3444
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812

Sales Model 3406C (Cont'd.)

3SF		
Original Part Number	**Part Name**	**Classic Part Number**
155-5619	Gasket	382-5054
232-3679	Kit-Gasket (Rs)	437-2039

3ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-4326	Gasket Kit	437-8111
3E-6772	Seal-Water	382-8017
3R-8530	Boss	425-3454
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216

3ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7731	Core Gp-O Clr	385-7228
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864

3ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7W-0140	Gear-Drive	399-8546
7W-1713	Core Gp-O Clr	438-2010
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7X-7954	Gasket Kit	393-5204
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-8258	Bearing-Sleeve	452-1077

Sales Model 3406C (Cont'd.)

3ZJ		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
9F-3212	Bearing-Ball	384-5953
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-2930	Gasket Kit - F	393-1026
100-2937	Kit-Gasket (Ocl)	436-8417
100-5953	Gasket Kit - F	437-4573
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215

3ZJ		
Original Part Number	Part Name	Classic Part Number
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
112-7993	Gasket Kit	437-3231
113-4610	Gasket Kit	436-8410
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
122-8900	Kit-Gasket(F)	437-3230
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
141-5787	Kit-Gasket(Ocl)	437-4611
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
149-0629	Gasket Kit - Sch	437-4594
150-1914	Manifold-Exh	434-6111
150-1916	Manifold-Exh	395-1322
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048

3ZJ		
Original Part Number	Part Name	Classic Part Number
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
219-3501	Kit - Gasket	437-8129
231-0649	Kit-Gasket (Sch)	437-8673
232-2922	Kit-Gasket-Rs	437-8671
232-3675	Kit-Gasket-Rs	437-8670
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
233-6728	Kit-Gasket-Fs	437-2032
233-9198	Kit-Gasket-Sch	437-2029
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
290-2060	Kit-Gasket-Sch	438-0149
321-5746	Bearing-Main	419-6367
325-2721	Kit-Gasket(T)	393-3662
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

Sales Model 3406C (Cont'd.)

4BM		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320

4BM		
Original Part Number	Part Name	Classic Part Number
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-3831	Seal-O-Ring	436-2657
6Y-3955	Bearing-Ball	417-9485
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470

4BM		
Original Part Number	Part Name	Classic Part Number
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9N-1545	Race-Thrust	394-9205
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035

Sales Model 3406C (Cont'd.)

4BM		
Original Part Number	Part Name	Classic Part Number
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699

4BM		
Original Part Number	Part Name	Classic Part Number
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266

4BM		
Original Part Number	Part Name	Classic Part Number
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

4CK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-4325	Kit-Gasket (F)	437-8112
3E-4326	Gasket Kit	437-8111
3E-6772	Seal-Water	382-8017
3R-8530	Boss	425-3454
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283

4CK		
Original Part Number	Part Name	Classic Part Number
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5P-7807	Bearing-Ball	314-8502
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757

4CK		
Original Part Number	Part Name	Classic Part Number
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7N-1572	Cover-Water Pump	377-5854

Sales Model 3406C (Cont'd.)

4CK		
Original Part Number	Part Name	Classic Part Number
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7W-0140	Gear-Drive	399-8546
7W-1713	Core Gp-O Clr	438-2010
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7X-7954	Gasket Kit	393-5204
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-2930	Gasket Kit - F	393-1026
100-2937	Kit-Gasket (Ocl)	436-8417
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689

4CK		
Original Part Number	Part Name	Classic Part Number
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
112-7993	Gasket Kit	437-3231
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
140-9631	Kit-Gasket(F)	437-3217
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035

4CK		
Original Part Number	Part Name	Classic Part Number
146-4229	Gasket Kit - Sch	437-4599
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
219-3501	Kit - Gasket	437-8129
231-0649	Kit-Gasket (Sch)	437-8673
232-2922	Kit-Gasket-Rs	437-8671
232-3675	Kit-Gasket-Rs	437-8670
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
290-2060	Kit-Gasket-Sch	438-0149
321-5746	Bearing-Main	419-6367
325-2721	Kit-Gasket(T)	393-3662
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387

Sales Model 3406C (Cont'd.)

4CK		
Original Part Number	Part Name	Classic Part Number
328-5574	Bearing-Rod	419-7266

4CK		
Original Part Number	Part Name	Classic Part Number
430-7619	Adapter-Cla	438-1812

4GW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1S-9209	Shaft-Tightener	374-6499
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2489	Muffler As	360-7870
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-5842	Screw-Bridge Adj	418-1934
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-8986	Cup-Rlr Bearing	415-1912
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3R-8530	Boss	425-3454
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883

4GW		
Original Part Number	Part Name	Classic Part Number
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1106	Shaft As-Rocker	377-5837
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3092	Spider As-Fan	363-7465
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4S-5367	Mount As	375-9986
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571

4GW		
Original Part Number	Part Name	Classic Part Number
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9538	Bearing-Roller	421-8183
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6N-0425	Coupling-Exhaust	394-9836
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-5978	Coupling-Exhaust	369-9487
6N-6490	Bracket As-Fan	420-8569

Sales Model 3406C (Cont'd.)

4GW		
Original Part Number	Part Name	Classic Part Number
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470

4GW		
Original Part Number	Part Name	Classic Part Number
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0788	Cover	440-0849
8N-1184	Elbow-Exhaust	392-4497
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-7148	Cap As-Rain	378-3994
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-7354	Manifold-Exhaust	386-3060
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513

4GW		
Original Part Number	Part Name	Classic Part Number
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-7025	Kit-Gasket(F)	437-3222
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-8780	Kit-Gasket (Ocl)	437-2013
177-9024	Adapter-Damper	299-1956

Sales Model 3406C (Cont'd.)

4GW		
Original Part Number	**Part Name**	**Classic Part Number**
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012

4GW		
Original Part Number	**Part Name**	**Classic Part Number**
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-3294	Gage As-O Level	398-2930
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
226-2018	Kit-Gasket-Acl	393-0921
232-3679	Kit-Gasket (Rs)	437-2039

4GW		
Original Part Number	**Part Name**	**Classic Part Number**
234-1874	Kit-Gasket-Fs	437-8668
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
256-9653	Flywheel As.	425-3444
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812

4JK		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3786	Rod-Thrt Cont	397-5051
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177

4JK		
Original Part Number	**Part Name**	**Classic Part Number**
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255

4JK		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-3955	Bearing-Ball	417-9485
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523

Sales Model 3406C (Cont'd.)

4JK		
Original Part Number	Part Name	Classic Part Number
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7N-8828	Pulley	420-6395
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9N-1545	Race-Thrust	394-9205
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552

4JK		
Original Part Number	Part Name	Classic Part Number
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-1987	Gasket Kit - F	437-3238
138-4338	Kit-Gasket-T	393-1032
138-6744	Rebuild Kit-Pump	363-7457
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
149-0625	Kit-Gasket(F)	437-4595

4MG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913

4JK		
Original Part Number	Part Name	Classic Part Number
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
223-3343	Kit-Gasket-Acl	437-8131
223-3345	Kit-Gasket-Sch	437-8130
232-2922	Kit-Gasket-Rs	437-8671
233-9473	Kit-Gasket-Sch	437-2025
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

Sales Model 3406C (Cont'd.)

4MG		
Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-6005	Bearing-Sleeve	417-4521
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-4326	Gasket Kit	437-8111
3E-6772	Seal-Water	382-8017
3R-8530	Boss	425-3454
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216

4MG		
Original Part Number	Part Name	Classic Part Number
4P-7731	Core Gp-O Clr	385-7228
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5F-8651	Bearing-Ball	420-3223
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-9221	Gasket Kit	391-1092
6V-9725	Kit-Gasket (F)	437-3200
6V-9921	Gasket Kit	437-3236
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-7955	Gasket-Cover	382-6899
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864

4MG		
Original Part Number	Part Name	Classic Part Number
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-5449	Spool-Press Rlf	434-2450
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7W-0140	Gear-Drive	399-8546
7W-1713	Core Gp-O Clr	438-2010
7W-2059	Gasket-Cyl Hd	380-1548
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7X-2754	Gasket Kit - F	437-3235
7X-7954	Gasket Kit	393-5204
8C-4455	Gasket Kit	436-8392
8C-5704	Gasket Kit - Sch	393-1027
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842

Sales Model 3406C (Cont'd.)

4MG		
Original Part Number	Part Name	Classic Part Number
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-2930	Gasket Kit - F	393-1026
100-2937	Kit-Gasket (Ocl)	436-8417
100-5953	Gasket Kit - F	437-4573
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744

4MG		
Original Part Number	Part Name	Classic Part Number
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
114-4787	Kit-Gasket (Ocl)	388-0657
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-4229	Gasket Kit - Sch	437-4599
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359

4MG		
Original Part Number	Part Name	Classic Part Number
171-8780	Kit-Gasket (Ocl)	437-2013
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
226-2018	Kit-Gasket-Acl	393-0921
231-0649	Kit-Gasket (Sch)	437-8673
232-2922	Kit-Gasket-Rs	437-8671
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
233-9474	Kit-Gasket (Sch)	437-2024
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
290-2060	Kit-Gasket-Sch	438-0149
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

4RG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913

Sales Model 3406C (Cont'd.)

4RG		
Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-3322	Gasket Kit - F	437-8114
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3786	Rod-Thrt Cont	397-5051
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885

4RG		
Original Part Number	Part Name	Classic Part Number
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522

4RG		
Original Part Number	Part Name	Classic Part Number
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7S-5003	Cap As-Rain	379-0184
7T-2036	Cap As-Fuel	361-1721
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9N-1545	Race-Thrust	394-9205
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853

Sales Model 3406C (Cont'd.)

4RG		
Original Part Number	Part Name	Classic Part Number
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193

4RG		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
146-4229	Gasket Kit - Sch	437-4599
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700

4RG		
Original Part Number	Part Name	Classic Part Number
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-6574	Kit-Gasket-Rs	437-2034
233-9474	Kit-Gasket (Sch)	437-2024
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

4T7		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957

4T7		
Original Part Number	Part Name	Classic Part Number
3E-6772	Seal-Water	382-8017
3N-3017	Adapter As	433-2031
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086

4T7		
Original Part Number	Part Name	Classic Part Number
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318

Sales Model 3406C (Cont'd.)

4T7		
Original Part Number	Part Name	Classic Part Number
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5P-7807	Bearing-Ball	314-8502
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7S-4411	Cap As-Rain	373-1912
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493

4T7		
Original Part Number	Part Name	Classic Part Number
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8L-4282	Hub	444-0573
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193

4T7		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

Sales Model 3406C (Cont'd.)

4TB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-5842	Screw-Bridge Adj	418-1934
2W-3391	Body As-F Inj V	383-3687
2W-7455	Gear As	396-9957
3B-8845	Bearing-Inner	417-4509
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
4B-7255	Cone-Bearing	386-4951
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572

4TB		
Original Part Number	Part Name	Classic Part Number
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-5772	Race & Roller As	394-9200
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9538	Bearing-Roller	421-8183
5S-4557	Bearing	311-9360
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518

4TB		
Original Part Number	Part Name	Classic Part Number
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-9221	Gasket Kit	391-1092
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-1220	Plunger As-Pump	419-4743
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-8371	Line As-Fuel Inj	373-1901
7S-4411	Cap As-Rain	373-1912
7W-0140	Gear-Drive	399-8546
7W-1927	Ring-Retainer	387-2935

Sales Model 3406C (Cont'd.)

4TB		
Original Part Number	**Part Name**	**Classic Part Number**
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9K-1171	Cup-Rlr Bearing	430-3339
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-7148	Cap As-Rain	378-3994
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-2930	Gasket Kit - F	393-1026
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691

4TB		
Original Part Number	**Part Name**	**Classic Part Number**
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
117-7899	Gasket Kit - Sch	436-8409
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502

4ZR		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913

4TB		
Original Part Number	**Part Name**	**Classic Part Number**
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
222-7974	Kit - Gasket	437-2044
222-7987	Kit - Gasket	437-2043
222-8662	Kit-Gasket(F)	437-8134
223-3345	Kit-Gasket-Sch	437-8130
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
233-6728	Kit-Gasket-Fs	437-2032
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

Sales Model 3406C (Cont'd.)

4ZR		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-4087	Gear As-Idler	418-9582
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572

4ZR		
Original Part Number	Part Name	Classic Part Number
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9538	Bearing-Roller	421-8183
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495

4ZR		
Original Part Number	Part Name	Classic Part Number
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0425	Coupling-Exhaust	394-9836
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531

Sales Model 3406C (Cont'd.)

4ZR		
Original Part Number	Part Name	Classic Part Number
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7T-2036	Cap As-Fuel	361-1721
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-1184	Elbow-Exhaust	392-4497
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-7148	Cap As-Rain	378-3994
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689

4ZR		
Original Part Number	Part Name	Classic Part Number
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3374	Gear-Camshaft Dr	376-9069
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
138-1987	Gasket Kit - F	437-3238
138-4338	Kit-Gasket-T	393-1032
138-6744	Rebuild Kit-Pump	363-7457
140-9631	Kit-Gasket(F)	437-3217
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
149-0625	Kit-Gasket(F)	437-4595
150-4637	Pan-Oil	377-5843

4ZR		
Original Part Number	Part Name	Classic Part Number
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
223-3343	Kit-Gasket-Acl	437-8131
223-3345	Kit-Gasket-Sch	437-8130
232-2922	Kit-Gasket-Rs	437-8671
233-9473	Kit-Gasket-Sch	437-2025
234-1874	Kit-Gasket-Fs	437-8668
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

Sales Model 3406C (Cont'd.)

5H9		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-4892	Lever-Gov Cont	439-4542
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1106	Shaft As-Rocker	377-5837
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885

5H9		
Original Part Number	Part Name	Classic Part Number
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5F-8651	Bearing-Ball	420-3223
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522

5H9		
Original Part Number	Part Name	Classic Part Number
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-8828	Pulley	420-6395
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000

Sales Model 3406C (Cont'd.)

5H9		
Original Part Number	**Part Name**	**Classic Part Number**
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566

5H9		
Original Part Number	**Part Name**	**Classic Part Number**
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011

5H9		
Original Part Number	**Part Name**	**Classic Part Number**
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

5KJ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-6005	Bearing-Sleeve	417-4521
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305

5KJ		
Original Part Number	**Part Name**	**Classic Part Number**
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-4326	Gasket Kit	437-8111
3E-6772	Seal-Water	382-8017
3R-8530	Boss	425-3454
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177

5KJ		
Original Part Number	**Part Name**	**Classic Part Number**
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550

Sales Model 3406C (Cont'd.)

5KJ		
Original Part Number	Part Name	Classic Part Number
4W-2474	Rotocoil As	388-6571
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5F-8651	Bearing-Ball	420-3223
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-9221	Gasket Kit	391-1092
6V-9725	Kit-Gasket (F)	437-3200
6V-9921	Gasket Kit	437-3236
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-7955	Gasket-Cover	382-6899
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522

5KJ		
Original Part Number	Part Name	Classic Part Number
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-5449	Spool-Press Rlf	434-2450
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7W-0140	Gear-Drive	399-8546
7W-1713	Core Gp-O Clr	438-2010
7W-2059	Gasket-Cyl Hd	380-1548
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7X-2754	Gasket Kit - F	437-3235
7X-7954	Gasket Kit	393-5204
8C-4455	Gasket Kit	436-8392
8C-5704	Gasket Kit - Sch	393-1027
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372

5KJ		
Original Part Number	Part Name	Classic Part Number
9L-5839	Coupling-Exhaust	374-7480
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-2930	Gasket Kit - F	393-1026
100-2937	Kit-Gasket (Ocl)	436-8417
100-5953	Gasket Kit - F	437-4573
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
114-4787	Kit-Gasket (Ocl)	388-0657
115-2367	Valve-Exhaust	384-8700

Sales Model 3406C (Cont'd.)

5KJ		
Original Part Number	Part Name	Classic Part Number
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-4229	Gasket Kit - Sch	437-4599

5KJ		
Original Part Number	Part Name	Classic Part Number
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
171-8780	Kit-Gasket (Ocl)	437-2013
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013

5KJ		
Original Part Number	Part Name	Classic Part Number
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
226-2018	Kit-Gasket-Acl	393-0921
231-0649	Kit-Gasket (Sch)	437-8673
232-2922	Kit-Gasket-Rs	437-8671
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
233-9474	Kit-Gasket (Sch)	437-2024
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
290-2060	Kit-Gasket-Sch	438-0149
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

6TB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2489	Muffler As	360-7870
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354

6TB		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-8986	Cup-Rlr Bearing	415-1912
2W-5540	Core As-Radiator	363-7452
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046

6TB		
Original Part Number	Part Name	Classic Part Number
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509

Sales Model 3406C (Cont'd.)

6TB		
Original Part Number	Part Name	Classic Part Number
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161

6TB		
Original Part Number	Part Name	Classic Part Number
5F-8651	Bearing-Ball	420-3223
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9538	Bearing-Roller	421-8183
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0425	Coupling-Exhaust	394-9836
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-5978	Coupling-Exhaust	369-9487
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-9221	Gasket Kit	391-1092
6V-9725	Kit-Gasket (F)	437-3200
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571

6TB		
Original Part Number	Part Name	Classic Part Number
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-1220	Plunger As-Pump	419-4743
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8018	Seal-Water	418-1964
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7W-0140	Gear-Drive	399-8546
7W-0182	Plunger & Bbl As	391-9893
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7W-7546	Gasket-Plate	433-8187

Sales Model 3406C (Cont'd.)

6TB		
Original Part Number	Part Name	Classic Part Number
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0788	Cover	440-0849
8N-1184	Elbow-Exhaust	392-4497
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-7148	Cap As-Rain	378-3994
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-2930	Gasket Kit - F	393-1026
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691

6TB		
Original Part Number	Part Name	Classic Part Number
101-8644	Kit-Gasket (Ocl)	436-8416
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
111-8015	Gasket As-Head	279-4977
114-4787	Kit-Gasket (Ocl)	388-0657
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572
117-0456	Crankshaft As	394-2587
117-7899	Gasket Kit - Sch	436-8409
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813

6TB		
Original Part Number	Part Name	Classic Part Number
138-6744	Rebuild Kit-Pump	363-7457
141-4617	Kit-Gasket(Acl)	393-0917
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-4229	Gasket Kit - Sch	437-4599
150-4637	Pan-Oil	377-5843
155-1379	Gasket Kit - Sch	386-3815
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
163-5636	Kit-Gasket(Ocl)	437-2017
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
187-8979	Gear As	393-3656
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
223-3343	Kit-Gasket-Acl	437-8131
231-0649	Kit-Gasket (Sch)	437-8673
232-3679	Kit-Gasket (Rs)	437-2039

Sales Model 3406C (Cont'd.)

6TB		
Original Part Number	**Part Name**	**Classic Part Number**
232-6574	Kit-Gasket-Rs	437-2034
232-6599	Kit-Gasket (Mch)	437-2033
232-6642	Kit-Gasket (Sch)	437-2020
233-9474	Kit-Gasket (Sch)	437-2024
234-1874	Kit-Gasket-Fs	437-8668

6TB		
Original Part Number	**Part Name**	**Classic Part Number**
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
290-2060	Kit-Gasket-Sch	438-0149
321-5746	Bearing-Main	419-6367

6TB		
Original Part Number	**Part Name**	**Classic Part Number**
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

7FB		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-6005	Bearing-Sleeve	417-4521
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-4326	Gasket Kit	437-8111
3E-6772	Seal-Water	382-8017
3R-8530	Boss	425-3454
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177

7FB		
Original Part Number	**Part Name**	**Classic Part Number**
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5F-8651	Bearing-Ball	420-3223
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360

7FB		
Original Part Number	**Part Name**	**Classic Part Number**
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-9221	Gasket Kit	391-1092
6V-9725	Kit-Gasket (F)	437-3200
6V-9921	Gasket Kit	437-3236
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-7955	Gasket-Cover	382-6899
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488

Sales Model 3406C (Cont'd.)

7FB		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-5449	Spool-Press Rlf	434-2450
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7W-0140	Gear-Drive	399-8546
7W-1713	Core Gp-O Clr	438-2010
7W-2059	Gasket-Cyl Hd	380-1548
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7X-2754	Gasket Kit - F	437-3235
7X-7954	Gasket Kit	393-5204
8C-4455	Gasket Kit	436-8392
8C-5704	Gasket Kit - Sch	393-1027
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468

7FB		
Original Part Number	Part Name	Classic Part Number
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-2930	Gasket Kit - F	393-1026
100-2937	Kit-Gasket (Ocl)	436-8417
100-5953	Gasket Kit - F	437-4573
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
114-4787	Kit-Gasket (Ocl)	388-0657
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566

7FB		
Original Part Number	Part Name	Classic Part Number
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-4229	Gasket Kit - Sch	437-4599
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
171-8780	Kit-Gasket (Ocl)	437-2013
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368

Sales Model 3406C (Cont'd.)

7FB		
Original Part Number	**Part Name**	**Classic Part Number**
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
226-2018	Kit-Gasket-Acl	393-0921
231-0649	Kit-Gasket (Sch)	437-8673
232-2922	Kit-Gasket-Rs	437-8671
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034

7FB		
Original Part Number	**Part Name**	**Classic Part Number**
233-9474	Kit-Gasket (Sch)	437-2024
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
290-2060	Kit-Gasket-Sch	438-0149
321-5746	Bearing-Main	419-6367

7FB		
Original Part Number	**Part Name**	**Classic Part Number**
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

7T2		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2489	Muffler As	360-7870
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3786	Rod-Thrt Cont	397-5051
4B-7270	Cone-Bearing	399-4439
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572

7T2		
Original Part Number	**Part Name**	**Classic Part Number**
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
6B-3223	Cup-Bearing	399-6065

7T2		
Original Part Number	**Part Name**	**Classic Part Number**
6I-1453	Crankshaft As	368-5916
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4411	Cap As-Rain	373-1912

Sales Model 3406C (Cont'd.)

7T2		
Original Part Number	**Part Name**	**Classic Part Number**
7S-5003	Cap As-Rain	379-0184
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-1184	Elbow-Exhaust	392-4497
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9L-6371	Rod-Eye	363-7459
9N-1545	Race-Thrust	394-9205
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
102-8501	Manifold-Exhaust	377-5853

7T2		
Original Part Number	**Part Name**	**Classic Part Number**
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
166-9142	Gasket	420-8546

7T2		
Original Part Number	**Part Name**	**Classic Part Number**
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
187-8979	Gear As	393-3656
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3679	Kit-Gasket (Rs)	437-2039
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

8FS		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164

8FS		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957

8FS		
Original Part Number	**Part Name**	**Classic Part Number**
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3786	Rod-Thrt Cont	397-5051
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499

Sales Model 3406C (Cont'd.)

8FS		
Original Part Number	Part Name	Classic Part Number
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854

8FS		
Original Part Number	Part Name	Classic Part Number
5L-7634	Elbow-Turbo Exh	380-1555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9538	Bearing-Roller	421-8183
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7N-8828	Pulley	420-6395
7S-5003	Cap As-Rain	379-0184
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475

8FS		
Original Part Number	Part Name	Classic Part Number
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915

Sales Model 3406C (Cont'd.)

8FS		
Original Part Number	**Part Name**	**Classic Part Number**
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-4338	Kit-Gasket-T	393-1032
138-6744	Rebuild Kit-Pump	363-7457
140-9631	Kit-Gasket(F)	437-3217
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843

8FS		
Original Part Number	**Part Name**	**Classic Part Number**
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013

8FS		
Original Part Number	**Part Name**	**Classic Part Number**
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
223-3343	Kit-Gasket-Acl	437-8131
232-2922	Kit-Gasket-Rs	437-8671
232-3675	Kit-Gasket-Rs	437-8670
232-3679	Kit-Gasket (Rs)	437-2039
233-9473	Kit-Gasket-Sch	437-2025
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

8PN		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974

8PN		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228

8PN		
Original Part Number	**Part Name**	**Classic Part Number**
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518

Sales Model 3406C (Cont'd.)

8PN		
Original Part Number	Part Name	Classic Part Number
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7W-0140	Gear-Drive	399-8546
7W-1713	Core Gp-O Clr	438-2010
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342

8PN		
Original Part Number	Part Name	Classic Part Number
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9F-3212	Bearing-Ball	384-5953
9L-6371	Rod-Eye	363-7459
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
122-8900	Kit-Gasket(F)	437-3230
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814

8PN		
Original Part Number	Part Name	Classic Part Number
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
138-7025	Kit-Gasket(F)	437-3222
141-5787	Kit-Gasket(Ocl)	437-4611
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
149-0625	Kit-Gasket(F)	437-4595
150-1914	Manifold-Exh	434-6111
150-1916	Manifold-Exh	395-1322
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
165-7573	Kit-Gasket (Fs)	438-0141
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
171-8780	Kit-Gasket (Ocl)	437-2013
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
189-1814	Kit-Gasket(Ocl)	437-2009
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012

Sales Model 3406C (Cont'd.)

8PN		
Original Part Number	**Part Name**	**Classic Part Number**
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
219-3501	Kit - Gasket	437-8129
222-1177	Kit-Gasket-Sch	437-2008

8PN		
Original Part Number	**Part Name**	**Classic Part Number**
232-3675	Kit-Gasket-Rs	437-8670
232-3679	Kit-Gasket (Rs)	437-2039
233-9198	Kit-Gasket-Sch	437-2029
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
321-5746	Bearing-Main	419-6367

8PN		
Original Part Number	**Part Name**	**Classic Part Number**
325-2721	Kit-Gasket(T)	393-3662
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

WJA		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2489	Muffler As	360-7870
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-8986	Cup-Rlr Bearing	415-1912
2W-5540	Core As-Radiator	363-7452
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046

WJA		
Original Part Number	**Part Name**	**Classic Part Number**
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086

WJA		
Original Part Number	**Part Name**	**Classic Part Number**
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161
5F-8651	Bearing-Ball	420-3223
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854

Sales Model 3406C (Cont'd.)

WJA		
Original Part Number	Part Name	Classic Part Number
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9538	Bearing-Roller	421-8183
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0425	Coupling-Exhaust	394-9836
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-5978	Coupling-Exhaust	369-9487
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-9221	Gasket Kit	391-1092
6V-9725	Kit-Gasket (F)	437-3200
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256

WJA		
Original Part Number	Part Name	Classic Part Number
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-1220	Plunger As-Pump	419-4743
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8018	Seal-Water	418-1964
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7W-0140	Gear-Drive	399-8546
7W-0182	Plunger & Bbl As	391-9893
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7W-7546	Gasket-Plate	433-8187
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301

WJA		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0788	Cover	440-0849
8N-1184	Elbow-Exhaust	392-4497
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-7148	Cap As-Rain	378-3994
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-2930	Gasket Kit - F	393-1026
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-8644	Kit-Gasket (Ocl)	436-8416
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513

Sales Model 3406C (Cont'd.)

WJA		
Original Part Number	**Part Name**	**Classic Part Number**
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
111-8015	Gasket As-Head	279-4977
114-4787	Kit-Gasket (Ocl)	388-0657
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572
117-0456	Crankshaft As	394-2587
117-7899	Gasket Kit - Sch	436-8409
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919

WJA		
Original Part Number	**Part Name**	**Classic Part Number**
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
141-4617	Kit-Gasket(Acl)	393-0917
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-4229	Gasket Kit - Sch	437-4599
150-4637	Pan-Oil	377-5843
155-1379	Gasket Kit - Sch	386-3815
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
163-5636	Kit-Gasket(Ocl)	437-2017
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
187-8979	Gear As	393-3656
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701

WJA		
Original Part Number	**Part Name**	**Classic Part Number**
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
223-3343	Kit-Gasket-Acl	437-8131
231-0649	Kit-Gasket (Sch)	437-8673
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
232-6599	Kit-Gasket (Mch)	437-2033
232-6642	Kit-Gasket (Sch)	437-2020
233-9474	Kit-Gasket (Sch)	437-2024
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
290-2060	Kit-Gasket-Sch	438-0149
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

ZKC		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356

ZKC		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164

ZKC		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174

Sales Model 3406C (Cont'd.)

ZKC		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3786	Rod-Thrt Cont	397-5051
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255

ZKC		
Original Part Number	Part Name	Classic Part Number
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7N-8828	Pulley	420-6395
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475

ZKC		
Original Part Number	Part Name	Classic Part Number
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9N-1545	Race-Thrust	394-9205
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587

Sales Model 3406C (Cont'd.)

ZKC		
Original Part Number	Part Name	Classic Part Number
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843

ZKC		
Original Part Number	Part Name	Classic Part Number
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701

ZKC		
Original Part Number	Part Name	Classic Part Number
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

Sales Model 3406E

1LW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-7693	Crankshaft As	269-8763
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4P-7827	Gear-Crankshaft	380-7533

1LW		
Original Part Number	Part Name	Classic Part Number
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6V-2202	Bearing-Spl Ball	380-1574
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488

1LW		
Original Part Number	Part Name	Classic Part Number
7M-4046	Bearing-Sleeve	394-8206
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-9805	Pin-Piston	295-6438
7W-1713	Core Gp-O Clr	438-2010
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
8H-9789	Bearing-Ball	374-8342
8N-0788	Cover	440-0849
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-4110	Bearing-Sleeve	394-8207

Sales Model 3406E (Cont'd.)

1LW		
Original Part Number	Part Name	Classic Part Number
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-6511	Bearing-Sleeve	380-7372
9F-3212	Bearing-Ball	384-5953
9L-6371	Rod-Eye	363-7459
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814

1LW		
Original Part Number	Part Name	Classic Part Number
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052
141-5787	Kit-Gasket(Ocl)	437-4611
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
150-1914	Manifold-Exh	434-6111
150-1916	Manifold-Exh	395-1322
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
170-7501	Kit-Gasket(Ocl)	437-2014
177-9024	Adapter-Damper	299-1956

1LW		
Original Part Number	Part Name	Classic Part Number
186-2001	Rotocoil As	397-5055
189-1814	Kit-Gasket(Ocl)	437-2009
190-0649	Tightener-Belt	434-1407
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
232-3233	Bearing-Main	376-9085
232-3675	Kit-Gasket-Rs	437-8670
232-3679	Kit-Gasket (Rs)	437-2039
233-6984	Kit-Gasket(Fs)	437-2045
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
325-2721	Kit-Gasket(T)	393-3662
328-4240	Arm As-V Rocker	433-0443
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
334-8389	Crankshaft As	242-3439
430-7619	Adapter-Cla	438-1812

1MM		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305

1MM		
Original Part Number	Part Name	Classic Part Number
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228

1MM		
Original Part Number	Part Name	Classic Part Number
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6I-2726	Bearing-Sleeve	419-4757

Sales Model 3406E (Cont'd.)

1MM		
Original Part Number	**Part Name**	**Classic Part Number**
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7W-1713	Core Gp-O Clr	438-2010
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9F-3212	Bearing-Ball	384-5953
9L-6371	Rod-Eye	363-7459
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716

1MM		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
108-7930	Bearing As	377-7463
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
150-1914	Manifold-Exh	434-6111
150-1916	Manifold-Exh	395-1322
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117

1MM		
Original Part Number	**Part Name**	**Classic Part Number**
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
189-1814	Kit-Gasket(Ocl)	437-2009
190-0649	Tightener-Belt	434-1407
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
232-3679	Kit-Gasket (Rs)	437-2039
233-6984	Kit-Gasket(Fs)	437-2045
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
325-2721	Kit-Gasket(T)	393-3662
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

2WS		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

2WS		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489

2WS		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2514	Gear-Flywheel	421-7283
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-7693	Crankshaft As	269-8763
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4P-7827	Gear-Crankshaft	380-7533

Sales Model 3406E (Cont'd.)

2WS		
Original Part Number	Part Name	Classic Part Number
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6V-2202	Bearing-Spl Ball	380-1574
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-9805	Pin-Piston	295-6438
7W-1713	Core Gp-O Clr	438-2010
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
8H-9789	Bearing-Ball	374-8342
8N-0788	Cover	440-0849
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-4110	Bearing-Sleeve	394-8207

2WS		
Original Part Number	Part Name	Classic Part Number
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-6511	Bearing-Sleeve	380-7372
9F-3212	Bearing-Ball	384-5953
9L-6371	Rod-Eye	363-7459
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554

2WS		
Original Part Number	Part Name	Classic Part Number
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
150-1914	Manifold-Exh	434-6111
150-1916	Manifold-Exh	395-1322
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
189-1814	Kit-Gasket(Ocl)	437-2009
190-0649	Tightener-Belt	434-1407
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
232-3233	Bearing-Main	376-9085
232-3679	Kit-Gasket (Rs)	437-2039
233-6984	Kit-Gasket(Fs)	437-2045
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
325-2721	Kit-Gasket(T)	393-3662
328-4240	Arm As-V Rocker	433-0443
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
334-8389	Crankshaft As	242-3439
430-7619	Adapter-Cla	438-1812

Sales Model 3406E (Cont'd.)

4AS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0913	Screen As-Bell	374-7489
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2954	Sleeve-Camshaft	299-2059
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-7693	Crankshaft As	269-8763
4P-2383	Adapter-Inlet	438-1812
4P-7827	Gear-Crankshaft	380-7533
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219
5P-8768	Kit-Gasket (Scl)	393-1024
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6N-5482	Plate-Friction	376-3637
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256

4AS		
Original Part Number	Part Name	Classic Part Number
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-9805	Pin-Piston	295-6438
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
8H-9789	Bearing-Ball	374-8342
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-4110	Bearing-Sleeve	394-8207
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9S-8597	Spring	399-8561
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
101-9640	Gear-Air Compr	398-2966

4AS		
Original Part Number	Part Name	Classic Part Number
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
150-1914	Manifold-Exh	434-6111
150-1916	Manifold-Exh	395-1322
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
190-0649	Tightener-Belt	434-1407
197-5510	Support As	419-0880
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665

Sales Model 3406E (Cont'd.)

4AS		
Original Part Number	**Part Name**	**Classic Part Number**
232-3233	Bearing-Main	376-9085
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367

4AS		
Original Part Number	**Part Name**	**Classic Part Number**
328-4240	Arm As-V Rocker	433-0443
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-4665

4AS		
Original Part Number	**Part Name**	**Classic Part Number**
328-5573	Bearing-Conn Rod	419-6387
334-8389	Crankshaft As	242-3439
430-7619	Adapter-Cla	438-1812

5DS		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547

5DS		
Original Part Number	**Part Name**	**Classic Part Number**
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7W-1713	Core Gp-O Clr	438-2010
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5733	Gasket	421-7333
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9F-3212	Bearing-Ball	384-5953
9L-6371	Rod-Eye	363-7459
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566

5DS		
Original Part Number	**Part Name**	**Classic Part Number**
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052
141-5787	Kit-Gasket(Ocl)	437-4611
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
150-1914	Manifold-Exh	434-6111
150-1916	Manifold-Exh	395-1322
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
189-1814	Kit-Gasket(Ocl)	437-2009

Sales Model 3406E (Cont'd.)

5DS		
Original Part Number	**Part Name**	**Classic Part Number**
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
232-3675	Kit-Gasket-Rs	437-8670

5DS		
Original Part Number	**Part Name**	**Classic Part Number**
232-3679	Kit-Gasket (Rs)	437-2039
233-6984	Kit-Gasket(Fs)	437-2045
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
325-2721	Kit-Gasket(T)	393-3662

5DS		
Original Part Number	**Part Name**	**Classic Part Number**
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

5EK		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7255	Shaft-Water Pump	325-6203
2W-7455	Gear As	396-9957
2W-7458	Crankshaft As	242-3439
3E-4325	Kit-Gasket (F)	437-8112
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191

5EK		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2954	Sleeve-Camshaft	299-2059
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-7693	Crankshaft As	269-8763
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4P-7827	Gear-Crankshaft	380-7533
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219

5EK		
Original Part Number	**Part Name**	**Classic Part Number**
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-3907	Adapter-Pilot	398-8348
6I-4024	Gasket-Plate	377-5839
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-5482	Plate-Friction	376-3637
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6N-9133	Gasket-Plate	398-2959
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-6002	Bearing-Sleeve	417-4523

Sales Model 3406E (Cont'd.)

5EK		
Original Part Number	Part Name	Classic Part Number
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-9805	Pin-Piston	295-6438
7W-0140	Gear-Drive	399-8546
7W-1713	Core Gp-O Clr	438-2010
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7X-7954	Gasket Kit	393-5204
8H-9789	Bearing-Ball	374-8342
8N-0788	Cover	440-0849
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-4110	Bearing-Sleeve	394-8207
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

5EK		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9F-3212	Bearing-Ball	384-5953
9L-6371	Rod-Eye	363-7459
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-8597	Spring	399-8561
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
100-2848	Ring-Guide	399-6057
100-2937	Kit-Gasket (Ocl)	436-8417
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
112-7993	Gasket Kit	437-3231
113-4610	Gasket Kit	436-8410
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572

5EK		
Original Part Number	Part Name	Classic Part Number
122-8900	Kit-Gasket(F)	437-3230
126-8557	Pulley	433-2027
127-5537	Core As-Oclr	325-6045
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052
141-5787	Kit-Gasket(Ocl)	437-4611
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
150-1914	Manifold-Exh	434-6111
150-1916	Manifold-Exh	395-1322
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-0560	Rebuild Kit-Pump	363-7458
170-4860	Bonnet-Oil Clr	430-5359
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687

Sales Model 3406E (Cont'd.)

5EK		
Original Part Number	Part Name	Classic Part Number
176-8182	Kit-Gasket(Scl)	437-2010
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368

5EK		
Original Part Number	Part Name	Classic Part Number
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
219-3501	Kit - Gasket	437-8129
223-3344	Kit-Gasket(Ocl)	437-2040
232-3233	Bearing-Main	376-9085
232-3675	Kit-Gasket-Rs	437-8670
232-3679	Kit-Gasket (Rs)	437-2039
233-6984	Kit-Gasket(Fs)	437-2045
233-9198	Kit-Gasket-Sch	437-2029
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
278-8781	Kit-Gasket (Sch)	437-8653
283-5666	Gasket-Cyl Head	388-6565

5EK		
Original Part Number	Part Name	Classic Part Number
321-5746	Bearing-Main	419-6367
325-2721	Kit-Gasket(T)	393-3662
328-4240	Arm As-V Rocker	433-0443
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
334-8389	Crankshaft As	242-3439
347-8681	Kit-Gasket(Fs)	438-0133
347-8682	Kit-Gasket(Ocl)	438-0132
347-8683	Kit-Gasket(Rs)	438-0131
347-8684	Kit-Gasket (Sch)	438-0130
347-8688	Kit-Gasket (Sch)	438-0170
430-7619	Adapter-Cla	438-1812

6BR		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-2489	Muffler As	360-7870
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2P-8986	Cup-Rlr Bearing	415-1912
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
4B-7270	Cone-Bearing	399-4439
4N-0209	Bonnet-Valve	378-3973
4N-0362	Cover As-Rgltr	419-4722
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915

6BR		
Original Part Number	Part Name	Classic Part Number
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2954	Sleeve-Camshaft	299-2059
4N-3092	Spider As-Fan	363-7465
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-7693	Crankshaft As	269-8763
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4P-7827	Gear-Crankshaft	380-7533
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323

6BR		
Original Part Number	Part Name	Classic Part Number
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-5482	Plate-Friction	376-3637

Sales Model 3406E (Cont'd.)

6BR		
Original Part Number	Part Name	Classic Part Number
6N-5978	Coupling-Exhaust	369-9487
6N-6490	Bracket As-Fan	420-8569
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8828	Pulley	420-6395
7N-8957	Gear-Crankshaft	422-2652
7N-9805	Pin-Piston	295-6438
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
8N-1184	Elbow-Exhaust	392-4497
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-8221	Bearing-Conn Rod	419-6377

6BR		
Original Part Number	Part Name	Classic Part Number
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9L-5839	Coupling-Exhaust	374-7480
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-7148	Cap As-Rain	378-3994
9S-8597	Spring	399-8561
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
101-9640	Gear-Air Compr	398-2966
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
127-5537	Core As-Oclr	325-6045
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589

6BR		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
163-5636	Kit-Gasket(Ocl)	437-2017
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
197-5510	Support As	419-0880
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
232-3233	Bearing-Main	376-9085
233-6984	Kit-Gasket(Fs)	437-2045
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-4665

Sales Model 3406E (Cont'd.)

6BR		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-6387

6BR		
Original Part Number	Part Name	Classic Part Number
334-8389	Crankshaft As	242-3439

6BR		
Original Part Number	Part Name	Classic Part Number
430-7619	Adapter-Cla	438-1812

6TS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7255	Shaft-Water Pump	325-6203
2W-7455	Gear As	396-9957
2W-7458	Crankshaft As	242-3439
3E-4325	Kit-Gasket (F)	437-8112
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2954	Sleeve-Camshaft	299-2059
4N-3714	Chamber As	363-7450

6TS		
Original Part Number	Part Name	Classic Part Number
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-7693	Crankshaft As	269-8763
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4P-7827	Gear-Crankshaft	380-7533
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-3907	Adapter-Pilot	398-8348
6I-4024	Gasket-Plate	377-5839
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-5482	Plate-Friction	376-3637

6TS		
Original Part Number	Part Name	Classic Part Number
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6N-9133	Gasket-Plate	398-2959
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-9805	Pin-Piston	295-6438

Sales Model 3406E (Cont'd.)

6TS		
Original Part Number	Part Name	Classic Part Number
7W-0140	Gear-Drive	399-8546
7W-1713	Core Gp-O Clr	438-2010
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7X-7954	Gasket Kit	393-5204
8H-9789	Bearing-Ball	374-8342
8N-0788	Cover	440-0849
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-4110	Bearing-Sleeve	394-8207
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9F-3212	Bearing-Ball	384-5953
9L-6371	Rod-Eye	363-7459
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-8597	Spring	399-8561
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
100-2848	Ring-Guide	399-6057
100-2937	Kit-Gasket (Ocl)	436-8417

6TS		
Original Part Number	Part Name	Classic Part Number
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
112-7993	Gasket Kit	437-3231
113-4610	Gasket Kit	436-8410
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572
122-8900	Kit-Gasket(F)	437-3230
126-8557	Pulley	433-2027
127-5537	Core As-Oclr	325-6045
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052
141-5787	Kit-Gasket(Ocl)	437-4611

6TS		
Original Part Number	Part Name	Classic Part Number
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
150-1914	Manifold-Exh	434-6111
150-1916	Manifold-Exh	395-1322
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-0560	Rebuild Kit-Pump	363-7458
170-4860	Bonnet-Oil Clr	430-5359
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
176-8182	Kit-Gasket(Scl)	437-2010
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
219-3501	Kit - Gasket	437-8129
223-3344	Kit-Gasket(Ocl)	437-2040
232-3233	Bearing-Main	376-9085

Sales Model 3406E (Cont'd.)

6TS		
Original Part Number	**Part Name**	**Classic Part Number**
232-3675	Kit-Gasket-Rs	437-8670
232-3679	Kit-Gasket (Rs)	437-2039
233-6984	Kit-Gasket(Fs)	437-2045
233-9198	Kit-Gasket-Sch	437-2029
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
278-8781	Kit-Gasket (Sch)	437-8653

6TS		
Original Part Number	**Part Name**	**Classic Part Number**
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
325-2721	Kit-Gasket(T)	393-3662
328-4240	Arm As-V Rocker	433-0443
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665

6TS		
Original Part Number	**Part Name**	**Classic Part Number**
334-8389	Crankshaft As	242-3439
347-8681	Kit-Gasket(Fs)	438-0133
347-8682	Kit-Gasket(Ocl)	438-0132
347-8683	Kit-Gasket(Rs)	438-0131
347-8684	Kit-Gasket (Sch)	438-0130
347-8688	Kit-Gasket (Sch)	438-0170
430-7619	Adapter-Cla	438-1812

9NN		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-7693	Crankshaft As	269-8763
4P-2383	Adapter-Inlet	438-1812
4P-7827	Gear-Crankshaft	380-7533
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320

9NN		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5701	Bearing-Main	419-6333
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7M-4046	Bearing-Sleeve	394-8206
7N-2156	Bearing-Sleeve	380-7373
7N-7998	Plate-Block	374-7496
7N-8828	Pulley	420-6395
7N-9805	Pin-Piston	295-6438
7W-3145	Plate	422-7894
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
8N-1849	Bearing-Conn Rod	379-0196

9NN		
Original Part Number	**Part Name**	**Classic Part Number**
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-6511	Bearing-Sleeve	380-7372
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814

Sales Model 3406E (Cont'd.)

9NN		
Original Part Number	Part Name	Classic Part Number
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546

9NN		
Original Part Number	Part Name	Classic Part Number
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
232-3233	Bearing-Main	376-9085
246-3130	Shaft-Water Pump	392-4508

9NN		
Original Part Number	Part Name	Classic Part Number
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
334-8389	Crankshaft As	242-3439
430-7619	Adapter-Cla	438-1812

9WR		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3R-8530	Boss	425-3454
4B-7255	Cone-Bearing	386-4951
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-7693	Crankshaft As	269-8763

9WR		
Original Part Number	Part Name	Classic Part Number
4P-2383	Adapter-Inlet	438-1812
4P-7827	Gear-Crankshaft	380-7533
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6L-2279	Plug-Ptf	419-4739
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6V-3831	Seal-O-Ring	436-2657
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7M-4046	Bearing-Sleeve	394-8206

9WR		
Original Part Number	Part Name	Classic Part Number
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7998	Plate-Block	374-7496
7N-9805	Pin-Piston	295-6438
7S-4411	Cap As-Rain	373-1912
7W-2164	Core As-Oclr	299-1996
7W-2731	Retainer	423-3541
7W-3145	Plate	422-7894
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-4110	Bearing-Sleeve	394-8207
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-6511	Bearing-Sleeve	380-7372

Sales Model 3406E (Cont'd.)

9WR		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035

9WR		
Original Part Number	Part Name	Classic Part Number
146-2601	Cover	399-6054
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
216-5582	Bearing-Sleeve	390-0914

9WR		
Original Part Number	Part Name	Classic Part Number
217-0578	Bearing-Rod	419-4665
232-3233	Bearing-Main	376-9085
243-6718	Kit-Brg(Main)	469-1690
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
334-8389	Crankshaft As	242-3439
430-7619	Adapter-Cla	438-1812

RET		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-0362	Cover As-Rgltr	419-4722
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320

RET		
Original Part Number	Part Name	Classic Part Number
4W-5701	Bearing-Main	419-6333
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7W-3145	Plate	422-7894
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9Y-2988	Breather As	361-1716

RET		
Original Part Number	Part Name	Classic Part Number
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
146-2601	Cover	399-6054
150-4637	Pan-Oil	377-5843

Sales Model 3406E (Cont'd.)

RET		
Original Part Number	**Part Name**	**Classic Part Number**
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956

RET		
Original Part Number	**Part Name**	**Classic Part Number**
186-2001	Rotocoil As	397-5055
197-5510	Support As	419-0880
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507

RET		
Original Part Number	**Part Name**	**Classic Part Number**
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
430-7619	Adapter-Cla	438-1812

Sales Model 3408

177		
Original Part Number	**Part Name**	**Classic Part Number**
1W-5009	Crankshaft As	398-2969
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323

177		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
6I-4613	Plate-Spacer	380-7405
6N-9133	Gasket-Plate	398-2959

177		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-9497	Bearing-Conn Rod	441-1563
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266

28V		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1T-0043	Bearing-Ball	390-5294
1W-5009	Crankshaft As	398-2969
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357

28V		
Original Part Number	**Part Name**	**Classic Part Number**
2W-3391	Body As-F Inj V	383-3687
2W-4087	Gear As-Idler	418-9582
2W-7980	Camshaft As	378-3972
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455

28V		
Original Part Number	**Part Name**	**Classic Part Number**
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710

Sales Model 3408 (Cont'd.)

28V		
Original Part Number	Part Name	Classic Part Number
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5F-8651	Bearing-Ball	420-3223
5L-9738	Coupling-Exhaust	311-9380
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9840	Kit-Gasket-Sch	437-8140
5P-9841	Gasket Kit - Vg	393-3626
5S-4557	Bearing	311-9360
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1032	Line As-Fuel Inj	390-0931
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922

28V		
Original Part Number	Part Name	Classic Part Number
6I-1038	Line As-Fuel Inj	390-0923
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-4597	Coupling-Exhaust	369-9489
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
6V-5920	Gasket Kit - F	388-0653
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1220	Plunger As-Pump	419-4743
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-5218	Manifold-Exhaust	435-4786
7N-5219	Manifold-Exhaust	425-2362
7N-7435	Kit-Major Repair	374-4724
7N-8828	Pulley	420-6395
7W-0182	Plunger & Bbl As	391-9893

28V		
Original Part Number	Part Name	Classic Part Number
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-2104	Bell As-Suction	380-1521
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
8T-1631	Kit-Gasket-Mch	436-8375
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1161	Line As-Fuel Inj	383-3705
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9N-5529	Body-F Inj Valve	378-3993
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552

Sales Model 3408 (Cont'd.)

28V		
Original Part Number	**Part Name**	**Classic Part Number**
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504

28V		
Original Part Number	**Part Name**	**Classic Part Number**
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869

28V		
Original Part Number	**Part Name**	**Classic Part Number**
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
222-9154	Kit - Gasket	437-8133
232-2600	Kit-Gasket-Fs	437-8672
232-4658	Kit-Gasket-Fs	437-2037
233-8683	Kit-Gasket-Mch	393-1039
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

67U		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-0156	Core As-Oclr	416-5525
1W-2489	Muffler As	360-7870
1W-2491	Muffler As-Eject	360-7871
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

67U		
Original Part Number	**Part Name**	**Classic Part Number**
2D-5658	Bearing-Ball	301-4628
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2W-3391	Body As-F Inj V	383-3687
2W-4087	Gear As-Idler	418-9582
2W-5540	Core As-Radiator	363-7452
2W-6632	Core As-Rad	391-1096
2W-7610	Gear-Hyd Pump Dr	418-1940
2W-7614	Gear-Crankshaft	425-7752

67U		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7980	Camshaft As	378-3972
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-8463	Bearing-Roller	394-9193
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191

Sales Model 3408 (Cont'd.)

67U		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1186	Bearing-Sleeve	417-4519
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-1849	Pipe-Air	421-7143
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4539	Sleeve	314-8720
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4N-8204	Mount As	374-1449
4N-8434	Spider As-Fan	451-9030
4P-5884	Core As-Oclr	435-0196
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890

67U		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4S-8472	Hood As-Preclnr	296-1355
4W-0419	Core As-Oclr	379-0182
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161
5F-7404	Nut-Bearing Lock	308-9878
5F-8651	Bearing-Ball	420-3223
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379

67U		
Original Part Number	**Part Name**	**Classic Part Number**
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5M-9644	Bearing-Outer	384-5929
5N-1932	Shaft-Clutch	425-0216
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-1370	Bearing As-Rlr	416-2164
5P-2448	Bearing-Ball	399-6064
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9840	Kit-Gasket-Sch	437-8140
5P-9841	Gasket Kit - Vg	393-3626
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1032	Line As-Fuel Inj	390-0931
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922
6I-1038	Line As-Fuel Inj	390-0923
6I-4613	Plate-Spacer	380-7405
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015

Sales Model 3408 (Cont'd.)

67U		
Original Part Number	Part Name	Classic Part Number
6L-8968	Coupling-Exhaust	311-9381
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-4597	Coupling-Exhaust	369-9489
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6V-0214	Kit-Gasket-Mch	437-4590
6V-0216	Kit-Gasket-Sch	437-4589
6V-0233	Kit-Gasket-T	437-4586
6V-0237	Kit-Gasket-Exp	437-4584
6V-1033	Rod End-Spher	375-5444
6V-1181	Gasket Kit	437-4578
6V-1785	Kit-Gasket-Mch	437-3190
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-3205	Manifold-Inlet	376-9060
7E-3909	Tube-Exhaust	398-8339
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7L-4302	Gasket	420-8570
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1220	Plunger As-Pump	419-4743

67U		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
7N-5218	Manifold-Exhaust	435-4786
7N-5219	Manifold-Exhaust	425-2362
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-0205	Core As-Oclr	379-0183
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0784	Manifold-Mount	393-1044
8N-0935	Gear-Pump Drive	399-8569
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726

67U		
Original Part Number	Part Name	Classic Part Number
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
8T-2455	Gasket Kit	436-8396
8T-2500	Kit-Gasket	393-1028
8T-4870	Gasket Kit	436-8378
8T-6479	Gasket Kit	436-8377
8T-6485	Gasket Kit	436-8406
9H-2256	Pump Gp-F Prm	311-9443
9K-8757	Rod End-Special	311-9361
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1161	Line As-Fuel Inj	383-3705
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9N-5529	Body-F Inj Valve	378-3993
9S-7148	Cap As-Rain	378-3994
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938

Sales Model 3408 (Cont'd.)

67U		
Original Part Number	Part Name	Classic Part Number
9Y-0238	Line As-F Inj	390-0939
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463

67U		
Original Part Number	Part Name	Classic Part Number
110-1337	Ring Kit-Pstn	377-5834
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
123-6597	Gasket Kit	436-8421
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
140-2749	Gasket Kit	393-1033
140-2859	Kit-Gasket-Mch	437-3218
141-4109	Core As-Oclr	416-5518
142-3035	Kit-Gasket (Wlg)	393-0926
142-5093	Kit-Gasket (Acl)	437-4605

67U		
Original Part Number	Part Name	Classic Part Number
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
163-4109	Manifold-Exhaust	433-9857
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
216-4592	Gasket Kit - Ocl	437-8145
217-0586	Bearing-Rod	419-7266
232-1841	Kit-Gasket (Fs)	387-2922
232-2600	Kit-Gasket-Fs	437-8672
232-4658	Kit-Gasket-Fs	437-2037
233-8669	Kit-Gasket-Mch	393-1038
234-1630	Kit-Gasket(Rs)	393-1040
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
256-9653	Flywheel As.	425-3444
283-5666	Gasket-Cyl Head	388-6565
283-6443	Kit-Gasket-T	437-8652
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

78Z		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2489	Muffler As	360-7870

78Z		
Original Part Number	Part Name	Classic Part Number
1W-2491	Muffler As-Eject	360-7871
1W-5009	Crankshaft As	398-2969
1W-5910	Tappet As-Guide&	383-1569
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164

78Z		
Original Part Number	Part Name	Classic Part Number
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305

Sales Model 3408 (Cont'd.)

78Z		
Original Part Number	**Part Name**	**Classic Part Number**
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2W-3391	Body As-F Inj V	383-3687
2W-4087	Gear As-Idler	418-9582
2W-5540	Core As-Radiator	363-7452
2W-6632	Core As-Rad	391-1096
2W-7455	Gear As	396-9957
2W-7980	Camshaft As	378-3972
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-8463	Bearing-Roller	394-9193
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465

78Z		
Original Part Number	**Part Name**	**Classic Part Number**
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4539	Sleeve	314-8720
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8204	Mount As	374-1449
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571

78Z		
Original Part Number	**Part Name**	**Classic Part Number**
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5M-9644	Bearing-Outer	384-5929
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1032	Line As-Fuel Inj	390-0931

Sales Model 3408 (Cont'd.)

78Z		
Original Part Number	Part Name	Classic Part Number
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922
6I-1038	Line As-Fuel Inj	390-0923
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-4613	Plate-Spacer	380-7405
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7653	Gage As-O Level	428-7206
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6V-0214	Kit-Gasket-Mch	437-4590
6V-0229	Gasket Kit	437-4587
6V-0233	Kit-Gasket-T	437-4586
6V-1181	Gasket Kit	437-4578
6V-1785	Kit-Gasket-Mch	437-3190
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206

78Z		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-5218	Manifold-Exhaust	435-4786
7N-5219	Manifold-Exhaust	425-2362
7N-7166	Race-Brg Thrust	417-4531
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470

78Z		
Original Part Number	Part Name	Classic Part Number
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
8T-2455	Gasket Kit	436-8396
8T-4870	Gasket Kit	436-8378
9L-5839	Coupling-Exhaust	374-7480
9N-1161	Line As-Fuel Inj	383-3705
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-7735	Bearing-Rod	419-4665

Sales Model 3408 (Cont'd.)

78Z		
Original Part Number	Part Name	Classic Part Number
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
109-7687	Bearing-Ball	420-3220
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504

78Z		
Original Part Number	Part Name	Classic Part Number
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
142-5093	Kit-Gasket (Acl)	437-4605
143-1314	Kit-Gasket-T	437-4603
144-0482	Gasket	420-8547
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699

78Z		
Original Part Number	Part Name	Classic Part Number
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
216-4592	Gasket Kit - Ocl	437-8145
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-2600	Kit-Gasket-Fs	437-8672
232-4658	Kit-Gasket-Fs	437-2037
233-8668	Kit-Gasket-Mch	437-2030
233-8669	Kit-Gasket-Mch	393-1038
233-8683	Kit-Gasket-Mch	393-1039
233-9200	Kit-Gasket-Sch	393-0927
233-9466	Kit-Gasket-Sch	437-2026
234-1630	Kit-Gasket(Rs)	393-1040
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-5666	Gasket-Cyl Head	388-6565
283-6443	Kit-Gasket-T	437-8652
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
430-7619	Adapter-Cla	438-1812

99U		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398

99U		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294

99U		
Original Part Number	Part Name	Classic Part Number
1W-5009	Crankshaft As	398-2969
1W-6987	Valve As-Check	420-6221

Sales Model 3408 (Cont'd.)

99U		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2W-3391	Body As-F Inj V	383-3687
2W-4087	Gear As-Idler	418-9582
2W-7980	Camshaft As	378-3972
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-8463	Bearing-Roller	394-9193
4B-7255	Cone-Bearing	386-4951
4L-8473	Plate-Wear	419-0883
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473

99U		
Original Part Number	Part Name	Classic Part Number
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

99U		
Original Part Number	Part Name	Classic Part Number
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-5772	Race & Roller As	394-9200
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9656	Cone-Bearing	399-4448
5M-9644	Bearing-Outer	384-5929
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9840	Kit-Gasket-Sch	437-8140
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1032	Line As-Fuel Inj	390-0931

Sales Model 3408 (Cont'd.)

99U		
Original Part Number	Part Name	Classic Part Number
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922
6I-1038	Line As-Fuel Inj	390-0923
6I-4613	Plate-Spacer	380-7405
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6V-0214	Kit-Gasket-Mch	437-4590
6V-0216	Kit-Gasket-Sch	437-4589
6V-0229	Gasket Kit	437-4587
6V-0233	Kit-Gasket-T	437-4586
6V-0235	Gasket Kit	437-4585
6V-0237	Kit-Gasket-Exp	437-4584
6V-0241	Gasket Kit - F	393-3628
6V-1181	Gasket Kit	437-4578
6V-1785	Kit-Gasket-Mch	437-3190
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
6V-5920	Gasket Kit - F	388-0653
6V-9921	Gasket Kit	437-3236
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-5085	Bushing	377-5829

99U		
Original Part Number	Part Name	Classic Part Number
7E-5996	Rod As-Conn	379-8864
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1220	Plunger As-Pump	419-4743
7N-2156	Bearing-Sleeve	380-7373
7S-4411	Cap As-Rain	373-1912
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
8F-6058	Bearing-Sleeve	416-5494
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
8T-2499	Kit-Gasket-Sch	436-8383
8T-2500	Kit-Gasket	393-1028
9H-2256	Pump Gp-F Prm	311-9443
9K-1171	Cup-Rlr Bearing	430-3339
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9N-1161	Line As-Fuel Inj	383-3705
9N-3668	Base As.-Coolant	419-4718

99U		
Original Part Number	Part Name	Classic Part Number
9N-3970	Line As-Fuel Inj	390-1005
9N-5529	Body-F Inj Valve	378-3993
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
123-6597	Gasket Kit	436-8421
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
142-5093	Kit-Gasket (Acl)	437-4605
143-0905	Gasket Kit	437-4617
143-1314	Kit-Gasket-T	437-4603
145-2867	Kit-Gasket (Wp)	449-9830

Sales Model 3408 (Cont'd.)

99U		
Original Part Number	**Part Name**	**Classic Part Number**
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
208-6161	Gasket Kit - F	437-8150
208-6163	Kit-Gasket-Sch	437-2004
208-6165	Kit-Gasket-Mch	437-8149

99U		
Original Part Number	**Part Name**	**Classic Part Number**
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266
232-2600	Kit-Gasket-Fs	437-8672
232-4658	Kit-Gasket-Fs	437-2037
233-8668	Kit-Gasket-Mch	437-2030
233-9466	Kit-Gasket-Sch	437-2026
234-1630	Kit-Gasket(Rs)	393-1040
234-1985	Kit-Gasket-Fs	437-8666

99U		
Original Part Number	**Part Name**	**Classic Part Number**
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-5666	Gasket-Cyl Head	388-6565
283-6443	Kit-Gasket-T	437-8652
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

BEF		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-5009	Crankshaft As	398-2969
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-8986	Cup-Rlr Bearing	415-1912
2W-7610	Gear-Hyd Pump Dr	418-1940
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473

BEF		
Original Part Number	**Part Name**	**Classic Part Number**
4N-1119	Gear-Tfr Pump	373-1884
4N-1186	Bearing-Sleeve	417-4519
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4W-0452	Seal As -Cshaft	325-6191
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5F-7404	Nut-Bearing Lock	308-9878

BEF		
Original Part Number	**Part Name**	**Classic Part Number**
5P-1370	Bearing As-Rlr	416-2164
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5S-4557	Bearing	311-9360
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-4613	Plate-Spacer	380-7405
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959

Sales Model 3408 (Cont'd.)

BEF		
Original Part Number	**Part Name**	**Classic Part Number**
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7E-3205	Manifold-Inlet	376-9060
7E-3909	Tube-Exhaust	398-8339
7E-5085	Bushing	377-5829
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
8F-6058	Bearing-Sleeve	416-5494
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0784	Manifold-Mount	393-1044
8N-0935	Gear-Pump Drive	399-8569
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-3666	Repair Kt-Major	377-5842
8S-6511	Bearing-Sleeve	380-7372

BEF		
Original Part Number	**Part Name**	**Classic Part Number**
8S-9151	Cup-Spl Tapered	374-8348
9L-5961	Adapter-Compr Dr	416-5508
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917

BEF		
Original Part Number	**Part Name**	**Classic Part Number**
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-6500	Rotocoil As.	397-5053
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
180-6645	Shaft As.	396-1566
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266

BFF		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-5009	Crankshaft As	398-2969
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2M-4208	Spacer-Timing	417-4533

BFF		
Original Part Number	**Part Name**	**Classic Part Number**
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-8986	Cup-Rlr Bearing	415-1912
2W-7610	Gear-Hyd Pump Dr	418-1940
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017

BFF		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525

Sales Model 3408 (Cont'd.)

BFF		
Original Part Number	Part Name	Classic Part Number
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1186	Bearing-Sleeve	417-4519
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4W-0452	Seal As -Cshaft	325-6191
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5F-7404	Nut-Bearing Lock	308-9878
5P-1370	Bearing As-Rlr	416-2164
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5S-4557	Bearing	311-9360
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715

BFF		
Original Part Number	Part Name	Classic Part Number
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-4613	Plate-Spacer	380-7405
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7E-3205	Manifold-Inlet	376-9060
7E-3909	Tube-Exhaust	398-8339
7E-5085	Bushing	377-5829
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
8F-6058	Bearing-Sleeve	416-5494
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0784	Manifold-Mount	393-1044
8N-0935	Gear-Pump Drive	399-8569

BFF		
Original Part Number	Part Name	Classic Part Number
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-3666	Repair Kt-Major	377-5842
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
9L-5961	Adapter-Compr Dr	416-5508
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
122-0321	Valve-Exhaust	384-8698

Sales Model 3408 (Cont'd.)

BFF		
Original Part Number	**Part Name**	**Classic Part Number**
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582

BFF		
Original Part Number	**Part Name**	**Classic Part Number**
135-4928	Shaft-Water Pump	386-3813
137-6500	Rotocoil As.	397-5053
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992

BFF		
Original Part Number	**Part Name**	**Classic Part Number**
180-6645	Shaft As.	396-1566
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266

DLA		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-5009	Crankshaft As	398-2969
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-8986	Cup-Rlr Bearing	415-1912
2W-7610	Gear-Hyd Pump Dr	418-1940
2W-7614	Gear-Crankshaft	425-7752
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837

DLA		
Original Part Number	**Part Name**	**Classic Part Number**
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1186	Bearing-Sleeve	417-4519
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4W-0452	Seal As -Cshaft	325-6191
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5F-7404	Nut-Bearing Lock	308-9878
5P-1370	Bearing As-Rlr	416-2164

DLA		
Original Part Number	**Part Name**	**Classic Part Number**
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5S-4557	Bearing	311-9360
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-4613	Plate-Spacer	380-7405
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980

Sales Model 3408 (Cont'd.)

DLA		
Original Part Number	Part Name	Classic Part Number
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-3205	Manifold-Inlet	376-9060
7E-3909	Tube-Exhaust	398-8339
7E-5085	Bushing	377-5829
7M-7219	Bearing-Thrust	384-4816
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
8F-6058	Bearing-Sleeve	416-5494
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0784	Manifold-Mount	393-1044
8N-0788	Cover	440-0849
8N-0935	Gear-Pump Drive	399-8569
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-3666	Repair Kt-Major	377-5842
8S-6511	Bearing-Sleeve	380-7372

DLA		
Original Part Number	Part Name	Classic Part Number
8S-9151	Cup-Spl Tapered	374-8348
9L-5961	Adapter-Compr Dr	416-5508
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917

DLA		
Original Part Number	Part Name	Classic Part Number
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
163-3103	Manifold-Exh	430-8992
167-8126	Damper As	382-8019
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266

Sales Model 3408B

1LG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913

Sales Model 3408B (Cont'd.)

1LG		
Original Part Number	Part Name	Classic Part Number
1P-4693	Cup-Rlr Bearing	377-7398
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-5009	Crankshaft As	398-2969
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2W-4087	Gear As-Idler	418-9582
2W-7980	Camshaft As	378-3972
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928

1LG		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4W-2541	Shaft-Gov Cont	399-8580
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975

1LG		
Original Part Number	Part Name	Classic Part Number
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5M-9644	Bearing-Outer	384-5929
5S-4557	Bearing	311-9360
5S-4557	Bearing	311-9360
6B-3223	Cup-Bearing	399-6065
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-4613	Plate-Spacer	380-7405
6L-2279	Plug-Ptf	419-4739
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6V-0237	Kit-Gasket-Exp	437-4584
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373

Sales Model 3408B (Cont'd.)

1LG		
Original Part Number	Part Name	Classic Part Number
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
8T-2500	Kit-Gasket	393-1028
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508

1LG		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813

1LG		
Original Part Number	Part Name	Classic Part Number
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
142-5093	Kit-Gasket (Acl)	437-4605
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266
232-2600	Kit-Gasket-Fs	437-8672
233-8668	Kit-Gasket-Mch	437-2030
234-1630	Kit-Gasket(Rs)	393-1040
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-5666	Gasket-Cyl Head	388-6565
283-6443	Kit-Gasket-T	437-8652
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

28V		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1T-0043	Bearing-Ball	390-5294
1W-5009	Crankshaft As	398-2969
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305

28V		
Original Part Number	Part Name	Classic Part Number
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2W-3391	Body As-F Inj V	383-3687
2W-4087	Gear As-Idler	418-9582
2W-7980	Camshaft As	378-3972
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4M-6107	Bearing-Roller	380-7507

28V		
Original Part Number	Part Name	Classic Part Number
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837

Sales Model 3408B (Cont'd.)

28V		
Original Part Number	Part Name	Classic Part Number
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5F-8651	Bearing-Ball	420-3223
5L-9738	Coupling-Exhaust	311-9380
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9840	Kit-Gasket-Sch	437-8140
5P-9841	Gasket Kit - Vg	393-3626
5S-4557	Bearing	311-9360
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715

28V		
Original Part Number	Part Name	Classic Part Number
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1032	Line As-Fuel Inj	390-0931
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922
6I-1038	Line As-Fuel Inj	390-0923
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-4597	Coupling-Exhaust	369-9489
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
6V-5920	Gasket Kit - F	388-0653
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742

28V		
Original Part Number	Part Name	Classic Part Number
7N-1220	Plunger As-Pump	419-4743
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-5218	Manifold-Exhaust	435-4786
7N-5219	Manifold-Exhaust	425-2362
7N-7435	Kit-Major Repair	374-4724
7N-8828	Pulley	420-6395
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-2104	Bell As-Suction	380-1521
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
8T-1631	Kit-Gasket-Mch	436-8375
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9L-6371	Rod-Eye	363-7459

Sales Model 3408B (Cont'd.)

28V		
Original Part Number	Part Name	Classic Part Number
9N-0316	Bracket-Pulley	434-1993
9N-1161	Line As-Fuel Inj	383-3705
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9N-5529	Body-F Inj Valve	378-3993
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063

28V		
Original Part Number	Part Name	Classic Part Number
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554

28V		
Original Part Number	Part Name	Classic Part Number
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
222-9154	Kit - Gasket	437-8133
232-2600	Kit-Gasket-Fs	437-8672
232-4658	Kit-Gasket-Fs	437-2037
233-8683	Kit-Gasket-Mch	393-1039
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

2BG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-1367	Plunger-Valve	432-8913
1W-5009	Crankshaft As	398-2969
1W-5009	Crankshaft As	398-2969
1W-6987	Valve As-Check	420-6221
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9171	Bonnet-Valve	374-4707

2BG		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2N-5842	Screw-Bridge Adj	418-1934
2W-4087	Gear As-Idler	418-9582

2BG		
Original Part Number	Part Name	Classic Part Number
2W-4087	Gear As-Idler	418-9582
2W-7980	Camshaft As	378-3972
2W-7980	Camshaft As	378-3972
3E-6772	Seal-Water	382-8017
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-1968	Mount-Shock	397-5046
3N-3786	Rod-Thrt Cont	397-5051
3N-3786	Rod-Thrt Cont	397-5051
4N-0342	Plate-Cam Thrust	375-9974
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722

Sales Model 3408B (Cont'd.)

2BG		
Original Part Number	Part Name	Classic Part Number
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1010	Support-Elbow	416-5509
4N-1015	Bearing-Sleeve	417-4525
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-1675	Manifold-Exhaust	443-2015
4N-2514	Gear-Flywheel	421-7283
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4520	Guide	388-6600

2BG		
Original Part Number	Part Name	Classic Part Number
4N-4539	Sleeve	314-8720
4N-4539	Sleeve	314-8720
4N-4668	Breather-Engine	396-7271
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-6658	Bearing-Sleeve	373-1885
4N-8204	Mount As	374-1449
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7807	Line As-Fuel Inj	373-1894

2BG		
Original Part Number	Part Name	Classic Part Number
4P-7808	Line As-Fuel Inj	373-1895
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4P-7812	Line As-Fuel Inj	373-1899
4W-2541	Shaft-Gov Cont	399-8580
4W-2541	Shaft-Gov Cont	399-8580
4W-5477	Pump Gp-F Tfr	380-1512
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-5998	Rod-Valve Push	379-0168

Sales Model 3408B (Cont'd.)

2BG		
Original Part Number	Part Name	Classic Part Number
5S-4557	Bearing	311-9360
5S-4557	Bearing	311-9360
6I-0031	Line As-Fuel Inj	374-4713
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-0038	Line As-Fuel Inj	374-4719
6I-4613	Plate-Spacer	380-7405
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7174	Shield-Oil	314-8544

2BG		
Original Part Number	Part Name	Classic Part Number
6N-7175	Rotocoil As	382-8042
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6N-9133	Gasket-Plate	398-2959
6V-2543	Gasket Kit	437-3206
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-3039	Core As-Oclr	363-7451
7E-5085	Bushing	377-5829
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-5996	Rod As-Conn	379-8864
7M-7219	Bearing-Thrust	384-4816
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7N-2156	Bearing-Sleeve	380-7373
7N-8828	Pulley	420-6395
7N-8828	Pulley	420-6395
7W-0182	Plunger & Bbl As	391-9893
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996

2BG		
Original Part Number	Part Name	Classic Part Number
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5435	Adapter-Nozzle	374-7493
8D-0983	Mounting	384-3470
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0561	Gear-Pump Idler	373-1886
8N-2104	Bell As-Suction	380-1521
8N-2104	Bell As-Suction	380-1521
8N-3248	Gasket As	415-1893
8N-3248	Gasket As	415-1893
8N-5305	Spacer	363-7464
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
8S-6511	Bearing-Sleeve	380-7372
8T-2455	Gasket Kit	436-8396
9L-5839	Coupling-Exhaust	374-7480
9Y-2988	Breather As	361-1716
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998

Sales Model 3408B (Cont'd.)

2BG		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
108-7930	Bearing As	377-7463

2BG		
Original Part Number	**Part Name**	**Classic Part Number**
115-2367	Valve-Exhaust	384-8700
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
127-6356	Cover As.-Pump	420-8566
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
137-6500	Rotocoil As.	397-5053
145-2867	Kit-Gasket (Wp)	449-9830

2BG		
Original Part Number	**Part Name**	**Classic Part Number**
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
160-9874	Kit-Gasket-Scl	386-3048
202-3572	Shaft As-Drive	426-0037
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
216-4592	Gasket Kit - Ocl	437-8145
217-0586	Bearing-Rod	419-7266
217-0586	Bearing-Rod	419-7266
232-2600	Kit-Gasket-Fs	437-8672
232-2600	Kit-Gasket-Fs	437-8672
233-8669	Kit-Gasket-Mch	393-1038
234-1630	Kit-Gasket(Rs)	393-1040
253-1752	Plate-Thrust	379-0170
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-5666	Gasket-Cyl Head	388-6565
283-5666	Gasket-Cyl Head	388-6565
283-6443	Kit-Gasket-T	437-8652
321-5746	Bearing-Main	419-6367
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
352-0209	Pump Gp-Water -B	375-4336

67U		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1S-7056	Bearing-Ball	422-6483

67U		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
1W-0156	Core As-Oclr	416-5525
1W-2489	Muffler As	360-7870
1W-2491	Muffler As-Eject	360-7871

67U		
Original Part Number	**Part Name**	**Classic Part Number**
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221

Sales Model 3408B (Cont'd.)

67U		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2W-3391	Body As-F Inj V	383-3687
2W-4087	Gear As-Idler	418-9582
2W-5540	Core As-Radiator	363-7452
2W-6632	Core As-Rad	391-1096
2W-7610	Gear-Hyd Pump Dr	418-1940
2W-7614	Gear-Crankshaft	425-7752
2W-7980	Camshaft As	378-3972
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-8463	Bearing-Roller	394-9193
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191

67U		
Original Part Number	Part Name	Classic Part Number
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1186	Bearing-Sleeve	417-4519
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-1849	Pipe-Air	421-7143
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4539	Sleeve	314-8720
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4N-8204	Mount As	374-1449
4N-8434	Spider As-Fan	451-9030
4P-5884	Core As-Oclr	435-0196
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890

67U		
Original Part Number	Part Name	Classic Part Number
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4S-8472	Hood As-Preclnr	296-1355
4W-0419	Core As-Oclr	379-0182
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161
5F-7404	Nut-Bearing Lock	308-9878
5F-8651	Bearing-Ball	420-3223
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379

Sales Model 3408B (Cont'd.)

67U		
Original Part Number	Part Name	Classic Part Number
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5M-9644	Bearing-Outer	384-5929
5N-1932	Shaft-Clutch	425-0216
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-1370	Bearing As-Rlr	416-2164
5P-2448	Bearing-Ball	399-6064
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9840	Kit-Gasket-Sch	437-8140
5P-9841	Gasket Kit - Vg	393-3626
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1032	Line As-Fuel Inj	390-0931
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922
6I-1038	Line As-Fuel Inj	390-0923
6I-4613	Plate-Spacer	380-7405
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015

67U		
Original Part Number	Part Name	Classic Part Number
6L-8968	Coupling-Exhaust	311-9381
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-4597	Coupling-Exhaust	369-9489
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6V-0214	Kit-Gasket-Mch	437-4590
6V-0216	Kit-Gasket-Sch	437-4589
6V-0233	Kit-Gasket-T	437-4586
6V-0237	Kit-Gasket-Exp	437-4584
6V-1033	Rod End-Spher	375-5444
6V-1181	Gasket Kit	437-4578
6V-1785	Kit-Gasket-Mch	437-3190
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-3205	Manifold-Inlet	376-9060
7E-3909	Tube-Exhaust	398-8339
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7L-4302	Gasket	420-8570
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1220	Plunger As-Pump	419-4743

67U		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
7N-5218	Manifold-Exhaust	435-4786
7N-5219	Manifold-Exhaust	425-2362
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-0205	Core As-Oclr	379-0183
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0784	Manifold-Mount	393-1044
8N-0935	Gear-Pump Drive	399-8569
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726

Sales Model 3408B (Cont'd.)

67U		
Original Part Number	Part Name	Classic Part Number
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
8T-2455	Gasket Kit	436-8396
8T-2500	Kit-Gasket	393-1028
8T-4870	Gasket Kit	436-8378
8T-6479	Gasket Kit	436-8377
8T-6485	Gasket Kit	436-8406
9H-2256	Pump Gp-F Prm	311-9443
9K-8757	Rod End-Special	311-9361
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1161	Line As-Fuel Inj	383-3705
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9N-5529	Body-F Inj Valve	378-3993
9S-7148	Cap As-Rain	378-3994
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938

67U		
Original Part Number	Part Name	Classic Part Number
9Y-0238	Line As-F Inj	390-0939
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
123-6597	Gasket Kit	436-8421
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814

67U		
Original Part Number	Part Name	Classic Part Number
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
140-2749	Gasket Kit	393-1033
140-2859	Kit-Gasket-Mch	437-3218
141-4109	Core As-Oclr	416-5518
142-3035	Kit-Gasket (Wlg)	393-0926
142-5093	Kit-Gasket (Acl)	437-4605
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
163-4109	Manifold-Exhaust	433-9857
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
216-4592	Gasket Kit - Ocl	437-8145
217-0586	Bearing-Rod	419-7266
232-1841	Kit-Gasket (Fs)	387-2922
232-2600	Kit-Gasket-Fs	437-8672
232-4658	Kit-Gasket-Fs	437-2037
233-8669	Kit-Gasket-Mch	393-1038
234-1630	Kit-Gasket(Rs)	393-1040
253-1752	Plate-Thrust	379-0170

Sales Model 3408B (Cont'd.)

67U		
Original Part Number	Part Name	Classic Part Number
255-6863	Gasket	450-5024
256-9653	Flywheel As.	425-3444
283-5666	Gasket-Cyl Head	388-6565

67U		
Original Part Number	Part Name	Classic Part Number
283-6443	Kit-Gasket-T	437-8652
321-5746	Bearing-Main	419-6367

67U		
Original Part Number	Part Name	Classic Part Number
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

6NB		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-5009	Crankshaft As	398-2969
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-4087	Gear As-Idler	418-9582
2W-5540	Core As-Radiator	363-7452
2W-7980	Camshaft As	378-3972
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-8463	Bearing-Roller	394-9193
4B-7270	Cone-Bearing	399-4439
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837

6NB		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5N-1932	Shaft-Clutch	425-0216
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065

6NB		
Original Part Number	Part Name	Classic Part Number
6I-4613	Plate-Spacer	380-7405
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7L-4302	Gasket	420-8570
7N-2156	Bearing-Sleeve	380-7373
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3145	Plate	422-7894
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342

Sales Model 3408B (Cont'd.)

6NB		
Original Part Number	Part Name	Classic Part Number
8L-4282	Hub	444-0573
8N-2104	Bell As-Suction	380-1521
8N-3248	Gasket As	415-1893
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9L-5961	Adapter-Compr Dr	416-5508
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
104-9635	Kit-Gasket-Sch	436-8415
108-5603	Screw-Adj Arm	379-0166

6NB		
Original Part Number	Part Name	Classic Part Number
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-3237	Precleaner As	432-4220
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
130-6856	Pre-Cleaner As	361-1717
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
142-3035	Kit-Gasket (Wlg)	393-0926

6NB		
Original Part Number	Part Name	Classic Part Number
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
217-7884	Gasket Kit - Wp	437-8143
232-2600	Kit-Gasket-Fs	437-8672
234-1630	Kit-Gasket(Rs)	393-1040
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

78Z		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2489	Muffler As	360-7870
1W-2491	Muffler As-Eject	360-7871
1W-5009	Crankshaft As	398-2969
1W-5910	Tappet As-Guide&	383-1569
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164

78Z		
Original Part Number	Part Name	Classic Part Number
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2W-3391	Body As-F Inj V	383-3687
2W-4087	Gear As-Idler	418-9582
2W-5540	Core As-Radiator	363-7452

78Z		
Original Part Number	Part Name	Classic Part Number
2W-6632	Core As-Rad	391-1096
2W-7455	Gear As	396-9957
2W-7980	Camshaft As	378-3972
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-8463	Bearing-Roller	394-9193
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0614	Cap-Crankshaft	448-9156

Sales Model 3408B (Cont'd.)

78Z		
Original Part Number	Part Name	Classic Part Number
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4539	Sleeve	314-8720
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8204	Mount As	374-1449
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891

78Z		
Original Part Number	Part Name	Classic Part Number
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5M-9644	Bearing-Outer	384-5929
5N-2902	Seal-Oil	314-8540

78Z		
Original Part Number	Part Name	Classic Part Number
5N-4504	Plate-Port	397-5048
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1032	Line As-Fuel Inj	390-0931
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922
6I-1038	Line As-Fuel Inj	390-0923
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-4613	Plate-Spacer	380-7405
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171

Sales Model 3408B (Cont'd.)

78Z		
Original Part Number	Part Name	Classic Part Number
6N-3025	Tube As	419-4656
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7653	Gage As-O Level	428-7206
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6V-0214	Kit-Gasket-Mch	437-4590
6V-0229	Gasket Kit	437-4587
6V-0233	Kit-Gasket-T	437-4586
6V-1181	Gasket Kit	437-4578
6V-1785	Kit-Gasket-Mch	437-3190
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373

78Z		
Original Part Number	Part Name	Classic Part Number
7N-5218	Manifold-Exhaust	435-4786
7N-5219	Manifold-Exhaust	425-2362
7N-7166	Race-Brg Thrust	417-4531
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
8T-2455	Gasket Kit	436-8396
8T-4870	Gasket Kit	436-8378
9L-5839	Coupling-Exhaust	374-7480

78Z		
Original Part Number	Part Name	Classic Part Number
9N-1161	Line As-Fuel Inj	383-3705
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744

Sales Model 3408B (Cont'd.)

78Z		
Original Part Number	Part Name	Classic Part Number
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
109-7687	Bearing-Ball	420-3220
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457

78Z		
Original Part Number	Part Name	Classic Part Number
142-5093	Kit-Gasket (Acl)	437-4605
143-1314	Kit-Gasket-T	437-4603
144-0482	Gasket	420-8547
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013

78Z		
Original Part Number	Part Name	Classic Part Number
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
216-4592	Gasket Kit - Ocl	437-8145
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-2600	Kit-Gasket-Fs	437-8672
232-4658	Kit-Gasket-Fs	437-2037
233-8668	Kit-Gasket-Mch	437-2030
233-8669	Kit-Gasket-Mch	393-1038
233-8683	Kit-Gasket-Mch	393-1039
233-9200	Kit-Gasket-Sch	393-0927
233-9466	Kit-Gasket-Sch	437-2026
234-1630	Kit-Gasket(Rs)	393-1040
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-5666	Gasket-Cyl Head	388-6565
283-6443	Kit-Gasket-T	437-8652
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
430-7619	Adapter-Cla	438-1812

8RG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-5009	Crankshaft As	398-2969
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7980	Camshaft As	378-3972
3E-6772	Seal-Water	382-8017

8RG		
Original Part Number	Part Name	Classic Part Number
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-1767	Valve-Bypass	419-4716

8RG		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

Sales Model 3408B (Cont'd.)

8RG		
Original Part Number	Part Name	Classic Part Number
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5P-7807	Bearing-Ball	314-8502
6I-4613	Plate-Spacer	380-7405
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-3039	Core As-Oclr	363-7451
7E-9907	Spacer-Fp Timing	394-0222
7N-2156	Bearing-Sleeve	380-7373
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475

8RG		
Original Part Number	Part Name	Classic Part Number
7W-5435	Adapter-Nozzle	374-7493
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9L-5961	Adapter-Compr Dr	416-5508
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704

8RG		
Original Part Number	Part Name	Classic Part Number
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
145-8503	Shaft As-Idler	426-0035
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

99U		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-5009	Crankshaft As	398-2969
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174

99U		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934

99U		
Original Part Number	Part Name	Classic Part Number
2W-3391	Body As-F Inj V	383-3687
2W-4087	Gear As-Idler	418-9582
2W-7980	Camshaft As	378-3972
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-8463	Bearing-Roller	394-9193
4B-7255	Cone-Bearing	386-4951

Sales Model 3408B (Cont'd.)

99U		
Original Part Number	Part Name	Classic Part Number
4L-8473	Plate-Wear	419-0883
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894

99U		
Original Part Number	Part Name	Classic Part Number
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-5772	Race & Roller As	394-9200
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9656	Cone-Bearing	399-4448
5M-9644	Bearing-Outer	384-5929
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9840	Kit-Gasket-Sch	437-8140
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713

99U		
Original Part Number	Part Name	Classic Part Number
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1032	Line As-Fuel Inj	390-0931
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922
6I-1038	Line As-Fuel Inj	390-0923
6I-4613	Plate-Spacer	380-7405
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6V-0214	Kit-Gasket-Mch	437-4590
6V-0216	Kit-Gasket-Sch	437-4589
6V-0229	Gasket Kit	437-4587
6V-0233	Kit-Gasket-T	437-4586
6V-0235	Gasket Kit	437-4585
6V-0237	Kit-Gasket-Exp	437-4584

Sales Model 3408B (Cont'd.)

99U		
Original Part Number	Part Name	Classic Part Number
6V-0241	Gasket Kit - F	393-3628
6V-1181	Gasket Kit	437-4578
6V-1785	Kit-Gasket-Mch	437-3190
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
6V-5920	Gasket Kit - F	388-0653
6V-9921	Gasket Kit	437-3236
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1220	Plunger As-Pump	419-4743
7N-2156	Bearing-Sleeve	380-7373
7S-4411	Cap As-Rain	373-1912
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
8F-6058	Bearing-Sleeve	416-5494
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8S-3653	Bonnet-Valve	374-4728

99U		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
8T-2499	Kit-Gasket-Sch	436-8383
8T-2500	Kit-Gasket	393-1028
9H-2256	Pump Gp-F Prm	311-9443
9K-1171	Cup-Rlr Bearing	430-3339
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9N-1161	Line As-Fuel Inj	383-3705
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9N-5529	Body-F Inj Valve	378-3993
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
123-6597	Gasket Kit	436-8421
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566

99U		
Original Part Number	Part Name	Classic Part Number
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
142-5093	Kit-Gasket (Acl)	437-4605
143-0905	Gasket Kit	437-4617
143-1314	Kit-Gasket-T	437-4603
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
208-6161	Gasket Kit - F	437-8150
208-6163	Kit-Gasket-Sch	437-2004
208-6165	Kit-Gasket-Mch	437-8149
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266
232-2600	Kit-Gasket-Fs	437-8672
232-4658	Kit-Gasket-Fs	437-2037
233-8668	Kit-Gasket-Mch	437-2030
233-9466	Kit-Gasket-Sch	437-2026
234-1630	Kit-Gasket(Rs)	393-1040
234-1985	Kit-Gasket-Fs	437-8666
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-5666	Gasket-Cyl Head	388-6565
283-6443	Kit-Gasket-T	437-8652
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

Sales Model 3408B (Cont'd.)

9TD		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-5009	Crankshaft As	398-2969
1W-5009	Crankshaft As	398-2969
1W-6987	Valve As-Check	420-6221
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2N-5842	Screw-Bridge Adj	418-1934
2W-4087	Gear As-Idler	418-9582
2W-4087	Gear As-Idler	418-9582
2W-7980	Camshaft As	378-3972
2W-7980	Camshaft As	378-3972
3E-6772	Seal-Water	382-8017
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3786	Rod-Thrt Cont	397-5051
3N-3786	Rod-Thrt Cont	397-5051
4N-0342	Plate-Cam Thrust	375-9974
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0362	Cover As-Rgltr	419-4722

9TD		
Original Part Number	Part Name	Classic Part Number
4N-0614	Cap-Crankshaft	448-9156
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1010	Support-Elbow	416-5509
4N-1015	Bearing-Sleeve	417-4525
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-1675	Manifold-Exhaust	443-2015
4N-2514	Gear-Flywheel	421-7283
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271

9TD		
Original Part Number	Part Name	Classic Part Number
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4W-2541	Shaft-Gov Cont	399-8580
4W-2541	Shaft-Gov Cont	399-8580
4W-5477	Pump Gp-F Tfr	380-1512
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5700	Bearing-Main	419-6320

Sales Model 3408B (Cont'd.)

9TD		
Original Part Number	Part Name	Classic Part Number
4W-5701	Bearing-Main	419-6333
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5S-4557	Bearing	311-9360
5S-4557	Bearing	311-9360
6I-0031	Line As-Fuel Inj	374-4713
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0037	Line As-Fuel Inj	374-4718

9TD		
Original Part Number	Part Name	Classic Part Number
6I-0038	Line As-Fuel Inj	374-4719
6I-0038	Line As-Fuel Inj	374-4719
6I-4613	Plate-Spacer	380-7405
6I-4613	Plate-Spacer	380-7405
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6N-9133	Gasket-Plate	398-2959
6V-3831	Seal-O-Ring	436-2657
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-3039	Core As-Oclr	363-7451
7E-5085	Bushing	377-5829
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-5996	Rod As-Conn	379-8864
7M-7219	Bearing-Thrust	384-4816
7M-7219	Bearing-Thrust	384-4816

9TD		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
7N-2156	Bearing-Sleeve	380-7373
7W-0182	Plunger & Bbl As	391-9893
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5435	Adapter-Nozzle	374-7493
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0561	Gear-Pump Idler	373-1886
8N-2104	Bell As-Suction	380-1521
8N-2104	Bell As-Suction	380-1521
8N-3248	Gasket As	415-1893
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372

Sales Model 3408B (Cont'd.)

9TD		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
8T-4870	Gasket Kit	436-8378
8T-6479	Gasket Kit	436-8377
9L-5839	Coupling-Exhaust	374-7480
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9Y-2988	Breather As	361-1716
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487

9TD		
Original Part Number	Part Name	Classic Part Number
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
131-3815	Seal Gp-Basic	325-6193
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813

9TD		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
137-6500	Rotocoil As.	397-5053
145-8503	Shaft As-Idler	426-0035
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
160-9874	Kit-Gasket-Scl	386-3048
202-3572	Shaft As-Drive	426-0037
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266
217-0586	Bearing-Rod	419-7266
232-2600	Kit-Gasket-Fs	437-8672
233-8669	Kit-Gasket-Mch	393-1038
234-1630	Kit-Gasket(Rs)	393-1040
253-1752	Plate-Thrust	379-0170
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
255-6863	Gasket	450-5024
256-9653	Flywheel As.	425-3444
283-5666	Gasket-Cyl Head	388-6565
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
352-0209	Pump Gp-Water -B	375-4336

BFD		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-5009	Crankshaft As	398-2969

BFD		
Original Part Number	Part Name	Classic Part Number
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705

BFD		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

Sales Model 3408B (Cont'd.)

BFD		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2W-7610	Gear-Hyd Pump Dr	418-1940
2W-7614	Gear-Crankshaft	425-7752
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1106	Shaft As-Rocker	377-5837
4N-1119	Gear-Tfr Pump	373-1884
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5F-7404	Nut-Bearing Lock	308-9878
5P-1370	Bearing As-Rlr	416-2164
6I-0031	Line As-Fuel Inj	374-4713

BFD		
Original Part Number	Part Name	Classic Part Number
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7M-7219	Bearing-Thrust	384-4816
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
8F-6058	Bearing-Sleeve	416-5494

BFD		
Original Part Number	Part Name	Classic Part Number
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917

Sales Model 3408B (Cont'd.)

BFD		
Original Part Number	**Part Name**	**Classic Part Number**
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703

BFD		
Original Part Number	**Part Name**	**Classic Part Number**
124-7609	Gear-Pump Idler	428-8504
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-6500	Rotocoil As.	397-5053
145-8503	Shaft As-Idler	426-0035
155-6637	Gear-Oil Drive	425-9189

BFD		
Original Part Number	**Part Name**	**Classic Part Number**
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
180-6645	Shaft As.	396-1566
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266

Sales Model 3408C

1TS		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-5009	Crankshaft As	398-2969
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2W-4087	Gear As-Idler	418-9582
2W-7980	Camshaft As	378-3972
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3786	Rod-Thrt Cont	397-5051
3N-8463	Bearing-Roller	394-9193
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974

1TS		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157

1TS		
Original Part Number	**Part Name**	**Classic Part Number**
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898

Sales Model 3408C (Cont'd.)

1TS		
Original Part Number	Part Name	Classic Part Number
4P-7812	Line As-Fuel Inj	373-1899
4W-2541	Shaft-Gov Cont	399-8580
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5M-9644	Bearing-Outer	384-5929
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-2448	Bearing-Ball	399-6064
5S-4557	Bearing	311-9360
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-4613	Plate-Spacer	380-7405
6L-2279	Plug-Ptf	419-4739
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556

1TS		
Original Part Number	Part Name	Classic Part Number
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6V-0233	Kit-Gasket-T	437-4586
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-3248	Gasket As	415-1893
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372

1TS		
Original Part Number	Part Name	Classic Part Number
8T-0209	Race-Spl Rlr Brg	384-5951
9L-5839	Coupling-Exhaust	374-7480
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
109-7687	Bearing-Ball	420-3220
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
123-6597	Gasket Kit	436-8421
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053

Sales Model 3408C (Cont'd.)

1TS		
Original Part Number	**Part Name**	**Classic Part Number**
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
202-3572	Shaft As-Drive	426-0037
208-6163	Kit-Gasket-Sch	437-2004
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266

1TS		
Original Part Number	**Part Name**	**Classic Part Number**
217-7884	Gasket Kit - Wp	437-8143
232-2600	Kit-Gasket-Fs	437-8672
232-6173	Kit-Gasket-Fs	393-0923
233-8668	Kit-Gasket-Mch	437-2030
234-1630	Kit-Gasket(Rs)	393-1040
253-1752	Plate-Thrust	379-0170

1TS		
Original Part Number	**Part Name**	**Classic Part Number**
255-6863	Gasket	450-5024
283-5666	Gasket-Cyl Head	388-6565
283-6443	Kit-Gasket-T	437-8652
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

67U		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-0156	Core As-Oclr	416-5525
1W-2489	Muffler As	360-7870
1W-2491	Muffler As-Eject	360-7871
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2W-3391	Body As-F Inj V	383-3687
2W-4087	Gear As-Idler	418-9582

67U		
Original Part Number	**Part Name**	**Classic Part Number**
2W-5540	Core As-Radiator	363-7452
2W-6632	Core As-Rad	391-1096
2W-7610	Gear-Hyd Pump Dr	418-1940
2W-7614	Gear-Crankshaft	425-7752
2W-7980	Camshaft As	378-3972
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-8463	Bearing-Roller	394-9193
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837

67U		
Original Part Number	**Part Name**	**Classic Part Number**
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1186	Bearing-Sleeve	417-4519
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-1849	Pipe-Air	421-7143
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4539	Sleeve	314-8720
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4N-8204	Mount As	374-1449
4N-8434	Spider As-Fan	451-9030
4P-5884	Core As-Oclr	435-0196
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888

Sales Model 3408C (Cont'd.)

67U		
Original Part Number	Part Name	Classic Part Number
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4S-8472	Hood As-Preclnr	296-1355
4W-0419	Core As-Oclr	379-0182
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161
5F-7404	Nut-Bearing Lock	308-9878
5F-8651	Bearing-Ball	420-3223
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711

67U		
Original Part Number	Part Name	Classic Part Number
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5M-9644	Bearing-Outer	384-5929
5N-1932	Shaft-Clutch	425-0216
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-1370	Bearing As-Rlr	416-2164
5P-2448	Bearing-Ball	399-6064
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9840	Kit-Gasket-Sch	437-8140
5P-9841	Gasket Kit - Vg	393-3626
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1032	Line As-Fuel Inj	390-0931
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922
6I-1038	Line As-Fuel Inj	390-0923
6I-4613	Plate-Spacer	380-7405

67U		
Original Part Number	Part Name	Classic Part Number
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-4597	Coupling-Exhaust	369-9489
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6V-0214	Kit-Gasket-Mch	437-4590
6V-0216	Kit-Gasket-Sch	437-4589
6V-0233	Kit-Gasket-T	437-4586
6V-0237	Kit-Gasket-Exp	437-4584
6V-1033	Rod End-Spher	375-5444
6V-1181	Gasket Kit	437-4578
6V-1785	Kit-Gasket-Mch	437-3190
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-3205	Manifold-Inlet	376-9060
7E-3909	Tube-Exhaust	398-8339
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7L-4302	Gasket	420-8570
7M-7219	Bearing-Thrust	384-4816

Sales Model 3408C (Cont'd.)

67U		
Original Part Number	Part Name	Classic Part Number
7N-1183	Plunger As-Fuel	419-4742
7N-1220	Plunger As-Pump	419-4743
7N-2156	Bearing-Sleeve	380-7373
7N-5218	Manifold-Exhaust	435-4786
7N-5219	Manifold-Exhaust	425-2362
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-0205	Core As-Oclr	379-0183
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3580	Bracket-Mtg	418-1939
7W-5435	Adapter-Nozzle	374-7493
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0784	Manifold-Mount	393-1044
8N-0935	Gear-Pump Drive	399-8569
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856

67U		
Original Part Number	Part Name	Classic Part Number
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
8T-2455	Gasket Kit	436-8396
8T-2500	Kit-Gasket	393-1028
8T-4870	Gasket Kit	436-8378
8T-6479	Gasket Kit	436-8377
8T-6485	Gasket Kit	436-8406
9H-2256	Pump Gp-F Prm	311-9443
9K-8757	Rod End-Special	311-9361
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-1161	Line As-Fuel Inj	383-3705
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9N-5529	Body-F Inj Valve	378-3993
9S-7148	Cap As-Rain	378-3994
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934

67U		
Original Part Number	Part Name	Classic Part Number
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
123-6597	Gasket Kit	436-8421
124-7609	Gear-Pump Idler	428-8504

Sales Model 3408C (Cont'd.)

67U		
Original Part Number	**Part Name**	**Classic Part Number**
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
140-2749	Gasket Kit	393-1033
140-2859	Kit-Gasket-Mch	437-3218

67U		
Original Part Number	**Part Name**	**Classic Part Number**
141-4109	Core As-Oclr	416-5518
142-3035	Kit-Gasket (Wlg)	393-0926
142-5093	Kit-Gasket (Acl)	437-4605
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
163-4109	Manifold-Exhaust	433-9857
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368

67U		
Original Part Number	**Part Name**	**Classic Part Number**
214-6045	Bellows As	435-4846
216-4592	Gasket Kit - Ocl	437-8145
217-0586	Bearing-Rod	419-7266
232-1841	Kit-Gasket (Fs)	387-2922
232-2600	Kit-Gasket-Fs	437-8672
232-4658	Kit-Gasket-Fs	437-2037
233-8669	Kit-Gasket-Mch	393-1038
234-1630	Kit-Gasket(Rs)	393-1040
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
256-9653	Flywheel As.	425-3444
283-5666	Gasket-Cyl Head	388-6565
283-6443	Kit-Gasket-T	437-8652
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

78Z		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2489	Muffler As	360-7870
1W-2491	Muffler As-Eject	360-7871
1W-5009	Crankshaft As	398-2969
1W-5910	Tappet As-Guide&	383-1569
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

78Z		
Original Part Number	**Part Name**	**Classic Part Number**
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2W-3391	Body As-F Inj V	383-3687
2W-4087	Gear As-Idler	418-9582
2W-5540	Core As-Radiator	363-7452
2W-6632	Core As-Rad	391-1096
2W-7455	Gear As	396-9957
2W-7980	Camshaft As	378-3972
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-8463	Bearing-Roller	394-9193
4M-6107	Bearing-Roller	380-7507

78Z		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928

Sales Model 3408C (Cont'd.)

78Z		
Original Part Number	Part Name	Classic Part Number
4N-1675	Manifold-Exhaust	443-2015
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4539	Sleeve	314-8720
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8204	Mount As	374-1449
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899

78Z		
Original Part Number	Part Name	Classic Part Number
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5M-9644	Bearing-Outer	384-5929
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717

78Z		
Original Part Number	Part Name	Classic Part Number
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1032	Line As-Fuel Inj	390-0931
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922
6I-1038	Line As-Fuel Inj	390-0923
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-4613	Plate-Spacer	380-7405
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7653	Gage As-O Level	428-7206
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6V-0214	Kit-Gasket-Mch	437-4590
6V-0229	Gasket Kit	437-4587
6V-0233	Kit-Gasket-T	437-4586

Sales Model 3408C (Cont'd.)

78Z		
Original Part Number	Part Name	Classic Part Number
6V-1181	Gasket Kit	437-4578
6V-1785	Kit-Gasket-Mch	437-3190
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-5218	Manifold-Exhaust	435-4786
7N-5219	Manifold-Exhaust	425-2362
7N-7166	Race-Brg Thrust	417-4531
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996

78Z		
Original Part Number	Part Name	Classic Part Number
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
8T-2455	Gasket Kit	436-8396
8T-4870	Gasket Kit	436-8378
9L-5839	Coupling-Exhaust	374-7480
9N-1161	Line As-Fuel Inj	383-3705
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939

78Z		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
109-7687	Bearing-Ball	420-3220
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566

Sales Model 3408C (Cont'd.)

78Z		
Original Part Number	Part Name	Classic Part Number
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
142-5093	Kit-Gasket (Acl)	437-4605
143-1314	Kit-Gasket-T	437-4603
144-0482	Gasket	420-8547
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869

78Z		
Original Part Number	Part Name	Classic Part Number
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
216-4592	Gasket Kit - Ocl	437-8145
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266

78Z		
Original Part Number	Part Name	Classic Part Number
232-2600	Kit-Gasket-Fs	437-8672
232-4658	Kit-Gasket-Fs	437-2037
233-8668	Kit-Gasket-Mch	437-2030
233-8669	Kit-Gasket-Mch	393-1038
233-8683	Kit-Gasket-Mch	393-1039
233-9200	Kit-Gasket-Sch	393-0927
233-9466	Kit-Gasket-Sch	437-2026
234-1630	Kit-Gasket(Rs)	393-1040
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-5666	Gasket-Cyl Head	388-6565
283-6443	Kit-Gasket-T	437-8652
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
430-7619	Adapter-Cla	438-1812

8RG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-5009	Crankshaft As	398-2969
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7980	Camshaft As	378-3972
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156

8RG		
Original Part Number	Part Name	Classic Part Number
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216

8RG		
Original Part Number	Part Name	Classic Part Number
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5P-7807	Bearing-Ball	314-8502
6I-4613	Plate-Spacer	380-7405
6N-1931	Plunger	379-0171

Sales Model 3408C (Cont'd.)

8RG		
Original Part Number	**Part Name**	**Classic Part Number**
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-3039	Core As-Oclr	363-7451
7E-9907	Spacer-Fp Timing	394-0222
7N-2156	Bearing-Sleeve	380-7373
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9L-5961	Adapter-Compr Dr	416-5508
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998

8RG		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193

8RG		
Original Part Number	**Part Name**	**Classic Part Number**
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
145-8503	Shaft As-Idler	426-0035
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

99U		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-5009	Crankshaft As	398-2969
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9454	Cup-Roller Brg	415-1914

99U		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2W-3391	Body As-F Inj V	383-3687
2W-4087	Gear As-Idler	418-9582
2W-7980	Camshaft As	378-3972
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434

99U		
Original Part Number	**Part Name**	**Classic Part Number**
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-8463	Bearing-Roller	394-9193
4B-7255	Cone-Bearing	386-4951
4L-8473	Plate-Wear	419-0883
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455

Sales Model 3408C (Cont'd.)

99U		
Original Part Number	Part Name	Classic Part Number
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218

99U		
Original Part Number	Part Name	Classic Part Number
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-5772	Race & Roller As	394-9200
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9656	Cone-Bearing	399-4448
5M-9644	Bearing-Outer	384-5929
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9840	Kit-Gasket-Sch	437-8140
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718

99U		
Original Part Number	Part Name	Classic Part Number
6I-0038	Line As-Fuel Inj	374-4719
6I-1032	Line As-Fuel Inj	390-0931
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922
6I-1038	Line As-Fuel Inj	390-0923
6I-4613	Plate-Spacer	380-7405
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6V-0214	Kit-Gasket-Mch	437-4590
6V-0216	Kit-Gasket-Sch	437-4589
6V-0229	Gasket Kit	437-4587
6V-0233	Kit-Gasket-T	437-4586
6V-0235	Gasket Kit	437-4585
6V-0237	Kit-Gasket-Exp	437-4584
6V-0241	Gasket Kit - F	393-3628
6V-1181	Gasket Kit	437-4578
6V-1785	Kit-Gasket-Mch	437-3190
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
6V-5920	Gasket Kit - F	388-0653
6V-9921	Gasket Kit	437-3236
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571

Sales Model 3408C (Cont'd.)

99U		
Original Part Number	**Part Name**	**Classic Part Number**
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1220	Plunger As-Pump	419-4743
7N-2156	Bearing-Sleeve	380-7373
7S-4411	Cap As-Rain	373-1912
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
8F-6058	Bearing-Sleeve	416-5494
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
8T-2499	Kit-Gasket-Sch	436-8383
8T-2500	Kit-Gasket	393-1028
9H-2256	Pump Gp-F Prm	311-9443
9K-1171	Cup-Rlr Bearing	430-3339

99U		
Original Part Number	**Part Name**	**Classic Part Number**
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9N-1161	Line As-Fuel Inj	383-3705
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9N-5529	Body-F Inj Valve	378-3993
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
123-6597	Gasket Kit	436-8421
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582

99U		
Original Part Number	**Part Name**	**Classic Part Number**
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
142-5093	Kit-Gasket (Acl)	437-4605
143-0905	Gasket Kit	437-4617
143-1314	Kit-Gasket-T	437-4603
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
208-6161	Gasket Kit - F	437-8150
208-6163	Kit-Gasket-Sch	437-2004
208-6165	Kit-Gasket-Mch	437-8149
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266
232-2600	Kit-Gasket-Fs	437-8672
232-4658	Kit-Gasket-Fs	437-2037
233-8668	Kit-Gasket-Mch	437-2030
233-9466	Kit-Gasket-Sch	437-2026
234-1630	Kit-Gasket(Rs)	393-1040
234-1985	Kit-Gasket-Fs	437-8666
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-5666	Gasket-Cyl Head	388-6565
283-6443	Kit-Gasket-T	437-8652
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

Sales Model 3408C (Cont'd.)

9ER		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-0156	Core As-Oclr	416-5525
1W-2491	Muffler As-Eject	360-7871
1W-5009	Crankshaft As	398-2969
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2W-4087	Gear As-Idler	418-9582
2W-7980	Camshaft As	378-3972
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
4B-7270	Cone-Bearing	399-4439
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837

9ER		
Original Part Number	Part Name	Classic Part Number
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4W-2541	Shaft-Gov Cont	399-8580
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555

9ER		
Original Part Number	Part Name	Classic Part Number
5L-8856	Coupling-Exhaust	311-9379
5M-9644	Bearing-Outer	384-5929
5N-1932	Shaft-Clutch	425-0216
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-4613	Plate-Spacer	380-7405
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657

Sales Model 3408C (Cont'd.)

9ER		
Original Part Number	Part Name	Classic Part Number
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-2104	Bell As-Suction	380-1521
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951

9ER		
Original Part Number	Part Name	Classic Part Number
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9N-3668	Base As.-Coolant	419-4718
9S-7148	Cap As-Rain	378-3994
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566

9ER		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
140-2749	Gasket Kit	393-1033
142-3035	Kit-Gasket (Wlg)	393-0926
142-5093	Kit-Gasket (Acl)	437-4605
143-2605	Kit-Gasket-Mch	393-0915
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
216-4592	Gasket Kit - Ocl	437-8145
217-0586	Bearing-Rod	419-7266
217-7884	Gasket Kit - Wp	437-8143
232-4658	Kit-Gasket-Fs	437-2037
233-9200	Kit-Gasket-Sch	393-0927
234-1630	Kit-Gasket(Rs)	393-1040
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
256-9653	Flywheel As.	425-3444
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

Sales Model 3408C (Cont'd.)

9XM		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-5009	Crankshaft As	398-2969
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-4087	Gear As-Idler	418-9582
2W-7980	Camshaft As	378-3972
3E-6772	Seal-Water	382-8017
3N-3368	Pipe-Exhaust	311-9434
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-1767	Valve-Bypass	419-4716
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975

9XM		
Original Part Number	Part Name	Classic Part Number
4W-5998	Rod-Valve Push	379-0168
5P-7807	Bearing-Ball	314-8502
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-5996	Rod As-Conn	379-8864
7E-9907	Spacer-Fp Timing	394-0222
7N-2156	Bearing-Sleeve	380-7373
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9L-5961	Adapter-Compr Dr	416-5508
9N-3668	Base As.-Coolant	419-4718
9S-7148	Cap As-Rain	378-3994
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984

9XM		
Original Part Number	Part Name	Classic Part Number
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

Sales Model 3408E

7PR		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1T-0043	Bearing-Ball	390-5294
1W-0156	Core As-Oclr	416-5525
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2491	Muffler As-Eject	360-7871
1W-5009	Crankshaft As	398-2969
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-4087	Gear As-Idler	418-9582
2W-7455	Gear As	396-9957
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3N-4892	Lever-Gov Cont	439-4542
4B-7270	Cone-Bearing	399-4439
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1015	Bearing-Sleeve	417-4525

7PR		
Original Part Number	Part Name	Classic Part Number
4N-1106	Shaft As-Rocker	377-5837
4N-1157	Coupling-Exhaust	379-0177
4N-1186	Bearing-Sleeve	417-4519
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161
5F-7404	Nut-Bearing Lock	308-9878
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854

7PR		
Original Part Number	Part Name	Classic Part Number
5L-7634	Elbow-Turbo Exh	380-1555
5N-1932	Shaft-Clutch	425-0216
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
6B-3223	Cup-Bearing	399-6065
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-4613	Plate-Spacer	380-7405
6L-2279	Plug-Ptf	419-4739
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7653	Gage As-O Level	428-7206
6N-9133	Gasket-Plate	398-2959
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847

Sales Model 3408E (Cont'd.)

7PR		
Original Part Number	Part Name	Classic Part Number
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-8828	Pulley	420-6395
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868

7PR		
Original Part Number	Part Name	Classic Part Number
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8112	Manifold-Exh	376-9063
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-0456	Crankshaft As	394-2587
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-3225	Shaft As	399-8582

7PR		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
155-6637	Gear-Oil Drive	425-9189
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-4109	Manifold-Exhaust	433-9857
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
234-1900	Kit-Gasket(Fs)	437-8667
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367

Sales Model 3408E (Cont'd.)

7PR		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665

7PR		
Original Part Number	Part Name	Classic Part Number
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

7PR		
Original Part Number	Part Name	Classic Part Number
430-7619	Adapter-Cla	438-1812

BKY		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-5009	Crankshaft As	398-2969
1W-6186	Shield As	374-4705
2A-4429	Lock-Retainer	379-0174
2W-7610	Gear-Hyd Pump Dr	418-1940
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1186	Bearing-Sleeve	417-4519
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168

BKY		
Original Part Number	Part Name	Classic Part Number
4W-6150	Adapter-Support	432-4219
5F-7404	Nut-Bearing Lock	308-9878
5P-1370	Bearing As-Rlr	416-2164
6I-4613	Plate-Spacer	380-7405
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7E-3205	Manifold-Inlet	376-9060
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
8N-0788	Cover	440-0849
8N-0935	Gear-Pump Drive	399-8569
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-3666	Repair Kt-Major	377-5842
8S-6511	Bearing-Sleeve	380-7372
9L-5961	Adapter-Compr Dr	416-5508
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
107-8112	Manifold-Exh	376-9063

BKY		
Original Part Number	Part Name	Classic Part Number
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-6500	Rotocoil As.	397-5053
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
163-4109	Manifold-Exhaust	433-9857
167-8126	Damper As	382-8019

Sales Model 3408E (Cont'd.)

BKY		
Original Part Number	**Part Name**	**Classic Part Number**
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
211-0592	Bearing - Main	419-6368

BKY		
Original Part Number	**Part Name**	**Classic Part Number**
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565

BKY		
Original Part Number	**Part Name**	**Classic Part Number**
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266

BLR		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-5009	Crankshaft As	398-2969
1W-6186	Shield As	374-4705
2A-4429	Lock-Retainer	379-0174
2P-8986	Cup-Rlr Bearing	415-1912
2W-7610	Gear-Hyd Pump Dr	418-1940
2W-7614	Gear-Crankshaft	425-7752
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-0452	Seal As -Cshaft	325-6191
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255

BLR		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5F-7404	Nut-Bearing Lock	308-9878
5P-1370	Bearing As-Rlr	416-2164
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-3205	Manifold-Inlet	376-9060
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562

BLR		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3666	Repair Kt-Major	377-5842
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
9L-5961	Adapter-Compr Dr	416-5508
9Y-9497	Bearing-Conn Rod	441-1563
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919

Sales Model 3408E (Cont'd.)

BLR		
Original Part Number	Part Name	Classic Part Number
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
145-8503	Shaft As-Idler	426-0035
152-3952	Impeller-Pump	374-4696
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869

BLR		
Original Part Number	Part Name	Classic Part Number
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
163-4109	Manifold-Exhaust	433-9857
167-8126	Damper As	382-8019
180-6645	Shaft As.	396-1566
202-3572	Shaft As-Drive	426-0037

BLR		
Original Part Number	Part Name	Classic Part Number
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
277-7089	Shaft As	380-7578
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266

ECP		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-5009	Crankshaft As	398-2969
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-8986	Cup-Rlr Bearing	415-1912
2W-4087	Gear As-Idler	418-9582
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-1186	Bearing-Sleeve	417-4519
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-0419	Core As-Oclr	379-0182

ECP		
Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As -Cshaft	325-6191
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5F-7404	Nut-Bearing Lock	308-9878
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451

ECP		
Original Part Number	Part Name	Classic Part Number
7E-3205	Manifold-Inlet	376-9060
7E-5996	Rod As-Conn	379-8864
7N-2156	Bearing-Sleeve	380-7373
7W-2315	Retainer	384-3475
8N-2104	Bell As-Suction	380-1521
8N-3666	Repair Kt-Major	377-5842
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
9L-5961	Adapter-Compr Dr	416-5508
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
115-2367	Valve-Exhaust	384-8700

Sales Model 3408E (Cont'd.)

ECP		
Original Part Number	Part Name	Classic Part Number
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919

ECP		
Original Part Number	Part Name	Classic Part Number
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
141-4109	Core As-Oclr	416-5518
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992

ECP		
Original Part Number	Part Name	Classic Part Number
163-4109	Manifold-Exhaust	433-9857
180-6645	Shaft As.	396-1566
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

ERA		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-5009	Crankshaft As	398-2969
1W-6186	Shield As	374-4705
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255

ERA		
Original Part Number	Part Name	Classic Part Number
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
6I-4613	Plate-Spacer	380-7405
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7E-3205	Manifold-Inlet	376-9060
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-3666	Repair Kt-Major	377-5842
8S-6511	Bearing-Sleeve	380-7372
9L-5961	Adapter-Compr Dr	416-5508
9Y-9497	Bearing-Conn Rod	441-1563

ERA		
Original Part Number	Part Name	Classic Part Number
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919

Sales Model 3408E (Cont'd.)

ERA		
Original Part Number	**Part Name**	**Classic Part Number**
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-6500	Rotocoil As.	397-5053
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519

ERA		
Original Part Number	**Part Name**	**Classic Part Number**
163-3103	Manifold-Exh	430-8992
163-4109	Manifold-Exhaust	433-9857
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
211-0592	Bearing - Main	419-6368

ERA		
Original Part Number	**Part Name**	**Classic Part Number**
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266

Sales Model 3412

2WJ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3368	Pipe-Exhaust	311-9434
3N-8463	Bearing-Roller	394-9193
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509

2WJ		
Original Part Number	**Part Name**	**Classic Part Number**
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4P-7688	Valve As-Check	420-6216
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379

2WJ		
Original Part Number	**Part Name**	**Classic Part Number**
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5996	Rod As-Conn	379-8864
7E-6003	Bearing-Sleeve	417-4522
7E-9907	Spacer-Fp Timing	394-0222

Sales Model 3412 (Cont'd.)

2WJ		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
7N-8629	Coupling-Elbow	419-4664
7N-8828	Pulley	420-6395
7T-2036	Cap As-Fuel	361-1721
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-3248	Gasket As	415-1893
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690

2WJ		
Original Part Number	Part Name	Classic Part Number
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919

2WJ		
Original Part Number	Part Name	Classic Part Number
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
142-3035	Kit-Gasket (Wlg)	393-0926
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
163-3103	Manifold-Exh	430-8992
207-1332	Bellows As	444-0569
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266
219-6544	Kit-Gasket-Acl	437-2001
232-2600	Kit-Gasket-Fs	437-8672
234-1630	Kit-Gasket(Rs)	393-1040
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
293-3018	Kit-Gasket (Sch)	438-0145
305-2669	Kit-Gasket (Cl)	438-0183
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

38S		
Original Part Number	Part Name	Classic Part Number
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-0458	Shield As-Turbo	367-6082
1W-0466	Shield As-Turbo	369-9495

38S		
Original Part Number	Part Name	Classic Part Number
1W-2491	Muffler As-Eject	360-7871
1W-3397	Plate	391-9810
1W-6183	Shield As-Manf	367-6083
1W-6184	Shield As	416-5524
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164

38S		
Original Part Number	Part Name	Classic Part Number
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532

Sales Model 3412 (Cont'd.)

38S		
Original Part Number	**Part Name**	**Classic Part Number**
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2W-3391	Body As-F Inj V	383-3687
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
2W-5540	Core As-Radiator	363-7452
2W-6632	Core As-Rad	391-1096
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-8463	Bearing-Roller	394-9193
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-1849	Pipe-Air	421-7143
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465

38S		
Original Part Number	**Part Name**	**Classic Part Number**
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4S-8472	Hood As-Preclnr	296-1355
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333

38S		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5N-1932	Shaft-Clutch	425-0216
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-2448	Bearing-Ball	399-6064
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-4597	Coupling-Exhaust	369-9489
6N-5978	Coupling-Exhaust	369-9487

Sales Model 3412 (Cont'd.)

38S		
Original Part Number	Part Name	Classic Part Number
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6V-0233	Kit-Gasket-T	437-4586
6V-1033	Rod End-Spher	375-5444
6V-1168	Gasket Kit	437-4565
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-2544	Gasket Kit	437-3205
6V-2545	Gasket Kit - F	437-3204
6V-2547	Gasket Kit - F	437-3189
6V-2998	Gasket Kit	437-3199
6V-3831	Seal-O-Ring	436-2657
6V-4540	Gasket Kit - Wp	393-1021
6V-4714	Kit-Gasket (Cl)	437-3197
6V-9921	Gasket Kit	437-3236
6Y-7652	Cup-Rlr Brg	399-6067
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1220	Plunger As-Pump	419-4743
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-5218	Manifold-Exhaust	435-4786
7N-5219	Manifold-Exhaust	425-2362
7N-7435	Kit-Major Repair	374-4724

38S		
Original Part Number	Part Name	Classic Part Number
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
8C-3467	Gasket Kit - F	437-4574
8C-8714	Kit-Gasket-Cl	436-8389
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9H-2256	Pump Gp-F Prm	311-9443

38S		
Original Part Number	Part Name	Classic Part Number
9K-8757	Rod End-Special	311-9361
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9N-1161	Line As-Fuel Inj	383-3705
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9N-5529	Body-F Inj Valve	378-3993
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704

Sales Model 3412 (Cont'd.)

38S		
Original Part Number	Part Name	Classic Part Number
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7566	Kit-Gasket-Acl	437-4570
124-7570	Kit-Gasket-Acl	437-4569
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457

38S		
Original Part Number	Part Name	Classic Part Number
140-2731	Kit-Gasket (Cl)	436-8403
140-2739	Kit-Gasket-Acl	437-3220
140-2746	Kit-Gasket-Mch	437-3219
140-2749	Gasket Kit	393-1033
142-1699	Gasket Kit	392-4507
142-3035	Kit-Gasket (Wlg)	393-0926
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
216-4592	Gasket Kit - Ocl	437-8145
217-0586	Bearing-Rod	419-7266

38S		
Original Part Number	Part Name	Classic Part Number
219-6544	Kit-Gasket-Acl	437-2001
232-2600	Kit-Gasket-Fs	437-8672
234-1630	Kit-Gasket(Rs)	393-1040
243-6718	Kit-Brg(Main)	469-1690
251-1224	Kit-Gasket-Mch	437-8655
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
256-9653	Flywheel As.	425-3444
283-6443	Kit-Gasket-T	437-8652
289-4093	Kit-Gasket-Sch	438-0152
289-4884	Kit-Gasket-Mch	437-8651
289-5160	Kit-Gasket-Sch	437-8663
289-5181	Kit-Gasket-Mch	438-0151
289-9183	Kit-Gasket-Sch	438-0150
293-3018	Kit-Gasket (Sch)	438-0145
293-3041	Kit-Gasket-Mch	438-0144
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

3JK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974

3JK		
Original Part Number	Part Name	Classic Part Number
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887

3JK		
Original Part Number	Part Name	Classic Part Number
4P-7688	Valve As-Check	420-6216
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5P-7807	Bearing-Ball	314-8502
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171

Sales Model 3412 (Cont'd.)

3JK		
Original Part Number	Part Name	Classic Part Number
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5996	Rod As-Conn	379-8864
7E-6003	Bearing-Sleeve	417-4522
7E-9907	Spacer-Fp Timing	394-0222
7N-2156	Bearing-Sleeve	380-7373
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9L-5961	Adapter-Compr Dr	416-5508
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563

3JK		
Original Part Number	Part Name	Classic Part Number
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
112-5538	Kit-Gasket-Sch	436-8412
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7570	Kit-Gasket-Acl	437-4569
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582

3JK		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
139-4750	Kit-Gasket-F	437-3221
139-4758	Gasket Kit	436-8405
139-8963	Kit-Gasket-Mch	436-8404
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
176-8167	Kit-Gasket-Acl	437-2011
177-9024	Adapter-Damper	299-1956
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
234-1630	Kit-Gasket(Rs)	393-1040
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

3NK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1T-0043	Bearing-Ball	390-5294
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556

3NK		
Original Part Number	Part Name	Classic Part Number
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271

3NK		
Original Part Number	Part Name	Classic Part Number
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975

Sales Model 3412 (Cont'd.)

3NK		
Original Part Number	Part Name	Classic Part Number
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
6L-2279	Plug-Ptf	419-4739
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5996	Rod As-Conn	379-8864
7L-4302	Gasket	420-8570
7N-2156	Bearing-Sleeve	380-7373
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3145	Plate	422-7894
8N-2104	Bell As-Suction	380-1521

3NK		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504

3NK		
Original Part Number	Part Name	Classic Part Number
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

5AG		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
3E-6772	Seal-Water	382-8017
4N-0685	Bearing-Sleeve	379-0191
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1320	Gasket-Adapter	398-2928
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4W-5477	Pump Gp-F Tfr	380-1512

5AG		
Original Part Number	Part Name	Classic Part Number
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571

5AG		
Original Part Number	Part Name	Classic Part Number
7E-5085	Bushing	377-5829
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
8C-4402	Gasket Kit - F	436-8393
8F-6058	Bearing-Sleeve	416-5494
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552

Sales Model 3412 (Cont'd.)

5AG		
Original Part Number	Part Name	Classic Part Number
101-3374	Gear-Camshaft Dr	376-9069
124-7570	Kit-Gasket-Acl	437-4569
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
456-2504	Kit-Ovhl-Cla	379-0174
456-2504	Kit-Ovhl-Cla	419-7266
456-2504	Kit-Ovhl-Cla	393-1021
456-2504	Kit-Ovhl-Cla	382-8042

5AG		
Original Part Number	Part Name	Classic Part Number
456-2504	Kit-Ovhl-Cla	379-0166
456-2504	Kit-Ovhl-Cla	374-8342
456-2504	Kit-Ovhl-Cla	363-7455
456-2504	Kit-Ovhl-Cla	361-1716
456-2504	Kit-Ovhl-Cla	311-9356
456-2504	Kit-Ovhl-Cla	386-3048
456-2506	Kit-Ovhl-Cla	311-9356
456-2506	Kit-Ovhl-Cla	379-0191
456-2506	Kit-Ovhl-Cla	393-1040
456-2506	Kit-Ovhl-Cla	393-1021
456-2506	Kit-Ovhl-Cla	386-3048
456-2506	Kit-Ovhl-Cla	382-8042
456-2506	Kit-Ovhl-Cla	380-7373
456-2506	Kit-Ovhl-Cla	380-7372

5AG		
Original Part Number	Part Name	Classic Part Number
456-2506	Kit-Ovhl-Cla	379-0174
456-2506	Kit-Ovhl-Cla	379-0170
456-2506	Kit-Ovhl-Cla	379-0166
456-2506	Kit-Ovhl-Cla	375-9974
456-2506	Kit-Ovhl-Cla	374-8342
456-2506	Kit-Ovhl-Cla	373-1885
456-2506	Kit-Ovhl-Cla	417-4524
456-2506	Kit-Ovhl-Cla	361-1716
456-2506	Kit-Ovhl-Cla	422-6919
456-2506	Kit-Ovhl-Cla	363-7455
456-2506	Kit-Ovhl-Cla	419-7266
456-2506	Kit-Ovhl-Cla	437-8672
456-2506	Kit-Ovhl-Cla	419-6368

5RL		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-2514	Gear-Flywheel	421-7283

5RL		
Original Part Number	Part Name	Classic Part Number
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896

5RL		
Original Part Number	Part Name	Classic Part Number
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4W-2541	Shaft-Gov Cont	399-8580
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168
5S-4557	Bearing	311-9360
6L-4714	Panel-Acl Filter	314-8532
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564

Sales Model 3412 (Cont'd.)

5RL		
Original Part Number	Part Name	Classic Part Number
6N-8441	Bearing-Sleeve	380-7371
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5085	Bushing	377-5829
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
8F-6058	Bearing-Sleeve	416-5494
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990

5RL		
Original Part Number	Part Name	Classic Part Number
8N-0561	Gear-Pump Idler	373-1886
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700

5RL		
Original Part Number	Part Name	Classic Part Number
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

60M		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-0458	Shield As-Turbo	367-6082
1W-0466	Shield As-Turbo	369-9495
1W-3397	Plate	391-9810
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955

60M		
Original Part Number	Part Name	Classic Part Number
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2W-3391	Body As-F Inj V	383-3687
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031

60M		
Original Part Number	Part Name	Classic Part Number
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-8463	Bearing-Roller	394-9193
4B-7255	Cone-Bearing	386-4951
4L-8473	Plate-Wear	419-0883
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884

Sales Model 3412 (Cont'd.)

60M		
Original Part Number	Part Name	Classic Part Number
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1849	Pipe-Air	421-7143
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323

60M		
Original Part Number	Part Name	Classic Part Number
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9656	Cone-Bearing	399-4448
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6V-0229	Gasket Kit	437-4587
6V-0233	Kit-Gasket-T	437-4586
6V-0235	Gasket Kit	437-4585

60M		
Original Part Number	Part Name	Classic Part Number
6V-0237	Kit-Gasket-Exp	437-4584
6V-2202	Bearing-Spl Ball	380-1574
6V-2539	Gasket Kit	437-3207
6V-2543	Gasket Kit	437-3206
6V-2546	Gasket Kit - F	437-3203
6V-3831	Seal-O-Ring	436-2657
6V-9921	Gasket Kit	437-3236
6Y-7652	Cup-Rlr Brg	399-6067
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1220	Plunger As-Pump	419-4743
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
8C-6553	Gasket Kit	436-8390
8F-6058	Bearing-Sleeve	416-5494
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866

Sales Model 3412 (Cont'd.)

60M		
Original Part Number	Part Name	Classic Part Number
8N-2104	Bell As-Suction	380-1521
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
8T-1630	Kit-Gasket-F	436-8387
9H-2256	Pump Gp-F Prm	311-9443
9L-5839	Coupling-Exhaust	374-7480
9N-1161	Line As-Fuel Inj	383-3705
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9N-5529	Body-F Inj Valve	378-3993
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704

60M		
Original Part Number	Part Name	Classic Part Number
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7566	Kit-Gasket-Acl	437-4570
124-7570	Kit-Gasket-Acl	437-4569
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
140-2739	Kit-Gasket-Acl	437-3220
143-0905	Gasket Kit	437-4617
143-1314	Kit-Gasket-T	437-4603
143-5428	Gasket Kit	437-8115
143-5430	Gasket Kit	437-4602
145-2867	Kit-Gasket (Wp)	449-9830
145-6726	Gasket Kit	437-4600
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019

60M		
Original Part Number	Part Name	Classic Part Number
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266
219-6544	Kit-Gasket-Acl	437-2001
221-3371	Kit-Gasket-Mch	437-2031
221-3372	Kit-Gasket-Sch	437-2006
232-2600	Kit-Gasket-Fs	437-8672
232-4504	Kit-Gasket-Fs	437-2038
232-4658	Kit-Gasket-Fs	437-2037
234-1630	Kit-Gasket(Rs)	393-1040
234-1985	Kit-Gasket-Fs	437-8666
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-5666	Gasket-Cyl Head	388-6565
283-6443	Kit-Gasket-T	437-8652
289-5181	Kit-Gasket-Mch	438-0151
289-9183	Kit-Gasket-Sch	438-0150
292-2500	Kit-Gasket-Mch	438-0147
293-3018	Kit-Gasket (Sch)	438-0145
293-3041	Kit-Gasket-Mch	438-0144
293-6012	Kit-Gasket-Mch	438-0128
293-6013	Kit-Gasket-Sch	438-0142
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

7BL		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163

7BL		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533

7BL		
Original Part Number	Part Name	Classic Part Number
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582

Sales Model 3412 (Cont'd.)

7BL		
Original Part Number	Part Name	Classic Part Number
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898

7BL		
Original Part Number	Part Name	Classic Part Number
4P-7812	Line As-Fuel Inj	373-1899
4W-2541	Shaft-Gov Cont	399-8580
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
8F-6058	Bearing-Sleeve	416-5494

7BL		
Original Part Number	Part Name	Classic Part Number
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9L-5961	Adapter-Compr Dr	416-5508
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
112-5538	Kit-Gasket-Sch	436-8412
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053

Sales Model 3412 (Cont'd.)

7BL		
Original Part Number	Part Name	Classic Part Number
138-6744	Rebuild Kit-Pump	363-7457
139-4758	Gasket Kit	436-8405
139-8963	Kit-Gasket-Mch	436-8404
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048

7BL		
Original Part Number	Part Name	Classic Part Number
167-8126	Damper As	382-8019
176-8167	Kit-Gasket-Acl	437-2011
177-9024	Adapter-Damper	299-1956
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266

7BL		
Original Part Number	Part Name	Classic Part Number
234-1630	Kit-Gasket(Rs)	393-1040
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

7DB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
2W-5540	Core As-Radiator	363-7452
2W-6632	Core As-Rad	391-1096
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
4B-7270	Cone-Bearing	399-4439
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283

7DB		
Original Part Number	Part Name	Classic Part Number
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5N-1932	Shaft-Clutch	425-0216
5N-3274	Plate	425-3648
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467

7DB		
Original Part Number	Part Name	Classic Part Number
6B-3223	Cup-Bearing	399-6065
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7L-4302	Gasket	420-8570
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3145	Plate	422-7894
8D-0983	Mounting	384-3470

Sales Model 3412 (Cont'd.)

7DB		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-2104	Bell As-Suction	380-1521
8N-3248	Gasket As	415-1893
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166

7DB		
Original Part Number	Part Name	Classic Part Number
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-3237	Precleaner As	432-4220
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457

7DB		
Original Part Number	Part Name	Classic Part Number
140-2746	Kit-Gasket-Mch	437-3219
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
207-1332	Bellows As	444-0569
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-2600	Kit-Gasket-Fs	437-8672
232-4504	Kit-Gasket-Fs	437-2038
233-9245	Kit-Gasket-Sch	437-2027
234-1630	Kit-Gasket(Rs)	393-1040
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
292-2500	Kit-Gasket-Mch	438-0147
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

7HG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556

7HG		
Original Part Number	Part Name	Classic Part Number
3E-6772	Seal-Water	382-8017
3N-8463	Bearing-Roller	394-9193
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450

7HG		
Original Part Number	Part Name	Classic Part Number
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890

Sales Model 3412 (Cont'd.)

7HG		
Original Part Number	Part Name	Classic Part Number
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4W-2541	Shaft-Gov Cont	399-8580
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
6L-2279	Plug-Ptf	419-4739
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042

7HG		
Original Part Number	Part Name	Classic Part Number
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5085	Bushing	377-5829
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
8F-6058	Bearing-Sleeve	416-5494
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552

7HG		
Original Part Number	Part Name	Classic Part Number
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

81Z		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398

81Z		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-1669	Piston	325-6158

81Z		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846

Sales Model 3412 (Cont'd.)

81Z		
Original Part Number	Part Name	Classic Part Number
1W-2491	Muffler As-Eject	360-7871
1W-5910	Tappet As-Guide&	383-1569
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2W-3391	Body As-F Inj V	383-3687
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
2W-5540	Core As-Radiator	363-7452
2W-6632	Core As-Rad	391-1096
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-8463	Bearing-Roller	394-9193
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502

81Z		
Original Part Number	Part Name	Classic Part Number
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895

81Z		
Original Part Number	Part Name	Classic Part Number
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-2448	Bearing-Ball	399-6064
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839

Sales Model 3412 (Cont'd.)

81Z		
Original Part Number	Part Name	Classic Part Number
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-4597	Coupling-Exhaust	369-9489
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7653	Gage As-O Level	428-7206
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6V-0233	Kit-Gasket-T	437-4586
6V-1168	Gasket Kit	437-4565
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-2544	Gasket Kit	437-3205
6V-2545	Gasket Kit - F	437-3204
6V-2998	Gasket Kit	437-3199
6V-3831	Seal-O-Ring	436-2657
6V-4540	Gasket Kit - Wp	393-1021
6V-4714	Kit-Gasket (Cl)	437-3197
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864

81Z		
Original Part Number	Part Name	Classic Part Number
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-5218	Manifold-Exhaust	435-4786
7N-5219	Manifold-Exhaust	425-2362
7N-7166	Race-Brg Thrust	417-4531
7N-8828	Pulley	420-6395
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8C-4402	Gasket Kit - F	436-8393
8C-6553	Gasket Kit	436-8390
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521

81Z		
Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9L-5839	Coupling-Exhaust	374-7480
9N-1161	Line As-Fuel Inj	383-3705
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276

Sales Model 3412 (Cont'd.)

81Z		
Original Part Number	Part Name	Classic Part Number
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
109-7687	Bearing-Ball	420-3220
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7566	Kit-Gasket-Acl	437-4570
124-7570	Kit-Gasket-Acl	437-4569
124-7609	Gear-Pump Idler	428-8504
127-1517	Gasket Kit - F	437-4568
127-1518	Gasket Kit - F	437-4567
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053

81Z		
Original Part Number	Part Name	Classic Part Number
138-6744	Rebuild Kit-Pump	363-7457
140-2739	Kit-Gasket-Acl	437-3220
140-2749	Gasket Kit	393-1033
142-1699	Gasket Kit	392-4507
142-3035	Kit-Gasket (Wlg)	393-0926
143-1314	Kit-Gasket-T	437-4603
144-0482	Gasket	420-8547
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
163-3103	Manifold-Exh	430-8992
164-6574	Kit-Gasket-Acl	437-2015
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013

81Z		
Original Part Number	Part Name	Classic Part Number
202-3572	Shaft As-Drive	426-0037
207-1332	Bellows As	444-0569
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
216-4592	Gasket Kit - Ocl	437-8145
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
219-6544	Kit-Gasket-Acl	437-2001
232-2600	Kit-Gasket-Fs	437-8672
234-1630	Kit-Gasket(Rs)	393-1040
243-6718	Kit-Brg(Main)	469-1690
251-1224	Kit-Gasket-Mch	437-8655
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-6443	Kit-Gasket-T	437-8652
289-4884	Kit-Gasket-Mch	437-8651
289-5160	Kit-Gasket-Sch	437-8663
289-5181	Kit-Gasket-Mch	438-0151
289-9183	Kit-Gasket-Sch	438-0150
293-3018	Kit-Gasket (Sch)	438-0145
293-3041	Kit-Gasket-Mch	438-0144
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109
430-7619	Adapter-Cla	438-1812

9JR		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
3E-6772	Seal-Water	382-8017

9JR		
Original Part Number	Part Name	Classic Part Number
4N-0685	Bearing-Sleeve	379-0191
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884

9JR		
Original Part Number	Part Name	Classic Part Number
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216

Sales Model 3412 (Cont'd.)

9JR		
Original Part Number	Part Name	Classic Part Number
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
5S-4557	Bearing	311-9360
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6003	Bearing-Sleeve	417-4522
7E-9907	Spacer-Fp Timing	394-0222
7W-0182	Plunger & Bbl As	391-9893

9JR		
Original Part Number	Part Name	Classic Part Number
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
8C-4402	Gasket Kit - F	436-8393
8F-6058	Bearing-Sleeve	416-5494
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-3374	Gear-Camshaft Dr	376-9069
108-2102	Bonnet-Valve	455-3274
108-6633	Pump Gp-Fuel Inj	420-6215
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7570	Kit-Gasket-Acl	437-4569
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266

9JR		
Original Part Number	Part Name	Classic Part Number
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
456-2507	Kit-Ovhl-Cla	417-4524
456-2507	Kit-Ovhl-Cla	382-8042
456-2507	Kit-Ovhl-Cla	419-7266
456-2507	Kit-Ovhl-Cla	437-8672
456-2507	Kit-Ovhl-Cla	419-6368
456-2507	Kit-Ovhl-Cla	399-8571
456-2507	Kit-Ovhl-Cla	393-1040
456-2507	Kit-Ovhl-Cla	393-1021
456-2507	Kit-Ovhl-Cla	386-3048
456-2507	Kit-Ovhl-Cla	384-8698
456-2507	Kit-Ovhl-Cla	380-7373
456-2507	Kit-Ovhl-Cla	380-7372
456-2507	Kit-Ovhl-Cla	374-8342
456-2507	Kit-Ovhl-Cla	311-9356
456-2507	Kit-Ovhl-Cla	361-1716
456-2507	Kit-Ovhl-Cla	384-8703
456-2507	Kit-Ovhl-Cla	373-1885
456-2507	Kit-Ovhl-Cla	379-0191
456-2507	Kit-Ovhl-Cla	379-0166
456-2507	Kit-Ovhl-Cla	379-0170
456-2507	Kit-Ovhl-Cla	379-0171
456-2507	Kit-Ovhl-Cla	379-0174
456-2507	Kit-Ovhl-Cla	363-7455
456-2510	Kit-Gasket-Cla	419-4716

9XF		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1T-0043	Bearing-Ball	390-5294
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017

9XF		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1675	Manifold-Exhaust	443-2015
4N-1767	Valve-Bypass	419-4716
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271

9XF		
Original Part Number	Part Name	Classic Part Number
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4P-7688	Valve As-Check	420-6216
4W-0419	Core As-Oclr	379-0182
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318

Sales Model 3412 (Cont'd.)

9XF		
Original Part Number	Part Name	Classic Part Number
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5B-9169	Plug-Drain	419-4736
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5996	Rod As-Conn	379-8864
7E-6003	Bearing-Sleeve	417-4522
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-8828	Pulley	420-6395
7W-2315	Retainer	384-3475

9XF		
Original Part Number	Part Name	Classic Part Number
7W-5435	Adapter-Nozzle	374-7493
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744

9XF		
Original Part Number	Part Name	Classic Part Number
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
141-4109	Core As-Oclr	416-5518
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
234-1630	Kit-Gasket(Rs)	393-1040
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

BCS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1T-0043	Bearing-Ball	390-5294
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163

BCS		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934

BCS		
Original Part Number	Part Name	Classic Part Number
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017

Sales Model 3412 (Cont'd.)

BCS		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1675	Manifold-Exhaust	443-2015
4N-1767	Valve-Bypass	419-4716
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4P-7688	Valve As-Check	420-6216
4W-0419	Core As-Oclr	379-0182
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656

BCS		
Original Part Number	Part Name	Classic Part Number
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5996	Rod As-Conn	379-8864
7E-6003	Bearing-Sleeve	417-4522
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069

BCS		
Original Part Number	Part Name	Classic Part Number
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
141-4109	Core As-Oclr	416-5518
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

Sales Model 3412 (Cont'd.)

BGE		
Original Part Number	Part Name	Classic Part Number
1N-3113	Support-Elbow	433-8185
1P-1367	Plunger-Valve	432-8913
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-8986	Cup-Rlr Bearing	415-1912
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
2W-7610	Gear-Hyd Pump Dr	418-1940
2W-7614	Gear-Crankshaft	425-7752
3E-6772	Seal-Water	382-8017
3K-9608	Guard-Dirt	374-1447
3N-3368	Pipe-Exhaust	311-9434
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-1767	Valve-Bypass	419-4716
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283

BGE		
Original Part Number	Part Name	Classic Part Number
4N-2954	Sleeve-Camshaft	299-2059
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4W-0452	Seal As -Cshaft	325-6191
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168

BGE		
Original Part Number	Part Name	Classic Part Number
4W-6150	Adapter-Support	432-4219
5P-1370	Bearing As-Rlr	416-2164
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
6N-0977	Bearing-Sleeve	417-4524
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7M-7219	Bearing-Thrust	384-4816
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
8F-6058	Bearing-Sleeve	416-5494
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562

Sales Model 3412 (Cont'd.)

BGE		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
9L-5961	Adapter-Compr Dr	416-5508
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984

BGE		
Original Part Number	Part Name	Classic Part Number
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3565	Tube As-Exhaust	374-4695

BGE		
Original Part Number	Part Name	Classic Part Number
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
145-8503	Shaft As-Idler	426-0035
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
180-6645	Shaft As.	396-1566
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
221-9356	Flywheel As	435-2575
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266

BKS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-8986	Cup-Rlr Bearing	415-1912
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556

BKS		
Original Part Number	Part Name	Classic Part Number
3E-6772	Seal-Water	382-8017
3K-9608	Guard-Dirt	374-1447
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1320	Gasket-Adapter	398-2928
4N-1849	Pipe-Air	421-7143
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271

BKS		
Original Part Number	Part Name	Classic Part Number
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892

Sales Model 3412 (Cont'd.)

BKS		
Original Part Number	Part Name	Classic Part Number
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4W-0452	Seal As -Cshaft	325-6191
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
6N-0977	Bearing-Sleeve	417-4524
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042

BKS		
Original Part Number	Part Name	Classic Part Number
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5085	Bushing	377-5829
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
8F-6058	Bearing-Sleeve	416-5494
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563

BKS		
Original Part Number	Part Name	Classic Part Number
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266

BLJ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164

BLJ		
Original Part Number	Part Name	Classic Part Number
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532

BLJ		
Original Part Number	Part Name	Classic Part Number
2N-5842	Screw-Bridge Adj	418-1934
2P-8986	Cup-Rlr Bearing	415-1912
2W-3875	Gear-Oil Pump Dr	399-8548

Sales Model 3412 (Cont'd.)

BLJ		
Original Part Number	**Part Name**	**Classic Part Number**
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
3K-9608	Guard-Dirt	374-1447
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1186	Bearing-Sleeve	417-4519
4N-1320	Gasket-Adapter	398-2928
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896

BLJ		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4W-0419	Core As-Oclr	379-0182
4W-0452	Seal As -Cshaft	325-6191
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5F-7404	Nut-Bearing Lock	308-9878
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
6N-0977	Bearing-Sleeve	417-4524
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5085	Bushing	377-5829
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401

BLJ		
Original Part Number	**Part Name**	**Classic Part Number**
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
8F-6058	Bearing-Sleeve	416-5494
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
122-0321	Valve-Exhaust	384-8698

Sales Model 3412 (Cont'd.)

BLJ		
Original Part Number	**Part Name**	**Classic Part Number**
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813

BLJ		
Original Part Number	**Part Name**	**Classic Part Number**
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
141-4109	Core As-Oclr	416-5518
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
180-6645	Shaft As.	396-1566

BLJ		
Original Part Number	**Part Name**	**Classic Part Number**
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266

DGJ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-5009	Crankshaft As	398-2969
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
2W-7980	Camshaft As	378-3972
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-1186	Bearing-Sleeve	417-4519
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323

DGJ		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5F-7404	Nut-Bearing Lock	308-9878
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7E-5996	Rod As-Conn	379-8864
7W-2315	Retainer	384-3475
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689

DGJ		
Original Part Number	**Part Name**	**Classic Part Number**
101-1817	Bridge As.-Exh	374-4690
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266

Sales Model 3412C

38S		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-0458	Shield As-Turbo	367-6082
1W-0466	Shield As-Turbo	369-9495
1W-2491	Muffler As-Eject	360-7871
1W-3397	Plate	391-9810
1W-6183	Shield As-Manf	367-6083
1W-6184	Shield As	416-5524
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2W-3391	Body As-F Inj V	383-3687
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
2W-5540	Core As-Radiator	363-7452
2W-6632	Core As-Rad	391-1096
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356

38S		
Original Part Number	**Part Name**	**Classic Part Number**
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-8463	Bearing-Roller	394-9193
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-1849	Pipe-Air	421-7143
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887

38S		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4S-8472	Hood As-Preclnr	296-1355
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161
5L-6326	Bearing-Ball	420-3222

Sales Model 3412C (Cont'd.)

38S		
Original Part Number	Part Name	Classic Part Number
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5N-1932	Shaft-Clutch	425-0216
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-2448	Bearing-Ball	399-6064
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-4597	Coupling-Exhaust	369-9489
6N-5978	Coupling-Exhaust	369-9487
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6V-0233	Kit-Gasket-T	437-4586
6V-1033	Rod End-Spher	375-5444

38S		
Original Part Number	Part Name	Classic Part Number
6V-1168	Gasket Kit	437-4565
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-2544	Gasket Kit	437-3205
6V-2545	Gasket Kit - F	437-3204
6V-2547	Gasket Kit - F	437-3189
6V-2998	Gasket Kit	437-3199
6V-3831	Seal-O-Ring	436-2657
6V-4540	Gasket Kit - Wp	393-1021
6V-4714	Kit-Gasket (Cl)	437-3197
6V-9921	Gasket Kit	437-3236
6Y-7652	Cup-Rlr Brg	399-6067
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1220	Plunger As-Pump	419-4743
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-5218	Manifold-Exhaust	435-4786
7N-5219	Manifold-Exhaust	425-2362
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278

38S		
Original Part Number	Part Name	Classic Part Number
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
8C-3467	Gasket Kit - F	437-4574
8C-8714	Kit-Gasket-Cl	436-8389
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9H-2256	Pump Gp-F Prm	311-9443
9K-8757	Rod End-Special	311-9361
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9N-1161	Line As-Fuel Inj	383-3705
9N-3668	Base As.-Coolant	419-4718

Sales Model 3412C (Cont'd.)

38S		
Original Part Number	**Part Name**	**Classic Part Number**
9N-3970	Line As-Fuel Inj	390-1005
9N-5529	Body-F Inj Valve	378-3993
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704

38S		
Original Part Number	**Part Name**	**Classic Part Number**
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7566	Kit-Gasket-Acl	437-4570
124-7570	Kit-Gasket-Acl	437-4569
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
140-2731	Kit-Gasket (Cl)	436-8403
140-2739	Kit-Gasket-Acl	437-3220
140-2746	Kit-Gasket-Mch	437-3219
140-2749	Gasket Kit	393-1033
142-1699	Gasket Kit	392-4507
142-3035	Kit-Gasket (Wlg)	393-0926
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-2867	Kit-Gasket (Wp)	449-9830

38S		
Original Part Number	**Part Name**	**Classic Part Number**
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
216-4592	Gasket Kit - Ocl	437-8145
217-0586	Bearing-Rod	419-7266
219-6544	Kit-Gasket-Acl	437-2001
232-2600	Kit-Gasket-Fs	437-8672
234-1630	Kit-Gasket(Rs)	393-1040
243-6718	Kit-Brg(Main)	469-1690
251-1224	Kit-Gasket-Mch	437-8655
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
256-9653	Flywheel As.	425-3444
283-6443	Kit-Gasket-T	437-8652
289-4093	Kit-Gasket-Sch	438-0152
289-4884	Kit-Gasket-Mch	437-8651
289-5160	Kit-Gasket-Sch	437-8663
289-5181	Kit-Gasket-Mch	438-0151
289-9183	Kit-Gasket-Sch	438-0150
293-3018	Kit-Gasket (Sch)	438-0145
293-3041	Kit-Gasket-Mch	438-0144
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

3JK		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163

3JK		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305

3JK		
Original Part Number	**Part Name**	**Classic Part Number**
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548

Sales Model 3412C (Cont'd.)

3JK		
Original Part Number	Part Name	Classic Part Number
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4P-7688	Valve As-Check	420-6216
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5P-7807	Bearing-Ball	314-8502
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544

3JK		
Original Part Number	Part Name	Classic Part Number
6N-7175	Rotocoil As	382-8042
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5996	Rod As-Conn	379-8864
7E-6003	Bearing-Sleeve	417-4522
7E-9907	Spacer-Fp Timing	394-0222
7N-2156	Bearing-Sleeve	380-7373
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9L-5961	Adapter-Compr Dr	416-5508
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
112-5538	Kit-Gasket-Sch	436-8412

3JK		
Original Part Number	Part Name	Classic Part Number
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7570	Kit-Gasket-Acl	437-4569
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
139-4750	Kit-Gasket-F	437-3221
139-4758	Gasket Kit	436-8405
139-8963	Kit-Gasket-Mch	436-8404
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
176-8167	Kit-Gasket-Acl	437-2011
177-9024	Adapter-Damper	299-1956
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
234-1630	Kit-Gasket(Rs)	393-1040
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

5AG		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221

Sales Model 3412C (Cont'd.)

5AG		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
3E-6772	Seal-Water	382-8017
4N-0685	Bearing-Sleeve	379-0191
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1320	Gasket-Adapter	398-2928
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371

5AG		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7E-5085	Bushing	377-5829
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
8C-4402	Gasket Kit - F	436-8393
8F-6058	Bearing-Sleeve	416-5494
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-3374	Gear-Camshaft Dr	376-9069
124-7570	Kit-Gasket-Acl	437-4569
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266

5AG		
Original Part Number	Part Name	Classic Part Number
456-2504	Kit-Ovhl-Cla	374-8342
456-2504	Kit-Ovhl-Cla	361-1716
456-2504	Kit-Ovhl-Cla	363-7455
456-2504	Kit-Ovhl-Cla	379-0174
456-2504	Kit-Ovhl-Cla	382-8042
456-2504	Kit-Ovhl-Cla	386-3048
456-2504	Kit-Ovhl-Cla	393-1021
456-2504	Kit-Ovhl-Cla	419-7266
456-2504	Kit-Ovhl-Cla	379-0166
456-2504	Kit-Ovhl-Cla	311-9356
456-2506	Kit-Ovhl-Cla	393-1040
456-2506	Kit-Ovhl-Cla	379-0191
456-2506	Kit-Ovhl-Cla	380-7372
456-2506	Kit-Ovhl-Cla	380-7373
456-2506	Kit-Ovhl-Cla	382-8042
456-2506	Kit-Ovhl-Cla	386-3048
456-2506	Kit-Ovhl-Cla	422-6919
456-2506	Kit-Ovhl-Cla	419-7266
456-2506	Kit-Ovhl-Cla	361-1716
456-2506	Kit-Ovhl-Cla	419-6368
456-2506	Kit-Ovhl-Cla	311-9356
456-2506	Kit-Ovhl-Cla	393-1021
456-2506	Kit-Ovhl-Cla	374-8342
456-2506	Kit-Ovhl-Cla	379-0174
456-2506	Kit-Ovhl-Cla	437-8672
456-2506	Kit-Ovhl-Cla	417-4524
456-2506	Kit-Ovhl-Cla	379-0166
456-2506	Kit-Ovhl-Cla	363-7455
456-2506	Kit-Ovhl-Cla	375-9974
456-2506	Kit-Ovhl-Cla	373-1885
456-2506	Kit-Ovhl-Cla	379-0170

60M		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-0458	Shield As-Turbo	367-6082
1W-0466	Shield As-Turbo	369-9495
1W-3397	Plate	391-9810
1W-6987	Valve As-Check	420-6221

60M		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305

60M		
Original Part Number	Part Name	Classic Part Number
2L-6744	Plunger	426-0030
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2W-3391	Body As-F Inj V	383-3687
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017

Sales Model 3412C (Cont'd.)

60M		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-8463	Bearing-Roller	394-9193
4B-7255	Cone-Bearing	386-4951
4L-8473	Plate-Wear	419-0883
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1849	Pipe-Air	421-7143
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890

60M		
Original Part Number	Part Name	Classic Part Number
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9656	Cone-Bearing	399-4448
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6L-2279	Plug-Ptf	419-4739

60M		
Original Part Number	Part Name	Classic Part Number
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6V-0229	Gasket Kit	437-4587
6V-0233	Kit-Gasket-T	437-4586
6V-0235	Gasket Kit	437-4585
6V-0237	Kit-Gasket-Exp	437-4584
6V-2202	Bearing-Spl Ball	380-1574
6V-2539	Gasket Kit	437-3207
6V-2543	Gasket Kit	437-3206
6V-2546	Gasket Kit - F	437-3203
6V-3831	Seal-O-Ring	436-2657
6V-9921	Gasket Kit	437-3236
6Y-7652	Cup-Rlr Brg	399-6067
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1220	Plunger As-Pump	419-4743
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811

Sales Model 3412C (Cont'd.)

60M		
Original Part Number	Part Name	Classic Part Number
7N-7878	Cover-Plate	434-2401
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
8C-6553	Gasket Kit	436-8390
8F-6058	Bearing-Sleeve	416-5494
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
8T-1630	Kit-Gasket-F	436-8387
9H-2256	Pump Gp-F Prm	311-9443
9L-5839	Coupling-Exhaust	374-7480
9N-1161	Line As-Fuel Inj	383-3705
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9N-5529	Body-F Inj Valve	378-3993
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563

60M		
Original Part Number	Part Name	Classic Part Number
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7566	Kit-Gasket-Acl	437-4570
124-7570	Kit-Gasket-Acl	437-4569
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
140-2739	Kit-Gasket-Acl	437-3220
143-0905	Gasket Kit	437-4617
143-1314	Kit-Gasket-T	437-4603
143-5428	Gasket Kit	437-8115
143-5430	Gasket Kit	437-4602

60M		
Original Part Number	Part Name	Classic Part Number
145-2867	Kit-Gasket (Wp)	449-9830
145-6726	Gasket Kit	437-4600
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266
219-6544	Kit-Gasket-Acl	437-2001
221-3371	Kit-Gasket-Mch	437-2031
221-3372	Kit-Gasket-Sch	437-2006
232-2600	Kit-Gasket-Fs	437-8672
232-4504	Kit-Gasket-Fs	437-2038
232-4658	Kit-Gasket-Fs	437-2037
234-1630	Kit-Gasket(Rs)	393-1040
234-1985	Kit-Gasket-Fs	437-8666
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-5666	Gasket-Cyl Head	388-6565
283-6443	Kit-Gasket-T	437-8652
289-5181	Kit-Gasket-Mch	438-0151
289-9183	Kit-Gasket-Sch	438-0150
292-2500	Kit-Gasket-Mch	438-0147
293-3018	Kit-Gasket (Sch)	438-0145
293-3041	Kit-Gasket-Mch	438-0144
293-6012	Kit-Gasket-Mch	438-0128
293-6013	Kit-Gasket-Sch	438-0142
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

Sales Model 3412C (Cont'd.)

81Z		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2491	Muffler As-Eject	360-7871
1W-5910	Tappet As-Guide&	383-1569
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2W-3391	Body As-F Inj V	383-3687
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
2W-5540	Core As-Radiator	363-7452
2W-6632	Core As-Rad	391-1096
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-8463	Bearing-Roller	394-9193
4M-6107	Bearing-Roller	380-7507

81Z		
Original Part Number	Part Name	Classic Part Number
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890

81Z		
Original Part Number	Part Name	Classic Part Number
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-2448	Bearing-Ball	399-6064

Sales Model 3412C (Cont'd.)

81Z		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-4597	Coupling-Exhaust	369-9489
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7653	Gage As-O Level	428-7206
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6V-0233	Kit-Gasket-T	437-4586
6V-1168	Gasket Kit	437-4565
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-2544	Gasket Kit	437-3205
6V-2545	Gasket Kit - F	437-3204
6V-2998	Gasket Kit	437-3199
6V-3831	Seal-O-Ring	436-2657
6V-4540	Gasket Kit - Wp	393-1021
6V-4714	Kit-Gasket (Cl)	437-3197

81Z		
Original Part Number	Part Name	Classic Part Number
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-5218	Manifold-Exhaust	435-4786
7N-5219	Manifold-Exhaust	425-2362
7N-7166	Race-Brg Thrust	417-4531
7N-8828	Pulley	420-6395
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8C-4402	Gasket Kit - F	436-8393
8C-6553	Gasket Kit	436-8390
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494

81Z		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9L-5839	Coupling-Exhaust	374-7480
9N-1161	Line As-Fuel Inj	383-3705
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069

Sales Model 3412C (Cont'd.)

81Z		
Original Part Number	Part Name	Classic Part Number
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
109-7687	Bearing-Ball	420-3220
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7566	Kit-Gasket-Acl	437-4570
124-7570	Kit-Gasket-Acl	437-4569
124-7609	Gear-Pump Idler	428-8504
127-1517	Gasket Kit - F	437-4568
127-1518	Gasket Kit - F	437-4567
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423

81Z		
Original Part Number	Part Name	Classic Part Number
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
140-2739	Kit-Gasket-Acl	437-3220
140-2749	Gasket Kit	393-1033
142-1699	Gasket Kit	392-4507
142-3035	Kit-Gasket (Wlg)	393-0926
143-1314	Kit-Gasket-T	437-4603
144-0482	Gasket	420-8547
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
163-3103	Manifold-Exh	430-8992
164-6574	Kit-Gasket-Acl	437-2015
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701

81Z		
Original Part Number	Part Name	Classic Part Number
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
207-1332	Bellows As	444-0569
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
216-4592	Gasket Kit - Ocl	437-8145
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
219-6544	Kit-Gasket-Acl	437-2001
232-2600	Kit-Gasket-Fs	437-8672
234-1630	Kit-Gasket(Rs)	393-1040
243-6718	Kit-Brg(Main)	469-1690
251-1224	Kit-Gasket-Mch	437-8655
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-6443	Kit-Gasket-T	437-8652
289-4884	Kit-Gasket-Mch	437-8651
289-5160	Kit-Gasket-Sch	437-8663
289-5181	Kit-Gasket-Mch	438-0151
289-9183	Kit-Gasket-Sch	438-0150
293-3018	Kit-Gasket (Sch)	438-0145
293-3041	Kit-Gasket-Mch	438-0144
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109
430-7619	Adapter-Cla	438-1812

8AR		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483

8AR		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1W-6186	Shield As	374-4705

Sales Model 3412C (Cont'd.)

8AR		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-8463	Bearing-Roller	394-9193
4B-7270	Cone-Bearing	399-4439
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465

8AR		
Original Part Number	Part Name	Classic Part Number
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4W-2541	Shaft-Gov Cont	399-8580
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255

8AR		
Original Part Number	Part Name	Classic Part Number
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161
5L-7520	Elbow-Exhaust	419-4711
5L-9738	Coupling-Exhaust	311-9380
5N-1932	Shaft-Clutch	425-0216
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065
6I-1240	Governor As	380-7538
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373

Sales Model 3412C (Cont'd.)

8AR		
Original Part Number	Part Name	Classic Part Number
7N-7435	Kit-Major Repair	374-4724
7N-8828	Pulley	420-6395
7S-5003	Cap As-Rain	379-0184
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9L-5961	Adapter-Compr Dr	416-5508
9N-3668	Base As.-Coolant	419-4718
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729

8AR		
Original Part Number	Part Name	Classic Part Number
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003

8AR		
Original Part Number	Part Name	Classic Part Number
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
140-2739	Kit-Gasket-Acl	437-3220
142-3035	Kit-Gasket (Wlg)	393-0926
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
164-6574	Kit-Gasket-Acl	437-2015
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266
219-6544	Kit-Gasket-Acl	437-2001
223-1102	Kit-Gasket-F	437-8132
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
256-9653	Flywheel As.	425-3444
293-3018	Kit-Gasket (Sch)	438-0145
293-3041	Kit-Gasket-Mch	438-0144
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

Sales Model 3412C (Cont'd.)

9BR		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
2W-7255	Shaft-Water Pump	325-6203
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3786	Rod-Thrt Cont	397-5051
3N-8463	Bearing-Roller	394-9193
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1320	Gasket-Adapter	398-2928
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600

9BR		
Original Part Number	Part Name	Classic Part Number
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4W-2541	Shaft-Gov Cont	399-8580
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5N-2902	Seal-Oil	314-8540

9BR		
Original Part Number	Part Name	Classic Part Number
5N-4504	Plate-Port	397-5048
5P-2448	Bearing-Ball	399-6064
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6L-2279	Plug-Ptf	419-4739
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6V-0233	Kit-Gasket-T	437-4586
6V-0237	Kit-Gasket-Exp	437-4584
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7N-8828	Pulley	420-6395
7W-0182	Plunger & Bbl As	391-9893

Sales Model 3412C (Cont'd.)

9BR		
Original Part Number	Part Name	Classic Part Number
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-3248	Gasket As	415-1893
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9N-3970	Line As-Fuel Inj	390-1005
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938

9BR		
Original Part Number	Part Name	Classic Part Number
9Y-0238	Line As-F Inj	390-0939
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-1760	Bearing-Ball	417-9493
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7566	Kit-Gasket-Acl	437-4570
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112

9BR		
Original Part Number	Part Name	Classic Part Number
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
140-2739	Kit-Gasket-Acl	437-3220
142-1699	Gasket Kit	392-4507
145-2867	Kit-Gasket (Wp)	449-9830
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
170-0560	Rebuild Kit-Pump	363-7458
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266
219-6544	Kit-Gasket-Acl	437-2001
221-3371	Kit-Gasket-Mch	437-2031
221-3372	Kit-Gasket-Sch	437-2006
232-4504	Kit-Gasket-Fs	437-2038
234-1630	Kit-Gasket(Rs)	393-1040
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-6443	Kit-Gasket-T	437-8652
289-5160	Kit-Gasket-Sch	437-8663
289-5181	Kit-Gasket-Mch	438-0151
289-9183	Kit-Gasket-Sch	438-0150
292-2500	Kit-Gasket-Mch	438-0147
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

B1A		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707

B1A		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-8986	Cup-Rlr Bearing	415-1912

B1A		
Original Part Number	Part Name	Classic Part Number
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974

Sales Model 3412C (Cont'd.)

B1A		
Original Part Number	Part Name	Classic Part Number
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1320	Gasket-Adapter	398-2928
4N-1849	Pipe-Air	421-7143
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4W-0452	Seal As -Cshaft	325-6191
4W-5477	Pump Gp-F Tfr	380-1512

B1A		
Original Part Number	Part Name	Classic Part Number
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5S-4557	Bearing	311-9360
6N-0977	Bearing-Sleeve	417-4524
6N-3025	Tube As	419-4656
6N-4597	Coupling-Exhaust	369-9489
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5085	Bushing	377-5829
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
8F-6058	Bearing-Sleeve	416-5494
8M-0874	Plunger As-Valve	311-9439

B1A		
Original Part Number	Part Name	Classic Part Number
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8N-3666	Repair Kt-Major	377-5842
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
9L-5961	Adapter-Compr Dr	416-5508
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919

Sales Model 3412C (Cont'd.)

B1A		
Original Part Number	**Part Name**	**Classic Part Number**
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
160-8178	Rod As-Conn	379-8869

B1A		
Original Part Number	**Part Name**	**Classic Part Number**
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170

B1A		
Original Part Number	**Part Name**	**Classic Part Number**
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266

BAK		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3368	Pipe-Exhaust	311-9434
3N-8463	Bearing-Roller	394-9193
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271

BAK		
Original Part Number	**Part Name**	**Classic Part Number**
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4P-7688	Valve As-Check	420-6216
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571

BAK		
Original Part Number	**Part Name**	**Classic Part Number**
7C-1068	Impeller-Pump	378-3981
7E-5996	Rod As-Conn	379-8864
7E-6003	Bearing-Sleeve	417-4522
7E-9907	Spacer-Fp Timing	394-0222
7N-2156	Bearing-Sleeve	380-7373
7N-8629	Coupling-Elbow	419-4664
7N-8828	Pulley	420-6395
7T-2036	Cap As-Fuel	361-1721
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-3248	Gasket As	415-1893
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984

Sales Model 3412C (Cont'd.)

BAK		
Original Part Number	Part Name	Classic Part Number
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504

BAK		
Original Part Number	Part Name	Classic Part Number
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
142-1699	Gasket Kit	392-4507
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
207-1332	Bellows As	444-0569
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846

BAK		
Original Part Number	Part Name	Classic Part Number
216-4592	Gasket Kit - Ocl	437-8145
217-0586	Bearing-Rod	419-7266
219-6544	Kit-Gasket-Acl	437-2001
219-6560	Kit-Gasket(F)	437-8153
219-6578	Kit-Gasket-Mch	437-8139
219-6610	Kit - Gasket	437-8138
219-7628	Kit-Gasket-Mch	437-8137
219-7629	Kit-Gasket-Sch	437-8136
219-7630	Kit - Gasket	437-2000
234-1630	Kit-Gasket(Rs)	393-1040
234-1900	Kit-Gasket(Fs)	437-8667
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

BAX		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017

BAX		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-8463	Bearing-Roller	394-9193
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928

BAX		
Original Part Number	Part Name	Classic Part Number
4N-1675	Manifold-Exhaust	443-2015
4N-1849	Pipe-Air	421-7143
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889

Sales Model 3412C (Cont'd.)

BAX		
Original Part Number	Part Name	Classic Part Number
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4W-2541	Shaft-Gov Cont	399-8580
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656

BAX		
Original Part Number	Part Name	Classic Part Number
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7N-8828	Pulley	420-6395
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-2104	Bell As-Suction	380-1521
8N-3248	Gasket As	415-1893
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951

BAX		
Original Part Number	Part Name	Classic Part Number
9L-5839	Coupling-Exhaust	374-7480
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457

Sales Model 3412C (Cont'd.)

BAX		
Original Part Number	Part Name	Classic Part Number
142-1699	Gasket Kit	392-4507
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
163-3103	Manifold-Exh	430-8992
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
216-4499	Kit-Gasket-Sch	437-8147
216-4530	Kit-Gasket-Mch	437-8146

BAX		
Original Part Number	Part Name	Classic Part Number
216-4592	Gasket Kit - Ocl	437-8145
217-0586	Bearing-Rod	419-7266
219-6544	Kit-Gasket-Acl	437-2001
219-6556	Kit-Gasket(F)	437-8141
219-7630	Kit - Gasket	437-2000
232-6173	Kit-Gasket-Fs	393-0923
234-1630	Kit-Gasket(Rs)	393-1040

BAX		
Original Part Number	Part Name	Classic Part Number
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

DK6		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3368	Pipe-Exhaust	311-9434
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885

DK6		
Original Part Number	Part Name	Classic Part Number
4N-8472	Housing-Aftclr	419-0887
4P-7688	Valve As-Check	420-6216
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5996	Rod As-Conn	379-8864
7E-6003	Bearing-Sleeve	417-4522
7E-9907	Spacer-Fp Timing	394-0222

DK6		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
7N-8629	Coupling-Elbow	419-4664
7N-8828	Pulley	420-6395
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-2102	Bonnet-Valve	455-3274

Sales Model 3412C (Cont'd.)

DK6		
Original Part Number	**Part Name**	**Classic Part Number**
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504

DK6		
Original Part Number	**Part Name**	**Classic Part Number**
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553

DK6		
Original Part Number	**Part Name**	**Classic Part Number**
137-6500	Rotocoil As.	397-5053
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

XJ5		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157

XJ5		
Original Part Number	**Part Name**	**Classic Part Number**
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4P-7688	Valve As-Check	420-6216
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5996	Rod As-Conn	379-8864

XJ5		
Original Part Number	**Part Name**	**Classic Part Number**
7E-6003	Bearing-Sleeve	417-4522
7E-9907	Spacer-Fp Timing	394-0222
7N-2156	Bearing-Sleeve	380-7373
7N-8828	Pulley	420-6395
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487

Sales Model 3412C (Cont'd.)

XJ5		
Original Part Number	Part Name	Classic Part Number
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703

XJ5		
Original Part Number	Part Name	Classic Part Number
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553

XJ5		
Original Part Number	Part Name	Classic Part Number
137-6500	Rotocoil As.	397-5053
142-3035	Kit-Gasket (Wlg)	393-0926
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

Sales Model 3412D

REA		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556

REA		
Original Part Number	Part Name	Classic Part Number
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3N-8463	Bearing-Roller	394-9193
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885

REA		
Original Part Number	Part Name	Classic Part Number
4N-8472	Housing-Aftclr	419-0887
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4W-2541	Shaft-Gov Cont	399-8580

Sales Model 3412D (Cont'd.)

REA		
Original Part Number	Part Name	Classic Part Number
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065
6L-2279	Plug-Ptf	419-4739
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6V-0237	Kit-Gasket-Exp	437-4584
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5085	Bushing	377-5829
7M-7219	Bearing-Thrust	384-4816

REA		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
7S-4411	Cap As-Rain	373-1912
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
8F-6058	Bearing-Sleeve	416-5494
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9L-5961	Adapter-Compr Dr	416-5508
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
100-6920	Adapter-Nozzle	380-1552

REA		
Original Part Number	Part Name	Classic Part Number
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
211-0592	Bearing - Main	419-6368
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
352-0200	Pump Gp-Water -B	434-6109

Sales Model 3412E

4CR		
Original Part Number	Part Name	Classic Part Number
1N-3113	Support-Elbow	433-8185
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354

4CR		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548

4CR		
Original Part Number	Part Name	Classic Part Number
2W-4087	Gear As-Idler	418-9582
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3368	Pipe-Exhaust	311-9434
4B-7270	Cone-Bearing	399-4439

Sales Model 3412E (Cont'd.)

4CR		
Original Part Number	Part Name	Classic Part Number
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1186	Bearing-Sleeve	417-4519
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168

4CR		
Original Part Number	Part Name	Classic Part Number
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161
5F-7404	Nut-Bearing Lock	308-9878
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5N-1932	Shaft-Clutch	425-0216
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7N-2156	Bearing-Sleeve	380-7373
7N-5089	Gasket	394-0890
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8828	Pulley	420-6395
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521

4CR		
Original Part Number	Part Name	Classic Part Number
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9L-5961	Adapter-Compr Dr	416-5508
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919

Sales Model 3412E (Cont'd.)

4CR		
Original Part Number	**Part Name**	**Classic Part Number**
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-4039	Kit-Gasket(F)	437-3224
138-6744	Rebuild Kit-Pump	363-7457
142-1699	Gasket Kit	392-4507
142-3035	Kit-Gasket (Wlg)	393-0926
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554

4CR		
Original Part Number	**Part Name**	**Classic Part Number**
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-4109	Manifold-Exhaust	433-9857
163-5316	Kit-Gasket(F)	437-2018
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
216-4592	Gasket Kit - Ocl	437-8145

4CR		
Original Part Number	**Part Name**	**Classic Part Number**
217-0586	Bearing-Rod	419-7266
234-1630	Kit-Gasket(Rs)	393-1040
234-1900	Kit-Gasket(Fs)	437-8667
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
293-1009	Kit-Gasket (Mch)	438-0146
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

9KS		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4W-5698	Bearing-Main	419-6323

9KS		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6L-2279	Plug-Ptf	419-4739
6N-0977	Bearing-Sleeve	417-4524
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5996	Rod As-Conn	379-8864
7N-2156	Bearing-Sleeve	380-7373

9KS		
Original Part Number	**Part Name**	**Classic Part Number**
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9L-5961	Adapter-Compr Dr	416-5508
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703

Sales Model 3412E (Cont'd.)

9KS		
Original Part Number	**Part Name**	**Classic Part Number**
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457

9KS		
Original Part Number	**Part Name**	**Classic Part Number**
139-4758	Gasket Kit	436-8405
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
167-8126	Damper As	382-8019
176-8167	Kit-Gasket-Acl	437-2011
176-8182	Kit-Gasket(Scl)	437-2010
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846

9KS		
Original Part Number	**Part Name**	**Classic Part Number**
215-7140	Kit-Gasket (Mch)	437-2002
215-7144	Kit-Gasket (Sch)	437-8148
217-0586	Bearing-Rod	419-7266
234-1914	Kit-Gasket(Fs)	437-2021
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

9PW		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-8463	Bearing-Roller	394-9193
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928

9PW		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
6B-3223	Cup-Bearing	399-6065

9PW		
Original Part Number	**Part Name**	**Classic Part Number**
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-0237	Kit-Gasket-Exp	437-4584
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7N-2156	Bearing-Sleeve	380-7373
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9L-5839	Coupling-Exhaust	374-7480
9N-3668	Base As.-Coolant	419-4718
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552

Sales Model 3412E (Cont'd.)

9PW		
Original Part Number	**Part Name**	**Classic Part Number**
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566

9PW		
Original Part Number	**Part Name**	**Classic Part Number**
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
167-8126	Damper As	382-8019

9PW		
Original Part Number	**Part Name**	**Classic Part Number**
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266
219-6544	Kit-Gasket-Acl	437-2001
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-6443	Kit-Gasket-T	437-8652
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

BDT		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-7125	Governor As	383-3672
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
4B-7270	Cone-Bearing	399-4439
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489

BDT		
Original Part Number	**Part Name**	**Classic Part Number**
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318

BDT		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5D-7449	Cup-Spl Tapered	416-2161
5L-7520	Elbow-Exhaust	419-4711
5N-1932	Shaft-Clutch	425-0216
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065
6L-4714	Panel-Acl Filter	314-8532
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657

Sales Model 3412E (Cont'd.)

BDT		
Original Part Number	Part Name	Classic Part Number
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-5089	Gasket	394-0890
7N-7435	Kit-Major Repair	374-4724
7N-8828	Pulley	420-6395
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3580	Bracket-Mtg	418-1939
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9L-5961	Adapter-Compr Dr	416-5508
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552

BDT		
Original Part Number	Part Name	Classic Part Number
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112

BDT		
Original Part Number	Part Name	Classic Part Number
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
142-1699	Gasket Kit	392-4507
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
145-8503	Shaft As-Idler	426-0035
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
163-4109	Manifold-Exhaust	433-9857
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
216-4592	Gasket Kit - Ocl	437-8145
217-0586	Bearing-Rod	419-7266
234-1630	Kit-Gasket(Rs)	393-1040
234-1900	Kit-Gasket(Fs)	437-8667
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
256-9653	Flywheel As.	425-3444
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

BFT		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305

BFT		
Original Part Number	Part Name	Classic Part Number
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
3E-6772	Seal-Water	382-8017

BFT		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
3N-3368	Pipe-Exhaust	311-9434
4B-7270	Cone-Bearing	399-4439
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974

Sales Model 3412E (Cont'd.)

BFT		
Original Part Number	Part Name	Classic Part Number
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1675	Manifold-Exhaust	443-2015
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
5N-1932	Shaft-Clutch	425-0216
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-6490	Bracket As-Fan	420-8569

BFT		
Original Part Number	Part Name	Classic Part Number
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7N-2156	Bearing-Sleeve	380-7373
7N-5089	Gasket	394-0890
7N-7435	Kit-Major Repair	374-4724
7N-8828	Pulley	420-6395
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9L-5961	Adapter-Compr Dr	416-5508
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926

BFT		
Original Part Number	Part Name	Classic Part Number
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-4109	Manifold-Exhaust	433-9857
180-6645	Shaft As.	396-1566
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

Sales Model 3412E (Cont'd.)

BNF		
Original Part Number	Part Name	Classic Part Number
1N-3113	Support-Elbow	433-8185
1P-1367	Plunger-Valve	432-8913
1S-9209	Shaft-Tightener	374-6499
1W-6186	Shield As	374-4705
2A-4429	Lock-Retainer	379-0174
2P-8986	Cup-Rlr Bearing	415-1912
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-7610	Gear-Hyd Pump Dr	418-1940
2W-7614	Gear-Crankshaft	425-7752
2W-8038	Gear-Camshaft	425-7751
2W-9978	Core As-Oclr	279-4983
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1157	Coupling-Exhaust	379-0177
4N-1186	Bearing-Sleeve	417-4519
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4W-0419	Core As-Oclr	379-0182
4W-0452	Seal As -Cshaft	325-6191
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255

BNF		
Original Part Number	Part Name	Classic Part Number
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5F-7404	Nut-Bearing Lock	308-9878
5P-1370	Bearing As-Rlr	416-2164
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
6N-0977	Bearing-Sleeve	417-4524
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-3205	Manifold-Inlet	376-9060
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-1713	Core Gp-O Clr	438-2010
7W-3145	Plate	422-7894
8N-0788	Cover	440-0849
8N-0935	Gear-Pump Drive	399-8569
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-3666	Repair Kt-Major	377-5842
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
9L-5961	Adapter-Compr Dr	416-5508
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605

BNF		
Original Part Number	Part Name	Classic Part Number
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
107-8106	Manifold-Exh	374-7487
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
141-4109	Core As-Oclr	416-5518
145-8503	Shaft As-Idler	426-0035
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
163-4109	Manifold-Exhaust	433-9857
180-6645	Shaft As.	396-1566

Sales Model 3412E (Cont'd.)

BNF		
Original Part Number	**Part Name**	**Classic Part Number**
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266

BNF		
Original Part Number	**Part Name**	**Classic Part Number**
221-9356	Flywheel As	435-2575
253-1752	Plate-Thrust	379-0170

BNF		
Original Part Number	**Part Name**	**Classic Part Number**
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266

EPL		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3368	Pipe-Exhaust	311-9434
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255

EPL		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
6N-0977	Bearing-Sleeve	417-4524
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7W-2315	Retainer	384-3475
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062

EPL		
Original Part Number	**Part Name**	**Classic Part Number**
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
180-6645	Shaft As.	396-1566
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367

Sales Model 3412E (Cont'd.)

EPL		
Original Part Number	Part Name	Classic Part Number
328-5574	Bearing-Rod	419-7266

EPL		
Original Part Number	Part Name	Classic Part Number
352-0200	Pump Gp-Water -B	434-6109

Z2D		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975

Z2D		
Original Part Number	Part Name	Classic Part Number
4W-5998	Rod-Valve Push	379-0168
6N-0977	Bearing-Sleeve	417-4524
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5996	Rod As-Conn	379-8864
7N-2156	Bearing-Sleeve	380-7373
7W-2315	Retainer	384-3475
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9L-5961	Adapter-Compr Dr	416-5508
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463

Z2D		
Original Part Number	Part Name	Classic Part Number
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
180-6645	Shaft As.	396-1566
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

Sales Model 3456

3LW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-2489	Muffler As	360-7870
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2P-8986	Cup-Rlr Bearing	415-1912
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
4B-7270	Cone-Bearing	399-4439
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-3092	Spider As-Fan	363-7465
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065

3LW		
Original Part Number	Part Name	Classic Part Number
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-2687	Spider As.-Fan	385-7199
6N-6490	Bracket As-Fan	420-8569
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
8N-1184	Elbow-Exhaust	392-4497
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9L-6371	Rod-Eye	363-7459

3LW		
Original Part Number	Part Name	Classic Part Number
9N-0316	Bracket-Pulley	434-1993
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-7148	Cap As-Rain	378-3994
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
101-9640	Gear-Air Compr	398-2966
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
155-5619	Gasket	382-5054

Sales Model 3456 (Cont'd.)

3LW		
Original Part Number	Part Name	Classic Part Number
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656

3LW		
Original Part Number	Part Name	Classic Part Number
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367

3LW		
Original Part Number	Part Name	Classic Part Number
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

9BZ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451

9BZ		
Original Part Number	Part Name	Classic Part Number
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7W-3145	Plate	422-7894
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813

9BZ		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

Sales Model 3456 (Cont'd.)

9YP		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811

9YP		
Original Part Number	Part Name	Classic Part Number
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9N-3167	Plate-Block Bot	430-4468
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

9YP		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387

BGA		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919

BGA		
Original Part Number	Part Name	Classic Part Number
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171

BGA		
Original Part Number	Part Name	Classic Part Number
6N-6490	Bracket As-Fan	420-8569
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190

Sales Model 3456 (Cont'd.)

BGA		
Original Part Number	Part Name	Classic Part Number
7N-8828	Pulley	420-6395
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566

BGA		
Original Part Number	Part Name	Classic Part Number
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
170-4860	Bonnet-Oil Clr	430-5359

BGA		
Original Part Number	Part Name	Classic Part Number
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

DPG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555

DPG		
Original Part Number	Part Name	Classic Part Number
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7W-3145	Plate	422-7894
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
102-8501	Manifold-Exhaust	377-5853

DPG		
Original Part Number	Part Name	Classic Part Number
102-8608	Manifold-Exhaust	376-9062
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
146-2601	Cover	399-6054
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956

Sales Model 3456 (Cont'd.)

DPG		
Original Part Number	**Part Name**	**Classic Part Number**
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665

DPG		
Original Part Number	**Part Name**	**Classic Part Number**
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443

DPG		
Original Part Number	**Part Name**	**Classic Part Number**
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665

EPE		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569

EPE		
Original Part Number	**Part Name**	**Classic Part Number**
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814

EPE		
Original Part Number	**Part Name**	**Classic Part Number**
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
170-4860	Bonnet-Oil Clr	430-5359
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

Sales Model 4200G

04C		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0210	Bearing-Ball	417-4498
5L-6326	Bearing-Ball	420-3222
9L-2685	Rod End	419-1866

Sales Model 4800G

03R		
Original Part Number	**Part Name**	**Classic Part Number**
2F-5721	Bearing-Ball	311-9354
5F-8651	Bearing-Ball	420-3223
6B-6224	Ferrule	419-4738
9B-0399	Link As-Cl Drive	431-5268
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

Sales Model 5500G

04C		
Original Part Number	**Part Name**	**Classic Part Number**
3H-1996	Bearing-Ball	380-1498
9L-2685	Rod End	419-1866

Sales Model 6000G

04C		
Original Part Number	**Part Name**	**Classic Part Number**
9B-0399	Link As-Cl Drive	431-5268
9L-2685	Rod End	419-1866
108-5603	Screw-Adj Arm	379-0166

Sales Model 6500G

05E		
Original Part Number	**Part Name**	**Classic Part Number**
9L-2685	Rod End	419-1866
108-5603	Screw-Adj Arm	379-0166

Sales Model 7500G

04C		
Original Part Number	**Part Name**	**Classic Part Number**
9B-0399	Link As-Cl Drive	431-5268
9L-2685	Rod End	419-1866

Sales Model 800G

01N		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368

Sales Model C-10

168		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
4P-3754	Core As-Oclr	438-2016
7W-5844	Bearing-Conn Rod	419-4650
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447

168		
Original Part Number	**Part Name**	**Classic Part Number**
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
176-4168	Bridge As-Valve	419-4727

168		
Original Part Number	**Part Name**	**Classic Part Number**
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
352-2077	Pump Gp-Water -B	434-6108

2PN		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
5S-8543	Bearing-Sleeve	376-3635
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7L-4302	Gasket	420-8570
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568
7W-5733	Gasket	421-7333
7W-5844	Bearing-Conn Rod	419-4650

2PN		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
113-6200	Gasket	438-2020
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
119-2940	Gasket	378-4002
133-3545	Tightener-Belt	434-1407
134-9807	Gasket Kit	437-3214
135-0239	Gasket Kit	437-4606
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554

2PN		
Original Part Number	**Part Name**	**Classic Part Number**
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
193-3322	Gasket Kit - Ocl	437-2007
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
221-0859	Kit-Gasket-T	437-8135
234-1874	Kit-Gasket-Fs	437-8668
252-7955	Kit-Gasket(Cl)	437-8654
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
352-2077	Pump Gp-Water -B	434-6108

Sales Model C-10 (Cont'd.)

3CS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-6658	Bearing-Sleeve	373-1885
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
5S-8543	Bearing-Sleeve	376-3635
6N-0977	Bearing-Sleeve	417-4524
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724

3CS		
Original Part Number	Part Name	Classic Part Number
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8H-9789	Bearing-Ball	374-8342
9Y-2988	Breather As	361-1716
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
113-6200	Gasket	438-2020
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
119-2940	Gasket	378-4002
133-3545	Tightener-Belt	434-1407
135-0239	Gasket Kit	437-4606
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484

3CS		
Original Part Number	Part Name	Classic Part Number
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
193-3322	Gasket Kit - Ocl	437-2007
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
219-6544	Kit-Gasket-Acl	437-2001
221-0859	Kit-Gasket-T	437-8135
234-1630	Kit-Gasket(Rs)	393-1040
252-7955	Kit-Gasket(Cl)	437-8654
253-1752	Plate-Thrust	379-0170
283-6443	Kit-Gasket-T	437-8652
316-4396	Kit-Gasket (Sch)	393-3661
319-8126	Kit-Gasket (Sch)	438-0136
328-5574	Bearing-Rod	419-7266
352-2077	Pump Gp-Water -B	434-6108

8YS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
5S-8543	Bearing-Sleeve	376-3635
6V-2202	Bearing-Spl Ball	380-1574

8YS		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281

8YS		
Original Part Number	Part Name	Classic Part Number
111-2645	Valve-Pump Byp	441-1561
113-6200	Gasket	438-2020
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

Sales Model C-10 (Cont'd.)

8YS		
Original Part Number	**Part Name**	**Classic Part Number**
118-2800	Housing As.-Rglt	419-4719
119-2940	Gasket	378-4002
133-3545	Tightener-Belt	434-1407
135-0239	Gasket Kit	437-4606
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
166-6352	Tube As.	432-4223

8YS		
Original Part Number	**Part Name**	**Classic Part Number**
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
193-3322	Gasket Kit - Ocl	437-2007

8YS		
Original Part Number	**Part Name**	**Classic Part Number**
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
221-0859	Kit-Gasket-T	437-8135
252-7955	Kit-Gasket(Cl)	437-8654
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
352-2077	Pump Gp-Water -B	434-6108

AKB		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
6V-3831	Seal-O-Ring	436-2657
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646

AKB		
Original Part Number	**Part Name**	**Classic Part Number**
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

AKB		
Original Part Number	**Part Name**	**Classic Part Number**
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
216-4781	Gasket Kit	437-8144

BCX		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-4668	Breather-Engine	396-7271
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041

BCX		
Original Part Number	**Part Name**	**Classic Part Number**
4P-8280	Manifold-Exhaust	430-7236
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-7188	Core As-Oclr	374-7501
4W-9822	Core Gp-O Clr	374-4711
5F-8651	Bearing-Ball	420-3223
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-8543	Bearing-Sleeve	376-3635

BCX		
Original Part Number	**Part Name**	**Classic Part Number**
6B-3223	Cup-Bearing	399-6065
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-2731	Retainer	423-3541
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
9S-7148	Cap As-Rain	378-3994

Sales Model C-10 (Cont'd.)

BCX		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446

BCX		
Original Part Number	**Part Name**	**Classic Part Number**
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
133-3545	Tightener-Belt	434-1407
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
166-6352	Tube As.	432-4223
176-4168	Bridge As-Valve	419-4727

BCX		
Original Part Number	**Part Name**	**Classic Part Number**
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
352-2077	Pump Gp-Water -B	434-6108

DWP		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
6V-3831	Seal-O-Ring	436-2657
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8H-9789	Bearing-Ball	374-8342

DWP		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259

DWP		
Original Part Number	**Part Name**	**Classic Part Number**
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367

F8H		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
6V-3831	Seal-O-Ring	436-2657
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650

F8H		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447

F8H		
Original Part Number	**Part Name**	**Classic Part Number**
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600

Sales Model C-10 (Cont'd.)

F8H		
Original Part Number	Part Name	Classic Part Number
176-6997	Shaft	399-8573

F8H		
Original Part Number	Part Name	Classic Part Number
176-6998	Impeller-Wtr Pmp	425-9367

F8H		
Original Part Number	Part Name	Classic Part Number
216-4781	Gasket Kit	437-8144

MBJ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
5S-8543	Bearing-Sleeve	376-3635
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650

MBJ		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
100-6267	Plate As-Idler	375-9983
101-3125	Gasket	420-8567
111-2645	Valve-Pump Byp	441-1561
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
133-3545	Tightener-Belt	434-1407
144-0502	Ring Kit-Piston	395-1312

MBJ		
Original Part Number	Part Name	Classic Part Number
144-0503	Piston Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
166-6352	Tube As.	432-4223
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
186-2001	Rotocoil As	397-5055
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
315-6671	Kit-Gasket(Op)	438-0139
323-4174	Kit-Gasket (Sch)	438-0134
352-2077	Pump Gp-Water -B	434-6108

Z2B		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-3754	Core As-Oclr	438-2016
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-7188	Core As-Oclr	374-7501
6V-3831	Seal-O-Ring	436-2657
7W-5844	Bearing-Conn Rod	419-4650
8H-9789	Bearing-Ball	374-8342

Z2B		
Original Part Number	Part Name	Classic Part Number
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
111-2645	Valve-Pump Byp	441-1561
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

Z2B		
Original Part Number	Part Name	Classic Part Number
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
352-2077	Pump Gp-Water -B	434-6108

Sales Model C-12

170		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446

170		
Original Part Number	**Part Name**	**Classic Part Number**
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600

170		
Original Part Number	**Part Name**	**Classic Part Number**
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
352-2077	Pump Gp-Water -B	434-6108

1YN		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
5S-8543	Bearing-Sleeve	376-3635
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568
7X-7975	Gasket Kit	437-3233
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281

1YN		
Original Part Number	**Part Name**	**Classic Part Number**
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
133-3545	Tightener-Belt	434-1407
134-9807	Gasket Kit	437-3214
135-0239	Gasket Kit	437-4606
142-2535	Gasket Kit	437-4593
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154

1YN		
Original Part Number	**Part Name**	**Classic Part Number**
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
193-3322	Gasket Kit - Ocl	437-2007
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
236-8883	Kit-Gasket-Ocl	437-8659
252-7955	Kit-Gasket(Cl)	437-8654
316-4396	Kit-Gasket (Sch)	393-3661
352-2077	Pump Gp-Water -B	434-6108

2KS		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174

2KS		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041

2KS		
Original Part Number	**Part Name**	**Classic Part Number**
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502

Sales Model C-12 (Cont'd.)

2KS		
Original Part Number	Part Name	Classic Part Number
5S-8543	Bearing-Sleeve	376-3635
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635

2KS		
Original Part Number	Part Name	Classic Part Number
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
133-3545	Tightener-Belt	434-1407
134-9807	Gasket Kit	437-3214
142-2535	Gasket Kit	437-4593
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223

2KS		
Original Part Number	Part Name	Classic Part Number
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
193-3322	Gasket Kit - Ocl	437-2007
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
236-8883	Kit-Gasket-Ocl	437-8659
252-7955	Kit-Gasket(Cl)	437-8654
315-6671	Kit-Gasket(Op)	438-0139
316-4396	Kit-Gasket (Sch)	393-3661
319-0848	Kit-Gasket(T)	438-0138
322-2929	Kit-Gasket (Sch)	438-0135
352-2077	Pump Gp-Water -B	434-6108

8YF		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
5S-8543	Bearing-Sleeve	376-3635
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568

8YF		
Original Part Number	Part Name	Classic Part Number
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

8YF		
Original Part Number	Part Name	Classic Part Number
118-2800	Housing As.-Rglt	419-4719
133-3545	Tightener-Belt	434-1407
134-9807	Gasket Kit	437-3214
142-2535	Gasket Kit	437-4593
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407

Sales Model C-12 (Cont'd.)

8YF		
Original Part Number	**Part Name**	**Classic Part Number**
193-3322	Gasket Kit - Ocl	437-2007
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
236-8883	Kit-Gasket-Ocl	437-8659

8YF		
Original Part Number	**Part Name**	**Classic Part Number**
252-7955	Kit-Gasket(Cl)	437-8654
315-6671	Kit-Gasket(Op)	438-0139
316-4396	Kit-Gasket (Sch)	393-3661
319-0848	Kit-Gasket(T)	438-0138

8YF		
Original Part Number	**Part Name**	**Classic Part Number**
322-2929	Kit-Gasket (Sch)	438-0135
352-2077	Pump Gp-Water -B	434-6108

9HP		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2W-9978	Core As-Oclr	279-4983
3N-3017	Adapter As	433-2031
4L-8473	Plate-Wear	419-0883
4N-2514	Gear-Flywheel	421-7283
5F-8651	Bearing-Ball	420-3223
5P-7807	Bearing-Ball	314-8502
6L-2279	Plug-Ptf	419-4739
6V-3831	Seal-O-Ring	436-2657
7L-7508	Bearing-Ball	420-6536
7S-4411	Cap As-Rain	373-1912
7W-2731	Retainer	423-3541

9HP		
Original Part Number	**Part Name**	**Classic Part Number**
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

9HP		
Original Part Number	**Part Name**	**Classic Part Number**
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
255-6863	Gasket	450-5024
352-2077	Pump Gp-Water -B	434-6108

9NS		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1W-3900	Gasket	472-8006
2A-4429	Lock-Retainer	379-0174
2P-0220	Gasket-Pump	398-2927
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4W-0452	Seal As -Cshaft	325-6191
5P-7807	Bearing-Ball	314-8502
5S-8543	Bearing-Sleeve	376-3635
6V-2202	Bearing-Spl Ball	380-1574

9NS		
Original Part Number	**Part Name**	**Classic Part Number**
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568
7W-5733	Gasket	421-7333
7X-7975	Gasket Kit	437-3233
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
108-7930	Bearing As	377-7463
111-2645	Valve-Pump Byp	441-1561

9NS		
Original Part Number	**Part Name**	**Classic Part Number**
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
133-3545	Tightener-Belt	434-1407
134-9807	Gasket Kit	437-3214
135-4928	Shaft-Water Pump	386-3813

Sales Model C-12 (Cont'd.)

9NS		
Original Part Number	Part Name	Classic Part Number
138-6744	Rebuild Kit-Pump	363-7457
140-2246	Gasket Kit	383-3710
140-9631	Kit-Gasket(F)	437-3217
142-2535	Gasket Kit	437-4593
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223

9NS		
Original Part Number	Part Name	Classic Part Number
166-9142	Gasket	420-8546
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-0605	Gasket Kit - Cl	382-5055
187-3307	Gasket As-Cyl	438-2022

9NS		
Original Part Number	Part Name	Classic Part Number
190-0649	Tightener-Belt	434-1407
193-3322	Gasket Kit - Ocl	437-2007
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
221-0859	Kit-Gasket-T	437-8135
234-1874	Kit-Gasket-Fs	437-8668
252-7955	Kit-Gasket(Cl)	437-8654
316-4396	Kit-Gasket (Sch)	393-3661
352-2077	Pump Gp-Water -B	434-6108
391-8229	Kit-Gasket-Fs	398-2955

9SM		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281

9SM		
Original Part Number	Part Name	Classic Part Number
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154

9SM		
Original Part Number	Part Name	Classic Part Number
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
193-3322	Gasket Kit - Ocl	437-2007
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
252-7955	Kit-Gasket(Cl)	437-8654
316-4396	Kit-Gasket (Sch)	393-3661
352-2077	Pump Gp-Water -B	434-6108

ALS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
6V-3831	Seal-O-Ring	436-2657

ALS		
Original Part Number	Part Name	Classic Part Number
7W-5164	Gasket	420-8568
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281

ALS		
Original Part Number	Part Name	Classic Part Number
111-2645	Valve-Pump Byp	441-1561
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447

Sales Model C-12 (Cont'd.)

ALS		
Original Part Number	**Part Name**	**Classic Part Number**
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

ALS		
Original Part Number	**Part Name**	**Classic Part Number**
147-3781	Kit-Gasket(Wp)	422-2484
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600

ALS		
Original Part Number	**Part Name**	**Classic Part Number**
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144

BCY		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
4N-1010	Support-Elbow	416-5509
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-7807	Bearing-Ball	314-8502
6V-3831	Seal-O-Ring	436-2657
7W-5164	Gasket	420-8568
8H-9789	Bearing-Ball	374-8342

BCY		
Original Part Number	**Part Name**	**Classic Part Number**
9L-5836	Coupling-Exhaust	385-7212
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
111-2645	Valve-Pump Byp	441-1561
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

BCY		
Original Part Number	**Part Name**	**Classic Part Number**
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
322-2929	Kit-Gasket (Sch)	438-0135
352-2077	Pump Gp-Water -B	434-6108

BDL		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4P-3754	Core As-Oclr	438-2016
4P-7731	Core Gp-O Clr	385-7228
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4P-9942	Seal-End Tank	385-7217

BDL		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9943	Seal-End Tank	385-7216
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-7188	Core As-Oclr	374-7501
4W-9822	Core Gp-O Clr	374-4711
5F-8651	Bearing-Ball	420-3223
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-8543	Bearing-Sleeve	376-3635
6B-3223	Cup-Bearing	399-6065
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-3039	Core As-Oclr	363-7451

BDL		
Original Part Number	**Part Name**	**Classic Part Number**
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-2731	Retainer	423-3541
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
9S-7148	Cap As-Rain	378-3994
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561

Sales Model C-12 (Cont'd.)

BDL		
Original Part Number	**Part Name**	**Classic Part Number**
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719

BDL		
Original Part Number	**Part Name**	**Classic Part Number**
133-3545	Tightener-Belt	434-1407
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
170-4860	Bonnet-Oil Clr	430-5359
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600

BDL		
Original Part Number	**Part Name**	**Classic Part Number**
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
315-6671	Kit-Gasket(Op)	438-0139
352-2077	Pump Gp-Water -B	434-6108

CPD		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5S-8543	Bearing-Sleeve	376-3635
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567

CPD		
Original Part Number	**Part Name**	**Classic Part Number**
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
133-3545	Tightener-Belt	434-1407
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554

CPD		
Original Part Number	**Part Name**	**Classic Part Number**
147-3781	Kit-Gasket(Wp)	422-2484
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
221-0859	Kit-Gasket-T	437-8135
316-4396	Kit-Gasket (Sch)	393-3661
352-2077	Pump Gp-Water -B	434-6108

GEP		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236

GEP		
Original Part Number	**Part Name**	**Classic Part Number**
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568

GEP		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561

Sales Model C-12 (Cont'd.)

GEP		
Original Part Number	Part Name	Classic Part Number
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

GEP		
Original Part Number	Part Name	Classic Part Number
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600

GEP		
Original Part Number	Part Name	Classic Part Number
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
352-2077	Pump Gp-Water -B	434-6108

K1M		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2W-9978	Core As-Oclr	279-4983
3N-3017	Adapter As	433-2031
4L-8473	Plate-Wear	419-0883
4N-2514	Gear-Flywheel	421-7283
5F-8651	Bearing-Ball	420-3223
5P-7807	Bearing-Ball	314-8502
6L-2279	Plug-Ptf	419-4739
6V-3831	Seal-O-Ring	436-2657
7L-7508	Bearing-Ball	420-6536
7S-4411	Cap As-Rain	373-1912
7W-2731	Retainer	423-3541

K1M		
Original Part Number	Part Name	Classic Part Number
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

K1M		
Original Part Number	Part Name	Classic Part Number
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
255-6863	Gasket	450-5024
352-2077	Pump Gp-Water -B	434-6108

MBL		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
5S-8543	Bearing-Sleeve	376-3635
6V-2202	Bearing-Spl Ball	380-1574

MBL		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
100-6267	Plate As-Idler	375-9983

MBL		
Original Part Number	Part Name	Classic Part Number
101-3125	Gasket	420-8567
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446

Sales Model C-12 (Cont'd.)

MBL		
Original Part Number	**Part Name**	**Classic Part Number**
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
133-3545	Tightener-Belt	434-1407
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048

MBL		
Original Part Number	**Part Name**	**Classic Part Number**
166-6352	Tube As.	432-4223
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
186-2001	Rotocoil As	397-5055
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110

MBL		
Original Part Number	**Part Name**	**Classic Part Number**
216-4781	Gasket Kit	437-8144
243-4690	Kit-Gasket (Ocl)	437-8658
243-4780	Kit-Gasket(Cl)	437-8657
244-1400	Kit-Gasket-Sch	437-8656
316-4396	Kit-Gasket (Sch)	393-3661
322-2929	Kit-Gasket (Sch)	438-0135
352-2077	Pump Gp-Water -B	434-6108

R1D		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-2156	Bearing-Sleeve	380-7373

R1D		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7435	Kit-Major Repair	374-4724
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5164	Gasket	420-8568
8H-9789	Bearing-Ball	374-8342
8S-6511	Bearing-Sleeve	380-7372
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-6054	Rod As-Conn	379-8868
9Y-7215	Sleeve-Isolator	425-3646
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
104-1706	Valve-Regulating	432-8281
108-7930	Bearing As	377-7463
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446

R1D		
Original Part Number	**Part Name**	**Classic Part Number**
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
147-3781	Kit-Gasket(Wp)	422-2484
150-1916	Manifold-Exh	395-1322
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
176-4168	Bridge As-Valve	419-4727

Sales Model C-12 (Cont'd.)

R1D		
Original Part Number	**Part Name**	**Classic Part Number**
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110

R1D		
Original Part Number	**Part Name**	**Classic Part Number**
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-4781	Gasket Kit	437-8144
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
243-6718	Kit-Brg(Main)	469-1690
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444

R1D		
Original Part Number	**Part Name**	**Classic Part Number**
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

RTW		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
6V-3831	Seal-O-Ring	436-2657
7W-5164	Gasket	420-8568
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567

RTW		
Original Part Number	**Part Name**	**Classic Part Number**
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

RTW		
Original Part Number	**Part Name**	**Classic Part Number**
118-2800	Housing As.-Rglt	419-4719
147-3781	Kit-Gasket(Wp)	422-2484
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144

TME		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
6V-3831	Seal-O-Ring	436-2657
7W-5164	Gasket	420-8568
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281

TME		
Original Part Number	**Part Name**	**Classic Part Number**
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

TME		
Original Part Number	**Part Name**	**Classic Part Number**
147-3781	Kit-Gasket(Wp)	422-2484
160-9874	Kit-Gasket-Scl	386-3048
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
352-2077	Pump Gp-Water -B	434-6108

Sales Model C-12

170		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446

170		
Original Part Number	**Part Name**	**Classic Part Number**
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600

170		
Original Part Number	**Part Name**	**Classic Part Number**
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
352-2077	Pump Gp-Water -B	434-6108

1YN		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
5S-8543	Bearing-Sleeve	376-3635
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568
7X-7975	Gasket Kit	437-3233
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281

1YN		
Original Part Number	**Part Name**	**Classic Part Number**
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
133-3545	Tightener-Belt	434-1407
134-9807	Gasket Kit	437-3214
135-0239	Gasket Kit	437-4606
142-2535	Gasket Kit	437-4593
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154

1YN		
Original Part Number	**Part Name**	**Classic Part Number**
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
193-3322	Gasket Kit - Ocl	437-2007
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
236-8883	Kit-Gasket-Ocl	437-8659
252-7955	Kit-Gasket(Cl)	437-8654
316-4396	Kit-Gasket (Sch)	393-3661
352-2077	Pump Gp-Water -B	434-6108

2KS		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174

2KS		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041

2KS		
Original Part Number	**Part Name**	**Classic Part Number**
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502

Sales Model C-12 (Cont'd.)

2KS		
Original Part Number	Part Name	Classic Part Number
5S-8543	Bearing-Sleeve	376-3635
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635

2KS		
Original Part Number	Part Name	Classic Part Number
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
133-3545	Tightener-Belt	434-1407
134-9807	Gasket Kit	437-3214
142-2535	Gasket Kit	437-4593
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223

2KS		
Original Part Number	Part Name	Classic Part Number
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
193-3322	Gasket Kit - Ocl	437-2007
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
236-8883	Kit-Gasket-Ocl	437-8659
252-7955	Kit-Gasket(Cl)	437-8654
315-6671	Kit-Gasket(Op)	438-0139
316-4396	Kit-Gasket (Sch)	393-3661
319-0848	Kit-Gasket(T)	438-0138
322-2929	Kit-Gasket (Sch)	438-0135
352-2077	Pump Gp-Water -B	434-6108

8YF		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
5S-8543	Bearing-Sleeve	376-3635
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568

8YF		
Original Part Number	Part Name	Classic Part Number
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

8YF		
Original Part Number	Part Name	Classic Part Number
118-2800	Housing As.-Rglt	419-4719
133-3545	Tightener-Belt	434-1407
134-9807	Gasket Kit	437-3214
142-2535	Gasket Kit	437-4593
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407

Sales Model C-12 (Cont'd.)

8YF		
Original Part Number	**Part Name**	**Classic Part Number**
193-3322	Gasket Kit - Ocl	437-2007
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
236-8883	Kit-Gasket-Ocl	437-8659

8YF		
Original Part Number	**Part Name**	**Classic Part Number**
252-7955	Kit-Gasket(Cl)	437-8654
315-6671	Kit-Gasket(Op)	438-0139
316-4396	Kit-Gasket (Sch)	393-3661
319-0848	Kit-Gasket(T)	438-0138

8YF		
Original Part Number	**Part Name**	**Classic Part Number**
322-2929	Kit-Gasket (Sch)	438-0135
352-2077	Pump Gp-Water -B	434-6108

9HP		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2W-9978	Core As-Oclr	279-4983
3N-3017	Adapter As	433-2031
4L-8473	Plate-Wear	419-0883
4N-2514	Gear-Flywheel	421-7283
5F-8651	Bearing-Ball	420-3223
5P-7807	Bearing-Ball	314-8502
6L-2279	Plug-Ptf	419-4739
6V-3831	Seal-O-Ring	436-2657
7L-7508	Bearing-Ball	420-6536
7S-4411	Cap As-Rain	373-1912
7W-2731	Retainer	423-3541

9HP		
Original Part Number	**Part Name**	**Classic Part Number**
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

9HP		
Original Part Number	**Part Name**	**Classic Part Number**
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
255-6863	Gasket	450-5024
352-2077	Pump Gp-Water -B	434-6108

9NS		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1W-3900	Gasket	472-8006
2A-4429	Lock-Retainer	379-0174
2P-0220	Gasket-Pump	398-2927
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4W-0452	Seal As -Cshaft	325-6191
5P-7807	Bearing-Ball	314-8502
5S-8543	Bearing-Sleeve	376-3635
6V-2202	Bearing-Spl Ball	380-1574

9NS		
Original Part Number	**Part Name**	**Classic Part Number**
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568
7W-5733	Gasket	421-7333
7X-7975	Gasket Kit	437-3233
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
108-7930	Bearing As	377-7463
111-2645	Valve-Pump Byp	441-1561

9NS		
Original Part Number	**Part Name**	**Classic Part Number**
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
133-3545	Tightener-Belt	434-1407
134-9807	Gasket Kit	437-3214
135-4928	Shaft-Water Pump	386-3813

Sales Model C-12 (Cont'd.)

9NS		
Original Part Number	Part Name	Classic Part Number
138-6744	Rebuild Kit-Pump	363-7457
140-2246	Gasket Kit	383-3710
140-9631	Kit-Gasket(F)	437-3217
142-2535	Gasket Kit	437-4593
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223

9NS		
Original Part Number	Part Name	Classic Part Number
166-9142	Gasket	420-8546
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-0605	Gasket Kit - Cl	382-5055
187-3307	Gasket As-Cyl	438-2022

9NS		
Original Part Number	Part Name	Classic Part Number
190-0649	Tightener-Belt	434-1407
193-3322	Gasket Kit - Ocl	437-2007
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
221-0859	Kit-Gasket-T	437-8135
234-1874	Kit-Gasket-Fs	437-8668
252-7955	Kit-Gasket(Cl)	437-8654
316-4396	Kit-Gasket (Sch)	393-3661
352-2077	Pump Gp-Water -B	434-6108
391-8229	Kit-Gasket-Fs	398-2955

9SM		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281

9SM		
Original Part Number	Part Name	Classic Part Number
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154

9SM		
Original Part Number	Part Name	Classic Part Number
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
193-3322	Gasket Kit - Ocl	437-2007
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
252-7955	Kit-Gasket(Cl)	437-8654
316-4396	Kit-Gasket (Sch)	393-3661
352-2077	Pump Gp-Water -B	434-6108

ALS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
6V-3831	Seal-O-Ring	436-2657

ALS		
Original Part Number	Part Name	Classic Part Number
7W-5164	Gasket	420-8568
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281

ALS		
Original Part Number	Part Name	Classic Part Number
111-2645	Valve-Pump Byp	441-1561
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447

Sales Model C-12 (Cont'd.)

ALS		
Original Part Number	**Part Name**	**Classic Part Number**
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

ALS		
Original Part Number	**Part Name**	**Classic Part Number**
147-3781	Kit-Gasket(Wp)	422-2484
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600

ALS		
Original Part Number	**Part Name**	**Classic Part Number**
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144

BCY		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
4N-1010	Support-Elbow	416-5509
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-7807	Bearing-Ball	314-8502
6V-3831	Seal-O-Ring	436-2657
7W-5164	Gasket	420-8568
8H-9789	Bearing-Ball	374-8342

BCY		
Original Part Number	**Part Name**	**Classic Part Number**
9L-5836	Coupling-Exhaust	385-7212
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
111-2645	Valve-Pump Byp	441-1561
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

BCY		
Original Part Number	**Part Name**	**Classic Part Number**
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
322-2929	Kit-Gasket (Sch)	438-0135
352-2077	Pump Gp-Water -B	434-6108

BDL		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4P-3754	Core As-Oclr	438-2016
4P-7731	Core Gp-O Clr	385-7228
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4P-9942	Seal-End Tank	385-7217

BDL		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9943	Seal-End Tank	385-7216
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-7188	Core As-Oclr	374-7501
4W-9822	Core Gp-O Clr	374-4711
5F-8651	Bearing-Ball	420-3223
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-8543	Bearing-Sleeve	376-3635
6B-3223	Cup-Bearing	399-6065
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-3039	Core As-Oclr	363-7451

BDL		
Original Part Number	**Part Name**	**Classic Part Number**
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-2731	Retainer	423-3541
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
9S-7148	Cap As-Rain	378-3994
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561

Sales Model C-12 (Cont'd.)

BDL		
Original Part Number	**Part Name**	**Classic Part Number**
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719

BDL		
Original Part Number	**Part Name**	**Classic Part Number**
133-3545	Tightener-Belt	434-1407
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
170-4860	Bonnet-Oil Clr	430-5359
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600

BDL		
Original Part Number	**Part Name**	**Classic Part Number**
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
315-6671	Kit-Gasket(Op)	438-0139
352-2077	Pump Gp-Water -B	434-6108

CPD		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5S-8543	Bearing-Sleeve	376-3635
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567

CPD		
Original Part Number	**Part Name**	**Classic Part Number**
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
133-3545	Tightener-Belt	434-1407
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554

CPD		
Original Part Number	**Part Name**	**Classic Part Number**
147-3781	Kit-Gasket(Wp)	422-2484
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
221-0859	Kit-Gasket-T	437-8135
316-4396	Kit-Gasket (Sch)	393-3661
352-2077	Pump Gp-Water -B	434-6108

GEP		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236

GEP		
Original Part Number	**Part Name**	**Classic Part Number**
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568

GEP		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561

Sales Model C-12 (Cont'd.)

GEP		
Original Part Number	**Part Name**	**Classic Part Number**
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

GEP		
Original Part Number	**Part Name**	**Classic Part Number**
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600

GEP		
Original Part Number	**Part Name**	**Classic Part Number**
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
352-2077	Pump Gp-Water -B	434-6108

K1M		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2W-9978	Core As-Oclr	279-4983
3N-3017	Adapter As	433-2031
4L-8473	Plate-Wear	419-0883
4N-2514	Gear-Flywheel	421-7283
5F-8651	Bearing-Ball	420-3223
5P-7807	Bearing-Ball	314-8502
6L-2279	Plug-Ptf	419-4739
6V-3831	Seal-O-Ring	436-2657
7L-7508	Bearing-Ball	420-6536
7S-4411	Cap As-Rain	373-1912
7W-2731	Retainer	423-3541

K1M		
Original Part Number	**Part Name**	**Classic Part Number**
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

K1M		
Original Part Number	**Part Name**	**Classic Part Number**
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
255-6863	Gasket	450-5024
352-2077	Pump Gp-Water -B	434-6108

MBL		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
5S-8543	Bearing-Sleeve	376-3635
6V-2202	Bearing-Spl Ball	380-1574

MBL		
Original Part Number	**Part Name**	**Classic Part Number**
6V-3831	Seal-O-Ring	436-2657
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
100-6267	Plate As-Idler	375-9983

MBL		
Original Part Number	**Part Name**	**Classic Part Number**
101-3125	Gasket	420-8567
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446

Sales Model C-12 (Cont'd.)

MBL		
Original Part Number	**Part Name**	**Classic Part Number**
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
133-3545	Tightener-Belt	434-1407
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048

MBL		
Original Part Number	**Part Name**	**Classic Part Number**
166-6352	Tube As.	432-4223
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
186-2001	Rotocoil As	397-5055
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110

MBL		
Original Part Number	**Part Name**	**Classic Part Number**
216-4781	Gasket Kit	437-8144
243-4690	Kit-Gasket (Ocl)	437-8658
243-4780	Kit-Gasket(Cl)	437-8657
244-1400	Kit-Gasket-Sch	437-8656
316-4396	Kit-Gasket (Sch)	393-3661
322-2929	Kit-Gasket (Sch)	438-0135
352-2077	Pump Gp-Water -B	434-6108

R1D		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-2156	Bearing-Sleeve	380-7373

R1D		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7435	Kit-Major Repair	374-4724
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5164	Gasket	420-8568
8H-9789	Bearing-Ball	374-8342
8S-6511	Bearing-Sleeve	380-7372
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-6054	Rod As-Conn	379-8868
9Y-7215	Sleeve-Isolator	425-3646
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
104-1706	Valve-Regulating	432-8281
108-7930	Bearing As	377-7463
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446

R1D		
Original Part Number	**Part Name**	**Classic Part Number**
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
147-3781	Kit-Gasket(Wp)	422-2484
150-1916	Manifold-Exh	395-1322
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
176-4168	Bridge As-Valve	419-4727

Sales Model C-12 (Cont'd.)

R1D		
Original Part Number	**Part Name**	**Classic Part Number**
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110

R1D		
Original Part Number	**Part Name**	**Classic Part Number**
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-4781	Gasket Kit	437-8144
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
243-6718	Kit-Brg(Main)	469-1690
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444

R1D		
Original Part Number	**Part Name**	**Classic Part Number**
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

RTW		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
6V-3831	Seal-O-Ring	436-2657
7W-5164	Gasket	420-8568
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567

RTW		
Original Part Number	**Part Name**	**Classic Part Number**
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

RTW		
Original Part Number	**Part Name**	**Classic Part Number**
118-2800	Housing As.-Rglt	419-4719
147-3781	Kit-Gasket(Wp)	422-2484
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144

TME		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
6V-3831	Seal-O-Ring	436-2657
7W-5164	Gasket	420-8568
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281

TME		
Original Part Number	**Part Name**	**Classic Part Number**
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

TME		
Original Part Number	**Part Name**	**Classic Part Number**
147-3781	Kit-Gasket(Wp)	422-2484
160-9874	Kit-Gasket-Scl	386-3048
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
352-2077	Pump Gp-Water -B	434-6108

Sales Model C-15

173		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-7693	Crankshaft As	269-8763
4P-2383	Adapter-Inlet	438-1812
4P-7827	Gear-Crankshaft	380-7533
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5P-8768	Kit-Gasket (Scl)	393-1024
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7M-4046	Bearing-Sleeve	394-8206

173		
Original Part Number	**Part Name**	**Classic Part Number**
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7998	Plate-Block	374-7496
7N-9805	Pin-Piston	295-6438
8N-1849	Bearing-Conn Rod	379-0196
8N-4110	Bearing-Sleeve	394-8207
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589

173		
Original Part Number	**Part Name**	**Classic Part Number**
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
232-3233	Bearing-Main	376-9085
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
334-8389	Crankshaft As	242-3439
430-7619	Adapter-Cla	438-1812

6NZ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354

6NZ		
Original Part Number	**Part Name**	**Classic Part Number**
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4W-2474	Rotocoil As	388-6571

6NZ		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467

Sales Model C-15 (Cont'd.)

6NZ		
Original Part Number	Part Name	Classic Part Number
6I-2726	Bearing-Sleeve	419-4757
6I-3066	Gasket-Cyl Head	380-1518
6I-3907	Adapter-Pilot	398-8348
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7W-1713	Core Gp-O Clr	438-2010
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9F-3212	Bearing-Ball	384-5953
9L-6371	Rod-Eye	363-7459

6NZ		
Original Part Number	Part Name	Classic Part Number
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
108-7930	Bearing As	377-7463
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
150-1914	Manifold-Exh	434-6111
150-1916	Manifold-Exh	395-1322
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054

6NZ		
Original Part Number	Part Name	Classic Part Number
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
189-1814	Kit-Gasket(Ocl)	437-2009
190-0649	Tightener-Belt	434-1407
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
222-7974	Kit - Gasket	437-2044
243-6718	Kit-Brg(Main)	469-1690
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
325-2721	Kit-Gasket(T)	393-3662
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

9NZ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
3E-6772	Seal-Water	382-8017

9NZ		
Original Part Number	Part Name	Classic Part Number
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

9NZ		
Original Part Number	Part Name	Classic Part Number
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6I-2726	Bearing-Sleeve	419-4757
6I-3066	Gasket-Cyl Head	380-1518

Sales Model C-15 (Cont'd.)

9NZ		
Original Part Number	Part Name	Classic Part Number
6I-3907	Adapter-Pilot	398-8348
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7W-1713	Core Gp-O Clr	438-2010
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9F-3212	Bearing-Ball	384-5953
9L-6371	Rod-Eye	363-7459
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718

9NZ		
Original Part Number	Part Name	Classic Part Number
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
108-7930	Bearing As	377-7463
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
150-1914	Manifold-Exh	434-6111
150-1916	Manifold-Exh	395-1322
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048

9NZ		
Original Part Number	Part Name	Classic Part Number
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
189-1814	Kit-Gasket(Ocl)	437-2009
190-0649	Tightener-Belt	434-1407
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
222-7974	Kit - Gasket	437-2044
243-6718	Kit-Brg(Main)	469-1690
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
325-2721	Kit-Gasket(T)	393-3662
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

BEM		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-2489	Muffler As	360-7870
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354

BEM		
Original Part Number	Part Name	Classic Part Number
2P-8986	Cup-Rlr Bearing	415-1912
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3P-1210	Cone-Roller Brg	399-4433
4B-7270	Cone-Bearing	399-4439
4N-0362	Cover As-Rgltr	419-4722

BEM		
Original Part Number	Part Name	Classic Part Number
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-3092	Spider As-Fan	363-7465
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919

Sales Model C-15 (Cont'd.)

BEM		
Original Part Number	Part Name	Classic Part Number
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724

BEM		
Original Part Number	Part Name	Classic Part Number
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-3248	Gasket As	415-1893
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-7148	Cap As-Rain	378-3994
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
101-9640	Gear-Air Compr	398-2966
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814

BEM		
Original Part Number	Part Name	Classic Part Number
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
146-2601	Cover	399-6054
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
197-5510	Support As	419-0880
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
430-7619	Adapter-Cla	438-1812

Sales Model C-15 (Cont'd.)

C2A		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7W-3145	Plate	422-7894
7W-5164	Gasket	420-8568
8H-9789	Bearing-Ball	374-8342
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480

C2A		
Original Part Number	Part Name	Classic Part Number
9N-3167	Plate-Block Bot	430-4468
9Y-2988	Breather As	361-1716
9Y-7215	Sleeve-Isolator	425-3646
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-1706	Valve-Regulating	432-8281
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554

C2A		
Original Part Number	Part Name	Classic Part Number
146-2601	Cover	399-6054
147-3781	Kit-Gasket(Wp)	422-2484
150-1914	Manifold-Exh	434-6111
150-1916	Manifold-Exh	395-1322
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-3307	Gasket As-Cyl	438-2022
187-8979	Gear As	393-3656
190-0649	Tightener-Belt	434-1407
197-5510	Support As	419-0880
197-9251	Pin As.-Piston	454-6110
211-0592	Bearing - Main	419-6368
216-4781	Gasket Kit	437-8144
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
352-2077	Pump Gp-Water -B	434-6108
430-7619	Adapter-Cla	438-1812

Sales Model C-15 (Cont'd.)

EGH		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7N-2156	Bearing-Sleeve	380-7373
7W-3145	Plate	422-7894

EGH		
Original Part Number	Part Name	Classic Part Number
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
150-1914	Manifold-Exh	434-6111
150-4637	Pan-Oil	377-5843

EGH		
Original Part Number	Part Name	Classic Part Number
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

MBN		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333

MBN		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6V-2202	Bearing-Spl Ball	380-1574
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373

MBN		
Original Part Number	Part Name	Classic Part Number
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7W-1713	Core Gp-O Clr	438-2010
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
8H-9789	Bearing-Ball	374-8342
8S-6511	Bearing-Sleeve	380-7372
9F-3212	Bearing-Ball	384-5953
9L-6371	Rod-Eye	363-7459
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665

Sales Model C-15 (Cont'd.)

MBN		
Original Part Number	Part Name	Classic Part Number
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
108-7930	Bearing As	377-7463
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052

MBN		
Original Part Number	Part Name	Classic Part Number
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
150-1914	Manifold-Exh	434-6111
150-1916	Manifold-Exh	395-1322
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
189-1814	Kit-Gasket(Ocl)	437-2009
190-0649	Tightener-Belt	434-1407
202-3572	Shaft As-Drive	426-0037

MBN		
Original Part Number	Part Name	Classic Part Number
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
325-2721	Kit-Gasket(T)	393-3662
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

Z2C		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4N-0362	Cover As-Rgltr	419-4722
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5B-9169	Plug-Drain	419-4736
6I-2726	Bearing-Sleeve	419-4757
6N-0597	Pulley-Fan	420-6391

Z2C		
Original Part Number	Part Name	Classic Part Number
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7N-2156	Bearing-Sleeve	380-7373
7N-8828	Pulley	420-6395
7W-3145	Plate	422-7894
7W-5733	Gasket	421-7333
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9N-0316	Bracket-Pulley	434-1993
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
108-7930	Bearing As	377-7463

Z2C		
Original Part Number	Part Name	Classic Part Number
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
146-2601	Cover	399-6054
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914

Sales Model C-15 (Cont'd.)

Z2C		
Original Part Number	**Part Name**	**Classic Part Number**
217-0578	Bearing-Rod	419-4665
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024

Z2C		
Original Part Number	**Part Name**	**Classic Part Number**
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443

Z2C		
Original Part Number	**Part Name**	**Classic Part Number**
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387

Sales Model C-16

174		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4P-2383	Adapter-Inlet	438-1812
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257

174		
Original Part Number	**Part Name**	**Classic Part Number**
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
153-7023	Valve-Inlet	391-1106

174		
Original Part Number	**Part Name**	**Classic Part Number**
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
430-7619	Adapter-Cla	438-1812

7CZ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174

7CZ		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904

7CZ		
Original Part Number	**Part Name**	**Classic Part Number**
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320

Sales Model C-16 (Cont'd.)

7CZ		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5701	Bearing-Main	419-6333
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6V-2202	Bearing-Spl Ball	380-1574
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7W-1713	Core Gp-O Clr	438-2010
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9F-3212	Bearing-Ball	384-5953
9L-6371	Rod-Eye	363-7459
9N-3167	Plate-Block Bot	430-4468

7CZ		
Original Part Number	**Part Name**	**Classic Part Number**
9N-3668	Base As.-Coolant	419-4718
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
108-7930	Bearing As	377-7463
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
150-1914	Manifold-Exh	434-6111
150-1916	Manifold-Exh	395-1322
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117

7CZ		
Original Part Number	**Part Name**	**Classic Part Number**
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
189-1814	Kit-Gasket(Ocl)	437-2009
190-0649	Tightener-Belt	434-1407
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
243-6718	Kit-Brg(Main)	469-1690
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
325-2721	Kit-Gasket(T)	393-3662
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
430-7619	Adapter-Cla	438-1812

BFM		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-2489	Muffler As	360-7870
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-7238	Shaft As-Pump Dr	379-0164

BFM		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2P-8986	Cup-Rlr Bearing	415-1912
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356

BFM		
Original Part Number	**Part Name**	**Classic Part Number**
3N-3017	Adapter As	433-2031
4B-7270	Cone-Bearing	399-4439
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283

Sales Model C-16 (Cont'd.)

BFM		
Original Part Number	Part Name	Classic Part Number
4N-3092	Spider As-Fan	363-7465
4N-4942	Rod-Eye	421-8919
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4P-7731	Core Gp-O Clr	385-7228
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-2687	Spider As.-Fan	385-7199
6N-6490	Bracket As-Fan	420-8569
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190

BFM		
Original Part Number	Part Name	Classic Part Number
7N-7435	Kit-Major Repair	374-4724
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-3248	Gasket As	415-1893
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9L-6371	Rod-Eye	363-7459
9N-0316	Bracket-Pulley	434-1993
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-7148	Cap As-Rain	378-3994
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
101-9640	Gear-Air Compr	398-2966
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589

BFM		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

Sales Model C-16 (Cont'd.)

W1A		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7N-2156	Bearing-Sleeve	380-7373
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372

W1A		
Original Part Number	**Part Name**	**Classic Part Number**
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8608	Manifold-Exhaust	376-9062
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
150-1914	Manifold-Exh	434-6111
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107

W1A		
Original Part Number	**Part Name**	**Classic Part Number**
154-1642	Gasket Kit - Scl	437-8117
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
189-1814	Kit-Gasket(Ocl)	437-2009
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
325-2721	Kit-Gasket(T)	393-3662
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

Sales Model C280-08

J4R		
Original Part Number	**Part Name**	**Classic Part Number**
5K-2294	Bearing	396-9912
9M-3914	Bearing-Aligning	420-2501

Sales Model CG137-8

FPL		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913

Sales Model CG137-8 (Cont'd.)

FPL		
Original Part Number	Part Name	Classic Part Number
1W-5009	Crankshaft As	398-2969
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2N-5842	Screw-Bridge Adj	418-1934
2W-4087	Gear As-Idler	418-9582
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255

FPL		
Original Part Number	Part Name	Classic Part Number
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-5996	Rod As-Conn	379-8864
7N-2156	Bearing-Sleeve	380-7373
7W-2315	Retainer	384-3475
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069

FPL		
Original Part Number	Part Name	Classic Part Number
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

Sales Model D11000

04C		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296

04C		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
3B-1142	Retainer-Spring	391-1099

04C		
Original Part Number	Part Name	Classic Part Number
4B-1455	Cap As-Filler	361-1719
5H-7071	Director-Water	388-0555
5S-1220	Lifter As-Valve	387-2926

Sales Model D11000 (Cont'd.)

04C		
Original Part Number	**Part Name**	**Classic Part Number**
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
8F-8523	Bearing-Sleeve	383-3701

04C		
Original Part Number	**Part Name**	**Classic Part Number**
9F-3358	Link As-Cl Drive	394-0207
9H-6236	Rod As	390-0999

04C		
Original Part Number	**Part Name**	**Classic Part Number**
9L-2685	Rod End	419-1866
121-7746	Pre-Cleaner As	360-2311

04H		
Original Part Number	**Part Name**	**Classic Part Number**
3B-6218	Muffler As	247-2672
3K-3124	Muffler-Trap	247-2673

04H		
Original Part Number	**Part Name**	**Classic Part Number**
5H-7071	Director-Water	388-0555
9S-7534	Pipe-Exh Ext	398-2950

09J		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1M-7250	Bowl	360-2296
1S-3743	Bearing-Ball	384-4786
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3H-0881	Ring-Piston	465-8998
3P-3623	Lock-Adj Nut	226-7989
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4H-7496	Plate-Pump Seal	420-6217

09J		
Original Part Number	**Part Name**	**Classic Part Number**
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-2256	Cage-Bearing	226-7973
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5S-1220	Lifter As-Valve	387-2926
6B-3223	Cup-Bearing	399-6065
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173

09J		
Original Part Number	**Part Name**	**Classic Part Number**
7B-5088	Drum-Steer Cl Dr	223-4813
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8F-8523	Bearing-Sleeve	383-3701
8M-8068	Bearing-Spl Ball	417-4500
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
121-7746	Pre-Cleaner As	360-2311

Sales Model D13000

01N		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296

01N		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2F-5721	Bearing-Ball	311-9354

01N		
Original Part Number	**Part Name**	**Classic Part Number**
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672

Sales Model D13000 (Cont'd.)

01N		
Original Part Number	Part Name	Classic Part Number
3H-0881	Ring-Piston	465-8998
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1220	Lifter As-Valve	387-2926

01N		
Original Part Number	Part Name	Classic Part Number
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7N-4170	Pump Gp-Eng Oil	379-0169
7N-9352	Gasket	433-8188

01N		
Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
9F-3358	Link As-Cl Drive	394-0207
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311

01T		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3H-0881	Ring-Piston	465-8998

01T		
Original Part Number	Part Name	Classic Part Number
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1220	Lifter As-Valve	387-2926
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536

01T		
Original Part Number	Part Name	Classic Part Number
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7N-4170	Pump Gp-Eng Oil	379-0169
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
9F-3358	Link As-Cl Drive	394-0207
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311

02V		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438

02V		
Original Part Number	Part Name	Classic Part Number
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3H-0881	Ring-Piston	465-8998
3K-3124	Muffler-Trap	247-2673
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997

02V		
Original Part Number	Part Name	Classic Part Number
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536

Sales Model D13000 (Cont'd.)

02V		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417

02V		
Original Part Number	**Part Name**	**Classic Part Number**
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8F-8523	Bearing-Sleeve	383-3701
9H-6236	Rod As	390-0999

02V		
Original Part Number	**Part Name**	**Classic Part Number**
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950

03R		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3H-0881	Ring-Piston	465-8998

03R		
Original Part Number	**Part Name**	**Classic Part Number**
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1220	Lifter As-Valve	387-2926
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536

03R		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7N-4170	Pump Gp-Eng Oil	379-0169
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
9F-3358	Link As-Cl Drive	394-0207
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311

03S		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438

03S		
Original Part Number	**Part Name**	**Classic Part Number**
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3H-0881	Ring-Piston	465-8998
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555

03S		
Original Part Number	**Part Name**	**Classic Part Number**
5S-1220	Lifter As-Valve	387-2926
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7N-4170	Pump Gp-Eng Oil	379-0169
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417

Sales Model D13000 (Cont'd.)

03S		
Original Part Number	**Part Name**	**Classic Part Number**
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8F-8523	Bearing-Sleeve	383-3701

03S		
Original Part Number	**Part Name**	**Classic Part Number**
8H-1994	Valve-Exhaust	443-1206
9F-3358	Link As-Cl Drive	394-0207
9H-6236	Rod As	390-0999

03S		
Original Part Number	**Part Name**	**Classic Part Number**
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311

04H		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672

04H		
Original Part Number	**Part Name**	**Classic Part Number**
3H-0881	Ring-Piston	465-8998
3K-3124	Muffler-Trap	247-2673
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5H-7071	Director-Water	388-0555
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358

04H		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4926	Retainer-Piston	314-8538
7N-9352	Gasket	433-8188
8F-8523	Bearing-Sleeve	383-3701
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311

04S		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3H-0881	Ring-Piston	465-8998
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823

04S		
Original Part Number	**Part Name**	**Classic Part Number**
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4H-7496	Plate-Pump Seal	420-6217
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5S-1220	Lifter As-Valve	387-2926
5S-7877	Bearing-Spl Ball	392-4491
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
7H-6967	Bearing-Ball	422-6489

04S		
Original Part Number	**Part Name**	**Classic Part Number**
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7N-4170	Pump Gp-Eng Oil	379-0169
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
9F-3358	Link As-Cl Drive	394-0207
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311

Sales Model D13000 (Cont'd.)

05E		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672

05E		
Original Part Number	**Part Name**	**Classic Part Number**
3H-0881	Ring-Piston	465-8998
3K-3124	Muffler-Trap	247-2673
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5H-7071	Director-Water	388-0555
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358

05E		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4926	Retainer-Piston	314-8538
7N-9352	Gasket	433-8188
8F-8523	Bearing-Sleeve	383-3701
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311

07S		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2978	Spider& Brg As	399-4424
2D-3188	Yoke	365-8822
2F-8509	Cone-Roller Brg	399-4434
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099

07S		
Original Part Number	**Part Name**	**Classic Part Number**
3H-0881	Ring-Piston	465-8998
4H-7496	Plate-Pump Seal	420-6217
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5S-1220	Lifter As-Valve	387-2926
5S-7877	Bearing-Spl Ball	392-4491
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739

07S		
Original Part Number	**Part Name**	**Classic Part Number**
7H-6967	Bearing-Ball	422-6489
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7N-4170	Pump Gp-Eng Oil	379-0169
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
121-7746	Pre-Cleaner As	360-2311

09J		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2F-5721	Bearing-Ball	311-9354

09J		
Original Part Number	**Part Name**	**Classic Part Number**
2F-8509	Cone-Roller Brg	399-4434
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3H-0881	Ring-Piston	465-8998
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
4B-1455	Cap As-Filler	361-1719

09J		
Original Part Number	**Part Name**	**Classic Part Number**
4B-7270	Cone-Bearing	399-4439
4H-7496	Plate-Pump Seal	420-6217
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502

Sales Model D13000 (Cont'd.)

09J		
Original Part Number	**Part Name**	**Classic Part Number**
5S-1220	Lifter As-Valve	387-2926
5S-7877	Bearing-Spl Ball	392-4491
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
7H-6967	Bearing-Ball	422-6489

09J		
Original Part Number	**Part Name**	**Classic Part Number**
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7N-4170	Pump Gp-Eng Oil	379-0169
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541

09J		
Original Part Number	**Part Name**	**Classic Part Number**
8B-5972	Bearing-Ball	314-8503
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
9F-3358	Link As-Cl Drive	394-0207
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311

28B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672

28B		
Original Part Number	**Part Name**	**Classic Part Number**
3H-0881	Ring-Piston	465-8998
3K-3124	Muffler-Trap	247-2673
4B-7270	Cone-Bearing	399-4439
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1220	Lifter As-Valve	387-2926
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
7L-7508	Bearing-Ball	420-6536

28B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7N-4170	Pump Gp-Eng Oil	379-0169
7N-9352	Gasket	433-8188
7W-2731	Retainer	423-3541
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
8H-9789	Bearing-Ball	374-8342
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950

29B		
Original Part Number	**Part Name**	**Classic Part Number**
2L-5271	Bearing-Ball	371-4305
2S-8884	Ring-Piston	465-8995
3H-0881	Ring-Piston	465-8998
4M-9183	Bearing-Sleeve	386-4924

29B		
Original Part Number	**Part Name**	**Classic Part Number**
4N-3875	Ring-Piston	465-8997
5F-8651	Bearing-Ball	420-3223
7H-6967	Bearing-Ball	422-6489
7M-4926	Retainer-Piston	314-8538

29B		
Original Part Number	**Part Name**	**Classic Part Number**
7N-4170	Pump Gp-Eng Oil	379-0169
7N-9352	Gasket	433-8188
8F-8523	Bearing-Sleeve	383-3701

30B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296

30B		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-8509	Cone-Roller Brg	399-4434

30B		
Original Part Number	**Part Name**	**Classic Part Number**
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
2S-8884	Ring-Piston	465-8995

Sales Model D13000 (Cont'd.)

30B		
Original Part Number	Part Name	Classic Part Number
3B-1142	Retainer-Spring	391-1099
3H-0881	Ring-Piston	465-8998
4H-7496	Plate-Pump Seal	420-6217
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5H-7071	Director-Water	388-0555

30B		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816

30B		
Original Part Number	Part Name	Classic Part Number
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
8B-5972	Bearing-Ball	314-8503
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866

Sales Model D17000

02V		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2S-4015	Plunger As-Valve	311-9438

02V		
Original Part Number	Part Name	Classic Part Number
3B-1142	Retainer-Spring	391-1099
3H-0881	Ring-Piston	465-8998
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
6B-6224	Ferrule	419-4738

02V		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
8F-8523	Bearing-Sleeve	383-3701
121-7746	Pre-Cleaner As	360-2311

03S		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099

03S		
Original Part Number	Part Name	Classic Part Number
3H-0881	Ring-Piston	465-8998
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-9371	Connector-Inlet	311-9375
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358

03S		
Original Part Number	Part Name	Classic Part Number
7B-7515	Bearing-Ball	399-6059
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8F-8523	Bearing-Sleeve	383-3701
9L-2685	Rod End	419-1866
121-7746	Pre-Cleaner As	360-2311

Sales Model D17000 (Cont'd.)

05E		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099

05E		
Original Part Number	**Part Name**	**Classic Part Number**
3H-0881	Ring-Piston	465-8998
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-9371	Connector-Inlet	311-9375
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358

05E		
Original Part Number	**Part Name**	**Classic Part Number**
7B-7515	Bearing-Ball	399-6059
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8F-8523	Bearing-Sleeve	383-3701
9L-2685	Rod End	419-1866
121-7746	Pre-Cleaner As	360-2311

08S		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099

08S		
Original Part Number	**Part Name**	**Classic Part Number**
3H-0881	Ring-Piston	465-8998
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-9371	Connector-Inlet	311-9375
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358

08S		
Original Part Number	**Part Name**	**Classic Part Number**
7B-7515	Bearing-Ball	399-6059
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8F-8523	Bearing-Sleeve	383-3701
9L-2685	Rod End	419-1866
121-7746	Pre-Cleaner As	360-2311

08V		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099

08V		
Original Part Number	**Part Name**	**Classic Part Number**
3H-0881	Ring-Piston	465-8998
4H-7496	Plate-Pump Seal	420-6217
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739

08V		
Original Part Number	**Part Name**	**Classic Part Number**
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
7S-7809	Cap As-Radiator	295-6417
8B-5972	Bearing-Ball	314-8503
8F-8523	Bearing-Sleeve	383-3701
121-7746	Pre-Cleaner As	360-2311

Sales Model D17000 (Cont'd.)

09J		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3H-0881	Ring-Piston	465-8998
4B-1455	Cap As-Filler	361-1719

09J		
Original Part Number	**Part Name**	**Classic Part Number**
4B-7270	Cone-Bearing	399-4439
4H-7496	Plate-Pump Seal	420-6217
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5L-9371	Connector-Inlet	311-9375
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739

09J		
Original Part Number	**Part Name**	**Classic Part Number**
7B-7515	Bearing-Ball	399-6059
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-8523	Bearing-Sleeve	383-3701
9L-2685	Rod End	419-1866
121-7746	Pre-Cleaner As	360-2311

Sales Model D311

04V		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2S-4015	Plunger As-Valve	311-9438
3B-6217	Muffler As	247-2671
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555

04V		
Original Part Number	**Part Name**	**Classic Part Number**
5L-9371	Connector-Inlet	311-9375
5P-9514	Bearing-Ball	417-9467
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489

04V		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
8H-4320	Bearing-Ball	419-2301
108-5603	Screw-Adj Arm	379-0166

07S		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2S-4015	Plunger As-Valve	311-9438
3B-6217	Muffler As	247-2671
4B-7255	Cone-Bearing	386-4951
4M-0410	Gear-Oil Pump Dr	428-6660

07S		
Original Part Number	**Part Name**	**Classic Part Number**
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7H-6967	Bearing-Ball	422-6489

07S		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
8H-4320	Bearing-Ball	419-2301
108-5603	Screw-Adj Arm	379-0166

Sales Model D311 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2S-4015	Plunger As-Valve	311-9438

Original Part Number	Part Name	Classic Part Number
4H-7496	Plate-Pump Seal	420-6217
5B-9169	Plug-Drain	419-4736

Original Part Number	Part Name	Classic Part Number
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
7M-7219	Bearing-Thrust	384-4816

Sales Model D311H

51B		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
3B-6217	Muffler As	247-2671
3N-3368	Pipe-Exhaust	311-9434
3S-9466	Bearing-Sleeve	314-8509
4B-7255	Cone-Bearing	386-4951
4L-8473	Plate-Wear	419-0883
4M-0410	Gear-Oil Pump Dr	428-6660
5B-9169	Plug-Drain	419-4736

51B		
Original Part Number	Part Name	Classic Part Number
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574

51B		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7E-5085	Bushing	377-5829
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
9H-2256	Pump Gp-F Prm	311-9443
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166
214-6045	Bellows As	435-4846

Sales Model D312

01N		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
2F-5721	Bearing-Ball	311-9354
2S-4015	Plunger As-Valve	311-9438

01N		
Original Part Number	Part Name	Classic Part Number
3K-3124	Muffler-Trap	247-2673
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555

01N		
Original Part Number	Part Name	Classic Part Number
6B-6224	Ferrule	419-4738
9B-1320	Valve-Check	377-5832
108-5603	Screw-Adj Arm	379-0166

Sales Model D315

04V		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-5080	Gasket Kt-V Gr	438-0180
2L-5271	Bearing-Ball	371-4305
2S-1273	Chamber As	319-3434
2S-4015	Plunger As-Valve	311-9438
2V-7198	Pilot As-Rec Spg	302-2709
3B-6218	Muffler As	247-2672

04V		
Original Part Number	Part Name	Classic Part Number
3K-3124	Muffler-Trap	247-2673
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5L-9371	Connector-Inlet	311-9375
5M-6709	Check As-Ball	380-7542
5P-9514	Bearing-Ball	417-9467
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489

04V		
Original Part Number	Part Name	Classic Part Number
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
8H-4320	Bearing-Ball	419-2301
8M-6676	Cylinder-Adj	226-4960
9B-1320	Valve-Check	377-5832
9H-7670	Piston	226-4961
9S-7534	Pipe-Exh Ext	398-2950
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

05V		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-5080	Gasket Kt-V Gr	438-0180
2S-1273	Chamber As	319-3434
2S-4015	Plunger As-Valve	311-9438

05V		
Original Part Number	Part Name	Classic Part Number
4H-7496	Plate-Pump Seal	420-6217
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358

05V		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7S-7809	Cap As-Radiator	295-6417
8H-4320	Bearing-Ball	419-2301
9B-1320	Valve-Check	377-5832
108-5603	Screw-Adj Arm	379-0166

09S		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1L-7205	Bearing-Ball	416-2167
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2H-5080	Gasket Kt-V Gr	438-0180
2L-5271	Bearing-Ball	371-4305
2S-1273	Chamber As	319-3434
2S-4015	Plunger As-Valve	311-9438
3B-6218	Muffler As	247-2672

09S		
Original Part Number	Part Name	Classic Part Number
3K-3124	Muffler-Trap	247-2673
4B-7255	Cone-Bearing	386-4951
4M-0410	Gear-Oil Pump Dr	428-6660
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5L-9371	Connector-Inlet	311-9375
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467

09S		
Original Part Number	Part Name	Classic Part Number
5S-1211	Cover-Valve	314-8665
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7S-7809	Cap As-Radiator	295-6417

Sales Model D315 (Cont'd.)

09S		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342

09S		
Original Part Number	Part Name	Classic Part Number
9B-0399	Link As-Cl Drive	431-5268
9B-1320	Valve-Check	377-5832
9S-7534	Pipe-Exh Ext	398-2950

09S		
Original Part Number	Part Name	Classic Part Number
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

Sales Model D315G

48B		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1L-7205	Bearing-Ball	416-2167
1M-7250	Bowl	360-2296
1P-7125	Governor As	383-3672
1S-1970	Chamber As	247-3292
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-6218	Muffler As	247-2672

48B		
Original Part Number	Part Name	Classic Part Number
3K-3124	Muffler-Trap	247-2673
4B-7255	Cone-Bearing	386-4951
4M-0410	Gear-Oil Pump Dr	428-6660
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-6224	Ferrule	419-4738
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067

48B		
Original Part Number	Part Name	Classic Part Number
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
8H-9789	Bearing-Ball	374-8342
9B-1320	Valve-Check	377-5832
9S-7534	Pipe-Exh Ext	398-2950
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311

52B		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1P-7125	Governor As	383-3672
1S-1970	Chamber As	247-3292
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438

52B		
Original Part Number	Part Name	Classic Part Number
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-6224	Ferrule	419-4738
6V-2202	Bearing-Spl Ball	380-1574
7M-4603	Body-Fuel Valve	311-9348

52B		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
8H-9789	Bearing-Ball	374-8342
9B-1320	Valve-Check	377-5832
108-5603	Screw-Adj Arm	379-0166

Sales Model D318

03V		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296

03V		
Original Part Number	Part Name	Classic Part Number
1S-1967	Chamber As	247-3291
2A-4429	Lock-Retainer	379-0174

03V		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354

Sales Model D318 (Cont'd.)

03V		
Original Part Number	**Part Name**	**Classic Part Number**
2L-5271	Bearing-Ball	371-4305
2S-1273	Chamber As	319-3434
2S-4015	Plunger As-Valve	311-9438
3B-6218	Muffler As	247-2672
3K-3124	Muffler-Trap	247-2673
4M-0410	Gear-Oil Pump Dr	428-6660
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555

03V		
Original Part Number	**Part Name**	**Classic Part Number**
5L-9371	Connector-Inlet	311-9375
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348

03V		
Original Part Number	**Part Name**	**Classic Part Number**
7M-7219	Bearing-Thrust	384-4816
7S-7809	Cap As-Radiator	295-6417
8H-4320	Bearing-Ball	419-2301
9B-1320	Valve-Check	377-5832
9S-7534	Pipe-Exh Ext	398-2950
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311

05V		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1L-7205	Bearing-Ball	416-2167
1M-7250	Bowl	360-2296
1P-7125	Governor As	383-3672
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-1273	Chamber As	319-3434
2S-4015	Plunger As-Valve	311-9438
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099

05V		
Original Part Number	**Part Name**	**Classic Part Number**
3B-6218	Muffler As	247-2672
3H-0881	Ring-Piston	465-8998
3K-3124	Muffler-Trap	247-2673
4M-0410	Gear-Oil Pump Dr	428-6660
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-9371	Connector-Inlet	311-9375
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489

05V		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8H-1994	Valve-Exhaust	443-1206
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9B-0399	Link As-Cl Drive	431-5268
9B-1320	Valve-Check	377-5832
9S-7534	Pipe-Exh Ext	398-2950
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311

06V		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
2A-4429	Lock-Retainer	379-0174

06V		
Original Part Number	**Part Name**	**Classic Part Number**
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2S-1273	Chamber As	319-3434
2S-4015	Plunger As-Valve	311-9438

06V		
Original Part Number	**Part Name**	**Classic Part Number**
3B-1142	Retainer-Spring	391-1099
4H-7496	Plate-Pump Seal	420-6217
4M-0410	Gear-Oil Pump Dr	428-6660

Sales Model D318 (Cont'd.)

06V		
Original Part Number	**Part Name**	**Classic Part Number**
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5S-7877	Bearing-Spl Ball	392-4491
6B-6224	Ferrule	419-4738

06V		
Original Part Number	**Part Name**	**Classic Part Number**
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
7B-7515	Bearing-Ball	399-6059
7F-2742	Bearing-Ball	422-6488
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816

06V		
Original Part Number	**Part Name**	**Classic Part Number**
7S-7809	Cap As-Radiator	295-6417
9B-1320	Valve-Check	377-5832
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311

Sales Model D318G

45B		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1L-7205	Bearing-Ball	416-2167
1M-7250	Bowl	360-2296
1P-7125	Governor As	383-3672
1S-1970	Chamber As	247-3292
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-6218	Muffler As	247-2672

45B		
Original Part Number	**Part Name**	**Classic Part Number**
3K-3124	Muffler-Trap	247-2673
4M-0410	Gear-Oil Pump Dr	428-6660
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-6224	Ferrule	419-4738
6V-2202	Bearing-Spl Ball	380-1574
7M-4603	Body-Fuel Valve	311-9348

45B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-7219	Bearing-Thrust	384-4816
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
8H-9789	Bearing-Ball	374-8342
9B-1320	Valve-Check	377-5832
9S-7534	Pipe-Exh Ext	398-2950
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311

53B		
Original Part Number	**Part Name**	**Classic Part Number**
1P-7125	Governor As	383-3672
1S-1970	Chamber As	247-3292
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
4M-0410	Gear-Oil Pump Dr	428-6660

53B		
Original Part Number	**Part Name**	**Classic Part Number**
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-6224	Ferrule	419-4738
6V-2202	Bearing-Spl Ball	380-1574

53B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
8H-9789	Bearing-Ball	374-8342
9B-1320	Valve-Check	377-5832
108-5603	Screw-Adj Arm	379-0166

Sales Model D320A

63B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2978	Spider & Brg As	399-4424
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
3N-3368	Pipe-Exhaust	311-9434
3S-9466	Bearing-Sleeve	314-8509
4B-7255	Cone-Bearing	386-4951
4L-8473	Plate-Wear	419-0883
4M-0410	Gear-Oil Pump Dr	428-6660

63B		
Original Part Number	**Part Name**	**Classic Part Number**
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574

63B		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067
7E-5085	Bushing	377-5829
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
108-5603	Screw-Adj Arm	379-0166
214-6045	Bellows As	435-4846

Sales Model D326

25B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1H-5338	Cup-Roller Brg	374-8345
1L-7205	Bearing-Ball	416-2167
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2P-1370	Cup-Rlr Brg	384-5921
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992

25B		
Original Part Number	**Part Name**	**Classic Part Number**
5B-9169	Plug-Drain	419-4736
5F-2465	Cup-Roller Brg	447-8060
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502
5S-1211	Cover-Valve	314-8665
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348

25B		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

Sales Model D326 (Cont'd.)

26B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992

26B		
Original Part Number	**Part Name**	**Classic Part Number**
4H-7496	Plate-Pump Seal	420-6217
5B-9169	Plug-Drain	419-4736
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502
5S-1211	Cover-Valve	314-8665
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
7B-7515	Bearing-Ball	399-6059
7F-2742	Bearing-Ball	422-6488
7H-6967	Bearing-Ball	422-6489

26B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

27B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992

27B		
Original Part Number	**Part Name**	**Classic Part Number**
4M-5226	Bearing-Ball	399-6061
5B-9169	Plug-Drain	419-4736
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502
5S-1211	Cover-Valve	314-8665
6B-6224	Ferrule	419-4738
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582

27B		
Original Part Number	**Part Name**	**Classic Part Number**
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

Sales Model D326F

39B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1L-7205	Bearing-Ball	416-2167
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099

39B		
Original Part Number	**Part Name**	**Classic Part Number**
3F-3049	Cone-Roller Brg	418-9600
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
4B-7270	Cone-Bearing	399-4439
4M-9215	Gear-Pump Idler	311-9391
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555

39B		
Original Part Number	**Part Name**	**Classic Part Number**
5L-9371	Connector-Inlet	311-9375
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg&	333-4954
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7L-2041	Shaft-Water Pump	428-7200

Sales Model D326F (Cont'd.)

39B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4603	Body-Fuel Valve	311-9348
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7N-7639	Rotator-Valve	383-1582
7T-2036	Cap As-Fuel	361-1721

39B		
Original Part Number	**Part Name**	**Classic Part Number**
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301

39B		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
124-3237	Precleaner As	432-4220

40B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992

40B		
Original Part Number	**Part Name**	**Classic Part Number**
4H-7496	Plate-Pump Seal	420-6217
4M-9215	Gear-Pump Idler	311-9391
5B-9169	Plug-Drain	419-4736
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
6B-6224	Ferrule	419-4738
7L-2041	Shaft-Water Pump	428-7200
7M-4603	Body-Fuel Valve	311-9348

40B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7N-7639	Rotator-Valve	383-1582
7T-2036	Cap As-Fuel	361-1721
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9M-5350	Spring-Valve	380-7573

Sales Model D330A

06A		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1M-0090	Gasket-Manifold	445-7701
1M-5270	Pipe-Extension	367-6065
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-7125	Governor As	383-3672
1T-0699	Impeller-Conv	235-1808
1T-1993	Wheel-Turbine	235-0920
1T-2069	Carrier-Bearing	439-4543
1W-7074	Kit-Rebuild-Pump	419-4712

06A		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2L-4238	Mount-Flexible	385-7222
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934
3F-3049	Cone-Roller Brg	418-9600

06A		
Original Part Number	**Part Name**	**Classic Part Number**
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3S-5017	Elbow-Exhaust	369-9498
3S-9466	Bearing-Sleeve	314-8509
4L-8473	Plate-Wear	419-0883
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5M-2824	Coupling-Exhaust	431-5270

Sales Model D330A (Cont'd.)

06A		
Original Part Number	**Part Name**	**Classic Part Number**
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4358	Manifold-Exhaust	261-0907
7M-4603	Body-Fuel Valve	311-9348

06A		
Original Part Number	**Part Name**	**Classic Part Number**
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

06A		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-2685	Rod End	419-1866
9M-4955	Pump Gp-F Tfr	242-3443
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166
232-3233	Bearing-Main	376-9085

56B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1M-0090	Gasket-Manifold	445-7701
1M-5270	Pipe-Extension	367-6065
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-7125	Governor As	383-3672
1T-0699	Impeller-Conv	235-1808
1T-1993	Wheel-Turbine	235-0920
1T-2069	Carrier-Bearing	439-4543
1W-7074	Kit-Rebuild-Pump	419-4712
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236

56B		
Original Part Number	**Part Name**	**Classic Part Number**
2L-4238	Mount-Flexible	385-7222
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934
3F-3049	Cone-Roller Brg	418-9600
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3S-5017	Elbow-Exhaust	369-9498
3S-9466	Bearing-Sleeve	314-8509
4L-8473	Plate-Wear	419-0883
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555

56B		
Original Part Number	**Part Name**	**Classic Part Number**
5L-8856	Coupling-Exhaust	311-9379
5M-2824	Coupling-Exhaust	431-5270
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4358	Manifold-Exhaust	261-0907

Sales Model D330A (Cont'd.)

56B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486

56B		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084

56B		
Original Part Number	**Part Name**	**Classic Part Number**
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-2685	Rod End	419-1866
9M-4955	Pump Gp-F Tfr	242-3443
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166
232-3233	Bearing-Main	376-9085

57B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1M-0090	Gasket-Manifold	445-7701
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
3S-9466	Bearing-Sleeve	314-8509
4L-8473	Plate-Wear	419-0883
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555

57B		
Original Part Number	**Part Name**	**Classic Part Number**
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-9080	Pulley-Alt Drive	264-5883
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494

57B		
Original Part Number	**Part Name**	**Classic Part Number**
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166
232-3233	Bearing-Main	376-9085

Sales Model D330A (Cont'd.)

85B		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1M-0090	Gasket-Manifold	445-7701
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
3F-3049	Cone-Roller Brg	418-9600
3N-3368	Pipe-Exhaust	311-9434
3S-5017	Elbow-Exhaust	369-9498
3S-9466	Bearing-Sleeve	314-8509
4L-8473	Plate-Wear	419-0883
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555

85B		
Original Part Number	Part Name	Classic Part Number
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-4358	Manifold-Exhaust	261-0907
7M-4603	Body-Fuel Valve	311-9348

85B		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085

86B		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1M-0090	Gasket-Manifold	445-7701
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2M-4208	Spacer-Timing	417-4533

86B		
Original Part Number	Part Name	Classic Part Number
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
3D-9126	Cup-Roller Brg	399-4435
3N-3368	Pipe-Exhaust	311-9434
3S-9466	Bearing-Sleeve	314-8509
4L-8473	Plate-Wear	419-0883
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379

86B		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-9080	Pulley-Alt Drive	264-5883
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829

Sales Model D330A (Cont'd.)

86B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494

86B		
Original Part Number	**Part Name**	**Classic Part Number**
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084

86B		
Original Part Number	**Part Name**	**Classic Part Number**
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085

Sales Model D330B

81B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1M-0090	Gasket-Manifold	445-7701
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-7125	Governor As	383-3672
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
3F-3049	Cone-Roller Brg	418-9600
3N-3368	Pipe-Exhaust	311-9434
3S-9466	Bearing-Sleeve	314-8509
4L-8473	Plate-Wear	419-0883
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854

81B		
Original Part Number	**Part Name**	**Classic Part Number**
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-4358	Manifold-Exhaust	261-0907
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7N-9805	Pin-Piston	295-6438
7T-2036	Cap As-Fuel	361-1721

81B		
Original Part Number	**Part Name**	**Classic Part Number**
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-2685	Rod End	419-1866
9M-4955	Pump Gp-F Tfr	242-3443
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085

Sales Model D330B (Cont'd.)

82B		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1M-0090	Gasket-Manifold	445-7701
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
3D-9126	Cup-Roller Brg	399-4435
3N-3368	Pipe-Exhaust	311-9434
3S-9466	Bearing-Sleeve	314-8509
4L-8473	Plate-Wear	419-0883
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222

82B		
Original Part Number	Part Name	Classic Part Number
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-9080	Pulley-Alt Drive	264-5883
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7N-9805	Pin-Piston	295-6438
7W-1927	Ring-Retainer	387-2935

82B		
Original Part Number	Part Name	Classic Part Number
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085

98B		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1M-0090	Gasket-Manifold	445-7701
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532

98B		
Original Part Number	Part Name	Classic Part Number
2S-4015	Plunger As-Valve	311-9438
3F-3049	Cone-Roller Brg	418-9600
3N-3368	Pipe-Exhaust	311-9434
3S-9466	Bearing-Sleeve	314-8509
4L-8473	Plate-Wear	419-0883
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467

98B		
Original Part Number	Part Name	Classic Part Number
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7L-7508	Bearing-Ball	420-6536

Sales Model D330B (Cont'd.)

98B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494

98B		
Original Part Number	**Part Name**	**Classic Part Number**
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084

98B		
Original Part Number	**Part Name**	**Classic Part Number**
9H-2256	Pump Gp-F Prm	311-9443
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085

99B		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
3D-9126	Cup-Roller Brg	399-4435
3N-3368	Pipe-Exhaust	311-9434
3S-9466	Bearing-Sleeve	314-8509
4L-8473	Plate-Wear	419-0883
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555

99B		
Original Part Number	**Part Name**	**Classic Part Number**
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-9080	Pulley-Alt Drive	264-5883
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348

99B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
9H-2256	Pump Gp-F Prm	311-9443
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085

Sales Model D330C

02B		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158

Sales Model D330C (Cont'd.)

02B		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1U-2668	Cartridge Gp	422-8117
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-6810	Pipe-Outlet	472-8036
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892

02B		
Original Part Number	**Part Name**	**Classic Part Number**
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3B-8845	Bearing-Inner	417-4509
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-4878	Pump Gp-F Tfr	390-0995
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572

02B		
Original Part Number	**Part Name**	**Classic Part Number**
4N-9944	Line As-Fuel Inj	380-1565
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-7188	Core As-Oclr	374-7501
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991

Sales Model D330C (Cont'd.)

02B		
Original Part Number	**Part Name**	**Classic Part Number**
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6V-0600	Gasket Kit	437-4583
6V-0611	Kit-Gasket-Fs	437-4581
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6V-2246	Gasket Kit	391-1091
6V-2523	Gasket Kit	437-3209
6V-2983	Gasket Kt	437-3213
6Y-7652	Cup-Rlr Brg	399-6067
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-7435	Kit-Major Repair	374-4724
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995

02B		
Original Part Number	**Part Name**	**Classic Part Number**
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7043	Mount As	389-6332
7S-7070	Head As-Cylinder	325-6107
7S-8443	Muffler	247-2675
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5687	Hub-Cshft	314-8684
7W-5692	Pulley-Cshaft	386-3041
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623

02B		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561

Sales Model D330C (Cont'd.)

02B		
Original Part Number	**Part Name**	**Classic Part Number**
9S-9328	Muffler	395-1308
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351

02B		
Original Part Number	**Part Name**	**Classic Part Number**
167-8123	Damper As	299-2006
169-1750	Seal Gp-Basic	472-8022
170-0556	Kit-Rebuild-Pump	383-3712
170-0558	Kit-Rebuild-Pump	390-1001
170-0560	Rebuild Kit-Pump	363-7458
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698

02B		
Original Part Number	**Part Name**	**Classic Part Number**
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

04B		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981

04B		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-6810	Pipe-Outlet	472-8036
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

04B		
Original Part Number	**Part Name**	**Classic Part Number**
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2S-4015	Plunger As-Valve	311-9438
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983

Sales Model D330C (Cont'd.)

04B		
Original Part Number	**Part Name**	**Classic Part Number**
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-5869	Support-Elbow	375-9973
3S-5017	Elbow-Exhaust	369-9498
3S-9466	Bearing-Sleeve	314-8509
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4M-9215	Gear-Pump Idler	311-9391
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-4864	Pump Gp-F Tfr	242-3442
4N-4878	Pump Gp-F Tfr	390-0995
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572

04B		
Original Part Number	**Part Name**	**Classic Part Number**
4N-9944	Line As-Fuel Inj	380-1565
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-7188	Core As-Oclr	374-7501
4W-9989	Gear As-Idler	302-2677
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015

04B		
Original Part Number	**Part Name**	**Classic Part Number**
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6V-0600	Gasket Kit	437-4583
6V-0611	Kit-Gasket-Fs	437-4581
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6V-2246	Gasket Kit	391-1091
6V-2523	Gasket Kit	437-3209
6V-2983	Gasket Kt	437-3213
6Y-7652	Cup-Rlr Brg	399-6067
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985

Sales Model D330C (Cont'd.)

04B		
Original Part Number	Part Name	Classic Part Number
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8M-0874	Plunger As-Valve	311-9439
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464

04B		
Original Part Number	Part Name	Classic Part Number
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-3668	Base As.-Coolant	419-4718
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-9328	Muffler	395-1308
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032

04B		
Original Part Number	Part Name	Classic Part Number
100-7860	Valve-Inlet	270-4360
106-8711	Elbow-Exhaust	383-3709
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
169-1750	Seal Gp-Basic	472-8022
170-0556	Kit-Rebuild-Pump	383-3712
170-0558	Kit-Rebuild-Pump	390-1001
170-0560	Rebuild Kit-Pump	363-7458
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646

Sales Model D330C (Cont'd.)

04B		
Original Part Number	**Part Name**	**Classic Part Number**
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
214-6045	Bellows As	435-4846

04B		
Original Part Number	**Part Name**	**Classic Part Number**
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438

04B		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

05B		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-6810	Pipe-Outlet	472-8036
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850

05B		
Original Part Number	**Part Name**	**Classic Part Number**
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7678	Gear-Water Pump	325-6088
3D-9126	Cup-Roller Brg	399-4435
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
4L-8473	Plate-Wear	419-0883
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4878	Pump Gp-F Tfr	390-0995
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572

05B		
Original Part Number	**Part Name**	**Classic Part Number**
4N-9944	Line As-Fuel Inj	380-1565
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475

Sales Model D330C (Cont'd.)

05B		
Original Part Number	Part Name	Classic Part Number
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6V-0611	Kit-Gasket-Fs	437-4581
6V-2202	Bearing-Spl Ball	380-1574
6V-2246	Gasket Kit	391-1091
6V-2523	Gasket Kit	437-3209
6V-2983	Gasket Kt	437-3213
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7L-7508	Bearing-Ball	420-6536
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935

05B		
Original Part Number	Part Name	Classic Part Number
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831

05B		
Original Part Number	Part Name	Classic Part Number
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-3668	Base As.-Coolant	419-4718
9N-5251	Piston Gp-Bsc	250-6557
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
169-1750	Seal Gp-Basic	472-8022
170-0556	Kit-Rebuild-Pump	383-3712
170-0560	Rebuild Kit-Pump	363-7458
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

Sales Model D330C (Cont'd.)

05B		
Original Part Number	**Part Name**	**Classic Part Number**
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259

05B		
Original Part Number	**Part Name**	**Classic Part Number**
196-0029	Gear As-Idler	374-4674
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438

05B		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

Sales Model D333A

58B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1M-0090	Gasket-Manifold	445-7701
1M-7250	Bowl	360-2296
1P-1367	Plunger-Valve	432-8913
1P-7125	Governor As	383-3672
1T-0699	Impeller-Conv	235-1808
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934
2S-6150	Cover-Pulley	428-8817
3B-6218	Muffler As	247-2672
3F-3049	Cone-Roller Brg	418-9600
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3S-5017	Elbow-Exhaust	369-9498
3S-9466	Bearing-Sleeve	314-8509
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883

58B		
Original Part Number	**Part Name**	**Classic Part Number**
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816

58B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-7358	Valve-Inlet	298-2774
7N-0128	Core As-Oil Clr	299-1994
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891

Sales Model D333A (Cont'd.)

58B		
Original Part Number	**Part Name**	**Classic Part Number**
9M-4789	Shaft-Gov Cont	297-7256
9M-4955	Pump Gp-F Tfr	242-3443
9M-5477	Bearing-Sleeve	374-6517

58B		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7534	Pipe-Exh Ext	398-2950
108-5603	Screw-Adj Arm	379-0166

58B		
Original Part Number	**Part Name**	**Classic Part Number**
121-7746	Pre-Cleaner As	360-2311
169-4200	Gasket	472-8023
232-3233	Bearing-Main	376-9085

59B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1M-0090	Gasket-Manifold	445-7701
1P-1367	Plunger-Valve	432-8913
1T-0441	Bearing-Ball	449-4738
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
3B-8845	Bearing-Inner	417-4509
3S-9466	Bearing-Sleeve	314-8509
4L-8473	Plate-Wear	419-0883
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555

59B		
Original Part Number	**Part Name**	**Classic Part Number**
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-9080	Pulley-Alt Drive	264-5883
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7N-9805	Pin-Piston	295-6438
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494

59B		
Original Part Number	**Part Name**	**Classic Part Number**
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166
169-4200	Gasket	472-8023
232-3233	Bearing-Main	376-9085

87B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1M-0090	Gasket-Manifold	445-7701
1P-1367	Plunger-Valve	432-8913
1P-7125	Governor As	383-3672
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

87B		
Original Part Number	**Part Name**	**Classic Part Number**
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
3F-3049	Cone-Roller Brg	418-9600

87B		
Original Part Number	**Part Name**	**Classic Part Number**
3N-3368	Pipe-Exhaust	311-9434
3S-9466	Bearing-Sleeve	314-8509
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555

Sales Model D333A (Cont'd.)

87B		
Original Part Number	**Part Name**	**Classic Part Number**
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381

87B		
Original Part Number	**Part Name**	**Classic Part Number**
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342

87B		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166
169-4200	Gasket	472-8023
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085

88B		
Original Part Number	**Part Name**	**Classic Part Number**
1M-0090	Gasket-Manifold	445-7701
1P-1367	Plunger-Valve	432-8913
1T-0441	Bearing-Ball	449-4738
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
3B-8845	Bearing-Inner	417-4509
3N-3368	Pipe-Exhaust	311-9434
3S-9466	Bearing-Sleeve	314-8509
4L-8473	Plate-Wear	419-0883
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555

88B		
Original Part Number	**Part Name**	**Classic Part Number**
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-9080	Pulley-Alt Drive	264-5883
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829

88B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891

Sales Model D333A (Cont'd.)

88B		
Original Part Number	**Part Name**	**Classic Part Number**
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166

88B		
Original Part Number	**Part Name**	**Classic Part Number**
169-4200	Gasket	472-8023
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085

Sales Model D333B

79B		
Original Part Number	**Part Name**	**Classic Part Number**
1M-0090	Gasket-Manifold	445-7701
1P-1367	Plunger-Valve	432-8913
1P-7125	Governor As	383-3672
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934
3N-3368	Pipe-Exhaust	311-9434
3S-5017	Elbow-Exhaust	369-9498
3S-9466	Bearing-Sleeve	314-8509
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379

79B		
Original Part Number	**Part Name**	**Classic Part Number**
5M-7925	Bearing-Roller	419-7774
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7N-9805	Pin-Piston	295-6438
7T-2036	Cap As-Fuel	361-1721

79B		
Original Part Number	**Part Name**	**Classic Part Number**
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166
169-4200	Gasket	472-8023
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085

80B		
Original Part Number	**Part Name**	**Classic Part Number**
1M-0090	Gasket-Manifold	445-7701

Sales Model D333B (Cont'd.)

80B		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
3B-8845	Bearing-Inner	417-4509
3N-3368	Pipe-Exhaust	311-9434
3S-9466	Bearing-Sleeve	314-8509
4L-8473	Plate-Wear	419-0883
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379

80B		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-9080	Pulley-Alt Drive	264-5883
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7N-9805	Pin-Piston	295-6438
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494

80B		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166
169-4200	Gasket	472-8023
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085

Sales Model D334

92B		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357

92B		
Original Part Number	Part Name	Classic Part Number
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555

92B		
Original Part Number	Part Name	Classic Part Number
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6L-2279	Plug-Ptf	419-4739

Sales Model D334 (Cont'd.)

92B		
Original Part Number	**Part Name**	**Classic Part Number**
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-9805	Pin-Piston	295-6438
7S-4411	Cap As-Rain	373-1912
7T-2036	Cap As-Fuel	361-1721

92B		
Original Part Number	**Part Name**	**Classic Part Number**
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-0703	Bearing-Sleeve	472-8037
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377

92B		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
9H-2256	Pump Gp-F Prm	311-9443
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
131-3815	Seal Gp-Basic	325-6193
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085

93B		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
3B-8845	Bearing-Inner	417-4509
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
4L-8473	Plate-Wear	419-0883
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-6326	Bearing-Ball	420-3222

93B		
Original Part Number	**Part Name**	**Classic Part Number**
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-9805	Pin-Piston	295-6438
7S-4411	Cap As-Rain	373-1912
7W-1927	Ring-Retainer	387-2935

93B		
Original Part Number	**Part Name**	**Classic Part Number**
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8L-4282	Hub	444-0573
8N-0703	Bearing-Sleeve	472-8037
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
9H-2256	Pump Gp-F Prm	311-9443
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
131-3815	Seal Gp-Basic	325-6193
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085

Sales Model D336

02A		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3S-9466	Bearing-Sleeve	314-8509
5L-7520	Elbow-Exhaust	419-4711

02A		
Original Part Number	**Part Name**	**Classic Part Number**
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5M-2054	Bearing	380-7510
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574

02A		
Original Part Number	**Part Name**	**Classic Part Number**
7E-5085	Bushing	377-5829
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
214-6045	Bellows As	435-4846

54B		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3S-9466	Bearing-Sleeve	314-8509
5L-7520	Elbow-Exhaust	419-4711

54B		
Original Part Number	**Part Name**	**Classic Part Number**
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5M-2054	Bearing	380-7510
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574

54B		
Original Part Number	**Part Name**	**Classic Part Number**
7E-5085	Bushing	377-5829
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
214-6045	Bellows As	435-4846

55B		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354

55B		
Original Part Number	**Part Name**	**Classic Part Number**
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434

55B		
Original Part Number	**Part Name**	**Classic Part Number**
3N-4892	Lever-Gov Cont	439-4542
3S-9466	Bearing-Sleeve	314-8509
4L-8473	Plate-Wear	419-0883
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223

Sales Model D336 (Cont'd.)

55B		
Original Part Number	**Part Name**	**Classic Part Number**
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5M-2054	Bearing	380-7510
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6L-2279	Plug-Ptf	419-4739

55B		
Original Part Number	**Part Name**	**Classic Part Number**
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7S-4411	Cap As-Rain	373-1912

55B		
Original Part Number	**Part Name**	**Classic Part Number**
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
214-6045	Bellows As	435-4846

60B		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
3B-8845	Bearing-Inner	417-4509
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3S-9466	Bearing-Sleeve	314-8509
4B-7255	Cone-Bearing	386-4951
4L-8473	Plate-Wear	419-0883

60B		
Original Part Number	**Part Name**	**Classic Part Number**
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-5772	Race & Roller As	394-9200
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951

60B		
Original Part Number	**Part Name**	**Classic Part Number**
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7E-5085	Bushing	377-5829
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7S-4411	Cap As-Rain	373-1912
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8M-0874	Plunger As-Valve	311-9439
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
214-6045	Bellows As	435-4846

Sales Model D333C

09A		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167

09A		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158

09A		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978

Sales Model D333C (Cont'd.)

09A		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3062	Retainer As	311-9445
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-8606	Valve-Inlet	443-1204
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

09A		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-3767	Tube-Disposal	377-5850
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7830	Pump Gp	314-8533
2S-4015	Plunger As-Valve	311-9438
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-5869	Support-Elbow	375-9973

09A		
Original Part Number	**Part Name**	**Classic Part Number**
3S-5017	Elbow-Exhaust	369-9498
3S-9466	Bearing-Sleeve	314-8509
4B-7270	Cone-Bearing	399-4439
4D-2619	Bearing	417-4494
4L-8473	Plate-Wear	419-0883
4M-9215	Gear-Pump Idler	311-9391
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2572	Spider As-Fan	451-9027
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4577	Muffler As.	308-9877
4N-4679	Pulley-Fan	394-9837
4N-4864	Pump Gp-F Tfr	242-3442
4N-4878	Pump Gp-F Tfr	390-0995
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4N-9213	Elbow-Exhaust	330-9270
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572
4N-9944	Line As-Fuel Inj	380-1565
4P-3546	Valve As-Relief	325-6236

Sales Model D333C (Cont'd.)

09A		
Original Part Number	Part Name	Classic Part Number
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9989	Gear As-Idler	302-2677
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024

09A		
Original Part Number	Part Name	Classic Part Number
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5P-9561	Gasket Kt-V G	437-8106
5P-9568	Gasket Kit	393-3625
5S-1757	Insert-Seat	311-9401
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-0714	Pulley-Alt	264-5884
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386

09A		
Original Part Number	Part Name	Classic Part Number
6V-0611	Kit-Gasket-Fs	437-4581
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
6V-2529	Gasket Kit	437-3208
6V-2983	Gasket Kt	437-3213
6V-5976	Kit-Gasket (Rs)	393-5200
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7K-2135	Bearing-Roller	417-4492
7L-7508	Bearing-Ball	420-6536
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5511	Gear As-Idler	233-2180
7N-5645	Tube As-Outlet	378-3984
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759

Sales Model D333C (Cont'd.)

09A		
Original Part Number	Part Name	Classic Part Number
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7639	Rotator-Valve	383-1582
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-4411	Cap As-Rain	373-1912
7S-8443	Muffler	247-2675
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5687	Hub-Cshft	314-8684
7W-5692	Pulley-Cshaft	386-3041
7W-5696	Hub-Cshft	424-5887
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-0983	Mounting	384-3470
8D-9973	Housing	391-9825
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212

09A		
Original Part Number	Part Name	Classic Part Number
8L-8867	Pulley	434-1409
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

09A		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8T-2466	Gasket Kit	393-5199
8W-3589	Link As-Spring	380-7389
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9N-3668	Base As.-Coolant	419-4718
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888

Sales Model D333C (Cont'd.)

09A		
Original Part Number	**Part Name**	**Classic Part Number**
9S-2355	Manifold-Exhaust	261-0891
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-7148	Cap As-Rain	378-3994
9S-7534	Pipe-Exh Ext	398-2950
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
102-1561	Lifter As-Valve	311-9402
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351

09A		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
170-0558	Kit-Rebuild-Pump	390-1001
170-0560	Rebuild Kit-Pump	363-7458
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698

09A		
Original Part Number	**Part Name**	**Classic Part Number**
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7772	Pump Gp-Water -B	438-2009
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
255-6863	Gasket	450-5024
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

23C		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1N-3165	Plunger-Rlf V	373-1883
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434

23C		
Original Part Number	**Part Name**	**Classic Part Number**
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340

23C		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-6810	Pipe-Outlet	472-8036
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

Sales Model D333C (Cont'd.)

23C		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2W-1225	Pump Gp-Water	380-7532
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8271	Arm As-Rocker	432-8912
3L-1425	Bearing-Ball	311-9356
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
4D-2619	Bearing	417-4494
4L-8473	Plate-Wear	419-0883
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716

23C		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2954	Sleeve-Camshaft	299-2059
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4679	Pulley-Fan	394-9837
4N-4864	Pump Gp-F Tfr	242-3442
4N-4878	Pump Gp-F Tfr	390-0995
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572
4N-9944	Line As-Fuel Inj	380-1565
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-7188	Core As-Oclr	374-7501
4W-9989	Gear As-Idler	302-2677
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-5553	Screw-Tappet Adj	311-9451
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5P-9568	Gasket Kit	393-3625
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

23C		
Original Part Number	**Part Name**	**Classic Part Number**
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6N-8992	Adapter-Fan	394-9810
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
6V-2580	Gasket Kt-V G	393-3637
6V-2983	Gasket Kt	437-3213
6V-4785	Gasket Kit - Fs	388-0661
6V-6894	Rebuild Kt-Pump	383-3696
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-4728	Rod As-Conn	379-8863
7E-5085	Bushing	377-5829
7E-7894	Bearing-Rod	419-7260
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206

Sales Model D333C (Cont'd.)

23C		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7W-2731	Retainer	423-3541
7W-5687	Hub-Cshft	314-8684
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8M-0874	Plunger As-Valve	311-9439

23C		
Original Part Number	Part Name	Classic Part Number
8N-0081	Trunnion	393-5196
8N-0701	Bearing-Sleeve	419-4745
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

23C		
Original Part Number	Part Name	Classic Part Number
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-7682	Valve-Inlet	385-9266
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-3668	Base As.-Coolant	419-4718
9N-5246	Bearing-Camshaft	384-4772
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939

Sales Model D333C (Cont'd.)

23C		
Original Part Number	Part Name	Classic Part Number
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
119-6772	Valve-Exhaust	384-8699
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
167-8123	Damper As	299-2006
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
170-0558	Kit-Rebuild-Pump	390-1001

23C		
Original Part Number	Part Name	Classic Part Number
170-0560	Rebuild Kit-Pump	363-7458
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646

23C		
Original Part Number	Part Name	Classic Part Number
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

62M		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1S-3062	Director-Water	418-9572
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2W-2621	Valve-Inlet	247-6892
4N-4878	Pump Gp-F Tfr	390-0995
4N-7693	Crankshaft As	269-8763
5L-7632	Support-Elbow	433-9854
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247

62M		
Original Part Number	Part Name	Classic Part Number
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6I-1345	Shaft As-O Pump	374-7475
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-2820	Pump Gp-Eng Oil	415-1903
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7L-7508	Bearing-Ball	420-6536
7M-4046	Bearing-Sleeve	394-8206

62M		
Original Part Number	Part Name	Classic Part Number
7N-8018	Seal-Water	418-1964
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

Sales Model D333C (Cont'd.)

62M		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831

62M		
Original Part Number	**Part Name**	**Classic Part Number**
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9H-5797	Plunger As-Pump	391-9891
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165

62M		
Original Part Number	**Part Name**	**Classic Part Number**
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
250-6557	Liner Kit-Cla	295-6438

62U		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4878	Pump Gp-F Tfr	390-0995
4N-7693	Crankshaft As	269-8763
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572

62U		
Original Part Number	**Part Name**	**Classic Part Number**
4N-9944	Line As-Fuel Inj	380-1565
4W-0452	Seal As -Cshaft	325-6191
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-7630	Bearing-Sleeve	394-0219
6H-3957	Bearing-Ball	311-9358
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7263	Gasket-Cyl Head	380-7386
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-1927	Ring-Retainer	387-2935

62U		
Original Part Number	**Part Name**	**Classic Part Number**
7W-7546	Gasket-Plate	433-8187
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084

Sales Model D333C (Cont'd.)

62U		
Original Part Number	**Part Name**	**Classic Part Number**
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891

62U		
Original Part Number	**Part Name**	**Classic Part Number**
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9S-7788	Ring-Piston	461-5124
9Y-1798	Seal-Water	379-0165
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193

62U		
Original Part Number	**Part Name**	**Classic Part Number**
167-8123	Damper As	299-2006
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
250-6557	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

66D		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3062	Retainer As	311-9445
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036

66D		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6987	Valve As-Check	420-6221
1W-8606	Valve-Inlet	443-1204
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-3767	Tube-Disposal	377-5850
2P-4698	Bearing-Sleeve	389-6318

66D		
Original Part Number	**Part Name**	**Classic Part Number**
2P-4701	Shaft As-Gear	297-7257
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7830	Pump Gp	314-8533
2S-4015	Plunger As-Valve	311-9438
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542

Sales Model D333C (Cont'd.)

66D		
Original Part Number	Part Name	Classic Part Number
3N-5869	Support-Elbow	375-9973
3S-5017	Elbow-Exhaust	369-9498
3S-9466	Bearing-Sleeve	314-8509
4B-7270	Cone-Bearing	399-4439
4D-2619	Bearing	417-4494
4L-8473	Plate-Wear	419-0883
4M-9215	Gear-Pump Idler	311-9391
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2572	Spider As-Fan	451-9027
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4577	Muffler As.	308-9877
4N-4679	Pulley-Fan	394-9837
4N-4864	Pump Gp-F Tfr	242-3442
4N-4878	Pump Gp-F Tfr	390-0995
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4N-9213	Elbow-Exhaust	330-9270
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572
4N-9944	Line As-Fuel Inj	380-1565

66D		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9989	Gear As-Idler	302-2677
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024

66D		
Original Part Number	Part Name	Classic Part Number
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5P-9561	Gasket Kt-V G	437-8106
5P-9568	Gasket Kit	393-3625
5S-1757	Insert-Seat	311-9401
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-0714	Pulley-Alt	264-5884
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386

Sales Model D333C (Cont'd.)

66D		
Original Part Number	Part Name	Classic Part Number
6V-0611	Kit-Gasket-Fs	437-4581
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
6V-2529	Gasket Kit	437-3208
6V-2983	Gasket Kt	437-3213
6V-5976	Kit-Gasket (Rs)	393-5200
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7K-2135	Bearing-Roller	417-4492
7L-7508	Bearing-Ball	420-6536
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5511	Gear As-Idler	233-2180
7N-5645	Tube As-Outlet	378-3984
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759

66D		
Original Part Number	Part Name	Classic Part Number
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7639	Rotator-Valve	383-1582
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-4411	Cap As-Rain	373-1912
7S-8443	Muffler	247-2675
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5687	Hub-Cshft	314-8684
7W-5692	Pulley-Cshaft	386-3041
7W-5696	Hub-Cshft	424-5887
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-0983	Mounting	384-3470
8D-9973	Housing	391-9825
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212

66D		
Original Part Number	Part Name	Classic Part Number
8L-8867	Pulley	434-1409
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

Sales Model D333C (Cont'd.)

66D		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8T-2466	Gasket Kit	393-5199
8W-3589	Link As-Spring	380-7389
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9N-3668	Base As.-Coolant	419-4718
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888

66D		
Original Part Number	Part Name	Classic Part Number
9S-2355	Manifold-Exhaust	261-0891
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-7148	Cap As-Rain	378-3994
9S-7534	Pipe-Exh Ext	398-2950
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
102-1561	Lifter As-Valve	311-9402
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
170-0558	Kit-Rebuild-Pump	390-1001

66D		
Original Part Number	Part Name	Classic Part Number
170-0560	Rebuild Kit-Pump	363-7458
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7772	Pump Gp-Water -B	438-2009
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
255-6863	Gasket	450-5024
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356

Sales Model D333C (Cont'd.)

66D		
Original Part Number	Part Name	Classic Part Number
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349

66D		
Original Part Number	Part Name	Classic Part Number
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

66D		
Original Part Number	Part Name	Classic Part Number
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

67D		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-6810	Pipe-Outlet	472-8036
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438

67D		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3B-8845	Bearing-Inner	417-4509
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
4L-8473	Plate-Wear	419-0883
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4878	Pump Gp-F Tfr	390-0995
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572
4N-9944	Line As-Fuel Inj	380-1565
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191

67D		
Original Part Number	Part Name	Classic Part Number
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5P-9568	Gasket Kit	393-3625
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-2820	Pump Gp-Eng Oil	415-1903

Sales Model D333C (Cont'd.)

67D		
Original Part Number	Part Name	Classic Part Number
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-0611	Kit-Gasket-Fs	437-4581
6V-2202	Bearing-Spl Ball	380-1574
6V-2529	Gasket Kit	437-3208
6V-2983	Gasket Kt	437-3213
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7L-7508	Bearing-Ball	420-6536
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7S-7070	Head As-Cylinder	325-6107
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342

67D		
Original Part Number	Part Name	Classic Part Number
8L-4282	Hub	444-0573
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832

67D		
Original Part Number	Part Name	Classic Part Number
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-5908	Gasket	433-8196
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-3668	Base As.-Coolant	419-4718
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
167-8123	Damper As	299-2006
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
170-0560	Rebuild Kit-Pump	363-7458
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7776	Pump Gp-Water -B	395-1314

Sales Model D333C (Cont'd.)

67D		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
214-6045	Bellows As	435-4846

67D		
Original Part Number	Part Name	Classic Part Number
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438

67D		
Original Part Number	Part Name	Classic Part Number
255-6863	Gasket	450-5024
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

70R		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3062	Retainer As	311-9445
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-8606	Valve-Inlet	443-1204
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513

70R		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-3767	Tube-Disposal	377-5850
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7830	Pump Gp	314-8533
2S-4015	Plunger As-Valve	311-9438
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356

70R		
Original Part Number	Part Name	Classic Part Number
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-5869	Support-Elbow	375-9973
3S-5017	Elbow-Exhaust	369-9498
3S-9466	Bearing-Sleeve	314-8509
4B-7270	Cone-Bearing	399-4439
4D-2619	Bearing	417-4494
4L-8473	Plate-Wear	419-0883
4M-9215	Gear-Pump Idler	311-9391
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2572	Spider As-Fan	451-9027

Sales Model D333C (Cont'd.)

70R		
Original Part Number	Part Name	Classic Part Number
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4577	Muffler As.	308-9877
4N-4679	Pulley-Fan	394-9837
4N-4864	Pump Gp-F Tfr	242-3442
4N-4878	Pump Gp-F Tfr	390-0995
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4N-9213	Elbow-Exhaust	330-9270
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572
4N-9944	Line As-Fuel Inj	380-1565
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

70R		
Original Part Number	Part Name	Classic Part Number
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-2541	Shaft-Gov Cont	399-8580
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9989	Gear As-Idler	302-2677
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5P-9561	Gasket Kt-V G	437-8106
5P-9568	Gasket Kit	393-3625
5S-1757	Insert-Seat	311-9401
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635

70R		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-0714	Pulley-Alt	264-5884
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-0611	Kit-Gasket-Fs	437-4581
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
6V-2529	Gasket Kit	437-3208
6V-2983	Gasket Kt	437-3213
6V-5976	Kit-Gasket (Rs)	393-5200
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488

Sales Model D333C (Cont'd.)

70R		
Original Part Number	Part Name	Classic Part Number
7K-2135	Bearing-Roller	417-4492
7L-7508	Bearing-Ball	420-6536
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5511	Gear As-Idler	233-2180
7N-5645	Tube As-Outlet	378-3984
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7639	Rotator-Valve	383-1582
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996

70R		
Original Part Number	Part Name	Classic Part Number
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-4411	Cap As-Rain	373-1912
7S-8443	Muffler	247-2675
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5687	Hub-Cshft	314-8684
7W-5692	Pulley-Cshaft	386-3041
7W-5696	Hub-Cshft	424-5887
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-0983	Mounting	384-3470
8D-9973	Housing	391-9825
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196

70R		
Original Part Number	Part Name	Classic Part Number
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372

Sales Model D333C (Cont'd.)

70R		
Original Part Number	Part Name	Classic Part Number
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8T-2466	Gasket Kit	393-5199
8W-3589	Link As-Spring	380-7389
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9N-3668	Base As.-Coolant	419-4718
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-7148	Cap As-Rain	378-3994
9S-7534	Pipe-Exh Ext	398-2950
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833

70R		
Original Part Number	Part Name	Classic Part Number
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
102-1561	Lifter As-Valve	311-9402
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
170-0558	Kit-Rebuild-Pump	390-1001
170-0560	Rebuild Kit-Pump	363-7458
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

70R		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7772	Pump Gp-Water -B	438-2009
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-9534	Bearing Kt-Main	468-8667
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
255-6863	Gasket	450-5024
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

Sales Model D337

22B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1L-7205	Bearing-Ball	416-2167
1P-7125	Governor As	383-3672
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
4B-7270	Cone-Bearing	399-4439

22B		
Original Part Number	**Part Name**	**Classic Part Number**
5B-9169	Plug-Drain	419-4736
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6V-2202	Bearing-Spl Ball	380-1574
7F-2742	Bearing-Ball	422-6488
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582

22B		
Original Part Number	**Part Name**	**Classic Part Number**
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
124-3237	Precleaner As	432-4220

23B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-9192	Bearing-Ball	394-8236
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992

23B		
Original Part Number	**Part Name**	**Classic Part Number**
4H-7496	Plate-Pump Seal	420-6217
5B-9169	Plug-Drain	419-4736
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5S-1211	Cover-Valve	314-8665
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
7B-7515	Bearing-Ball	399-6059
7F-2742	Bearing-Ball	422-6488
7H-6967	Bearing-Ball	422-6489

23B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

24B		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2S-3966	Ring-Seal	297-7237
5B-9169	Plug-Drain	419-4736
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502

24B		
Original Part Number	**Part Name**	**Classic Part Number**
5S-1211	Cover-Valve	314-8665
6B-6224	Ferrule	419-4738
7L-7508	Bearing-Ball	420-6536
7S-7809	Cap As-Radiator	295-6417
8F-5104	Screen As-Se Pan	314-8539

24B		
Original Part Number	**Part Name**	**Classic Part Number**
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
9L-2685	Rod End	419-1866
124-3237	Precleaner As	432-4220

Sales Model D337F

37B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1L-7205	Bearing-Ball	416-2167
1S-1888	Bracket-Lamp	297-7147
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3F-3049	Cone-Roller Brg	418-9600
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356

37B		
Original Part Number	**Part Name**	**Classic Part Number**
3N-1968	Mount-Shock	397-5046
4B-7270	Cone-Bearing	399-4439
4M-9215	Gear-Pump Idler	311-9391
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-9371	Connector-Inlet	311-9375
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7L-2041	Shaft-Water Pump	428-7200
7M-4603	Body-Fuel Valve	311-9348

37B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7N-7639	Rotator-Valve	383-1582
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
124-3237	Precleaner As	432-4220

38B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3B-8845	Bearing-Inner	417-4509
3H-5867	Retainer-Spring	390-0992

38B		
Original Part Number	**Part Name**	**Classic Part Number**
4H-7496	Plate-Pump Seal	420-6217
4M-9215	Gear-Pump Idler	311-9391
5B-9169	Plug-Drain	419-4736
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
7L-2041	Shaft-Water Pump	428-7200

38B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4603	Body-Fuel Valve	311-9348
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7N-7639	Rotator-Valve	383-1582
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9M-5350	Spring-Valve	380-7573

Sales Model D339

34B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167

Sales Model D339 (Cont'd.)

34B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296
1S-7056	Bearing-Ball	422-6483
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3F-3049	Cone-Roller Brg	418-9600
3H-0881	Ring-Piston	465-8998
3H-8726	Mount As	385-7208
4H-9640	Bearing-Sleeve	386-4921
4M-9183	Bearing-Sleeve	386-4924
4M-9215	Gear-Pump Idler	311-9391

34B		
Original Part Number	**Part Name**	**Classic Part Number**
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9553	Gasket Kit - Wp	393-3624
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-7816	Seal-O-Ring	314-8542
6N-5987	Shaft-Water Pump	390-0998
6V-2202	Bearing-Spl Ball	380-1574
7B-7515	Bearing-Ball	399-6059
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348

34B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
121-7746	Pre-Cleaner As	360-2311
162-3904	Pump As-F Prm	391-1102

Sales Model D3400

01N		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296
1S-1967	Chamber As	247-3291
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-1273	Chamber As	319-3434
2S-4015	Plunger As-Valve	311-9438

01N		
Original Part Number	**Part Name**	**Classic Part Number**
4M-0410	Gear-Oil Pump Dr	428-6660
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489

01N		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4603	Body-Fuel Valve	311-9348
7S-7809	Cap As-Radiator	295-6417
9B-1320	Valve-Check	377-5832
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311

Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1T-0043	Bearing-Ball	390-5294

Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2S-4015	Plunger As-Valve	311-9438

Original Part Number	**Part Name**	**Classic Part Number**
3B-6217	Muffler As	247-2671
4B-7255	Cone-Bearing	386-4951

Sales Model D3400 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
6H-3957	Bearing-Ball	311-9358

Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7H-6967	Bearing-Ball	422-6489
7T-2036	Cap As-Fuel	361-1721

Original Part Number	Part Name	Classic Part Number
7W-2731	Retainer	423-3541
108-5603	Screw-Adj Arm	379-0166

Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2S-4015	Plunger As-Valve	311-9438
3B-6217	Muffler As	247-2671

Original Part Number	Part Name	Classic Part Number
4B-7255	Cone-Bearing	386-4951
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
6H-3957	Bearing-Ball	311-9358
6Y-7652	Cup-Rlr Brg	399-6067

Original Part Number	Part Name	Classic Part Number
7H-6967	Bearing-Ball	422-6489
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
108-5603	Screw-Adj Arm	379-0166

Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2S-4015	Plunger As-Valve	311-9438
3B-6217	Muffler As	247-2671

Original Part Number	Part Name	Classic Part Number
4B-7255	Cone-Bearing	386-4951
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
6H-3957	Bearing-Ball	311-9358
6Y-7652	Cup-Rlr Brg	399-6067

Original Part Number	Part Name	Classic Part Number
7H-6967	Bearing-Ball	422-6489
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
108-5603	Screw-Adj Arm	379-0166

Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2S-4015	Plunger As-Valve	311-9438
3B-6217	Muffler As	247-2671

Original Part Number	Part Name	Classic Part Number
4B-7255	Cone-Bearing	386-4951
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
6H-3957	Bearing-Ball	311-9358
6Y-7652	Cup-Rlr Brg	399-6067

Original Part Number	Part Name	Classic Part Number
7H-6967	Bearing-Ball	422-6489
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
108-5603	Screw-Adj Arm	379-0166

Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2S-4015	Plunger As-Valve	311-9438
3B-6217	Muffler As	247-2671

Original Part Number	Part Name	Classic Part Number
4B-7255	Cone-Bearing	386-4951
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
6H-3957	Bearing-Ball	311-9358
6Y-7652	Cup-Rlr Brg	399-6067

Original Part Number	Part Name	Classic Part Number
7H-6967	Bearing-Ball	422-6489
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
108-5603	Screw-Adj Arm	379-0166

Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2S-4015	Plunger As-Valve	311-9438
3B-6217	Muffler As	247-2671

Original Part Number	Part Name	Classic Part Number
4B-7255	Cone-Bearing	386-4951
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
6H-3957	Bearing-Ball	311-9358
6Y-7652	Cup-Rlr Brg	399-6067

Original Part Number	Part Name	Classic Part Number
7H-6967	Bearing-Ball	422-6489
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
108-5603	Screw-Adj Arm	379-0166

Sales Model D342

05A		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296
1P-1367	Plunger-Valve	432-8913
1P-7125	Governor As	383-3672
1S-7056	Bearing-Ball	422-6483
1S-8607	Baffle	380-7540
1W-7035	Kit-Pump (Rbd)	421-1553
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2L-5271	Bearing-Ball	371-4305
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3H-0881	Ring-Piston	465-8998
3H-8726	Mount As	385-7208
3N-3368	Pipe-Exhaust	311-9434
4B-7270	Cone-Bearing	399-4439
4H-9640	Bearing-Sleeve	386-4921
4M-9183	Bearing-Sleeve	386-4924
4M-9215	Gear-Pump Idler	311-9391
4N-3875	Ring-Piston	465-8997
4S-7793	Thrower-Cshft O	367-6085
5B-9169	Plug-Drain	419-4736
5F-7404	Nut-Bearing Lock	308-9878
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555

05A		
Original Part Number	**Part Name**	**Classic Part Number**
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9738	Coupling-Exhaust	311-9380
5N-8501	Head As-Cyl	256-4762
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9553	Gasket Kit - Wp	393-3624
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-5987	Shaft-Water Pump	390-0998
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7N-3352	Plate-Spacer	386-3062

05A		
Original Part Number	**Part Name**	**Classic Part Number**
7N-4170	Pump Gp-Eng Oil	379-0169
7N-4407	Gasket-Rod Comp	433-9853
7N-7639	Rotator-Valve	383-1582
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-5026	Cover-Adj Pulley	445-7698
8H-9789	Bearing-Ball	374-8342
8N-4810	Gasket-Cyl Head	437-2046
8N-6004	Head As-Cyl	247-3369
8N-7923	Bearing-Main	419-7275
8N-7924	Bearing-Main	419-7276
8N-7933	Bearing-Conn Rod	419-7280
8N-7934	Bearing-Conn Rod	419-6308
9H-2256	Pump Gp-F Prm	311-9443
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
9S-5771	Bushing As	385-7219
124-3237	Precleaner As	432-4220
162-3904	Pump As-F Prm	391-1102
214-6045	Bellows As	435-4846

31B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167

31B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296

Sales Model D342 (Cont'd.)

31B		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-7125	Governor As	383-3672
1S-7056	Bearing-Ball	422-6483
1S-8607	Baffle	380-7540
1W-7035	Kit-Pump (Rbd)	421-1553
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2L-5271	Bearing-Ball	371-4305
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3H-0881	Ring-Piston	465-8998
3H-8726	Mount As	385-7208
3N-3368	Pipe-Exhaust	311-9434
4B-7270	Cone-Bearing	399-4439
4H-9640	Bearing-Sleeve	386-4921
4M-9183	Bearing-Sleeve	386-4924
4M-9215	Gear-Pump Idler	311-9391
4N-3875	Ring-Piston	465-8997
4S-7793	Thrower-Cshft O	367-6085
5B-9169	Plug-Drain	419-4736
5F-7404	Nut-Bearing Lock	308-9878
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854

31B		
Original Part Number	Part Name	Classic Part Number
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9738	Coupling-Exhaust	311-9380
5N-8501	Head As-Cyl	256-4762
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9553	Gasket Kit - Wp	393-3624
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-5987	Shaft-Water Pump	390-0998
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7N-3352	Plate-Spacer	386-3062
7N-4170	Pump Gp-Eng Oil	379-0169

31B		
Original Part Number	Part Name	Classic Part Number
7N-4407	Gasket-Rod Comp	433-9853
7N-7639	Rotator-Valve	383-1582
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-5026	Cover-Adj Pulley	445-7698
8H-9789	Bearing-Ball	374-8342
8N-4810	Gasket-Cyl Head	437-2046
8N-6004	Head As-Cyl	247-3369
8N-7923	Bearing-Main	419-7275
8N-7924	Bearing-Main	419-7276
8N-7933	Bearing-Conn Rod	419-7280
8N-7934	Bearing-Conn Rod	419-6308
9H-2256	Pump Gp-F Prm	311-9443
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
9S-5771	Bushing As	385-7219
124-3237	Precleaner As	432-4220
162-3904	Pump As-F Prm	391-1102
214-6045	Bellows As	435-4846

32B		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368

32B		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483

32B		
Original Part Number	Part Name	Classic Part Number
1S-8607	Baffle	380-7540
1W-7035	Kit-Pump (Rbd)	421-1553

Sales Model D342 (Cont'd.)

32B		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2L-5271	Bearing-Ball	371-4305
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3B-8845	Bearing-Inner	417-4509
3H-0881	Ring-Piston	465-8998
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
4B-7255	Cone-Bearing	386-4951
4H-7496	Plate-Pump Seal	420-6217
4H-9640	Bearing-Sleeve	386-4921
4M-9183	Bearing-Sleeve	386-4924
4M-9215	Gear-Pump Idler	311-9391
4N-3875	Ring-Piston	465-8997
4S-7793	Thrower-Cshft O	367-6085
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-5772	Race & Roller As	394-9200

32B		
Original Part Number	**Part Name**	**Classic Part Number**
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5N-8501	Head As-Cyl	256-4762
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9553	Gasket Kit - Wp	393-3624
5S-1220	Lifter As-Valve	387-2926
5S-9080	Pulley-Alt Drive	264-5883
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-5987	Shaft-Water Pump	390-0998
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7N-3352	Plate-Spacer	386-3062

32B		
Original Part Number	**Part Name**	**Classic Part Number**
7N-4407	Gasket-Rod Comp	433-9853
7N-7639	Rotator-Valve	383-1582
7N-9352	Gasket	433-8188
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8N-4810	Gasket-Cyl Head	437-2046
8N-6004	Head As-Cyl	247-3369
8N-7923	Bearing-Main	419-7275
8N-7924	Bearing-Main	419-7276
8N-7933	Bearing-Conn Rod	419-7280
8N-7934	Bearing-Conn Rod	419-6308
9H-2256	Pump Gp-F Prm	311-9443
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
124-3237	Precleaner As	432-4220
162-3904	Pump As-F Prm	391-1102
214-6045	Bellows As	435-4846

35J		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1S-8607	Baffle	380-7540
2A-4429	Lock-Retainer	379-0174

35J		
Original Part Number	**Part Name**	**Classic Part Number**
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438

35J		
Original Part Number	**Part Name**	**Classic Part Number**
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3H-0881	Ring-Piston	465-8998
4H-9640	Bearing-Sleeve	386-4921
4M-9183	Bearing-Sleeve	386-4924

Sales Model D342 (Cont'd.)

35J		
Original Part Number	Part Name	Classic Part Number
4M-9215	Gear-Pump Idler	311-9391
4N-3875	Ring-Piston	465-8997
4S-7793	Thrower-Cshft O	367-6085
5F-7404	Nut-Bearing Lock	308-9878
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9738	Coupling-Exhaust	311-9380
5N-8501	Head As-Cyl	256-4762
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738

35J		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6L-7816	Seal-O-Ring	314-8542
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7N-3352	Plate-Spacer	386-3062
7N-4407	Gasket-Rod Comp	433-9853
7N-7639	Rotator-Valve	383-1582
7N-9352	Gasket	433-8188
7T-2036	Cap As-Fuel	361-1721
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494

35J		
Original Part Number	Part Name	Classic Part Number
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-4810	Gasket-Cyl Head	437-2046
8N-6004	Head As-Cyl	247-3369
8N-7923	Bearing-Main	419-7275
8N-7924	Bearing-Main	419-7276
8N-7933	Bearing-Conn Rod	419-7280
8N-7934	Bearing-Conn Rod	419-6308
9H-6236	Rod As	390-0999
9M-5350	Spring-Valve	380-7573
9S-5771	Bushing As	385-7219
162-3904	Pump As-F Prm	391-1102

Sales Model D342C

05A		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296
1P-1367	Plunger-Valve	432-8913
1P-7125	Governor As	383-3672
1S-7056	Bearing-Ball	422-6483
1S-8607	Baffle	380-7540
1W-7035	Kit-Pump (Rbd)	421-1553
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2L-5271	Bearing-Ball	371-4305
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438

05A		
Original Part Number	Part Name	Classic Part Number
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3H-0881	Ring-Piston	465-8998
3H-8726	Mount As	385-7208
3N-3368	Pipe-Exhaust	311-9434
4B-7270	Cone-Bearing	399-4439
4H-9640	Bearing-Sleeve	386-4921
4M-9183	Bearing-Sleeve	386-4924
4M-9215	Gear-Pump Idler	311-9391
4N-3875	Ring-Piston	465-8997
4S-7793	Thrower-Cshft O	367-6085
5B-9169	Plug-Drain	419-4736
5F-7404	Nut-Bearing Lock	308-9878
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555

05A		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9738	Coupling-Exhaust	311-9380
5N-8501	Head As-Cyl	256-4762
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9553	Gasket Kit - Wp	393-3624
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358

Sales Model D342C (Cont'd.)

05A		
Original Part Number	**Part Name**	**Classic Part Number**
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-5987	Shaft-Water Pump	390-0998
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7N-3352	Plate-Spacer	386-3062

05A		
Original Part Number	**Part Name**	**Classic Part Number**
7N-4170	Pump Gp-Eng Oil	379-0169
7N-4407	Gasket-Rod Comp	433-9853
7N-7639	Rotator-Valve	383-1582
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-5026	Cover-Adj Pulley	445-7698

05A		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
8N-4810	Gasket-Cyl Head	437-2046
8N-6004	Head As-Cyl	247-3369
8N-7923	Bearing-Main	419-7275
8N-7924	Bearing-Main	419-7276
8N-7933	Bearing-Conn Rod	419-7280
8N-7934	Bearing-Conn Rod	419-6308
9H-2256	Pump Gp-F Prm	311-9443
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
9S-5771	Bushing As	385-7219
124-3237	Precleaner As	432-4220
162-3904	Pump As-F Prm	391-1102
214-6045	Bellows As	435-4846

31B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296
1P-1367	Plunger-Valve	432-8913
1P-7125	Governor As	383-3672
1S-7056	Bearing-Ball	422-6483
1S-8607	Baffle	380-7540
1W-7035	Kit-Pump (Rbd)	421-1553
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2L-5271	Bearing-Ball	371-4305
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099

31B		
Original Part Number	**Part Name**	**Classic Part Number**
3H-0881	Ring-Piston	465-8998
3H-8726	Mount As	385-7208
3N-3368	Pipe-Exhaust	311-9434
4B-7270	Cone-Bearing	399-4439
4H-9640	Bearing-Sleeve	386-4921
4M-9183	Bearing-Sleeve	386-4924
4M-9215	Gear-Pump Idler	311-9391
4N-3875	Ring-Piston	465-8997
4S-7793	Thrower-Cshft O	367-6085
5B-9169	Plug-Drain	419-4736
5F-7404	Nut-Bearing Lock	308-9878
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555

31B		
Original Part Number	**Part Name**	**Classic Part Number**
5L-8856	Coupling-Exhaust	311-9379
5L-9738	Coupling-Exhaust	311-9380
5N-8501	Head As-Cyl	256-4762
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9553	Gasket Kit - Wp	393-3624
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381

Sales Model D342C (Cont'd.)

31B		
Original Part Number	**Part Name**	**Classic Part Number**
6N-5987	Shaft-Water Pump	390-0998
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7N-3352	Plate-Spacer	386-3062
7N-4170	Pump Gp-Eng Oil	379-0169
7N-4407	Gasket-Rod Comp	433-9853
7N-7639	Rotator-Valve	383-1582

31B		
Original Part Number	**Part Name**	**Classic Part Number**
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-5026	Cover-Adj Pulley	445-7698
8H-9789	Bearing-Ball	374-8342
8N-4810	Gasket-Cyl Head	437-2046

31B		
Original Part Number	**Part Name**	**Classic Part Number**
8N-6004	Head As-Cyl	247-3369
8N-7923	Bearing-Main	419-7275
8N-7924	Bearing-Main	419-7276
8N-7933	Bearing-Conn Rod	419-7280
8N-7934	Bearing-Conn Rod	419-6308
9H-2256	Pump Gp-F Prm	311-9443
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
9S-5771	Bushing As	385-7219
124-3237	Precleaner As	432-4220
162-3904	Pump As-F Prm	391-1102
214-6045	Bellows As	435-4846

32B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1S-8607	Baffle	380-7540
1W-7035	Kit-Pump (Rbd)	421-1553
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2L-5271	Bearing-Ball	371-4305
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3B-8845	Bearing-Inner	417-4509
3H-0881	Ring-Piston	465-8998
3N-3368	Pipe-Exhaust	311-9434

32B		
Original Part Number	**Part Name**	**Classic Part Number**
3N-4892	Lever-Gov Cont	439-4542
4B-7255	Cone-Bearing	386-4951
4H-7496	Plate-Pump Seal	420-6217
4H-9640	Bearing-Sleeve	386-4921
4M-9183	Bearing-Sleeve	386-4924
4M-9215	Gear-Pump Idler	311-9391
4N-3875	Ring-Piston	465-8997
4S-7793	Thrower-Cshft O	367-6085
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-5772	Race & Roller As	394-9200
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5N-8501	Head As-Cyl	256-4762

32B		
Original Part Number	**Part Name**	**Classic Part Number**
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9553	Gasket Kit - Wp	393-3624
5S-1220	Lifter As-Valve	387-2926
5S-9080	Pulley-Alt Drive	264-5883
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-5987	Shaft-Water Pump	390-0998
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538

Sales Model D342C (Cont'd.)

32B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7N-3352	Plate-Spacer	386-3062
7N-4407	Gasket-Rod Comp	433-9853
7N-7639	Rotator-Valve	383-1582
7N-9352	Gasket	433-8188
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494

32B		
Original Part Number	**Part Name**	**Classic Part Number**
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8N-4810	Gasket-Cyl Head	437-2046
8N-6004	Head As-Cyl	247-3369
8N-7923	Bearing-Main	419-7275
8N-7924	Bearing-Main	419-7276
8N-7933	Bearing-Conn Rod	419-7280

32B		
Original Part Number	**Part Name**	**Classic Part Number**
8N-7934	Bearing-Conn Rod	419-6308
9H-2256	Pump Gp-F Prm	311-9443
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
124-3237	Precleaner As	432-4220
162-3904	Pump As-F Prm	391-1102
214-6045	Bellows As	435-4846

49B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1S-8607	Baffle	380-7540
1W-7035	Kit-Pump (Rbd)	421-1553
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-5254	Bearing-Outer	377-7419
2L-5271	Bearing-Ball	371-4305
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3H-0881	Ring-Piston	465-8998
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
4B-7270	Cone-Bearing	399-4439
4H-9640	Bearing-Sleeve	386-4921

49B		
Original Part Number	**Part Name**	**Classic Part Number**
4M-9183	Bearing-Sleeve	386-4924
4M-9215	Gear-Pump Idler	311-9391
4N-3875	Ring-Piston	465-8997
4S-7793	Thrower-Cshft O	367-6085
5B-9169	Plug-Drain	419-4736
5F-7404	Nut-Bearing Lock	308-9878
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9738	Coupling-Exhaust	311-9380
5N-8501	Head As-Cyl	256-4762
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9553	Gasket Kit - Wp	393-3624
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738

49B		
Original Part Number	**Part Name**	**Classic Part Number**
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-5987	Shaft-Water Pump	390-0998
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7N-3352	Plate-Spacer	386-3062
7N-4170	Pump Gp-Eng Oil	379-0169
7N-4407	Gasket-Rod Comp	433-9853
7N-7639	Rotator-Valve	383-1582
7N-9352	Gasket	433-8188
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721

Sales Model D342C (Cont'd.)

49B		
Original Part Number	**Part Name**	**Classic Part Number**
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-5026	Cover-Adj Pulley	445-7698

49B		
Original Part Number	**Part Name**	**Classic Part Number**
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-4810	Gasket-Cyl Head	437-2046
8N-6004	Head As-Cyl	247-3369
8N-7923	Bearing-Main	419-7275
8N-7924	Bearing-Main	419-7276
8N-7933	Bearing-Conn Rod	419-7280
8N-7934	Bearing-Conn Rod	419-6308

49B		
Original Part Number	**Part Name**	**Classic Part Number**
9H-2256	Pump Gp-F Prm	311-9443
9H-6236	Rod As	390-0999
9M-5350	Spring-Valve	380-7573
9S-5771	Bushing As	385-7219
9S-7148	Cap As-Rain	378-3994
124-3237	Precleaner As	432-4220
162-3904	Pump As-F Prm	391-1102
214-6045	Bellows As	435-4846

50B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1S-8607	Baffle	380-7540
1W-7035	Kit-Pump (Rbd)	421-1553
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2L-5271	Bearing-Ball	371-4305
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3B-8845	Bearing-Inner	417-4509
3H-0881	Ring-Piston	465-8998
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
4B-7255	Cone-Bearing	386-4951
4H-7496	Plate-Pump Seal	420-6217

50B		
Original Part Number	**Part Name**	**Classic Part Number**
4H-9640	Bearing-Sleeve	386-4921
4M-9183	Bearing-Sleeve	386-4924
4M-9215	Gear-Pump Idler	311-9391
4N-3875	Ring-Piston	465-8997
4S-7793	Thrower-Cshft O	367-6085
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-5772	Race & Roller As	394-9200
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5N-8501	Head As-Cyl	256-4762
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9553	Gasket Kit - Wp	393-3624
5S-1220	Lifter As-Valve	387-2926
5S-9080	Pulley-Alt Drive	264-5883
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739

50B		
Original Part Number	**Part Name**	**Classic Part Number**
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-5987	Shaft-Water Pump	390-0998
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7N-3352	Plate-Spacer	386-3062
7N-4407	Gasket-Rod Comp	433-9853
7N-7639	Rotator-Valve	383-1582
7N-9352	Gasket	433-8188
7S-4411	Cap As-Rain	373-1912
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701

Sales Model D342C (Cont'd.)

50B		
Original Part Number	**Part Name**	**Classic Part Number**
8H-1994	Valve-Exhaust	443-1206
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8N-4810	Gasket-Cyl Head	437-2046
8N-6004	Head As-Cyl	247-3369
8N-7923	Bearing-Main	419-7275

50B		
Original Part Number	**Part Name**	**Classic Part Number**
8N-7924	Bearing-Main	419-7276
8N-7933	Bearing-Conn Rod	419-7280
8N-7934	Bearing-Conn Rod	419-6308
9H-2256	Pump Gp-F Prm	311-9443
9H-6236	Rod As	390-0999

50B		
Original Part Number	**Part Name**	**Classic Part Number**
9M-5350	Spring-Valve	380-7573
9S-7148	Cap As-Rain	378-3994
124-3237	Precleaner As	432-4220
162-3904	Pump As-F Prm	391-1102
214-6045	Bellows As	435-4846

Sales Model D343A

33B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3S-9466	Bearing-Sleeve	314-8509
4B-7255	Cone-Bearing	386-4951
4L-8473	Plate-Wear	419-0883
4M-9215	Gear-Pump Idler	311-9391
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
5B-9169	Plug-Drain	419-4736

33B		
Original Part Number	**Part Name**	**Classic Part Number**
5F-8651	Bearing-Ball	420-3223
5L-2660	Bearing-Sleeve	311-9363
5L-5772	Race & Roller As	394-9200
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9656	Cone-Bearing	399-4448
5M-3560	Bearing-Sleeve	392-4521
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7E-5085	Bushing	377-5829

33B		
Original Part Number	**Part Name**	**Classic Part Number**
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
9H-2256	Pump Gp-F Prm	311-9443
9M-8395	Bearing-Sleeve	391-1103

Sales Model D343A (Cont'd.)

33B		
Original Part Number	Part Name	Classic Part Number
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493

33B		
Original Part Number	Part Name	Classic Part Number
9S-7148	Cap As-Rain	378-3994
162-3904	Pump As-F Prm	391-1102

33B		
Original Part Number	Part Name	Classic Part Number
214-6045	Bellows As	435-4846

62B		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1L-7205	Bearing-Ball	416-2167
1P-1367	Plunger-Valve	432-8913
1P-7125	Governor As	383-3672
1S-7056	Bearing-Ball	422-6483
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3S-9466	Bearing-Sleeve	314-8509
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4M-9215	Gear-Pump Idler	311-9391
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
5B-9169	Plug-Drain	419-4736
5F-7404	Nut-Bearing Lock	308-9878
5F-8651	Bearing-Ball	420-3223
5L-2660	Bearing-Sleeve	311-9363
5L-7520	Elbow-Exhaust	419-4711

62B		
Original Part Number	Part Name	Classic Part Number
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5M-3560	Bearing-Sleeve	392-4521
5P-2448	Bearing-Ball	399-6064
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6L-2279	Plug-Ptf	419-4739
6L-3353	Rod End-Special	416-2134
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189

62B		
Original Part Number	Part Name	Classic Part Number
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9M-8395	Bearing-Sleeve	391-1103
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-7148	Cap As-Rain	378-3994
162-3904	Pump As-F Prm	391-1102
214-6045	Bellows As	435-4846

Sales Model D343A (Cont'd.)

63M		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
5L-7632	Support-Elbow	433-9854
5L-9738	Coupling-Exhaust	311-9380
5M-3560	Bearing-Sleeve	392-4521

63M		
Original Part Number	Part Name	Classic Part Number
5P-8789	Gasket Kt	393-3620
5S-8543	Bearing-Sleeve	376-3635
7E-5085	Bushing	377-5829
7L-7508	Bearing-Ball	420-6536
7M-7226	Gasket-Cam Cover	433-8189
7S-3206	Seal-O-Ring	436-2656
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250

63M		
Original Part Number	Part Name	Classic Part Number
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493

Sales Model D346

39J		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1W-6005	Bearing-Sleeve	417-4521
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-7242	Tube As	444-5677
2S-5100	Valve-Ball	386-3049
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-2078	Pump Gp-Fuel Tfr	311-9444
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3S-1467	Pump Gp-F Inj -B	452-9555
3S-9466	Bearing-Sleeve	314-8509
4M-9215	Gear-Pump Idler	311-9391

39J		
Original Part Number	Part Name	Classic Part Number
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
4W-5693	Bearing-Con Rod	419-6324
5B-9169	Plug-Drain	419-4736
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5P-2448	Bearing-Ball	399-6064
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951

39J		
Original Part Number	Part Name	Classic Part Number
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-2063	Shaft As-Pump	386-3055
7N-5449	Spool-Press Rlf	434-2450
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-9489	Chamber As	247-3301
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9S-6743	Chamber As	247-3303
131-3815	Seal Gp-Basic	325-6193
214-6045	Bellows As	435-4846

Sales Model D346 (Cont'd.)

40J		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1W-6005	Bearing-Sleeve	417-4521
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-7242	Tube As	444-5677
2S-5100	Valve-Ball	386-3049
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-2078	Pump Gp-Fuel Tfr	311-9444
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3S-1467	Pump Gp-F Inj -B	452-9555
3S-9466	Bearing-Sleeve	314-8509
4M-9215	Gear-Pump Idler	311-9391

40J		
Original Part Number	Part Name	Classic Part Number
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
4W-5693	Bearing-Con Rod	419-6324
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9656	Cone-Bearing	399-4448
5P-2448	Bearing-Ball	399-6064
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015

40J		
Original Part Number	Part Name	Classic Part Number
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-2063	Shaft As-Pump	386-3055
7N-5449	Spool-Press Rlf	434-2450
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-8110	Gasket-Cam Hsg	433-8186
8N-9489	Chamber As	247-3301
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9S-6743	Chamber As	247-3303
131-3815	Seal Gp-Basic	325-6193
214-6045	Bellows As	435-4846

98N		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-9209	Shaft-Tightener	374-6499
1W-6005	Bearing-Sleeve	417-4521
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-3966	Ring-Seal	297-7237
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541

98N		
Original Part Number	Part Name	Classic Part Number
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3S-1467	Pump Gp-F Inj -B	452-9555
3S-9466	Bearing-Sleeve	314-8509
4M-9215	Gear-Pump Idler	311-9391
4S-5367	Mount As	375-9986
4W-5693	Bearing-Con Rod	419-6324
5H-7071	Director-Water	388-0555
5L-8856	Coupling-Exhaust	311-9379
5M-2824	Coupling-Exhaust	431-5270

98N		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6V-2202	Bearing-Spl Ball	380-1574
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-5449	Spool-Press Rlf	434-2450
8F-6058	Bearing-Sleeve	416-5494

Sales Model D346 (Cont'd.)

98N		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439

98N		
Original Part Number	Part Name	Classic Part Number
8N-9489	Chamber As	247-3301
9S-6743	Chamber As	247-3303

98N		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
162-3904	Pump As-F Prm	391-1102

Sales Model D348

36J		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1W-6005	Bearing-Sleeve	417-4521
1W-6356	Gasket	438-1795
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-7242	Tube As	444-5677
2S-5100	Valve-Ball	386-3049
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-2078	Pump Gp-Fuel Tfr	311-9444
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3S-1467	Pump Gp-F Inj -B	452-9555
3S-9466	Bearing-Sleeve	314-8509
4M-9215	Gear-Pump Idler	311-9391
4N-4519	Quadrant-Control	444-0572

36J		
Original Part Number	Part Name	Classic Part Number
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
4W-5693	Bearing-Con Rod	419-6324
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5P-2448	Bearing-Ball	399-6064
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381

36J		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-2063	Shaft As-Pump	386-3055
7N-5449	Spool-Press Rlf	434-2450
7W-2731	Retainer	423-3541
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-3248	Gasket As	415-1893
8N-8110	Gasket-Cam Hsg	433-8186
8N-9489	Chamber As	247-3301
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9S-6743	Chamber As	247-3303
131-3815	Seal Gp-Basic	325-6193
207-1332	Bellows As	444-0569
214-6045	Bellows As	435-4846

38J		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1W-6005	Bearing-Sleeve	417-4521

38J		
Original Part Number	Part Name	Classic Part Number
1W-6356	Gasket	438-1795
1W-8539	Bearing-Conn Rod	419-7251

38J		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955

Sales Model D348 (Cont'd.)

38J		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-7242	Tube As	444-5677
2S-5100	Valve-Ball	386-3049
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-2078	Pump Gp-Fuel Tfr	311-9444
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3S-1467	Pump Gp-F Inj -B	452-9555
3S-9466	Bearing-Sleeve	314-8509
4M-9215	Gear-Pump Idler	311-9391
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
4W-5693	Bearing-Con Rod	419-6324
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161

38J		
Original Part Number	Part Name	Classic Part Number
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9656	Cone-Bearing	399-4448
5L-9738	Coupling-Exhaust	311-9380
5P-2448	Bearing-Ball	399-6064
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489

38J		
Original Part Number	Part Name	Classic Part Number
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-2063	Shaft As-Pump	386-3055
7N-5449	Spool-Press Rlf	434-2450
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-8110	Gasket-Cam Hsg	433-8186
8N-9489	Chamber As	247-3301
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9S-6743	Chamber As	247-3303
131-3815	Seal Gp-Basic	325-6193
207-1332	Bellows As	444-0569
214-6045	Bellows As	435-4846

57K		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-9209	Shaft-Tightener	374-6499
1W-6005	Bearing-Sleeve	417-4521
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-3966	Ring-Seal	297-7237
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
3N-3368	Pipe-Exhaust	311-9434

57K		
Original Part Number	Part Name	Classic Part Number
3N-4892	Lever-Gov Cont	439-4542
3S-1467	Pump Gp-F Inj -B	452-9555
3S-9466	Bearing-Sleeve	314-8509
4M-9215	Gear-Pump Idler	311-9391
4S-5367	Mount As	375-9986
4W-5693	Bearing-Con Rod	419-6324
5H-7071	Director-Water	388-0555
5L-9738	Coupling-Exhaust	311-9380
5M-2824	Coupling-Exhaust	431-5270
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620

57K		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6L-4714	Panel-Acl Filter	314-8532
6V-2202	Bearing-Spl Ball	380-1574
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-5449	Spool-Press Rlf	434-2450
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342

Sales Model D348 (Cont'd.)

57K		
Original Part Number	Part Name	Classic Part Number
8M-0874	Plunger As-Valve	311-9439
8N-3666	Repair Kt-Major	377-5842
8N-8110	Gasket-Cam Hsg	433-8186

57K		
Original Part Number	Part Name	Classic Part Number
8N-9489	Chamber As	247-3301
9M-8395	Bearing-Sleeve	391-1103
9S-6743	Chamber As	247-3303
110-1337	Ring Kit-Pstn	377-5834

57K		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
162-3904	Pump As-F Prm	391-1102

Sales Model D349

32R		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-6005	Bearing-Sleeve	417-4521
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-3966	Ring-Seal	297-7237
2S-6150	Cover-Pulley	428-8817
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3S-1467	Pump Gp-F Inj -B	452-9555

32R		
Original Part Number	Part Name	Classic Part Number
3S-9466	Bearing-Sleeve	314-8509
4M-9215	Gear-Pump Idler	311-9391
4W-5693	Bearing-Con Rod	419-6324
5H-7071	Director-Water	388-0555
5L-9738	Coupling-Exhaust	311-9380
5M-2824	Coupling-Exhaust	431-5270
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6V-2202	Bearing-Spl Ball	380-1574

32R		
Original Part Number	Part Name	Classic Part Number
7F-2742	Bearing-Ball	422-6488
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-5449	Spool-Press Rlf	434-2450
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-9489	Chamber As	247-3301
9S-6743	Chamber As	247-3303
131-3815	Seal Gp-Basic	325-6193
162-3904	Pump As-F Prm	391-1102

61P		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-6005	Bearing-Sleeve	417-4521
1W-6356	Gasket	438-1795
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030

61P		
Original Part Number	Part Name	Classic Part Number
2N-7242	Tube As	444-5677
2S-5100	Valve-Ball	386-3049
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-2078	Pump Gp-Fuel Tfr	311-9444
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3S-1467	Pump Gp-F Inj -B	452-9555
3S-9466	Bearing-Sleeve	314-8509

61P		
Original Part Number	Part Name	Classic Part Number
4M-9215	Gear-Pump Idler	311-9391
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
4W-5693	Bearing-Con Rod	419-6324
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711

Sales Model D349 (Cont'd.)

61P		
Original Part Number	Part Name	Classic Part Number
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951

61P		
Original Part Number	Part Name	Classic Part Number
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-2063	Shaft As-Pump	386-3055
7N-5449	Spool-Press Rlf	434-2450
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512

61P		
Original Part Number	Part Name	Classic Part Number
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-9489	Chamber As	247-3301
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9S-6743	Chamber As	247-3303
108-1760	Bearing-Ball	417-9493
131-3815	Seal Gp-Basic	325-6193
207-1332	Bellows As	444-0569
214-6045	Bellows As	435-4846

62P		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-6005	Bearing-Sleeve	417-4521
1W-6356	Gasket	438-1795
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-7242	Tube As	444-5677
2S-5100	Valve-Ball	386-3049
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-2078	Pump Gp-Fuel Tfr	311-9444
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3S-1467	Pump Gp-F Inj -B	452-9555
3S-9466	Bearing-Sleeve	314-8509
4M-9215	Gear-Pump Idler	311-9391

62P		
Original Part Number	Part Name	Classic Part Number
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
4W-5693	Bearing-Con Rod	419-6324
5B-9169	Plug-Drain	419-4736
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9656	Cone-Bearing	399-4448
5L-9738	Coupling-Exhaust	311-9380
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381

62P		
Original Part Number	Part Name	Classic Part Number
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-2063	Shaft As-Pump	386-3055
7N-5449	Spool-Press Rlf	434-2450
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-9489	Chamber As	247-3301
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9S-6743	Chamber As	247-3303
108-1760	Bearing-Ball	417-9493
131-3815	Seal Gp-Basic	325-6193
207-1332	Bellows As	444-0569
214-6045	Bellows As	435-4846

Sales Model D353C

46B		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1N-4317	Bearing-Main	419-7253
1N-4336	Bearing-Conn Rod	419-6329
1N-4337	Bearing-Conn Rod	419-6328
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1S-8607	Baffle	380-7540
1W-1822	Valve-Exhaust	443-1205
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-6440	Gasket-Cyl Head	449-9548
1W-8606	Valve-Inlet	443-1204
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-2330	Bearing-Sleeve	452-9554
2H-3069	Lifter As-Valve	387-2927
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2S-2430	Thrower-Chsft O	380-7543
2S-3966	Ring-Seal	297-7237
2S-7264	Pump As-Fuel Inj	395-1318
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3L-1425	Bearing-Ball	311-9356
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4M-4431	Shaft-Pump Dr	390-0994
4M-9214	Shaft-Pump Drive	314-8543
4M-9215	Gear-Pump Idler	311-9391

46B		
Original Part Number	Part Name	Classic Part Number
4M-9216	Gear-Pump Drive	311-9390
4N-3664	Guide-Valve	314-8524
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
5B-9169	Plug-Drain	419-4736
5F-7404	Nut-Bearing Lock	308-9878
5F-8651	Bearing-Ball	420-3223
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5M-6211	Shaft-Planet	219-9684
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-8974	Gasket Kit - Wp	387-2912
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6H-5845	Baffle-Oil	390-0926
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-1813	Pump Gp-Bft 1 Gr	330-9279
6N-2460	Pump Gp-Eng Oil	395-1316
6N-6969	Chamber As	247-3299
6N-9654	Core As-Oil Clr	435-4787

46B		
Original Part Number	Part Name	Classic Part Number
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
6V-2936	Gasket Kt-V G	387-2915
7H-6967	Bearing-Ball	422-6489
7L-2041	Shaft-Water Pump	428-7200
7L-7508	Bearing-Ball	420-6536
7L-8240	Bellows	419-4741
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-2275	Bearing-Sleeve	311-9365
8N-3451	Line As-Fuel Inj	390-0927
8N-3452	Line As-Fuel Inj	390-0928
8N-3453	Line As-Fuel Inj	390-0940
8N-3454	Line As-Fuel Inj	390-0930
8N-3455	Line As-Fuel Inj	390-0920
8N-3723	Valve-Exhaust	311-9472
8S-3617	Chamber As	247-3302

Sales Model D353C (Cont'd.)

46B		
Original Part Number	Part Name	Classic Part Number
9H-2256	Pump Gp-F Prm	311-9443
9M-5350	Spring-Valve	380-7573

46B		
Original Part Number	Part Name	Classic Part Number
102-1561	Lifter As-Valve	311-9402
124-3237	Precleaner As	432-4220
125-2728	Core As	395-1302

46B		
Original Part Number	Part Name	Classic Part Number
162-3904	Pump As-F Prm	391-1102
214-6045	Bellows As	435-4846

47B		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1N-4317	Bearing-Main	419-7253
1N-4336	Bearing-Conn Rod	419-6329
1N-4337	Bearing-Conn Rod	419-6328
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1S-8607	Baffle	380-7540
1W-1822	Valve-Exhaust	443-1205
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-6440	Gasket-Cyl Head	449-9548
1W-8606	Valve-Inlet	443-1204
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-2330	Bearing-Sleeve	452-9554
2H-3069	Lifter As-Valve	387-2927
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2S-2430	Thrower-Chsft O	380-7543
2S-3966	Ring-Seal	297-7237
2S-7264	Pump As-Fuel Inj	395-1318
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542

47B		
Original Part Number	Part Name	Classic Part Number
4H-7496	Plate-Pump Seal	420-6217
4L-8473	Plate-Wear	419-0883
4M-4431	Shaft-Pump Dr	390-0994
4M-9214	Shaft-Pump Drive	314-8543
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4N-3664	Guide-Valve	314-8524
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9738	Coupling-Exhaust	311-9380
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-8974	Gasket Kit - Wp	387-2912
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6H-5845	Baffle-Oil	390-0926
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542

47B		
Original Part Number	Part Name	Classic Part Number
6L-8968	Coupling-Exhaust	311-9381
6N-2460	Pump Gp-Eng Oil	395-1316
6N-6969	Chamber As	247-3299
6V-2202	Bearing-Spl Ball	380-1574
6V-2936	Gasket Kt-V G	387-2915
7H-6967	Bearing-Ball	422-6489
7L-2041	Shaft-Water Pump	428-7200
7L-7508	Bearing-Ball	420-6536
7L-8240	Bellows	419-4741
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-4515	Body As-Piston	311-9346
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-2275	Bearing-Sleeve	311-9365
8N-3451	Line As-Fuel Inj	390-0927
8N-3452	Line As-Fuel Inj	390-0928
8N-3453	Line As-Fuel Inj	390-0940

Sales Model D353C (Cont'd.)

47B		
Original Part Number	Part Name	Classic Part Number
8N-3454	Line As-Fuel Inj	390-0930
8N-3455	Line As-Fuel Inj	390-0920
8N-3723	Valve-Exhaust	311-9472

47B		
Original Part Number	Part Name	Classic Part Number
8S-3617	Chamber As	247-3302
9H-2256	Pump Gp-F Prm	311-9443
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402

47B		
Original Part Number	Part Name	Classic Part Number
125-2728	Core As	395-1302
162-3904	Pump As-F Prm	391-1102
214-6045	Bellows As	435-4846

Sales Model D353D

46B		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1N-4317	Bearing-Main	419-7253
1N-4336	Bearing-Conn Rod	419-6329
1N-4337	Bearing-Conn Rod	419-6328
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1S-8607	Baffle	380-7540
1W-1822	Valve-Exhaust	443-1205
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-6440	Gasket-Cyl Head	449-9548
1W-8606	Valve-Inlet	443-1204
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-2330	Bearing-Sleeve	452-9554
2H-3069	Lifter As-Valve	387-2927
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2S-2430	Thrower-Chsft O	380-7543
2S-3966	Ring-Seal	297-7237
2S-7264	Pump As-Fuel Inj	395-1318
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992

46B		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4M-4431	Shaft-Pump Dr	390-0994
4M-9214	Shaft-Pump Drive	314-8543
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4N-3664	Guide-Valve	314-8524
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
5B-9169	Plug-Drain	419-4736
5F-7404	Nut-Bearing Lock	308-9878
5F-8651	Bearing-Ball	420-3223
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5M-6211	Shaft-Planet	219-9684
5P-7807	Bearing-Ball	314-8502

46B		
Original Part Number	Part Name	Classic Part Number
5P-8970	Gasket Kt-Liner	383-1576
5P-8974	Gasket Kit - Wp	387-2912
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6H-5845	Baffle-Oil	390-0926
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-1813	Pump Gp-Bft 1 Gr	330-9279
6N-2460	Pump Gp-Eng Oil	395-1316
6N-6969	Chamber As	247-3299
6N-9654	Core As-Oil Clr	435-4787
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
6V-2936	Gasket Kt-V G	387-2915
7H-6967	Bearing-Ball	422-6489
7L-2041	Shaft-Water Pump	428-7200
7L-7508	Bearing-Ball	420-6536
7L-8240	Bellows	419-4741
7M-4603	Body-Fuel Valve	311-9348

Sales Model D353D (Cont'd.)

46B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512

46B		
Original Part Number	**Part Name**	**Classic Part Number**
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-2275	Bearing-Sleeve	311-9365
8N-3451	Line As-Fuel Inj	390-0927
8N-3452	Line As-Fuel Inj	390-0928
8N-3453	Line As-Fuel Inj	390-0940
8N-3454	Line As-Fuel Inj	390-0930

46B		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3455	Line As-Fuel Inj	390-0920
8N-3723	Valve-Exhaust	311-9472
8S-3617	Chamber As	247-3302
9H-2256	Pump Gp-F Prm	311-9443
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
124-3237	Precleaner As	432-4220
125-2728	Core As	395-1302
162-3904	Pump As-F Prm	391-1102
214-6045	Bellows As	435-4846

47B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1N-4317	Bearing-Main	419-7253
1N-4336	Bearing-Conn Rod	419-6329
1N-4337	Bearing-Conn Rod	419-6328
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1S-8607	Baffle	380-7540
1W-1822	Valve-Exhaust	443-1205
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-6440	Gasket-Cyl Head	449-9548
1W-8606	Valve-Inlet	443-1204
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-2330	Bearing-Sleeve	452-9554
2H-3069	Lifter As-Valve	387-2927
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030

47B		
Original Part Number	**Part Name**	**Classic Part Number**
2S-2430	Thrower-Chsft O	380-7543
2S-3966	Ring-Seal	297-7237
2S-7264	Pump As-Fuel Inj	395-1318
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
4H-7496	Plate-Pump Seal	420-6217
4L-8473	Plate-Wear	419-0883
4M-4431	Shaft-Pump Dr	390-0994
4M-9214	Shaft-Pump Drive	314-8543
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4N-3664	Guide-Valve	314-8524
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
5B-9169	Plug-Drain	419-4736

47B		
Original Part Number	**Part Name**	**Classic Part Number**
5F-8651	Bearing-Ball	420-3223
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9738	Coupling-Exhaust	311-9380
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-8974	Gasket Kit - Wp	387-2912
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6H-5845	Baffle-Oil	390-0926
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-2460	Pump Gp-Eng Oil	395-1316

Sales Model D353D (Cont'd.)

47B		
Original Part Number	**Part Name**	**Classic Part Number**
6N-6969	Chamber As	247-3299
6V-2202	Bearing-Spl Ball	380-1574
6V-2936	Gasket Kt-V G	387-2915
7H-6967	Bearing-Ball	422-6489
7L-2041	Shaft-Water Pump	428-7200
7L-7508	Bearing-Ball	420-6536
7L-8240	Bellows	419-4741
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-4515	Body As-Piston	311-9346
7N-7639	Rotator-Valve	383-1582

47B		
Original Part Number	**Part Name**	**Classic Part Number**
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-2275	Bearing-Sleeve	311-9365
8N-3451	Line As-Fuel Inj	390-0927
8N-3452	Line As-Fuel Inj	390-0928

47B		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3453	Line As-Fuel Inj	390-0940
8N-3454	Line As-Fuel Inj	390-0930
8N-3455	Line As-Fuel Inj	390-0920
8N-3723	Valve-Exhaust	311-9472
8S-3617	Chamber As	247-3302
9H-2256	Pump Gp-F Prm	311-9443
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
125-2728	Core As	395-1302
162-3904	Pump As-F Prm	391-1102
214-6045	Bellows As	435-4846

Sales Model D353E

46B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1N-4317	Bearing-Main	419-7253
1N-4336	Bearing-Conn Rod	419-6329
1N-4337	Bearing-Conn Rod	419-6328
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1S-8607	Baffle	380-7540
1W-1822	Valve-Exhaust	443-1205
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-6440	Gasket-Cyl Head	449-9548
1W-8606	Valve-Inlet	443-1204
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-2330	Bearing-Sleeve	452-9554

46B		
Original Part Number	**Part Name**	**Classic Part Number**
2H-3069	Lifter As-Valve	387-2927
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2S-2430	Thrower-Chsft O	380-7543
2S-3966	Ring-Seal	297-7237
2S-7264	Pump As-Fuel Inj	395-1318
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3L-1425	Bearing-Ball	311-9356
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4M-4431	Shaft-Pump Dr	390-0994
4M-9214	Shaft-Pump Drive	314-8543

46B		
Original Part Number	**Part Name**	**Classic Part Number**
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4N-3664	Guide-Valve	314-8524
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
5B-9169	Plug-Drain	419-4736
5F-7404	Nut-Bearing Lock	308-9878
5F-8651	Bearing-Ball	420-3223
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380

Sales Model D353E (Cont'd.)

46B		
Original Part Number	Part Name	Classic Part Number
5M-6211	Shaft-Planet	219-9684
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-8974	Gasket Kit - Wp	387-2912
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6H-5845	Baffle-Oil	390-0926
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-1813	Pump Gp-Bft 1 Gr	330-9279
6N-2460	Pump Gp-Eng Oil	395-1316
6N-6969	Chamber As	247-3299
6N-9654	Core As-Oil Clr	435-4787
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173

46B		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6V-2936	Gasket Kt-V G	387-2915
7H-6967	Bearing-Ball	422-6489
7L-2041	Shaft-Water Pump	428-7200
7L-7508	Bearing-Ball	420-6536
7L-8240	Bellows	419-4741
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342

46B		
Original Part Number	Part Name	Classic Part Number
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-2275	Bearing-Sleeve	311-9365
8N-3451	Line As-Fuel Inj	390-0927
8N-3452	Line As-Fuel Inj	390-0928
8N-3453	Line As-Fuel Inj	390-0940
8N-3454	Line As-Fuel Inj	390-0930
8N-3455	Line As-Fuel Inj	390-0920
8N-3723	Valve-Exhaust	311-9472
8S-3617	Chamber As	247-3302
9H-2256	Pump Gp-F Prm	311-9443
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
124-3237	Precleaner As	432-4220
125-2728	Core As	395-1302
162-3904	Pump As-F Prm	391-1102
214-6045	Bellows As	435-4846

47B		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1N-4317	Bearing-Main	419-7253
1N-4336	Bearing-Conn Rod	419-6329
1N-4337	Bearing-Conn Rod	419-6328
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1S-8607	Baffle	380-7540
1W-1822	Valve-Exhaust	443-1205
1W-3062	Retainer As	311-9445

47B		
Original Part Number	Part Name	Classic Part Number
1W-5105	Ring Gp-Piston	311-9446
1W-6440	Gasket-Cyl Head	449-9548
1W-8606	Valve-Inlet	443-1204
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-2330	Bearing-Sleeve	452-9554
2H-3069	Lifter As-Valve	387-2927
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2S-2430	Thrower-Chsft O	380-7543

47B		
Original Part Number	Part Name	Classic Part Number
2S-3966	Ring-Seal	297-7237
2S-7264	Pump As-Fuel Inj	395-1318
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
4H-7496	Plate-Pump Seal	420-6217
4L-8473	Plate-Wear	419-0883
4M-4431	Shaft-Pump Dr	390-0994

Sales Model D353E (Cont'd.)

47B		
Original Part Number	Part Name	Classic Part Number
4M-9214	Shaft-Pump Drive	314-8543
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4N-3664	Guide-Valve	314-8524
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9738	Coupling-Exhaust	311-9380
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-8974	Gasket Kit - Wp	387-2912
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358

47B		
Original Part Number	Part Name	Classic Part Number
6H-5845	Baffle-Oil	390-0926
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-2460	Pump Gp-Eng Oil	395-1316
6N-6969	Chamber As	247-3299
6V-2202	Bearing-Spl Ball	380-1574
6V-2936	Gasket Kt-V G	387-2915
7H-6967	Bearing-Ball	422-6489
7L-2041	Shaft-Water Pump	428-7200
7L-7508	Bearing-Ball	420-6536
7L-8240	Bellows	419-4741
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-4515	Body As-Piston	311-9346
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300
7W-2731	Retainer	423-3541

47B		
Original Part Number	Part Name	Classic Part Number
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-2275	Bearing-Sleeve	311-9365
8N-3451	Line As-Fuel Inj	390-0927
8N-3452	Line As-Fuel Inj	390-0928
8N-3453	Line As-Fuel Inj	390-0940
8N-3454	Line As-Fuel Inj	390-0930
8N-3455	Line As-Fuel Inj	390-0920
8N-3723	Valve-Exhaust	311-9472
8S-3617	Chamber As	247-3302
9H-2256	Pump Gp-F Prm	311-9443
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
125-2728	Core As	395-1302
162-3904	Pump As-F Prm	391-1102
214-6045	Bellows As	435-4846

77B		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1N-4317	Bearing-Main	419-7253
1N-4336	Bearing-Conn Rod	419-6329
1N-4337	Bearing-Conn Rod	419-6328
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1S-8607	Baffle	380-7540
1W-1822	Valve-Exhaust	443-1205
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446

77B		
Original Part Number	Part Name	Classic Part Number
1W-6440	Gasket-Cyl Head	449-9548
1W-8606	Valve-Inlet	443-1204
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-2330	Bearing-Sleeve	452-9554
2H-3069	Lifter As-Valve	387-2927
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2S-2430	Thrower-Chsft O	380-7543

77B		
Original Part Number	Part Name	Classic Part Number
2S-3966	Ring-Seal	297-7237
2S-7264	Pump As-Fuel Inj	395-1318
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3N-3368	Pipe-Exhaust	311-9434
4L-8473	Plate-Wear	419-0883
4M-4431	Shaft-Pump Dr	390-0994
4M-9214	Shaft-Pump Drive	314-8543
4M-9215	Gear-Pump Idler	311-9391

Sales Model D353E (Cont'd.)

77B		
Original Part Number	Part Name	Classic Part Number
4M-9216	Gear-Pump Drive	311-9390
4N-3664	Guide-Valve	314-8524
5B-9169	Plug-Drain	419-4736
5F-7404	Nut-Bearing Lock	308-9878
5F-8651	Bearing-Ball	420-3223
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9738	Coupling-Exhaust	311-9380
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-8974	Gasket Kit - Wp	387-2912
5S-1757	Insert-Seat	311-9401
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6H-5845	Baffle-Oil	390-0926
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951

77B		
Original Part Number	Part Name	Classic Part Number
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-2460	Pump Gp-Eng Oil	395-1316
6N-6969	Chamber As	247-3299
6V-2202	Bearing-Spl Ball	380-1574
6V-2936	Gasket Kt-V G	387-2915
7H-6967	Bearing-Ball	422-6489
7L-2041	Shaft-Water Pump	428-7200
7L-7508	Bearing-Ball	420-6536
7L-8240	Bellows	419-4741
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541

77B		
Original Part Number	Part Name	Classic Part Number
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8M-0874	Plunger As-Valve	311-9439
8N-2275	Bearing-Sleeve	311-9365
8N-3451	Line As-Fuel Inj	390-0927
8N-3452	Line As-Fuel Inj	390-0928
8N-3453	Line As-Fuel Inj	390-0940
8N-3454	Line As-Fuel Inj	390-0930
8N-3455	Line As-Fuel Inj	390-0920
8N-3723	Valve-Exhaust	311-9472
8S-3617	Chamber As	247-3302
9H-2256	Pump Gp-F Prm	311-9443
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
125-2728	Core As	395-1302
162-3904	Pump As-F Prm	391-1102
214-6045	Bellows As	435-4846

Sales Model D364

19B		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3H-0881	Ring-Piston	465-8998

19B		
Original Part Number	Part Name	Classic Part Number
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665

19B		
Original Part Number	Part Name	Classic Part Number
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541

Sales Model D364 (Cont'd.)

19B		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539

19B		
Original Part Number	Part Name	Classic Part Number
8F-6058	Bearing-Sleeve	416-5494
8H-1994	Valve-Exhaust	443-1206

19B		
Original Part Number	Part Name	Classic Part Number
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866

20B		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2H-6489	Race-Brg Outer	374-8350
2S-8884	Ring-Piston	465-8995
3F-3049	Cone-Roller Brg	418-9600
3H-0881	Ring-Piston	465-8998
4B-7270	Cone-Bearing	399-4439
4M-9183	Bearing-Sleeve	386-4924

20B		
Original Part Number	Part Name	Classic Part Number
4N-3875	Ring-Piston	465-8997
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-3223	Cup-Bearing	399-6065
6H-3957	Bearing-Ball	311-9358
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489

20B		
Original Part Number	Part Name	Classic Part Number
7M-4926	Retainer-Piston	314-8538
7S-7809	Cap As-Radiator	295-6417
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
9L-2685	Rod End	419-1866

21B		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1B-3978	Cup-Roller Brg	399-4437
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3H-0881	Ring-Piston	465-8998
4M-9183	Bearing-Sleeve	386-4924

21B		
Original Part Number	Part Name	Classic Part Number
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348

21B		
Original Part Number	Part Name	Classic Part Number
7M-4926	Retainer-Piston	314-8538
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-1994	Valve-Exhaust	443-1206
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866

Sales Model D375

16B		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167

16B		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
2A-4429	Lock-Retainer	379-0174

16B		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628

Sales Model D375 (Cont'd.)

16B		
Original Part Number	**Part Name**	**Classic Part Number**
2F-5721	Bearing-Ball	311-9354
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3H-0881	Ring-Piston	465-8998
4H-7496	Plate-Pump Seal	420-6217
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555

16B		
Original Part Number	**Part Name**	**Classic Part Number**
5P-7807	Bearing-Ball	314-8502
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348

16B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4926	Retainer-Piston	314-8538
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-1994	Valve-Exhaust	443-1206
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866

17B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3F-3049	Cone-Roller Brg	418-9600
3H-0881	Ring-Piston	465-8998
4B-7270	Cone-Bearing	399-4439
4H-7496	Plate-Pump Seal	420-6217
4M-9183	Bearing-Sleeve	386-4924

17B		
Original Part Number	**Part Name**	**Classic Part Number**
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348

17B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4926	Retainer-Piston	314-8538
7S-7809	Cap As-Radiator	295-6417
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-1994	Valve-Exhaust	443-1206
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866

18B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1B-3978	Cup-Roller Brg	399-4437
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2S-8884	Ring-Piston	465-8995

18B		
Original Part Number	**Part Name**	**Classic Part Number**
3B-1142	Retainer-Spring	391-1099
3H-0881	Ring-Piston	465-8998
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223

18B		
Original Part Number	**Part Name**	**Classic Part Number**
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489

Sales Model D375 (Cont'd.)

18B		
Original Part Number	Part Name	Classic Part Number
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7S-7809	Cap As-Radiator	295-6417

18B		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494

18B		
Original Part Number	Part Name	Classic Part Number
8H-1994	Valve-Exhaust	443-1206
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866

Sales Model D375D

43B		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1B-3978	Cup-Roller Brg	399-4437
1P-7115	Mount As	418-1936
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2L-6744	Plunger	426-0030
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3H-0881	Ring-Piston	465-8998
3L-1425	Bearing-Ball	311-9356
4H-7496	Plate-Pump Seal	420-6217
4M-9183	Bearing-Sleeve	386-4924

43B		
Original Part Number	Part Name	Classic Part Number
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-9371	Connector-Inlet	311-9375
5P-7807	Bearing-Ball	314-8502
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574

43B		
Original Part Number	Part Name	Classic Part Number
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-1994	Valve-Exhaust	443-1206
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
124-3237	Precleaner As	432-4220

44B		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-6744	Plunger	426-0030
2S-8884	Ring-Piston	465-8995

44B		
Original Part Number	Part Name	Classic Part Number
3B-1142	Retainer-Spring	391-1099
3F-3049	Cone-Roller Brg	418-9600
3H-0881	Ring-Piston	465-8998
4B-7270	Cone-Bearing	399-4439
4H-7496	Plate-Pump Seal	420-6217

44B		
Original Part Number	Part Name	Classic Part Number
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467

Sales Model D375D (Cont'd.)

44B		
Original Part Number	**Part Name**	**Classic Part Number**
5S-1211	Cover-Valve	314-8665
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489

44B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8B-5972	Bearing-Ball	314-8503

44B		
Original Part Number	**Part Name**	**Classic Part Number**
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-1994	Valve-Exhaust	443-1206
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

Sales Model D379B

34Z		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1P-0009	Rod As-Conn	311-9450
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1W-1822	Valve-Exhaust	443-1205
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-7080	Kit-Pump (Rbd)	392-4515
1W-8606	Valve-Inlet	443-1204
1W-9205	Line As-Fuel Inj	311-9415
1W-9206	Line As-Fuel Inj	311-9416
1W-9207	Line As-Fuel Inj	311-9417
1W-9208	Line As-Fuel Inj	311-9418
1W-9209	Line As-Fuel Inj	311-9419
1W-9210	Line As-Fuel Inj	311-9420
1W-9211	Line As-Fuel Inj	311-9421
1W-9212	Line As-Fuel Inj	311-9422
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305

34Z		
Original Part Number	**Part Name**	**Classic Part Number**
2N-3236	Gasket-Man Exh	415-1900
2N-3386	Support-Shield	419-1863
2N-5693	Gasket-Aftclr	438-2019
2N-7242	Tube As	444-5677
2P-1757	Hub-Fan Pulley	296-1357
2S-3966	Ring-Seal	297-7237
2S-5100	Valve-Ball	386-3049
2S-7264	Pump As-Fuel Inj	395-1318
2W-6250	Support	422-7897
2W-7176	Shaft-Fp Dr	432-8906
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
3N-2078	Pump Gp-Fuel Tfr	311-9444
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3N-6841	Tube As-Inlet Rh	311-9464
3N-7326	Thrower-Cshft O	311-9458
3N-7327	Thrower-Cshft O	311-9459
3N-8463	Bearing-Roller	394-9193
3N-9160	Ring-Cshft Seal	311-9447

34Z		
Original Part Number	**Part Name**	**Classic Part Number**
3S-9466	Bearing-Sleeve	314-8509
4H-7496	Plate-Pump Seal	420-6217
4L-3437	Gasket	420-8572
4L-3756	Bearing-Thrust	311-9366
4L-4653	Plate-Thrust	311-9440
4L-6706	Gasket	421-1028
4M-6107	Bearing-Roller	380-7507
4M-9215	Gear-Pump Idler	311-9391
4N-3339	Spider As.	419-0891
4N-3664	Guide-Valve	314-8524
4N-6302	Belt Set-Vee	314-8495
4W-2566	Adapter-Seal	383-1573
4W-2567	Adapter-Seal	383-1574
4W-2606	Seal Gp-Cshft -A	311-9452
4W-2607	Seal Gp-Cshft -A	311-9453
4W-5550	Core As-Oclr	311-9377
5B-9169	Plug-Drain	419-4736
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5L-2093	Gasket	393-3619
5L-2648	Bearing-Sleeve	311-9362
5L-2660	Bearing-Sleeve	311-9363
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854

Sales Model D379B (Cont'd.)

34Z		
Original Part Number	Part Name	Classic Part Number
5L-8856	Coupling-Exhaust	311-9379
5L-9370	Elbow-Man Inlet	311-9388
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5N-1841	Flange-Pipe	426-0029
5N-2902	Seal-Oil	314-8540
5N-4378	Shaft As-Pump	311-9456
5N-4504	Plate-Port	397-5048
5N-6165	Bearing	425-3587
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
5S-4557	Bearing	311-9360
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-6481	Elbow-Air Inlet	311-9385
6L-6490	Sleeve-O-Ring	398-8346
6L-7751	Rod End-Spher	472-8015

34Z		
Original Part Number	Part Name	Classic Part Number
6L-7816	Seal-O-Ring	314-8542
6L-8761	Sleeve-O-Ring	396-7268
6L-8968	Coupling-Exhaust	311-9381
6N-0597	Pulley-Fan	420-6391
6V-3736	Gasket Kt-Instl	438-0157
6V-3737	Gasket Kt-Lines	438-0171
6V-3743	Kit-Gasket Pump	438-0169
6V-5465	Gasket Kt	438-0166
7L-0103	Impeller-Pump	398-2967
7L-0104	Impeller-Pump	311-9395
7L-8240	Bellows	419-4741
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-2063	Shaft As-Pump	386-3055
7N-4515	Body As-Piston	311-9346
7N-7639	Rotator-Valve	383-1582
7N-8828	Pulley	420-6395
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300
7S-7809	Cap As-Radiator	295-6417

34Z		
Original Part Number	Part Name	Classic Part Number
7W-2731	Retainer	423-3541
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-3972	Baffle	311-9345
8M-0874	Plunger As-Valve	311-9439
8N-1365	Gear-Drive	394-8222
8N-2275	Bearing-Sleeve	311-9365
8N-3248	Gasket As	415-1893
8N-3723	Valve-Exhaust	311-9472
8N-7764	Bearing-Main	419-6310
8N-7765	Bearing-Main	419-7269
8N-7766	Bearing-Main	419-7270
8N-7771	Bearing-Conn Rod	419-7272
8S-3617	Chamber As	247-3302
8T-0209	Race-Spl Rlr Brg	384-5951
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
108-1760	Bearing-Ball	417-9493
214-6045	Bellows As	435-4846
255-6863	Gasket	450-5024

68B		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1P-0009	Rod As-Conn	311-9450
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1W-1822	Valve-Exhaust	443-1205
1W-1877	Gear As-Idler	426-0027
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-7080	Kit-Pump (Rbd)	392-4515
1W-8606	Valve-Inlet	443-1204
1W-9205	Line As-Fuel Inj	311-9415

68B		
Original Part Number	Part Name	Classic Part Number
1W-9206	Line As-Fuel Inj	311-9416
1W-9207	Line As-Fuel Inj	311-9417
1W-9208	Line As-Fuel Inj	311-9418
1W-9209	Line As-Fuel Inj	311-9419
1W-9210	Line As-Fuel Inj	311-9420
1W-9211	Line As-Fuel Inj	311-9421
1W-9212	Line As-Fuel Inj	311-9422
2A-4429	Lock-Retainer	379-0174

68B		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2L-4444	Bearing	419-6029
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-3236	Gasket-Man Exh	415-1900
2N-3386	Support-Shield	419-1863
2N-5693	Gasket-Aftclr	438-2019
2N-7242	Tube As	444-5677
2P-1757	Hub-Fan Pulley	296-1357
2S-3966	Ring-Seal	297-7237

Sales Model D379B (Cont'd.)

68B		
Original Part Number	Part Name	Classic Part Number
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-7264	Pump As-Fuel Inj	395-1318
2W-6250	Support	422-7897
2W-7176	Shaft-Fp & Gov Dr	432-8906
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
3N-2078	Pump Gp-Fuel Tfr	311-9444
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3N-6841	Tube As-Inlet Rh	311-9464
3N-7326	Thrower-Cshft O	311-9458
3N-7327	Thrower-Cshft O	311-9459
3N-8463	Bearing-Roller	394-9193
3N-9160	Ring-Cshft Seal	311-9447
3S-1723	Kit-Gasket (Wp)	438-0178
3S-9466	Bearing-Sleeve	314-8509
4H-7496	Plate-Pump Seal	420-6217
4L-3437	Gasket	420-8572
4L-3756	Bearing-Thrust	311-9366
4L-4653	Plate-Thrust	311-9440
4L-6706	Gasket	421-1028
4M-6107	Bearing-Roller	380-7507
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4N-3339	Spider As.	419-0891
4N-3664	Guide-Valve	314-8524
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-6302	Belt Set-Vee	314-8495

68B		
Original Part Number	Part Name	Classic Part Number
4W-2541	Shaft-Gov Cont	399-8580
4W-2566	Adapter-Seal	383-1573
4W-2567	Adapter-Seal	383-1574
4W-2606	Seal Gp-Cshft -A	311-9452
4W-2607	Seal Gp-Cshft -A	311-9453
4W-5550	Core As-Oclr	311-9377
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161
5F-8651	Bearing-Ball	420-3223
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5L-2093	Gasket	393-3619
5L-2648	Bearing-Sleeve	311-9362
5L-2660	Bearing-Sleeve	311-9363
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9370	Elbow-Man Inlet	311-9388
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5N-1841	Flange-Pipe	426-0029
5N-2902	Seal-Oil	314-8540
5N-4378	Shaft As-Pump	311-9456
5N-4504	Plate-Port	397-5048
5N-6165	Bearing	425-3587
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
5S-4557	Bearing	311-9360
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739

68B		
Original Part Number	Part Name	Classic Part Number
6L-3353	Rod End-Special	416-2134
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-6481	Elbow-Air Inlet	311-9385
6L-6490	Sleeve-O-Ring	398-8346
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8761	Sleeve-O-Ring	396-7268
6L-8968	Coupling-Exhaust	311-9381
6N-0597	Pulley-Fan	420-6391
6V-2202	Bearing-Spl Ball	380-1574
6V-3736	Gasket Kt-Instl	438-0157
6V-3737	Gasket Kt-Lines	438-0171
6V-3743	Kit-Gasket Pump	438-0169
6V-5426	Kit-Gasket-Wp	438-0167
6V-5428	Kit-Gasket-Ocl	386-3044
6V-5465	Gasket Kt	438-0166
6V-5467	Gasket Kt-F Sys	387-2924
6V-5468	Kit-Gasket	438-0165
7H-6967	Bearing-Ball	422-6489
7L-0103	Impeller-Pump	398-2967
7L-0104	Impeller-Pump	311-9395
7L-8240	Bellows	419-4741
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-2063	Shaft As-Pump	386-3055
7N-4515	Body As-Piston	311-9346
7N-7639	Rotator-Valve	383-1582
7N-8828	Pulley	420-6395
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503

Sales Model D379B (Cont'd.)

68B		
Original Part Number	**Part Name**	**Classic Part Number**
8D-0983	Mounting	384-3470
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-3972	Baffle	311-9345
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-1365	Gear-Drive	394-8222
8N-2275	Bearing-Sleeve	311-9365

68B		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3248	Gasket As	415-1893
8N-3723	Valve-Exhaust	311-9472
8N-7764	Bearing-Main	419-6310
8N-7765	Bearing-Main	419-7269
8N-7766	Bearing-Main	419-7270
8N-7771	Bearing-Conn Rod	419-7272
8N-7773	Bearing-Conn Rod	419-7274
8S-3617	Chamber As	247-3302
8T-0209	Race-Spl Rlr Brg	384-5951

68B		
Original Part Number	**Part Name**	**Classic Part Number**
9H-2256	Pump Gp-F Prm	311-9443
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
214-6045	Bellows As	435-4846
255-6863	Gasket	450-5024

69B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-9252	Rod End-Yoke	377-5849
1P-0009	Rod As-Conn	311-9450
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1W-1822	Valve-Exhaust	443-1205
1W-1877	Gear As-Idler	426-0027
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-7080	Kit-Pump (Rbd)	392-4515
1W-8606	Valve-Inlet	443-1204
1W-9205	Line As-Fuel Inj	311-9415
1W-9206	Line As-Fuel Inj	311-9416
1W-9207	Line As-Fuel Inj	311-9417
1W-9208	Line As-Fuel Inj	311-9418
1W-9209	Line As-Fuel Inj	311-9419
1W-9210	Line As-Fuel Inj	311-9420
1W-9211	Line As-Fuel Inj	311-9421
1W-9212	Line As-Fuel Inj	311-9422
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354

69B		
Original Part Number	**Part Name**	**Classic Part Number**
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-3236	Gasket-Man Exh	415-1900
2N-3386	Support-Shield	419-1863
2N-5693	Gasket-Aftclr	438-2019
2N-7242	Tube As	444-5677
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-7264	Pump As-Fuel Inj	395-1318
2W-7176	Shaft-Fp & Gov Dr	432-8906
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3J-2903	Cover	422-6922
3N-2078	Pump Gp-Fuel Tfr	311-9444
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3N-6841	Tube As-Inlet Rh	311-9464
3N-7326	Thrower-Cshft O	311-9458
3N-7327	Thrower-Cshft O	311-9459
3N-8463	Bearing-Roller	394-9193

69B		
Original Part Number	**Part Name**	**Classic Part Number**
3N-9160	Ring-Cshft Seal	311-9447
3S-1723	Kit-Gasket (Wp)	438-0178
3S-9466	Bearing-Sleeve	314-8509
4B-7270	Cone-Bearing	399-4439
4H-7496	Plate-Pump Seal	420-6217
4L-3437	Gasket	420-8572
4L-3756	Bearing-Thrust	311-9366
4L-4653	Plate-Thrust	311-9440
4L-6706	Gasket	421-1028
4M-6107	Bearing-Roller	380-7507
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4N-3664	Guide-Valve	314-8524
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
4W-2566	Adapter-Seal	383-1573
4W-2567	Adapter-Seal	383-1574
4W-2606	Seal Gp-Cshft -A	311-9452
4W-2607	Seal Gp-Cshft -A	311-9453
4W-5550	Core As-Oclr	311-9377
5B-9169	Plug-Drain	419-4736

Sales Model D379B (Cont'd.)

69B		
Original Part Number	Part Name	Classic Part Number
5F-8651	Bearing-Ball	420-3223
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5L-2093	Gasket	393-3619
5L-2648	Bearing-Sleeve	311-9362
5L-2660	Bearing-Sleeve	311-9363
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9370	Elbow-Man Inlet	311-9388
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5N-1841	Flange-Pipe	426-0029
5N-2902	Seal-Oil	314-8540
5N-4378	Shaft As-Pump	311-9456
5N-4504	Plate-Port	397-5048
5N-6165	Bearing	425-3587
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
5S-4557	Bearing	311-9360
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739

69B		
Original Part Number	Part Name	Classic Part Number
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-6481	Elbow-Air Inlet	311-9385
6L-6490	Sleeve-O-Ring	398-8346
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8761	Sleeve-O-Ring	396-7268
6L-8968	Coupling-Exhaust	311-9381
6V-3736	Gasket Kt-Instl	438-0157
6V-3737	Gasket Kt-Lines	438-0171
6V-3743	Kit-Gasket Pump	438-0169
6V-5426	Kit-Gasket-Wp	438-0167
6V-5428	Kit-Gasket-Ocl	386-3044
6V-5465	Gasket Kt	438-0166
6V-5468	Kit-Gasket	438-0165
6V-5495	Gasket Kt-Exp Tk	393-5211
7L-0103	Impeller-Pump	398-2967
7L-0104	Impeller-Pump	311-9395
7L-8240	Bellows	419-4741
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-2063	Shaft As-Pump	386-3055
7N-4515	Body As-Piston	311-9346

69B		
Original Part Number	Part Name	Classic Part Number
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8L-3972	Baffle	311-9345
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-1365	Gear-Drive	394-8222
8N-2275	Bearing-Sleeve	311-9365
8N-3723	Valve-Exhaust	311-9472
8N-7764	Bearing-Main	419-6310
8N-7765	Bearing-Main	419-7269
8N-7766	Bearing-Main	419-7270
8N-7771	Bearing-Conn Rod	419-7272
8N-7773	Bearing-Conn Rod	419-7274
8S-3617	Chamber As	247-3302
8T-0209	Race-Spl Rlr Brg	384-5951
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
214-6045	Bellows As	435-4846
255-6863	Gasket	450-5024

76B		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1P-0009	Rod As-Conn	311-9450
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1W-1822	Valve-Exhaust	443-1205
1W-1877	Gear As-Idler	426-0027

76B		
Original Part Number	Part Name	Classic Part Number
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-7080	Kit-Pump (Rbd)	392-4515
1W-8606	Valve-Inlet	443-1204
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2L-4444	Bearing	419-6029

76B		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-3236	Gasket-Man Exh	415-1900
2N-5693	Gasket-Aftclr	438-2019
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-7264	Pump As-Fuel Inj	395-1318

Sales Model D379B (Cont'd.)

76B		
Original Part Number	Part Name	Classic Part Number
2W-7176	Shaft-Fp & Gov Dr	432-8906
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3N-7326	Thrower-Cshft O	311-9458
3N-7327	Thrower-Cshft O	311-9459
3N-9160	Ring-Cshft Seal	311-9447
3S-1723	Kit-Gasket (Wp)	438-0178
4H-7496	Plate-Pump Seal	420-6217
4L-3437	Gasket	420-8572
4L-3756	Bearing-Thrust	311-9366
4L-4653	Plate-Thrust	311-9440
4L-6706	Gasket	421-1028
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4N-3664	Guide-Valve	314-8524
4W-5550	Core As-Oclr	311-9377
5B-9169	Plug-Drain	419-4736
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5L-2093	Gasket	393-3619
5L-2648	Bearing-Sleeve	311-9362
5L-2660	Bearing-Sleeve	311-9363
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854

76B		
Original Part Number	Part Name	Classic Part Number
5L-8856	Coupling-Exhaust	311-9379
5L-9370	Elbow-Man Inlet	311-9388
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5N-1841	Flange-Pipe	426-0029
5N-4378	Shaft As-Pump	311-9456
5N-6165	Bearing	425-3587
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
5S-4557	Bearing	311-9360
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-6481	Elbow-Air Inlet	311-9385
6L-6490	Sleeve-O-Ring	398-8346
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8761	Sleeve-O-Ring	396-7268
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
6V-3736	Gasket Kt-Instl	438-0157
6V-3737	Gasket Kt-Lines	438-0171
6V-5426	Kit-Gasket-Wp	438-0167
6V-5465	Gasket Kt	438-0166
7H-6967	Bearing-Ball	422-6489

76B		
Original Part Number	Part Name	Classic Part Number
7L-0103	Impeller-Pump	398-2967
7L-0104	Impeller-Pump	311-9395
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-4515	Body As-Piston	311-9346
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8L-3972	Baffle	311-9345
8N-1365	Gear-Drive	394-8222
8N-2275	Bearing-Sleeve	311-9365
8N-3723	Valve-Exhaust	311-9472
8N-7764	Bearing-Main	419-6310
8N-7765	Bearing-Main	419-7269
8N-7766	Bearing-Main	419-7270
8N-7771	Bearing-Conn Rod	419-7272
8S-3617	Chamber As	247-3302
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
214-6045	Bellows As	435-4846
255-6863	Gasket	450-5024

Sales Model D379A

68B		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167

Sales Model D379A (Cont'd.)

68B		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1P-0009	Rod As-Conn	311-9450
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1W-1822	Valve-Exhaust	443-1205
1W-1877	Gear As-Idler	426-0027
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-7080	Kit-Pump (Rbd)	392-4515
1W-8606	Valve-Inlet	443-1204
1W-9205	Line As-Fuel Inj	311-9415
1W-9206	Line As-Fuel Inj	311-9416
1W-9207	Line As-Fuel Inj	311-9417
1W-9208	Line As-Fuel Inj	311-9418
1W-9209	Line As-Fuel Inj	311-9419
1W-9210	Line As-Fuel Inj	311-9420
1W-9211	Line As-Fuel Inj	311-9421
1W-9212	Line As-Fuel Inj	311-9422
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2L-4444	Bearing	419-6029
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-3236	Gasket-Man Exh	415-1900
2N-3386	Support-Shield	419-1863
2N-5693	Gasket-Aftclr	438-2019
2N-7242	Tube As	444-5677
2P-1757	Hub-Fan Pulley	296-1357
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-7264	Pump As-Fuel Inj	395-1318
2W-6250	Support	422-7897

68B		
Original Part Number	Part Name	Classic Part Number
2W-7176	Shaft-Fp & Gov Dr	432-8906
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
3N-2078	Pump Gp-Fuel Tfr	311-9444
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3N-6841	Tube As-Inlet Rh	311-9464
3N-7326	Thrower-Cshft O	311-9458
3N-7327	Thrower-Cshft O	311-9459
3N-8463	Bearing-Roller	394-9193
3N-9160	Ring-Cshft Seal	311-9447
3S-1723	Kit-Gasket (Wp)	438-0178
3S-9466	Bearing-Sleeve	314-8509
4H-7496	Plate-Pump Seal	420-6217
4L-3437	Gasket	420-8572
4L-3756	Bearing-Thrust	311-9366
4L-4653	Plate-Thrust	311-9440
4L-6706	Gasket	421-1028
4M-6107	Bearing-Roller	380-7507
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4N-3339	Spider As.	419-0891
4N-3664	Guide-Valve	314-8524
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-6302	Belt Set-Vee	314-8495
4W-2541	Shaft-Gov Cont	399-8580
4W-2566	Adapter-Seal	383-1573
4W-2567	Adapter-Seal	383-1574
4W-2606	Seal Gp-Cshft -A	311-9452
4W-2607	Seal Gp-Cshft -A	311-9453

68B		
Original Part Number	Part Name	Classic Part Number
4W-5550	Core As-Oclr	311-9377
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161
5F-8651	Bearing-Ball	420-3223
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5L-2093	Gasket	393-3619
5L-2648	Bearing-Sleeve	311-9362
5L-2660	Bearing-Sleeve	311-9363
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9370	Elbow-Man Inlet	311-9388
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5N-1841	Flange-Pipe	426-0029
5N-2902	Seal-Oil	314-8540
5N-4378	Shaft As-Pump	311-9456
5N-4504	Plate-Port	397-5048
5N-6165	Bearing	425-3587
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
5S-4557	Bearing	311-9360
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6L-3353	Rod End-Special	416-2134
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-6481	Elbow-Air Inlet	311-9385

Sales Model D379A (Cont'd.)

68B		
Original Part Number	**Part Name**	**Classic Part Number**
6L-6490	Sleeve-O-Ring	398-8346
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8761	Sleeve-O-Ring	396-7268
6L-8968	Coupling-Exhaust	311-9381
6N-0597	Pulley-Fan	420-6391
6V-2202	Bearing-Spl Ball	380-1574
6V-3736	Gasket Kt-Instl	438-0157
6V-3737	Gasket Kt-Lines	438-0171
6V-3743	Kit-Gasket Pump	438-0169
6V-5426	Kit-Gasket-Wp	438-0167
6V-5428	Kit-Gasket-Ocl	386-3044
6V-5465	Gasket Kt	438-0166
6V-5467	Gasket Kt-F Sys	387-2924
6V-5468	Kit-Gasket	438-0165
7H-6967	Bearing-Ball	422-6489
7L-0103	Impeller-Pump	398-2967
7L-0104	Impeller-Pump	311-9395
7L-8240	Bellows	419-4741
7M-4603	Body-Fuel Valve	311-9348

68B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-2063	Shaft As-Pump	386-3055
7N-4515	Body As-Piston	311-9346
7N-7639	Rotator-Valve	383-1582
7N-8828	Pulley	420-6395
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8D-0983	Mounting	384-3470
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8L-3972	Baffle	311-9345
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-1365	Gear-Drive	394-8222

68B		
Original Part Number	**Part Name**	**Classic Part Number**
8N-2275	Bearing-Sleeve	311-9365
8N-3248	Gasket As	415-1893
8N-3723	Valve-Exhaust	311-9472
8N-7764	Bearing-Main	419-6310
8N-7765	Bearing-Main	419-7269
8N-7766	Bearing-Main	419-7270
8N-7771	Bearing-Conn Rod	419-7272
8N-7773	Bearing-Conn Rod	419-7274
8S-3617	Chamber As	247-3302
8T-0209	Race-Spl Rlr Brg	384-5951
9H-2256	Pump Gp-F Prm	311-9443
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
214-6045	Bellows As	435-4846
255-6863	Gasket	450-5024

69B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-9252	Rod End-Yoke	377-5849
1P-0009	Rod As-Conn	311-9450
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1W-1822	Valve-Exhaust	443-1205
1W-1877	Gear As-Idler	426-0027
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-7080	Kit-Pump (Rbd)	392-4515
1W-8606	Valve-Inlet	443-1204
1W-9205	Line As-Fuel Inj	311-9415
1W-9206	Line As-Fuel Inj	311-9416

69B		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9207	Line As-Fuel Inj	311-9417
1W-9208	Line As-Fuel Inj	311-9418
1W-9209	Line As-Fuel Inj	311-9419
1W-9210	Line As-Fuel Inj	311-9420
1W-9211	Line As-Fuel Inj	311-9421
1W-9212	Line As-Fuel Inj	311-9422
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030

69B		
Original Part Number	**Part Name**	**Classic Part Number**
2N-3236	Gasket-Man Exh	415-1900
2N-3386	Support-Shield	419-1863
2N-5693	Gasket-Aftclr	438-2019
2N-7242	Tube As	444-5677
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-7264	Pump As-Fuel Inj	395-1318
2W-7176	Shaft-Fp & Gov Dr	432-8906
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992

Sales Model D379A (Cont'd.)

69B		
Original Part Number	Part Name	Classic Part Number
3J-2903	Cover	422-6922
3N-2078	Pump Gp-Fuel Tfr	311-9444
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3N-6841	Tube As-Inlet Rh	311-9464
3N-7326	Thrower-Cshft O	311-9458
3N-7327	Thrower-Cshft O	311-9459
3N-8463	Bearing-Roller	394-9193
3N-9160	Ring-Cshft Seal	311-9447
3S-1723	Kit-Gasket (Wp)	438-0178
3S-9466	Bearing-Sleeve	314-8509
4B-7270	Cone-Bearing	399-4439
4H-7496	Plate-Pump Seal	420-6217
4L-3437	Gasket	420-8572
4L-3756	Bearing-Thrust	311-9366
4L-4653	Plate-Thrust	311-9440
4L-6706	Gasket	421-1028
4M-6107	Bearing-Roller	380-7507
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4N-3664	Guide-Valve	314-8524
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
4W-2566	Adapter-Seal	383-1573
4W-2567	Adapter-Seal	383-1574
4W-2606	Seal Gp-Cshft -A	311-9452
4W-2607	Seal Gp-Cshft -A	311-9453
4W-5550	Core As-Oclr	311-9377
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5L-2093	Gasket	393-3619

69B		
Original Part Number	Part Name	Classic Part Number
5L-2648	Bearing-Sleeve	311-9362
5L-2660	Bearing-Sleeve	311-9363
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9370	Elbow-Man Inlet	311-9388
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5N-1841	Flange-Pipe	426-0029
5N-2902	Seal-Oil	314-8540
5N-4378	Shaft As-Pump	311-9456
5N-4504	Plate-Port	397-5048
5N-6165	Bearing	425-3587
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
5S-4557	Bearing	311-9360
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-6481	Elbow-Air Inlet	311-9385
6L-6490	Sleeve-O-Ring	398-8346
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8761	Sleeve-O-Ring	396-7268
6L-8968	Coupling-Exhaust	311-9381
6V-3736	Gasket Kt-Instl	438-0157
6V-3737	Gasket Kt-Lines	438-0171
6V-3743	Kit-Gasket Pump	438-0169
6V-5426	Kit-Gasket-Wp	438-0167
6V-5428	Kit-Gasket-Ocl	386-3044
6V-5465	Gasket Kt	438-0166
6V-5468	Kit-Gasket	438-0165

69B		
Original Part Number	Part Name	Classic Part Number
6V-5495	Gasket Kt-Exp Tk	393-5211
7L-0103	Impeller-Pump	398-2967
7L-0104	Impeller-Pump	311-9395
7L-8240	Bellows	419-4741
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-2063	Shaft As-Pump	386-3055
7N-4515	Body As-Piston	311-9346
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8L-3972	Baffle	311-9345
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-1365	Gear-Drive	394-8222
8N-2275	Bearing-Sleeve	311-9365
8N-3723	Valve-Exhaust	311-9472
8N-7764	Bearing-Main	419-6310
8N-7765	Bearing-Main	419-7269
8N-7766	Bearing-Main	419-7270
8N-7771	Bearing-Conn Rod	419-7272
8N-7773	Bearing-Conn Rod	419-7274
8S-3617	Chamber As	247-3302
8T-0209	Race-Spl Rlr Brg	384-5951
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
214-6045	Bellows As	435-4846
255-6863	Gasket	450-5024

Sales Model D386

13B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3E-6772	Seal-Water	382-8017
3H-0881	Ring-Piston	465-8998
4M-9183	Bearing-Sleeve	386-4924
4N-0685	Bearing-Sleeve	379-0191
4N-3875	Ring-Piston	465-8997
4N-6658	Bearing-Sleeve	373-1885
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555

13B		
Original Part Number	**Part Name**	**Classic Part Number**
5P-7807	Bearing-Ball	314-8502
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538

13B		
Original Part Number	**Part Name**	**Classic Part Number**
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
7W-5733	Gasket	421-7333
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-1994	Valve-Exhaust	443-1206
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866
131-7123	Bearing-Sleeve	422-6919
155-5619	Gasket	382-5054
166-9142	Gasket	420-8546
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665

14B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3F-3049	Cone-Roller Brg	418-9600
3H-0881	Ring-Piston	465-8998
4B-7270	Cone-Bearing	399-4439
4H-7496	Plate-Pump Seal	420-6217
4M-9183	Bearing-Sleeve	386-4924

14B		
Original Part Number	**Part Name**	**Classic Part Number**
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348

15B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368

14B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4926	Retainer-Piston	314-8538
7S-7809	Cap As-Radiator	295-6417
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-1994	Valve-Exhaust	443-1206
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866

Sales Model D386 (Cont'd.)

15B		
Original Part Number	Part Name	Classic Part Number
1S-1970	Chamber As	247-3292
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2S-4015	Plunger As-Valve	311-9438
2S-8884	Ring-Piston	465-8995
3H-0881	Ring-Piston	465-8998
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736

15B		
Original Part Number	Part Name	Classic Part Number
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6H-3957	Bearing-Ball	311-9358
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816

15B		
Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As-Radiator	295-6417
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866

Sales Model D397

10B		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3H-0881	Ring-Piston	465-8998
4H-7496	Plate-Pump Seal	420-6217
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997

10B		
Original Part Number	Part Name	Classic Part Number
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-9371	Connector-Inlet	311-9375
5P-7807	Bearing-Ball	314-8502
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6V-2202	Bearing-Spl Ball	380-1574

10B		
Original Part Number	Part Name	Classic Part Number
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-1994	Valve-Exhaust	443-1206
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866

11B		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2S-8884	Ring-Piston	465-8995

11B		
Original Part Number	Part Name	Classic Part Number
3B-1142	Retainer-Spring	391-1099
3F-3049	Cone-Roller Brg	418-9600
3H-0881	Ring-Piston	465-8998
4B-7270	Cone-Bearing	399-4439
4H-7496	Plate-Pump Seal	420-6217

11B		
Original Part Number	Part Name	Classic Part Number
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502

Sales Model D397 (Cont'd.)

11B		
Original Part Number	**Part Name**	**Classic Part Number**
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6V-2202	Bearing-Spl Ball	380-1574

11B		
Original Part Number	**Part Name**	**Classic Part Number**
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7S-7809	Cap As-Radiator	295-6417
8B-5972	Bearing-Ball	314-8503

11B		
Original Part Number	**Part Name**	**Classic Part Number**
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-1994	Valve-Exhaust	443-1206
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866

12B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3H-0881	Ring-Piston	465-8998
4H-7496	Plate-Pump Seal	420-6217
4M-9183	Bearing-Sleeve	386-4924

12B		
Original Part Number	**Part Name**	**Classic Part Number**
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348

12B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4926	Retainer-Piston	314-8538
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-1994	Valve-Exhaust	443-1206
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866

Sales Model D398

34J		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-9252	Rod End-Yoke	377-5849
1P-0009	Rod As-Conn	311-9450
1W-1822	Valve-Exhaust	443-1205
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-8606	Valve-Inlet	443-1204
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438

34J		
Original Part Number	**Part Name**	**Classic Part Number**
2S-7264	Pump As-Fuel Inj	395-1318
2W-7176	Shaft-Fp & Gov Dr	432-8906
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3N-3368	Pipe-Exhaust	311-9434
3N-7326	Thrower-Cshft O	311-9458
3N-7327	Thrower-Cshft O	311-9459

34J		
Original Part Number	**Part Name**	**Classic Part Number**
3N-9160	Ring-Cshft Seal	311-9447
4L-3437	Gasket	420-8572
4L-3756	Bearing-Thrust	311-9366
4L-4653	Plate-Thrust	311-9440
4L-6706	Gasket	421-1028
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4N-3664	Guide-Valve	314-8524
5H-5553	Screw-Tappet Adj	311-9451

Sales Model D398 (Cont'd.)

34J		
Original Part Number	**Part Name**	**Classic Part Number**
5H-7071	Director-Water	388-0555
5L-2093	Gasket	393-3619
5L-2648	Bearing-Sleeve	311-9362
5L-2660	Bearing-Sleeve	311-9363
5L-9738	Coupling-Exhaust	311-9380
5N-4378	Shaft As-Pump	311-9456
5N-6165	Bearing	425-3587
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
6B-6224	Ferrule	419-4738

34J		
Original Part Number	**Part Name**	**Classic Part Number**
6L-4714	Panel-Acl Filter	314-8532
6L-7816	Seal-O-Ring	314-8542
7L-0103	Impeller-Pump	398-2967
7L-0104	Impeller-Pump	311-9395
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7817	Valve-Inlet	311-9474
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300

34J		
Original Part Number	**Part Name**	**Classic Part Number**
8L-3972	Baffle	311-9345
8N-1365	Gear-Drive	394-8222
8N-2275	Bearing-Sleeve	311-9365
8N-3723	Valve-Exhaust	311-9472
8N-7764	Bearing-Main	419-6310
8N-7765	Bearing-Main	419-7269
8N-7766	Bearing-Main	419-7270
8N-7771	Bearing-Conn Rod	419-7272
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402

Sales Model D397D

41B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1P-7115	Mount As	418-1936
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2L-4238	Mount-Flexible	385-7222
2L-4444	Bearing	419-6029
2L-6744	Plunger	426-0030
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3H-0881	Ring-Piston	465-8998
4H-7496	Plate-Pump Seal	420-6217
4M-9183	Bearing-Sleeve	386-4924

41B		
Original Part Number	**Part Name**	**Classic Part Number**
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-9371	Connector-Inlet	311-9375
5P-7807	Bearing-Ball	314-8502
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348

41B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4926	Retainer-Piston	314-8538
7N-7639	Rotator-Valve	383-1582
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-1994	Valve-Exhaust	443-1206
8H-4320	Bearing-Ball	419-2301
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
124-3237	Precleaner As	432-4220

42B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167

Sales Model D397D (Cont'd.)

42B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-6744	Plunger	426-0030
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3F-3049	Cone-Roller Brg	418-9600
3H-0881	Ring-Piston	465-8998
4B-7270	Cone-Bearing	399-4439
4H-7496	Plate-Pump Seal	420-6217
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997

42B		
Original Part Number	**Part Name**	**Classic Part Number**
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6L-7816	Seal-O-Ring	314-8542
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348

42B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4926	Retainer-Piston	314-8538
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-1994	Valve-Exhaust	443-1206
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

Sales Model D398A

66B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-9252	Rod End-Yoke	377-5849
1P-0009	Rod As-Conn	311-9450
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1W-1822	Valve-Exhaust	443-1205
1W-1877	Gear As-Idler	426-0027
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-6356	Gasket	438-1795
1W-7080	Kit-Pump (Rbd)	392-4515
1W-8606	Valve-Inlet	443-1204
1W-9201	Line As-Fuel Inj	311-9411
1W-9202	Line As-Fuel Inj	311-9412
1W-9203	Line As-Fuel Inj	311-9413
1W-9204	Line As-Fuel Inj	311-9414
1W-9205	Line As-Fuel Inj	311-9415

66B		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9206	Line As-Fuel Inj	311-9416
1W-9207	Line As-Fuel Inj	311-9417
1W-9208	Line As-Fuel Inj	311-9418
1W-9209	Line As-Fuel Inj	311-9419
1W-9210	Line As-Fuel Inj	311-9420
1W-9211	Line As-Fuel Inj	311-9421
1W-9212	Line As-Fuel Inj	311-9422
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2L-4444	Bearing	419-6029
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-3236	Gasket-Man Exh	415-1900

66B		
Original Part Number	**Part Name**	**Classic Part Number**
2N-3386	Support-Shield	419-1863
2N-5693	Gasket-Aftclr	438-2019
2N-7242	Tube As	444-5677
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-7264	Pump As-Fuel Inj	395-1318
2W-6250	Support	422-7897
2W-7176	Shaft-Fp & Gov Dr	432-8906
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3J-2903	Cover	422-6922
3N-2078	Pump Gp-Fuel Tfr	311-9444
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3N-6841	Tube As-Inlet Rh	311-9464

Sales Model D398A (Cont'd.)

66B		
Original Part Number	Part Name	Classic Part Number
3N-7326	Thrower-Cshft O	311-9458
3N-7327	Thrower-Cshft O	311-9459
3N-8463	Bearing-Roller	394-9193
3N-9160	Ring-Cshft Seal	311-9447
3S-1723	Kit-Gasket (Wp)	438-0178
3S-9466	Bearing-Sleeve	314-8509
4H-7496	Plate-Pump Seal	420-6217
4L-3437	Gasket	420-8572
4L-3756	Bearing-Thrust	311-9366
4L-4653	Plate-Thrust	311-9440
4L-6706	Gasket	421-1028
4M-6107	Bearing-Roller	380-7507
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4N-3664	Guide-Valve	314-8524
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
4W-2566	Adapter-Seal	383-1573
4W-2567	Adapter-Seal	383-1574
4W-2606	Seal Gp-Cshft -A	311-9452
4W-2607	Seal Gp-Cshft -A	311-9453
4W-5549	Core As-Oclr	311-9376
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161
5F-8651	Bearing-Ball	420-3223
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5L-2093	Gasket	393-3619
5L-2648	Bearing-Sleeve	311-9362
5L-2660	Bearing-Sleeve	311-9363
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854

66B		
Original Part Number	Part Name	Classic Part Number
5L-8856	Coupling-Exhaust	311-9379
5L-9370	Elbow-Man Inlet	311-9388
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5N-1841	Flange-Pipe	426-0029
5N-2902	Seal-Oil	314-8540
5N-3274	Plate	425-3648
5N-4378	Shaft As-Pump	311-9456
5N-4504	Plate-Port	397-5048
5N-6165	Bearing	425-3587
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
5S-4557	Bearing	311-9360
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6L-3353	Rod End-Special	416-2134
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-6481	Elbow-Air Inlet	311-9385
6L-6490	Sleeve-O-Ring	398-8346
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8761	Sleeve-O-Ring	396-7268
6L-8968	Coupling-Exhaust	311-9381
6N-6969	Chamber As	247-3299
6V-2202	Bearing-Spl Ball	380-1574
6V-3736	Gasket Kt-Instl	438-0157
6V-3737	Gasket Kt-Lines	438-0171
6V-3749	Gasket Kt	387-2916
6V-5426	Kit-Gasket-Wp	438-0167

66B		
Original Part Number	Part Name	Classic Part Number
6V-5428	Kit-Gasket-Ocl	386-3044
6V-5465	Gasket Kt	438-0166
6V-5467	Gasket Kt-F Sys	387-2924
6V-5468	Kit-Gasket	438-0165
6V-6384	Kit-Gasket-Wp	387-2917
6V-6385	Kit-Gasket (Wp)	438-0161
6V-7266	Gasket Kt-Head	393-5212
7H-6967	Bearing-Ball	422-6489
7L-0103	Impeller-Pump	398-2967
7L-0104	Impeller-Pump	311-9395
7L-8240	Bellows	419-4741
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-2063	Shaft As-Pump	386-3055
7N-4515	Body As-Piston	311-9346
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8L-3972	Baffle	311-9345
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-1365	Gear-Drive	394-8222
8N-2275	Bearing-Sleeve	311-9365
8N-3723	Valve-Exhaust	311-9472
8N-7764	Bearing-Main	419-6310
8N-7765	Bearing-Main	419-7269
8N-7766	Bearing-Main	419-7270
8N-7771	Bearing-Conn Rod	419-7272

Sales Model D398A (Cont'd.)

66B		
Original Part Number	**Part Name**	**Classic Part Number**
8N-7773	Bearing-Conn Rod	419-7274
8S-3617	Chamber As	247-3302
8T-0209	Race-Spl Rlr Brg	384-5951

66B		
Original Part Number	**Part Name**	**Classic Part Number**
9H-2256	Pump Gp-F Prm	311-9443
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866

66B		
Original Part Number	**Part Name**	**Classic Part Number**
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
207-1332	Bellows As	444-0569
214-6045	Bellows As	435-4846
255-6863	Gasket	450-5024

67B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-9252	Rod End-Yoke	377-5849
1P-0009	Rod As-Conn	311-9450
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1W-1822	Valve-Exhaust	443-1205
1W-1877	Gear As-Idler	426-0027
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-6356	Gasket	438-1795
1W-7080	Kit-Pump (Rbd)	392-4515
1W-8606	Valve-Inlet	443-1204
1W-9201	Line As-Fuel Inj	311-9411
1W-9202	Line As-Fuel Inj	311-9412
1W-9203	Line As-Fuel Inj	311-9413
1W-9204	Line As-Fuel Inj	311-9414
1W-9205	Line As-Fuel Inj	311-9415
1W-9206	Line As-Fuel Inj	311-9416
1W-9207	Line As-Fuel Inj	311-9417
1W-9208	Line As-Fuel Inj	311-9418
1W-9209	Line As-Fuel Inj	311-9419
1W-9210	Line As-Fuel Inj	311-9420
1W-9211	Line As-Fuel Inj	311-9421
1W-9212	Line As-Fuel Inj	311-9422
2A-4429	Lock-Retainer	379-0174

67B		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-3236	Gasket-Man Exh	415-1900
2N-3386	Support-Shield	419-1863
2N-5693	Gasket-Aftclr	438-2019
2N-7242	Tube As	444-5677
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-7264	Pump As-Fuel Inj	395-1318
2W-7176	Shaft-Fp & Gov Dr	432-8906
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3J-2903	Cover	422-6922
3N-2078	Pump Gp-Fuel Tfr	311-9444
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3N-6841	Tube As-Inlet Rh	311-9464
3N-7326	Thrower-Cshft O	311-9458
3N-7327	Thrower-Cshft O	311-9459
3N-8463	Bearing-Roller	394-9193
3N-9160	Ring-Cshft Seal	311-9447
3S-1723	Kit-Gasket (Wp)	438-0178
3S-9466	Bearing-Sleeve	314-8509

67B		
Original Part Number	**Part Name**	**Classic Part Number**
4B-7270	Cone-Bearing	399-4439
4H-7496	Plate-Pump Seal	420-6217
4L-3437	Gasket	420-8572
4L-3756	Bearing-Thrust	311-9366
4L-4653	Plate-Thrust	311-9440
4L-6706	Gasket	421-1028
4M-6107	Bearing-Roller	380-7507
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4N-3664	Guide-Valve	314-8524
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
4W-2566	Adapter-Seal	383-1573
4W-2567	Adapter-Seal	383-1574
4W-2606	Seal Gp-Cshft -A	311-9452
4W-2607	Seal Gp-Cshft -A	311-9453
4W-5549	Core As-Oclr	311-9376
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5L-2093	Gasket	393-3619
5L-2648	Bearing-Sleeve	311-9362
5L-2660	Bearing-Sleeve	311-9363
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9370	Elbow-Man Inlet	311-9388

Sales Model D398A (Cont'd.)

67B		
Original Part Number	Part Name	Classic Part Number
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5N-1841	Flange-Pipe	426-0029
5N-2902	Seal-Oil	314-8540
5N-3274	Plate	425-3648
5N-4378	Shaft As-Pump	311-9456
5N-4504	Plate-Port	397-5048
5N-6165	Bearing	425-3587
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-6481	Elbow-Air Inlet	311-9385
6L-6490	Sleeve-O-Ring	398-8346
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8761	Sleeve-O-Ring	396-7268
6L-8968	Coupling-Exhaust	311-9381
6V-3736	Gasket Kt-Instl	438-0157

67B		
Original Part Number	Part Name	Classic Part Number
6V-3737	Gasket Kt-Lines	438-0171
6V-3743	Kit-Gasket Pump	438-0169
6V-3749	Gasket Kt	387-2916
6V-5426	Kit-Gasket-Wp	438-0167
6V-5428	Kit-Gasket-Ocl	386-3044
6V-5465	Gasket Kt	438-0166
6V-5468	Kit-Gasket	438-0165
6V-5495	Gasket Kt-Exp Tk	393-5211
6V-6375	Gasket Kt-Lines	438-0162
6V-7266	Gasket Kt-Head	393-5212
7L-0103	Impeller-Pump	398-2967
7L-0104	Impeller-Pump	311-9395
7L-8240	Bellows	419-4741
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-2063	Shaft As-Pump	386-3055
7N-4515	Body As-Piston	311-9346
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300
7S-7809	Cap As-Radiator	295-6417

67B		
Original Part Number	Part Name	Classic Part Number
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8L-3972	Baffle	311-9345
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-1365	Gear-Drive	394-8222
8N-2275	Bearing-Sleeve	311-9365
8N-3723	Valve-Exhaust	311-9472
8N-7764	Bearing-Main	419-6310
8N-7765	Bearing-Main	419-7269
8N-7766	Bearing-Main	419-7270
8N-7771	Bearing-Conn Rod	419-7272
8N-7773	Bearing-Conn Rod	419-7274
8S-3617	Chamber As	247-3302
8T-0209	Race-Spl Rlr Brg	384-5951
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
207-1332	Bellows As	444-0569
214-6045	Bellows As	435-4846

Sales Model D398B

35Z		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1P-0009	Rod As-Conn	311-9450
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1W-1822	Valve-Exhaust	443-1205
1W-1877	Gear As-Idler	426-0027
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446

35Z		
Original Part Number	Part Name	Classic Part Number
1W-6356	Gasket	438-1795
1W-7080	Kit-Pump (Rbd)	392-4515
1W-8606	Valve-Inlet	443-1204
1W-9201	Line As-Fuel Inj	311-9411
1W-9202	Line As-Fuel Inj	311-9412
1W-9203	Line As-Fuel Inj	311-9413

35Z		
Original Part Number	Part Name	Classic Part Number
1W-9204	Line As-Fuel Inj	311-9414
1W-9205	Line As-Fuel Inj	311-9415
1W-9206	Line As-Fuel Inj	311-9416
1W-9207	Line As-Fuel Inj	311-9417
1W-9208	Line As-Fuel Inj	311-9418

Sales Model D398B (Cont'd.)

35Z		
Original Part Number	Part Name	Classic Part Number
1W-9209	Line As-Fuel Inj	311-9419
1W-9210	Line As-Fuel Inj	311-9420
1W-9211	Line As-Fuel Inj	311-9421
1W-9212	Line As-Fuel Inj	311-9422
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-3236	Gasket-Man Exh	415-1900
2N-3386	Support-Shield	419-1863
2N-5693	Gasket-Aftclr	438-2019
2N-7242	Tube As	444-5677
2S-3966	Ring-Seal	297-7237
2S-5100	Valve-Ball	386-3049
2S-7264	Pump As-Fuel Inj	395-1318
2W-6250	Support	422-7897
2W-7176	Shaft-Fp & Gov Dr	432-8906
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3J-2903	Cover	422-6922
3N-2078	Pump Gp-Fuel Tfr	311-9444
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3N-6841	Tube As-Inlet Rh	311-9464
3N-7326	Thrower-Cshft O	311-9458
3N-7327	Thrower-Cshft O	311-9459
3N-8463	Bearing-Roller	394-9193
3N-9160	Ring-Cshft Seal	311-9447
3S-9466	Bearing-Sleeve	314-8509
4H-7496	Plate-Pump Seal	420-6217

35Z		
Original Part Number	Part Name	Classic Part Number
4L-3437	Gasket	420-8572
4L-3756	Bearing-Thrust	311-9366
4L-4653	Plate-Thrust	311-9440
4L-6706	Gasket	421-1028
4M-6107	Bearing-Roller	380-7507
4M-9215	Gear-Pump Idler	311-9391
4N-3664	Guide-Valve	314-8524
4W-2566	Adapter-Seal	383-1573
4W-2567	Adapter-Seal	383-1574
4W-2606	Seal Gp-Cshft -A	311-9452
4W-2607	Seal Gp-Cshft -A	311-9453
4W-5549	Core As-Oclr	311-9376
5B-9169	Plug-Drain	419-4736
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5L-2093	Gasket	393-3619
5L-2648	Bearing-Sleeve	311-9362
5L-2660	Bearing-Sleeve	311-9363
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9370	Elbow-Man Inlet	311-9388
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5N-1841	Flange-Pipe	426-0029
5N-2902	Seal-Oil	314-8540
5N-3274	Plate	425-3648
5N-4378	Shaft As-Pump	311-9456
5N-4504	Plate-Port	397-5048
5N-6165	Bearing	425-3587
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
5S-4557	Bearing	311-9360
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739

35Z		
Original Part Number	Part Name	Classic Part Number
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-6481	Elbow-Air Inlet	311-9385
6L-6490	Sleeve-O-Ring	398-8346
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8761	Sleeve-O-Ring	396-7268
6L-8968	Coupling-Exhaust	311-9381
6V-3736	Gasket Kt-Instl	438-0157
6V-3737	Gasket Kt-Lines	438-0171
6V-3743	Kit-Gasket Pump	438-0169
6V-3749	Gasket Kt	387-2916
6V-5465	Gasket Kt	438-0166
7L-0103	Impeller-Pump	398-2967
7L-0104	Impeller-Pump	311-9395
7L-8240	Bellows	419-4741
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-2063	Shaft As-Pump	386-3055
7N-4515	Body As-Piston	311-9346
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8L-3972	Baffle	311-9345
8M-0874	Plunger As-Valve	311-9439
8N-1365	Gear-Drive	394-8222
8N-2275	Bearing-Sleeve	311-9365
8N-3723	Valve-Exhaust	311-9472
8N-7764	Bearing-Main	419-6310
8N-7765	Bearing-Main	419-7269
8N-7766	Bearing-Main	419-7270

Sales Model D398B (Cont'd.)

35Z		
Original Part Number	**Part Name**	**Classic Part Number**
8N-7771	Bearing-Conn Rod	419-7272
8S-3617	Chamber As	247-3302
8T-0209	Race-Spl Rlr Brg	384-5951

35Z		
Original Part Number	**Part Name**	**Classic Part Number**
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
108-1760	Bearing-Ball	417-9493

35Z		
Original Part Number	**Part Name**	**Classic Part Number**
207-1332	Bellows As	444-0569
214-6045	Bellows As	435-4846

66B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-9252	Rod End-Yoke	377-5849
1P-0009	Rod As-Conn	311-9450
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1W-1822	Valve-Exhaust	443-1205
1W-1877	Gear As-Idler	426-0027
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-6356	Gasket	438-1795
1W-7080	Kit-Pump (Rbd)	392-4515
1W-8606	Valve-Inlet	443-1204
1W-9201	Line As-Fuel Inj	311-9411
1W-9202	Line As-Fuel Inj	311-9412
1W-9203	Line As-Fuel Inj	311-9413
1W-9204	Line As-Fuel Inj	311-9414
1W-9205	Line As-Fuel Inj	311-9415
1W-9206	Line As-Fuel Inj	311-9416
1W-9207	Line As-Fuel Inj	311-9417
1W-9208	Line As-Fuel Inj	311-9418
1W-9209	Line As-Fuel Inj	311-9419
1W-9210	Line As-Fuel Inj	311-9420
1W-9211	Line As-Fuel Inj	311-9421
1W-9212	Line As-Fuel Inj	311-9422
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

66B		
Original Part Number	**Part Name**	**Classic Part Number**
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2L-4444	Bearing	419-6029
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-3236	Gasket-Man Exh	415-1900
2N-3386	Support-Shield	419-1863
2N-5693	Gasket-Aftclr	438-2019
2N-7242	Tube As	444-5677
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-7264	Pump As-Fuel Inj	395-1318
2W-6250	Support	422-7897
2W-7176	Shaft-Fp & Gov Dr	432-8906
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3J-2903	Cover	422-6922
3N-2078	Pump Gp-Fuel Tfr	311-9444
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3N-6841	Tube As-Inlet Rh	311-9464
3N-7326	Thrower-Cshft O	311-9458
3N-7327	Thrower-Cshft O	311-9459
3N-8463	Bearing-Roller	394-9193
3N-9160	Ring-Cshft Seal	311-9447
3S-1723	Kit-Gasket (Wp)	438-0178

66B		
Original Part Number	**Part Name**	**Classic Part Number**
3S-9466	Bearing-Sleeve	314-8509
4H-7496	Plate-Pump Seal	420-6217
4L-3437	Gasket	420-8572
4L-3756	Bearing-Thrust	311-9366
4L-4653	Plate-Thrust	311-9440
4L-6706	Gasket	421-1028
4M-6107	Bearing-Roller	380-7507
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4N-3664	Guide-Valve	314-8524
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
4W-2566	Adapter-Seal	383-1573
4W-2567	Adapter-Seal	383-1574
4W-2606	Seal Gp-Cshft -A	311-9452
4W-2607	Seal Gp-Cshft -A	311-9453
4W-5549	Core As-Oclr	311-9376
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161
5F-8651	Bearing-Ball	420-3223
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5L-2093	Gasket	393-3619
5L-2648	Bearing-Sleeve	311-9362
5L-2660	Bearing-Sleeve	311-9363
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854

Sales Model D398B (Cont'd.)

66B		
Original Part Number	Part Name	Classic Part Number
5L-8856	Coupling-Exhaust	311-9379
5L-9370	Elbow-Man Inlet	311-9388
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5N-1841	Flange-Pipe	426-0029
5N-2902	Seal-Oil	314-8540
5N-3274	Plate	425-3648
5N-4378	Shaft As-Pump	311-9456
5N-4504	Plate-Port	397-5048
5N-6165	Bearing	425-3587
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
5S-4557	Bearing	311-9360
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6L-3353	Rod End-Special	416-2134
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-6481	Elbow-Air Inlet	311-9385
6L-6490	Sleeve-O-Ring	398-8346
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542

66B		
Original Part Number	Part Name	Classic Part Number
6L-8761	Sleeve-O-Ring	396-7268
6L-8968	Coupling-Exhaust	311-9381
6N-6969	Chamber As	247-3299
6V-2202	Bearing-Spl Ball	380-1574
6V-3736	Gasket Kt-Instl	438-0157
6V-3737	Gasket Kt-Lines	438-0171
6V-3749	Gasket Kt	387-2916
6V-5426	Kit-Gasket-Wp	438-0167
6V-5428	Kit-Gasket-Ocl	386-3044
6V-5465	Gasket Kt	438-0166
6V-5467	Gasket Kt-F Sys	387-2924
6V-5468	Kit-Gasket	438-0165
6V-6384	Kit-Gasket-Wp	387-2917
6V-6385	Kit-Gasket (Wp)	438-0161
6V-7266	Gasket Kt-Head	393-5212
7H-6967	Bearing-Ball	422-6489
7L-0103	Impeller-Pump	398-2967
7L-0104	Impeller-Pump	311-9395
7L-8240	Bellows	419-4741
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-2063	Shaft As-Pump	386-3055
7N-4515	Body As-Piston	311-9346
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300

66B		
Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8L-3972	Baffle	311-9345
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-1365	Gear-Drive	394-8222
8N-2275	Bearing-Sleeve	311-9365
8N-3723	Valve-Exhaust	311-9472
8N-7764	Bearing-Main	419-6310
8N-7765	Bearing-Main	419-7269
8N-7766	Bearing-Main	419-7270
8N-7771	Bearing-Conn Rod	419-7272
8N-7773	Bearing-Conn Rod	419-7274
8S-3617	Chamber As	247-3302
8T-0209	Race-Spl Rlr Brg	384-5951
9H-2256	Pump Gp-F Prm	311-9443
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
207-1332	Bellows As	444-0569
214-6045	Bellows As	435-4846
255-6863	Gasket	450-5024

67B		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-9252	Rod End-Yoke	377-5849
1P-0009	Rod As-Conn	311-9450
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936

67B		
Original Part Number	Part Name	Classic Part Number
1W-1822	Valve-Exhaust	443-1205
1W-1877	Gear As-Idler	426-0027
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-6356	Gasket	438-1795
1W-7080	Kit-Pump (Rbd)	392-4515

67B		
Original Part Number	Part Name	Classic Part Number
1W-8606	Valve-Inlet	443-1204
1W-9201	Line As-Fuel Inj	311-9411
1W-9202	Line As-Fuel Inj	311-9412
1W-9203	Line As-Fuel Inj	311-9413

Sales Model D398B (Cont'd.)

67B		
Original Part Number	Part Name	Classic Part Number
1W-9204	Line As-Fuel Inj	311-9414
1W-9205	Line As-Fuel Inj	311-9415
1W-9206	Line As-Fuel Inj	311-9416
1W-9207	Line As-Fuel Inj	311-9417
1W-9208	Line As-Fuel Inj	311-9418
1W-9209	Line As-Fuel Inj	311-9419
1W-9210	Line As-Fuel Inj	311-9420
1W-9211	Line As-Fuel Inj	311-9421
1W-9212	Line As-Fuel Inj	311-9422
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-3236	Gasket-Man Exh	415-1900
2N-3386	Support-Shield	419-1863
2N-5693	Gasket-Aftclr	438-2019
2N-7242	Tube As	444-5677
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-7264	Pump As-Fuel Inj	395-1318
2W-7176	Shaft-Fp & Gov Dr	432-8906
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3J-2903	Cover	422-6922
3N-2078	Pump Gp-Fuel Tfr	311-9444
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3N-6841	Tube As-Inlet Rh	311-9464

67B		
Original Part Number	Part Name	Classic Part Number
3N-7326	Thrower-Cshft O	311-9458
3N-7327	Thrower-Cshft O	311-9459
3N-8463	Bearing-Roller	394-9193
3N-9160	Ring-Cshft Seal	311-9447
3S-1723	Kit-Gasket (Wp)	438-0178
3S-9466	Bearing-Sleeve	314-8509
4B-7270	Cone-Bearing	399-4439
4H-7496	Plate-Pump Seal	420-6217
4L-3437	Gasket	420-8572
4L-3756	Bearing-Thrust	311-9366
4L-4653	Plate-Thrust	311-9440
4L-6706	Gasket	421-1028
4M-6107	Bearing-Roller	380-7507
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4N-3664	Guide-Valve	314-8524
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
4W-2566	Adapter-Seal	383-1573
4W-2567	Adapter-Seal	383-1574
4W-2606	Seal Gp-Cshft -A	311-9452
4W-2607	Seal Gp-Cshft -A	311-9453
4W-5549	Core As-Oclr	311-9376
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5L-2093	Gasket	393-3619
5L-2648	Bearing-Sleeve	311-9362
5L-2660	Bearing-Sleeve	311-9363
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379

67B		
Original Part Number	Part Name	Classic Part Number
5L-9370	Elbow-Man Inlet	311-9388
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5N-1841	Flange-Pipe	426-0029
5N-2902	Seal-Oil	314-8540
5N-3274	Plate	425-3648
5N-4378	Shaft As-Pump	311-9456
5N-4504	Plate-Port	397-5048
5N-6165	Bearing	425-3587
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-6481	Elbow-Air Inlet	311-9385
6L-6490	Sleeve-O-Ring	398-8346
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8761	Sleeve-O-Ring	396-7268
6L-8968	Coupling-Exhaust	311-9381
6V-3736	Gasket Kt-Instl	438-0157
6V-3737	Gasket Kt-Lines	438-0171
6V-3743	Kit-Gasket Pump	438-0169
6V-3749	Gasket Kt	387-2916
6V-5426	Kit-Gasket-Wp	438-0167
6V-5428	Kit-Gasket-Ocl	386-3044
6V-5465	Gasket Kt	438-0166
6V-5468	Kit-Gasket	438-0165
6V-5495	Gasket Kt-Exp Tk	393-5211
6V-6375	Gasket Kt-Lines	438-0162
6V-7266	Gasket Kt-Head	393-5212
7L-0103	Impeller-Pump	398-2967

Sales Model D398B (Cont'd.)

67B		
Original Part Number	Part Name	Classic Part Number
7L-0104	Impeller-Pump	311-9395
7L-8240	Bellows	419-4741
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-2063	Shaft As-Pump	386-3055
7N-4515	Body As-Piston	311-9346
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300
7S-7809	Cap As-Radiator	295-6417

67B		
Original Part Number	Part Name	Classic Part Number
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8L-3972	Baffle	311-9345
8L-4282	Hub	444-0573
8M-0874	Plunger As-Valve	311-9439
8N-1365	Gear-Drive	394-8222
8N-2275	Bearing-Sleeve	311-9365
8N-3723	Valve-Exhaust	311-9472
8N-7764	Bearing-Main	419-6310
8N-7765	Bearing-Main	419-7269
8N-7766	Bearing-Main	419-7270
8N-7771	Bearing-Conn Rod	419-7272

67B		
Original Part Number	Part Name	Classic Part Number
8N-7773	Bearing-Conn Rod	419-7274
8S-3617	Chamber As	247-3302
8T-0209	Race-Spl Rlr Brg	384-5951
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
207-1332	Bellows As	444-0569
214-6045	Bellows As	435-4846

75B		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-9252	Rod End-Yoke	377-5849
1P-0009	Rod As-Conn	311-9450
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1W-1822	Valve-Exhaust	443-1205
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-7080	Kit-Pump (Rbd)	392-4515
1W-8606	Valve-Inlet	443-1204
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4444	Bearing	419-6029
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-3236	Gasket-Man Exh	415-1900
2N-5693	Gasket-Aftclr	438-2019
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-7264	Pump As-Fuel Inj	395-1318
2W-7176	Shaft-Fp & Gov Dr	432-8906

75B		
Original Part Number	Part Name	Classic Part Number
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3N-7326	Thrower-Cshft O	311-9458
3N-7327	Thrower-Cshft O	311-9459
3N-9160	Ring-Cshft Seal	311-9447
3S-1723	Kit-Gasket (Wp)	438-0178
4H-7496	Plate-Pump Seal	420-6217
4L-3437	Gasket	420-8572
4L-3756	Bearing-Thrust	311-9366
4L-4653	Plate-Thrust	311-9440
4L-6706	Gasket	421-1028
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4N-3664	Guide-Valve	314-8524
5B-9169	Plug-Drain	419-4736
5H-5553	Screw-Tappet Adj	311-9451

75B		
Original Part Number	Part Name	Classic Part Number
5H-7071	Director-Water	388-0555
5L-2093	Gasket	393-3619
5L-2648	Bearing-Sleeve	311-9362
5L-2660	Bearing-Sleeve	311-9363
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9370	Elbow-Man Inlet	311-9388
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5N-1841	Flange-Pipe	426-0029
5N-4378	Shaft As-Pump	311-9456
5N-6165	Bearing	425-3587
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
5S-4557	Bearing	311-9360
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532

Sales Model D398B (Cont'd.)

75B		
Original Part Number	Part Name	Classic Part Number
6L-4716	Gasket-Exhaust	398-2951
6L-6481	Elbow-Air Inlet	311-9385
6L-6490	Sleeve-O-Ring	398-8346
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8761	Sleeve-O-Ring	396-7268
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
6V-3736	Gasket Kt-Instl	438-0157
6V-3737	Gasket Kt-Lines	438-0171
6V-5426	Kit-Gasket-Wp	438-0167
6V-7266	Gasket Kt-Head	393-5212
7L-0103	Impeller-Pump	398-2967
7L-0104	Impeller-Pump	311-9395

75B		
Original Part Number	Part Name	Classic Part Number
7L-8240	Bellows	419-4741
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-4515	Body As-Piston	311-9346
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8L-3972	Baffle	311-9345

75B		
Original Part Number	Part Name	Classic Part Number
8N-1365	Gear-Drive	394-8222
8N-2275	Bearing-Sleeve	311-9365
8N-3723	Valve-Exhaust	311-9472
8N-7764	Bearing-Main	419-6310
8N-7765	Bearing-Main	419-7269
8N-7766	Bearing-Main	419-7270
8N-7771	Bearing-Conn Rod	419-7272
8S-3617	Chamber As	247-3302
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
214-6045	Bellows As	435-4846
255-6863	Gasket	450-5024

Sales Model D399

35B		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-9252	Rod End-Yoke	377-5849
1P-0009	Rod As-Conn	311-9450
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1W-1822	Valve-Exhaust	443-1205
1W-1877	Gear As-Idler	426-0027
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-6356	Gasket	438-1795
1W-7080	Kit-Pump (Rbd)	392-4515
1W-8606	Valve-Inlet	443-1204
1W-9191	Line As-Fuel Inj	311-9403
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030

35B		
Original Part Number	Part Name	Classic Part Number
2N-3236	Gasket-Man Exh	415-1900
2N-3386	Support-Shield	419-1863
2N-5693	Gasket-Aftclr	438-2019
2N-7242	Tube As	444-5677
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-7264	Pump As-Fuel Inj	395-1318
2W-6250	Support	422-7897
2W-7177	Shaft-Fp & Gov Dr	433-9215
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3J-2903	Cover	422-6922
3N-2078	Pump Gp-Fuel Tfr	311-9444

35B		
Original Part Number	Part Name	Classic Part Number
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3N-6841	Tube As-Inlet Rh	311-9464
3N-7326	Thrower-Cshft O	311-9458
3N-7327	Thrower-Cshft O	311-9459
3N-7702	Shaft-Pump Idler	428-7201
3N-8463	Bearing-Roller	394-9193
3N-9160	Ring-Cshft Seal	311-9447
3S-9466	Bearing-Sleeve	314-8509
4H-7496	Plate-Pump Seal	420-6217
4L-3437	Gasket	420-8572
4L-3756	Bearing-Thrust	311-9366
4L-4653	Plate-Thrust	311-9440
4L-6706	Gasket	421-1028

Sales Model D399 (Cont'd.)

35B		
Original Part Number	**Part Name**	**Classic Part Number**
4M-6107	Bearing-Roller	380-7507
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4N-3664	Guide-Valve	314-8524
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
4W-2566	Adapter-Seal	383-1573
4W-2567	Adapter-Seal	383-1574
4W-2606	Seal Gp-Cshft -A	311-9452
4W-2607	Seal Gp-Cshft -A	311-9453
5B-9169	Plug-Drain	419-4736
5D-0470	Valve Gp-Qrel	314-8549
5D-7449	Cup-Spl Tapered	416-2161
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5L-2093	Gasket	393-3619
5L-2648	Bearing-Sleeve	311-9362
5L-2660	Bearing-Sleeve	311-9363
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9370	Elbow-Man Inlet	311-9388
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5N-1841	Flange-Pipe	426-0029
5N-2902	Seal-Oil	314-8540
5N-3274	Plate	425-3648
5N-4378	Shaft As-Pump	311-9456
5N-4504	Plate-Port	397-5048

35B		
Original Part Number	**Part Name**	**Classic Part Number**
5N-6165	Bearing	425-3587
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
5S-4557	Bearing	311-9360
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-3353	Rod End-Special	416-2134
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-6481	Elbow-Air Inlet	311-9385
6L-6490	Sleeve-O-Ring	398-8346
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8761	Sleeve-O-Ring	396-7268
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
6V-3736	Gasket Kt-Instl	438-0157
6V-3737	Gasket Kt-Lines	438-0171
6V-3743	Kit-Gasket Pump	438-0169
6V-5428	Kit-Gasket-Ocl	386-3044
6V-5465	Gasket Kt	438-0166
6V-5468	Kit-Gasket	438-0165
6V-6384	Kit-Gasket-Wp	387-2917
6V-9259	Gasket Kt	393-5213
6V-9698	Gasket Kt-Pump	388-0647
7L-0103	Impeller-Pump	398-2967
7L-0104	Impeller-Pump	311-9395
7L-8240	Bellows	419-4741
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538

36Z		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167

35B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-2063	Shaft As-Pump	386-3055
7N-4515	Body As-Piston	311-9346
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8L-3972	Baffle	311-9345
8L-4282	Hub	444-0573
8L-5769	Shaft-Fan	439-1137
8M-0874	Plunger As-Valve	311-9439
8N-1365	Gear-Drive	394-8222
8N-2275	Bearing-Sleeve	311-9365
8N-3723	Valve-Exhaust	311-9472
8N-7764	Bearing-Main	419-6310
8N-7765	Bearing-Main	419-7269
8N-7766	Bearing-Main	419-7270
8N-7771	Bearing-Conn Rod	419-7272
8N-7773	Bearing-Conn Rod	419-7274
8S-1892	Gasket Kt-Wp	436-8398
8S-3617	Chamber As	247-3302
8T-0209	Race-Spl Rlr Brg	384-5951
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
207-1332	Bellows As	444-0569
214-6045	Bellows As	435-4846
255-6863	Gasket	450-5024

Sales Model D399 (Cont'd.)

36Z		
Original Part Number	Part Name	Classic Part Number
1P-0009	Rod As-Conn	311-9450
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1W-1822	Valve-Exhaust	443-1205
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-6356	Gasket	438-1795
1W-7080	Kit-Pump (Rbd)	392-4515
1W-8606	Valve-Inlet	443-1204
1W-9191	Line As-Fuel Inj	311-9403
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-3236	Gasket-Man Exh	415-1900
2N-3386	Support-Shield	419-1863
2N-5693	Gasket-Aftclr	438-2019
2N-7242	Tube As	444-5677
2S-3966	Ring-Seal	297-7237
2S-5100	Valve-Ball	386-3049
2S-7264	Pump As-Fuel Inj	395-1318
2W-6250	Support	422-7897
2W-7177	Shaft-Fp & Gov Dr	433-9215
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3J-2903	Cover	422-6922
3N-2078	Pump Gp-Fuel Tfr	311-9444
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3N-6841	Tube As-Inlet Rh	311-9464
3N-7326	Thrower-Cshft O	311-9458
3N-7327	Thrower-Cshft O	311-9459
3N-7702	Shaft-Pump Idler	428-7201
3N-8463	Bearing-Roller	394-9193
3N-9160	Ring-Cshft Seal	311-9447

36Z		
Original Part Number	Part Name	Classic Part Number
3S-9466	Bearing-Sleeve	314-8509
4H-7496	Plate-Pump Seal	420-6217
4L-3437	Gasket	420-8572
4L-3756	Bearing-Thrust	311-9366
4L-4653	Plate-Thrust	311-9440
4L-6706	Gasket	421-1028
4M-6107	Bearing-Roller	380-7507
4M-9215	Gear-Pump Idler	311-9391
4N-3664	Guide-Valve	314-8524
4W-2566	Adapter-Seal	383-1573
4W-2567	Adapter-Seal	383-1574
4W-2606	Seal Gp-Cshft -A	311-9452
4W-2607	Seal Gp-Cshft -A	311-9453
5B-9169	Plug-Drain	419-4736
5D-0470	Valve Gp-Qrel	314-8549
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5L-2093	Gasket	393-3619
5L-2648	Bearing-Sleeve	311-9362
5L-2660	Bearing-Sleeve	311-9363
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9370	Elbow-Man Inlet	311-9388
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5N-1841	Flange-Pipe	426-0029
5N-2902	Seal-Oil	314-8540
5N-3274	Plate	425-3648
5N-4378	Shaft As-Pump	311-9456
5N-4504	Plate-Port	397-5048
5N-6165	Bearing	425-3587
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-9514	Bearing-Ball	417-9467

36Z		
Original Part Number	Part Name	Classic Part Number
5S-1757	Insert-Seat	311-9401
5S-4557	Bearing	311-9360
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-6481	Elbow-Air Inlet	311-9385
6L-6490	Sleeve-O-Ring	398-8346
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8761	Sleeve-O-Ring	396-7268
6L-8968	Coupling-Exhaust	311-9381
6V-3736	Gasket Kt-Instl	438-0157
6V-3737	Gasket Kt-Lines	438-0171
6V-3743	Kit-Gasket Pump	438-0169
6V-3751	Gasket Kt-V G	393-5222
6V-5465	Gasket Kt	438-0166
7L-0103	Impeller-Pump	398-2967
7L-0104	Impeller-Pump	311-9395
7L-8240	Bellows	419-4741
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-2063	Shaft As-Pump	386-3055
7N-4515	Body As-Piston	311-9346
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8L-3972	Baffle	311-9345
8L-5769	Shaft-Fan	439-1137
8M-0874	Plunger As-Valve	311-9439
8N-1365	Gear-Drive	394-8222
8N-2275	Bearing-Sleeve	311-9365

Sales Model D399 (Cont'd.)

36Z		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3723	Valve-Exhaust	311-9472
8N-7764	Bearing-Main	419-6310
8N-7765	Bearing-Main	419-7269
8N-7766	Bearing-Main	419-7270
8N-7771	Bearing-Conn Rod	419-7272

36Z		
Original Part Number	**Part Name**	**Classic Part Number**
8S-3617	Chamber As	247-3302
8T-0209	Race-Spl Rlr Brg	384-5951
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

36Z		
Original Part Number	**Part Name**	**Classic Part Number**
102-1561	Lifter As-Valve	311-9402
207-1332	Bellows As	444-0569
214-6045	Bellows As	435-4846
255-6863	Gasket	450-5024

91B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-9252	Rod End-Yoke	377-5849
1P-0009	Rod As-Conn	311-9450
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1W-1822	Valve-Exhaust	443-1205
1W-1877	Gear As-Idler	426-0027
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-6356	Gasket	438-1795
1W-7080	Kit-Pump (Rbd)	392-4515
1W-8606	Valve-Inlet	443-1204
1W-9191	Line As-Fuel Inj	311-9403
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-3236	Gasket-Man Exh	415-1900
2N-3386	Support-Shield	419-1863
2N-5693	Gasket-Aftclr	438-2019
2N-7242	Tube As	444-5677
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-7264	Pump As-Fuel Inj	395-1318
2W-7177	Shaft-Fp & Gov Dr	433-9215
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992

91B		
Original Part Number	**Part Name**	**Classic Part Number**
3J-2903	Cover	422-6922
3N-2078	Pump Gp-Fuel Tfr	311-9444
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3N-6841	Tube As-Inlet Rh	311-9464
3N-7326	Thrower-Cshft O	311-9458
3N-7327	Thrower-Cshft O	311-9459
3N-7702	Shaft-Pump Idler	428-7201
3N-8463	Bearing-Roller	394-9193
3N-9160	Ring-Cshft Seal	311-9447
3S-9466	Bearing-Sleeve	314-8509
4B-7270	Cone-Bearing	399-4439
4H-7496	Plate-Pump Seal	420-6217
4L-3437	Gasket	420-8572
4L-3756	Bearing-Thrust	311-9366
4L-4653	Plate-Thrust	311-9440
4L-6706	Gasket	421-1028
4M-6107	Bearing-Roller	380-7507
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4N-3664	Guide-Valve	314-8524
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
4W-2566	Adapter-Seal	383-1573
4W-2567	Adapter-Seal	383-1574

91B		
Original Part Number	**Part Name**	**Classic Part Number**
4W-2606	Seal Gp-Cshft -A	311-9452
4W-2607	Seal Gp-Cshft -A	311-9453
5B-9169	Plug-Drain	419-4736
5D-0470	Valve Gp-Qrel	314-8549
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5L-2093	Gasket	393-3619
5L-2648	Bearing-Sleeve	311-9362
5L-2660	Bearing-Sleeve	311-9363
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9370	Elbow-Man Inlet	311-9388
5L-9371	Connector-Inlet	311-9375
5L-9738	Coupling-Exhaust	311-9380
5N-1841	Flange-Pipe	426-0029
5N-2902	Seal-Oil	314-8540
5N-3274	Plate	425-3648
5N-4378	Shaft As-Pump	311-9456
5N-4504	Plate-Port	397-5048
5N-6165	Bearing	425-3587
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739

Sales Model D399 (Cont'd.)

91B		
Original Part Number	Part Name	Classic Part Number
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-6481	Elbow-Air Inlet	311-9385
6L-6490	Sleeve-O-Ring	398-8346
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8761	Sleeve-O-Ring	396-7268
6L-8968	Coupling-Exhaust	311-9381
6V-3736	Gasket Kt-Instl	438-0157
6V-3737	Gasket Kt-Lines	438-0171
6V-5428	Kit-Gasket-Ocl	386-3044
6V-5465	Gasket Kt	438-0166
6V-5468	Kit-Gasket	438-0165
6V-5495	Gasket Kt-Exp Tk	393-5211
6V-6384	Kit-Gasket-Wp	387-2917
6V-9259	Gasket Kt	393-5213
6V-9698	Gasket Kt-Pump	388-0647

91B		
Original Part Number	Part Name	Classic Part Number
7L-0103	Impeller-Pump	398-2967
7L-0104	Impeller-Pump	311-9395
7L-8240	Bellows	419-4741
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-2063	Shaft As-Pump	386-3055
7N-4515	Body As-Piston	311-9346
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432
7S-5787	Chamber As	247-3300
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8F-6058	Bearing-Sleeve	416-5494
8L-3972	Baffle	311-9345
8L-4282	Hub	444-0573

91B		
Original Part Number	Part Name	Classic Part Number
8M-0874	Plunger As-Valve	311-9439
8N-1365	Gear-Drive	394-8222
8N-2275	Bearing-Sleeve	311-9365
8N-3723	Valve-Exhaust	311-9472
8N-7764	Bearing-Main	419-6310
8N-7765	Bearing-Main	419-7269
8N-7766	Bearing-Main	419-7270
8N-7771	Bearing-Conn Rod	419-7272
8N-7773	Bearing-Conn Rod	419-7274
8S-1892	Gasket Kt-Wp	436-8398
8S-3617	Chamber As	247-3302
8T-0209	Race-Spl Rlr Brg	384-5951
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
207-1332	Bellows As	444-0569
214-6045	Bellows As	435-4846

Sales Model D4400

01N		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
2S-4015	Plunger As-Valve	311-9438
5B-9169	Plug-Drain	419-4736

01N		
Original Part Number	Part Name	Classic Part Number
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358

01N		
Original Part Number	Part Name	Classic Part Number
7H-6967	Bearing-Ball	422-6489
108-5603	Screw-Adj Arm	379-0166

01S		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438

01S		
Original Part Number	Part Name	Classic Part Number
3B-1142	Retainer-Spring	391-1099
3B-6217	Muffler As	247-2671
3H-0881	Ring-Piston	465-8998
4B-7255	Cone-Bearing	386-4951
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997

01S		
Original Part Number	Part Name	Classic Part Number
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6Y-7652	Cup-Rlr Brg	399-6067
7B-7515	Bearing-Ball	399-6059

Sales Model D4400 (Cont'd.)

01S		
Original Part Number	Part Name	Classic Part Number
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7N-9352	Gasket	433-8188

01S		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8F-8523	Bearing-Sleeve	383-3701
8H-9789	Bearing-Ball	374-8342
9B-0399	Link As-Cl Drive	431-5268

01S		
Original Part Number	Part Name	Classic Part Number
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311

03R		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6217	Muffler As	247-2671
3H-0881	Ring-Piston	465-8998
4B-7255	Cone-Bearing	386-4951
4M-9183	Bearing-Sleeve	386-4924

03R		
Original Part Number	Part Name	Classic Part Number
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6Y-7652	Cup-Rlr Brg	399-6067
7B-7515	Bearing-Ball	399-6059
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816

03R		
Original Part Number	Part Name	Classic Part Number
7N-9352	Gasket	433-8188
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8F-8523	Bearing-Sleeve	383-3701
8H-9789	Bearing-Ball	374-8342
9B-0399	Link As-Cl Drive	431-5268
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311

04H		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6217	Muffler As	247-2671
3H-0881	Ring-Piston	465-8998
4B-7255	Cone-Bearing	386-4951
4M-9183	Bearing-Sleeve	386-4924

04H		
Original Part Number	Part Name	Classic Part Number
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6Y-7652	Cup-Rlr Brg	399-6067
7B-7515	Bearing-Ball	399-6059
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816

04H		
Original Part Number	Part Name	Classic Part Number
7N-9352	Gasket	433-8188
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8F-8523	Bearing-Sleeve	383-3701
8H-9789	Bearing-Ball	374-8342
9B-0399	Link As-Cl Drive	431-5268
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311

Sales Model D4400 (Cont'd.)

06S		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6217	Muffler As	247-2671
3H-0881	Ring-Piston	465-8998
4B-7255	Cone-Bearing	386-4951
4M-9183	Bearing-Sleeve	386-4924

06S		
Original Part Number	**Part Name**	**Classic Part Number**
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6Y-7652	Cup-Rlr Brg	399-6067
7B-7515	Bearing-Ball	399-6059
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816

06S		
Original Part Number	**Part Name**	**Classic Part Number**
7N-9352	Gasket	433-8188
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8F-8523	Bearing-Sleeve	383-3701
8H-9789	Bearing-Ball	374-8342
9B-0399	Link As-Cl Drive	431-5268
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311

Sales Model D4600

01N		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2S-4015	Plunger As-Valve	311-9438

01N		
Original Part Number	**Part Name**	**Classic Part Number**
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489

01N		
Original Part Number	**Part Name**	**Classic Part Number**
9B-0399	Link As-Cl Drive	431-5268
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

01S		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1B-3922	Cup-Roller Brg	416-2158
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2S-4015	Plunger As-Valve	311-9438
3B-6217	Muffler As	247-2671

01S		
Original Part Number	**Part Name**	**Classic Part Number**
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7M-7219	Bearing-Thrust	384-4816

01S		
Original Part Number	**Part Name**	**Classic Part Number**
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8H-9789	Bearing-Ball	374-8342
9B-0399	Link As-Cl Drive	431-5268
9B-1320	Valve-Check	377-5832
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

Sales Model D4600 (Cont'd.)

03R		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1B-3922	Cup-Roller Brg	416-2158
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2S-4015	Plunger As-Valve	311-9438
3B-6217	Muffler As	247-2671

03R		
Original Part Number	Part Name	Classic Part Number
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7M-7219	Bearing-Thrust	384-4816

03R		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8H-9789	Bearing-Ball	374-8342
9B-0399	Link As-Cl Drive	431-5268
9B-1320	Valve-Check	377-5832
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

04H		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1B-3922	Cup-Roller Brg	416-2158
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2S-4015	Plunger As-Valve	311-9438
3B-6217	Muffler As	247-2671

04H		
Original Part Number	Part Name	Classic Part Number
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7M-7219	Bearing-Thrust	384-4816

04H		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8H-9789	Bearing-Ball	374-8342
9B-0399	Link As-Cl Drive	431-5268
9B-1320	Valve-Check	377-5832
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

05S		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1B-3922	Cup-Roller Brg	416-2158
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2S-4015	Plunger As-Valve	311-9438
3B-6217	Muffler As	247-2671

05S		
Original Part Number	Part Name	Classic Part Number
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7M-7219	Bearing-Thrust	384-4816

05S		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8H-9789	Bearing-Ball	374-8342
9B-0399	Link As-Cl Drive	431-5268
9B-1320	Valve-Check	377-5832
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

Sales Model D468

01N		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
2F-5721	Bearing-Ball	311-9354
2S-4015	Plunger As-Valve	311-9438

01N		
Original Part Number	Part Name	Classic Part Number
3K-3124	Muffler-Trap	247-2673
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
6B-6224	Ferrule	419-4738

01N		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
9B-1320	Valve-Check	377-5832
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

Sales Model D6100

04C		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
2A-4429	Lock-Retainer	379-0174
3B-1142	Retainer-Spring	391-1099

04C		
Original Part Number	Part Name	Classic Part Number
4B-1455	Cap As-Filler	361-1719
5H-7071	Director-Water	388-0555
6H-3957	Bearing-Ball	311-9358
8F-8523	Bearing-Sleeve	383-3701

04C		
Original Part Number	Part Name	Classic Part Number
8H-4320	Bearing-Ball	419-2301
9B-0399	Link As-Cl Drive	431-5268
9L-2685	Rod End	419-1866

Sales Model D6600

05E		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1B-3922	Cup-Roller Brg	416-2158
2A-4429	Lock-Retainer	379-0174
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672

05E		
Original Part Number	Part Name	Classic Part Number
3H-0881	Ring-Piston	465-8998
3K-3124	Muffler-Trap	247-2673
4B-1455	Cap As-Filler	361-1719
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
6H-3957	Bearing-Ball	311-9358
7M-4926	Retainer-Piston	314-8538

05E		
Original Part Number	Part Name	Classic Part Number
7N-9352	Gasket	433-8188
7W-2731	Retainer	423-3541
8F-8523	Bearing-Sleeve	383-3701
8H-4320	Bearing-Ball	419-2301
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
9Y-9431	Precleaner As	361-1718

Sales Model D7700

04C		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
3B-1142	Retainer-Spring	391-1099

04C		
Original Part Number	Part Name	Classic Part Number
4B-1455	Cap As-Filler	361-1719
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
6H-3957	Bearing-Ball	311-9358
8F-8523	Bearing-Sleeve	383-3701

04C		
Original Part Number	Part Name	Classic Part Number
8H-4320	Bearing-Ball	419-2301
9B-0399	Link As-Cl Drive	431-5268
9L-2685	Rod End	419-1866
9Y-9431	Precleaner As	361-1718

04H		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167

04H		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1B-3922	Cup-Roller Brg	416-2158

Sales Model D7700 (Cont'd.)

04H		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3K-3124	Muffler-Trap	247-2673

04H		
Original Part Number	**Part Name**	**Classic Part Number**
4B-1455	Cap As-Filler	361-1719
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
6H-3957	Bearing-Ball	311-9358
7M-4926	Retainer-Piston	314-8538

04H		
Original Part Number	**Part Name**	**Classic Part Number**
7M-7219	Bearing-Thrust	384-4816
8F-8523	Bearing-Sleeve	383-3701
8H-4320	Bearing-Ball	419-2301
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
9Y-9431	Precleaner As	361-1718

09J		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099

09J		
Original Part Number	**Part Name**	**Classic Part Number**
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538

09J		
Original Part Number	**Part Name**	**Classic Part Number**
7M-7219	Bearing-Thrust	384-4816
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
8B-5972	Bearing-Ball	314-8503
8F-8523	Bearing-Sleeve	383-3701
8F-8523	Bearing-Sleeve	383-3701
9B-0399	Link As-Cl Drive	431-5268
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9L-2685	Rod End	419-1866
121-7746	Pre-Cleaner As	360-2311

Sales Model D8800

01N		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4493	Cone-Spl Tapered	386-4939
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438

01N		
Original Part Number	**Part Name**	**Classic Part Number**
3H-0881	Ring-Piston	465-8998
4H-7496	Plate-Pump Seal	420-6217
4N-3875	Ring-Piston	465-8997
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502

01N		
Original Part Number	**Part Name**	**Classic Part Number**
5S-7877	Bearing-Spl Ball	392-4491
7B-7515	Bearing-Ball	399-6059
7F-2742	Bearing-Ball	422-6488
7M-7219	Bearing-Thrust	384-4816
8B-5972	Bearing-Ball	314-8503
9L-2685	Rod End	419-1866

Sales Model D8800 (Cont'd.)

02S		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1B-3922	Cup-Roller Brg	416-2158
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672

02S		
Original Part Number	**Part Name**	**Classic Part Number**
3H-0881	Ring-Piston	465-8998
3K-3124	Muffler-Trap	247-2673
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
7L-7508	Bearing-Ball	420-6536

02S		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
8F-8523	Bearing-Sleeve	383-3701
9F-3358	Link As-Cl Drive	394-0207
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311

03V		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
2A-4429	Lock-Retainer	379-0174
2S-4015	Plunger As-Valve	311-9438
3B-6218	Muffler As	247-2672
3H-0881	Ring-Piston	465-8998

03V		
Original Part Number	**Part Name**	**Classic Part Number**
3K-3124	Muffler-Trap	247-2673
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555

03V		
Original Part Number	**Part Name**	**Classic Part Number**
6H-3957	Bearing-Ball	311-9358
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
9S-7534	Pipe-Exh Ext	398-2950

04H		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1B-3922	Cup-Roller Brg	416-2158
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672

04H		
Original Part Number	**Part Name**	**Classic Part Number**
3H-0881	Ring-Piston	465-8998
3K-3124	Muffler-Trap	247-2673
4B-1455	Cap As-Filler	361-1719
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
6H-3957	Bearing-Ball	311-9358
7M-4926	Retainer-Piston	314-8538

04H		
Original Part Number	**Part Name**	**Classic Part Number**
7W-2731	Retainer	423-3541
8F-8523	Bearing-Sleeve	383-3701
8H-4320	Bearing-Ball	419-2301
9B-0399	Link As-Cl Drive	431-5268
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311

05E		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1B-3922	Cup-Roller Brg	416-2158
1M-7250	Bowl	360-2296

05E		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099

05E		
Original Part Number	**Part Name**	**Classic Part Number**
3B-6218	Muffler As	247-2672
3H-0881	Ring-Piston	465-8998
3K-3124	Muffler-Trap	247-2673
4B-1455	Cap As-Filler	361-1719
4N-3875	Ring-Piston	465-8997

Sales Model D8800 (Cont'd.)

05E		
Original Part Number	**Part Name**	**Classic Part Number**
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
6H-3957	Bearing-Ball	311-9358
7M-4926	Retainer-Piston	314-8538

05E		
Original Part Number	**Part Name**	**Classic Part Number**
7W-2731	Retainer	423-3541
8F-8523	Bearing-Sleeve	383-3701
8H-4320	Bearing-Ball	419-2301
9B-0399	Link As-Cl Drive	431-5268

05E		
Original Part Number	**Part Name**	**Classic Part Number**
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311

06S		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1B-3922	Cup-Roller Brg	416-2158
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672

06S		
Original Part Number	**Part Name**	**Classic Part Number**
3H-0881	Ring-Piston	465-8998
3K-3124	Muffler-Trap	247-2673
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
7L-7508	Bearing-Ball	420-6536

06S		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
8F-8523	Bearing-Sleeve	383-3701
9F-3358	Link As-Cl Drive	394-0207
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311

09J		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-2846	Cap As-Filler	311-9368
1B-3922	Cup-Roller Brg	416-2158
1B-3922	Cup-Roller Brg	416-2158
1M-7250	Bowl	360-2296
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2S-4015	Plunger As-Valve	311-9438
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-1142	Retainer-Spring	391-1099

09J		
Original Part Number	**Part Name**	**Classic Part Number**
3B-6218	Muffler As	247-2672
3B-6218	Muffler As	247-2672
3H-0881	Ring-Piston	465-8998
3H-0881	Ring-Piston	465-8998
3K-3124	Muffler-Trap	247-2673
3K-3124	Muffler-Trap	247-2673
4B-1455	Cap As-Filler	361-1719
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
4N-3875	Ring-Piston	465-8997
5B-9169	Plug-Drain	419-4736
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5H-7071	Director-Water	388-0555
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738

09J		
Original Part Number	**Part Name**	**Classic Part Number**
6H-3957	Bearing-Ball	311-9358
6H-3957	Bearing-Ball	311-9358
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
7W-2731	Retainer	423-3541
8F-8523	Bearing-Sleeve	383-3701
8F-8523	Bearing-Sleeve	383-3701
8H-4320	Bearing-Ball	419-2301
9B-0399	Link As-Cl Drive	431-5268
9F-3358	Link As-Cl Drive	394-0207
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866

Sales Model D8800 (Cont'd.)

09J		
Original Part Number	Part Name	Classic Part Number
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950

09J		
Original Part Number	Part Name	Classic Part Number
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311

09J		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311

Sales Model D9900

04C		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849

04C		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
9B-0399	Link As-Cl Drive	431-5268

04C		
Original Part Number	Part Name	Classic Part Number
9L-2685	Rod End	419-1866
121-7746	Pre-Cleaner As	360-2311

Sales Model G333B

84B		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1M-0090	Gasket-Manifold	445-7701
1P-1367	Plunger-Valve	432-8913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4238	Mount-Flexible	385-7222
3N-3368	Pipe-Exhaust	311-9434
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854

84B		
Original Part Number	Part Name	Classic Part Number
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7M-4046	Bearing-Sleeve	394-8206
7M-7358	Valve-Inlet	298-2774
7W-2731	Retainer	423-3541

84B		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166
169-4200	Gasket	472-8023
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085

Sales Model G333C

68D		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167

68D		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913

Sales Model G333C (Cont'd.)

68D		
Original Part Number	Part Name	Classic Part Number
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-3062	Retainer As	311-9445
1W-8606	Valve-Inlet	443-1204
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-4238	Mount-Flexible	385-7222
2P-6245	Shaft As-Pump	325-6197
3B-1142	Retainer-Spring	391-1099
3N-1968	Mount-Shock	397-5046
3N-3368	Pipe-Exhaust	311-9434
4B-7270	Cone-Bearing	399-4439
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-7693	Crankshaft As	269-8763
4W-0452	Seal As -Cshaft	325-6191
4W-2541	Shaft-Gov Cont	399-8580
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-8768	Kit-Gasket (Scl)	393-1024
5S-1757	Insert-Seat	311-9401
5S-5917	Screw-Rocker Adj	380-7537

68D		
Original Part Number	Part Name	Classic Part Number
5S-7630	Bearing-Sleeve	394-0219
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6I-1345	Shaft As-O Pump	374-7475
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-2820	Pump Gp-Eng Oil	415-1903
6N-7263	Gasket-Cyl Head	380-7386
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-7639	Rotator-Valve	383-1582
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7S-3161	Lifter-Valve	279-4996
7W-2731	Retainer	423-3541
7W-5692	Pulley-Cshaft	386-3041
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8N-1984	Rod As-Conn	242-3441
8N-4110	Bearing-Sleeve	394-8207

68D		
Original Part Number	Part Name	Classic Part Number
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0493	Shaft As-Pump	325-6198
8S-6511	Bearing-Sleeve	380-7372
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9S-7148	Cap As-Rain	378-3994
9Y-1798	Seal-Water	379-0165
102-1561	Lifter As-Valve	311-9402
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
167-8123	Damper As	299-2006
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
214-6045	Bellows As	435-4846
232-3233	Bearing-Main	376-9085
328-5572	Bearing-Rod	419-6349

Sales Model G3406

1RK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356

1RK		
Original Part Number	Part Name	Classic Part Number
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164

1RK		
Original Part Number	Part Name	Classic Part Number
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174

Sales Model G3406 (Cont'd.)

1RK		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3N-1968	Mount-Shock	397-5046
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5N-1841	Flange-Pipe	426-0029
5P-9514	Bearing-Ball	417-9467
6B-7469	Spacer	417-4535
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757

1RK		
Original Part Number	Part Name	Classic Part Number
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-6490	Sleeve-O-Ring	398-8346
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7L-7508	Bearing-Ball	420-6536
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7X-7954	Gasket Kit	393-5204
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9S-7148	Cap As-Rain	378-3994
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563

1RK		
Original Part Number	Part Name	Classic Part Number
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
109-6928	Gasket Kit	436-8413
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
124-3237	Precleaner As	432-4220
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-6574	Kit-Gasket-Rs	437-2034
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367

Sales Model G3406 (Cont'd.)

1RK		
Original Part Number	**Part Name**	**Classic Part Number**
328-5573	Bearing-Conn Rod	419-4665

1RK		
Original Part Number	**Part Name**	**Classic Part Number**
328-5573	Bearing-Conn Rod	419-6387

1RK		
Original Part Number	**Part Name**	**Classic Part Number**
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

4FD		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2W-5540	Core As-Radiator	363-7452
2W-7455	Gear As	396-9957
3E-4326	Gasket Kit	437-8111
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3786	Rod-Thrt Cont	397-5051
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3092	Spider As-Fan	363-7465

4FD		
Original Part Number	**Part Name**	**Classic Part Number**
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5N-1841	Flange-Pipe	426-0029
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518

4FD		
Original Part Number	**Part Name**	**Classic Part Number**
6I-4024	Gasket-Plate	377-5839
6L-3353	Rod End-Special	416-2134
6L-6490	Sleeve-O-Ring	398-8346
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301

Sales Model G3406 (Cont'd.)

4FD		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-6371	Rod-Eye	363-7459
9S-7148	Cap As-Rain	378-3994
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-8644	Kit-Gasket (Ocl)	436-8416

4FD		
Original Part Number	**Part Name**	**Classic Part Number**
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
109-6928	Gasket Kit	436-8413
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572
117-0456	Crankshaft As	394-2587
124-3237	Precleaner As	432-4220
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554

4FD		
Original Part Number	**Part Name**	**Classic Part Number**
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-8780	Kit-Gasket (Ocl)	437-2013
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

4SZ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

4SZ		
Original Part Number	**Part Name**	**Classic Part Number**
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3N-1968	Mount-Shock	397-5046
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0685	Bearing-Sleeve	379-0191

4SZ		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885

Sales Model G3406 (Cont'd.)

4SZ		
Original Part Number	**Part Name**	**Classic Part Number**
4P-2383	Adapter-Inlet	438-1812
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5N-1841	Flange-Pipe	426-0029
5P-9514	Bearing-Ball	417-9467
6B-7469	Spacer	417-4535
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-6490	Sleeve-O-Ring	398-8346
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7L-7508	Bearing-Ball	420-6536

4SZ		
Original Part Number	**Part Name**	**Classic Part Number**
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7X-7954	Gasket Kit	393-5204
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9S-7148	Cap As-Rain	378-3994
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
109-6928	Gasket Kit	436-8413
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700

4SZ		
Original Part Number	**Part Name**	**Classic Part Number**
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
124-3237	Precleaner As	432-4220
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-6574	Kit-Gasket-Rs	437-2034
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

5HZ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344

5HZ		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
1W-1669	Piston	325-6158

Sales Model G3406 (Cont'd.)

5HZ		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2W-5540	Core As-Radiator	363-7452
2W-7455	Gear As	396-9957
3E-4326	Gasket Kit	437-8111
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3786	Rod-Thrt Cont	397-5051
4B-7270	Cone-Bearing	399-4439
4L-8473	Plate-Wear	419-0883
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904

5HZ		
Original Part Number	Part Name	Classic Part Number
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5N-1841	Flange-Pipe	426-0029
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-3353	Rod End-Special	416-2134
6L-6490	Sleeve-O-Ring	398-8346
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7653	Gage As-O Level	428-7206
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7E-0558	Bearing-Rod	419-7256

5HZ		
Original Part Number	Part Name	Classic Part Number
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3248	Gasket As	415-1893
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-6371	Rod-Eye	363-7459
9S-7148	Cap As-Rain	378-3994
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552

Sales Model G3406 (Cont'd.)

5HZ		
Original Part Number	Part Name	Classic Part Number
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-8644	Kit-Gasket (Ocl)	436-8416
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
109-6928	Gasket Kit	436-8413
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-3657	Kit-Gasket-Ocl	437-4572
117-0456	Crankshaft As	394-2587
124-3237	Precleaner As	432-4220
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455

5HZ		
Original Part Number	Part Name	Classic Part Number
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-8780	Kit-Gasket (Ocl)	437-2013

5HZ		
Original Part Number	Part Name	Classic Part Number
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
234-1874	Kit-Gasket-Fs	437-8668
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

6H6		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489

6H6		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5998	Rod-Valve Push	379-0168
6I-1453	Crankshaft As	368-5916
6I-2981	Plate-Block	374-7495
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556

6H6		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7W-2164	Core As-Oclr	299-1996
7W-5733	Gasket	421-7333
8N-2104	Bell As-Suction	380-1521
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716

Sales Model G3406 (Cont'd.)

6H6		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-7735	Bearing-Rod	419-4665
101-1816	Bridge As-Intake	374-4689
101-1818	Bridge As-Exh	374-4691
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589

6H6		
Original Part Number	**Part Name**	**Classic Part Number**
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956

6H6		
Original Part Number	**Part Name**	**Classic Part Number**
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665

KAR		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885

KAR		
Original Part Number	**Part Name**	**Classic Part Number**
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168
5N-1841	Flange-Pipe	426-0029
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6I-1453	Crankshaft As	368-5916
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6L-6490	Sleeve-O-Ring	398-8346
6N-0597	Pulley-Fan	420-6391
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-3955	Bearing-Ball	417-9485
7C-0307	Gasket	399-8571

KAR		
Original Part Number	**Part Name**	**Classic Part Number**
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-8828	Pulley	420-6395
7W-2164	Core As-Oclr	299-1996
7W-5733	Gasket	421-7333
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-3248	Gasket As	415-1893
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9S-7148	Cap As-Rain	378-3994
9W-9930	Mount As	295-6437
9W-9931	Mount As.	360-2354
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
101-1816	Bridge As-Intake	374-4689
101-1818	Bridge As-Exh	374-4691
108-5603	Screw-Adj Arm	379-0166

Sales Model G3406 (Cont'd.)

KAR		
Original Part Number	Part Name	Classic Part Number
108-7930	Bearing As	377-7463
117-0456	Crankshaft As	394-2587
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919

KAR		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956

KAR		
Original Part Number	Part Name	Classic Part Number
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665

Sales Model G3408

6NB		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-5009	Crankshaft As	398-2969
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-4087	Gear As-Idler	418-9582
2W-5540	Core As-Radiator	363-7452
2W-7980	Camshaft As	378-3972
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-8463	Bearing-Roller	394-9193
4B-7270	Cone-Bearing	399-4439
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974

6NB		
Original Part Number	Part Name	Classic Part Number
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333

6NB		
Original Part Number	Part Name	Classic Part Number
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5N-1932	Shaft-Clutch	425-0216
5N-2902	Seal-Oil	314-8540
5N-4504	Plate-Port	397-5048
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065
6I-4613	Plate-Spacer	380-7405
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0597	Pulley-Fan	420-6391
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171

Sales Model G3408 (Cont'd.)

6NB		
Original Part Number	Part Name	Classic Part Number
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7L-4302	Gasket	420-8570
7N-2156	Bearing-Sleeve	380-7373
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3145	Plate	422-7894
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-2104	Bell As-Suction	380-1521
8N-3248	Gasket As	415-1893
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372

6NB		
Original Part Number	Part Name	Classic Part Number
8T-0209	Race-Spl Rlr Brg	384-5951
9L-5961	Adapter-Compr Dr	416-5508
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
104-9635	Kit-Gasket-Sch	436-8415
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-3237	Precleaner As	432-4220
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
130-6856	Pre-Cleaner As	361-1717

6NB		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
142-3035	Kit-Gasket (Wlg)	393-0926
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
217-7884	Gasket Kit - Wp	437-8143
232-2600	Kit-Gasket-Fs	437-8672
234-1630	Kit-Gasket(Rs)	393-1040
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

6RJ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1T-0043	Bearing-Ball	390-5294
1W-5009	Crankshaft As	398-2969
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174

6RJ		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-4087	Gear As-Idler	418-9582
2W-7980	Camshaft As	378-3972
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356

6RJ		
Original Part Number	Part Name	Classic Part Number
3N-1968	Mount-Shock	397-5046
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156

Sales Model G3408 (Cont'd.)

6RJ		
Original Part Number	Part Name	Classic Part Number
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
5P-2448	Bearing-Ball	399-6064
6I-4613	Plate-Spacer	380-7405
6L-2279	Plug-Ptf	419-4739
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544

6RJ		
Original Part Number	Part Name	Classic Part Number
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-5996	Rod As-Conn	379-8864
7L-4302	Gasket	420-8570
7N-2156	Bearing-Sleeve	380-7373
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3145	Plate	422-7894
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463

6RJ		
Original Part Number	Part Name	Classic Part Number
109-7687	Bearing-Ball	420-3220
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-3237	Precleaner As	432-4220
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
142-3035	Kit-Gasket (Wlg)	393-0926
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

PRS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-5009	Crankshaft As	398-2969
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354

PRS		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-4087	Gear As-Idler	418-9582
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046

PRS		
Original Part Number	Part Name	Classic Part Number
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489

Sales Model G3408 (Cont'd.)

PRS		
Original Part Number	Part Name	Classic Part Number
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5L-7520	Elbow-Exhaust	419-4711
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6V-2202	Bearing-Spl Ball	380-1574

PRS		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-5996	Rod As-Conn	379-8864
7N-2156	Bearing-Sleeve	380-7373
7N-8828	Pulley	420-6395
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3145	Plate	422-7894
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-3248	Gasket As	415-1893
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463

PRS		
Original Part Number	Part Name	Classic Part Number
109-7687	Bearing-Ball	420-3220
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-3237	Precleaner As	432-4220
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

Sales Model G3408C

3WR		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-5009	Crankshaft As	398-2969
1W-7238	Shaft As-Pump Dr	379-0164

3WR		
Original Part Number	Part Name	Classic Part Number
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305

3WR		
Original Part Number	Part Name	Classic Part Number
2N-5842	Screw-Bridge Adj	418-1934
2W-4087	Gear As-Idler	418-9582

Sales Model G3408C (Cont'd.)

3WR		
Original Part Number	Part Name	Classic Part Number
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
6I-4613	Plate-Spacer	380-7405
6L-2279	Plug-Ptf	419-4739
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171

3WR		
Original Part Number	Part Name	Classic Part Number
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7N-2156	Bearing-Sleeve	380-7373
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463

3WR		
Original Part Number	Part Name	Classic Part Number
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

6FW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-5009	Crankshaft As	398-2969
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174

6FW		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-4087	Gear As-Idler	418-9582
3E-6772	Seal-Water	382-8017
3N-1968	Mount-Shock	397-5046

6FW		
Original Part Number	Part Name	Classic Part Number
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191

Sales Model G3408C (Cont'd.)

6FW		
Original Part Number	Part Name	Classic Part Number
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042

6FW		
Original Part Number	Part Name	Classic Part Number
6N-9133	Gasket-Plate	398-2959
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-5996	Rod As-Conn	379-8864
7N-2156	Bearing-Sleeve	380-7373
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463

6FW		
Original Part Number	Part Name	Classic Part Number
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

8YR		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-5009	Crankshaft As	398-2969
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-4087	Gear As-Idler	418-9582
3E-6772	Seal-Water	382-8017
3N-1968	Mount-Shock	397-5046

8YR		
Original Part Number	Part Name	Classic Part Number
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271

8YR		
Original Part Number	Part Name	Classic Part Number
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255

Sales Model G3408C (Cont'd.)

8YR		
Original Part Number	Part Name	Classic Part Number
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
6I-4613	Plate-Spacer	380-7405
6L-2279	Plug-Ptf	419-4739
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7N-2156	Bearing-Sleeve	380-7373
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
8N-2104	Bell As-Suction	380-1521

8YR		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193

8YR		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

BAZ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-5009	Crankshaft As	398-2969
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-4087	Gear As-Idler	418-9582
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356

BAZ		
Original Part Number	Part Name	Classic Part Number
3N-1968	Mount-Shock	397-5046
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271

BAZ		
Original Part Number	Part Name	Classic Part Number
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168

Sales Model G3408C (Cont'd.)

BAZ		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-5996	Rod As-Conn	379-8864
7N-2156	Bearing-Sleeve	380-7373
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3145	Plate	422-7894

BAZ		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504

BAZ		
Original Part Number	Part Name	Classic Part Number
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

Sales Model G3412

3NK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1T-0043	Bearing-Ball	390-5294
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582

3NK		
Original Part Number	Part Name	Classic Part Number
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-3714	Chamber As	363-7450

3NK		
Original Part Number	Part Name	Classic Part Number
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318

Sales Model G3412 (Cont'd.)

3NK		
Original Part Number	Part Name	Classic Part Number
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
6L-2279	Plug-Ptf	419-4739
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5996	Rod As-Conn	379-8864
7L-4302	Gasket	420-8570
7N-2156	Bearing-Sleeve	380-7373
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3145	Plate	422-7894

3NK		
Original Part Number	Part Name	Classic Part Number
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703

3NK		
Original Part Number	Part Name	Classic Part Number
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

5KR		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722

5KR		
Original Part Number	Part Name	Classic Part Number
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318

5KR		
Original Part Number	Part Name	Classic Part Number
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168
6L-2279	Plug-Ptf	419-4739
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257

Sales Model G3412 (Cont'd.)

5KR		
Original Part Number	Part Name	Classic Part Number
7E-5996	Rod As-Conn	379-8864
7N-2156	Bearing-Sleeve	380-7373
7W-3145	Plate	422-7894
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984

5KR		
Original Part Number	Part Name	Classic Part Number
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
117-9712	Shaft-Dr Idler	425-7754
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553

5KR		
Original Part Number	Part Name	Classic Part Number
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

6ZM		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4B-7270	Cone-Bearing	399-4439
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191

6ZM		
Original Part Number	Part Name	Classic Part Number
4N-0913	Screen As-Bell	374-7489
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
5N-1932	Shaft-Clutch	425-0216
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065
6L-2279	Plug-Ptf	419-4739
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171

6ZM		
Original Part Number	Part Name	Classic Part Number
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7N-2156	Bearing-Sleeve	380-7373
7W-2731	Retainer	423-3541
7W-3145	Plate	422-7894
8C-6553	Gasket Kit	436-8390
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951

Sales Model G3412 (Cont'd.)

6ZM		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
117-9712	Shaft-Dr Idler	425-7754
127-6356	Cover As.-Pump	420-8566

6ZM		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-4504	Kit-Gasket-Fs	437-2038

6ZM		
Original Part Number	Part Name	Classic Part Number
234-1630	Kit-Gasket(Rs)	393-1040
234-1985	Kit-Gasket-Fs	437-8666
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
292-2500	Kit-Gasket-Mch	438-0147
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

7DB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
2W-5540	Core As-Radiator	363-7452
2W-6632	Core As-Rad	391-1096
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
4B-7270	Cone-Bearing	399-4439

7DB		
Original Part Number	Part Name	Classic Part Number
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-3092	Spider As-Fan	363-7465
4N-3339	Spider As.	419-0891
4N-3714	Chamber As	363-7450
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-2541	Shaft-Gov Cont	399-8580
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

7DB		
Original Part Number	Part Name	Classic Part Number
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5N-1932	Shaft-Clutch	425-0216
5N-3274	Plate	425-3648
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-0597	Pulley-Fan	420-6391

Sales Model G3412 (Cont'd.)

7DB		
Original Part Number	**Part Name**	**Classic Part Number**
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7L-4302	Gasket	420-8570
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7N-8828	Pulley	420-6395
7S-4411	Cap As-Rain	373-1912
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3145	Plate	422-7894
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
8L-4282	Hub	444-0573
8N-2104	Bell As-Suction	380-1521
8N-3248	Gasket As	415-1893
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372

7DB		
Original Part Number	**Part Name**	**Classic Part Number**
8T-0209	Race-Spl Rlr Brg	384-5951
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-3237	Precleaner As	432-4220
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919

7DB		
Original Part Number	**Part Name**	**Classic Part Number**
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
140-2746	Kit-Gasket-Mch	437-3219
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
207-1332	Bellows As	444-0569
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-2600	Kit-Gasket-Fs	437-8672
232-4504	Kit-Gasket-Fs	437-2038
233-9245	Kit-Gasket-Sch	437-2027
234-1630	Kit-Gasket(Rs)	393-1040
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
292-2500	Kit-Gasket-Mch	438-0147
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

GNA		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934

GNA		
Original Part Number	**Part Name**	**Classic Part Number**
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031

GNA		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489

Sales Model G3412 (Cont'd.)

GNA		
Original Part Number	Part Name	Classic Part Number
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5P-2448	Bearing-Ball	399-6064
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657

GNA		
Original Part Number	Part Name	Classic Part Number
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5996	Rod As-Conn	379-8864
7L-4302	Gasket	420-8570
7N-2156	Bearing-Sleeve	380-7373
7S-4411	Cap As-Rain	373-1912
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463

GNA		
Original Part Number	Part Name	Classic Part Number
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

KAP		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556

KAP		
Original Part Number	Part Name	Classic Part Number
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271

KAP		
Original Part Number	Part Name	Classic Part Number
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168

Sales Model G3412 (Cont'd.)

KAP		
Original Part Number	Part Name	Classic Part Number
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
5P-2448	Bearing-Ball	399-6064
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5996	Rod As-Conn	379-8864
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541

KAP		
Original Part Number	Part Name	Classic Part Number
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698

KAP		
Original Part Number	Part Name	Classic Part Number
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

Sales Model G3412C

6ZM		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548

6ZM		
Original Part Number	Part Name	Classic Part Number
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4B-7270	Cone-Bearing	399-4439
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489

6ZM		
Original Part Number	Part Name	Classic Part Number
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255

Sales Model G3412C (Cont'd.)

6ZM		
Original Part Number	Part Name	Classic Part Number
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
5N-1932	Shaft-Clutch	425-0216
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065
6L-2279	Plug-Ptf	419-4739
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7N-2156	Bearing-Sleeve	380-7373

6ZM		
Original Part Number	Part Name	Classic Part Number
7W-2731	Retainer	423-3541
7W-3145	Plate	422-7894
8C-6553	Gasket Kit	436-8390
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
117-9712	Shaft-Dr Idler	425-7754
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193

6ZM		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-4504	Kit-Gasket-Fs	437-2038
234-1630	Kit-Gasket(Rs)	393-1040
234-1985	Kit-Gasket-Fs	437-8666
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
292-2500	Kit-Gasket-Mch	438-0147
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

8LW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017
3N-1968	Mount-Shock	397-5046

8LW		
Original Part Number	Part Name	Classic Part Number
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323

8LW		
Original Part Number	Part Name	Classic Part Number
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042

Sales Model G3412C (Cont'd.)

8LW		
Original Part Number	**Part Name**	**Classic Part Number**
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7N-2156	Bearing-Sleeve	380-7373
7W-3145	Plate	422-7894
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
101-1816	Bridge As-Intake	374-4689

8LW		
Original Part Number	**Part Name**	**Classic Part Number**
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
117-9712	Shaft-Dr Idler	425-7754
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919

8LW		
Original Part Number	**Part Name**	**Classic Part Number**
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

9RR		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

9RR		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168
6L-2279	Plug-Ptf	419-4739
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7N-2156	Bearing-Sleeve	380-7373
7W-3145	Plate	422-7894
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372

9RR		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
117-9712	Shaft-Dr Idler	425-7754
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368

Sales Model G3412C (Cont'd.)

9RR		
Original Part Number	Part Name	Classic Part Number
214-6045	Bellows As	435-4846
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170

9RR		
Original Part Number	Part Name	Classic Part Number
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665

9RR		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

SPY		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318

SPY		
Original Part Number	Part Name	Classic Part Number
4W-5703	Bearing-Con Rod	419-7255
4W-5998	Rod-Valve Push	379-0168
5B-9169	Plug-Drain	419-4736
5L-7520	Elbow-Exhaust	419-4711
5P-2448	Bearing-Ball	399-6064
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7N-2156	Bearing-Sleeve	380-7373
7W-2731	Retainer	423-3541
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716

SPY		
Original Part Number	Part Name	Classic Part Number
9Y-9497	Bearing-Conn Rod	441-1563
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
117-9712	Shaft-Dr Idler	425-7754
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
211-0592	Bearing - Main	419-6368
214-6045	Bellows As	435-4846
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
255-6863	Gasket	450-5024
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

Sales Model G342C

71B		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
1S-8607	Baffle	380-7540
1W-7035	Kit-Pump (Rbd)	421-1553
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2P-0484	Chamber As	247-3296
2S-3966	Ring-Seal	297-7237
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
4B-7270	Cone-Bearing	399-4439
4H-7496	Plate-Pump Seal	420-6217
4H-9640	Bearing-Sleeve	386-4921
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
4S-7793	Thrower-Cshft O	367-6085
5B-9169	Plug-Drain	419-4736

71B		
Original Part Number	Part Name	Classic Part Number
5F-7404	Nut-Bearing Lock	308-9878
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5N-8501	Head As-Cyl	256-4762
5P-9237	Gasket Kit	438-0174
5P-9514	Bearing-Ball	417-9467
5P-9553	Gasket Kit - Wp	393-3624
5S-1220	Lifter As-Valve	387-2926
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
6V-7479	Gasket Kt-Cyl Hd	438-0160
7H-6967	Bearing-Ball	422-6489
7M-4926	Retainer-Piston	314-8538

71B		
Original Part Number	Part Name	Classic Part Number
7M-5692	Impeller-Pump	433-0791
7N-0128	Core As-Oil Clr	299-1994
7N-3352	Plate-Spacer	386-3062
7N-4407	Gasket-Rod Comp	433-9853
7N-7639	Rotator-Valve	383-1582
7N-9352	Gasket	433-8188
7S-4411	Cap As-Rain	373-1912
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8N-4810	Gasket-Cyl Head	437-2046
8N-7923	Bearing-Main	419-7275
8N-7924	Bearing-Main	419-7276
8N-7933	Bearing-Conn Rod	419-7280
8N-7934	Bearing-Conn Rod	419-6308
9H-6236	Rod As	390-0999
9M-5350	Spring-Valve	380-7573
9S-5771	Bushing As	385-7219
214-6045	Bellows As	435-4846

Sales Model G343

97N		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7056	Bearing-Ball	422-6483
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2P-3839	Crankshaft As	398-2968

97N		
Original Part Number	Part Name	Classic Part Number
2S-3966	Ring-Seal	297-7237
3N-1968	Mount-Shock	397-5046
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
4B-7255	Cone-Bearing	386-4951
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600

97N		
Original Part Number	Part Name	Classic Part Number
4W-2541	Shaft-Gov Cont	399-8580
5B-9169	Plug-Drain	419-4736
5F-8651	Bearing-Ball	420-3223
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9738	Coupling-Exhaust	311-9380

Sales Model G343 (Cont'd.)

97N		
Original Part Number	**Part Name**	**Classic Part Number**
5M-3560	Bearing-Sleeve	392-4521
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-8543	Bearing-Sleeve	376-3635
6L-2279	Plug-Ptf	419-4739
6L-3353	Rod End-Special	416-2134
6L-4716	Gasket-Exhaust	398-2951

97N		
Original Part Number	**Part Name**	**Classic Part Number**
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7S-3206	Seal-O-Ring	436-2656

97N		
Original Part Number	**Part Name**	**Classic Part Number**
7S-4411	Cap As-Rain	373-1912
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
7W-2731	Retainer	423-3541
8L-4282	Hub	444-0573
8S-1522	Chamber As	390-1004
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
214-6045	Bellows As	435-4846

Sales Model G348

92R		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-6005	Bearing-Sleeve	417-4521
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-7242	Tube As	444-5677
2S-5100	Valve-Ball	386-3049
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600

92R		
Original Part Number	**Part Name**	**Classic Part Number**
4W-2541	Shaft-Gov Cont	399-8580
4W-5693	Bearing-Con Rod	419-6324
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9738	Coupling-Exhaust	311-9380
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6L-2279	Plug-Ptf	419-4739
6L-3353	Rod End-Special	416-2134

92R		
Original Part Number	**Part Name**	**Classic Part Number**
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7M-7219	Bearing-Thrust	384-4816
7N-5449	Spool-Press Rlf	434-2450
7S-4411	Cap As-Rain	373-1912
7W-2731	Retainer	423-3541
8L-4282	Hub	444-0573
8N-8110	Gasket-Cam Hsg	433-8186
131-3815	Seal Gp-Basic	325-6193
214-6045	Bellows As	435-4846

Sales Model G349

93R		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-6005	Bearing-Sleeve	417-4521
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-7242	Tube As	444-5677
2S-5100	Valve-Ball	386-3049
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
4N-4519	Quadrant-Control	444-0572

93R		
Original Part Number	**Part Name**	**Classic Part Number**
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
4W-5693	Bearing-Con Rod	419-6324
5B-9169	Plug-Drain	419-4736
5D-7449	Cup-Spl Tapered	416-2161
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9738	Coupling-Exhaust	311-9380
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
6L-2279	Plug-Ptf	419-4739
6L-3353	Rod End-Special	416-2134

93R		
Original Part Number	**Part Name**	**Classic Part Number**
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
7M-7219	Bearing-Thrust	384-4816
7N-5449	Spool-Press Rlf	434-2450
7S-4411	Cap As-Rain	373-1912
7W-2731	Retainer	423-3541
8L-4282	Hub	444-0573
108-1760	Bearing-Ball	417-9493
131-3815	Seal Gp-Basic	325-6193
214-6045	Bellows As	435-4846

Sales Model G353D

64B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1N-4317	Bearing-Main	419-7253
1N-4336	Bearing-Conn Rod	419-6329
1N-4337	Bearing-Conn Rod	419-6328
1P-1367	Plunger-Valve	432-8913
1S-8607	Baffle	380-7540
1W-1822	Valve-Exhaust	443-1205
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-6440	Gasket-Cyl Head	449-9548
1W-8606	Valve-Inlet	443-1204
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-2330	Bearing-Sleeve	452-9554

64B		
Original Part Number	**Part Name**	**Classic Part Number**
2H-3069	Lifter As-Valve	387-2927
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2S-2430	Thrower-Chsft O	380-7543
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
4B-7270	Cone-Bearing	399-4439
4M-4431	Shaft-Pump Dr	390-0994
4N-3664	Guide-Valve	314-8524
5B-9169	Plug-Drain	419-4736
5F-7404	Nut-Bearing Lock	308-9878
5F-8651	Bearing-Ball	420-3223

64B		
Original Part Number	**Part Name**	**Classic Part Number**
5H-7071	Director-Water	388-0555
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-8974	Gasket Kit - Wp	387-2912
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6H-5845	Baffle-Oil	390-0926
6L-2279	Plug-Ptf	419-4739
6L-3353	Rod End-Special	416-2134

Sales Model G353D (Cont'd.)

64B		
Original Part Number	**Part Name**	**Classic Part Number**
6L-4716	Gasket-Exhaust	398-2951
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-2460	Pump Gp-Eng Oil	395-1316
6N-6969	Chamber As	247-3299
6N-9654	Core As-Oil Clr	435-4787
6V-2202	Bearing-Spl Ball	380-1574

64B		
Original Part Number	**Part Name**	**Classic Part Number**
7C-4297	Seal As-Cshaft	325-6192
7L-2041	Shaft-Water Pump	428-7200
7L-7508	Bearing-Ball	420-6536
7L-8240	Bellows	419-4741
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-7817	Valve-Inlet	311-9474
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432

64B		
Original Part Number	**Part Name**	**Classic Part Number**
7S-4411	Cap As-Rain	373-1912
7W-2731	Retainer	423-3541
8H-2810	Case As-Filter	314-8512
8N-2275	Bearing-Sleeve	311-9365
8N-3723	Valve-Exhaust	311-9472
8S-3617	Chamber As	247-3302
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
125-2728	Core As	395-1302
214-6045	Bellows As	435-4846

Sales Model G379A

72B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1P-0009	Rod As-Conn	311-9450
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-7080	Kit-Pump (Rbd)	392-4515
1W-8606	Valve-Inlet	443-1204
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2L-4444	Bearing	419-6029
2L-5271	Bearing-Ball	371-4305
2N-3236	Gasket-Man Exh	415-1900
2N-5693	Gasket-Aftclr	438-2019
2N-7242	Tube As	444-5677
2P-1757	Hub-Fan Pulley	296-1357
2S-3966	Ring-Seal	297-7237
2S-5100	Valve-Ball	386-3049
2W-7176	Shaft-Fp Dr	432-8906
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992

72B		
Original Part Number	**Part Name**	**Classic Part Number**
3L-1425	Bearing-Ball	311-9356
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3N-7326	Thrower-Cshft O	311-9458
3N-7327	Thrower-Cshft O	311-9459
3N-9160	Ring-Cshft Seal	311-9447
3S-1723	Kit-Gasket (Wp)	438-0178
4B-7270	Cone-Bearing	399-4439
4H-7496	Plate-Pump Seal	420-6217
4L-3437	Gasket	420-8572
4L-3756	Bearing-Thrust	311-9366
4L-4653	Plate-Thrust	311-9440
4L-6706	Gasket	421-1028
4N-3339	Spider As.	419-0891
4N-3664	Guide-Valve	314-8524
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-6302	Belt Set-Vee	314-8495
4W-2541	Shaft-Gov Cont	399-8580
4W-2566	Adapter-Seal	383-1573

72B		
Original Part Number	**Part Name**	**Classic Part Number**
4W-2567	Adapter-Seal	383-1574
4W-2606	Seal Gp-Cshft -A	311-9452
4W-2607	Seal Gp-Cshft -A	311-9453
4W-5550	Core As-Oclr	311-9377
5B-9169	Plug-Drain	419-4736
5H-7071	Director-Water	388-0555
5L-2093	Gasket	393-3619
5L-2648	Bearing-Sleeve	311-9362
5L-2660	Bearing-Sleeve	311-9363
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9370	Elbow-Man Inlet	311-9388
5L-9371	Connector-Inlet	311-9375
5N-1841	Flange-Pipe	426-0029
5N-4378	Shaft As-Pump	311-9456
5N-6165	Bearing	425-3587
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401

Sales Model G379A (Cont'd.)

72B		
Original Part Number	Part Name	Classic Part Number
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6L-3353	Rod End-Special	416-2134
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-6481	Elbow-Air Inlet	311-9385
6L-6490	Sleeve-O-Ring	398-8346
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8761	Sleeve-O-Ring	396-7268
6L-8968	Coupling-Exhaust	311-9381
6N-0597	Pulley-Fan	420-6391
6V-2202	Bearing-Spl Ball	380-1574
6V-3743	Kit-Gasket Pump	438-0169

72B		
Original Part Number	Part Name	Classic Part Number
6V-5426	Kit-Gasket-Wp	438-0167
6V-5428	Kit-Gasket-Ocl	386-3044
7H-6967	Bearing-Ball	422-6489
7L-0103	Impeller-Pump	398-2967
7L-0104	Impeller-Pump	311-9395
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-7639	Rotator-Valve	383-1582
7N-8828	Pulley	420-6395
7N-9810	Pin-Piston	311-9432
7S-4411	Cap As-Rain	373-1912
7S-5787	Chamber As	247-3300
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8D-0983	Mounting	384-3470
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494

72B		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-3972	Baffle	311-9345
8L-4282	Hub	444-0573
8N-1365	Gear-Drive	394-8222
8N-2275	Bearing-Sleeve	311-9365
8N-3248	Gasket As	415-1893
8N-3723	Valve-Exhaust	311-9472
8N-7764	Bearing-Main	419-6310
8N-7765	Bearing-Main	419-7269
8N-7766	Bearing-Main	419-7270
8N-7771	Bearing-Conn Rod	419-7272
8N-7773	Bearing-Conn Rod	419-7274
8S-3617	Chamber As	247-3302
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
214-6045	Bellows As	435-4846

Sales Model G398A

73B		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1P-0009	Rod As-Conn	311-9450
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1W-1877	Gear As-Idler	426-0027
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-7080	Kit-Pump (Rbd)	392-4515
1W-8606	Valve-Inlet	443-1204
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2L-4444	Bearing	419-6029
2L-5271	Bearing-Ball	371-4305
2N-3236	Gasket-Man Exh	415-1900

73B		
Original Part Number	Part Name	Classic Part Number
2N-5693	Gasket-Aftclr	438-2019
2N-7242	Tube As	444-5677
2S-3966	Ring-Seal	297-7237
2S-5100	Valve-Ball	386-3049
2W-7176	Shaft-Fp & Gov Dr	432-8906
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3N-7326	Thrower-Cshft O	311-9458
3N-7327	Thrower-Cshft O	311-9459

73B		
Original Part Number	Part Name	Classic Part Number
3N-9160	Ring-Cshft Seal	311-9447
3S-1723	Kit-Gasket (Wp)	438-0178
4B-7270	Cone-Bearing	399-4439
4H-7496	Plate-Pump Seal	420-6217
4L-3437	Gasket	420-8572
4L-3756	Bearing-Thrust	311-9366
4L-4653	Plate-Thrust	311-9440
4L-6706	Gasket	421-1028
4N-3664	Guide-Valve	314-8524
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
4W-2566	Adapter-Seal	383-1573
4W-2567	Adapter-Seal	383-1574

Sales Model G398A (Cont'd.)

73B		
Original Part Number	**Part Name**	**Classic Part Number**
4W-2606	Seal Gp-Cshft -A	311-9452
4W-2607	Seal Gp-Cshft -A	311-9453
4W-5549	Core As-Oclr	311-9376
5B-9169	Plug-Drain	419-4736
5H-7071	Director-Water	388-0555
5L-2093	Gasket	393-3619
5L-2648	Bearing-Sleeve	311-9362
5L-2660	Bearing-Sleeve	311-9363
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9370	Elbow-Man Inlet	311-9388
5L-9371	Connector-Inlet	311-9375
5N-1841	Flange-Pipe	426-0029
5N-3274	Plate	425-3648
5N-4378	Shaft As-Pump	311-9456
5N-6165	Bearing	425-3587
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358

73B		
Original Part Number	**Part Name**	**Classic Part Number**
6L-2279	Plug-Ptf	419-4739
6L-3353	Rod End-Special	416-2134
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-6481	Elbow-Air Inlet	311-9385
6L-6490	Sleeve-O-Ring	398-8346
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8761	Sleeve-O-Ring	396-7268
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
6V-5426	Kit-Gasket-Wp	438-0167
6V-5428	Kit-Gasket-Ocl	386-3044
6V-5465	Gasket Kt	438-0166
6V-6371	Gasket Kit	438-0164
6V-6375	Gasket Kt-Lines	438-0162
6V-6384	Kit-Gasket-Wp	387-2917
6V-6385	Kit-Gasket (Wp)	438-0161
7H-6967	Bearing-Ball	422-6489
7L-0103	Impeller-Pump	398-2967
7L-0104	Impeller-Pump	311-9395
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816

73B		
Original Part Number	**Part Name**	**Classic Part Number**
7M-7817	Valve-Inlet	311-9474
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432
7S-4411	Cap As-Rain	373-1912
7S-5787	Chamber As	247-3300
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8L-3972	Baffle	311-9345
8L-4282	Hub	444-0573
8N-1365	Gear-Drive	394-8222
8N-2275	Bearing-Sleeve	311-9365
8N-3723	Valve-Exhaust	311-9472
8N-7764	Bearing-Main	419-6310
8N-7765	Bearing-Main	419-7269
8N-7766	Bearing-Main	419-7270
8N-7771	Bearing-Conn Rod	419-7272
8N-7773	Bearing-Conn Rod	419-7274
8S-3617	Chamber As	247-3302
8T-2489	Gasket Kit - Sch	436-8408
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
214-6045	Bellows As	435-4846

Sales Model G399

49C		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1P-0009	Rod As-Conn	311-9450
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1W-1877	Gear As-Idler	426-0027
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446

49C		
Original Part Number	**Part Name**	**Classic Part Number**
1W-8606	Valve-Inlet	443-1204
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-4444	Bearing	419-6029
2L-5271	Bearing-Ball	371-4305
2N-3236	Gasket-Man Exh	415-1900

49C		
Original Part Number	**Part Name**	**Classic Part Number**
2N-5693	Gasket-Aftclr	438-2019
2N-7242	Tube As	444-5677
2S-3966	Ring-Seal	297-7237
2S-5100	Valve-Ball	386-3049
2W-7177	Shaft-Fp & Gov Dr	433-9215
3B-1142	Retainer-Spring	391-1099

Sales Model G399 (Cont'd.)

49C		
Original Part Number	Part Name	Classic Part Number
3H-5867	Retainer-Spring	390-0992
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-4892	Lever-Gov Cont	439-4542
3N-7326	Thrower-Cshft O	311-9458
3N-7327	Thrower-Cshft O	311-9459
3N-7702	Shaft-Pump Idler	428-7201
3N-9160	Ring-Cshft Seal	311-9447
4B-7270	Cone-Bearing	399-4439
4H-7496	Plate-Pump Seal	420-6217
4L-3437	Gasket	420-8572
4L-3756	Bearing-Thrust	311-9366
4L-4653	Plate-Thrust	311-9440
4L-6706	Gasket	421-1028
4N-3664	Guide-Valve	314-8524
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4W-2541	Shaft-Gov Cont	399-8580
4W-2566	Adapter-Seal	383-1573
4W-2567	Adapter-Seal	383-1574
4W-2606	Seal Gp-Cshft -A	311-9452
4W-2607	Seal Gp-Cshft -A	311-9453
5B-9169	Plug-Drain	419-4736
5D-0470	Valve Gp-Qrel	314-8549
5D-7449	Cup-Spl Tapered	416-2161
5H-7071	Director-Water	388-0555
5L-2093	Gasket	393-3619
5L-2648	Bearing-Sleeve	311-9362

49C		
Original Part Number	Part Name	Classic Part Number
5L-2660	Bearing-Sleeve	311-9363
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5L-9370	Elbow-Man Inlet	311-9388
5L-9371	Connector-Inlet	311-9375
5N-1841	Flange-Pipe	426-0029
5N-3274	Plate	425-3648
5N-4378	Shaft As-Pump	311-9456
5N-6165	Bearing	425-3587
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-9514	Bearing-Ball	417-9467
5S-1757	Insert-Seat	311-9401
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6L-2279	Plug-Ptf	419-4739
6L-3353	Rod End-Special	416-2134
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-6481	Elbow-Air Inlet	311-9385
6L-6490	Sleeve-O-Ring	398-8346
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6V-5428	Kit-Gasket-Ocl	386-3044
6V-5465	Gasket Kt	438-0166
6V-6375	Gasket Kt-Lines	438-0162

49C		
Original Part Number	Part Name	Classic Part Number
6V-6384	Kit-Gasket-Wp	387-2917
6V-6385	Kit-Gasket (Wp)	438-0161
6V-9255	Gasket Kt	387-2913
6V-9259	Gasket Kt	393-5213
7L-0103	Impeller-Pump	398-2967
7L-0104	Impeller-Pump	311-9395
7L-4302	Gasket	420-8570
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-7639	Rotator-Valve	383-1582
7N-9810	Pin-Piston	311-9432
7S-4411	Cap As-Rain	373-1912
7S-5787	Chamber As	247-3300
7W-2731	Retainer	423-3541
8H-2810	Case As-Filter	314-8512
8L-3972	Baffle	311-9345
8L-4282	Hub	444-0573
8L-5769	Shaft-Fan	439-1137
8N-1365	Gear-Drive	394-8222
8N-2275	Bearing-Sleeve	311-9365
8N-3723	Valve-Exhaust	311-9472
8N-7764	Bearing-Main	419-6310
8N-7765	Bearing-Main	419-7269
8N-7766	Bearing-Main	419-7270
8N-7771	Bearing-Conn Rod	419-7272
8N-7773	Bearing-Conn Rod	419-7274
8S-3617	Chamber As	247-3302
8T-2489	Gasket Kit - Sch	436-8408
9M-5350	Spring-Valve	380-7573
102-1561	Lifter As-Valve	311-9402
214-6045	Bellows As	435-4846

Sales Model G3512H

GF3		
Original Part Number	Part Name	Classic Part Number
1P-7115	Mount As	418-1936

Sales Model G3512H (Cont'd.)

GF3		
Original Part Number	Part Name	Classic Part Number
1W-6005	Bearing-Sleeve	417-4521
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

GF3		
Original Part Number	Part Name	Classic Part Number
2N-5842	Screw-Bridge Adj	418-1934
2S-5100	Valve-Ball	386-3049
4N-1320	Gasket-Adapter	398-2928

GF3		
Original Part Number	Part Name	Classic Part Number
7N-5449	Spool-Press Rlf	434-2450
131-3815	Seal Gp-Basic	325-6193

GF4		
Original Part Number	Part Name	Classic Part Number
1P-7115	Mount As	418-1936
1W-6005	Bearing-Sleeve	417-4521
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

GF4		
Original Part Number	Part Name	Classic Part Number
2N-5842	Screw-Bridge Adj	418-1934
2S-5100	Valve-Ball	386-3049
4N-1320	Gasket-Adapter	398-2928

GF4		
Original Part Number	Part Name	Classic Part Number
7N-5449	Spool-Press Rlf	434-2450
131-3815	Seal Gp-Basic	325-6193

Sales Model XG135

AL4		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356

AL4		
Original Part Number	Part Name	Classic Part Number
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4W-0452	Seal As -Cshaft	325-6191
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437

AL4		
Original Part Number	Part Name	Classic Part Number
5S-7630	Bearing-Sleeve	394-0219
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1647	Arm Gp-V Rocker	433-0451
6I-1650	Arm Gp-V Rocker	433-0450
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7C-2880	Bell As-Suction	380-1520
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-5910	Impeller-Pump	314-8686
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995

Sales Model XG135 (Cont'd.)

AL4		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
8H-9789	Bearing-Ball	374-8342
8L-4529	Pulley-Alt	264-5889
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464

AL4		
Original Part Number	Part Name	Classic Part Number
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165

AL4		
Original Part Number	Part Name	Classic Part Number
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
167-8123	Damper As	299-2006
169-1750	Seal Gp-Basic	472-8022
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

Sales Model XQ375

X3F		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
3L-1425	Bearing-Ball	311-9356
4N-2514	Gear-Flywheel	421-7283
5P-7807	Bearing-Ball	314-8502

X3F		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
6V-2202	Bearing-Spl Ball	380-1574
6Y-3955	Bearing-Ball	417-9485
7T-8816	Bearing-Spl Ball	420-2491

X3F		
Original Part Number	Part Name	Classic Part Number
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
8N-5305	Spacer	363-7464
9W-9930	Mount As	295-6437

Sales Model XQ500

X5F		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-2514	Gear-Flywheel	421-7283
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5P-7807	Bearing-Ball	314-8502
6N-1931	Plunger	379-0171

X5F		
Original Part Number	Part Name	Classic Part Number
7C-0145	Core As-Oclr	374-4720
7N-2156	Bearing-Sleeve	380-7373
8S-6511	Bearing-Sleeve	380-7372
9F-3212	Bearing-Ball	384-5953
9N-3167	Plate-Block Bot	430-4468
9W-9930	Mount As	295-6437
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
131-7123	Bearing-Sleeve	422-6919

X5F		
Original Part Number	Part Name	Classic Part Number
133-3359	Manifold-Exhaust	419-4730
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170

Sales Model XQE500

S1P		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6N-1931	Plunger	379-0171
6V-2202	Bearing-Spl Ball	380-1574

S1P		
Original Part Number	Part Name	Classic Part Number
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7N-2156	Bearing-Sleeve	380-7373
8S-6511	Bearing-Sleeve	380-7372
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

S1P		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443

Sales Model XQP500

XP5		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6N-1931	Plunger	379-0171
6V-2202	Bearing-Spl Ball	380-1574

XP5		
Original Part Number	Part Name	Classic Part Number
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7N-2156	Bearing-Sleeve	380-7373
8S-6511	Bearing-Sleeve	380-7372
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

XP5		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443

Sales Model M318D

D9X		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
8B-5972	Bearing-Ball	314-8503

D9X		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
9F-3212	Bearing-Ball	384-5953
087-5548	Bearing-Sleeve	396-1568

D9X		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
134-8948	Plate	399-8588

W8R		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
8B-5972	Bearing-Ball	314-8503

W8R		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
9F-3212	Bearing-Ball	384-5953
087-5548	Bearing-Sleeve	396-1568

W8R		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319

Cat Classic Parts for Excavators

Cat excavators are built to last; however, As. the machine ages, the cost to Repair the machine is often re-evaluated. This is why Caterpillar offers the Cat Classic parts product Line. They are intended to help you manage your owning and operating costs towards the End of a product's life cycle. Cat Classic parts are available for several older models of excavators.

Cat Classic parts provide owners of older Cat products with low cost Repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts coverage for excavators includes:

- Engine
- Final Drive
- Linkage Pin
- Transmission Shafts/Gears
- Non-Moving U/C
- Pump Drive
- ...and many more.

Sales Model 205

3HC		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294

3HC		
Original Part Number	**Part Name**	**Classic Part Number**
6H-3957	Bearing-Ball	311-9358
8G-4189	Bearing-Aligning	295-6411

4DC		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
6H-3957	Bearing-Ball	311-9358

4DC		
Original Part Number	**Part Name**	**Classic Part Number**
7H-6967	Bearing-Ball	422-6489
8G-4189	Bearing-Aligning	295-6411

Sales Model 205B

5ZF		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498

5ZF		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-4689	Gasket-Cyl Head	377-5840

5ZF		
Original Part Number	**Part Name**	**Classic Part Number**
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025

Excavators

Sales Model 205B (Cont'd.)

5ZF		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9X-2192	Gasket Kit-Sch	393-5189
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926

5ZF		
Original Part Number	Part Name	Classic Part Number
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376

5ZF		
Original Part Number	Part Name	Classic Part Number
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model 206

2RC		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-0479	Bearing-Cone	380-7506
6H-3957	Bearing-Ball	311-9358

2RC		
Original Part Number	Part Name	Classic Part Number
6V-0832	Cone-Rlr Bearing	453-3654
7H-6967	Bearing-Ball	422-6489
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411

2RC		
Original Part Number	Part Name	Classic Part Number
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As	384-5959
121-7632	Disc-Clutch	394-9195
178-8608	Cone	422-6479

3GC		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-0479	Bearing-Cone	380-7506
6H-3957	Bearing-Ball	311-9358

3GC		
Original Part Number	Part Name	Classic Part Number
6V-0832	Cone-Rlr Bearing	453-3654
7H-6967	Bearing-Ball	422-6489
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411

3GC		
Original Part Number	Part Name	Classic Part Number
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As	384-5959
121-7632	Disc-Clutch	394-9195
178-8608	Cone	422-6479

Sales Model 206B

9BF		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384

Sales Model 206B (Cont'd.)

9BF		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2L-5271	Bearing-Ball	371-4305
2N-1599	Gear	378-3970
2S-0479	Bearing-Cone	380-7506
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-4689	Gasket-Cyl Head	377-5840
6V-0832	Cone-Rlr Bearing	453-3654
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025

9BF		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As	384-5959
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219

9BF		
Original Part Number	Part Name	Classic Part Number
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
121-7632	Disc-Clutch	394-9195
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
178-8608	Cone	422-6479
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model 211

4EC		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294

4EC		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
8G-4189	Bearing-Aligning	295-6411

5CC		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
6H-3957	Bearing-Ball	311-9358

5CC		
Original Part Number	Part Name	Classic Part Number
7H-6967	Bearing-Ball	422-6489
8G-4189	Bearing-Aligning	295-6411

Excavators

Sales Model 211B

6XG		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-4689	Gasket-Cyl Head	377-5840
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

6XG		
Original Part Number	Part Name	Classic Part Number
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069

6XG		
Original Part Number	Part Name	Classic Part Number
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model 212

3JC		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-0479	Bearing-Cone	380-7506
6H-3957	Bearing-Ball	311-9358

3JC		
Original Part Number	Part Name	Classic Part Number
6V-0832	Cone-Rlr Bearing	453-3654
7H-6967	Bearing-Ball	422-6489
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411

3JC		
Original Part Number	Part Name	Classic Part Number
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As	384-5959
121-7632	Disc-Clutch	394-9195
178-8608	Cone	422-6479

5DC		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-0479	Bearing-Cone	380-7506
6H-3957	Bearing-Ball	311-9358

5DC		
Original Part Number	Part Name	Classic Part Number
6V-0832	Cone-Rlr Bearing	453-3654
7H-6967	Bearing-Ball	422-6489
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411

5DC		
Original Part Number	Part Name	Classic Part Number
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As	384-5959
121-7632	Disc-Clutch	394-9195
178-8608	Cone	422-6479

Sales Model 212B

3PJ		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2L-5271	Bearing-Ball	371-4305
2N-1599	Gear	378-3970
2S-0479	Bearing-Cone	380-7506
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-4689	Gasket-Cyl Head	377-5840
6V-0832	Cone-Rlr Bearing	453-3654
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

3PJ		
Original Part Number	**Part Name**	**Classic Part Number**
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As	384-5959
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020

3PJ		
Original Part Number	**Part Name**	**Classic Part Number**
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
121-7632	Disc-Clutch	394-9195
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
178-8608	Cone	422-6479
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model 213

3ZC		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1T-0043	Bearing-Ball	390-5294

3ZC		
Original Part Number	**Part Name**	**Classic Part Number**
6H-3957	Bearing-Ball	311-9358
8G-4189	Bearing-Aligning	295-6411

9XB		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1T-0043	Bearing-Ball	390-5294

9XB		
Original Part Number	**Part Name**	**Classic Part Number**
6H-3957	Bearing-Ball	311-9358
8G-4189	Bearing-Aligning	295-6411

Excavators

Sales Model 213B

1EJ		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449

1EJ		
Original Part Number	**Part Name**	**Classic Part Number**
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7X-2522	Gasket Kit	437-8648
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
106-2822	Gasket Kit	436-8376
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219

1EJ		
Original Part Number	**Part Name**	**Classic Part Number**
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
286-2494	Kit-Gasket-Sch	387-2920
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model 214

1KB		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-7250	Bowl	360-2296
1T-0043	Bearing-Ball	390-5294
1T-0299	Cup-Roller Brg	422-6494
2D-9191	Cone-Roller Brg	374-1837

1KB		
Original Part Number	**Part Name**	**Classic Part Number**
2F-5721	Bearing-Ball	311-9354
6D-1734	Cup-Roller Brg	416-2171
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
8A-2251	Liner-Cylinder	376-9068

1KB		
Original Part Number	**Part Name**	**Classic Part Number**
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
030-0060	Bearing-Cup	415-1926

9MB		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-7250	Bowl	360-2296
1T-0043	Bearing-Ball	390-5294

9MB		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0299	Cup-Roller Brg	422-6494
2D-9191	Cone-Roller Brg	374-1837

9MB		
Original Part Number	**Part Name**	**Classic Part Number**
2F-5721	Bearing-Ball	311-9354
6D-1734	Cup-Roller Brg	416-2171
6H-3957	Bearing-Ball	311-9358

Sales Model 214 (Cont'd.)

9MB		
Original Part Number	Part Name	Classic Part Number
7H-6967	Bearing-Ball	422-6489
8B-5972	Bearing-Ball	314-8503

9MB		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411

9MB		
Original Part Number	Part Name	Classic Part Number
030-0060	Bearing-Cup	415-1926

Sales Model 214B

4CF		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1W-1064	Gear-Flywheel	374-4703
2D-9191	Cone-Roller Brg	374-1837
2L-5271	Bearing-Ball	371-4305
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025

4CF		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7X-2522	Gasket Kit	437-8648
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
106-2822	Gasket Kit	436-8376
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020

4CF		
Original Part Number	Part Name	Classic Part Number
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
286-2494	Kit-Gasket-Sch	387-2920
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

9MF		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1W-1064	Gear-Flywheel	374-4703
2D-9191	Cone-Roller Brg	374-1837
2L-5271	Bearing-Ball	371-4305

9MF		
Original Part Number	Part Name	Classic Part Number
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513

9MF		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443

Sales Model 214B (Cont'd.)

9MF		
Original Part Number	Part Name	Classic Part Number
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7X-2522	Gasket Kit	437-8648
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411

9MF		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
106-2822	Gasket Kit	436-8376
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336

9MF		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
286-2494	Kit-Gasket-Sch	387-2920
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model 215

14Z		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-2696	Cone-Bearing	374-1834
1P-3934	Cup-Roller Brg	420-6535

14Z		
Original Part Number	Part Name	Classic Part Number
1P-3935	Cone-Roller Brg	377-7397
1S-5331	Cylinder-Adj	226-0214
1T-0299	Cup-Roller Brg	422-6494
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558

14Z		
Original Part Number	Part Name	Classic Part Number
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2K-5065	Cone-Roller Brg	416-2157
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493

Sales Model 215 (Cont'd.)

14Z		
Original Part Number	Part Name	Classic Part Number
2N-3254	Cone-Roller Brg	380-7501
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-8986	Cup-Rlr Bearing	415-1912
2V-0706	Bearing-Sleeve	388-0637
2V-0707	Bearing-Sleeve	360-2328
2W-1223	Pump Gp-Water	385-7197
2W-8271	Arm As-Rocker	432-8912
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
3V-5257	Bracket-Carr Rlr	297-7149
3V-5317	Gear	231-0010
3V-6648	Pin As	308-9884
4E-3456	Lever As	367-6081
4E-7717	Shaft-Sprocket	432-6606
4E-9426	Collar	231-0000
4F-2393	Bearing-Ball	380-1499
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4T-9311	Housing	396-0652
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-9577	Shaft-Planet	231-0001
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5C-0857	Plate-Mating	376-3624
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003

14Z		
Original Part Number	Part Name	Classic Part Number
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer-Pin	299-2047
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5D-2989	Bearing	380-7511
5D-7449	Cup-Spl Tapered	416-2161
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5V-7222	Gear-Final Drive	231-0237
6A-7099	Bearing-Sleeve	388-0644
6A-7129	Bearing-Sleeve	301-3130
6A-7196	Pilot-Front	385-7200
6B-7469	Spacer	417-4535
6C-0739	Carrier As	231-0012
6C-1573	Rod	297-7238
6C-5062	Pinion	231-0016
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387

14Z		
Original Part Number	Part Name	Classic Part Number
6N-1553	Coupling-Exhaust	295-6422
6N-3256	Mount As	314-8688
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6V-6896	Rebuild Kit	390-1006
6Y-1690	Carrier-Ring	384-3849
6Y-3151	Stator-Converter	388-6562
6Y-4819	Carrier-Planet	296-1348
6Y-7909	Disc-Friction	374-4676
6Y-7956	Disc-Friction	374-4677
7C-7955	Gasket-Cover	382-6899
7E-5085	Bushing	377-5829
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-8893	Cone-Roller Brg	374-1846
7J-9708	Bearing-Sleeve	299-1964
7K-7237	Gear-Planet	231-0009
7K-8877	Cone-Bearing	374-1847
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-7219	Bearing-Thrust	384-4816
7N-0061	Muffler As	360-7889
7N-0691	Elbow-Water Rglt	378-3983
7N-3536	Gear-Fuel	279-4993
7N-5206	Mount As	374-1451
7N-7166	Race-Brg Thrust	417-4531
7P-2372	Joint As	367-6072
7T-3370	Yoke As	302-2702
7T-4753	Stator-Converter	384-5945
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207

Sales Model 215 (Cont'd.)

14Z		
Original Part Number	Part Name	Classic Part Number
7V-5981	Driver	231-0256
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8D-2256	Cone-Roller Brg	374-1848
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8J-6322	Cup-Roller Brg	399-4447
8J-6861	Bearing As	384-5950
8K-0509	Plate-Mating	382-5053
8K-1754	Spacer	231-0247
8K-4850	Cage-Bearing	451-0745
8M-6191	Sleeve-Bolt	226-0234
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3539	Plunger As-Pump	377-5861
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8P-0953	Turbine-Conv	297-7269
8P-0961	Impeller-Conv	433-9204
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579

14Z		
Original Part Number	Part Name	Classic Part Number
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9K-1171	Cup-Rlr Bearing	430-3339
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-6371	Rod-Eye	363-7459
9L-7682	Valve-Inlet	385-9266
9M-4789	Shaft-Gov Cont	297-7256
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398

14Z		
Original Part Number	Part Name	Classic Part Number
9P-8517	Case-Xmsn	394-0909
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-2400	Housing As	231-0249
9V-9408	Spring	425-9369
9W-3605	Carrier-Ring	314-8662
9W-6390	Sleeve	385-3795
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9Y-5168	Manifold-Exhaust	374-7483
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
119-5727	Bearing-Spl Ball	417-9491
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
136-7813	Bearing-Race	460-8296
206-6405	Bearing-Spl Ball	420-2503
289-2946	Seal-U-Cup	472-8030
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

57Y		
Original Part Number	Part Name	Classic Part Number
5C-5837	Retainer-Pin	299-2047

57Y		
Original Part Number	Part Name	Classic Part Number
7C-7955	Gasket-Cover	382-6899
7W-2059	Gasket-Cyl Hd	380-1548

61Z		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296

Sales Model 215 (Cont'd.)

61Z		
Original Part Number	Part Name	Classic Part Number
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2P-1757	Hub-Fan Pulley	296-1357
2V-0706	Bearing-Sleeve	388-0637
2V-0707	Bearing-Sleeve	360-2328
2W-1223	Pump Gp-Water	385-7197
2W-8271	Arm As-Rocker	432-8912
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3V-6648	Pin As	308-9884

61Z		
Original Part Number	Part Name	Classic Part Number
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4T-9311	Housing	396-0652
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5C-0857	Plate-Mating	376-3624
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer-Pin	299-2047
5P-7807	Bearing-Ball	314-8502
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
6A-7099	Bearing-Sleeve	388-0644
6A-7129	Bearing-Sleeve	301-3130
6C-5062	Pinion	231-0016
6N-1553	Coupling-Exhaust	295-6422
6N-3256	Mount As	314-8688
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-7909	Disc-Friction	374-4676
7C-7955	Gasket-Cover	382-6899
7E-5085	Bushing	377-5829
7J-8893	Cone-Roller Brg	374-1846
7M-7219	Bearing-Thrust	384-4816
7N-0061	Muffler As	360-7889
7N-0691	Elbow-Water Rglt	378-3983

61Z		
Original Part Number	Part Name	Classic Part Number
7N-3536	Gear-Fuel	279-4993
7N-5206	Mount As	374-1451
7N-7166	Race-Brg Thrust	417-4531
7P-2372	Joint As	367-6072
7V-5981	Driver	231-0256
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8J-6322	Cup-Roller Brg	399-4447
8J-6861	Bearing As	384-5950
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3539	Plunger As-Pump	377-5861
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
9K-8757	Rod End-Special	311-9361
9L-6371	Rod-Eye	363-7459
9L-7682	Valve-Inlet	385-9266
9M-4789	Shaft-Gov Cont	297-7256
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-2400	Housing As	231-0249
9W-6390	Sleeve	385-3795
9Y-5168	Manifold-Exhaust	374-7483
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
289-2946	Seal-U-Cup	472-8030

Sales Model 215 (Cont'd.)

95Z		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
2P-0220	Gasket-Pump	398-2927
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
5C-5837	Retainer-Pin	299-2047
5P-8768	Kit-Gasket (Scl)	393-1024

95Z		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6V-7459	Gasket Kit	391-1095
7N-8018	Seal-Water	418-1964
7N-8022	Gasket-Cyl Head	378-3985
8H-9789	Bearing-Ball	374-8342
9Y-1798	Seal-Water	379-0165
131-3815	Seal Gp-Basic	325-6193

95Z		
Original Part Number	Part Name	Classic Part Number
170-0566	Kit-Rebuild-Pump	377-5835
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
234-8013	Kit-Gasket-Sch	437-8650
391-8229	Kit-Gasket-Fs	398-2955

96L		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
5P-9514	Bearing-Ball	417-9467

96L		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
7N-1164	Mount As	295-5451

Sales Model 215B

2XC		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3576	Block Gp-Cyl	279-4978
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7936	Spider As-Fan	383-3673
1S-3062	Director-Water	418-9572
1T-0210	Bearing-Ball	417-4498
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755

2XC		
Original Part Number	Part Name	Classic Part Number
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513

2XC		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2K-5065	Cone-Roller Brg	416-2157
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1438	Pipe-Exh Ext	325-6157
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230

Sales Model 215B (Cont'd.)

2XC		
Original Part Number	Part Name	Classic Part Number
2P-5608	Pipe-Extension	367-6066
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2S-5551	Coupling-Exhaust	398-2934
2V-0706	Bearing-Sleeve	388-0637
2V-0707	Bearing-Sleeve	360-2328
2W-1223	Pump Gp-Water	385-7197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-3428	Muffler As	298-2784
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8271	Arm As-Rocker	432-8912
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3S-5017	Elbow-Exhaust	369-9498
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
3V-6648	Pin As	308-9884
4E-3456	Lever As	367-6081
4E-9426	Collar	231-0000
4F-2393	Bearing-Ball	380-1499
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-4161	Mount As	374-1448
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4N-8204	Mount As	374-1449
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008

2XC		
Original Part Number	Part Name	Classic Part Number
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-9311	Housing	396-0652
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5C-0857	Plate-Mating	376-3624
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer-Pin	299-2047
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917

2XC		
Original Part Number	Part Name	Classic Part Number
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6A-7099	Bearing-Sleeve	388-0644
6A-7129	Bearing-Sleeve	301-3130
6A-7196	Pilot-Front	385-7200
6B-7469	Spacer	417-4535
6C-0739	Carrier As	231-0012
6C-1573	Rod	297-7238
6C-5062	Pinion	231-0016
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935

Sales Model 215B (Cont'd.)

2XC		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6V-6896	Rebuild Kit	390-1006
6W-1958	Element	390-5284
6Y-1690	Carrier-Ring	384-3849
6Y-3151	Stator-Converter	388-6562
6Y-4819	Carrier-Planet	296-1348
6Y-7909	Disc-Friction	374-4676
7C-7955	Gasket-Cover	382-6899
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-8893	Cone-Roller Brg	374-1846
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0061	Muffler As	360-7889
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0691	Elbow-Water Rglt	378-3983
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5206	Mount As	374-1451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-2372	Joint As	367-6072
7P-3466	Bearing-Sleeve	422-9523
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417

2XC		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7T-3370	Yoke As	302-2702
7T-4753	Stator-Converter	384-5945
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-5981	Driver	231-0256
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-2256	Cone-Roller Brg	374-1848
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8J-6322	Cup-Roller Brg	399-4447
8J-6861	Bearing As	384-5950
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3753	Rod As-Conn	379-8867
8N-4110	Bearing-Sleeve	394-8207

2XC		
Original Part Number	Part Name	Classic Part Number
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6308	Bearing-Conn Rod	419-7267
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-0961	Impeller-Conv	433-9204
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217

Sales Model 215B (Cont'd.)

2XC		
Original Part Number	Part Name	Classic Part Number
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9K-1171	Cup-Rlr Bearing	430-3339
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-6371	Rod-Eye	363-7459
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5769	Cover-Housing	325-6050
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923

2XC		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-2400	Housing As	231-0249
9W-3605	Carrier-Ring	314-8662
9W-6390	Sleeve	385-3795
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
9Y-5168	Manifold-Exhaust	374-7483
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
119-5727	Bearing-Spl Ball	417-9491
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351

2XC		
Original Part Number	Part Name	Classic Part Number
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005

4FC		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298

4FC		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913

4FC		
Original Part Number	Part Name	Classic Part Number
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344

Sales Model 215B (Cont'd.)

4FC		
Original Part Number	Part Name	Classic Part Number
1P-2696	Cone-Bearing	374-1834
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1T-0210	Bearing-Ball	417-4498
1T-0299	Cup-Roller Brg	422-6494
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870

4FC		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2V-0706	Bearing-Sleeve	388-0637
2V-0707	Bearing-Sleeve	360-2328
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
3V-5257	Bracket-Carr Rlr	297-7149
3V-5317	Gear	231-0010
3V-6648	Pin As	308-9884
4E-7717	Shaft-Sprocket	432-6606
4E-9426	Collar	231-0000
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-4010	Muffler As	298-2788
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985

4FC		
Original Part Number	Part Name	Classic Part Number
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-9311	Housing	396-0652
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5C-0857	Plate-Mating	376-3624
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer-Pin	299-2047
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5D-7449	Cup-Spl Tapered	416-2161
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-7222	Gear-Final Drive	231-0237

Sales Model 215B (Cont'd.)

4FC		
Original Part Number	Part Name	Classic Part Number
6A-7099	Bearing-Sleeve	388-0644
6A-7129	Bearing-Sleeve	301-3130
6B-7469	Spacer	417-4535
6C-0739	Carrier As	231-0012
6C-5062	Pinion	231-0016
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200
6V-7459	Gasket Kit	391-1095
6W-1958	Element	390-5284
6Y-7909	Disc-Friction	374-4676
6Y-7956	Disc-Friction	374-4677
7C-2880	Bell As-Suction	380-1520
7C-3567	Mount As	314-8689
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985

4FC		
Original Part Number	Part Name	Classic Part Number
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7V-5981	Driver	231-0256
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8D-2256	Cone-Roller Brg	374-1848
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8J-6322	Cup-Roller Brg	399-4447
8J-6861	Bearing As	384-5950
8K-0509	Plate-Mating	382-5053
8K-1754	Spacer	231-0247
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8K-4850	Cage-Bearing	451-0745
8M-6191	Sleeve-Bolt	226-0234
8N-0081	Trunnion	393-5196
8N-0111	Mount As	374-1452
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210

4FC		
Original Part Number	Part Name	Classic Part Number
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8T-1606	Kit-Gskt-Sch	386-3046
9K-1171	Cup-Rlr Bearing	430-3339
9K-8757	Rod End-Special	311-9361
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-2400	Housing As	231-0249

Sales Model 215B (Cont'd.)

4FC		
Original Part Number	Part Name	Classic Part Number
9V-9408	Spring	425-9369
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353

4FC		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365

4FC		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-8013	Kit-Gasket-Sch	437-8650
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

4JC		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-2696	Cone-Bearing	374-1834
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-5331	Cylinder-Adj	226-0214
1T-0299	Cup-Roller Brg	422-6494
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859

4JC		
Original Part Number	Part Name	Classic Part Number
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2V-0706	Bearing-Sleeve	388-0637

4JC		
Original Part Number	Part Name	Classic Part Number
2V-0707	Bearing-Sleeve	360-2328
2W-1223	Pump Gp-Water	385-7197
2W-8271	Arm As-Rocker	432-8912
3H-8726	Mount As	385-7208
3V-5257	Bracket-Carr Rlr	297-7149
3V-5317	Gear	231-0010
3V-6648	Pin As	308-9884
4E-7717	Shaft-Sprocket	432-6606
4E-9426	Collar	231-0000
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4T-9311	Housing	396-0652
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5C-0857	Plate-Mating	376-3624
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222

Sales Model 215B (Cont'd.)

4JC		
Original Part Number	Part Name	Classic Part Number
5C-3715	Gear	231-0223
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer-Pin	299-2047
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5D-7449	Cup-Spl Tapered	416-2161
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5V-7222	Gear-Final Drive	231-0237
6A-7099	Bearing-Sleeve	388-0644
6A-7129	Bearing-Sleeve	301-3130
6C-0739	Carrier As	231-0012
6C-5062	Pinion	231-0016
6N-1553	Coupling-Exhaust	295-6422
6N-3256	Mount As	314-8688
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-7909	Disc-Friction	374-4676
6Y-7956	Disc-Friction	374-4677
7C-7955	Gasket-Cover	382-6899

4JC		
Original Part Number	Part Name	Classic Part Number
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-7219	Bearing-Thrust	384-4816
7N-0061	Muffler As	360-7889
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-7166	Race-Brg Thrust	417-4531
7P-2372	Joint As	367-6072
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8D-2256	Cone-Roller Brg	374-1848
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8J-6322	Cup-Roller Brg	399-4447
8J-6861	Bearing As	384-5950
8K-0509	Plate-Mating	382-5053
8K-1754	Spacer	231-0247
8K-4850	Cage-Bearing	451-0745
8M-6191	Sleeve-Bolt	226-0234

4JC		
Original Part Number	Part Name	Classic Part Number
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
9K-1171	Cup-Rlr Bearing	430-3339
9K-8757	Rod End-Special	311-9361
9L-6371	Rod-Eye	363-7459
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-2400	Housing As	231-0249
9V-9408	Spring	425-9369
9W-6390	Sleeve	385-3795
9Y-5168	Manifold-Exhaust	374-7483
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
289-2946	Seal-U-Cup	472-8030

9YB		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769

9YB		
Original Part Number	Part Name	Classic Part Number
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3062	Director-Water	418-9572
1T-0210	Bearing-Ball	417-4498
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158

9YB		
Original Part Number	Part Name	Classic Part Number
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

Sales Model 215B (Cont'd.)

9YB		
Original Part Number	Part Name	Classic Part Number
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2V-0706	Bearing-Sleeve	388-0637
2V-0707	Bearing-Sleeve	360-2328
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
3V-6648	Pin As	308-9884
4E-9426	Collar	231-0000
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720

9YB		
Original Part Number	Part Name	Classic Part Number
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-4010	Muffler As	298-2788
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-9311	Housing	396-0652
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5C-0857	Plate-Mating	376-3624
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer-Pin	299-2047

9YB		
Original Part Number	Part Name	Classic Part Number
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6A-7099	Bearing-Sleeve	388-0644
6A-7129	Bearing-Sleeve	301-3130
6A-7196	Pilot-Front	385-7200
6B-7469	Spacer	417-4535
6C-0739	Carrier As	231-0012
6C-1573	Rod	297-7238
6C-5062	Pinion	231-0016
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200
6V-7459	Gasket Kit	391-1095
6W-1958	Element	390-5284
6Y-7909	Disc-Friction	374-4676
7C-2880	Bell As-Suction	380-1520
7C-3567	Mount As	314-8689
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7J-8893	Cone-Roller Brg	374-1846

Sales Model 215B (Cont'd.)

9YB		
Original Part Number	Part Name	Classic Part Number
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7V-5981	Driver	231-0256
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8D-2256	Cone-Roller Brg	374-1848
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8J-6322	Cup-Roller Brg	399-4447
8J-6861	Bearing As	384-5950
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8N-0081	Trunnion	393-5196
8N-0111	Mount As	374-1452
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381

9YB		
Original Part Number	Part Name	Classic Part Number
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8T-1606	Kit-Gskt-Sch	386-3046
9K-1171	Cup-Rlr Bearing	430-3339
9K-8757	Rod End-Special	311-9361
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923

9YB		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-2400	Housing As	231-0249
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-8013	Kit-Gasket-Sch	437-8650
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351

Sales Model 215B (Cont'd.)

9YB		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2946	Seal-U-Cup	472-8030

9YB		
Original Part Number	Part Name	Classic Part Number
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349

9YB		
Original Part Number	Part Name	Classic Part Number
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 215C

4HG		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3062	Director-Water	418-9572
1T-0210	Bearing-Ball	417-4498
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

4HG		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2V-0706	Bearing-Sleeve	388-0637
2V-0707	Bearing-Sleeve	360-2328
2V-1722	Pin As	241-2525
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055

4HG		
Original Part Number	Part Name	Classic Part Number
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
4E-1065	Pin As	241-2538
4E-9426	Collar	231-0000
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-4010	Muffler As	298-2788
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777

Sales Model 215C (Cont'd.)

4HG		
Original Part Number	Part Name	Classic Part Number
4P-9964	Line As-Fuel Inj	298-2778
4T-9311	Housing	396-0652
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5C-0857	Plate-Mating	376-3624
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer-Pin	299-2047
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6A-7099	Bearing-Sleeve	388-0644
6A-7129	Bearing-Sleeve	301-3130
6A-7196	Pilot-Front	385-7200
6B-7469	Spacer	417-4535
6C-0739	Carrier As	231-0012
6C-1573	Rod	297-7238
6C-5062	Pinion	231-0016
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

4HG		
Original Part Number	Part Name	Classic Part Number
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6W-1958	Element	390-5284
6Y-7909	Disc-Friction	374-4676
7C-2880	Bell As-Suction	380-1520
7C-3567	Mount As	314-8689
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7J-8893	Cone-Roller Brg	374-1846
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7V-5981	Driver	231-0256
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8D-2256	Cone-Roller Brg	374-1848
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342

4HG		
Original Part Number	Part Name	Classic Part Number
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8J-6322	Cup-Roller Brg	399-4447
8J-6861	Bearing As	384-5950
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8N-0081	Trunnion	393-5196
8N-0111	Mount As	374-1452
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081

Sales Model 215C (Cont'd.)

4HG		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8R-7336	Bearing	301-3394
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8T-1606	Kit-Gskt-Sch	386-3046
9K-1171	Cup-Rlr Bearing	430-3339
9K-8425	Bearing-Sleeve	314-8638
9K-8757	Rod End-Special	311-9361
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042

4HG		
Original Part Number	**Part Name**	**Classic Part Number**
9U-2400	Housing As	231-0249
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484

4HG		
Original Part Number	**Part Name**	**Classic Part Number**
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 215D

9TF		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851

9TF		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3062	Director-Water	418-9572
1T-0210	Bearing-Ball	417-4498
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716

9TF		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354

Sales Model 215D (Cont'd.)

9TF		
Original Part Number	Part Name	Classic Part Number
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2V-0706	Bearing-Sleeve	388-0637
2V-1722	Pin As	241-2525
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
4E-1065	Pin As	241-2538
4E-9426	Collar	231-0000
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-4010	Muffler As	298-2788
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008

9TF		
Original Part Number	Part Name	Classic Part Number
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-9311	Housing	396-0652
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5C-0857	Plate-Mating	376-3624
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer-Pin	299-2047
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

9TF		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6A-7099	Bearing-Sleeve	388-0644
6A-7129	Bearing-Sleeve	301-3130
6A-7196	Pilot-Front	385-7200
6B-7469	Spacer	417-4535
6C-0739	Carrier As	231-0012
6C-1573	Rod	297-7238
6C-5062	Pinion	231-0016
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6W-1958	Element	390-5284
6Y-7909	Disc-Friction	374-4676
7C-2880	Bell As-Suction	380-1520
7C-3567	Mount As	314-8689
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7J-8893	Cone-Roller Brg	374-1846
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497

Sales Model 215D (Cont'd.)

9TF		
Original Part Number	Part Name	Classic Part Number
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7V-5981	Driver	231-0256
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8D-2256	Cone-Roller Brg	374-1848
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8J-6861	Bearing As	384-5950
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8L-4889	Shaft-Aux Drive	433-9212
8N-0081	Trunnion	393-5196
8N-0111	Mount As	374-1452
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200

9TF		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8R-7336	Bearing	301-3394
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8T-1606	Kit-Gskt-Sch	386-3046
9K-1171	Cup-Rlr Bearing	430-3339
9K-8425	Bearing-Sleeve	314-8638
9K-8757	Rod End-Special	311-9361
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-2400	Housing As	231-0249
9W-6390	Sleeve	385-3795

9TF		
Original Part Number	Part Name	Classic Part Number
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
174-0739	Gasket Kit - F	437-2012
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349

Sales Model 215D (Cont'd.)

9TF		
Original Part Number	Part Name	Classic Part Number
334-8389	Crankshaft As	242-3439

9TF		
Original Part Number	Part Name	Classic Part Number
337-0872	Crankshaft As	242-3440

Sales Model 219

5CF		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-2696	Cone-Bearing	374-1834
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1T-0210	Bearing-Ball	417-4498
1T-0299	Cup-Roller Brg	422-6494
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716

5CF		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2V-0706	Bearing-Sleeve	388-0637

5CF		
Original Part Number	Part Name	Classic Part Number
2V-0707	Bearing-Sleeve	360-2328
2V-1722	Pin As	241-2525
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
3V-5257	Bracket-Carr Rlr	297-7149
3V-5317	Gear	231-0010
4E-1065	Pin As	241-2538
4E-7717	Shaft-Sprocket	432-6606
4E-9426	Collar	231-0000
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-4010	Muffler As	298-2788
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985

Sales Model 219 (Cont'd.)

5CF		
Original Part Number	Part Name	Classic Part Number
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-9311	Housing	396-0652
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5C-0857	Plate-Mating	376-3624
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer-Pin	299-2047
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5D-7449	Cup-Spl Tapered	416-2161
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-7222	Gear-Final Drive	231-0237

5CF		
Original Part Number	Part Name	Classic Part Number
6A-7099	Bearing-Sleeve	388-0644
6A-7129	Bearing-Sleeve	301-3130
6B-7469	Spacer	417-4535
6C-0739	Carrier As	231-0012
6C-5062	Pinion	231-0016
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6W-1958	Element	390-5284
6Y-7909	Disc-Friction	374-4676
6Y-7956	Disc-Friction	374-4677
7C-2880	Bell As-Suction	380-1520
7C-3567	Mount As	314-8689
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438

5CF		
Original Part Number	Part Name	Classic Part Number
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7V-5981	Driver	231-0256
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8D-2256	Cone-Roller Brg	374-1848
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8J-6322	Cup-Roller Brg	399-4447
8J-6861	Bearing As	384-5950
8K-0509	Plate-Mating	382-5053
8K-1754	Spacer	231-0247
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8K-4850	Cage-Bearing	451-0745
8M-6191	Sleeve-Bolt	226-0234
8N-0081	Trunnion	393-5196
8N-0111	Mount As	374-1452
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

Sales Model 219 (Cont'd.)

5CF		
Original Part Number	Part Name	Classic Part Number
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8R-7336	Bearing	301-3394
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8T-1606	Kit-Gskt-Sch	386-3046

5CF		
Original Part Number	Part Name	Classic Part Number
9K-1171	Cup-Rlr Bearing	430-3339
9K-8425	Bearing-Sleeve	314-8638
9K-8757	Rod End-Special	311-9361
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-2400	Housing As	231-0249
9V-9408	Spring	425-9369
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

5CF		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 219D

5XG		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296

5XG		
Original Part Number	Part Name	Classic Part Number
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761

5XG		
Original Part Number	Part Name	Classic Part Number
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147

Sales Model 219D (Cont'd.)

5XG		
Original Part Number	Part Name	Classic Part Number
1P-2662	Cone-Roller Brg	374-1851
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-2696	Cone-Bearing	374-1834
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1T-0210	Bearing-Ball	417-4498
1T-0299	Cup-Roller Brg	422-6494
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844

5XG		
Original Part Number	Part Name	Classic Part Number
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2V-0706	Bearing-Sleeve	388-0637
2V-1722	Pin As	241-2525
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
3V-5257	Bracket-Carr Rlr	297-7149
3V-5317	Gear	231-0010
4E-1065	Pin As	241-2538
4E-7717	Shaft-Sprocket	432-6606
4E-9426	Collar	231-0000
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-4010	Muffler As	298-2788
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984

5XG		
Original Part Number	Part Name	Classic Part Number
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-9311	Housing	396-0652
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5C-0857	Plate-Mating	376-3624
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer-Pin	299-2047
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5D-7449	Cup-Spl Tapered	416-2161
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

Sales Model 219D (Cont'd.)

5XG		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
5V-7222	Gear-Final Drive	231-0237
6A-7099	Bearing-Sleeve	388-0644
6A-7129	Bearing-Sleeve	301-3130
6B-7469	Spacer	417-4535
6C-0739	Carrier As	231-0012
6C-5062	Pinion	231-0016
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-2466	Kit-Gasket-Fs	437-3211
6V-5976	Kit-Gasket (Rs)	393-5200
6W-1958	Element	390-5284
6Y-7909	Disc-Friction	374-4676
6Y-7956	Disc-Friction	374-4677
7C-2880	Bell As-Suction	380-1520
7C-3567	Mount As	314-8689
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531

5XG		
Original Part Number	Part Name	Classic Part Number
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7V-5981	Driver	231-0256
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8D-2256	Cone-Roller Brg	374-1848
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8J-6322	Cup-Roller Brg	399-4447
8J-6861	Bearing As	384-5950
8K-0509	Plate-Mating	382-5053
8K-1754	Spacer	231-0247
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8K-4850	Cage-Bearing	451-0745
8L-4889	Shaft-Aux Drive	433-9212
8M-6191	Sleeve-Bolt	226-0234
8N-0081	Trunnion	393-5196
8N-0111	Mount As	374-1452
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381

5XG		
Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8R-7336	Bearing	301-3394
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
9K-1171	Cup-Rlr Bearing	430-3339
9K-8425	Bearing-Sleeve	314-8638
9K-8757	Rod End-Special	311-9361

Sales Model 219D (Cont'd.)

5XG		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-2400	Housing As	231-0249
9V-9408	Spring	425-9369
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311

5XG		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687

5XG		
Original Part Number	Part Name	Classic Part Number
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 224

2JC		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1M-7250	Bowl	360-2296
1T-0043	Bearing-Ball	390-5294
1T-0299	Cup-Roller Brg	422-6494

2JC		
Original Part Number	Part Name	Classic Part Number
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
6H-3957	Bearing-Ball	311-9358

2JC		
Original Part Number	Part Name	Classic Part Number
7H-6967	Bearing-Ball	422-6489
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411

5TC		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1M-7250	Bowl	360-2296
1T-0043	Bearing-Ball	390-5294
1T-0299	Cup-Roller Brg	422-6494

5TC		
Original Part Number	Part Name	Classic Part Number
2D-9191	Cone-Roller Brg	374-1837
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489

5TC		
Original Part Number	Part Name	Classic Part Number
8A-2251	Liner-Cylinder	376-9068
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411

Sales Model 224B

7WF		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1W-1064	Gear-Flywheel	374-4703
2D-9191	Cone-Roller Brg	374-1837
2L-5271	Bearing-Ball	371-4305
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025

7WF		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7X-2522	Gasket Kit	437-8648
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
106-2822	Gasket Kit	436-8376
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020

7WF		
Original Part Number	Part Name	Classic Part Number
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
286-2494	Kit-Gasket-Sch	387-2920
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model 225

20S		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902

20S		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-7115	Mount As	418-1936
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572

20S		
Original Part Number	Part Name	Classic Part Number
1S-5331	Cylinder-Adj	226-0214
1U-2738	Piston Assembly	367-6074
1W-1219	Trunnion As	314-8724
1W-2572	Muffler As.	247-2663
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

Sales Model 225 (Cont'd.)

20S		
Original Part Number	Part Name	Classic Part Number
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2V-1722	Pin As	241-2525
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
3G-6910	Bearing-Plate	419-4733
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3V-5148	Pinion-Swing Gr	231-0251
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709

20S		
Original Part Number	Part Name	Classic Part Number
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
5C-6739	Bearing-Sleeve	445-7704
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-3964	Muffler As	360-7884
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6Y-7956	Disc-Friction	374-4677
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7K-8877	Cone-Bearing	374-1847
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173

20S		
Original Part Number	Part Name	Classic Part Number
7N-2874	Line As-Fuel Inj	298-2779
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7V-5979	Gear	231-0238
7V-5981	Driver	231-0256
7W-0508	Gear-Fp Drive	296-1351
7W-5687	Hub-Cshft	314-8684
8H-7980	Piston	226-0249
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8K-0455	Pin	241-2547
8K-0509	Plate-Mating	382-5053
8K-0533	Bearing-Sleeve	314-8637
8K-1754	Spacer	231-0247
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8M-6191	Sleeve-Bolt	226-0234
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711

Sales Model 225 (Cont'd.)

20S		
Original Part Number	Part Name	Classic Part Number
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831

20S		
Original Part Number	Part Name	Classic Part Number
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-2632	Pin As	241-2523
9B-1320	Valve-Check	377-5832
9C-4912	Pin As	241-2517
9L-2685	Rod End	419-1866
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9V-9408	Spring	425-9369
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125

20S		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2946	Seal-U-Cup	472-8030
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

51U		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1P-0963	Guard As-Roller	226-0179
1P-2636	Cup-Roller Brg	396-4147

51U		
Original Part Number	Part Name	Classic Part Number
1P-2662	Cone-Roller Brg	374-1851
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-2696	Cone-Bearing	374-1834
1P-8554	Coupling-Exhaust	325-6052
1S-5331	Cylinder-Adj	226-0214
1T-0210	Bearing-Ball	417-4498
1T-0299	Cup-Roller Brg	422-6494
1U-2738	Piston Assembly	367-6074

51U		
Original Part Number	Part Name	Classic Part Number
1U-3998	Seal As	472-8005
1W-2572	Muffler As.	247-2663
1W-6987	Valve As-Check	420-6221
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2K-6413	Pin	360-2270

Sales Model 225 (Cont'd.)

51U		
Original Part Number	Part Name	Classic Part Number
2N-2139	Cone-Roller Brg	415-1911
2P-1370	Cup-Rlr Brg	384-5921
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2V-0705	Pin As	241-2524
2V-0706	Bearing-Sleeve	388-0637
2V-0707	Bearing-Sleeve	360-2328
2V-1722	Pin As	241-2525
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
3D-9126	Cup-Roller Brg	399-4435
3G-6910	Bearing-Plate	419-4733
3J-2903	Cover	422-6922
3K-4290	Rod End	374-1823
3P-1210	Cone-Roller Brg	399-4433
3V-4643	Rod As	389-6333
3V-5148	Pinion-Swing Gr	231-0251
3V-5257	Bracket-Carr Rlr	297-7149
3V-5317	Gear	231-0010
4D-0487	Valve As-Check	375-4334
4E-7717	Shaft-Sprocket	432-6606
4E-9426	Collar	231-0000
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4P-7688	Valve As-Check	420-6216
5C-0857	Plate-Mating	376-3624
5C-1834	Gear	231-0002
5C-6739	Bearing-Sleeve	445-7704
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5D-7449	Cup-Spl Tapered	416-2161
5L-6326	Bearing-Ball	420-3222

51U		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8545	Gasket Kit	437-8626
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5V-7222	Gear-Final Drive	231-0237
6A-7099	Bearing-Sleeve	388-0644
6B-7469	Spacer	417-4535
6C-0739	Carrier As	231-0012
6N-3256	Mount As	314-8688
6V-2202	Bearing-Spl Ball	380-1574
6V-2909	Gasket Kit - F	388-0652
6V-6894	Rebuild Kt-Pump	383-3696
6W-1958	Element	390-5284
6Y-7909	Disc-Friction	374-4676
6Y-7956	Disc-Friction	374-4677
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-5663	Muffler As	247-2667
7E-7894	Bearing-Rod	419-7260
7H-4566	Cup-Roller Brg	399-6068
7K-8877	Cone-Bearing	374-1847
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-7219	Bearing-Thrust	384-4816
7V-5979	Gear	231-0238
7V-5981	Driver	231-0256
7W-2059	Gasket-Cyl Hd	380-1548
8D-2256	Cone-Roller Brg	374-1848
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8K-0455	Pin	241-2547

51U		
Original Part Number	Part Name	Classic Part Number
8K-0509	Plate-Mating	382-5053
8K-0533	Bearing-Sleeve	314-8637
8K-1754	Spacer	231-0247
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-2518	Joint As	231-0267
8K-4850	Cage-Bearing	451-0745
8M-6191	Sleeve-Bolt	226-0234
8N-0701	Bearing-Sleeve	419-4745
8N-9523	Elbow	425-2566
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8V-2632	Pin As	241-2523
8V-2634	Pin As	241-2518
9B-1320	Valve-Check	377-5832
9C-4737	Pin As	241-2520
9C-4912	Pin As	241-2517
9C-6187	Pin As	241-2521
9K-1171	Cup-Rlr Bearing	430-3339
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-5920	Bearing-Conn Rod	419-6383
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9U-0654	Coupling	297-7167
9V-9408	Spring	425-9369
9W-6390	Sleeve	385-3795
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935

Sales Model 225 (Cont'd.)

51U		
Original Part Number	Part Name	Classic Part Number
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939

51U		
Original Part Number	Part Name	Classic Part Number
005-4834	Cone-Rlr Bearing	422-6490
114-0468	Pin-G.E.T.	443-1203
119-6772	Valve-Exhaust	384-8699

51U		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
124-3237	Precleaner As	432-4220
234-7989	Kit-Gasket-Sch	437-8122
289-2946	Seal-U-Cup	472-8030

61X		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1T-0210	Bearing-Ball	417-4498
1U-2738	Piston Assembly	367-6074
1W-2572	Muffler As.	247-2663
1W-6987	Valve As-Check	420-6221
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2V-0705	Pin As	241-2524
2V-0706	Bearing-Sleeve	388-0637
2V-0707	Bearing-Sleeve	360-2328
2V-1722	Pin As	241-2525
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
3D-9126	Cup-Roller Brg	399-4435
3G-6910	Bearing-Plate	419-4733
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
3V-5148	Pinion-Swing Gr	231-0251
4D-0487	Valve As-Check	375-4334
4N-0209	Bonnet-Valve	378-3973

61X		
Original Part Number	Part Name	Classic Part Number
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4P-7688	Valve As-Check	420-6216
5C-6739	Bearing-Sleeve	445-7704
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8545	Gasket Kit	437-8626
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
6N-3256	Mount As	314-8688
6V-2202	Bearing-Spl Ball	380-1574
6V-2909	Gasket Kit - F	388-0652
6V-6894	Rebuild Kt-Pump	383-3696
6W-1958	Element	390-5284
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7V-5979	Gear	231-0238
7V-5981	Driver	231-0256
7W-2059	Gasket-Cyl Hd	380-1548
8H-2810	Case As-Filter	314-8512
8J-4411	Bearing-Aligning	384-4815
8K-0455	Pin	241-2547

61X		
Original Part Number	Part Name	Classic Part Number
8K-0533	Bearing-Sleeve	314-8637
8K-2518	Joint As	231-0267
8N-0701	Bearing-Sleeve	419-4745
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-2632	Pin As	241-2523
8V-2634	Pin As	241-2518
9B-1320	Valve-Check	377-5832
9C-4737	Pin As	241-2520
9C-4912	Pin As	241-2517
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-6390	Sleeve	385-3795
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
114-0468	Pin-G.E.T.	443-1203
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311

Sales Model 225 (Cont'd.)

61X		
Original Part Number	**Part Name**	**Classic Part Number**
234-7989	Kit-Gasket-Sch	437-8122

61X		
Original Part Number	**Part Name**	**Classic Part Number**
289-2946	Seal-U-Cup	472-8030

76U		
Original Part Number	**Part Name**	**Classic Part Number**
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-2696	Cone-Bearing	374-1834
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1T-0210	Bearing-Ball	417-4498
1T-0299	Cup-Roller Brg	422-6494
1U-2738	Piston Assembly	367-6074
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2572	Muffler As.	247-2663
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981

76U		
Original Part Number	**Part Name**	**Classic Part Number**
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2V-0705	Pin As	241-2524
2V-0706	Bearing-Sleeve	388-0637
2V-0707	Bearing-Sleeve	360-2328
2V-1722	Pin As	241-2525
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892

76U		
Original Part Number	**Part Name**	**Classic Part Number**
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-6910	Bearing-Plate	419-4733
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3V-5148	Pinion-Swing Gr	231-0251
3V-5257	Bracket-Carr Rlr	297-7149
3V-5317	Gear	231-0010
4D-0487	Valve As-Check	375-4334
4E-7717	Shaft-Sprocket	432-6606
4E-9426	Collar	231-0000
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

Sales Model 225 (Cont'd.)

76U		
Original Part Number	Part Name	Classic Part Number
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5C-0857	Plate-Mating	376-3624
5C-1834	Gear	231-0002
5C-6739	Bearing-Sleeve	445-7704
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5D-7449	Cup-Spl Tapered	416-2161
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-7222	Gear-Final Drive	231-0237
6B-7469	Spacer	417-4535
6C-0739	Carrier As	231-0012
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422

76U		
Original Part Number	Part Name	Classic Part Number
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-7459	Gasket Kit	391-1095
6W-1958	Element	390-5284
6Y-7909	Disc-Friction	374-4676
6Y-7956	Disc-Friction	374-4677
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-9980	Camshaft	377-5851
7K-8877	Cone-Bearing	374-1847
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7V-5979	Gear	231-0238
7V-5981	Driver	231-0256
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8D-2256	Cone-Roller Brg	374-1848
8H-2810	Case As-Filter	314-8512

76U		
Original Part Number	Part Name	Classic Part Number
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-0533	Bearing-Sleeve	314-8637
8K-1754	Spacer	231-0247
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8K-4850	Cage-Bearing	451-0745
8M-6191	Sleeve-Bolt	226-0234
8N-0081	Trunnion	393-5196
8N-0111	Mount As	374-1452
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290

Sales Model 225 (Cont'd.)

76U		
Original Part Number	**Part Name**	**Classic Part Number**
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8V-2632	Pin As	241-2523
8V-2634	Pin As	241-2518
9C-4737	Pin As	241-2520
9C-4912	Pin As	241-2517
9C-6187	Pin As	241-2521
9K-1171	Cup-Rlr Bearing	430-3339
9K-8757	Rod End-Special	311-9361

76U		
Original Part Number	**Part Name**	**Classic Part Number**
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167
9V-9408	Spring	425-9369
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353

76U		
Original Part Number	**Part Name**	**Classic Part Number**
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
174-0739	Gasket Kit - F	437-2012
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-7996	Kit-Gasket-Sch	437-8665
234-8013	Kit-Gasket-Sch	437-8650
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 225B

2ZD		
Original Part Number	**Part Name**	**Classic Part Number**
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883

2ZD		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913

2ZD		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-2696	Cone-Bearing	374-1834

Sales Model 225B (Cont'd.)

2ZD		
Original Part Number	Part Name	Classic Part Number
1P-8554	Coupling-Exhaust	325-6052
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1T-0210	Bearing-Ball	417-4498
1T-0299	Cup-Roller Brg	422-6494
1U-2738	Piston Assembly	367-6074
1U-3998	Seal As	472-8005
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2572	Muffler As.	247-2663
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

2ZD		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2V-0705	Pin As	241-2524
2V-0706	Bearing-Sleeve	388-0637
2V-0707	Bearing-Sleeve	360-2328
2V-1722	Pin As	241-2525
2W-1225	Pump Gp-Water	380-7532
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8271	Arm As-Rocker	432-8912
3D-9126	Cup-Roller Brg	399-4435
3G-6910	Bearing-Plate	419-4733
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3V-5148	Pinion-Swing Gr	231-0251
3V-5257	Bracket-Carr Rlr	297-7149
3V-5317	Gear	231-0010
4D-0487	Valve As-Check	375-4334
4E-7717	Shaft-Sprocket	432-6606
4E-9426	Collar	231-0000
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764

2ZD		
Original Part Number	Part Name	Classic Part Number
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-1684	Bearing	377-7428
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5C-0857	Plate-Mating	376-3624
5C-1834	Gear	231-0002
5C-3784	Pin As	241-2512
5C-5829	Pin As	241-2510
5C-5837	Retainer-Pin	299-2047
5C-6739	Bearing-Sleeve	445-7704
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5D-7449	Cup-Spl Tapered	416-2161
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502

Sales Model 225B (Cont'd.)

2ZD		
Original Part Number	Part Name	Classic Part Number
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-7222	Gear-Final Drive	231-0237
6A-7099	Bearing-Sleeve	388-0644
6A-7129	Bearing-Sleeve	301-3130
6B-7469	Spacer	417-4535
6C-0739	Carrier As	231-0012
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-6894	Rebuild Kt-Pump	383-3696
6V-9729	Gasket Kit - F	393-5195
6W-1958	Element	390-5284
6Y-7909	Disc-Friction	374-4676
6Y-7956	Disc-Friction	374-4677
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-5663	Muffler As	247-2667
7E-7894	Bearing-Rod	419-7260

2ZD		
Original Part Number	Part Name	Classic Part Number
7E-9980	Camshaft	377-5851
7K-8877	Cone-Bearing	374-1847
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7V-5979	Gear	231-0238
7V-5981	Driver	231-0256
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8D-2256	Cone-Roller Brg	374-1848
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8J-6861	Bearing As	384-5950
8K-0509	Plate-Mating	382-5053
8K-0533	Bearing-Sleeve	314-8637
8K-1754	Spacer	231-0247
8K-2082	Spring-Recoil	388-6560

2ZD		
Original Part Number	Part Name	Classic Part Number
8K-2198	Cylinder	382-5062
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8K-4850	Cage-Bearing	451-0745
8M-6191	Sleeve-Bolt	226-0234
8N-0081	Trunnion	393-5196
8N-0111	Mount As	374-1452
8N-0701	Bearing-Sleeve	419-4745
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081

Sales Model 225B (Cont'd.)

2ZD		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9523	Elbow	425-2566
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8V-2632	Pin As	241-2523
8V-2634	Pin As	241-2518
9C-4737	Pin As	241-2520
9C-4912	Pin As	241-2517
9C-6187	Pin As	241-2521
9K-1171	Cup-Rlr Bearing	430-3339
9K-8425	Bearing-Sleeve	314-8638
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5769	Cover-Housing	325-6050
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914

2ZD		
Original Part Number	**Part Name**	**Classic Part Number**
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167
9V-9408	Spring	425-9369
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

2ZD		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

3YD		
Original Part Number	**Part Name**	**Classic Part Number**
1B-6577	Cone-Spl Tapered	374-1839
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761

3YD		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-2696	Cone-Bearing	374-1834

3YD		
Original Part Number	**Part Name**	**Classic Part Number**
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1T-0210	Bearing-Ball	417-4498
1T-0299	Cup-Roller Brg	422-6494
1U-2738	Piston Assembly	367-6074
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

Sales Model 225B (Cont'd.)

3YD		
Original Part Number	Part Name	Classic Part Number
1W-2572	Muffler As.	247-2663
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2V-0705	Pin As	241-2524
2V-0706	Bearing-Sleeve	388-0637
2V-0707	Bearing-Sleeve	360-2328
2V-1722	Pin As	241-2525
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357

3YD		
Original Part Number	Part Name	Classic Part Number
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-3521	Bearing	380-7513
3G-6910	Bearing-Plate	419-4733
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3V-5148	Pinion-Swing Gr	231-0251
3V-5257	Bracket-Carr Rlr	297-7149
3V-5317	Gear	231-0010
4D-0487	Valve As-Check	375-4334
4E-7717	Shaft-Sprocket	432-6606
4E-9426	Collar	231-0000
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116

3YD		
Original Part Number	Part Name	Classic Part Number
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-1684	Bearing	377-7428
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5C-1834	Gear	231-0002
5C-3784	Pin As	241-2512
5C-5829	Pin As	241-2510
5C-5837	Retainer-Pin	299-2047
5C-6739	Bearing-Sleeve	445-7704
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5D-7449	Cup-Spl Tapered	416-2161
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-7222	Gear-Final Drive	231-0237
6A-7099	Bearing-Sleeve	388-0644
6A-7129	Bearing-Sleeve	301-3130
6B-7469	Spacer	417-4535
6C-0739	Carrier As	231-0012
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

Sales Model 225B (Cont'd.)

3YD		
Original Part Number	Part Name	Classic Part Number
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6W-1958	Element	390-5284
6Y-7956	Disc-Friction	374-4677
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-9980	Camshaft	377-5851
7K-8877	Cone-Bearing	374-1847
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7V-5979	Gear	231-0238
7V-5981	Driver	231-0256
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8D-2256	Cone-Roller Brg	374-1848
8H-2810	Case As-Filter	314-8512

3YD		
Original Part Number	Part Name	Classic Part Number
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8J-6861	Bearing As	384-5950
8K-0509	Plate-Mating	382-5053
8K-0533	Bearing-Sleeve	314-8637
8K-1754	Spacer	231-0247
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8K-4850	Cage-Bearing	451-0745
8M-6191	Sleeve-Bolt	226-0234
8N-0081	Trunnion	393-5196
8N-0111	Mount As	374-1452
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290

3YD		
Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8T-1606	Kit-Gskt-Sch	386-3046
8V-2632	Pin As	241-2523
8V-2634	Pin As	241-2518
9C-4737	Pin As	241-2520
9C-4912	Pin As	241-2517
9C-6187	Pin As	241-2521
9K-1171	Cup-Rlr Bearing	430-3339
9K-8425	Bearing-Sleeve	314-8638
9K-8757	Rod End-Special	311-9361
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-9408	Spring	425-9369
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833

Sales Model 225B (Cont'd.)

3YD		
Original Part Number	Part Name	Classic Part Number
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

3YD		
Original Part Number	Part Name	Classic Part Number
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
174-0739	Gasket Kit - F	437-2012
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

3YD		
Original Part Number	Part Name	Classic Part Number
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 225D

2SJ		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-2696	Cone-Bearing	374-1834
1P-8554	Coupling-Exhaust	325-6052
1S-5331	Cylinder-Adj	226-0214
1T-0210	Bearing-Ball	417-4498
1T-0299	Cup-Roller Brg	422-6494
1W-6356	Gasket	438-1795
1W-6987	Valve As-Check	420-6221

2SJ		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2V-0706	Bearing-Sleeve	388-0637
2V-0707	Bearing-Sleeve	360-2328
2V-1722	Pin As	241-2525
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
3V-5148	Pinion-Swing Gr	231-0251

2SJ		
Original Part Number	Part Name	Classic Part Number
3V-5257	Bracket-Carr Rlr	297-7149
3V-5317	Gear	231-0010
4D-0487	Valve As-Check	375-4334
4E-7717	Shaft-Sprocket	432-6606
4E-9426	Collar	231-0000
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4P-7688	Valve As-Check	420-6216
4T-1684	Bearing	377-7428
5C-1834	Gear	231-0002
5C-3784	Pin As	241-2512
5C-5829	Pin As	241-2510
5C-5837	Retainer-Pin	299-2047
5C-6739	Bearing-Sleeve	445-7704

Sales Model 225D (Cont'd.)

2SJ		
Original Part Number	Part Name	Classic Part Number
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5D-7449	Cup-Spl Tapered	416-2161
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5V-7222	Gear-Final Drive	231-0237
6A-7099	Bearing-Sleeve	388-0644
6A-7129	Bearing-Sleeve	301-3130
6C-0739	Carrier As	231-0012
6N-3256	Mount As	314-8688
6V-2202	Bearing-Spl Ball	380-1574
6V-6894	Rebuild Kt-Pump	383-3696
6V-9729	Gasket Kit - F	393-5195
6W-1958	Element	390-5284
6Y-7956	Disc-Friction	374-4677
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863

2SJ		
Original Part Number	Part Name	Classic Part Number
7E-5663	Muffler As	247-2667
7E-7894	Bearing-Rod	419-7260
7K-8877	Cone-Bearing	374-1847
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
7V-5979	Gear	231-0238
7V-5981	Driver	231-0256
7W-2059	Gasket-Cyl Hd	380-1548
8D-2256	Cone-Roller Brg	374-1848
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8J-6861	Bearing As	384-5950
8K-0509	Plate-Mating	382-5053
8K-1754	Spacer	231-0247
8K-2518	Joint As	231-0267
8K-4850	Cage-Bearing	451-0745
8M-6191	Sleeve-Bolt	226-0234
8N-0701	Bearing-Sleeve	419-4745
8N-9523	Elbow	425-2566
8S-9075	Bearing-Cone	418-9612

2SJ		
Original Part Number	Part Name	Classic Part Number
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8V-2632	Pin As	241-2523
8V-2634	Pin As	241-2518
9C-4737	Pin As	241-2520
9K-1171	Cup-Rlr Bearing	430-3339
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9V-9408	Spring	425-9369
9W-6390	Sleeve	385-3795
114-0468	Pin-G.E.T.	443-1203
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
124-3237	Precleaner As	432-4220
242-9834	Kit-Gasket-Mch	387-2923
289-2946	Seal-U-Cup	472-8030

6RG		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902

6RG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-2696	Cone-Bearing	374-1834
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1T-0210	Bearing-Ball	417-4498
1T-0299	Cup-Roller Brg	422-6494

6RG		
Original Part Number	Part Name	Classic Part Number
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2572	Muffler As.	247-2663
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

Sales Model 225D (Cont'd.)

6RG		
Original Part Number	Part Name	Classic Part Number
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2V-0706	Bearing-Sleeve	388-0637
2V-0707	Bearing-Sleeve	360-2328
2V-1722	Pin As	241-2525
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-3521	Bearing	380-7513
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356

6RG		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
3V-5148	Pinion-Swing Gr	231-0251
3V-5257	Bracket-Carr Rlr	297-7149
3V-5317	Gear	231-0010
4D-0487	Valve As-Check	375-4334
4E-7717	Shaft-Sprocket	432-6606
4E-9426	Collar	231-0000
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-1684	Bearing	377-7428
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882

6RG		
Original Part Number	Part Name	Classic Part Number
5C-1834	Gear	231-0002
5C-5829	Pin As	241-2510
5C-5837	Retainer-Pin	299-2047
5C-6739	Bearing-Sleeve	445-7704
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5D-7449	Cup-Spl Tapered	416-2161
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-7222	Gear-Final Drive	231-0237
6A-7099	Bearing-Sleeve	388-0644
6A-7129	Bearing-Sleeve	301-3130
6B-7469	Spacer	417-4535
6C-0739	Carrier As	231-0012
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6W-1958	Element	390-5284
6Y-7956	Disc-Friction	374-4677
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151

Sales Model 225D (Cont'd.)

6RG		
Original Part Number	Part Name	Classic Part Number
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-9980	Camshaft	377-5851
7K-8877	Cone-Bearing	374-1847
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7V-5979	Gear	231-0238
7V-5981	Driver	231-0256
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8D-2256	Cone-Roller Brg	374-1848
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8J-6861	Bearing As	384-5950
8K-0509	Plate-Mating	382-5053
8K-1754	Spacer	231-0247

6RG		
Original Part Number	Part Name	Classic Part Number
8K-2518	Joint As	231-0267
8K-4850	Cage-Bearing	451-0745
8M-6191	Sleeve-Bolt	226-0234
8N-0081	Trunnion	393-5196
8N-0111	Mount As	374-1452
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084

6RG		
Original Part Number	Part Name	Classic Part Number
8R-7336	Bearing	301-3394
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8T-1606	Kit-Gskt-Sch	386-3046
8T-9486	Gasket Kt	393-5197
8V-2632	Pin As	241-2523
8V-2634	Pin As	241-2518
9C-4737	Pin As	241-2520
9K-1171	Cup-Rlr Bearing	430-3339
9K-8757	Rod End-Special	311-9361
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-9408	Spring	425-9369
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

Sales Model 225D (Cont'd.)

6RG		
Original Part Number	**Part Name**	**Classic Part Number**
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

6RG		
Original Part Number	**Part Name**	**Classic Part Number**
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
174-0739	Gasket Kit - F	437-2012
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	295-6438

6RG		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 229

1AG		
Original Part Number	**Part Name**	**Classic Part Number**
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-2696	Cone-Bearing	374-1834
1S-3062	Director-Water	418-9572
1T-0210	Bearing-Ball	417-4498
1T-0299	Cup-Roller Brg	422-6494
1W-1219	Trunnion As	314-8724
1W-2572	Muffler As.	247-2663
1W-2870	Shaft As-Balance	314-8715

1AG		
Original Part Number	**Part Name**	**Classic Part Number**
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

1AG		
Original Part Number	**Part Name**	**Classic Part Number**
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2V-0705	Pin As	241-2524
2V-0706	Bearing-Sleeve	388-0637
2V-0707	Bearing-Sleeve	360-2328
2V-1722	Pin As	241-2525
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3V-5148	Pinion-Swing Gr	231-0251
3V-5317	Gear	231-0010
4D-0487	Valve As-Check	375-4334
4E-7717	Shaft-Sprocket	432-6606
4E-9426	Collar	231-0000

Sales Model 229 (Cont'd.)

1AG		
Original Part Number	Part Name	Classic Part Number
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-1684	Bearing	377-7428
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5C-1834	Gear	231-0002
5C-6739	Bearing-Sleeve	445-7704
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467

1AG		
Original Part Number	Part Name	Classic Part Number
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-7222	Gear-Final Drive	231-0237
6B-7469	Spacer	417-4535
6C-0739	Carrier As	231-0012
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200
6W-1958	Element	390-5284
6Y-7956	Disc-Friction	374-4677
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-9980	Camshaft	377-5851
7K-8877	Cone-Bearing	374-1847
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497

1AG		
Original Part Number	Part Name	Classic Part Number
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8D-2256	Cone-Roller Brg	374-1848
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-0533	Bearing-Sleeve	314-8637
8K-1754	Spacer	231-0247
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-4850	Cage-Bearing	451-0745
8N-0081	Trunnion	393-5196
8N-0111	Mount As	374-1452
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200

Sales Model 229 (Cont'd.)

1AG		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8V-2632	Pin As	241-2523
8V-2634	Pin As	241-2518

1AG		
Original Part Number	Part Name	Classic Part Number
9C-4737	Pin As	241-2520
9C-4912	Pin As	241-2517
9C-6187	Pin As	241-2521
9K-1171	Cup-Rlr Bearing	430-3339
9K-8425	Bearing-Sleeve	314-8638
9K-8757	Rod End-Special	311-9361
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351

1AG		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
174-0739	Gasket Kit - F	437-2012
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-8013	Kit-Gasket-Sch	437-8650
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

1GF		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883

1GF		
Original Part Number	Part Name	Classic Part Number
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-2696	Cone-Bearing	374-1834
1P-8554	Coupling-Exhaust	325-6052

1GF		
Original Part Number	Part Name	Classic Part Number
1S-5331	Cylinder-Adj	226-0214
1T-0210	Bearing-Ball	417-4498
1T-0299	Cup-Roller Brg	422-6494
1U-3998	Seal As	472-8005
1V-9148	Bearing-Sleeve	308-9811
1W-2572	Muffler As.	247-2663
1W-6987	Valve As-Check	420-6221

Sales Model 229 (Cont'd.)

1GF		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2V-0705	Pin As	241-2524
2V-0706	Bearing-Sleeve	388-0637
2V-0707	Bearing-Sleeve	360-2328
2V-1722	Pin As	241-2525
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
3D-9126	Cup-Roller Brg	399-4435
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
3V-5148	Pinion-Swing Gr	231-0251
3V-5257	Bracket-Carr Rlr	297-7149
3V-5317	Gear	231-0010
4D-0487	Valve As-Check	375-4334
4E-7717	Shaft-Sprocket	432-6606
4E-9426	Collar	231-0000
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4P-7688	Valve As-Check	420-6216
4T-1684	Bearing	377-7428
5C-1834	Gear	231-0002
5C-6739	Bearing-Sleeve	445-7704
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006

1GF		
Original Part Number	Part Name	Classic Part Number
5D-7449	Cup-Spl Tapered	416-2161
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5V-7222	Gear-Final Drive	231-0237
6B-7469	Spacer	417-4535
6C-0739	Carrier As	231-0012
6N-3256	Mount As	314-8688
6V-2202	Bearing-Spl Ball	380-1574
6V-6894	Rebuild Kt-Pump	383-3696
6V-9729	Gasket Kit - F	393-5195
6W-1958	Element	390-5284
6Y-7956	Disc-Friction	374-4677
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-5663	Muffler As	247-2667
7E-7894	Bearing-Rod	419-7260
7K-8877	Cone-Bearing	374-1847
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
7V-5979	Gear	231-0238
7V-5981	Driver	231-0256
7W-2059	Gasket-Cyl Hd	380-1548
8D-2256	Cone-Roller Brg	374-1848
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-0533	Bearing-Sleeve	314-8637

1GF		
Original Part Number	Part Name	Classic Part Number
8K-1754	Spacer	231-0247
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-2518	Joint As	231-0267
8K-4850	Cage-Bearing	451-0745
8M-6191	Sleeve-Bolt	226-0234
8N-0701	Bearing-Sleeve	419-4745
8N-9523	Elbow	425-2566
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8V-2632	Pin As	241-2523
8V-2634	Pin As	241-2518
9B-1320	Valve-Check	377-5832
9C-4737	Pin As	241-2520
9C-4912	Pin As	241-2517
9C-6187	Pin As	241-2521
9K-1171	Cup-Rlr Bearing	430-3339
9K-8423	Bearing-Sleeve	421-9043
9K-8425	Bearing-Sleeve	314-8638
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-0654	Coupling	297-7167
9V-9408	Spring	425-9369
9W-6390	Sleeve	385-3795
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937

Sales Model 229 (Cont'd.)

1GF		
Original Part Number	Part Name	Classic Part Number
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
114-0468	Pin-G.E.T.	443-1203

1GF		
Original Part Number	Part Name	Classic Part Number
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311

1GF		
Original Part Number	Part Name	Classic Part Number
124-3237	Precleaner As	432-4220
289-2946	Seal-U-Cup	472-8030

Sales Model 229D

2LJ		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1S-3062	Director-Water	418-9572
1T-0210	Bearing-Ball	417-4498
1T-0299	Cup-Roller Brg	422-6494
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2572	Muffler As.	247-2663
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036

2LJ		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2V-0706	Bearing-Sleeve	388-0637
2V-0707	Bearing-Sleeve	360-2328
2V-1722	Pin As	241-2525
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055

2LJ		
Original Part Number	Part Name	Classic Part Number
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-3521	Bearing	380-7513
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
4D-0487	Valve As-Check	375-4334
4E-1011	Pin As	430-9676
4E-7717	Shaft-Sprocket	432-6606
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115

Sales Model 229D (Cont'd.)

2LJ		
Original Part Number	Part Name	Classic Part Number
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-1684	Bearing	377-7428
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5C-6739	Bearing-Sleeve	445-7704
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6W-1958	Element	390-5284
6Y-7956	Disc-Friction	374-4677
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939

2LJ		
Original Part Number	Part Name	Classic Part Number
7D-8349	Cone-Rlr Brg	419-6074
7E-9980	Camshaft	377-5851
7K-8877	Cone-Bearing	374-1847
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8E-2058	Bearing	384-5949
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-4850	Cage-Bearing	451-0745
8N-0081	Trunnion	393-5196
8N-0111	Mount As	374-1452
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

2LJ		
Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-1606	Kit-Gskt-Sch	386-3046
8T-9486	Gasket Kt	393-5197
8V-2632	Pin As	241-2523

Sales Model 229D (Cont'd.)

2LJ		
Original Part Number	Part Name	Classic Part Number
8V-2634	Pin As	241-2518
9C-4737	Pin As	241-2520
9K-8757	Rod End-Special	311-9361
9N-5769	Cover-Housing	325-6050
9R-9505	Bearing-Sleeve	453-6516
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977

2LJ		
Original Part Number	Part Name	Classic Part Number
112-1773	Piston	347-0462
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
141-7277	Kit-Gasket-Fs	437-4610
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687

2LJ		
Original Part Number	Part Name	Classic Part Number
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
174-0739	Gasket Kit - F	437-2012
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 231D

1NK		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-8554	Coupling-Exhaust	325-6052
1T-0210	Bearing-Ball	417-4498
1T-0299	Cup-Roller Brg	422-6494
1W-6987	Valve As-Check	420-6221

1NK		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2N-2139	Cone-Roller Brg	415-1911
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
3G-3521	Bearing	380-7513
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
3V-4643	Rod As	389-6333

1NK		
Original Part Number	Part Name	Classic Part Number
4D-0487	Valve As-Check	375-4334
4E-1035	Pin	241-2553
4E-7717	Shaft-Sprocket	432-6606
4E-9426	Collar	231-0000
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4P-7688	Valve As-Check	420-6216
4T-1684	Bearing	377-7428
5C-0857	Plate-Mating	376-3624
5C-1834	Gear	231-0002

Sales Model 231D (Cont'd.)

1NK		
Original Part Number	Part Name	Classic Part Number
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
6A-7196	Pilot-Front	385-7200
6C-0739	Carrier As	231-0012
6C-1573	Rod	297-7238
6N-3256	Mount As	314-8688
6V-2202	Bearing-Spl Ball	380-1574
6V-6894	Rebuild Kt-Pump	383-3696
6W-1958	Element	390-5284
6Y-7909	Disc-Friction	374-4676
6Y-7956	Disc-Friction	374-4677
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-5663	Muffler As	247-2667
7E-7894	Bearing-Rod	419-7260
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
7W-2059	Gasket-Cyl Hd	380-1548
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571

1NK		
Original Part Number	Part Name	Classic Part Number
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1780	Cylinder	360-2261
8D-2256	Cone-Roller Brg	374-1848
8H-8175	Bearing-Sleeve	376-3636
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-4850	Cage-Bearing	451-0745
8N-0701	Bearing-Sleeve	419-4745
8N-9523	Elbow	425-2566
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
9K-1171	Cup-Rlr Bearing	430-3339
9K-8423	Bearing-Sleeve	421-9043
9K-8425	Bearing-Sleeve	314-8638

1NK		
Original Part Number	Part Name	Classic Part Number
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-6390	Sleeve	385-3795
087-5978	Flange	374-3496
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
124-3237	Precleaner As	432-4220
134-8950	Plate	399-8587
145-3037	Support	480-8271
191-3235	Housing-Sprocket	394-0200
242-9834	Kit-Gasket-Mch	387-2923
357-7540	Valve-Fill	360-2292

5WJ		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3165	Plunger-Rlf V	373-1883
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851

5WJ		
Original Part Number	Part Name	Classic Part Number
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-2696	Cone-Bearing	374-1834
1P-8554	Coupling-Exhaust	325-6052
1T-0210	Bearing-Ball	417-4498
1T-0299	Cup-Roller Brg	422-6494
1W-6987	Valve As-Check	420-6221
2A-4429	Lock-Retainer	379-0174

5WJ		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2N-2139	Cone-Roller Brg	415-1911
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844

Sales Model 231D (Cont'd.)

5WJ		
Original Part Number	Part Name	Classic Part Number
2V-0706	Bearing-Sleeve	388-0637
2V-1722	Pin As	241-2525
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
3V-5317	Gear	231-0010
4D-0487	Valve As-Check	375-4334
4E-1035	Pin	241-2553
4E-7717	Shaft-Sprocket	432-6606
4E-9426	Collar	231-0000
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4161	Mount As	374-1448
4N-4539	Sleeve	314-8720
4P-7688	Valve As-Check	420-6216
4T-1684	Bearing	377-7428
5C-1834	Gear	231-0002
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5V-7222	Gear-Final Drive	231-0237

5WJ		
Original Part Number	Part Name	Classic Part Number
6C-0739	Carrier As	231-0012
6N-3256	Mount As	314-8688
6V-2202	Bearing-Spl Ball	380-1574
6V-6894	Rebuild Kt-Pump	383-3696
6W-1958	Element	390-5284
6Y-7956	Disc-Friction	374-4677
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-5663	Muffler As	247-2667
7E-7894	Bearing-Rod	419-7260
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
7W-2059	Gasket-Cyl Hd	380-1548
8D-2256	Cone-Roller Brg	374-1848
8H-8175	Bearing-Sleeve	376-3636
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-1754	Spacer	231-0247
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-4850	Cage-Bearing	451-0745
8N-0701	Bearing-Sleeve	419-4745
8N-9523	Elbow	425-2566

5WJ		
Original Part Number	Part Name	Classic Part Number
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
9K-1171	Cup-Rlr Bearing	430-3339
9K-8423	Bearing-Sleeve	421-9043
9K-8425	Bearing-Sleeve	314-8638
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-0654	Coupling	297-7167
9W-6390	Sleeve	385-3795
087-5978	Flange	374-3496
119-6772	Valve-Exhaust	384-8699
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
134-8948	Plate	399-8588
134-8950	Plate	399-8587
242-9834	Kit-Gasket-Mch	387-2923

Sales Model 235

32K		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345

32K		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978

32K		
Original Part Number	Part Name	Classic Part Number
1N-3958	Elbow	325-6087
1P-0963	Guard As-Roller	226-0179
1P-1367	Plunger-Valve	432-8913

Sales Model 235 (Cont'd.)

32K		
Original Part Number	Part Name	Classic Part Number
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-2696	Cone-Bearing	374-1834
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0299	Cup-Roller Brg	422-6494
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844

32K		
Original Part Number	Part Name	Classic Part Number
2P-1438	Pipe-Exh Ext	325-6157
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-3767	Tube-Disposal	377-5850
2P-4611	Pipe-Exhaust	365-8821
2P-5608	Pipe-Extension	367-6066
2P-6245	Shaft As-Pump	325-6197
2S-5551	Coupling-Exhaust	398-2934
2V-0447	Bearing-Sleeve	380-7559
2V-0705	Pin As	241-2524
2V-1256	Bearing-Sleeve	422-9529
2V-1722	Pin As	241-2525
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-3428	Muffler As	298-2784
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-3521	Bearing	380-7513
3G-5750	Bearing-Plate	419-4734
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3S-5017	Elbow-Exhaust	369-9498
3V-4643	Rod As	389-6333
3V-5317	Gear	231-0010
3Y-9984	Manifold-Exhaust	325-6123

32K		
Original Part Number	Part Name	Classic Part Number
4E-1011	Pin As	430-9676
4E-1035	Pin	241-2553
4E-1065	Pin As	241-2538
4E-7608	Bearing-Sleeve	388-0639
4E-7717	Shaft-Sprocket	432-6606
4E-9426	Collar	231-0000
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4161	Mount As	374-1448
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986

Sales Model 235 (Cont'd.)

32K		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9386	Line As-Fuel Inj	279-4987
4T-1684	Bearing	377-7428
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-3632	Muffler As	385-7224
4W-6869	Spacer-Fuel Pump	417-4534
5C-0857	Plate-Mating	376-3624
5C-1834	Gear	231-0002
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-7222	Gear-Final Drive	231-0237
6B-7469	Spacer	417-4535
6C-0739	Carrier As	231-0012
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544

32K		
Original Part Number	**Part Name**	**Classic Part Number**
6N-7263	Gasket-Cyl Head	380-7386
6S-2828	Cup-Roller Brg	384-5932
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
6W-3662	Ring-Drive	446-3079
6Y-7909	Disc-Friction	374-4676
6Y-7956	Disc-Friction	374-4677
6Y-8842	Block-Rubber	432-8274
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7J-8295	Head	388-0566
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290

32K		
Original Part Number	**Part Name**	**Classic Part Number**
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7V-6898	Pin As	241-2539
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-2256	Cone-Roller Brg	374-1848
8E-2058	Bearing	384-5949
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-1754	Spacer	231-0247
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-4850	Cage-Bearing	451-0745
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

Sales Model 235 (Cont'd.)

32K		
Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-9151	Cup-Spl Tapered	374-8348
8V-2632	Pin As	241-2523

32K		
Original Part Number	Part Name	Classic Part Number
8V-5439	Pin As	241-2531
9B-1320	Valve-Check	377-5832
9K-1171	Cup-Rlr Bearing	430-3339
9K-8423	Bearing-Sleeve	421-9043
9K-8425	Bearing-Sleeve	314-8638
9K-8428	Pin As	241-2533
9K-8435	Pin	241-2552
9K-8757	Rod End-Special	311-9361
9L-5908	Gasket	433-8196
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
109-4848	Pulley-Cshaft	416-5507
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
124-3237	Precleaner As	432-4220
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477

32K		
Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6556	Kit-Liner-Cla	250-6564
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351

Sales Model 235 (Cont'd.)

32K		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989

32K		
Original Part Number	Part Name	Classic Part Number
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

32K		
Original Part Number	Part Name	Classic Part Number
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

62X		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1438	Pipe-Exh Ext	325-6157
2P-1738	Plate As-Oil Pan	325-6164

62X		
Original Part Number	Part Name	Classic Part Number
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-3767	Tube-Disposal	377-5850
2P-4611	Pipe-Exhaust	365-8821
2P-5608	Pipe-Extension	367-6066
2P-6245	Shaft As-Pump	325-6197
2S-5551	Coupling-Exhaust	398-2934
2V-0447	Bearing-Sleeve	380-7559
2V-1256	Bearing-Sleeve	422-9529
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-3428	Muffler As	298-2784
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-3521	Bearing	380-7513
3G-5750	Bearing-Plate	419-4734
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3S-5017	Elbow-Exhaust	369-9498
4E-1011	Pin As	430-9676
4E-1035	Pin	241-2553

62X		
Original Part Number	Part Name	Classic Part Number
4E-1065	Pin As	241-2538
4E-7608	Bearing-Sleeve	388-0639
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4161	Mount As	374-1448
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988

Sales Model 235 (Cont'd.)

62X		
Original Part Number	Part Name	Classic Part Number
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-1684	Bearing	377-7428
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-3632	Muffler As	385-7224
4W-6869	Spacer-Fuel Pump	417-4534
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6S-2828	Cup-Roller Brg	384-5932
6V-2202	Bearing-Spl Ball	380-1574

62X		
Original Part Number	Part Name	Classic Part Number
6V-2527	Gasket Kit	387-2918
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7V-6898	Pin As	241-2539

62X		
Original Part Number	Part Name	Classic Part Number
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-2058	Bearing	384-5949
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290

Sales Model 235 (Cont'd.)

62X		
Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8V-5439	Pin As	241-2531
9B-1320	Valve-Check	377-5832
9K-8423	Bearing-Sleeve	421-9043
9K-8425	Bearing-Sleeve	314-8638
9K-8428	Pin As	241-2533
9K-8435	Pin	241-2552
9K-8757	Rod End-Special	311-9361
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558

62X		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

62X		
Original Part Number	Part Name	Classic Part Number
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6556	Kit-Liner-Cla	250-6564
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

64R		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839

64R		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087

64R		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851

Sales Model 235 (Cont'd.)

64R		
Original Part Number	Part Name	Classic Part Number
1P-2696	Cone-Bearing	374-1834
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1S-3062	Director-Water	418-9572
1T-0299	Cup-Roller Brg	422-6494
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9191	Cone-Roller Brg	374-1837
2J-2152	Cup-Roller Brg	374-1852
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1438	Pipe-Exh Ext	325-6157
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

64R		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-5608	Pipe-Extension	367-6066
2P-6245	Shaft As-Pump	325-6197
2S-5551	Coupling-Exhaust	398-2934
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-3428	Muffler As	298-2784
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-5750	Bearing-Plate	419-4734
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3S-5017	Elbow-Exhaust	369-9498
3V-4643	Rod As	389-6333
3Y-9984	Manifold-Exhaust	325-6123
4E-1011	Pin As	430-9676
4E-7717	Shaft-Sprocket	432-6606
4N-0432	Bearing-Ball	417-4499
4N-4161	Mount As	374-1448
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988

64R		
Original Part Number	Part Name	Classic Part Number
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5C-0857	Plate-Mating	376-3624
5L-6326	Bearing-Ball	420-3222
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6S-2828	Cup-Roller Brg	384-5932
6V-2202	Bearing-Spl Ball	380-1574
6W-3662	Ring-Drive	446-3079
6Y-7909	Disc-Friction	374-4676
6Y-7956	Disc-Friction	374-4677
6Y-8842	Block-Rubber	432-8274
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829

Sales Model 235 (Cont'd.)

64R		
Original Part Number	Part Name	Classic Part Number
7E-9980	Camshaft	377-5851
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-2058	Bearing	384-5949
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-4850	Cage-Bearing	451-0745
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849

64R		
Original Part Number	Part Name	Classic Part Number
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8V-5439	Pin As	241-2531
9K-8757	Rod End-Special	311-9361
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050

64R		
Original Part Number	Part Name	Classic Part Number
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
109-4848	Pulley-Cshaft	416-5507
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835

Sales Model 235 (Cont'd.)

64R		
Original Part Number	**Part Name**	**Classic Part Number**
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351

64R		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349

64R		
Original Part Number	**Part Name**	**Classic Part Number**
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

81X		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-2696	Cone-Bearing	374-1834
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0299	Cup-Roller Brg	422-6494
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221

81X		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1438	Pipe-Exh Ext	325-6157
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-3767	Tube-Disposal	377-5850
2P-4611	Pipe-Exhaust	365-8821
2P-5608	Pipe-Extension	367-6066
2P-6245	Shaft As-Pump	325-6197
2S-5551	Coupling-Exhaust	398-2934
2V-0447	Bearing-Sleeve	380-7559
2V-1256	Bearing-Sleeve	422-9529

81X		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-3428	Muffler As	298-2784
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-3521	Bearing	380-7513
3G-5750	Bearing-Plate	419-4734
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3S-5017	Elbow-Exhaust	369-9498
3V-4643	Rod As	389-6333
3V-5317	Gear	231-0010
4E-1011	Pin As	430-9676
4E-1035	Pin	241-2553
4E-1065	Pin As	241-2538
4E-7608	Bearing-Sleeve	388-0639
4E-7717	Shaft-Sprocket	432-6606
4E-9426	Collar	231-0000
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362

Sales Model 235 (Cont'd.)

81X		
Original Part Number	Part Name	Classic Part Number
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4161	Mount As	374-1448
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-1684	Bearing	377-7428
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-3632	Muffler As	385-7224
4W-6869	Spacer-Fuel Pump	417-4534
5C-0857	Plate-Mating	376-3624
5C-1834	Gear	231-0002
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5L-6326	Bearing-Ball	420-3222

81X		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-7222	Gear-Final Drive	231-0237
6B-7469	Spacer	417-4535
6C-0739	Carrier As	231-0012
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6S-2828	Cup-Roller Brg	384-5932
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
6W-3662	Ring-Drive	446-3079
6Y-7909	Disc-Friction	374-4676
6Y-7956	Disc-Friction	374-4677
6Y-8842	Block-Rubber	432-8274
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7J-8295	Head	388-0566
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847

81X		
Original Part Number	Part Name	Classic Part Number
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7V-6898	Pin As	241-2539
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-2256	Cone-Roller Brg	374-1848
8E-2058	Bearing	384-5949
8H-2810	Case As-Filter	314-8512

Sales Model 235 (Cont'd.)

81X		
Original Part Number	Part Name	Classic Part Number
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-1754	Spacer	231-0247
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-4850	Cage-Bearing	451-0745
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290

81X		
Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-9151	Cup-Spl Tapered	374-8348
8V-5439	Pin As	241-2531
9B-1320	Valve-Check	377-5832
9K-1171	Cup-Rlr Bearing	430-3339
9K-8423	Bearing-Sleeve	421-9043
9K-8425	Bearing-Sleeve	314-8638
9K-8428	Pin As	241-2533
9K-8435	Pin	241-2552
9K-8757	Rod End-Special	311-9361
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888

81X		
Original Part Number	Part Name	Classic Part Number
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

Sales Model 235 (Cont'd.)

81X		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085

81X		
Original Part Number	Part Name	Classic Part Number
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6556	Kit-Liner-Cla	250-6564
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438

81X		
Original Part Number	Part Name	Classic Part Number
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

83X		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1S-3062	Director-Water	418-9572
1T-0299	Cup-Roller Brg	422-6494
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

83X		
Original Part Number	Part Name	Classic Part Number
2D-9191	Cone-Roller Brg	374-1837
2J-2152	Cup-Roller Brg	374-1852
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1438	Pipe-Exh Ext	325-6157
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-5608	Pipe-Extension	367-6066
2P-6245	Shaft As-Pump	325-6197
2S-5551	Coupling-Exhaust	398-2934
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-3428	Muffler As	298-2784
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203

83X		
Original Part Number	Part Name	Classic Part Number
2W-7458	Crankshaft As	242-3439
3G-5750	Bearing-Plate	419-4734
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3S-5017	Elbow-Exhaust	369-9498
3V-4643	Rod As	389-6333
4E-1011	Pin As	430-9676
4E-7717	Shaft-Sprocket	432-6606
4N-0432	Bearing-Ball	417-4499
4N-4161	Mount As	374-1448
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191

Sales Model 235 (Cont'd.)

83X		
Original Part Number	Part Name	Classic Part Number
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5C-0857	Plate-Mating	376-3624
5L-6326	Bearing-Ball	420-3222
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6S-2828	Cup-Roller Brg	384-5932
6V-2202	Bearing-Spl Ball	380-1574
6W-3662	Ring-Drive	446-3079
6Y-7909	Disc-Friction	374-4676
6Y-7956	Disc-Friction	374-4677
6Y-8842	Block-Rubber	432-8274
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670

83X		
Original Part Number	Part Name	Classic Part Number
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-2058	Bearing	384-5949
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-4850	Cage-Bearing	451-0745
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

83X		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8V-5439	Pin As	241-2531
9K-8757	Rod End-Special	311-9361
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167

Sales Model 235 (Cont'd.)

83X		
Original Part Number	Part Name	Classic Part Number
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

83X		
Original Part Number	Part Name	Classic Part Number
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365

83X		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 235B

1FD		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0299	Cup-Roller Brg	422-6494

1FD		
Original Part Number	Part Name	Classic Part Number
1U-2738	Piston Assembly	367-6074
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

1FD		
Original Part Number	Part Name	Classic Part Number
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1438	Pipe-Exh Ext	325-6157
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

Sales Model 235B (Cont'd.)

1FD		
Original Part Number	Part Name	Classic Part Number
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4611	Pipe-Exhaust	365-8821
2P-5608	Pipe-Extension	367-6066
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2V-0447	Bearing-Sleeve	380-7559
2V-1256	Bearing-Sleeve	422-9529
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-3428	Muffler As	298-2784
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3G-3521	Bearing	380-7513
3G-4292	Bearing	425-6439
3G-5750	Bearing-Plate	419-4734
3G-6910	Bearing-Plate	419-4733
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3S-5017	Elbow-Exhaust	369-9498
3V-4643	Rod As	389-6333
3Y-9984	Manifold-Exhaust	325-6123
4E-1011	Pin As	430-9676
4E-1035	Pin	241-2553

1FD		
Original Part Number	Part Name	Classic Part Number
4E-1065	Pin As	241-2538
4E-7608	Bearing-Sleeve	388-0639
4E-7717	Shaft-Sprocket	432-6606
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4161	Mount As	374-1448
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-1684	Bearing	377-7428
4W-0452	Seal As -Cshaft	325-6191

1FD		
Original Part Number	Part Name	Classic Part Number
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-3632	Muffler As	385-7224
4W-6869	Spacer-Fuel Pump	417-4534
5C-0857	Plate-Mating	376-3624
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6S-2828	Cup-Roller Brg	384-5932
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200

Sales Model 235B (Cont'd.)

1FD		
Original Part Number	Part Name	Classic Part Number
6W-3662	Ring-Drive	446-3079
6Y-7909	Disc-Friction	374-4676
6Y-7956	Disc-Friction	374-4677
6Y-8842	Block-Rubber	432-8274
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290

1FD		
Original Part Number	Part Name	Classic Part Number
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-2058	Bearing	384-5949
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-4850	Cage-Bearing	451-0745
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564

1FD		
Original Part Number	Part Name	Classic Part Number
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415

Sales Model 235B (Cont'd.)

1FD		
Original Part Number	Part Name	Classic Part Number
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8V-5439	Pin As	241-2531
9B-1320	Valve-Check	377-5832
9K-8423	Bearing-Sleeve	421-9043
9K-8425	Bearing-Sleeve	314-8638
9K-8428	Pin As	241-2533
9K-8435	Pin	241-2552
9K-8757	Rod End-Special	311-9361
9L-5908	Gasket	433-8196
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165

1FD		
Original Part Number	Part Name	Classic Part Number
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
109-4848	Pulley-Cshaft	416-5507
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
124-3237	Precleaner As	432-4220
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484

1FD		
Original Part Number	Part Name	Classic Part Number
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

4ED		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147

4ED		
Original Part Number	Part Name	Classic Part Number
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-8554	Coupling-Exhaust	325-6052

4ED		
Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0299	Cup-Roller Brg	422-6494
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

Sales Model 235B (Cont'd.)

4ED		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4611	Pipe-Exhaust	365-8821
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2V-0447	Bearing-Sleeve	380-7559
2V-1256	Bearing-Sleeve	422-9529

4ED		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3G-3521	Bearing	380-7513
3G-5750	Bearing-Plate	419-4734
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3S-5017	Elbow-Exhaust	369-9498
3V-4643	Rod As	389-6333
4E-1011	Pin As	430-9676
4E-1035	Pin	241-2553
4E-1065	Pin As	241-2538
4E-7608	Bearing-Sleeve	388-0639
4E-7717	Shaft-Sprocket	432-6606
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4161	Mount As	374-1448
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366

4ED		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-1684	Bearing	377-7428
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-3632	Muffler As	385-7224
4W-6869	Spacer-Fuel Pump	417-4534
5C-0857	Plate-Mating	376-3624
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883

Sales Model 235B (Cont'd.)

4ED		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6S-2828	Cup-Roller Brg	384-5932
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200
6W-3662	Ring-Drive	446-3079
6Y-7909	Disc-Friction	374-4676
6Y-7956	Disc-Friction	374-4677
6Y-8842	Block-Rubber	432-8274
7C-3862	Camshaft	458-0151
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780

4ED		
Original Part Number	Part Name	Classic Part Number
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-2058	Bearing	384-5949
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-4850	Cage-Bearing	451-0745
8N-0002	Trunnion As	314-8728

4ED		
Original Part Number	Part Name	Classic Part Number
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

Sales Model 235B (Cont'd.)

4ED		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8V-5439	Pin As	241-2531
9B-1320	Valve-Check	377-5832
9K-8423	Bearing-Sleeve	421-9043
9K-8425	Bearing-Sleeve	314-8638
9K-8435	Pin	241-2552
9K-8757	Rod End-Special	311-9361
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888

4ED		
Original Part Number	Part Name	Classic Part Number
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

4ED		
Original Part Number	Part Name	Classic Part Number
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

7WC		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839

7WC		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087

7WC		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851

Sales Model 235B (Cont'd.)

7WC		
Original Part Number	Part Name	Classic Part Number
1P-2696	Cone-Bearing	374-1834
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0299	Cup-Roller Brg	422-6494
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075

7WC		
Original Part Number	Part Name	Classic Part Number
2P-1374	Cone-Rlr Brg	374-1844
2P-1438	Pipe-Exh Ext	325-6157
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4611	Pipe-Exhaust	365-8821
2P-5608	Pipe-Extension	367-6066
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2V-0447	Bearing-Sleeve	380-7559
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-3428	Muffler As	298-2784
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3G-4292	Bearing	425-6439
3G-5750	Bearing-Plate	419-4734
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3S-5017	Elbow-Exhaust	369-9498
3V-4643	Rod As	389-6333
3Y-9984	Manifold-Exhaust	325-6123

7WC		
Original Part Number	Part Name	Classic Part Number
4E-1011	Pin As	430-9676
4E-1035	Pin	241-2553
4E-1065	Pin As	241-2538
4E-7608	Bearing-Sleeve	388-0639
4E-7717	Shaft-Sprocket	432-6606
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4161	Mount As	374-1448
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987

Sales Model 235B (Cont'd.)

7WC		
Original Part Number	Part Name	Classic Part Number
4T-1684	Bearing	377-7428
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-3632	Muffler As	385-7224
4W-6869	Spacer-Fuel Pump	417-4534
5C-0857	Plate-Mating	376-3624
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6S-2828	Cup-Roller Brg	384-5932

7WC		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200
6W-3662	Ring-Drive	446-3079
6Y-7909	Disc-Friction	374-4676
6Y-7956	Disc-Friction	374-4677
6Y-8842	Block-Rubber	432-8274
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496

7WC		
Original Part Number	Part Name	Classic Part Number
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-2058	Bearing	384-5949
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-4850	Cage-Bearing	451-0745
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

Sales Model 235B (Cont'd.)

7WC		
Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372

7WC		
Original Part Number	Part Name	Classic Part Number
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8V-5439	Pin As	241-2531
9B-1320	Valve-Check	377-5832
9K-8423	Bearing-Sleeve	421-9043
9K-8425	Bearing-Sleeve	314-8638
9K-8428	Pin As	241-2533
9K-8435	Pin	241-2552
9K-8757	Rod End-Special	311-9361
9L-5908	Gasket	433-8196
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
109-4848	Pulley-Cshaft	416-5507
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977

7WC		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
124-3237	Precleaner As	432-4220
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6556	Kit-Liner-Cla	250-6564

Sales Model 235B (Cont'd.)

7WC		
Original Part Number	Part Name	Classic Part Number
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438

7WC		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

7WC		
Original Part Number	Part Name	Classic Part Number
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

9PC		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0299	Cup-Roller Brg	422-6494
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036

9PC		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1438	Pipe-Exh Ext	325-6157
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4611	Pipe-Exhaust	365-8821
2P-5608	Pipe-Extension	367-6066
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197

9PC		
Original Part Number	Part Name	Classic Part Number
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2V-0447	Bearing-Sleeve	380-7559
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-3428	Muffler As	298-2784
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3G-5750	Bearing-Plate	419-4734
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3S-5017	Elbow-Exhaust	369-9498
3V-4643	Rod As	389-6333
3Y-9984	Manifold-Exhaust	325-6123
4E-1011	Pin As	430-9676
4E-1035	Pin	241-2553
4E-1065	Pin As	241-2538
4E-7608	Bearing-Sleeve	388-0639
4E-7717	Shaft-Sprocket	432-6606
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716

Sales Model 235B (Cont'd.)

9PC		
Original Part Number	Part Name	Classic Part Number
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4161	Mount As	374-1448
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-1684	Bearing	377-7428
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-3632	Muffler As	385-7224
4W-6869	Spacer-Fuel Pump	417-4534
5C-0857	Plate-Mating	376-3624
5L-6326	Bearing-Ball	420-3222

9PC		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6S-2828	Cup-Roller Brg	384-5932
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200
6W-3662	Ring-Drive	446-3079
6Y-7909	Disc-Friction	374-4676
6Y-7956	Disc-Friction	374-4677
6Y-8842	Block-Rubber	432-8274
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847

9PC		
Original Part Number	Part Name	Classic Part Number
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417

Sales Model 235B (Cont'd.)

9PC		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-2058	Bearing	384-5949
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-4850	Cage-Bearing	451-0745
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

9PC		
Original Part Number	Part Name	Classic Part Number
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8V-5439	Pin As	241-2531
9B-1320	Valve-Check	377-5832
9K-8423	Bearing-Sleeve	421-9043
9K-8425	Bearing-Sleeve	314-8638

9PC		
Original Part Number	Part Name	Classic Part Number
9K-8435	Pin	241-2552
9K-8757	Rod End-Special	311-9361
9L-5908	Gasket	433-8196
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
109-4848	Pulley-Cshaft	416-5507
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
124-3237	Precleaner As	432-4220
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125

Sales Model 235B (Cont'd.)

9PC		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

9PC		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892

9PC		
Original Part Number	Part Name	Classic Part Number
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 235C

2PG		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0299	Cup-Roller Brg	422-6494
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

2PG		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837

2PG		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4611	Pipe-Exhaust	365-8821

Sales Model 235C (Cont'd.)

2PG		
Original Part Number	Part Name	Classic Part Number
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2V-0447	Bearing-Sleeve	380-7559
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3G-4292	Bearing	425-6439
3G-5750	Bearing-Plate	419-4734
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3S-5017	Elbow-Exhaust	369-9498
3V-4643	Rod As	389-6333
3Y-9984	Manifold-Exhaust	325-6123
4E-1011	Pin As	430-9676
4E-1035	Pin	241-2553
4E-1065	Pin As	241-2538
4E-7608	Bearing-Sleeve	388-0639
4E-7717	Shaft-Sprocket	432-6606
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4161	Mount As	374-1448
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176

2PG		
Original Part Number	Part Name	Classic Part Number
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-1684	Bearing	377-7428
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-3632	Muffler As	385-7224
4W-6869	Spacer-Fuel Pump	417-4534
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

2PG		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6S-2828	Cup-Roller Brg	384-5932
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200
6W-3662	Ring-Drive	446-3079
6Y-7956	Disc-Friction	374-4677
6Y-8842	Block-Rubber	432-8274
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670

Sales Model 235C (Cont'd.)

2PG		
Original Part Number	Part Name	Classic Part Number
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-2058	Bearing	384-5949
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636

2PG		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-4850	Cage-Bearing	451-0745
8L-4889	Shaft-Aux Drive	433-9212
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349

2PG		
Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8T-1622	Gasket Kit - Sch	436-8388
8V-5439	Pin As	241-2531
9B-1320	Valve-Check	377-5832
9K-8423	Bearing-Sleeve	421-9043
9K-8425	Bearing-Sleeve	314-8638
9K-8435	Pin	241-2552
9K-8757	Rod End-Special	311-9361
9L-5908	Gasket	433-8196
9M-5477	Bearing-Sleeve	374-6517

Sales Model 235C (Cont'd.)

2PG		
Original Part Number	Part Name	Classic Part Number
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
109-4848	Pulley-Cshaft	416-5507
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
124-3237	Precleaner As	432-4220
127-5537	Core As-Oclr	325-6045

2PG		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

2PG		
Original Part Number	Part Name	Classic Part Number
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

3WG		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-7895	Cone-Roller Brg	396-4145

3WG		
Original Part Number	Part Name	Classic Part Number
1P-7936	Spider As-Fan	383-3673
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0299	Cup-Roller Brg	422-6494
1U-2738	Piston Assembly	367-6074
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

3WG		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173

Sales Model 235C (Cont'd.)

3WG		
Original Part Number	Part Name	Classic Part Number
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4611	Pipe-Exhaust	365-8821
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2V-0447	Bearing-Sleeve	380-7559
2V-1256	Bearing-Sleeve	422-9529
2W-1707	Ring-Piston Top	270-4356

3WG		
Original Part Number	Part Name	Classic Part Number
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3F-4971	Pin	295-5693
3G-3521	Bearing	380-7513
3G-4292	Bearing	425-6439
3G-5750	Bearing-Plate	419-4734
3G-6910	Bearing-Plate	419-4733
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3S-5017	Elbow-Exhaust	369-9498
3V-4643	Rod As	389-6333
3V-8976	Cylinder As	433-7508
3Y-9984	Manifold-Exhaust	325-6123
4E-1011	Pin As	430-9676
4E-1035	Pin	241-2553
4E-1065	Pin As	241-2538
4E-7608	Bearing-Sleeve	388-0639
4E-7717	Shaft-Sprocket	432-6606
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4161	Mount As	374-1448
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763

3WG		
Original Part Number	Part Name	Classic Part Number
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-1684	Bearing	377-7428
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-3632	Muffler As	385-7224
4W-6869	Spacer-Fuel Pump	417-4534
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

Sales Model 235C (Cont'd.)

3WG		
Original Part Number	Part Name	Classic Part Number
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6S-2828	Cup-Roller Brg	384-5932
6V-2202	Bearing-Spl Ball	380-1574
6W-3662	Ring-Drive	446-3079
6Y-7956	Disc-Friction	374-4677
6Y-8842	Block-Rubber	432-8274
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435

3WG		
Original Part Number	Part Name	Classic Part Number
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-2058	Bearing	384-5949

3WG		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-4850	Cage-Bearing	451-0745
8L-4889	Shaft-Aux Drive	433-9212
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464

Sales Model 235C (Cont'd.)

3WG		
Original Part Number	Part Name	Classic Part Number
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8T-1622	Gasket Kit - Sch	436-8388
8V-5439	Pin As	241-2531
9B-1320	Valve-Check	377-5832
9K-8423	Bearing-Sleeve	421-9043
9K-8425	Bearing-Sleeve	314-8638
9K-8435	Pin	241-2552
9K-8757	Rod End-Special	311-9361

3WG		
Original Part Number	Part Name	Classic Part Number
9L-5908	Gasket	433-8196
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
109-4848	Pulley-Cshaft	416-5507
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
124-3237	Precleaner As	432-4220
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125

3WG		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 235C (Cont'd.)

4DG		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0299	Cup-Roller Brg	422-6494
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501

4DG		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4611	Pipe-Exhaust	365-8821
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2V-0447	Bearing-Sleeve	380-7559
2V-1256	Bearing-Sleeve	422-9529
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3F-4971	Pin	295-5693
3G-3521	Bearing	380-7513
3G-4292	Bearing	425-6439
3G-5750	Bearing-Plate	419-4734
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3S-5017	Elbow-Exhaust	369-9498
3V-4643	Rod As	389-6333
3V-8976	Cylinder As	433-7508

4DG		
Original Part Number	Part Name	Classic Part Number
4E-1011	Pin As	430-9676
4E-1035	Pin	241-2553
4E-1065	Pin As	241-2538
4E-7608	Bearing-Sleeve	388-0639
4E-7717	Shaft-Sprocket	432-6606
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4161	Mount As	374-1448
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987

Sales Model 235C (Cont'd.)

4DG		
Original Part Number	Part Name	Classic Part Number
4T-1684	Bearing	377-7428
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-3632	Muffler As	385-7224
4W-6869	Spacer-Fuel Pump	417-4534
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544

4DG		
Original Part Number	Part Name	Classic Part Number
6N-7263	Gasket-Cyl Head	380-7386
6S-2828	Cup-Roller Brg	384-5932
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200
6W-3662	Ring-Drive	446-3079
6Y-7956	Disc-Friction	374-4677
6Y-8842	Block-Rubber	432-8274
7C-3862	Camshaft	458-0151
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724

4DG		
Original Part Number	Part Name	Classic Part Number
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger& Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-2058	Bearing	384-5949
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-4850	Cage-Bearing	451-0745
8L-4889	Shaft-Aux Drive	433-9212
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436

Sales Model 235C (Cont'd.)

4DG		
Original Part Number	Part Name	Classic Part Number
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198

4DG		
Original Part Number	Part Name	Classic Part Number
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8T-1622	Gasket Kit - Sch	436-8388
8V-5439	Pin As	241-2531
9B-1320	Valve-Check	377-5832
9K-8423	Bearing-Sleeve	421-9043
9K-8425	Bearing-Sleeve	314-8638
9K-8435	Pin	241-2552
9K-8757	Rod End-Special	311-9361
9L-5908	Gasket	433-8196
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165

4DG		
Original Part Number	Part Name	Classic Part Number
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
172-7775	Pump Gp-Water -B	398-2942

Sales Model 235C (Cont'd.)

4DG		
Original Part Number	Part Name	Classic Part Number
172-7776	Pump Gp-Water -B	395-1314
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893

4DG		
Original Part Number	Part Name	Classic Part Number
241-3381	Valve Kit-Cla	247-6892
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351

4DG		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

5AF		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-2696	Cone-Bearing	374-1834
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0299	Cup-Roller Brg	422-6494
1U-2738	Piston Assembly	367-6074
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020

5AF		
Original Part Number	Part Name	Classic Part Number
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

5AF		
Original Part Number	Part Name	Classic Part Number
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4611	Pipe-Exhaust	365-8821
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2V-0447	Bearing-Sleeve	380-7559
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3G-4292	Bearing	425-6439
3G-5750	Bearing-Plate	419-4734
3G-6910	Bearing-Plate	419-4733
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3S-5017	Elbow-Exhaust	369-9498
3V-4643	Rod As	389-6333
3V-5317	Gear	231-0010
3Y-9984	Manifold-Exhaust	325-6123
4E-1011	Pin As	430-9676

Sales Model 235C (Cont'd.)

5AF		
Original Part Number	Part Name	Classic Part Number
4E-1035	Pin	241-2553
4E-1065	Pin As	241-2538
4E-7608	Bearing-Sleeve	388-0639
4E-7717	Shaft-Sprocket	432-6606
4E-9426	Collar	231-0000
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4161	Mount As	374-1448
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987

5AF		
Original Part Number	Part Name	Classic Part Number
4T-1684	Bearing	377-7428
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-3632	Muffler As	385-7224
4W-6869	Spacer-Fuel Pump	417-4534
5C-1834	Gear	231-0002
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5V-7222	Gear-Final Drive	231-0237
6B-7469	Spacer	417-4535
6C-0739	Carrier As	231-0012
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688

5AF		
Original Part Number	Part Name	Classic Part Number
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6S-2828	Cup-Roller Brg	384-5932
6V-2202	Bearing-Spl Ball	380-1574
6W-3662	Ring-Drive	446-3079
6Y-7956	Disc-Friction	374-4677
6Y-8842	Block-Rubber	432-8274
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531

Sales Model 235C (Cont'd.)

5AF		
Original Part Number	Part Name	Classic Part Number
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger& Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-2256	Cone-Roller Brg	374-1848
8E-2058	Bearing	384-5949
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-1754	Spacer	231-0247
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-4850	Cage-Bearing	451-0745
8L-4889	Shaft-Aux Drive	433-9212
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381

5AF		
Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174

5AF		
Original Part Number	Part Name	Classic Part Number
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8T-1622	Gasket Kit -Sch	436-8388
8V-5439	Pin As	241-2531
9B-1320	Valve-Check	377-5832
9K-1171	Cup-Rlr Bearing	430-3339
9K-8423	Bearing-Sleeve	421-9043
9K-8425	Bearing-Sleeve	314-8638
9K-8435	Pin	241-2552
9K-8757	Rod End-Special	311-9361
9L-5908	Gasket	433-8196
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994

Sales Model 235C (Cont'd.)

5AF		
Original Part Number	Part Name	Classic Part Number
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
109-4848	Pulley-Cshaft	416-5507
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
124-3237	Precleaner As	432-4220
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361

5AF		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365

5AF		
Original Part Number	Part Name	Classic Part Number
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 235D

8KJ		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673

8KJ		
Original Part Number	Part Name	Classic Part Number
1S-3062	Director-Water	418-9572
1T-0299	Cup-Roller Brg	422-6494
1U-2738	Piston Assembly	367-6074
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689

8KJ		
Original Part Number	Part Name	Classic Part Number
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9191	Cone-Roller Brg	374-1837

Sales Model 235D (Cont'd.)

8KJ		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4611	Pipe-Exhaust	365-8821
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2V-1256	Bearing-Sleeve	422-9529
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3G-3521	Bearing	380-7513
3G-4292	Bearing	425-6439
3G-5750	Bearing-Plate	419-4734
3G-6910	Bearing-Plate	419-4733
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433

8KJ		
Original Part Number	Part Name	Classic Part Number
3S-5017	Elbow-Exhaust	369-9498
3V-4643	Rod As	389-6333
3V-8976	Cylinder As	433-7508
3Y-9984	Manifold-Exhaust	325-6123
4E-1011	Pin As	430-9676
4E-1035	Pin	241-2553
4E-1065	Pin As	241-2538
4E-7608	Bearing-Sleeve	388-0639
4E-7717	Shaft-Sprocket	432-6606
4N-0432	Bearing-Ball	417-4499
4N-4161	Mount As	374-1448
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-1684	Bearing	377-7428
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-3632	Muffler As	385-7224
4W-6869	Spacer-Fuel Pump	417-4534
5D-7449	Cup-Spl Tapered	416-2161

8KJ		
Original Part Number	Part Name	Classic Part Number
5F-1248	Cone-Roller Brg	399-4441
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-3256	Mount As	314-8688
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6S-2828	Cup-Roller Brg	384-5932
6V-2202	Bearing-Spl Ball	380-1574
6W-3662	Ring-Drive	446-3079
6Y-7956	Disc-Friction	374-4677
6Y-8842	Block-Rubber	432-8274
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0619	Pulley-Fan	383-1581

Sales Model 235D (Cont'd.)

8KJ		
Original Part Number	Part Name	Classic Part Number
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-2058	Bearing	384-5949
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-4850	Cage-Bearing	451-0745
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196

8KJ		
Original Part Number	Part Name	Classic Part Number
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
9K-8423	Bearing-Sleeve	421-9043
9K-8425	Bearing-Sleeve	314-8638
9K-8757	Rod End-Special	311-9361

8KJ		
Original Part Number	Part Name	Classic Part Number
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
109-4848	Pulley-Cshaft	416-5507
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
124-3237	Precleaner As	432-4220
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835

Sales Model 235D (Cont'd.)

8KJ		
Original Part Number	**Part Name**	**Classic Part Number**
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4357

8KJ		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989

8KJ		
Original Part Number	**Part Name**	**Classic Part Number**
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

8TJ		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1S-3062	Director-Water	418-9572
1T-0299	Cup-Roller Brg	422-6494
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

8TJ		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4611	Pipe-Exhaust	365-8821
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2V-1256	Bearing-Sleeve	422-9529
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203

8TJ		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3G-3521	Bearing	380-7513
3G-5750	Bearing-Plate	419-4734
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3S-5017	Elbow-Exhaust	369-9498
3V-4643	Rod As	389-6333
3V-8976	Cylinder As	433-7508
3Y-9984	Manifold-Exhaust	325-6123
4E-1011	Pin As	430-9676
4E-1035	Pin	241-2553
4E-1065	Pin As	241-2538
4E-7608	Bearing-Sleeve	388-0639
4E-7717	Shaft-Sprocket	432-6606
4N-0432	Bearing-Ball	417-4499
4N-4161	Mount As	374-1448
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988

Sales Model 235D (Cont'd.)

8TJ		
Original Part Number	Part Name	Classic Part Number
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-1684	Bearing	377-7428
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-3632	Muffler As	385-7224
4W-6869	Spacer-Fuel Pump	417-4534
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-3256	Mount As	314-8688
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544

8TJ		
Original Part Number	Part Name	Classic Part Number
6S-2828	Cup-Roller Brg	384-5932
6V-2202	Bearing-Spl Ball	380-1574
6W-3662	Ring-Drive	446-3079
6Y-7956	Disc-Friction	374-4677
6Y-8842	Block-Rubber	432-8274
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-2058	Bearing	384-5949
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815

8TJ		
Original Part Number	Part Name	Classic Part Number
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-4850	Cage-Bearing	451-0745
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438

Sales Model 235D (Cont'd.)

8TJ		
Original Part Number	Part Name	Classic Part Number
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8V-5439	Pin As	241-2531
9K-8423	Bearing-Sleeve	421-9043
9K-8425	Bearing-Sleeve	314-8638
9K-8757	Rod End-Special	311-9361
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531

8TJ		
Original Part Number	Part Name	Classic Part Number
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
109-4848	Pulley-Cshaft	416-5507
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
124-3237	Precleaner As	432-4220
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006

8TJ		
Original Part Number	Part Name	Classic Part Number
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 245

82X		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7895	Cone-Roller Brg	396-4145
1S-9209	Shaft-Tightener	374-6499
1U-2738	Piston Assembly	367-6074
1V-5736	Bearing-Sleeve	379-0187

82X		
Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533

82X		
Original Part Number	Part Name	Classic Part Number
2M-4209	Spacer-Timing	417-4532
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017

Sales Model 245 (Cont'd.)

82X		
Original Part Number	Part Name	Classic Part Number
3F-4971	Pin	295-5693
3G-3521	Bearing	380-7513
3G-5750	Bearing-Plate	419-4734
3G-6910	Bearing-Plate	419-4733
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3V-8976	Cylinder As	433-7508
4J-6374	Bearing-Sleeve	295-6407
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4539	Sleeve	314-8720
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355

82X		
Original Part Number	Part Name	Classic Part Number
4T-1684	Bearing	377-7428
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5G-3612	Cap Gp-Protn	295-6419
5L-6326	Bearing-Ball	420-3222
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8053	Kit-Gasket (Sch)	415-1901
5P-8366	Gasket Kit - Sch	387-2911
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-3256	Mount As	314-8688
6N-7154	Rotocoil As	380-7556
6S-2828	Cup-Roller Brg	384-5932

82X		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-7956	Disc-Friction	374-4677
6Y-8842	Block-Rubber	432-8274
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6398	Muffler As	360-7885
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7J-6250	Bearing-Sleeve	385-3803
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8371	Line As-Fuel Inj	373-1901
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417

Sales Model 245 (Cont'd.)

82X		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-4392	Bearing-Sleeve	389-6325
8M-0874	Plunger As-Valve	311-9439
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8N-9622	Bracket As-Fan	433-2024
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8V-2639	Pin As	241-2542
9K-8757	Rod End-Special	311-9361
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-5529	Body-F Inj Valve	378-3993
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9W-6390	Sleeve	385-3795

82X		
Original Part Number	Part Name	Classic Part Number
9Y-1917	Pulley-Fan	395-1311
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
114-4787	Kit-Gasket (Ocl)	388-0657
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919

82X		
Original Part Number	Part Name	Classic Part Number
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-6574	Kit-Gasket-Rs	437-2034
233-7083	Kit-Gasket-Fs	387-2919
234-1874	Kit-Gasket-Fs	437-8668
253-1752	Plate-Thrust	379-0170
289-2946	Seal-U-Cup	472-8030
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812

Sales Model 245 (Cont'd.)

84X		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7895	Cone-Roller Brg	396-4145
1S-9209	Shaft-Tightener	374-6499
1U-2738	Piston Assembly	367-6074
1V-5736	Bearing-Sleeve	379-0187
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3F-4971	Pin	295-5693
3G-3521	Bearing	380-7513
3G-5750	Bearing-Plate	419-4734
3G-6910	Bearing-Plate	419-4733
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433

84X		
Original Part Number	**Part Name**	**Classic Part Number**
3V-8976	Cylinder As	433-7508
4J-6374	Bearing-Sleeve	295-6407
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4539	Sleeve	314-8720
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-1684	Bearing	377-7428
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318

84X		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5G-3612	Cap Gp-Protn	295-6419
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-3256	Mount As	314-8688
6N-7154	Rotocoil As	380-7556
6S-2828	Cup-Roller Brg	384-5932
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-7956	Disc-Friction	374-4677
6Y-8842	Block-Rubber	432-8274
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6398	Muffler As	360-7885
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522

Sales Model 245 (Cont'd.)

84X		
Original Part Number	Part Name	Classic Part Number
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7J-6250	Bearing-Sleeve	385-3803
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-4392	Bearing-Sleeve	389-6325
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8N-9622	Bracket As-Fan	433-2024

84X		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
8V-2639	Pin As	241-2542
9K-8757	Rod End-Special	311-9361
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9W-6390	Sleeve	385-3795
9Y-1917	Pulley-Fan	395-1311
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587

84X		
Original Part Number	Part Name	Classic Part Number
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
233-7083	Kit-Gasket-Fs	387-2919
253-1752	Plate-Thrust	379-0170
289-2946	Seal-U-Cup	472-8030
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812

Sales Model 245 (Cont'd.)

94L		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7895	Cone-Roller Brg	396-4145
1S-9209	Shaft-Tightener	374-6499
1U-2738	Piston Assembly	367-6074
1V-5736	Bearing-Sleeve	379-0187
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3F-4971	Pin	295-5693
3G-3521	Bearing	380-7513
3G-5750	Bearing-Plate	419-4734
3G-6910	Bearing-Plate	419-4733
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433

94L		
Original Part Number	Part Name	Classic Part Number
3V-8976	Cylinder As	433-7508
4J-6374	Bearing-Sleeve	295-6407
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4539	Sleeve	314-8720
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-1684	Bearing	377-7428
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318

94L		
Original Part Number	Part Name	Classic Part Number
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5G-3612	Cap Gp-Protn	295-6419
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-3256	Mount As	314-8688
6N-7154	Rotocoil As	380-7556
6S-2828	Cup-Roller Brg	384-5932
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-7956	Disc-Friction	374-4677
6Y-8842	Block-Rubber	432-8274
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6398	Muffler As	360-7885
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522

Sales Model 245 (Cont'd.)

94L		
Original Part Number	Part Name	Classic Part Number
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7J-6250	Bearing-Sleeve	385-3803
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-4392	Bearing-Sleeve	389-6325
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8N-9622	Bracket As-Fan	433-2024

94L		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
8V-2639	Pin As	241-2542
9K-8757	Rod End-Special	311-9361
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9W-6390	Sleeve	385-3795
9Y-1917	Pulley-Fan	395-1311
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587

94L		
Original Part Number	Part Name	Classic Part Number
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
289-2946	Seal-U-Cup	472-8030
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812

Sales Model 245 (Cont'd.)

95V		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7895	Cone-Roller Brg	396-4145
1S-9209	Shaft-Tightener	374-6499
1U-2738	Piston Assembly	367-6074
1V-5736	Bearing-Sleeve	379-0187
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3F-4971	Pin	295-5693
3G-3521	Bearing	380-7513
3G-5750	Bearing-Plate	419-4734
3G-6910	Bearing-Plate	419-4733
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823

95V		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3V-8976	Cylinder As	433-7508
4B-7255	Cone-Bearing	386-4951
4J-6374	Bearing-Sleeve	295-6407
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4539	Sleeve	314-8720
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-1684	Bearing	377-7428
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571

95V		
Original Part Number	Part Name	Classic Part Number
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5G-3612	Cap Gp-Protn	295-6419
5L-6326	Bearing-Ball	420-3222
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-8053	Kit-Gasket (Sch)	415-1901
5P-8366	Gasket Kit - Sch	387-2911
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-3256	Mount As	314-8688
6N-7154	Rotocoil As	380-7556
6S-2828	Cup-Roller Brg	384-5932
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079

Sales Model 245 (Cont'd.)

95V		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7956	Disc-Friction	374-4677
6Y-8842	Block-Rubber	432-8274
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6398	Muffler As	360-7885
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7J-6250	Bearing-Sleeve	385-3803
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8371	Line As-Fuel Inj	373-1901
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893

95V		
Original Part Number	Part Name	Classic Part Number
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-4392	Bearing-Sleeve	389-6325
8M-0874	Plunger As-Valve	311-9439
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8N-9622	Bracket As-Fan	433-2024
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8V-2639	Pin As	241-2542
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-5529	Body-F Inj Valve	378-3993
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9W-6390	Sleeve	385-3795
9Y-1917	Pulley-Fan	395-1311
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926

95V		
Original Part Number	Part Name	Classic Part Number
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
114-4787	Kit-Gasket (Ocl)	388-0657
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546

Sales Model 245 (Cont'd.)

95V		
Original Part Number	**Part Name**	**Classic Part Number**
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701

95V		
Original Part Number	**Part Name**	**Classic Part Number**
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-6574	Kit-Gasket-Rs	437-2034
233-7083	Kit-Gasket-Fs	387-2919
234-1874	Kit-Gasket-Fs	437-8668

95V		
Original Part Number	**Part Name**	**Classic Part Number**
253-1752	Plate-Thrust	379-0170
289-2946	Seal-U-Cup	472-8030
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812

Sales Model 245B

1SJ		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7895	Cone-Roller Brg	396-4145
1S-9209	Shaft-Tightener	374-6499
1U-2738	Piston Assembly	367-6074
1V-5736	Bearing-Sleeve	379-0187
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305

1SJ		
Original Part Number	**Part Name**	**Classic Part Number**
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3F-4971	Pin	295-5693
3G-3521	Bearing	380-7513
3G-5750	Bearing-Plate	419-4734
3G-6910	Bearing-Plate	419-4733
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3V-8976	Cylinder As	433-7508
4J-6374	Bearing-Sleeve	295-6407
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499

1SJ		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4539	Sleeve	314-8720
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-1463	Muffler As	360-7876
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216

Sales Model 245B (Cont'd.)

1SJ		
Original Part Number	Part Name	Classic Part Number
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4T-1684	Bearing	377-7428
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5G-3612	Cap Gp-Protn	295-6419
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-3256	Mount As	314-8688
6N-7154	Rotocoil As	380-7556
6S-2828	Cup-Roller Brg	384-5932
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-7956	Disc-Friction	374-4677

1SJ		
Original Part Number	Part Name	Classic Part Number
6Y-8842	Block-Rubber	432-8274
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6398	Muffler As	360-7885
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7J-6250	Bearing-Sleeve	385-3803
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7X-7954	Gasket Kit	393-5204
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571

1SJ		
Original Part Number	Part Name	Classic Part Number
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-4392	Bearing-Sleeve	389-6325
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8N-9622	Bracket As-Fan	433-2024
8S-6511	Bearing-Sleeve	380-7372
8V-2639	Pin As	241-2542
9K-8757	Rod End-Special	311-9361
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9W-6390	Sleeve	385-3795
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691

Sales Model 245B (Cont'd.)

1SJ		
Original Part Number	**Part Name**	**Classic Part Number**
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589

1SJ		
Original Part Number	**Part Name**	**Classic Part Number**
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-3235	Housing-Sprocket	394-0200
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699

1SJ		
Original Part Number	**Part Name**	**Classic Part Number**
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-6574	Kit-Gasket-Rs	437-2034
234-1874	Kit-Gasket-Fs	437-8668
253-1752	Plate-Thrust	379-0170
289-2946	Seal-U-Cup	472-8030
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812

6MF		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7895	Cone-Roller Brg	396-4145
1S-9209	Shaft-Tightener	374-6499
1U-2738	Piston Assembly	367-6074
1V-5736	Bearing-Sleeve	379-0187
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569

6MF		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817

6MF		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3F-4971	Pin	295-5693
3G-3521	Bearing	380-7513
3G-5750	Bearing-Plate	419-4734
3G-6910	Bearing-Plate	419-4733
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3V-8976	Cylinder As	433-7508
4J-6374	Bearing-Sleeve	295-6407
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489

Sales Model 245B (Cont'd.)

6MF		
Original Part Number	Part Name	Classic Part Number
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4539	Sleeve	314-8720
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-1463	Muffler As	360-7876
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4T-1684	Bearing	377-7428
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441

6MF		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-3256	Mount As	314-8688
6N-7154	Rotocoil As	380-7556
6S-2828	Cup-Roller Brg	384-5932
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-7956	Disc-Friction	374-4677
6Y-8842	Block-Rubber	432-8274
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6398	Muffler As	360-7885
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7J-6250	Bearing-Sleeve	385-3803
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922

6MF		
Original Part Number	Part Name	Classic Part Number
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-7809	Cap As-Radiator	295-6417
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7X-7954	Gasket Kit	393-5204
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-4392	Bearing-Sleeve	389-6325
8M-0874	Plunger As-Valve	311-9439
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-5305	Spacer	363-7464
8N-8258	Bearing-Sleeve	452-1077
8N-9622	Bracket As-Fan	433-2024
8S-6511	Bearing-Sleeve	380-7372
8V-2639	Pin As	241-2542
9K-8757	Rod End-Special	311-9361
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718

Sales Model 245B (Cont'd.)

6MF		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9W-6390	Sleeve	385-3795
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215

6MF		
Original Part Number	**Part Name**	**Classic Part Number**
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812

6MF		
Original Part Number	**Part Name**	**Classic Part Number**
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-6574	Kit-Gasket-Rs	437-2034
234-1874	Kit-Gasket-Fs	437-8668
253-1752	Plate-Thrust	379-0170
289-2946	Seal-U-Cup	472-8030
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812

Sales Model 245D

4LK		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7895	Cone-Roller Brg	396-4145

4LK		
Original Part Number	**Part Name**	**Classic Part Number**
1S-9209	Shaft-Tightener	374-6499
1U-2738	Piston Assembly	367-6074
1V-5736	Bearing-Sleeve	379-0187
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356

4LK		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354

Sales Model 245D (Cont'd.)

4LK		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2N-5842	Screw-Bridge Adj	418-1934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3F-4971	Pin	295-5693
3G-3521	Bearing	380-7513
3G-5750	Bearing-Plate	419-4734
3G-6910	Bearing-Plate	419-4733
3H-8726	Mount As	385-7208
3P-1210	Cone-Roller Brg	399-4433
3V-8976	Cylinder As	433-7508
4J-6374	Bearing-Sleeve	295-6407
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4539	Sleeve	314-8720
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-1463	Muffler As	360-7876
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216

4LK		
Original Part Number	Part Name	Classic Part Number
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4T-1684	Bearing	377-7428
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5L-6326	Bearing-Ball	420-3222
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-3256	Mount As	314-8688
6N-7154	Rotocoil As	380-7556
6S-2828	Cup-Roller Brg	384-5932
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-7956	Disc-Friction	374-4677

4LK		
Original Part Number	Part Name	Classic Part Number
6Y-8842	Block-Rubber	432-8274
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7J-6250	Bearing-Sleeve	385-3803
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8018	Seal-Water	418-1964
7S-7809	Cap As-Radiator	295-6417
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053

Sales Model 245D (Cont'd.)

4LK		
Original Part Number	Part Name	Classic Part Number
8K-4392	Bearing-Sleeve	389-6325
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
8V-2639	Pin As	241-2542
9K-8757	Rod End-Special	311-9361
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9W-6390	Sleeve	385-3795
9Y-0635	Spacer	435-8519
9Y-1798	Seal-Water	379-0165
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689

4LK		
Original Part Number	Part Name	Classic Part Number
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
111-8015	Gasket As-Head	279-4977
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035

4LK		
Original Part Number	Part Name	Classic Part Number
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3679	Kit-Gasket (Rs)	437-2039
233-9456	Kit-Gasket-Sch	422-7510
253-1752	Plate-Thrust	379-0170
289-2946	Seal-U-Cup	472-8030
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

7ZJ		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7895	Cone-Roller Brg	396-4145

7ZJ		
Original Part Number	Part Name	Classic Part Number
1S-9209	Shaft-Tightener	374-6499
1U-2738	Piston Assembly	367-6074
1V-5736	Bearing-Sleeve	379-0187
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356

7ZJ		
Original Part Number	Part Name	Classic Part Number
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2D-9191	Cone-Roller Brg	374-1837

Sales Model 245D (Cont'd.)

7ZJ		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-2139	Cone-Roller Brg	415-1911
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2N-5842	Screw-Bridge Adj	418-1934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-3322	Gasket Kit - F	437-8114
3E-6772	Seal-Water	382-8017
3E-7473	Gasket Kit	393-3616
3F-4971	Pin	295-5693
3G-3521	Bearing	380-7513
3G-5750	Bearing-Plate	419-4734
3G-6910	Bearing-Plate	419-4733
3H-8726	Mount As	385-7208
3P-1210	Cone-Roller Brg	399-4433
3V-8976	Cylinder As	433-7508
4J-6374	Bearing-Sleeve	295-6407
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4539	Sleeve	314-8720
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885

7ZJ		
Original Part Number	Part Name	Classic Part Number
4P-1463	Muffler As	360-7876
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4T-1684	Bearing	377-7428
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5G-3612	Cap Gp-Protn	295-6419
5L-8856	Coupling-Exhaust	311-9379
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-3256	Mount As	314-8688
6N-7154	Rotocoil As	380-7556
6S-2828	Cup-Roller Brg	384-5932
6V-2202	Bearing-Spl Ball	380-1574

7ZJ		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-7956	Disc-Friction	374-4677
6Y-8842	Block-Rubber	432-8274
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7J-6250	Bearing-Sleeve	385-3803
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494

Sales Model 245D (Cont'd.)

7ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
8H-2810	Case As-Filter	314-8512
8J-4492	Stem	383-3702
8K-0509	Plate-Mating	382-5053
8K-4392	Bearing-Sleeve	389-6325
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
8V-2639	Pin As	241-2542
9K-8757	Rod End-Special	311-9361
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9W-6390	Sleeve	385-3795
9Y-0635	Spacer	435-8519
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000

7ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
114-0468	Pin-G.E.T.	443-1203
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845

7ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
223-3343	Kit-Gasket-Acl	437-8131
232-2922	Kit-Gasket-Rs	437-8671
232-3679	Kit-Gasket (Rs)	437-2039
233-9456	Kit-Gasket-Sch	422-7510
234-1874	Kit-Gasket-Fs	437-8668
253-1752	Plate-Thrust	379-0170
289-2946	Seal-U-Cup	472-8030
290-2060	Kit-Gasket-Sch	438-0149
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

Sales Model 301.5, 301.6, 301.8, 302.5

3YW, BDH, BFA, 4AZ		
Original Part Number	**Part Name**	**Classic Part Number**
150-3416	Muffler	360-9620

Sales Model 302.5C

GBB		
Original Part Number	**Part Name**	**Classic Part Number**
176-3900	Accumulator	416-5513

Sales Model 302C

KSG		
Original Part Number	**Part Name**	**Classic Part Number**
8D-0983	Mounting	384-3470

LJF		
Original Part Number	**Part Name**	**Classic Part Number**
8C-3111	Rod End-Spher	392-4523

LJF		
Original Part Number	**Part Name**	**Classic Part Number**
8D-0983	Mounting	384-3470
347-6081	Gauge As	360-2348

Sales Model 303

CAR		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8D-0983	Mounting	384-3470
8N-3666	Repair Kt-Major	377-5842

CAR		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9931	Mount As.	360-2354
100-6267	Plate As-Idler	375-9983
110-1337	Ring Kit-Pstn	377-5834
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693

CAR		
Original Part Number	**Part Name**	**Classic Part Number**
176-3900	Accumulator	416-5513
347-6081	Gauge As	360-2348

DMA		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8D-0983	Mounting	384-3470

DMA		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3666	Repair Kt-Major	377-5842
9W-9931	Mount As.	360-2354
100-6267	Plate As-Idler	375-9983
110-1337	Ring Kit-Pstn	377-5834

DMA		
Original Part Number	**Part Name**	**Classic Part Number**
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348

FAD		
Original Part Number	**Part Name**	**Classic Part Number**
8C-3111	Rod End-Spher	392-4523
347-6081	Gauge As	360-2348

Excavators

Sales Model 303.5

AFW		
Original Part Number	**Part Name**	**Classic Part Number**
8D-0983	Mounting	384-3470
347-6081	Gauge As	360-2348

DCH		
Original Part Number	**Part Name**	**Classic Part Number**
8D-0983	Mounting	384-3470
347-6081	Gauge As	360-2348

Sales Model 303.5C

CRL		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067

CRL		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

DMY		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067
9D-7924	Mount As	360-2356

DMY		
Original Part Number	**Part Name**	**Classic Part Number**
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348

Sales Model 303.5D

RHP		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067
9D-7924	Mount As	360-2356

RHP		
Original Part Number	**Part Name**	**Classic Part Number**
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348

SEG		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

Sales Model 303.5E

AC5		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

Sales Model 303.5E (Cont'd.)

BG8		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348

CR9		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

JWY		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348

RKY		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067
9D-7924	Mount As	360-2356
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348

RSE		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

SFH		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

Sales Model 303C

AZS		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

BXT		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067
9D-7924	Mount As	360-2356
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348

MSP		
Original Part Number	**Part Name**	**Classic Part Number**
8C-3111	Rod End-Spher	392-4523
347-6081	Gauge As	360-2348

Excavators

Sales Model 303E

CR7		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

HHM		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067
9D-7924	Mount As	360-2356
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348

SGE		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

SMG		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

Sales Model 304

BTN		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8D-0983	Mounting	384-3470
8N-3666	Repair Kt-Major	377-5842

BTN		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9931	Mount As.	360-2354
100-6267	Plate As-Idler	375-9983
110-1337	Ring Kit-Pstn	377-5834
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693

BTN		
Original Part Number	**Part Name**	**Classic Part Number**
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348

NAD		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8D-0983	Mounting	384-3470

NAD		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3666	Repair Kt-Major	377-5842
9W-9931	Mount As.	360-2354
100-6267	Plate As-Idler	375-9983
110-1337	Ring Kit-Pstn	377-5834

NAD		
Original Part Number	**Part Name**	**Classic Part Number**
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
176-3900	Accumulator	416-5513
347-6081	Gauge As	360-2348

Sales Model 304.5

ANR		
Original Part Number	**Part Name**	**Classic Part Number**
8D-0983	Mounting	384-3470
347-6081	Gauge As	360-2348

WAK		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1647	Impeller-Conv	377-7415
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358

WAK		
Original Part Number	**Part Name**	**Classic Part Number**
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2P-8986	Cup-Rlr Bearing	415-1912
2V-7990	Tube As	373-5382

WAK		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2752	Cartridge Gp-Rr	422-8127
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4E-3456	Lever As	367-6081
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8344	Spider As-Fan	416-5520
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

Sales Model 304.5 (Cont'd.)

WAK		
Original Part Number	Part Name	Classic Part Number
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0092	Hub As	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-3680	Bellcrank	308-9802
4V-3842	Support-Trunnion	396-9935
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-6527	Disc	376-9050
4V-7543	Retainer	281-1699
4V-7545	Gear-Ring	394-9823
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534

WAK		
Original Part Number	Part Name	Classic Part Number
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
4Y-1034	Pin As	396-0641
5L-2031	Cup-Roller Brg	384-5927
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
5V-7574	Ring-Retaining	392-4483
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2932	Pump Gp-Vn Bsc-B	422-8155
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015

WAK		
Original Part Number	Part Name	Classic Part Number
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200
6W-2899	Shaft-Pinion	446-3057
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7I-4187	Yoke-1550	380-1510
7K-0686	Trunnion-Rear	297-7266
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451

Sales Model 304.5 (Cont'd.)

WAK		
Original Part Number	Part Name	Classic Part Number
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7V-0638	Spacer	425-3651
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8D-0983	Mounting	384-3470
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858

WAK		
Original Part Number	Part Name	Classic Part Number
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-1537	Gear-Sun	446-3061
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-5842	Gear-Transfer	394-0913

WAK		
Original Part Number	Part Name	Classic Part Number
9G-8117	Housing As-Cl	302-2686
9L-2685	Rod End	419-1866
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9V-0247	Plate	417-4527
9V-8693	Actuator Gp-Bk	375-2629
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
138-2317	Wheel	396-9948
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

Excavators

Sales Model 304.5 (Cont'd.)

WAK		
Original Part Number	**Part Name**	**Classic Part Number**
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646

WAK		
Original Part Number	**Part Name**	**Classic Part Number**
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
247-2670	Muffler-Classic	247-2675
270-4353	Kit-Liner-Cla	295-6438

WAK		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
275-0120	Pin As	419-7245
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
347-6081	Gauge As	360-2348

Sales Model 304.5E

FXT		
Original Part Number	**Part Name**	**Classic Part Number**
6K-4148	Bearing-Sleeve	393-3670
347-6081	Gauge As	360-2348

Sales Model 304C

ENW		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067
9D-7924	Mount As	360-2356

ENW		
Original Part Number	**Part Name**	**Classic Part Number**
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348

FPK		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067
9D-7924	Mount As	360-2356

FPK		
Original Part Number	**Part Name**	**Classic Part Number**
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348

NBM		
Original Part Number	**Part Name**	**Classic Part Number**
8C-3111	Rod End-Spher	392-4523
347-6081	Gauge As	360-2348

STB		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

Sales Model 304D

TYK		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
9D-7924	Mount As	360-2356

TYK		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348

Sales Model 304E

CJ2		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348

GC5		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

HC5		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

ME4		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348

SSC		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

TSR		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

TTN		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
9D-7924	Mount As	360-2356

TTN		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348

Excavators

Sales Model 305

BMW		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8D-0983	Mounting	384-3470

BMW		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3666	Repair Kt-Major	377-5842
9W-9931	Mount As.	360-2354
100-6267	Plate As-Idler	375-9983
110-1337	Ring Kit-Pstn	377-5834

BMW		
Original Part Number	**Part Name**	**Classic Part Number**
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348

DCR		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483

DCR		
Original Part Number	**Part Name**	**Classic Part Number**
8C-3111	Rod End-Spher	392-4523
347-6081	Gauge As	360-2348

DGT		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8D-0983	Mounting	384-3470

DGT		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3666	Repair Kt-Major	377-5842
9W-9931	Mount As.	360-2354
100-6267	Plate As-Idler	375-9983
110-1337	Ring Kit-Pstn	377-5834

DGT		
Original Part Number	**Part Name**	**Classic Part Number**
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
176-3900	Accumulator	416-5513
347-6081	Gauge As	360-2348

DSA		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
6Y-9930	Mount As	360-2353
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
8D-0983	Mounting	384-3470

DSA		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3666	Repair Kt-Major	377-5842
9W-9931	Mount As.	360-2354
100-6267	Plate As-Idler	375-9983
110-1337	Ring Kit-Pstn	377-5834

DSA		
Original Part Number	**Part Name**	**Classic Part Number**
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
176-3900	Accumulator	416-5513
347-6081	Gauge As	360-2348

Sales Model 305.5

CXZ		
Original Part Number	**Part Name**	**Classic Part Number**
8D-0983	Mounting	384-3470

CXZ		
Original Part Number	**Part Name**	**Classic Part Number**
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348

DCK		
Original Part Number	**Part Name**	**Classic Part Number**
8D-0983	Mounting	384-3470

Sales Model 305.5 (Cont'd.)

DCK		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295

DCK		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348

Sales Model 305.5D

FLZ		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
6Y-7652	Cup-Rlr Brg	399-6067
9D-7924	Mount As	360-2356

FLZ		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348

YHS		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

Sales Model 305.5E

CR5		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
347-6081	Gauge As	360-2348

EJX		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
3P-1210	Cone-Roller Brg	399-4433
6Y-7652	Cup-Rlr Brg	399-6067

EJX		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348

FKY		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
6Y-7652	Cup-Rlr Brg	399-6067
9D-7924	Mount As	360-2356

FKY		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348

FR5		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433

FR5		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

Sales Model 305.5E (Cont'd.)

FSC		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

MX5		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433

MX5		
Original Part Number	**Part Name**	**Classic Part Number**
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348

NC5		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433

NC5		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

WE2		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433

WE2		
Original Part Number	**Part Name**	**Classic Part Number**
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348

YGB		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

Sales Model 305C

GYZ		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
9D-7924	Mount As	360-2356

GYZ		
Original Part Number	**Part Name**	**Classic Part Number**
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348

HWJ		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
9D-7924	Mount As	360-2356

HWJ		
Original Part Number	**Part Name**	**Classic Part Number**
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348

KMC		
Original Part Number	**Part Name**	**Classic Part Number**
8C-3111	Rod End-Spher	392-4523
347-6081	Gauge As	360-2348

Sales Model 305D

WCJ		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

XER		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
6Y-7652	Cup-Rlr Brg	399-6067
9D-7924	Mount As	360-2356

XER		
Original Part Number	**Part Name**	**Classic Part Number**
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348

Sales Model 305E

BZ5		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433

BZ5		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

DF5		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433

DF5		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

DJX		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
3P-1210	Cone-Roller Brg	399-4433
6Y-7652	Cup-Rlr Brg	399-6067

DJX		
Original Part Number	**Part Name**	**Classic Part Number**
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348

H5M		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
347-6081	Gauge As	360-2348

WDL		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

XFA		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
6Y-7652	Cup-Rlr Brg	399-6067

Sales Model 305E (Cont'd.)

XFA		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
226-8202	Seal-Wiper	472-8024

XFA		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348

XSC		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
347-6081	Gauge As	360-2348

Sales Model 306

MXH		
Original Part Number	Part Name	Classic Part Number
8D-0983	Mounting	384-3470

MXH		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348

SMD		
Original Part Number	Part Name	Classic Part Number
8D-0983	Mounting	384-3470

SMD		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348

Sales Model 306E

E2W		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433

E2W		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348

FHL		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433

FHL		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348

Sales Model 307

2PM		
Original Part Number	Part Name	Classic Part Number
8C-3111	Rod End-Spher	392-4523

Sales Model 307 (Cont'd.)

2PM		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
289-2935	Seal As-Buffer	472-8028

2PM		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348

2PM		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292

2WM		
Original Part Number	Part Name	Classic Part Number
8C-3111	Rod End-Spher	392-4523
127-8592	Muffler As	347-0463
223-3095	Gauge As	360-2295

2WM		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

9ZL		
Original Part Number	Part Name	Classic Part Number
8C-3111	Rod End-Spher	392-4523
223-3095	Gauge As	360-2295

9ZL		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028
308-1845	Seal-Wiper	472-8032

9ZL		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 307B

4RW		
Original Part Number	Part Name	Classic Part Number
117-6270	Support As	434-1400
223-3095	Gauge As	360-2295

4RW		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028
308-1845	Seal-Wiper	472-8032

4RW		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

5CW		
Original Part Number	Part Name	Classic Part Number
117-6270	Support As	434-1400
223-3095	Gauge As	360-2295

5CW		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028
308-1845	Seal-Wiper	472-8032

5CW		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

6KZ		
Original Part Number	Part Name	Classic Part Number
117-6270	Support As	434-1400
223-3095	Gauge As	360-2295

6KZ		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028
308-1845	Seal-Wiper	472-8032

6KZ		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

7DZ		
Original Part Number	Part Name	Classic Part Number
117-6270	Support As	434-1400
223-3095	Gauge As	360-2295

7DZ		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028
308-1845	Seal-Wiper	472-8032

7DZ		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Excavators

Sales Model 307B (Cont'd.)

AFB		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-9930	Mount As	360-2353
9W-9931	Mount As.	360-2354

AFB		
Original Part Number	**Part Name**	**Classic Part Number**
117-6270	Support As	434-1400
223-3095	Gauge As	360-2295

AFB		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 307C

BAJ		
Original Part Number	**Part Name**	**Classic Part Number**
5F-8651	Bearing-Ball	420-3223
7J-5131	Trunnion	296-1371
163-3749	Bearing-Sleeve	433-7505

BAJ		
Original Part Number	**Part Name**	**Classic Part Number**
223-3095	Gauge As	360-2295
289-2935	Seal As-Buffer	472-8028
308-1845	Seal-Wiper	472-8032

BAJ		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BCM		
Original Part Number	**Part Name**	**Classic Part Number**
4T-8054	Seal As	472-8010
4V-8675	Bearing-Sleeve	394-0187
5F-8651	Bearing-Ball	420-3223

BCM		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9592	Bearing-Sleeve	360-2336
223-3095	Gauge As	360-2295
289-2935	Seal As-Buffer	472-8028

BCM		
Original Part Number	**Part Name**	**Classic Part Number**
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BNE		
Original Part Number	**Part Name**	**Classic Part Number**
4T-8054	Seal As	472-8010
4V-8675	Bearing-Sleeve	394-0187
5F-8651	Bearing-Ball	420-3223
7K-9592	Bearing-Sleeve	360-2336

BNE		
Original Part Number	**Part Name**	**Classic Part Number**
086-0523	Pin	314-8696
223-3095	Gauge As	360-2295
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

BNE		
Original Part Number	**Part Name**	**Classic Part Number**
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 307D

DSG		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
3P-1210	Cone-Roller Brg	399-4433
5F-8651	Bearing-Ball	420-3223
7K-9592	Bearing-Sleeve	360-2336

DSG		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
168-0444	Pin	393-3687

DSG		
Original Part Number	**Part Name**	**Classic Part Number**
191-3235	Housing-Sprocket	394-0200
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 307D (Cont'd.)

ECT		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
5F-8651	Bearing-Ball	420-3223

ECT		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348

ECT		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292

LBY		
Original Part Number	Part Name	Classic Part Number
5F-8651	Bearing-Ball	420-3223
223-3095	Gauge As	360-2295

LBY		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WZX		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433

WZX		
Original Part Number	Part Name	Classic Part Number
5F-8651	Bearing-Ball	420-3223
223-3095	Gauge As	360-2295

WZX		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

XCH		
Original Part Number	Part Name	Classic Part Number
5P-3489	Race-Brg Outer	396-9905

XCH		
Original Part Number	Part Name	Classic Part Number
6Y-3484	Bearing-Spl Ball	416-2166
168-0444	Pin	393-3687

Sales Model 307E

CE2		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
5F-8651	Bearing-Ball	420-3223

CE2		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

H1Y		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
5F-8651	Bearing-Ball	420-3223

H1Y		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KC9		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433

KC9		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Excavators

Sales Model 308B

3YS		
Original Part Number	Part Name	Classic Part Number
8C-3111	Rod End-Spher	392-4523
223-3095	Gauge As	360-2295

3YS		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 308C

CPE		
Original Part Number	Part Name	Classic Part Number
5F-8651	Bearing-Ball	420-3223
7J-5131	Trunnion	296-1371
117-6270	Support As	434-1400

CPE		
Original Part Number	Part Name	Classic Part Number
163-3749	Bearing-Sleeve	433-7505
223-3095	Gauge As	360-2295

CPE		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CRW		
Original Part Number	Part Name	Classic Part Number
5F-8651	Bearing-Ball	420-3223
7J-5131	Trunnion	296-1371
8C-3111	Rod End-Spher	392-4523

CRW		
Original Part Number	Part Name	Classic Part Number
117-6270	Support As	434-1400
223-3095	Gauge As	360-2295

CRW		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KCX		
Original Part Number	Part Name	Classic Part Number
4V-8675	Bearing-Sleeve	394-0187
5F-8651	Bearing-Ball	420-3223
8C-3111	Rod End-Spher	392-4523

KCX		
Original Part Number	Part Name	Classic Part Number
117-6270	Support As	434-1400
223-3095	Gauge As	360-2295
289-2935	Seal As-Buffer	472-8028
308-1845	Seal-Wiper	472-8032

KCX		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 308D

FYC		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
2B-0941	Spacer	418-1955
5F-8651	Bearing-Ball	420-3223

FYC		
Original Part Number	Part Name	Classic Part Number
7K-9592	Bearing-Sleeve	360-2336
168-0444	Pin	393-3687

FYC		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GBT		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
5F-8651	Bearing-Ball	420-3223

Sales Model 308D (Cont'd.)

GBT		
Original Part Number	Part Name	Classic Part Number
7K-9592	Bearing-Sleeve	360-2336

GBT		
Original Part Number	Part Name	Classic Part Number
168-0444	Pin	393-3687
223-3095	Gauge As	360-2295

GBT		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

HSA		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
5F-8651	Bearing-Ball	420-3223
086-0414	Flange	392-4522

HSA		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
163-3749	Bearing-Sleeve	433-7505

HSA		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JPS		
Original Part Number	Part Name	Classic Part Number
5F-8651	Bearing-Ball	420-3223
8C-3111	Rod End-Spher	392-4523
223-3095	Gauge As	360-2295

JPS		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 308E

F8C		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
5F-8651	Bearing-Ball	420-3223

F8C		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

FJX		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
3P-1210	Cone-Roller Brg	399-4433

FJX		
Original Part Number	Part Name	Classic Part Number
5F-8651	Bearing-Ball	420-3223
7K-9592	Bearing-Sleeve	360-2336

FJX		
Original Part Number	Part Name	Classic Part Number
168-0444	Pin	393-3687
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GBJ		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
5F-8651	Bearing-Ball	420-3223
7K-9592	Bearing-Sleeve	360-2336

GBJ		
Original Part Number	Part Name	Classic Part Number
168-0444	Pin	393-3687
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

HAM		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 308E (Cont'd.)

HEL		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348

HEL		
Original Part Number	**Part Name**	**Classic Part Number**
357-7540	Valve-Fill	360-2292

JBE		
Original Part Number	**Part Name**	**Classic Part Number**
8C-3111	Rod End-Spher	392-4523

JBE		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JSN		
Original Part Number	**Part Name**	**Classic Part Number**
8C-3111	Rod End-Spher	392-4523

JSN		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MY2		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433

MY2		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SR8		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
8C-3111	Rod End-Spher	392-4523

SR8		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TAZ		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
5F-8651	Bearing-Ball	420-3223

TAZ		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TM2		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
8C-3111	Rod End-Spher	392-4523

TM2		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TMX		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
3P-1210	Cone-Roller Brg	399-4433

TMX		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9592	Bearing-Sleeve	360-2336
168-0444	Pin	393-3687

TMX		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 311

5PK		
Original Part Number	Part Name	Classic Part Number
1R-6322	Cylinder	384-3463
4T-8054	Seal As	472-8010
5I-7914	Muffler	435-4791
5L-6326	Bearing-Ball	420-3222
6I-6457	Rod	421-8920
7Y-3428	Bearing-Sleeve	314-8647
8C-3111	Rod End-Spher	392-4523

5PK		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0166	Spring	399-4400
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909

5PK		
Original Part Number	Part Name	Classic Part Number
137-3060	Bearing-Sleeve	360-2320
223-3095	Gauge As	360-2295
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

9LJ		
Original Part Number	Part Name	Classic Part Number
1R-6322	Cylinder	384-3463
4T-8054	Seal As	472-8010
5I-7619	Pulley	301-4772
5I-7914	Muffler	435-4791
5L-6326	Bearing-Ball	420-3222
6I-6457	Rod	421-8920
7Y-3428	Bearing-Sleeve	314-8647

9LJ		
Original Part Number	Part Name	Classic Part Number
8C-3111	Rod End-Spher	392-4523
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0166	Spring	399-4400
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641

9LJ		
Original Part Number	Part Name	Classic Part Number
099-0722	Link As	415-1909
137-3060	Bearing-Sleeve	360-2320
223-3095	Gauge As	360-2295
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 311B

2LS		
Original Part Number	Part Name	Classic Part Number
1R-6322	Cylinder	384-3463
5L-6326	Bearing-Ball	420-3222
6I-6457	Rod	421-8920
7Y-3428	Bearing-Sleeve	314-8647
086-0414	Flange	392-4522
086-0523	Pin	314-8696

2LS		
Original Part Number	Part Name	Classic Part Number
099-0166	Spring	399-4400
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
117-6270	Support As	434-1400

2LS		
Original Part Number	Part Name	Classic Part Number
137-3060	Bearing-Sleeve	360-2320
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

2MS		
Original Part Number	Part Name	Classic Part Number
1R-6322	Cylinder	384-3463
5L-6326	Bearing-Ball	420-3222
6I-6457	Rod	421-8920
7Y-3428	Bearing-Sleeve	314-8647
086-0414	Flange	392-4522
086-0523	Pin	314-8696

2MS		
Original Part Number	Part Name	Classic Part Number
099-0166	Spring	399-4400
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
117-6270	Support As	434-1400

2MS		
Original Part Number	Part Name	Classic Part Number
137-3060	Bearing-Sleeve	360-2320
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 311B (Cont'd.)

8GR		
Original Part Number	Part Name	Classic Part Number
1R-6322	Cylinder	384-3463
3G-2797	Bearing-Sleeve	360-2329
5L-6326	Bearing-Ball	420-3222
6I-6457	Rod	421-8920
7Y-3428	Bearing-Sleeve	314-8647

8GR		
Original Part Number	Part Name	Classic Part Number
7Y-6608	Bearing	314-8649
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0166	Spring	399-4400
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641

8GR		
Original Part Number	Part Name	Classic Part Number
099-0722	Link As	415-1909
117-6270	Support As	434-1400
137-3060	Bearing-Sleeve	360-2320
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

8HR		
Original Part Number	Part Name	Classic Part Number
1R-6322	Cylinder	384-3463
3G-2797	Bearing-Sleeve	360-2329
5L-6326	Bearing-Ball	420-3222
6I-6457	Rod	421-8920
7Y-3428	Bearing-Sleeve	314-8647

8HR		
Original Part Number	Part Name	Classic Part Number
7Y-6608	Bearing	314-8649
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0166	Spring	399-4400
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641

8HR		
Original Part Number	Part Name	Classic Part Number
099-0722	Link As	415-1909
117-6270	Support As	434-1400
137-3060	Bearing-Sleeve	360-2320
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 311C

CKE		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
5L-6326	Bearing-Ball	420-3222
7Y-0225	Shaft-Planet	301-4571
7Y-1685	Rod	333-4952
7Y-1780	Cylinder	360-2261
8G-1682	Pin	241-2585

CKE		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0166	Spring	399-4400
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909

CKE		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CLK		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
3G-2797	Bearing-Sleeve	360-2329
5L-6326	Bearing-Ball	420-3222
7Y-0225	Shaft-Planet	301-4571
7Y-1685	Rod	333-4952
7Y-1780	Cylinder	360-2261

CLK		
Original Part Number	Part Name	Classic Part Number
8G-1682	Pin	241-2585
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0166	Spring	399-4400
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909

CLK		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 311C (Cont'd.)

PAD		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
5L-6326	Bearing-Ball	420-3222
086-0414	Flange	392-4522

PAD		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
099-0166	Spring	399-4400
223-3095	Gauge As	360-2295

PAD		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 311D

AKW		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
4T-8054	Seal As	472-8010
5L-6326	Bearing-Ball	420-3222
7I-7181	Piston	393-5217
7Y-0225	Shaft-Planet	301-4571
7Y-1685	Rod	333-4952
7Y-1780	Cylinder	360-2261

AKW		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
227-6789	Bearing-Sleeve	360-2322

AKW		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CLA		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
4T-8054	Seal As	472-8010
5L-6326	Bearing-Ball	420-3222
086-0414	Flange	392-4522

CLA		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

CLA		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DDW		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
5L-6326	Bearing-Ball	420-3222
086-0414	Flange	392-4522

DDW		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

DDW		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DWR		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
4T-8054	Seal As	472-8010
5L-6326	Bearing-Ball	420-3222
086-0523	Pin	314-8696

DWR		
Original Part Number	Part Name	Classic Part Number
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325
289-2935	Seal As-Buffer	472-8028

DWR		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LKA		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010

Sales Model 311D (Cont'd.)

LKA		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
086-0414	Flange	392-4522
086-0523	Pin	314-8696
125-2950	Gear As	301-4762

LKA		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

LKA		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PNJ		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
5L-6326	Bearing-Ball	420-3222
086-0523	Pin	314-8696

PNJ		
Original Part Number	Part Name	Classic Part Number
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

PNJ		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 311F

JFT		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696

JFT		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KCW		
Original Part Number	Part Name	Classic Part Number
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185

KCW		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
086-0414	Flange	392-4522
086-0523	Pin	314-8696

KCW		
Original Part Number	Part Name	Classic Part Number
099-0721	Bearing-Sleeve	314-8641
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LZF		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696

LZF		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 312

6BL		
Original Part Number	Part Name	Classic Part Number
1R-6322	Cylinder	384-3463
6I-6457	Rod	421-8920
6I-9103	Bearing-Outer	421-8182
7Y-1685	Rod	333-4952

6BL		
Original Part Number	Part Name	Classic Part Number
7Y-1687	Piston As	360-2266
7Y-1780	Cylinder	360-2261
7Y-3428	Bearing-Sleeve	314-8647

6BL		
Original Part Number	Part Name	Classic Part Number
8C-3111	Rod End-Spher	392-4523
9S-7534	Pipe-Exh Ext	398-2950
9Y-1403	Muffler As	393-0930
086-0414	Flange	392-4522

Sales Model 312 (Cont'd.)

6BL		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
099-0166	Spring	399-4400
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641

6BL		
Original Part Number	Part Name	Classic Part Number
099-0722	Link As	415-1909
102-8139	Spring	392-4526
108-9191	Pin As	424-3515
117-5553	Guard As-Tck Gde	419-4729
134-8948	Plate	399-8588

6BL		
Original Part Number	Part Name	Classic Part Number
137-3060	Bearing-Sleeve	360-2320
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

6GK		
Original Part Number	Part Name	Classic Part Number
1R-6322	Cylinder	384-3463
5I-7619	Pulley	301-4772
5I-7914	Muffler	435-4791
5L-6326	Bearing-Ball	420-3222
6I-6457	Rod	421-8920
7Y-3428	Bearing-Sleeve	314-8647
8C-3111	Rod End-Spher	392-4523
9J-2759	Trunnion	394-0216

6GK		
Original Part Number	Part Name	Classic Part Number
9S-7534	Pipe-Exh Ext	398-2950
9Y-1403	Muffler As	393-0930
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0166	Spring	399-4400
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641

6GK		
Original Part Number	Part Name	Classic Part Number
099-0722	Link As	415-1909
108-9191	Pin As	424-3515
137-3060	Bearing-Sleeve	360-2320
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

7DK		
Original Part Number	Part Name	Classic Part Number
1R-6322	Cylinder	384-3463
5I-7914	Muffler	435-4791
5L-6326	Bearing-Ball	420-3222
6I-6457	Rod	421-8920
7Y-3428	Bearing-Sleeve	314-8647
8C-3111	Rod End-Spher	392-4523

7DK		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0166	Spring	399-4400
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641

7DK		
Original Part Number	Part Name	Classic Part Number
099-0722	Link As	415-1909
108-9191	Pin As	424-3515
137-3060	Bearing-Sleeve	360-2320
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 312B

2KW		
Original Part Number	Part Name	Classic Part Number
1R-6322	Cylinder	384-3463
4N-4942	Rod-Eye	421-8919
6I-6457	Rod	421-8920
6Y-9930	Mount As	360-2353
7Y-3428	Bearing-Sleeve	314-8647
9S-7534	Pipe-Exh Ext	398-2950
9W-9931	Mount As.	360-2354
9Y-1403	Muffler As	393-0930

2KW		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0166	Spring	399-4400
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
108-9191	Pin As	424-3515

2KW		
Original Part Number	Part Name	Classic Part Number
117-6270	Support As	434-1400
137-2819	Bearing-Sleeve	360-2317
137-3060	Bearing-Sleeve	360-2320
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 312B (Cont'd.)

2NS		
Original Part Number	**Part Name**	**Classic Part Number**
1R-6322	Cylinder	384-3463
5L-6326	Bearing-Ball	420-3222
6I-6457	Rod	421-8920
7Y-3428	Bearing-Sleeve	314-8647
8G-1682	Pin	241-2585
086-0414	Flange	392-4522

2NS		
Original Part Number	**Part Name**	**Classic Part Number**
086-0523	Pin	314-8696
099-0166	Spring	399-4400
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909

2NS		
Original Part Number	**Part Name**	**Classic Part Number**
108-9191	Pin As	424-3515
117-6270	Support As	434-1400
137-3060	Bearing-Sleeve	360-2320
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

3ES		
Original Part Number	**Part Name**	**Classic Part Number**
1R-6322	Cylinder	384-3463
5L-6326	Bearing-Ball	420-3222
6I-6457	Rod	421-8920
7Y-3428	Bearing-Sleeve	314-8647
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0166	Spring	399-4400

3ES		
Original Part Number	**Part Name**	**Classic Part Number**
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
108-9191	Pin As	424-3515
117-6270	Support As	434-1400
134-8948	Plate	399-8588

3ES		
Original Part Number	**Part Name**	**Classic Part Number**
134-8949	Plate	383-2110
137-3060	Bearing-Sleeve	360-2320
193-5016	Flange	425-3644
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

3FS		
Original Part Number	**Part Name**	**Classic Part Number**
1R-6322	Cylinder	384-3463
3G-2797	Bearing-Sleeve	360-2329
5L-6326	Bearing-Ball	420-3222
6I-6457	Rod	421-8920
7Y-3428	Bearing-Sleeve	314-8647
8G-1682	Pin	241-2585

3FS		
Original Part Number	**Part Name**	**Classic Part Number**
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0166	Spring	399-4400
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909

3FS		
Original Part Number	**Part Name**	**Classic Part Number**
108-9191	Pin As	424-3515
117-6270	Support As	434-1400
137-3060	Bearing-Sleeve	360-2320
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

6SW		
Original Part Number	**Part Name**	**Classic Part Number**
1R-6322	Cylinder	384-3463
4N-4942	Rod-Eye	421-8919
6I-6457	Rod	421-8920
6I-9103	Bearing-Outer	421-8182
6Y-9930	Mount As	360-2353
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1780	Cylinder	360-2261
7Y-3428	Bearing-Sleeve	314-8647
9S-7534	Pipe-Exh Ext	398-2950

6SW		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9931	Mount As.	360-2354
9Y-1403	Muffler As	393-0930
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0166	Spring	399-4400
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
102-8139	Spring	392-4526

6SW		
Original Part Number	**Part Name**	**Classic Part Number**
108-9191	Pin As	424-3515
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
137-2819	Bearing-Sleeve	360-2317
137-3060	Bearing-Sleeve	360-2320
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 312B (Cont'd.)

8JR		
Original Part Number	Part Name	Classic Part Number
1R-6322	Cylinder	384-3463
3G-2797	Bearing-Sleeve	360-2329
5L-6326	Bearing-Ball	420-3222
6I-6457	Rod	421-8920
7Y-3428	Bearing-Sleeve	314-8647
7Y-6608	Bearing	314-8649

8JR		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0166	Spring	399-4400
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909

8JR		
Original Part Number	Part Name	Classic Part Number
108-9191	Pin As	424-3515
117-6270	Support As	434-1400
137-3060	Bearing-Sleeve	360-2320
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

9FS		
Original Part Number	Part Name	Classic Part Number
1R-6322	Cylinder	384-3463
4N-4942	Rod-Eye	421-8919
6I-6457	Rod	421-8920
6Y-9930	Mount As	360-2353
7Y-3428	Bearing-Sleeve	314-8647
9S-7534	Pipe-Exh Ext	398-2950
9W-9931	Mount As.	360-2354
9Y-1403	Muffler As	393-0930

9FS		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0166	Spring	399-4400
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
108-9191	Pin As	424-3515

9FS		
Original Part Number	Part Name	Classic Part Number
117-6270	Support As	434-1400
137-2819	Bearing-Sleeve	360-2317
137-3060	Bearing-Sleeve	360-2320
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

9GR		
Original Part Number	Part Name	Classic Part Number
1R-6322	Cylinder	384-3463
3G-2797	Bearing-Sleeve	360-2329
5L-6326	Bearing-Ball	420-3222
6I-6457	Rod	421-8920
7Y-3428	Bearing-Sleeve	314-8647
8G-1682	Pin	241-2585

9GR		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0166	Spring	399-4400
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909

9GR		
Original Part Number	Part Name	Classic Part Number
108-9191	Pin As	424-3515
117-6270	Support As	434-1400
137-3060	Bearing-Sleeve	360-2320
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

9HR		
Original Part Number	Part Name	Classic Part Number
1R-6322	Cylinder	384-3463
3G-2797	Bearing-Sleeve	360-2329
5L-6326	Bearing-Ball	420-3222
6I-6457	Rod	421-8920
7Y-3428	Bearing-Sleeve	314-8647
7Y-6608	Bearing	314-8649

9HR		
Original Part Number	Part Name	Classic Part Number
8G-1682	Pin	241-2585
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0166	Spring	399-4400
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641

9HR		
Original Part Number	Part Name	Classic Part Number
099-0722	Link As	415-1909
108-9191	Pin As	424-3515
117-6270	Support As	434-1400
137-3060	Bearing-Sleeve	360-2320
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 312B (Cont'd.)

9NW		
Original Part Number	Part Name	Classic Part Number
1R-6322	Cylinder	384-3463
4N-4942	Rod-Eye	421-8919
6I-6457	Rod	421-8920
6Y-9930	Mount As	360-2353
7Y-3428	Bearing-Sleeve	314-8647
9S-7534	Pipe-Exh Ext	398-2950
9W-9931	Mount As.	360-2354
9Y-1403	Muffler As	393-0930

9NW		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0166	Spring	399-4400
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
108-9191	Pin As	424-3515

9NW		
Original Part Number	Part Name	Classic Part Number
117-6270	Support As	434-1400
137-2819	Bearing-Sleeve	360-2317
137-3060	Bearing-Sleeve	360-2320
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 312C

BNN		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
6I-9103	Bearing-Outer	421-8182
7Y-0225	Shaft-Planet	301-4571
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1780	Cylinder	360-2261

BNN		
Original Part Number	Part Name	Classic Part Number
9S-7534	Pipe-Exh Ext	398-2950
9Y-1403	Muffler As	393-0930
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0722	Link As	415-1909
102-8139	Spring	392-4526

BNN		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BWH		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
9S-7534	Pipe-Exh Ext	398-2950
9Y-1403	Muffler As	393-0930

BWH		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0722	Link As	415-1909

BWH		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CAE		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
5L-6326	Bearing-Ball	420-3222
7I-7181	Piston	393-5217
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-1685	Rod	333-4952
7Y-1780	Cylinder	360-2261
7Y-5128	Bearing-Sleeve	314-8648

CAE		
Original Part Number	Part Name	Classic Part Number
7Y-6608	Bearing	314-8649
8G-1682	Pin	241-2585
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
108-9191	Pin As	424-3515
117-5553	Guard As-Tck Gde	419-4729

CAE		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
236-6269	Bearing-Sleeve	453-6500
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 312C (Cont'd.)

CBA		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-6608	Bearing	314-8649

CBA		
Original Part Number	Part Name	Classic Part Number
8G-1682	Pin	241-2585
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0721	Bearing-Sleeve	314-8641

CBA		
Original Part Number	Part Name	Classic Part Number
099-0722	Link As	415-1909
108-9191	Pin As	424-3515
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CBT		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
9S-7534	Pipe-Exh Ext	398-2950
9Y-1403	Muffler As	393-0930

CBT		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0722	Link As	415-1909

CBT		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DBN		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
6I-9103	Bearing-Outer	421-8182
7Y-0225	Shaft-Planet	301-4571
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266

DBN		
Original Part Number	Part Name	Classic Part Number
7Y-1780	Cylinder	360-2261
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0722	Link As	415-1909
102-8139	Spring	392-4526

DBN		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

FDS		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
3G-2797	Bearing-Sleeve	360-2329
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336

FDS		
Original Part Number	Part Name	Classic Part Number
8G-1682	Pin	241-2585
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909

FDS		
Original Part Number	Part Name	Classic Part Number
108-9191	Pin As	424-3515
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 312D

BRW		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

BRW		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DGF		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296

Sales Model 312D (Cont'd.)

DGF		
Original Part Number	**Part Name**	**Classic Part Number**
086-0414	Flange	392-4522
086-0523	Pin	314-8696

DGF		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325

DGF		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DLP		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
5L-6326	Bearing-Ball	420-3222
086-0414	Flange	392-4522

DLP		
Original Part Number	**Part Name**	**Classic Part Number**
086-0523	Pin	314-8696
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

DLP		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

EAB		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
086-0414	Flange	392-4522

EAB		
Original Part Number	**Part Name**	**Classic Part Number**
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

EAB		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

FAB		
Original Part Number	**Part Name**	**Classic Part Number**
086-0414	Flange	392-4522
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

FAB		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

FBJ		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
5L-6326	Bearing-Ball	420-3222
7I-7181	Piston	393-5217
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261
086-0414	Flange	392-4522

FBJ		
Original Part Number	**Part Name**	**Classic Part Number**
086-0523	Pin	314-8696
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
227-6789	Bearing-Sleeve	360-2322

FBJ		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GAP		
Original Part Number	**Part Name**	**Classic Part Number**
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

GAP		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GWN		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296

Sales Model 312D (Cont'd.)

GWN		
Original Part Number	**Part Name**	**Classic Part Number**
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

GWN		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

HBF		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

HBF		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

HCW		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
4I-0453	Bearing-Sleeve	360-2331
5L-6326	Bearing-Ball	420-3222

HCW		
Original Part Number	**Part Name**	**Classic Part Number**
086-0414	Flange	392-4522
086-0523	Pin	314-8696
125-2950	Gear As	301-4762

HCW		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

HJX		
Original Part Number	**Part Name**	**Classic Part Number**
5L-6326	Bearing-Ball	420-3222
086-0414	Flange	392-4522
086-0523	Pin	314-8696

HJX		
Original Part Number	**Part Name**	**Classic Part Number**
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

HJX		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JBC		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
5L-6326	Bearing-Ball	420-3222
086-0414	Flange	392-4522

JBC		
Original Part Number	**Part Name**	**Classic Part Number**
086-0523	Pin	314-8696
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

JBC		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KCD		
Original Part Number	**Part Name**	**Classic Part Number**
5L-6326	Bearing-Ball	420-3222
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261
086-0414	Flange	392-4522

KCD		
Original Part Number	**Part Name**	**Classic Part Number**
086-0523	Pin	314-8696
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762

KCD		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KES		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296

Sales Model 312D (Cont'd.)

KES		
Original Part Number	**Part Name**	**Classic Part Number**
5L-6326	Bearing-Ball	420-3222
086-0414	Flange	392-4522
086-0523	Pin	314-8696

KES		
Original Part Number	**Part Name**	**Classic Part Number**
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

KES		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KLE		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261

KLE		
Original Part Number	**Part Name**	**Classic Part Number**
086-0414	Flange	392-4522
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

KLE		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KMZ		
Original Part Number	**Part Name**	**Classic Part Number**
086-0414	Flange	392-4522

KMZ		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LDD		
Original Part Number	**Part Name**	**Classic Part Number**
086-0414	Flange	392-4522

LDD		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LRK		
Original Part Number	**Part Name**	**Classic Part Number**
5L-6326	Bearing-Ball	420-3222
086-0414	Flange	392-4522
086-0523	Pin	314-8696

LRK		
Original Part Number	**Part Name**	**Classic Part Number**
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

LRK		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MGJ		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
086-0414	Flange	392-4522

MGJ		
Original Part Number	**Part Name**	**Classic Part Number**
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

MGJ		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MPP		
Original Part Number	**Part Name**	**Classic Part Number**
086-0414	Flange	392-4522
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

MPP		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 312D (Cont'd.)

PHH		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
086-0414	Flange	392-4522
086-0523	Pin	314-8696

PHH		
Original Part Number	Part Name	Classic Part Number
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

PHH		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RCP		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
086-0414	Flange	392-4522
086-0523	Pin	314-8696

RCP		
Original Part Number	Part Name	Classic Part Number
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

RCP		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RHL		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
5L-6326	Bearing-Ball	420-3222
086-0414	Flange	392-4522

RHL		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

RHL		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RKF		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261
086-0414	Flange	392-4522

RKF		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762

RKF		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RXZ		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

RXZ		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SKA		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
086-0414	Flange	392-4522
086-0523	Pin	314-8696

SKA		
Original Part Number	Part Name	Classic Part Number
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

SKA		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TGY		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222

Sales Model 312D (Cont'd.)

TGY		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696

TGY		
Original Part Number	Part Name	Classic Part Number
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

TGY		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TJY		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
086-0414	Flange	392-4522

TJY		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

TJY		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WHJ		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
086-0414	Flange	392-4522

WHJ		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

WHJ		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

XGK		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
5L-6326	Bearing-Ball	420-3222
086-0414	Flange	392-4522

XGK		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

XGK		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 312E

GAC		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
086-0414	Flange	392-4522
086-0523	Pin	314-8696

GAC		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MJD		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185

MJD		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
086-0414	Flange	392-4522
086-0523	Pin	314-8696

MJD		
Original Part Number	Part Name	Classic Part Number
099-0721	Bearing-Sleeve	314-8641
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 312E (Cont'd.)

PZL		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
086-0414	Flange	392-4522
086-0523	Pin	314-8696

PZL		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
240-2913	Bearing-Sleeve	360-2325

PZL		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WEY		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
086-0414	Flange	392-4522

WEY		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

WEY		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 312F

FKE		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

FKE		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KMK		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
086-0414	Flange	392-4522
086-0523	Pin	314-8696

KMK		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

NLG		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
086-0414	Flange	392-4522

NLG		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

NLG		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 313B

9PR		
Original Part Number	Part Name	Classic Part Number
1R-6322	Cylinder	384-3463
6I-6457	Rod	421-8920
7Y-3428	Bearing-Sleeve	314-8647

9PR		
Original Part Number	Part Name	Classic Part Number
8C-3111	Rod End-Spher	392-4523
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0166	Spring	399-4400

9PR		
Original Part Number	Part Name	Classic Part Number
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909

Sales Model 313B (Cont'd.)

9PR		
Original Part Number	Part Name	Classic Part Number
137-3060	Bearing-Sleeve	360-2320

9PR		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348

9PR		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292

AEX		
Original Part Number	Part Name	Classic Part Number
1R-6322	Cylinder	384-3463
6I-6457	Rod	421-8920
7Y-3428	Bearing-Sleeve	314-8647
7Y-6608	Bearing	314-8649
086-0414	Flange	392-4522
086-0523	Pin	314-8696

AEX		
Original Part Number	Part Name	Classic Part Number
099-0166	Spring	399-4400
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
108-9191	Pin As	424-3515

AEX		
Original Part Number	Part Name	Classic Part Number
137-3060	Bearing-Sleeve	360-2320
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BAS		
Original Part Number	Part Name	Classic Part Number
1R-6322	Cylinder	384-3463
6I-6457	Rod	421-8920
7Y-3428	Bearing-Sleeve	314-8647
086-0414	Flange	392-4522
086-0523	Pin	314-8696

BAS		
Original Part Number	Part Name	Classic Part Number
099-0166	Spring	399-4400
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909

BAS		
Original Part Number	Part Name	Classic Part Number
108-9191	Pin As	424-3515
137-3060	Bearing-Sleeve	360-2320
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 313C

HGF		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
7I-7181	Piston	393-5217
086-0414	Flange	392-4522
086-0523	Pin	314-8696

HGF		
Original Part Number	Part Name	Classic Part Number
099-0722	Link As	415-1909
108-9191	Pin As	424-3515
117-6270	Support As	434-1400
223-3095	Gauge As	360-2295

HGF		
Original Part Number	Part Name	Classic Part Number
227-6789	Bearing-Sleeve	360-2322
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WSA		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
8C-3111	Rod End-Spher	392-4523
086-0414	Flange	392-4522

WSA		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
099-0722	Link As	415-1909
117-6270	Support As	434-1400

WSA		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 313D

FAP		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

FAP		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GAJ		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261

GAJ		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

GAJ		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KXD		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
086-0523	Pin	314-8696

KXD		
Original Part Number	Part Name	Classic Part Number
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

KXD		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LBR		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
5L-6326	Bearing-Ball	420-3222
8C-3111	Rod End-Spher	392-4523
086-0414	Flange	392-4522

LBR		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
125-2950	Gear As	301-4762
236-6269	Bearing-Sleeve	453-6500

LBR		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LCE		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
5L-6326	Bearing-Ball	420-3222
7I-7181	Piston	393-5217
086-0414	Flange	392-4522

LCE		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
125-2950	Gear As	301-4762
227-6789	Bearing-Sleeve	360-2322

LCE		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PHF		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261

PHF		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

PHF		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 313D (Cont'd.)

PLD		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
086-0414	Flange	392-4522

PLD		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

PLD		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RKN		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261
086-0414	Flange	392-4522

RKN		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

RKN		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WPK		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
086-0414	Flange	392-4522
086-0523	Pin	314-8696

WPK		
Original Part Number	Part Name	Classic Part Number
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

WPK		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ZAA		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

ZAA		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 313F

GJD		
Original Part Number	Part Name	Classic Part Number
3G-2797	Bearing-Sleeve	360-2329
086-0414	Flange	392-4522

GJD		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

GJD		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

HDK		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

HDK		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 314C

KHB		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
7I-7181	Piston	393-5217
7Y-0225	Shaft-Planet	301-4571
7Y-1685	Rod	333-4952
7Y-1780	Cylinder	360-2261
086-0414	Flange	392-4522

KHB		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
099-0722	Link As	415-1909
108-9191	Pin As	424-3515
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400

KHB		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KJA		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
8C-3111	Rod End-Spher	392-4523
086-0414	Flange	392-4522
086-0523	Pin	314-8696

KJA		
Original Part Number	Part Name	Classic Part Number
099-0722	Link As	415-1909
108-9191	Pin As	424-3515
117-6270	Support As	434-1400
223-3095	Gauge As	360-2295

KJA		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PCA		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
8G-1682	Pin	241-2585
086-0414	Flange	392-4522
086-0523	Pin	314-8696

PCA		
Original Part Number	Part Name	Classic Part Number
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
108-9191	Pin As	424-3515

PCA		
Original Part Number	Part Name	Classic Part Number
117-6270	Support As	434-1400
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SNY		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
086-0414	Flange	392-4522
086-0523	Pin	314-8696

SNY		
Original Part Number	Part Name	Classic Part Number
108-9191	Pin As	424-3515
117-6270	Support As	434-1400
223-3095	Gauge As	360-2295

SNY		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 314D

BYJ		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
5L-6326	Bearing-Ball	420-3222
8C-3111	Rod End-Spher	392-4523
086-0414	Flange	392-4522

BYJ		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

BYJ		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 314D (Cont'd.)

MFK		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
2B-0941	Spacer	418-1955
5L-6326	Bearing-Ball	420-3222
7I-7181	Piston	393-5217
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261
086-0414	Flange	392-4522

MFK		
Original Part Number	**Part Name**	**Classic Part Number**
086-0523	Pin	314-8696
087-5805	Pin	301-7967
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
227-6789	Bearing-Sleeve	360-2322

MFK		
Original Part Number	**Part Name**	**Classic Part Number**
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

	PDP		
SNP	**Original Part Number**	**Part Name**	**Classic Part Number**
	2B-0941	Spacer	418-1955
PDP	4I-0453	Bearing-Sleeve	360-2331
PDP	5L-6326	Bearing-Ball	420-3222
PDP	8C-3111	Rod End-Spher	392-4523

	PDP		
SNP	**Original Part Number**	**Part Name**	**Classic Part Number**
PDP	086-0414	Flange	392-4522
PDP	086-0523	Pin	314-8696
PDP	125-2950	Gear As	301-4762
PDP	240-2913	Bearing-Sleeve	360-2325

	PDP		
SNP	**Original Part Number**	**Part Name**	**Classic Part Number**
PDP	347-6081	Gauge As	360-2348
PDP	357-7540	Valve-Fill	360-2292

SBP		
Original Part Number	**Part Name**	**Classic Part Number**
5L-6326	Bearing-Ball	420-3222
8C-3111	Rod End-Spher	392-4523
086-0414	Flange	392-4522

SBP		
Original Part Number	**Part Name**	**Classic Part Number**
086-0523	Pin	314-8696
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

SBP		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SSZ		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
5L-6326	Bearing-Ball	420-3222
8C-3111	Rod End-Spher	392-4523
086-0414	Flange	392-4522

SSZ		
Original Part Number	**Part Name**	**Classic Part Number**
086-0523	Pin	314-8696
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

SSZ		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TXN		
Original Part Number	**Part Name**	**Classic Part Number**
5L-6326	Bearing-Ball	420-3222
8C-3111	Rod End-Spher	392-4523
086-0414	Flange	392-4522

TXN		
Original Part Number	**Part Name**	**Classic Part Number**
086-0523	Pin	314-8696
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

WLN		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955

TXN		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 314D (Cont'd.)

WLN		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
8C-3111	Rod End-Spher	392-4523
086-0523	Pin	314-8696

WLN		
Original Part Number	Part Name	Classic Part Number
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

WLN		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

XHR		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
5L-6326	Bearing-Ball	420-3222
8C-3111	Rod End-Spher	392-4523

XHR		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
125-2950	Gear As	301-4762
240-2913	Bearing-Sleeve	360-2325

XHR		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 314E

DKD		
Original Part Number	Part Name	Classic Part Number
8C-3111	Rod End-Spher	392-4523
086-0414	Flange	392-4522

DKD		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

DKD		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ECN		
Original Part Number	Part Name	Classic Part Number
8C-3111	Rod End-Spher	392-4523
086-0414	Flange	392-4522

ECN		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

ECN		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GMD		
Original Part Number	Part Name	Classic Part Number
8C-3111	Rod End-Spher	392-4523
086-0414	Flange	392-4522

GMD		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

GMD		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

YCW		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261
8C-3111	Rod End-Spher	392-4523

YCW		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

YCW		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 314E (Cont'd.)

ZJT		
Original Part Number	**Part Name**	**Classic Part Number**
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
4T-8054	Seal As	472-8010

ZJT		
Original Part Number	**Part Name**	**Classic Part Number**
8C-3111	Rod End-Spher	392-4523
086-0414	Flange	392-4522
086-0523	Pin	314-8696
099-0721	Bearing-Sleeve	314-8641

ZJT		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 314F

LFC		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
3G-2797	Bearing-Sleeve	360-2329

LFC		
Original Part Number	**Part Name**	**Classic Part Number**
086-0414	Flange	392-4522
086-0523	Pin	314-8696

LFC		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MFR		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PRG		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
086-0414	Flange	392-4522

PRG		
Original Part Number	**Part Name**	**Classic Part Number**
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

PRG		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RAF		
Original Part Number	**Part Name**	**Classic Part Number**
8C-3111	Rod End-Spher	392-4523
086-0414	Flange	392-4522

RAF		
Original Part Number	**Part Name**	**Classic Part Number**
086-0523	Pin	314-8696
240-2913	Bearing-Sleeve	360-2325

RAF		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 315

3ZM		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-4811	Pin As	480-8268
6I-9103	Bearing-Outer	421-8182
7Y-1685	Rod	333-4952

3ZM		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1687	Piston As	360-2266
7Y-1780	Cylinder	360-2261
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634

3ZM		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-3428	Bearing-Sleeve	314-8647
8C-3111	Rod End-Spher	392-4523
9S-7534	Pipe-Exh Ext	398-2950
9Y-1403	Muffler As	393-0930

Sales Model 315 (Cont'd.)

3ZM		
Original Part Number	**Part Name**	**Classic Part Number**
086-0414	Flange	392-4522
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5978	Flange	374-3496
102-8139	Spring	392-4526
106-6878	Pin	372-7510

3ZM		
Original Part Number	**Part Name**	**Classic Part Number**
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587

3ZM		
Original Part Number	**Part Name**	**Classic Part Number**
137-2819	Bearing-Sleeve	360-2317
193-5016	Flange	425-3644
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

4YM		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-4811	Pin As	480-8268
6I-9103	Bearing-Outer	421-8182
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1780	Cylinder	360-2261
7Y-2395	Bearing-Sleeve	314-8646

4YM		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
8C-3111	Rod End-Spher	392-4523
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
102-8139	Spring	392-4526

4YM		
Original Part Number	**Part Name**	**Classic Part Number**
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

6XM		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-4811	Pin As	480-8268
6I-9103	Bearing-Outer	421-8182
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1780	Cylinder	360-2261
7Y-2395	Bearing-Sleeve	314-8646

6XM		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
8C-3111	Rod End-Spher	392-4523
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
102-8139	Spring	392-4526

6XM		
Original Part Number	**Part Name**	**Classic Part Number**
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

6YM		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-4811	Pin As	480-8268
6I-9103	Bearing-Outer	421-8182
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1780	Cylinder	360-2261
7Y-2395	Bearing-Sleeve	314-8646

6YM		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
8C-3111	Rod End-Spher	392-4523
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
102-8139	Spring	392-4526

6YM		
Original Part Number	**Part Name**	**Classic Part Number**
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

1SW		
Original Part Number	**Part Name**	**Classic Part Number**
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4I-4811	Pin As	480-8268
6I-9103	Bearing-Outer	421-8182
7Y-1685	Rod	333-4952
7Y-1780	Cylinder	360-2261
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
8G-1682	Pin	241-2585

1SW		
Original Part Number	**Part Name**	**Classic Part Number**
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
102-8139	Spring	392-4526
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642

1SW		
Original Part Number	**Part Name**	**Classic Part Number**
133-2437	Link	377-6199
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
223-3095	Gauge As	360-2295
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

2DW		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-4811	Pin As	480-8268
6I-9103	Bearing-Outer	421-8182
7Y-1685	Rod	333-4952
7Y-1780	Cylinder	360-2261
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
087-5802	Link-Rh	301-7964

2DW		
Original Part Number	**Part Name**	**Classic Part Number**
087-5803	Link As	301-7966
102-8139	Spring	392-4526
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642

2DW		
Original Part Number	**Part Name**	**Classic Part Number**
133-2437	Link	377-6199
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
223-3095	Gauge As	360-2295
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

3AW		
Original Part Number	**Part Name**	**Classic Part Number**
3B-6217	Muffler As	247-2671
4I-0453	Bearing-Sleeve	360-2331
4I-4811	Pin As	480-8268
6H-3957	Bearing-Ball	311-9358
6I-9103	Bearing-Outer	421-8182
7Y-1685	Rod	333-4952
7Y-1780	Cylinder	360-2261
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
8G-1682	Pin	241-2585

3AW		
Original Part Number	**Part Name**	**Classic Part Number**
005-8639	Bearing-Aligning	415-1925
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
102-8139	Spring	392-4526
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642

3AW		
Original Part Number	**Part Name**	**Classic Part Number**
133-2437	Link	377-6199
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
223-3095	Gauge As	360-2295
226-8202	Seal-Wiper	472-8024
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 315B (Cont'd.)

5SW		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-4811	Pin As	480-8268
6Y-9930	Mount As	360-2353
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-1685	Rod	333-4952
7Y-1780	Cylinder	360-2261
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-5128	Bearing-Sleeve	314-8648

5SW		
Original Part Number	Part Name	Classic Part Number
7Y-6607	Bearing	372-7508
7Y-6626	Bearing	314-8650
9S-7534	Pipe-Exh Ext	398-2950
9W-9931	Mount As.	360-2354
9Y-1403	Muffler As	393-0930
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
102-8139	Spring	392-4526
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679

5SW		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
133-2437	Link	377-6199
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
191-3235	Housing-Sprocket	394-0200
223-3095	Gauge As	360-2295
236-6269	Bearing-Sleeve	453-6500
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

7RZ		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4T-8054	Seal As	472-8010
6Y-9930	Mount As	360-2353
7Y-1606	Spring	375-5447
7Y-2396	Bearing-Sleeve	314-8634
9L-2685	Rod End	419-1866
9W-9931	Mount As.	360-2354

7RZ		
Original Part Number	Part Name	Classic Part Number
087-5802	Link-Rh	301-7964
107-9739	Pin As	393-3689
115-6428	Piston As	394-0188
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673

7RZ		
Original Part Number	Part Name	Classic Part Number
128-9882	Bearing-Sleeve	314-8642
137-2819	Bearing-Sleeve	360-2317
223-3095	Gauge As	360-2295
226-8202	Seal-Wiper	472-8024
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 315C

AKE		
Original Part Number	Part Name	Classic Part Number
2V-0707	Bearing-Sleeve	360-2328
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4I-4811	Pin As	480-8268
7Y-0225	Shaft-Planet	301-4571
7Y-1685	Rod	333-4952

AKE		
Original Part Number	Part Name	Classic Part Number
7Y-1780	Cylinder	360-2261
7Y-2396	Bearing-Sleeve	314-8634
8G-1682	Pin	241-2585
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
106-6878	Pin	372-7510
107-9739	Pin As	393-3689

AKE		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
137-2919	Bearing-Sleeve	360-2319
163-3749	Bearing-Sleeve	433-7505
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322

Sales Model 315C (Cont'd.)

AKE		
Original Part Number	**Part Name**	**Classic Part Number**
236-6268	Bearing-Sleeve	453-6499
240-2913	Bearing-Sleeve	360-2325

AKE		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

AKE		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ANF		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-4811	Pin As	480-8268
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1685	Rod	333-4952
7Y-1780	Cylinder	360-2261
9S-7534	Pipe-Exh Ext	398-2950
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966

ANF		
Original Part Number	**Part Name**	**Classic Part Number**
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
133-2437	Link	377-6199
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271

ANF		
Original Part Number	**Part Name**	**Classic Part Number**
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BTL		
Original Part Number	**Part Name**	**Classic Part Number**
2V-0707	Bearing-Sleeve	360-2328
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4I-4811	Pin As	480-8268
7Y-0225	Shaft-Planet	301-4571
7Y-1685	Rod	333-4952
7Y-1780	Cylinder	360-2261
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966

BTL		
Original Part Number	**Part Name**	**Classic Part Number**
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
137-2919	Bearing-Sleeve	360-2319
163-3749	Bearing-Sleeve	433-7505
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322

BTL		
Original Part Number	**Part Name**	**Classic Part Number**
236-6268	Bearing-Sleeve	453-6499
240-2913	Bearing-Sleeve	360-2325
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CFB		
Original Part Number	**Part Name**	**Classic Part Number**
2V-0707	Bearing-Sleeve	360-2328
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4I-4811	Pin As	480-8268

CFB		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-1685	Rod	333-4952
7Y-1780	Cylinder	360-2261
087-5802	Link-Rh	301-7964

CFB		
Original Part Number	**Part Name**	**Classic Part Number**
087-5803	Link As	301-7966
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
134-8948	Plate	399-8588

Sales Model 315C (Cont'd.)

CFB		
Original Part Number	**Part Name**	**Classic Part Number**
137-2919	Bearing-Sleeve	360-2319
163-3749	Bearing-Sleeve	433-7505

CFB		
Original Part Number	**Part Name**	**Classic Part Number**
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499

CFB		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CFL		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-4811	Pin As	480-8268
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-1685	Rod	333-4952
7Y-1780	Cylinder	360-2261
087-5802	Link-Rh	301-7964

CFL		
Original Part Number	**Part Name**	**Classic Part Number**
087-5803	Link As	301-7966
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
137-2919	Bearing-Sleeve	360-2319
163-3749	Bearing-Sleeve	433-7505

CFL		
Original Part Number	**Part Name**	**Classic Part Number**
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CFT		
Original Part Number	**Part Name**	**Classic Part Number**
2V-0707	Bearing-Sleeve	360-2328
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4I-4811	Pin As	480-8268
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-1685	Rod	333-4952
7Y-1780	Cylinder	360-2261

CFT		
Original Part Number	**Part Name**	**Classic Part Number**
8G-1682	Pin	241-2585
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319
163-3749	Bearing-Sleeve	433-7505

CFT		
Original Part Number	**Part Name**	**Classic Part Number**
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CJC		
Original Part Number	**Part Name**	**Classic Part Number**
2V-0707	Bearing-Sleeve	360-2328
3W-8239	Sleeve-Wear	360-2342
3Y-2768	Ring	439-4544
4I-0453	Bearing-Sleeve	360-2331
4I-4811	Pin As	480-8268
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
7Y-0223	Shaft-Planet	301-4625

CJC		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1685	Rod	333-4952
7Y-1780	Cylinder	360-2261
8G-1682	Pin	241-2585
9J-9812	Bearing	434-7258
087-5802	Link-Rh	301-7964

CJC		
Original Part Number	**Part Name**	**Classic Part Number**
087-5803	Link As	301-7966
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445

Sales Model 315C (Cont'd.)

CJC		
Original Part Number	**Part Name**	**Classic Part Number**
145-3037	Support	480-8271
150-0351	Spacer	396-7291
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
223-3095	Gauge As	360-2295

CJC		
Original Part Number	**Part Name**	**Classic Part Number**
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
240-2913	Bearing-Sleeve	360-2325

CJC		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 315D

BYK		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
4I-4811	Pin As	480-8268
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261

BYK		
Original Part Number	**Part Name**	**Classic Part Number**
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762

BYK		
Original Part Number	**Part Name**	**Classic Part Number**
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BZN		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
4I-4811	Pin As	480-8268
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261
087-5802	Link-Rh	301-7964

BZN		
Original Part Number	**Part Name**	**Classic Part Number**
087-5803	Link As	301-7966
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
163-3749	Bearing-Sleeve	433-7505

BZN		
Original Part Number	**Part Name**	**Classic Part Number**
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CJN		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
3Y-2768	Ring	439-4544
4I-4811	Pin As	480-8268
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625

CJN		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1780	Cylinder	360-2261
7Y-2396	Bearing-Sleeve	314-8634
9J-9812	Bearing	434-7258
087-5802	Link-Rh	301-7964

CJN		
Original Part Number	**Part Name**	**Classic Part Number**
087-5803	Link As	301-7966
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
145-3037	Support	480-8271
150-0351	Spacer	396-7291
163-3749	Bearing-Sleeve	433-7505

Sales Model 315D (Cont'd.)

CJN		
Original Part Number	**Part Name**	**Classic Part Number**
191-3235	Housing-Sprocket	394-0200
226-8202	Seal-Wiper	472-8024
239-4378	Support	480-8274

CJN		
Original Part Number	**Part Name**	**Classic Part Number**
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969

CJN		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JGS		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
3G-4704	Bearing-Sleeve	379-0185
4I-4811	Pin As	480-8268
4T-8054	Seal As	472-8010
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571

JGS		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1780	Cylinder	360-2261
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
099-0721	Bearing-Sleeve	314-8641
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729

JGS		
Original Part Number	**Part Name**	**Classic Part Number**
125-2950	Gear As	301-4762
163-3749	Bearing-Sleeve	433-7505
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JHA		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
5L-6326	Bearing-Ball	420-3222
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966

JHA		
Original Part Number	**Part Name**	**Classic Part Number**
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
163-3749	Bearing-Sleeve	433-7505

JHA		
Original Part Number	**Part Name**	**Classic Part Number**
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KBD		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
5L-6326	Bearing-Ball	420-3222
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966

KBD		
Original Part Number	**Part Name**	**Classic Part Number**
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
163-3749	Bearing-Sleeve	433-7505

KBD		
Original Part Number	**Part Name**	**Classic Part Number**
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

NCM		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571

NCM		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1685	Rod	333-4952

NCM		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1780	Cylinder	360-2261
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
106-6878	Pin	372-7510

Sales Model 315D (Cont'd.)

NCM		
Original Part Number	Part Name	Classic Part Number
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
145-3037	Support	480-8271
163-3749	Bearing-Sleeve	433-7505

NCM		
Original Part Number	Part Name	Classic Part Number
191-3235	Housing-Sprocket	394-0200
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275

NCM		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TLE		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1685	Rod	333-4952
7Y-1780	Cylinder	360-2261
087-5802	Link-Rh	301-7964

TLE		
Original Part Number	Part Name	Classic Part Number
087-5803	Link As	301-7966
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
145-3037	Support	480-8271
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200

TLE		
Original Part Number	Part Name	Classic Part Number
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 315F

SFM		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696

SFM		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TDY		
Original Part Number	Part Name	Classic Part Number
3G-2797	Bearing-Sleeve	360-2329
086-0414	Flange	392-4522

TDY		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
106-6878	Pin	372-7510

TDY		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WBL		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696

WBL		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 316E

DZW		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
4I-4811	Pin As	480-8268
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261

DZW		
Original Part Number	Part Name	Classic Part Number
8G-1682	Pin	241-2585
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
106-6878	Pin	372-7510
121-7746	Pre-Cleaner As	360-2311
163-3749	Bearing-Sleeve	433-7505

DZW		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WZY		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
4I-4811	Pin As	480-8268
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261

WZY		
Original Part Number	Part Name	Classic Part Number
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
106-6878	Pin	372-7510
121-7746	Pre-Cleaner As	360-2311
240-2912	Bearing-Sleeve	418-1969

WZY		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

YZZ		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
4I-4811	Pin As	480-8268
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261
086-0414	Flange	392-4522

YZZ		
Original Part Number	Part Name	Classic Part Number
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
121-7746	Pre-Cleaner As	360-2311
163-3749	Bearing-Sleeve	433-7505

YZZ		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 316F

ECZ		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
4I-4811	Pin As	480-8268
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966

ECZ		
Original Part Number	Part Name	Classic Part Number
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
121-7746	Pre-Cleaner As	360-2311
163-3749	Bearing-Sleeve	433-7505
240-2912	Bearing-Sleeve	418-1969

XAD		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296

ECZ		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 316F (Cont'd.)

XAD		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261
087-5802	Link-Rh	301-7964

XAD		
Original Part Number	Part Name	Classic Part Number
087-5803	Link As	301-7966
106-6878	Pin	372-7510
121-7746	Pre-Cleaner As	360-2311
240-2912	Bearing-Sleeve	418-1969

XAD		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

YDL		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
4I-4811	Pin As	480-8268
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261

YDL		
Original Part Number	Part Name	Classic Part Number
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
106-6878	Pin	372-7510
121-7746	Pre-Cleaner As	360-2311
240-2912	Bearing-Sleeve	418-1969

YDL		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ZCR		
Original Part Number	Part Name	Classic Part Number
7Y-1780	Cylinder	360-2261

ZCR		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 317

4MM		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-4811	Pin As	480-8268
6I-9103	Bearing-Outer	421-8182
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1780	Cylinder	360-2261
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-6607	Bearing	372-7508
7Y-6626	Bearing	314-8650

4MM		
Original Part Number	Part Name	Classic Part Number
8C-3111	Rod End-Spher	392-4523
9S-7534	Pipe-Exh Ext	398-2950
9Y-1403	Muffler As	393-0930
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5978	Flange	374-3496
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
102-8139	Spring	392-4526
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
115-6427	Spring	301-4776

4MM		
Original Part Number	Part Name	Classic Part Number
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2819	Bearing-Sleeve	360-2317
145-3037	Support	480-8271
193-5016	Flange	425-3644
223-3095	Gauge As	360-2295
236-6269	Bearing-Sleeve	453-6500
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 317 (Cont'd.)

9SR		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-4811	Pin As	480-8268
6I-9103	Bearing-Outer	421-8182
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1780	Cylinder	360-2261
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634

9SR		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-3428	Bearing-Sleeve	314-8647
8C-3111	Rod End-Spher	392-4523
9S-7534	Pipe-Exh Ext	398-2950
9Y-1403	Muffler As	393-0930
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
102-8139	Spring	392-4526
106-6878	Pin	372-7510

9SR		
Original Part Number	**Part Name**	**Classic Part Number**
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
137-2819	Bearing-Sleeve	360-2317
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 317B

6DZ		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-4811	Pin As	480-8268
6Y-9930	Mount As	360-2353
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-5128	Bearing-Sleeve	314-8648

6DZ		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-6607	Bearing	372-7508
7Y-6626	Bearing	314-8650
9W-9931	Mount As.	360-2354
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729

6DZ		
Original Part Number	**Part Name**	**Classic Part Number**
117-6270	Support As	434-1400
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
133-2437	Link	377-6199
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
191-3235	Housing-Sprocket	394-0200
223-3095	Gauge As	360-2295
236-6269	Bearing-Sleeve	453-6500
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

9WW		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-4811	Pin As	480-8268
6Y-9930	Mount As	360-2353
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727

9WW		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-2395	Bearing-Sleeve	314-8646

9WW		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-2396	Bearing-Sleeve	314-8634
7Y-5128	Bearing-Sleeve	314-8648
7Y-6607	Bearing	372-7508
7Y-6626	Bearing	314-8650
9W-9931	Mount As.	360-2354

Sales Model 317B (Cont'd.)

9WW		
Original Part Number	**Part Name**	**Classic Part Number**
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
115-6427	Spring	301-4776
115-6428	Piston As	394-0188

9WW		
Original Part Number	**Part Name**	**Classic Part Number**
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
133-2437	Link	377-6199
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271

9WW		
Original Part Number	**Part Name**	**Classic Part Number**
191-3235	Housing-Sprocket	394-0200
223-3095	Gauge As	360-2295
236-6269	Bearing-Sleeve	453-6500
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 318B

3LR		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648

3LR		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
115-6428	Piston As	394-0188
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
119-2863	Pin	314-8698
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
126-9461	Pin	392-4528
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642

3LR		
Original Part Number	**Part Name**	**Classic Part Number**
128-9884	Bearing-Sleeve	360-2315
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-8479	Spacer	395-1323
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
223-3095	Gauge As	360-2295
236-6270	Bearing-Sleeve	425-6436
244-8504	Pin As	426-0032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

5BJ		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727

5BJ		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659

5BJ		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1606	Spring	375-5447
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634

Sales Model 318B (Cont'd.)

5BJ		
Original Part Number	Part Name	Classic Part Number
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
106-6878	Pin	372-7510
115-6428	Piston As	394-0188

5BJ		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315

5BJ		
Original Part Number	Part Name	Classic Part Number
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-8479	Spacer	395-1323
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

7KZ		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648

7KZ		
Original Part Number	Part Name	Classic Part Number
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
115-6428	Piston As	394-0188
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
119-2863	Pin	314-8698
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
126-9461	Pin	392-4528
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642

7KZ		
Original Part Number	Part Name	Classic Part Number
128-9884	Bearing-Sleeve	360-2315
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-8479	Spacer	395-1323
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
223-3095	Gauge As	360-2295
236-6270	Bearing-Sleeve	425-6436
244-8504	Pin As	426-0032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ADC		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
6Y-9930	Mount As	360-2353
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671

ADC		
Original Part Number	Part Name	Classic Part Number
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-2357	Pin	301-4564
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647

ADC		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6607	Bearing	372-7508
7Y-6626	Bearing	314-8650
9W-9931	Mount As.	360-2354
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628

Sales Model 318B (Cont'd.)

ADC		
Original Part Number	Part Name	Classic Part Number
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
107-9739	Pin As	393-3689
115-6427	Spring	301-4776
115-6428	Piston As	394-0188

ADC		
Original Part Number	Part Name	Classic Part Number
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
119-2863	Pin	314-8698
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
126-9461	Pin	392-4528
133-2437	Link	377-6199
134-8948	Plate	399-8588
137-2819	Bearing-Sleeve	360-2317

ADC		
Original Part Number	Part Name	Classic Part Number
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
191-3235	Housing-Sprocket	394-0200
223-3095	Gauge As	360-2295
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
244-8504	Pin As	426-0032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

AEJ		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
6Y-9930	Mount As	360-2353
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-2357	Pin	301-4564
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626

AEJ		
Original Part Number	Part Name	Classic Part Number
7Y-6607	Bearing	372-7508
7Y-6626	Bearing	314-8650
9W-9931	Mount As.	360-2354
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
107-9739	Pin As	393-3689
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729

AEJ		
Original Part Number	Part Name	Classic Part Number
117-6270	Support As	434-1400
119-2863	Pin	314-8698
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
126-9461	Pin	392-4528
133-2437	Link	377-6199
134-8948	Plate	399-8588
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
191-3235	Housing-Sprocket	394-0200
223-3095	Gauge As	360-2295
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
244-8504	Pin As	426-0032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 318C

BTG		
Original Part Number	Part Name	Classic Part Number
4I-0704	Bearing-Sleeve	360-2332

Sales Model 318C (Cont'd.)

BTG		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-5131	Bearing-Sleeve	301-4626
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815

BTG		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
133-2437	Link	377-6199
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

BTG		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CWP		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964

CWP		
Original Part Number	Part Name	Classic Part Number
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
128-9863	Bearing-Sleeve	314-8630
128-9884	Bearing-Sleeve	360-2315
133-2437	Link	377-6199
134-8948	Plate	399-8588
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260

CWP		
Original Part Number	Part Name	Classic Part Number
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969

Sales Model 318C (Cont'd.)

CWP		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326

CWP		
Original Part Number	**Part Name**	**Classic Part Number**
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
314-8717	Shaft-Cla	360-2273

CWP		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DAH		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0704	Bearing-Sleeve	360-2332
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-5131	Bearing-Sleeve	301-4626
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047

DAH		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
133-2437	Link	377-6199
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

DAH		
Original Part Number	**Part Name**	**Classic Part Number**
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

FAA		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0704	Bearing-Sleeve	360-2332
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-5131	Bearing-Sleeve	301-4626
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964

FAA		
Original Part Number	**Part Name**	**Classic Part Number**
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762

FAA		
Original Part Number	**Part Name**	**Classic Part Number**
126-9461	Pin	392-4528
133-2437	Link	377-6199
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

Sales Model 318C (Cont'd.)

FAA		
Original Part Number	**Part Name**	**Classic Part Number**
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499

FAA		
Original Part Number	**Part Name**	**Classic Part Number**
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969

FAA		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GPA		
Original Part Number	**Part Name**	**Classic Part Number**
3G-5285	Bearing-Sleeve	360-2312
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969

GPA		
Original Part Number	**Part Name**	**Classic Part Number**
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
133-2437	Link	377-6199
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505

GPA		
Original Part Number	**Part Name**	**Classic Part Number**
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MDY		
Original Part Number	**Part Name**	**Classic Part Number**
3G-5285	Bearing-Sleeve	360-2312
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659

MDY		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1644	Gear-Planet	301-3406
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
9V-0247	Plate	417-4527
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968

MDY		
Original Part Number	**Part Name**	**Classic Part Number**
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528

Sales Model 318C (Cont'd.)

MDY		
Original Part Number	**Part Name**	**Classic Part Number**
133-2437	Link	377-6199
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505

MDY		
Original Part Number	**Part Name**	**Classic Part Number**
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500

MDY		
Original Part Number	**Part Name**	**Classic Part Number**
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 318D

DPJ		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
106-6878	Pin	372-7510

DPJ		
Original Part Number	**Part Name**	**Classic Part Number**
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
163-3749	Bearing-Sleeve	433-7505
240-2912	Bearing-Sleeve	418-1969

DPJ		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

HAH		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261
087-5802	Link-Rh	301-7964

HAH		
Original Part Number	**Part Name**	**Classic Part Number**
087-5803	Link As	301-7966
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
163-3749	Bearing-Sleeve	433-7505

HAH		
Original Part Number	**Part Name**	**Classic Part Number**
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

HBP		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261
087-5802	Link-Rh	301-7964

HBP		
Original Part Number	**Part Name**	**Classic Part Number**
087-5803	Link As	301-7966
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
163-3749	Bearing-Sleeve	433-7505

HBP		
Original Part Number	**Part Name**	**Classic Part Number**
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 318D (Cont'd.)

JEB		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
4I-4811	Pin As	480-8268
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966

JEB		
Original Part Number	Part Name	Classic Part Number
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
121-7746	Pre-Cleaner As	360-2311
163-3749	Bearing-Sleeve	433-7505

JEB		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TZS		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
4I-4811	Pin As	480-8268
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966

TZS		
Original Part Number	Part Name	Classic Part Number
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
121-7746	Pre-Cleaner As	360-2311
163-3749	Bearing-Sleeve	433-7505

TZS		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WGR		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
4I-4811	Pin As	480-8268
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261
087-5802	Link-Rh	301-7964

WGR		
Original Part Number	Part Name	Classic Part Number
087-5803	Link As	301-7966
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
121-7746	Pre-Cleaner As	360-2311
125-2950	Gear As	301-4762
163-3749	Bearing-Sleeve	433-7505

WGR		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

XAH		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
106-6878	Pin	372-7510

XAH		
Original Part Number	Part Name	Classic Part Number
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
163-3749	Bearing-Sleeve	433-7505
240-2912	Bearing-Sleeve	418-1969

XAH		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

XGS		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
4I-4811	Pin As	480-8268

XGS		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261

XGS		
Original Part Number	Part Name	Classic Part Number
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966

Sales Model 318D (Cont'd.)

XGS		
Original Part Number	Part Name	Classic Part Number
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729

XGS		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
163-3749	Bearing-Sleeve	433-7505
240-2912	Bearing-Sleeve	418-1969

XGS		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ZKJ		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
5L-6326	Bearing-Ball	420-3222
7Y-0225	Shaft-Planet	301-4571
7Y-1780	Cylinder	360-2261
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966

ZKJ		
Original Part Number	Part Name	Classic Part Number
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
163-3749	Bearing-Sleeve	433-7505

ZKJ		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 318E

DZF		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
4I-4811	Pin As	480-8268
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
094-1509	Shaft-Planet	360-2273

DZF		
Original Part Number	Part Name	Classic Part Number
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
114-1398	Gauge-Oil Level	394-9815
121-7746	Pre-Cleaner As	360-2311
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

DZF		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WZS		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659

WZS		
Original Part Number	Part Name	Classic Part Number
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
094-1509	Shaft-Planet	360-2273
106-6878	Pin	372-7510
114-1398	Gauge-Oil Level	394-9815
121-7746	Pre-Cleaner As	360-2311
145-3037	Support	480-8271

WZS		
Original Part Number	Part Name	Classic Part Number
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274

Sales Model 318E (Cont'd.)

WZS		
Original Part Number	Part Name	Classic Part Number
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969

WZS		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348

WZS		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292

Sales Model 318F

FFT		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966

FFT		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
106-6878	Pin	372-7510
114-1398	Gauge-Oil Level	394-9815
121-7746	Pre-Cleaner As	360-2311
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

FFT		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GNX		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274

GNX		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274

GNX		
Original Part Number	Part Name	Classic Part Number
239-4390	Recoil Gp-Adj&-A	480-8275
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

HCP		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
4I-4811	Pin As	480-8268
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
094-1509	Shaft-Planet	360-2273
106-6878	Pin	372-7510
107-9739	Pin As	393-3689
114-1398	Gauge-Oil Level	394-9815

HCP		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274

HCP		
Original Part Number	Part Name	Classic Part Number
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Excavators

Sales Model 319C

KGL		
Original Part Number	Part Name	Classic Part Number
4I-0704	Bearing-Sleeve	360-2332
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-5131	Bearing-Sleeve	301-4626
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047

KGL		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
133-2437	Link	377-6199
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

KGL		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 319D

AYF		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967

AYF		
Original Part Number	Part Name	Classic Part Number
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200

AYF		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BZH		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222

Sales Model 319D (Cont'd.)

BZH		
Original Part Number	Part Name	Classic Part Number
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273

BZH		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

BZH		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DAY		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969

DAY		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

DAY		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

EAW		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968

EAW		
Original Part Number	Part Name	Classic Part Number
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
107-9739	Pin As	393-3689
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200

EAW		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 319D (Cont'd.)

FMH		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968

FMH		
Original Part Number	Part Name	Classic Part Number
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
107-9739	Pin As	393-3689
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200

FMH		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KFM		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968

KFM		
Original Part Number	Part Name	Classic Part Number
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200

KFM		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KRM		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969

KRM		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

KRM		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 319D (Cont'd.)

RJP		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967

RJP		
Original Part Number	Part Name	Classic Part Number
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200

RJP		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WBJ		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968

WBJ		
Original Part Number	Part Name	Classic Part Number
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200

WBJ		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ZCA		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968

ZCA		
Original Part Number	Part Name	Classic Part Number
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200

ZCA		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 319D (Cont'd.)

ZGZ		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968

ZGZ		
Original Part Number	Part Name	Classic Part Number
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200

ZGZ		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320

1KL		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-3954	Tube As	301-4779
4I-3957	Tube As	301-4801
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-7619	Pulley	301-4772
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-7959	Pulley As	301-5256
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7I-7180	Piston	421-7142
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1563	Gear Gp-Brg & Bsc	385-3776

1KL		
Original Part Number	Part Name	Classic Part Number
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3553	Bearing-Sleeve	301-0433
7Y-4666	Bearing-Sleeve	314-8636
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626

1KL		
Original Part Number	Part Name	Classic Part Number
7Y-6389	Bearing	372-7507
7Y-6607	Bearing	372-7508
7Y-6608	Bearing	314-8649
7Y-6626	Bearing	314-8650
8C-3111	Rod End-Spher	392-4523
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
094-1509	Shaft-Planet	360-2273
094-1850	Bearing-Trunnion	419-4747
096-4002	Bearing	420-3221
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909

Sales Model 320 (Cont'd.)

1KL		
Original Part Number	Part Name	Classic Part Number
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
125-2950	Gear As	301-4762
127-5970	Gear-Planet	301-3398
128-9882	Bearing-Sleeve	314-8642
134-8948	Plate	399-8588
134-8949	Plate	383-2110

1KL		
Original Part Number	Part Name	Classic Part Number
135-2376	Gasket Kit-Lower	393-3634
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644

1KL		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

1TL		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-3954	Tube As	301-4779
4I-3957	Tube As	301-4801
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5I-8628	Plate-Valve	301-4771
6E-4985	Cover-Filter	424-2015
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

1TL		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1563	Gear Gp-Brg & Bsc	385-3776
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952

1TL		
Original Part Number	Part Name	Classic Part Number
7Y-1687	Piston As	360-2266
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2040	Muffler As	301-7975
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3553	Bearing-Sleeve	301-0433
7Y-4666	Bearing-Sleeve	314-8636
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6389	Bearing	372-7507
7Y-6607	Bearing	372-7508
7Y-6608	Bearing	314-8649

Sales Model 320 (Cont'd.)

1TL		
Original Part Number	Part Name	Classic Part Number
7Y-6626	Bearing	314-8650
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
094-1509	Shaft-Planet	360-2273
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381

1TL		
Original Part Number	Part Name	Classic Part Number
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
119-2940	Gasket	378-4002
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
126-5875	Flywheel As.	374-4694
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
134-8948	Plate	399-8588
134-8949	Plate	383-2110
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-3037	Support	480-8271
152-3952	Impeller-Pump	374-4696

1TL		
Original Part Number	Part Name	Classic Part Number
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
281-2813	Kit-Gasket-Sch	387-2921
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

1XM		
Original Part Number	Part Name	Classic Part Number
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-7619	Pulley	301-4772
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-7959	Pulley As	301-5256

1XM		
Original Part Number	Part Name	Classic Part Number
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
6K-8088	Bearing-Roller	399-4428
7E-7302	Bracket	416-5497
7K-9639	Bearing-Sleeve	314-8643
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729

1XM		
Original Part Number	Part Name	Classic Part Number
7Y-1432	Carrier-Planet	314-8659
7Y-1563	Gear Gp-Brg & Bsc	385-3776
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2348	Pin	314-8697

Sales Model 320 (Cont'd.)

1XM		
Original Part Number	Part Name	Classic Part Number
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
9D-7924	Mount As	360-2356
9W-9940	Mount As.	360-2355
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967

1XM		
Original Part Number	Part Name	Classic Part Number
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
094-1509	Shaft-Planet	360-2273
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
125-2950	Gear As	301-4762
127-5970	Gear-Planet	301-3398
134-8948	Plate	399-8588
134-8949	Plate	383-2110
135-2376	Gasket Kit-Lower	393-3634
137-2819	Bearing-Sleeve	360-2317

1XM		
Original Part Number	Part Name	Classic Part Number
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
163-3749	Bearing-Sleeve	433-7505
176-3900	Accumulator	416-5513
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

2DL		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4T-8054	Seal As	472-8010
5I-7619	Pulley	301-4772
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-7959	Pulley As	301-5256
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
6E-4985	Cover-Filter	424-2015
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728

2DL		
Original Part Number	Part Name	Classic Part Number
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635

2DL		
Original Part Number	Part Name	Classic Part Number
7Y-3428	Bearing-Sleeve	314-8647
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
094-1509	Shaft-Planet	360-2273
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655

Sales Model 320 (Cont'd.)

2DL		
Original Part Number	**Part Name**	**Classic Part Number**
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
125-2950	Gear As	301-4762
127-5970	Gear-Planet	301-3398
134-8948	Plate	399-8588
134-8949	Plate	383-2110
135-2376	Gasket Kit-Lower	393-3634
137-2819	Bearing-Sleeve	360-2317

2DL		
Original Part Number	**Part Name**	**Classic Part Number**
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589

2DL		
Original Part Number	**Part Name**	**Classic Part Number**
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
236-6270	Bearing-Sleeve	425-6436
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

3RK		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2D-5658	Bearing-Ball	301-4628
2K-6413	Pin	360-2270
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5I-8628	Plate-Valve	301-4771
6E-4985	Cover-Filter	424-2015
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025

3RK		
Original Part Number	**Part Name**	**Classic Part Number**
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2040	Muffler As	301-7975
7Y-2348	Pin	314-8697

3RK		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
094-1509	Shaft-Planet	360-2273
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654

Sales Model 320 (Cont'd.)

3RK		
Original Part Number	Part Name	Classic Part Number
096-7913	Bearing-Sleeve	314-8655
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
119-2940	Gasket	378-4002
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
126-5875	Flywheel As.	374-4694
127-5970	Gear-Planet	301-3398
134-8948	Plate	399-8588
134-8949	Plate	383-2110
136-0819	Valve-Exhaust	384-8697

3RK		
Original Part Number	Part Name	Classic Part Number
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-3037	Support	480-8271
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372

3RK		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

3XK		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-3954	Tube As	301-4779
4I-3957	Tube As	301-4801
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603

3XK		
Original Part Number	Part Name	Classic Part Number
4W-2042	Spacer	325-6217
5C-5837	Retainer-Pin	299-2047
5I-8628	Plate-Valve	301-4771
6A-7129	Bearing-Sleeve	301-3130
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7K-5448	Cup-Bearing	415-1922
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551

3XK		
Original Part Number	Part Name	Classic Part Number
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1563	Gear Gp-Brg & Bsc	385-3776
7Y-1606	Spring	375-5447
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500

Sales Model 320 (Cont'd.)

3XK		
Original Part Number	Part Name	Classic Part Number
7Y-1774	Carrier-Planet	376-7654
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2040	Muffler As	301-7975
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-4666	Bearing-Sleeve	314-8636
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6389	Bearing	372-7507
7Y-6607	Bearing	372-7508
7Y-6608	Bearing	314-8649
7Y-6626	Bearing	314-8650
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8R-7336	Bearing	301-3394
8S-0248	Breather As	325-6033
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9V-0247	Plate	417-4527
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968

3XK		
Original Part Number	Part Name	Classic Part Number
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-2941	Gasket Kit	393-1020
100-2951	Gasket-Kit Sch	447-8649
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336

3XK		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-3037	Support	480-8271
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 320 (Cont'd.)

3XM		
Original Part Number	Part Name	Classic Part Number
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
6E-4985	Cover-Filter	424-2015
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765

3XM		
Original Part Number	Part Name	Classic Part Number
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
094-1509	Shaft-Planet	360-2273
094-1850	Bearing-Trunnion	419-4747
096-4002	Bearing	420-3221
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569

3XM		
Original Part Number	Part Name	Classic Part Number
122-5077	Cylinder	301-4673
125-2950	Gear As	301-4762
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
134-8948	Plate	399-8588
135-2376	Gasket Kit-Lower	393-3634
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
272-4673	Muffler	301-7974
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

4BK		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2D-5658	Bearing-Ball	301-4628
2K-6413	Pin	360-2270
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511

4BK		
Original Part Number	Part Name	Classic Part Number
4I-3954	Tube As	301-4779
4I-3957	Tube As	301-4801
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

4BK		
Original Part Number	Part Name	Classic Part Number
5I-8628	Plate-Valve	301-4771
6E-4985	Cover-Filter	424-2015
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

Sales Model 320 (Cont'd.)

4BK		
Original Part Number	Part Name	Classic Part Number
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1563	Gear Gp-Brg & Bsc	385-3776
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2040	Muffler As	301-7975
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635

4BK		
Original Part Number	Part Name	Classic Part Number
7Y-3428	Bearing-Sleeve	314-8647
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
094-1509	Shaft-Planet	360-2273
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
119-2940	Gasket	378-4002
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
126-5875	Flywheel As.	374-4694
127-5970	Gear-Planet	301-3398
134-8948	Plate	399-8588
134-8949	Plate	383-2110

4JM		
Original Part Number	Part Name	Classic Part Number
3J-2903	Cover	422-6922

4BK		
Original Part Number	Part Name	Classic Part Number
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-3037	Support	480-8271
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 320 (Cont'd.)

4JM		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-3954	Tube As	301-4779
4I-3957	Tube As	301-4801
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
6E-4985	Cover-Filter	424-2015
7I-7180	Piston	421-7142
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1563	Gear Gp-Brg & Bsc	385-3776
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634

4JM		
Original Part Number	Part Name	Classic Part Number
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3553	Bearing-Sleeve	301-0433
7Y-4666	Bearing-Sleeve	314-8636
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6389	Bearing	372-7507
7Y-6607	Bearing	372-7508
7Y-6608	Bearing	314-8649
7Y-6626	Bearing	314-8650
8C-3111	Rod End-Spher	392-4523
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
094-1509	Shaft-Planet	360-2273
094-1850	Bearing-Trunnion	419-4747
096-4002	Bearing	420-3221
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641

4JM		
Original Part Number	Part Name	Classic Part Number
099-0722	Link As	415-1909
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
125-2950	Gear As	301-4762
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
134-8948	Plate	399-8588
135-2376	Gasket Kit-Lower	393-3634
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
272-4673	Muffler	301-7974
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

4ZJ		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2D-5658	Bearing-Ball	301-4628

4ZJ		
Original Part Number	Part Name	Classic Part Number
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667

4ZJ		
Original Part Number	Part Name	Classic Part Number
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331

Sales Model 320 (Cont'd.)

4ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5C-5837	Retainer-Pin	299-2047
5I-8628	Plate-Valve	301-4771
6A-7129	Bearing-Sleeve	301-3130
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7K-5448	Cup-Bearing	415-1922
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1563	Gear Gp-Brg & Bsc	385-3776

4ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1606	Spring	375-5447
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2040	Muffler As	301-7975
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-4666	Bearing-Sleeve	314-8636
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8R-7336	Bearing	301-3394
8S-0248	Breather As	325-6033
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9V-0247	Plate	417-4527
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629

4ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-2941	Gasket Kit	393-1020
100-2951	Gasket-Kit Sch	447-8649
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-3037	Support	480-8271
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200

Sales Model 320 (Cont'd.)

4ZJ		
Original Part Number	Part Name	Classic Part Number
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6268	Bearing-Sleeve	453-6499

4ZJ		
Original Part Number	Part Name	Classic Part Number
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912

4ZJ		
Original Part Number	Part Name	Classic Part Number
277-7089	Shaft As	380-7578
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

7GJ		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
6E-4985	Cover-Filter	424-2015
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261

7GJ		
Original Part Number	Part Name	Classic Part Number
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
094-1509	Shaft-Planet	360-2273
094-1850	Bearing-Trunnion	419-4747
096-4002	Bearing	420-3221
096-7911	Bearing-Sleeve	314-8653

7GJ		
Original Part Number	Part Name	Classic Part Number
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655
114-0468	Pin-G.E.T.	443-1203
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
125-2950	Gear As	301-4762
127-5970	Gear-Planet	301-3398
134-8948	Plate	399-8588
134-8949	Plate	383-2110
135-2376	Gasket Kit-Lower	393-3634
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589

Sales Model 320 (Cont'd.)

7GJ		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322

7GJ		
Original Part Number	Part Name	Classic Part Number
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
272-4673	Muffler	301-7974

7GJ		
Original Part Number	Part Name	Classic Part Number
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

7WK		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5I-8628	Plate-Valve	301-4771
6E-4985	Cover-Filter	424-2015
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705

7WK		
Original Part Number	Part Name	Classic Part Number
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2040	Muffler As	301-7975
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512

7WK		
Original Part Number	Part Name	Classic Part Number
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
094-1509	Shaft-Planet	360-2273
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
119-2940	Gasket	378-4002
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
126-5875	Flywheel As.	374-4694
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9883	Bearing-Sleeve	360-2314
134-8948	Plate	399-8588
134-8949	Plate	383-2110
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317

Sales Model 320 (Cont'd.)

7WK		
Original Part Number	Part Name	Classic Part Number
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-3037	Support	480-8271
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505

7WK		
Original Part Number	Part Name	Classic Part Number
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

7WK		
Original Part Number	Part Name	Classic Part Number
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

8HJ		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-3954	Tube As	301-4779
4I-3957	Tube As	301-4801
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
6E-4985	Cover-Filter	424-2015
7I-7180	Piston	421-7142
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1563	Gear Gp-Brg & Bsc	385-3776
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952

8HJ		
Original Part Number	Part Name	Classic Part Number
7Y-1687	Piston As	360-2266
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3553	Bearing-Sleeve	301-0433
7Y-4666	Bearing-Sleeve	314-8636
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6389	Bearing	372-7507
7Y-6607	Bearing	372-7508
7Y-6608	Bearing	314-8649
7Y-6626	Bearing	314-8650
8C-3111	Rod End-Spher	392-4523

8HJ		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
094-1509	Shaft-Planet	360-2273
094-1850	Bearing-Trunnion	419-4747
096-4002	Bearing	420-3221
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
114-0468	Pin-G.E.T.	443-1203
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
125-2950	Gear As	301-4762
127-5970	Gear-Planet	301-3398

Sales Model 320 (Cont'd.)

8HJ		
Original Part Number	Part Name	Classic Part Number
128-9882	Bearing-Sleeve	314-8642
134-8948	Plate	399-8588
134-8949	Plate	383-2110
135-2376	Gasket Kit-Lower	393-3634
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318

8HJ		
Original Part Number	Part Name	Classic Part Number
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589

8HJ		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
272-4673	Muffler	301-7974
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

8LK		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-7619	Pulley	301-4772
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-7959	Pulley As	301-5256
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2348	Pin	314-8697

8LK		
Original Part Number	Part Name	Classic Part Number
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
094-1509	Shaft-Planet	360-2273
094-1850	Bearing-Trunnion	419-4747
096-4002	Bearing	420-3221
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655

8LK		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
125-2950	Gear As	301-4762
127-5970	Gear-Planet	301-3398
134-8948	Plate	399-8588
134-8949	Plate	383-2110
135-2376	Gasket Kit-Lower	393-3634
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320 (Cont'd.)

9KK		
Original Part Number	Part Name	Classic Part Number
1T-0210	Bearing-Ball	417-4498
2D-5658	Bearing-Ball	301-4628
2K-6413	Pin	360-2270
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-3954	Tube As	301-4779
4I-3957	Tube As	301-4801
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4T-8054	Seal As	472-8010
5I-7619	Pulley	301-4772
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-7959	Pulley As	301-5256
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
6E-4985	Cover-Filter	424-2015
7I-7180	Piston	421-7142
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1563	Gear Gp-Brg & Bsc	385-3776
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624

9KK		
Original Part Number	Part Name	Classic Part Number
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3553	Bearing-Sleeve	301-0433
7Y-4666	Bearing-Sleeve	314-8636
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6389	Bearing	372-7507
7Y-6607	Bearing	372-7508
7Y-6608	Bearing	314-8649
7Y-6626	Bearing	314-8650
8C-3111	Rod End-Spher	392-4523
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
094-1509	Shaft-Planet	360-2273
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655
099-0718	Bearing-Sleeve	360-2313

9KK		
Original Part Number	Part Name	Classic Part Number
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
102-8112	Cylinder	360-2276
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
125-2950	Gear As	301-4762
127-5970	Gear-Planet	301-3398
128-9882	Bearing-Sleeve	314-8642
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
135-2376	Gasket Kit-Lower	393-3634
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
236-6270	Bearing-Sleeve	425-6436
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320 (Cont'd.)

9WG		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-3954	Tube As	301-4779
4I-3957	Tube As	301-4801
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5C-5837	Retainer-Pin	299-2047
5I-8628	Plate-Valve	301-4771
6A-7129	Bearing-Sleeve	301-3130
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7K-5448	Cup-Bearing	415-1922
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545

9WG		
Original Part Number	Part Name	Classic Part Number
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1563	Gear Gp-Brg & Bsc	385-3776
7Y-1606	Spring	375-5447
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2040	Muffler As	301-7975
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-4666	Bearing-Sleeve	314-8636

9WG		
Original Part Number	Part Name	Classic Part Number
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8R-7336	Bearing	301-3394
8S-0248	Breather As	325-6033
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9V-0247	Plate	417-4527
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-2941	Gasket Kit	393-1020
100-2951	Gasket-Kit Sch	447-8649
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729

Sales Model 320 (Cont'd.)

9WG		
Original Part Number	Part Name	Classic Part Number
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376

9WG		
Original Part Number	Part Name	Classic Part Number
145-0165	Bearing-Main	419-6388
145-3037	Support	480-8271
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6268	Bearing-Sleeve	453-6499

9WG		
Original Part Number	Part Name	Classic Part Number
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 320B

1CS		
Original Part Number	Part Name	Classic Part Number
3G-5285	Bearing-Sleeve	360-2312
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624

1CS		
Original Part Number	Part Name	Classic Part Number
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
094-1850	Bearing-Trunnion	419-4747
096-4002	Bearing	420-3221
106-6878	Pin	372-7510

1CS		
Original Part Number	Part Name	Classic Part Number
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630

Sales Model 320B (Cont'd.)

1CS		
Original Part Number	Part Name	Classic Part Number
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
128-9884	Bearing-Sleeve	360-2315
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317

1CS		
Original Part Number	Part Name	Classic Part Number
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-3037	Support	480-8271
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589

1CS		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
272-4673	Muffler	301-7974
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

1XS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
1W-2489	Muffler As	360-7870
1W-4369	Pulley-Alt	296-1340
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2L-5271	Bearing-Ball	371-4305
2N-1599	Gear	378-3970
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489

1XS		
Original Part Number	Part Name	Classic Part Number
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-7693	Crankshaft As	269-8763
4P-2383	Adapter-Inlet	438-1812
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-7827	Gear-Crankshaft	380-7533
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5I-8628	Plate-Valve	301-4771
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024

1XS		
Original Part Number	Part Name	Classic Part Number
6I-1099	Manifold-Exh	424-6366
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-6794	Arm As-Injector	433-0449
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7N-2156	Bearing-Sleeve	380-7373
7N-7998	Plate-Block	374-7496
7N-9805	Pin-Piston	295-6438
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190

Sales Model 320B (Cont'd.)

1XS		
Original Part Number	Part Name	Classic Part Number
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3553	Bearing-Sleeve	301-0433
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8J-2880	Cap-Bearing	295-6420
8N-1184	Elbow-Exhaust	392-4497
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-4110	Bearing-Sleeve	394-8207
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

1XS		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-6511	Bearing-Sleeve	380-7372
9J-2759	Trunnion	394-0216
9L-5839	Coupling-Exhaust	374-7480
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9W-9931	Mount As.	360-2354
9Y-2988	Breather As	361-1716
9Y-5295	Tube-Gov Conn	419-4756
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
086-0414	Flange	392-4522
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-3125	Gasket	420-8567
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381

1XS		
Original Part Number	Part Name	Classic Part Number
108-7930	Bearing As	377-7463
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
113-6200	Gasket	438-2020
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
118-9906	Muffler As	360-7865
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
122-5076	Rod	301-4569
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
127-5970	Gear-Planet	301-3398
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
135-4928	Shaft-Water Pump	386-3813
136-0819	Valve-Exhaust	384-8697

Sales Model 320B (Cont'd.)

1XS		
Original Part Number	Part Name	Classic Part Number
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
138-9381	Plate-Spacer	424-7052
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-3037	Support	480-8271
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
152-3952	Impeller-Pump	374-4696
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
186-5652	Pin	392-4532

1XS		
Original Part Number	Part Name	Classic Part Number
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3233	Bearing-Main	376-9085
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969

1XS		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
253-1752	Plate-Thrust	379-0170
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
278-1365	Arm As-Ui Rkr	433-7507
314-8717	Shaft-Cla	360-2273
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
430-7619	Adapter-Cla	438-1812
441-9566	Gear-Flywheel	374-4703

2AS		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
1W-4369	Pulley-Alt	296-1340
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268

2AS		
Original Part Number	Part Name	Classic Part Number
4I-4812	Pin As	480-8269
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5I-8628	Plate-Valve	301-4771
5P-7807	Bearing-Ball	314-8502
6I-1099	Manifold-Exh	424-6366
6Y-9930	Mount As	360-2353
7C-3729	Pulley	376-9066

2AS		
Original Part Number	Part Name	Classic Part Number
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7K-5448	Cup-Bearing	415-1922
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551

Sales Model 320B (Cont'd.)

2AS		
Original Part Number	Part Name	Classic Part Number
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-3553	Bearing-Sleeve	301-0433
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
087-5533	Bearing-Sleeve	314-8628

2AS		
Original Part Number	Part Name	Classic Part Number
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
109-9323	Muffler As	369-9491
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
113-6200	Gasket	438-2020
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
118-9906	Muffler As	360-7865
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
122-5076	Rod	301-4569
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199

2AS		
Original Part Number	Part Name	Classic Part Number
134-8948	Plate	399-8588
134-8949	Plate	383-2110
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-3037	Support	480-8271
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912

Sales Model 320B (Cont'd.)

2AS		
Original Part Number	**Part Name**	**Classic Part Number**
277-7089	Shaft As	380-7578
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348

2AS		
Original Part Number	**Part Name**	**Classic Part Number**
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

2AS		
Original Part Number	**Part Name**	**Classic Part Number**
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

2WZ		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966

2WZ		
Original Part Number	**Part Name**	**Classic Part Number**
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
094-1850	Bearing-Trunnion	419-4747
096-4002	Bearing	420-3221
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630

2WZ		
Original Part Number	**Part Name**	**Classic Part Number**
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
133-2437	Link	377-6199
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
145-3037	Support	480-8271
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
272-4673	Muffler	301-7974
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

3MR		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-7959	Pulley As	301-5256
5I-8628	Plate-Valve	301-4771

3MR		
Original Part Number	**Part Name**	**Classic Part Number**
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624

3MR		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964

Sales Model 320B (Cont'd.)

3MR		
Original Part Number	Part Name	Classic Part Number
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
094-1850	Bearing-Trunnion	419-4747
096-4002	Bearing	420-3221
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
122-5076	Rod	301-4569

3MR		
Original Part Number	Part Name	Classic Part Number
122-5077	Cylinder	301-4673
125-2950	Gear As	301-4762
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
128-9884	Bearing-Sleeve	360-2315
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-3037	Support	480-8271

3MR		
Original Part Number	Part Name	Classic Part Number
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
272-4673	Muffler	301-7974
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

3YZ		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
1W-4369	Pulley-Alt	296-1340
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

3YZ		
Original Part Number	Part Name	Classic Part Number
5I-8628	Plate-Valve	301-4771
5P-7807	Bearing-Ball	314-8502
6I-1099	Manifold-Exh	424-6366
6Y-9930	Mount As	360-2353
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7K-5448	Cup-Bearing	415-1922
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705

3YZ		
Original Part Number	Part Name	Classic Part Number
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634

Sales Model 320B (Cont'd.)

3YZ		
Original Part Number	Part Name	Classic Part Number
7Y-3428	Bearing-Sleeve	314-8647
7Y-3553	Bearing-Sleeve	301-0433
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8S-0248	Breather As	325-6033
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
113-6200	Gasket	438-2020
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
115-6427	Spring	301-4776

3YZ		
Original Part Number	Part Name	Classic Part Number
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
118-9906	Muffler As	360-7865
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
122-5076	Rod	301-4569
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-3037	Support	480-8271
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560

3YZ		
Original Part Number	Part Name	Classic Part Number
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
300-9500	Kit-Gasket-Sch	387-2914
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

4FS		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331

4FS		
Original Part Number	Part Name	Classic Part Number
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268

Sales Model 320B (Cont'd.)

4FS		
Original Part Number	Part Name	Classic Part Number
4I-4812	Pin As	480-8269
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-7959	Pulley As	301-5256
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647

4FS		
Original Part Number	Part Name	Classic Part Number
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
094-1850	Bearing-Trunnion	419-4747
096-4002	Bearing	420-3221
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
125-2950	Gear As	301-4762
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
128-9884	Bearing-Sleeve	360-2315

4FS		
Original Part Number	Part Name	Classic Part Number
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
272-4673	Muffler	301-7974
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

4MR		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-7959	Pulley As	301-5256
5I-8628	Plate-Valve	301-4771

4MR		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624

4MR		
Original Part Number	Part Name	Classic Part Number
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647

Sales Model 320B (Cont'd.)

4MR		
Original Part Number	Part Name	Classic Part Number
7Y-3553	Bearing-Sleeve	301-0433
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
094-1850	Bearing-Trunnion	419-4747
096-4002	Bearing	420-3221
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
115-6427	Spring	301-4776
115-6428	Piston As	394-0188

4MR		
Original Part Number	Part Name	Classic Part Number
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
125-2950	Gear As	301-4762
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
128-9884	Bearing-Sleeve	360-2315
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319

4MR		
Original Part Number	Part Name	Classic Part Number
137-3060	Bearing-Sleeve	360-2320
145-3037	Support	480-8271
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
272-4673	Muffler	301-7974
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

4NR		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2G-8631	Bearing-Sleeve	391-9811
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4T-8054	Seal As	472-8010
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-7959	Pulley As	301-5256
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
5V-1511	Pin As	418-1945
6K-8088	Bearing-Roller	399-4428
7E-7302	Bracket	416-5497

4NR		
Original Part Number	Part Name	Classic Part Number
7J-9344	Bearing-Sleeve	360-2334
7J-9682	Bearing-Sleeve	360-2335
7K-9593	Bearing-Sleeve	360-2337
7K-9639	Bearing-Sleeve	314-8643
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266

4NR		
Original Part Number	Part Name	Classic Part Number
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
9D-7924	Mount As	360-2356
9W-9940	Mount As.	360-2355
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968

Sales Model 320B (Cont'd.)

4NR		
Original Part Number	Part Name	Classic Part Number
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
107-2139	Pin As.	360-2352
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
119-2863	Pin	314-8698
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
125-2950	Gear As	301-4762

4NR		
Original Part Number	Part Name	Classic Part Number
126-9461	Pin	392-4528
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
128-9884	Bearing-Sleeve	360-2315
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271

4NR		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
272-4673	Muffler	301-7974
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

4XW		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266

4XW		
Original Part Number	Part Name	Classic Part Number
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
107-2139	Pin As.	360-2352
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047

4XW		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
119-2863	Pin	314-8698
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199

Sales Model 320B (Cont'd.)

4XW		
Original Part Number	Part Name	Classic Part Number
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
191-3235	Housing-Sprocket	394-0200

4XW		
Original Part Number	Part Name	Classic Part Number
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500

4XW		
Original Part Number	Part Name	Classic Part Number
236-6271	Bearing-Sleeve	360-2324
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

5BR		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2K-6413	Pin	360-2270
2V-0707	Bearing-Sleeve	360-2328
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-7959	Pulley As	301-5256
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261

5BR		
Original Part Number	Part Name	Classic Part Number
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
107-2139	Pin As.	360-2352
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
119-2863	Pin	314-8698
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673

5BR		
Original Part Number	Part Name	Classic Part Number
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
128-9884	Bearing-Sleeve	360-2315
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
240-2913	Bearing-Sleeve	360-2325

Sales Model 320B (Cont'd.)

5BR		
Original Part Number	Part Name	Classic Part Number
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032

5BR		
Original Part Number	Part Name	Classic Part Number
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
272-4673	Muffler	301-7974

5BR		
Original Part Number	Part Name	Classic Part Number
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

5CS		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-7959	Pulley As	301-5256
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647

5CS		
Original Part Number	Part Name	Classic Part Number
7Y-3553	Bearing-Sleeve	301-0433
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
107-2139	Pin As.	360-2352
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
119-2863	Pin	314-8698
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630

5CS		
Original Part Number	Part Name	Classic Part Number
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
128-9884	Bearing-Sleeve	360-2315
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320
137-8479	Spacer	395-1323
145-3037	Support	480-8271
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
272-4673	Muffler	301-7974
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320B (Cont'd.)

5GW		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
2D-5658	Bearing-Ball	301-4628
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646

5GW		
Original Part Number	Part Name	Classic Part Number
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
9F-3212	Bearing-Ball	384-5953
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
107-2139	Pin As.	360-2352
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
119-2863	Pin	314-8698
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314

5GW		
Original Part Number	Part Name	Classic Part Number
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6271	Bearing-Sleeve	360-2324
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

5MS		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
1W-4369	Pulley-Alt	296-1340
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667

5MS		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4P-3683	Pump Gp-Water -B	374-7498

5MS		
Original Part Number	Part Name	Classic Part Number
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5I-8628	Plate-Valve	301-4771
5P-7807	Bearing-Ball	314-8502
6I-1099	Manifold-Exh	424-6366

Sales Model 320B (Cont'd.)

5MS		
Original Part Number	Part Name	Classic Part Number
6Y-9930	Mount As	360-2353
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7K-5448	Cup-Bearing	415-1922
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3428	Bearing-Sleeve	314-8647
7Y-3553	Bearing-Sleeve	301-0433
7Y-5108	Rod As	394-0912

5MS		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8S-0248	Breather As	325-6033
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
113-6200	Gasket	438-2020
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
117-5612	Pipe	398-2965
117-6270	Support As	434-1400
118-9906	Muffler As	360-7865
119-2863	Pin	314-8698

5MS		
Original Part Number	Part Name	Classic Part Number
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
130-9293	Rod	314-8708
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3240	Housing-Motor	418-1962
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6268	Bearing-Sleeve	453-6499

Sales Model 320B (Cont'd.)

5MS		
Original Part Number	Part Name	Classic Part Number
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

5MS		
Original Part Number	Part Name	Classic Part Number
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

5MS		
Original Part Number	Part Name	Classic Part Number
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

6CR		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2K-6413	Pin	360-2270
2V-0707	Bearing-Sleeve	360-2328
3G-5285	Bearing-Sleeve	360-2312
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-7959	Pulley As	301-5256
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
6K-8088	Bearing-Roller	399-4428
7E-7302	Bracket	416-5497
7K-9639	Bearing-Sleeve	314-8643
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952

6CR		
Original Part Number	Part Name	Classic Part Number
7Y-1687	Piston As	360-2266
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-3553	Bearing-Sleeve	301-0433
7Y-4666	Bearing-Sleeve	314-8636
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9D-7924	Mount As	360-2356
9F-3212	Bearing-Ball	384-5953
9W-9940	Mount As.	360-2355
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313

6CR		
Original Part Number	Part Name	Classic Part Number
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
106-6878	Pin	372-7510
107-2139	Pin As.	360-2352
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
119-2863	Pin	314-8698
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588

Sales Model 320B (Cont'd.)

6CR		
Original Part Number	Part Name	Classic Part Number
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320
137-8479	Spacer	395-1323
145-3037	Support	480-8271
163-3749	Bearing-Sleeve	433-7505

6CR		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499

6CR		
Original Part Number	Part Name	Classic Part Number
236-6271	Bearing-Sleeve	360-2324
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
272-4673	Muffler	301-7974
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

6LS		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
3F-4971	Pin	295-5693
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4K-0299	Bearing-Sleeve	308-9816
4K-0300	Bearing-Sleeve	308-9817
4T-8054	Seal As	472-8010
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-7959	Pulley As	301-5256
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
6Y-9930	Mount As	360-2353
7K-0078	Bearing-Sleeve	308-9825
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671

6LS		
Original Part Number	Part Name	Classic Part Number
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
9F-3212	Bearing-Ball	384-5953
9W-9931	Mount As.	360-2354
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
102-8112	Cylinder	360-2276
107-2139	Pin As.	360-2352
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046

6LS		
Original Part Number	Part Name	Classic Part Number
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-6270	Support As	434-1400
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
130-9293	Rod	314-8708
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
191-3235	Housing-Sprocket	394-0200

Sales Model 320B (Cont'd.)

6LS		
Original Part Number	**Part Name**	**Classic Part Number**
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322

6LS		
Original Part Number	**Part Name**	**Classic Part Number**
236-6268	Bearing-Sleeve	453-6499
236-6271	Bearing-Sleeve	360-2324
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032

6LS		
Original Part Number	**Part Name**	**Classic Part Number**
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
272-4673	Muffler	301-7974
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

6LW		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
1W-4369	Pulley-Alt	296-1340
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5I-8628	Plate-Valve	301-4771
5P-7807	Bearing-Ball	314-8502
6I-1099	Manifold-Exh	424-6366
6Y-9930	Mount As	360-2353
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449

6LW		
Original Part Number	**Part Name**	**Classic Part Number**
7I-7180	Piston	421-7142
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-4666	Bearing-Sleeve	314-8636
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648

6LW		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-5131	Bearing-Sleeve	301-4626
8S-0248	Breather As	325-6033
9V-0247	Plate	417-4527
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
113-6200	Gasket	438-2020
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729

Sales Model 320B (Cont'd.)

6LW		
Original Part Number	Part Name	Classic Part Number
117-6270	Support As	434-1400
118-9906	Muffler As	360-7865
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
122-5076	Rod	301-4569
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
127-5970	Gear-Planet	301-3398
128-9882	Bearing-Sleeve	314-8642
129-7768	Bearing-Sleeve	360-2316
130-9293	Rod	314-8708
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336

6LW		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-3037	Support	480-8271
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6268	Bearing-Sleeve	453-6499

6LW		
Original Part Number	Part Name	Classic Part Number
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

7JR		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
1W-4369	Pulley-Alt	296-1340
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596

7JR		
Original Part Number	Part Name	Classic Part Number
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5I-8628	Plate-Valve	301-4771
5P-7807	Bearing-Ball	314-8502
6I-1099	Manifold-Exh	424-6366
6Y-9930	Mount As	360-2353
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449

7JR		
Original Part Number	Part Name	Classic Part Number
7I-7180	Piston	421-7142
7K-5448	Cup-Bearing	415-1922
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1513	Pipe As-Exhaust	301-5249

Sales Model 320B (Cont'd.)

7JR		
Original Part Number	Part Name	Classic Part Number
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-3553	Bearing-Sleeve	301-0433
7Y-4666	Bearing-Sleeve	314-8636
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8S-0248	Breather As	325-6033
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9V-0247	Plate	417-4527
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

7JR		
Original Part Number	Part Name	Classic Part Number
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
113-6200	Gasket	438-2020
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
118-9906	Muffler As	360-7865
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
122-5076	Rod	301-4569
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320

7JR		
Original Part Number	Part Name	Classic Part Number
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-3037	Support	480-8271
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107

Sales Model 320B (Cont'd.)

7JR		
Original Part Number	Part Name	Classic Part Number
352-2160	Pump Gp-Water -B	433-0789

7JR		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292

7JR		
Original Part Number	Part Name	Classic Part Number
441-9566	Gear-Flywheel	374-4703

7ZZ		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647

7ZZ		
Original Part Number	Part Name	Classic Part Number
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
125-2950	Gear As	301-4762
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315

7ZZ		
Original Part Number	Part Name	Classic Part Number
133-2437	Link	377-6199
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
272-4673	Muffler	301-7974
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

8ES		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203

8GZ		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771

8GZ		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671

8GZ		
Original Part Number	Part Name	Classic Part Number
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952

Sales Model 320B (Cont'd.)

8GZ		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1687	Piston As	360-2266
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679

8GZ		
Original Part Number	**Part Name**	**Classic Part Number**
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
125-2950	Gear As	301-4762
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
133-2437	Link	377-6199
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
163-3749	Bearing-Sleeve	433-7505

8GZ		
Original Part Number	**Part Name**	**Classic Part Number**
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
272-4673	Muffler	301-7974
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

9CS		
Original Part Number	**Part Name**	**Classic Part Number**
114-0468	Pin-G.E.T.	443-1203

9JS		
Original Part Number	**Part Name**	**Classic Part Number**
2D-5658	Bearing-Ball	301-4628
3F-4971	Pin	295-5693
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4K-0299	Bearing-Sleeve	308-9816
4K-0300	Bearing-Sleeve	308-9817
4T-8054	Seal As	472-8010
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-7959	Pulley As	301-5256

9JS		
Original Part Number	**Part Name**	**Classic Part Number**
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
6Y-9930	Mount As	360-2353
7K-0078	Bearing-Sleeve	308-9825
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718

9JS		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
9W-9931	Mount As.	360-2354
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273

Sales Model 320B (Cont'd.)

9JS		
Original Part Number	Part Name	Classic Part Number
102-8112	Cylinder	360-2276
107-2139	Pin As.	360-2352
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642

9JS		
Original Part Number	Part Name	Classic Part Number
128-9883	Bearing-Sleeve	360-2314
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
130-9293	Rod	314-8708
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644

9JS		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6271	Bearing-Sleeve	360-2324
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
272-4673	Muffler	301-7974
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

9WS		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

9WS		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2N-1599	Gear	378-3970
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203

9WS		
Original Part Number	Part Name	Classic Part Number
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4N-0432	Bearing-Ball	417-4499
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-3683	Pump Gp-Water -B	374-7498
4P-7688	Valve As-Check	420-6216
4P-7790	Shaft As-Arm	457-4596
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8577	Rod As-Injector	455-5513
4W-0452	Seal As -Cshaft	325-6191

Sales Model 320B (Cont'd.)

9WS		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-8628	Plate-Valve	301-4771
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1099	Manifold-Exh	424-6366
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-9930	Mount As	360-2353
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7M-4046	Bearing-Sleeve	394-8206

9WS		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-8064	Valve-Inlet	384-8705
7W-9020	Bell As-Pump Suc	378-3989
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765

9WS		
Original Part Number	Part Name	Classic Part Number
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-4666	Bearing-Sleeve	314-8636
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

Sales Model 320B (Cont'd.)

9WS		
Original Part Number	Part Name	Classic Part Number
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-0247	Plate	417-4527
9W-9931	Mount As.	360-2354
9Y-1798	Seal-Water	379-0165
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-6267	Plate As-Idler	375-9983
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
111-8015	Gasket As-Head	279-4977
113-6200	Gasket	438-2020

9WS		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
118-9906	Muffler As	360-7865
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
130-9293	Rod	314-8708
131-3815	Seal Gp-Basic	325-6193
133-2437	Link	377-6199
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-8948	Plate	399-8588
134-8949	Plate	383-2110
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320

9WS		
Original Part Number	Part Name	Classic Part Number
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
148-7455	Valve - Exhaust	270-4361
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

Sales Model 320B (Cont'd.)

9WS		
Original Part Number	Part Name	Classic Part Number
232-3233	Bearing-Main	376-9085
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

9WS		
Original Part Number	Part Name	Classic Part Number
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
271-5658	Crankshaft As.	368-5912

9WS		
Original Part Number	Part Name	Classic Part Number
277-7089	Shaft As	380-7578
314-8717	Shaft-Cla	360-2273
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BBG		
Original Part Number	Part Name	Classic Part Number
4I-4812	Pin As	480-8269
5I-7959	Pulley As	301-5256
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952

BBG		
Original Part Number	Part Name	Classic Part Number
7Y-1687	Piston As	360-2266
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
094-1509	Shaft-Planet	360-2273
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400

BBG		
Original Part Number	Part Name	Classic Part Number
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
125-2950	Gear As	301-4762
127-5970	Gear-Planet	301-3398
145-3037	Support	480-8271
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
250-2398	Pin As	382-8047
272-4673	Muffler	301-7974
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BNP		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3W-8239	Sleeve-Wear	360-2342
4I-0465	Pin	372-7511

BNP		
Original Part Number	Part Name	Classic Part Number
4I-4812	Pin As	480-8269
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5I-8628	Plate-Valve	301-4771
6I-1099	Manifold-Exh	424-6366
6Y-9930	Mount As	360-2353

BNP		
Original Part Number	Part Name	Classic Part Number
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551

Sales Model 320B (Cont'd.)

BNP		
Original Part Number	Part Name	Classic Part Number
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8S-0248	Breather As	325-6033
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9349	Mount-Rubber	384-3469

BNP		
Original Part Number	Part Name	Classic Part Number
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
113-6200	Gasket	438-2020
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
118-9906	Muffler As	360-7865
119-2940	Gasket	378-4002
122-5076	Rod	301-4569
126-5875	Flywheel As.	374-4694
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-3037	Support	480-8271
152-3952	Impeller-Pump	374-4696

BNP		
Original Part Number	Part Name	Classic Part Number
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

AKH		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273

AKH		
Original Part Number	**Part Name**	**Classic Part Number**
107-2139	Pin As.	360-2352
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
121-7746	Pre-Cleaner As	360-2311
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274

AKH		
Original Part Number	**Part Name**	**Classic Part Number**
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ALF		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222

ALF		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556

ALF		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-3553	Bearing-Sleeve	301-0433

Sales Model 320C (Cont'd.)

ALF		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
107-2139	Pin As.	360-2352
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762

ALF		
Original Part Number	Part Name	Classic Part Number
126-9461	Pin	392-4528
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200

ALF		
Original Part Number	Part Name	Classic Part Number
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ALX		
Original Part Number	Part Name	Classic Part Number
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648

ALX		
Original Part Number	Part Name	Classic Part Number
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316

ALX		
Original Part Number	Part Name	Classic Part Number
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343

Sales Model 320C (Cont'd.)

ALX		
Original Part Number	**Part Name**	**Classic Part Number**
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436

ALX		
Original Part Number	**Part Name**	**Classic Part Number**
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2916	Bearing-Sleeve	360-2327

ALX		
Original Part Number	**Part Name**	**Classic Part Number**
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

AMC		
Original Part Number	**Part Name**	**Classic Part Number**
2K-6413	Pin	360-2270
2V-0707	Bearing-Sleeve	360-2328
3G-5285	Bearing-Sleeve	360-2312
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
6K-8088	Bearing-Roller	399-4428
7E-7302	Bracket	416-5497
7K-9592	Bearing-Sleeve	360-2336
7K-9639	Bearing-Sleeve	314-8643
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626

AMC		
Original Part Number	**Part Name**	**Classic Part Number**
8C-3111	Rod End-Spher	392-4523
9D-7924	Mount As	360-2356
9W-9940	Mount As.	360-2355
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
107-2139	Pin As.	360-2352
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445

AMC		
Original Part Number	**Part Name**	**Classic Part Number**
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
176-3900	Accumulator	416-5513
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320C (Cont'd.)

ANB		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
2V-0707	Bearing-Sleeve	360-2328
3G-5285	Bearing-Sleeve	360-2312
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
6E-4985	Cover-Filter	424-2015
6K-8088	Bearing-Roller	399-4428
7E-7302	Bracket	416-5497
7K-9592	Bearing-Sleeve	360-2336
7K-9639	Bearing-Sleeve	314-8643
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-3553	Bearing-Sleeve	301-0433
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9D-7924	Mount As	360-2356

ANB		
Original Part Number	Part Name	Classic Part Number
9W-9940	Mount As.	360-2355
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
106-6878	Pin	372-7510
107-2139	Pin As.	360-2352
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
128-9882	Bearing-Sleeve	314-8642
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319

ANB		
Original Part Number	Part Name	Classic Part Number
137-3060	Bearing-Sleeve	360-2320
137-8479	Spacer	395-1323
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
176-3900	Accumulator	416-5513
179-3008	Cylinder	480-8272
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

APA		
Original Part Number	Part Name	Classic Part Number
4I-0704	Bearing-Sleeve	360-2332

APA		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269

APA		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625

Sales Model 320C (Cont'd.)

APA		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729

APA		
Original Part Number	**Part Name**	**Classic Part Number**
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322

APA		
Original Part Number	**Part Name**	**Classic Part Number**
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2916	Bearing-Sleeve	360-2327
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

AXK		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5533	Bearing-Sleeve	314-8628

AXK		
Original Part Number	**Part Name**	**Classic Part Number**
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
107-2139	Pin As.	360-2352
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2820	Bearing-Sleeve	360-2318

AXK		
Original Part Number	**Part Name**	**Classic Part Number**
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500

Sales Model 320C (Cont'd.)

AXK		
Original Part Number	Part Name	Classic Part Number
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969

AXK		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047

AXK		
Original Part Number	Part Name	Classic Part Number
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BBL		
Original Part Number	Part Name	Classic Part Number
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273

BBL		
Original Part Number	Part Name	Classic Part Number
107-2139	Pin As.	360-2352
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
186-5652	Pin	392-4532
186-5662	Pin	421-1560
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589

BBL		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BCB		
Original Part Number	Part Name	Classic Part Number
3G-5285	Bearing-Sleeve	360-2312
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332

BCB		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571

BCB		
Original Part Number	Part Name	Classic Part Number
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-3428	Bearing-Sleeve	314-8647

Sales Model 320C (Cont'd.)

BCB		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316

BCB		
Original Part Number	Part Name	Classic Part Number
133-2437	Link	377-6199
134-8949	Plate	383-2110
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343

BCB		
Original Part Number	Part Name	Classic Part Number
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BCN		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443

BCN		
Original Part Number	Part Name	Classic Part Number
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1513	Pipe As-Exhaust	301-5249

BCN		
Original Part Number	Part Name	Classic Part Number
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

Sales Model 320C (Cont'd.)

BCN		
Original Part Number	Part Name	Classic Part Number
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
113-6200	Gasket	438-2020
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
118-9906	Muffler As	360-7865
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697

BCN		
Original Part Number	Part Name	Classic Part Number
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322

BCN		
Original Part Number	Part Name	Classic Part Number
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BDB		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729

BDB		
Original Part Number	Part Name	Classic Part Number
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969

BDB		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316

Sales Model 320C (Cont'd.)

BDB		
Original Part Number	**Part Name**	**Classic Part Number**
133-2437	Link	377-6199
134-8949	Plate	383-2110
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200

BDB		
Original Part Number	**Part Name**	**Classic Part Number**
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436

BDB		
Original Part Number	**Part Name**	**Classic Part Number**
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BDC		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5K-8265	Pin	241-2590
5L-6326	Bearing-Ball	420-3222
6K-6047	Pin	241-2603
6K-6054	Pin	241-2605
6K-8088	Bearing-Roller	399-4428
7E-7302	Bracket	416-5497
7K-9601	Bearing-Sleeve	360-2338
7K-9602	Bearing-Sleeve	360-2339
7K-9639	Bearing-Sleeve	314-8643
7K-9642	Bearing-Sleeve	360-2340
7K-9644	Bearing-Sleeve	360-2341
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406

BDC		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9D-7924	Mount As	360-2356
9W-9940	Mount As.	360-2355
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
107-2139	Pin As.	360-2352
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528

BDC		
Original Part Number	**Part Name**	**Classic Part Number**
128-9882	Bearing-Sleeve	314-8642
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
176-3900	Accumulator	416-5513
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499

Sales Model 320C (Cont'd.)

BDC		
Original Part Number	Part Name	Classic Part Number
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969

BDC		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351

BDC		
Original Part Number	Part Name	Classic Part Number
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BDE		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987

BDE		
Original Part Number	Part Name	Classic Part Number
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
099-0722	Link As	415-1909
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692

BDE		
Original Part Number	Part Name	Classic Part Number
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
113-6200	Gasket	438-2020
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
118-9906	Muffler As	360-7865
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388

Sales Model 320C (Cont'd.)

BDE		
Original Part Number	Part Name	Classic Part Number
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372

BDE		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969

BDE		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BEA		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

BEA		
Original Part Number	Part Name	Classic Part Number
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-5128	Bearing-Sleeve	314-8648

BEA		
Original Part Number	Part Name	Classic Part Number
7Y-5131	Bearing-Sleeve	301-4626
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
113-6200	Gasket	438-2020
114-1398	Gauge-Oil Level	394-9815

Sales Model 320C (Cont'd.)

BEA		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
118-9906	Muffler As	360-7865
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388

BEA		
Original Part Number	Part Name	Classic Part Number
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6268	Bearing-Sleeve	453-6499

BEA		
Original Part Number	Part Name	Classic Part Number
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BER		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5K-8265	Pin	241-2590
5L-6326	Bearing-Ball	420-3222
6K-6047	Pin	241-2603
6K-6054	Pin	241-2605
6K-8088	Bearing-Roller	399-4428
7E-7302	Bracket	416-5497
7K-9601	Bearing-Sleeve	360-2338

BER		
Original Part Number	Part Name	Classic Part Number
7K-9602	Bearing-Sleeve	360-2339
7K-9639	Bearing-Sleeve	314-8643
7K-9642	Bearing-Sleeve	360-2340
7K-9644	Bearing-Sleeve	360-2341
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564

BER		
Original Part Number	Part Name	Classic Part Number
7Y-2392	Link-Rh	301-4765
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-3553	Bearing-Sleeve	301-0433
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9D-7924	Mount As	360-2356
9W-9940	Mount As.	360-2355
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966

Sales Model 320C (Cont'd.)

BER		
Original Part Number	**Part Name**	**Classic Part Number**
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
107-2139	Pin As.	360-2352
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
128-9882	Bearing-Sleeve	314-8642
129-7768	Bearing-Sleeve	360-2316

BER		
Original Part Number	**Part Name**	**Classic Part Number**
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
176-3900	Accumulator	416-5513
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589

BER		
Original Part Number	**Part Name**	**Classic Part Number**
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BGB		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4K-0299	Bearing-Sleeve	308-9816
4K-0300	Bearing-Sleeve	308-9817
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-0078	Bearing-Sleeve	308-9825
7Y-1644	Gear-Planet	301-3406
7Y-2396	Bearing-Sleeve	314-8634
7Y-3550	Pin	360-2350
7Y-5131	Bearing-Sleeve	301-4626
9F-3212	Bearing-Ball	384-5953

BGB		
Original Part Number	**Part Name**	**Classic Part Number**
094-1509	Shaft-Planet	360-2273
096-7912	Bearing-Sleeve	314-8654
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
125-2950	Gear As	301-4762
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317

BGB		
Original Part Number	**Part Name**	**Classic Part Number**
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6271	Bearing-Sleeve	360-2324
240-2913	Bearing-Sleeve	360-2325

Sales Model 320C (Cont'd.)

BGB		
Original Part Number	Part Name	Classic Part Number
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351

BGB		
Original Part Number	Part Name	Classic Part Number
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348

BGB		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292

BKK		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-0078	Bearing-Sleeve	308-9825
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
094-1509	Shaft-Planet	360-2273
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471

BKK		
Original Part Number	Part Name	Classic Part Number
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8949	Plate	383-2110
137-2919	Bearing-Sleeve	360-2319
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644

BKK		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6271	Bearing-Sleeve	360-2324
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BMZ		
Original Part Number	Part Name	Classic Part Number
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5128	Bearing-Sleeve	314-8648

BMZ		
Original Part Number	Part Name	Classic Part Number
7Y-5131	Bearing-Sleeve	301-4626
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
107-2139	Pin As.	360-2352
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199

BMZ		
Original Part Number	Part Name	Classic Part Number
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322

Sales Model 320C (Cont'd.)

BMZ		
Original Part Number	**Part Name**	**Classic Part Number**
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324

BMZ		
Original Part Number	**Part Name**	**Classic Part Number**
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032

BMZ		
Original Part Number	**Part Name**	**Classic Part Number**
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BPR		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969

BPR		
Original Part Number	**Part Name**	**Classic Part Number**
094-1509	Shaft-Planet	360-2273
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505

BPR		
Original Part Number	**Part Name**	**Classic Part Number**
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BRX		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269

BRX		
Original Part Number	**Part Name**	**Classic Part Number**
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729

BRX		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-3553	Bearing-Sleeve	301-0433

Sales Model 320C (Cont'd.)

BRX		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729

BRX		
Original Part Number	Part Name	Classic Part Number
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
128-9882	Bearing-Sleeve	314-8642
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200

BRX		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CCD		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
227-6789	Bearing-Sleeve	360-2322
240-2913	Bearing-Sleeve	360-2325

CLM		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-3428	Bearing-Sleeve	314-8647

CLM		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729

CLM		
Original Part Number	Part Name	Classic Part Number
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274

Sales Model 320C (Cont'd.)

CLM		
Original Part Number	**Part Name**	**Classic Part Number**
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322

CLM		
Original Part Number	**Part Name**	**Classic Part Number**
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969

CLM		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CLZ		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969

CLZ		
Original Part Number	**Part Name**	**Classic Part Number**
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200

CLZ		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DBG		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771

DBG		
Original Part Number	**Part Name**	**Classic Part Number**
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729

DBG		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765

Sales Model 320C (Cont'd.)

DBG		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9V-0247	Plate	417-4527
086-0414	Flange	392-4522
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
107-2139	Pin As.	360-2352
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762

DBG		
Original Part Number	Part Name	Classic Part Number
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295

DBG		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

EAG		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648

EAG		
Original Part Number	Part Name	Classic Part Number
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316

EAG		
Original Part Number	Part Name	Classic Part Number
133-2437	Link	377-6199
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499

Sales Model 320C (Cont'd.)

EAG		
Original Part Number	**Part Name**	**Classic Part Number**
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324

EAG		
Original Part Number	**Part Name**	**Classic Part Number**
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047

EAG		
Original Part Number	**Part Name**	**Classic Part Number**
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

EGA		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
9V-0247	Plate	417-4527
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815

EGA		
Original Part Number	**Part Name**	**Classic Part Number**
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
148-4634	Shaft-Planet	360-2274
179-3008	Cylinder	480-8272
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644

EGA		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6271	Bearing-Sleeve	360-2324
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

EGL		
Original Part Number	**Part Name**	**Classic Part Number**
2D-5658	Bearing-Ball	301-4628
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564

EGL		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-2392	Link-Rh	301-4765
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9V-0247	Plate	417-4527
086-0414	Flange	392-4522
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273

EGL		
Original Part Number	**Part Name**	**Classic Part Number**
107-2139	Pin As.	360-2352
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319

Sales Model 320C (Cont'd.)

EGL		
Original Part Number	Part Name	Classic Part Number
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295

EGL		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969

EGL		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

FBA		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966

FBA		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
099-0722	Link As	415-1909
107-2139	Pin As.	360-2352
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272

FBA		
Original Part Number	Part Name	Classic Part Number
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320C (Cont'd.)

FBB		
Original Part Number	Part Name	Classic Part Number
3G-2797	Bearing-Sleeve	360-2329
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968

FBB		
Original Part Number	Part Name	Classic Part Number
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200

FBB		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GAA		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564

GAA		
Original Part Number	Part Name	Classic Part Number
7Y-2392	Link-Rh	301-4765
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-3553	Bearing-Sleeve	301-0433
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968

GAA		
Original Part Number	Part Name	Classic Part Number
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
107-2139	Pin As.	360-2352
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
128-9882	Bearing-Sleeve	314-8642

Sales Model 320C (Cont'd.)

GAA		
Original Part Number	Part Name	Classic Part Number
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274

GAA		
Original Part Number	Part Name	Classic Part Number
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499

GAA		
Original Part Number	Part Name	Classic Part Number
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GAB		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273

GAB		
Original Part Number	Part Name	Classic Part Number
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295

GAB		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320C (Cont'd.)

GAD		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-5128	Bearing-Sleeve	314-8648
8W-8512	Pin As	385-7220
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569

GAD		
Original Part Number	**Part Name**	**Classic Part Number**
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343

GAD		
Original Part Number	**Part Name**	**Classic Part Number**
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6271	Bearing-Sleeve	360-2324
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GLA		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9V-0247	Plate	417-4527
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964

GLA		
Original Part Number	**Part Name**	**Classic Part Number**
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
099-0722	Link As	415-1909
107-2139	Pin As.	360-2352
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319

GLA		
Original Part Number	**Part Name**	**Classic Part Number**
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969

Sales Model 320C (Cont'd.)

GLA		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326

GLA		
Original Part Number	Part Name	Classic Part Number
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047

GLA		
Original Part Number	Part Name	Classic Part Number
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GNG		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
086-0414	Flange	392-4522
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968

GNG		
Original Part Number	Part Name	Classic Part Number
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
107-2139	Pin As.	360-2352
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560

GNG		
Original Part Number	Part Name	Classic Part Number
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

HBC		
Original Part Number	Part Name	Classic Part Number
4I-0465	Pin	372-7511
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625

HBC		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697

HBC		
Original Part Number	Part Name	Classic Part Number
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967

Sales Model 320C (Cont'd.)

HBC		
Original Part Number	Part Name	Classic Part Number
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
107-2139	Pin As.	360-2352
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319

HBC		
Original Part Number	Part Name	Classic Part Number
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499

HBC		
Original Part Number	Part Name	Classic Part Number
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

HKT		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-3553	Bearing-Sleeve	301-0433

HKT		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
107-2139	Pin As.	360-2352
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729

HKT		
Original Part Number	Part Name	Classic Part Number
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
128-9882	Bearing-Sleeve	314-8642
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505

Sales Model 320C (Cont'd.)

HKT		
Original Part Number	Part Name	Classic Part Number
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322

HKT		
Original Part Number	Part Name	Classic Part Number
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969

HKT		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JPL		
Original Part Number	Part Name	Classic Part Number
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-0078	Bearing-Sleeve	308-9825
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2581	Guard As-Trk Gde	480-8270
9V-0247	Plate	417-4527
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046

JPL		
Original Part Number	Part Name	Classic Part Number
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
117-5612	Pipe	398-2965
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
148-4634	Shaft-Planet	360-2274
179-3008	Cylinder	480-8272
191-3235	Housing-Sprocket	394-0200

JPL		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6271	Bearing-Sleeve	360-2324
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JTG		
Original Part Number	Part Name	Classic Part Number
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659

JTG		
Original Part Number	Part Name	Classic Part Number
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9V-0247	Plate	417-4527
086-0414	Flange	392-4522
087-5533	Bearing-Sleeve	314-8628

JTG		
Original Part Number	Part Name	Classic Part Number
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
107-2139	Pin As.	360-2352
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815

Sales Model 320C (Cont'd.)

JTG		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260

JTG		
Original Part Number	Part Name	Classic Part Number
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499

JTG		
Original Part Number	Part Name	Classic Part Number
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MAA		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
086-0414	Flange	392-4522

MAA		
Original Part Number	Part Name	Classic Part Number
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
107-2139	Pin As.	360-2352
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271

MAA		
Original Part Number	Part Name	Classic Part Number
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326

Sales Model 320C (Cont'd.)

MAA		
Original Part Number	Part Name	Classic Part Number
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351

MAA		
Original Part Number	Part Name	Classic Part Number
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348

MAA		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292

MAB		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
2V-0707	Bearing-Sleeve	360-2328
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
086-0414	Flange	392-4522
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966

MAB		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
107-2139	Pin As.	360-2352
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532

MAB		
Original Part Number	Part Name	Classic Part Number
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MAC		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269

MAC		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729

MAC		
Original Part Number	Part Name	Classic Part Number
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648

Sales Model 320C (Cont'd.)

MAC		
Original Part Number	Part Name	Classic Part Number
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199

MAC		
Original Part Number	Part Name	Classic Part Number
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
228-5621	Bearing-Sleeve	360-2323

MAC		
Original Part Number	Part Name	Classic Part Number
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

NAE		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-0078	Bearing-Sleeve	308-9825
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-3428	Bearing-Sleeve	314-8647
7Y-3549	Pin	360-2349
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967

NAE		
Original Part Number	Part Name	Classic Part Number
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
133-2437	Link	377-6199
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200

NAE		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320C (Cont'd.)

PAA		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
086-0414	Flange	392-4522
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966

PAA		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
107-2139	Pin As.	360-2352
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
186-5652	Pin	392-4532

PAA		
Original Part Number	Part Name	Classic Part Number
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PAB		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
2V-0707	Bearing-Sleeve	360-2328
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
6W-9173	Bearing	374-1457

PAB		
Original Part Number	Part Name	Classic Part Number
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647

PAB		
Original Part Number	Part Name	Classic Part Number
7Y-3553	Bearing-Sleeve	301-0433
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9F-3212	Bearing-Ball	384-5953
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969

Sales Model 320C (Cont'd.)

PAB		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
107-2139	Pin As.	360-2352
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
128-9882	Bearing-Sleeve	314-8642
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110

PAB		
Original Part Number	Part Name	Classic Part Number
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343

PAB		
Original Part Number	Part Name	Classic Part Number
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PAC		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966

PAC		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271

PAC		
Original Part Number	Part Name	Classic Part Number
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969

Sales Model 320C (Cont'd.)

PAC		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032

PAC		
Original Part Number	Part Name	Classic Part Number
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273

PAC		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RAW		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5K-8265	Pin	241-2590
5L-6326	Bearing-Ball	420-3222
6K-6047	Pin	241-2603
6K-6054	Pin	241-2605
7K-9601	Bearing-Sleeve	360-2338
7K-9602	Bearing-Sleeve	360-2339
7K-9639	Bearing-Sleeve	314-8643
7K-9642	Bearing-Sleeve	360-2340
7K-9644	Bearing-Sleeve	360-2341
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648

RAW		
Original Part Number	Part Name	Classic Part Number
7Y-5131	Bearing-Sleeve	301-4626
8W-8512	Pin As	385-7220
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
107-2139	Pin As.	360-2352
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
128-9882	Bearing-Sleeve	314-8642
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271

RAW		
Original Part Number	Part Name	Classic Part Number
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SAH		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331

Sales Model 320C (Cont'd.)

SAH		
Original Part Number	Part Name	Classic Part Number
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-0078	Bearing-Sleeve	308-9825
7Y-1644	Gear-Planet	301-3406
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-3550	Pin	360-2350
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8W-8512	Pin As	385-7220
9F-3212	Bearing-Ball	384-5953
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968

SAH		
Original Part Number	Part Name	Classic Part Number
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
199-4582	Bearing-Needle	388-6589

SAH		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SBN		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4T-8054	Seal As	472-8010
5I-8628	Plate-Valve	301-4771
5K-8265	Pin	241-2590
5L-6326	Bearing-Ball	420-3222
6K-6047	Pin	241-2603
6K-6054	Pin	241-2605
7J-1309	Bearing-Aligning	360-2275
7K-9601	Bearing-Sleeve	360-2338
7K-9602	Bearing-Sleeve	360-2339

SBN		
Original Part Number	Part Name	Classic Part Number
7K-9639	Bearing-Sleeve	314-8643
7K-9642	Bearing-Sleeve	360-2340
7K-9644	Bearing-Sleeve	360-2341
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648

SBN		
Original Part Number	Part Name	Classic Part Number
7Y-5131	Bearing-Sleeve	301-4626
8W-8512	Pin As	385-7220
9M-1328	Bearing-Aligning	325-6018
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
099-0722	Link As	415-1909
107-2139	Pin As.	360-2352
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815

Sales Model 320C (Cont'd.)

SBN		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
128-9882	Bearing-Sleeve	314-8642
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445

SBN		
Original Part Number	Part Name	Classic Part Number
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500

SBN		
Original Part Number	Part Name	Classic Part Number
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TBR		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8W-8512	Pin As	385-7220
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966

TBR		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
137-2919	Bearing-Sleeve	360-2319
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

TBR		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

A6F		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

A6F		
Original Part Number	**Part Name**	**Classic Part Number**
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

A6F		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

A8F		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

A8F		
Original Part Number	**Part Name**	**Classic Part Number**
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

A8F		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

A9F		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671

A9F		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

A9F		
Original Part Number	**Part Name**	**Classic Part Number**
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271

Sales Model 320D (Cont'd.)

A9F		
Original Part Number	Part Name	Classic Part Number
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

A9F		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969

A9F		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

AMR		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588

AMR		
Original Part Number	Part Name	Classic Part Number
134-8950	Plate	399-8587
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499

AMR		
Original Part Number	Part Name	Classic Part Number
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

AZR		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

AZR		
Original Part Number	Part Name	Classic Part Number
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
134-8950	Plate	399-8587
137-2820	Bearing-Sleeve	360-2318
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274

AZR		
Original Part Number	Part Name	Classic Part Number
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

Sales Model 320D (Cont'd.)

AZR		
Original Part Number	**Part Name**	**Classic Part Number**
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327

AZR		
Original Part Number	**Part Name**	**Classic Part Number**
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348

AZR		
Original Part Number	**Part Name**	**Classic Part Number**
357-7540	Valve-Fill	360-2292

BW2		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-1644	Gear-Planet	301-3406
8W-8512	Pin As	385-7220
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

BW2		
Original Part Number	**Part Name**	**Classic Part Number**
129-7768	Bearing-Sleeve	360-2316
148-4634	Shaft-Planet	360-2274
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
236-6271	Bearing-Sleeve	360-2324

BW2		
Original Part Number	**Part Name**	**Classic Part Number**
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BWP		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0523	Pin	314-8696
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047

BWP		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

BWP		
Original Part Number	**Part Name**	**Classic Part Number**
227-6789	Bearing-Sleeve	360-2322
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BWW		
Original Part Number	**Part Name**	**Classic Part Number**
3W-8409	Bearing	398-8336
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7J-1309	Bearing-Aligning	360-2275

BWW		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1644	Gear-Planet	301-3406
8G-0935	Cap	425-3584
8W-8512	Pin As	385-7220
8Y-1853	Strip	428-7633
9M-1328	Bearing-Aligning	325-6018

BWW		
Original Part Number	**Part Name**	**Classic Part Number**
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698
125-2950	Gear As	301-4762

Sales Model 320D (Cont'd.)

BWW		
Original Part Number	Part Name	Classic Part Number
129-7768	Bearing-Sleeve	360-2316
148-4634	Shaft-Planet	360-2274
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
199-4582	Bearing-Needle	388-6589

BWW		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

BWW		
Original Part Number	Part Name	Classic Part Number
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BWZ		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0523	Pin	314-8696
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

BWZ		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
134-8950	Plate	399-8587
137-2820	Bearing-Sleeve	360-2318
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

BWZ		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BZF		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406

BZF		
Original Part Number	Part Name	Classic Part Number
8W-8512	Pin As	385-7220
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
148-4634	Shaft-Planet	360-2274
179-3008	Cylinder	480-8272
191-3235	Housing-Sprocket	394-0200

BZF		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BZP		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269

BZP		
Original Part Number	Part Name	Classic Part Number
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222

BZP		
Original Part Number	Part Name	Classic Part Number
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571

Sales Model 320D (Cont'd.)

BZP		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-3549	Pin	360-2349
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698

BZP		
Original Part Number	**Part Name**	**Classic Part Number**
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
236-6271	Bearing-Sleeve	360-2324

BZP		
Original Part Number	**Part Name**	**Classic Part Number**
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CWN		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2395	Bearing-Sleeve	314-8646
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729

CWN		
Original Part Number	**Part Name**	**Classic Part Number**
125-2950	Gear As	301-4762
128-9863	Bearing-Sleeve	314-8630
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8950	Plate	399-8587
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295

CWN		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CXY		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771

CXY		
Original Part Number	**Part Name**	**Classic Part Number**
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571

CXY		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659

Sales Model 320D (Cont'd.)

CXY		
Original Part Number	Part Name	Classic Part Number
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762

CXY		
Original Part Number	Part Name	Classic Part Number
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

CXY		
Original Part Number	Part Name	Classic Part Number
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CY2		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
8W-8512	Pin As	385-7220
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

CY2		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
129-7768	Bearing-Sleeve	360-2316
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
236-6271	Bearing-Sleeve	360-2324

CY2		
Original Part Number	Part Name	Classic Part Number
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CYZ		
Original Part Number	Part Name	Classic Part Number
3W-8409	Bearing	398-8336
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
8G-0935	Cap	425-3584
8W-8512	Pin As	385-7220
8Y-1853	Strip	428-7633

CYZ		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

CYZ		
Original Part Number	Part Name	Classic Part Number
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320D (Cont'd.)

DFB		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

DFB		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
134-8950	Plate	399-8587
137-2820	Bearing-Sleeve	360-2318
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

DFB		
Original Part Number	Part Name	Classic Part Number
227-6789	Bearing-Sleeve	360-2322
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DFM		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

DFM		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

DFM		
Original Part Number	Part Name	Classic Part Number
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DFT		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-0078	Bearing-Sleeve	308-9825
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729

DFT		
Original Part Number	Part Name	Classic Part Number
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762

DFT		
Original Part Number	Part Name	Classic Part Number
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274

Sales Model 320D (Cont'd.)

DFT		
Original Part Number	Part Name	Classic Part Number
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969

DFT		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273

DFT		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DHE		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

DHE		
Original Part Number	Part Name	Classic Part Number
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

DHE		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DHK		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2357	Pin	301-4564
7Y-2396	Bearing-Sleeve	314-8634
7Y-4666	Bearing-Sleeve	314-8636
7Y-5131	Bearing-Sleeve	301-4626
086-0523	Pin	314-8696

DHK		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
134-8950	Plate	399-8587
137-8479	Spacer	395-1323
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200

DHK		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DNP		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268

Sales Model 320D (Cont'd.)

DNP		
Original Part Number	Part Name	Classic Part Number
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

DNP		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274

DNP		
Original Part Number	Part Name	Classic Part Number
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

EAL		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0523	Pin	314-8696
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

EAL		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274

EAL		
Original Part Number	Part Name	Classic Part Number
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

EAX		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-1644	Gear-Planet	301-3406
8W-8512	Pin As	385-7220
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

EAX		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
148-4634	Shaft-Planet	360-2274
179-3008	Cylinder	480-8272
199-4582	Bearing-Needle	388-6589

EAX		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

EBT		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771

EBT		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571

EBT		
Original Part Number	Part Name	Classic Part Number
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659

Sales Model 320D (Cont'd.)

EBT		
Original Part Number	Part Name	Classic Part Number
7Y-1644	Gear-Planet	301-3406
7Y-5131	Bearing-Sleeve	301-4626
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
134-8950	Plate	399-8587

EBT		
Original Part Number	Part Name	Classic Part Number
137-2820	Bearing-Sleeve	360-2318
137-8479	Spacer	395-1323
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275

EBT		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

EBY		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2396	Bearing-Sleeve	314-8634
7Y-5131	Bearing-Sleeve	301-4626
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729

EBY		
Original Part Number	Part Name	Classic Part Number
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8950	Plate	399-8587
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343

EBY		
Original Part Number	Part Name	Classic Part Number
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

EJT		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625

EJT		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967

EJT		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588

Sales Model 320D (Cont'd.)

EJT		
Original Part Number	**Part Name**	**Classic Part Number**
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

EJT		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969

EJT		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

EKT		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

EKT		
Original Part Number	**Part Name**	**Classic Part Number**
117-5553	Guard As-Tck Gde	419-4729
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274

EKT		
Original Part Number	**Part Name**	**Classic Part Number**
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

FAL		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

FAL		
Original Part Number	**Part Name**	**Classic Part Number**
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

FAL		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

FKK		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268

Sales Model 320D (Cont'd.)

FKK		
Original Part Number	Part Name	Classic Part Number
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

FKK		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274

FKK		
Original Part Number	Part Name	Classic Part Number
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

FNA		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2395	Bearing-Sleeve	314-8646
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046

FNA		
Original Part Number	Part Name	Classic Part Number
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
128-9863	Bearing-Sleeve	314-8630
128-9884	Bearing-Sleeve	360-2315
134-8948	Plate	399-8588
134-8950	Plate	399-8587
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
192-8318	Bearing-Sleeve	360-2321

FNA		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

FXK		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625

FXK		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659

FXK		
Original Part Number	Part Name	Classic Part Number
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046

Sales Model 320D (Cont'd.)

FXK		
Original Part Number	Part Name	Classic Part Number
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505

FXK		
Original Part Number	Part Name	Classic Part Number
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274

FXK		
Original Part Number	Part Name	Classic Part Number
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GBA		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

GBA		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

GBA		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GDP		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
086-0523	Pin	314-8696

GDP		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200

GDP		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351

Sales Model 320D (Cont'd.)

GDP		
Original Part Number	Part Name	Classic Part Number
314-8717	Shaft-Cla	360-2273

GDP		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348

GDP		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292

GKL		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046

GKL		
Original Part Number	Part Name	Classic Part Number
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

GKL		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GKS		
Original Part Number	Part Name	Classic Part Number
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-1644	Gear-Planet	301-3406
8W-8512	Pin As	385-7220
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

GKS		
Original Part Number	Part Name	Classic Part Number
125-2950	Gear As	301-4762
128-9884	Bearing-Sleeve	360-2315
137-2819	Bearing-Sleeve	360-2317
148-4634	Shaft-Planet	360-2274
179-3008	Cylinder	480-8272

GKS		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GMX		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

GMX		
Original Part Number	Part Name	Classic Part Number
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

GMX		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320D (Cont'd.)

HDM		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0523	Pin	314-8696
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

HDM		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

HDM		
Original Part Number	**Part Name**	**Classic Part Number**
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

HJC		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

HJC		
Original Part Number	**Part Name**	**Classic Part Number**
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

HJC		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JFM		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0523	Pin	314-8696
087-5805	Pin	301-7967

JFM		
Original Part Number	**Part Name**	**Classic Part Number**
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
134-8948	Plate	399-8588
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

JFM		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320D (Cont'd.)

JFZ		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

JFZ		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

JFZ		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JGZ		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815

JGZ		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

JGZ		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JPD		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659

JPD		
Original Part Number	Part Name	Classic Part Number
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271

JPD		
Original Part Number	Part Name	Classic Part Number
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275

Sales Model 320D (Cont'd.)

JPD		
Original Part Number	**Part Name**	**Classic Part Number**
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

JPD		
Original Part Number	**Part Name**	**Classic Part Number**
240-2915	Bearing-Sleeve	360-2326
314-8717	Shaft-Cla	360-2273

JPD		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JZA		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2040	Muffler As	301-7975
087-5805	Pin	301-7967

JZA		
Original Part Number	**Part Name**	**Classic Part Number**
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

JZA		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KAF		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2395	Bearing-Sleeve	314-8646
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648

KAF		
Original Part Number	**Part Name**	**Classic Part Number**
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
128-9863	Bearing-Sleeve	314-8630
128-9884	Bearing-Sleeve	360-2315
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589

KAF		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
236-6269	Bearing-Sleeve	453-6500
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320D (Cont'd.)

KBS		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

KBS		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

KBS		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KGF		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

KGF		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322

KGF		
Original Part Number	Part Name	Classic Part Number
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KHN		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571

KHN		
Original Part Number	Part Name	Classic Part Number
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

KHN		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316

Sales Model 320D (Cont'd.)

KHN		
Original Part Number	**Part Name**	**Classic Part Number**
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

KHN		
Original Part Number	**Part Name**	**Classic Part Number**
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969

KHN		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KHR		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0523	Pin	314-8696
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

KHR		
Original Part Number	**Part Name**	**Classic Part Number**
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322

KHR		
Original Part Number	**Part Name**	**Classic Part Number**
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KLM		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967

KLM		
Original Part Number	**Part Name**	**Classic Part Number**
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200

KTF		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268

KLM		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320D (Cont'd.)

KTF		
Original Part Number	Part Name	Classic Part Number
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

KTF		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

KTF		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KZF		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2040	Muffler As	301-7975
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

KZF		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322

KZF		
Original Part Number	Part Name	Classic Part Number
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LCA		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522

LCA		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274

LCA		
Original Part Number	Part Name	Classic Part Number
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

Sales Model 320D (Cont'd.)

LCA		
Original Part Number	**Part Name**	**Classic Part Number**
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273

LCA		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LMA		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967

LMA		
Original Part Number	**Part Name**	**Classic Part Number**
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

LMA		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MCH		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

MCH		
Original Part Number	**Part Name**	**Classic Part Number**
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589

MCH		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MDE		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222

MDE		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729

MDE		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
086-0523	Pin	314-8696

Sales Model 320D (Cont'd.)

MDE		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316

MDE		
Original Part Number	Part Name	Classic Part Number
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6271	Bearing-Sleeve	360-2324

MDE		
Original Part Number	Part Name	Classic Part Number
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MDJ		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815

MDJ		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

MDJ		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MGG		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5805	Pin	301-7967

MGG		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200

MGG		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273

Sales Model 320D (Cont'd.)

MGG		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348

MGG		
Original Part Number	**Part Name**	**Classic Part Number**
357-7540	Valve-Fill	360-2292

MZD		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2040	Muffler As	301-7975
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

MZD		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

MZD		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

NBF		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967

NBF		
Original Part Number	**Part Name**	**Classic Part Number**
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

NBF		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

NBH		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406

NBH		
Original Part Number	**Part Name**	**Classic Part Number**
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200

NBH		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

Sales Model 320D (Cont'd.)

NBH		
Original Part Number	Part Name	Classic Part Number
314-8717	Shaft-Cla	360-2273

NBH		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348

NBH		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292

NBT		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967

NBT		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

NBT		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PBB		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0523	Pin	314-8696
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

PBB		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

PBB		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PCM		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571

PCM		
Original Part Number	Part Name	Classic Part Number
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

PCM		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588

Sales Model 320D (Cont'd.)

PCM		
Original Part Number	**Part Name**	**Classic Part Number**
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

PCM		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969

PCM		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PCX		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0523	Pin	314-8696
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

PCX		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322

PCX		
Original Part Number	**Part Name**	**Classic Part Number**
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PHX		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

PHX		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589

PHX		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320D (Cont'd.)

RAR		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5805	Pin	301-7967

RAR		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

RAR		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RBL		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762

RBL		
Original Part Number	Part Name	Classic Part Number
134-8948	Plate	399-8588
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322

RBL		
Original Part Number	Part Name	Classic Part Number
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RDZ		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
087-5805	Pin	301-7967
114-1398	Gauge-Oil Level	394-9815

RDZ		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
134-8948	Plate	399-8588
145-3037	Support	480-8271
227-6228	Cage	360-2343

RDZ		
Original Part Number	Part Name	Classic Part Number
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969

Sales Model 320D (Cont'd.)

RDZ		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325

RDZ		
Original Part Number	Part Name	Classic Part Number
240-2915	Bearing-Sleeve	360-2326

RDZ		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292

SCW		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047

SCW		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
137-2820	Bearing-Sleeve	360-2318
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322

SCW		
Original Part Number	Part Name	Classic Part Number
236-6269	Bearing-Sleeve	453-6500
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SDZ		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967

SDZ		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

SDZ		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SFW		
Original Part Number	Part Name	Classic Part Number
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671

SFW		
Original Part Number	Part Name	Classic Part Number
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
094-1509	Shaft-Planet	360-2273

SFW		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729

Sales Model 320D (Cont'd.)

SFW		
Original Part Number	Part Name	Classic Part Number
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

SFW		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
314-8717	Shaft-Cla	360-2273

SFW		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SNS		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

SNS		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
134-8950	Plate	399-8587
137-2820	Bearing-Sleeve	360-2318
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

SNS		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SPN		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5805	Pin	301-7967

SPN		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

SPN		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320D (Cont'd.)

SRT		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-1644	Gear-Planet	301-3406
8W-8512	Pin As	385-7220
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729

SRT		
Original Part Number	**Part Name**	**Classic Part Number**
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
179-3008	Cylinder	480-8272
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
236-6271	Bearing-Sleeve	360-2324

SRT		
Original Part Number	**Part Name**	**Classic Part Number**
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

STN		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
087-5805	Pin	301-7967
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729

STN		
Original Part Number	**Part Name**	**Classic Part Number**
134-8948	Plate	399-8588
145-3037	Support	480-8271
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275

STN		
Original Part Number	**Part Name**	**Classic Part Number**
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
357-7540	Valve-Fill	360-2292

TAE		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

TAE		
Original Part Number	**Part Name**	**Classic Part Number**
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

TAE		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TDH		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771

TDH		
Original Part Number	**Part Name**	**Classic Part Number**
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336

TDH		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671

Sales Model 320D (Cont'd.)

TDH		
Original Part Number	Part Name	Classic Part Number
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762

TDH		
Original Part Number	Part Name	Classic Part Number
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
239-4378	Support	480-8274

TDH		
Original Part Number	Part Name	Classic Part Number
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TDN		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5805	Pin	301-7967

TDN		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

TDN		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TMF		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729

TMF		
Original Part Number	Part Name	Classic Part Number
119-2863	Pin	314-8698
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
236-6271	Bearing-Sleeve	360-2324

TMF		
Original Part Number	Part Name	Classic Part Number
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320D (Cont'd.)

WBF		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5805	Pin	301-7967

WBF		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

WBF		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WBN		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273

WBN		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

WBN		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WJN		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659

WJN		
Original Part Number	Part Name	Classic Part Number
7Y-1644	Gear-Planet	301-3406
7Y-2395	Bearing-Sleeve	314-8646
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967

WJN		
Original Part Number	Part Name	Classic Part Number
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
128-9863	Bearing-Sleeve	314-8630
128-9884	Bearing-Sleeve	360-2315

Sales Model 320D (Cont'd.)

WJN		
Original Part Number	Part Name	Classic Part Number
134-8948	Plate	399-8588
134-8950	Plate	399-8587
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
192-8318	Bearing-Sleeve	360-2321

WJN		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6269	Bearing-Sleeve	453-6500
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

WJN		
Original Part Number	Part Name	Classic Part Number
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

XAK		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

XAK		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

XAK		
Original Part Number	Part Name	Classic Part Number
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

XBB		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-0078	Bearing-Sleeve	308-9825
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-3549	Pin	360-2349
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

XBB		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

XBB		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320D (Cont'd.)

XCK		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2396	Bearing-Sleeve	314-8634
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

XCK		
Original Part Number	Part Name	Classic Part Number
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
137-8479	Spacer	395-1323
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

XCK		
Original Part Number	Part Name	Classic Part Number
227-6789	Bearing-Sleeve	360-2322
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

YBE		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

YBE		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

YBE		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

YDS		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

YDS		
Original Part Number	Part Name	Classic Part Number
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

YDS		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320D (Cont'd.)

YEA		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5805	Pin	301-7967

YEA		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

YEA		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ZBD		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0523	Pin	314-8696
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

ZBD		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

ZBD		
Original Part Number	Part Name	Classic Part Number
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ZBH		
Original Part Number	Part Name	Classic Part Number
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
094-1509	Shaft-Planet	360-2273

ZBH		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

ZBH		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320D (Cont'd.)

ZCS		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5805	Pin	301-7967

ZCS		
Original Part Number	**Part Name**	**Classic Part Number**
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

ZCS		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ZGB		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046

ZGB		
Original Part Number	**Part Name**	**Classic Part Number**
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

ZGB		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320E

AWS		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729

AWS		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274

AWS		
Original Part Number	**Part Name**	**Classic Part Number**
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275

Sales Model 320E (Cont'd.)

AWS		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

AWS		
Original Part Number	Part Name	Classic Part Number
240-2915	Bearing-Sleeve	360-2326
314-8717	Shaft-Cla	360-2273

AWS		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DFG		
Original Part NumberDFG	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2396	Bearing-Sleeve	314-8634
087-5533	Bearing-Sleeve	314-8628

DFG		
Original Part NumberDFG	Part Name	Classic Part Number
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

DFG		
Original Part NumberDFG	Part Name	Classic Part Number
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KLT		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5533	Bearing-Sleeve	314-8628

KLT		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

KLT		
Original Part Number	Part Name	Classic Part Number
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LAK		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336

LAK		
Original Part Number	Part Name	Classic Part Number
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729

LAK		
Original Part Number	Part Name	Classic Part Number
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
086-0523	Pin	314-8696

Sales Model 320E (Cont'd.)

LAK		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200

LAK		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969

LAK		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LHN		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2396	Bearing-Sleeve	314-8634
087-5805	Pin	301-7967

LHN		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274

LHN		
Original Part Number	Part Name	Classic Part Number
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MEW		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
134-8948	Plate	399-8588

MEW		
Original Part Number	Part Name	Classic Part Number
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275

MEW		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

NAZ		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771

NAZ		
Original Part Number	Part Name	Classic Part Number
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625

NAZ		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729

Sales Model 320E (Cont'd.)

NAZ		
Original Part Number	Part Name	Classic Part Number
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698

NAZ		
Original Part Number	Part Name	Classic Part Number
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275

NAZ		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PNL		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2396	Bearing-Sleeve	314-8634
087-5805	Pin	301-7967

PNL		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
119-2863	Pin	314-8698
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274

PNL		
Original Part Number	Part Name	Classic Part Number
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

REE		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522

REE		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

SHX		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268

REE		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320E (Cont'd.)

SHX		
Original Part Number	Part Name	Classic Part Number
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

SHX		
Original Part Number	Part Name	Classic Part Number
119-2863	Pin	314-8698
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275

SHX		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SXE		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406

SXE		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

SXE		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TEX		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522

TEX		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

TEX		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320E (Cont'd.)

TFX		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-5131	Bearing-Sleeve	301-4626

TFX		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
119-2863	Pin	314-8698
134-8948	Plate	399-8588
137-8479	Spacer	395-1323
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

TFX		
Original Part Number	Part Name	Classic Part Number
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TNJ		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-5131	Bearing-Sleeve	301-4626

TNJ		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698
134-8948	Plate	399-8588
137-8479	Spacer	395-1323
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

TNJ		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WBK		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-5131	Bearing-Sleeve	301-4626
086-0414	Flange	392-4522

WBK		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698
134-8948	Plate	399-8588
137-8479	Spacer	395-1323
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

WBK		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320F

ELD		
Original Part Number	**Part Name**	**Classic Part Number**
086-0414	Flange	392-4522
134-8948	Plate	399-8588

FGX		
Original Part Number	**Part Name**	**Classic Part Number**
086-0414	Flange	392-4522
134-8948	Plate	399-8588

GKR		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
086-0414	Flange	392-4522
087-5805	Pin	301-7967

GKR		
Original Part Number	**Part Name**	**Classic Part Number**
119-2863	Pin	314-8698
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

HKN		
Original Part Number	**Part Name**	**Classic Part Number**
086-0414	Flange	392-4522

HKN		
Original Part Number	**Part Name**	**Classic Part Number**
240-2912	Bearing-Sleeve	418-1969
244-8504	Pin As	426-0032

NHD		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

NHD		
Original Part Number	**Part Name**	**Classic Part Number**
119-2863	Pin	314-8698
121-7746	Pre-Cleaner As	360-2311
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274

NHD		
Original Part Number	**Part Name**	**Classic Part Number**
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

REW		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

REW		
Original Part Number	**Part Name**	**Classic Part Number**
121-7746	Pre-Cleaner As	360-2311
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274

REW		
Original Part Number	**Part Name**	**Classic Part Number**
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320F (Cont'd.)

SFX		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

SFX		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

SFX		
Original Part Number	Part Name	Classic Part Number
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TET		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

TET		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

TET		
Original Part Number	Part Name	Classic Part Number
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WJJ		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

WJJ		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

WJJ		
Original Part Number	Part Name	Classic Part Number
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

XCB		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522

XCB		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
244-8504	Pin As	426-0032

YBM		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522

YBM		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698

YBM		
Original Part Number	Part Name	Classic Part Number
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
199-4582	Bearing-Needle	388-6589

Sales Model 320F (Cont'd.)

YBM		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275

YBM		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

YBM		
Original Part Number	Part Name	Classic Part Number
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ZRC		
Original Part Number	Part Name	Classic Part Number
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

ZRC		
Original Part Number	Part Name	Classic Part Number
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274

ZRC		
Original Part Number	Part Name	Classic Part Number
239-4390	Recoil Gp-Adj&-A	480-8275
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 320S

6KM		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5C-5837	Retainer-Pin	299-2047
5I-8628	Plate-Valve	301-4771
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066

6KM		
Original Part Number	Part Name	Classic Part Number
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7K-5448	Cup-Bearing	415-1922
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759

6KM		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1563	Gear Gp-Brg	385-3776
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654
7Y-1775	Shaft-Pinion	314-8718
7Y-2040	Muffler As	301-7975
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556

Sales Model 320S (Cont'd.)

6KM		
Original Part Number	Part Name	Classic Part Number
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-4666	Bearing-Sleeve	314-8636
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9V-0247	Plate	417-4527
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273

6KM		
Original Part Number	Part Name	Classic Part Number
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505

6KM		
Original Part Number	Part Name	Classic Part Number
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 321B

9CZ		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628

Sales Model 321B (Cont'd.)

9CZ		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967

9CZ		
Original Part Number	Part Name	Classic Part Number
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
107-2139	Pin As.	360-2352
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
127-5970	Gear-Planet	301-3398
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8949	Plate	383-2110
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445

9CZ		
Original Part Number	Part Name	Classic Part Number
145-3037	Support	480-8271
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

AKG		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771

AKG		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406

AKG		
Original Part Number	Part Name	Classic Part Number
7Y-1646	Shaft-Planet	301-4624
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3428	Bearing-Sleeve	314-8647

Sales Model 321B (Cont'd.)

AKG		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
107-2139	Pin As.	360-2352
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400

AKG		
Original Part Number	Part Name	Classic Part Number
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
127-5970	Gear-Planet	301-3398
128-9882	Bearing-Sleeve	314-8642
133-2437	Link	377-6199
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322

AKG		
Original Part Number	Part Name	Classic Part Number
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KGA		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1772	Cage	374-3500
7Y-1775	Shaft-Pinion	314-8718

KGA		
Original Part Number	Part Name	Classic Part Number
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679

KGA		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
127-5970	Gear-Planet	301-3398
128-9882	Bearing-Sleeve	314-8642
133-2437	Link	377-6199
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200

Sales Model 321B (Cont'd.)

KGA		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500

KGA		
Original Part Number	Part Name	Classic Part Number
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

KGA		
Original Part Number	Part Name	Classic Part Number
244-8504	Pin As	426-0032
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 321C

DAX		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273

DAX		
Original Part Number	Part Name	Classic Part Number
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560

DAX		
Original Part Number	Part Name	Classic Part Number
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
250-2402	Pin As	360-2351
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KBB		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331

Sales Model 321C (Cont'd.)

KBB		
Original Part Number	Part Name	Classic Part Number
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047

KBB		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644

KBB		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
250-2402	Pin As	360-2351
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KCR		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964

KCR		
Original Part Number	Part Name	Classic Part Number
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
133-2437	Link	377-6199
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319

KCR		
Original Part Number	Part Name	Classic Part Number
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500

Sales Model 321C (Cont'd.)

KCR		
Original Part Number	Part Name	Classic Part Number
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969

KCR		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032

KCR		
Original Part Number	Part Name	Classic Part Number
250-2402	Pin As	360-2351
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MCF		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273

MCF		
Original Part Number	Part Name	Classic Part Number
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
119-2863	Pin	314-8698
122-5076	Rod	301-4569
125-2950	Gear As	301-4762
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
191-3235	Housing-Sprocket	394-0200

MCF		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 321D

JCX		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571

JCX		
Original Part Number	Part Name	Classic Part Number
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047

JCX		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274

Sales Model 321D (Cont'd.)

JCX		
Original Part Number	Part Name	Classic Part Number
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274

JCX		
Original Part Number	Part Name	Classic Part Number
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

JCX		
Original Part Number	Part Name	Classic Part Number
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KBH		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
087-5805	Pin	301-7967
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729

KBH		
Original Part Number	Part Name	Classic Part Number
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589

KBH		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6270	Bearing-Sleeve	425-6436
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
250-2402	Pin As	360-2351
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KBZ		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

KBZ		
Original Part Number	Part Name	Classic Part Number
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

KBZ		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 321D (Cont'd.)

MDT		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

MDT		
Original Part Number	Part Name	Classic Part Number
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

MDT		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MPG		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

MPG		
Original Part Number	Part Name	Classic Part Number
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

MPG		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

NAS		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

NAS		
Original Part Number	Part Name	Classic Part Number
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

NAS		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 321D (Cont'd.)

PBD		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729

PBD		
Original Part Number	Part Name	Classic Part Number
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6271	Bearing-Sleeve	360-2324

PBD		
Original Part Number	Part Name	Classic Part Number
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TXA		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967

TXA		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

TXA		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 321F

TZY		
Original Part Number	Part Name	Classic Part Number
4I-4812	Pin As	480-8269
7Y-1644	Gear-Planet	301-3406
094-1509	Shaft-Planet	360-2273
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274

TZY		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275

TZY		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
357-7540	Valve-Fill	360-2292

Sales Model 321F (Cont'd.)

WKA		
Original Part Number	Part Name	Classic Part Number
4I-4812	Pin As	480-8269
7Y-1644	Gear-Planet	301-3406
094-1509	Shaft-Planet	360-2273
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274

WKA		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275

WKA		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ZDH		
Original Part Number	Part Name	Classic Part Number
4I-4812	Pin As	480-8269
7Y-1644	Gear-Planet	301-3406
094-1509	Shaft-Planet	360-2273
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274

ZDH		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275

ZDH		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 322

4RM		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

4RM		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7I-7712	Cylinder	393-1019
7I-7713	Rod	391-9873
7I-7714	Piston As	422-9530
7I-7717	Spring	392-4525
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659

4RM		
Original Part Number	Part Name	Classic Part Number
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2040	Muffler As	301-7975
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266

Sales Model 322 (Cont'd.)

4RM		
Original Part Number	Part Name	Classic Part Number
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349

4RM		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505

4RM		
Original Part Number	Part Name	Classic Part Number
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
264-6898	Kit-Gasket-Sch	382-5069
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

7WL		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922

7WL		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513

7WL		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673

Sales Model 322 (Cont'd.)

7WL		
Original Part Number	Part Name	Classic Part Number
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7I-7712	Cylinder	393-1019
7I-7713	Rod	391-9873
7I-7714	Piston As	422-9530
7I-7717	Spring	392-4525
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2040	Muffler As	301-7975
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433

7WL		
Original Part Number	Part Name	Classic Part Number
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
096-7913	Bearing-Sleeve	314-8655
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437

7WL		
Original Part Number	Part Name	Classic Part Number
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
264-6898	Kit-Gasket-Sch	382-5069

Sales Model 322 (Cont'd.)

7WL		
Original Part Number	Part Name	Classic Part Number
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348

7WL		
Original Part Number	Part Name	Classic Part Number
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

7WL		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

8CL		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7I-7712	Cylinder	393-1019
7I-7713	Rod	391-9873
7I-7714	Piston As	422-9530
7I-7717	Spring	392-4525
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545

8CL		
Original Part Number	Part Name	Classic Part Number
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2040	Muffler As	301-7975
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6607	Bearing	372-7508
7Y-6626	Bearing	314-8650
8C-3111	Rod End-Spher	392-4523

8CL		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
096-7913	Bearing-Sleeve	314-8655
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437

Sales Model 322 (Cont'd.)

8CL		
Original Part Number	Part Name	Classic Part Number
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388

8CL		
Original Part Number	Part Name	Classic Part Number
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370

8CL		
Original Part Number	Part Name	Classic Part Number
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
264-6898	Kit-Gasket-Sch	382-5069
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

8ML		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

8ML		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7I-7712	Cylinder	393-1019
7I-7713	Rod	391-9873
7I-7714	Piston As	422-9530
7I-7717	Spring	392-4525
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659

8ML		
Original Part Number	Part Name	Classic Part Number
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2040	Muffler As	301-7975
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266

Sales Model 322 (Cont'd.)

8ML		
Original Part Number	Part Name	Classic Part Number
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349

8ML		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505

8ML		
Original Part Number	Part Name	Classic Part Number
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
264-6898	Kit-Gasket-Sch	382-5069
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

9JL		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922

9JL		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513

9JL		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673

Sales Model 322 (Cont'd.)

9JL		
Original Part Number	Part Name	Classic Part Number
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7I-7712	Cylinder	393-1019
7I-7713	Rod	391-9873
7I-7714	Piston As	422-9530
7I-7717	Spring	392-4525
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2040	Muffler As	301-7975
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375

9JL		
Original Part Number	Part Name	Classic Part Number
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
128-9863	Bearing-Sleeve	314-8630

9JL		
Original Part Number	Part Name	Classic Part Number
128-9864	Bearing-Sleeve	425-6437
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317

Sales Model 322 (Cont'd.)

9JL		
Original Part Number	Part Name	Classic Part Number
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
264-6898	Kit-Gasket-Sch	382-5069
271-5658	Crankshaft As.	368-5912

9JL		
Original Part Number	Part Name	Classic Part Number
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107

9JL		
Original Part Number	Part Name	Classic Part Number
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

9RL		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1T-0210	Bearing-Ball	417-4498
1W-1064	Gear-Flywheel	374-4703
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2K-6413	Pin	360-2270
2N-1599	Gear	378-3970
2P-4611	Pipe-Exhaust	365-8821
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4665	Bearing-Sleeve	364-5267
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6I-1099	Manifold-Exh	424-6366
6V-2202	Bearing-Spl Ball	380-1574
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

9RL		
Original Part Number	Part Name	Classic Part Number
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7I-7712	Cylinder	393-1019
7I-7713	Rod	391-9873
7I-7714	Piston As	422-9530
7I-7717	Spring	392-4525
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2040	Muffler As	301-7975

9RL		
Original Part Number	Part Name	Classic Part Number
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3551	Bearing-Sleeve	380-7375
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9M-3914	Bearing-Aligning	420-2501
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983

Sales Model 322 (Cont'd.)

9RL		
Original Part Number	**Part Name**	**Classic Part Number**
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316

9RL		
Original Part Number	**Part Name**	**Classic Part Number**
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295

9RL		
Original Part Number	**Part Name**	**Classic Part Number**
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
264-6898	Kit-Gasket-Sch	382-5069
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 322B

1AS		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3G-5285	Bearing-Sleeve	360-2312
4I-0453	Bearing-Sleeve	360-2331

1AS		
Original Part Number	**Part Name**	**Classic Part Number**
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6E-4985	Cover-Filter	424-2015
6I-1099	Manifold-Exh	424-6366

1AS		
Original Part Number	**Part Name**	**Classic Part Number**
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025

Sales Model 322B (Cont'd.)

1AS		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7I-7712	Cylinder	393-1019
7I-7713	Rod	391-9873
7I-7714	Piston As	422-9530
7I-7717	Spring	392-4525
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-3551	Bearing-Sleeve	380-7375
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-5131	Bearing-Sleeve	301-4626
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5805	Pin	301-7967
087-5978	Flange	374-3496

1AS		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
106-6878	Pin	372-7510
107-7708	Bearing-Main	419-6381
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587

1AS		
Original Part Number	Part Name	Classic Part Number
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
191-3235	Housing-Sprocket	394-0200
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
244-8504	Pin As	426-0032
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

1YS		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-6413	Pin	360-2270
2N-1599	Gear	378-3970

1YS		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332

1YS		
Original Part Number	Part Name	Classic Part Number
4I-4619	Pin As	425-2564
4I-7401	Spring	380-7414
4K-0299	Bearing-Sleeve	308-9816
4K-0300	Bearing-Sleeve	308-9817

Sales Model 322B (Cont'd.)

1YS		
Original Part Number	Part Name	Classic Part Number
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
6Y-9930	Mount As	360-2353
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7I-7712	Cylinder	393-1019
7I-7713	Rod	391-9873
7I-7714	Piston As	422-9530
7I-7717	Spring	392-4525
7K-0078	Bearing-Sleeve	308-9825
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0207	Cylinder	383-1584
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1258	Piston	367-6091
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729

1YS		
Original Part Number	Part Name	Classic Part Number
7Y-1432	Carrier-Planet	314-8659
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1738	Support	443-5198
7Y-2395	Bearing-Sleeve	314-8646
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6607	Bearing	372-7508
7Y-6626	Bearing	314-8650
8S-0248	Breather As	325-6033
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641

1YS		
Original Part Number	Part Name	Classic Part Number
099-0722	Link As	415-1909
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5435	Pin As	393-0934
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
118-5196	Pin	380-7397
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110

Sales Model 322B (Cont'd.)

1YS		
Original Part Number	Part Name	Classic Part Number
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
188-4211	Cylinder As	425-9366
191-3118	Cyl Gp-0170 1680	399-8560

1YS		
Original Part Number	Part Name	Classic Part Number
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436

1YS		
Original Part Number	Part Name	Classic Part Number
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
289-7886	Rod As	422-7246
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

1ZS		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
6Y-9930	Mount As	360-2353
7C-3760	Tube As-O Drain	375-5443

1ZS		
Original Part Number	Part Name	Classic Part Number
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7I-7712	Cylinder	393-1019
7I-7713	Rod	391-9873
7I-7714	Piston As	422-9530
7I-7717	Spring	392-4525
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545

1ZS		
Original Part Number	Part Name	Classic Part Number
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289

Sales Model 322B (Cont'd.)

1ZS		
Original Part Number	Part Name	Classic Part Number
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8S-0248	Breather As	325-6033
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349

1ZS		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
186-5730	Pin	393-3688
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813

1ZS		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
191-3235	Housing-Sprocket	394-0200
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-7886	Rod As	422-7246
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 322B (Cont'd.)

2ES		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
6Y-9930	Mount As	360-2353
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7I-7712	Cylinder	393-1019
7I-7713	Rod	391-9873
7I-7714	Piston As	422-9530
7I-7717	Spring	392-4525
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659

2ES		
Original Part Number	Part Name	Classic Part Number
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8S-0248	Breather As	325-6033
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983

2ES		
Original Part Number	Part Name	Classic Part Number
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319

Sales Model 322B (Cont'd.)

2ES		
Original Part Number	**Part Name**	**Classic Part Number**
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
186-5730	Pin	393-3688
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
191-3235	Housing-Sprocket	394-0200

2ES		
Original Part Number	**Part Name**	**Classic Part Number**
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

2ES		
Original Part Number	**Part Name**	**Classic Part Number**
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-7886	Rod As	422-7246
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

3NR		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

3NR		
Original Part Number	**Part Name**	**Classic Part Number**
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7I-7712	Cylinder	393-1019
7I-7713	Rod	391-9873
7I-7714	Piston As	422-9530
7I-7717	Spring	392-4525
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1508	Muffler As	395-1303

3NR		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626

Sales Model 322B (Cont'd.)

3NR		
Original Part Number	Part Name	Classic Part Number
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5805	Pin	301-7967
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694

3NR		
Original Part Number	Part Name	Classic Part Number
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535

3NR		
Original Part Number	Part Name	Classic Part Number
191-3235	Housing-Sprocket	394-0200
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

5CR		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513

5CR		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449

5CR		
Original Part Number	Part Name	Classic Part Number
7I-7180	Piston	421-7142
7I-7712	Cylinder	393-1019
7I-7713	Rod	391-9873
7I-7714	Piston As	422-9530
7I-7717	Spring	392-4525
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545

Sales Model 322B (Cont'd.)

5CR		
Original Part Number	Part Name	Classic Part Number
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6607	Bearing	372-7508
7Y-6626	Bearing	314-8650
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0523	Pin	314-8696
087-5805	Pin	301-7967
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909

5CR		
Original Part Number	Part Name	Classic Part Number
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320
137-8479	Spacer	395-1323

5CR		
Original Part Number	Part Name	Classic Part Number
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
191-3235	Housing-Sprocket	394-0200
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 322B (Cont'd.)

8MR		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7I-7712	Cylinder	393-1019
7I-7713	Rod	391-9873
7I-7714	Piston As	422-9530
7I-7717	Spring	392-4525
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249

8MR		
Original Part Number	Part Name	Classic Part Number
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

8MR		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
191-3235	Housing-Sprocket	394-0200

Sales Model 322B (Cont'd.)

8MR		
Original Part Number	Part Name	Classic Part Number
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371

8MR		
Original Part Number	Part Name	Classic Part Number
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246

8MR		
Original Part Number	Part Name	Classic Part Number
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

8NR		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3G-5285	Bearing-Sleeve	360-2312
4I-0453	Bearing-Sleeve	360-2331
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7I-7712	Cylinder	393-1019
7I-7713	Rod	391-9873
7I-7714	Piston As	422-9530
7I-7717	Spring	392-4525

8NR		
Original Part Number	Part Name	Classic Part Number
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577

8NR		
Original Part Number	Part Name	Classic Part Number
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6607	Bearing	372-7508
7Y-6626	Bearing	314-8650
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
106-6878	Pin	372-7510
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9349	Mount-Rubber	384-3469

Sales Model 322B (Cont'd.)

8NR		
Original Part Number	Part Name	Classic Part Number
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
117-6270	Support As	434-1400
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9884	Bearing-Sleeve	360-2315
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587

8NR		
Original Part Number	Part Name	Classic Part Number
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320
137-8479	Spacer	395-1323
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
191-3235	Housing-Sprocket	394-0200
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644

8NR		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-7886	Rod As	422-7246
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 322C

ADX		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332

ADX		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5L-6326	Bearing-Ball	420-3222
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

ADX		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765

Sales Model 322C (Cont'd.)

ADX		
Original Part Number	Part Name	Classic Part Number
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698

ADX		
Original Part Number	Part Name	Classic Part Number
126-9461	Pin	392-4528
127-3467	Manifold-Exhaust	394-9827
128-9863	Bearing-Sleeve	314-8630
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
186-5730	Pin	393-3688
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321

ADX		
Original Part Number	Part Name	Classic Part Number
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BFK		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4N-2572	Spider As-Fan	451-9027

BFK		
Original Part Number	Part Name	Classic Part Number
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443

BFK		
Original Part Number	Part Name	Classic Part Number
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449

Sales Model 322C (Cont'd.)

BFK		
Original Part Number	Part Name	Classic Part Number
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5978	Flange	374-3496
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047

BFK		
Original Part Number	Part Name	Classic Part Number
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
186-5730	Pin	393-3688
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536

BFK		
Original Part Number	Part Name	Classic Part Number
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-7886	Rod As	422-7246
347-6081	Gauge As	360-2348
352-2153	Pump As-Water	433-0444
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BFN		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970

BFN		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332

BFN		
Original Part Number	Part Name	Classic Part Number
4N-2572	Spider As-Fan	451-9027
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603

Sales Model 322C (Cont'd.)

BFN		
Original Part Number	Part Name	Classic Part Number
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968

BFN		
Original Part Number	Part Name	Classic Part Number
087-5845	Pin	301-7969
087-5978	Flange	374-3496
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
119-2940	Gasket	378-4002
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
163-3749	Bearing-Sleeve	433-7505
188-4211	Cylinder As	425-9366

BFN		
Original Part Number	Part Name	Classic Part Number
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2153	Pump As-Water	433-0444
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BFX		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667

BFX		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4N-2572	Spider As-Fan	451-9027
4P-7790	Shaft As-Arm	457-4596

BFX		
Original Part Number	Part Name	Classic Part Number
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443

Sales Model 322C (Cont'd.)

BFX		
Original Part Number	Part Name	Classic Part Number
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496

BFX		
Original Part Number	Part Name	Classic Part Number
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
119-2940	Gasket	378-4002
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
163-3749	Bearing-Sleeve	433-7505
188-4211	Cylinder As	425-9366

BFX		
Original Part Number	Part Name	Classic Part Number
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2153	Pump As-Water	433-0444
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BGR		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4N-2572	Spider As-Fan	451-9027

BGR		
Original Part Number	Part Name	Classic Part Number
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443

BGR		
Original Part Number	Part Name	Classic Part Number
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449

Sales Model 322C (Cont'd.)

BGR		
Original Part Number	Part Name	Classic Part Number
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5978	Flange	374-3496
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047

BGR		
Original Part Number	Part Name	Classic Part Number
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
186-5730	Pin	393-3688
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536

BGR		
Original Part Number	Part Name	Classic Part Number
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-7886	Rod As	422-7246
347-6081	Gauge As	360-2348
352-2153	Pump As-Water	433-0444
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BKJ		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-6413	Pin	360-2270

BKJ		
Original Part Number	Part Name	Classic Part Number
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3W-8239	Sleeve-Wear	360-2342
4I-0704	Bearing-Sleeve	360-2332

BKJ		
Original Part Number	Part Name	Classic Part Number
4N-2572	Spider As-Fan	451-9027
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603

Sales Model 322C (Cont'd.)

BKJ		
Original Part Number	Part Name	Classic Part Number
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3553	Bearing-Sleeve	301-0433
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6607	Bearing	372-7508
7Y-6626	Bearing	314-8650
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
099-0718	Bearing-Sleeve	360-2313

BKJ		
Original Part Number	Part Name	Classic Part Number
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-9461	Pin	392-4528
128-9864	Bearing-Sleeve	425-6437
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

BKJ		
Original Part Number	Part Name	Classic Part Number
163-3749	Bearing-Sleeve	433-7505
186-5730	Pin	393-3688
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-7886	Rod As	422-7246
347-6081	Gauge As	360-2348
352-2153	Pump As-Water	433-0444
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 322C (Cont'd.)

BKM		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4N-2572	Spider As-Fan	451-9027
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3553	Bearing-Sleeve	301-0433
7Y-4666	Bearing-Sleeve	314-8636

BKM		
Original Part Number	Part Name	Classic Part Number
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6607	Bearing	372-7508
7Y-6626	Bearing	314-8650
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-9461	Pin	392-4528
128-9864	Bearing-Sleeve	425-6437
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199

BKM		
Original Part Number	Part Name	Classic Part Number
133-4995	Gasket-Cyl Head	434-2445
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
163-3749	Bearing-Sleeve	433-7505
186-5730	Pin	393-3688
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583

Sales Model 322C (Cont'd.)

BKM		
Original Part Number	Part Name	Classic Part Number
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

BKM		
Original Part Number	Part Name	Classic Part Number
289-7886	Rod As	422-7246
347-6081	Gauge As	360-2348
352-2153	Pump As-Water	433-0444

BKM		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BLP		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4N-2572	Spider As-Fan	451-9027
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350

BLP		
Original Part Number	Part Name	Classic Part Number
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-9461	Pin	392-4528
129-7768	Bearing-Sleeve	360-2316

BLP		
Original Part Number	Part Name	Classic Part Number
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
163-3749	Bearing-Sleeve	433-7505
186-5730	Pin	393-3688
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436

Sales Model 322C (Cont'd.)

BLP		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032

BLP		
Original Part Number	Part Name	Classic Part Number
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

BLP		
Original Part Number	Part Name	Classic Part Number
289-7886	Rod As	422-7246
347-6081	Gauge As	360-2348
352-2153	Pump As-Water	433-0444
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BMX		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4N-2572	Spider As-Fan	451-9027
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-3428	Bearing-Sleeve	314-8647

BMX		
Original Part Number	Part Name	Classic Part Number
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3553	Bearing-Sleeve	301-0433
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6607	Bearing	372-7508
7Y-6626	Bearing	314-8650
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491

BMX		
Original Part Number	Part Name	Classic Part Number
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
119-2940	Gasket	378-4002
128-9864	Bearing-Sleeve	425-6437
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
163-3749	Bearing-Sleeve	433-7505
186-5730	Pin	393-3688
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813

Sales Model 322C (Cont'd.)

BMX		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322

BMX		
Original Part Number	Part Name	Classic Part Number
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032

BMX		
Original Part Number	Part Name	Classic Part Number
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2153	Pump As-Water	433-0444
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BNY		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4N-2572	Spider As-Fan	451-9027
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551

BNY		
Original Part Number	Part Name	Classic Part Number
7W-4137	Shaft As.	378-3986
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692

BNY		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5553	Guard As-Tck Gde	419-4729
119-2940	Gasket	378-4002
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

Sales Model 322C (Cont'd.)

BNY		
Original Part Number	**Part Name**	**Classic Part Number**
163-3749	Bearing-Sleeve	433-7505
186-5730	Pin	393-3688
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870

BNY		
Original Part Number	**Part Name**	**Classic Part Number**
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

BNY		
Original Part Number	**Part Name**	**Classic Part Number**
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2153	Pump As-Water	433-0444
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BPH		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
1W-4369	Pulley-Alt	296-1340
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4N-2572	Spider As-Fan	451-9027
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986

BPH		
Original Part Number	**Part Name**	**Classic Part Number**
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5805	Pin	301-7967
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
129-7768	Bearing-Sleeve	360-2316
133-4995	Gasket-Cyl Head	434-2445

BPH		
Original Part Number	**Part Name**	**Classic Part Number**
136-0819	Valve-Exhaust	384-8697
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
186-5730	Pin	393-3688
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326

Sales Model 322C (Cont'd.)

BPH		
Original Part Number	Part Name	Classic Part Number
244-8504	Pin As	426-0032
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

BPH		
Original Part Number	Part Name	Classic Part Number
289-7886	Rod As	422-7246
347-6081	Gauge As	360-2348
352-2153	Pump As-Water	433-0444

BPH		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BTE		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5L-6326	Bearing-Ball	420-3222
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964

BTE		
Original Part Number	Part Name	Classic Part Number
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
099-0722	Link As	415-1909
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
126-9461	Pin	392-4528
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505

BTE		
Original Part Number	Part Name	Classic Part Number
186-5730	Pin	393-3688
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348

Sales Model 322C (Cont'd.)

BTE		
Original Part Number	**Part Name**	**Classic Part Number**
357-7540	Valve-Fill	360-2292

BTE		
Original Part Number	**Part Name**	**Classic Part Number**
441-9566	Gear-Flywheel	374-4703

BYL		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4I-4619	Pin As	425-2564
4K-0299	Bearing-Sleeve	308-9816
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7181	Piston	393-5217
7K-0078	Bearing-Sleeve	308-9825
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-0680	Piston	360-2262
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648

BYL		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-5131	Bearing-Sleeve	301-4626
8W-8512	Pin As	385-7220
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
118-5196	Pin	380-7397
127-3467	Manifold-Exhaust	394-9827
128-9863	Bearing-Sleeve	314-8630
128-9883	Bearing-Sleeve	360-2314
133-4995	Gasket-Cyl Head	434-2445
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318

BYL		
Original Part Number	**Part Name**	**Classic Part Number**
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
191-3118	Cyl Gp-0170 1680	399-8560
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6270	Bearing-Sleeve	425-6436
240-2915	Bearing-Sleeve	360-2326
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

C3R		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4I-4619	Pin As	425-2564
4K-0299	Bearing-Sleeve	308-9816
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673

C3R		
Original Part Number	**Part Name**	**Classic Part Number**
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7181	Piston	393-5217
7K-0078	Bearing-Sleeve	308-9825
7W-9027	Base-Oil Cooler	399-8545

C3R		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8W-8512	Pin As	385-7220
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381

Sales Model 322C (Cont'd.)

C3R		
Original Part Number	Part Name	Classic Part Number
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
118-5196	Pin	380-7397
127-3467	Manifold-Exhaust	394-9827
128-9863	Bearing-Sleeve	314-8630
128-9883	Bearing-Sleeve	360-2314
133-4995	Gasket-Cyl Head	434-2445

C3R		
Original Part Number	Part Name	Classic Part Number
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3044	Cylinder	385-6138
191-3118	Cyl Gp-0170 1680	399-8560
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371

C3R		
Original Part Number	Part Name	Classic Part Number
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6270	Bearing-Sleeve	425-6436
240-2915	Bearing-Sleeve	360-2326
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

CAM		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
1W-4369	Pulley-Alt	296-1340
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4N-2572	Spider As-Fan	451-9027
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7W-3773	Pulley-Cshaft	383-1583

CAM		
Original Part Number	Part Name	Classic Part Number
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-3553	Bearing-Sleeve	301-0433
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-6607	Bearing	372-7508
7Y-6626	Bearing	314-8650
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0523	Pin	314-8696
087-5805	Pin	301-7967
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692

CAM		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
128-9864	Bearing-Sleeve	425-6437
129-7768	Bearing-Sleeve	360-2316
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

Sales Model 322C (Cont'd.)

CAM		
Original Part Number	**Part Name**	**Classic Part Number**
163-3749	Bearing-Sleeve	433-7505
179-3044	Cylinder	385-6138
186-5730	Pin	393-3688
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370

CAM		
Original Part Number	**Part Name**	**Classic Part Number**
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032

CAM		
Original Part Number	**Part Name**	**Classic Part Number**
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-7886	Rod As	422-7246
347-6081	Gauge As	360-2348
352-2153	Pump As-Water	433-0444
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

CBY		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
1W-4369	Pulley-Alt	296-1340
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-4619	Pin As	425-2564
4K-0299	Bearing-Sleeve	308-9816
4K-0300	Bearing-Sleeve	308-9817
4N-2572	Spider As-Fan	451-9027
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7181	Piston	393-5217

CBY		
Original Part Number	**Part Name**	**Classic Part Number**
7K-0078	Bearing-Sleeve	308-9825
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5805	Pin	301-7967
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219

CBY		
Original Part Number	**Part Name**	**Classic Part Number**
115-4237	Pulley-Idler	374-4693
118-5196	Pin	380-7397
119-2940	Gasket	378-4002
128-9863	Bearing-Sleeve	314-8630
128-9883	Bearing-Sleeve	360-2314
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
179-3044	Cylinder	385-6138
191-3118	Cyl Gp-0170 1680	399-8560
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
240-2915	Bearing-Sleeve	360-2326
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912

Sales Model 322C (Cont'd.)

CBY		
Original Part Number	**Part Name**	**Classic Part Number**
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348

CBY		
Original Part Number	**Part Name**	**Classic Part Number**
352-2153	Pump As-Water	433-0444

CBY		
Original Part Number	**Part Name**	**Classic Part Number**
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

DAA		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5L-6326	Bearing-Ball	420-3222
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967

DAA		
Original Part Number	**Part Name**	**Classic Part Number**
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
126-9461	Pin	392-4528
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
186-5730	Pin	393-3688
188-4211	Cylinder As	425-9366

DAA		
Original Part Number	**Part Name**	**Classic Part Number**
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-7886	Rod As	422-7246
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 322C (Cont'd.)

EMR		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5L-6326	Bearing-Ball	420-3222
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969

EMR		
Original Part Number	Part Name	Classic Part Number
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
126-9461	Pin	392-4528
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
186-5652	Pin	392-4532
186-5662	Pin	421-1560
186-5730	Pin	393-3688
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813

EMR		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-7886	Rod As	422-7246
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

FED		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703

FED		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

Sales Model 322C (Cont'd.)

FED		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5L-6326	Bearing-Ball	420-3222
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496

FED		
Original Part Number	Part Name	Classic Part Number
099-0722	Link As	415-1909
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
126-9461	Pin	392-4528
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
179-3044	Cylinder	385-6138
186-5730	Pin	393-3688
188-4211	Cylinder As	425-9366

FED		
Original Part Number	Part Name	Classic Part Number
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-7886	Rod As	422-7246
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

HBG		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

HBG		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331

HBG		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5L-6326	Bearing-Ball	420-3222

Sales Model 322C (Cont'd.)

HBG		
Original Part Number	**Part Name**	**Classic Part Number**
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729

HBG		
Original Part Number	**Part Name**	**Classic Part Number**
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-4995	Gasket-Cyl Head	434-2445
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
186-5730	Pin	393-3688
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371

HBG		
Original Part Number	**Part Name**	**Classic Part Number**
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

HEK		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
3W-8239	Sleeve-Wear	360-2342
4I-0704	Bearing-Sleeve	360-2332
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7K-9592	Bearing-Sleeve	360-2336

HEK		
Original Part Number	**Part Name**	**Classic Part Number**
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3553	Bearing-Sleeve	301-0433
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6607	Bearing	372-7508
7Y-6626	Bearing	314-8650
9F-3212	Bearing-Ball	384-5953

HEK		
Original Part Number	**Part Name**	**Classic Part Number**
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

Sales Model 322C (Cont'd.)

HEK		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
126-9461	Pin	392-4528
127-3467	Manifold-Exhaust	394-9827
128-9864	Bearing-Sleeve	425-6437
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320

HEK		
Original Part Number	Part Name	Classic Part Number
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
186-5730	Pin	393-3688
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370

HEK		
Original Part Number	Part Name	Classic Part Number
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-7886	Rod As	422-7246
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

KCF		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5L-6326	Bearing-Ball	420-3222
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449

KCF		
Original Part Number	Part Name	Classic Part Number
7K-9592	Bearing-Sleeve	360-2336
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046

KCF		
Original Part Number	Part Name	Classic Part Number
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8948	Plate	399-8588
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-0162	Bearing-Main	419-6380

Sales Model 322C (Cont'd.)

KCF		
Original Part Number	**Part Name**	**Classic Part Number**
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
186-5730	Pin	393-3688
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322

KCF		
Original Part Number	**Part Name**	**Classic Part Number**
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

KCF		
Original Part Number	**Part Name**	**Classic Part Number**
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

LAR		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8W-8512	Pin As	385-7220
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491

LAR		
Original Part Number	**Part Name**	**Classic Part Number**
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-4995	Gasket-Cyl Head	434-2445
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
179-3044	Cylinder	385-6138
186-5730	Pin	393-3688
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870

LAR		
Original Part Number	**Part Name**	**Classic Part Number**
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-7886	Rod As	422-7246
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

M2H		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703

Sales Model 322C (Cont'd.)

M2H		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8W-8512	Pin As	385-7220
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046

M2H		
Original Part Number	Part Name	Classic Part Number
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-4995	Gasket-Cyl Head	434-2445
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
186-5730	Pin	393-3688
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295

M2H		
Original Part Number	Part Name	Classic Part Number
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-7886	Rod As	422-7246
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

MAR		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5L-6326	Bearing-Ball	420-3222
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449

MAR		
Original Part Number	Part Name	Classic Part Number
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368

MAR		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
099-0722	Link As	415-1909
101-1530	Bearing-Main	419-6382
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047

Sales Model 322C (Cont'd.)

MAR		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
126-9461	Pin	392-4528
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

MAR		
Original Part Number	Part Name	Classic Part Number
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
179-3044	Cylinder	385-6138
186-5652	Pin	392-4532
186-5662	Pin	421-1560
186-5730	Pin	393-3688
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

MAR		
Original Part Number	Part Name	Classic Part Number
236-4413	Pump Gp-Water -B	434-6110
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
250-2402	Pin As	360-2351
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-7886	Rod As	422-7246
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

SLX		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
1W-4369	Pulley-Alt	296-1340
2A-4429	Lock-Retainer	379-0174
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4K-0299	Bearing-Sleeve	308-9816
4N-2572	Spider As-Fan	451-9027
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443

SLX		
Original Part Number	Part Name	Classic Part Number
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7K-0078	Bearing-Sleeve	308-9825
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-0680	Piston	360-2262

SLX		
Original Part Number	Part Name	Classic Part Number
7Y-5102	Bearing-Sleeve	380-7368
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-3167	Pin As	418-9575
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

Sales Model 322C (Cont'd.)

SLX		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380

SLX		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

SLX		
Original Part Number	Part Name	Classic Part Number
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2153	Pump As-Water	433-0444
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 323D

BYM		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

BYM		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

BYM		
Original Part Number	Part Name	Classic Part Number
227-6789	Bearing-Sleeve	360-2322
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CWG		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659

CWG		
Original Part Number	Part Name	Classic Part Number
7Y-1644	Gear-Planet	301-3406
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762

CWG		
Original Part Number	Part Name	Classic Part Number
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

Sales Model 323D (Cont'd.)

CWG		
Original Part Number	**Part Name**	**Classic Part Number**
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275

CWG		
Original Part Number	**Part Name**	**Classic Part Number**
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

CWG		
Original Part Number	**Part Name**	**Classic Part Number**
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CYD		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815

CYD		
Original Part Number	**Part Name**	**Classic Part Number**
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322

CYD		
Original Part Number	**Part Name**	**Classic Part Number**
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DKW		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-1644	Gear-Planet	301-3406
7Y-2581	Guard As-Trk Gde	480-8270
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815

DKW		
Original Part Number	**Part Name**	**Classic Part Number**
117-5612	Pipe	398-2965
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8950	Plate	399-8587
148-4634	Shaft-Planet	360-2274
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

DKW		
Original Part Number	**Part Name**	**Classic Part Number**
227-6789	Bearing-Sleeve	360-2322
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 323D (Cont'd.)

GTF		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

GTF		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

GTF		
Original Part Number	Part Name	Classic Part Number
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JEG		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

JEG		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

JEG		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JLG		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628

JLG		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
099-0722	Link As	415-1909
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8950	Plate	399-8587

JLG		
Original Part Number	Part Name	Classic Part Number
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274

Sales Model 323D (Cont'd.)

JLG		
Original Part Number	**Part Name**	**Classic Part Number**
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969

JLG		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351

JLG		
Original Part Number	**Part Name**	**Classic Part Number**
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KBX		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

KBX		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

KBX		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KCE		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

KCE		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

KCE		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LFL		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222

LFL		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571

LFL		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406

Sales Model 323D (Cont'd.)

LFL		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8950	Plate	399-8587

LFL		
Original Part Number	Part Name	Classic Part Number
134-8951	Plate	382-5061
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
236-6271	Bearing-Sleeve	360-2324

LFL		
Original Part Number	Part Name	Classic Part Number
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

NDE		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

NDE		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

NDE		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

NES		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-1644	Gear-Planet	301-3406
7Y-2581	Guard As-Trk Gde	480-8270
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

NES		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8950	Plate	399-8587
148-4634	Shaft-Planet	360-2274
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
199-4582	Bearing-Needle	388-6589

NES		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 323D (Cont'd.)

NZF		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2040	Muffler As	301-7975
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-0468	Pin-G.E.T.	443-1203

NZF		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

NZF		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PBE		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-0468	Pin-G.E.T.	443-1203

PBE		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200

PBE		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PBM		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5533	Bearing-Sleeve	314-8628

PBM		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588

PBM		
Original Part Number	Part Name	Classic Part Number
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6271	Bearing-Sleeve	360-2324

Sales Model 323D (Cont'd.)

PBM		
Original Part Number	**Part Name**	**Classic Part Number**
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969

PBM		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351

PBM		
Original Part Number	**Part Name**	**Classic Part Number**
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PJP		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-0468	Pin-G.E.T.	443-1203

PJP		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

PJP		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RAC		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

RAC		
Original Part Number	**Part Name**	**Classic Part Number**
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

RAC		
Original Part Number	**Part Name**	**Classic Part Number**
227-6789	Bearing-Sleeve	360-2322
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SDC		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268

Sales Model 323D (Cont'd.)

SDC		
Original Part Number	Part Name	Classic Part Number
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
099-0722	Link As	415-1909
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047

SDC		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

SDC		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SED		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-1644	Gear-Planet	301-3406
7Y-2581	Guard As-Trk Gde	480-8270
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

SED		
Original Part Number	Part Name	Classic Part Number
117-5612	Pipe	398-2965
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8950	Plate	399-8587
148-4634	Shaft-Planet	360-2274
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

SED		
Original Part Number	Part Name	Classic Part Number
227-6789	Bearing-Sleeve	360-2322
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TDT		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406

TDT		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274

TDT		
Original Part Number	Part Name	Classic Part Number
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969

Sales Model 323D (Cont'd.)

TDT		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325

TDT		
Original Part Number	**Part Name**	**Classic Part Number**
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348

TDT		
Original Part Number	**Part Name**	**Classic Part Number**
357-7540	Valve-Fill	360-2292

WGC		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

WGC		
Original Part Number	**Part Name**	**Classic Part Number**
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

WGC		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WNE		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5533	Bearing-Sleeve	314-8628

WNE		
Original Part Number	**Part Name**	**Classic Part Number**
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200

WNE		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

XBK		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571

XBK		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0523	Pin	314-8696

XBK		
Original Part Number	**Part Name**	**Classic Part Number**
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729

Sales Model 323D (Cont'd.)

XBK		
Original Part Number	Part Name	Classic Part Number
119-2863	Pin	314-8698
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

XBK		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969

XBK		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

YCR		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273

YCR		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

YCR		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

YSD		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

YSD		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
129-7768	Bearing-Sleeve	360-2316
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

YSD		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
236-6271	Bearing-Sleeve	360-2324
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 323D (Cont'd.)

ZMF		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
5L-6326	Bearing-Ball	420-3222
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5533	Bearing-Sleeve	314-8628

ZMF		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
125-2950	Gear As	301-4762
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200

ZMF		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 323E

RAP		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5533	Bearing-Sleeve	314-8628

RAP		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

RAP		
Original Part Number	Part Name	Classic Part Number
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TDW		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729

TDW		
Original Part Number	Part Name	Classic Part Number
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698

TDW		
Original Part Number	Part Name	Classic Part Number
134-8948	Plate	399-8588
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
186-5662	Pin	421-1560
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

Sales Model 323E (Cont'd.)

TDW		
Original Part Number	Part Name	Classic Part Number
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969

TDW		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273

TDW		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

YRP		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
7Y-2581	Guard As-Trk Gde	480-8270

YRP		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
119-2863	Pin	314-8698
134-8948	Plate	399-8588
148-4634	Shaft-Planet	360-2274
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560

YRP		
Original Part Number	Part Name	Classic Part Number
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 323F

LMK		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
087-5805	Pin	301-7967

LMK		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

LMK		
Original Part Number	Part Name	Classic Part Number
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MDL		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269

MDL		
Original Part Number	Part Name	Classic Part Number
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625

MDL		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671

Sales Model 323F (Cont'd.)

MDL		
Original Part Number	Part Name	Classic Part Number
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698
134-8948	Plate	399-8588

MDL		
Original Part Number	Part Name	Classic Part Number
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274

MDL		
Original Part Number	Part Name	Classic Part Number
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

P39		
Original Part Number	Part Name	Classic Part Number
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-1644	Gear-Planet	301-3406
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

P39		
Original Part Number	Part Name	Classic Part Number
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274

P39		
Original Part Number	Part Name	Classic Part Number
239-4390	Recoil Gp-Adj&-A	480-8275
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PLB		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

PLB		
Original Part Number	Part Name	Classic Part Number
119-2863	Pin	314-8698
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275

PLB		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

XCF		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729

XCF		
Original Part Number	Part Name	Classic Part Number
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

XCF		
Original Part Number	Part Name	Classic Part Number
119-2863	Pin	314-8698
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200

Sales Model 323F (Cont'd.)

XCF		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275

XCF		
Original Part Number	**Part Name**	**Classic Part Number**
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2402	Pin As	360-2351

XCF		
Original Part Number	**Part Name**	**Classic Part Number**
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

YEC		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

YEC		
Original Part Number	**Part Name**	**Classic Part Number**
121-7746	Pre-Cleaner As	360-2311
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274

YEC		
Original Part Number	**Part Name**	**Classic Part Number**
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

YEJ		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
5I-8628	Plate-Valve	301-4771
7K-9592	Bearing-Sleeve	360-2336
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1644	Gear-Planet	301-3406
086-0414	Flange	392-4522
086-0523	Pin	314-8696

YEJ		
Original Part Number	**Part Name**	**Classic Part Number**
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698
134-8948	Plate	399-8588
134-8950	Plate	399-8587
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
191-3235	Housing-Sprocket	394-0200
199-4582	Bearing-Needle	388-6589

YEJ		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ZDF		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
5I-8628	Plate-Valve	301-4771
7Y-1644	Gear-Planet	301-3406
7Y-2581	Guard As-Trk Gde	480-8270
086-0414	Flange	392-4522
094-1509	Shaft-Planet	360-2273

ZDF		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
121-7746	Pre-Cleaner As	360-2311
148-4634	Shaft-Planet	360-2274
179-3008	Cylinder	480-8272
199-4582	Bearing-Needle	388-6589

ZDF		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
240-2912	Bearing-Sleeve	418-1969
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 324D

AWN		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3427	Bearing-Sleeve	314-8635
9Y-2988	Breather As	361-1716
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381

AWN		
Original Part Number	Part Name	Classic Part Number
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
128-9863	Bearing-Sleeve	314-8630
133-4995	Gasket-Cyl Head	434-2445
134-8948	Plate	399-8588
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
186-5652	Pin	392-4532
186-5662	Pin	421-1560
186-5730	Pin	393-3688
212-4893	Bearing-Thrust	419-6372

AWN		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BTK		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626

BTK		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380

BTK		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
186-5730	Pin	393-3688
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2915	Bearing-Sleeve	360-2326
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912

Sales Model 324D (Cont'd.)

BTK		
Original Part Number	**Part Name**	**Classic Part Number**
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348

BTK		
Original Part Number	**Part Name**	**Classic Part Number**
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BYE		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4811	Pin As	480-8268
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2395	Bearing-Sleeve	314-8646
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
9Y-2988	Breather As	361-1716
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5805	Pin	301-7967

BYE		
Original Part Number	**Part Name**	**Classic Part Number**
087-5806	Pin	301-7968
087-5845	Pin	301-7969
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
128-9863	Bearing-Sleeve	314-8630
128-9884	Bearing-Sleeve	360-2315
133-4995	Gasket-Cyl Head	434-2445
134-8948	Plate	399-8588
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
186-5730	Pin	393-3688

BYE		
Original Part Number	**Part Name**	**Classic Part Number**
188-4211	Cylinder As	425-9366
192-8318	Bearing-Sleeve	360-2321
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

CJX		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657

CJX		
Original Part Number	**Part Name**	**Classic Part Number**
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336

CJX		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
7Y-5131	Bearing-Sleeve	301-4626
9Y-2988	Breather As	361-1716
086-0523	Pin	314-8696
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381

Sales Model 324D (Cont'd.)

CJX		
Original Part Number	Part Name	Classic Part Number
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
133-4995	Gasket-Cyl Head	434-2445
134-8948	Plate	399-8588
134-8950	Plate	399-8587
134-8951	Plate	382-5061

CJX		
Original Part Number	Part Name	Classic Part Number
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
186-5730	Pin	393-3688
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

CJX		
Original Part Number	Part Name	Classic Part Number
236-4413	Pump Gp-Water -B	434-6110
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

DFP		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-3428	Bearing-Sleeve	314-8647
9Y-2988	Breather As	361-1716
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5805	Pin	301-7967

DFP		
Original Part Number	Part Name	Classic Part Number
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
133-4995	Gasket-Cyl Head	434-2445
134-8948	Plate	399-8588
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

DFP		
Original Part Number	Part Name	Classic Part Number
186-5730	Pin	393-3688
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

ECH		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703

Sales Model 324D (Cont'd.)

ECH		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2395	Bearing-Sleeve	314-8646
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
9Y-2988	Breather As	361-1716
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969

ECH		
Original Part Number	Part Name	Classic Part Number
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
128-9863	Bearing-Sleeve	314-8630
128-9884	Bearing-Sleeve	360-2315
133-4995	Gasket-Cyl Head	434-2445
134-8948	Plate	399-8588
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

ECH		
Original Part Number	Part Name	Classic Part Number
186-5730	Pin	393-3688
188-4211	Cylinder As	425-9366
192-8318	Bearing-Sleeve	360-2321
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

EJC		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-5128	Bearing-Sleeve	314-8648

EJC		
Original Part Number	Part Name	Classic Part Number
7Y-5131	Bearing-Sleeve	301-4626
9Y-2988	Breather As	361-1716
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061

EJC		
Original Part Number	Part Name	Classic Part Number
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
186-5730	Pin	393-3688
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

Sales Model 324D (Cont'd.)

EJC		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326

EJC		
Original Part Number	Part Name	Classic Part Number
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710

EJC		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

GPK		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
9Y-2988	Breather As	361-1716
086-0523	Pin	314-8696
101-1530	Bearing-Main	419-6382

GPK		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
186-5730	Pin	393-3688
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372

GPK		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2913	Bearing-Sleeve	360-2325
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

JAT		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336

JAT		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
9Y-2988	Breather As	361-1716
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729

JAT		
Original Part Number	Part Name	Classic Part Number
119-2863	Pin	314-8698
133-4995	Gasket-Cyl Head	434-2445
134-8948	Plate	399-8588
134-8950	Plate	399-8587
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
186-5730	Pin	393-3688
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295

Sales Model 324D (Cont'd.)

JAT		
Original Part Number	**Part Name**	**Classic Part Number**
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

JAT		
Original Part Number	**Part Name**	**Classic Part Number**
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912

JAT		
Original Part Number	**Part Name**	**Classic Part Number**
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

JGK		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4619	Pin As	425-2564
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7181	Piston	393-5217
7K-0078	Bearing-Sleeve	308-9825
7Y-0225	Shaft-Planet	301-4571
7Y-0680	Piston	360-2262
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648

JGK		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-5131	Bearing-Sleeve	301-4626
8W-8512	Pin As	385-7220
9Y-2988	Breather As	361-1716
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
118-5196	Pin	380-7397
128-9863	Bearing-Sleeve	314-8630
128-9883	Bearing-Sleeve	360-2314
133-4995	Gasket-Cyl Head	434-2445
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318

JGK		
Original Part Number	**Part Name**	**Classic Part Number**
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
191-3118	Cyl Gp-0170 1680	399-8560
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6270	Bearing-Sleeve	425-6436
240-2915	Bearing-Sleeve	360-2326
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

JJG		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657

JJG		
Original Part Number	**Part Name**	**Classic Part Number**
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336

JJG		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
7Y-2396	Bearing-Sleeve	314-8634
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626

Sales Model 324D (Cont'd.)

JJG		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
086-0523	Pin	314-8696
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8948	Plate	399-8588

JJG		
Original Part Number	Part Name	Classic Part Number
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
186-5730	Pin	393-3688
189-3922	Pin	393-0938
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322

JJG		
Original Part Number	Part Name	Classic Part Number
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

JKR		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-0078	Bearing-Sleeve	308-9825
7Y-0225	Shaft-Planet	301-4571
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626

JKR		
Original Part Number	Part Name	Classic Part Number
8W-8512	Pin As	385-7220
9Y-2988	Breather As	361-1716
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272

JKR		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
186-5730	Pin	393-3688
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6270	Bearing-Sleeve	425-6436
240-2915	Bearing-Sleeve	360-2326
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 324D (Cont'd.)

JLS		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4619	Pin As	425-2564
4K-0299	Bearing-Sleeve	308-9816
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7181	Piston	393-5217
7K-0078	Bearing-Sleeve	308-9825
7Y-0225	Shaft-Planet	301-4571
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648

JLS		
Original Part Number	Part Name	Classic Part Number
7Y-5131	Bearing-Sleeve	301-4626
8W-8512	Pin As	385-7220
9Y-2988	Breather As	361-1716
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
118-5196	Pin	380-7397
128-9863	Bearing-Sleeve	314-8630
128-9883	Bearing-Sleeve	360-2314
133-4995	Gasket-Cyl Head	434-2445
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380

JLS		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
179-3044	Cylinder	385-6138
191-3118	Cyl Gp-0170 1680	399-8560
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6270	Bearing-Sleeve	425-6436
240-2915	Bearing-Sleeve	360-2326
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

JZR		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
9Y-2988	Breather As	361-1716
086-0523	Pin	314-8696
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382

JZR		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

JZR		
Original Part Number	Part Name	Classic Part Number
186-5730	Pin	393-3688
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710

Sales Model 324D (Cont'd.)

JZR		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348

JZR		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292

JZR		
Original Part Number	Part Name	Classic Part Number
441-9566	Gear-Flywheel	374-4703

LAB		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9Y-2988	Breather As	361-1716

LAB		
Original Part Number	Part Name	Classic Part Number
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8951	Plate	382-5061
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

LAB		
Original Part Number	Part Name	Classic Part Number
154-8030	Gasket	394-0894
186-5730	Pin	393-3688
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2915	Bearing-Sleeve	360-2326
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

LKN		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-5128	Bearing-Sleeve	314-8648

LKN		
Original Part Number	Part Name	Classic Part Number
7Y-5131	Bearing-Sleeve	301-4626
9Y-2988	Breather As	361-1716
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587

LKN		
Original Part Number	Part Name	Classic Part Number
134-8951	Plate	382-5061
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
186-5730	Pin	393-3688
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

Sales Model 324D (Cont'd.)

LKN		
Original Part Number	**Part Name**	**Classic Part Number**
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

LKN		
Original Part Number	**Part Name**	**Classic Part Number**
240-2915	Bearing-Sleeve	360-2326
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912

LKN		
Original Part Number	**Part Name**	**Classic Part Number**
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

MND		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
9Y-2988	Breather As	361-1716
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382

MND		
Original Part Number	**Part Name**	**Classic Part Number**
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
133-4995	Gasket-Cyl Head	434-2445
134-8948	Plate	399-8588
134-8950	Plate	399-8587
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
186-5730	Pin	393-3688

MND		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

NPC		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336

NPC		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9Y-2988	Breather As	361-1716
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069

NPC		
Original Part Number	**Part Name**	**Classic Part Number**
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
186-5730	Pin	393-3688
189-3922	Pin	393-0938

Sales Model 324D (Cont'd.)

NPC		
Original Part Number	**Part Name**	**Classic Part Number**
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

NPC		
Original Part Number	**Part Name**	**Classic Part Number**
236-4413	Pump Gp-Water -B	434-6110
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326

NPC		
Original Part Number	**Part Name**	**Classic Part Number**
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

PYT		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9Y-2988	Breather As	361-1716
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5805	Pin	301-7967

PYT		
Original Part Number	**Part Name**	**Classic Part Number**
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
186-5730	Pin	393-3688
189-3922	Pin	393-0938

PYT		
Original Part Number	**Part Name**	**Classic Part Number**
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

SYM		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657

SYM		
Original Part Number	**Part Name**	**Classic Part Number**
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449

SYM		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9Y-2988	Breather As	361-1716
101-1530	Bearing-Main	419-6382

Sales Model 324D (Cont'd.)

SYM		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2820	Bearing-Sleeve	360-2318

SYM		
Original Part Number	Part Name	Classic Part Number
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
186-5730	Pin	393-3688
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

SYM		
Original Part Number	Part Name	Classic Part Number
236-4413	Pump Gp-Water -B	434-6110
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

T2D		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9Y-2988	Breather As	361-1716
101-1530	Bearing-Main	419-6382

T2D		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
186-5730	Pin	393-3688
189-3922	Pin	393-0938

T2D		
Original Part Number	Part Name	Classic Part Number
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

TRH		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667

TRH		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657

TRH		
Original Part Number	Part Name	Classic Part Number
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

Sales Model 324D (Cont'd.)

TRH		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9Y-2988	Breather As	361-1716
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069

TRH		
Original Part Number	Part Name	Classic Part Number
117-5553	Guard As-Tck Gde	419-4729
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
186-5730	Pin	393-3688
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870

TRH		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2915	Bearing-Sleeve	360-2326
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

TSN		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
9Y-2988	Breather As	361-1716
086-0523	Pin	314-8696
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382

TSN		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
119-2863	Pin	314-8698
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
186-5730	Pin	393-3688
189-3922	Pin	393-0938

TSN		
Original Part Number	Part Name	Classic Part Number
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

JCZ		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

JCZ		
Original Part Number	**Part Name**	**Classic Part Number**
134-8948	Plate	399-8588
134-8950	Plate	399-8587
134-8951	Plate	382-5061
186-5730	Pin	393-3688
189-3922	Pin	393-0938

JCZ		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KTE		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
086-0414	Flange	392-4522
086-0523	Pin	314-8696
114-0468	Pin-G.E.T.	443-1203

KTE		
Original Part Number	**Part Name**	**Classic Part Number**
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
134-8948	Plate	399-8588
134-8950	Plate	399-8587
134-8951	Plate	382-5061
186-5730	Pin	393-3688

KTE		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LDG		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
086-0523	Pin	314-8696
087-5805	Pin	301-7967
087-5978	Flange	374-3496

LDG		
Original Part Number	**Part Name**	**Classic Part Number**
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698
134-8950	Plate	399-8587
134-8951	Plate	382-5061
186-5730	Pin	393-3688

LDG		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PNW		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-5131	Bearing-Sleeve	301-4626
086-0414	Flange	392-4522
086-0523	Pin	314-8696

PNW		
Original Part Number	**Part Name**	**Classic Part Number**
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
186-5730	Pin	393-3688

PNW		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
193-5016	Flange	425-3644
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TLF		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
7K-9592	Bearing-Sleeve	360-2336

TLF		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
086-0414	Flange	392-4522

TLF		
Original Part Number	**Part Name**	**Classic Part Number**
086-0523	Pin	314-8696
087-5805	Pin	301-7967

Sales Model 324E (Cont'd.)

TLF		
Original Part Number	Part Name	Classic Part Number
087-5978	Flange	374-3496
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698

TLF		
Original Part Number	Part Name	Classic Part Number
134-8950	Plate	399-8587
134-8951	Plate	382-5061
186-5730	Pin	393-3688
189-3922	Pin	393-0938
240-2912	Bearing-Sleeve	418-1969

TLF		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 325

2JK		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1T-0210	Bearing-Ball	417-4498
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2K-6413	Pin	360-2270
2N-1599	Gear	378-3970
2P-4611	Pipe-Exhaust	365-8821
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4617	Pin As	424-6367
4I-4619	Pin As	425-2564
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6I-1099	Manifold-Exh	424-6366
6V-2202	Bearing-Spl Ball	380-1574

2JK		
Original Part Number	Part Name	Classic Part Number
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128

2JK		
Original Part Number	Part Name	Classic Part Number
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308

Sales Model 325 (Cont'd.)

2JK		
Original Part Number	Part Name	Classic Part Number
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692

2JK		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5612	Pipe	398-2965
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336

2JK		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

2SK		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2V-0707	Bearing-Sleeve	360-2328

2SK		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4617	Pin As	424-6367

2SK		
Original Part Number	Part Name	Classic Part Number
4I-4619	Pin As	425-2564
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

Sales Model 325 (Cont'd.)

2SK		
Original Part Number	Part Name	Classic Part Number
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564

2SK		
Original Part Number	Part Name	Classic Part Number
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
8V-2632	Pin As	241-2523
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-2941	Gasket Kit	393-1020

2SK		
Original Part Number	Part Name	Classic Part Number
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366

Sales Model 325 (Cont'd.)

2SK		
Original Part Number	**Part Name**	**Classic Part Number**
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870

2SK		
Original Part Number	**Part Name**	**Classic Part Number**
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246

2SK		
Original Part Number	**Part Name**	**Classic Part Number**
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

2SL		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-1524	Cylinder As	394-8216
4I-4617	Pin As	424-6367
4I-4619	Pin As	425-2564
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6E-0787	Bearing-Sleeve	425-6443
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

2SL		
Original Part Number	**Part Name**	**Classic Part Number**
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7K-5448	Cup-Bearing	415-1922
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671

2SL		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577

Sales Model 325 (Cont'd.)

2SL		
Original Part Number	Part Name	Classic Part Number
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6389	Bearing	372-7507
7Y-6607	Bearing	372-7508
7Y-6608	Bearing	314-8649
7Y-6626	Bearing	314-8650
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
8V-2632	Pin As	241-2523
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9V-0247	Plate	417-4527
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641

2SL		
Original Part Number	Part Name	Classic Part Number
099-0722	Link As	415-1909
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317

2SL		
Original Part Number	Part Name	Classic Part Number
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

3LL		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703

3LL		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628

3LL		
Original Part Number	Part Name	Classic Part Number
2N-1599	Gear	378-3970
2V-0707	Bearing-Sleeve	360-2328

Sales Model 325 (Cont'd.)

3LL		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4617	Pin As	424-6367
4I-4619	Pin As	425-2564
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7K-5448	Cup-Bearing	415-1922
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637

3LL		
Original Part Number	Part Name	Classic Part Number
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626

3LL		
Original Part Number	Part Name	Classic Part Number
7Y-6389	Bearing	372-7507
7Y-6607	Bearing	372-7508
7Y-6608	Bearing	314-8649
7Y-6626	Bearing	314-8650
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
8V-2632	Pin As	241-2523
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9V-0247	Plate	417-4527
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
113-6200	Gasket	438-2020

Sales Model 325 (Cont'd.)

3LL		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697

3LL		
Original Part Number	Part Name	Classic Part Number
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589

3LL		
Original Part Number	Part Name	Classic Part Number
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

5WK		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-6413	Pin	360-2270
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4617	Pin As	424-6367
4I-4619	Pin As	425-2564
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

5WK		
Original Part Number	Part Name	Classic Part Number
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545

5WK		
Original Part Number	Part Name	Classic Part Number
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249

Sales Model 325 (Cont'd.)

5WK		
Original Part Number	Part Name	Classic Part Number
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964

5WK		
Original Part Number	Part Name	Classic Part Number
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697

5WK		
Original Part Number	Part Name	Classic Part Number
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

6KK		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703

6KK		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628

6KK		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
2N-1599	Gear	378-3970

Sales Model 325 (Cont'd.)

6KK		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4617	Pin As	424-6367
4I-4619	Pin As	425-2564
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694

6KK		
Original Part Number	Part Name	Classic Part Number
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626

6KK		
Original Part Number	Part Name	Classic Part Number
7Y-6389	Bearing	372-7507
7Y-6607	Bearing	372-7508
7Y-6608	Bearing	314-8649
7Y-6626	Bearing	314-8650
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630

Sales Model 325 (Cont'd.)

6KK		
Original Part Number	Part Name	Classic Part Number
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-3060	Bearing-Sleeve	360-2320

6KK		
Original Part Number	Part Name	Classic Part Number
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371

6KK		
Original Part Number	Part Name	Classic Part Number
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

6RM		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-6413	Pin	360-2270
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4617	Pin As	424-6367
4I-4619	Pin As	425-2564
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366

6RM		
Original Part Number	Part Name	Classic Part Number
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625

6RM		
Original Part Number	Part Name	Classic Part Number
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646

Sales Model 325 (Cont'd.)

6RM		
Original Part Number	Part Name	Classic Part Number
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629

6RM		
Original Part Number	Part Name	Classic Part Number
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-5196	Pin	380-7397
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317

6RM		
Original Part Number	Part Name	Classic Part Number
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
264-6898	Kit-Gasket-Sch	382-5069
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

7CJ		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955

7CJ		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2K-6413	Pin	360-2270
2N-1599	Gear	378-3970

7CJ		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922

Sales Model 325 (Cont'd.)

7CJ		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4617	Pin As	424-6367
4I-4619	Pin As	425-2564
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128

7CJ		
Original Part Number	Part Name	Classic Part Number
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6389	Bearing	372-7507
7Y-6607	Bearing	372-7508
7Y-6608	Bearing	314-8649

7CJ		
Original Part Number	Part Name	Classic Part Number
7Y-6626	Bearing	314-8650
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642

Sales Model 325 (Cont'd.)

7CJ		
Original Part Number	Part Name	Classic Part Number
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388

7CJ		
Original Part Number	Part Name	Classic Part Number
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

7CJ		
Original Part Number	Part Name	Classic Part Number
236-6270	Bearing-Sleeve	425-6436
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

7LJ		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-1524	Cylinder As	394-8216
4I-4617	Pin As	424-6367
4I-4619	Pin As	425-2564
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6E-0787	Bearing-Sleeve	425-6443

7LJ		
Original Part Number	Part Name	Classic Part Number
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625

7LJ		
Original Part Number	Part Name	Classic Part Number
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634

Sales Model 325 (Cont'd.)

7LJ		
Original Part Number	Part Name	Classic Part Number
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6389	Bearing	372-7507
7Y-6607	Bearing	372-7508
7Y-6608	Bearing	314-8649
7Y-6626	Bearing	314-8650
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
8V-2632	Pin As	241-2523
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969

7LJ		
Original Part Number	Part Name	Classic Part Number
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5612	Pipe	398-2965
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697

7LJ		
Original Part Number	Part Name	Classic Part Number
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 325 (Cont'd.)

7LM		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1T-0210	Bearing-Ball	417-4498
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2K-6413	Pin	360-2270
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4617	Pin As	424-6367
4I-4619	Pin As	425-2564
4I-7401	Spring	380-7414
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6I-1099	Manifold-Exh	424-6366
6V-2202	Bearing-Spl Ball	380-1574
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7W-3773	Pulley-Cshaft	383-1583

7LM		
Original Part Number	Part Name	Classic Part Number
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0207	Cylinder	383-1584
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1258	Piston	367-6091
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1738	Support	443-5198
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817

7LM		
Original Part Number	Part Name	Classic Part Number
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6389	Bearing	372-7507
7Y-6607	Bearing	372-7508
7Y-6608	Bearing	314-8649
7Y-6626	Bearing	314-8650
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909

Sales Model 325 (Cont'd.)

7LM		
Original Part Number	Part Name	Classic Part Number
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-5196	Pin	380-7397
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437

7LM		
Original Part Number	Part Name	Classic Part Number
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-3060	Bearing-Sleeve	360-2320
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962

7LM		
Original Part Number	Part Name	Classic Part Number
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
264-6898	Kit-Gasket-Sch	382-5069
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

7TG		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-6413	Pin	360-2270
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4617	Pin As	424-6367
4I-4619	Pin As	425-2564

7TG		
Original Part Number	Part Name	Classic Part Number
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

7TG		
Original Part Number	Part Name	Classic Part Number
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758

Sales Model 325 (Cont'd.)

7TG		
Original Part Number	Part Name	Classic Part Number
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636

7TG		
Original Part Number	Part Name	Classic Part Number
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5612	Pipe	398-2965
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437

7TG		
Original Part Number	Part Name	Classic Part Number
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

Sales Model 325 (Cont'd.)

7TG		
Original Part Number	**Part Name**	**Classic Part Number**
357-7540	Valve-Fill	360-2292

7TG		
Original Part Number	**Part Name**	**Classic Part Number**
441-9566	Gear-Flywheel	374-4703

8JG		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-6413	Pin	360-2270
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4617	Pin As	424-6367
4I-4619	Pin As	425-2564
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705

8JG		
Original Part Number	**Part Name**	**Classic Part Number**
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349

8JG		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636

Sales Model 325 (Cont'd.)

8JG		
Original Part Number	**Part Name**	**Classic Part Number**
110-7209	Carrier As	301-5237
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5612	Pipe	398-2965
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110

8JG		
Original Part Number	**Part Name**	**Classic Part Number**
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589

8JG		
Original Part Number	**Part Name**	**Classic Part Number**
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

8NK		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1T-0210	Bearing-Ball	417-4498
1V-8241	Bearing-Sleeve	308-9808
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2K-6413	Pin	360-2270
2N-1599	Gear	378-3970
2P-4611	Pipe-Exhaust	365-8821
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
3W-8239	Sleeve-Wear	360-2342
3Y-2768	Ring	439-4544
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4617	Pin As	424-6367
4I-4619	Pin As	425-2564

8NK		
Original Part Number	**Part Name**	**Classic Part Number**
4I-7401	Spring	380-7414
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-1684	Bearing	377-7428
4T-8054	Seal As	472-8010
4V-8520	Bearing-Sleeve	307-1527
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6I-1099	Manifold-Exh	424-6366
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
7C-3729	Pulley	376-9066

8NK		
Original Part Number	**Part Name**	**Classic Part Number**
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7J-1309	Bearing-Aligning	360-2275
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0207	Cylinder	383-1584

Sales Model 325 (Cont'd.)

8NK		
Original Part Number	Part Name	Classic Part Number
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1258	Piston	367-6091
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1738	Support	443-5198
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266

8NK		
Original Part Number	Part Name	Classic Part Number
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6389	Bearing	372-7507
7Y-6607	Bearing	372-7508
7Y-6608	Bearing	314-8649
7Y-6626	Bearing	314-8650
8C-3111	Rod End-Spher	392-4523
8E-2058	Bearing	384-5949
8H-2810	Case As-Filter	314-8512
8J-8809	Pump Gp-Gr -A	419-4653
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
9J-2759	Trunnion	394-0216
9K-8757	Rod End-Special	311-9361
9M-3914	Bearing-Aligning	420-2501
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654

8NK		
Original Part Number	Part Name	Classic Part Number
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5612	Pipe	398-2965
118-5196	Pin	380-7397
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-3060	Bearing-Sleeve	360-2320

Sales Model 325 (Cont'd.)

8NK		
Original Part Number	Part Name	Classic Part Number
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589

8NK		
Original Part Number	Part Name	Classic Part Number
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317

8NK		
Original Part Number	Part Name	Classic Part Number
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

8NL		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-6413	Pin	360-2270
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4617	Pin As	424-6367
4I-4619	Pin As	425-2564
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

8NL		
Original Part Number	Part Name	Classic Part Number
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671

8NL		
Original Part Number	Part Name	Classic Part Number
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433

Sales Model 325 (Cont'd.)

8NL		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-7056	Gear-Planet	374-3497

8NL		
Original Part Number	**Part Name**	**Classic Part Number**
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388

8NL		
Original Part Number	**Part Name**	**Classic Part Number**
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

8YK		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-6413	Pin	360-2270
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
3W-8239	Sleeve-Wear	360-2342

8YK		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4617	Pin As	424-6367
4I-4619	Pin As	425-2564
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513

8YK		
Original Part Number	**Part Name**	**Classic Part Number**
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

Sales Model 325 (Cont'd.)

8YK		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270

8YK		
Original Part Number	Part Name	Classic Part Number
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381

8YK		
Original Part Number	Part Name	Classic Part Number
107-7750	Pulley	382-6896
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5612	Pipe	398-2965
118-5196	Pin	380-7397
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372

Sales Model 325 (Cont'd.)

8YK		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436

8YK		
Original Part Number	Part Name	Classic Part Number
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

8YK		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

9KL		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-6413	Pin	360-2270
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4617	Pin As	424-6367
4I-4619	Pin As	425-2564
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7W-3773	Pulley-Cshaft	383-1583

9KL		
Original Part Number	Part Name	Classic Part Number
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646

9KL		
Original Part Number	Part Name	Classic Part Number
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6389	Bearing	372-7507
7Y-6607	Bearing	372-7508
7Y-6608	Bearing	314-8649
7Y-6626	Bearing	314-8650
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033

Sales Model 325 (Cont'd.)

9KL		
Original Part Number	Part Name	Classic Part Number
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349

9KL		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-3060	Bearing-Sleeve	360-2320
137-8479	Spacer	395-1323
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388

9KL		
Original Part Number	Part Name	Classic Part Number
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

9SG		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331

9SG		
Original Part Number	Part Name	Classic Part Number
4I-0704	Bearing-Sleeve	360-2332
4I-4617	Pin As	424-6367
4I-4619	Pin As	425-2564
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366

9SG		
Original Part Number	Part Name	Classic Part Number
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142

Sales Model 325 (Cont'd.)

9SG		
Original Part Number	Part Name	Classic Part Number
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289

9SG		
Original Part Number	Part Name	Classic Part Number
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
8V-2632	Pin As	241-2523
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203

9SG		
Original Part Number	Part Name	Classic Part Number
114-1383	Shaft-Planet	398-8349
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370

Sales Model 325 (Cont'd.)

9SG		
Original Part Number	**Part Name**	**Classic Part Number**
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317

9SG		
Original Part Number	**Part Name**	**Classic Part Number**
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107

9SG		
Original Part Number	**Part Name**	**Classic Part Number**
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

9ZK		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3J-2903	Cover	422-6922
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4617	Pin As	424-6367
4I-4619	Pin As	425-2564
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7K-5448	Cup-Bearing	415-1922

9ZK		
Original Part Number	**Part Name**	**Classic Part Number**
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646

9ZK		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
8V-2632	Pin As	241-2523
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531

Sales Model 325 (Cont'd.)

9ZK		
Original Part Number	**Part Name**	**Classic Part Number**
9V-0247	Plate	417-4527
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219

9ZK		
Original Part Number	**Part Name**	**Classic Part Number**
115-4237	Pulley-Idler	374-4693
117-5612	Pipe	398-2965
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366

9ZK		
Original Part Number	**Part Name**	**Classic Part Number**
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 325B

1GS		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3G-5285	Bearing-Sleeve	360-2312

1GS		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-4619	Pin As	425-2564
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513

1GS		
Original Part Number	**Part Name**	**Classic Part Number**
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6E-4985	Cover-Filter	424-2015
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

Sales Model 325B (Cont'd.)

1GS		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3428	Bearing-Sleeve	314-8647
7Y-3551	Bearing-Sleeve	380-7375
7Y-3553	Bearing-Sleeve	301-0433

1GS		
Original Part Number	Part Name	Classic Part Number
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
106-6878	Pin	372-7510
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2775	Pin As	418-1967
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5435	Pin As	393-0934
117-5612	Pipe	398-2965
117-6270	Support As	434-1400
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630

1GS		
Original Part Number	Part Name	Classic Part Number
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-8479	Spacer	395-1323
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
191-3240	Housing-Motor	418-1962
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 325B (Cont'd.)

2JR		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
1T-0210	Bearing-Ball	417-4498
1W-1064	Gear-Flywheel	374-4703
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2K-5065	Cone-Roller Brg	416-2157
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2N-1599	Gear	378-3970
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

2JR		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-1524	Cylinder As	394-8216
4I-4619	Pin As	425-2564
4I-7401	Spring	380-7414
4K-0299	Bearing-Sleeve	308-9816
4K-0300	Bearing-Sleeve	308-9817
4N-0432	Bearing-Ball	417-4499
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-7693	Crankshaft As	269-8763
4P-2383	Adapter-Inlet	438-1812
4P-3546	Valve As-Relief	325-6236
4P-3683	Pump Gp-Water -B	374-7498
4P-7688	Valve As-Check	420-6216
4P-7790	Shaft As-Arm	457-4596
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009

2JR		
Original Part Number	Part Name	Classic Part Number
4P-8577	Rod As-Injector	455-5513
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-6869	Spacer-Fuel Pump	417-4534
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1099	Manifold-Exh	424-6366

Sales Model 325B (Cont'd.)

2JR		
Original Part Number	Part Name	Classic Part Number
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-1931	Plunger	379-0171
6N-7174	Shield-Oil	314-8544
6S-3051	Cup-Rlr Brg	415-1928
6V-2202	Bearing-Spl Ball	380-1574
6Y-9930	Mount As	360-2353
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7K-0078	Bearing-Sleeve	308-9825
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2156	Bearing-Sleeve	380-7373

2JR		
Original Part Number	Part Name	Classic Part Number
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7V-0638	Spacer	425-3651
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-8064	Valve-Inlet	384-8705
7W-9020	Bell As-Pump Suc	378-3989
7W-9027	Base-Oil Cooler	399-8545
7Y-0207	Cylinder	383-1584
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-0912	Bearing-Rlr As	417-4513
7Y-1100	Bearing-Roller	394-8226
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209

2JR		
Original Part Number	Part Name	Classic Part Number
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1738	Support	443-5198
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8D-2256	Cone-Roller Brg	374-1848
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037

Sales Model 325B (Cont'd.)

2JR		
Original Part Number	Part Name	Classic Part Number
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8V-6435	Spider & Brg Kit	377-7451
9F-3212	Bearing-Ball	384-5953
9K-1171	Cup-Rlr Bearing	430-3339
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124

2JR		
Original Part Number	Part Name	Classic Part Number
9S-8679	Chamber As	325-6042
9W-9931	Mount As.	360-2354
9Y-1798	Seal-Water	379-0165
9Y-2988	Breather As	361-1716
9Y-5295	Tube-Gov Conn	419-4756
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-6267	Plate As-Idler	375-9983
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8112	Cylinder	360-2276
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
108-7930	Bearing As	377-7463
109-9323	Muffler As	369-9491
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046

2JR		
Original Part Number	Part Name	Classic Part Number
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
109-9463	Muffler As	360-7864
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
110-7216	Gear-Sun	391-9877
110-7228	Carrier-Planet	390-0918
110-7232	Gear-Sun	417-9472
110-7243	Carrier As	384-5961
111-8015	Gasket As-Head	279-4977
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2775	Pin As	418-1967
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5435	Pin As	393-0934
117-5612	Pipe	398-2965
117-6270	Support As	434-1400
118-5196	Pin	380-7397
119-2940	Gasket	378-4002
123-2111	Piston	462-5714
126-5875	Flywheel As.	374-4694
127-3467	Manifold-Exhaust	394-9827
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
129-9907	Impeller-Pump	383-1589
130-9293	Rod	314-8708
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919

Sales Model 325B (Cont'd.)

2JR		
Original Part Number	Part Name	Classic Part Number
133-3359	Manifold-Exhaust	419-4730
133-4995	Gasket-Cyl Head	434-2445
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
135-4928	Shaft-Water Pump	386-3813
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-3060	Bearing-Sleeve	360-2320
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
148-7455	Valve - Exhaust	270-4361
152-3952	Impeller-Pump	374-4696
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-8030	Gasket	394-0894
155-5619	Gasket	382-5054
156-0738	Rod As	394-8210
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
163-1387	Gear-Flywheel	374-4697
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351

2JR		
Original Part Number	Part Name	Classic Part Number
166-9142	Gasket	420-8546
167-8123	Damper As	299-2006
167-8126	Damper As	382-8019
168-4531	Body As-Piston	477-7127
168-8453	Bearing-Spl Ball	417-4497
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-4860	Bonnet-Oil Clr	430-5359
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
188-4211	Cylinder As	425-9366
191-3118	Cyl Gp-0170 1680	399-8560
191-3240	Housing-Motor	418-1962
191-3243	Housing-Motor	418-1963
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
202-3572	Shaft As-Drive	426-0037
207-8176	Cover-Xmsn	420-3218
211-0592	Bearing - Main	419-6368
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322

2JR		
Original Part Number	Part Name	Classic Part Number
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3233	Bearing-Main	376-9085
236-6270	Bearing-Sleeve	425-6436
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
253-1752	Plate-Thrust	379-0170
255-2899	Pipe As-Tail	301-5246
256-9653	Flywheel As.	425-3444
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
278-1365	Arm As-Ui Rkr	433-7507
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
391-8229	Kit-Gasket-Fs	398-2955
430-7619	Adapter-Cla	438-1812
441-9566	Gear-Flywheel	374-4703

Sales Model 325B (Cont'd.)

4DS		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
1W-4369	Pulley-Alt	296-1340
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4619	Pin As	425-2564
4I-4811	Pin As	480-8268
4I-7401	Spring	380-7414
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-7807	Bearing-Ball	314-8502
6I-1099	Manifold-Exh	424-6366
6Y-9930	Mount As	360-2353
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7K-5448	Cup-Bearing	415-1922
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545

4DS		
Original Part Number	Part Name	Classic Part Number
7Y-0207	Cylinder	383-1584
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1258	Piston	367-6091
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1738	Support	443-5198
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636

4DS		
Original Part Number	Part Name	Classic Part Number
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6607	Bearing	372-7508
7Y-6626	Bearing	314-8650
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9V-0247	Plate	417-4527
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471

Sales Model 325B (Cont'd.)

4DS		
Original Part Number	Part Name	Classic Part Number
109-9369	Mount-Rubber	393-1047
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
110-7216	Gear-Sun	391-9877
110-7228	Carrier-Planet	390-0918
110-7232	Gear-Sun	417-9472
110-7243	Carrier As	384-5961
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2775	Pin As	418-1967
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5435	Pin As	393-0934
117-5612	Pipe	398-2965
117-6270	Support As	434-1400
117-6675	Step As	419-0881
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708

4DS		
Original Part Number	Part Name	Classic Part Number
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
168-8453	Bearing-Spl Ball	417-4497
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
191-3240	Housing-Motor	418-1962
191-3243	Housing-Motor	418-1963
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589

4DS		
Original Part Number	Part Name	Classic Part Number
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

5BS		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
1W-4369	Pulley-Alt	296-1340
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667

5BS		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-1524	Cylinder As	394-8216
4I-4619	Pin As	425-2564
4I-4811	Pin As	480-8268
4P-3683	Pump Gp-Water -B	374-7498

5BS		
Original Part Number	Part Name	Classic Part Number
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-7807	Bearing-Ball	314-8502
6I-1099	Manifold-Exh	424-6366
6Y-9930	Mount As	360-2353

Sales Model 325B (Cont'd.)

5BS		
Original Part Number	Part Name	Classic Part Number
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7K-5448	Cup-Bearing	415-1922
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270

5BS		
Original Part Number	Part Name	Classic Part Number
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6607	Bearing	372-7508
7Y-6626	Bearing	314-8650
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9V-0247	Plate	417-4527
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313

5BS		
Original Part Number	Part Name	Classic Part Number
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
110-7216	Gear-Sun	391-9877
110-7228	Carrier-Planet	390-0918
110-7232	Gear-Sun	417-9472
110-7243	Carrier As	384-5961
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2775	Pin As	418-1967
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5435	Pin As	393-0934
117-5612	Pipe	398-2965
117-6270	Support As	434-1400
117-6675	Step As	419-0881
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
133-2437	Link	377-6199

Sales Model 325B (Cont'd.)

5BS		
Original Part Number	Part Name	Classic Part Number
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
168-8453	Bearing-Spl Ball	417-4497
188-4211	Cylinder As	425-9366

5BS		
Original Part Number	Part Name	Classic Part Number
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
191-3118	Cyl Gp-0170 1680	399-8560
191-3240	Housing-Motor	418-1962
191-3243	Housing-Motor	418-1963
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6269	Bearing-Sleeve	453-6500

5BS		
Original Part Number	Part Name	Classic Part Number
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-7886	Rod As	422-7246
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

5LW		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203

6DN		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
1W-4369	Pulley-Alt	296-1340
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4619	Pin As	425-2564
4I-4811	Pin As	480-8268
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596

6DN		
Original Part Number	Part Name	Classic Part Number
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-7807	Bearing-Ball	314-8502
6I-1099	Manifold-Exh	424-6366
6Y-9930	Mount As	360-2353
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449

6DN		
Original Part Number	Part Name	Classic Part Number
7I-7180	Piston	421-7142
7K-5448	Cup-Bearing	415-1922
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689

Sales Model 325B (Cont'd.)

6DN		
Original Part Number	Part Name	Classic Part Number
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6607	Bearing	372-7508
7Y-6626	Bearing	314-8650
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9S-3581	Cup-Roller Brg	415-1923

6DN		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2775	Pin As	418-1967
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693

6DN		
Original Part Number	Part Name	Classic Part Number
117-5435	Pin As	393-0934
117-5612	Pipe	398-2965
117-6270	Support As	434-1400
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
191-3240	Housing-Motor	418-1962
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589

Sales Model 325B (Cont'd.)

6DN		
Original Part Number	Part Name	Classic Part Number
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969

6DN		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912

6DN		
Original Part Number	Part Name	Classic Part Number
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

7EN		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-4619	Pin As	425-2564
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545

7EN		
Original Part Number	Part Name	Classic Part Number
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349

7EN		
Original Part Number	Part Name	Classic Part Number
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046

Sales Model 325B (Cont'd.)

7EN		
Original Part Number	Part Name	Classic Part Number
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2775	Pin As	418-1967
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5435	Pin As	393-0934
117-6270	Support As	434-1400
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314

7EN		
Original Part Number	Part Name	Classic Part Number
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-8479	Spacer	395-1323
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
191-3240	Housing-Motor	418-1962

7EN		
Original Part Number	Part Name	Classic Part Number
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

8FN		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
1W-4369	Pulley-Alt	296-1340
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-4619	Pin As	425-2564
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-7807	Bearing-Ball	314-8502

8FN		
Original Part Number	Part Name	Classic Part Number
6I-1099	Manifold-Exh	424-6366
6Y-9930	Mount As	360-2353
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7K-5448	Cup-Bearing	415-1922
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986

8FN		
Original Part Number	Part Name	Classic Part Number
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128

Sales Model 325B (Cont'd.)

8FN		
Original Part Number	Part Name	Classic Part Number
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
086-0414	Flange	392-4522

8FN		
Original Part Number	Part Name	Classic Part Number
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2775	Pin As	418-1967
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5435	Pin As	393-0934
117-5612	Pipe	398-2965
117-6270	Support As	434-1400
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
136-0819	Valve-Exhaust	384-8697

8FN		
Original Part Number	Part Name	Classic Part Number
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
191-3240	Housing-Motor	418-1962
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

Sales Model 325B (Cont'd.)

8FN		
Original Part Number	**Part Name**	**Classic Part Number**
357-7540	Valve-Fill	360-2292

8FN		
Original Part Number	**Part Name**	**Classic Part Number**
441-9566	Gear-Flywheel	374-4703

8GM		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-4619	Pin As	425-2564
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689

8GM		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8H-2810	Case As-Filter	314-8512

8GM		
Original Part Number	**Part Name**	**Classic Part Number**
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2775	Pin As	418-1967
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5435	Pin As	393-0934
117-6270	Support As	434-1400
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314

Sales Model 325B (Cont'd.)

8GM		
Original Part Number	Part Name	Classic Part Number
130-9293	Rod	314-8708
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-8479	Spacer	395-1323
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696

8GM		
Original Part Number	Part Name	Classic Part Number
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
191-3240	Housing-Motor	418-1962
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371

8GM		
Original Part Number	Part Name	Classic Part Number
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

8PR		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4I-4619	Pin As	425-2564
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6E-4985	Cover-Filter	424-2015
6I-1099	Manifold-Exh	424-6366
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

8PR		
Original Part Number	Part Name	Classic Part Number
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128

8PR		
Original Part Number	Part Name	Classic Part Number
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266

Sales Model 325B (Cont'd.)

8PR		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
105-1738	Manifold-Exhaust	374-4692
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237

8PR		
Original Part Number	**Part Name**	**Classic Part Number**
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2775	Pin As	418-1967
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5435	Pin As	393-0934
117-5612	Pipe	398-2965
117-6270	Support As	434-1400
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-9461	Pin	392-4528
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
128-9884	Bearing-Sleeve	360-2315
130-9293	Rod	314-8708
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-0162	Bearing-Main	419-6380

8PR		
Original Part Number	**Part Name**	**Classic Part Number**
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
191-3240	Housing-Motor	418-1962
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

ABD		
Original Part Number	**Part Name**	**Classic Part Number**
114-0468	Pin-G.E.T.	443-1203

Sales Model 325C

AMH		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368

AMH		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
186-5652	Pin	392-4532
186-5662	Pin	421-1560
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813

AMH		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BFE		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331

BFE		
Original Part Number	Part Name	Classic Part Number
4I-0704	Bearing-Sleeve	360-2332
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8636	Cone-Bearing	418-9606

BFE		
Original Part Number	Part Name	Classic Part Number
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7K-0078	Bearing-Sleeve	308-9825
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-2348	Pin	314-8697

Sales Model 325C (Cont'd.)

BFE		
Original Part Number	Part Name	Classic Part Number
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3553	Bearing-Sleeve	301-0433
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9F-3212	Bearing-Ball	384-5953
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
101-1530	Bearing-Main	419-6382
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381

BFE		
Original Part Number	Part Name	Classic Part Number
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
119-2863	Pin	314-8698
126-9461	Pin	392-4528
127-3467	Manifold-Exhaust	394-9827
128-9864	Bearing-Sleeve	425-6437
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
186-5652	Pin	392-4532
186-5662	Pin	421-1560
188-4211	Cylinder As	425-9366

BFE		
Original Part Number	Part Name	Classic Part Number
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BKH		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4N-2572	Spider As-Fan	451-9027

BKH		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

BKH		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7I-7181	Piston	393-5217
7K-9592	Bearing-Sleeve	360-2336
7W-9027	Base-Oil Cooler	399-8545

Sales Model 325C (Cont'd.)

BKH		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047

BKH		
Original Part Number	Part Name	Classic Part Number
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
117-6270	Support As	434-1400
123-2111	Piston	462-5714
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
179-3044	Cylinder	385-6138
186-5652	Pin	392-4532
186-5662	Pin	421-1560
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536

BKH		
Original Part Number	Part Name	Classic Part Number
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BKT		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

BKT		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2581	Guard As-Trk Gde	480-8270

BKT		
Original Part Number	Part Name	Classic Part Number
7Y-3428	Bearing-Sleeve	314-8647
7Y-3551	Bearing-Sleeve	380-7375
7Y-5128	Bearing-Sleeve	314-8648
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046

Sales Model 325C (Cont'd.)

BKT		
Original Part Number	Part Name	Classic Part Number
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

BKT		
Original Part Number	Part Name	Classic Part Number
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
186-5652	Pin	392-4532
186-5662	Pin	421-1560
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

BKT		
Original Part Number	Part Name	Classic Part Number
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BKW		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
3G-5285	Bearing-Sleeve	360-2312
4I-0453	Bearing-Sleeve	360-2331
4N-2572	Spider As-Fan	451-9027
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7181	Piston	393-5217
7K-9592	Bearing-Sleeve	360-2336
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556

BKW		
Original Part Number	Part Name	Classic Part Number
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382

BKW		
Original Part Number	Part Name	Classic Part Number
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
117-5612	Pipe	398-2965
117-6270	Support As	434-1400
123-2111	Piston	462-5714
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
137-8479	Spacer	395-1323
145-0162	Bearing-Main	419-6380

Sales Model 325C (Cont'd.)

BKW		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
179-3044	Cylinder	385-6138
186-5652	Pin	392-4532
186-5662	Pin	421-1560
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535

BKW		
Original Part Number	Part Name	Classic Part Number
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6270	Bearing-Sleeve	425-6436

BKW		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BLA		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368

BLA		
Original Part Number	Part Name	Classic Part Number
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

BLA		
Original Part Number	Part Name	Classic Part Number
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2916	Bearing-Sleeve	360-2327
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BLX		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703

Sales Model 325C (Cont'd.)

BLX		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
3G-5285	Bearing-Sleeve	360-2312
4I-0453	Bearing-Sleeve	360-2331
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-2395	Bearing-Sleeve	314-8646
7Y-2581	Guard As-Trk Gde	480-8270
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
087-5805	Pin	301-7967

BLX		
Original Part Number	**Part Name**	**Classic Part Number**
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
128-9863	Bearing-Sleeve	314-8630
128-9884	Bearing-Sleeve	360-2315
133-4995	Gasket-Cyl Head	434-2445
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

BLX		
Original Part Number	**Part Name**	**Classic Part Number**
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
188-4211	Cylinder As	425-9366
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BMM		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4I-4811	Pin As	480-8268
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

BMM		
Original Part Number	**Part Name**	**Classic Part Number**
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7K-9592	Bearing-Sleeve	360-2336
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-2348	Pin	314-8697

BMM		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349

Sales Model 325C (Cont'd.)

BMM		
Original Part Number	Part Name	Classic Part Number
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3553	Bearing-Sleeve	301-0433
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
9F-3212	Bearing-Ball	384-5953
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
119-2863	Pin	314-8698

BMM		
Original Part Number	Part Name	Classic Part Number
123-2111	Piston	462-5714
126-9461	Pin	392-4528
127-3467	Manifold-Exhaust	394-9827
128-9884	Bearing-Sleeve	360-2315
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2821	Bearing-Sleeve	419-4717
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
179-3044	Cylinder	385-6138
186-5652	Pin	392-4532
186-5662	Pin	421-1560
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935

BMM		
Original Part Number	Part Name	Classic Part Number
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BTD		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673

BTD		
Original Part Number	Part Name	Classic Part Number
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571

BTD		
Original Part Number	Part Name	Classic Part Number
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817

Sales Model 325C (Cont'd.)

BTD		
Original Part Number	Part Name	Classic Part Number
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445

BTD		
Original Part Number	Part Name	Classic Part Number
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
186-5652	Pin	392-4532
186-5662	Pin	421-1560
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870

BTD		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

CRB		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-9027	Base-Oil Cooler	399-8545

CRB		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648

CRB		
Original Part Number	Part Name	Classic Part Number
7Y-5131	Bearing-Sleeve	301-4626
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
099-0722	Link As	415-1909
101-1530	Bearing-Main	419-6382
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203

Sales Model 325C (Cont'd.)

CRB		
Original Part Number	Part Name	Classic Part Number
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
119-2863	Pin	314-8698
126-9461	Pin	392-4528
127-3467	Manifold-Exhaust	394-9827
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

CRB		
Original Part Number	Part Name	Classic Part Number
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
179-3044	Cylinder	385-6138
186-5652	Pin	392-4532
186-5662	Pin	421-1560
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322

CRB		
Original Part Number	Part Name	Classic Part Number
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

CSJ		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571

CSJ		
Original Part Number	Part Name	Classic Part Number
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
086-0414	Flange	392-4522
087-5802	Link-Rh	301-7964

CSJ		
Original Part Number	Part Name	Classic Part Number
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
119-2863	Pin	314-8698
126-9461	Pin	392-4528

Sales Model 325C (Cont'd.)

CSJ		
Original Part Number	**Part Name**	**Classic Part Number**
127-3467	Manifold-Exhaust	394-9827
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505

CSJ		
Original Part Number	**Part Name**	**Classic Part Number**
179-3008	Cylinder	480-8272
186-5652	Pin	392-4532
186-5662	Pin	421-1560
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

CSJ		
Original Part Number	**Part Name**	**Classic Part Number**
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

DTF		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7K-0078	Bearing-Sleeve	308-9825
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368

DTF		
Original Part Number	**Part Name**	**Classic Part Number**
9V-0247	Plate	417-4527
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2821	Bearing-Sleeve	419-4717
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

DTF		
Original Part Number	**Part Name**	**Classic Part Number**
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
179-3044	Cylinder	385-6138
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2916	Bearing-Sleeve	360-2327
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 325C (Cont'd.)

G1L		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626

G1L		
Original Part Number	Part Name	Classic Part Number
8W-8512	Pin As	385-7220
101-1530	Bearing-Main	419-6382
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505

G1L		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
186-5652	Pin	392-4532
186-5662	Pin	421-1560
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

JLC		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449

JLC		
Original Part Number	Part Name	Classic Part Number
7I-7180	Piston	421-7142
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636

JLC		
Original Part Number	Part Name	Classic Part Number
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
9V-0247	Plate	417-4527
086-0414	Flange	392-4522
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382

Sales Model 325C (Cont'd.)

JLC		
Original Part Number	Part Name	Classic Part Number
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
119-2863	Pin	314-8698
126-9461	Pin	392-4528
127-3467	Manifold-Exhaust	394-9827
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319

JLC		
Original Part Number	Part Name	Classic Part Number
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
179-3008	Cylinder	480-8272
186-5652	Pin	392-4532
186-5662	Pin	421-1560
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

JLC		
Original Part Number	Part Name	Classic Part Number
236-4413	Pump Gp-Water -B	434-6110
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6277	Bearing-Sleeve	419-0884
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

JLD		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-9027	Base-Oil Cooler	399-8545

JLD		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626

JLD		
Original Part Number	Part Name	Classic Part Number
9V-0247	Plate	417-4527
086-0414	Flange	392-4522
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

Sales Model 325C (Cont'd.)

JLD		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
119-2863	Pin	314-8698
126-9461	Pin	392-4528
127-3467	Manifold-Exhaust	394-9827
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

JLD		
Original Part Number	Part Name	Classic Part Number
163-3749	Bearing-Sleeve	433-7505
179-3044	Cylinder	385-6138
186-5652	Pin	392-4532
186-5662	Pin	421-1560
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

JLD		
Original Part Number	Part Name	Classic Part Number
236-6270	Bearing-Sleeve	425-6436
236-6277	Bearing-Sleeve	419-0884
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

M2K		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765

M2K		
Original Part Number	Part Name	Classic Part Number
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8W-8512	Pin As	385-7220
101-1530	Bearing-Main	419-6382
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445

M2K		
Original Part Number	Part Name	Classic Part Number
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-3749	Bearing-Sleeve	433-7505
179-3044	Cylinder	385-6138
186-5652	Pin	392-4532
186-5662	Pin	421-1560
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

Sales Model 325C (Cont'd.)

M2K		
Original Part Number	**Part Name**	**Classic Part Number**
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2915	Bearing-Sleeve	360-2326

M2K		
Original Part Number	**Part Name**	**Classic Part Number**
240-2916	Bearing-Sleeve	360-2327
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912

M2K		
Original Part Number	**Part Name**	**Classic Part Number**
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

S3M		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4I-4619	Pin As	425-2564
4K-0299	Bearing-Sleeve	308-9816
4K-0300	Bearing-Sleeve	308-9817
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7K-0078	Bearing-Sleeve	308-9825
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368

S3M		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-5128	Bearing-Sleeve	314-8648
8W-8512	Pin As	385-7220
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
118-5196	Pin	380-7397
123-2111	Piston	462-5714
127-3467	Manifold-Exhaust	394-9827
128-9863	Bearing-Sleeve	314-8630
128-9883	Bearing-Sleeve	360-2314
133-4995	Gasket-Cyl Head	434-2445
137-2822	Bearing-Sleeve	453-0971

S3M		
Original Part Number	**Part Name**	**Classic Part Number**
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
156-0738	Rod As	394-8210
179-3044	Cylinder	385-6138
188-4211	Cylinder As	425-9366
192-8318	Bearing-Sleeve	360-2321
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Y4P		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4619	Pin As	425-2564
4W-1203	Cup-Rlr Brg	418-9603

Y4P		
Original Part Number	**Part Name**	**Classic Part Number**
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

Y4P		
Original Part Number	**Part Name**	**Classic Part Number**
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571

Sales Model 325C (Cont'd.)

Y4P		
Original Part Number	Part Name	Classic Part Number
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
127-3467	Manifold-Exhaust	394-9827
128-9863	Bearing-Sleeve	314-8630

Y4P		
Original Part Number	Part Name	Classic Part Number
128-9882	Bearing-Sleeve	314-8642
133-4995	Gasket-Cyl Head	434-2445
137-2822	Bearing-Sleeve	453-0971
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3044	Cylinder	385-6138
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870

Y4P		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 325D

A3R		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368

A3R		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
086-0523	Pin	314-8696
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
133-4995	Gasket-Cyl Head	434-2445
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

A3R		
Original Part Number	Part Name	Classic Part Number
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
244-8504	Pin As	426-0032
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 325D (Cont'd.)

AZP		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
9Y-2988	Breather As	361-1716

AZP		
Original Part Number	Part Name	Classic Part Number
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

AZP		
Original Part Number	Part Name	Classic Part Number
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

C7K		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-5102	Bearing-Sleeve	380-7368

C7K		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
8W-8512	Pin As	385-7220
9Y-2988	Breather As	361-1716
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

C7K		
Original Part Number	Part Name	Classic Part Number
154-8030	Gasket	394-0894
179-3044	Cylinder	385-6138
186-5662	Pin	421-1560
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 325D (Cont'd.)

C8L		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
4I-4619	Pin As	425-2564
4K-0299	Bearing-Sleeve	308-9816
4K-0300	Bearing-Sleeve	308-9817
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7K-0078	Bearing-Sleeve	308-9825
7Y-0225	Shaft-Planet	301-4571
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368

C8L		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
8H-5352	Bearing-Ball	453-3658
8W-8512	Pin As	385-7220
9Y-2988	Breather As	361-1716
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
118-5196	Pin	380-7397
123-2111	Piston	462-5714
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
133-4995	Gasket-Cyl Head	434-2445
137-2822	Bearing-Sleeve	453-0971

C8L		
Original Part Number	Part Name	Classic Part Number
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
156-0738	Rod As	394-8210
179-3044	Cylinder	385-6138
188-4211	Cylinder As	425-9366
192-8318	Bearing-Sleeve	360-2321
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2915	Bearing-Sleeve	360-2326
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

C9M		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
4I-4619	Pin As	425-2564
4K-0299	Bearing-Sleeve	308-9816
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673

C9M		
Original Part Number	Part Name	Classic Part Number
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7K-0078	Bearing-Sleeve	308-9825
7Y-0225	Shaft-Planet	301-4571
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648

C9M		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
9Y-2988	Breather As	361-1716
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

Sales Model 325D (Cont'd.)

C9M		
Original Part Number	**Part Name**	**Classic Part Number**
115-4072	Bearing	397-5069
118-5196	Pin	380-7397
123-2111	Piston	462-5714
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
133-4995	Gasket-Cyl Head	434-2445
137-2822	Bearing-Sleeve	453-0971
145-0162	Bearing-Main	419-6380

C9M		
Original Part Number	**Part Name**	**Classic Part Number**
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
156-0738	Rod As	394-8210
179-3044	Cylinder	385-6138
188-4211	Cylinder As	425-9366
192-8318	Bearing-Sleeve	360-2321
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

C9M		
Original Part Number	**Part Name**	**Classic Part Number**
236-4413	Pump Gp-Water -B	434-6110
240-2915	Bearing-Sleeve	360-2326
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

CJM		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4811	Pin As	480-8268
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
9Y-2988	Breather As	361-1716

CJM		
Original Part Number	**Part Name**	**Classic Part Number**
087-5805	Pin	301-7967
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

CJM		
Original Part Number	**Part Name**	**Classic Part Number**
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2912	Bearing-Sleeve	418-1969
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

CYW		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603

CYW		
Original Part Number	**Part Name**	**Classic Part Number**
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

CYW		
Original Part Number	**Part Name**	**Classic Part Number**
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336

Sales Model 325D (Cont'd.)

CYW		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368
9Y-2988	Breather As	361-1716
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069

CYW		
Original Part Number	Part Name	Classic Part Number
117-5612	Pipe	398-2965
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372

CYW		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

DAP		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4811	Pin As	480-8268
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
9Y-2988	Breather As	361-1716
086-0414	Flange	392-4522
086-0523	Pin	314-8696

DAP		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272

DAP		
Original Part Number	Part Name	Classic Part Number
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2912	Bearing-Sleeve	418-1969
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

DBH		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703

Sales Model 325D (Cont'd.)

DBH		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
9Y-2988	Breather As	361-1716
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381

DBH		
Original Part Number	Part Name	Classic Part Number
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272

DBH		
Original Part Number	Part Name	Classic Part Number
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

ERK		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368

ERK		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

ERK		
Original Part Number	Part Name	Classic Part Number
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

GBR		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703

Sales Model 325D (Cont'd.)

GBR		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4811	Pin As	480-8268
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7Y-0225	Shaft-Planet	301-4571
7Y-2349	Pin	301-4556
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
9Y-2988	Breather As	361-1716
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967

GBR		
Original Part Number	Part Name	Classic Part Number
101-1530	Bearing-Main	419-6382
107-2139	Pin As.	360-2352
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
119-2863	Pin	314-8698
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
179-3044	Cylinder	385-6138
186-5662	Pin	421-1560

GBR		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
228-5621	Bearing-Sleeve	360-2323
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6269	Bearing-Sleeve	453-6500
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

GPB		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

GPB		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368
7Y-5131	Bearing-Sleeve	301-4626
9Y-2988	Breather As	361-1716
086-0523	Pin	314-8696
087-5805	Pin	301-7967
099-0722	Link As	415-1909
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381

GPB		
Original Part Number	Part Name	Classic Part Number
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
119-2863	Pin	314-8698
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318

Sales Model 325D (Cont'd.)

GPB		
Original Part Number	**Part Name**	**Classic Part Number**
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295

GPB		
Original Part Number	**Part Name**	**Classic Part Number**
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

GPB		
Original Part Number	**Part Name**	**Classic Part Number**
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

KBE		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
9Y-2988	Breather As	361-1716
101-1530	Bearing-Main	419-6382

KBE		
Original Part Number	**Part Name**	**Classic Part Number**
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

KBE		
Original Part Number	**Part Name**	**Classic Part Number**
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

KDG		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

KDG		
Original Part Number	**Part Name**	**Classic Part Number**
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
9Y-2988	Breather As	361-1716

KDG		
Original Part Number	**Part Name**	**Classic Part Number**
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069

Sales Model 325D (Cont'd.)

KDG		
Original Part Number	Part Name	Classic Part Number
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

KDG		
Original Part Number	Part Name	Classic Part Number
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370

KDG		
Original Part Number	Part Name	Classic Part Number
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

LAL		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368
9Y-2988	Breather As	361-1716

LAL		
Original Part Number	Part Name	Classic Part Number
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

LAL		
Original Part Number	Part Name	Classic Part Number
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

MCL		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4811	Pin As	480-8268
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673

MCL		
Original Part Number	Part Name	Classic Part Number
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368

MCL		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

Sales Model 325D (Cont'd.)

MCL		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
119-2863	Pin	314-8698
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

MCL		
Original Part Number	Part Name	Classic Part Number
154-8030	Gasket	394-0894
179-3044	Cylinder	385-6138
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

MCL		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

NAC		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368
9Y-2988	Breather As	361-1716

NAC		
Original Part Number	Part Name	Classic Part Number
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

NAC		
Original Part Number	Part Name	Classic Part Number
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

PAL		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

PAL		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

PAL		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368

Sales Model 325D (Cont'd.)

PAL		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445

PAL		
Original Part Number	Part Name	Classic Part Number
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295

PAL		
Original Part Number	Part Name	Classic Part Number
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

PEH		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
3G-5285	Bearing-Sleeve	360-2312
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626

PEH		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
087-5533	Bearing-Sleeve	314-8628
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272

PEH		
Original Part Number	Part Name	Classic Part Number
186-5662	Pin	421-1560
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6269	Bearing-Sleeve	453-6500
240-2912	Bearing-Sleeve	418-1969
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

PKE		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703

Sales Model 325D (Cont'd.)

PKE		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4811	Pin As	480-8268
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368
9Y-2988	Breather As	361-1716
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382

PKE		
Original Part Number	**Part Name**	**Classic Part Number**
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
119-2863	Pin	314-8698
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560

PKE		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

SCR		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
9Y-2988	Breather As	361-1716
086-0414	Flange	392-4522
086-0523	Pin	314-8696

SCR		
Original Part Number	**Part Name**	**Classic Part Number**
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
119-2863	Pin	314-8698
126-9461	Pin	392-4528
127-3467	Manifold-Exhaust	394-9827
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445

SCR		
Original Part Number	**Part Name**	**Classic Part Number**
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

Sales Model 325D (Cont'd.)

SCR		
Original Part Number	Part Name	Classic Part Number
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

SCR		
Original Part Number	Part Name	Classic Part Number
244-8504	Pin As	426-0032
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710

SCR		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

T2S		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368
9Y-2988	Breather As	361-1716

T2S		
Original Part Number	Part Name	Classic Part Number
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

T2S		
Original Part Number	Part Name	Classic Part Number
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 325F

XAA		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
7Y-1644	Gear-Planet	301-3406
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
119-2863	Pin	314-8698
145-3037	Support	480-8271

XAA		
Original Part Number	Part Name	Classic Part Number
148-4634	Shaft-Planet	360-2274
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275

XAA		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 325F (Cont'd.)

YCA		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
7Y-1644	Gear-Planet	301-3406
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
119-2863	Pin	314-8698

YCA		
Original Part Number	**Part Name**	**Classic Part Number**
145-3037	Support	480-8271
148-4634	Shaft-Planet	360-2274
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275

YCA		
Original Part Number	**Part Name**	**Classic Part Number**
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 326D

JFL		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729

JFL		
Original Part Number	**Part Name**	**Classic Part Number**
134-8950	Plate	399-8587
134-8951	Plate	382-5061
186-5730	Pin	393-3688
240-2913	Bearing-Sleeve	360-2325

JFL		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KGY		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
086-0523	Pin	314-8696
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

KGY		
Original Part Number	**Part Name**	**Classic Part Number**
117-5553	Guard As-Tck Gde	419-4729
134-8950	Plate	399-8587
134-8951	Plate	382-5061
186-5730	Pin	393-3688
189-3922	Pin	393-0938

KGY		
Original Part Number	**Part Name**	**Classic Part Number**
227-6789	Bearing-Sleeve	360-2322
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MGW		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
086-0523	Pin	314-8696
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729

MGW		
Original Part Number	**Part Name**	**Classic Part Number**
134-8950	Plate	399-8587
134-8951	Plate	382-5061
186-5730	Pin	393-3688
189-3922	Pin	393-0938
223-3095	Gauge As	360-2295
227-6789	Bearing-Sleeve	360-2322

MGW		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 326D (Cont'd.)

NBX		
Original Part Number	Part Name	Classic Part Number
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
086-0523	Pin	314-8696
114-1383	Shaft-Planet	398-8349

NBX		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
186-5730	Pin	393-3688

NBX		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
227-6789	Bearing-Sleeve	360-2322
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PJM		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
9Y-2988	Breather As	361-1716
086-0523	Pin	314-8696
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381

PJM		
Original Part Number	Part Name	Classic Part Number
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5553	Guard As-Tck Gde	419-4729
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
186-5730	Pin	393-3688
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372

PJM		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2913	Bearing-Sleeve	360-2325
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

REC		
Original Part Number	Part Name	Classic Part Number
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
086-0523	Pin	314-8696
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349

REC		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5553	Guard As-Tck Gde	419-4729
134-8950	Plate	399-8587
134-8951	Plate	382-5061

REC		
Original Part Number	Part Name	Classic Part Number
186-5730	Pin	393-3688
189-3922	Pin	393-0938
227-6789	Bearing-Sleeve	360-2322
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 326F

HCJ		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268

Sales Model 326F (Cont'd.)

HCJ		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5805	Pin	301-7967
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

HCJ		
Original Part Number	**Part Name**	**Classic Part Number**
119-2863	Pin	314-8698
134-8950	Plate	399-8587
134-8951	Plate	382-5061
186-5730	Pin	393-3688
189-3922	Pin	393-0938
240-2912	Bearing-Sleeve	418-1969

HCJ		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SGK		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
086-0414	Flange	392-4522
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

SGK		
Original Part Number	**Part Name**	**Classic Part Number**
134-8950	Plate	399-8587
134-8951	Plate	382-5061
186-5730	Pin	393-3688
189-3922	Pin	393-0938
240-2913	Bearing-Sleeve	360-2325

SGK		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TMR		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
086-0414	Flange	392-4522
086-0523	Pin	314-8696
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349

TMR		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
134-8950	Plate	399-8587
134-8951	Plate	382-5061
186-5730	Pin	393-3688

TMR		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TPG		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

TPG		
Original Part Number	**Part Name**	**Classic Part Number**
134-8950	Plate	399-8587
186-5730	Pin	393-3688

TPG		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WGL		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
086-0414	Flange	392-4522
086-0523	Pin	314-8696
114-0468	Pin-G.E.T.	443-1203

WGL		
Original Part Number	**Part Name**	**Classic Part Number**
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
134-8950	Plate	399-8587
186-5730	Pin	393-3688
189-3922	Pin	393-0938

WGL		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 326F (Cont'd.)

XFK		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
7Y-0225	Shaft-Planet	301-4571
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5805	Pin	301-7967
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349

XFK		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698
134-8950	Plate	399-8587
134-8951	Plate	382-5061
186-5730	Pin	393-3688
189-3922	Pin	393-0938

XFK		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 328D

BYH		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7181	Piston	393-5217
7Y-0225	Shaft-Planet	301-4571
9Y-2988	Breather As	361-1716
087-5847	Bearing-Sleeve	314-8629

BYH		
Original Part Number	Part Name	Classic Part Number
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589

BYH		
Original Part Number	Part Name	Classic Part Number
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
228-5621	Bearing-Sleeve	360-2323
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2916	Bearing-Sleeve	360-2327
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

GTN		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

GTN		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
9Y-2988	Breather As	361-1716
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047

GTN		
Original Part Number	Part Name	Classic Part Number
114-1383	Shaft-Planet	398-8349
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

Sales Model 328D (Cont'd.)

GTN		
Original Part Number	**Part Name**	**Classic Part Number**
179-3044	Cylinder	385-6138
186-5662	Pin	421-1560
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371

GTN		
Original Part Number	**Part Name**	**Classic Part Number**
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2913	Bearing-Sleeve	360-2325
240-2916	Bearing-Sleeve	360-2327

GTN		
Original Part Number	**Part Name**	**Classic Part Number**
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

MKR		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7181	Piston	393-5217
7Y-0225	Shaft-Planet	301-4571
9Y-2988	Breather As	361-1716
087-5847	Bearing-Sleeve	314-8629

MKR		
Original Part Number	**Part Name**	**Classic Part Number**
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3044	Cylinder	385-6138
186-5662	Pin	421-1560

MKR		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2916	Bearing-Sleeve	360-2327
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

RMX		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

RMX		
Original Part Number	**Part Name**	**Classic Part Number**
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
9Y-2988	Breather As	361-1716
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445

RMX		
Original Part Number	**Part Name**	**Classic Part Number**
134-8950	Plate	399-8587
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3044	Cylinder	385-6138
186-5662	Pin	421-1560
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870

Sales Model 328D (Cont'd.)

RMX		
Original Part Number	Part Name	Classic Part Number
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

RMX		
Original Part Number	Part Name	Classic Part Number
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348

RMX		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

SWF		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
9Y-2988	Breather As	361-1716
087-5978	Flange	374-3496

SWF		
Original Part Number	Part Name	Classic Part Number
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3044	Cylinder	385-6138
186-5662	Pin	421-1560

SWF		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2916	Bearing-Sleeve	360-2327
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 329D

BBF		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4811	Pin As	480-8268
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

BBF		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
9Y-2988	Breather As	361-1716
087-5805	Pin	301-7967
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046

BBF		
Original Part Number	Part Name	Classic Part Number
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

Sales Model 329D (Cont'd.)

BBF		
Original Part Number	Part Name	Classic Part Number
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295

BBF		
Original Part Number	Part Name	Classic Part Number
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2912	Bearing-Sleeve	418-1969

BBF		
Original Part Number	Part Name	Classic Part Number
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BFC		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368
9Y-2988	Breather As	361-1716

BFC		
Original Part Number	Part Name	Classic Part Number
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

BFC		
Original Part Number	Part Name	Classic Part Number
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

BYS		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

BYS		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
9Y-2988	Breather As	361-1716
086-0523	Pin	314-8696
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203

BYS		
Original Part Number	Part Name	Classic Part Number
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380

Sales Model 329D (Cont'd.)

BYS		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870

BYS		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

BYS		
Original Part Number	Part Name	Classic Part Number
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

CZF		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368
9Y-2988	Breather As	361-1716

CZF		
Original Part Number	Part Name	Classic Part Number
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

CZF		
Original Part Number	Part Name	Classic Part Number
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

DJF		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

DJF		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
9Y-2988	Breather As	361-1716
086-0523	Pin	314-8696
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381

DJF		
Original Part Number	Part Name	Classic Part Number
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445

Sales Model 329D (Cont'd.)

DJF		
Original Part Number	**Part Name**	**Classic Part Number**
134-8950	Plate	399-8587
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938

DJF		
Original Part Number	**Part Name**	**Classic Part Number**
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

DJF		
Original Part Number	**Part Name**	**Classic Part Number**
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

DTZ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270

DTZ		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-2988	Breather As	361-1716
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

DTZ		
Original Part Number	**Part Name**	**Classic Part Number**
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

EBM		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

EBM		
Original Part Number	**Part Name**	**Classic Part Number**
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368
9Y-2988	Breather As	361-1716

EBM		
Original Part Number	**Part Name**	**Classic Part Number**
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965

Sales Model 329D (Cont'd.)

EBM		
Original Part Number	Part Name	Classic Part Number
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

EBM		
Original Part Number	Part Name	Classic Part Number
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

EBM		
Original Part Number	Part Name	Classic Part Number
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

JHJ		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368
9Y-2988	Breather As	361-1716

JHJ		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
133-4995	Gasket-Cyl Head	434-2445
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

JHJ		
Original Part Number	Part Name	Classic Part Number
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
244-8504	Pin As	426-0032
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

KJB		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349

KJB		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
134-8950	Plate	399-8587
134-8951	Plate	382-5061
179-3008	Cylinder	480-8272

KJB		
Original Part Number	Part Name	Classic Part Number
186-5662	Pin	421-1560
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 329D (Cont'd.)

LFW		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5128	Bearing-Sleeve	314-8648
9Y-2988	Breather As	361-1716

LFW		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560

LFW		
Original Part Number	**Part Name**	**Classic Part Number**
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6269	Bearing-Sleeve	453-6500
240-2912	Bearing-Sleeve	418-1969
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

MNB		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368

MNB		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-2988	Breather As	361-1716
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
119-2863	Pin	314-8698

MNB		
Original Part Number	**Part Name**	**Classic Part Number**
126-9461	Pin	392-4528
127-3467	Manifold-Exhaust	394-9827
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870

Sales Model 329D (Cont'd.)

MNB		
Original Part Number	**Part Name**	**Classic Part Number**
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

MNB		
Original Part Number	**Part Name**	**Classic Part Number**
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
255-2899	Pipe As-Tail	301-5246

MNB		
Original Part Number	**Part Name**	**Classic Part Number**
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

RGA		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
086-0523	Pin	314-8696
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349

RGA		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
134-8950	Plate	399-8587
134-8951	Plate	382-5061
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560

RGA		
Original Part Number	**Part Name**	**Classic Part Number**
227-6789	Bearing-Sleeve	360-2322
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RSK		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368
9Y-2988	Breather As	361-1716

RSK		
Original Part Number	**Part Name**	**Classic Part Number**
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

RSK		
Original Part Number	**Part Name**	**Classic Part Number**
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
244-8504	Pin As	426-0032
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

SCY		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703

Sales Model 329D (Cont'd.)

SCY		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368
9Y-2988	Breather As	361-1716
101-1530	Bearing-Main	419-6382

SCY		
Original Part Number	**Part Name**	**Classic Part Number**
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

SCY		
Original Part Number	**Part Name**	**Classic Part Number**
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

SHJ		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
086-0523	Pin	314-8696
114-0468	Pin-G.E.T.	443-1203

SHJ		
Original Part Number	**Part Name**	**Classic Part Number**
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
134-8950	Plate	399-8587
134-8951	Plate	382-5061
179-3008	Cylinder	480-8272

SHJ		
Original Part Number	**Part Name**	**Classic Part Number**
186-5662	Pin	421-1560
189-3922	Pin	393-0938
227-6789	Bearing-Sleeve	360-2322
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TAY		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4811	Pin As	480-8268
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

TAY		
Original Part Number	**Part Name**	**Classic Part Number**
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
9Y-2988	Breather As	361-1716
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5805	Pin	301-7967
087-5978	Flange	374-3496

TAY		
Original Part Number	**Part Name**	**Classic Part Number**
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587

Sales Model 329D (Cont'd.)

TAY		
Original Part Number	Part Name	Classic Part Number
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372

TAY		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

TAY		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

THW		
Original Part Number	Part Name	Classic Part Number
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
086-0523	Pin	314-8696
114-0468	Pin-G.E.T.	443-1203

THW		
Original Part Number	Part Name	Classic Part Number
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
134-8950	Plate	399-8587
134-8951	Plate	382-5061
179-3008	Cylinder	480-8272

THW		
Original Part Number	Part Name	Classic Part Number
186-5662	Pin	421-1560
189-3922	Pin	393-0938
227-6789	Bearing-Sleeve	360-2322
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TMJ		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
086-0523	Pin	314-8696
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349

TMJ		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
134-8950	Plate	399-8587
134-8951	Plate	382-5061
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560

TMJ		
Original Part Number	Part Name	Classic Part Number
227-6789	Bearing-Sleeve	360-2322
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TPM		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

TPM		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368
9Y-2988	Breather As	361-1716
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047

TPM		
Original Part Number	Part Name	Classic Part Number
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380

Sales Model 329D (Cont'd.)

TPM		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372

TPM		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

TPM		
Original Part Number	Part Name	Classic Part Number
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

TZL		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
9Y-2988	Breather As	361-1716

TZL		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

TZL		
Original Part Number	Part Name	Classic Part Number
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

WDK		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

WDK		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
9Y-2988	Breather As	361-1716
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046

WDK		
Original Part Number	Part Name	Classic Part Number
109-9369	Mount-Rubber	393-1047
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399

Sales Model 329D (Cont'd.)

WDK		
Original Part Number	Part Name	Classic Part Number
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938

WDK		
Original Part Number	Part Name	Classic Part Number
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

WDK		
Original Part Number	Part Name	Classic Part Number
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

WDT		
Original Part Number	Part Name	Classic Part Number
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
086-0523	Pin	314-8696

WDT		
Original Part Number	Part Name	Classic Part Number
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
179-3008	Cylinder	480-8272

WDT		
Original Part Number	Part Name	Classic Part Number
186-5662	Pin	421-1560
189-3922	Pin	393-0938
227-6789	Bearing-Sleeve	360-2322
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WLT		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368
9Y-2988	Breather As	361-1716

WLT		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

WLT		
Original Part Number	Part Name	Classic Part Number
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 329D (Cont'd.)

XDB		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368
9Y-2988	Breather As	361-1716
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628

XDB		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

XDB		
Original Part Number	Part Name	Classic Part Number
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

YFW		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
9Y-2988	Breather As	361-1716
086-0414	Flange	392-4522

YFW		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
087-5978	Flange	374-3496
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5612	Pipe	398-2965
133-4995	Gasket-Cyl Head	434-2445
134-8950	Plate	399-8587
134-8951	Plate	382-5061
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3008	Cylinder	480-8272

YFW		
Original Part Number	Part Name	Classic Part Number
186-5662	Pin	421-1560
189-3922	Pin	393-0938
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 329E

K2L		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5102	Bearing-Sleeve	380-7368
114-1383	Shaft-Planet	398-8349

K2L		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
134-8950	Plate	399-8587
137-2817	Bearing-Sleeve	434-2399

K2L		
Original Part Number	**Part Name**	**Classic Part Number**
179-3008	Cylinder	480-8272
179-3044	Cylinder	385-6138
186-5662	Pin	421-1560
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KNR		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

KNR		
Original Part Number	**Part Name**	**Classic Part Number**
117-5612	Pipe	398-2965
137-2820	Bearing-Sleeve	360-2318
179-3008	Cylinder	480-8272

KNR		
Original Part Number	**Part Name**	**Classic Part Number**
240-2915	Bearing-Sleeve	360-2326
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LTM		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

LTM		
Original Part Number	**Part Name**	**Classic Part Number**
117-5612	Pipe	398-2965
179-3008	Cylinder	480-8272

LTM		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PLW		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
086-0523	Pin	314-8696
114-1383	Shaft-Planet	398-8349

PLW		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399

PLW		
Original Part Number	**Part Name**	**Classic Part Number**
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
193-5016	Flange	425-3644
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PTY		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
086-0523	Pin	314-8696
087-5978	Flange	374-3496

PTY		
Original Part Number	**Part Name**	**Classic Part Number**
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
134-8950	Plate	399-8587

PTY		
Original Part Number	**Part Name**	**Classic Part Number**
134-8951	Plate	382-5061
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 329E (Cont'd.)

RDX		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
086-0414	Flange	392-4522
086-0523	Pin	314-8696

RDX		
Original Part Number	**Part Name**	**Classic Part Number**
087-5978	Flange	374-3496
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
134-8950	Plate	399-8587

RDX		
Original Part Number	**Part Name**	**Classic Part Number**
134-8951	Plate	382-5061
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RLD		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
086-0523	Pin	314-8696
087-5978	Flange	374-3496
114-1383	Shaft-Planet	398-8349

RLD		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
134-8950	Plate	399-8587
134-8951	Plate	382-5061
179-3008	Cylinder	480-8272

RLD		
Original Part Number	**Part Name**	**Classic Part Number**
186-5662	Pin	421-1560
189-3922	Pin	393-0938
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TST		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
086-0523	Pin	314-8696
087-5978	Flange	374-3496
114-1383	Shaft-Planet	398-8349

TST		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399

TST		
Original Part Number	**Part Name**	**Classic Part Number**
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WJK		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
086-0414	Flange	392-4522
086-0523	Pin	314-8696

WJK		
Original Part Number	**Part Name**	**Classic Part Number**
087-5978	Flange	374-3496
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
134-8950	Plate	399-8587

WJK		
Original Part Number	**Part Name**	**Classic Part Number**
134-8951	Plate	382-5061
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ZCD		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571

ZCD		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-2581	Guard As-Trk Gde	480-8270
7Y-5131	Bearing-Sleeve	301-4626

ZCD		
Original Part Number	**Part Name**	**Classic Part Number**
086-0414	Flange	392-4522
086-0523	Pin	314-8696
114-1383	Shaft-Planet	398-8349

Sales Model 329E (Cont'd.)

ZCD		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
134-8950	Plate	399-8587
134-8951	Plate	382-5061

ZCD		
Original Part Number	Part Name	Classic Part Number
137-2817	Bearing-Sleeve	434-2399
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938

ZCD		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
250-2402	Pin As	360-2351
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 329F

ERL		
Original Part Number	Part Name	Classic Part Number
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
086-0414	Flange	392-4522
086-0523	Pin	314-8696

ERL		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
134-8950	Plate	399-8587
179-3008	Cylinder	480-8272

ERL		
Original Part Number	Part Name	Classic Part Number
186-5662	Pin	421-1560
189-3922	Pin	393-0938
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GCX		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
086-0523	Pin	314-8696
114-1383	Shaft-Planet	398-8349

GCX		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
179-3008	Cylinder	480-8272

GCX		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GKK		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

GKK		
Original Part Number	Part Name	Classic Part Number
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560

GKK		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LBN		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
086-0523	Pin	314-8696
114-1383	Shaft-Planet	398-8349

LBN		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560

LBN		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 329F (Cont'd.)

RCN		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5978	Flange	374-3496

RCN		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
134-8950	Plate	399-8587

RCN		
Original Part Number	Part Name	Classic Part Number
134-8951	Plate	382-5061
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WBA		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
086-0523	Pin	314-8696
114-1383	Shaft-Planet	398-8349

WBA		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560

WBA		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

YHA		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
087-5978	Flange	374-3496
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349

YHA		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
134-8950	Plate	399-8587
134-8951	Plate	382-5061
179-3008	Cylinder	480-8272

YHA		
Original Part Number	Part Name	Classic Part Number
186-5662	Pin	421-1560
189-3922	Pin	393-0938
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ZNN		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5978	Flange	374-3496

ZNN		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
117-5612	Pipe	398-2965
134-8950	Plate	399-8587

ZNN		
Original Part Number	Part Name	Classic Part Number
134-8951	Plate	382-5061
179-3008	Cylinder	480-8272
186-5662	Pin	421-1560
189-3922	Pin	393-0938
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 330

2EL		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572

2EL		
Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

2EL		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515

Sales Model 330 (Cont'd.)

2EL		
Original Part Number	Part Name	Classic Part Number
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-4444	Bearing	419-6029
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-7401	Spring	380-7414

2EL		
Original Part Number	Part Name	Classic Part Number
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5I-3371	Pin As	393-3668
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358

2EL		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-0896	Cover	424-0128
7Y-0912	Bearing-Rlr As	417-4513
7Y-1035	Mount	383-2118
7Y-1100	Bearing-Roller	394-8226
7Y-1215	Coupling	422-3512

Sales Model 330 (Cont'd.)

2EL		
Original Part Number	Part Name	Classic Part Number
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1461	Coupling	301-4649
7Y-1738	Support	443-5198
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6389	Bearing	372-7507
7Y-6607	Bearing	372-7508
7Y-6608	Bearing	314-8649
7Y-6626	Bearing	314-8650
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893

2EL		
Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050

2EL		
Original Part Number	Part Name	Classic Part Number
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-0247	Plate	417-4527
9Y-1798	Seal-Water	379-0165
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
087-6372	Pin	396-7284
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-7860	Valve-Inlet	270-4360
103-5345	Bearing-Sleeve	393-3640
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
110-7228	Carrier-Planet	390-0918
110-7232	Gear-Sun	417-9472
110-7243	Carrier As	384-5961
111-8015	Gasket As-Head	279-4977
113-2966	Pin As	380-7398
114-0468	Pin-G.E.T.	443-1203
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
131-3815	Seal Gp-Basic	325-6193
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381

Sales Model 330 (Cont'd.)

2EL		
Original Part Number	Part Name	Classic Part Number
137-2819	Bearing-Sleeve	360-2317
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
168-8453	Bearing-Spl Ball	417-4497
169-1750	Seal Gp-Basic	472-8022

2EL		
Original Part Number	Part Name	Classic Part Number
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
188-4211	Cylinder As	425-9366
191-3240	Housing-Motor	418-1962
191-3243	Housing-Motor	418-1963
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

2EL		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
232-3233	Bearing-Main	376-9085
236-6270	Bearing-Sleeve	425-6436
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

2ZM		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
1T-0210	Bearing-Ball	417-4498
1W-1064	Gear-Flywheel	374-4703
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513

2ZM		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2K-6413	Pin	360-2270
2L-4238	Mount-Flexible	385-7222
2L-4444	Bearing	419-6029
2N-1599	Gear	378-3970
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2R-0524	Cone-Bearing	422-6484

2ZM		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267
4I-4666	Bearing-Sleeve	388-0640
4I-4807	Pin	383-2139
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4I-7401	Spring	380-7414
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027

Sales Model 330 (Cont'd.)

2ZM		
Original Part Number	Part Name	Classic Part Number
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-3683	Pump Gp-Water -B	374-7498
4P-7688	Valve As-Check	420-6216
4P-7790	Shaft As-Arm	457-4596
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8577	Rod As-Injector	455-5513
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5I-3371	Pin As	393-3668
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

2ZM		
Original Part Number	Part Name	Classic Part Number
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1099	Manifold-Exh	424-6366
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-4297	Seal As-Cshaft	325-6192
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-7344	Muffler As	360-7886
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964

2ZM		
Original Part Number	Part Name	Classic Part Number
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-8443	Muffler	247-2675
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8064	Valve-Inlet	384-8705
7W-9020	Bell As-Pump Suc	378-3989
7W-9027	Base-Oil Cooler	399-8545
7Y-0207	Cylinder	383-1584
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-0912	Bearing-Rlr As	417-4513
7Y-1035	Mount	383-2118
7Y-1100	Bearing-Roller	394-8226
7Y-1215	Coupling	422-3512
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671

Sales Model 330 (Cont'd.)

2ZM		
Original Part Number	Part Name	Classic Part Number
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1738	Support	443-5198
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893

2ZM		
Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196

2ZM		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
087-6372	Pin	396-7284
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382
102-8112	Cylinder	360-2276
103-5345	Bearing-Sleeve	393-3640
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
110-7216	Gear-Sun	391-9877
110-7228	Carrier-Planet	390-0918
110-7232	Gear-Sun	417-9472
110-7243	Carrier As	384-5961
111-8015	Gasket As-Head	279-4977
113-2966	Pin As	380-7398
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
118-5196	Pin	380-7397
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311

Sales Model 330 (Cont'd.)

2ZM		
Original Part Number	Part Name	Classic Part Number
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
130-9293	Rod	314-8708
131-3815	Seal Gp-Basic	325-6193
134-3038	Gasket Kit	437-3228
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
148-7455	Valve - Exhaust	270-4361
152-3952	Impeller-Pump	374-4696

2ZM		
Original Part Number	Part Name	Classic Part Number
163-1387	Gear-Flywheel	374-4697
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
168-8453	Bearing-Spl Ball	417-4497
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
187-0605	Gasket Kit - Cl	382-5055
188-4211	Cylinder As	425-9366
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962

2ZM		
Original Part Number	Part Name	Classic Part Number
191-3243	Housing-Motor	418-1963
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3233	Bearing-Main	376-9085
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

5YM		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1V-8241	Bearing-Sleeve	308-9808
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

5YM		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

5YM		
Original Part Number	Part Name	Classic Part Number
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354

Sales Model 330 (Cont'd.)

5YM		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
2L-4444	Bearing	419-6029
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2R-0524	Cone-Bearing	422-6484
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-3521	Bearing	380-7513
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267
4I-4666	Bearing-Sleeve	388-0640
4I-4807	Pin	383-2139
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4I-7401	Spring	380-7414
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009

5YM		
Original Part Number	Part Name	Classic Part Number
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4T-8054	Seal As	472-8010
4V-8520	Bearing-Sleeve	307-1527
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5I-3371	Pin As	393-3668
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

5YM		
Original Part Number	Part Name	Classic Part Number
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0912	Bearing-Rlr As	417-4513
7Y-1035	Mount	383-2118
7Y-1100	Bearing-Roller	394-8226
7Y-1215	Coupling	422-3512
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1461	Coupling	301-4649
7Y-1738	Support	443-5198
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556

Sales Model 330 (Cont'd.)

5YM		
Original Part Number	Part Name	Classic Part Number
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

5YM		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568

5YM		
Original Part Number	Part Name	Classic Part Number
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
087-6372	Pin	396-7284
100-7860	Valve-Inlet	270-4360
103-5345	Bearing-Sleeve	393-3640
110-7228	Carrier-Planet	390-0918
110-7232	Gear-Sun	417-9472
110-7243	Carrier As	384-5961
111-8015	Gasket As-Head	279-4977
113-2966	Pin As	380-7398
114-0468	Pin-G.E.T.	443-1203
115-6400	Spring	399-8564
118-5196	Pin	380-7397
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
131-3815	Seal Gp-Basic	325-6193
134-3038	Gasket Kit	437-3228
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126

Sales Model 330 (Cont'd.)

5YM		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
168-8453	Bearing-Spl Ball	417-4497
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

5YM		
Original Part Number	Part Name	Classic Part Number
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
187-0605	Gasket Kit - Cl	382-5055
188-4211	Cylinder As	425-9366
191-3243	Housing-Motor	418-1963
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
232-3233	Bearing-Main	376-9085

5YM		
Original Part Number	Part Name	Classic Part Number
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

6SK		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2K-6413	Pin	360-2270
2L-4444	Bearing	419-6029
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164

6SK		
Original Part Number	Part Name	Classic Part Number
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268

6SK		
Original Part Number	Part Name	Classic Part Number
4I-4807	Pin	383-2139
4I-7401	Spring	380-7414
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690

Sales Model 330 (Cont'd.)

6SK		
Original Part Number	Part Name	Classic Part Number
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5I-3371	Pin As	393-3668
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686

6SK		
Original Part Number	Part Name	Classic Part Number
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0912	Bearing-Rlr As	417-4513
7Y-1035	Mount	383-2118
7Y-1100	Bearing-Roller	394-8226
7Y-1215	Coupling	422-3512
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1461	Coupling	301-4649
7Y-1738	Support	443-5198
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308

6SK		
Original Part Number	Part Name	Classic Part Number
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

Sales Model 330 (Cont'd.)

6SK		
Original Part Number	Part Name	Classic Part Number
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
087-6372	Pin	396-7284
100-7860	Valve-Inlet	270-4360
103-5345	Bearing-Sleeve	393-3640
109-9463	Muffler As	360-7864
111-8015	Gasket As-Head	279-4977

6SK		
Original Part Number	Part Name	Classic Part Number
113-2966	Pin As	380-7398
114-0468	Pin-G.E.T.	443-1203
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
131-3815	Seal Gp-Basic	325-6193
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484

6SK		
Original Part Number	Part Name	Classic Part Number
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
188-4211	Cylinder As	425-9366
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
232-3233	Bearing-Main	376-9085
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

6WJ		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

6WJ		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036

6WJ		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354

Sales Model 330 (Cont'd.)

6WJ		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
2L-4444	Bearing	419-6029
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-7401	Spring	380-7414
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984

6WJ		
Original Part Number	Part Name	Classic Part Number
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5I-3371	Pin As	393-3668
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574

6WJ		
Original Part Number	Part Name	Classic Part Number
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0912	Bearing-Rlr As	417-4513
7Y-1035	Mount	383-2118
7Y-1100	Bearing-Roller	394-8226
7Y-1215	Coupling	422-3512
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1461	Coupling	301-4649
7Y-1738	Support	443-5198
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817

Sales Model 330 (Cont'd.)

6WJ		
Original Part Number	Part Name	Classic Part Number
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349

6WJ		
Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
087-6372	Pin	396-7284
100-7860	Valve-Inlet	270-4360
103-5345	Bearing-Sleeve	393-3640
111-8015	Gasket As-Head	279-4977
113-2966	Pin As	380-7398
114-0468	Pin-G.E.T.	443-1203
128-9864	Bearing-Sleeve	425-6437

6WJ		
Original Part Number	Part Name	Classic Part Number
128-9882	Bearing-Sleeve	314-8642
131-3815	Seal Gp-Basic	325-6193
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
188-4211	Cylinder As	425-9366
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589

Sales Model 330 (Cont'd.)

6WJ		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
232-3233	Bearing-Main	376-9085
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317

6WJ		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988

6WJ		
Original Part Number	Part Name	Classic Part Number
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

6ZK		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-4444	Bearing	419-6029
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357

6ZK		
Original Part Number	Part Name	Classic Part Number
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-7401	Spring	380-7414
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691

6ZK		
Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5I-3371	Pin As	393-3668
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206

Sales Model 330 (Cont'd.)

6ZK		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0912	Bearing-Rlr As	417-4513
7Y-1035	Mount	383-2118
7Y-1100	Bearing-Roller	394-8226
7Y-1215	Coupling	422-3512
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1461	Coupling	301-4649
7Y-1738	Support	443-5198
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375

6ZK		
Original Part Number	Part Name	Classic Part Number
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377

6ZK		
Original Part Number	Part Name	Classic Part Number
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-0247	Plate	417-4527
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
087-6372	Pin	396-7284
100-7860	Valve-Inlet	270-4360
103-5345	Bearing-Sleeve	393-3640
111-8015	Gasket As-Head	279-4977
113-2966	Pin As	380-7398
114-0468	Pin-G.E.T.	443-1203
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
131-3815	Seal Gp-Basic	325-6193
134-8949	Plate	383-2110

Sales Model 330 (Cont'd.)

6ZK		
Original Part Number	Part Name	Classic Part Number
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

6ZK		
Original Part Number	Part Name	Classic Part Number
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-3044	Cylinder	385-6138
188-4211	Cylinder As	425-9366

6ZK		
Original Part Number	Part Name	Classic Part Number
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
232-3233	Bearing-Main	376-9085
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

8CK		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-4444	Bearing	419-6029
2P-0220	Gasket-Pump	398-2927

8CK		
Original Part Number	Part Name	Classic Part Number
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2R-0524	Cone-Bearing	422-6484
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356

8CK		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-7401	Spring	380-7414
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

Sales Model 330 (Cont'd.)

8CK		
Original Part Number	Part Name	Classic Part Number
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5I-3371	Pin As	393-3668
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7E-9980	Camshaft	377-5851

8CK		
Original Part Number	Part Name	Classic Part Number
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0912	Bearing-Rlr As	417-4513
7Y-1035	Mount	383-2118
7Y-1100	Bearing-Roller	394-8226
7Y-1215	Coupling	422-3512
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1461	Coupling	301-4649
7Y-1738	Support	443-5198
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-3427	Bearing-Sleeve	314-8635

8CK		
Original Part Number	Part Name	Classic Part Number
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047

Sales Model 330 (Cont'd.)

8CK		
Original Part Number	**Part Name**	**Classic Part Number**
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-0247	Plate	417-4527
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967

8CK		
Original Part Number	**Part Name**	**Classic Part Number**
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
087-6372	Pin	396-7284
100-7860	Valve-Inlet	270-4360
103-5345	Bearing-Sleeve	393-3640
111-8015	Gasket As-Head	279-4977
113-2966	Pin As	380-7398
114-0468	Pin-G.E.T.	443-1203
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
131-3815	Seal Gp-Basic	325-6193
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127

8CK		
Original Part Number	**Part Name**	**Classic Part Number**
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
188-4211	Cylinder As	425-9366
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
232-3233	Bearing-Main	376-9085
236-6270	Bearing-Sleeve	425-6436
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

8FK		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978

Sales Model 330 (Cont'd.)

8FK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1S-9209	Shaft-Tightener	374-6499
1V-8241	Bearing-Sleeve	308-9808
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5910	Tappet As-Guide&	383-1569
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2K-6413	Pin	360-2270
2L-4444	Bearing	419-6029
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

8FK		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2R-0524	Cone-Bearing	422-6484
2S-6150	Cover-Pulley	428-8817
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7455	Gear As	396-9957
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
3G-3521	Bearing	380-7513
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4I-7401	Spring	380-7414
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271

8FK		
Original Part Number	Part Name	Classic Part Number
4N-4782	Pulley	325-6176
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-7693	Crankshaft As	269-8763
4P-2383	Adapter-Inlet	438-1812
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4T-8054	Seal As	472-8010
4V-8520	Bearing-Sleeve	307-1527
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318

Sales Model 330 (Cont'd.)

8FK		
Original Part Number	Part Name	Classic Part Number
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5I-3371	Pin As	393-3668
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-5976	Kit-Gasket (Rs)	393-5200

8FK		
Original Part Number	Part Name	Classic Part Number
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996

8FK		
Original Part Number	Part Name	Classic Part Number
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5687	Hub-Cshft	314-8684
7W-5733	Gasket	421-7333
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-0896	Cover	424-0128
7Y-0912	Bearing-Rlr As	417-4513
7Y-1035	Mount	383-2118
7Y-1100	Bearing-Roller	394-8226
7Y-1215	Coupling	422-3512
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1461	Coupling	301-4649
7Y-1738	Support	443-5198
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266

Sales Model 330 (Cont'd.)

8FK		
Original Part Number	Part Name	Classic Part Number
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1726	Rod As-Conn	379-8866
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232

8FK		
Original Part Number	Part Name	Classic Part Number
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8258	Bearing-Sleeve	452-1077
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5839	Coupling-Exhaust	374-7480
9L-5908	Gasket	433-8196
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496

8FK		
Original Part Number	Part Name	Classic Part Number
087-6372	Pin	396-7284
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-7860	Valve-Inlet	270-4360
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-7354	Manifold-Exhaust	386-3060
102-3927	Muffler As	420-6219
102-8608	Manifold-Exhaust	376-9062
103-5345	Bearing-Sleeve	393-3640
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
110-7228	Carrier-Planet	390-0918
110-7232	Gear-Sun	417-9472
110-7243	Carrier As	384-5961
111-8015	Gasket As-Head	279-4977
113-2966	Pin As	380-7398
114-0468	Pin-G.E.T.	443-1203
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
118-5196	Pin	380-7397
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
128-2922	Kit-Gasket (Wp)	386-3814
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314

Sales Model 330 (Cont'd.)

8FK		
Original Part Number	Part Name	Classic Part Number
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
135-4928	Shaft-Water Pump	386-3813
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
148-7455	Valve - Exhaust	270-4361
160-9874	Kit-Gasket-Scl	386-3048
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
166-9142	Gasket	420-8546
167-8123	Damper As	299-2006
167-8126	Damper As	382-8019

8FK		
Original Part Number	Part Name	Classic Part Number
168-4531	Body As-Piston	477-7127
168-8453	Bearing-Spl Ball	417-4497
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
188-4211	Cylinder As	425-9366
191-3240	Housing-Motor	418-1962
191-3243	Housing-Motor	418-1963
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013

8FK		
Original Part Number	Part Name	Classic Part Number
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
223-3095	Gauge As	360-2295
232-3233	Bearing-Main	376-9085
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
253-1752	Plate-Thrust	379-0170
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
430-7619	Adapter-Cla	438-1812

8RL		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

8RL		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659

8RL		
Original Part Number	Part Name	Classic Part Number
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

Sales Model 330 (Cont'd.)

8RL		
Original Part Number	Part Name	Classic Part Number
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2K-6413	Pin	360-2270
2L-4444	Bearing	419-6029
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-7401	Spring	380-7414
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

8RL		
Original Part Number	Part Name	Classic Part Number
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5I-3371	Pin As	393-3668
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991

8RL		
Original Part Number	Part Name	Classic Part Number
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0912	Bearing-Rlr As	417-4513
7Y-1035	Mount	383-2118
7Y-1100	Bearing-Roller	394-8226
7Y-1215	Coupling	422-3512
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1461	Coupling	301-4649
7Y-1738	Support	443-5198
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646

Sales Model 330 (Cont'd.)

8RL		
Original Part Number	Part Name	Classic Part Number
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047

8RL		
Original Part Number	Part Name	Classic Part Number
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
087-6372	Pin	396-7284
100-7860	Valve-Inlet	270-4360
103-5345	Bearing-Sleeve	393-3640
109-9463	Muffler As	360-7864

8RL		
Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As-Head	279-4977
113-2966	Pin As	380-7398
114-0468	Pin-G.E.T.	443-1203
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
131-3815	Seal Gp-Basic	325-6193
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835

Sales Model 330 (Cont'd.)

8RL		
Original Part Number	Part Name	Classic Part Number
172-7767	Pump Gp-Water -B	296-1365
188-4211	Cylinder As	425-9366
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589

8RL		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
232-3233	Bearing-Main	376-9085
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357

8RL		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

9ML		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2K-6413	Pin	360-2270
2L-4444	Bearing	419-6029
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872

9ML		
Original Part Number	Part Name	Classic Part Number
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-7401	Spring	380-7414
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985

9ML		
Original Part Number	Part Name	Classic Part Number
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5I-3371	Pin As	393-3668
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358

Sales Model 330 (Cont'd.)

9ML		
Original Part Number	Part Name	Classic Part Number
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0912	Bearing-Rlr As	417-4513
7Y-1035	Mount	383-2118
7Y-1100	Bearing-Roller	394-8226
7Y-1215	Coupling	422-3512
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209

9ML		
Original Part Number	Part Name	Classic Part Number
7Y-1461	Coupling	301-4649
7Y-1738	Support	443-5198
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

9ML		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568

Sales Model 330 (Cont'd.)

9ML		
Original Part Number	Part Name	Classic Part Number
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
087-6372	Pin	396-7284
100-7860	Valve-Inlet	270-4360
103-5345	Bearing-Sleeve	393-3640
109-9463	Muffler As	360-7864
111-8015	Gasket As-Head	279-4977
113-2966	Pin As	380-7398
114-0468	Pin-G.E.T.	443-1203
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
131-3815	Seal Gp-Basic	325-6193
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971

9ML		
Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574

9ML		
Original Part Number	Part Name	Classic Part Number
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
188-4211	Cylinder As	425-9366
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
232-3233	Bearing-Main	376-9085
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

9NG		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036

9NG		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2K-6413	Pin	360-2270
2L-4444	Bearing	419-6029
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

9NG		
Original Part Number	Part Name	Classic Part Number
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439

Sales Model 330 (Cont'd.)

9NG		
Original Part Number	Part Name	Classic Part Number
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-7401	Spring	380-7414
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5I-3371	Pin As	393-3668
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024

9NG		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277

9NG		
Original Part Number	Part Name	Classic Part Number
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0912	Bearing-Rlr As	417-4513
7Y-1035	Mount	383-2118
7Y-1100	Bearing-Roller	394-8226
7Y-1215	Coupling	422-3512
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1461	Coupling	301-4649
7Y-1738	Support	443-5198
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212

Sales Model 330 (Cont'd.)

9NG		
Original Part Number	Part Name	Classic Part Number
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587

9NG		
Original Part Number	Part Name	Classic Part Number
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
087-6372	Pin	396-7284
100-7860	Valve-Inlet	270-4360
103-5345	Bearing-Sleeve	393-3640
111-8015	Gasket As-Head	279-4977
113-2966	Pin As	380-7398
114-0468	Pin-G.E.T.	443-1203
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
131-3815	Seal Gp-Basic	325-6193
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126

9NG		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-3044	Cylinder	385-6138
188-4211	Cylinder As	425-9366
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
232-3233	Bearing-Main	376-9085
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 330 (Cont'd.)

9PJ		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2K-6413	Pin	360-2270
2L-4444	Bearing	419-6029
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216

9PJ		
Original Part Number	Part Name	Classic Part Number
4I-4665	Bearing-Sleeve	364-5267
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-7401	Spring	380-7414
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5I-3371	Pin As	393-3668
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360

9PJ		
Original Part Number	Part Name	Classic Part Number
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895

Sales Model 330 (Cont'd.)

9PJ		
Original Part Number	Part Name	Classic Part Number
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0912	Bearing-Rlr As	417-4513
7Y-1035	Mount	383-2118
7Y-1100	Bearing-Roller	394-8226
7Y-1215	Coupling	422-3512
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1461	Coupling	301-4649
7Y-1738	Support	443-5198
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037

9PJ		
Original Part Number	Part Name	Classic Part Number
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895

9PJ		
Original Part Number	Part Name	Classic Part Number
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
087-6372	Pin	396-7284
100-7860	Valve-Inlet	270-4360
103-5345	Bearing-Sleeve	393-3640
109-9463	Muffler As	360-7864
111-8015	Gasket As-Head	279-4977
113-2966	Pin As	380-7398
114-0468	Pin-G.E.T.	443-1203
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
131-3815	Seal Gp-Basic	325-6193
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

Sales Model 330 (Cont'd.)

9PJ		
Original Part Number	**Part Name**	**Classic Part Number**
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

9PJ		
Original Part Number	**Part Name**	**Classic Part Number**
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
188-4211	Cylinder As	425-9366
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
232-3233	Bearing-Main	376-9085

9PJ		
Original Part Number	**Part Name**	**Classic Part Number**
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

9WJ		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2K-6413	Pin	360-2270
2L-4444	Bearing	419-6029
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229

9WJ		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2R-0524	Cone-Bearing	422-6484
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272

9WJ		
Original Part Number	**Part Name**	**Classic Part Number**
4I-7401	Spring	380-7414
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4T-8054	Seal As	472-8010

Sales Model 330 (Cont'd.)

9WJ		
Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5I-3371	Pin As	393-3668
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531

9WJ		
Original Part Number	Part Name	Classic Part Number
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-0896	Cover	424-0128
7Y-0912	Bearing-Rlr As	417-4513
7Y-1035	Mount	383-2118
7Y-1100	Bearing-Roller	394-8226
7Y-1215	Coupling	422-3512
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1461	Coupling	301-4649
7Y-1738	Support	443-5198
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350

9WJ		
Original Part Number	Part Name	Classic Part Number
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585

Sales Model 330 (Cont'd.)

9WJ		
Original Part Number	Part Name	Classic Part Number
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
087-6372	Pin	396-7284
100-7860	Valve-Inlet	270-4360
103-5345	Bearing-Sleeve	393-3640
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
110-7228	Carrier-Planet	390-0918

9WJ		
Original Part Number	Part Name	Classic Part Number
110-7232	Gear-Sun	417-9472
110-7243	Carrier As	384-5961
111-8015	Gasket As-Head	279-4977
113-2966	Pin As	380-7398
114-0468	Pin-G.E.T.	443-1203
118-5196	Pin	380-7397
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
131-3815	Seal Gp-Basic	325-6193
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127

9WJ		
Original Part Number	Part Name	Classic Part Number
168-8453	Bearing-Spl Ball	417-4497
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-3044	Cylinder	385-6138
188-4211	Cylinder As	425-9366
191-3240	Housing-Motor	418-1962
191-3243	Housing-Motor	418-1963
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
232-3233	Bearing-Main	376-9085
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 330B

1JS		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-5285	Bearing-Sleeve	360-2312
3L-1425	Bearing-Ball	311-9356
4I-0453	Bearing-Sleeve	360-2331

1JS		
Original Part Number	Part Name	Classic Part Number
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267
4I-4666	Bearing-Sleeve	388-0640
4I-7401	Spring	380-7414
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

1JS		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-4985	Cover-Filter	424-2015
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0912	Bearing-Rlr As	417-4513
7Y-1100	Bearing-Roller	394-8226
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209

Sales Model 330B (Cont'd.)

1JS		
Original Part Number	Part Name	Classic Part Number
7Y-1738	Support	443-5198
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290

1JS		
Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
087-5978	Flange	374-3496
087-6372	Pin	396-7284
100-7860	Valve-Inlet	270-4360
103-5345	Bearing-Sleeve	393-3640
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
109-9463	Muffler As	360-7864
110-7228	Carrier-Planet	390-0918
110-7232	Gear-Sun	417-9472
110-7243	Carrier As	384-5961
111-8015	Gasket As-Head	279-4977
113-2966	Pin As	380-7398
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
117-6270	Support As	434-1400
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642

1JS		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
168-8453	Bearing-Spl Ball	417-4497
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687

Sales Model 330B (Cont'd.)

1JS		
Original Part Number	**Part Name**	**Classic Part Number**
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
191-3118	Cyl Gp-0170 1680	399-8560
191-3243	Housing-Motor	418-1963

1JS		
Original Part Number	**Part Name**	**Classic Part Number**
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
232-3233	Bearing-Main	376-9085
236-6277	Bearing-Sleeve	419-0884
247-8853	Cyl Gp-0150 1156	399-8583

1JS		
Original Part Number	**Part Name**	**Classic Part Number**
247-8856	Rod As	395-1317
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
391-8229	Kit-Gasket-Fs	398-2955

2RR		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230

2RR		
Original Part Number	**Part Name**	**Classic Part Number**
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-5285	Bearing-Sleeve	360-2312
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-7401	Spring	380-7414
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008

2RR		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

Sales Model 330B (Cont'd.)

2RR		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0912	Bearing-Rlr As	417-4513
7Y-1100	Bearing-Roller	394-8226
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1738	Support	443-5198

2RR		
Original Part Number	Part Name	Classic Part Number
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232

2RR		
Original Part Number	Part Name	Classic Part Number
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5978	Flange	374-3496
087-6372	Pin	396-7284
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-7860	Valve-Inlet	270-4360
103-5345	Bearing-Sleeve	393-3640
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
109-9463	Muffler As	360-7864
110-7228	Carrier-Planet	390-0918
110-7232	Gear-Sun	417-9472
110-7243	Carrier As	384-5961
111-8015	Gasket As-Head	279-4977

Sales Model 330B (Cont'd.)

2RR		
Original Part Number	Part Name	Classic Part Number
113-2966	Pin As	380-7398
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
117-6270	Support As	434-1400
123-2111	Piston	462-5714
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
131-3815	Seal Gp-Basic	325-6193
134-3038	Gasket Kit	437-3228
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
137-3060	Bearing-Sleeve	360-2320
142-0226	Kit-Gasket-Fs	393-1034
142-0227	Gasket Kit	437-4608
142-0228	Gasket Kit - Sch	393-1035
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125

2RR		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
168-8453	Bearing-Spl Ball	417-4497
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
187-0605	Gasket Kit - Cl	382-5055
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
191-3118	Cyl Gp-0170 1680	399-8560

2RR		
Original Part Number	Part Name	Classic Part Number
191-3243	Housing-Motor	418-1963
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
232-3233	Bearing-Main	376-9085
236-6277	Bearing-Sleeve	419-0884
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

3YR		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659

3YR		
Original Part Number	Part Name	Classic Part Number
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354

3YR		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

Sales Model 330B (Cont'd.)

3YR		
Original Part Number	Part Name	Classic Part Number
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4I-7401	Spring	380-7414
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987

3YR		
Original Part Number	Part Name	Classic Part Number
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-9930	Mount As	360-2353
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951

3YR		
Original Part Number	Part Name	Classic Part Number
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0912	Bearing-Rlr As	417-4513
7Y-1100	Bearing-Roller	394-8226
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1738	Support	443-5198
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433

Sales Model 330B (Cont'd.)

3YR		
Original Part Number	Part Name	Classic Part Number
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

3YR		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9931	Mount As.	360-2354
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
087-5978	Flange	374-3496
087-6372	Pin	396-7284
100-7860	Valve-Inlet	270-4360
103-5345	Bearing-Sleeve	393-3640
107-2139	Pin As.	360-2352
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
109-9463	Muffler As	360-7864
110-7228	Carrier-Planet	390-0918
110-7232	Gear-Sun	417-9472
110-7243	Carrier As	384-5961
111-8015	Gasket As-Head	279-4977
113-2966	Pin As	380-7398
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815

3YR		
Original Part Number	Part Name	Classic Part Number
117-5435	Pin As	393-0934
117-6270	Support As	434-1400
119-2863	Pin	314-8698
123-2111	Piston	462-5714
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3038	Gasket Kit	437-3228
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
142-0226	Kit-Gasket-Fs	393-1034
142-0227	Gasket Kit	437-4608
142-0228	Gasket Kit - Sch	393-1035
143-5447	Gasket Kit - F	393-1036
143-5448	Gasket Kit - Sch	447-8652
148-7455	Valve - Exhaust	270-4361
148-9810	Gasket Kit	393-3631
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351

Sales Model 330B (Cont'd.)

3YR		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
168-8453	Bearing-Spl Ball	417-4497
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835

3YR		
Original Part Number	Part Name	Classic Part Number
172-7767	Pump Gp-Water -B	296-1365
187-0605	Gasket Kit - Cl	382-5055
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
191-3118	Cyl Gp-0170 1680	399-8560
191-3243	Housing-Motor	418-1963
192-8318	Bearing-Sleeve	360-2321
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
232-3233	Bearing-Main	376-9085

3YR		
Original Part Number	Part Name	Classic Part Number
236-6270	Bearing-Sleeve	425-6436
236-6277	Bearing-Sleeve	419-0884
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

4RS		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354

4RS		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678

4RS		
Original Part Number	Part Name	Classic Part Number
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-1524	Cylinder As	394-8216
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4I-7401	Spring	380-7414
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176

Sales Model 330B (Cont'd.)

4RS		
Original Part Number	Part Name	Classic Part Number
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

4RS		
Original Part Number	Part Name	Classic Part Number
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-9930	Mount As	360-2353
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0912	Bearing-Rlr As	417-4513
7Y-1100	Bearing-Roller	394-8226
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1738	Support	443-5198
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556

4RS		
Original Part Number	Part Name	Classic Part Number
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623

Sales Model 330B (Cont'd.)

4RS		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-0247	Plate	417-4527
9W-9931	Mount As.	360-2354
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568

4RS		
Original Part Number	Part Name	Classic Part Number
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
087-6372	Pin	396-7284
100-7860	Valve-Inlet	270-4360
103-5345	Bearing-Sleeve	393-3640
107-2139	Pin As.	360-2352
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
109-9463	Muffler As	360-7864
110-7228	Carrier-Planet	390-0918
110-7232	Gear-Sun	417-9472
110-7243	Carrier As	384-5961
111-8015	Gasket As-Head	279-4977
113-2966	Pin As	380-7398
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
117-6270	Support As	434-1400
117-6675	Step As	419-0881
119-2863	Pin	314-8698
123-2111	Piston	462-5714
126-9461	Pin	392-4528
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
131-3815	Seal Gp-Basic	325-6193
133-2437	Link	377-6199
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-8950	Plate	399-8587

4RS		
Original Part Number	Part Name	Classic Part Number
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
137-2919	Bearing-Sleeve	360-2319
142-0226	Kit-Gasket-Fs	393-1034
142-0227	Gasket Kit	437-4608
143-5447	Gasket Kit - F	393-1036
143-5448	Gasket Kit - Sch	447-8652
148-7455	Valve - Exhaust	270-4361
148-9810	Gasket Kit	393-3631
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
168-8453	Bearing-Spl Ball	417-4497
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

Sales Model 330B (Cont'd.)

4RS		
Original Part Number	Part Name	Classic Part Number
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
187-0605	Gasket Kit - Cl	382-5055
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
191-3118	Cyl Gp-0170 1680	399-8560
191-3243	Housing-Motor	418-1963
192-8318	Bearing-Sleeve	360-2321
196-0028	Gear As-Idler	364-5259

4RS		
Original Part Number	Part Name	Classic Part Number
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
232-3233	Bearing-Main	376-9085
236-6270	Bearing-Sleeve	425-6436
236-6277	Bearing-Sleeve	419-0884
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032

4RS		
Original Part Number	Part Name	Classic Part Number
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
391-8229	Kit-Gasket-Fs	398-2955

5EZ		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229

5EZ		
Original Part Number	Part Name	Classic Part Number
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-5285	Bearing-Sleeve	360-2312
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216
4I-7401	Spring	380-7414
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763

5EZ		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024

Sales Model 330B (Cont'd.)

5EZ		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584

5EZ		
Original Part Number	Part Name	Classic Part Number
7Y-0912	Bearing-Rlr As	417-4513
7Y-1100	Bearing-Roller	394-8226
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1738	Support	443-5198
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349

5EZ		
Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
087-5978	Flange	374-3496
087-6372	Pin	396-7284
100-7860	Valve-Inlet	270-4360
103-5345	Bearing-Sleeve	393-3640
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
109-9463	Muffler As	360-7864
110-7228	Carrier-Planet	390-0918
110-7232	Gear-Sun	417-9472
110-7243	Carrier As	384-5961
111-8015	Gasket As-Head	279-4977
113-2966	Pin As	380-7398
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
117-6270	Support As	434-1400
128-9882	Bearing-Sleeve	314-8642

Sales Model 330B (Cont'd.)

5EZ		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2818	Bearing-Sleeve	380-7381
137-2821	Bearing-Sleeve	419-4717
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
168-8453	Bearing-Spl Ball	417-4497
169-1750	Seal Gp-Basic	472-8022

5EZ		
Original Part Number	Part Name	Classic Part Number
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
191-3118	Cyl Gp-0170 1680	399-8560
191-3243	Housing-Motor	418-1963
192-8318	Bearing-Sleeve	360-2321

5EZ		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
232-3233	Bearing-Main	376-9085
236-6277	Bearing-Sleeve	419-0884
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
391-8229	Kit-Gasket-Fs	398-2955

5LR		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927

5LR		
Original Part Number	Part Name	Classic Part Number
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439

5LR		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4I-7401	Spring	380-7414
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

Sales Model 330B (Cont'd.)

5LR		
Original Part Number	Part Name	Classic Part Number
4P-7830	Gear-Oil Drive	472-8009
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-9930	Mount As	360-2353
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531

5LR		
Original Part Number	Part Name	Classic Part Number
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0912	Bearing-Rlr As	417-4513
7Y-1100	Bearing-Roller	394-8226
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1738	Support	443-5198
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626

5LR		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050

Sales Model 330B (Cont'd.)

5LR		
Original Part Number	Part Name	Classic Part Number
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9931	Mount As.	360-2354
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
087-5978	Flange	374-3496
087-6372	Pin	396-7284
100-7860	Valve-Inlet	270-4360
103-5345	Bearing-Sleeve	393-3640
107-2139	Pin As.	360-2352
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
109-9463	Muffler As	360-7864
110-7228	Carrier-Planet	390-0918
110-7232	Gear-Sun	417-9472
110-7243	Carrier As	384-5961
111-8015	Gasket As-Head	279-4977
113-2966	Pin As	380-7398
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
117-6270	Support As	434-1400
119-2863	Pin	314-8698
123-2111	Piston	462-5714
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007

5LR		
Original Part Number	Part Name	Classic Part Number
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
142-0226	Kit-Gasket-Fs	393-1034
142-0227	Gasket Kit	437-4608
143-5447	Gasket Kit - F	393-1036
143-5448	Gasket Kit - Sch	447-8652
148-7455	Valve - Exhaust	270-4361
148-9810	Gasket Kit	393-3631
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
168-8453	Bearing-Spl Ball	417-4497
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

5LR		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
187-0605	Gasket Kit - Cl	382-5055
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
191-3118	Cyl Gp-0170 1680	399-8560
191-3243	Housing-Motor	418-1963
192-8318	Bearing-Sleeve	360-2321
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
232-3233	Bearing-Main	376-9085
236-6270	Bearing-Sleeve	425-6436
236-6277	Bearing-Sleeve	419-0884
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 330B (Cont'd.)

5LS		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332

5LS		
Original Part Number	Part Name	Classic Part Number
4I-1524	Cylinder As	394-8216
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-4811	Pin As	480-8268
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4I-7401	Spring	380-7414
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

5LS		
Original Part Number	Part Name	Classic Part Number
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-9930	Mount As	360-2353
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0912	Bearing-Rlr As	417-4513
7Y-1100	Bearing-Roller	394-8226
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1738	Support	443-5198
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647

Sales Model 330B (Cont'd.)

5LS		
Original Part Number	Part Name	Classic Part Number
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6607	Bearing	372-7508
7Y-6626	Bearing	314-8650
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349

5LS		
Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-0247	Plate	417-4527
9W-9931	Mount As.	360-2354
9Y-1798	Seal-Water	379-0165
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
087-6372	Pin	396-7284
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-7860	Valve-Inlet	270-4360

5LS		
Original Part Number	Part Name	Classic Part Number
103-5345	Bearing-Sleeve	393-3640
107-2139	Pin As.	360-2352
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
109-9463	Muffler As	360-7864
110-7228	Carrier-Planet	390-0918
110-7232	Gear-Sun	417-9472
110-7243	Carrier As	384-5961
111-8015	Gasket As-Head	279-4977
113-2966	Pin As	380-7398
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
117-6270	Support As	434-1400
117-6675	Step As	419-0881
119-2863	Pin	314-8698
123-2111	Piston	462-5714
126-9461	Pin	392-4528
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
131-3815	Seal Gp-Basic	325-6193
133-2437	Link	377-6199
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317

Sales Model 330B (Cont'd.)

5LS		
Original Part Number	**Part Name**	**Classic Part Number**
137-2820	Bearing-Sleeve	360-2318
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
137-2919	Bearing-Sleeve	360-2319
142-0226	Kit-Gasket-Fs	393-1034
142-0227	Gasket Kit	437-4608
143-5447	Gasket Kit - F	393-1036
143-5448	Gasket Kit - Sch	447-8652
148-7455	Valve - Exhaust	270-4361
148-9810	Gasket Kit	393-3631
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
168-8453	Bearing-Spl Ball	417-4497
169-1750	Seal Gp-Basic	472-8022

5LS		
Original Part Number	**Part Name**	**Classic Part Number**
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
187-0605	Gasket Kit - Cl	382-5055
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
191-3118	Cyl Gp-0170 1680	399-8560
191-3243	Housing-Motor	418-1963
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589

5LS		
Original Part Number	**Part Name**	**Classic Part Number**
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
232-3233	Bearing-Main	376-9085
236-6270	Bearing-Sleeve	425-6436
236-6277	Bearing-Sleeve	419-0884
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
391-8229	Kit-Gasket-Fs	398-2955

6DR		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221

6DR		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357

6DR		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439

Sales Model 330B (Cont'd.)

6DR		
Original Part Number	Part Name	Classic Part Number
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3L-1425	Bearing-Ball	311-9356
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267
4I-4666	Bearing-Sleeve	388-0640
4I-4807	Pin	383-2139
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4I-7401	Spring	380-7414
4K-0299	Bearing-Sleeve	308-9816
4K-0300	Bearing-Sleeve	308-9817
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691

6DR		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-4985	Cover-Filter	424-2015
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-9930	Mount As	360-2353
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7K-0078	Bearing-Sleeve	308-9825
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951

6DR		
Original Part Number	Part Name	Classic Part Number
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-8736	Pipe-Ext Exhaust	382-5066
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0912	Bearing-Rlr As	417-4513
7Y-1100	Bearing-Roller	394-8226
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1461	Coupling	301-4649
7Y-1738	Support	443-5198
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308

Sales Model 330B (Cont'd.)

6DR		
Original Part Number	Part Name	Classic Part Number
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

6DR		
Original Part Number	Part Name	Classic Part Number
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9F-3212	Bearing-Ball	384-5953
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9931	Mount As.	360-2354
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
087-6372	Pin	396-7284
100-7860	Valve-Inlet	270-4360
103-5345	Bearing-Sleeve	393-3640
105-2659	Bearing-Sleeve	419-2304
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
109-9463	Muffler As	360-7864
110-7228	Carrier-Planet	390-0918
110-7232	Gear-Sun	417-9472
110-7243	Carrier As	384-5961
111-8015	Gasket As-Head	279-4977

6DR		
Original Part Number	Part Name	Classic Part Number
113-2966	Pin As	380-7398
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-6400	Spring	399-8564
117-5435	Pin As	393-0934
117-6270	Support As	434-1400
118-5196	Pin	380-7397
123-2111	Piston	462-5714
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3038	Gasket Kit	437-3228
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
142-0226	Kit-Gasket-Fs	393-1034
142-0227	Gasket Kit	437-4608
142-0228	Gasket Kit - Sch	393-1035
148-7455	Valve - Exhaust	270-4361
156-0738	Rod As	394-8210

Sales Model 330B (Cont'd.)

6DR		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
168-8453	Bearing-Spl Ball	417-4497
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835

6DR		
Original Part Number	Part Name	Classic Part Number
172-7767	Pump Gp-Water -B	296-1365
179-3044	Cylinder	385-6138
187-0605	Gasket Kit - Cl	382-5055
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
191-3118	Cyl Gp-0170 1680	399-8560
191-3243	Housing-Motor	418-1963
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
201-4802	Sleeve	419-2309
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085

6DR		
Original Part Number	Part Name	Classic Part Number
236-6270	Bearing-Sleeve	425-6436
236-6277	Bearing-Sleeve	419-0884
240-2915	Bearing-Sleeve	360-2326
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

8SR		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

8SR		
Original Part Number	Part Name	Classic Part Number
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230

8SR		
Original Part Number	Part Name	Classic Part Number
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267
4I-4666	Bearing-Sleeve	388-0640

Sales Model 330B (Cont'd.)

8SR		
Original Part Number	Part Name	Classic Part Number
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-7401	Spring	380-7414
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535

8SR		
Original Part Number	Part Name	Classic Part Number
6E-4985	Cover-Filter	424-2015
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0912	Bearing-Rlr As	417-4513
7Y-1100	Bearing-Roller	394-8226
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1738	Support	443-5198
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647

8SR		
Original Part Number	Part Name	Classic Part Number
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232

Sales Model 330B (Cont'd.)

8SR		
Original Part Number	Part Name	Classic Part Number
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5978	Flange	374-3496
087-6372	Pin	396-7284
100-7860	Valve-Inlet	270-4360
103-5345	Bearing-Sleeve	393-3640
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
109-9463	Muffler As	360-7864
110-7228	Carrier-Planet	390-0918
110-7232	Gear-Sun	417-9472
110-7243	Carrier As	384-5961
111-8015	Gasket As-Head	279-4977
113-2966	Pin As	380-7398
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
117-6270	Support As	434-1400

8SR		
Original Part Number	Part Name	Classic Part Number
123-2111	Piston	462-5714
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
168-8453	Bearing-Spl Ball	417-4497
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

8SR		
Original Part Number	Part Name	Classic Part Number
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
187-0605	Gasket Kit - Cl	382-5055
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
191-3118	Cyl Gp-0170 1680	399-8560
191-3243	Housing-Motor	418-1963
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
232-3233	Bearing-Main	376-9085
236-6277	Bearing-Sleeve	419-0884
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 330B (Cont'd.)

8TR		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-5285	Bearing-Sleeve	360-2312
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267

8TR		
Original Part Number	Part Name	Classic Part Number
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-7401	Spring	380-7414
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

8TR		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-4985	Cover-Filter	424-2015
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0912	Bearing-Rlr As	417-4513
7Y-1100	Bearing-Roller	394-8226
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1738	Support	443-5198

Sales Model 330B (Cont'd.)

8TR		
Original Part Number	Part Name	Classic Part Number
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290

8TR		
Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5978	Flange	374-3496
087-6372	Pin	396-7284
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
100-7860	Valve-Inlet	270-4360
103-5345	Bearing-Sleeve	393-3640
106-6878	Pin	372-7510
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
109-9463	Muffler As	360-7864
110-7228	Carrier-Planet	390-0918
110-7232	Gear-Sun	417-9472
110-7243	Carrier As	384-5961

8TR		
Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As-Head	279-4977
113-2966	Pin As	380-7398
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
117-6270	Support As	434-1400
123-2111	Piston	462-5714
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3038	Gasket Kit	437-3228
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
137-3060	Bearing-Sleeve	360-2320
142-0226	Kit-Gasket-Fs	393-1034
142-0227	Gasket Kit	437-4608
142-0228	Gasket Kit - Sch	393-1035
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125

Sales Model 330B (Cont'd.)

8TR		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
168-8453	Bearing-Spl Ball	417-4497
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835

8TR		
Original Part Number	Part Name	Classic Part Number
187-0605	Gasket Kit - Cl	382-5055
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
191-3118	Cyl Gp-0170 1680	399-8560
191-3243	Housing-Motor	418-1963
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
201-4802	Sleeve	419-2309
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658

8TR		
Original Part Number	Part Name	Classic Part Number
232-3233	Bearing-Main	376-9085
236-6277	Bearing-Sleeve	419-0884
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

9HN		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927

9HN		
Original Part Number	Part Name	Classic Part Number
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-5285	Bearing-Sleeve	360-2312

9HN		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-7401	Spring	380-7414
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009

Sales Model 330B (Cont'd.)

9HN		
Original Part Number	Part Name	Classic Part Number
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217

9HN		
Original Part Number	Part Name	Classic Part Number
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0207	Cylinder	383-1584
7Y-0912	Bearing-Rlr As	417-4513
7Y-1100	Bearing-Roller	394-8226
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1738	Support	443-5198
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648

9HN		
Original Part Number	Part Name	Classic Part Number
7Y-5131	Bearing-Sleeve	301-4626
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050

Sales Model 330B (Cont'd.)

9HN		
Original Part Number	Part Name	Classic Part Number
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5978	Flange	374-3496
087-6372	Pin	396-7284
100-7860	Valve-Inlet	270-4360
103-5345	Bearing-Sleeve	393-3640
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
109-9463	Muffler As	360-7864
110-7228	Carrier-Planet	390-0918
110-7232	Gear-Sun	417-9472
110-7243	Carrier As	384-5961
111-8015	Gasket As-Head	279-4977
113-2966	Pin As	380-7398
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
117-6270	Support As	434-1400
123-2111	Piston	462-5714
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
131-3815	Seal Gp-Basic	325-6193
134-3038	Gasket Kit	437-3228
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399

9HN		
Original Part Number	Part Name	Classic Part Number
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
142-0226	Kit-Gasket-Fs	393-1034
142-0227	Gasket Kit	437-4608
142-0228	Gasket Kit - Sch	393-1035
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
168-8453	Bearing-Spl Ball	417-4497
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
187-0605	Gasket Kit - Cl	382-5055

9HN		
Original Part Number	Part Name	Classic Part Number
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
191-3118	Cyl Gp-0170 1680	399-8560
191-3243	Housing-Motor	418-1963
192-8318	Bearing-Sleeve	360-2321
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
232-3233	Bearing-Main	376-9085
236-6277	Bearing-Sleeve	419-0884
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model 330C

B1K		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174

Sales Model 330C (Cont'd.)

B1K		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2W-7213	Bearing-Sleeve	419-4667
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
4K-0299	Bearing-Sleeve	308-9816
4K-0300	Bearing-Sleeve	308-9817
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5I-3301	Pin As	387-2929
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7K-0078	Bearing-Sleeve	308-9825
7K-9592	Bearing-Sleeve	360-2336

B1K		
Original Part Number	Part Name	Classic Part Number
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
8W-8512	Pin As	385-7220
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
105-2659	Bearing-Sleeve	419-2304
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934

B1K		
Original Part Number	Part Name	Classic Part Number
123-2111	Piston	462-5714
128-9882	Bearing-Sleeve	314-8642
156-0738	Rod As	394-8210
161-3411	Gasket	394-0896
188-4211	Cylinder As	425-9366
192-8318	Bearing-Sleeve	360-2321
205-6642	Muffler As	480-8273
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

B2L		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2W-7213	Bearing-Sleeve	419-4667
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
4K-0299	Bearing-Sleeve	308-9816
4K-0300	Bearing-Sleeve	308-9817
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5I-3301	Pin As	387-2929
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7K-0078	Bearing-Sleeve	308-9825
7K-9592	Bearing-Sleeve	360-2336

B2L		
Original Part Number	Part Name	Classic Part Number
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
105-2659	Bearing-Sleeve	419-2304
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
123-2111	Piston	462-5714

B2L		
Original Part Number	Part Name	Classic Part Number
128-9882	Bearing-Sleeve	314-8642
156-0738	Rod As	394-8210
161-3411	Gasket	394-0896
188-4211	Cylinder As	425-9366
192-8318	Bearing-Sleeve	360-2321
205-6642	Muffler As	480-8273
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 330C (Cont'd.)

B3M		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7K-9592	Bearing-Sleeve	360-2336
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368

B3M		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
8S-6782	Adapter-Exhaust	383-1586
8W-8512	Pin As	385-7220
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321

B3M		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
236-6277	Bearing-Sleeve	419-0884
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

B4N		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2W-7213	Bearing-Sleeve	419-4667
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7K-9592	Bearing-Sleeve	360-2336
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375

B4N		
Original Part Number	Part Name	Classic Part Number
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
8W-8512	Pin As	385-7220
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938

B4N		
Original Part Number	Part Name	Classic Part Number
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
205-6642	Muffler As	480-8273
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
236-6277	Bearing-Sleeve	419-0884
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BTM		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
3G-5285	Bearing-Sleeve	360-2312

BTM		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649

BTM		
Original Part Number	Part Name	Classic Part Number
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375

Sales Model 330C (Cont'd.)

BTM		
Original Part Number	Part Name	Classic Part Number
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8S-6782	Adapter-Exhaust	383-1586
087-5978	Flange	374-3496
107-7750	Pulley	382-6896
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815

BTM		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8950	Plate	399-8587
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321

BTM		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
223-3095	Gauge As	360-2295
229-1490	Sleeve-Injector	393-3659
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CAP		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2W-7213	Bearing-Sleeve	419-4667
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7Y-1461	Coupling	301-4649
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368

CAP		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8S-6782	Adapter-Exhaust	383-1586
087-5548	Bearing-Sleeve	396-1568
087-5978	Flange	374-3496
107-2139	Pin As.	360-2352
107-7750	Pulley	382-6896
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
161-3411	Gasket	394-0896
163-3749	Bearing-Sleeve	433-7505
179-3044	Cylinder	385-6138

CAP		
Original Part Number	Part Name	Classic Part Number
186-5652	Pin	392-4532
186-5662	Pin	421-1560
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589
201-4802	Sleeve	419-2309
205-6642	Muffler As	480-8273
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
236-6270	Bearing-Sleeve	425-6436
236-6277	Bearing-Sleeve	419-0884
240-2912	Bearing-Sleeve	418-1969
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327

Sales Model 330C (Cont'd.)

CAP		
Original Part Number	**Part Name**	**Classic Part Number**
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317

CAP		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

CAP		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CGZ		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2W-7213	Bearing-Sleeve	419-4667
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626

CGZ		
Original Part Number	**Part Name**	**Classic Part Number**
8S-6782	Adapter-Exhaust	383-1586
087-5548	Bearing-Sleeve	396-1568
087-5978	Flange	374-3496
107-2139	Pin As.	360-2352
107-7750	Pulley	382-6896
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
161-3411	Gasket	394-0896
163-3749	Bearing-Sleeve	433-7505
179-3044	Cylinder	385-6138
186-5652	Pin	392-4532
186-5662	Pin	421-1560
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813

CGZ		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589
201-4802	Sleeve	419-2309
205-6642	Muffler As	480-8273
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
236-6270	Bearing-Sleeve	425-6436
236-6277	Bearing-Sleeve	419-0884
240-2912	Bearing-Sleeve	418-1969
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

CYA		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2W-7213	Bearing-Sleeve	419-4667
4I-4666	Bearing-Sleeve	388-0640

CYA		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

CYA		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1461	Coupling	301-4649
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375

Sales Model 330C (Cont'd.)

CYA		
Original Part Number	Part Name	Classic Part Number
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8S-6782	Adapter-Exhaust	383-1586
087-5548	Bearing-Sleeve	396-1568
087-5978	Flange	374-3496
107-7750	Pulley	382-6896
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934

CYA		
Original Part Number	Part Name	Classic Part Number
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2919	Bearing-Sleeve	360-2319
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
192-8318	Bearing-Sleeve	360-2321

CYA		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
201-4802	Sleeve	419-2309
205-6642	Muffler As	480-8273
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
236-6277	Bearing-Sleeve	419-0884
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DKY		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
7Y-2396	Bearing-Sleeve	314-8634
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375

DKY		
Original Part Number	Part Name	Classic Part Number
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
087-5548	Bearing-Sleeve	396-1568
087-5978	Flange	374-3496
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8948	Plate	399-8588
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2819	Bearing-Sleeve	360-2317
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
188-4211	Cylinder As	425-9366

DKY		
Original Part Number	Part Name	Classic Part Number
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589
201-4802	Sleeve	419-2309
205-6642	Muffler As	480-8273
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
236-6277	Bearing-Sleeve	419-0884
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 330C (Cont'd.)

GAG		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2W-7213	Bearing-Sleeve	419-4667
3G-5285	Bearing-Sleeve	360-2312
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626

GAG		
Original Part Number	Part Name	Classic Part Number
8S-6782	Adapter-Exhaust	383-1586
087-5548	Bearing-Sleeve	396-1568
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
107-7750	Pulley	382-6896
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2919	Bearing-Sleeve	360-2319
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938

GAG		
Original Part Number	Part Name	Classic Part Number
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
236-6277	Bearing-Sleeve	419-0884
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GKX		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375

GKX		
Original Part Number	Part Name	Classic Part Number
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8S-6782	Adapter-Exhaust	383-1586
087-5548	Bearing-Sleeve	396-1568
087-5978	Flange	374-3496
107-7750	Pulley	382-6896
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934

GKX		
Original Part Number	Part Name	Classic Part Number
134-8950	Plate	399-8587
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3008	Cylinder	480-8272
179-3044	Cylinder	385-6138
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589

Sales Model 330C (Cont'd.)

GKX		
Original Part Number	Part Name	Classic Part Number
205-6642	Muffler As	480-8273
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659

GKX		
Original Part Number	Part Name	Classic Part Number
236-6277	Bearing-Sleeve	419-0884
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317

GKX		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

HAA		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2W-7213	Bearing-Sleeve	419-4667
3G-5285	Bearing-Sleeve	360-2312
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-4811	Pin As	480-8268
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648

HAA		
Original Part Number	Part Name	Classic Part Number
7Y-5131	Bearing-Sleeve	301-4626
8S-6782	Adapter-Exhaust	383-1586
086-0523	Pin	314-8696
087-5548	Bearing-Sleeve	396-1568
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
107-7750	Pulley	382-6896
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
133-2437	Link	377-6199
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
161-3411	Gasket	394-0896
163-3749	Bearing-Sleeve	433-7505
179-3044	Cylinder	385-6138

HAA		
Original Part Number	Part Name	Classic Part Number
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
236-6270	Bearing-Sleeve	425-6436
236-6277	Bearing-Sleeve	419-0884
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JAB		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174

Sales Model 330C (Cont'd.)

JAB		
Original Part Number	**Part Name**	**Classic Part Number**
2D-5658	Bearing-Ball	301-4628
2W-7213	Bearing-Sleeve	419-4667
3G-5285	Bearing-Sleeve	360-2312
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
7Y-2396	Bearing-Sleeve	314-8634
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368

JAB		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8S-6782	Adapter-Exhaust	383-1586
087-5548	Bearing-Sleeve	396-1568
087-5978	Flange	374-3496
107-7750	Pulley	382-6896
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2919	Bearing-Sleeve	360-2319
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
188-4211	Cylinder As	425-9366

JAB		
Original Part Number	**Part Name**	**Classic Part Number**
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
236-6277	Bearing-Sleeve	419-0884
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JCD		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
2W-7213	Bearing-Sleeve	419-4667
4I-0704	Bearing-Sleeve	360-2332
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-4811	Pin As	480-8268
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016

JCD		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8S-6782	Adapter-Exhaust	383-1586
9V-0247	Plate	417-4527

JCD		
Original Part Number	**Part Name**	**Classic Part Number**
086-0523	Pin	314-8696
087-5548	Bearing-Sleeve	396-1568
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
099-0722	Link As	415-1909
107-2139	Pin As.	360-2352
107-7750	Pulley	382-6896
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-6400	Spring	399-8564
117-5435	Pin As	393-0934
119-2863	Pin	314-8698

Sales Model 330C (Cont'd.)

JCD		
Original Part Number	Part Name	Classic Part Number
126-9461	Pin	392-4528
133-2437	Link	377-6199
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
161-3411	Gasket	394-0896
163-3749	Bearing-Sleeve	433-7505
179-3044	Cylinder	385-6138
186-5652	Pin	392-4532
186-5662	Pin	421-1560
188-4211	Cylinder As	425-9366

JCD		
Original Part Number	Part Name	Classic Part Number
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589
201-4802	Sleeve	419-2309
205-6642	Muffler As	480-8273
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
236-6270	Bearing-Sleeve	425-6436

JCD		
Original Part Number	Part Name	Classic Part Number
236-6277	Bearing-Sleeve	419-0884
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JNK		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
2W-7213	Bearing-Sleeve	419-4667
4I-0704	Bearing-Sleeve	360-2332
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-4811	Pin As	480-8268
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7Y-1461	Coupling	301-4649
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3428	Bearing-Sleeve	314-8647

JNK		
Original Part Number	Part Name	Classic Part Number
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8S-6782	Adapter-Exhaust	383-1586
9V-0247	Plate	417-4527
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496

JNK		
Original Part Number	Part Name	Classic Part Number
107-2139	Pin As.	360-2352
107-7750	Pulley	382-6896
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-6400	Spring	399-8564
117-5435	Pin As	393-0934
119-2863	Pin	314-8698
126-9461	Pin	392-4528
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
161-3411	Gasket	394-0896
163-3749	Bearing-Sleeve	433-7505
179-3044	Cylinder	385-6138

Sales Model 330C (Cont'd.)

JNK		
Original Part Number	Part Name	Classic Part Number
186-5652	Pin	392-4532
186-5662	Pin	421-1560
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589
201-4802	Sleeve	419-2309
205-6642	Muffler As	480-8273

JNK		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6277	Bearing-Sleeve	419-0884
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

JNK		
Original Part Number	Part Name	Classic Part Number
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KDD		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2W-7213	Bearing-Sleeve	419-4667
3G-5285	Bearing-Sleeve	360-2312
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-4811	Pin As	480-8268
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368

KDD		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8S-6782	Adapter-Exhaust	383-1586
086-0523	Pin	314-8696
087-5548	Bearing-Sleeve	396-1568
087-5978	Flange	374-3496
099-0722	Link As	415-1909
107-2139	Pin As.	360-2352
107-7750	Pulley	382-6896
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
161-3411	Gasket	394-0896
163-3749	Bearing-Sleeve	433-7505
179-3044	Cylinder	385-6138

KDD		
Original Part Number	Part Name	Classic Part Number
186-5652	Pin	392-4532
186-5662	Pin	421-1560
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
236-6270	Bearing-Sleeve	425-6436
236-6277	Bearing-Sleeve	419-0884
240-2912	Bearing-Sleeve	418-1969
240-2915	Bearing-Sleeve	360-2326
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317

Sales Model 330C (Cont'd.)

KDD		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348

KDD		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292

MCA		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368

MCA		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
8S-6782	Adapter-Exhaust	383-1586
087-5548	Bearing-Sleeve	396-1568
087-5978	Flange	374-3496
107-7750	Pulley	382-6896
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8950	Plate	399-8587
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3008	Cylinder	480-8272
179-3044	Cylinder	385-6138
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938

MCA		
Original Part Number	Part Name	Classic Part Number
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
236-6277	Bearing-Sleeve	419-0884
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MKM		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
2W-7213	Bearing-Sleeve	419-4667
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350

MKM		
Original Part Number	Part Name	Classic Part Number
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8G-4189	Bearing-Aligning	295-6411
8S-6782	Adapter-Exhaust	383-1586
9V-0247	Plate	417-4527
087-5548	Bearing-Sleeve	396-1568
087-5978	Flange	374-3496
107-7750	Pulley	382-6896
114-0468	Pin-G.E.T.	443-1203

MKM		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
115-6400	Spring	399-8564
117-5435	Pin As	393-0934
134-8950	Plate	399-8587
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938

Sales Model 330C (Cont'd.)

MKM		
Original Part Number	Part Name	Classic Part Number
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589

MKM		
Original Part Number	Part Name	Classic Part Number
205-6642	Muffler As	480-8273
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659

MKM		
Original Part Number	Part Name	Classic Part Number
236-6277	Bearing-Sleeve	419-0884
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RBH		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
7Y-2395	Bearing-Sleeve	314-8646
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8S-6782	Adapter-Exhaust	383-1586
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969

RBH		
Original Part Number	Part Name	Classic Part Number
087-5978	Flange	374-3496
087-6372	Pin	396-7284
107-7750	Pulley	382-6896
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
128-9884	Bearing-Sleeve	360-2315
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535

RBH		
Original Part Number	Part Name	Classic Part Number
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
236-6277	Bearing-Sleeve	419-0884
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 330D

B6H		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667

B6H		
Original Part Number	Part Name	Classic Part Number
4I-4666	Bearing-Sleeve	388-0640
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603

B6H		
Original Part Number	Part Name	Classic Part Number
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658

Sales Model 330D (Cont'd.)

B6H		
Original Part Number	Part Name	Classic Part Number
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069

B6H		
Original Part Number	Part Name	Classic Part Number
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273

B6H		
Original Part Number	Part Name	Classic Part Number
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
238-0293	Adapter-Jacket	424-0742
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

E4K		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
4N-2514	Gear-Flywheel	421-7283
5I-3301	Pin As	387-2929
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7K-0078	Bearing-Sleeve	308-9825
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648

E4K		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
105-2659	Bearing-Sleeve	419-2304
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
123-2111	Piston	462-5714
128-9882	Bearing-Sleeve	314-8642

E4K		
Original Part Number	Part Name	Classic Part Number
156-0738	Rod As	394-8210
161-3411	Gasket	394-0896
188-4211	Cylinder As	425-9366
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
238-0293	Adapter-Jacket	424-0742
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

EAH		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8S-6782	Adapter-Exhaust	383-1586
087-5548	Bearing-Sleeve	396-1568

EAH		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938

EAH		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 330D (Cont'd.)

EDX		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
7Y-3552	Bearing-Sleeve	364-5266
7Y-4666	Bearing-Sleeve	314-8636

EDX		
Original Part Number	**Part Name**	**Classic Part Number**
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061

EDX		
Original Part Number	**Part Name**	**Classic Part Number**
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ERN		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4811	Pin As	480-8268
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
087-5533	Bearing-Sleeve	314-8628

ERN		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
119-2863	Pin	314-8698
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
186-5662	Pin	421-1560
189-3922	Pin	393-0938

ERN		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

FFK		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
087-5548	Bearing-Sleeve	396-1568

FFK		
Original Part Number	**Part Name**	**Classic Part Number**
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589

FFK		
Original Part Number	**Part Name**	**Classic Part Number**
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 330D (Cont'd.)

GBC		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
7Y-4666	Bearing-Sleeve	314-8636
8H-5352	Bearing-Ball	453-3658

GBC		
Original Part Number	Part Name	Classic Part Number
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

GBC		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GGE		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586

GGE		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

GGE		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

H3K		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
4K-0299	Bearing-Sleeve	308-9816
4K-0300	Bearing-Sleeve	308-9817
4N-2514	Gear-Flywheel	421-7283
5I-3301	Pin As	387-2929
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7K-0078	Bearing-Sleeve	308-9825

H3K		
Original Part Number	Part Name	Classic Part Number
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
8W-8512	Pin As	385-7220
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
105-2659	Bearing-Sleeve	419-2304

H3K		
Original Part Number	Part Name	Classic Part Number
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
123-2111	Piston	462-5714
128-9882	Bearing-Sleeve	314-8642
156-0738	Rod As	394-8210
161-3411	Gasket	394-0896
188-4211	Cylinder As	425-9366
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589

Sales Model 330D (Cont'd.)

H3K		
Original Part Number	**Part Name**	**Classic Part Number**
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659

H3K		
Original Part Number	**Part Name**	**Classic Part Number**
238-0293	Adapter-Jacket	424-0742
247-8853	Cyl Gp-0150 1156	399-8583

H3K		
Original Part Number	**Part Name**	**Classic Part Number**
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

HAS		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628

HAS		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589

HAS		
Original Part Number	**Part Name**	**Classic Part Number**
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
238-0293	Adapter-Jacket	424-0742
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JLP		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628

JLP		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589

JLP		
Original Part Number	**Part Name**	**Classic Part Number**
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
238-0293	Adapter-Jacket	424-0742
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KAB		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
3G-5285	Bearing-Sleeve	360-2312
4N-2514	Gear-Flywheel	421-7283

KAB		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1461	Coupling	301-4649
7Y-5131	Bearing-Sleeve	301-4626
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586

KAB		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069

Sales Model 330D (Cont'd.)

KAB		
Original Part Number	Part Name	Classic Part Number
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938

KAB		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323

KAB		
Original Part Number	Part Name	Classic Part Number
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

L2K		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
4N-2514	Gear-Flywheel	421-7283
8H-5352	Bearing-Ball	453-3658

L2K		
Original Part Number	Part Name	Classic Part Number
8S-6782	Adapter-Exhaust	383-1586
8W-8512	Pin As	385-7220
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
189-3922	Pin	393-0938

L2K		
Original Part Number	Part Name	Classic Part Number
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
238-0293	Adapter-Jacket	424-0742
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LCJ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658

LCJ		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

LCJ		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LDR		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4811	Pin As	480-8268
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
086-0523	Pin	314-8696

LDR		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069

LDR		
Original Part Number	Part Name	Classic Part Number
117-5435	Pin As	393-0934
133-2437	Link	377-6199
134-8951	Plate	382-5061
137-2919	Bearing-Sleeve	360-2319
161-3411	Gasket	394-0896
163-3749	Bearing-Sleeve	433-7505
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589

Sales Model 330D (Cont'd.)

LDR		
Original Part Number	**Part Name**	**Classic Part Number**
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659

LDR		
Original Part Number	**Part Name**	**Classic Part Number**
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969

LDR		
Original Part Number	**Part Name**	**Classic Part Number**
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LRM		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628

LRM		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938

LRM		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MEY		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
7Y-4666	Bearing-Sleeve	314-8636
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586

MEY		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

MEY		
Original Part Number	**Part Name**	**Classic Part Number**
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MWP		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
4N-2514	Gear-Flywheel	421-7283

MWP		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9592	Bearing-Sleeve	360-2336
7Y-1461	Coupling	301-4649
7Y-3550	Pin	360-2350
7Y-4666	Bearing-Sleeve	314-8636
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586

MWP		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069

Sales Model 330D (Cont'd.)

MWP		
Original Part Number	**Part Name**	**Classic Part Number**
117-5435	Pin As	393-0934
134-8950	Plate	399-8587
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938

MWP		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323

MWP		
Original Part Number	**Part Name**	**Classic Part Number**
229-1490	Sleeve-Injector	393-3659
238-0293	Adapter-Jacket	424-0742
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

NBD		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
7Y-4666	Bearing-Sleeve	314-8636
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586

NBD		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

NBD		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
238-0293	Adapter-Jacket	424-0742
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

NEF		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4811	Pin As	480-8268
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
086-0523	Pin	314-8696
087-5548	Bearing-Sleeve	396-1568
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966

NEF		
Original Part Number	**Part Name**	**Classic Part Number**
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
133-2437	Link	377-6199
134-8951	Plate	382-5061
137-2919	Bearing-Sleeve	360-2319
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
186-5730	Pin	393-3688

NEF		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PCK		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174

Sales Model 330D (Cont'd.)

PCK		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586

PCK		
Original Part Number	**Part Name**	**Classic Part Number**
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
188-4211	Cylinder As	425-9366
189-3922	Pin	393-0938
192-8318	Bearing-Sleeve	360-2321

PCK		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PFC		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658

PFC		
Original Part Number	**Part Name**	**Classic Part Number**
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938

PFC		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PTE		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349

PTE		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
134-8950	Plate	399-8587
134-8951	Plate	382-5061
179-3008	Cylinder	480-8272

PTE		
Original Part Number	**Part Name**	**Classic Part Number**
186-5662	Pin	421-1560
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

R2D		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658

R2D		
Original Part Number	**Part Name**	**Classic Part Number**
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815

R2D		
Original Part Number	**Part Name**	**Classic Part Number**
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589

Sales Model 330D (Cont'd.)

R2D		
Original Part Number	**Part Name**	**Classic Part Number**
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323

R2D		
Original Part Number	**Part Name**	**Classic Part Number**
229-1490	Sleeve-Injector	393-3659
238-0293	Adapter-Jacket	424-0742

R2D		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RAS		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586

RAS		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

RAS		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RCK		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349

RCK		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
134-8950	Plate	399-8587
134-8951	Plate	382-5061
179-3008	Cylinder	480-8272

RCK		
Original Part Number	**Part Name**	**Classic Part Number**
186-5662	Pin	421-1560
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RDA		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4811	Pin As	480-8268
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368

RDA		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-5128	Bearing-Sleeve	314-8648
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
087-5978	Flange	374-3496
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8948	Plate	399-8588

RDA		
Original Part Number	**Part Name**	**Classic Part Number**
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2919	Bearing-Sleeve	360-2319
161-3411	Gasket	394-0896
163-3749	Bearing-Sleeve	433-7505
179-3044	Cylinder	385-6138
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589

Sales Model 330D (Cont'd.)

RDA		
Original Part Number	**Part Name**	**Classic Part Number**
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
236-6269	Bearing-Sleeve	453-6500

RDA		
Original Part Number	**Part Name**	**Classic Part Number**
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326

RDA		
Original Part Number	**Part Name**	**Classic Part Number**
240-2916	Bearing-Sleeve	360-2327
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RDK		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-5352	Bearing-Ball	453-3658
087-5533	Bearing-Sleeve	314-8628

RDK		
Original Part Number	**Part Name**	**Classic Part Number**
087-5805	Pin	301-7967
087-5978	Flange	374-3496
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8950	Plate	399-8587
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
188-4211	Cylinder As	425-9366
189-3922	Pin	393-0938
189-3923	Pin	393-0935
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323

RDK		
Original Part Number	**Part Name**	**Classic Part Number**
229-1490	Sleeve-Injector	393-3659
236-6269	Bearing-Sleeve	453-6500
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

T2Y		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586

T2Y		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

T2Y		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 330D (Cont'd.)

Original Part Number	Part NTHJame	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
2W-7213	Bearing-Sleeve	419-4667
4I-4811	Pin As	480-8268
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7Y-1461	Coupling	301-4649
7Y-2349	Pin	301-4556
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
8H-5352	Bearing-Ball	453-3658

Original Part Number	Part NTHJame	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
107-2139	Pin As.	360-2352
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
119-2863	Pin	314-8698
134-8948	Plate	399-8588
134-8951	Plate	382-5061
137-2820	Bearing-Sleeve	360-2318
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589

Original Part Number	Part NTHJame	Classic Part Number
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
236-6269	Bearing-Sleeve	453-6500
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 335F

JJR		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
134-8950	Plate	399-8587

JJR		
Original Part Number	Part Name	Classic Part Number
134-8951	Plate	382-5061
179-3044	Cylinder	385-6138
240-2916	Bearing-Sleeve	360-2327

JJR		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KNE		
Original Part Number	Part Name	Classic Part Number
7K-9592	Bearing-Sleeve	360-2336
7Y-0225	Shaft-Planet	301-4571
114-1383	Shaft-Planet	398-8349

KNE		
Original Part Number	Part Name	Classic Part Number
134-8950	Plate	399-8587
179-3044	Cylinder	385-6138
186-5662	Pin	421-1560

KNE		
Original Part Number	Part Name	Classic Part Number
240-2916	Bearing-Sleeve	360-2327
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 336D

DFS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913

Sales Model 336D (Cont'd.)

DFS		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586

DFS		
Original Part Number	**Part Name**	**Classic Part Number**
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061

DFS		
Original Part Number	**Part Name**	**Classic Part Number**
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
205-6642	Muffler As	480-8273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DTS		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4811	Pin As	480-8268
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
087-5533	Bearing-Sleeve	314-8628

DTS		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
119-2863	Pin	314-8698
134-8948	Plate	399-8588
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
189-3922	Pin	393-0938

DTS		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

EAF		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
8S-6782	Adapter-Exhaust	383-1586
087-5548	Bearing-Sleeve	396-1568

EAF		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

EAF		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

EAN		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586

EAN		
Original Part Number	**Part Name**	**Classic Part Number**
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

EAN		
Original Part Number	**Part Name**	**Classic Part Number**
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 336D (Cont'd.)

EFT		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586

EFT		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896

EFT		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ELR		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
087-5533	Bearing-Sleeve	314-8628

ELR		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

ELR		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

EMX		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7K-9592	Bearing-Sleeve	360-2336
7Y-1461	Coupling	301-4649

EMX		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938

EMX		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

FAE		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586

FAE		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061

FAE		
Original Part Number	Part Name	Classic Part Number
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
205-6642	Muffler As	480-8273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 336D (Cont'd.)

FAJ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
8S-6782	Adapter-Exhaust	383-1586
087-5548	Bearing-Sleeve	396-1568

FAJ		
Original Part Number	**Part Name**	**Classic Part Number**
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

FAJ		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

FAR		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586

FAR		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896

FAR		
Original Part Number	**Part Name**	**Classic Part Number**
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GAM		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628

GAM		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

GAM		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GJA		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586

GJA		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

GJA		
Original Part Number	**Part Name**	**Classic Part Number**
205-6642	Muffler As	480-8273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 336D (Cont'd.)

HBH		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667

HBH		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934

HBH		
Original Part Number	Part Name	Classic Part Number
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
357-7540	Valve-Fill	360-2292

HBK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
8S-6782	Adapter-Exhaust	383-1586
087-5548	Bearing-Sleeve	396-1568

HBK		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

HBK		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

J2F		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628

J2F		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589

J2F		
Original Part Number	Part Name	Classic Part Number
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
238-0293	Adapter-Jacket	424-0742
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JBF		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4811	Pin As	480-8268
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628

JBF		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
119-2863	Pin	314-8698
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
189-3922	Pin	393-0938

JBF		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032

Sales Model 336D (Cont'd.)

JBF		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348

JBF		
Original Part Number	**Part Name**	**Classic Part Number**
357-7540	Valve-Fill	360-2292

JBT		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8S-6782	Adapter-Exhaust	383-1586
087-5548	Bearing-Sleeve	396-1568

JBT		
Original Part Number	**Part Name**	**Classic Part Number**
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938

JBT		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JER		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7K-9592	Bearing-Sleeve	360-2336
7Y-1461	Coupling	301-4649

JER		
Original Part Number	**Part Name**	**Classic Part Number**
8H-5352	Bearing-Ball	453-3658
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

JER		
Original Part Number	**Part Name**	**Classic Part Number**
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JEW		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628

JEW		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061

JEW		
Original Part Number	**Part Name**	**Classic Part Number**
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JRX		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913

Sales Model 336D (Cont'd.)

JRX		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
114-1398	Gauge-Oil Level	394-9815

JRX		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
189-3922	Pin	393-0938
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323

JRX		
Original Part Number	Part Name	Classic Part Number
229-1490	Sleeve-Injector	393-3659
238-0293	Adapter-Jacket	424-0742
347-6081	Gauge As	360-2348

JWR		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4811	Pin As	480-8268
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
087-5533	Bearing-Sleeve	314-8628

JWR		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
119-2863	Pin	314-8698
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589

JWR		
Original Part Number	Part Name	Classic Part Number
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JXH		
Original Part Number	Part Name	Classic Part Number
7Y-1461	Coupling	301-4649
114-1398	Gauge-Oil Level	394-9815

JXH		
Original Part Number	Part Name	Classic Part Number
117-5435	Pin As	393-0934
179-3044	Cylinder	385-6138
199-4582	Bearing-Needle	388-6589

JXH		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KBT		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
8S-6782	Adapter-Exhaust	383-1586

KBT		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

KBT		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
205-6642	Muffler As	480-8273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 336D (Cont'd.)

KCJ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628

KCJ		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061

KCJ		
Original Part Number	**Part Name**	**Classic Part Number**
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KDJ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658

KDJ		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

KDJ		
Original Part Number	**Part Name**	**Classic Part Number**
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KKT		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7K-9592	Bearing-Sleeve	360-2336
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586

KKT		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

KKT		
Original Part Number	**Part Name**	**Classic Part Number**
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LAH		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
8S-6782	Adapter-Exhaust	383-1586

LAH		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061

LAH		
Original Part Number	**Part Name**	**Classic Part Number**
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
205-6642	Muffler As	480-8273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 336D (Cont'd.)

Original Part Number	Part NaLAMme	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628

Original Part Number	Part NaLAMme	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

Original Part Number	Part NaLAMme	Classic Part Number
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LBX		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203

LBX		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

LBX		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LMG		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4811	Pin As	480-8268
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628

LMG		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
119-2863	Pin	314-8698
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589

LMG		
Original Part Number	**Part Name**	**Classic Part Number**
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LNE		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1461	Coupling	301-4649
114-1398	Gauge-Oil Level	394-9815

LNE		
Original Part Number	**Part Name**	**Classic Part Number**
117-5435	Pin As	393-0934
179-3044	Cylinder	385-6138
199-4582	Bearing-Needle	388-6589

LNE		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 336D (Cont'd.)

M4T		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628

M4T		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589

M4T		
Original Part Number	Part Name	Classic Part Number
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
238-0293	Adapter-Jacket	424-0742
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MDS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
087-5533	Bearing-Sleeve	314-8628

MDS		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

MDS		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MEH		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203

MEH		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

MEH		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MFA		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
8S-6782	Adapter-Exhaust	383-1586

MFA		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061

MFA		
Original Part Number	Part Name	Classic Part Number
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323

Sales Model 336D (Cont'd.)

MFA		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348

MFA		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292

MPL		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8S-6782	Adapter-Exhaust	383-1586
087-5548	Bearing-Sleeve	396-1568

MPL		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938

MPL		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MYG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658

MYG		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

MYG		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MYP		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658

MYP		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

MYP		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

NAH		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913

Sales Model 336D (Cont'd.)

NAH		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568

NAH		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

NAH		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

NBN		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8S-6782	Adapter-Exhaust	383-1586

NBN		
Original Part Number	**Part Name**	**Classic Part Number**
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

NBN		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

NLS		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4811	Pin As	480-8268
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7K-9592	Bearing-Sleeve	360-2336
7Y-1461	Coupling	301-4649
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-5352	Bearing-Ball	453-3658

NLS		
Original Part Number	**Part Name**	**Classic Part Number**
086-0523	Pin	314-8696
087-5548	Bearing-Sleeve	396-1568
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
133-2437	Link	377-6199
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2919	Bearing-Sleeve	360-2319
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
186-5730	Pin	393-3688
188-4211	Cylinder As	425-9366

NLS		
Original Part Number	**Part Name**	**Classic Part Number**
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 336D (Cont'd.)

PFK		
Original Part Number	Part Name	Classic Part Number
7Y-1461	Coupling	301-4649
114-1398	Gauge-Oil Level	394-9815

PFK		
Original Part Number	Part Name	Classic Part Number
117-5435	Pin As	393-0934
179-3044	Cylinder	385-6138
199-4582	Bearing-Needle	388-6589

PFK		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PGW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7K-9592	Bearing-Sleeve	360-2336
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586

PGW		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

PGW		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PPN		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
087-5533	Bearing-Sleeve	314-8628

PPN		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938

PPN		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PRF		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7K-9592	Bearing-Sleeve	360-2336

PRF		
Original Part Number	Part Name	Classic Part Number
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203

PRF		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8950	Plate	399-8587
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

Sales Model 336D (Cont'd.)

PRF		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273

PRF		
Original Part Number	**Part Name**	**Classic Part Number**
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659

PRF		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PTB		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628

PTB		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589

PTB		
Original Part Number	**Part Name**	**Classic Part Number**
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RFX		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1461	Coupling	301-4649
114-1398	Gauge-Oil Level	394-9815

RFX		
Original Part Number	**Part Name**	**Classic Part Number**
117-5435	Pin As	393-0934
179-3044	Cylinder	385-6138
199-4582	Bearing-Needle	388-6589

RFX		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SKE		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7K-9592	Bearing-Sleeve	360-2336
7Y-1461	Coupling	301-4649
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368

SKE		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-5128	Bearing-Sleeve	314-8648
8H-5352	Bearing-Ball	453-3658
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
087-5978	Flange	374-3496
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8950	Plate	399-8587
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

SKE		
Original Part Number	**Part Name**	**Classic Part Number**
188-4211	Cylinder As	425-9366
189-3922	Pin	393-0938
189-3923	Pin	393-0935
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
236-6269	Bearing-Sleeve	453-6500
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

Sales Model 336D (Cont'd.)

SKE		
Original Part Number	Part Name	Classic Part Number
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327

SKE		
Original Part Number	Part Name	Classic Part Number
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317

SKE		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TLY		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628

TLY		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

TLY		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

W3K		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7K-9592	Bearing-Sleeve	360-2336
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628

W3K		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589

W3K		
Original Part Number	Part Name	Classic Part Number
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
238-0293	Adapter-Jacket	424-0742
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WBC		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658

WBC		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934

WBC		
Original Part Number	Part Name	Classic Part Number
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323

Sales Model 336D (Cont'd.)

WBC		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348

WBC		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292

WDC		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628

WDC		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

WDC		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WET		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628

WET		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938

WET		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WRK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7K-9592	Bearing-Sleeve	360-2336
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628

WRK		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8950	Plate	399-8587
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938

WRK		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 336D (Cont'd.)

XBH		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586

XBH		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

XBH		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

YCF		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628

YCF		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

YCF		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ZCT		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628

ZCT		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938

ZCT		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
238-0293	Adapter-Jacket	424-0742
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ZML		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667

ZML		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

ZML		
Original Part Number	Part Name	Classic Part Number
7K-9592	Bearing-Sleeve	360-2336
7Y-1461	Coupling	301-4649

Excavators

Sales Model 336D (Cont'd.)

ZML		
Original Part Number	**Part Name**	**Classic Part Number**
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815

ZML		
Original Part Number	**Part Name**	**Classic Part Number**
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589

ZML		
Original Part Number	**Part Name**	**Classic Part Number**
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 336E

BMH		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
114-1398	Gauge-Oil Level	394-9815

BMH		
Original Part Number	**Part Name**	**Classic Part Number**
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938

BMH		
Original Part Number	**Part Name**	**Classic Part Number**
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BZD		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
6V-3831	Seal-O-Ring	436-2657
7K-9592	Bearing-Sleeve	360-2336

BZD		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-2988	Breather As	361-1716
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

BZD		
Original Part Number	**Part Name**	**Classic Part Number**
179-3044	Cylinder	385-6138
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BZY		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
6V-3831	Seal-O-Ring	436-2657
7K-9592	Bearing-Sleeve	360-2336
9Y-2988	Breather As	361-1716

BZY		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
087-5978	Flange	374-3496
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8950	Plate	399-8587
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

BZY		
Original Part Number	**Part Name**	**Classic Part Number**
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 336E (Cont'd.)

CMR		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
6V-3831	Seal-O-Ring	436-2657
7K-9592	Bearing-Sleeve	360-2336

CMR		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061

CMR		
Original Part Number	Part Name	Classic Part Number
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DPX		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
114-1398	Gauge-Oil Level	394-9815

DPX		
Original Part Number	Part Name	Classic Part Number
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938

DPX		
Original Part Number	Part Name	Classic Part Number
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DSZ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603

DSZ		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934

DSZ		
Original Part Number	Part Name	Classic Part Number
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

FJH		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
6V-3831	Seal-O-Ring	436-2657
7K-9592	Bearing-Sleeve	360-2336

FJH		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

FJH		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GNY		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716

GNY		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061

GNY		
Original Part Number	Part Name	Classic Part Number
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323

Sales Model 336E (Cont'd.)

GNY		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348

GNY		
Original Part Number	**Part Name**	**Classic Part Number**
357-7540	Valve-Fill	360-2292

GTJ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
6V-3831	Seal-O-Ring	436-2657
7K-9592	Bearing-Sleeve	360-2336
9Y-2988	Breather As	361-1716
087-5533	Bearing-Sleeve	314-8628

GTJ		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938

GTJ		
Original Part Number	**Part Name**	**Classic Part Number**
228-5621	Bearing-Sleeve	360-2323
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

HDW		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
4N-2514	Gear-Flywheel	421-7283
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
114-0468	Pin-G.E.T.	443-1203

HDW		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

HDW		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

J3T		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603

J3T		
Original Part Number	**Part Name**	**Classic Part Number**
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934

J3T		
Original Part Number	**Part Name**	**Classic Part Number**
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JEA		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
4N-2514	Gear-Flywheel	421-7283
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
114-0468	Pin-G.E.T.	443-1203

JEA		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

JEA		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 336E (Cont'd.)

JRJ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
6V-3831	Seal-O-Ring	436-2657
7K-9592	Bearing-Sleeve	360-2336

JRJ		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

JRJ		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KDL		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
6V-3831	Seal-O-Ring	436-2657
7K-9592	Bearing-Sleeve	360-2336

KDL		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

KDL		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KED		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
6V-3831	Seal-O-Ring	436-2657
7K-9592	Bearing-Sleeve	360-2336

KED		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061

KED		
Original Part Number	Part Name	Classic Part Number
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RZA		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
4N-2514	Gear-Flywheel	421-7283
6V-3831	Seal-O-Ring	436-2657
7K-9592	Bearing-Sleeve	360-2336

RZA		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

RZA		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SSL		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913

Sales Model 336E (Cont'd.)

SSL		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
4N-2514	Gear-Flywheel	421-7283
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
114-1398	Gauge-Oil Level	394-9815

SSL		
Original Part Number	**Part Name**	**Classic Part Number**
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938

SSL		
Original Part Number	**Part Name**	**Classic Part Number**
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

T3Z		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
6V-3831	Seal-O-Ring	436-2657
8H-5352	Bearing-Ball	453-3658

T3Z		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-2988	Breather As	361-1716
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589

T3Z		
Original Part Number	**Part Name**	**Classic Part Number**
228-5621	Bearing-Sleeve	360-2323
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TEG		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
4I-4811	Pin As	480-8268
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
6V-3831	Seal-O-Ring	436-2657
7K-9592	Bearing-Sleeve	360-2336
9Y-2988	Breather As	361-1716

TEG		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

TEG		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TMZ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568

TMZ		
Original Part Number	**Part Name**	**Classic Part Number**
087-5978	Flange	374-3496
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8950	Plate	399-8587
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

TMZ		
Original Part Number	**Part Name**	**Classic Part Number**
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 336E (Cont'd.)

YCE		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568

YCE		
Original Part Number	Part Name	Classic Part Number
087-5978	Flange	374-3496
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8950	Plate	399-8587
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

YCE		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

YEP		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
6V-3831	Seal-O-Ring	436-2657
7K-9592	Bearing-Sleeve	360-2336
7Y-5131	Bearing-Sleeve	301-4626

YEP		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568
087-5978	Flange	374-3496
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8950	Plate	399-8587

YEP		
Original Part Number	Part Name	Classic Part Number
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 336F

B34		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716

B34		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896

B34		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

B35		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716

B35		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896

B35		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

B39		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913

Sales Model 336F (Cont'd.)

B39		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
114-1398	Gauge-Oil Level	394-9815

B39		
Original Part Number	Part Name	Classic Part Number
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

B39		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DFY		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568

DFY		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

DFY		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DSW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568

DSW		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

DSW		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KFT		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568

KFT		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

KFT		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KGH		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568

KGH		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

KGH		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 336F (Cont'd.)

LCL		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568

LCL		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

LCL		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LTP		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
087-5533	Bearing-Sleeve	314-8628

LTP		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

LTP		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MTW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568

MTW		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

MTW		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

NAJ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568

NAJ		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

NAJ		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

NBL		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568

NBL		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061

NBL		
Original Part Number	Part Name	Classic Part Number
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323

Sales Model 336F (Cont'd.)

NBL		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348

NBL		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292

NBS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568

NBS		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

NBS		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PFL		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568

PFL		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

PFL		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RAY		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568

RAY		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

RAY		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RKB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
7K-9592	Bearing-Sleeve	360-2336
9Y-2988	Breather As	361-1716

RKB		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

SSN		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913

RKB		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 336F (Cont'd.)

SSN		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815

SSN		
Original Part Number	Part Name	Classic Part Number
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323

SSN		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TZA		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
7K-9592	Bearing-Sleeve	360-2336
9Y-2988	Breather As	361-1716

TZA		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

TZA		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WTZ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568

WTZ		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

WTZ		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

YFD		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568

YFD		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

YFD		
Original Part Number	Part Name	Classic Part Number
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ZBJ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716

ZBJ		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138

ZBJ		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Excavators

Sales Model 340D

HHK		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628

HHK		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896

HHK		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JTN		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7Y-1461	Coupling	301-4649
8S-6782	Adapter-Exhaust	383-1586
087-5533	Bearing-Sleeve	314-8628

JTN		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
134-8951	Plate	382-5061
161-3411	Gasket	394-0896
189-3922	Pin	393-0938

JTN		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SGY		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-1461	Coupling	301-4649
114-1398	Gauge-Oil Level	394-9815

SGY		
Original Part Number	**Part Name**	**Classic Part Number**
117-5435	Pin As	393-0934
199-4582	Bearing-Needle	388-6589

SGY		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 340F

EAR		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
087-5548	Bearing-Sleeve	396-1568

EAR		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
189-3922	Pin	393-0938

EAR		
Original Part Number	**Part Name**	**Classic Part Number**
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 340F (Cont'd.)

YBF		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
4I-4811	Pin As	480-8268
6V-3831	Seal-O-Ring	436-2657
9Y-2988	Breather As	361-1716
114-1398	Gauge-Oil Level	394-9815

YBF		
Original Part Number	Part Name	Classic Part Number
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
228-5621	Bearing-Sleeve	360-2323
240-2912	Bearing-Sleeve	418-1969

YBF		
Original Part Number	Part Name	Classic Part Number
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 345B

2NW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5F-2830	Bearing-Needle	384-5925
5I-8628	Plate-Valve	301-4771
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654
7Y-3552	Bearing-Sleeve	364-5266

2NW		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
8H-9789	Bearing-Ball	374-8342
9W-9931	Mount As.	360-2354
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
111-2645	Valve-Pump Byp	441-1561
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719

2NW		
Original Part Number	Part Name	Classic Part Number
133-3545	Tightener-Belt	434-1407
137-2817	Bearing-Sleeve	434-2399
142-2535	Gasket Kit	437-4593
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
236-8883	Kit-Gasket-Ocl	437-8659
314-8717	Shaft-Cla	360-2273
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

Sales Model 345B (Cont'd.)

2SW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5F-2830	Bearing-Needle	384-5925
5I-3301	Pin As	387-2929
5I-8628	Plate-Valve	301-4771
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
6Y-9930	Mount As	360-2353
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634

2SW		
Original Part Number	Part Name	Classic Part Number
7Y-3428	Bearing-Sleeve	314-8647
7Y-3552	Bearing-Sleeve	364-5266
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8H-9789	Bearing-Ball	374-8342
9V-0247	Plate	417-4527
9W-9931	Mount As.	360-2354
9Y-7215	Sleeve-Isolator	425-3646
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
107-2139	Pin As.	360-2352
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
110-7216	Gear-Sun	391-9877
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281

2SW		
Original Part Number	Part Name	Classic Part Number
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
117-6675	Step As	419-0881
118-2800	Housing As.-Rglt	419-4719
119-2863	Pin	314-8698
123-2111	Piston	462-5714
126-9461	Pin	392-4528
128-9864	Bearing-Sleeve	425-6437
133-2437	Link	377-6199
133-3545	Tightener-Belt	434-1407
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
137-2821	Bearing-Sleeve	419-4717
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
163-3749	Bearing-Sleeve	433-7505
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
191-3118	Cyl Gp-0170 1680	399-8560
197-9251	Pin As.-Piston	454-6110

Sales Model 345B (Cont'd.)

2SW		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323

2SW		
Original Part Number	**Part Name**	**Classic Part Number**
236-6270	Bearing-Sleeve	425-6436
236-8883	Kit-Gasket-Ocl	437-8659
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326

2SW		
Original Part Number	**Part Name**	**Classic Part Number**
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

2ZW		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5F-2830	Bearing-Needle	384-5925
5I-8628	Plate-Valve	301-4771
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6E-4985	Cover-Filter	424-2015
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654
7Y-2396	Bearing-Sleeve	314-8634

2ZW		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
108-9191	Pin As	424-3515
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448

2ZW		
Original Part Number	**Part Name**	**Classic Part Number**
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714
128-9864	Bearing-Sleeve	425-6437
133-3545	Tightener-Belt	434-1407
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-3060	Bearing-Sleeve	360-2320
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144

Sales Model 345B (Cont'd.)

2ZW		
Original Part Number	**Part Name**	**Classic Part Number**
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323

2ZW		
Original Part Number	**Part Name**	**Classic Part Number**
314-8717	Shaft-Cla	360-2273
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137

2ZW		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

3MW		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5F-2830	Bearing-Needle	384-5925
5I-8628	Plate-Valve	301-4771
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368

3MW		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
108-9191	Pin As	424-3515
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

3MW		
Original Part Number	**Part Name**	**Classic Part Number**
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714
128-9864	Bearing-Sleeve	425-6437
133-3545	Tightener-Belt	434-1407
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-3060	Bearing-Sleeve	360-2320
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
314-8717	Shaft-Cla	360-2273
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348

Sales Model 345B (Cont'd.)

3MW		
Original Part Number	Part Name	Classic Part Number
352-2077	Pump Gp-Water -B	434-6108

3MW		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292

4SS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5F-2830	Bearing-Needle	384-5925
5I-8628	Plate-Valve	301-4771
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6E-4985	Cover-Filter	424-2015
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
6Y-9930	Mount As	360-2353
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647

4SS		
Original Part Number	Part Name	Classic Part Number
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9W-9931	Mount As.	360-2354
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714

4SS		
Original Part Number	Part Name	Classic Part Number
128-9864	Bearing-Sleeve	425-6437
133-3545	Tightener-Belt	434-1407
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
142-2535	Gasket Kit	437-4593
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
236-8883	Kit-Gasket-Ocl	437-8659
252-7955	Kit-Gasket(Cl)	437-8654
314-8717	Shaft-Cla	360-2273
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

Sales Model 345B (Cont'd.)

5WS		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4J-5241	Retainer	434-1415
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5F-2830	Bearing-Needle	384-5925
5I-8628	Plate-Valve	301-4771
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6E-4985	Cover-Filter	424-2015
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368

5WS		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
108-9191	Pin As	424-3515
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719

5WS		
Original Part Number	**Part Name**	**Classic Part Number**
123-2111	Piston	462-5714
128-9864	Bearing-Sleeve	425-6437
133-3545	Tightener-Belt	434-1407
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-3060	Bearing-Sleeve	360-2320
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
314-8717	Shaft-Cla	360-2273
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

6MW		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384

6MW		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484

Sales Model 345B (Cont'd.)

6MW		
Original Part Number	Part Name	Classic Part Number
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5F-2830	Bearing-Needle	384-5925
5I-8628	Plate-Valve	301-4771
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646

6MW		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
108-9191	Pin As	424-3515
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714

6MW		
Original Part Number	Part Name	Classic Part Number
128-9864	Bearing-Sleeve	425-6437
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-3060	Bearing-Sleeve	360-2320
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
236-8883	Kit-Gasket-Ocl	437-8659
252-7955	Kit-Gasket(Cl)	437-8654
314-8717	Shaft-Cla	360-2273
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

6XS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334

6XS		
Original Part Number	Part Name	Classic Part Number
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041

6XS		
Original Part Number	Part Name	Classic Part Number
4P-8280	Manifold-Exhaust	430-7236
5F-2830	Bearing-Needle	384-5925
5I-8628	Plate-Valve	301-4771

Sales Model 345B (Cont'd.)

6XS		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6E-4985	Cover-Filter	424-2015
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313

6XS		
Original Part Number	Part Name	Classic Part Number
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
108-9191	Pin As	424-3515
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714
128-9864	Bearing-Sleeve	425-6437
133-3545	Tightener-Belt	434-1407
134-8951	Plate	382-5061

6XS		
Original Part Number	Part Name	Classic Part Number
137-2817	Bearing-Sleeve	434-2399
137-3060	Bearing-Sleeve	360-2320
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
236-8883	Kit-Gasket-Ocl	437-8659
314-8717	Shaft-Cla	360-2273
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

7KS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283

7KS		
Original Part Number	Part Name	Classic Part Number
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5F-2830	Bearing-Needle	384-5925
5I-8628	Plate-Valve	301-4771
5P-7807	Bearing-Ball	314-8502

7KS		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
6Y-9930	Mount As	360-2353
7I-7180	Piston	421-7142

Sales Model 345B (Cont'd.)

7KS		
Original Part Number	Part Name	Classic Part Number
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8H-9789	Bearing-Ball	374-8342
9V-0247	Plate	417-4527
9W-9931	Mount As.	360-2354
9Y-7215	Sleeve-Isolator	425-3646
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909

7KS		
Original Part Number	Part Name	Classic Part Number
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
107-2139	Pin As.	360-2352
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
110-7216	Gear-Sun	391-9877
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714
128-9864	Bearing-Sleeve	425-6437
133-3545	Tightener-Belt	434-1407
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
137-3060	Bearing-Sleeve	360-2320

7KS		
Original Part Number	Part Name	Classic Part Number
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
163-3749	Bearing-Sleeve	433-7505
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
236-6270	Bearing-Sleeve	425-6436
236-8883	Kit-Gasket-Ocl	437-8659
240-2915	Bearing-Sleeve	360-2326
314-8717	Shaft-Cla	360-2273
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

8KW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484

8KW		
Original Part Number	Part Name	Classic Part Number
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272

8KW		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041

Sales Model 345B (Cont'd.)

8KW		
Original Part Number	Part Name	Classic Part Number
4P-8280	Manifold-Exhaust	430-7236
5F-2830	Bearing-Needle	384-5925
5I-8628	Plate-Valve	301-4771
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568

8KW		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
108-9191	Pin As	424-3515
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714
128-9864	Bearing-Sleeve	425-6437

8KW		
Original Part Number	Part Name	Classic Part Number
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-3060	Bearing-Sleeve	360-2320
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
236-8883	Kit-Gasket-Ocl	437-8659
252-7955	Kit-Gasket(Cl)	437-8654
314-8717	Shaft-Cla	360-2273
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

8RW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272

8RW		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5F-2830	Bearing-Needle	384-5925

8RW		
Original Part Number	Part Name	Classic Part Number
5I-8628	Plate-Valve	301-4771
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274

Sales Model 345B (Cont'd.)

8RW		
Original Part Number	Part Name	Classic Part Number
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281

8RW		
Original Part Number	Part Name	Classic Part Number
105-2659	Bearing-Sleeve	419-2304
108-9191	Pin As	424-3515
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714
128-9864	Bearing-Sleeve	425-6437
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-3060	Bearing-Sleeve	360-2320

8RW		
Original Part Number	Part Name	Classic Part Number
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
236-8883	Kit-Gasket-Ocl	437-8659
252-7955	Kit-Gasket(Cl)	437-8654
314-8717	Shaft-Cla	360-2273
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

9CW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016

9CW		
Original Part Number	Part Name	Classic Part Number
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5F-2830	Bearing-Needle	384-5925
5I-8628	Plate-Valve	301-4771
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6V-2202	Bearing-Spl Ball	380-1574

9CW		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-1768	Gear-Ring	450-9167

Sales Model 345B (Cont'd.)

9CW		
Original Part Number	Part Name	Classic Part Number
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
108-9191	Pin As	424-3515
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049

9CW		
Original Part Number	Part Name	Classic Part Number
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714
128-9864	Bearing-Sleeve	425-6437
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-3060	Bearing-Sleeve	360-2320
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154

9CW		
Original Part Number	Part Name	Classic Part Number
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
236-8883	Kit-Gasket-Ocl	437-8659
252-7955	Kit-Gasket(Cl)	437-8654
314-8717	Shaft-Cla	360-2273
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

9GS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236

9GS		
Original Part Number	Part Name	Classic Part Number
5F-2830	Bearing-Needle	384-5925
5I-8628	Plate-Valve	301-4771
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
6Y-9930	Mount As	360-2353
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568

9GS		
Original Part Number	Part Name	Classic Part Number
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648

Sales Model 345B (Cont'd.)

9GS		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
9W-9931	Mount As.	360-2354
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447

9GS		
Original Part Number	Part Name	Classic Part Number
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714
128-9864	Bearing-Sleeve	425-6437
133-3545	Tightener-Belt	434-1407
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
142-2535	Gasket Kit	437-4593
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573

9GS		
Original Part Number	Part Name	Classic Part Number
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
236-8883	Kit-Gasket-Ocl	437-8659
314-8717	Shaft-Cla	360-2273
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

AGS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
6E-4985	Cover-Filter	424-2015

AGS		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9W-9931	Mount As.	360-2354

AGS		
Original Part Number	Part Name	Classic Part Number
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
110-7216	Gear-Sun	391-9877
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

Sales Model 345B (Cont'd.)

AGS		
Original Part Number	**Part Name**	**Classic Part Number**
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714
134-8951	Plate	382-5061

AGS		
Original Part Number	**Part Name**	**Classic Part Number**
137-2817	Bearing-Sleeve	434-2399
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
193-3322	Gasket Kit - Ocl	437-2007
197-9251	Pin As.-Piston	454-6110

AGS		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
236-8883	Kit-Gasket-Ocl	437-8659
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

AKJ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
6E-4985	Cover-Filter	424-2015
6V-3831	Seal-O-Ring	436-2657
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647

AKJ		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
110-7216	Gear-Sun	391-9877
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448

AKJ		
Original Part Number	**Part Name**	**Classic Part Number**
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
193-3322	Gasket Kit - Ocl	437-2007

Sales Model 345B (Cont'd.)

AKJ		
Original Part Number	**Part Name**	**Classic Part Number**
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658

AKJ		
Original Part Number	**Part Name**	**Classic Part Number**
228-5621	Bearing-Sleeve	360-2323
236-8883	Kit-Gasket-Ocl	437-8659
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137

AKJ		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

AKX		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
6E-4985	Cover-Filter	424-2015
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342

AKX		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9931	Mount As.	360-2354
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
110-7216	Gear-Sun	391-9877
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714

AKX		
Original Part Number	**Part Name**	**Classic Part Number**
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
193-3322	Gasket Kit - Ocl	437-2007
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
236-8883	Kit-Gasket-Ocl	437-8659
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

Sales Model 345B (Cont'd.)

ALB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342

ALB		
Original Part Number	Part Name	Classic Part Number
9W-9931	Mount As.	360-2354
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
110-7216	Gear-Sun	391-9877
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400

ALB		
Original Part Number	Part Name	Classic Part Number
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

ALD		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016

ALD		
Original Part Number	Part Name	Classic Part Number
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
6E-4985	Cover-Filter	424-2015
6V-3831	Seal-O-Ring	436-2657
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650

ALD		
Original Part Number	Part Name	Classic Part Number
7X-7975	Gasket Kit	437-3233
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628

Sales Model 345B (Cont'd.)

ALD		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
110-7216	Gear-Sun	391-9877
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447

ALD		
Original Part Number	Part Name	Classic Part Number
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573

ALD		
Original Part Number	Part Name	Classic Part Number
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
193-3322	Gasket Kit - Ocl	437-2007
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

ALL		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
6E-4985	Cover-Filter	424-2015
6V-3831	Seal-O-Ring	436-2657
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650

ALL		
Original Part Number	Part Name	Classic Part Number
7X-7975	Gasket Kit	437-3233
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
110-7216	Gear-Sun	391-9877
111-2645	Valve-Pump Byp	441-1561

ALL		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399

Sales Model 345B (Cont'd.)

ALL		
Original Part Number	**Part Name**	**Classic Part Number**
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367

ALL		
Original Part Number	**Part Name**	**Classic Part Number**
187-3307	Gasket As-Cyl	438-2022
193-3322	Gasket Kit - Ocl	437-2007
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658

ALL		
Original Part Number	**Part Name**	**Classic Part Number**
228-5621	Bearing-Sleeve	360-2323
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

AMD		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648

AMD		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
110-7216	Gear-Sun	391-9877
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719

AMD		
Original Part Number	**Part Name**	**Classic Part Number**
123-2111	Piston	462-5714
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
193-3322	Gasket Kit - Ocl	437-2007
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348

Sales Model 345B (Cont'd.)

AMD		
Original Part Number	Part Name	Classic Part Number
352-2077	Pump Gp-Water -B	434-6108

AMD		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292

AMJ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568

AMJ		
Original Part Number	Part Name	Classic Part Number
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5978	Flange	374-3496
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
110-7216	Gear-Sun	391-9877
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714
133-2437	Link	377-6199
134-8950	Plate	399-8587
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399

AMJ		
Original Part Number	Part Name	Classic Part Number
137-2919	Bearing-Sleeve	360-2319
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
163-3749	Bearing-Sleeve	433-7505
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
193-3322	Gasket Kit - Ocl	437-2007
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

Sales Model 345B (Cont'd.)

AMN		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626

AMN		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
110-7216	Gear-Sun	391-9877
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714

AMN		
Original Part Number	Part Name	Classic Part Number
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-8479	Spacer	395-1323
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
193-3322	Gasket Kit - Ocl	437-2007
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

APB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601

APB		
Original Part Number	Part Name	Classic Part Number
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041

APB		
Original Part Number	Part Name	Classic Part Number
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568

Sales Model 345B (Cont'd.)

APB		
Original Part Number	Part Name	Classic Part Number
7W-5844	Bearing-Conn Rod	419-4650
7Y-3428	Bearing-Sleeve	314-8647
7Y-3552	Bearing-Sleeve	364-5266
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
9W-9931	Mount As.	360-2354
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-6372	Pin	396-7284
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304

APB		
Original Part Number	Part Name	Classic Part Number
110-7216	Gear-Sun	391-9877
111-2645	Valve-Pump Byp	441-1561
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-6400	Spring	399-8564
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714
137-2817	Bearing-Sleeve	434-2399
147-3781	Kit-Gasket(Wp)	422-2484

APB		
Original Part Number	Part Name	Classic Part Number
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

AYR		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467

AYR		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4666	Bearing-Sleeve	314-8636

AYR		
Original Part Number	Part Name	Classic Part Number
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304

Sales Model 345B (Cont'd.)

AYR		
Original Part Number	Part Name	Classic Part Number
110-7216	Gear-Sun	391-9877
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399

AYR		
Original Part Number	Part Name	Classic Part Number
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
163-3749	Bearing-Sleeve	433-7505
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
192-8318	Bearing-Sleeve	360-2321
193-3322	Gasket Kit - Ocl	437-2007

AYR		
Original Part Number	Part Name	Classic Part Number
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

BFG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5F-2830	Bearing-Needle	384-5925

BFG		
Original Part Number	Part Name	Classic Part Number
5I-8628	Plate-Valve	301-4771
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
6Y-9930	Mount As	360-2353
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654

BFG		
Original Part Number	Part Name	Classic Part Number
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-3428	Bearing-Sleeve	314-8647
7Y-3552	Bearing-Sleeve	364-5266
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8H-9789	Bearing-Ball	374-8342
9V-0247	Plate	417-4527
9W-9931	Mount As.	360-2354
9Y-7215	Sleeve-Isolator	425-3646

Sales Model 345B (Cont'd.)

BFG		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
107-2139	Pin As.	360-2352
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
110-7216	Gear-Sun	391-9877
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447

BFG		
Original Part Number	Part Name	Classic Part Number
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
119-2863	Pin	314-8698
126-9461	Pin	392-4528
133-2437	Link	377-6199
133-3545	Tightener-Belt	434-1407
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
137-2919	Bearing-Sleeve	360-2319
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
163-3749	Bearing-Sleeve	433-7505
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600

BFG		
Original Part Number	Part Name	Classic Part Number
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
236-6270	Bearing-Sleeve	425-6436
236-8883	Kit-Gasket-Ocl	437-8659
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
244-8504	Pin As	426-0032
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

CCC		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016

CCC		
Original Part Number	Part Name	Classic Part Number
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5F-2830	Bearing-Needle	384-5925
5I-3301	Pin As	387-2929
5P-7807	Bearing-Ball	314-8502
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650

CCC		
Original Part Number	Part Name	Classic Part Number
7X-7975	Gasket Kit	437-3233
7Y-0912	Bearing-Rlr As	417-4513
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648

Sales Model 345B (Cont'd.)

CCC		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-5131	Bearing-Sleeve	301-4626
8H-9789	Bearing-Ball	374-8342
9V-0247	Plate	417-4527
9W-9931	Mount As.	360-2354
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-6372	Pin	396-7284
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
107-2139	Pin As.	360-2352
110-7216	Gear-Sun	391-9877
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447

CCC		
Original Part Number	**Part Name**	**Classic Part Number**
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
117-6675	Step As	419-0881
118-2800	Housing As.-Rglt	419-4719
119-2863	Pin	314-8698
123-2111	Piston	462-5714
126-9461	Pin	392-4528
133-2437	Link	377-6199
134-8948	Plate	399-8588
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
137-2821	Bearing-Sleeve	419-4717
137-2919	Bearing-Sleeve	360-2319
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
163-3749	Bearing-Sleeve	433-7505
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367

CCC		
Original Part Number	**Part Name**	**Classic Part Number**
186-5652	Pin	392-4532
186-5662	Pin	421-1560
187-3307	Gasket As-Cyl	438-2022
193-3322	Gasket Kit - Ocl	437-2007
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
315-6671	Kit-Gasket(Op)	438-0139
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

CDJ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829

CDJ		
Original Part Number	**Part Name**	**Classic Part Number**
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502

CDJ		
Original Part Number	**Part Name**	**Classic Part Number**
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233

Sales Model 345B (Cont'd.)

CDJ		
Original Part Number	Part Name	Classic Part Number
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9W-9931	Mount As.	360-2354
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
110-7216	Gear-Sun	391-9877
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349

CDJ		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727

CDJ		
Original Part Number	Part Name	Classic Part Number
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
193-3322	Gasket Kit - Ocl	437-2007
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
236-8883	Kit-Gasket-Ocl	437-8659
316-4396	Kit-Gasket (Sch)	393-3661
319-3607	Kit-Gasket(Rs)	438-0137
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

CFM		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
4D-0487	Valve As-Check	375-4334
4I-5016	Pin	396-7272
4K-0299	Bearing-Sleeve	308-9816
4K-0300	Bearing-Sleeve	308-9817
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016

CFM		
Original Part Number	Part Name	Classic Part Number
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7K-0078	Bearing-Sleeve	308-9825
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7Y-3552	Bearing-Sleeve	364-5266
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

CFM		
Original Part Number	Part Name	Classic Part Number
9W-9931	Mount As.	360-2354
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-6372	Pin	396-7284
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
110-7216	Gear-Sun	391-9877
111-2645	Valve-Pump Byp	441-1561
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

Sales Model 345B (Cont'd.)

CFM		
Original Part Number	Part Name	Classic Part Number
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-6400	Spring	399-8564
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400

CFM		
Original Part Number	Part Name	Classic Part Number
118-2800	Housing As.-Rglt	419-4719
137-2817	Bearing-Sleeve	434-2399
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367

CFM		
Original Part Number	Part Name	Classic Part Number
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

DCW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368

DCW		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9W-9931	Mount As.	360-2354
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
110-7216	Gear-Sun	391-9877
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446

DCW		
Original Part Number	Part Name	Classic Part Number
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658

Sales Model 345B (Cont'd.)

DCW		
Original Part Number	Part Name	Classic Part Number
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348

DCW		
Original Part Number	Part Name	Classic Part Number
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

DET		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7Y-3552	Bearing-Sleeve	364-5266
8H-9789	Bearing-Ball	374-8342
9V-0247	Plate	417-4527
9W-9931	Mount As.	360-2354
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628

DET		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
087-6372	Pin	396-7284
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
110-7216	Gear-Sun	391-9877
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719

DET		
Original Part Number	Part Name	Classic Part Number
123-2111	Piston	462-5714
137-2817	Bearing-Sleeve	434-2399
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
236-8883	Kit-Gasket-Ocl	437-8659
315-6671	Kit-Gasket(Op)	438-0139
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

FEE		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4D-0487	Valve As-Check	375-4334

FEE		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236

FEE		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650

Sales Model 345B (Cont'd.)

FEE		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9V-0247	Plate	417-4527
9W-9931	Mount As.	360-2354
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
110-7216	Gear-Sun	391-9877
111-2645	Valve-Pump Byp	441-1561
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

FEE		
Original Part Number	Part Name	Classic Part Number
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
123-2111	Piston	462-5714
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825

FEE		
Original Part Number	Part Name	Classic Part Number
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
315-6671	Kit-Gasket(Op)	438-0139
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

Sales Model 345C

A3L		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
4N-2514	Gear-Flywheel	421-7283

A3L		
Original Part Number	Part Name	Classic Part Number
7I-7181	Piston	393-5217
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349

A3L		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
115-6400	Spring	399-8564
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

BWY		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484

BWY		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

BWY		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273

Sales Model 345C (Cont'd.)

BWY		
Original Part Number	Part Name	Classic Part Number
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

BWY		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323

BWY		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DHP		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

DHP		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589

DHP		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ELS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

ELS		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

ELS		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ESD		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272

ESD		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

ESD		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

Sales Model 345C (Cont'd.)

ESD		
Original Part Number	**Part Name**	**Classic Part Number**
134-8951	Plate	382-5061
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589

ESD		
Original Part Number	**Part Name**	**Classic Part Number**
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658

ESD		
Original Part Number	**Part Name**	**Classic Part Number**
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

FPC		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

FPC		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

FPC		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GBH		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

GBH		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
134-8951	Plate	382-5061
148-3091	Bearing-Sleeve	365-8825

GBH		
Original Part Number	**Part Name**	**Classic Part Number**
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GCL		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
7Y-0912	Bearing-Rlr As	417-4513

GCL		
Original Part Number	**Part Name**	**Classic Part Number**
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877

GCL		
Original Part Number	**Part Name**	**Classic Part Number**
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658

Sales Model 345C (Cont'd.)

GCL		
Original Part Number	Part Name	Classic Part Number
228-5621	Bearing-Sleeve	360-2323

GCL		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348

GCL		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292

GPH		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4N-2514	Gear-Flywheel	421-7283
7I-7181	Piston	393-5217
7T-8816	Bearing-Spl Ball	420-2491
7Y-0912	Bearing-Rlr As	417-4513
7Y-2349	Pin	301-4556
7Y-3428	Bearing-Sleeve	314-8647
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648

GPH		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
107-2139	Pin As.	360-2352
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
134-8949	Plate	383-2110
137-2820	Bearing-Sleeve	360-2318
148-3091	Bearing-Sleeve	365-8825

GPH		
Original Part Number	Part Name	Classic Part Number
193-5016	Flange	425-3644
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
236-6269	Bearing-Sleeve	453-6500
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JAR		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

JAR		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589

JAR		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LYS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4N-2514	Gear-Flywheel	421-7283

LYS		
Original Part Number	Part Name	Classic Part Number
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

LYS		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349

Sales Model 345C (Cont'd.)

LYS		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
134-8949	Plate	383-2110
148-3091	Bearing-Sleeve	365-8825
193-5016	Flange	425-3644

LYS		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323

LYS		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MDC		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

MDC		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

MDC		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PJW		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
5I-3301	Pin As	387-2929
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658

PJW		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
134-8951	Plate	382-5061

PJW		
Original Part Number	**Part Name**	**Classic Part Number**
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RFN		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4I-5015	Pin	365-8829

RFN		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2514	Gear-Flywheel	421-7283
7I-7181	Piston	393-5217
7T-8816	Bearing-Spl Ball	420-2491
7Y-5128	Bearing-Sleeve	314-8648

RFN		
Original Part Number	**Part Name**	**Classic Part Number**
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568

Sales Model 345C (Cont'd.)

RFN		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589

RFN		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436

RFN		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

S5M		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

S5M		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

S5M		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SCN		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4N-2514	Gear-Flywheel	421-7283
7I-7181	Piston	393-5217
7T-8816	Bearing-Spl Ball	420-2491
7Y-2349	Pin	301-4556
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
8H-5352	Bearing-Ball	453-3658

SCN		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
107-2139	Pin As.	360-2352
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
137-2820	Bearing-Sleeve	360-2318
199-4582	Bearing-Needle	388-6589

SCN		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
236-6269	Bearing-Sleeve	453-6500
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SPC		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913

Sales Model 345C (Cont'd.)

SPC		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4I-4811	Pin As	480-8268
4N-2514	Gear-Flywheel	421-7283
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7T-8816	Bearing-Spl Ball	420-2491
7Y-0912	Bearing-Rlr As	417-4513
7Y-2349	Pin	301-4556
7Y-3428	Bearing-Sleeve	314-8647
7Y-5128	Bearing-Sleeve	314-8648
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

SPC		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
107-2139	Pin As.	360-2352
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
119-2863	Pin	314-8698
134-8948	Plate	399-8588
137-2820	Bearing-Sleeve	360-2318
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589

SPC		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
236-6269	Bearing-Sleeve	453-6500
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
244-8504	Pin As	426-0032
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TAJ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658

TAJ		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
134-8951	Plate	382-5061

TAJ		
Original Part Number	Part Name	Classic Part Number
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TBA		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

TBA		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
105-2659	Bearing-Sleeve	419-2304
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
123-2111	Piston	462-5714

TBA		
Original Part Number	Part Name	Classic Part Number
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 345C (Cont'd.)

TDG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658

TDG		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
134-8951	Plate	382-5061

TDG		
Original Part Number	Part Name	Classic Part Number
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WDE		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
7Y-5128	Bearing-Sleeve	314-8648
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

WDE		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295

WDE		
Original Part Number	Part Name	Classic Part Number
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
236-6269	Bearing-Sleeve	453-6500
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 345D

BYC		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

BYC		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

BYC		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 345D (Cont'd.)

BYW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

BYW		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

BYW		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DPA		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4I-4811	Pin As	480-8268
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

DPA		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
137-2919	Bearing-Sleeve	360-2319
148-3091	Bearing-Sleeve	365-8825

DPA		
Original Part Number	Part Name	Classic Part Number
163-3749	Bearing-Sleeve	433-7505
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
240-2912	Bearing-Sleeve	418-1969
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

EEH		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
5I-3301	Pin As	387-2929
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658

EEH		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

EEH		
Original Part Number	Part Name	Classic Part Number
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

FES		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913

Sales Model 345D (Cont'd.)

FES		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

FES		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

FES		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

HLC		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4I-4812	Pin As	480-8269
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
7Y-5128	Bearing-Sleeve	314-8648
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

HLC		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825
186-5662	Pin	421-1560
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295

HLC		
Original Part Number	Part Name	Classic Part Number
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
236-6269	Bearing-Sleeve	453-6500
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JKN		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

JKN		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

JKN		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 345D (Cont'd.)

KFH		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

KFH		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

KFH		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LKY		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

LKY		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

LKY		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MLK		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

MLK		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

MLK		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

NEG		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484

NEG		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283

NEG		
Original Part Number	**Part Name**	**Classic Part Number**
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

Sales Model 345D (Cont'd.)

NEG		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203

NEG		
Original Part Number	**Part Name**	**Classic Part Number**
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589

NEG		
Original Part Number	**Part Name**	**Classic Part Number**
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

NLM		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

NLM		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

NLM		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PBT		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

PBT		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

PBT		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RAE		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283

RAE		
Original Part Number	**Part Name**	**Classic Part Number**
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

RAE		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349

Sales Model 345D (Cont'd.)

RAE		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589

RAE		
Original Part Number	**Part Name**	**Classic Part Number**
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323

RAE		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RAJ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

RAJ		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

RAJ		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RGD		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

RGD		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

RGD		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RGG		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491

RGG		
Original Part Number	**Part Name**	**Classic Part Number**
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877

RGG		
Original Part Number	**Part Name**	**Classic Part Number**
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658

Sales Model 345D (Cont'd.)

RGG		
Original Part Number	Part Name	Classic Part Number
228-5621	Bearing-Sleeve	360-2323

RGG		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348

RGG		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292

TKH		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

TKH		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

TKH		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

YEE		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

YEE		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

YEE		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 349D

CE4		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491

CE4		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

CE4		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 349D (Cont'd.)

DKN		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491

DKN		
Original Part Number	**Part Name**	**Classic Part Number**
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349

DKN		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348

FLA		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-9789	Bearing-Ball	374-8342

FLA		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

FLA		
Original Part Number	**Part Name**	**Classic Part Number**
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

GKF		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

GKF		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

GKF		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JGB		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491

JGB		
Original Part Number	**Part Name**	**Classic Part Number**
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877

JGB		
Original Part Number	**Part Name**	**Classic Part Number**
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295

Sales Model 349D (Cont'd.)

JGB		
Original Part Number	Part Name	Classic Part Number
225-4529	Cyl Gp-0160 1356	393-3658

JGB		
Original Part Number	Part Name	Classic Part Number
228-5621	Bearing-Sleeve	360-2323

JGB		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KHS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

KHS		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

KHS		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KLH		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

KLH		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

KLH		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MCX		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491

MCX		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

MCX		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 349D (Cont'd.)

MEN		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

MEN		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

MEN		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

NNF		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

NNF		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

NNF		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PFD		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658

PFD		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

PFD		
Original Part Number	Part Name	Classic Part Number
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PZG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174

PZG		
Original Part Number	Part Name	Classic Part Number
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433

PZG		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491

Sales Model 349D (Cont'd.)

PZG		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877

PZG		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589

PZG		
Original Part Number	Part Name	Classic Part Number
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RAN		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658

RAN		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

RAN		
Original Part Number	Part Name	Classic Part Number
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RBJ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

RBJ		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

RBJ		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SDM		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283

SDM		
Original Part Number	Part Name	Classic Part Number
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568

SDM		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

Sales Model 349D (Cont'd.)

SDM		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
225-4529	Cyl Gp-0160 1356	393-3658

SDM		
Original Part Number	**Part Name**	**Classic Part Number**
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348

SDM		
Original Part Number	**Part Name**	**Classic Part Number**
357-7540	Valve-Fill	360-2292

SDM		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658

SDM		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

SDM		
Original Part Number	**Part Name**	**Classic Part Number**
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WTD		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

WTD		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
148-3091	Bearing-Sleeve	365-8825

WTD		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

XAC		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658

XAC		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

XAC		
Original Part Number	**Part Name**	**Classic Part Number**
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 349D (Cont'd.)

YAE		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-9789	Bearing-Ball	374-8342

YAE		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

YAE		
Original Part Number	Part Name	Classic Part Number
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

YAG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-9789	Bearing-Ball	374-8342

YAG		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

YAG		
Original Part Number	Part Name	Classic Part Number
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ZAE		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
7T-8816	Bearing-Spl Ball	420-2491
8H-9789	Bearing-Ball	374-8342

ZAE		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

ZAE		
Original Part Number	Part Name	Classic Part Number
148-3091	Bearing-Sleeve	365-8825
199-4582	Bearing-Needle	388-6589
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 349E

DGE		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628

DGE		
Original Part Number	Part Name	Classic Part Number
2R-0524	Cone-Bearing	422-6484
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

DGE		
Original Part Number	Part Name	Classic Part Number
7F-2742	Bearing-Ball	422-6488
7T-8816	Bearing-Spl Ball	420-2491

Sales Model 349E (Cont'd.)

DGE		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273

DGE		
Original Part Number	**Part Name**	**Classic Part Number**
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
199-4582	Bearing-Needle	388-6589

DGE		
Original Part Number	**Part Name**	**Classic Part Number**
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

ETC		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
7T-8816	Bearing-Spl Ball	420-2491
8H-9789	Bearing-Ball	374-8342

ETC		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

ETC		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

FEJ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
7T-8816	Bearing-Spl Ball	420-2491
8H-9789	Bearing-Ball	374-8342

FEJ		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

FEJ		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

FJB		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
7T-8816	Bearing-Spl Ball	420-2491
8H-9789	Bearing-Ball	374-8342

FJB		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349

FJB		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 349E (Cont'd.)

FKF		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
7T-8816	Bearing-Spl Ball	420-2491

FKF		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

FKF		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JAE		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
7T-8816	Bearing-Spl Ball	420-2491

JAE		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

JAE		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KCN		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7F-2742	Bearing-Ball	422-6488
7T-8816	Bearing-Spl Ball	420-2491

KCN		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349

KCN		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KFX		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
7T-8816	Bearing-Spl Ball	420-2491
8H-9789	Bearing-Ball	374-8342

KFX		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

KFX		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 349E (Cont'd.)

MPZ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7F-2742	Bearing-Ball	422-6488
7T-8816	Bearing-Spl Ball	420-2491

MPZ		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349

MPZ		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MTS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
7T-8816	Bearing-Spl Ball	420-2491

MTS		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

MTS		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MZW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
7T-8816	Bearing-Spl Ball	420-2491
8H-9789	Bearing-Ball	374-8342

MZW		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

MZW		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RGH		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
7T-8816	Bearing-Spl Ball	420-2491
8H-9789	Bearing-Ball	374-8342

RGH		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349

RGH		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 349E (Cont'd.)

S3P		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4I-4812	Pin As	480-8269
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5I-8628	Plate-Valve	301-4771
6H-3957	Bearing-Ball	311-9358
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7F-2742	Bearing-Ball	422-6488
7T-8816	Bearing-Spl Ball	420-2491

S3P		
Original Part Number	Part Name	Classic Part Number
7Y-1644	Gear-Planet	301-3406
7Y-2396	Bearing-Sleeve	314-8634
7Y-3552	Bearing-Sleeve	364-5266
7Y-5102	Bearing-Sleeve	380-7368
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503
8H-9789	Bearing-Ball	374-8342
094-1509	Shaft-Planet	360-2273
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380

S3P		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
148-4634	Shaft-Planet	360-2274
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
227-6228	Cage	360-2343
228-5621	Bearing-Sleeve	360-2323
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

SPG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
7T-8816	Bearing-Spl Ball	420-2491
8H-9789	Bearing-Ball	374-8342

SPG		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349

SPG		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TFG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

TFG		
Original Part Number	Part Name	Classic Part Number
7F-2742	Bearing-Ball	422-6488
7T-8816	Bearing-Spl Ball	420-2491
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

TFG		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

Sales Model 349E (Cont'd.)

TFG		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589

TFG		
Original Part Number	Part Name	Classic Part Number
228-5621	Bearing-Sleeve	360-2323

TFG		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WHZ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
7T-8816	Bearing-Spl Ball	420-2491
8H-9789	Bearing-Ball	374-8342

WHZ		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349

WHZ		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 349F

BZ2		
Original Part Numbr	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

BZ2		
Original Part Numbr	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

BZ2		
Original Part Numbr	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

FH2		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
8H-9789	Bearing-Ball	374-8342

FH2		
Original Part Number	Part Name	Classic Part Number
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

FH2		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

HLB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628

HLB		
Original Part Number	Part Name	Classic Part Number
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
8H-9789	Bearing-Ball	374-8342

HLB		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568

Sales Model 349F (Cont'd.)

HLB		
Original Part Number	**Part Name**	**Classic Part Number**
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

HLB		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323

HLB		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

HPD		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

HPD		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

HPD		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KEA		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

KEA		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

KEA		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RAX		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

RAX		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

RAX		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SFG		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913

Sales Model 349F (Cont'd.)

SFG		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

SFG		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

SFG		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SFT		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

SFT		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

SFT		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TEW		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

TEW		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

TEW		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 350

2ZL		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

2ZL		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221

2ZL		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927

Sales Model 350 (Cont'd.)

2ZL		
Original Part Number	Part Name	Classic Part Number
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2R-0524	Cone-Bearing	422-6484
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
4I-4665	Bearing-Sleeve	364-5267
4I-4807	Pin	383-2139
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-0432	Bearing-Ball	417-4499
4N-3092	Spider As-Fan	363-7465
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9395	Line As-Fuel Inj	383-3690

2ZL		
Original Part Number	Part Name	Classic Part Number
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
6Y-9930	Mount As	360-2353
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811

2ZL		
Original Part Number	Part Name	Classic Part Number
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-1035	Mount	383-2118
7Y-1315	Pipe As-Tail	385-7209
7Y-1978	Muffler As	360-7893
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-5128	Bearing-Sleeve	314-8648
8C-3111	Rod End-Spher	392-4523
8G-0890	Bearing-Align	374-8340
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623

Sales Model 350 (Cont'd.)

2ZL		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9931	Mount As.	360-2354

2ZL		
Original Part Number	Part Name	Classic Part Number
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
105-2659	Bearing-Sleeve	419-2304
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-6400	Spring	399-8564
123-2111	Piston	462-5714
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-8951	Plate	382-5061
148-3091	Bearing-Sleeve	365-8825
148-7455	Valve - Exhaust	270-4361
156-0738	Rod As	394-8210
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

2ZL		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
176-3900	Accumulator	416-5513
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
225-4529	Cyl Gp-0160 1356	393-3658
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

3ML		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913

3ML		
Original Part Number	Part Name	Classic Part Number
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

3ML		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006

Sales Model 350 (Cont'd.)

3ML		
Original Part Number	Part Name	Classic Part Number
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2R-0524	Cone-Bearing	422-6484
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267
4I-4807	Pin	383-2139
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-0432	Bearing-Ball	417-4499
4N-3092	Spider As-Fan	363-7465
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236

3ML		
Original Part Number	Part Name	Classic Part Number
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-0787	Bearing-Sleeve	425-6443
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991

3ML		
Original Part Number	Part Name	Classic Part Number
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
6Y-9930	Mount As	360-2353
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-1035	Mount	383-2118
7Y-1315	Pipe As-Tail	385-7209
7Y-1978	Muffler As	360-7893
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-4269	Bearing As-Rlr	419-2308

Sales Model 350 (Cont'd.)

3ML		
Original Part Number	Part Name	Classic Part Number
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081

3ML		
Original Part Number	Part Name	Classic Part Number
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9931	Mount As.	360-2354
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
100-7860	Valve-Inlet	270-4360
105-2659	Bearing-Sleeve	419-2304
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-6400	Spring	399-8564
118-5196	Pin	380-7397
123-2111	Piston	462-5714
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
148-3091	Bearing-Sleeve	365-8825
148-7455	Valve - Exhaust	270-4361
156-0738	Rod As	394-8210
164-6560	Body As-Piston	477-7125

3ML		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
176-3900	Accumulator	416-5513
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model 350 (Cont'd.)

7RK		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2R-0524	Cone-Bearing	422-6484
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
4I-4665	Bearing-Sleeve	364-5267

7RK		
Original Part Number	Part Name	Classic Part Number
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-0432	Bearing-Ball	417-4499
4N-3092	Spider As-Fan	363-7465
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273

7RK		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
6Y-9930	Mount As	360-2353
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-1035	Mount	383-2118
7Y-1315	Pipe As-Tail	385-7209
7Y-1978	Muffler As	360-7893
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577

Sales Model 350 (Cont'd.)

7RK		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083

7RK		
Original Part Number	Part Name	Classic Part Number
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9931	Mount As.	360-2354
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
100-7860	Valve-Inlet	270-4360
105-2659	Bearing-Sleeve	419-2304
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-6400	Spring	399-8564
123-2111	Piston	462-5714
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
134-8951	Plate	382-5061
148-3091	Bearing-Sleeve	365-8825
148-7455	Valve - Exhaust	270-4361
156-0738	Rod As	394-8210
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126

8HK		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978

7RK		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
176-3900	Accumulator	416-5513
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 350 (Cont'd.)

8HK		
Original Part Number	Part Name	Classic Part Number
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2R-0524	Cone-Bearing	422-6484
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
4I-4665	Bearing-Sleeve	364-5267
4I-5015	Pin	365-8829

8HK		
Original Part Number	Part Name	Classic Part Number
4I-5016	Pin	396-7272
4N-0432	Bearing-Ball	417-4499
4N-3092	Spider As-Fan	363-7465
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475

8HK		
Original Part Number	Part Name	Classic Part Number
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-1035	Mount	383-2118
7Y-1315	Pipe As-Tail	385-7209
7Y-1978	Muffler As	360-7893
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-5128	Bearing-Sleeve	314-8648

Sales Model 350 (Cont'd.)

8HK		
Original Part Number	Part Name	Classic Part Number
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438

8HK		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9931	Mount As.	360-2354
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
100-7860	Valve-Inlet	270-4360
105-2659	Bearing-Sleeve	419-2304
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-6400	Spring	399-8564
123-2111	Piston	462-5714
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-8951	Plate	382-5061
148-3091	Bearing-Sleeve	365-8825
148-7455	Valve - Exhaust	270-4361

8HK		
Original Part Number	Part Name	Classic Part Number
156-0738	Rod As	394-8210
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
176-3900	Accumulator	416-5513
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 350 (Cont'd.)

8KZ		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2R-0524	Cone-Bearing	422-6484
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216
4N-0432	Bearing-Ball	417-4499

8KZ		
Original Part Number	Part Name	Classic Part Number
4N-3092	Spider As-Fan	363-7465
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-0787	Bearing-Sleeve	425-6443
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475

8KZ		
Original Part Number	Part Name	Classic Part Number
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-1035	Mount	383-2118
7Y-1315	Pipe As-Tail	385-7209
7Y-1978	Muffler As	360-7893
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037

Sales Model 350 (Cont'd.)

8KZ		
Original Part Number	Part Name	Classic Part Number
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372

8KZ		
Original Part Number	Part Name	Classic Part Number
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9931	Mount As.	360-2354
9Y-1798	Seal-Water	379-0165
094-1509	Shaft-Planet	360-2273
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-1383	Shaft-Planet	398-8349
115-6400	Spring	399-8564
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
137-2817	Bearing-Sleeve	434-2399
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351

8KZ		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

9DK		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087

9DK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572

9DK		
Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

Sales Model 350 (Cont'd.)

9DK		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2R-0524	Cone-Bearing	422-6484
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216
4I-4665	Bearing-Sleeve	364-5267
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-0432	Bearing-Ball	417-4499
4N-3092	Spider As-Fan	363-7465
4N-4782	Pulley	325-6176

9DK		
Original Part Number	Part Name	Classic Part Number
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-0787	Bearing-Sleeve	425-6443
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

9DK		
Original Part Number	Part Name	Classic Part Number
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
6Y-9930	Mount As	360-2353
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-1035	Mount	383-2118
7Y-1315	Pipe As-Tail	385-7209
7Y-1978	Muffler As	360-7893
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-5128	Bearing-Sleeve	314-8648
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512

Sales Model 350 (Cont'd.)

9DK		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500

9DK		
Original Part Number	Part Name	Classic Part Number
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9931	Mount As.	360-2354
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
100-7860	Valve-Inlet	270-4360
105-2659	Bearing-Sleeve	419-2304
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-6400	Spring	399-8564
123-2111	Piston	462-5714
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
148-3091	Bearing-Sleeve	365-8825
148-7455	Valve - Exhaust	270-4361
156-0738	Rod As	394-8210
164-6560	Body As-Piston	477-7125

9DK		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
176-3900	Accumulator	416-5513
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 350 (Cont'd.)

9FL		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2R-0524	Cone-Bearing	422-6484
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-3521	Bearing	380-7513
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216

9FL		
Original Part Number	Part Name	Classic Part Number
4I-4665	Bearing-Sleeve	364-5267
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-0432	Bearing-Ball	417-4499
4N-3092	Spider As-Fan	363-7465
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883

9FL		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6E-0787	Bearing-Sleeve	425-6443
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-1035	Mount	383-2118
7Y-1315	Pipe As-Tail	385-7209
7Y-1978	Muffler As	360-7893
7Y-2348	Pin	314-8697

Sales Model 350 (Cont'd.)

9FL		
Original Part Number	Part Name	Classic Part Number
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-4492	Stem	383-3702
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585

9FL		
Original Part Number	Part Name	Classic Part Number
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9931	Mount As.	360-2354
9Y-1798	Seal-Water	379-0165
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5847	Bearing-Sleeve	314-8629
094-1509	Shaft-Planet	360-2273
100-7860	Valve-Inlet	270-4360
105-2659	Bearing-Sleeve	419-2304
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
114-1383	Shaft-Planet	398-8349
115-6400	Spring	399-8564
123-2111	Piston	462-5714
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004

9FL		
Original Part Number	Part Name	Classic Part Number
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-8951	Plate	382-5061
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
137-2821	Bearing-Sleeve	419-4717
143-5447	Gasket Kit - F	393-1036
143-5448	Gasket Kit - Sch	447-8652
148-3091	Bearing-Sleeve	365-8825
148-7455	Valve - Exhaust	270-4361
156-0738	Rod As	394-8210
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

Sales Model 350 (Cont'd.)

9FL		
Original Part Number	Part Name	Classic Part Number
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
176-3900	Accumulator	416-5513
187-0605	Gasket Kit - Cl	382-5055
191-3118	Cyl Gp-0170 1680	399-8560

9FL		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357

9FL		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 352F

A9J		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

A9J		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

A9J		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KBP		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

KBP		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

KBP		
Original Part Number	Part Name	Classic Part Number
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SD2		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488

SD2		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877

SD2		
Original Part Number	Part Name	Classic Part Number
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
199-4582	Bearing-Needle	388-6589

Sales Model 352F (Cont'd.)

SD2		
Original Part Number	**Part Name**	**Classic Part Number**
228-5621	Bearing-Sleeve	360-2323

SD2		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348

SD2		
Original Part Number	**Part Name**	**Classic Part Number**
357-7540	Valve-Fill	360-2292

WNA		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

WNA		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

WNA		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

XAJ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
8H-9789	Bearing-Ball	374-8342
087-5533	Bearing-Sleeve	314-8628

XAJ		
Original Part Number	**Part Name**	**Classic Part Number**
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

XAJ		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

XAL		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
8H-9789	Bearing-Ball	374-8342

XAL		
Original Part Number	**Part Name**	**Classic Part Number**
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

XAL		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

YEG		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
7F-2742	Bearing-Ball	422-6488
8H-9789	Bearing-Ball	374-8342

YEG		
Original Part Number	**Part Name**	**Classic Part Number**
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349

YEG		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323

Sales Model 352F (Cont'd.)

YEG		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348

YEG		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292

Sales Model 365B

4XZ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4W-0452	Seal As -Cshaft	325-6191
5P-7807	Bearing-Ball	314-8502
6V-3831	Seal-O-Ring	436-2657
7W-5164	Gasket	420-8568
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2396	Bearing-Sleeve	314-8634
7Y-4269	Bearing As-Rlr	419-2308
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648

4XZ		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
107-2139	Pin As.	360-2352
111-2645	Valve-Pump Byp	441-1561
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
147-3781	Kit-Gasket(Wp)	422-2484

4XZ		
Original Part Number	Part Name	Classic Part Number
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
163-3749	Bearing-Sleeve	433-7505
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
186-5652	Pin	392-4532
186-5662	Pin	421-1560
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2915	Bearing-Sleeve	360-2326
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

9PZ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433

9PZ		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236

9PZ		
Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As -Cshaft	325-6191
5P-7807	Bearing-Ball	314-8502
6E-0787	Bearing-Sleeve	425-6443
6V-3831	Seal-O-Ring	436-2657

Sales Model 365B (Cont'd.)

9PZ		
Original Part Number	Part Name	Classic Part Number
6Y-9930	Mount As	360-2353
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7W-5164	Gasket	420-8568
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-2349	Pin	301-4556
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-4269	Bearing As-Rlr	419-2308
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9W-9931	Mount As.	360-2354
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
107-2139	Pin As.	360-2352

9PZ		
Original Part Number	Part Name	Classic Part Number
111-2645	Valve-Pump Byp	441-1561
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318
137-2821	Bearing-Sleeve	419-4717
147-3781	Kit-Gasket(Wp)	422-2484

9PZ		
Original Part Number	Part Name	Classic Part Number
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
236-6269	Bearing-Sleeve	453-6500
240-2915	Bearing-Sleeve	360-2326
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

9TZ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4W-0452	Seal As -Cshaft	325-6191
5P-7807	Bearing-Ball	314-8502
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7W-5164	Gasket	420-8568
7Y-0225	Shaft-Planet	301-4571

9TZ		
Original Part Number	Part Name	Classic Part Number
7Y-0912	Bearing-Rlr As	417-4513
7Y-2396	Bearing-Sleeve	314-8634
7Y-4269	Bearing As-Rlr	419-2308
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9W-9931	Mount As.	360-2354
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
114-1398	Gauge-Oil Level	394-9815

9TZ		
Original Part Number	Part Name	Classic Part Number
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
176-4168	Bridge As-Valve	419-4727

Sales Model 365B (Cont'd.)

9TZ		
Original Part Number	Part Name	Classic Part Number
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367

9TZ		
Original Part Number	Part Name	Classic Part Number
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295

9TZ		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

AGD		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4W-0452	Seal As -Cshaft	325-6191
5P-7807	Bearing-Ball	314-8502
6V-3831	Seal-O-Ring	436-2657
7W-5164	Gasket	420-8568
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-2396	Bearing-Sleeve	314-8634
7Y-4269	Bearing As-Rlr	419-2308
7Y-5102	Bearing-Sleeve	380-7368

AGD		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

AGD		
Original Part Number	Part Name	Classic Part Number
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

BTH		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236

BTH		
Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As -Cshaft	325-6191
5P-7807	Bearing-Ball	314-8502
6V-3831	Seal-O-Ring	436-2657
7W-5164	Gasket	420-8568
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765

BTH		
Original Part Number	Part Name	Classic Part Number
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-4269	Bearing As-Rlr	419-2308
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567

Sales Model 365B (Cont'd.)

BTH		
Original Part Number	Part Name	Classic Part Number
104-1706	Valve-Regulating	432-8281
107-2139	Pin As.	360-2352
111-2645	Valve-Pump Byp	441-1561
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

BTH		
Original Part Number	Part Name	Classic Part Number
117-6270	Support As	434-1400
137-2820	Bearing-Sleeve	360-2318
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
186-5652	Pin	392-4532
186-5662	Pin	421-1560
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110

BTH		
Original Part Number	Part Name	Classic Part Number
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
236-6270	Bearing-Sleeve	425-6436
240-2912	Bearing-Sleeve	418-1969
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

CFJ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4W-0452	Seal As -Cshaft	325-6191
5P-7807	Bearing-Ball	314-8502
6V-3831	Seal-O-Ring	436-2657
7W-5164	Gasket	420-8568
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-2396	Bearing-Sleeve	314-8634
7Y-4269	Bearing As-Rlr	419-2308
7Y-5102	Bearing-Sleeve	380-7368

CFJ		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

CFJ		
Original Part Number	Part Name	Classic Part Number
117-6270	Support As	434-1400
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

Sales Model 365B (Cont'd.)

CTY		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4W-0452	Seal As -Cshaft	325-6191
5P-7807	Bearing-Ball	314-8502
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7W-5164	Gasket	420-8568
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-4269	Bearing As-Rlr	419-2308
8H-9789	Bearing-Ball	374-8342
9W-9931	Mount As.	360-2354

CTY		
Original Part Number	Part Name	Classic Part Number
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
137-2817	Bearing-Sleeve	434-2399

CTY		
Original Part Number	Part Name	Classic Part Number
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

DER		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4W-0452	Seal As -Cshaft	325-6191
5P-7807	Bearing-Ball	314-8502
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7W-5164	Gasket	420-8568
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-2396	Bearing-Sleeve	314-8634

DER		
Original Part Number	Part Name	Classic Part Number
7Y-4269	Bearing As-Rlr	419-2308
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9W-9931	Mount As.	360-2354
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446

DER		
Original Part Number	Part Name	Classic Part Number
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
134-8951	Plate	382-5061
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323

Sales Model 365B (Cont'd.)

DER		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348

DER		
Original Part Number	**Part Name**	**Classic Part Number**
352-2077	Pump Gp-Water -B	434-6108

DER		
Original Part Number	**Part Name**	**Classic Part Number**
357-7540	Valve-Fill	360-2292

JMB		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4W-0452	Seal As -Cshaft	325-6191
5P-7807	Bearing-Ball	314-8502
6E-0787	Bearing-Sleeve	425-6443
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7W-5164	Gasket	420-8568
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-2349	Pin	301-4556
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-4269	Bearing As-Rlr	419-2308
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8H-9789	Bearing-Ball	374-8342
9W-9931	Mount As.	360-2354

JMB		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
107-2139	Pin As.	360-2352
111-2645	Valve-Pump Byp	441-1561
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
123-2111	Piston	462-5714
134-8949	Plate	383-2110
137-2817	Bearing-Sleeve	434-2399
137-2820	Bearing-Sleeve	360-2318

JMB		
Original Part Number	**Part Name**	**Classic Part Number**
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
160-9874	Kit-Gasket-Scl	386-3048
163-3749	Bearing-Sleeve	433-7505
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
193-5016	Flange	425-3644
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
236-6269	Bearing-Sleeve	453-6500
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

PEG		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
3J-2903	Cover	422-6922

PEG		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041

PEG		
Original Part Number	**Part Name**	**Classic Part Number**
4P-8280	Manifold-Exhaust	430-7236
4W-0452	Seal As -Cshaft	325-6191
5P-7807	Bearing-Ball	314-8502

Sales Model 365B (Cont'd.)

PEG		
Original Part Number	Part Name	Classic Part Number
6E-0787	Bearing-Sleeve	425-6443
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7W-5164	Gasket	420-8568
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-4269	Bearing As-Rlr	419-2308
7Y-5102	Bearing-Sleeve	380-7368
8H-9789	Bearing-Ball	374-8342
9W-9931	Mount As.	360-2354
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
111-2645	Valve-Pump Byp	441-1561

PEG		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
123-2111	Piston	462-5714
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825

PEG		
Original Part Number	Part Name	Classic Part Number
160-9874	Kit-Gasket-Scl	386-3048
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

SDL		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4W-0452	Seal As -Cshaft	325-6191
5P-7807	Bearing-Ball	314-8502
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7W-5164	Gasket	420-8568
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-4269	Bearing As-Rlr	419-2308
8H-9789	Bearing-Ball	374-8342
9W-9931	Mount As.	360-2354

SDL		
Original Part Number	Part Name	Classic Part Number
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
137-2817	Bearing-Sleeve	434-2399

SDL		
Original Part Number	Part Name	Classic Part Number
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108
357-7540	Valve-Fill	360-2292

ELC		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547

ELC		
Original Part Number	**Part Name**	**Classic Part Number**
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-4269	Bearing As-Rlr	419-2308
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

ELC		
Original Part Number	**Part Name**	**Classic Part Number**
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

FEN		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271

FEN		
Original Part Number	**Part Name**	**Classic Part Number**
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7N-2155	Bearing	383-2133

FEN		
Original Part Number	**Part Name**	**Classic Part Number**
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-4269	Bearing As-Rlr	419-2308
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521

Sales Model 365C (Cont'd.)

FEN		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813

FEN		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914

FEN		
Original Part Number	Part Name	Classic Part Number
217-8938	Tightening-Belt	419-4735
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MCS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547

MCS		
Original Part Number	Part Name	Classic Part Number
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-4269	Bearing As-Rlr	419-2308
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

MCS		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 365C (Cont'd.)

MCY		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190

MCY		
Original Part Number	Part Name	Classic Part Number
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-2349	Pin	301-4556
7Y-3428	Bearing-Sleeve	314-8647
7Y-4269	Bearing As-Rlr	419-2308
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
107-2139	Pin As.	360-2352
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
134-8949	Plate	383-2110
135-4928	Shaft-Water Pump	386-3813
137-2820	Bearing-Sleeve	360-2318
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106

MCY		
Original Part Number	Part Name	Classic Part Number
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
163-3749	Bearing-Sleeve	433-7505
167-8126	Damper As	382-8019
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
193-5016	Flange	425-3644
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
236-6269	Bearing-Sleeve	453-6500
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MEM		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

MEM		
Original Part Number	Part Name	Classic Part Number
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271

MEM		
Original Part Number	Part Name	Classic Part Number
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333

Sales Model 365C (Cont'd.)

MEM		
Original Part Number	Part Name	Classic Part Number
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-2349	Pin	301-4556
7Y-3428	Bearing-Sleeve	314-8647
7Y-4269	Bearing As-Rlr	419-2308
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372

MEM		
Original Part Number	Part Name	Classic Part Number
101-3125	Gasket	420-8567
107-2139	Pin As.	360-2352
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
134-8949	Plate	383-2110
135-4928	Shaft-Water Pump	386-3813
137-2820	Bearing-Sleeve	360-2318
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656

MEM		
Original Part Number	Part Name	Classic Part Number
193-5016	Flange	425-3644
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
236-6269	Bearing-Sleeve	453-6500
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PAR		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

PAR		
Original Part Number	Part Name	Classic Part Number
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6E-0787	Bearing-Sleeve	425-6443
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-4269	Bearing As-Rlr	419-2308

PAR		
Original Part Number	Part Name	Classic Part Number
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
105-2659	Bearing-Sleeve	419-2304
108-7930	Bearing As	377-7463
123-2111	Piston	462-5714
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

Sales Model 365C (Cont'd.)

PAR		
Original Part Number	**Part Name**	**Classic Part Number**
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
148-3091	Bearing-Sleeve	365-8825
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048

PAR		
Original Part Number	**Part Name**	**Classic Part Number**
167-8126	Damper As	382-8019
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
223-3095	Gauge As	360-2295

PAR		
Original Part Number	**Part Name**	**Classic Part Number**
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 374D

PAP		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571

PAP		
Original Part Number	**Part Name**	**Classic Part Number**
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-2396	Bearing-Sleeve	314-8634
7Y-4269	Bearing As-Rlr	419-2308
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

PAP		
Original Part Number	**Part Name**	**Classic Part Number**
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PAS		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913

Sales Model 374D (Cont'd.)

PAS		
Original Part Number	Part Name	Classic Part Number
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7N-2155	Bearing	383-2133

PAS		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-2396	Bearing-Sleeve	314-8634
7Y-4269	Bearing As-Rlr	419-2308
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

PAS		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PAX		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603

PAX		
Original Part Number	Part Name	Classic Part Number
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7Y-0225	Shaft-Planet	301-4571

PAX		
Original Part Number	Part Name	Classic Part Number
7Y-0912	Bearing-Rlr As	417-4513
7Y-2396	Bearing-Sleeve	314-8634
7Y-4269	Bearing As-Rlr	419-2308
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

Sales Model 374D (Cont'd.)

PAX		
Original Part Number	**Part Name**	**Classic Part Number**
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656

PAX		
Original Part Number	**Part Name**	**Classic Part Number**
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
246-3130	Shaft-Water Pump	392-4508

PAX		
Original Part Number	**Part Name**	**Classic Part Number**
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PJA		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571

PJA		
Original Part Number	**Part Name**	**Classic Part Number**
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-2396	Bearing-Sleeve	314-8634
7Y-4269	Bearing As-Rlr	419-2308
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

PJA		
Original Part Number	**Part Name**	**Classic Part Number**
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 374E

JKC		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913

Sales Model 374E (Cont'd.)

JKC		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7Y-0225	Shaft-Planet	301-4571

JKC		
Original Part Number	Part Name	Classic Part Number
7Y-0912	Bearing-Rlr As	417-4513
7Y-2396	Bearing-Sleeve	314-8634
7Y-4269	Bearing As-Rlr	419-2308
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813

JKC		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
228-5621	Bearing-Sleeve	360-2323
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 374F

AP4		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373

AP4		
Original Part Number	Part Name	Classic Part Number
7N-2213	Bearing-Sleeve	394-0190
7N-7878	Cover-Plate	434-2401
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-2396	Bearing-Sleeve	314-8634
7Y-4269	Bearing As-Rlr	419-2308
7Y-5128	Bearing-Sleeve	314-8648
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

AP4		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
228-5621	Bearing-Sleeve	360-2323
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443

Sales Model 374F (Cont'd.)

AP4		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348

AP4		
Original Part Number	**Part Name**	**Classic Part Number**
357-7540	Valve-Fill	360-2292

AT2		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190

AT2		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7878	Cover-Plate	434-2401
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-2396	Bearing-Sleeve	314-8634
7Y-4269	Bearing As-Rlr	419-2308
7Y-5128	Bearing-Sleeve	314-8648
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813

AT2		
Original Part Number	**Part Name**	**Classic Part Number**
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
228-5621	Bearing-Sleeve	360-2323
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DNM		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171

DNM		
Original Part Number	**Part Name**	**Classic Part Number**
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-2396	Bearing-Sleeve	314-8634
7Y-4269	Bearing As-Rlr	419-2308
7Y-5128	Bearing-Sleeve	314-8648
8N-2104	Bell As-Suction	380-1521

DNM		
Original Part Number	**Part Name**	**Classic Part Number**
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035

Sales Model 374F (Cont'd.)

DNM		
Original Part Number	Part Name	Classic Part Number
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656

DNM		
Original Part Number	Part Name	Classic Part Number
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
228-5621	Bearing-Sleeve	360-2323

DNM		
Original Part Number	Part Name	Classic Part Number
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

DP4		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7N-2155	Bearing	383-2133

DP4		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7Y-0225	Shaft-Planet	301-4571
7Y-4269	Bearing As-Rlr	419-2308
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

DP4		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
347-6081	Gauge As	360-2348

MFL		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333

MFL		
Original Part Number	Part Name	Classic Part Number
6N-1931	Plunger	379-0171
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7878	Cover-Plate	434-2401
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-2396	Bearing-Sleeve	314-8634
7Y-4269	Bearing As-Rlr	419-2308
7Y-5128	Bearing-Sleeve	314-8648

MFL		
Original Part Number	Part Name	Classic Part Number
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813

Sales Model 374F (Cont'd.)

MFL		
Original Part Number	**Part Name**	**Classic Part Number**
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656

MFL		
Original Part Number	**Part Name**	**Classic Part Number**
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
228-5621	Bearing-Sleeve	360-2323
246-3130	Shaft-Water Pump	392-4508

MFL		
Original Part Number	**Part Name**	**Classic Part Number**
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

NFJ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190

NFJ		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7878	Cover-Plate	434-2401
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-2396	Bearing-Sleeve	314-8634
7Y-4269	Bearing As-Rlr	419-2308
7Y-5128	Bearing-Sleeve	314-8648
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813

NFJ		
Original Part Number	**Part Name**	**Classic Part Number**
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
228-5621	Bearing-Sleeve	360-2323
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 375

1JM		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1S-9209	Shaft-Tightener	374-6499
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356

1JM		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1700	Pump Gp-F Tfr	377-5846
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690

1JM		
Original Part Number	**Part Name**	**Classic Part Number**
1W-5910	Tappet As-Guide&	383-1569
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354

Sales Model 375 (Cont'd.)

1JM		
Original Part Number	Part Name	Classic Part Number
2L-4444	Bearing	419-6029
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
4J-5241	Retainer	434-1415
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255

1JM		
Original Part Number	Part Name	Classic Part Number
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-0787	Bearing-Sleeve	425-6443
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811

1JM		
Original Part Number	Part Name	Classic Part Number
7N-7878	Cover-Plate	434-2401
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7Y-0912	Bearing-Rlr As	417-4513
7Y-1035	Mount	383-2118
7Y-1100	Bearing-Roller	394-8226
7Y-1215	Coupling	422-3512
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
8C-3111	Rod End-Spher	392-4523
8F-6058	Bearing-Sleeve	416-5494
8G-0890	Bearing-Align	374-8340
8H-2810	Case As-Filter	314-8512
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9W-9931	Mount As.	360-2354
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060

Sales Model 375 (Cont'd.)

1JM		
Original Part Number	Part Name	Classic Part Number
102-3927	Muffler As	420-6219
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
128-2922	Kit-Gasket (Wp)	386-3814
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919

1JM		
Original Part Number	Part Name	Classic Part Number
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
137-2817	Bearing-Sleeve	434-2399
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701

1JM		
Original Part Number	Part Name	Classic Part Number
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
228-5621	Bearing-Sleeve	360-2323
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
430-7619	Adapter-Cla	438-1812

6NK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1S-9209	Shaft-Tightener	374-6499
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5910	Tappet As-Guide&	383-1569
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-4444	Bearing	419-6029
2L-5271	Bearing-Ball	371-4305

6NK		
Original Part Number	Part Name	Classic Part Number
2N-5842	Screw-Bridge Adj	418-1934
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709

6NK		
Original Part Number	Part Name	Classic Part Number
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318

Sales Model 375 (Cont'd.)

6NK		
Original Part Number	Part Name	Classic Part Number
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-0787	Bearing-Sleeve	425-6443
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190

6NK		
Original Part Number	Part Name	Classic Part Number
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7Y-0912	Bearing-Rlr As	417-4513
7Y-1035	Mount	383-2118
7Y-1100	Bearing-Roller	394-8226
7Y-1215	Coupling	422-3512
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
8C-3111	Rod End-Spher	392-4523
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-4492	Stem	383-3702
8L-4889	Shaft-Aux Drive	433-9212
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9W-9931	Mount As.	360-2354
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-5953	Gasket Kit - F	437-4573
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689

6NK		
Original Part Number	Part Name	Classic Part Number
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-7354	Manifold-Exhaust	386-3060
102-3927	Muffler As	420-6219
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
149-0625	Kit-Gasket(F)	437-4595
149-0629	Gasket Kit - Sch	437-4594
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701

Sales Model 375 (Cont'd.)

6NK		
Original Part Number	**Part Name**	**Classic Part Number**
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665

6NK		
Original Part Number	**Part Name**	**Classic Part Number**
217-0586	Bearing-Rod	419-7266
234-1874	Kit-Gasket-Fs	437-8668
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665

6NK		
Original Part Number	**Part Name**	**Classic Part Number**
328-5574	Bearing-Rod	419-7266
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
430-7619	Adapter-Cla	438-1812

Original Part Number	**Part N6RLame**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1S-9209	Shaft-Tightener	374-6499
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5910	Tappet As-Guide&	383-1569
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-4444	Bearing	419-6029
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283

Original Part Number	**Part N6RLame**	**Classic Part Number**
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883

Original Part Number	**Part N6RLame**	**Classic Part Number**
6B-7469	Spacer	417-4535
6E-0787	Bearing-Sleeve	425-6443
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
6Y-9930	Mount As	360-2353
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854

Sales Model 375 (Cont'd.)

Original Part Number	Part N6RLame	Classic Part Number
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7Y-0912	Bearing-Rlr As	417-4513
7Y-1035	Mount	383-2118
7Y-1100	Bearing-Roller	394-8226
7Y-1215	Coupling	422-3512
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
8C-3111	Rod End-Spher	392-4523
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9W-9931	Mount As.	360-2354
9Y-2988	Breather As	361-1716

Original Part Number	Part N6RLame	Classic Part Number
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-5953	Gasket Kit - F	437-4573
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-7354	Manifold-Exhaust	386-3060
102-3927	Muffler As	420-6219
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813

Original Part Number	Part N6RLame	Classic Part Number
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
234-1874	Kit-Gasket-Fs	437-8668
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
430-7619	Adapter-Cla	438-1812

8WJ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-9209	Shaft-Tightener	374-6499
1W-1669	Piston	325-6158

8WJ		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-4738	Bearing-Sleeve	325-6020

8WJ		
Original Part Number	Part Name	Classic Part Number
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5910	Tappet As-Guide&	383-1569
1W-9302	Gear-Crankshaft	386-3059

Sales Model 375 (Cont'd.)

8WJ		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-4444	Bearing	419-6029
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
4J-5241	Retainer	434-1415
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318

8WJ		
Original Part Number	Part Name	Classic Part Number
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-0787	Bearing-Sleeve	425-6443
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
6Y-9930	Mount As	360-2353
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373

8WJ		
Original Part Number	Part Name	Classic Part Number
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7Y-0912	Bearing-Rlr As	417-4513
7Y-1035	Mount	383-2118
7Y-1100	Bearing-Roller	394-8226
7Y-1215	Coupling	422-3512
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
8C-3111	Rod End-Spher	392-4523
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9W-9931	Mount As.	360-2354
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-2930	Gasket Kit - F	393-1026
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690

Sales Model 375 (Cont'd.)

8WJ		
Original Part Number	Part Name	Classic Part Number
101-1818	Bridge As-Exh	374-4691
101-7354	Manifold-Exhaust	386-3060
102-3927	Muffler As	420-6219
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
128-2922	Kit-Gasket (Wp)	386-3814
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193

8WJ		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
137-2817	Bearing-Sleeve	434-2399
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700

8WJ		
Original Part Number	Part Name	Classic Part Number
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
228-5621	Bearing-Sleeve	360-2323
234-1874	Kit-Gasket-Fs	437-8668
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
430-7619	Adapter-Cla	438-1812

8XG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1S-9209	Shaft-Tightener	374-6499
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5910	Tappet As-Guide&	383-1569
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-4444	Bearing	419-6029

8XG		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056

8XG		
Original Part Number	Part Name	Classic Part Number
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323

Sales Model 375 (Cont'd.)

8XG		
Original Part Number	Part Name	Classic Part Number
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-0787	Bearing-Sleeve	425-6443
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
6Y-9930	Mount As	360-2353
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816

8XG		
Original Part Number	Part Name	Classic Part Number
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7Y-0912	Bearing-Rlr As	417-4513
7Y-1035	Mount	383-2118
7Y-1100	Bearing-Roller	394-8226
7Y-1215	Coupling	422-3512
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
8C-3111	Rod End-Spher	392-4523
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9W-9931	Mount As.	360-2354
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-5953	Gasket Kit - F	437-4573
100-6920	Adapter-Nozzle	380-1552

8XG		
Original Part Number	Part Name	Classic Part Number
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-3927	Muffler As	420-6219
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700

Sales Model 375 (Cont'd.)

8XG		
Original Part Number	**Part Name**	**Classic Part Number**
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368

8XG		
Original Part Number	**Part Name**	**Classic Part Number**
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
234-1874	Kit-Gasket-Fs	437-8668
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665

8XG		
Original Part Number	**Part Name**	**Classic Part Number**
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
430-7619	Adapter-Cla	438-1812

9WL		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1S-9209	Shaft-Tightener	374-6499
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5910	Tappet As-Guide&	383-1569
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-4444	Bearing	419-6029
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509

9WL		
Original Part Number	**Part Name**	**Classic Part Number**
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
5P-7807	Bearing-Ball	314-8502

9WL		
Original Part Number	**Part Name**	**Classic Part Number**
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-0787	Bearing-Sleeve	425-6443
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7M-7219	Bearing-Thrust	384-4816

Sales Model 375 (Cont'd.)

9WL		
Original Part Number	Part Name	Classic Part Number
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7Y-0912	Bearing-Rlr As	417-4513
7Y-1035	Mount	383-2118
7Y-1100	Bearing-Roller	394-8226
7Y-1215	Coupling	422-3512
7Y-3428	Bearing-Sleeve	314-8647
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-5128	Bearing-Sleeve	314-8648
8C-3111	Rod End-Spher	392-4523
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-4492	Stem	383-3702
8L-4889	Shaft-Aux Drive	433-9212
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9W-9931	Mount As.	360-2354

9WL		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
100-2848	Ring-Guide	399-6057
100-5953	Gasket Kit - F	437-4573
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-7354	Manifold-Exhaust	386-3060
102-3927	Muffler As	420-6219
102-8608	Manifold-Exhaust	376-9062
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
123-2111	Piston	462-5714
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
137-2817	Bearing-Sleeve	434-2399

9WL		
Original Part Number	Part Name	Classic Part Number
137-2821	Bearing-Sleeve	419-4717
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
149-0625	Kit-Gasket(F)	437-4595
149-0629	Gasket Kit - Sch	437-4594
155-5619	Gasket	382-5054
156-0738	Rod As	394-8210
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
228-5621	Bearing-Sleeve	360-2323
234-1874	Kit-Gasket-Fs	437-8668
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
430-7619	Adapter-Cla	438-1812

Sales Model 385B

ANS		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5P-7807	Bearing-Ball	314-8502
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257

ANS		
Original Part Number	**Part Name**	**Classic Part Number**
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
114-0468	Pin-G.E.T.	443-1203
117-6270	Support As	434-1400
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193

ANS		
Original Part Number	**Part Name**	**Classic Part Number**
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
189-1814	Kit-Gasket(Ocl)	437-2009
190-0649	Tightener-Belt	434-1407
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
223-3095	Gauge As	360-2295
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
430-7619	Adapter-Cla	438-1812

BKF		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020

BKF		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690

Sales Model 385B (Cont'd.)

BKF		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5P-7807	Bearing-Ball	314-8502
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133

BKF		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9W-9931	Mount As.	360-2354
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
117-6270	Support As	434-1400
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919

BKF		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
189-1814	Kit-Gasket(Ocl)	437-2009
190-0649	Tightener-Belt	434-1407
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
223-3095	Gauge As	360-2295
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
430-7619	Adapter-Cla	438-1812

BKX		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689

BKX		
Original Part Number	Part Name	Classic Part Number
1W-4746	Retainer-Gear	295-5690
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163

BKX		
Original Part Number	Part Name	Classic Part Number
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

Sales Model 385B (Cont'd.)

BKX		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5P-7807	Bearing-Ball	314-8502
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190

BKX		
Original Part Number	Part Name	Classic Part Number
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-4269	Bearing As-Rlr	419-2308
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9W-9931	Mount As.	360-2354
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
117-6270	Support As	434-1400
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052

BKX		
Original Part Number	Part Name	Classic Part Number
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
190-0649	Tightener-Belt	434-1407
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
223-3095	Gauge As	360-2295
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
430-7619	Adapter-Cla	438-1812

BLY		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059

BLY		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283

BLY		
Original Part Number	Part Name	Classic Part Number
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

Sales Model 385B (Cont'd.)

BLY		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5P-7807	Bearing-Ball	314-8502
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521

BLY		
Original Part Number	**Part Name**	**Classic Part Number**
8S-6511	Bearing-Sleeve	380-7372
9W-9931	Mount As.	360-2354
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
117-6270	Support As	434-1400
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107

BLY		
Original Part Number	**Part Name**	**Classic Part Number**
154-1642	Gasket Kit - Scl	437-8117
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
189-1814	Kit-Gasket(Ocl)	437-2009
190-0649	Tightener-Belt	434-1407
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
223-3095	Gauge As	360-2295
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
430-7619	Adapter-Cla	438-1812

CLS		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

CLS		
Original Part Number	**Part Name**	**Classic Part Number**
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904

CLS		
Original Part Number	**Part Name**	**Classic Part Number**
4P-2383	Adapter-Inlet	438-1812
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5P-7807	Bearing-Ball	314-8502
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657

Sales Model 385B (Cont'd.)

CLS		
Original Part Number	Part Name	Classic Part Number
6Y-9930	Mount As	360-2353
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9W-9931	Mount As.	360-2354
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868

CLS		
Original Part Number	Part Name	Classic Part Number
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
117-6270	Support As	434-1400
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
137-2817	Bearing-Sleeve	434-2399
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117

CLS		
Original Part Number	Part Name	Classic Part Number
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
189-1814	Kit-Gasket(Ocl)	437-2009
190-0649	Tightener-Belt	434-1407
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
223-3095	Gauge As	360-2295
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
430-7619	Adapter-Cla	438-1812

FDL		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017

FDL		
Original Part Number	Part Name	Classic Part Number
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

FDL		
Original Part Number	Part Name	Classic Part Number
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5P-7807	Bearing-Ball	314-8502
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257

Sales Model 385B (Cont'd.)

FDL		
Original Part Number	Part Name	Classic Part Number
7I-7180	Piston	421-7142
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-2349	Pin	301-4556
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9W-9931	Mount As.	360-2354
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8608	Manifold-Exhaust	376-9062

FDL		
Original Part Number	Part Name	Classic Part Number
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
107-2139	Pin As.	360-2352
108-7930	Bearing As	377-7463
117-6270	Support As	434-1400
123-2111	Piston	462-5714
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
160-9874	Kit-Gasket-Scl	386-3048
163-3749	Bearing-Sleeve	433-7505
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
188-4211	Cylinder As	425-9366
189-1814	Kit-Gasket(Ocl)	437-2009
189-3878	Link As	438-1813

MYA		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913

FDL		
Original Part Number	Part Name	Classic Part Number
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
190-0649	Tightener-Belt	434-1407
192-8318	Bearing-Sleeve	360-2321
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
223-3095	Gauge As	360-2295
225-4529	Cyl Gp-0160 1356	393-3658
228-5621	Bearing-Sleeve	360-2323
236-6269	Bearing-Sleeve	453-6500
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
430-7619	Adapter-Cla	438-1812

Sales Model 385B (Cont'd.)

MYA		
Original Part Number	Part Name	Classic Part Number
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5P-7807	Bearing-Ball	314-8502
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257

MYA		
Original Part Number	Part Name	Classic Part Number
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9W-9931	Mount As.	360-2354
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
117-6270	Support As	434-1400
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193

MYA		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
189-1814	Kit-Gasket(Ocl)	437-2009
190-0649	Tightener-Belt	434-1407
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
223-3095	Gauge As	360-2295
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
430-7619	Adapter-Cla	438-1812

RCD		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020

RCD		
Original Part Number	Part Name	Classic Part Number
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-7238	Shaft As-Pump Dr	379-0164

RCD		
Original Part Number	Part Name	Classic Part Number
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059

Sales Model 385B (Cont'd.)

RCD		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5P-7807	Bearing-Ball	314-8502
6I-2726	Bearing-Sleeve	419-4757
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190

RCD		
Original Part Number	Part Name	Classic Part Number
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9W-9931	Mount As.	360-2354
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
117-6270	Support As	434-1400
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813

RCD		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
189-1814	Kit-Gasket(Ocl)	437-2009
190-0649	Tightener-Belt	434-1407
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
223-3095	Gauge As	360-2295
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
430-7619	Adapter-Cla	438-1812

Sales Model 385C

EAM		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020

EAM		
Original Part Number	Part Name	Classic Part Number
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690

EAM		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

Sales Model 385C (Cont'd.)

EAM		
Original Part Number	Part Name	Classic Part Number
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6E-0787	Bearing-Sleeve	425-6443
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373

EAM		
Original Part Number	Part Name	Classic Part Number
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
117-6270	Support As	434-1400
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

EAM		
Original Part Number	Part Name	Classic Part Number
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
223-3095	Gauge As	360-2295
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

EDA		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812

EDA		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373

EDA		
Original Part Number	Part Name	Classic Part Number
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372

Sales Model 385C (Cont'd.)

EDA		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813

EDA		
Original Part Number	**Part Name**	**Classic Part Number**
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914

EDA		
Original Part Number	**Part Name**	**Classic Part Number**
217-8938	Tightening-Belt	419-4735
223-3095	Gauge As	360-2295
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JCM		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547

JCM		
Original Part Number	**Part Name**	**Classic Part Number**
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

JCM		
Original Part Number	**Part Name**	**Classic Part Number**
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
223-3095	Gauge As	360-2295
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 385C (Cont'd.)

KBC		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451

KBC		
Original Part Number	Part Name	Classic Part Number
7C-5665	Elbow-90 Deg	399-8547
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589

KBC		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
223-3095	Gauge As	360-2295
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KGB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4I-4811	Pin As	480-8268
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271

KGB		
Original Part Number	Part Name	Classic Part Number
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7I-7180	Piston	421-7142
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016

KGB		
Original Part Number	Part Name	Classic Part Number
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-2349	Pin	301-4556
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636

Sales Model 385C (Cont'd.)

KGB		
Original Part Number	Part Name	Classic Part Number
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
107-2139	Pin As.	360-2352
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318

KGB		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
163-3749	Bearing-Sleeve	433-7505
186-2001	Rotocoil As	397-5055
186-5662	Pin	421-1560
187-8979	Gear As	393-3656
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
192-8318	Bearing-Sleeve	360-2321
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
223-3095	Gauge As	360-2295

KGB		
Original Part Number	Part Name	Classic Part Number
228-5621	Bearing-Sleeve	360-2323
236-6269	Bearing-Sleeve	453-6500
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
246-3130	Shaft-Water Pump	392-4508
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KKK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

KKK		
Original Part Number	Part Name	Classic Part Number
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894

KKK		
Original Part Number	Part Name	Classic Part Number
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

Sales Model 385C (Cont'd.)

KKK		
Original Part Number	Part Name	Classic Part Number
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048

KKK		
Original Part Number	Part Name	Classic Part Number
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
223-3095	Gauge As	360-2295

KKK		
Original Part Number	Part Name	Classic Part Number
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MMA		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6E-0787	Bearing-Sleeve	425-6443
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451

MMA		
Original Part Number	Part Name	Classic Part Number
7C-5665	Elbow-90 Deg	399-8547
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
117-6270	Support As	434-1400
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589

MMA		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
223-3095	Gauge As	360-2295
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MNZ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913

Sales Model 385C (Cont'd.)

MNZ		
Original Part Number	Part Name	Classic Part Number
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547

MNZ		
Original Part Number	Part Name	Classic Part Number
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

MNZ		
Original Part Number	Part Name	Classic Part Number
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
223-3095	Gauge As	360-2295
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

SBE		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271

SBE		
Original Part Number	Part Name	Classic Part Number
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133

SBE		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521

Sales Model 385C (Cont'd.)

SBE		
Original Part Number	**Part Name**	**Classic Part Number**
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813

SBE		
Original Part Number	**Part Name**	**Classic Part Number**
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
189-3922	Pin	393-0938
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914

SBE		
Original Part Number	**Part Name**	**Classic Part Number**
217-8938	Tightening-Belt	419-4735
223-3095	Gauge As	360-2295
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

T2E		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4I-4811	Pin As	480-8268
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7I-7180	Piston	421-7142
7J-6461	Crown	325-6054

T2E		
Original Part Number	**Part Name**	**Classic Part Number**
7J-9884	Bearing-Sleeve	325-6016
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7Y-2349	Pin	301-4556
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
107-2139	Pin As.	360-2352
108-7930	Bearing As	377-7463

T2E		
Original Part Number	**Part Name**	**Classic Part Number**
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
163-3749	Bearing-Sleeve	433-7505
186-2001	Rotocoil As	397-5055
186-5662	Pin	421-1560
187-8979	Gear As	393-3656
188-4211	Cylinder As	425-9366
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535

Sales Model 385C (Cont'd.)

T2E		
Original Part Number	**Part Name**	**Classic Part Number**
192-8318	Bearing-Sleeve	360-2321
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
236-6269	Bearing-Sleeve	453-6500

T2E		
Original Part Number	**Part Name**	**Classic Part Number**
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
246-3130	Shaft-Water Pump	392-4508
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
253-1752	Plate-Thrust	379-0170

T2E		
Original Part Number	**Part Name**	**Classic Part Number**
278-1365	Arm As-Ui Rkr	433-7507
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

T2F		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6E-0787	Bearing-Sleeve	425-6443

T2F		
Original Part Number	**Part Name**	**Classic Part Number**
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7Y-4269	Bearing As-Rlr	419-2308
7Y-5102	Bearing-Sleeve	380-7368
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
117-6270	Support As	434-1400
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

T2F		
Original Part Number	**Part Name**	**Classic Part Number**
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
223-3095	Gauge As	360-2295
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 390D

BYP		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657

BYP		
Original Part Number	Part Name	Classic Part Number
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-4269	Bearing As-Rlr	419-2308
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

BYP		
Original Part Number	Part Name	Classic Part Number
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
223-3095	Gauge As	360-2295
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KCZ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603

KCZ		
Original Part Number	Part Name	Classic Part Number
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7Y-4269	Bearing As-Rlr	419-2308

KCZ		
Original Part Number	Part Name	Classic Part Number
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

Sales Model 390D (Cont'd.)

KCZ		
Original Part Number	Part Name	Classic Part Number
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054

KCZ		
Original Part Number	Part Name	Classic Part Number
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
223-3095	Gauge As	360-2295

KCZ		
Original Part Number	Part Name	Classic Part Number
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WAG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657

WAG		
Original Part Number	Part Name	Classic Part Number
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-4269	Bearing As-Rlr	419-2308
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

WAG		
Original Part Number	Part Name	Classic Part Number
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
223-3095	Gauge As	360-2295
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WAP		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690

WAP		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922

WAP		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283

Sales Model 390D (Cont'd.)

WAP		
Original Part Number	Part Name	Classic Part Number
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894

WAP		
Original Part Number	Part Name	Classic Part Number
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052

WAP		
Original Part Number	Part Name	Classic Part Number
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
223-3095	Gauge As	360-2295
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

WBT		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323

WBT		
Original Part Number	Part Name	Classic Part Number
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-4269	Bearing As-Rlr	419-2308

WBT		
Original Part Number	Part Name	Classic Part Number
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

Excavators

Sales Model 390D (Cont'd.)

WBT		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055

WBT		
Original Part Number	Part Name	Classic Part Number
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
223-3095	Gauge As	360-2295

WBT		
Original Part Number	Part Name	Classic Part Number
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 390E

JBK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
7C-0145	Core As-Oclr	374-4720
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190

JBK		
Original Part Number	Part Name	Classic Part Number
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

JBK		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 390F

B37		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489

B37		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171

B37		
Original Part Number	Part Name	Classic Part Number
7C-0145	Core As-Oclr	374-4720
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7Y-4269	Bearing As-Rlr	419-2308

Sales Model 390F (Cont'd.)

B37		
Original Part Number	Part Name	Classic Part Number
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

B37		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368

B37		
Original Part Number	Part Name	Classic Part Number
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
347-6081	Gauge As	360-2348

GAY		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
7C-0145	Core As-Oclr	374-4720
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373

GAY		
Original Part Number	Part Name	Classic Part Number
7N-2213	Bearing-Sleeve	394-0190
7N-7878	Cover-Plate	434-2401
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

GAY		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

HJD		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4W-5698	Bearing-Main	419-6323

HJD		
Original Part Number	Part Name	Classic Part Number
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
7C-0145	Core As-Oclr	374-4720
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373

HJD		
Original Part Number	Part Name	Classic Part Number
7N-2213	Bearing-Sleeve	394-0190
7N-7878	Cover-Plate	434-2401
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648

Sales Model 390F (Cont'd.)

HJD		
Original Part Number	Part Name	Classic Part Number
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

HJD		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914

HJD		
Original Part Number	Part Name	Classic Part Number
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

HSM		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
7C-0145	Core As-Oclr	374-4720
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373

HSM		
Original Part Number	Part Name	Classic Part Number
7N-2213	Bearing-Sleeve	394-0190
7N-7878	Cover-Plate	434-2401
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

HSM		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MGF		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4W-5698	Bearing-Main	419-6323

MGF		
Original Part Number	Part Name	Classic Part Number
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
7C-0145	Core As-Oclr	374-4720
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373

MGF		
Original Part Number	Part Name	Classic Part Number
7N-2213	Bearing-Sleeve	394-0190
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8N-2104	Bell As-Suction	380-1521

Sales Model 390F (Cont'd.)

MGF		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

MGF		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368

MGF		
Original Part Number	Part Name	Classic Part Number
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PT7		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
7C-0145	Core As-Oclr	374-4720
7N-2155	Bearing	383-2133

PT7		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7Y-4269	Bearing As-Rlr	419-2308
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
138-9381	Plate-Spacer	424-7052

PT7		
Original Part Number	Part Name	Classic Part Number
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

TYE		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171

TYE		
Original Part Number	Part Name	Classic Part Number
7C-0145	Core As-Oclr	374-4720
7I-7180	Piston	421-7142
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7878	Cover-Plate	434-2401
7Y-4269	Bearing As-Rlr	419-2308
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648

TYE		
Original Part Number	Part Name	Classic Part Number
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656

Sales Model 390F (Cont'd.)

TYE		
Original Part Number	**Part Name**	**Classic Part Number**
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508

TYE		
Original Part Number	**Part Name**	**Classic Part Number**
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443

TYE		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 538

FM3		
Original Part Number	**Part Name**	**Classic Part Number**
8W-8512	Pin As	385-7220

GMY		
Original Part Number	**Part Name**	**Classic Part Number**
4D-4065	Rod End-Spher	374-1824
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
7Y-1644	Gear-Planet	301-3406
8W-8512	Pin As	385-7220
094-1509	Shaft-Planet	360-2273

GMY		
Original Part Number	**Part Name**	**Classic Part Number**
114-1398	Gauge-Oil Level	394-9815
148-4634	Shaft-Planet	360-2274
179-3008	Cylinder	480-8272
199-4582	Bearing-Needle	388-6589

GMY		
Original Part Number	**Part Name**	**Classic Part Number**
227-6228	Cage	360-2343
240-2913	Bearing-Sleeve	360-2325
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

KBJ		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4812	Pin As	480-8269
7K-0078	Bearing-Sleeve	308-9825
7Y-1644	Gear-Planet	301-3406
8W-8512	Pin As	385-7220
094-1509	Shaft-Planet	360-2273
114-1398	Gauge-Oil Level	394-9815

KBJ		
Original Part Number	**Part Name**	**Classic Part Number**
128-9884	Bearing-Sleeve	360-2315
148-4634	Shaft-Planet	360-2274
179-3008	Cylinder	480-8272
199-4582	Bearing-Needle	388-6589
227-6228	Cage	360-2343

KBJ		
Original Part Number	**Part Name**	**Classic Part Number**
250-2402	Pin As	360-2351
314-8717	Shaft-Cla	360-2273
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 558

FM5		
Original Part Number	**Part Name**	**Classic Part Number**
8W-8512	Pin As	385-7220

LRT		
Original Part Number	**Part Name**	**Classic Part Number**
3D-9132	Cone-Roller Brg	453-3652

Sales Model 558 (Cont'd.)

LRT		
Original Part Number	Part Name	Classic Part Number
3D-9133	Cup-Roller Brg	418-9601
3P-1210	Cone-Roller Brg	399-4433
4D-4065	Rod End-Spher	374-1824
4I-4619	Pin As	425-2564
7I-7180	Piston	421-7142
7K-0078	Bearing-Sleeve	308-9825
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368

LRT		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
8H-5352	Bearing-Ball	453-3658
8W-8512	Pin As	385-7220
087-5805	Pin	301-7967
114-1398	Gauge-Oil Level	394-9815
118-5196	Pin	380-7397
128-9863	Bearing-Sleeve	314-8630
128-9883	Bearing-Sleeve	360-2314

LRT		
Original Part Number	Part Name	Classic Part Number
188-4211	Cylinder As	425-9366
192-8318	Bearing-Sleeve	360-2321
240-2915	Bearing-Sleeve	360-2326
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

RHS		
Original Part Number	Part Name	Classic Part Number
8W-8512	Pin As	385-7220

Sales Model 568

BRB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3P-1210	Cone-Roller Brg	399-4433
4N-2514	Gear-Flywheel	421-7283
6V-3831	Seal-O-Ring	436-2657
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7K-0078	Bearing-Sleeve	308-9825
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368

BRB		
Original Part Number	Part Name	Classic Part Number
7Y-5128	Bearing-Sleeve	314-8648
8H-5352	Bearing-Ball	453-3658
8W-8512	Pin As	385-7220
9Y-2988	Breather As	361-1716
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
105-2659	Bearing-Sleeve	419-2304
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934

BRB		
Original Part Number	Part Name	Classic Part Number
123-2111	Piston	462-5714
128-9882	Bearing-Sleeve	314-8642
156-0738	Rod As	394-8210
161-3411	Gasket	394-0896
188-4211	Cylinder As	425-9366
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

YJX		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2B-0941	Spacer	418-1955
3D-9132	Cone-Roller Brg	453-3652

YJX		
Original Part Number	Part Name	Classic Part Number
3D-9133	Cup-Roller Brg	418-9601
4N-2514	Gear-Flywheel	421-7283
6V-3831	Seal-O-Ring	436-2657

YJX		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
8W-8512	Pin As	385-7220
9Y-2988	Breather As	361-1716

Sales Model 568 (Cont'd.)

YJX		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934

YJX		
Original Part Number	Part Name	Classic Part Number
161-3411	Gasket	394-0896
189-3922	Pin	393-0938
228-5621	Bearing-Sleeve	360-2323

YJX		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 6015

DHB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
7C-0145	Core As-Oclr	374-4720

DHB		
Original Part Number	Part Name	Classic Part Number
7C-0307	Gasket	399-8571
7N-2156	Bearing-Sleeve	380-7373
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9N-3167	Plate-Block Bot	430-4468
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

DHB		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443

DHF		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

DHF		
Original Part Number	Part Name	Classic Part Number
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7N-2156	Bearing-Sleeve	380-7373
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521

DHF		
Original Part Number	Part Name	Classic Part Number
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9N-3167	Plate-Block Bot	430-4468
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589

Sales Model 6015 (Cont'd.)

DHF		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107

DHF		
Original Part Number	Part Name	Classic Part Number
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914

DHF		
Original Part Number	Part Name	Classic Part Number
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443

Sales Model 6015B

LWN		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

LWN		
Original Part Number	Part Name	Classic Part Number
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5F-7404	Nut-Bearing Lock	308-9878
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
6Y-9960	Mount As.	376-3639
7C-0145	Core As-Oclr	374-4720
7N-2156	Bearing-Sleeve	380-7373
8N-2104	Bell As-Suction	380-1521
8N-7257	Mount As	396-0660
8S-6511	Bearing-Sleeve	380-7372
101-3374	Gear-Camshaft Dr	376-9069

LWN		
Original Part Number	Part Name	Classic Part Number
108-7930	Bearing As	377-7463
117-9712	Shaft-Dr Idler	425-7754
127-6356	Cover As.-Pump	420-8566
131-7123	Bearing-Sleeve	422-6919
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367

MKE		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283

MKE		
Original Part Number	Part Name	Classic Part Number
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5F-7404	Nut-Bearing Lock	308-9878
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
6Y-9960	Mount As.	376-3639
7C-0145	Core As-Oclr	374-4720

MKE		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
8N-2104	Bell As-Suction	380-1521
8N-7257	Mount As	396-0660
8S-6511	Bearing-Sleeve	380-7372
101-3374	Gear-Camshaft Dr	376-9069
108-7930	Bearing As	377-7463
117-9712	Shaft-Dr Idler	425-7754
127-6356	Cover As.-Pump	420-8566

Sales Model 6015B (Cont'd.)

MKE		
Original Part Number	**Part Name**	**Classic Part Number**
131-7123	Bearing-Sleeve	422-6919
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107

MKE		
Original Part Number	**Part Name**	**Classic Part Number**
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368

MKE		
Original Part Number	**Part Name**	**Classic Part Number**
216-5582	Bearing-Sleeve	390-0914
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367

PZE		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

PZE		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5F-7404	Nut-Bearing Lock	308-9878
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
6Y-9960	Mount As.	376-3639
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7N-2156	Bearing-Sleeve	380-7373
8N-2104	Bell As-Suction	380-1521
8N-7257	Mount As	396-0660
8S-6511	Bearing-Sleeve	380-7372
101-3374	Gear-Camshaft Dr	376-9069

PZE		
Original Part Number	**Part Name**	**Classic Part Number**
108-7930	Bearing As	377-7463
117-9712	Shaft-Dr Idler	425-7754
127-6356	Cover As.-Pump	420-8566
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367

WSN		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323

WSN		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5F-7404	Nut-Bearing Lock	308-9878
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-8842	Block-Rubber	432-8274
6Y-9960	Mount As.	376-3639
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7N-2156	Bearing-Sleeve	380-7373
8N-2104	Bell As-Suction	380-1521
8N-7257	Mount As	396-0660

WSN		
Original Part Number	**Part Name**	**Classic Part Number**
8S-6511	Bearing-Sleeve	380-7372
101-3374	Gear-Camshaft Dr	376-9069
108-7930	Bearing As	377-7463
117-9712	Shaft-Dr Idler	425-7754
127-6356	Cover As.-Pump	420-8566
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368

Sales Model 6015B (Cont'd.)

WSN		
Original Part Number	Part Name	Classic Part Number
216-5582	Bearing-Sleeve	390-0914

WSN		
Original Part Number	Part Name	Classic Part Number
238-0293	Adapter-Jacket	424-0742

WSN		
Original Part Number	Part Name	Classic Part Number
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367

Sales Model 6018

DHD		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571

DHD		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
7N-7878	Cover-Plate	434-2401
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9N-3167	Plate-Block Bot	430-4468
101-3125	Gasket	420-8567
102-8608	Manifold-Exhaust	376-9062
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589

DHD		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443

DHT		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

DHT		
Original Part Number	Part Name	Classic Part Number
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7N-2156	Bearing-Sleeve	380-7373
7N-7878	Cover-Plate	434-2401
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521

DHT		
Original Part Number	Part Name	Classic Part Number
8N-5305	Spacer	363-7464
8S-6511	Bearing-Sleeve	380-7372
9N-3167	Plate-Block Bot	430-4468
101-3125	Gasket	420-8567
102-8608	Manifold-Exhaust	376-9062
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814

Sales Model 6018 (Cont'd.)

DHT		
Original Part Number	Part Name	Classic Part Number
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106

DHT		
Original Part Number	Part Name	Classic Part Number
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914

DHT		
Original Part Number	Part Name	Classic Part Number
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443

Sales Model 6020B

D4R		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1849	Pipe-Air	421-7143
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323

D4R		
Original Part Number	Part Name	Classic Part Number
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
7C-0145	Core As-Oclr	374-4720
7N-2156	Bearing-Sleeve	380-7373
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3374	Gear-Camshaft Dr	376-9069
108-7930	Bearing As	377-7463

D4R		
Original Part Number	Part Name	Classic Part Number
117-9712	Shaft-Dr Idler	425-7754
127-6356	Cover As.-Pump	420-8566
131-7123	Bearing-Sleeve	422-6919
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367

DNR		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3P-1210	Cone-Roller Brg	399-4433
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

DNR		
Original Part Number	Part Name	Classic Part Number
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7N-2156	Bearing-Sleeve	380-7373
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3374	Gear-Camshaft Dr	376-9069
108-7930	Bearing As	377-7463
117-9712	Shaft-Dr Idler	425-7754
127-6356	Cover As.-Pump	420-8566

DNR		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
238-0293	Adapter-Jacket	424-0742
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367

Sales Model 6030

DHG		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
3P-1210	Cone-Roller Brg	399-4433
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6V-3831	Seal-O-Ring	436-2657

DHG		
Original Part Number	Part Name	Classic Part Number
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-7930	Bearing As	377-7463
117-9712	Shaft-Dr Idler	425-7754
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193

DHG		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
238-0293	Adapter-Jacket	424-0742
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
352-0200	Pump Gp-Water -B	434-6109

DHL		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
3P-1210	Cone-Roller Brg	399-4433
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320

DHL		
Original Part Number	Part Name	Classic Part Number
4W-5701	Bearing-Main	419-6333
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-7930	Bearing As	377-7463
117-9712	Shaft-Dr Idler	425-7754
127-6356	Cover As.-Pump	420-8566

DHL		
Original Part Number	Part Name	Classic Part Number
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914

Excavators

Sales Model 6030 (Cont'd.)

DHL		
Original Part Number	Part Name	Classic Part Number
217-8938	Tightening-Belt	419-4735
238-0293	Adapter-Jacket	424-0742

DHL		
Original Part Number	Part Name	Classic Part Number
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367

DHL		
Original Part Number	Part Name	Classic Part Number
352-0200	Pump Gp-Water -B	434-6109

Sales Model 6030B

EX3		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720

EX3		
Original Part Number	Part Name	Classic Part Number
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-7930	Bearing As	377-7463
117-9712	Shaft-Dr Idler	425-7754
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919

EX3		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
238-0293	Adapter-Jacket	424-0742
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
352-0200	Pump Gp-Water -B	434-6109

EX4		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271

EX4		
Original Part Number	Part Name	Classic Part Number
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6V-3831	Seal-O-Ring	436-2657
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7N-2156	Bearing-Sleeve	380-7373

EX4		
Original Part Number	Part Name	Classic Part Number
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-7930	Bearing As	377-7463
117-9712	Shaft-Dr Idler	425-7754

Sales Model 6030B (Cont'd.)

EX4		
Original Part Number	Part Name	Classic Part Number
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112

EX4		
Original Part Number	Part Name	Classic Part Number
137-1970	Impeller-Pump	380-1553
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914

EX4		
Original Part Number	Part Name	Classic Part Number
217-8938	Tightening-Belt	419-4735
238-0293	Adapter-Jacket	424-0742
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
352-0200	Pump Gp-Water -B	434-6109

Sales Model 6040

DHJ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
3P-1210	Cone-Roller Brg	399-4433
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-6658	Bearing-Sleeve	373-1885
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320

DHJ		
Original Part Number	Part Name	Classic Part Number
4W-5701	Bearing-Main	419-6333
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3374	Gear-Camshaft Dr	376-9069
108-7930	Bearing As	377-7463
117-9712	Shaft-Dr Idler	425-7754

DHJ		
Original Part Number	Part Name	Classic Part Number
127-6356	Cover As.-Pump	420-8566
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367

DHX		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
3P-1210	Cone-Roller Brg	399-4433
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-6658	Bearing-Sleeve	373-1885

DHX		
Original Part Number	Part Name	Classic Part Number
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
8N-2104	Bell As-Suction	380-1521

DHX		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
101-3374	Gear-Camshaft Dr	376-9069
108-7930	Bearing As	377-7463
117-9712	Shaft-Dr Idler	425-7754
127-6356	Cover As.-Pump	420-8566
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813

Excavators

Sales Model 6040 (Cont'd.)

DHX		
Original Part Number	**Part Name**	**Classic Part Number**
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
186-2001	Rotocoil As	397-5055

DHX		
Original Part Number	**Part Name**	**Classic Part Number**
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914

DHX		
Original Part Number	**Part Name**	**Classic Part Number**
217-8938	Tightening-Belt	419-4735
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367

Sales Model 6060

DH3		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1W-6005	Bearing-Sleeve	417-4521
2A-4429	Lock-Retainer	379-0174

DH3		
Original Part Number	**Part Name**	**Classic Part Number**
2N-5842	Screw-Bridge Adj	418-1934
4N-1320	Gasket-Adapter	398-2928
7N-5449	Spool-Press Rlf	434-2450

DH3		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
9Y-0635	Spacer	435-8519

DHN		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1W-6005	Bearing-Sleeve	417-4521
2A-4429	Lock-Retainer	379-0174

DHN		
Original Part Number	**Part Name**	**Classic Part Number**
2N-5842	Screw-Bridge Adj	418-1934
4N-1320	Gasket-Adapter	398-2928
7N-5449	Spool-Press Rlf	434-2450

DHN		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
9Y-0635	Spacer	435-8519

Sales Model E70

3BG		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
308-1845	Seal-Wiper	472-8032

3CG		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
308-1845	Seal-Wiper	472-8032

Sales Model E70B

5TG		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4903	Mount As	396-7274

Sales Model E70B (Cont'd.)

5TG		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
7C-4349	Mount As	383-2117

5TG		
Original Part Number	Part Name	Classic Part Number
9Y-9431	Precleaner As	361-1718
127-8592	Muffler As	347-0463

5TG		
Original Part Number	Part Name	Classic Part Number
135-8167	Pipe-Extension	395-1305

Sales Model E110

3GG		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203

Sales Model E110B

8MF		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3E-7461	Gasket Kit-Sch	437-4575
4B-1455	Cap As-Filler	361-1719
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6I-1099	Manifold-Exh	424-6366
6I-4689	Gasket-Cyl Head	377-5840
6V-2202	Bearing-Spl Ball	380-1574
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

8MF		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069

8MF		
Original Part Number	Part Name	Classic Part Number
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
119-2950	Gasket	433-8195
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Excavators

Sales Model E120B

6JF		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
6I-4689	Gasket-Cyl Head	377-5840
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025

6JF		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219

6JF		
Original Part Number	Part Name	Classic Part Number
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
119-2950	Gasket	433-8195
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model E180

1RF		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981

1RF		
Original Part Number	Part Name	Classic Part Number
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2N-1599	Gear	378-3970
2W-1223	Pump Gp-Water	385-7197

1RF		
Original Part Number	Part Name	Classic Part Number
2W-8271	Arm As-Rocker	432-8912
3N-4892	Lever-Gov Cont	439-4542
4N-0432	Bearing-Ball	417-4499
4P-7688	Valve As-Check	420-6216
4W-6869	Spacer-Fuel Pump	417-4534
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537

Sales Model E180 (Cont'd.)

1RF		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
6N-1553	Coupling-Exhaust	295-6422
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
7C-7955	Gasket-Cover	382-6899
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-7166	Race-Brg Thrust	417-4531

1RF		
Original Part Number	Part Name	Classic Part Number
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
9L-7682	Valve-Inlet	385-9266

1RF		
Original Part Number	Part Name	Classic Part Number
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9Y-5168	Manifold-Exhaust	374-7483
114-0468	Pin-G.E.T.	443-1203
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
134-8949	Plate	383-2110
193-5016	Flange	425-3644

Sales Model E200B

4SG		
Original Part Number	Part Name	Classic Part Number
096-4002	Bearing	420-3221

6KF		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449

6KF		
Original Part Number	Part Name	Classic Part Number
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7X-2522	Gasket Kit	437-8648
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
096-4002	Bearing	420-3221
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
106-2822	Gasket Kit	436-8376
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693

6KF		
Original Part Number	Part Name	Classic Part Number
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
134-8948	Plate	399-8588
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

1FG		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2W-1707	Ring-Piston Top	270-4356

1FG		
Original Part Number	Part Name	Classic Part Number
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing-Ball	311-9356
3N-4892	Lever-Gov Cont	439-4542
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5P-8768	Kit-Gasket (Scl)	393-1024

1FG		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613

Sales Model E240 (Cont'd.)

1FG		
Original Part Number	**Part Name**	**Classic Part Number**
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585

1FG		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1606	Kit-Gskt-Sch	386-3046
8T-9486	Gasket Kt	393-5197
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
134-8948	Plate	399-8588
134-8949	Plate	383-2110
148-7455	Valve - Exhaust	270-4361

1FG		
Original Part Number	**Part Name**	**Classic Part Number**
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

2HF		
Original Part Number	**Part Name**	**Classic Part Number**
2K-6413	Pin	360-2270

8SF		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2K-6413	Pin	360-2270
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449

8SF		
Original Part Number	**Part Name**	**Classic Part Number**
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-3428	Bearing-Sleeve	314-8647
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694

8SF		
Original Part Number	**Part Name**	**Classic Part Number**
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
264-6898	Kit-Gasket-Sch	382-5069
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

9PF		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2K-6413	Pin	360-2270
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443

9PF		
Original Part Number	**Part Name**	**Classic Part Number**
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545

9PF		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-3428	Bearing-Sleeve	314-8647
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697

Sales Model E240B (Cont'd.)

9PF		
Original Part Number	Part Name	Classic Part Number
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697

9PF		
Original Part Number	Part Name	Classic Part Number
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
264-6898	Kit-Gasket-Sch	382-5069

9PF		
Original Part Number	Part Name	Classic Part Number
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model E240C

2RL		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
2K-6413	Pin	360-2270
113-6200	Gasket	438-2020

2RL		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
119-2940	Gasket	378-4002
134-8948	Plate	399-8588

2RL		
Original Part Number	Part Name	Classic Part Number
134-8949	Plate	383-2110
193-5016	Flange	425-3644

Sales Model E300

1KG		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
114-0468	Pin-G.E.T.	443-1203

2CF		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-5480	Cover As.-End	299-1998
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036

2CF		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

2CF		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088

Sales Model E300 (Cont'd.)

2CF		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
3N-4892	Lever-Gov Cont	439-4542
4N-0432	Bearing-Ball	417-4499
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

2CF		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2834	Kit-Repair	374-4723
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212

2CF		
Original Part Number	Part Name	Classic Part Number
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587

Sales Model E300 (Cont'd.)

2CF		
Original Part Number	Part Name	Classic Part Number
9L-5521	Manifold-Exhaust	396-9895
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351

2CF		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698

2CF		
Original Part Number	Part Name	Classic Part Number
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-8016	Kit-Gasket-Sch	393-0919
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

Sales Model E300B

1WJ		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
114-0468	Pin-G.E.T.	443-1203

2HJ		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270

Sales Model EL200B

7DF		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513

7DF		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

7DF		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986

Excavators

Sales Model EL200B (Cont'd.)

7DF		
Original Part Number	**Part Name**	**Classic Part Number**
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381

7DF		
Original Part Number	**Part Name**	**Classic Part Number**
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
134-8948	Plate	399-8588
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697

7DF		
Original Part Number	**Part Name**	**Classic Part Number**
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model EL240

4JF		
Original Part Number	**Part Name**	**Classic Part Number**
2K-6413	Pin	360-2270
114-0468	Pin-G.E.T.	443-1203
134-8948	Plate	399-8588

4MF		
Original Part Number	**Part Name**	**Classic Part Number**
2K-6413	Pin	360-2270

Sales Model EL240B

5WG		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066

5WG		
Original Part Number	**Part Name**	**Classic Part Number**
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986

5WG		
Original Part Number	**Part Name**	**Classic Part Number**
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-2396	Bearing-Sleeve	314-8634
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

Sales Model EL240B (Cont'd.)

5WG		
Original Part Number	Part Name	Classic Part Number
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380

5WG		
Original Part Number	Part Name	Classic Part Number
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370

5WG		
Original Part Number	Part Name	Classic Part Number
229-5154	Bearing-Thrust	419-6369
264-6898	Kit-Gasket-Sch	382-5069
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

5WG		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449

5WG		
Original Part Number	Part Name	Classic Part Number
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697

5WG		
Original Part Number	Part Name	Classic Part Number
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
264-6898	Kit-Gasket-Sch	382-5069
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model EL240C

9PK		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384

Excavators

Sales Model EL240C (Cont'd.)

9PK		
Original Part Number	**Part Name**	**Classic Part Number**
2K-6413	Pin	360-2270
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203

9PK		
Original Part Number	**Part Name**	**Classic Part Number**
119-2940	Gasket	378-4002
134-8948	Plate	399-8588

9PK		
Original Part Number	**Part Name**	**Classic Part Number**
134-8949	Plate	383-2110
193-5016	Flange	425-3644

Sales Model EL300

4NF		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
4W-0452	Seal As -Cshaft	325-6191
5P-8768	Kit-Gasket (Scl)	393-1024

4NF		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7628	Gasket	419-1811
7N-8018	Seal-Water	418-1964
7W-7546	Gasket-Plate	433-8187
9Y-1798	Seal-Water	379-0165
111-8015	Gasket As-Head	279-4977

4NF		
Original Part Number	**Part Name**	**Classic Part Number**
114-0468	Pin-G.E.T.	443-1203
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

4SF		
Original Part Number	**Part Name**	**Classic Part Number**
2K-6413	Pin	360-2270

Sales Model EL300B

3FJ		
Original Part Number	**Part Name**	**Classic Part Number**
114-0468	Pin-G.E.T.	443-1203

Sales Model M312

6TL		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
2S-0479	Bearing-Cone	380-7506
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6V-0832	Cone-Rlr Bearing	453-3654
7Y-2396	Bearing-Sleeve	314-8634

6TL		
Original Part Number	**Part Name**	**Classic Part Number**
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
9R-6950	Pinion-Planetary	391-9872
086-0414	Flange	392-4522
086-0523	Pin	314-8696
106-6878	Pin	372-7510

6TL		
Original Part Number	**Part Name**	**Classic Part Number**
114-0468	Pin-G.E.T.	443-1203
121-7627	Bearing-Roller	453-3653
121-7632	Disc-Clutch	394-9195
134-8948	Plate	399-8588
178-8608	Cone	422-6479
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model M313C

BDR		
Original Part Number	Part Name	Classic Part Number
2S-0479	Bearing-Cone	380-7506
4I-0453	Bearing-Sleeve	360-2331
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6V-0832	Cone-Rlr Bearing	453-3654
7Y-2396	Bearing-Sleeve	314-8634

BDR		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
9R-6950	Pinion-Planetary	391-9872
086-0523	Pin	314-8696
106-6878	Pin	372-7510
121-7627	Bearing-Roller	453-3653

BDR		
Original Part Number	Part Name	Classic Part Number
121-7632	Disc-Clutch	394-9195
130-6879	Seal	347-0482
134-8948	Plate	399-8588
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348

H2A		
Original Part Number	Part Name	Classic Part Number
2S-0479	Bearing-Cone	380-7506
4I-0453	Bearing-Sleeve	360-2331
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6V-0832	Cone-Rlr Bearing	453-3654
7Y-2396	Bearing-Sleeve	314-8634

H2A		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
9R-6950	Pinion-Planetary	391-9872
086-0523	Pin	314-8696
106-6878	Pin	372-7510
121-7627	Bearing-Roller	453-3653

H2A		
Original Part Number	Part Name	Classic Part Number
121-7632	Disc-Clutch	394-9195
130-6879	Seal	347-0482
134-8948	Plate	399-8588
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348

Sales Model M313D

J3A		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
7Y-2396	Bearing-Sleeve	314-8634

J3A		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
086-0523	Pin	314-8696
106-6878	Pin	372-7510

J3A		
Original Part Number	Part Name	Classic Part Number
121-7627	Bearing-Roller	453-3653
130-6879	Seal	347-0482
134-8948	Plate	399-8588
178-8608	Cone	422-6479

K3D		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
7Y-2396	Bearing-Sleeve	314-8634

K3D		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
086-0523	Pin	314-8696
106-6878	Pin	372-7510

K3D		
Original Part Number	Part Name	Classic Part Number
121-7627	Bearing-Roller	453-3653
130-6879	Seal	347-0482
134-8948	Plate	399-8588
178-8608	Cone	422-6479

Excavators

Sales Model M313D (Cont'd.)

W3H		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
7Y-2396	Bearing-Sleeve	314-8634

W3H		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
086-0523	Pin	314-8696
106-6878	Pin	372-7510

W3H		
Original Part Number	Part Name	Classic Part Number
121-7627	Bearing-Roller	453-3653
130-6879	Seal	347-0482
134-8948	Plate	399-8588
178-8608	Cone	422-6479

Sales Model M314F

F4A		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
7Y-2396	Bearing-Sleeve	314-8634

F4A		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
086-0523	Pin	314-8696

F4A		
Original Part Number	Part Name	Classic Part Number
106-6878	Pin	372-7510
121-7627	Bearing-Roller	453-3653
130-6879	Seal	347-0482
178-8608	Cone	422-6479

Sales Model M315

7ML		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2S-0479	Bearing-Cone	380-7506
4I-0453	Bearing-Sleeve	360-2331
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6V-0832	Cone-Rlr Bearing	453-3654
7Y-2396	Bearing-Sleeve	314-8634

7ML		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
8H-9789	Bearing-Ball	374-8342
9R-6950	Pinion-Planetary	391-9872
086-0414	Flange	392-4522
086-0523	Pin	314-8696
106-6878	Pin	372-7510

7ML		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
121-7627	Bearing-Roller	453-3653
121-7632	Disc-Clutch	394-9195
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319
178-8608	Cone	422-6479
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model M315C

BDM		
Original Part Number	Part Name	Classic Part Number
2S-0479	Bearing-Cone	380-7506
2V-0707	Bearing-Sleeve	360-2328
4I-0453	Bearing-Sleeve	360-2331

BDM		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6V-0832	Cone-Rlr Bearing	453-3654
7Y-2396	Bearing-Sleeve	314-8634

BDM		
Original Part Number	Part Name	Classic Part Number
7Y-3552	Bearing-Sleeve	364-5266
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503

Sales Model M315C (Cont'd.)

BDM		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
8H-9789	Bearing-Ball	374-8342
9R-6950	Pinion-Planetary	391-9872
086-0523	Pin	314-8696

BDM		
Original Part Number	Part Name	Classic Part Number
106-6878	Pin	372-7510
121-7627	Bearing-Roller	453-3653
121-7632	Disc-Clutch	394-9195
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319

BDM		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348

H2B		
Original Part Number	Part Name	Classic Part Number
2S-0479	Bearing-Cone	380-7506
2V-0707	Bearing-Sleeve	360-2328
4I-0453	Bearing-Sleeve	360-2331
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6V-0832	Cone-Rlr Bearing	453-3654
7Y-2396	Bearing-Sleeve	314-8634

H2B		
Original Part Number	Part Name	Classic Part Number
7Y-3552	Bearing-Sleeve	364-5266
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
8H-9789	Bearing-Ball	374-8342
9R-6950	Pinion-Planetary	391-9872
086-0523	Pin	314-8696

H2B		
Original Part Number	Part Name	Classic Part Number
106-6878	Pin	372-7510
121-7627	Bearing-Roller	453-3653
121-7632	Disc-Clutch	394-9195
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348

Sales Model M315D

CA4		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
7Y-2396	Bearing-Sleeve	314-8634

CA4		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
086-0523	Pin	314-8696

CA4		
Original Part Number	Part Name	Classic Part Number
106-6878	Pin	372-7510
121-7627	Bearing-Roller	453-3653
130-6879	Seal	347-0482
178-8608	Cone	422-6479

CH3		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
7Y-2396	Bearing-Sleeve	314-8634

CH3		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
086-0523	Pin	314-8696

CH3		
Original Part Number	Part Name	Classic Part Number
106-6878	Pin	372-7510
121-7627	Bearing-Roller	453-3653
130-6879	Seal	347-0482
178-8608	Cone	422-6479

J5B		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331

Sales Model M315D (Cont'd.)

J5B		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
7Y-2396	Bearing-Sleeve	314-8634
7Y-3552	Bearing-Sleeve	364-5266

J5B		
Original Part Number	Part Name	Classic Part Number
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411

J5B		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
106-6878	Pin	372-7510
134-8948	Plate	399-8588

K5E		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
7Y-2396	Bearing-Sleeve	314-8634

K5E		
Original Part Number	Part Name	Classic Part Number
7Y-3552	Bearing-Sleeve	364-5266
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503

K5E		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
086-0523	Pin	314-8696
106-6878	Pin	372-7510
134-8948	Plate	399-8588

W5M		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
7Y-2396	Bearing-Sleeve	314-8634

W5M		
Original Part Number	Part Name	Classic Part Number
7Y-3552	Bearing-Sleeve	364-5266
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503

W5M		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
086-0523	Pin	314-8696
106-6878	Pin	372-7510
134-8948	Plate	399-8588

Sales Model M315F

F5B		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
8B-5972	Bearing-Ball	314-8503
121-7627	Bearing-Roller	453-3653

F5B		
Original Part Number	Part Name	Classic Part Number
130-6879	Seal	347-0482
178-8608	Cone	422-6479

Sales Model M316C

BDX		
Original Part Number	Part Name	Classic Part Number
2D-9191	Cone-Roller Brg	374-1837
2S-0479	Bearing-Cone	380-7506
2V-0707	Bearing-Sleeve	360-2328
3W-8239	Sleeve-Wear	360-2342

BDX		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6V-0832	Cone-Rlr Bearing	453-3654

BDX		
Original Part Number	Part Name	Classic Part Number
7Y-2396	Bearing-Sleeve	314-8634
7Y-3552	Bearing-Sleeve	364-5266
7Y-5131	Bearing-Sleeve	301-4626

Sales Model M316C (Cont'd.)

BDX		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
8H-9789	Bearing-Ball	374-8342
9R-6950	Pinion-Planetary	391-9872
086-0414	Flange	392-4522

BDX		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
106-6878	Pin	372-7510
121-7627	Bearing-Roller	453-3653
121-7632	Disc-Clutch	394-9195
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319

BDX		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348

H2C		
Original Part Number	Part Name	Classic Part Number
2D-9191	Cone-Roller Brg	374-1837
2S-0479	Bearing-Cone	380-7506
2V-0707	Bearing-Sleeve	360-2328
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6V-0832	Cone-Rlr Bearing	453-3654
7Y-2396	Bearing-Sleeve	314-8634

H2C		
Original Part Number	Part Name	Classic Part Number
7Y-3552	Bearing-Sleeve	364-5266
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
8H-9789	Bearing-Ball	374-8342
9R-6950	Pinion-Planetary	391-9872
086-0414	Flange	392-4522
086-0523	Pin	314-8696
106-6878	Pin	372-7510

H2C		
Original Part Number	Part Name	Classic Part Number
121-7627	Bearing-Roller	453-3653
121-7632	Disc-Clutch	394-9195
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348

Sales Model M316D

D6W		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
7Y-2396	Bearing-Sleeve	314-8634

D6W		
Original Part Number	Part Name	Classic Part Number
7Y-3552	Bearing-Sleeve	364-5266
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503

D6W		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
086-0523	Pin	314-8696
106-6878	Pin	372-7510
134-8948	Plate	399-8588

P6K		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
7Y-2396	Bearing-Sleeve	314-8634

P6K		
Original Part Number	Part Name	Classic Part Number
7Y-3552	Bearing-Sleeve	364-5266
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503

P6K		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
086-0523	Pin	314-8696
106-6878	Pin	372-7510
134-8948	Plate	399-8588

Excavators

Sales Model M316D (Cont'd.)

W6A		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
7Y-2396	Bearing-Sleeve	314-8634

W6A		
Original Part Number	Part Name	Classic Part Number
7Y-3552	Bearing-Sleeve	364-5266
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503

W6A		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
086-0523	Pin	314-8696
106-6878	Pin	372-7510
134-8948	Plate	399-8588

Sales Model M316F

F6N		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
7Y-2396	Bearing-Sleeve	314-8634

F6N		
Original Part Number	Part Name	Classic Part Number
7Y-3552	Bearing-Sleeve	364-5266
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503

F6N		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
086-0523	Pin	314-8696
106-6878	Pin	372-7510

Sales Model M317D

CA6		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
7Y-2396	Bearing-Sleeve	314-8634

CA6		
Original Part Number	Part Name	Classic Part Number
7Y-3552	Bearing-Sleeve	364-5266
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503

CA6		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
086-0523	Pin	314-8696
106-6878	Pin	372-7510

CH5		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
7Y-2396	Bearing-Sleeve	314-8634

CH5		
Original Part Number	Part Name	Classic Part Number
7Y-3552	Bearing-Sleeve	364-5266
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503

CH5		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
086-0523	Pin	314-8696
106-6878	Pin	372-7510

Sales Model M318

6ES		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384

Sales Model M318 (Cont'd.)

6ES		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2D-9191	Cone-Roller Brg	374-1837
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7K-0078	Bearing-Sleeve	308-9825
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551

6ES		
Original Part Number	Part Name	Classic Part Number
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7Y-3428	Bearing-Sleeve	314-8647
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8S-0248	Breather As	325-6033
9F-3212	Bearing-Ball	384-5953
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219

6ES		
Original Part Number	Part Name	Classic Part Number
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
120-0300	Fan As-Radiator	419-4648
126-5875	Flywheel As.	374-4694
134-8948	Plate	399-8588
134-8949	Plate	383-2110
136-0819	Valve-Exhaust	384-8697
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
165-5255	Pin As	425-6449
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

8AL		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2N-1599	Gear	378-3970
2S-0479	Bearing-Cone	380-7506
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513

8AL		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
6V-0832	Cone-Rlr Bearing	453-3654
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

8AL		
Original Part Number	Part Name	Classic Part Number
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545

Sales Model M318 (Cont'd.)

8AL		
Original Part Number	Part Name	Classic Part Number
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8S-0248	Breather As	325-6033
9R-6950	Pinion-Planetary	391-9872
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692

8AL		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
120-0300	Fan As-Radiator	419-4648
121-7627	Bearing-Roller	453-3653
121-7632	Disc-Clutch	394-9195
126-5875	Flywheel As.	374-4694
134-8948	Plate	399-8588
134-8949	Plate	383-2110
136-0819	Valve-Exhaust	384-8697
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336

8AL		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
165-5255	Pin As	425-6449
178-8608	Cone	422-6479
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

8SS		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2D-9191	Cone-Roller Brg	374-1837
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317

8SS		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7Y-3428	Bearing-Sleeve	314-8647
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8S-0248	Breather As	325-6033

8SS		
Original Part Number	Part Name	Classic Part Number
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
120-0300	Fan As-Radiator	419-4648
126-5875	Flywheel As.	374-4694

Sales Model M318 (Cont'd.)

8SS		
Original Part Number	Part Name	Classic Part Number
134-8948	Plate	399-8588
134-8949	Plate	383-2110
136-0819	Valve-Exhaust	384-8697
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388

8SS		
Original Part Number	Part Name	Classic Part Number
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
165-5255	Pin As	425-6449
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370

8SS		
Original Part Number	Part Name	Classic Part Number
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

BMD		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2N-1599	Gear	378-3970
2S-0479	Bearing-Cone	380-7506
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
6V-0832	Cone-Rlr Bearing	453-3654
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551

BMD		
Original Part Number	Part Name	Classic Part Number
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7Y-2357	Pin	301-4564
7Y-3428	Bearing-Sleeve	314-8647
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8S-0248	Breather As	325-6033
9R-6950	Pinion-Planetary	391-9872
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
120-0300	Fan As-Radiator	419-4648

BMD		
Original Part Number	Part Name	Classic Part Number
121-7627	Bearing-Roller	453-3653
121-7632	Disc-Clutch	394-9195
126-5875	Flywheel As.	374-4694
134-8948	Plate	399-8588
136-0819	Valve-Exhaust	384-8697
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
165-5255	Pin As	425-6449
178-8608	Cone	422-6479
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

BCZ		
Original Part Number	**Part Name**	**Classic Part Number**
2S-0479	Bearing-Cone	380-7506
6H-3957	Bearing-Ball	311-9358
6V-0832	Cone-Rlr Bearing	453-3654
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
8H-9789	Bearing-Ball	374-8342

BCZ		
Original Part Number	**Part Name**	**Classic Part Number**
9R-6950	Pinion-Planetary	391-9872
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
121-7627	Bearing-Roller	453-3653
121-7632	Disc-Clutch	394-9195
134-8948	Plate	399-8588

BCZ		
Original Part Number	**Part Name**	**Classic Part Number**
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
193-5016	Flange	425-3644
347-6081	Gauge As	360-2348

BEB		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9191	Cone-Roller Brg	374-1837
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411

BEB		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317

BEB		
Original Part Number	**Part Name**	**Classic Part Number**
176-3900	Accumulator	416-5513
193-5016	Flange	425-3644
347-6081	Gauge As	360-2348

H2D		
Original Part Number	**Part Name**	**Classic Part Number**
2S-0479	Bearing-Cone	380-7506
6H-3957	Bearing-Ball	311-9358
6V-0832	Cone-Rlr Bearing	453-3654
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
8H-9789	Bearing-Ball	374-8342

H2D		
Original Part Number	**Part Name**	**Classic Part Number**
9R-6950	Pinion-Planetary	391-9872
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
121-7627	Bearing-Roller	453-3653
121-7632	Disc-Clutch	394-9195
134-8948	Plate	399-8588

H2D		
Original Part Number	**Part Name**	**Classic Part Number**
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
193-5016	Flange	425-3644
347-6081	Gauge As	360-2348

H2F		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9191	Cone-Roller Brg	374-1837
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411

H2F		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317

H2F		
Original Part Number	**Part Name**	**Classic Part Number**
176-3900	Accumulator	416-5513
193-5016	Flange	425-3644
347-6081	Gauge As	360-2348

Sales Model M318D

D8W		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411

D8W		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
134-8948	Plate	399-8588

P8L		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411

P8L		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
134-8948	Plate	399-8588

P9M		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
8B-5972	Bearing-Ball	314-8503

P9M		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
9F-3212	Bearing-Ball	384-5953
087-5548	Bearing-Sleeve	396-1568

P9M		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
134-8948	Plate	399-8588

W8P		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
7Y-2396	Bearing-Sleeve	314-8634

W8P		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
087-5548	Bearing-Sleeve	396-1568

W8P		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319

Sales Model M318F

F8B		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
7Y-2396	Bearing-Sleeve	314-8634

F8B		
Original Part Number	Part Name	Classic Part Number
7Y-3552	Bearing-Sleeve	364-5266
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503

F8B		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
086-0523	Pin	314-8696
106-6878	Pin	372-7510
134-8948	Plate	399-8588

6WL		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703
2D-9191	Cone-Roller Brg	374-1837
2N-1599	Gear	378-3970
2S-0479	Bearing-Cone	380-7506
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
6V-0832	Cone-Rlr Bearing	453-3654
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7K-0078	Bearing-Sleeve	308-9825
7W-3773	Pulley-Cshaft	383-1583

6WL		
Original Part Number	**Part Name**	**Classic Part Number**
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8S-0248	Breather As	325-6033
9F-3212	Bearing-Ball	384-5953
9R-6950	Pinion-Planetary	391-9872
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002

6WL		
Original Part Number	**Part Name**	**Classic Part Number**
120-0300	Fan As-Radiator	419-4648
121-7627	Bearing-Roller	453-3653
121-7632	Disc-Clutch	394-9195
126-5875	Flywheel As.	374-4694
134-8948	Plate	399-8588
134-8949	Plate	383-2110
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
137-8479	Spacer	395-1323
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
165-5255	Pin As	425-6449
178-8608	Cone	422-6479
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

9PS		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1W-1064	Gear-Flywheel	374-4703

Sales Model M320 (Cont'd.)

9PS		
Original Part Number	Part Name	Classic Part Number
2D-9191	Cone-Roller Brg	374-1837
2N-1599	Gear	378-3970
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3W-8239	Sleeve-Wear	360-2342
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6I-1099	Manifold-Exh	424-6366
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7K-0078	Bearing-Sleeve	308-9825
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551

9PS		
Original Part Number	Part Name	Classic Part Number
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7Y-2396	Bearing-Sleeve	314-8634
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
087-5533	Bearing-Sleeve	314-8628
087-5805	Pin	301-7967
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
114-0468	Pin-G.E.T.	443-1203
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
120-0300	Fan As-Radiator	419-4648

9PS		
Original Part Number	Part Name	Classic Part Number
126-5875	Flywheel As.	374-4694
134-8948	Plate	399-8588
134-8949	Plate	383-2110
136-0819	Valve-Exhaust	384-8697
137-2819	Bearing-Sleeve	360-2317
137-8479	Spacer	395-1323
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
193-5016	Flange	425-3644
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-6270	Bearing-Sleeve	425-6436
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model M320D

CH9		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411

CH9		
Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
087-5548	Bearing-Sleeve	396-1568

CH9		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
106-6878	Pin	372-7510
134-8948	Plate	399-8588

Excavators

Sales Model M320D (Cont'd.)

EN8		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411

EN8		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967

EN8		
Original Part Number	Part Name	Classic Part Number
134-8948	Plate	399-8588

Sales Model M320F

F2W		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411

F2W		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
087-5805	Pin	301-7967
134-8948	Plate	399-8588

Sales Model M322C

BDK		
Original Part Number	Part Name	Classic Part Number
2D-9191	Cone-Roller Brg	374-1837
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
6H-3957	Bearing-Ball	311-9358
7Y-2396	Bearing-Sleeve	314-8634

BDK		
Original Part Number	Part Name	Classic Part Number
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
8H-9789	Bearing-Ball	374-8342
9F-3212	Bearing-Ball	384-5953
087-5805	Pin	301-7967

BDK		
Original Part Number	Part Name	Classic Part Number
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
176-3900	Accumulator	416-5513
193-5016	Flange	425-3644
347-6081	Gauge As	360-2348

BDY		
Original Part Number	Part Name	Classic Part Number
2D-9191	Cone-Roller Brg	374-1837
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
6H-3957	Bearing-Ball	311-9358
7Y-5131	Bearing-Sleeve	301-4626

BDY		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
8H-9789	Bearing-Ball	374-8342
9F-3212	Bearing-Ball	384-5953
087-5805	Pin	301-7967
134-8948	Plate	399-8588

BDY		
Original Part Number	Part Name	Classic Part Number
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
176-3900	Accumulator	416-5513
193-5016	Flange	425-3644
347-6081	Gauge As	360-2348

Sales Model M322C (Cont'd.)

H2E		
Original Part Number	Part Name	Classic Part Number
2D-9191	Cone-Roller Brg	374-1837
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
6H-3957	Bearing-Ball	311-9358
7Y-2396	Bearing-Sleeve	314-8634

H2E		
Original Part Number	Part Name	Classic Part Number
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
8H-9789	Bearing-Ball	374-8342
9F-3212	Bearing-Ball	384-5953
087-5805	Pin	301-7967

H2E		
Original Part Number	Part Name	Classic Part Number
134-8948	Plate	399-8588
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
176-3900	Accumulator	416-5513
193-5016	Flange	425-3644
347-6081	Gauge As	360-2348

H2G		
Original Part Number	Part Name	Classic Part Number
2D-9191	Cone-Roller Brg	374-1837
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
6H-3957	Bearing-Ball	311-9358
7Y-5131	Bearing-Sleeve	301-4626

H2G		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
8H-9789	Bearing-Ball	374-8342
9F-3212	Bearing-Ball	384-5953
087-5805	Pin	301-7967
134-8948	Plate	399-8588

H2G		
Original Part Number	Part Name	Classic Part Number
134-8949	Plate	383-2110
137-2819	Bearing-Sleeve	360-2317
137-2919	Bearing-Sleeve	360-2319
176-3900	Accumulator	416-5513
193-5016	Flange	425-3644
347-6081	Gauge As	360-2348

Sales Model M322D

D2W		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
6H-3957	Bearing-Ball	311-9358

D2W		
Original Part Number	Part Name	Classic Part Number
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411

D2W		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319

EN2		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332

EN2		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503

EN2		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
134-8948	Plate	399-8588

EN9		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331

EN9		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
8B-5972	Bearing-Ball	314-8503

Sales Model M322D (Cont'd.)

EN9		
Original Part Number	Part Name	Classic Part Number
9F-3212	Bearing-Ball	384-5953
087-5548	Bearing-Sleeve	396-1568

EN9		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
134-8948	Plate	399-8588

P2T		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332

P2T		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503

P2T		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
087-5805	Pin	301-7967
134-8948	Plate	399-8588

P3W		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332

P3W		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
6H-3957	Bearing-Ball	311-9358
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503
9F-3212	Bearing-Ball	384-5953

P3W		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
115-4072	Bearing	397-5069
134-8948	Plate	399-8588
161-3411	Gasket	394-0896
229-1490	Sleeve-Injector	393-3659

W2S		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
6H-3957	Bearing-Ball	311-9358
7K-0078	Bearing-Sleeve	308-9825

W2S		
Original Part Number	Part Name	Classic Part Number
7Y-2396	Bearing-Sleeve	314-8634
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503

W2S		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
087-5805	Pin	301-7967
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319

Sales Model M322F

F2Z		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332

F2Z		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503

Sales Model M324D

EN3		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332

EN3		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503

EN3		
Original Part Number	Part Name	Classic Part Number
9F-3212	Bearing-Ball	384-5953
087-5805	Pin	301-7967
134-8948	Plate	399-8588

Sales Model M325B

BGN		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1H-5338	Cup-Roller Brg	374-8345
1S-7057	Gasket	420-6384
1T-0210	Bearing-Ball	417-4498
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-5065	Cone-Roller Brg	416-2157
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4I-1524	Cylinder As	394-8216
4I-4619	Pin As	425-2564
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-2526	Cup-Rlr Bearing	380-7498
6I-1099	Manifold-Exh	424-6366
6S-3051	Cup-Rlr Brg	415-1928
6Y-9930	Mount As	360-2353
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025

BGN		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7K-0078	Bearing-Sleeve	308-9825
7V-0638	Spacer	425-3651
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-2345	Pin	394-0211
7Y-3550	Pin	360-2350
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636
7Y-5102	Bearing-Sleeve	380-7368
7Y-5128	Bearing-Sleeve	314-8648
8D-2256	Cone-Roller Brg	374-1848
8F-9365	Pin	319-3463
8S-0248	Breather As	325-6033
8V-6435	Spider & Brg Kit	377-7451
9F-3212	Bearing-Ball	384-5953

BGN		
Original Part Number	Part Name	Classic Part Number
9K-1171	Cup-Rlr Bearing	430-3339
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
087-5805	Pin	301-7967
094-1509	Shaft-Planet	360-2273
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
110-7216	Gear-Sun	391-9877
113-6200	Gasket	438-2020
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2775	Pin As	418-1967
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5435	Pin As	393-0934
117-6270	Support As	434-1400
118-5196	Pin	380-7397
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
128-9863	Bearing-Sleeve	314-8630

Sales Model M325B (Cont'd.)

BGN		
Original Part Number	Part Name	Classic Part Number
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
136-0819	Valve-Exhaust	384-8697
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388

BGN		
Original Part Number	Part Name	Classic Part Number
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
188-4211	Cylinder As	425-9366
191-3118	Cyl Gp-0170 1680	399-8560
192-8318	Bearing-Sleeve	360-2321
199-4582	Bearing-Needle	388-6589
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370

BGN		
Original Part Number	Part Name	Classic Part Number
229-5154	Bearing-Thrust	419-6369
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
300-9500	Kit-Gasket-Sch	387-2914
347-6081	Gauge As	360-2348
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model M325C

PAN		
Original Part Number	Part Name	Classic Part Number
1T-0210	Bearing-Ball	417-4498
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4I-0704	Bearing-Sleeve	360-2332
4I-4619	Pin As	425-2564
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7K-0078	Bearing-Sleeve	308-9825
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-3550	Pin	360-2350
7Y-5131	Bearing-Sleeve	301-4626

PAN		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
119-2863	Pin	314-8698
123-2111	Piston	462-5714
126-9461	Pin	392-4528
127-3467	Manifold-Exhaust	394-9827
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642

PAN		
Original Part Number	Part Name	Classic Part Number
128-9883	Bearing-Sleeve	360-2314
133-2437	Link	377-6199
133-4995	Gasket-Cyl Head	434-2445
137-2822	Bearing-Sleeve	453-0971
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
156-0738	Rod As	394-8210
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6270	Bearing-Sleeve	425-6436

Sales Model M325C (Cont'd.)

PAN		
Original Part Number	Part Name	Classic Part Number
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

PAN		
Original Part Number	Part Name	Classic Part Number
244-8504	Pin As	426-0032
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912

PAN		
Original Part Number	Part Name	Classic Part Number
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
441-9566	Gear-Flywheel	374-4703

XJA		
Original Part Number	Part Name	Classic Part Number
1T-0210	Bearing-Ball	417-4498
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7W-9027	Base-Oil Cooler	399-8545

XJA		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
7Y-3550	Pin	360-2350
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

XJA		
Original Part Number	Part Name	Classic Part Number
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
441-9566	Gear-Flywheel	374-4703

Sales Model W330B

AME		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221

AME		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

AME		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-5285	Bearing-Sleeve	360-2312
3L-1425	Bearing-Ball	311-9356
4I-1524	Cylinder As	394-8216

Sales Model W330B (Cont'd.)

AME		
Original Part Number	Part Name	Classic Part Number
4N-0432	Bearing-Ball	417-4499
4N-2572	Spider As-Fan	451-9027
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5I-3301	Pin As	387-2929
5P-1949	Cup-Rlr Bearing	415-1916
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475

AME		
Original Part Number	Part Name	Classic Part Number
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-6425	Muffler As	386-3045
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-9930	Mount As	360-2353
7E-9980	Camshaft	377-5851
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
7Y-0912	Bearing-Rlr As	417-4513
7Y-1100	Bearing-Roller	394-8226
7Y-1315	Pipe As-Tail	385-7209
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-5102	Bearing-Sleeve	380-7368
7Y-5131	Bearing-Sleeve	301-4626
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-4889	Shaft-Aux Drive	433-9212
8N-0703	Bearing-Sleeve	472-8037

AME		
Original Part Number	Part Name	Classic Part Number
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9F-3212	Bearing-Ball	384-5953
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9931	Mount As.	360-2354
9Y-1798	Seal-Water	379-0165

Sales Model W330B (Cont'd.)

AME		
Original Part Number	Part Name	Classic Part Number
087-6372	Pin	396-7284
100-7860	Valve-Inlet	270-4360
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
109-9463	Muffler As	360-7864
111-8015	Gasket As-Head	279-4977
114-1398	Gauge-Oil Level	394-9815
117-5435	Pin As	393-0934
117-6270	Support As	434-1400
128-9882	Bearing-Sleeve	314-8642
131-3815	Seal Gp-Basic	325-6193
137-2818	Bearing-Sleeve	380-7381
137-2821	Bearing-Sleeve	419-4717
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125

AME		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
191-3118	Cyl Gp-0170 1680	399-8560

AME		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
223-3095	Gauge As	360-2295
232-3233	Bearing-Main	376-9085
236-6277	Bearing-Sleeve	419-0884
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
347-6081	Gauge As	360-2348
391-8229	Kit-Gasket-Fs	398-2955

Sales Model W345B

ANJ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
4D-0487	Valve As-Check	375-4334
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568

ANJ		
Original Part Number	Part Name	Classic Part Number
7W-5844	Bearing-Conn Rod	419-4650
7Y-3552	Bearing-Sleeve	364-5266
8H-9789	Bearing-Ball	374-8342
9W-9931	Mount As.	360-2354
9Y-7215	Sleeve-Isolator	425-3646
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-6372	Pin	396-7284
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
110-7216	Gear-Sun	391-9877

ANJ		
Original Part Number	Part Name	Classic Part Number
111-2645	Valve-Pump Byp	441-1561
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719

Sales Model W345B (Cont'd.)

ANJ		
Original Part Number	Part Name	Classic Part Number
137-2817	Bearing-Sleeve	434-2399
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727

ANJ		
Original Part Number	Part Name	Classic Part Number
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589

ANJ		
Original Part Number	Part Name	Classic Part Number
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108

CDY		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
4D-0487	Valve As-Check	375-4334
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
5P-7807	Bearing-Ball	314-8502
6V-3831	Seal-O-Ring	436-2657
6Y-9930	Mount As	360-2353
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7Y-3552	Bearing-Sleeve	364-5266
8G-4189	Bearing-Aligning	295-6411
8H-9789	Bearing-Ball	374-8342
9W-9931	Mount As.	360-2354
9Y-7215	Sleeve-Isolator	425-3646

CDY		
Original Part Number	Part Name	Classic Part Number
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-6372	Pin	396-7284
094-1509	Shaft-Planet	360-2273
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-2659	Bearing-Sleeve	419-2304
110-7216	Gear-Sun	391-9877
111-2645	Valve-Pump Byp	441-1561
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

CDY		
Original Part Number	Part Name	Classic Part Number
117-6270	Support As	434-1400
118-2800	Housing As.-Rglt	419-4719
137-2817	Bearing-Sleeve	434-2399
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-3091	Bearing-Sleeve	365-8825
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
199-4582	Bearing-Needle	388-6589
216-4781	Gasket Kit	437-8144
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
352-2077	Pump Gp-Water -B	434-6108

Sales Model 3066

4LW		
Original Part Number	**Part Name**	**Classic Part Number**
5I-7619	Pulley	301-4772
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014

4LW		
Original Part Number	**Part Name**	**Classic Part Number**
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-7959	Pulley As	301-5256

4LW		
Original Part Number	**Part Name**	**Classic Part Number**
5L-6326	Bearing-Ball	420-3222
125-2950	Gear As	301-4762
272-4673	Muffler	301-7974

Sales Model 325C

S2C		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7K-0078	Bearing-Sleeve	308-9825
7W-9027	Base-Oil Cooler	399-8545
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270

S2C		
Original Part Number	Part Name	Classic Part Number
7Y-3550	Pin	360-2350
9F-3212	Bearing-Ball	384-5953
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9323	Muffler As	369-9491
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
137-2817	Bearing-Sleeve	434-2399
137-2819	Bearing-Sleeve	360-2317
137-2821	Bearing-Sleeve	419-4717

S2C		
Original Part Number	Part Name	Classic Part Number
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3044	Cylinder	385-6138
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 325D

C4H		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270

C4H		
Original Part Number	Part Name	Classic Part Number
7Y-3550	Pin	360-2350
9F-3212	Bearing-Ball	384-5953
9Y-2988	Breather As	361-1716
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

C4H		
Original Part Number	Part Name	Classic Part Number
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3044	Cylinder	385-6138
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Material Handlers

Sales Model 325D (Cont'd.)

RJK		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7Y-0225	Shaft-Planet	301-4571
7Y-2581	Guard As-Trk Gde	480-8270

RJK		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-3550	Pin	360-2350
9F-3212	Bearing-Ball	384-5953
9Y-2988	Breather As	361-1716
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
137-2817	Bearing-Sleeve	434-2399
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

RJK		
Original Part Number	**Part Name**	**Classic Part Number**
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
179-3044	Cylinder	385-6138
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
441-9566	Gear-Flywheel	374-4703

Sales Model 330C

D3C		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7K-9592	Bearing-Sleeve	360-2336
7Y-1461	Coupling	301-4649
7Y-3550	Pin	360-2350

D3C		
Original Part Number	**Part Name**	**Classic Part Number**
8G-4189	Bearing-Aligning	295-6411
8S-6782	Adapter-Exhaust	383-1586
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
189-4148	Pin As	423-3536
199-4582	Bearing-Needle	388-6589

D3C		
Original Part Number	**Part Name**	**Classic Part Number**
205-6642	Muffler As	480-8273
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 330D

C5K		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174

C5K		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283

C5K		
Original Part Number	**Part Name**	**Classic Part Number**
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

Sales Model 330D (Cont'd.)

C5K		
Original Part Number	Part Name	Classic Part Number
7K-0078	Bearing-Sleeve	308-9825
7Y-1461	Coupling	301-4649
7Y-3550	Pin	360-2350
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586

C5K		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
199-4582	Bearing-Needle	388-6589
205-6642	Muffler As	480-8273

C5K		
Original Part Number	Part Name	Classic Part Number
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
238-0293	Adapter-Jacket	424-0742
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

JJM		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
8H-5352	Bearing-Ball	453-3658
114-1398	Gauge-Oil Level	394-9815

JJM		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
179-3044	Cylinder	385-6138
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589
228-5621	Bearing-Sleeve	360-2323

JJM		
Original Part Number	Part Name	Classic Part Number
229-1490	Sleeve-Injector	393-3659
238-0293	Adapter-Jacket	424-0742
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

LEM		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
7K-0078	Bearing-Sleeve	308-9825
7Y-1461	Coupling	301-4649
7Y-3550	Pin	360-2350
8G-4189	Bearing-Aligning	295-6411

LEM		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
199-4582	Bearing-Needle	388-6589

LEM		
Original Part Number	Part Name	Classic Part Number
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
238-0293	Adapter-Jacket	424-0742
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

PEL		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2R-0524	Cone-Bearing	422-6484
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283

PEL		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7Y-1461	Coupling	301-4649
8H-5352	Bearing-Ball	453-3658
087-5533	Bearing-Sleeve	314-8628

PEL		
Original Part Number	Part Name	Classic Part Number
087-5548	Bearing-Sleeve	396-1568
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934

Material Handlers

Sales Model 330D (Cont'd.)

PEL		
Original Part Number	Part Name	Classic Part Number
161-3411	Gasket	394-0896
189-3922	Pin	393-0938
199-4582	Bearing-Needle	388-6589

PEL		
Original Part Number	Part Name	Classic Part Number
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659

PEL		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 345C

D3S		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7T-8816	Bearing-Spl Ball	420-2491

D3S		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349

D3S		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

M2R		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7T-8816	Bearing-Spl Ball	420-2491

M2R		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349

M2R		
Original Part Number	Part Name	Classic Part Number
114-1398	Gauge-Oil Level	394-9815
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

MTE		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
4N-2514	Gear-Flywheel	421-7283
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217

MTE		
Original Part Number	Part Name	Classic Part Number
7T-8816	Bearing-Spl Ball	420-2491
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273

MTE		
Original Part Number	Part Name	Classic Part Number
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295

Sales Model 345C (Cont'd.)

MTE		
Original Part Number	Part Name	Classic Part Number
228-5621	Bearing-Sleeve	360-2323

MTE		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348

MTE		
Original Part Number	Part Name	Classic Part Number
357-7540	Valve-Fill	360-2292

Sales Model 365C

GWC		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451

GWC		
Original Part Number	Part Name	Classic Part Number
7C-5665	Elbow-90 Deg	399-8547
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-0225	Shaft-Planet	301-4571
7Y-0912	Bearing-Rlr As	417-4513
7Y-4269	Bearing As-Rlr	419-2308
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

GWC		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 385C

WAW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020

WAW		
Original Part Number	Part Name	Classic Part Number
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174

WAW		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922

Sales Model 385C (Cont'd.)

WAW		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190

WAW		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7Y-4269	Bearing As-Rlr	419-2308
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
137-2817	Bearing-Sleeve	434-2399

WAW		
Original Part Number	**Part Name**	**Classic Part Number**
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model K50

K5A		
Original Part Number	**Part Name**	**Classic Part Number**
164-4413	Mount	419-0876

K5D		
Original Part Number	**Part Name**	**Classic Part Number**
164-4413	Mount	419-0876

Sales Model K60

K6A		
Original Part Number	**Part Name**	**Classic Part Number**
164-4413	Mount	419-0876

K6D		
Original Part Number	**Part Name**	**Classic Part Number**
164-4413	Mount	419-0876

Sales Model K70

K7A		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
164-4413	Mount	419-0876

K7D		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
164-4413	Mount	419-0876

Sales Model M318D

D9X		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
8B-5972	Bearing-Ball	314-8503

D9X		
Original Part Number	**Part Name**	**Classic Part Number**
8G-4189	Bearing-Aligning	295-6411
9F-3212	Bearing-Ball	384-5953
087-5548	Bearing-Sleeve	396-1568

D9X		
Original Part Number	**Part Name**	**Classic Part Number**
087-5805	Pin	301-7967
134-8948	Plate	399-8588

W8R		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
8B-5972	Bearing-Ball	314-8503

W8R		
Original Part Number	**Part Name**	**Classic Part Number**
8G-4189	Bearing-Aligning	295-6411
9F-3212	Bearing-Ball	384-5953
087-5548	Bearing-Sleeve	396-1568

W8R		
Original Part Number	**Part Name**	**Classic Part Number**
087-5805	Pin	301-7967
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319

Sales Model M322D

D3X		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332
6H-3957	Bearing-Ball	311-9358

D3X		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503
9F-3212	Bearing-Ball	384-5953
087-5805	Pin	301-7967

D3X		
Original Part Number	**Part Name**	**Classic Part Number**
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319

W2T		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332

W2T		
Original Part Number	**Part Name**	**Classic Part Number**
6H-3957	Bearing-Ball	311-9358
7Y-5131	Bearing-Sleeve	301-4626

W2T		
Original Part Number	**Part Name**	**Classic Part Number**
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411

Sales Model M322D (Cont'd.)

W2T		
Original Part Number	**Part Name**	**Classic Part Number**
9F-3212	Bearing-Ball	384-5953
087-5805	Pin	301-7967

W2T		
Original Part Number	**Part Name**	**Classic Part Number**
134-8948	Plate	399-8588
137-2919	Bearing-Sleeve	360-2319

Sales Model M325D

EDF		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0210	Bearing-Ball	417-4498
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7Y-0225	Shaft-Planet	301-4571
7Y-3550	Pin	360-2350
9Y-2988	Breather As	361-1716

EDF		
Original Part Number	**Part Name**	**Classic Part Number**
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
119-2863	Pin	314-8698
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
212-4893	Bearing-Thrust	419-6372

EDF		
Original Part Number	**Part Name**	**Classic Part Number**
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
441-9566	Gear-Flywheel	374-4703

ETE		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0210	Bearing-Ball	417-4498
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4619	Pin As	425-2564
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

ETE		
Original Part Number	**Part Name**	**Classic Part Number**
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7Y-0225	Shaft-Planet	301-4571
9Y-2988	Breather As	361-1716
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

ETE		
Original Part Number	**Part Name**	**Classic Part Number**
115-4072	Bearing	397-5069
123-2111	Piston	462-5714
128-9863	Bearing-Sleeve	314-8630
128-9883	Bearing-Sleeve	360-2314
133-4995	Gasket-Cyl Head	434-2445
137-2822	Bearing-Sleeve	453-0971
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
156-0738	Rod As	394-8210

Sales Model M325D (Cont'd.)

ETE		
Original Part Number	Part Name	Classic Part Number
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370

ETE		
Original Part Number	Part Name	Classic Part Number
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912

ETE		
Original Part Number	Part Name	Classic Part Number
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
441-9566	Gear-Flywheel	374-4703

GE8		
Original Part Number	Part Name	Classic Part Number
1T-0210	Bearing-Ball	417-4498
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449

GE8		
Original Part Number	Part Name	Classic Part Number
7Y-0225	Shaft-Planet	301-4571
9Y-2988	Breather As	361-1716
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

GE8		
Original Part Number	Part Name	Classic Part Number
154-8030	Gasket	394-0894
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
441-9566	Gear-Flywheel	374-4703

KAY		
Original Part Number	Part Name	Classic Part Number
1T-0210	Bearing-Ball	417-4498
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7Y-0225	Shaft-Planet	301-4571
9Y-2988	Breather As	361-1716

KAY		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
119-2863	Pin	314-8698
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
212-4893	Bearing-Thrust	419-6372

KAY		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
441-9566	Gear-Flywheel	374-4703

Sales Model M325D (Cont'd.)

KGG		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0210	Bearing-Ball	417-4498
1W-1064	Gear-Flywheel	374-4703
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4I-4619	Pin As	425-2564
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6V-3831	Seal-O-Ring	436-2657
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7I-7180	Piston	421-7142
7Y-0225	Shaft-Planet	301-4571
7Y-3550	Pin	360-2350
9Y-2988	Breather As	361-1716
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568

KGG		
Original Part Number	**Part Name**	**Classic Part Number**
087-5805	Pin	301-7967
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
109-9350	Mount-Rubber	393-1046
109-9369	Mount-Rubber	393-1047
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069
119-2863	Pin	314-8698
123-2111	Piston	462-5714
128-9863	Bearing-Sleeve	314-8630
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
133-4995	Gasket-Cyl Head	434-2445
137-2822	Bearing-Sleeve	453-0971
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

KGG		
Original Part Number	**Part Name**	**Classic Part Number**
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
156-0738	Rod As	394-8210
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
244-8504	Pin As	426-0032
255-2899	Pipe As-Tail	301-5246
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
347-6081	Gauge As	360-2348
441-9566	Gear-Flywheel	374-4703

Sales Model M330D

KRE		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

KRE		
Original Part Number	**Part Name**	**Classic Part Number**
7I-7181	Piston	393-5217
8H-5352	Bearing-Ball	453-3658
8S-6782	Adapter-Exhaust	383-1586
105-2659	Bearing-Sleeve	419-2304
114-1398	Gauge-Oil Level	394-9815
115-4072	Bearing	397-5069

KRE		
Original Part Number	**Part Name**	**Classic Part Number**
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
205-6642	Muffler As	480-8273
228-5621	Bearing-Sleeve	360-2323
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348

MBR		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174

MBR		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7213	Bearing-Sleeve	419-4667
4N-2514	Gear-Flywheel	421-7283

MBR		
Original Part Number	**Part Name**	**Classic Part Number**
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
7I-7181	Piston	393-5217

Sales Model M330D (Cont'd.)

MBR		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
105-2659	Bearing-Sleeve	419-2304
114-1398	Gauge-Oil Level	394-9815

MBR		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
117-5435	Pin As	393-0934
161-3411	Gasket	394-0896
228-5621	Bearing-Sleeve	360-2323

MBR		
Original Part Number	Part Name	Classic Part Number
229-1490	Sleeve-Injector	393-3659
347-6081	Gauge As	360-2348

Sales Model MH3022

FM2		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
6H-3957	Bearing-Ball	311-9358
8B-5972	Bearing-Ball	314-8503

FM2		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
087-5548	Bearing-Sleeve	396-1568

FM2		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
134-8948	Plate	399-8588

Sales Model MH3024

FM4		
Original Part Number	Part Name	Classic Part Number
4I-0453	Bearing-Sleeve	360-2331
4I-0704	Bearing-Sleeve	360-2332

FM4		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503

FM4		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
134-8948	Plate	399-8588

Sales Model MH3037

JLH		
Original Part Number	Part Name	Classic Part Number
9W-9940	Mount As.	360-2355

KPM		
Original Part Number	Part Name	Classic Part Number
125-2873	Core As-Ac Cond	436-2254

Material Handlers

Sales Model MH3049

HPB		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667

HPB		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

HPB		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
161-3411	Gasket	394-0896

Sales Model MH3059

RBR		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667

RBR		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

RBR		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
161-3411	Gasket	394-0896

Sales Model MH3295

PA9		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
3E-6772	Seal-Water	382-8017
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
6N-1931	Plunger	379-0171
7C-0145	Core As-Oclr	374-4720
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373

PA9		
Original Part Number	Part Name	Classic Part Number
7N-2213	Bearing-Sleeve	394-0190
7Y-4269	Bearing As-Rlr	419-2308
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107

PA9		
Original Part Number	Part Name	Classic Part Number
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
228-5621	Bearing-Sleeve	360-2323
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model RT40

4XG		
Original Part Number	Part Name	Classic Part Number
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2H-3712	Bearing-Ball	392-4488
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-3966	Ring-Seal	297-7237
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
3L-1425	Bearing-Ball	311-9356
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
5P-8768	Kit-Gasket (Scl)	393-1024

4XG		
Original Part Number	Part Name	Classic Part Number
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6Y-7929	Disc-Friction	456-0555
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-3038	Gear-Reverse	445-1097
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8F-6058	Bearing-Sleeve	416-5494
8G-4189	Bearing-Aligning	295-6411

4XG		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

Sales Model RT40 (Cont'd.)

4XG		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-7788	Ring-Piston	461-5124
9Y-1798	Seal-Water	379-0165

4XG		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-9431	Precleaner As	361-1718
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-7860	Valve-Inlet	270-4360
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
170-7502	Shaft-Dr Idler	374-7484

4XG		
Original Part Number	**Part Name**	**Classic Part Number**
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
274-4553	Disc-Clutch	416-2153
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

5PF		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2H-3712	Bearing-Ball	392-4488
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

5PF		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-3966	Ring-Seal	297-7237
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
3L-1425	Bearing-Ball	311-9356
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236

5PF		
Original Part Number	**Part Name**	**Classic Part Number**
4P-8915	Gasket-Cyl Head	377-5838
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6Y-7929	Disc-Friction	456-0555
7C-2880	Bell As-Suction	380-1520

Sales Model RT40 (Cont'd.)

5PF		
Original Part Number	Part Name	Classic Part Number
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-3038	Gear-Reverse	445-1097
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8F-6058	Bearing-Sleeve	416-5494
8G-4189	Bearing-Aligning	295-6411
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555

5PF		
Original Part Number	Part Name	Classic Part Number
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050

5PF		
Original Part Number	Part Name	Classic Part Number
9S-2356	Manifold-Exhaust	261-0905
9S-7788	Ring-Piston	461-5124
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-9431	Precleaner As	361-1718
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
274-4553	Disc-Clutch	416-2153
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

4XG		
Original Part Number	Part Name	Classic Part Number
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2H-3712	Bearing-Ball	392-4488
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-3966	Ring-Seal	297-7237
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
3L-1425	Bearing-Ball	311-9356
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
5P-8768	Kit-Gasket (Scl)	393-1024

4XG		
Original Part Number	Part Name	Classic Part Number
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6Y-7929	Disc-Friction	456-0555
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-3038	Gear-Reverse	445-1097
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8F-6058	Bearing-Sleeve	416-5494
8G-4189	Bearing-Aligning	295-6411

4XG		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

Sales Model RT50 (Cont'd.)

4XG		
Original Part Number	Part Name	Classic Part Number
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-7788	Ring-Piston	461-5124
9Y-1798	Seal-Water	379-0165

4XG		
Original Part Number	Part Name	Classic Part Number
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-9431	Precleaner As	361-1718
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-7860	Valve-Inlet	270-4360
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
170-7502	Shaft-Dr Idler	374-7484

4XG		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
274-4553	Disc-Clutch	416-2153
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

5PF		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2H-3712	Bearing-Ball	392-4488
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

5PF		
Original Part Number	Part Name	Classic Part Number
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-3966	Ring-Seal	297-7237
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
3L-1425	Bearing-Ball	311-9356
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236

5PF		
Original Part Number	Part Name	Classic Part Number
4P-8915	Gasket-Cyl Head	377-5838
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6Y-7929	Disc-Friction	456-0555
7C-2880	Bell As-Suction	380-1520

Sales Model RT50 (Cont'd.)

5PF		
Original Part Number	Part Name	Classic Part Number
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-3038	Gear-Reverse	445-1097
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8F-6058	Bearing-Sleeve	416-5494
8G-4189	Bearing-Aligning	295-6411
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555

5PF		
Original Part Number	Part Name	Classic Part Number
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050

5PF		
Original Part Number	Part Name	Classic Part Number
9S-2356	Manifold-Exhaust	261-0905
9S-7788	Ring-Piston	461-5124
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-9431	Precleaner As	361-1718
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
274-4553	Disc-Clutch	416-2153
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

Sales Model RT50 (Cont'd.)

8DJ		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1T-0043	Bearing-Ball	390-5294
2H-3712	Bearing-Ball	392-4488
2S-3966	Ring-Seal	297-7237
6Y-7929	Disc-Friction	456-0555
7T-3038	Gear-Reverse	445-1097

8DJ		
Original Part Number	Part Name	Classic Part Number
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
8G-4189	Bearing-Aligning	295-6411
005-0469	Cup-Rlr Bearing	418-9610

8DJ		
Original Part Number	Part Name	Classic Part Number
005-0471	Cone-Spl Tapered	415-1924
121-7746	Pre-Cleaner As	360-2311
274-4553	Disc-Clutch	416-2153

Sales Model RT60

5DG		
Original Part Number	Part Name	Classic Part Number
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2H-3712	Bearing-Ball	392-4488
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357

5DG		
Original Part Number	Part Name	Classic Part Number
2W-2621	Valve-Inlet	247-6892
3L-1425	Bearing-Ball	311-9356
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6Y-7929	Disc-Friction	456-0555
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192

5DG		
Original Part Number	Part Name	Classic Part Number
7E-5085	Bushing	377-5829
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-3038	Gear-Reverse	445-1097
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8F-6058	Bearing-Sleeve	416-5494
8G-4189	Bearing-Aligning	295-6411
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037

Sales Model RT60 (Cont'd.)

5DG		
Original Part Number	Part Name	Classic Part Number
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

5DG		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-7788	Ring-Piston	461-5124
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-9431	Precleaner As	361-1718
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

5DG		
Original Part Number	Part Name	Classic Part Number
100-7860	Valve-Inlet	270-4360
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
274-4553	Disc-Clutch	416-2153
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

Sales Model RTC60

4XG		
Original Part Number	Part Name	Classic Part Number
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769

4XG		
Original Part Number	Part Name	Classic Part Number
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294

4XG		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513

Sales Model RTC60 (Cont'd.)

4XG		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2H-3712	Bearing-Ball	392-4488
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-3966	Ring-Seal	297-7237
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
3L-1425	Bearing-Ball	311-9356
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991

4XG		
Original Part Number	Part Name	Classic Part Number
6N-7174	Shield-Oil	314-8544
6Y-7929	Disc-Friction	456-0555
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-3038	Gear-Reverse	445-1097
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8F-6058	Bearing-Sleeve	416-5494
8G-4189	Bearing-Aligning	295-6411
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441

4XG		
Original Part Number	Part Name	Classic Part Number
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517

Sales Model RTC60 (Cont'd.)

4XG		
Original Part Number	**Part Name**	**Classic Part Number**
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-7788	Ring-Piston	461-5124
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-9431	Precleaner As	361-1718
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-7860	Valve-Inlet	270-4360
131-3815	Seal Gp-Basic	325-6193

4XG		
Original Part Number	**Part Name**	**Classic Part Number**
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259

4XG		
Original Part Number	**Part Name**	**Classic Part Number**
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
274-4553	Disc-Clutch	416-2153
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

5PF		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2H-3712	Bearing-Ball	392-4488
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

5PF		
Original Part Number	**Part Name**	**Classic Part Number**
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-3966	Ring-Seal	297-7237
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
3L-1425	Bearing-Ball	311-9356
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

5PF		
Original Part Number	**Part Name**	**Classic Part Number**
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6Y-7929	Disc-Friction	456-0555
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995

Sales Model RTC60 (Cont'd.)

5PF		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-3038	Gear-Reverse	445-1097
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8F-6058	Bearing-Sleeve	416-5494
8G-4189	Bearing-Aligning	295-6411
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

5PF		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-7788	Ring-Piston	461-5124
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032

5PF		
Original Part Number	Part Name	Classic Part Number
9Y-9431	Precleaner As	361-1718
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
274-4553	Disc-Clutch	416-2153
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

Material Handlers

Sales Model RT80

1GJ		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1W-1064	Gear-Flywheel	374-4703
2H-3712	Bearing-Ball	392-4488
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6H-3957	Bearing-Ball	311-9358
6I-4689	Gasket-Cyl Head	377-5840
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317

1GJ		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7J-8210	Cone-Roller Brg	423-6987
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195

1GJ		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
165-9864	Gasket Kit-Sch	388-0659
178-8608	Cone	422-6479
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model RT100

1GJ		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1W-1064	Gear-Flywheel	374-4703
2H-3712	Bearing-Ball	392-4488
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596

1GJ		
Original Part Number	Part Name	Classic Part Number
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
6H-3957	Bearing-Ball	311-9358
6I-4689	Gasket-Cyl Head	377-5840
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025

1GJ		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7J-8210	Cone-Roller Brg	423-6987
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8G-4189	Bearing-Aligning	295-6411
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983

Sales Model RT100 (Cont'd.)

1GJ		
Original Part Number	Part Name	Classic Part Number
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
121-7746	Pre-Cleaner As	360-2311
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380

1GJ		
Original Part Number	Part Name	Classic Part Number
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
165-9864	Gasket Kit-Sch	388-0659
178-8608	Cone	422-6479
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371

1GJ		
Original Part Number	Part Name	Classic Part Number
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model TH62

3LN		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1T-0043	Bearing-Ball	390-5294
2H-3712	Bearing-Ball	392-4488
6N-3964	Muffler As	360-7884

3LN		
Original Part Number	Part Name	Classic Part Number
7P-3466	Bearing-Sleeve	422-9523
8G-4189	Bearing-Aligning	295-6411

3LN		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
297-6870	Kit-Dt Gasket	451-1510

4TM		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1T-0043	Bearing-Ball	390-5294
2H-3712	Bearing-Ball	392-4488
5P-7487	Bearing-Aligning	434-3300

4TM		
Original Part Number	Part Name	Classic Part Number
6N-3964	Muffler As	360-7884
7P-3466	Bearing-Sleeve	422-9523
8G-4189	Bearing-Aligning	295-6411

4TM		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
297-6870	Kit-Dt Gasket	451-1510

Sales Model TH63

3NN		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1T-0043	Bearing-Ball	390-5294
2H-3712	Bearing-Ball	392-4488
6N-3964	Muffler As	360-7884

3NN		
Original Part Number	Part Name	Classic Part Number
7P-3466	Bearing-Sleeve	422-9523
8G-4189	Bearing-Aligning	295-6411

3NN		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024

5WM		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296

Material Handlers

Sales Model TH63 (Cont'd.)

5WM		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
2H-3712	Bearing-Ball	392-4488
6N-3964	Muffler As	360-7884

5WM		
Original Part Number	Part Name	Classic Part Number
7P-3466	Bearing-Sleeve	422-9523
8G-4189	Bearing-Aligning	295-6411

5WM		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024

Sales Model TH82

3JN		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1T-0043	Bearing-Ball	390-5294
2H-3712	Bearing-Ball	392-4488
6N-3964	Muffler As	360-7884

3JN		
Original Part Number	Part Name	Classic Part Number
7P-3466	Bearing-Sleeve	422-9523
8G-4189	Bearing-Aligning	295-6411

3JN		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024

3KN		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1T-0043	Bearing-Ball	390-5294
2H-3712	Bearing-Ball	392-4488

3KN		
Original Part Number	Part Name	Classic Part Number
6N-3964	Muffler As	360-7884
8G-4189	Bearing-Aligning	295-6411

3KN		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024

Sales Model TH83

3RN		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1T-0043	Bearing-Ball	390-5294
2H-3712	Bearing-Ball	392-4488
6N-3964	Muffler As	360-7884

3RN		
Original Part Number	Part Name	Classic Part Number
7P-3466	Bearing-Sleeve	422-9523
8G-4189	Bearing-Aligning	295-6411

3RN		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024

Sales Model TH103

3PN		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1T-0043	Bearing-Ball	390-5294
1T-0441	Bearing-Ball	449-4738
2H-3712	Bearing-Ball	392-4488

3PN		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
6D-1734	Cup-Roller Brg	416-2171
6V-4582	Bearing-Ball	380-1504

3PN		
Original Part Number	Part Name	Classic Part Number
7P-3466	Bearing-Sleeve	422-9523
8G-4189	Bearing-Aligning	295-6411
8H-9789	Bearing-Ball	374-8342

Sales Model TH103 (Cont'd.)

3PN		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
178-8608	Cone	422-6479

3PN		
Original Part Number	Part Name	Classic Part Number
199-0760	Bearing-Roller	465-8981
226-8202	Seal-Wiper	472-8024

Sales Model TH210

CEC		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
226-8202	Seal-Wiper	472-8024

MHT		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
226-8202	Seal-Wiper	472-8024

Sales Model TH215

CEG		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
226-8202	Seal-Wiper	472-8024

MHS		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
226-8202	Seal-Wiper	472-8024

Sales Model TH220B

SLA		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2R-0524	Cone-Bearing	422-6484
3E-4924	Mounting As	391-9812
4N-2514	Gear-Flywheel	421-7283
6D-1734	Cup-Roller Brg	416-2171
7T-8816	Bearing-Spl Ball	420-2491
8H-9789	Bearing-Ball	374-8342
9W-9931	Mount As.	360-2354

SLA		
Original Part Number	Part Name	Classic Part Number
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
094-1509	Shaft-Planet	360-2273
108-1760	Bearing-Ball	417-9493
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139

SLA		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
226-8202	Seal-Wiper	472-8024
331-8538	Seal-Wheel	391-9874
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292
392-6301	Kit-Spider & Brg	390-0915

Material Handlers

Sales Model TH330B

SLB		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4924	Mounting As	391-9812
6D-1734	Cup-Roller Brg	416-2171
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610

SLB		
Original Part Number	**Part Name**	**Classic Part Number**
005-0471	Cone-Spl Tapered	415-1924
108-1760	Bearing-Ball	417-9493
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139

SLB		
Original Part Number	**Part Name**	**Classic Part Number**
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model TH340B

SLC		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4924	Mounting As	391-9812
6D-1734	Cup-Roller Brg	416-2171
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

SLC		
Original Part Number	**Part Name**	**Classic Part Number**
108-1760	Bearing-Ball	417-9493
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024

SLC		
Original Part Number	**Part Name**	**Classic Part Number**
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model TH350B

SLD		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4924	Mounting As	391-9812
6D-1734	Cup-Roller Brg	416-2171
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

SLD		
Original Part Number	**Part Name**	**Classic Part Number**
108-1760	Bearing-Ball	417-9493
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024

SLD		
Original Part Number	**Part Name**	**Classic Part Number**
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model TH355B

JRK		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4924	Mounting As	391-9812
6D-1734	Cup-Roller Brg	416-2171
9W-9931	Mount As.	360-2354

JRK		
Original Part Number	**Part Name**	**Classic Part Number**
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

JRK		
Original Part Number	**Part Name**	**Classic Part Number**
108-1760	Bearing-Ball	417-9493
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139

Sales Model TH355B (Cont'd.)

JRK		
Original Part Number	Part Name	Classic Part Number
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024

JRK		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

JRK		
Original Part Number	Part Name	Classic Part Number
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model TH360B

SLE		
Original Part Number	Part Name	Classic Part Number
3E-4924	Mounting As	391-9812
6D-1734	Cup-Roller Brg	416-2171
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

SLE		
Original Part Number	Part Name	Classic Part Number
108-1760	Bearing-Ball	417-9493
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024

SLE		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model TH460B

SLF		
Original Part Number	Part Name	Classic Part Number
3E-4924	Mounting As	391-9812
6D-1734	Cup-Roller Brg	416-2171
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

SLF		
Original Part Number	Part Name	Classic Part Number
108-1760	Bearing-Ball	417-9493
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981

SLF		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model TH560B

SLG		
Original Part Number	Part Name	Classic Part Number
3E-4924	Mounting As	391-9812
6D-1734	Cup-Roller Brg	416-2171
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

SLG		
Original Part Number	Part Name	Classic Part Number
108-1760	Bearing-Ball	417-9493
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981

SLG		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Material Handlers

Sales Model TH580B

SLH		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4924	Mounting As	391-9812
6D-1734	Cup-Roller Brg	416-2171
9W-9931	Mount As.	360-2354
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

SLH		
Original Part Number	**Part Name**	**Classic Part Number**
108-1760	Bearing-Ball	417-9493
122-1881	Plate-Clutch	347-0475
122-6787	Yoke As	416-2139
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
199-0760	Bearing-Roller	465-8981

SLH		
Original Part Number	**Part Name**	**Classic Part Number**
226-8202	Seal-Wiper	472-8024
331-8538	Seal-Wheel	391-9874
392-6301	Kit-Spider & Brg	390-0915

Sales Model W345C

R5K		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
4I-5016	Pin	396-7272
4N-2514	Gear-Flywheel	421-7283
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7T-8816	Bearing-Spl Ball	420-2491

R5K		
Original Part Number	**Part Name**	**Classic Part Number**
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
087-5548	Bearing-Sleeve	396-1568
094-1509	Shaft-Planet	360-2273
110-7216	Gear-Sun	391-9877
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815

R5K		
Original Part Number	**Part Name**	**Classic Part Number**
199-4582	Bearing-Needle	388-6589
223-3095	Gauge As	360-2295
228-5621	Bearing-Sleeve	360-2323
347-6081	Gauge As	360-2348

Cat® Classic™ Parts for Motor Graders

Cat® motor graders have long, productive lives, and maintenance costs need to be evaluated As. these machines age. Cat® Classic™ parts are a Repair option targeted at the End of the product life cycle when lower cost options are more desired. Caterpillar offers the Classic parts Line for several older models of motor graders. Cat Classic parts is a Repair option that is priced to allow the machines to continue to be operated profitably As. they age.

Cat Classic parts provide owners of older Cat products with low cost Repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts coverage for motor graders includes:

- Axle
- Engine
- Final Drive
- Flywheel Clutch
- Linkage Pin
- SteeRing
- Transmission
- Trunnion/Blade Support
- ...and many more.

Sales Model 12

06M		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
3B-6217	Muffler As	247-2671
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498

06M		
Original Part Number	**Part Name**	**Classic Part Number**
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2229	Cage-Bearing	229-1598
4D-6664	Coupling-Shaft	243-0338
4D-6926	Segment-Control	228-9455
5D-6201	Shoe-Yoke	243-0356
5D-7449	Cup-Spl Tapered	416-2161
5D-9745	Shoe-Guide	330-9285
5F-8651	Bearing-Ball	420-3223

06M		
Original Part Number	**Part Name**	**Classic Part Number**
6B-3158	Shoe-Yoke Lh	243-0357
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6F-6992	Cap-Ballsocket	297-7160
7M-1154	Bearing-Spl	417-4515
7T-2036	Cap As-Fuel	361-1721
8B-5972	Bearing-Ball	314-8503
8W-9587	Flange As	373-5394
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

07T		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849

07T		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430

Sales Model 12 (Cont'd.)

07T		
Original Part Number	**Part Name**	**Classic Part Number**
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-6217	Muffler As	247-2671
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440

07T		
Original Part Number	**Part Name**	**Classic Part Number**
4B-9374	Bearing-Cup	380-7494
4D-2229	Cage-Bearing	229-1598
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6926	Segment-Control	228-9455
5D-6201	Shoe-Yoke	243-0356
5D-7449	Cup-Spl Tapered	416-2161
5D-9745	Shoe-Guide	330-9285
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
6B-3158	Shoe-Yoke Lh	243-0357
6B-6224	Ferrule	419-4738

07T		
Original Part Number	**Part Name**	**Classic Part Number**
6B-7469	Spacer	417-4535
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7M-1154	Bearing-Spl	417-4515
8B-5972	Bearing-Ball	314-8503
8H-4320	Bearing-Ball	419-2301
8W-9587	Flange As	373-5394
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

08T		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
1S-1967	Chamber As	247-3291
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2S-1273	Chamber As	319-3434
2S-4015	Plunger As-Valve	311-9438
3B-6218	Muffler As	247-2672
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498

08T		
Original Part Number	**Part Name**	**Classic Part Number**
3K-3124	Muffler-Trap	247-2673
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2229	Cage-Bearing	229-1598
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405
4F-2393	Bearing-Ball	380-1499
4M-0410	Gear-Oil Pump Dr	428-6660
5D-6201	Shoe-Yoke	243-0356
5D-7449	Cup-Spl Tapered	416-2161
5D-9745	Shoe-Guide	330-9285
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665
6B-3158	Shoe-Yoke Lh	243-0357
6B-6224	Ferrule	419-4738

08T		
Original Part Number	**Part Name**	**Classic Part Number**
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-2947	Shaft	243-0346
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7M-1154	Bearing-Spl	417-4515
7M-4603	Body-Fuel Valve	311-9348
7S-7809	Cap As-Radiator	295-6417
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8H-4320	Bearing-Ball	419-2301
8W-6324	Kit-Wear Strip	424-0739
8W-9587	Flange As	373-5394
9B-1320	Valve-Check	377-5832
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311

09K		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368

Sales Model 12 (Cont'd.)

09K		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-6217	Muffler As	247-2671
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498

09K		
Original Part Number	Part Name	Classic Part Number
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2229	Cage-Bearing	229-1598
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6926	Segment-Control	228-9455
5D-6201	Shoe-Yoke	243-0356
5D-7449	Cup-Spl Tapered	416-2161
5D-9745	Shoe-Guide	330-9285
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555

09K		
Original Part Number	Part Name	Classic Part Number
6B-3158	Shoe-Yoke Lh	243-0357
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7M-1154	Bearing-Spl	417-4515
8B-5972	Bearing-Ball	314-8503
8H-4320	Bearing-Ball	419-2301
8W-9587	Flange As	373-5394
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

38E		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272

38E		
Original Part Number	Part Name	Classic Part Number
8W-6324	Kit-Wear Strip	424-0739
9M-3914	Bearing-Aligning	420-2501

70D		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
1S-1967	Chamber As	247-3291
1S-3743	Bearing-Ball	384-4786
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-6421	Bearing-Outer	417-4510
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354

70D		
Original Part Number	Part Name	Classic Part Number
2H-3517	Bearing-Inner	417-4505
2S-1273	Chamber As	319-3434
2S-4015	Plunger As-Valve	311-9438
3B-6218	Muffler As	247-2672
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3K-3124	Muffler-Trap	247-2673
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2229	Cage-Bearing	229-1598
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405

70D		
Original Part Number	Part Name	Classic Part Number
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4M-0410	Gear-Oil Pump Dr	428-6660
5D-4799	Bearing-Roller	416-2160
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5D-9906	Shaft-Axle	228-9413
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665
6B-3158	Shoe-Yoke Lh	243-0357
6B-6224	Ferrule	419-4738
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160

Motor Graders

Sales Model 12 (Cont'd.)

70D		
Original Part Number	**Part Name**	**Classic Part Number**
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7H-6967	Bearing-Ball	422-6489

70D		
Original Part Number	**Part Name**	**Classic Part Number**
7M-1154	Bearing-Spl	417-4515
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7S-7809	Cap As-Radiator	295-6417
8D-5344	Gear-Worm	243-0341
8W-6324	Kit-Wear Strip	424-0739
8W-9587	Flange As	373-5394

70D		
Original Part Number	**Part Name**	**Classic Part Number**
9B-1320	Valve-Check	377-5832
9D-2716	Spindle-Wheel	228-9463
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311

71D		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424

71D		
Original Part Number	**Part Name**	**Classic Part Number**
2D-3188	Yoke	365-8822
2D-6341	Pin	330-9273
4D-4661	Pump Gp-Vn Bsc-A	422-8162
5F-8651	Bearing-Ball	420-3223
5S-1211	Cover-Valve	314-8665

71D		
Original Part Number	**Part Name**	**Classic Part Number**
6F-6992	Cap-Ballsocket	297-7160
6I-8860	Cup-Roller Brg	380-7495
8W-6324	Kit-Wear Strip	424-0739
8W-9587	Flange As	373-5394
121-7746	Pre-Cleaner As	360-2311

80C		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
1S-1970	Chamber As	247-3292
1T-0210	Bearing-Ball	417-4498
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2S-4015	Plunger As-Valve	311-9438
3B-6218	Muffler As	247-2672
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3K-3124	Muffler-Trap	247-2673
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440

80C		
Original Part Number	**Part Name**	**Classic Part Number**
4B-9374	Bearing-Cup	380-7494
4D-2229	Cage-Bearing	229-1598
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405
4F-2393	Bearing-Ball	380-1499
4M-0410	Gear-Oil Pump Dr	428-6660
5D-6201	Shoe-Yoke	243-0356
5D-7449	Cup-Spl Tapered	416-2161
5D-9745	Shoe-Guide	330-9285
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-3158	Shoe-Yoke Lh	243-0357
6B-6224	Ferrule	419-4738
6D-6859	Bearing	330-9248

80C		
Original Part Number	**Part Name**	**Classic Part Number**
6F-6992	Cap-Ballsocket	297-7160
6G-2947	Shaft	243-0346
6V-2202	Bearing-Spl Ball	380-1574
7M-1154	Bearing-Spl	417-4515
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7S-7809	Cap As-Radiator	295-6417
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8H-4320	Bearing-Ball	419-2301
8W-6324	Kit-Wear Strip	424-0739
8W-9587	Flange As	373-5394
9B-1320	Valve-Check	377-5832
9S-7534	Pipe-Exh Ext	398-2950
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311

Sales Model 12 (Cont'd.)

94C		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849

94C		
Original Part Number	Part Name	Classic Part Number
8W-6324	Kit-Wear Strip	424-0739

94C		
Original Part Number	Part Name	Classic Part Number
9M-3914	Bearing-Aligning	420-2501

Sales Model 12E

12F		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872

12F		
Original Part Number	Part Name	Classic Part Number
2P-6245	Shaft As-Pump	325-6197
2P-7830	Pump Gp	314-8533
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4D-6664	Coupling-Shaft	243-0338
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

12F		
Original Part Number	Part Name	Classic Part Number
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-2061	Pan As-Oil Sump	416-5519
4W-6869	Spacer-Fuel Pump	417-4534
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-3158	Shoe-Yoke Lh	243-0357
6G-2947	Shaft	243-0346
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951

Sales Model 12E (Cont'd.)

12F		
Original Part Number	Part Name	Classic Part Number
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8D-5344	Gear-Worm	243-0341
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210

12F		
Original Part Number	Part Name	Classic Part Number
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558

12F		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438

Sales Model 12E (Cont'd.)

12F		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989

12F		
Original Part Number	**Part Name**	**Classic Part Number**
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

12F		
Original Part Number	**Part Name**	**Classic Part Number**
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

17K		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1W-3900	Gasket	472-8006
1W-5300	Rotocoil As	443-2659
1W-6473	Compressor Gp -B	448-9150
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1757	Hub-Fan Pulley	296-1357
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230

17K		
Original Part Number	**Part Name**	**Classic Part Number**
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-7830	Pump Gp	314-8533
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
3B-6218	Muffler As	247-2672
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
4N-4864	Pump Gp-F Tfr	242-3442
4N-7693	Crankshaft As	269-8763
4P-0660	Muffler As	298-2787
4W-2061	Pan As-Oil Sump	416-5519
5D-4799	Bearing-Roller	416-2160
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5D-9906	Shaft-Axle	228-9413
5H-0047	Disc-Cl Drive	388-0576

17K		
Original Part Number	**Part Name**	**Classic Part Number**
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-3158	Shoe-Yoke Lh	243-0357
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-2202	Bearing-Spl Ball	380-1574
7C-4297	Seal As-Cshaft	325-6192
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919

Sales Model 12E (Cont'd.)

17K		
Original Part Number	Part Name	Classic Part Number
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8D-5344	Gear-Worm	243-0341
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441

17K		
Original Part Number	Part Name	Classic Part Number
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
8W-9587	Flange As	373-5394
9D-2716	Spindle-Wheel	228-9463

17K		
Original Part Number	Part Name	Classic Part Number
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-2685	Rod End	419-1866
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6129	Pulley-Alt Drive	264-5891
9S-7534	Pipe-Exh Ext	398-2950
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005

21F		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272

21F		
Original Part Number	Part Name	Classic Part Number
2D-6341	Pin	330-9273
5P-9514	Bearing-Ball	417-9467

Sales Model 12E (Cont'd.)

21F		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
7N-7386	Gasket-Cyl Head	392-4519

21F		
Original Part Number	Part Name	Classic Part Number
7S-3206	Seal-O-Ring	436-2656
8H-4320	Bearing-Ball	419-2301

21F		
Original Part Number	Part Name	Classic Part Number
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739

99E		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1M-0090	Gasket-Manifold	445-7701
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296
1P-1367	Plunger-Valve	432-8913
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1T-0210	Bearing-Ball	417-4498
1W-7073	Rebuild Kt-Pump	383-3677
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-6421	Bearing-Outer	417-4510
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934

99E		
Original Part Number	Part Name	Classic Part Number
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
3B-6218	Muffler As	247-2672
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3S-5017	Elbow-Exhaust	369-9498
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4T-8054	Seal As	472-8010
5D-4799	Bearing-Roller	416-2160
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5D-9906	Shaft-Axle	228-9413
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5H-7071	Director-Water	388-0555

99E		
Original Part Number	Part Name	Classic Part Number
5L-7632	Support-Elbow	433-9854
5M-2824	Coupling-Exhaust	431-5270
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-9080	Pulley-Alt Drive	264-5883
6B-3158	Shoe-Yoke Lh	243-0357
6B-6224	Ferrule	419-4738
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6V-2202	Bearing-Spl Ball	380-1574
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7M-1154	Bearing-Spl	417-4515
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7N-0128	Core As-Oil Clr	299-1994
7N-2957	Cover-Rad Cap	361-1722

Motor Graders

Sales Model 12E (Cont'd.)

99E		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
8D-5344	Gear-Worm	243-0341
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-3368	Valve-Check	388-6599
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

99E		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
9B-1320	Valve-Check	377-5832
9D-2716	Spindle-Wheel	228-9463

99E		
Original Part Number	**Part Name**	**Classic Part Number**
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9M-4789	Shaft-Gov Cont	297-7256
9M-4955	Pump Gp-F Tfr	242-3443
9M-5477	Bearing-Sleeve	374-6517
9S-7534	Pipe-Exh Ext	398-2950
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
169-4200	Gasket	472-8023
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085

Sales Model 12F

13K		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1P-5480	Cover As.-End	299-1998
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-0057	Plate-Clutch	377-7404
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681

13K		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2G-2858	Cap-Pivot	243-0345
2G-7464	Insert-Bolt	386-4918
2H-3517	Bearing-Inner	417-4505
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532

13K		
Original Part Number	**Part Name**	**Classic Part Number**
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7830	Pump Gp	314-8533
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892

Sales Model 12F (Cont'd.)

13K		
Original Part Number	Part Name	Classic Part Number
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3B-6218	Muffler As	247-2672
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3J-9325	Piston	390-0993
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3V-4046	Plate-Pressure	380-7470
4B-1455	Cap As-Filler	361-1719
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4D-6698	Bearing-Td Hsg	228-9405
4F-2041	Cup-Roller Brg	418-9609
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764

13K		
Original Part Number	Part Name	Classic Part Number
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
5D-4799	Bearing-Roller	416-2160
5D-9906	Shaft-Axle	228-9413
5H-0047	Disc-Cl Drive	388-0576
5L-6326	Bearing-Ball	420-3222
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-8367	Strip-Wear	297-7263
5T-8500	Shoe-Circle Dr	243-0359
5T-8501	Shoe-Circle Dr	243-0358
6B-7469	Spacer	417-4535
6D-1734	Cup-Roller Brg	416-2171
6D-2348	Disc-Friction	380-7489
6D-5415	Plate	382-8043
6D-6859	Bearing	330-9248
6D-8671	Bolt-Draft	243-0333
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4525	Strip-Wear	282-6624
6H-3957	Bearing-Ball	311-9358

13K		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-1945	Gear-Worm	469-4668
7D-4519	Shaft	245-5807
7D-4523	Coupling	245-5817
7D-5859	Adapter	297-7136
7D-5861	Adapter	243-0364
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7K-2135	Bearing-Roller	417-4492
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172

Sales Model 12F (Cont'd.)

13K		
Original Part Number	**Part Name**	**Classic Part Number**
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-7435	Kit-Major Repair	374-4724
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5696	Hub-Cshft	424-5887
7W-9020	Bell As-Pump Suc	378-3989
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-9973	Housing	391-9825
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196

13K		
Original Part Number	**Part Name**	**Classic Part Number**
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174

13K		
Original Part Number	**Part Name**	**Classic Part Number**
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
8W-3589	Link As-Spring	380-7389
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
9B-1320	Valve-Check	377-5832
9D-2716	Spindle-Wheel	228-9463
9F-3212	Bearing-Ball	384-5953
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-6129	Pulley-Alt Drive	264-5891
9S-7534	Pipe-Exh Ext	398-2950
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977

Sales Model 12F (Cont'd.)

13K		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
153-3580	Shaft	299-2055
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

13K		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085

13K		
Original Part Number	Part Name	Classic Part Number
236-8675	Disc-Friction	428-7202
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

73G		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1M-0090	Gasket-Manifold	445-7701
1M-7250	Bowl	360-2296
1P-1367	Plunger-Valve	432-8913
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1W-7073	Rebuild Kt-Pump	383-3677
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2G-2858	Cap-Pivot	243-0345
2G-7464	Insert-Bolt	386-4918

73G		
Original Part Number	Part Name	Classic Part Number
2H-3517	Bearing-Inner	417-4505
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
3B-6218	Muffler As	247-2672
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3S-5017	Elbow-Exhaust	369-9498
4B-1455	Cap As-Filler	361-1719
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598

73G		
Original Part Number	Part Name	Classic Part Number
4D-6698	Bearing-Td Hsg	228-9405
4F-2041	Cup-Roller Brg	418-9609
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4T-8054	Seal As	472-8010
5D-4799	Bearing-Roller	416-2160
5D-9906	Shaft-Axle	228-9413
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5H-7071	Director-Water	388-0555
5L-7632	Support-Elbow	433-9854
5M-5856	Pipe-Extension	373-1913
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5T-8500	Shoe-Circle Dr	243-0359
5T-8501	Shoe-Circle Dr	243-0358
6B-6224	Ferrule	419-4738
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6D-8671	Bolt-Draft	243-0333

Sales Model 12F (Cont'd.)

73G		
Original Part Number	**Part Name**	**Classic Part Number**
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4525	Strip-Wear	282-6624
6V-2202	Bearing-Spl Ball	380-1574
7D-4519	Shaft	245-5807
7D-4523	Coupling	245-5817
7D-5861	Adapter	243-0364
7E-5085	Bushing	377-5829
7M-1154	Bearing-Spl	417-4515
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7N-0128	Core As-Oil Clr	299-1994
7N-2957	Cover-Rad Cap	361-1722

73G		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
8D-5344	Gear-Worm	243-0341
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739

73G		
Original Part Number	**Part Name**	**Classic Part Number**
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9M-4789	Shaft-Gov Cont	297-7256
9M-4955	Pump Gp-F Tfr	242-3443
9M-5477	Bearing-Sleeve	374-6517
9S-7534	Pipe-Exh Ext	398-2950
9T-5096	Flexplate	455-3271
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
130-6856	Pre-Cleaner As	361-1717
153-3580	Shaft	299-2055
169-4200	Gasket	472-8023
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
308-1845	Seal-Wiper	472-8032

89H		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1W-3900	Gasket	472-8006
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

89H		
Original Part Number	**Part Name**	**Classic Part Number**
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2G-2858	Cap-Pivot	243-0345
2G-7464	Insert-Bolt	386-4918
2H-3517	Bearing-Inner	417-4505
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
2K-9295	Bearing-Cone	422-6480

89H		
Original Part Number	**Part Name**	**Classic Part Number**
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979

Sales Model 12F (Cont'd.)

89H		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3B-4124	Cup-Spl Tapered	422-6481
3B-6218	Muffler As	247-2672
3D-4718	Bearing-Sleeve	245-5795
3H-8726	Mount As	385-7208
3J-9325	Piston	390-0993
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-8393	Plate-Clutch	388-0592
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-6698	Bearing-Td Hsg	228-9405
4F-2041	Cup-Roller Brg	418-9609
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4M-1641	Dowel-Reaction	386-4952
4N-4864	Pump Gp-F Tfr	242-3442
4N-7693	Crankshaft As	269-8763
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4S-6707	Piston-Clutch	215-1686
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
5D-4799	Bearing-Roller	416-2160

89H		
Original Part Number	Part Name	Classic Part Number
5D-9906	Shaft-Axle	228-9413
5H-0047	Disc-Cl Drive	388-0576
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-8367	Strip-Wear	297-7263
5T-8500	Shoe-Circle Dr	243-0359
5T-8501	Shoe-Circle Dr	243-0358
6B-7469	Spacer	417-4535
6D-1734	Cup-Roller Brg	416-2171
6D-2348	Disc-Friction	380-7489
6D-5415	Plate	382-8043
6D-6859	Bearing	330-9248
6D-8671	Bolt-Draft	243-0333
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4525	Strip-Wear	282-6624

89H		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7C-4297	Seal As-Cshaft	325-6192
7D-1945	Gear-Worm	469-4668
7D-4519	Shaft	245-5807
7D-4523	Coupling	245-5817
7D-5859	Adapter	297-7136
7D-5861	Adapter	243-0364
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192

Sales Model 12F (Cont'd.)

89H		
Original Part Number	**Part Name**	**Classic Part Number**
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8F-6058	Bearing-Sleeve	416-5494
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-8623	Gear-Sun	213-8755
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556

89H		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
9D-2716	Spindle-Wheel	228-9463
9F-3212	Bearing-Ball	384-5953
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954

89H		
Original Part Number	**Part Name**	**Classic Part Number**
9M-2049	Gear-Ring	214-0533
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-6129	Pulley-Alt Drive	264-5891
9S-7534	Pipe-Exh Ext	398-2950
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
153-3580	Shaft	299-2055
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

Sales Model 12F (Cont'd.)

89H		
Original Part Number	Part Name	Classic Part Number
341-2430	Damper As-Cshft	299-2005

89H		
Original Part Number	Part Name	Classic Part Number
368-0297	Plate-Clutch	377-7420

Sales Model 12G

3PL		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
1U-4661	Lever Gp	396-7267
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036

3PL		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-5768	Gear-Bevel	388-0646
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8739	Retainer	389-6314
2G-9098	Cap	300-2573

3PL		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
2M-8714	Cone-Roller Brg	420-2492
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4364	Housing As-Cl	396-9928
2P-4432	Gear-Ring	418-9583
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-4611	Pipe-Exhaust	365-8821
2P-5769	Coupling	394-9812
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439

Sales Model 12G (Cont'd.)

3PL		
Original Part Number	Part Name	Classic Part Number
2W-7678	Gear-Water Pump	325-6088
2W-9094	Adapter-Exhaust	299-2534
2W-9978	Core As-Oclr	279-4983
3L-1425	Bearing-Ball	311-9356
3P-0165	Pulley-Fan Drive	298-2775
3P-0296	Gear	416-2149
3P-0297	Shaft As	275-5297
3P-0298	Carrier-Input	384-5922
3P-0329	Drum As-Gear	380-7484
3P-0726	Shaft As	275-5298
3P-0786	Coupling	433-0440
3P-0801	Plate-Clutch	383-2119
3P-0951	Bearing-Spl Ball	416-2159
3P-3424	Shaft	416-5526
3P-5349	Piston As	275-5292
3P-5737	Shaft As-Clutch	275-5273
3P-5955	Disc-Friction	428-7205
3T-2095	Bearing-Sleeve	384-3459
4B-7270	Cone-Bearing	399-4439
4D-2619	Bearing	417-4494
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988

3PL		
Original Part Number	Part Name	Classic Part Number
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-0470	Valve Gp-Qrel	314-8549
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-0925	Actuator Gp-Bk	379-0198
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013

3PL		
Original Part Number	Part Name	Classic Part Number
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-8425	Valve Gp-Cont -K	367-6086
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1878	Muffler As	360-7883
6N-7174	Shield-Oil	314-8544
6P-2090	Base-Xmsn O Fil	397-5049
6V-2202	Bearing-Spl Ball	380-1574
6Y-0305	Cage As-Bearing	297-7150
6Y-0306	Bearing-Sleeve	391-1104
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
6Y-7916	Disc-Friction	428-7204
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-7889	Gear-Ring	275-5276

Sales Model 12G (Cont'd.)

3PL		
Original Part Number	Part Name	Classic Part Number
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-3451	Gear-Planet	297-7188
7G-3452	Gear-Planet	275-5290
7G-3461	Gear-Planet	275-5291
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-8576	Bearing As	435-4848
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-9647	Piston-Clutch	275-5294

3PL		
Original Part Number	Part Name	Classic Part Number
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-2469	Shaft-Drive	275-5280
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-3744	Shaft-Drive	275-5283
8D-3877	Gear-Sun	275-5278
8D-3949	Ring-Wear	330-9283
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7693	Housing	384-4830
8D-7996	Bearing-Sleeve	472-8018
8D-8159	Retainer	419-8661
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-1616	Lever	330-9271
8J-6322	Cup-Roller Brg	399-4447
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436

3PL		
Original Part Number	Part Name	Classic Part Number
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1656	Plate-Clutch	367-6071
8P-5961	Gear-Ring	385-6137
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416

Sales Model 12G (Cont'd.)

3PL		
Original Part Number	**Part Name**	**Classic Part Number**
8W-0328	Cylinder-Damper	419-4715
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2308	Shaft-Planet	275-5285
8W-3589	Link As-Spring	380-7389
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9D-9968	Washer-Thrust	391-9890
9M-1853	Mount As.	376-3638
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891

3PL		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
104-3014	Gasket Kit	388-0656
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
109-5562	Shaft-Pin (Bev)	275-5272
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361

3PL		
Original Part Number	**Part Name**	**Classic Part Number**
153-3580	Shaft	299-2055
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-3986	Gasket Kit	390-5275
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
246-5916	Kit-Seal-H.Cyl-1	472-8026
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
288-2552	Kit-Gasket-Txg	391-9884
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989

Sales Model 12G (Cont'd.)

3PL		
Original Part Number	Part Name	Classic Part Number
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

3PL		
Original Part Number	Part Name	Classic Part Number
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

3PL		
Original Part Number	Part Name	Classic Part Number
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

3WC		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-5480	Cover As.-End	299-1998
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
1U-4661	Lever Gp	396-7267
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

3WC		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-2858	Cap-Pivot	243-0345
2G-5768	Gear-Bevel	388-0646
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-7464	Insert-Bolt	386-4918
2G-8238	Yoke As	282-6631

3WC		
Original Part Number	Part Name	Classic Part Number
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8739	Retainer	389-6314
2G-9098	Cap	300-2573
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4364	Housing As-Cl	396-9928
2P-4432	Gear-Ring	418-9583
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-4611	Pipe-Exhaust	365-8821
2P-4698	Bearing-Sleeve	389-6318
2P-5608	Pipe-Extension	367-6066
2P-5769	Coupling	394-9812
2P-6245	Shaft As-Pump	325-6197

Sales Model 12G (Cont'd.)

3WC		
Original Part Number	**Part Name**	**Classic Part Number**
2P-7828	Pan-Oil	314-8691
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9094	Adapter-Exhaust	299-2534
2W-9978	Core As-Oclr	279-4983
3G-1853	Cyl Gp-076 406 Y	415-1895
3G-4752	Cyl Gp-035-060-Y	390-0987
3G-5223	Cyl Gp-0083-1016	399-8557
3G-5224	Cyl Gp-0083-0459	425-9375
3J-6575	Trunnion	297-7265
3L-1425	Bearing-Ball	311-9356
3P-0114	Elbow-Exhaust	314-8516
3P-0165	Pulley-Fan Drive	298-2775
3P-0296	Gear	416-2149
3P-0297	Shaft As	275-5297
3P-0298	Carrier-Input	384-5922
3P-0329	Drum As-Gear	380-7484
3P-0726	Shaft As	275-5298
3P-0786	Coupling	433-0440
3P-0801	Plate-Clutch	383-2119
3P-0951	Bearing-Spl Ball	416-2159
3P-3424	Shaft	416-5526
3P-5349	Piston As	275-5292
3P-5737	Shaft As-Clutch	275-5273
3P-5955	Disc-Friction	428-7205
3T-2095	Bearing-Sleeve	384-3459
3Y-2768	Ring	439-4544

3WC		
Original Part Number	**Part Name**	**Classic Part Number**
4B-7270	Cone-Bearing	399-4439
4D-2619	Bearing	417-4494
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8942	Muffler As	298-2786
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987

3WC		
Original Part Number	**Part Name**	**Classic Part Number**
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-0470	Valve Gp-Qrel	314-8549
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-0925	Actuator Gp-Bk	379-0198
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8500	Shoe-Circle Dr	243-0359
5T-8501	Shoe-Circle Dr	243-0358
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535

Sales Model 12G (Cont'd.)

3WC		
Original Part Number	Part Name	Classic Part Number
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-8425	Valve Gp-Cont -K	367-6086
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-2090	Base-Xmsn O Fil	397-5049
6V-2202	Bearing-Spl Ball	380-1574
6Y-0305	Cage As-Bearing	297-7150
6Y-0306	Bearing-Sleeve	391-1104
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
6Y-7916	Disc-Friction	428-7204
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-5861	Adapter	243-0364
7D-7889	Gear-Ring	275-5276

3WC		
Original Part Number	Part Name	Classic Part Number
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-3451	Gear-Planet	297-7188
7G-3452	Gear-Planet	275-5290
7G-3461	Gear-Planet	275-5291
7J-3351	Head	380-1515
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7K-9348	Pin	252-6872
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497

3WC		
Original Part Number	Part Name	Classic Part Number
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-8576	Bearing As	435-4848
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-9647	Piston-Clutch	275-5294
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-0983	Mounting	384-3470
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-2469	Shaft-Drive	275-5280
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-3744	Shaft-Drive	275-5283
8D-3877	Gear-Sun	275-5278
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7693	Housing	384-4830
8D-7996	Bearing-Sleeve	472-8018
8D-8159	Retainer	419-8661
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512

Sales Model 12G (Cont'd.)

3WC		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
8J-0546	Cyl Gp-076 276 Y	430-8116
8J-1616	Lever	330-9271
8J-1624	Valve As	390-0997
8J-2022	Piston As-Pump	367-6073
8J-6296	Shaft	419-6072
8J-6322	Cup-Roller Brg	399-4447
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290

3WC		
Original Part Number	**Part Name**	**Classic Part Number**
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1656	Plate-Clutch	367-6071
8P-5961	Gear-Ring	385-6137
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8W-0328	Cylinder-Damper	419-4715
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-3589	Link As-Spring	380-7389
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739

3WC		
Original Part Number	**Part Name**	**Classic Part Number**
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
9B-1320	Valve-Check	377-5832
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3288	Bolt-Draft	333-4941
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9J-3466	Cyl Gp-028 121 Y	393-0913
9M-1853	Mount As.	376-3638
9M-5477	Bearing-Sleeve	374-6517
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032

Sales Model 12G (Cont'd.)

3WC		
Original Part Number	Part Name	Classic Part Number
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
104-3014	Gasket Kit	388-0656
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
109-5562	Shaft-Pin (Bev)	275-5272
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
139-0683	Gasket Kit	390-5290
143-7356	Bearing As	380-1483
147-3310	Spindle-Wheel	383-2111

3WC		
Original Part Number	Part Name	Classic Part Number
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-3986	Gasket Kit	390-5275

3WC		
Original Part Number	Part Name	Classic Part Number
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
234-8015	Kit-Gasket-Sch	437-8674
236-7724	Retainer	299-2048
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
246-5916	Kit-Seal-H.Cyl-1	472-8026
250-6556	Kit-Liner-Cla	250-6564
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
288-2552	Kit-Gasket-Txg	391-9884
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

61M		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147

61M		
Original Part Number	Part Name	Classic Part Number
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-4695	Cup-Rlr Bearing	374-1842

61M		
Original Part Number	Part Name	Classic Part Number
1P-4696	Cone-Rlr Bearing	374-1843
1P-5480	Cover As.-End	299-1998
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453

Sales Model 12G (Cont'd.)

61M		
Original Part Number	Part Name	Classic Part Number
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
1U-4661	Lever Gp	396-7267
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-2858	Cap-Pivot	243-0345
2G-5768	Gear-Bevel	388-0646
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-7464	Insert-Bolt	386-4918
2G-8238	Yoke As	282-6631

61M		
Original Part Number	Part Name	Classic Part Number
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8739	Retainer	389-6314
2G-9098	Cap	300-2573
2K-6413	Pin	360-2270
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8714	Cone-Roller Brg	420-2492
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4364	Housing As-Cl	396-9928
2P-4432	Gear-Ring	418-9583
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-4611	Pipe-Exhaust	365-8821
2P-5608	Pipe-Extension	367-6066
2P-5609	Muffler As.	247-2665
2P-5769	Coupling	394-9812
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7830	Pump Gp	314-8533

61M		
Original Part Number	Part Name	Classic Part Number
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9094	Adapter-Exhaust	299-2534
2W-9978	Core As-Oclr	279-4983
3B-6218	Muffler As	247-2672
3D-9126	Cup-Roller Brg	399-4435
3G-1853	Cyl Gp-076 406 Y	415-1895
3G-4752	Cyl Gp-035-060-Y	390-0987
3G-5223	Cyl Gp-0083-1016	399-8557
3G-5224	Cyl Gp-0083-0459	425-9375
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-0165	Pulley-Fan Drive	298-2775
3P-0296	Gear	416-2149
3P-0297	Shaft As	275-5297
3P-0298	Carrier-Input	384-5922
3P-0329	Drum As-Gear	380-7484
3P-0726	Shaft As	275-5298
3P-0786	Coupling	433-0440
3P-0801	Plate-Clutch	383-2119
3P-0951	Bearing-Spl Ball	416-2159
3P-3424	Shaft	416-5526
3P-5349	Piston As	275-5292
3P-5737	Shaft As-Clutch	275-5273
3P-5955	Disc-Friction	428-7205
3T-2095	Bearing-Sleeve	384-3459

Sales Model 12G (Cont'd.)

61M		
Original Part Number	Part Name	Classic Part Number
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-2619	Bearing	417-4494
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4N-8942	Muffler As	298-2786
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986

61M		
Original Part Number	Part Name	Classic Part Number
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-6869	Spacer-Fuel Pump	417-4534
5D-0470	Valve Gp-Qrel	314-8549
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-0925	Actuator Gp-Bk	379-0198
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013

61M		
Original Part Number	Part Name	Classic Part Number
5T-8367	Strip-Wear	297-7263
5T-8500	Shoe-Circle Dr	243-0359
5T-8501	Shoe-Circle Dr	243-0358
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-8425	Valve Gp-Cont -K	367-6086
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0622	Elbow-Exhaust	380-7534
6N-1036	Gear-Oil Pump	279-4991
6N-1878	Muffler As	360-7883
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-2090	Base-Xmsn O Fil	397-5049
6S-3051	Cup-Rlr Brg	415-1928
6V-2202	Bearing-Spl Ball	380-1574

Sales Model 12G (Cont'd.)

61M		
Original Part Number	**Part Name**	**Classic Part Number**
6V-2527	Gasket Kit	387-2918
6Y-0305	Cage As-Bearing	297-7150
6Y-0306	Bearing-Sleeve	391-1104
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
6Y-7916	Disc-Friction	428-7204
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-5861	Adapter	243-0364
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-3451	Gear-Planet	297-7188
7G-3452	Gear-Planet	275-5290
7G-3461	Gear-Planet	275-5291
7J-3351	Head	380-1515
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581

61M		
Original Part Number	**Part Name**	**Classic Part Number**
7N-1152	Pulley-Fan	333-4951
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-8576	Bearing As	435-4848
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-9647	Piston-Clutch	275-5294
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5696	Hub-Cshft	424-5887
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8D-0983	Mounting	384-3470

61M		
Original Part Number	**Part Name**	**Classic Part Number**
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-2469	Shaft-Drive	275-5280
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-3744	Shaft-Drive	275-5283
8D-3877	Gear-Sun	275-5278
8D-3949	Ring-Wear	330-9283
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7083	Bearing	386-4930
8D-7086	Bearing	330-9251
8D-7096	Pin-Axle Leaning	297-7219
8D-7167	Pin	389-6319
8D-7284	Bearing	330-9252
8D-7427	Shaft-Dr Pinion	282-6568
8D-7693	Housing	384-4830
8D-7996	Bearing-Sleeve	472-8018
8D-8159	Retainer	419-8661
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8E-5284	Bearing	388-0582
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8J-0546	Cyl Gp-076 276 Y	430-8116
8J-1616	Lever	330-9271
8J-1624	Valve As	390-0997
8J-2022	Piston As-Pump	367-6073
8J-6296	Shaft	419-6072
8J-6322	Cup-Roller Brg	399-4447
8J-6384	Bearing-Sleeve	472-8034
8M-0874	Plunger As-Valve	311-9439

Sales Model 12G (Cont'd.)

61M		
Original Part Number	Part Name	Classic Part Number
8M-3368	Valve-Check	388-6599
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

61M		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1656	Plate-Clutch	367-6071
8P-5961	Gear-Ring	385-6137
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8W-0328	Cylinder-Damper	419-4715
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-3589	Link As-Spring	380-7389
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105

61M		
Original Part Number	Part Name	Classic Part Number
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
9B-1320	Valve-Check	377-5832
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3288	Bolt-Draft	333-4941
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9D-9968	Washer-Thrust	391-9890
9F-3212	Bearing-Ball	384-5953
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-3466	Cyl Gp-028 121 Y	393-0913
9M-1853	Mount As.	376-3638
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-7148	Cap As-Rain	378-3994
9S-7534	Pipe-Exh Ext	398-2950
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032

Sales Model 12G (Cont'd.)

61M		
Original Part Number	**Part Name**	**Classic Part Number**
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
109-5562	Shaft-Pin (Bev)	275-5272
110-1337	Ring Kit-Pstn	377-5834
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp-Univ	297-4858
121-7746	Pre-Cleaner As	360-2311
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
139-0683	Gasket Kit	390-5290
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554

61M		
Original Part Number	**Part Name**	**Classic Part Number**
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
170-0560	Rebuild Kit-Pump	363-7458
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7772	Pump Gp-Water -B	438-2009
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314

61M		
Original Part Number	**Part Name**	**Classic Part Number**
174-6822	Bearing-Sleeve	387-2901
184-9843	Head	347-0461
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-3986	Gasket Kit	390-5275
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
234-8015	Kit-Gasket-Sch	437-8674
236-7724	Retainer	299-2048
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
246-5916	Kit-Seal-H.Cyl-1	472-8026
250-6555	Kit-Liner-Cla	250-6563
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
288-2552	Kit-Gasket-Txg	391-9884
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 12H

125		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988

Sales Model 12H (Cont'd.)

125		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-7213	Bearing-Sleeve	419-4667
3J-6575	Trunnion	297-7265
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007

125		
Original Part Number	**Part Name**	**Classic Part Number**
4M-6107	Bearing-Roller	380-7507
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
6E-0775	Head	425-9373
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6H-2577	Spider Gp-Brg&	333-4954
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939

125		
Original Part Number	**Part Name**	**Classic Part Number**
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816

Sales Model 12H (Cont'd.)

125		
Original Part Number	**Part Name**	**Classic Part Number**
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-6147	Body As	369-9499
9T-2387	Rod As	393-5218
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
104-8655	Bearing-Sleeve	391-9892
105-3196	Motor Gp-Grtr	282-6547

125		
Original Part Number	**Part Name**	**Classic Part Number**
106-7131	Shaft	288-8714
110-4652	Housing	302-2683
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
115-4072	Bearing	397-5069
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
135-7393	Head	382-6895
143-7356	Bearing As	380-1483
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-6485	Cyl Gp-102 472 Y	390-0985
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
161-3411	Gasket	394-0896

125		
Original Part Number	**Part Name**	**Classic Part Number**
163-1387	Gear-Flywheel	374-4697
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

2GS		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384

2GS		
Original Part Number	**Part Name**	**Classic Part Number**
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513

2GS		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561

Sales Model 12H (Cont'd.)

2GS		
Original Part Number	Part Name	Classic Part Number
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

2GS		
Original Part Number	Part Name	Classic Part Number
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247

2GS		
Original Part Number	Part Name	Classic Part Number
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574

Sales Model 12H (Cont'd.)

2GS		
Original Part Number	Part Name	Classic Part Number
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721

2GS		
Original Part Number	Part Name	Classic Part Number
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5164	Gasket	420-8568
7W-5696	Hub-Cshft	424-5887
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210

2GS		
Original Part Number	Part Name	Classic Part Number
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739

Sales Model 12H (Cont'd.)

2GS		
Original Part Number	Part Name	Classic Part Number
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-3125	Gasket	420-8567
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892

2GS		
Original Part Number	Part Name	Classic Part Number
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

2GS		
Original Part Number	Part Name	Classic Part Number
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055
187-3307	Gasket As-Cyl	438-2022
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
316-4396	Kit-Gasket (Sch)	393-3661
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model 12H (Cont'd.)

2LR		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354

2LR		
Original Part Number	Part Name	Classic Part Number
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439

2LR		
Original Part Number	Part Name	Classic Part Number
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433

Sales Model 12H (Cont'd.)

2LR		
Original Part Number	Part Name	Classic Part Number
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954

2LR		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686

2LR		
Original Part Number	Part Name	Classic Part Number
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599

Sales Model 12H (Cont'd.)

2LR		
Original Part Number	Part Name	Classic Part Number
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403

2LR		
Original Part Number	Part Name	Classic Part Number
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925

2LR		
Original Part Number	Part Name	Classic Part Number
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
130-1455	Gasket Kit	437-4604
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351

Sales Model 12H (Cont'd.)

2LR		
Original Part Number	Part Name	Classic Part Number
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461

2LR		
Original Part Number	Part Name	Classic Part Number
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438

2LR		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

2WR		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

2WR		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258

2WR		
Original Part Number	Part Name	Classic Part Number
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4611	Pipe-Exhaust	365-8821
2P-6245	Shaft As-Pump	325-6197

Sales Model 12H (Cont'd.)

2WR		
Original Part Number	Part Name	Classic Part Number
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9094	Adapter-Exhaust	299-2534
2W-9978	Core As-Oclr	279-4983
3J-6575	Trunnion	297-7265
3Y-2768	Ring	439-4544
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355

2WR		
Original Part Number	Part Name	Classic Part Number
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530

2WR		
Original Part Number	Part Name	Classic Part Number
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297

Sales Model 12H (Cont'd.)

2WR		
Original Part Number	Part Name	Classic Part Number
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7J-3351	Head	380-1515
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7K-9348	Pin	252-6872
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341

2WR		
Original Part Number	Part Name	Classic Part Number
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081

2WR		
Original Part Number	Part Name	Classic Part Number
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1853	Mount As.	376-3638

Motor Graders

Sales Model 12H (Cont'd.)

2WR		
Original Part Number	**Part Name**	**Classic Part Number**
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
130-1455	Gasket Kit	437-4604

2WR		
Original Part Number	**Part Name**	**Classic Part Number**
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
135-7393	Head	382-6895
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
152-6485	Cyl Gp-102 472 Y	390-0985
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687

2WR		
Original Part Number	**Part Name**	**Classic Part Number**
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
255-2899	Pipe As-Tail	301-5246
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

4ER		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347

4ER		
Original Part Number	**Part Name**	**Classic Part Number**
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978

4ER		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147

Sales Model 12H (Cont'd.)

4ER		
Original Part Number	Part Name	Classic Part Number
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6377	Sprocket	275-5286
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258

4ER		
Original Part Number	Part Name	Classic Part Number
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4611	Pipe-Exhaust	365-8821
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9094	Adapter-Exhaust	299-2534
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632

4ER		
Original Part Number	Part Name	Classic Part Number
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930

Sales Model 12H (Cont'd.)

4ER		
Original Part Number	Part Name	Classic Part Number
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0735	Chain Gp	390-5262
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-7213	Carrier-Planet	396-9936
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954

4ER		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899

4ER		
Original Part Number	Part Name	Classic Part Number
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034

Sales Model 12H (Cont'd.)

4ER		
Original Part Number	Part Name	Classic Part Number
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019

4ER		
Original Part Number	Part Name	Classic Part Number
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2307	Shaft-Planet	275-5284
8W-2308	Shaft-Planet	275-5285
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

4ER		
Original Part Number	Part Name	Classic Part Number
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
130-1455	Gasket Kit	437-4604
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3309	Spindle	282-6628
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591

Sales Model 12H (Cont'd.)

4ER		
Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
155-1379	Gasket Kit - Sch	386-3815
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

4ER		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
255-2899	Pipe As-Tail	301-5246
265-5287	Ring-Seal	472-8028

4ER		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

4XM		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294

4XM		
Original Part Number	Part Name	Classic Part Number
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382

4XM		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350

Sales Model 12H (Cont'd.)

4XM		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4611	Pipe-Exhaust	365-8821
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9094	Adapter-Exhaust	299-2534
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

4XM		
Original Part Number	Part Name	Classic Part Number
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247

4XM		
Original Part Number	Part Name	Classic Part Number
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574

Sales Model 12H (Cont'd.)

4XM		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656

4XM		
Original Part Number	**Part Name**	**Classic Part Number**
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210

4XM		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739

Sales Model 12H (Cont'd.)

4XM		
Original Part Number	Part Name	Classic Part Number
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9L-5908	Gasket	433-8196
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9T-5729	Cyl Gp-0038 0158	422-2486
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892

4XM		
Original Part Number	Part Name	Classic Part Number
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
130-1455	Gasket Kit	437-4604
130-1521	Gasket Kit - Sch	393-1030
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127

4XM		
Original Part Number	Part Name	Classic Part Number
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
255-2899	Pipe As-Tail	301-5246
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model 12H (Cont'd.)

5ZM		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354

5ZM		
Original Part Number	Part Name	Classic Part Number
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6377	Sprocket	275-5286
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4611	Pipe-Exhaust	365-8821
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203

5ZM		
Original Part Number	Part Name	Classic Part Number
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9094	Adapter-Exhaust	299-2534
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262

Sales Model 12H (Cont'd.)

5ZM		
Original Part Number	Part Name	Classic Part Number
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0735	Chain Gp	390-5262
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624

5ZM		
Original Part Number	Part Name	Classic Part Number
6G-5704	Piston	394-9838
6G-7213	Carrier-Planet	396-9936
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206

5ZM		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682

Sales Model 12H (Cont'd.)

5ZM		
Original Part Number	Part Name	Classic Part Number
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372

5ZM		
Original Part Number	Part Name	Classic Part Number
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2307	Shaft-Planet	275-5284
8W-2308	Shaft-Planet	275-5285
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9L-5908	Gasket	433-8196
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891

5ZM		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3309	Spindle	282-6628
147-3310	Spindle-Wheel	383-2111

Sales Model 12H (Cont'd.)

5ZM		
Original Part Number	Part Name	Classic Part Number
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

5ZM		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
255-2899	Pipe As-Tail	301-5246

5ZM		
Original Part Number	Part Name	Classic Part Number
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

8MN		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497

8MN		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382

8MN		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350

Sales Model 12H (Cont'd.)

8MN		
Original Part Number	**Part Name**	**Classic Part Number**
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4611	Pipe-Exhaust	365-8821
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9094	Adapter-Exhaust	299-2534
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

8MN		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467

8MN		
Original Part Number	**Part Name**	**Classic Part Number**
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544

Sales Model 12H (Cont'd.)

8MN		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969

8MN		
Original Part Number	Part Name	Classic Part Number
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

8MN		
Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570

Sales Model 12H (Cont'd.)

8MN		
Original Part Number	Part Name	Classic Part Number
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035

8MN		
Original Part Number	Part Name	Classic Part Number
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127

8MN		
Original Part Number	Part Name	Classic Part Number
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
255-2899	Pipe As-Tail	301-5246
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model 12H (Cont'd.)

AMZ		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
1W-6810	Pipe-Outlet	472-8036
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-7213	Bearing-Sleeve	419-4667

AMZ		
Original Part Number	Part Name	Classic Part Number
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4S-8472	Hood As-Preclnr	296-1355
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838

AMZ		
Original Part Number	Part Name	Classic Part Number
6H-2577	Spider Gp-Brg&	333-4954
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214

Sales Model 12H (Cont'd.)

AMZ		
Original Part Number	Part Name	Classic Part Number
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500

AMZ		
Original Part Number	Part Name	Classic Part Number
9S-6147	Body As	369-9499
9T-2387	Rod As	393-5218
9W-9930	Mount As	295-6437
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
104-8655	Bearing-Sleeve	391-9892
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
115-4072	Bearing	397-5069
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
143-7356	Bearing As	380-1483
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549

AMZ		
Original Part Number	Part Name	Classic Part Number
148-2593	Head	383-1591
151-5349	Head	383-1592
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

CBK		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504

CBK		
Original Part Number	Part Name	Classic Part Number
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
1W-6810	Pipe-Outlet	472-8036
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682

CBK		
Original Part Number	Part Name	Classic Part Number
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049

Sales Model 12H (Cont'd.)

CBK		
Original Part Number	Part Name	Classic Part Number
2V-4331	Collar	387-2910
2W-7213	Bearing-Sleeve	419-4667
3J-6575	Trunnion	297-7265
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4S-8472	Hood As-Preclnr	296-1355
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337

CBK		
Original Part Number	Part Name	Classic Part Number
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6H-2577	Spider Gp-Brg&	333-4954
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732

CBK		
Original Part Number	Part Name	Classic Part Number
8W-2308	Shaft-Planet	275-5285
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-6147	Body As	369-9499
9T-2387	Rod As	393-5218
9W-9930	Mount As	295-6437
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
104-8655	Bearing-Sleeve	391-9892
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683

Sales Model 12H (Cont'd.)

CBK		
Original Part Number	**Part Name**	**Classic Part Number**
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
115-4072	Bearing	397-5069
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
135-7393	Head	382-6895
143-7356	Bearing As	380-1483
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591

CBK		
Original Part Number	**Part Name**	**Classic Part Number**
151-5349	Head	383-1592
152-6485	Cyl Gp-102 472 Y	390-0985
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659

CBK		
Original Part Number	**Part Name**	**Classic Part Number**
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
252-5650	Rim As	397-5067
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

XZJ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340

XZJ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6377	Sprocket	275-5286
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259

XZJ		
Original Part Number	**Part Name**	**Classic Part Number**
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4611	Pipe-Exhaust	365-8821
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289

Sales Model 12H (Cont'd.)

XZJ		
Original Part Number	Part Name	Classic Part Number
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9094	Adapter-Exhaust	299-2534
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191

XZJ		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0735	Chain Gp	390-5262
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160

XZJ		
Original Part Number	Part Name	Classic Part Number
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-7213	Carrier-Planet	396-9936
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847

Sales Model 12H (Cont'd.)

XZJ		
Original Part Number	Part Name	Classic Part Number
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277

XZJ		
Original Part Number	Part Name	Classic Part Number
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042

XZJ		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2307	Shaft-Planet	275-5284
8W-2308	Shaft-Planet	275-5285
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923

Sales Model 12H (Cont'd.)

XZJ		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193

XZJ		
Original Part Number	Part Name	Classic Part Number
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3309	Spindle	282-6628
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901

XZJ		
Original Part Number	Part Name	Classic Part Number
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
255-2899	Pipe As-Tail	301-5246
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model 12K

Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347

Original Part Number	Part Name	Classic Part Number
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486

Original Part Number	Part Name	Classic Part Number
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851

Sales Model 12K (Cont'd.)

Original Part Number	Part Name	Classic Part Number
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-9514	Bearing-Ball	417-9467
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-8642	Race-Brg Outer	396-9898
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7W-5095	Gear-Flywheel	425-9190
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2308	Shaft-Planet	275-5285
8W-4652	Housing-Spindle	385-7215

Sales Model 12K (Cont'd.)

Original Part Number	Part Name	Classic Part Number
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
8Y-0809	Spider Gp-Brg&	417-4526
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-8285	Cap	391-9822
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

Original Part Number	Part Name	Classic Part Number
9T-2387	Rod As	393-5218
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
104-8655	Bearing-Sleeve	391-9892
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
115-4072	Bearing	397-5069
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
133-4995	Gasket-Cyl Head	434-2445
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696

Original Part Number	Part Name	Classic Part Number
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
200-7929	Housing	416-5489
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

SZP		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-4693	Cup-Rlr Bearing	377-7398

SZP		
Original Part Number	Part Name	Classic Part Number
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488

SZP		
Original Part Number	Part Name	Classic Part Number
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450

Sales Model 12K (Cont'd.)

SZP		
Original Part Number	Part Name	Classic Part Number
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-9514	Bearing-Ball	417-9467
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565

SZP		
Original Part Number	Part Name	Classic Part Number
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-8642	Race-Brg Outer	396-9898
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7W-5095	Gear-Flywheel	425-9190
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4766	Pin-Cylinder	365-8832

SZP		
Original Part Number	Part Name	Classic Part Number
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2308	Shaft-Planet	275-5285
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
8Y-0809	Spider Gp-Brg&	417-4526
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-8285	Cap	391-9822
9M-1328	Bearing-Aligning	325-6018

Sales Model 12K (Cont'd.)

SZP		
Original Part Number	Part Name	Classic Part Number
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-2387	Rod As	393-5218
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
104-8655	Bearing-Sleeve	391-9892
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
115-4072	Bearing	397-5069

SZP		
Original Part Number	Part Name	Classic Part Number
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
133-4995	Gasket-Cyl Head	434-2445
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
200-7929	Housing	416-5489
212-4893	Bearing-Thrust	419-6372

SZP		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

Sales Model 12M

B92		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

B92		
Original Part Number	Part Name	Classic Part Number
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788

B92		
Original Part Number	Part Name	Classic Part Number
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065

Sales Model 12M (Cont'd.)

B92		
Original Part Number	**Part Name**	**Classic Part Number**
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019

B92		
Original Part Number	**Part Name**	**Classic Part Number**
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
105-3196	Motor Gp-Grtr	282-6547
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

B92		
Original Part Number	**Part Name**	**Classic Part Number**
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

B9F		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450

B9F		
Original Part Number	**Part Name**	**Classic Part Number**
2G-8631	Bearing-Sleeve	391-9811
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
3J-6575	Trunnion	297-7265
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010

B9F		
Original Part Number	**Part Name**	**Classic Part Number**
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566

Sales Model 12M (Cont'd.)

B9F		
Original Part Number	Part Name	Classic Part Number
6L-7751	Rod End-Spher	472-8015
6V-0347	Cone-Spl Tapered	420-6537
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8J-6384	Bearing-Sleeve	472-8034

B9F		
Original Part Number	Part Name	Classic Part Number
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
9T-5729	Cyl Gp-0038 0158	422-2486
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134

B9F		
Original Part Number	Part Name	Classic Part Number
135-7393	Head	382-6895
148-2593	Head	383-1591
152-6485	Cyl Gp-102 472 Y	390-0985
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

B9R		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911

B9R		
Original Part Number	Part Name	Classic Part Number
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6I-8642	Race-Brg Outer	396-9898
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566

B9R		
Original Part Number	Part Name	Classic Part Number
6L-7751	Rod End-Spher	472-8015
6V-0347	Cone-Spl Tapered	420-6537
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7M-7219	Bearing-Thrust	384-4816
8D-5344	Gear-Worm	243-0341
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569

Sales Model 12M (Cont'd.)

B9R		
Original Part Number	**Part Name**	**Classic Part Number**
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-2754	Insert	333-4948
9M-2042	Race-Roller Brg	417-9500
9T-5729	Cyl Gp-0038 0158	422-2486

B9R		
Original Part Number	**Part Name**	**Classic Part Number**
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
148-2593	Head	383-1591
178-3086	Ballstud	374-1453

B9R		
Original Part Number	**Part Name**	**Classic Part Number**
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

E9P		
Original Part Number	**Part Name**	**Classic Part Number**
2D-2654	Ring-Lock	380-1488
2K-6413	Pin	360-2270

E9P		
Original Part Number	**Part Name**	**Classic Part Number**
4T-8054	Seal As	472-8010
8W-9566	Flange As	376-9073

E9R		
Original Part Number	**Part Name**	**Classic Part Number**
2D-2654	Ring-Lock	380-1488
2K-6413	Pin	360-2270

E9R		
Original Part Number	**Part Name**	**Classic Part Number**
4T-8054	Seal As	472-8010
8W-9566	Flange As	376-9073

F9B		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350

F9B		
Original Part Number	**Part Name**	**Classic Part Number**
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
6B-3223	Cup-Bearing	399-6065

F9B		
Original Part Number	**Part Name**	**Classic Part Number**
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019

Sales Model 12M (Cont'd.)

F9B		
Original Part Number	Part Name	Classic Part Number
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018

F9B		
Original Part Number	Part Name	Classic Part Number
9M-2042	Race-Roller Brg	417-9500
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461

F9B		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

F9M		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010

F9M		
Original Part Number	Part Name	Classic Part Number
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384

F9M		
Original Part Number	Part Name	Classic Part Number
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

Sales Model 12M (Cont'd.)

N9B		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507

N9B		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
6B-3223	Cup-Bearing	399-6065
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384

N9B		
Original Part Number	**Part Name**	**Classic Part Number**
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

N9F		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

N9F		
Original Part Number	**Part Name**	**Classic Part Number**
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962

N9F		
Original Part Number	**Part Name**	**Classic Part Number**
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065

Sales Model 12M (Cont'd.)

N9F		
Original Part Number	Part Name	Classic Part Number
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018

N9F		
Original Part Number	Part Name	Classic Part Number
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
030-0060	Bearing-Cup	415-1926

N9F		
Original Part Number	Part Name	Classic Part Number
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

N9P		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007

N9P		
Original Part Number	Part Name	Classic Part Number
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969

N9P		
Original Part Number	Part Name	Classic Part Number
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
161-3411	Gasket	394-0896

Sales Model 12M (Cont'd.)

N9P		
Original Part Number	**Part Name**	**Classic Part Number**
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

N9P		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031

N9P		
Original Part Number	**Part Name**	**Classic Part Number**
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

N9R		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010

N9R		
Original Part Number	**Part Name**	**Classic Part Number**
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384

N9R		
Original Part Number	**Part Name**	**Classic Part Number**
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

R9B		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486

R9B		
Original Part Number	**Part Name**	**Classic Part Number**
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344

R9B		
Original Part Number	**Part Name**	**Classic Part Number**
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294

Sales Model 12M (Cont'd.)

R9B		
Original Part Number	Part Name	Classic Part Number
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065

R9B		
Original Part Number	Part Name	Classic Part Number
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6I-8642	Race-Brg Outer	396-9898
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-0347	Cone-Spl Tapered	420-6537
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7M-7219	Bearing-Thrust	384-4816
8D-5344	Gear-Worm	243-0341
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8J-6384	Bearing-Sleeve	472-8034

R9B		
Original Part Number	Part Name	Classic Part Number
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-2754	Insert	333-4948
9M-2042	Race-Roller Brg	417-9500
9T-5729	Cyl Gp-0038 0158	422-2486
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
148-2593	Head	383-1591
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

R9P		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020

R9P		
Original Part Number	Part Name	Classic Part Number
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811

R9P		
Original Part Number	Part Name	Classic Part Number
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962

Sales Model 12M (Cont'd.)

R9P		
Original Part Number	**Part Name**	**Classic Part Number**
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502

R9P		
Original Part Number	**Part Name**	**Classic Part Number**
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121

R9P		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

R9R		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007

R9R		
Original Part Number	**Part Name**	**Classic Part Number**
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-0347	Cone-Spl Tapered	420-6537
6Y-9960	Mount As.	376-3639

R9R		
Original Part Number	**Part Name**	**Classic Part Number**
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7J-5131	Trunnion	296-1371
7M-7219	Bearing-Thrust	384-4816
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9296	Bearing	330-9253
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121

Sales Model 12M (Cont'd.)

R9R		
Original Part Number	**Part Name**	**Classic Part Number**
9M-2042	Race-Roller Brg	417-9500
9W-9931	Mount As.	360-2354
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547

R9R		
Original Part Number	**Part Name**	**Classic Part Number**
107-8375	Shaft As	439-1134
148-2593	Head	383-1591
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

R9R		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

R9S		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010

R9S		
Original Part Number	**Part Name**	**Classic Part Number**
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384

R9S		
Original Part Number	**Part Name**	**Classic Part Number**
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

64C		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1S-1967	Chamber As	247-3291
1S-3743	Bearing-Ball	384-4786
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-6421	Bearing-Outer	417-4510
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2S-1273	Chamber As	319-3434
2S-4015	Plunger As-Valve	311-9438
3D-4343	Chain-Tandem Dr	394-0214

64C		
Original Part Number	**Part Name**	**Classic Part Number**
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2229	Cage-Bearing	229-1598
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4M-0410	Gear-Oil Pump Dr	428-6660
5D-4799	Bearing-Roller	416-2160
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5D-9906	Shaft-Axle	228-9413
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665

64C		
Original Part Number	**Part Name**	**Classic Part Number**
6B-3158	Shoe-Yoke Lh	243-0357
6B-6224	Ferrule	419-4738
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
7H-6967	Bearing-Ball	422-6489
7M-1154	Bearing-Spl	417-4515
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7S-7809	Cap As-Radiator	295-6417
8D-5344	Gear-Worm	243-0341
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
9B-1320	Valve-Check	377-5832
9L-2685	Rod End	419-1866
108-5603	Screw-Adj Arm	379-0166

78E		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1S-1970	Chamber As	247-3292
1S-3743	Bearing-Ball	384-4786
1T-0210	Bearing-Ball	417-4498
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-6421	Bearing-Outer	417-4510
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354

78E		
Original Part Number	**Part Name**	**Classic Part Number**
2H-3517	Bearing-Inner	417-4505
2S-4015	Plunger As-Valve	311-9438
3D-4343	Chain-Tandem Dr	394-0214
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2229	Cage-Bearing	229-1598
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6926	Segment-Control	228-9455

78E		
Original Part Number	**Part Name**	**Classic Part Number**
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4M-0410	Gear-Oil Pump Dr	428-6660
5D-4799	Bearing-Roller	416-2160
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5D-9906	Shaft-Axle	228-9413
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665
6B-3158	Shoe-Yoke Lh	243-0357
6B-6224	Ferrule	419-4738
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160

Sales Model 14B (Cont'd.)

78E		
Original Part Number	**Part Name**	**Classic Part Number**
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
7M-1154	Bearing-Spl	417-4515
7M-4603	Body-Fuel Valve	311-9348

78E		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7S-7809	Cap As-Radiator	295-6417

78E		
Original Part Number	**Part Name**	**Classic Part Number**
8D-5344	Gear-Worm	243-0341
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
9B-1320	Valve-Check	377-5832
108-5603	Screw-Adj Arm	379-0166

Sales Model 14C

35F		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1M-0090	Gasket-Manifold	445-7701
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-6341	Pin	330-9273
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633

35F		
Original Part Number	**Part Name**	**Classic Part Number**
4K-3150	Pin	385-3788
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
6F-6992	Cap-Ballsocket	297-7160
6V-2202	Bearing-Spl Ball	380-1574
7M-4046	Bearing-Sleeve	394-8206
7M-7358	Valve-Inlet	298-2774
7N-0128	Core As-Oil Clr	299-1994
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
8N-8221	Bearing-Conn Rod	419-6377

35F		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
9H-2256	Pump Gp-F Prm	311-9443
9M-5477	Bearing-Sleeve	374-6517
169-4200	Gasket	472-8023
232-3233	Bearing-Main	376-9085

Sales Model 14D

96F		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1M-0090	Gasket-Manifold	445-7701
1M-5270	Pipe-Extension	367-6065
1P-1367	Plunger-Valve	432-8913
1S-3743	Bearing-Ball	384-4786

96F		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7073	Rebuild Kt-Pump	383-3677
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488

96F		
Original Part Number	**Part Name**	**Classic Part Number**
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354

Sales Model 14D (Cont'd.)

96F		
Original Part Number	**Part Name**	**Classic Part Number**
2H-3517	Bearing-Inner	417-4505
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
3D-4343	Chain-Tandem Dr	394-0214
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3S-5017	Elbow-Exhaust	369-9498
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633

96F		
Original Part Number	**Part Name**	**Classic Part Number**
4K-3150	Pin	385-3788
4T-8054	Seal As	472-8010
5D-4799	Bearing-Roller	416-2160
5D-9906	Shaft-Axle	228-9413
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5H-7071	Director-Water	388-0555
5L-7632	Support-Elbow	433-9854
5M-2824	Coupling-Exhaust	431-5270
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-9080	Pulley-Alt Drive	264-5883
6B-6224	Ferrule	419-4738
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7M-1154	Bearing-Spl	417-4515
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7N-0128	Core As-Oil Clr	299-1994

96F		
Original Part Number	**Part Name**	**Classic Part Number**
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
8D-5344	Gear-Worm	243-0341
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-4955	Pump Gp-F Tfr	242-3443
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166
169-4200	Gasket	472-8023
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085

Sales Model 14E

12K		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296

12K		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913

12K		
Original Part Number	**Part Name**	**Classic Part Number**
1P-4303	Head As-Cylinder	242-3434
1P-8554	Coupling-Exhaust	325-6052

Sales Model 14E (Cont'd.)

12K		
Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As-Fan	296-1344
1S-0057	Plate-Clutch	377-7404
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1W-3900	Gasket	472-8006
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2G-2858	Cap-Pivot	243-0345
2G-7464	Insert-Bolt	386-4918
2H-3517	Bearing-Inner	417-4505
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1757	Hub-Fan Pulley	296-1357
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-5608	Pipe-Extension	367-6066
2P-5609	Muffler As.	247-2665
2P-6128	Pulley	264-5872
2P-7830	Pump Gp	314-8533
2S-6097	Tang	375-9979

12K		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
3D-4343	Chain-Tandem Dr	394-0214
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3J-9325	Piston	390-0993
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3V-4046	Plate-Pressure	380-7470
4B-1455	Cap As-Filler	361-1719
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4F-2041	Cup-Roller Brg	418-9609
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4N-4864	Pump Gp-F Tfr	242-3442
4N-7693	Crankshaft As	269-8763
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
5D-4799	Bearing-Roller	416-2160
5D-9906	Shaft-Axle	228-9413
5H-0047	Disc-Cl Drive	388-0576
5L-6326	Bearing-Ball	420-3222
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247

12K		
Original Part Number	Part Name	Classic Part Number
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-8367	Strip-Wear	297-7263
6D-1734	Cup-Roller Brg	416-2171
6D-2348	Disc-Friction	380-7489
6D-5415	Plate	382-8043
6D-6859	Bearing	330-9248
6D-8671	Bolt-Draft	243-0333
6F-6992	Cap-Ballsocket	297-7160
6G-1919	Cap-Pivot	243-0337
6H-3957	Bearing-Ball	311-9358
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7C-4297	Seal As-Cshaft	325-6192
7D-1945	Gear-Worm	469-4668
7D-4519	Shaft	245-5807
7D-4523	Coupling	245-5817
7D-5859	Adapter	297-7136
7D-5861	Adapter	243-0364
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2957	Cover-Rad Cap	361-1722

Sales Model 14E (Cont'd.)

12K		
Original Part Number	Part Name	Classic Part Number
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-5344	Gear-Worm	243-0341
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

12K		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
9D-2716	Spindle-Wheel	228-9463
9F-3212	Bearing-Ball	384-5953
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558

12K		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
236-8675	Disc-Friction	428-7202
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005

72G		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368

Sales Model 14E (Cont'd.)

72G		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1W-3900	Gasket	472-8006
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2G-2858	Cap-Pivot	243-0345
2G-7464	Insert-Bolt	386-4918
2H-3517	Bearing-Inner	417-4505
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
2K-9295	Bearing-Cone	422-6480
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

72G		
Original Part Number	Part Name	Classic Part Number
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-5608	Pipe-Extension	367-6066
2P-5609	Muffler As.	247-2665
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3B-4124	Cup-Spl Tapered	422-6481
3D-4343	Chain-Tandem Dr	394-0214
3D-4718	Bearing-Sleeve	245-5795
3H-8726	Mount As	385-7208
3J-9325	Piston	390-0993
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-8393	Plate-Clutch	388-0592
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4F-2041	Cup-Roller Brg	418-9609
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4M-1641	Dowel-Reaction	386-4952
4N-4864	Pump Gp-F Tfr	242-3442
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236

72G		
Original Part Number	Part Name	Classic Part Number
4S-6707	Piston-Clutch	215-1686
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
5D-4799	Bearing-Roller	416-2160
5D-9906	Shaft-Axle	228-9413
5H-0047	Disc-Cl Drive	388-0576
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-8367	Strip-Wear	297-7263
6B-7469	Spacer	417-4535
6D-1734	Cup-Roller Brg	416-2171
6D-2348	Disc-Friction	380-7489

Sales Model 14E (Cont'd.)

72G		
Original Part Number	Part Name	Classic Part Number
6D-5415	Plate	382-8043
6D-6859	Bearing	330-9248
6D-8671	Bolt-Draft	243-0333
6F-6992	Cap-Ballsocket	297-7160
6G-1919	Cap-Pivot	243-0337
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7C-4297	Seal As-Cshaft	325-6192
7D-1945	Gear-Worm	469-4668
7D-4519	Shaft	245-5807
7D-4523	Coupling	245-5817
7D-5859	Adapter	297-7136
7D-5861	Adapter	243-0364
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995

72G		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-5344	Gear-Worm	243-0341
8F-6058	Bearing-Sleeve	416-5494
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-8623	Gear-Sun	213-8755
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564

72G		
Original Part Number	Part Name	Classic Part Number
8N-3183	Piston Gp-Basic	250-6556
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
9D-2716	Spindle-Wheel	228-9463
9F-3212	Bearing-Ball	384-5953
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756

Sales Model 14E (Cont'd.)

72G		
Original Part Number	Part Name	Classic Part Number
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042

72G		
Original Part Number	Part Name	Classic Part Number
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314

72G		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420

99G		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1M-0090	Gasket-Manifold	445-7701
1P-1367	Plunger-Valve	432-8913
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1W-7073	Rebuild Kt-Pump	383-3677
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2G-2858	Cap-Pivot	243-0345
2G-7464	Insert-Bolt	386-4918
2H-3517	Bearing-Inner	417-4505
2K-4507	Bearing-Sleeve	325-6021

99G		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
3D-4343	Chain-Tandem Dr	394-0214
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3S-5017	Elbow-Exhaust	369-9498
4B-1455	Cap As-Filler	361-1719
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4F-2041	Cup-Roller Brg	418-9609

99G		
Original Part Number	Part Name	Classic Part Number
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4T-8054	Seal As	472-8010
5D-4799	Bearing-Roller	416-2160
5D-9906	Shaft-Axle	228-9413
5H-0047	Disc-Cl Drive	388-0576
5H-7071	Director-Water	388-0555
5L-7632	Support-Elbow	433-9854
5M-5856	Pipe-Extension	373-1913
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
6B-6224	Ferrule	419-4738
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6D-8671	Bolt-Draft	243-0333
6F-6992	Cap-Ballsocket	297-7160
6G-1919	Cap-Pivot	243-0337
6V-2202	Bearing-Spl Ball	380-1574

Motor Graders

Sales Model 14E (Cont'd.)

99G		
Original Part Number	**Part Name**	**Classic Part Number**
7D-4519	Shaft	245-5807
7D-4523	Coupling	245-5817
7D-5861	Adapter	243-0364
7E-5085	Bushing	377-5829
7M-1154	Bearing-Spl	417-4515
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7N-0128	Core As-Oil Clr	299-1994
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656

99G		
Original Part Number	**Part Name**	**Classic Part Number**
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
8D-5344	Gear-Worm	243-0341
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739

99G		
Original Part Number	**Part Name**	**Classic Part Number**
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-2685	Rod End	419-1866
9M-4789	Shaft-Gov Cont	297-7256
9M-4955	Pump Gp-F Tfr	242-3443
9M-5477	Bearing-Sleeve	374-6517
9T-5096	Flexplate	455-3271
108-5603	Screw-Adj Arm	379-0166
169-4200	Gasket	472-8023
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
308-1845	Seal-Wiper	472-8032

Sales Model 14G

03L		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1B-5675	Bearing	377-7396
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3958	Bearing-Needle	434-6114
1P-4693	Cup-Rlr Bearing	377-7398
1P-5480	Cover As.-End	299-1998
1S-3062	Director-Water	418-9572
1U-2738	Piston Assembly	367-6074
1U-4661	Lever Gp	396-7267
1W-1219	Trunnion As	314-8724

03L		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2F-5721	Bearing-Ball	311-9354

03L		
Original Part Number	**Part Name**	**Classic Part Number**
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3645	Pump Gp-Gr 2 Bsc	450-2389
2P-4363	Housing-Clutch	391-9833
2P-4426	Shaft As-Planet	384-3478
2P-4429	Shaft As-Planet	384-4828

Sales Model 14G (Cont'd.)

03L		
Original Part Number	Part Name	Classic Part Number
2P-4431	Gear-Ring	394-9832
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-5769	Coupling	394-9812
2P-5774	Gear As-Oil Pump	428-6659
2P-6245	Shaft As-Pump	325-6197
2P-7032	Spacer-Bearing	396-4138
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3D-9126	Cup-Roller Brg	399-4435
3G-6910	Bearing-Plate	419-4733
3P-0801	Plate-Clutch	383-2119
3P-0894	Shaft As-Planet	302-3446
3P-0895	Bearing-Spl Ball	394-9184
3P-1609	Carrier-Planet	302-4292
3P-1619	Gear-Transfer	468-5017
3P-1624	Flange As	468-5018
3P-1651	Piston As	302-4296
3P-1691	Housing As	432-5219
3P-1697	Coupling	390-0911
3P-2852	Clutch-Hub	301-4902
3P-2854	Shaft As-Clutch	416-2127
3P-2855	Plate-Clutch	377-7422
3P-2863	Gear-Idler	399-6044
3P-2865	Shaft As-Idler	393-1056
3P-3424	Shaft	416-5526
3P-5955	Disc-Friction	428-7205
3P-7042	Housing-Clutch	390-0912
3T-2095	Bearing-Sleeve	384-3459

03L		
Original Part Number	Part Name	Classic Part Number
4B-7270	Cone-Bearing	399-4439
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8670	Shaft-Planet	300-2590
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-0470	Valve Gp-Qrel	314-8549
5F-7404	Nut-Bearing Lock	308-9878
5M-5018	Bearing-Roller	380-7509
5P-3490	Cone-Rlr Bearing	380-7518
5P-8768	Kit-Gasket (Scl)	393-1024

03L		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5T-0925	Actuator Gp-Bk	379-0198
5T-7130	Housing	396-0656
6B-7469	Spacer	417-4535
6D-8671	Bolt-Draft	243-0333
6G-8425	Valve Gp-Cont -K	367-6086
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8088	Bearing-Roller	399-4428
6N-0622	Elbow-Exhaust	380-7534
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-2090	Base-Xmsn O Fil	397-5049
6T-1235	Gasket	433-8190
6V-2202	Bearing-Spl Ball	380-1574
6Y-0306	Bearing-Sleeve	391-1104
6Y-0576	Support As	416-5531
6Y-0579	Coupling	434-9636
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655

Sales Model 14G (Cont'd.)

03L		
Original Part Number	Part Name	Classic Part Number
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-3453	Gear-Planet	377-7444
7G-3454	Gear-Planet	300-2578
7G-3455	Gear-Planet	300-2582
7G-3456	Gear-Planet	300-2583
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2834	Kit-Repair	374-4723
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-9647	Piston-Clutch	275-5294
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8D-1648	Disc	367-6070
8D-2452	Gear-Sun	394-8233
8D-2459	Gear-Planet	390-5293
8D-2519	Shaft-Planet	300-2591

03L		
Original Part Number	Part Name	Classic Part Number
8D-2528	Shaft-Drive	394-9829
8D-2878	Ring-Wear	330-9282
8D-4942	Housing As	392-4514
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-1616	Lever	330-9271
8J-1624	Valve As	390-0997
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377

03L		
Original Part Number	Part Name	Classic Part Number
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1656	Plate-Clutch	367-6071
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-0328	Cylinder-Damper	419-4715
9D-1491	Coupling	416-2121
9D-5741	Worm-Circle Dr	297-7270
9D-5746	Gear-Worm	299-2011
9D-5921	Shaft-Dr Pinion	297-7254
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
030-0060	Bearing-Cup	415-1926

Sales Model 14G (Cont'd.)

03L		
Original Part Number	Part Name	Classic Part Number
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
105-3196	Motor Gp-Grtr	282-6547
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
131-3815	Seal Gp-Basic	325-6193
135-0524	Piston-Clutch	380-7402
141-6136	Socket Gp	333-4953
141-6137	Socket Gp	325-6212
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3311	Spindle-Wheel	469-8102
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125

03L		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6820	Bearing-Sleeve	387-2903
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

03L		
Original Part Number	Part Name	Classic Part Number
206-5794	Gear-Sun	394-8233
221-9755	Gear-Planet	390-5293
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6558	Liner Kit-Cla	295-6438
252-5650	Rim As	397-5067
260-7799	Pinion-Circ Dr	367-6094
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

96U		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504

96U		
Original Part Number	Part Name	Classic Part Number
1P-5480	Cover As.-End	299-1998
1P-7115	Mount As	418-1936
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1U-2738	Piston Assembly	367-6074
1U-4661	Lever Gp	396-7267
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

96U		
Original Part Number	Part Name	Classic Part Number
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-5838	Shaft	425-6452
2G-6285	Valve Kt	383-1570

Sales Model 14G (Cont'd.)

96U		
Original Part Number	**Part Name**	**Classic Part Number**
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-7464	Insert-Bolt	386-4918
2G-8609	Pin	319-3450
2G-8610	Pin	389-6316
2G-8630	Pin	389-6304
2G-8631	Bearing-Sleeve	391-9811
2G-8639	Bearing-Sleeve	380-7560
2G-8735	Pin	391-1105
2G-8739	Retainer	389-6314
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
2M-8714	Cone-Roller Brg	420-2492
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3645	Pump Gp-Gr 2 Bsc	450-2389
2P-4363	Housing-Clutch	391-9833
2P-4426	Shaft As-Planet	384-3478
2P-4429	Shaft As-Planet	384-4828
2P-4431	Gear-Ring	394-9832
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-4611	Pipe-Exhaust	365-8821
2P-5608	Pipe-Extension	367-6066
2P-5609	Muffler As.	247-2665
2P-5769	Coupling	394-9812

96U		
Original Part Number	**Part Name**	**Classic Part Number**
2P-5774	Gear As-Oil Pump	428-6659
2P-6245	Shaft As-Pump	325-6197
2P-7032	Spacer-Bearing	396-4138
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3D-9126	Cup-Roller Brg	399-4435
3G-2580	Bearing-Sleeve	422-9526
3G-6910	Bearing-Plate	419-4733
3L-1425	Bearing-Ball	311-9356
3P-0165	Pulley-Fan Drive	298-2775
3P-0801	Plate-Clutch	383-2119
3P-0894	Shaft As-Planet	302-3446
3P-0895	Bearing-Spl Ball	394-9184
3P-1609	Carrier-Planet	302-4292
3P-1619	Gear-Transfer	468-5017
3P-1624	Flange As	468-5018
3P-1651	Piston As	302-4296
3P-1691	Housing As	432-5219
3P-1697	Coupling	390-0911
3P-2852	Clutch-Hub	301-4902
3P-2854	Shaft As-Clutch	416-2127
3P-2855	Plate-Clutch	377-7422
3P-2863	Gear-Idler	399-6044
3P-2865	Shaft As-Idler	393-1056
3P-3424	Shaft	416-5526
3P-5955	Disc-Friction	428-7205
3P-7042	Housing-Clutch	390-0912
3T-2095	Bearing-Sleeve	384-3459

96U		
Original Part Number	**Part Name**	**Classic Part Number**
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-2619	Bearing	417-4494
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4K-8561	Pin	299-2036
4K-8734	Bearing-Sleeve	299-1962
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984

Sales Model 14G (Cont'd.)

96U		
Original Part Number	Part Name	Classic Part Number
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4S-8670	Shaft-Planet	300-2590
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-0470	Valve Gp-Qrel	314-8549
5F-7404	Nut-Bearing Lock	308-9878
5J-7010	Seal As	472-8011
5L-6326	Bearing-Ball	420-3222
5L-9656	Cone-Bearing	399-4448
5M-5018	Bearing-Roller	380-7509
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0925	Actuator Gp-Bk	379-0198
5T-5222	Shoe-Circle Gde	297-7261

96U		
Original Part Number	Part Name	Classic Part Number
5T-7130	Housing	396-0656
5T-8365	Strip-Wear	380-7418
6B-7469	Spacer	417-4535
6D-4909	Cap-Pivot	297-7159
6D-8671	Bolt-Draft	243-0333
6E-0775	Head	425-9373
6G-4372	Strip-Wear	380-7416
6G-4524	Strip-Wear	380-7417
6G-4642	Shim	434-1863
6G-4680	Adapter	302-2633
6G-4831	Shaft	391-9809
6G-8425	Valve Gp-Cont -K	367-6086
6G-9430	Bracket	418-1938
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0622	Elbow-Exhaust	380-7534
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-2090	Base-Xmsn O Fil	397-5049
6T-1235	Gasket	433-8190
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
6Y-0306	Bearing-Sleeve	391-1104
6Y-0576	Support As	416-5531
6Y-0579	Coupling	434-9636
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-5859	Adapter	297-7136

96U		
Original Part Number	Part Name	Classic Part Number
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-3453	Gear-Planet	377-7444
7G-3454	Gear-Planet	300-2578
7G-3455	Gear-Planet	300-2582
7G-3456	Gear-Planet	300-2583
7J-3351	Head	380-1515
7J-8295	Head	388-0566
7J-8893	Cone-Roller Brg	374-1846
7J-9708	Bearing-Sleeve	299-1964
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724

Sales Model 14G (Cont'd.)

96U		
Original Part Number	Part Name	Classic Part Number
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7T-9647	Piston-Clutch	275-5294
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8D-0983	Mounting	384-3470
8D-1648	Disc	367-6070
8D-1833	Pin	364-5269
8D-2351	Pin	297-7217
8D-2452	Gear-Sun	394-8233
8D-2459	Gear-Planet	390-5293
8D-2519	Shaft-Planet	300-2591
8D-2528	Shaft-Drive	394-9829
8D-2878	Ring-Wear	330-9282
8D-3997	Pin As	389-6302
8D-4673	Pin-Cylinder	302-2711
8D-4942	Housing As	392-4514
8D-7083	Bearing	386-4930
8D-7086	Bearing	330-9251
8D-7719	Spider & Brg As	384-5946
8D-9159	Bearing-Sleeve	472-8019
8D-9973	Housing	391-9825
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-1616	Lever	330-9271
8J-1624	Valve As	390-0997
8M-3368	Valve-Check	388-6599
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196

96U		
Original Part Number	Part Name	Classic Part Number
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

96U		
Original Part Number	Part Name	Classic Part Number
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1656	Plate-Clutch	367-6071
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-1622	Gasket Kit - Sch	436-8388
8T-7047	Gasket Kit	384-5952
8W-0328	Cylinder-Damper	419-4715
8W-3589	Link As-Spring	380-7389
8W-4167	Bearing-Sleeve	361-1694
8W-5293	Pin	282-6570
8W-8512	Pin As	385-7220
8W-9566	Flange As	376-9073
8X-5425	Guide As-Hose	432-4222
8X-8067	Mounting	394-0205
9B-1320	Valve-Check	377-5832
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2252	Insert	385-6139
9D-5741	Worm-Circle Dr	297-7270
9D-5746	Gear-Worm	299-2011
9D-5921	Shaft-Dr Pinion	297-7254
9D-7924	Mount As	360-2356
9D-9967	Washer-Thrust	389-6323

Sales Model 14G (Cont'd.)

96U		
Original Part Number	Part Name	Classic Part Number
9F-3212	Bearing-Ball	384-5953
9M-1853	Mount As.	376-3638
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9T-8944	Cyl Gp-102 356 Y	393-3665
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
002-1212	Cup-Roller Brg	399-4446
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
104-7238	Plate	380-7404
105-0017	Cylinder	416-2130
105-3196	Motor Gp-Grtr	282-6547
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
127-3365	Joint Gp-Slip	367-6067
131-3815	Seal Gp-Basic	325-6193

96U		
Original Part Number	Part Name	Classic Part Number
134-4200	Manifold-Exhaust	443-2060
135-0524	Piston-Clutch	380-7402
141-6136	Socket Gp	333-4953
141-6137	Socket Gp	325-6212
141-6138	Socket Gp	325-6213
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3311	Spindle-Wheel	469-8102
148-7455	Valve - Exhaust	270-4361
151-5349	Head	383-1592
155-1379	Gasket Kit - Sch	386-3815
164-6560	Body As-Piston	477-7125
165-2495	Cyl Gp-0064-0292	399-8562
165-2496	Cyl Gp-0064-0292	399-8568
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
170-0560	Rebuild Kit-Pump	363-7458
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

96U		
Original Part Number	Part Name	Classic Part Number
172-6712	Impeller-Pump	325-6112
172-7772	Pump Gp-Water -B	438-2009
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
174-6820	Bearing-Sleeve	387-2903
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-5794	Gear-Sun	394-8233
221-9755	Gear-Planet	390-5293
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
247-7143	Yoke	451-9025
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
252-5650	Rim As	397-5067
255-2899	Pipe As-Tail	301-5246
260-7799	Pinion-Circ Dr	367-6094
262-4339	Kit-Dt Gasket	451-1509
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
275-2316	Kit-Dt Bearing	464-9066
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
319-2229	Shoe-Circle Gde	396-7288
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

7WJ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434

7WJ		
Original Part Number	**Part Name**	**Classic Part Number**
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8610	Pin	389-6316
2G-8630	Pin	389-6304
2G-8631	Bearing-Sleeve	391-9811
2G-8639	Bearing-Sleeve	380-7560
2G-8735	Pin	391-1105
2G-8739	Retainer	389-6314
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
2M-8714	Cone-Roller Brg	420-2492
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4363	Housing-Clutch	391-9833
2P-4426	Shaft As-Planet	384-3478
2P-4429	Shaft As-Planet	384-4828
2P-4431	Gear-Ring	394-9832
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-5769	Coupling	394-9812
2P-6245	Shaft As-Pump	325-6197
2P-7032	Spacer-Bearing	396-4138

7WJ		
Original Part Number	**Part Name**	**Classic Part Number**
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3D-9126	Cup-Roller Brg	399-4435
3G-2580	Bearing-Sleeve	422-9526
3L-1425	Bearing-Ball	311-9356
3P-0801	Plate-Clutch	383-2119
3P-0894	Shaft As-Planet	302-3446
3P-0895	Bearing-Spl Ball	394-9184
3P-1609	Carrier-Planet	302-4292
3P-1619	Gear-Transfer	468-5017
3P-1624	Flange As	468-5018
3P-1651	Piston As	302-4296
3P-1691	Housing As	432-5219
3P-1697	Coupling	390-0911
3P-2852	Clutch-Hub	301-4902
3P-2854	Shaft As-Clutch	416-2127
3P-2855	Plate-Clutch	377-7422
3P-2863	Gear-Idler	399-6044
3P-2865	Shaft As-Idler	393-1056
3P-3424	Shaft	416-5526
3P-5955	Disc-Friction	428-7205
3P-7042	Housing-Clutch	390-0912
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7463	Seal-Lip Type	472-8007

Sales Model 14H (Cont'd.)

7WJ		
Original Part Number	Part Name	Classic Part Number
4K-7467	Bearing As-Rlr	380-1500
4K-8561	Pin	299-2036
4K-8734	Bearing-Sleeve	299-1962
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-9325	Pulley-Alt Drive	419-4657
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4S-8670	Shaft-Planet	300-2590
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5D-0470	Valve Gp-Qrel	314-8549
5F-7404	Nut-Bearing Lock	308-9878
5L-9656	Cone-Bearing	399-4448
5M-5018	Bearing-Roller	380-7509
5P-3490	Cone-Rlr Bearing	380-7518

7WJ		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5P-9568	Gasket Kit	393-3625
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0925	Actuator Gp-Bk	379-0198
5T-7130	Housing	396-0656
5T-8365	Strip-Wear	380-7418
6B-7469	Spacer	417-4535
6E-0775	Head	425-9373
6G-4372	Strip-Wear	380-7416
6G-4524	Strip-Wear	380-7417
6G-4642	Shim	434-1863
6G-4680	Adapter	302-2633
6G-4831	Shaft	391-9809
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0597	Pulley-Fan	420-6391
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-2090	Base-Xmsn O Fil	397-5049
6T-1235	Gasket	433-8190
6V-2202	Bearing-Spl Ball	380-1574
6Y-0306	Bearing-Sleeve	391-1104
6Y-0576	Support As	416-5531
6Y-0579	Coupling	434-9636

7WJ		
Original Part Number	Part Name	Classic Part Number
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-3453	Gear-Planet	377-7444
7G-3454	Gear-Planet	300-2578
7G-3455	Gear-Planet	300-2582
7G-3456	Gear-Planet	300-2583
7I-5399	Shaft	421-8178
7J-8893	Cone-Roller Brg	374-1846
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-9647	Piston-Clutch	275-5294
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935

Sales Model 14H (Cont'd.)

7WJ		
Original Part Number	Part Name	Classic Part Number
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1648	Disc	367-6070
8D-2452	Gear-Sun	394-8233
8D-2459	Gear-Planet	390-5293
8D-2519	Shaft-Planet	300-2591
8D-2528	Shaft-Drive	394-9829
8D-3997	Pin As	389-6302
8D-4673	Pin-Cylinder	302-2711
8D-4942	Housing As	392-4514
8D-7719	Spider & Brg As	384-5946
8D-9159	Bearing-Sleeve	472-8019
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8M-3368	Valve-Check	388-6599
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5884	Pulley-Fan Drive	416-5500
8N-5929	Cover-Water Pump	296-1349

7WJ		
Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1656	Plate-Clutch	367-6071
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1624	Lever	299-2019
8W-4167	Bearing-Sleeve	361-1694
8W-5293	Pin	282-6570
8W-8512	Pin As	385-7220
8W-9566	Flange As	376-9073
8X-5425	Guide As-Hose	432-4222
8X-8067	Mounting	394-0205
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2252	Insert	385-6139
9D-5921	Shaft-Dr Pinion	297-7254
9D-7924	Mount As	360-2356
9L-5908	Gasket	433-8196
9M-1853	Mount As.	376-3638
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6147	Body As	369-9499

7WJ		
Original Part Number	Part Name	Classic Part Number
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-5729	Cyl Gp-0038 0158	422-2486
9T-8944	Cyl Gp-102 356 Y	393-3665
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-7238	Plate	380-7404
105-0017	Cylinder	416-2130
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
113-9098	Pin	425-6447
113-9099	Pin	425-3449
127-3365	Joint Gp-Slip	367-6067
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3036	Gasket Kit	393-3629
134-3038	Gasket Kit	437-3228
134-4200	Manifold-Exhaust	443-2060
135-0524	Piston-Clutch	380-7402
141-6136	Socket Gp	333-4953
141-6137	Socket Gp	325-6212
142-0228	Gasket Kit - Sch	393-1035
144-0502	Ring Kit-Piston	395-1312

Sales Model 14H (Cont'd.)

7WJ		
Original Part Number	Part Name	Classic Part Number
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3311	Spindle-Wheel	469-8102
148-7455	Valve - Exhaust	270-4361
151-5349	Head	383-1592
164-6560	Body As-Piston	477-7125
165-2495	Cyl Gp-0064-0292	399-8562
165-2496	Cyl Gp-0064-0292	399-8568
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

7WJ		
Original Part Number	Part Name	Classic Part Number
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6820	Bearing-Sleeve	387-2903
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-5794	Gear-Sun	394-8233
221-9755	Gear-Planet	390-5293
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
247-7143	Yoke	451-9025
252-5650	Rim As	397-5067
262-4339	Kit-Dt Gasket	451-1509

7WJ		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
275-2316	Kit-Dt Bearing	464-9066
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
319-2229	Shoe-Circle Gde	396-7288
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

ASE		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1W-6810	Pipe-Outlet	472-8036
2A-4429	Lock-Retainer	379-0174

ASE		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8630	Pin	389-6304
2G-8631	Bearing-Sleeve	391-9811
2G-8639	Bearing-Sleeve	380-7560
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
2M-8714	Cone-Roller Brg	420-2492
2P-4363	Housing-Clutch	391-9833
2P-4426	Shaft As-Planet	384-3478

ASE		
Original Part Number	Part Name	Classic Part Number
2P-4429	Shaft As-Planet	384-4828
2P-4431	Gear-Ring	394-9832
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-7032	Spacer-Bearing	396-4138
2S-5100	Valve-Ball	386-3049
3D-9126	Cup-Roller Brg	399-4435
3G-2580	Bearing-Sleeve	422-9526
3P-0801	Plate-Clutch	383-2119
3P-0894	Shaft As-Planet	302-3446
3P-0895	Bearing-Spl Ball	394-9184
3P-1609	Carrier-Planet	302-4292
3P-1624	Flange As	468-5018
3P-1651	Piston As	302-4296
3P-1691	Housing As	432-5219
3P-1697	Coupling	390-0911

Sales Model 14H (Cont'd.)

ASE		
Original Part Number	**Part Name**	**Classic Part Number**
3P-2852	Clutch-Hub	301-4902
3P-2854	Shaft As-Clutch	416-2127
3P-2855	Plate-Clutch	377-7422
3P-2865	Shaft As-Idler	393-1056
3P-3424	Shaft	416-5526
3P-5955	Disc-Friction	428-7205
3P-7042	Housing-Clutch	390-0912
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4K-8734	Bearing-Sleeve	299-1962
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4S-8472	Hood As-Preclnr	296-1355
4S-8670	Shaft-Planet	300-2590
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5D-0470	Valve Gp-Qrel	314-8549
5F-7404	Nut-Bearing Lock	308-9878
5M-5018	Bearing-Roller	380-7509
5P-3490	Cone-Rlr Bearing	380-7518
5T-0925	Actuator Gp-Bk	379-0198
5T-7130	Housing	396-0656
5T-8365	Strip-Wear	380-7418
6E-0775	Head	425-9373
6G-4372	Strip-Wear	380-7416

ASE		
Original Part Number	**Part Name**	**Classic Part Number**
6G-4524	Strip-Wear	380-7417
6G-4642	Shim	434-1863
6G-4680	Adapter	302-2633
6G-4831	Shaft	391-9809
6I-1240	Governor As	380-7538
6L-7751	Rod End-Spher	472-8015
6P-2090	Base-Xmsn O Fil	397-5049
6T-1235	Gasket	433-8190
6V-3831	Seal-O-Ring	436-2657
6Y-0306	Bearing-Sleeve	391-1104
6Y-0576	Support As	416-5531
6Y-0579	Coupling	434-9636
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-3453	Gear-Planet	377-7444
7G-3454	Gear-Planet	300-2578
7G-3455	Gear-Planet	300-2582
7G-3456	Gear-Planet	300-2583
7J-8893	Cone-Roller Brg	374-1846
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-7435	Kit-Major Repair	374-4724
7T-9647	Piston-Clutch	275-5294
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8D-1648	Disc	367-6070
8D-2452	Gear-Sun	394-8233
8D-2459	Gear-Planet	390-5293
8D-2519	Shaft-Planet	300-2591
8D-2528	Shaft-Drive	394-9829
8D-3997	Pin As	389-6302
8D-4673	Pin-Cylinder	302-2711
8D-4942	Housing As	392-4514

ASE		
Original Part Number	**Part Name**	**Classic Part Number**
8D-7719	Spider & Brg As	384-5946
8D-9159	Bearing-Sleeve	472-8019
8D-9973	Housing	391-9825
8H-9789	Bearing-Ball	374-8342
8P-1656	Plate-Clutch	367-6071
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4167	Bearing-Sleeve	361-1694
8W-5293	Pin	282-6570
8W-8512	Pin As	385-7220
8W-9566	Flange As	376-9073
8X-5425	Guide As-Hose	432-4222
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2252	Insert	385-6139
9D-5921	Shaft-Dr Pinion	297-7254
9D-7924	Mount As	360-2356
9M-1853	Mount As.	376-3638
9T-5729	Cyl Gp-0038 0158	422-2486
9T-8944	Cyl Gp-102 356 Y	393-3665
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
104-7238	Plate	380-7404
111-2645	Valve-Pump Byp	441-1561
113-9098	Pin	425-6447
113-9099	Pin	425-3449
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259

Sales Model 14H (Cont'd.)

ASE		
Original Part Number	Part Name	Classic Part Number
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
127-3365	Joint Gp-Slip	367-6067
141-6136	Socket Gp	333-4953
141-6137	Socket Gp	325-6212
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3311	Spindle-Wheel	469-8102
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
151-5349	Head	383-1592
165-2495	Cyl Gp-0064-0292	399-8562

ASE		
Original Part Number	Part Name	Classic Part Number
165-2496	Cyl Gp-0064-0292	399-8568
166-6352	Tube As.	432-4223
174-6820	Bearing-Sleeve	387-2903
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
206-5794	Gear-Sun	394-8233
216-4781	Gasket Kit	437-8144

ASE		
Original Part Number	Part Name	Classic Part Number
221-9755	Gear-Planet	390-5293
226-8202	Seal-Wiper	472-8024
247-7143	Yoke	451-9025
252-5650	Rim As	397-5067
262-4339	Kit-Dt Gasket	451-1509
275-2316	Kit-Dt Bearing	464-9066
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
315-6671	Kit-Gasket(Op)	438-0139
319-2229	Shoe-Circle Gde	396-7288
319-3607	Kit-Gasket(Rs)	438-0137
352-2077	Pump Gp-Water -B	434-6108

Sales Model 14L

B94		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-1034	Valve-Safety	380-7555
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667

B94		
Original Part Number	Part Name	Classic Part Number
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
6B-3223	Cup-Bearing	399-6065
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639

B94		
Original Part Number	Part Name	Classic Part Number
7D-8437	Cone-Roller Brg	380-1502
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-6324	Kit-Wear Strip	424-0739
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
105-3196	Motor Gp-Grtr	282-6547
115-4072	Bearing	397-5069
143-7356	Bearing As	380-1483

Motor Graders

Sales Model 14L (Cont'd.)

B94		
Original Part Number	**Part Name**	**Classic Part Number**
148-2593	Head	383-1591
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461

B94		
Original Part Number	**Part Name**	**Classic Part Number**
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028

B94		
Original Part Number	**Part Name**	**Classic Part Number**
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032

Sales Model 14M

B9J		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3937	Cup-Roller Brg	377-7394
1B-4038	Cup-Roller Brg	423-6988
1B-4043	Cone-Roller Brg	377-7395
1H-4478	Pin	330-9272
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-6516	Bearing As-Rlr	435-2572
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259

B9J		
Original Part Number	**Part Name**	**Classic Part Number**
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
3G-2580	Bearing-Sleeve	422-9526
3J-2333	Bearing-Sleeve	422-9525
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4K-8734	Bearing-Sleeve	299-1962
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4V-3044	Plate-Lock	308-9911
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3495	Collar	383-2129
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-3929	Bearing As-Rlr	416-2163
5P-3490	Cone-Rlr Bearing	380-7518

B9J		
Original Part Number	**Part Name**	**Classic Part Number**
5T-8365	Strip-Wear	380-7418
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6G-4680	Adapter	302-2633
6G-4831	Shaft	391-9809
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7G-0437	Plate-Clutch	417-9466
7J-2604	Bearing-Sleeve	380-7369
7J-5131	Trunnion	296-1371
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7T-8816	Bearing-Spl Ball	420-2491
7V-0638	Spacer	425-3651
8D-1817	Cup-Roller Brg	434-3296
8D-2256	Cone-Roller Brg	374-1848
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8H-9789	Bearing-Ball	374-8342
8J-5654	Bearing-Sleeve	325-6028
8J-5778	Bearing-Sleeve	374-8359
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4167	Bearing-Sleeve	361-1694
8W-8512	Pin As	385-7220
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9D-2252	Insert	385-6139

Sales Model 14M (Cont'd.)

B9J		
Original Part Number	Part Name	Classic Part Number
9D-5921	Shaft-Dr Pinion	297-7254
9D-7924	Mount As	360-2356
9K-1171	Cup-Rlr Bearing	430-3339
9M-4370	Bearing-Sleeve	453-6515
9T-8944	Cyl Gp-102 356 Y	393-3665
9W-9930	Mount As	295-6437

B9J		
Original Part Number	Part Name	Classic Part Number
002-1212	Cup-Roller Brg	399-4446
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-3125	Gasket	420-8567
104-7238	Plate	380-7404
105-3196	Motor Gp-Grtr	282-6547

B9J		
Original Part Number	Part Name	Classic Part Number
105-8735	Gear-Diff Bevel	416-2154
132-6597	Cone-Spl	422-6477
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032

E9S		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350

E9S		
Original Part Number	Part Name	Classic Part Number
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
3G-2580	Bearing-Sleeve	422-9526
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4K-8734	Bearing-Sleeve	299-1962
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
5P-3490	Cone-Rlr Bearing	380-7518
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6G-4831	Shaft	391-9809
6Y-9960	Mount As.	376-3639
7G-0437	Plate-Clutch	417-9466
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7T-8816	Bearing-Spl Ball	420-2491

E9S		
Original Part Number	Part Name	Classic Part Number
8D-9159	Bearing-Sleeve	472-8019
8H-9789	Bearing-Ball	374-8342
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4167	Bearing-Sleeve	361-1694
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9D-2252	Insert	385-6139
9M-4370	Bearing-Sleeve	453-6515
9T-8944	Cyl Gp-102 356 Y	393-3665
9W-9930	Mount As	295-6437
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
127-5537	Core As-Oclr	325-6045
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032

N9S		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272

N9S		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535

Sales Model 14M (Cont'd.)

N9S		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3935	Cone-Roller Brg	377-7397
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-4507	Bearing-Sleeve	325-6021

N9S		
Original Part Number	**Part Name**	**Classic Part Number**
2K-6413	Pin	360-2270
3G-2580	Bearing-Sleeve	422-9526
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4K-8734	Bearing-Sleeve	299-1962
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
5P-3490	Cone-Rlr Bearing	380-7518
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6G-4372	Strip-Wear	380-7416
6G-4831	Shaft	391-9809
6Y-9960	Mount As.	376-3639
7G-0437	Plate-Clutch	417-9466
7J-5131	Trunnion	296-1371
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816

N9S		
Original Part Number	**Part Name**	**Classic Part Number**
8D-9159	Bearing-Sleeve	472-8019
8H-9789	Bearing-Ball	374-8342
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4167	Bearing-Sleeve	361-1694
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9D-2252	Insert	385-6139
9M-4370	Bearing-Sleeve	453-6515
9T-8944	Cyl Gp-102 356 Y	393-3665
9W-9930	Mount As	295-6437
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
127-5537	Core As-Oclr	325-6045
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032

R9J		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3937	Cup-Roller Brg	377-7394
1B-4038	Cup-Roller Brg	423-6988
1B-4043	Cone-Roller Brg	377-7395
1H-4478	Pin	330-9272
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399

R9J		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-6516	Bearing As-Rlr	435-2572
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7387	Bearing-Sleeve	330-9258

R9J		
Original Part Number	**Part Name**	**Classic Part Number**
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
3G-2580	Bearing-Sleeve	422-9526
3J-2333	Bearing-Sleeve	422-9525
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633

Sales Model 14M (Cont'd.)

R9J		
Original Part Number	Part Name	Classic Part Number
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4K-8734	Bearing-Sleeve	299-1962
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4V-3044	Plate-Lock	308-9911
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3495	Collar	383-2129
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-3929	Bearing As-Rlr	416-2163
5P-3490	Cone-Rlr Bearing	380-7518
5T-8365	Strip-Wear	380-7418
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6G-4680	Adapter	302-2633
6G-4831	Shaft	391-9809
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639

R9J		
Original Part Number	Part Name	Classic Part Number
7G-0437	Plate-Clutch	417-9466
7J-2604	Bearing-Sleeve	380-7369
7J-5131	Trunnion	296-1371
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7T-8816	Bearing-Spl Ball	420-2491
7V-0638	Spacer	425-3651
8D-1817	Cup-Roller Brg	434-3296
8D-2256	Cone-Roller Brg	374-1848
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8H-9789	Bearing-Ball	374-8342
8J-5654	Bearing-Sleeve	325-6028
8J-5778	Bearing-Sleeve	374-8359
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4167	Bearing-Sleeve	361-1694
8W-8512	Pin As	385-7220
8W-9566	Flange As	376-9073

R9J		
Original Part Number	Part Name	Classic Part Number
9D-1491	Coupling	416-2121
9D-2252	Insert	385-6139
9D-5921	Shaft-Dr Pinion	297-7254
9D-7924	Mount As	360-2356
9K-1171	Cup-Rlr Bearing	430-3339
9M-4370	Bearing-Sleeve	453-6515
9T-8944	Cyl Gp-102 356 Y	393-3665
9W-9930	Mount As	295-6437
002-1212	Cup-Roller Brg	399-4446
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-3125	Gasket	420-8567
104-7238	Plate	380-7404
105-3196	Motor Gp-Grtr	282-6547
105-8735	Gear-Diff Bevel	416-2154
132-6597	Cone-Spl	422-6477
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032

S9J		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174

S9J		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-1034	Valve-Safety	380-7555
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-4507	Bearing-Sleeve	325-6021

S9J		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
3G-2580	Bearing-Sleeve	422-9526
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4K-8734	Bearing-Sleeve	299-1962
4N-2514	Gear-Flywheel	421-7283

Motor Graders

Sales Model 14M (Cont'd.)

S9J		
Original Part Number	**Part Name**	**Classic Part Number**
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5P-3490	Cone-Rlr Bearing	380-7518
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6G-4831	Shaft	391-9809
6Y-9960	Mount As.	376-3639
7G-0437	Plate-Clutch	417-9466
7K-8877	Cone-Bearing	374-1847
7T-8816	Bearing-Spl Ball	420-2491
8D-9159	Bearing-Sleeve	472-8019

S9J		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4167	Bearing-Sleeve	361-1694
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9D-2252	Insert	385-6139
9M-4370	Bearing-Sleeve	453-6515
9T-8944	Cyl Gp-102 356 Y	393-3665
9W-9930	Mount As	295-6437

S9J		
Original Part Number	**Part Name**	**Classic Part Number**
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-3125	Gasket	420-8567
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032

Sales Model 14N

N9X		
Original Part Number	**Part Name**	**Classic Part Number**
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
3G-2580	Bearing-Sleeve	422-9526

N9X		
Original Part Number	**Part Name**	**Classic Part Number**
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633

N9X		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-9960	Mount As.	376-3639
9W-9930	Mount As	295-6437

Sales Model 16

49G		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296
1M-8776	Bearing-Roller	417-4516
1P-1367	Plunger-Valve	432-8913
1S-0057	Plate-Clutch	377-7404
1S-1888	Bracket-Lamp	297-7147
1T-0299	Cup-Roller Brg	422-6494
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488

49G		
Original Part Number	**Part Name**	**Classic Part Number**
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-6341	Pin	330-9273
2D-6421	Bearing-Outer	417-4510
2F-5721	Bearing-Ball	311-9354
2G-7464	Insert-Bolt	386-4918
2H-3517	Bearing-Inner	417-4505
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532

49G		
Original Part Number	**Part Name**	**Classic Part Number**
2M-8340	Rod End-Yoke	374-4678
2P-3839	Crankshaft As	398-2968
2S-0479	Bearing-Cone	380-7506
2S-3966	Ring-Seal	297-7237
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
3F-4971	Pin	295-5693
3G-2717	Cartridge Gp	439-1132
3G-2720	Cartridge Gp-Rr	448-5051
3G-2749	Cartridge Gp-Rr	422-8125

Sales Model 16 (Cont'd.)

49G		
Original Part Number	Part Name	Classic Part Number
3G-7653	Cartridge Gp	422-8099
3H-8726	Mount As	385-7208
3J-2333	Bearing-Sleeve	422-9525
3K-4290	Rod End	374-1823
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3V-4046	Plate-Pressure	380-7470
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4J-1612	Pin	308-9896
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5F-8651	Bearing-Ball	420-3223
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5M-7925	Bearing-Roller	419-7774
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5S-1211	Cover-Valve	314-8665

49G		
Original Part Number	Part Name	Classic Part Number
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-6619	Shoe-Circle Gde	468-9792
5T-6620	Shoe-Circle Gde	424-4943
5T-8365	Strip-Wear	380-7418
6D-4671	Ballstud	420-6530
6D-4909	Cap-Pivot	297-7159
6D-8671	Bolt-Draft	243-0333
6G-4372	Strip-Wear	380-7416
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6N-9211	Core As-O Clr	435-6049
6N-9653	Core As-Oil Clr	386-3056
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7D-5859	Adapter	297-7136
7D-5861	Adapter	243-0364
7E-5085	Bushing	377-5829
7G-2496	Gear-Planet	446-3071
7H-6967	Bearing-Ball	422-6489
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281

49G		
Original Part Number	Part Name	Classic Part Number
7W-2138	Bearing-Main	419-7250
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8M-0874	Plunger As-Valve	311-9439
8N-4445	Pipe-Exhaust Ext	386-3061
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3517	Bearing-Spl Ball	417-4501
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-6782	Adapter-Exhaust	383-1586
8S-9686	Gasket Kit	393-5215
8W-9566	Flange As	376-9073
9F-3212	Bearing-Ball	384-5953
9M-1328	Bearing-Aligning	325-6018
9M-8395	Bearing-Sleeve	391-1103
9S-5746	Ferrule-Seal	392-4493
9T-5096	Flexplate	455-3271
121-7746	Pre-Cleaner As	360-2311
128-3935	Bearing-Race	396-9897
130-6856	Pre-Cleaner As	361-1717
162-3904	Pump As-F Prm	391-1102
226-8202	Seal-Wiper	472-8024
236-8675	Disc-Friction	428-7202
308-1845	Seal-Wiper	472-8032

Sales Model 16G

93U		
Original Part Number	Part Name	Classic Part Number
1B-3937	Cup-Roller Brg	377-7394

Sales Model 16G (Cont'd.)

93U		
Original Part Number	Part Name	Classic Part Number
1B-4043	Cone-Roller Brg	377-7395
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-7895	Cone-Roller Brg	396-4145
1P-9945	Bracket As-Fan	296-1344
1U-2738	Piston Assembly	367-6074
1U-4661	Lever Gp	396-7267
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2D-6516	Bearing As-Rlr	435-2572
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-6339	Hub-Brake	430-7621
2G-7759	Cage As	399-8574
2G-8083	Pin	393-3666

93U		
Original Part Number	Part Name	Classic Part Number
2G-8084	Pin	392-4531
2G-8623	Pin	393-3675
2G-8735	Pin	391-1105
2G-8739	Retainer	389-6314
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1757	Hub-Fan Pulley	296-1357
2P-3645	Pump Gp-Gr 2 Bsc	450-2389
2P-4363	Housing-Clutch	391-9833
2P-4426	Shaft As-Planet	384-3478
2P-4429	Shaft As-Planet	384-4828
2P-4431	Gear-Ring	394-9832
2P-4433	Gear-Ring	384-4787
2P-4440	Gear	434-4386
2P-4510	Piston-Clutch	275-5293
2P-4611	Pipe-Exhaust	365-8821
2P-5769	Coupling	394-9812
2P-5774	Gear As-Oil Pump	428-6659
2P-7032	Spacer-Bearing	396-4138
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2W-3391	Body As-F Inj V	383-3687
2W-5540	Core As-Radiator	363-7452
2W-7455	Gear As	396-9957
2W-7933	Core As-O Clr	374-4708
3D-9126	Cup-Roller Brg	399-4435
3E-6772	Seal-Water	382-8017
3G-2580	Bearing-Sleeve	422-9526
3G-6910	Bearing-Plate	419-4733

93U		
Original Part Number	Part Name	Classic Part Number
3G-7600	Cyl Gp-076 314 U	422-4936
3H-8726	Mount As	385-7208
3J-2333	Bearing-Sleeve	422-9525
3L-1425	Bearing-Ball	311-9356
3P-0801	Plate-Clutch	383-2119
3P-0894	Shaft As-Planet	302-3446
3P-0895	Bearing-Spl Ball	394-9184
3P-1609	Carrier-Planet	302-4292
3P-1619	Gear-Transfer	468-5017
3P-1624	Flange As	468-5018
3P-1651	Piston As	302-4296
3P-1691	Housing As	432-5219
3P-1697	Coupling	390-0911
3P-2852	Clutch-Hub	301-4902
3P-2854	Shaft As-Clutch	416-2127
3P-2855	Plate-Clutch	377-7422
3P-2863	Gear-Idler	399-6044
3P-2865	Shaft As-Idler	393-1056
3P-3424	Shaft	416-5526
3P-5955	Disc-Friction	428-7205
3P-7042	Housing-Clutch	390-0912
3T-2095	Bearing-Sleeve	384-3459
3Y-2768	Ring	439-4544
4B-1455	Cap As-Filler	361-1719
4D-2619	Bearing	417-4494
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509

Sales Model 16G (Cont'd.)

93U		
Original Part Number	Part Name	Classic Part Number
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4577	Muffler As.	308-9877
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4N-9325	Pulley-Alt Drive	419-4657
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355
4S-8670	Shaft-Planet	300-2590
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-3044	Plate-Lock	308-9911
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219

93U		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5J-7010	Seal As	472-8011
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3495	Collar	383-2129
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-3929	Bearing As-Rlr	416-2163
5L-9656	Cone-Bearing	399-4448
5M-5018	Bearing-Roller	380-7509
5P-7807	Bearing-Ball	314-8502
5P-8053	Kit-Gasket (Sch)	415-1901
5P-8366	Gasket Kit - Sch	387-2911
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-6619	Shoe-Circle Gde	468-9792
5T-6620	Shoe-Circle Gde	424-4943
5T-8365	Strip-Wear	380-7418
6E-0775	Head	425-9373
6G-4372	Strip-Wear	380-7416
6G-4524	Strip-Wear	380-7417
6G-4642	Shim	434-1863
6G-4680	Adapter	302-2633
6G-4831	Shaft	391-9809
6G-8425	Valve Gp-Cont -K	367-6086
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1931	Plunger	379-0171

93U		
Original Part Number	Part Name	Classic Part Number
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6P-2090	Base-Xmsn O Fil	397-5049
6T-1235	Gasket	433-8190
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-0306	Bearing-Sleeve	391-1104
6Y-0576	Support As	416-5531
6Y-0579	Coupling	434-9636
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7G-3453	Gear-Planet	377-7444
7G-3454	Gear-Planet	300-2578
7G-3455	Gear-Planet	300-2582
7G-3456	Gear-Planet	300-2583
7J-2604	Bearing-Sleeve	380-7369
7J-3351	Head	380-1515
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8893	Cone-Roller Brg	374-1846

Sales Model 16G (Cont'd.)

93U		
Original Part Number	Part Name	Classic Part Number
7J-9708	Bearing-Sleeve	299-1964
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-1220	Plunger As-Pump	419-4743
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-8371	Line As-Fuel Inj	373-1901
7N-8923	Muffler As	416-5499
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-9647	Piston-Clutch	275-5294
7W-0140	Gear-Drive	399-8546
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8C-5704	Gasket Kit - Sch	393-1027
8D-0983	Mounting	384-3470
8D-1634	Retainer	416-5533
8D-1648	Disc	367-6070
8D-1651	Cover	396-7279
8D-1669	Gear-Sun	418-9596
8D-1671	Gear-Planet	416-2155
8D-1817	Cup-Roller Brg	434-3296
8D-1833	Pin	364-5269
8D-2256	Cone-Roller Brg	374-1848
8D-2277	Gear	399-4431
8D-2351	Pin	297-7217
8D-2423	Shaft-Drive	394-8221
8D-4278	Spacer	435-6048

93U		
Original Part Number	Part Name	Classic Part Number
8D-4675	Pin-Cylinder	391-9863
8D-7719	Spider & Brg As	384-5946
8D-8233	Retainer	399-4429
8D-8572	Bearing-Sleeve	380-7384
8D-8587	Gear-Transfer	398-8352
8D-9457	Gear-Diff	430-9000
8D-9973	Housing	391-9825
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-1616	Lever	330-9271
8J-1624	Valve As	390-0997
8J-5654	Bearing-Sleeve	325-6028
8J-5778	Bearing-Sleeve	374-8359
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8N-1184	Elbow-Exhaust	392-4497
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-5884	Pulley-Fan Drive	416-5500
8N-8258	Bearing-Sleeve	452-1077
8P-1656	Plate-Clutch	367-6071
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-7047	Gasket Kit	384-5952
8W-0328	Cylinder-Damper	419-4715
8W-2309	Shaft-Planet	392-4504
8W-3589	Link As-Spring	380-7389
8W-4167	Bearing-Sleeve	361-1694

93U		
Original Part Number	Part Name	Classic Part Number
8W-5293	Pin	282-6570
8W-5296	Pin	438-2017
8W-6493	Pin	395-1320
8W-6494	Pin	391-9902
8W-7452	Housing	416-2141
8W-8512	Pin As	385-7220
8X-5425	Guide As-Hose	432-4222
8X-8067	Mounting	394-0205
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-7924	Mount As	360-2356
9F-3212	Bearing-Ball	384-5953
9K-1171	Cup-Rlr Bearing	430-3339
9L-5839	Coupling-Exhaust	374-7480
9M-1853	Mount As.	376-3638
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-5529	Body-F Inj Valve	378-3993
9T-2852	Cylinder As-Lh	423-7869
9T-3055	Cylinder As	430-5962
9T-4761	Head	325-6108
9T-8944	Cyl Gp-102 356 Y	393-3665
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
002-1212	Cup-Roller Brg	399-4446
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691

Sales Model 16G (Cont'd.)

93U		
Original Part Number	Part Name	Classic Part Number
101-3125	Gasket	420-8567
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
104-7238	Plate	380-7404
105-0017	Cylinder	416-2130
105-3196	Motor Gp-Grtr	282-6547
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-3365	Joint Gp-Slip	367-6067
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589

93U		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
133-8890	Race	399-4423
135-0524	Piston-Clutch	380-7402
135-4928	Shaft-Water Pump	386-3813
141-6136	Socket Gp	333-4953
141-6137	Socket Gp	325-6212
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
151-5349	Head	383-1592
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-5212	Rod As	399-8575
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700

93U		
Original Part Number	Part Name	Classic Part Number
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
226-8202	Seal-Wiper	472-8024
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
234-1874	Kit-Gasket-Fs	437-8668
247-7143	Yoke	451-9025
253-1752	Plate-Thrust	379-0170
255-2899	Pipe As-Tail	301-5246
262-4339	Kit-Dt Gasket	451-1509
275-2316	Kit-Dt Bearing	464-9066
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
319-2229	Shoe-Circle Gde	396-7288
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812

Sales Model 16H

3JR		
Original Part Number	Part Name	Classic Part Number
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395
1B-5675	Bearing	377-7396
1P-1367	Plunger-Valve	432-8913

3JR		
Original Part Number	Part Name	Classic Part Number
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399

3JR		
Original Part Number	Part Name	Classic Part Number
1P-7895	Cone-Roller Brg	396-4145
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356

Sales Model 16H (Cont'd.)

3JR		
Original Part Number	Part Name	Classic Part Number
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2D-6516	Bearing As-Rlr	435-2572
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-6339	Hub-Brake	430-7621
2G-7759	Cage As	399-8574
2L-5271	Bearing-Ball	371-4305
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2N-5842	Screw-Bridge Adj	418-1934
2P-4363	Housing-Clutch	391-9833
2P-4426	Shaft As-Planet	384-3478
2P-4429	Shaft As-Planet	384-4828
2P-4431	Gear-Ring	394-9832
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-5769	Coupling	394-9812
2P-7032	Spacer-Bearing	396-4138
2S-5100	Valve-Ball	386-3049
2W-5540	Core As-Radiator	363-7452
2W-7455	Gear As	396-9957
3D-9126	Cup-Roller Brg	399-4435
3E-6772	Seal-Water	382-8017
3J-2333	Bearing-Sleeve	422-9525
3P-0801	Plate-Clutch	383-2119
3P-0894	Shaft As-Planet	302-3446

3JR		
Original Part Number	Part Name	Classic Part Number
3P-0895	Bearing-Spl Ball	394-9184
3P-1609	Carrier-Planet	302-4292
3P-1619	Gear-Transfer	468-5017
3P-1624	Flange As	468-5018
3P-1651	Piston As	302-4296
3P-1691	Housing As	432-5219
3P-1697	Coupling	390-0911
3P-2852	Clutch-Hub	301-4902
3P-2854	Shaft As-Clutch	416-2127
3P-2855	Plate-Clutch	377-7422
3P-2863	Gear-Idler	399-6044
3P-2865	Shaft As-Idler	393-1056
3P-3424	Shaft	416-5526
3P-5955	Disc-Friction	428-7205
3P-7042	Housing-Clutch	390-0912
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-6649	Muffler As	416-5527
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355

3JR		
Original Part Number	Part Name	Classic Part Number
4S-8670	Shaft-Planet	300-2590
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5K-3929	Bearing As-Rlr	416-2163
5M-5018	Bearing-Roller	380-7509
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
6I-1240	Governor As	380-7538
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6K-8088	Bearing-Roller	399-4428
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6P-2090	Base-Xmsn O Fil	397-5049
6T-1235	Gasket	433-8190
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-0306	Bearing-Sleeve	391-1104
6Y-0576	Support As	416-5531
6Y-0579	Coupling	434-9636
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265

Sales Model 16H (Cont'd.)

3JR		
Original Part Number	Part Name	Classic Part Number
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7G-3453	Gear-Planet	377-7444
7G-3454	Gear-Planet	300-2578
7G-3455	Gear-Planet	300-2582
7G-3456	Gear-Planet	300-2583
7J-2604	Bearing-Sleeve	380-7369
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7T-9647	Piston-Clutch	275-5294
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-1634	Retainer	416-5533
8D-1648	Disc	367-6070

3JR		
Original Part Number	Part Name	Classic Part Number
8D-1651	Cover	396-7279
8D-1669	Gear-Sun	418-9596
8D-1671	Gear-Planet	416-2155
8D-1817	Cup-Roller Brg	434-3296
8D-2256	Cone-Roller Brg	374-1848
8D-2277	Gear	399-4431
8D-2423	Shaft-Drive	394-8221
8D-4278	Spacer	435-6048
8D-8233	Retainer	399-4429
8D-8587	Gear-Transfer	398-8352
8D-9457	Gear-Diff	430-9000
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8M-3368	Valve-Check	388-6599
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8P-1656	Plate-Clutch	367-6071
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-2309	Shaft-Planet	392-4504
8W-7452	Housing	416-2141
9D-1491	Coupling	416-2121
9K-1171	Cup-Rlr Bearing	430-3339
9L-5839	Coupling-Exhaust	374-7480
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
002-1212	Cup-Roller Brg	399-4446
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926

3JR		
Original Part Number	Part Name	Classic Part Number
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
105-3196	Motor Gp-Grtr	282-6547
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-3365	Joint Gp-Slip	367-6067
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
133-8890	Race	399-4423
135-0524	Piston-Clutch	380-7402
135-4928	Shaft-Water Pump	386-3813
138-6743	Gasket Kit	437-3223
138-6744	Rebuild Kit-Pump	363-7457
141-6136	Socket Gp	333-4953

Sales Model 16H (Cont'd.)

3JR		
Original Part Number	Part Name	Classic Part Number
141-6137	Socket Gp	325-6212
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956

3JR		
Original Part Number	Part Name	Classic Part Number
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
201-5243	Kit-Gasket(F)	437-2019
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368

3JR		
Original Part Number	Part Name	Classic Part Number
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3679	Kit-Gasket (Rs)	437-2039
234-1874	Kit-Gasket-Fs	437-8668
247-7143	Yoke	451-9025
253-1752	Plate-Thrust	379-0170
290-2060	Kit-Gasket-Sch	438-0149
307-1961	Plate	472-8031
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812

6ZJ		
Original Part Number	Part Name	Classic Part Number
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7115	Mount As	418-1936
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-7895	Cone-Roller Brg	396-4145
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174

6ZJ		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-6516	Bearing As-Rlr	435-2572
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-6339	Hub-Brake	430-7621
2G-7759	Cage As	399-8574
2G-8083	Pin	393-3666
2G-8084	Pin	392-4531
2G-8623	Pin	393-3675
2G-8735	Pin	391-1105
2G-8739	Retainer	389-6314
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2N-5842	Screw-Bridge Adj	418-1934

6ZJ		
Original Part Number	Part Name	Classic Part Number
2P-1757	Hub-Fan Pulley	296-1357
2P-4363	Housing-Clutch	391-9833
2P-4426	Shaft As-Planet	384-3478
2P-4429	Shaft As-Planet	384-4828
2P-4431	Gear-Ring	394-9832
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-5769	Coupling	394-9812
2P-7032	Spacer-Bearing	396-4138
2S-5100	Valve-Ball	386-3049
2W-5540	Core As-Radiator	363-7452
2W-7455	Gear As	396-9957
3D-9126	Cup-Roller Brg	399-4435
3E-6772	Seal-Water	382-8017
3G-2580	Bearing-Sleeve	422-9526
3H-8726	Mount As	385-7208
3J-2333	Bearing-Sleeve	422-9525
3L-1425	Bearing-Ball	311-9356
3P-0801	Plate-Clutch	383-2119

Sales Model 16H (Cont'd.)

6ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
3P-0894	Shaft As-Planet	302-3446
3P-0895	Bearing-Spl Ball	394-9184
3P-1609	Carrier-Planet	302-4292
3P-1619	Gear-Transfer	468-5017
3P-1624	Flange As	468-5018
3P-1651	Piston As	302-4296
3P-1691	Housing As	432-5219
3P-1697	Coupling	390-0911
3P-2852	Clutch-Hub	301-4902
3P-2854	Shaft As-Clutch	416-2127
3P-2855	Plate-Clutch	377-7422
3P-2863	Gear-Idler	399-6044
3P-2865	Shaft As-Idler	393-1056
3P-3424	Shaft	416-5526
3P-5955	Disc-Friction	428-7205
3P-7042	Housing-Clutch	390-0912
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4N-9325	Pulley-Alt Drive	419-4657
4P-2383	Adapter-Inlet	438-1812

6ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
4P-6649	Muffler As	416-5527
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355
4S-8670	Shaft-Planet	300-2590
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-3044	Plate-Lock	308-9911
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5J-7010	Seal As	472-8011
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3495	Collar	383-2129
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-3929	Bearing As-Rlr	416-2163
5L-9656	Cone-Bearing	399-4448
5M-5018	Bearing-Roller	380-7509
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-8365	Strip-Wear	380-7418
6E-0775	Head	425-9373
6G-4372	Strip-Wear	380-7416
6G-4524	Strip-Wear	380-7417

6ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
6G-4642	Shim	434-1863
6G-4680	Adapter	302-2633
6G-4831	Shaft	391-9809
6I-1240	Governor As	380-7538
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6P-2090	Base-Xmsn O Fil	397-5049
6T-1235	Gasket	433-8190
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-0306	Bearing-Sleeve	391-1104
6Y-0576	Support As	416-5531
6Y-0579	Coupling	434-9636
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488

Sales Model 16H (Cont'd.)

6ZJ		
Original Part Number	Part Name	Classic Part Number
7G-3453	Gear-Planet	377-7444
7G-3454	Gear-Planet	300-2578
7G-3455	Gear-Planet	300-2582
7G-3456	Gear-Planet	300-2583
7I-5399	Shaft	421-8178
7J-2604	Bearing-Sleeve	380-7369
7J-8893	Cone-Roller Brg	374-1846
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7T-9647	Piston-Clutch	275-5294
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-1634	Retainer	416-5533
8D-1648	Disc	367-6070
8D-1651	Cover	396-7279
8D-1669	Gear-Sun	418-9596
8D-1671	Gear-Planet	416-2155
8D-1817	Cup-Roller Brg	434-3296
8D-2256	Cone-Roller Brg	374-1848
8D-2277	Gear	399-4431
8D-2423	Shaft-Drive	394-8221
8D-4278	Spacer	435-6048
8D-4675	Pin-Cylinder	391-9863
8D-7719	Spider & Brg As	384-5946
8D-8233	Retainer	399-4429
8D-8572	Bearing-Sleeve	380-7384
8D-8587	Gear-Transfer	398-8352
8D-9457	Gear-Diff	430-9000

6ZJ		
Original Part Number	Part Name	Classic Part Number
8D-9973	Housing	391-9825
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-5654	Bearing-Sleeve	325-6028
8J-5778	Bearing-Sleeve	374-8359
8M-3368	Valve-Check	388-6599
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-5305	Spacer	363-7464
8N-5884	Pulley-Fan Drive	416-5500
8N-8258	Bearing-Sleeve	452-1077
8P-1656	Plate-Clutch	367-6071
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-2309	Shaft-Planet	392-4504
8W-4167	Bearing-Sleeve	361-1694
8W-5293	Pin	282-6570
8W-5296	Pin	438-2017
8W-6493	Pin	395-1320
8W-6494	Pin	391-9902
8W-7452	Housing	416-2141
8W-8512	Pin As	385-7220
8X-5425	Guide As-Hose	432-4222
8X-8067	Mounting	394-0205
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-7924	Mount As	360-2356
9K-1171	Cup-Rlr Bearing	430-3339
9L-5839	Coupling-Exhaust	374-7480
9M-1853	Mount As.	376-3638
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9T-2852	Cylinder As-Lh	423-7869
9T-3055	Cylinder As	430-5962

6ZJ		
Original Part Number	Part Name	Classic Part Number
9T-8944	Cyl Gp-102 356 Y	393-3665
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
002-1212	Cup-Roller Brg	399-4446
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
104-7238	Plate	380-7404
105-0017	Cylinder	416-2130
105-3196	Motor Gp-Grtr	282-6547
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-3365	Joint Gp-Slip	367-6067

Sales Model 16H (Cont'd.)

6ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
133-8890	Race	399-4423
135-0524	Piston-Clutch	380-7402
135-4928	Shaft-Water Pump	386-3813
138-6743	Gasket Kit	437-3223
138-6744	Rebuild Kit-Pump	363-7457
141-6136	Socket Gp	333-4953
141-6137	Socket Gp	325-6212
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
150-4637	Pan-Oil	377-5843
151-5349	Head	383-1592
155-5619	Gasket	382-5054

6ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-5212	Rod As	399-8575
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
201-5243	Kit-Gasket(F)	437-2019
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368

6ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
226-2018	Kit-Gasket-Acl	393-0921
226-8202	Seal-Wiper	472-8024
232-3679	Kit-Gasket (Rs)	437-2039
234-1874	Kit-Gasket-Fs	437-8668
247-7143	Yoke	451-9025
253-1752	Plate-Thrust	379-0170
262-4339	Kit-Dt Gasket	451-1509
275-2316	Kit-Dt Bearing	464-9066
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
290-2060	Kit-Gasket-Sch	438-0149
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
319-2229	Shoe-Circle Gde	396-7288
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812

ATS		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-7895	Cone-Roller Brg	396-4145
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

ATS		
Original Part Number	**Part Name**	**Classic Part Number**
2D-6341	Pin	330-9273
2D-6516	Bearing As-Rlr	435-2572
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-6339	Hub-Brake	430-7621
2G-7759	Cage As	399-8574
2G-8623	Pin	393-3675
2K-4507	Bearing-Sleeve	325-6021
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501

ATS		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1757	Hub-Fan Pulley	296-1357
2P-4363	Housing-Clutch	391-9833
2P-4426	Shaft As-Planet	384-3478
2P-4429	Shaft As-Planet	384-4828
2P-4431	Gear-Ring	394-9832
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-5769	Coupling	394-9812
2P-7032	Spacer-Bearing	396-4138
2S-5100	Valve-Ball	386-3049
2W-5540	Core As-Radiator	363-7452
3D-9126	Cup-Roller Brg	399-4435

Sales Model 16H (Cont'd.)

ATS		
Original Part Number	**Part Name**	**Classic Part Number**
3G-2580	Bearing-Sleeve	422-9526
3J-2333	Bearing-Sleeve	422-9525
3L-1425	Bearing-Ball	311-9356
3P-0801	Plate-Clutch	383-2119
3P-0894	Shaft As-Planet	302-3446
3P-0895	Bearing-Spl Ball	394-9184
3P-1609	Carrier-Planet	302-4292
3P-1624	Flange As	468-5018
3P-1651	Piston As	302-4296
3P-1691	Housing As	432-5219
3P-1697	Coupling	390-0911
3P-2852	Clutch-Hub	301-4902
3P-2854	Shaft As-Clutch	416-2127
3P-2855	Plate-Clutch	377-7422
3P-2865	Shaft As-Idler	393-1056
3P-3424	Shaft	416-5526
3P-5955	Disc-Friction	428-7205
3P-7042	Housing-Clutch	390-0912
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-2514	Gear-Flywheel	421-7283
4N-8434	Spider As-Fan	451-9030
4N-9325	Pulley-Alt Drive	419-4657
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4S-8670	Shaft-Planet	300-2590
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-3044	Plate-Lock	308-9911
5D-0470	Valve Gp-Qrel	314-8549
5J-7010	Seal As	472-8011

ATS		
Original Part Number	**Part Name**	**Classic Part Number**
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3495	Collar	383-2129
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-3929	Bearing As-Rlr	416-2163
5M-5018	Bearing-Roller	380-7509
5T-8365	Strip-Wear	380-7418
6E-0775	Head	425-9373
6G-4372	Strip-Wear	380-7416
6G-4524	Strip-Wear	380-7417
6G-4642	Shim	434-1863
6G-4680	Adapter	302-2633
6G-4831	Shaft	391-9809
6I-1240	Governor As	380-7538
6L-7751	Rod End-Spher	472-8015
6P-2090	Base-Xmsn O Fil	397-5049
6T-1235	Gasket	433-8190
6V-3831	Seal-O-Ring	436-2657
6Y-0306	Bearing-Sleeve	391-1104
6Y-0576	Support As	416-5531
6Y-0579	Coupling	434-9636
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
7D-8636	Cone-Bearing	418-9606
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-3453	Gear-Planet	377-7444
7G-3454	Gear-Planet	300-2578
7G-3455	Gear-Planet	300-2582
7G-3456	Gear-Planet	300-2583
7I-5399	Shaft	421-8178
7J-2604	Bearing-Sleeve	380-7369
7J-8893	Cone-Roller Brg	374-1846
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-7435	Kit-Major Repair	374-4724
7T-9647	Piston-Clutch	275-5294
7W-5164	Gasket	420-8568

ATS		
Original Part Number	**Part Name**	**Classic Part Number**
8D-1634	Retainer	416-5533
8D-1648	Disc	367-6070
8D-1651	Cover	396-7279
8D-1669	Gear-Sun	418-9596
8D-1671	Gear-Planet	416-2155
8D-1817	Cup-Roller Brg	434-3296
8D-2256	Cone-Roller Brg	374-1848
8D-2277	Gear	399-4431
8D-2423	Shaft-Drive	394-8221
8D-4278	Spacer	435-6048
8D-4675	Pin-Cylinder	391-9863
8D-7719	Spider & Brg As	384-5946
8D-8233	Retainer	399-4429
8D-8572	Bearing-Sleeve	380-7384
8D-8587	Gear-Transfer	398-8352
8D-9457	Gear-Diff	430-9000
8D-9973	Housing	391-9825
8H-9789	Bearing-Ball	374-8342
8J-5654	Bearing-Sleeve	325-6028
8J-5778	Bearing-Sleeve	374-8359
8N-5305	Spacer	363-7464
8N-5884	Pulley-Fan Drive	416-5500
8N-7257	Mount As	396-0660
8P-1656	Plate-Clutch	367-6071
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-2309	Shaft-Planet	392-4504
8W-4167	Bearing-Sleeve	361-1694
8W-5293	Pin	282-6570
8W-5296	Pin	438-2017
8W-6493	Pin	395-1320
8W-6494	Pin	391-9902
8W-7452	Housing	416-2141
8W-8512	Pin As	385-7220
8X-5425	Guide As-Hose	432-4222
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-7924	Mount As	360-2356
9D-9665	Bracket-Cyl Mtg	299-1980

Sales Model 16H (Cont'd.)

ATS		
Original Part Number	**Part Name**	**Classic Part Number**
9K-1171	Cup-Rlr Bearing	430-3339
9M-1853	Mount As.	376-3638
9N-3668	Base As.-Coolant	419-4718
9T-2852	Cylinder As-Lh	423-7869
9T-3055	Cylinder As	430-5962
9T-8944	Cyl Gp-102 356 Y	393-3665
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
104-7238	Plate	380-7404
105-3196	Motor Gp-Grtr	282-6547
111-2645	Valve-Pump Byp	441-1561
115-4517	Core As-Oclr	421-7281

ATS		
Original Part Number	**Part Name**	**Classic Part Number**
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
127-3365	Joint Gp-Slip	367-6067
132-6597	Cone-Spl	422-6477
141-6136	Socket Gp	333-4953
141-6137	Socket Gp	325-6212
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
151-5349	Head	383-1592
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223

ATS		
Original Part Number	**Part Name**	**Classic Part Number**
170-5212	Rod As	399-8575
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
226-8202	Seal-Wiper	472-8024
247-7143	Yoke	451-9025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
319-2229	Shoe-Circle Gde	396-7288
352-2077	Pump Gp-Water -B	434-6108

Sales Model 16M

B9H		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395
1H-4478	Pin	330-9272
1P-1367	Plunger-Valve	432-8913
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6516	Bearing As-Rlr	435-2572
2F-8509	Cone-Roller Brg	399-4434

B9H		
Original Part Number	**Part Name**	**Classic Part Number**
2H-6489	Race-Brg Outer	374-8350
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
3G-2580	Bearing-Sleeve	422-9526
3J-2333	Bearing-Sleeve	422-9525
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-3044	Plate-Lock	308-9911
5K-3490	Spacer	308-9933

B9H		
Original Part Number	**Part Name**	**Classic Part Number**
5K-3491	Spacer	308-9934
5K-3495	Collar	383-2129
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-3929	Bearing As-Rlr	416-2163
6E-0775	Head	425-9373
6G-4372	Strip-Wear	380-7416
6G-4680	Adapter	302-2633
6G-4831	Shaft	391-9809
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7G-0437	Plate-Clutch	417-9466
7J-2604	Bearing-Sleeve	380-7369
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335

Sales Model 16M (Cont'd.)

B9H		
Original Part Number	**Part Name**	**Classic Part Number**
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7T-8816	Bearing-Spl Ball	420-2491
8D-1817	Cup-Roller Brg	434-3296
8D-2256	Cone-Roller Brg	374-1848
8D-8572	Bearing-Sleeve	380-7384
8H-9789	Bearing-Ball	374-8342
8J-5654	Bearing-Sleeve	325-6028
8J-5778	Bearing-Sleeve	374-8359
8S-9075	Bearing-Cone	418-9612

B9H		
Original Part Number	**Part Name**	**Classic Part Number**
8S-9076	Cup-Bearing	418-9613
8W-4167	Bearing-Sleeve	361-1694
8W-8512	Pin As	385-7220
9D-1491	Coupling	416-2121
9D-2252	Insert	385-6139
9D-7924	Mount As	360-2356
9K-1171	Cup-Rlr Bearing	430-3339
9M-4370	Bearing-Sleeve	453-6515
9T-8944	Cyl Gp-102 356 Y	393-3665
9W-9930	Mount As	295-6437
002-1212	Cup-Roller Brg	399-4446

B9H		
Original Part Number	**Part Name**	**Classic Part Number**
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
105-3196	Motor Gp-Grtr	282-6547
105-8735	Gear-Diff Bevel	416-2154
132-6597	Cone-Spl	422-6477
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032

E9Y		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395
1H-4478	Pin	330-9272
1P-1367	Plunger-Valve	432-8913
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6516	Bearing As-Rlr	435-2572
2H-6489	Race-Brg Outer	374-8350
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
3G-2580	Bearing-Sleeve	422-9526
3J-2333	Bearing-Sleeve	422-9525
3J-2903	Cover	422-6922
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633

E9Y		
Original Part Number	**Part Name**	**Classic Part Number**
4K-3150	Pin	385-3788
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
5K-3929	Bearing As-Rlr	416-2163
6E-0775	Head	425-9373
6G-4372	Strip-Wear	380-7416
6G-4831	Shaft	391-9809
6Y-9960	Mount As.	376-3639
7G-0437	Plate-Clutch	417-9466
7J-2604	Bearing-Sleeve	380-7369
7K-8877	Cone-Bearing	374-1847
7T-8816	Bearing-Spl Ball	420-2491
8D-1817	Cup-Roller Brg	434-3296
8D-2256	Cone-Roller Brg	374-1848
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8H-9789	Bearing-Ball	374-8342
8J-5654	Bearing-Sleeve	325-6028
8J-5778	Bearing-Sleeve	374-8359
8S-9075	Bearing-Cone	418-9612

E9Y		
Original Part Number	**Part Name**	**Classic Part Number**
8S-9076	Cup-Bearing	418-9613
8W-4167	Bearing-Sleeve	361-1694
9D-1491	Coupling	416-2121
9D-2252	Insert	385-6139
9D-7924	Mount As	360-2356
9K-1171	Cup-Rlr Bearing	430-3339
9M-4370	Bearing-Sleeve	453-6515
9T-8944	Cyl Gp-102 356 Y	393-3665
9W-9930	Mount As	295-6437
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
127-5537	Core As-Oclr	325-6045
132-6597	Cone-Spl	422-6477
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032

Sales Model 16M (Cont'd.)

N9Y		
Original Part Number	Part Name	Classic Part Number
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395
1H-4478	Pin	330-9272
1P-1367	Plunger-Valve	432-8913
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6516	Bearing As-Rlr	435-2572
2H-6489	Race-Brg Outer	374-8350
2K-4507	Bearing-Sleeve	325-6021
3G-2580	Bearing-Sleeve	422-9526
3J-2333	Bearing-Sleeve	422-9525
3J-2903	Cover	422-6922
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633

N9Y		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
5K-3929	Bearing As-Rlr	416-2163
6E-0775	Head	425-9373
6G-4372	Strip-Wear	380-7416
6G-4831	Shaft	391-9809
6Y-9960	Mount As.	376-3639
7G-0437	Plate-Clutch	417-9466
7J-2604	Bearing-Sleeve	380-7369
7K-8877	Cone-Bearing	374-1847
8D-1817	Cup-Roller Brg	434-3296
8D-2256	Cone-Roller Brg	374-1848
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8H-9789	Bearing-Ball	374-8342
8J-5654	Bearing-Sleeve	325-6028
8J-5778	Bearing-Sleeve	374-8359
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613

N9Y		
Original Part Number	Part Name	Classic Part Number
8W-4167	Bearing-Sleeve	361-1694
9D-1491	Coupling	416-2121
9D-2252	Insert	385-6139
9D-7924	Mount As	360-2356
9K-1171	Cup-Rlr Bearing	430-3339
9M-4370	Bearing-Sleeve	453-6515
9T-8944	Cyl Gp-102 356 Y	393-3665
9W-9930	Mount As	295-6437
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
127-5537	Core As-Oclr	325-6045
132-6597	Cone-Spl	422-6477
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032

R9H		
Original Part Number	Part Name	Classic Part Number
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395
1H-4478	Pin	330-9272
1P-1367	Plunger-Valve	432-8913
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6516	Bearing As-Rlr	435-2572
2F-8509	Cone-Roller Brg	399-4434
2H-6489	Race-Brg Outer	374-8350

R9H		
Original Part Number	Part Name	Classic Part Number
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
3G-2580	Bearing-Sleeve	422-9526
3J-2333	Bearing-Sleeve	422-9525
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-3044	Plate-Lock	308-9911
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3495	Collar	383-2129
5K-3499	Pin-Lower	308-9898

R9H		
Original Part Number	Part Name	Classic Part Number
5K-3502	Cap-Lower	308-9835
5K-3929	Bearing As-Rlr	416-2163
6E-0775	Head	425-9373
6G-4372	Strip-Wear	380-7416
6G-4680	Adapter	302-2633
6G-4831	Shaft	391-9809
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7G-0437	Plate-Clutch	417-9466
7J-2604	Bearing-Sleeve	380-7369
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7T-8816	Bearing-Spl Ball	420-2491

Motor Graders

Sales Model 16M (Cont'd.)

R9H		
Original Part Number	**Part Name**	**Classic Part Number**
8D-1817	Cup-Roller Brg	434-3296
8D-2256	Cone-Roller Brg	374-1848
8D-8572	Bearing-Sleeve	380-7384
8H-9789	Bearing-Ball	374-8342
8J-5654	Bearing-Sleeve	325-6028
8J-5778	Bearing-Sleeve	374-8359
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4167	Bearing-Sleeve	361-1694

R9H		
Original Part Number	**Part Name**	**Classic Part Number**
8W-8512	Pin As	385-7220
9D-1491	Coupling	416-2121
9D-2252	Insert	385-6139
9D-7924	Mount As	360-2356
9K-1171	Cup-Rlr Bearing	430-3339
9M-4370	Bearing-Sleeve	453-6515
9T-8944	Cyl Gp-102 356 Y	393-3665
9W-9930	Mount As	295-6437
002-1212	Cup-Roller Brg	399-4446
005-0469	Cup-Rlr Bearing	418-9610

R9H		
Original Part Number	**Part Name**	**Classic Part Number**
005-0471	Cone-Spl Tapered	415-1924
105-3196	Motor Gp-Grtr	282-6547
105-8735	Gear-Diff Bevel	416-2154
132-6597	Cone-Spl	422-6477
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032

Sales Model 18M

E9W		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395
1H-4478	Pin	330-9272
1P-1367	Plunger-Valve	432-8913
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6516	Bearing As-Rlr	435-2572
2H-6489	Race-Brg Outer	374-8350
2K-4507	Bearing-Sleeve	325-6021
3G-2580	Bearing-Sleeve	422-9526
3J-2333	Bearing-Sleeve	422-9525
3J-2903	Cover	422-6922
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633

E9W		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
5K-3929	Bearing As-Rlr	416-2163
6E-0775	Head	425-9373
6G-4372	Strip-Wear	380-7416
6G-4831	Shaft	391-9809
6Y-9960	Mount As.	376-3639
7G-0437	Plate-Clutch	417-9466
7J-2604	Bearing-Sleeve	380-7369
7K-8877	Cone-Bearing	374-1847
7T-8816	Bearing-Spl Ball	420-2491
8D-1817	Cup-Roller Brg	434-3296
8D-2256	Cone-Roller Brg	374-1848
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8H-9789	Bearing-Ball	374-8342
8J-5654	Bearing-Sleeve	325-6028
8J-5778	Bearing-Sleeve	374-8359
8S-9075	Bearing-Cone	418-9612

E9W		
Original Part Number	**Part Name**	**Classic Part Number**
8S-9076	Cup-Bearing	418-9613
8W-4167	Bearing-Sleeve	361-1694
9D-1491	Coupling	416-2121
9D-2252	Insert	385-6139
9D-7924	Mount As	360-2356
9K-1171	Cup-Rlr Bearing	430-3339
9M-4370	Bearing-Sleeve	453-6515
9T-8944	Cyl Gp-102 356 Y	393-3665
9W-9930	Mount As	295-6437
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
127-5537	Core As-Oclr	325-6045
132-6597	Cone-Spl	422-6477
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032

Sales Model 18M (Cont'd.)

N9A		
Original Part Number	Part Name	Classic Part Number
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395
1H-4478	Pin	330-9272
1P-1367	Plunger-Valve	432-8913
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6516	Bearing As-Rlr	435-2572
2H-6489	Race-Brg Outer	374-8350
2K-4507	Bearing-Sleeve	325-6021
3G-2580	Bearing-Sleeve	422-9526
3J-2333	Bearing-Sleeve	422-9525
3J-2903	Cover	422-6922
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633

N9A		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
5K-3929	Bearing As-Rlr	416-2163
6E-0775	Head	425-9373
6G-4372	Strip-Wear	380-7416
6G-4831	Shaft	391-9809
6Y-9960	Mount As.	376-3639
7G-0437	Plate-Clutch	417-9466
7J-2604	Bearing-Sleeve	380-7369
7K-8877	Cone-Bearing	374-1847
8D-1817	Cup-Roller Brg	434-3296
8D-2256	Cone-Roller Brg	374-1848
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8H-9789	Bearing-Ball	374-8342
8J-5654	Bearing-Sleeve	325-6028
8J-5778	Bearing-Sleeve	374-8359
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4167	Bearing-Sleeve	361-1694

N9A		
Original Part Number	Part Name	Classic Part Number
9D-1491	Coupling	416-2121
9D-2252	Insert	385-6139
9D-7924	Mount As	360-2356
9K-1171	Cup-Rlr Bearing	430-3339
9M-4370	Bearing-Sleeve	453-6515
9T-8944	Cyl Gp-102 356 Y	393-3665
9W-9930	Mount As	295-6437
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
127-5537	Core As-Oclr	325-6045
132-6597	Cone-Spl	422-6477
133-4995	Gasket-Cyl Head	434-2445
226-8202	Seal-Wiper	472-8024
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032

Sales Model 112

02M		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2F-5721	Bearing-Ball	311-9354

02M		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
4B-7064	Shaft-Worm	245-5803
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6926	Segment-Control	228-9455
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5T-0735	Chain Gp	390-5262

02M		
Original Part Number	Part Name	Classic Part Number
6B-3158	Shoe-Yoke Lh	243-0357
6B-6224	Ferrule	419-4738
6F-6992	Cap-Ballsocket	297-7160
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7M-1154	Bearing-Spl	417-4515
8B-5972	Bearing-Ball	314-8503
8H-4320	Bearing-Ball	419-2301
8W-9587	Flange As	373-5394
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311

Motor Graders

Sales Model 112 (Cont'd.)

03M		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395
1T-0210	Bearing-Ball	417-4498
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2F-5721	Bearing-Ball	311-9354

03M		
Original Part Number	**Part Name**	**Classic Part Number**
2L-5271	Bearing-Ball	371-4305
4B-7064	Shaft-Worm	245-5803
4D-6664	Coupling-Shaft	243-0338
4D-6926	Segment-Control	228-9455
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5F-8651	Bearing-Ball	420-3223
5T-0735	Chain Gp	390-5262
6B-3158	Shoe-Yoke Lh	243-0357
6B-6224	Ferrule	419-4738
6F-6992	Cap-Ballsocket	297-7160

03M		
Original Part Number	**Part Name**	**Classic Part Number**
7M-1154	Bearing-Spl	417-4515
7T-2036	Cap As-Fuel	361-1721
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8H-4320	Bearing-Ball	419-2301
8W-9587	Flange As	373-5394
9L-2685	Rod End	419-1866
108-5603	Screw-Adj Arm	379-0166

03U		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1S-1967	Chamber As	247-3291
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2H-5080	Gasket Kt-V Gr	438-0180
2S-1273	Chamber As	319-3434
2S-4015	Plunger As-Valve	311-9438
3B-6218	Muffler As	247-2672
3D-4718	Bearing-Sleeve	245-5795
3K-3124	Muffler-Trap	247-2673

03U		
Original Part Number	**Part Name**	**Classic Part Number**
4B-7064	Shaft-Worm	245-5803
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455
4F-2393	Bearing-Ball	380-1499
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5T-0735	Chain Gp	390-5262
6B-3158	Shoe-Yoke Lh	243-0357
6B-6224	Ferrule	419-4738
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918

03U		
Original Part Number	**Part Name**	**Classic Part Number**
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
7H-6967	Bearing-Ball	422-6489
7M-1154	Bearing-Spl	417-4515
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8H-4320	Bearing-Ball	419-2301
8W-6324	Kit-Wear Strip	424-0739
8W-9587	Flange As	373-5394
9B-1320	Valve-Check	377-5832
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

04M		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3924	Cone-Roller Brg	422-6482
1B-3937	Cup-Roller Brg	377-7394

04M		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4043	Cone-Roller Brg	377-7395
2A-4429	Lock-Retainer	379-0174
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822

04M		
Original Part Number	**Part Name**	**Classic Part Number**
2D-5961	Pin-Axle Pivot	228-9438
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
4B-7064	Shaft-Worm	245-5803

Sales Model 112 (Cont'd.)

04M		
Original Part Number	Part Name	Classic Part Number
4D-6664	Coupling-Shaft	243-0338
4D-6926	Segment-Control	228-9455
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5F-8651	Bearing-Ball	420-3223

04M		
Original Part Number	Part Name	Classic Part Number
5H-7071	Director-Water	388-0555
6B-3158	Shoe-Yoke Lh	243-0357
6B-6224	Ferrule	419-4738
6F-6992	Cap-Ballsocket	297-7160
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489

04M		
Original Part Number	Part Name	Classic Part Number
7M-1154	Bearing-Spl	417-4515
8B-5972	Bearing-Ball	314-8503
8H-4320	Bearing-Ball	419-2301
108-5603	Screw-Adj Arm	379-0166

05M		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3924	Cone-Roller Brg	422-6482
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395
1T-0210	Bearing-Ball	417-4498
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438

05M		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
4B-7064	Shaft-Worm	245-5803
4D-6664	Coupling-Shaft	243-0338
4D-6926	Segment-Control	228-9455
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5F-8651	Bearing-Ball	420-3223
6B-3158	Shoe-Yoke Lh	243-0357
6B-6224	Ferrule	419-4738

05M		
Original Part Number	Part Name	Classic Part Number
6F-6992	Cap-Ballsocket	297-7160
7M-1154	Bearing-Spl	417-4515
7T-2036	Cap As-Fuel	361-1721
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8H-4320	Bearing-Ball	419-2301
9L-2685	Rod End	419-1866
108-5603	Screw-Adj Arm	379-0166

68E		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1M-0090	Gasket-Manifold	445-7701
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-3743	Bearing-Ball	384-4786
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2H-3517	Bearing-Inner	417-4505
2L-5271	Bearing-Ball	371-4305

68E		
Original Part Number	Part Name	Classic Part Number
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
3B-6218	Muffler As	247-2672
3D-4718	Bearing-Sleeve	245-5795
3K-3124	Muffler-Trap	247-2673
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2229	Cage-Bearing	229-1598
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455

68E		
Original Part Number	Part Name	Classic Part Number
4F-2393	Bearing-Ball	380-1499
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5H-7071	Director-Water	388-0555
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5T-0735	Chain Gp	390-5262
6B-3158	Shoe-Yoke Lh	243-0357
6B-6224	Ferrule	419-4738
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495

Sales Model 112 (Cont'd.)

68E		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7M-1154	Bearing-Spl	417-4515
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7358	Valve-Inlet	298-2774
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417

68E		
Original Part Number	Part Name	Classic Part Number
7W-1927	Ring-Retainer	387-2935
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083

68E		
Original Part Number	Part Name	Classic Part Number
8N-8229	Bearing-Main	376-9084
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
8W-9587	Flange As	373-5394
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9M-4955	Pump Gp-F Tfr	242-3443
9M-5477	Bearing-Sleeve	374-6517
9S-7534	Pipe-Exh Ext	398-2950
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085

81C		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1S-1970	Chamber As	247-3292
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2H-5080	Gasket Kt-V Gr	438-0180
2S-4015	Plunger As-Valve	311-9438
3B-6218	Muffler As	247-2672
3D-4718	Bearing-Sleeve	245-5795
3K-3124	Muffler-Trap	247-2673
4B-7064	Shaft-Worm	245-5803
4D-4661	Pump Gp-Vn Bsc-A	422-8162

81C		
Original Part Number	Part Name	Classic Part Number
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455
4F-2393	Bearing-Ball	380-1499
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5T-0735	Chain Gp	390-5262
6B-3158	Shoe-Yoke Lh	243-0357
6B-6224	Ferrule	419-4738
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495

81C		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
7M-1154	Bearing-Spl	417-4515
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8H-4320	Bearing-Ball	419-2301
8W-6324	Kit-Wear Strip	424-0739
8W-9587	Flange As	373-5394
9B-1320	Valve-Check	377-5832
9S-7534	Pipe-Exh Ext	398-2950
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

Sales Model 112E

72H		
Original Part Number	Part Name	Classic Part Number
1H-4478	Pin	330-9272
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822

72H		
Original Part Number	Part Name	Classic Part Number
2D-6341	Pin	330-9273
4D-6664	Coupling-Shaft	243-0338
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285

72H		
Original Part Number	Part Name	Classic Part Number
6B-3158	Shoe-Yoke Lh	243-0357
6G-2947	Shaft	243-0346
8W-6324	Kit-Wear Strip	424-0739
226-8202	Seal-Wiper	472-8024

91G		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1H-4478	Pin	330-9272
1M-0090	Gasket-Manifold	445-7701
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-3743	Bearing-Ball	384-4786
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2H-3517	Bearing-Inner	417-4505
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
3B-6218	Muffler As	247-2672
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494

91G		
Original Part Number	Part Name	Classic Part Number
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
5D-4799	Bearing-Roller	416-2160
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5T-0735	Chain Gp	390-5262
6B-3158	Shoe-Yoke Lh	243-0357
6B-6224	Ferrule	419-4738
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6V-2202	Bearing-Spl Ball	380-1574
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-5085	Bushing	377-5829
7M-1154	Bearing-Spl	417-4515

91G		
Original Part Number	Part Name	Classic Part Number
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
9B-1320	Valve-Check	377-5832
9D-2716	Spindle-Wheel	228-9463
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9M-4789	Shaft-Gov Cont	297-7256
9M-4955	Pump Gp-F Tfr	242-3443

Motor Graders

Sales Model 112E (Cont'd.)

91G		
Original Part Number	**Part Name**	**Classic Part Number**
9M-5477	Bearing-Sleeve	374-6517
9S-7534	Pipe-Exh Ext	398-2950

91G		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

91G		
Original Part Number	**Part Name**	**Classic Part Number**
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085

Sales Model 112F

46D		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1H-4478	Pin	330-9272
1M-0090	Gasket-Manifold	445-7701
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2H-3517	Bearing-Inner	417-4505
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
3D-4718	Bearing-Sleeve	245-5795

46D		
Original Part Number	**Part Name**	**Classic Part Number**
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3S-5017	Elbow-Exhaust	369-9498
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
5D-4799	Bearing-Roller	416-2160
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5H-7071	Director-Water	388-0555
5M-2824	Coupling-Exhaust	431-5270
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5T-0735	Chain Gp	390-5262
6B-3158	Shoe-Yoke Lh	243-0357

46D		
Original Part Number	**Part Name**	**Classic Part Number**
6B-6224	Ferrule	419-4738
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6V-2202	Bearing-Spl Ball	380-1574
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-5085	Bushing	377-5829
7M-1154	Bearing-Spl	417-4515
7M-4046	Bearing-Sleeve	394-8206
7M-4358	Manifold-Exhaust	261-0907
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

Sales Model 112F (Cont'd.)

46D		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073

46D		
Original Part Number	Part Name	Classic Part Number
8W-9587	Flange As	373-5394
9D-2716	Spindle-Wheel	228-9463
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-2685	Rod End	419-1866
9M-4789	Shaft-Gov Cont	297-7256
9M-4955	Pump Gp-F Tfr	242-3443

46D		
Original Part Number	Part Name	Classic Part Number
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085

74H		
Original Part Number	Part Name	Classic Part Number
1H-4478	Pin	330-9272
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822

74H		
Original Part Number	Part Name	Classic Part Number
2D-6341	Pin	330-9273
4D-6664	Coupling-Shaft	243-0338
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285

74H		
Original Part Number	Part Name	Classic Part Number
6B-3158	Shoe-Yoke Lh	243-0357
6G-2947	Shaft	243-0346
8W-6324	Kit-Wear Strip	424-0739
226-8202	Seal-Wiper	472-8024

80J		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424

80J		
Original Part Number	Part Name	Classic Part Number
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-7830	Pump Gp	314-8533
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892

80J		
Original Part Number	Part Name	Classic Part Number
3B-6218	Muffler As	247-2672
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710

Sales Model 112F (Cont'd.)

80J		
Original Part Number	**Part Name**	**Classic Part Number**
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
5D-4799	Bearing-Roller	416-2160
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5H-0047	Disc-Cl Drive	388-0576
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0735	Chain Gp	390-5262
6B-3158	Shoe-Yoke Lh	243-0357
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-8860	Cup-Roller Brg	380-7495
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-5085	Bushing	377-5829
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206

80J		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
8D-5344	Gear-Worm	243-0341
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556

80J		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
8W-9587	Flange As	373-5394
9D-2716	Spindle-Wheel	228-9463
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-2685	Rod End	419-1866
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050

Sales Model 112F (Cont'd.)

80J		
Original Part Number	Part Name	Classic Part Number
9S-2356	Manifold-Exhaust	261-0905
9S-7534	Pipe-Exh Ext	398-2950
9S-7788	Ring-Piston	461-5124
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125

80J		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024

80J		
Original Part Number	Part Name	Classic Part Number
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

82F		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1M-0090	Gasket-Manifold	445-7701
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-3743	Bearing-Ball	384-4786
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2H-3517	Bearing-Inner	417-4505
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2S-4015	Plunger As-Valve	311-9438

82F		
Original Part Number	Part Name	Classic Part Number
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
3D-4718	Bearing-Sleeve	245-5795
3S-5017	Elbow-Exhaust	369-9498
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2229	Cage-Bearing	229-1598
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455
4F-2393	Bearing-Ball	380-1499
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5H-7071	Director-Water	388-0555
5M-2824	Coupling-Exhaust	431-5270
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467

82F		
Original Part Number	Part Name	Classic Part Number
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5T-0735	Chain Gp	390-5262
6B-3158	Shoe-Yoke Lh	243-0357
6B-6224	Ferrule	419-4738
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7M-1154	Bearing-Spl	417-4515
7M-4046	Bearing-Sleeve	394-8206
7M-4358	Manifold-Exhaust	261-0907
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7358	Valve-Inlet	298-2774
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519

Sales Model 112F (Cont'd.)

82F		
Original Part Number	**Part Name**	**Classic Part Number**
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377

82F		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8222	Bearing-Conn Rod	419-6322
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
8W-9587	Flange As	373-5394
9H-2256	Pump Gp-F Prm	311-9443

82F		
Original Part Number	**Part Name**	**Classic Part Number**
9H-5797	Plunger As-Pump	391-9891
9M-4955	Pump Gp-F Tfr	242-3443
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085

89J		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-0057	Plate-Clutch	377-7404
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273

89J		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-7830	Pump Gp	314-8533
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
3B-6218	Muffler As	247-2672
3D-4718	Bearing-Sleeve	245-5795
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3H-1996	Bearing-Ball	380-1498

89J		
Original Part Number	**Part Name**	**Classic Part Number**
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3V-4046	Plate-Pressure	380-7470
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
5D-4799	Bearing-Roller	416-2160
5D-6201	Shoe-Yoke	243-0356

Sales Model 112F (Cont'd.)

89J		
Original Part Number	Part Name	Classic Part Number
5D-9745	Shoe-Guide	330-9285
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0735	Chain Gp	390-5262
6B-3158	Shoe-Yoke Lh	243-0357
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-8860	Cup-Roller Brg	380-7495
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-2237	Gasket Kit	437-3212
6V-2246	Gasket Kit	391-1091
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-5085	Bushing	377-5829
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348

89J		
Original Part Number	Part Name	Classic Part Number
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711

89J		
Original Part Number	Part Name	Classic Part Number
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
8W-9587	Flange As	373-5394
9D-2716	Spindle-Wheel	228-9463
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-2685	Rod End	419-1866
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905

Motor Graders

Sales Model 112F (Cont'd.)

89J		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7534	Pipe-Exh Ext	398-2950
9S-7788	Ring-Piston	461-5124
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126

89J		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024

89J		
Original Part Number	**Part Name**	**Classic Part Number**
232-3233	Bearing-Main	376-9085
236-8675	Disc-Friction	428-7202
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

Sales Model 120

10R		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1B-3941	Cone-Roller Brg	422-6486
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1P-9945	Bracket As-Fan	296-1344
1S-0057	Plate-Clutch	377-7404
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1W-3900	Gasket	472-8006
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123

10R		
Original Part Number	**Part Name**	**Classic Part Number**
2D-2654	Ring-Lock	380-1488
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1757	Hub-Fan Pulley	296-1357
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-7830	Pump Gp	314-8533

10R		
Original Part Number	**Part Name**	**Classic Part Number**
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3B-6218	Muffler As	247-2672
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3V-4046	Plate-Pressure	380-7470
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2156	Bearing As-Rlr	422-6485

Sales Model 120 (Cont'd.)

10R		
Original Part Number	Part Name	Classic Part Number
4D-2229	Cage-Bearing	229-1598
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4864	Pump Gp-F Tfr	242-3442
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-0660	Muffler As	298-2787
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
5D-4799	Bearing-Roller	416-2160
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5D-9906	Shaft-Axle	228-9413
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

10R		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0735	Chain Gp	390-5262
6B-3158	Shoe-Yoke Lh	243-0357
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
7C-4297	Seal As-Cshaft	325-6192
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173

10R		
Original Part Number	Part Name	Classic Part Number
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3325	Arm Gp-V Rocker	314-8623

Sales Model 120 (Cont'd.)

10R		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739

10R		
Original Part Number	**Part Name**	**Classic Part Number**
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
9B-1320	Valve-Check	377-5832
9D-2716	Spindle-Wheel	228-9463
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-2685	Rod End	419-1866
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6129	Pulley-Alt Drive	264-5891
9S-7534	Pipe-Exh Ext	398-2950
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193

10R		
Original Part Number	**Part Name**	**Classic Part Number**
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
236-8675	Disc-Friction	428-7202
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005

13U		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981

13U		
Original Part Number	**Part Name**	**Classic Part Number**
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438

13U		
Original Part Number	**Part Name**	**Classic Part Number**
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-9295	Bearing-Cone	422-6480
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229

Sales Model 120 (Cont'd.)

13U		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3B-4124	Cup-Spl Tapered	422-6481
3B-6218	Muffler As	247-2672
3D-4718	Bearing-Sleeve	245-5795
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-8393	Plate-Clutch	388-0592
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4N-0209	Bonnet-Valve	378-3973

13U		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-6707	Piston-Clutch	215-1686
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5L-6326	Bearing-Ball	420-3222
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024

13U		
Original Part Number	**Part Name**	**Classic Part Number**
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-3158	Shoe-Yoke Lh	243-0357
6B-7469	Spacer	417-4535
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918

Sales Model 120 (Cont'd.)

13U		
Original Part Number	**Part Name**	**Classic Part Number**
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-8623	Gear-Sun	213-8755

13U		
Original Part Number	**Part Name**	**Classic Part Number**
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

13U		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
9B-1320	Valve-Check	377-5832
9D-2716	Spindle-Wheel	228-9463
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6129	Pulley-Alt Drive	264-5891
9S-7534	Pipe-Exh Ext	398-2950
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032

Sales Model 120 (Cont'd.)

13U		
Original Part Number	Part Name	Classic Part Number
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484

13U		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893

13U		
Original Part Number	Part Name	Classic Part Number
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420

14K		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1W-3900	Gasket	472-8006
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

14K		
Original Part Number	Part Name	Classic Part Number
2P-1738	Plate As-Oil Pan	325-6164
2P-1757	Hub-Fan Pulley	296-1357
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-7830	Pump Gp	314-8533
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
3B-6218	Muffler As	247-2672
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338

14K		
Original Part Number	Part Name	Classic Part Number
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
4N-4864	Pump Gp-F Tfr	242-3442
4N-7693	Crankshaft As	269-8763
4P-0660	Muffler As	298-2787
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
5D-4799	Bearing-Roller	416-2160
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5D-9906	Shaft-Axle	228-9413
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883

Sales Model 120 (Cont'd.)

14K		
Original Part Number	Part Name	Classic Part Number
5T-0735	Chain Gp	390-5262
6B-3158	Shoe-Yoke Lh	243-0357
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
7C-4297	Seal As-Cshaft	325-6192
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417

14K		
Original Part Number	Part Name	Classic Part Number
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083

14K		
Original Part Number	Part Name	Classic Part Number
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
8W-9587	Flange As	373-5394
9D-2716	Spindle-Wheel	228-9463
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-2685	Rod End	419-1866
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6129	Pulley-Alt Drive	264-5891
9S-7534	Pipe-Exh Ext	398-2950
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
250-6555	Kit-Liner-Cla	250-6563

Sales Model 120 (Cont'd.)

14K		
Original Part Number	Part Name	Classic Part Number
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438

14K		
Original Part Number	Part Name	Classic Part Number
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

14K		
Original Part Number	Part Name	Classic Part Number
341-2430	Damper As-Cshft	299-2005

34R		
Original Part Number	Part Name	Classic Part Number
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-3900	Gasket	472-8006
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2P-0220	Gasket-Pump	398-2927
2P-1738	Plate As-Oil Pan	325-6164
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7693	Crankshaft As	269-8763
4W-2061	Pan As-Oil Sump	416-5519
5P-9514	Bearing-Ball	417-9467
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6H-3957	Bearing-Ball	311-9358
6N-5482	Plate-Friction	376-3637
6N-7263	Gasket-Cyl Head	380-7386
6V-2202	Bearing-Spl Ball	380-1574

34R		
Original Part Number	Part Name	Classic Part Number
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-5687	Hub-Cshft	314-8684
8H-9789	Bearing-Ball	374-8342
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0875	Valve-Exhaust	247-6893
8N-5929	Cover-Water Pump	296-1349
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081

34R		
Original Part Number	Part Name	Classic Part Number
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-2389	Body-Fuel Valve	377-5831
8S-3995	Gage As-Level	430-8042
9B-1320	Valve-Check	377-5832
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
131-3815	Seal Gp-Basic	325-6193
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005

Sales Model 120 (Cont'd.)

64U		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-2566	Ring-Lock	416-2123
2D-5961	Pin-Axle Pivot	228-9438
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7830	Pump Gp	314-8533

64U		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3H-1996	Bearing-Ball	380-1498
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405
4F-2041	Cup-Roller Brg	418-9609
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986

64U		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9386	Line As-Fuel Inj	279-4987
4W-2061	Pan As-Oil Sump	416-5519
4W-6869	Spacer-Fuel Pump	417-4534
5F-8651	Bearing-Ball	420-3223
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-8860	Cup-Roller Brg	380-7495
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
7C-3862	Camshaft	458-0151
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-9980	Camshaft	377-5851
7M-1154	Bearing-Spl	417-4515
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779

Sales Model 120 (Cont'd.)

64U		
Original Part Number	**Part Name**	**Classic Part Number**
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8D-5344	Gear-Worm	243-0341
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711

64U		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8W-9587	Flange As	373-5394
9B-1320	Valve-Check	377-5832
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042

64U		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988

Sales Model 120 (Cont'd.)

64U		
Original Part Number	**Part Name**	**Classic Part Number**
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

64U		
Original Part Number	**Part Name**	**Classic Part Number**
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

64U		
Original Part Number	**Part Name**	**Classic Part Number**
391-8229	Kit-Gasket-Fs	398-2955

89G		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1H-4478	Pin	330-9272
1M-0090	Gasket-Manifold	445-7701
1M-7250	Bowl	360-2296
1P-1367	Plunger-Valve	432-8913
1S-3743	Bearing-Ball	384-4786
1W-7073	Rebuild Kt-Pump	383-3677
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2H-3517	Bearing-Inner	417-4505
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
3B-6218	Muffler As	247-2672
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494

89G		
Original Part Number	**Part Name**	**Classic Part Number**
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
5D-4799	Bearing-Roller	416-2160
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5D-9906	Shaft-Axle	228-9413
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5T-0735	Chain Gp	390-5262
6B-3158	Shoe-Yoke Lh	243-0357
6B-6224	Ferrule	419-4738
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6V-2202	Bearing-Spl Ball	380-1574
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-5085	Bushing	377-5829
7M-1154	Bearing-Spl	417-4515
7M-4046	Bearing-Sleeve	394-8206

89G		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7N-0128	Core As-Oil Clr	299-1994
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
8H-9789	Bearing-Ball	374-8342
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
9B-1320	Valve-Check	377-5832
9D-2716	Spindle-Wheel	228-9463
9H-2256	Pump Gp-F Prm	311-9443
9L-2685	Rod End	419-1866
9M-4789	Shaft-Gov Cont	297-7256
9M-4955	Pump Gp-F Tfr	242-3443
9M-5477	Bearing-Sleeve	374-6517
9S-7534	Pipe-Exh Ext	398-2950

Sales Model 120 (Cont'd.)

89G		
Original Part Number	**Part Name**	**Classic Part Number**
108-5603	Screw-Adj Arm	379-0166

89G		
Original Part Number	**Part Name**	**Classic Part Number**
121-7746	Pre-Cleaner As	360-2311
169-4200	Gasket	472-8023

89G		
Original Part Number	**Part Name**	**Classic Part Number**
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085

90R		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4478	Pin	330-9272
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-9295	Bearing-Cone	422-6480
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-6245	Shaft As-Pump	325-6197
2W-2621	Valve-Inlet	247-6892
2W-9978	Core As-Oclr	279-4983
3B-4124	Cup-Spl Tapered	422-6481
3D-4718	Bearing-Sleeve	245-5795
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-8393	Plate-Clutch	388-0592
3S-3875	Screen-Suction	435-4849

90R		
Original Part Number	**Part Name**	**Classic Part Number**
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4N-4864	Pump Gp-F Tfr	242-3442
4N-7693	Crankshaft As	269-8763
4S-6707	Piston-Clutch	215-1686
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
5D-4799	Bearing-Roller	416-2160
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5D-9906	Shaft-Axle	228-9413
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5P-7807	Bearing-Ball	314-8502

90R		
Original Part Number	**Part Name**	**Classic Part Number**
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-3158	Shoe-Yoke Lh	243-0357
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6T-1980	Collar-Idler End	226-0210
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4926	Retainer-Piston	314-8538

Motor Graders

Sales Model 120 (Cont'd.)

90R		
Original Part Number	**Part Name**	**Classic Part Number**
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
8B-8439	Bearing-Ball	399-6069
8F-6058	Bearing-Sleeve	416-5494
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-8623	Gear-Sun	213-8755
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8677	Carrier-Planet	213-4449

90R		
Original Part Number	**Part Name**	**Classic Part Number**
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8W-6324	Kit-Wear Strip	424-0739
8W-9587	Flange As	373-5394
9H-2256	Pump Gp-F Prm	311-9443

90R		
Original Part Number	**Part Name**	**Classic Part Number**
9H-5797	Plunger As-Pump	391-9891
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
250-6557	Liner Kit-Cla	295-6438
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420

Sales Model 120B

10R		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1B-3941	Cone-Roller Brg	422-6486
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087

10R		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1P-9945	Bracket As-Fan	296-1344
1S-0057	Plate-Clutch	377-7404
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786

10R		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430

Sales Model 120B (Cont'd.)

10R		
Original Part Number	Part Name	Classic Part Number
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1757	Hub-Fan Pulley	296-1357
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-7830	Pump Gp	314-8533
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3B-6218	Muffler As	247-2672
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3V-4046	Plate-Pressure	380-7470
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440

10R		
Original Part Number	Part Name	Classic Part Number
4B-9374	Bearing-Cup	380-7494
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4864	Pump Gp-F Tfr	242-3442
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-0660	Muffler As	298-2787
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
5D-4799	Bearing-Roller	416-2160
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5D-9906	Shaft-Axle	228-9413
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247

10R		
Original Part Number	Part Name	Classic Part Number
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0735	Chain Gp	390-5262
6B-3158	Shoe-Yoke Lh	243-0357
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
7C-4297	Seal As-Cshaft	325-6192
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951

Sales Model 120B (Cont'd.)

10R		
Original Part Number	Part Name	Classic Part Number
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564

10R		
Original Part Number	Part Name	Classic Part Number
8N-3183	Piston Gp-Basic	250-6556
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
9B-1320	Valve-Check	377-5832
9D-2716	Spindle-Wheel	228-9463
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-2685	Rod End	419-1866
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557

10R		
Original Part Number	Part Name	Classic Part Number
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6129	Pulley-Alt Drive	264-5891
9S-7534	Pipe-Exh Ext	398-2950
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
236-8675	Disc-Friction	428-7202
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005

Sales Model 120B (Cont'd.)

32C		
Original Part Number	Part Name	Classic Part Number
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230

32C		
Original Part Number	Part Name	Classic Part Number
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7830	Pump Gp	314-8533
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985

32C		
Original Part Number	Part Name	Classic Part Number
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-2061	Pan As-Oil Sump	416-5519
4W-6869	Spacer-Fuel Pump	417-4534
5D-4799	Bearing-Roller	416-2160
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5D-9906	Shaft-Axle	228-9413
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5P-8768	Kit-Gasket (Scl)	393-1024
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-3158	Shoe-Yoke Lh	243-0357
6B-7469	Spacer	417-4535
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-8860	Cup-Roller Brg	380-7495
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
7D-6524	Shaft-Axle	228-8917

Sales Model 120B (Cont'd.)

32C		
Original Part Number	Part Name	Classic Part Number
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-9980	Camshaft	377-5851
7M-1154	Bearing-Spl	417-4515
7M-4046	Bearing-Sleeve	394-8206
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8D-5344	Gear-Worm	243-0341
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563

32C		
Original Part Number	Part Name	Classic Part Number
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8W-6324	Kit-Wear Strip	424-0739
8W-9587	Flange As	373-5394
9D-2716	Spindle-Wheel	228-9463
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-7534	Pipe-Exh Ext	398-2950
9S-7788	Ring-Piston	461-5124

32C		
Original Part Number	Part Name	Classic Part Number
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
250-6555	Kit-Liner-Cla	250-6563
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349

Sales Model 120B (Cont'd.)

32C		
Original Part Number	**Part Name**	**Classic Part Number**
334-8389	Crankshaft As	242-3439

32C		
Original Part Number	**Part Name**	**Classic Part Number**
341-2430	Damper As-Cshft	299-2005

34R		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1W-3900	Gasket	472-8006
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2P-0220	Gasket-Pump	398-2927
2P-1738	Plate As-Oil Pan	325-6164
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7693	Crankshaft As	269-8763
4W-2061	Pan As-Oil Sump	416-5519
5P-9514	Bearing-Ball	417-9467
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6H-3957	Bearing-Ball	311-9358
6N-5482	Plate-Friction	376-3637
6N-7263	Gasket-Cyl Head	380-7386
6V-2202	Bearing-Spl Ball	380-1574

34R		
Original Part Number	**Part Name**	**Classic Part Number**
7E-9980	Camshaft	377-5851
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-5687	Hub-Cshft	314-8684
8H-9789	Bearing-Ball	374-8342
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0875	Valve-Exhaust	247-6893
8N-5929	Cover-Water Pump	296-1349
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081

34R		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-2389	Body-Fuel Valve	377-5831
8S-3995	Gage As-Level	430-8042
9B-1320	Valve-Check	377-5832
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
131-3815	Seal Gp-Basic	325-6193
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005

64U		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4478	Pin	330-9272

Sales Model 120B (Cont'd.)

64U		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-3743	Bearing-Ball	384-4786
1W-1219	Trunnion As	314-8724
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438

64U		
Original Part Number	**Part Name**	**Classic Part Number**
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-3517	Bearing-Inner	417-4505
2M-8340	Rod End-Yoke	374-4678
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1738	Plate As-Oil Pan	325-6164
2P-1757	Hub-Fan Pulley	296-1357
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-6245	Shaft As-Pump	325-6197
2P-7830	Pump Gp	314-8533
2P-7830	Pump Gp	314-8533
2W-1707	Ring-Piston Top	270-4356

64U		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7458	Crankshaft As	242-3439
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3L-1425	Bearing-Ball	311-9356
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4B-9374	Bearing-Cup	380-7494
4D-2156	Bearing As-Rlr	422-6485
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4D-2229	Cage-Bearing	229-1598
4D-6664	Coupling-Shaft	243-0338
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
4F-2041	Cup-Roller Brg	418-9609
4N-0209	Bonnet-Valve	378-3973

Sales Model 120B (Cont'd.)

64U		
Original Part Number	Part Name	Classic Part Number
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-2061	Pan As-Oil Sump	416-5519
4W-2061	Pan As-Oil Sump	416-5519
4W-6869	Spacer-Fuel Pump	417-4534

64U		
Original Part Number	Part Name	Classic Part Number
5D-4799	Bearing-Roller	416-2160
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5D-9906	Shaft-Axle	228-9413
5F-8651	Bearing-Ball	420-3223
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7630	Bearing-Sleeve	394-0219
6B-3158	Shoe-Yoke Lh	243-0357
6B-7469	Spacer	417-4535
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1345	Shaft As-O Pump	374-7475

64U		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
6I-8860	Cup-Roller Brg	380-7495
6N-1036	Gear-Oil Pump	279-4991
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6N-7263	Gasket-Cyl Head	380-7386
6V-2202	Bearing-Spl Ball	380-1574
7C-3862	Camshaft	458-0151
7C-3862	Camshaft	458-0151
7D-6524	Shaft-Axle	228-8917
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7D-7442	Hub-Fd Gear	228-8918
7E-9980	Camshaft	377-5851
7E-9980	Camshaft	377-5851
7M-1154	Bearing-Spl	417-4515
7M-1154	Bearing-Spl	417-4515
7M-4046	Bearing-Sleeve	394-8206
7M-4046	Bearing-Sleeve	394-8206
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173

Sales Model 120B (Cont'd.)

64U		
Original Part Number	Part Name	Classic Part Number
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2876	Line As-Fuel Inj	298-2781
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-0508	Gear-Fp Drive	296-1351
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187

64U		
Original Part Number	Part Name	Classic Part Number
7W-7546	Gasket-Plate	433-8187
8D-5344	Gear-Worm	243-0341
8D-5344	Gear-Worm	243-0341
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8H-9789	Bearing-Ball	374-8342
8N-0081	Trunnion	393-5196
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3251	Shaft As-Rkr Arm	314-8711

64U		
Original Part Number	Part Name	Classic Part Number
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8227	Bearing-Main	376-9082

Sales Model 120B (Cont'd.)

64U		
Original Part Number	Part Name	Classic Part Number
8N-8228	Bearing-Main	376-9083
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-6511	Bearing-Sleeve	380-7372
8W-6324	Kit-Wear Strip	424-0739
8W-9587	Flange As	373-5394
8W-9587	Flange As	373-5394
9B-1320	Valve-Check	377-5832
9B-1320	Valve-Check	377-5832
9D-2716	Spindle-Wheel	228-9463
9M-5477	Bearing-Sleeve	374-6517
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-2355	Manifold-Exhaust	261-0891
9S-6129	Pulley-Alt Drive	264-5891
9S-7534	Pipe-Exh Ext	398-2950
9S-7788	Ring-Piston	461-5124

64U		
Original Part Number	Part Name	Classic Part Number
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5188	Shaft-Water Pump	325-6202

64U		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6555	Kit-Liner-Cla	250-6563
250-6558	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 120B (Cont'd.)

7KB		
Original Part Number	Part Name	Classic Part Number
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7830	Pump Gp	314-8533
2W-1707	Ring-Piston Top	270-4356

7KB		
Original Part Number	Part Name	Classic Part Number
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4W-2061	Pan As-Oil Sump	416-5519
5D-4799	Bearing-Roller	416-2160
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5D-9906	Shaft-Axle	228-9413
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5P-8768	Kit-Gasket (Scl)	393-1024

7KB		
Original Part Number	Part Name	Classic Part Number
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-3158	Shoe-Yoke Lh	243-0357
6B-7469	Spacer	417-4535
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-8860	Cup-Roller Brg	380-7495
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
7C-3862	Camshaft	458-0151
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-9980	Camshaft	377-5851
7M-1154	Bearing-Spl	417-4515
7M-4046	Bearing-Sleeve	394-8206
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779

Sales Model 120B (Cont'd.)

7KB		
Original Part Number	Part Name	Classic Part Number
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-0508	Gear-Fp Drive	296-1351
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8D-5344	Gear-Worm	243-0341
8H-9789	Bearing-Ball	374-8342
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200

7KB		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8W-6324	Kit-Wear Strip	424-0739
8W-9587	Flange As	373-5394
9B-1320	Valve-Check	377-5832
9D-2716	Spindle-Wheel	228-9463
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050

7KB		
Original Part Number	Part Name	Classic Part Number
9S-2355	Manifold-Exhaust	261-0891
9S-7534	Pipe-Exh Ext	398-2950
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
153-3580	Shaft	299-2055
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

Motor Graders

Sales Model 120G

11W		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1M-0090	Gasket-Manifold	445-7701
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-5480	Cover As.-End	299-1998
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1U-3998	Seal As	472-8005
1U-4661	Lever Gp	396-7267
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036

11W		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2G-1085	Housing As-Diff	393-0928
2G-2858	Cap-Pivot	243-0345
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6375	Shaft-Drive	275-5282
2G-6377	Sprocket	275-5286
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-7464	Insert-Bolt	386-4918
2G-8609	Pin	319-3450
2G-8616	Pin	282-6554
2G-8620	Pin	282-6556
2G-8628	Pin	282-6559
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8736	Bearing-Sleeve	299-1959
2G-8769	Pin	282-6562
2G-9097	Cap	418-1926
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

11W		
Original Part Number	Part Name	Classic Part Number
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4364	Housing As-Cl	396-9928
2P-4432	Gear-Ring	418-9583
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-4611	Pipe-Exhaust	365-8821
2P-5769	Coupling	394-9812
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8907	Spider As-Fan	330-9289
2P-8986	Cup-Rlr Bearing	415-1912
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3E-8905	Gasket Kit	393-3617
3G-1853	Cyl Gp-076 406 Y	415-1895
3G-4752	Cyl Gp-035-060-Y	390-0987
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3P-0114	Elbow-Exhaust	314-8516

Sales Model 120G (Cont'd.)

11W		
Original Part Number	Part Name	Classic Part Number
3P-0165	Pulley-Fan Drive	298-2775
3P-0296	Gear	416-2149
3P-0297	Shaft As	275-5297
3P-0298	Carrier-Input	384-5922
3P-0329	Drum As-Gear	380-7484
3P-0726	Shaft As	275-5298
3P-0786	Coupling	433-0440
3P-0801	Plate-Clutch	383-2119
3P-0951	Bearing-Spl Ball	416-2159
3P-3424	Shaft	416-5526
3P-5349	Piston As	275-5292
3P-5737	Shaft As-Clutch	275-5273
3P-5955	Disc-Friction	428-7205
3S-5017	Elbow-Exhaust	369-9498
3T-2095	Bearing-Sleeve	384-3459
4B-1455	Cap As-Filler	361-1719
4D-2619	Bearing	417-4494
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008

11W		
Original Part Number	Part Name	Classic Part Number
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5H-7071	Director-Water	388-0555
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5K-0990	Pin	299-2035
5L-6326	Bearing-Ball	420-3222
5L-7632	Support-Elbow	433-9854
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406

11W		
Original Part Number	Part Name	Classic Part Number
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0735	Chain Gp	390-5262
5T-0906	Cover	282-6625
5T-0925	Actuator Gp-Bk	379-0198
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-8367	Strip-Wear	297-7263
5T-8500	Shoe-Circle Dr	243-0359
5T-8501	Shoe-Circle Dr	243-0358
5T-8739	Spider Gp-Brg&	373-5386
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6D-5415	Plate	382-8043
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-7213	Carrier-Planet	396-9936
6G-8425	Valve Gp-Cont -K	367-6086
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-4190	Cap-Lower	297-7161

Sales Model 120G (Cont'd.)

11W		
Original Part Number	**Part Name**	**Classic Part Number**
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-2090	Base-Xmsn O Fil	397-5049
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200
6Y-0305	Cage As-Bearing	297-7150
6Y-0306	Bearing-Sleeve	391-1104
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-5861	Adapter	243-0364
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-5085	Bushing	377-5829
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-3451	Gear-Planet	297-7188
7G-3452	Gear-Planet	275-5290
7G-3461	Gear-Planet	275-5291
7J-3351	Head	380-1515
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816

11W		
Original Part Number	**Part Name**	**Classic Part Number**
7M-7358	Valve-Inlet	298-2774
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-3536	Gear-Fuel	279-4993
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-6677	Core As-O Clr	299-1995
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8576	Bearing As	435-4848
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-9647	Piston-Clutch	275-5294
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8D-0983	Mounting	384-3470
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341

11W		
Original Part Number	**Part Name**	**Classic Part Number**
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8572	Bearing-Sleeve	380-7384
8D-8633	Shaft-Drive	275-5281
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-1616	Lever	330-9271
8J-1624	Valve As	390-0997
8J-2022	Piston As-Pump	367-6073
8J-6296	Shaft	419-6072
8J-6322	Cup-Roller Brg	399-4447
8J-6384	Bearing-Sleeve	472-8034
8J-8590	Cyl Gp-076 274 Y	430-5963
8M-3368	Valve-Check	388-6599
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564

Sales Model 120G (Cont'd.)

11W		
Original Part Number	Part Name	Classic Part Number
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1656	Plate-Clutch	367-6071
8P-5961	Gear-Ring	385-6137
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
8T-1606	Kit-Gskt-Sch	386-3046
8T-9486	Gasket Kt	393-5197
8W-0328	Cylinder-Damper	419-4715
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732

11W		
Original Part Number	Part Name	Classic Part Number
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2307	Shaft-Planet	275-5284
8W-3589	Link As-Spring	380-7389
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-8628	Spindle-Fr Axle	282-6571
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
9B-1320	Valve-Check	377-5832
9D-1491	Coupling	416-2121
9D-1511	Bearing-Sleeve	333-4943
9D-1512	Bearing-Sleeve	333-4944
9D-1589	Mounting	387-2928
9D-2756	Insert	333-4949
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9H-5797	Plunger As-Pump	391-9891
9J-3466	Cyl Gp-028 121 Y	393-0913
9M-1853	Mount As.	376-3638
9M-2417	Retainer-Gear	380-7409
9M-4955	Pump Gp-F Tfr	242-3443

11W		
Original Part Number	Part Name	Classic Part Number
9M-5477	Bearing-Sleeve	374-6517
9M-8395	Bearing-Sleeve	391-1103
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
108-5603	Screw-Adj Arm	379-0166
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp-Univ	297-4858
121-7746	Pre-Cleaner As	360-2311
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627

Sales Model 120G (Cont'd.)

11W		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
139-0683	Gasket Kit	390-5290
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

11W		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7772	Pump Gp-Water -B	438-2009
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
184-9843	Head	347-0461
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-3986	Gasket Kit	390-5275
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
234-8013	Kit-Gasket-Sch	437-8650
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
246-5916	Kit-Seal-H.Cyl-1	472-8026

11W		
Original Part Number	Part Name	Classic Part Number
250-6556	Kit-Liner-Cla	250-6564
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
288-2552	Kit-Gasket-Txg	391-9884
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

2AB		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-5480	Cover As.-End	299-1998
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572

2AB		
Original Part Number	Part Name	Classic Part Number
1U-4661	Lever Gp	396-7267
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221

2AB		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2G-1085	Housing As-Diff	393-0928
2G-2858	Cap-Pivot	243-0345
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6375	Shaft-Drive	275-5282
2G-6377	Sprocket	275-5286
2G-7464	Insert-Bolt	386-4918

Sales Model 120G (Cont'd.)

2AB		
Original Part Number	Part Name	Classic Part Number
2G-8609	Pin	319-3450
2G-8616	Pin	282-6554
2G-8620	Pin	282-6556
2G-8628	Pin	282-6559
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8736	Bearing-Sleeve	299-1959
2G-8769	Pin	282-6562
2G-9097	Cap	418-1926
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4364	Housing As-Cl	396-9928
2P-4432	Gear-Ring	418-9583
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-4611	Pipe-Exhaust	365-8821
2P-5769	Coupling	394-9812
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8907	Spider As-Fan	330-9289
2P-8986	Cup-Rlr Bearing	415-1912
2S-5100	Valve-Ball	386-3049
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088

2AB		
Original Part Number	Part Name	Classic Part Number
3G-4752	Cyl Gp-035-060-Y	390-0987
3L-1425	Bearing-Ball	311-9356
3P-0114	Elbow-Exhaust	314-8516
3P-0165	Pulley-Fan Drive	298-2775
3P-0296	Gear	416-2149
3P-0297	Shaft As	275-5297
3P-0298	Carrier-Input	384-5922
3P-0329	Drum As-Gear	380-7484
3P-0726	Shaft As	275-5298
3P-0786	Coupling	433-0440
3P-0801	Plate-Clutch	383-2119
3P-0951	Bearing-Spl Ball	416-2159
3P-3424	Shaft	416-5526
3P-5349	Piston As	275-5292
3P-5737	Shaft As-Clutch	275-5273
3P-5955	Disc-Friction	428-7205
3T-2095	Bearing-Sleeve	384-3459
4B-1455	Cap As-Filler	361-1719
4D-2619	Bearing	417-4494
4K-7463	Seal-Lip Type	472-8007
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985

2AB		
Original Part Number	Part Name	Classic Part Number
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5K-0990	Pin	299-2035
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5T-0735	Chain Gp	390-5262
5T-0925	Actuator Gp-Bk	379-0198
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386

Sales Model 120G (Cont'd.)

2AB		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6D-5415	Plate	382-8043
6F-2956	Cup-Spl Tapered	420-6538
6G-1908	Housing As-Drive	297-7198
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-7213	Carrier-Planet	396-9936
6G-8425	Valve Gp-Cont -K	367-6086
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-2090	Base-Xmsn O Fil	397-5049
6V-2202	Bearing-Spl Ball	380-1574
6Y-0305	Cage As-Bearing	297-7150
6Y-0306	Bearing-Sleeve	391-1104
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-5861	Adapter	243-0364
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-9267	Yoke	330-9297
7E-9918	Repair Kit-Major	388-0655

2AB		
Original Part Number	Part Name	Classic Part Number
7E-9980	Camshaft	377-5851
7G-3451	Gear-Planet	297-7188
7G-3452	Gear-Planet	275-5290
7G-3461	Gear-Planet	275-5291
7J-3351	Head	380-1515
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-2834	Kit-Repair	374-4723
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-8576	Bearing As	435-4848
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-9647	Piston-Clutch	275-5294
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8D-0983	Mounting	384-3470
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8633	Shaft-Drive	275-5281
8D-8634	Gear-Planet	275-5275

2AB		
Original Part Number	Part Name	Classic Part Number
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-1616	Lever	330-9271
8J-1624	Valve As	390-0997
8J-2022	Piston As-Pump	367-6073
8J-6296	Shaft	419-6072
8J-6322	Cup-Roller Brg	399-4447
8J-6384	Bearing-Sleeve	472-8034
8J-8590	Cyl Gp-076 274 Y	430-5963
8M-3368	Valve-Check	388-6599
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349

Sales Model 120G (Cont'd.)

2AB		
Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1656	Plate-Clutch	367-6071
8P-5961	Gear-Ring	385-6137
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8W-0328	Cylinder-Damper	419-4715
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2307	Shaft-Planet	275-5284
8W-3589	Link As-Spring	380-7389
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-8628	Spindle-Fr Axle	282-6571
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
9D-1491	Coupling	416-2121
9D-1511	Bearing-Sleeve	333-4943

2AB		
Original Part Number	Part Name	Classic Part Number
9D-1512	Bearing-Sleeve	333-4944
9D-1589	Mounting	387-2928
9D-2756	Insert	333-4949
9D-3242	Cone-Roller Brg	453-3659
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9J-3466	Cyl Gp-028 121 Y	393-0913
9M-1853	Mount As.	376-3638
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
105-0017	Cylinder	416-2130
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548

4HD		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988

2AB		
Original Part Number	Part Name	Classic Part Number
126-7130	Shaft As	275-5300
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
147-3309	Spindle	282-6628
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
312-0782	Worm-Circ Drv	282-6623
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 120G (Cont'd.)

4HD		
Original Part Number	Part Name	Classic Part Number
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1U-3998	Seal As	472-8005
1U-4661	Lever Gp	396-7267
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955

4HD		
Original Part Number	Part Name	Classic Part Number
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-1085	Housing As-Diff	393-0928
2G-2858	Cap-Pivot	243-0345
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6375	Shaft-Drive	275-5282
2G-6377	Sprocket	275-5286
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-7464	Insert-Bolt	386-4918
2G-8609	Pin	319-3450
2G-8616	Pin	282-6554
2G-8620	Pin	282-6556
2G-8628	Pin	282-6559
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8736	Bearing-Sleeve	299-1959
2G-8769	Pin	282-6562
2G-9097	Cap	418-1926
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4364	Housing As-Cl	396-9928

4HD		
Original Part Number	Part Name	Classic Part Number
2P-4432	Gear-Ring	418-9583
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-4611	Pipe-Exhaust	365-8821
2P-5769	Coupling	394-9812
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8907	Spider As-Fan	330-9289
2P-8986	Cup-Rlr Bearing	415-1912
2S-5100	Valve-Ball	386-3049
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3L-1425	Bearing-Ball	311-9356
3P-0114	Elbow-Exhaust	314-8516
3P-0165	Pulley-Fan Drive	298-2775
3P-0296	Gear	416-2149
3P-0297	Shaft As	275-5297
3P-0298	Carrier-Input	384-5922
3P-0329	Drum As-Gear	380-7484
3P-0726	Shaft As	275-5298
3P-0786	Coupling	433-0440
3P-0801	Plate-Clutch	383-2119
3P-0951	Bearing-Spl Ball	416-2159
3P-3424	Shaft	416-5526
3P-5349	Piston As	275-5292
3P-5737	Shaft As-Clutch	275-5273
3P-5955	Disc-Friction	428-7205
3T-2095	Bearing-Sleeve	384-3459
4B-1455	Cap As-Filler	361-1719
4D-2619	Bearing	417-4494
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764

Sales Model 120G (Cont'd.)

4HD		
Original Part Number	Part Name	Classic Part Number
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5K-0990	Pin	299-2035
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541

4HD		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0735	Chain Gp	390-5262
5T-0906	Cover	282-6625
5T-0925	Actuator Gp-Bk	379-0198
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-5415	Plate	382-8043
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-7213	Carrier-Planet	396-9936
6G-8425	Valve Gp-Cont -K	367-6086
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-4190	Cap-Lower	297-7161

4HD		
Original Part Number	Part Name	Classic Part Number
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-1878	Muffler As	360-7883
6N-7174	Shield-Oil	314-8544
6P-2090	Base-Xmsn O Fil	397-5049
6V-2202	Bearing-Spl Ball	380-1574
6Y-0305	Cage As-Bearing	297-7150
6Y-0306	Bearing-Sleeve	391-1104
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-5861	Adapter	243-0364
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-3451	Gear-Planet	297-7188
7G-3452	Gear-Planet	275-5290
7G-3461	Gear-Planet	275-5291
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531

Sales Model 120G (Cont'd.)

4HD		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-8576	Bearing As	435-4848
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-9647	Piston-Clutch	275-5294
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8D-0983	Mounting	384-3470
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8572	Bearing-Sleeve	380-7384
8D-8633	Shaft-Drive	275-5281
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-1616	Lever	330-9271
8J-6322	Cup-Roller Brg	399-4447
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893

4HD		
Original Part Number	**Part Name**	**Classic Part Number**
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1656	Plate-Clutch	367-6071
8P-5961	Gear-Ring	385-6137
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1606	Kit-Gskt-Sch	386-3046

4HD		
Original Part Number	**Part Name**	**Classic Part Number**
8T-9486	Gasket Kt	393-5197
8W-0328	Cylinder-Damper	419-4715
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2307	Shaft-Planet	275-5284
8W-3589	Link As-Spring	380-7389
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-8628	Spindle-Fr Axle	282-6571
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
9D-1491	Coupling	416-2121
9D-1511	Bearing-Sleeve	333-4943
9D-1512	Bearing-Sleeve	333-4944
9D-1589	Mounting	387-2928
9D-2756	Insert	333-4949
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1853	Mount As.	376-3638
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923

Sales Model 120G (Cont'd.)

4HD		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp-Univ	297-4858

4HD		
Original Part Number	Part Name	Classic Part Number
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
139-0683	Gasket Kit	390-5290
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-0739	Gasket Kit - F	437-2012

4HD		
Original Part Number	Part Name	Classic Part Number
184-9843	Head	347-0461
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-3986	Gasket Kit	390-5275
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
246-5916	Kit-Seal-H.Cyl-1	472-8026
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
288-2552	Kit-Gasket-Txg	391-9884
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

61W		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1B-5675	Bearing	377-7396
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770

61W		
Original Part Number	Part Name	Classic Part Number
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-5480	Cover As.-End	299-1998
1S-3062	Director-Water	418-9572
1U-4661	Lever Gp	396-7267
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

61W		
Original Part Number	Part Name	Classic Part Number
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173

Sales Model 120G (Cont'd.)

61W		
Original Part Number	Part Name	Classic Part Number
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-5383	Gasket	445-7709
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2G-1085	Housing As-Diff	393-0928
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6375	Shaft-Drive	275-5282
2G-6377	Sprocket	275-5286
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4364	Housing As-Cl	396-9928
2P-4432	Gear-Ring	418-9583
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-5769	Coupling	394-9812
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203

61W		
Original Part Number	Part Name	Classic Part Number
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3P-0114	Elbow-Exhaust	314-8516
3P-0296	Gear	416-2149
3P-0297	Shaft As	275-5297
3P-0298	Carrier-Input	384-5922
3P-0329	Drum As-Gear	380-7484
3P-0726	Shaft As	275-5298
3P-0786	Coupling	433-0440
3P-0801	Plate-Clutch	383-2119
3P-0951	Bearing-Spl Ball	416-2159
3P-3424	Shaft	416-5526
3P-5349	Piston As	275-5292
3P-5737	Shaft As-Clutch	275-5273
3P-5955	Disc-Friction	428-7205
3T-2095	Bearing-Sleeve	384-3459
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

61W		
Original Part Number	Part Name	Classic Part Number
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5T-0925	Actuator Gp-Bk	379-0198
5T-1362	Univ Joint As-5C	325-6011
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-1908	Housing As-Drive	297-7198
6G-7213	Carrier-Planet	396-9936
6G-8425	Valve Gp-Cont -K	367-6086
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

Sales Model 120G (Cont'd.)

61W		
Original Part Number	Part Name	Classic Part Number
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-2090	Base-Xmsn O Fil	397-5049
6V-2202	Bearing-Spl Ball	380-1574
6Y-0305	Cage As-Bearing	297-7150
6Y-0306	Bearing-Sleeve	391-1104
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-9267	Yoke	330-9297
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-3451	Gear-Planet	297-7188
7G-3452	Gear-Planet	275-5290
7G-3461	Gear-Planet	275-5291
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2834	Kit-Repair	374-4723
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656

61W		
Original Part Number	Part Name	Classic Part Number
7S-8576	Bearing As	435-4848
7S-8631	Shaft As	275-5296
7T-9647	Piston-Clutch	275-5294
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8D-5344	Gear-Worm	243-0341
8D-8572	Bearing-Sleeve	380-7384
8D-8633	Shaft-Drive	275-5281
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9804	Housing-Drive	302-2682
8H-2810	Case As-Filter	314-8512
8J-1616	Lever	330-9271
8J-1624	Valve As	390-0997
8J-2022	Piston As-Pump	367-6073
8J-6296	Shaft	419-6072
8J-6322	Cup-Roller Brg	399-4447
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200

61W		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1656	Plate-Clutch	367-6071
8P-5961	Gear-Ring	385-6137
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8W-0328	Cylinder-Damper	419-4715
8W-2307	Shaft-Planet	275-5284
8W-5092	Pinion-Circle Dr	282-6569
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-9587	Flange As	373-5394
9D-1491	Coupling	416-2121
9D-3242	Cone-Roller Brg	453-3659
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

Sales Model 120G (Cont'd.)

61W		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
105-3196	Motor Gp-Grtr	282-6547
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp-Univ	297-4858
126-7130	Shaft As	275-5300
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626

61W		
Original Part Number	**Part Name**	**Classic Part Number**
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
147-3309	Spindle	282-6628
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687

61W		
Original Part Number	**Part Name**	**Classic Part Number**
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
312-0782	Worm-Circ Drv	282-6623
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

82V		
Original Part Number	**Part Name**	**Classic Part Number**
1B-5675	Bearing	377-7396
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
3P-0951	Bearing-Spl Ball	416-2159
3T-2095	Bearing-Sleeve	384-3459

82V		
Original Part Number	**Part Name**	**Classic Part Number**
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
6K-8088	Bearing-Roller	399-4428
6Y-0306	Bearing-Sleeve	391-1104
7S-8576	Bearing As	435-4848

82V		
Original Part Number	**Part Name**	**Classic Part Number**
8J-6322	Cup-Roller Brg	399-4447
9D-1589	Mounting	387-2928
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
139-0683	Gasket Kit	390-5290
196-3986	Gasket Kit	390-5275

87V		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913

87V		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-5480	Cover As.-End	299-1998
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453

87V		
Original Part Number	**Part Name**	**Classic Part Number**
1S-3062	Director-Water	418-9572
1U-3998	Seal As	472-8005
1U-4661	Lever Gp	396-7267
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716

Sales Model 120G (Cont'd.)

87V		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-1085	Housing As-Diff	393-0928
2G-2858	Cap-Pivot	243-0345
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6375	Shaft-Drive	275-5282
2G-6377	Sprocket	275-5286
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-7464	Insert-Bolt	386-4918
2G-8609	Pin	319-3450
2G-8616	Pin	282-6554
2G-8620	Pin	282-6556
2G-8628	Pin	282-6559
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561

87V		
Original Part Number	Part Name	Classic Part Number
2G-8736	Bearing-Sleeve	299-1959
2G-8769	Pin	282-6562
2G-9097	Cap	418-1926
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4364	Housing As-Cl	396-9928
2P-4432	Gear-Ring	418-9583
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-4611	Pipe-Exhaust	365-8821
2P-5769	Coupling	394-9812
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8907	Spider As-Fan	330-9289
2P-8986	Cup-Rlr Bearing	415-1912
2S-5100	Valve-Ball	386-3049
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3E-8905	Gasket Kit	393-3617
3G-1853	Cyl Gp-076 406 Y	415-1895
3G-4752	Cyl Gp-035-060-Y	390-0987
3L-1425	Bearing-Ball	311-9356
3P-0114	Elbow-Exhaust	314-8516

87V		
Original Part Number	Part Name	Classic Part Number
3P-0165	Pulley-Fan Drive	298-2775
3P-0296	Gear	416-2149
3P-0297	Shaft As	275-5297
3P-0298	Carrier-Input	384-5922
3P-0329	Drum As-Gear	380-7484
3P-0726	Shaft As	275-5298
3P-0786	Coupling	433-0440
3P-0801	Plate-Clutch	383-2119
3P-0951	Bearing-Spl Ball	416-2159
3P-3424	Shaft	416-5526
3P-5349	Piston As	275-5292
3P-5737	Shaft As-Clutch	275-5273
3P-5955	Disc-Friction	428-7205
3T-2095	Bearing-Sleeve	384-3459
4B-1455	Cap As-Filler	361-1719
4D-2619	Bearing	417-4494
4K-7463	Seal-Lip Type	472-8007
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8942	Muffler As	298-2786
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

Sales Model 120G (Cont'd.)

87V		
Original Part Number	Part Name	Classic Part Number
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5D-9745	Shoe-Guide	330-9285
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5K-0990	Pin	299-2035
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

87V		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0735	Chain Gp	390-5262
5T-0906	Cover	282-6625
5T-0925	Actuator Gp-Bk	379-0198
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-5415	Plate	382-8043
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-7213	Carrier-Planet	396-9936
6G-8425	Valve Gp-Cont -K	367-6086
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422

87V		
Original Part Number	Part Name	Classic Part Number
6N-1878	Muffler As	360-7883
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-2090	Base-Xmsn O Fil	397-5049
6V-0600	Gasket Kit	437-4583
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6V-5976	Kit-Gasket (Rs)	393-5200
6Y-0305	Cage As-Bearing	297-7150
6Y-0306	Bearing-Sleeve	391-1104
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-5861	Adapter	243-0364
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-9547	Pin As.-Drawbar	295-0414
7G-3451	Gear-Planet	297-7188
7G-3452	Gear-Planet	275-5290
7G-3461	Gear-Planet	275-5291
7J-3351	Head	380-1515
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581

Sales Model 120G (Cont'd.)

87V		
Original Part Number	Part Name	Classic Part Number
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-3536	Gear-Fuel	279-4993
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-8576	Bearing As	435-4848
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-9647	Piston-Clutch	275-5294
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8D-0983	Mounting	384-3470
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7284	Bearing	330-9252
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8572	Bearing-Sleeve	380-7384

87V		
Original Part Number	Part Name	Classic Part Number
8D-8633	Shaft-Drive	275-5281
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-1616	Lever	330-9271
8J-1624	Valve As	390-0997
8J-2022	Piston As-Pump	367-6073
8J-6296	Shaft	419-6072
8J-6322	Cup-Roller Brg	399-4447
8J-6384	Bearing-Sleeve	472-8034
8J-8590	Cyl Gp-076 274 Y	430-5963
8M-3368	Valve-Check	388-6599
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623

87V		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1656	Plate-Clutch	367-6071
8P-5961	Gear-Ring	385-6137
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8T-1606	Kit-Gskt-Sch	386-3046
8T-9486	Gasket Kt	393-5197
8W-0328	Cylinder-Damper	419-4715
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2307	Shaft-Planet	275-5284
8W-3589	Link As-Spring	380-7389

Sales Model 120G (Cont'd.)

87V		
Original Part Number	Part Name	Classic Part Number
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-8628	Spindle-Fr Axle	282-6571
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
9B-1320	Valve-Check	377-5832
9D-1491	Coupling	416-2121
9D-1511	Bearing-Sleeve	333-4943
9D-1512	Bearing-Sleeve	333-4944
9D-1589	Mounting	387-2928
9D-2756	Insert	333-4949
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9J-3466	Cyl Gp-028 121 Y	393-0913
9M-1853	Mount As.	376-3638
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891

87V		
Original Part Number	Part Name	Classic Part Number
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-1337	Ring Kit-Pstn	377-5834
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
139-0683	Gasket Kit	390-5290
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549
148-7455	Valve - Exhaust	270-4361

87V		
Original Part Number	Part Name	Classic Part Number
153-3580	Shaft	299-2055
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0556	Kit-Rebuild-Pump	383-3712
170-0560	Rebuild Kit-Pump	363-7458
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7772	Pump Gp-Water -B	438-2009
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
184-9843	Head	347-0461
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-3986	Gasket Kit	390-5275
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
234-7996	Kit-Gasket-Sch	437-8665
234-8013	Kit-Gasket-Sch	437-8650
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
246-5916	Kit-Seal-H.Cyl-1	472-8026
250-6556	Kit-Liner-Cla	250-6564
250-6557	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356

Sales Model 120G (Cont'd.)

87V		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
288-2552	Kit-Gasket-Txg	391-9884
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988

87V		
Original Part Number	Part Name	Classic Part Number
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

87V		
Original Part Number	Part Name	Classic Part Number
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 120H

124		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2G-1034	Valve-Safety	380-7555
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6377	Sprocket	275-5286
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049

124		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-0735	Chain Gp	390-5262
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-8367	Strip-Wear	297-7263
6F-2956	Cup-Spl Tapered	420-6538
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6H-2577	Spider Gp-Brg&	333-4954
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576

124		
Original Part Number	Part Name	Classic Part Number
6K-4193	Plate-Lock	282-6566
6Y-9960	Mount As.	376-3639
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7W-5095	Gear-Flywheel	425-9190
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8805	Cover	299-2002
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-4652	Housing-Spindle	385-7215

Sales Model 120H (Cont'd.)

124		
Original Part Number	**Part Name**	**Classic Part Number**
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500

124		
Original Part Number	**Part Name**	**Classic Part Number**
9S-6147	Body As	369-9499
9T-2387	Rod As	393-5218
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
104-8655	Bearing-Sleeve	391-9892
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
110-4652	Housing	302-2683
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
115-4072	Bearing	397-5069
124-3240	Pin	282-6548
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549

124		
Original Part Number	**Part Name**	**Classic Part Number**
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
154-8030	Gasket	394-0894
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

2AN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7115	Mount As	418-1936
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-4369	Pulley-Alt	296-1340
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955

2AN		
Original Part Number	**Part Name**	**Classic Part Number**
2D-2654	Ring-Lock	380-1488
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2858	Cap-Pivot	243-0345
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-7309	Shaft	393-3682

2AN		
Original Part Number	**Part Name**	**Classic Part Number**
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-7464	Insert-Bolt	386-4918
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8616	Pin	282-6554
2G-8617	Pin	282-6555
2G-8620	Pin	282-6556
2G-8621	Pin	282-6557
2G-8628	Pin	282-6559
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561

Sales Model 120H (Cont'd.)

2AN		
Original Part Number	Part Name	Classic Part Number
2G-8736	Bearing-Sleeve	299-1959
2G-8769	Pin	282-6562
2G-9097	Cap	418-1926
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-8907	Spider As-Fan	330-9289
2P-8986	Cup-Rlr Bearing	415-1912
2S-5100	Valve-Ball	386-3049
2W-7213	Bearing-Sleeve	419-4667
3J-6575	Trunnion	297-7265
3Y-2768	Ring	439-4544
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4P-5433	Compressor As	419-4728
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5K-0990	Pin	299-2035
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-8367	Strip-Wear	297-7263

2AN		
Original Part Number	Part Name	Classic Part Number
5T-8739	Spider Gp-Brg&	373-5386
6D-5415	Plate	382-8043
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-7213	Carrier-Planet	396-9936
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-1099	Manifold-Exh	424-6366
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-5861	Adapter	243-0364
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449

2AN		
Original Part Number	Part Name	Classic Part Number
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7J-3351	Head	380-1515
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7K-9348	Pin	252-6872
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8S-0248	Breather As	325-6033
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2307	Shaft-Planet	275-5284

Sales Model 120H (Cont'd.)

2AN		
Original Part Number	**Part Name**	**Classic Part Number**
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8289	Sprocket	282-6629
8W-8628	Spindle-Fr Axle	282-6571
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1511	Bearing-Sleeve	333-4943
9D-1512	Bearing-Sleeve	333-4944
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-2756	Insert	333-4949
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-3581	Cup-Roller Brg	415-1923

2AN		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3582	Cone-Roller Brg	396-4144
9T-2387	Rod As	393-5218
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-1738	Manifold-Exhaust	374-4692
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3240	Pin	282-6548
126-5875	Flywheel As.	374-4694
131-3736	Socket Gp-Basic	325-6211

2AN		
Original Part Number	**Part Name**	**Classic Part Number**
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
163-1387	Gear-Flywheel	374-4697
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
352-2153	Pump As-Water	433-0444

3GR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147

3GR		
Original Part Number	**Part Name**	**Classic Part Number**
1P-2662	Cone-Roller Brg	374-1851
1S-7057	Gasket	420-6384

3GR		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
2D-9454	Cup-Roller Brg	415-1914
2G-1034	Valve-Safety	380-7555

Sales Model 120H (Cont'd.)

3GR		
Original Part Number	Part Name	Classic Part Number
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
2W-7213	Bearing-Sleeve	419-4667
4M-6107	Bearing-Roller	380-7507
4P-5433	Compressor As	419-4728
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
5K-0989	Cap-Upper	297-7158
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5T-1362	Univ Joint As-5C	325-6011
6F-2956	Cup-Spl Tapered	420-6538
6G-1908	Housing As-Drive	297-7198
6G-7213	Carrier-Planet	396-9936
6I-1099	Manifold-Exh	424-6366
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

3GR		
Original Part Number	Part Name	Classic Part Number
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9804	Housing-Drive	302-2682
8H-2810	Case As-Filter	314-8512
8M-3368	Valve-Check	388-6599
8S-0248	Breather As	325-6033
8W-2307	Shaft-Planet	275-5284
8W-5092	Pinion-Circle Dr	282-6569
8W-8289	Sprocket	282-6629
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9M-2042	Race-Roller Brg	417-9500
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926

3GR		
Original Part Number	Part Name	Classic Part Number
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
105-3196	Motor Gp-Grtr	282-6547
107-7708	Bearing-Main	419-6381
112-5495	Joint Gp-Univ	297-4858
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
136-0819	Valve-Exhaust	384-8697
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-3309	Spindle	282-6628
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
307-1961	Plate	472-8031
312-0782	Worm-Circ Drv	282-6623
352-2153	Pump As-Water	433-0444

4MK		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272

4MK		
Original Part Number	Part Name	Classic Part Number
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147

Sales Model 120H (Cont'd.)

4MK		
Original Part Number	**Part Name**	**Classic Part Number**
1P-2662	Cone-Roller Brg	374-1851
1P-7115	Mount As	418-1936
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-1064	Gear-Flywheel	374-4703
1W-4369	Pulley-Alt	296-1340
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2858	Cap-Pivot	243-0345
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6377	Sprocket	275-5286
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-7464	Insert-Bolt	386-4918
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8616	Pin	282-6554
2G-8617	Pin	282-6555
2G-8620	Pin	282-6556
2G-8621	Pin	282-6557
2G-8628	Pin	282-6559
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8736	Bearing-Sleeve	299-1959
2G-8769	Pin	282-6562
2G-9097	Cap	418-1926

4MK		
Original Part Number	**Part Name**	**Classic Part Number**
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469
2N-1599	Gear	378-3970
2N-2139	Cone-Roller Brg	415-1911
2P-8907	Spider As-Fan	330-9289
2P-8986	Cup-Rlr Bearing	415-1912
2S-5100	Valve-Ball	386-3049
2W-7213	Bearing-Sleeve	419-4667
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5K-0990	Pin	299-2035
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5T-0735	Chain Gp	390-5262
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-8367	Strip-Wear	297-7263

4MK		
Original Part Number	**Part Name**	**Classic Part Number**
5T-8739	Spider Gp-Brg&	373-5386
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-7213	Carrier-Planet	396-9936
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-1099	Manifold-Exh	424-6366
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-5861	Adapter	243-0364
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297

Sales Model 120H (Cont'd.)

4MK		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8S-0248	Breather As	325-6033
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732

4MK		
Original Part Number	Part Name	Classic Part Number
8W-2307	Shaft-Planet	275-5284
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-8628	Spindle-Fr Axle	282-6571
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1511	Bearing-Sleeve	333-4943
9D-1512	Bearing-Sleeve	333-4944
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-2756	Insert	333-4949
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-2387	Rod As	393-5218
9T-5729	Cyl Gp-0038 0158	422-2486

4MK		
Original Part Number	Part Name	Classic Part Number
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-1738	Manifold-Exhaust	374-4692
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3240	Pin	282-6548
126-5875	Flywheel As.	374-4694
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549

Motor Graders

Sales Model 120H (Cont'd.)

4MK		
Original Part Number	**Part Name**	**Classic Part Number**
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
163-1387	Gear-Flywheel	374-4697
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024

4MK		
Original Part Number	**Part Name**	**Classic Part Number**
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031

4MK		
Original Part Number	**Part Name**	**Classic Part Number**
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

5FM		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7115	Mount As	418-1936
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6377	Sprocket	275-5286
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350

5FM		
Original Part Number	**Part Name**	**Classic Part Number**
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2W-7213	Bearing-Sleeve	419-4667
4K-3004	Bearing-Trun Sup	314-8632
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467

5FM		
Original Part Number	**Part Name**	**Classic Part Number**
5S-9080	Pulley-Alt Drive	264-5883
5T-0735	Chain Gp	390-5262
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-7213	Carrier-Planet	396-9936
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-1099	Manifold-Exh	424-6366
6I-1240	Governor As	380-7538

Sales Model 120H (Cont'd.)

5FM		
Original Part Number	Part Name	Classic Part Number
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-2202	Bearing-Spl Ball	380-1574
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7K-2135	Bearing-Roller	417-4492
7P-1577	Pin As	375-9969
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251

5FM		
Original Part Number	Part Name	Classic Part Number
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8S-0248	Breather As	325-6033
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2307	Shaft-Planet	275-5284
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335

5FM		
Original Part Number	Part Name	Classic Part Number
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-2387	Rod As	393-5218
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-0017	Cylinder	416-2130
105-1738	Manifold-Exhaust	374-4692
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
112-5495	Joint Gp-Univ	297-4858
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3240	Pin	282-6548
126-5875	Flywheel As.	374-4694
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627

Motor Graders

Sales Model 120H (Cont'd.)

5FM		
Original Part Number	**Part Name**	**Classic Part Number**
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
178-3086	Ballstud	374-1453
184-9843	Head	347-0461

5FM		
Original Part Number	**Part Name**	**Classic Part Number**
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912

5FM		
Original Part Number	**Part Name**	**Classic Part Number**
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

6NM		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7115	Mount As	418-1936
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2858	Cap-Pivot	243-0345
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6377	Sprocket	275-5286
2G-7309	Shaft	393-3682

6NM		
Original Part Number	**Part Name**	**Classic Part Number**
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-7464	Insert-Bolt	386-4918
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9097	Cap	418-1926
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2W-7213	Bearing-Sleeve	419-4667
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4P-5433	Compressor As	419-4728
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603

6NM		
Original Part Number	**Part Name**	**Classic Part Number**
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5T-0735	Chain Gp	390-5262
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6D-5415	Plate	382-8043
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337

Sales Model 120H (Cont'd.)

6NM		
Original Part Number	Part Name	Classic Part Number
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-7213	Carrier-Planet	396-9936
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-1099	Manifold-Exh	424-6366
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-5861	Adapter	243-0364
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583

6NM		
Original Part Number	Part Name	Classic Part Number
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8S-0248	Breather As	325-6033
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2307	Shaft-Planet	275-5284
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8286	Sprocket	299-2061

6NM		
Original Part Number	Part Name	Classic Part Number
8W-8289	Sprocket	282-6629
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1511	Bearing-Sleeve	333-4943
9D-1512	Bearing-Sleeve	333-4944
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-2756	Insert	333-4949
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-2387	Rod As	393-5218
9T-5729	Cyl Gp-0038 0158	422-2486
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-0017	Cylinder	416-2130
105-1738	Manifold-Exhaust	374-4692
105-2094	Cyl Gp-0076 1194	423-7868

Motor Graders

Sales Model 120H (Cont'd.)

6NM		
Original Part Number	Part Name	Classic Part Number
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
112-5495	Joint Gp-Univ	297-4858
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3240	Pin	282-6548
126-5875	Flywheel As.	374-4694
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627

6NM		
Original Part Number	Part Name	Classic Part Number
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
163-1387	Gear-Flywheel	374-4697
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371

6NM		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
352-2153	Pump As-Water	433-0444

6TM		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7115	Mount As	418-1936
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6377	Sprocket	275-5286
2G-7309	Shaft	393-3682

6TM		
Original Part Number	Part Name	Classic Part Number
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2W-7213	Bearing-Sleeve	419-4667
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-7790	Shaft As-Arm	457-4596

6TM		
Original Part Number	Part Name	Classic Part Number
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5T-0735	Chain Gp	390-5262
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-8367	Strip-Wear	297-7263

Sales Model 120H (Cont'd.)

6TM		
Original Part Number	Part Name	Classic Part Number
5T-8739	Spider Gp-Brg&	373-5386
6D-5415	Plate	382-8043
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-7213	Carrier-Planet	396-9936
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-1099	Manifold-Exh	424-6366
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449

6TM		
Original Part Number	Part Name	Classic Part Number
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7K-2135	Bearing-Roller	417-4492
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8S-0248	Breather As	325-6033
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2307	Shaft-Planet	275-5284
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215

6TM		
Original Part Number	Part Name	Classic Part Number
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-2387	Rod As	393-5218
9T-5729	Cyl Gp-0038 0158	422-2486
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-0017	Cylinder	416-2130

Motor Graders

Sales Model 120H (Cont'd.)

6TM		
Original Part Number	**Part Name**	**Classic Part Number**
105-1738	Manifold-Exhaust	374-4692
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
112-5495	Joint Gp-Univ	297-4858
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3240	Pin	282-6548
126-5875	Flywheel As.	374-4694
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
136-0819	Valve-Exhaust	384-8697

6TM		
Original Part Number	**Part Name**	**Classic Part Number**
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370

6TM		
Original Part Number	**Part Name**	**Classic Part Number**
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

6YN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7115	Mount As	418-1936
1S-7057	Gasket	420-6384
1U-3998	Seal As	472-8005
1W-4369	Pulley-Alt	296-1340
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555

6YN		
Original Part Number	**Part Name**	**Classic Part Number**
2G-2858	Cap-Pivot	243-0345
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6377	Sprocket	275-5286
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-7464	Insert-Bolt	386-4918
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8616	Pin	282-6554
2G-8617	Pin	282-6555
2G-8620	Pin	282-6556
2G-8621	Pin	282-6557
2G-8628	Pin	282-6559
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561

6YN		
Original Part Number	**Part Name**	**Classic Part Number**
2G-8736	Bearing-Sleeve	299-1959
2G-8769	Pin	282-6562
2G-9097	Cap	418-1926
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-8907	Spider As-Fan	330-9289
2P-8986	Cup-Rlr Bearing	415-1912
2S-5100	Valve-Ball	386-3049
2W-7213	Bearing-Sleeve	419-4667
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-7790	Shaft As-Arm	457-4596

Sales Model 120H (Cont'd.)

6YN		
Original Part Number	**Part Name**	**Classic Part Number**
4P-8577	Rod As-Injector	455-5513
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5K-0990	Pin	299-2035
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5T-0735	Chain Gp	390-5262
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6D-5415	Plate	382-8043
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-7213	Carrier-Planet	396-9936
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-1099	Manifold-Exh	424-6366
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898

6YN		
Original Part Number	**Part Name**	**Classic Part Number**
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-5861	Adapter	243-0364
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341

6YN		
Original Part Number	**Part Name**	**Classic Part Number**
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8S-0248	Breather As	325-6033
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2307	Shaft-Planet	275-5284
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-8628	Spindle-Fr Axle	282-6571
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814

Motor Graders

Sales Model 120H (Cont'd.)

6YN		
Original Part Number	**Part Name**	**Classic Part Number**
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1511	Bearing-Sleeve	333-4943
9D-1512	Bearing-Sleeve	333-4944
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-2756	Insert	333-4949
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-2387	Rod As	393-5218
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834

6YN		
Original Part Number	**Part Name**	**Classic Part Number**
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-0017	Cylinder	416-2130
105-1738	Manifold-Exhaust	374-4692
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
112-5495	Joint Gp-Univ	297-4858
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3240	Pin	282-6548
126-5875	Flywheel As.	374-4694
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549

6YN		
Original Part Number	**Part Name**	**Classic Part Number**
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
163-1387	Gear-Flywheel	374-4697
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

9FN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914

9FN		
Original Part Number	**Part Name**	**Classic Part Number**
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811

9FN		
Original Part Number	**Part Name**	**Classic Part Number**
2G-8633	Pin	282-6561
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010

Sales Model 120H (Cont'd.)

9FN		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-9514	Bearing-Ball	417-9467
5T-0735	Chain Gp	390-5262
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
6F-2956	Cup-Spl Tapered	420-6538
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-7213	Carrier-Planet	396-9936
6I-8642	Race-Brg Outer	396-9898
6V-2202	Bearing-Spl Ball	380-1574
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7G-0437	Plate-Clutch	417-9466
7K-2135	Bearing-Roller	417-4492
8D-2429	Pin As	319-3445
8D-5949	Stud	416-5492
8D-7996	Bearing-Sleeve	472-8018

9FN		
Original Part Number	Part Name	Classic Part Number
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2307	Shaft-Planet	275-5284
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-9566	Flange As	376-9073
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
9D-1491	Coupling	416-2121

9FN		
Original Part Number	Part Name	Classic Part Number
9D-3242	Cone-Roller Brg	453-3659
9M-2042	Race-Roller Brg	417-9500
9T-2387	Rod As	393-5218
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549
148-2593	Head	383-1591
153-3580	Shaft	299-2055
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

9YR		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7115	Mount As	418-1936
1S-7057	Gasket	420-6384

9YR		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273

9YR		
Original Part Number	Part Name	Classic Part Number
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2858	Cap-Pivot	243-0345
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550

Sales Model 120H (Cont'd.)

9YR		
Original Part Number	Part Name	Classic Part Number
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6377	Sprocket	275-5286
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-7464	Insert-Bolt	386-4918
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9097	Cap	418-1926
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2W-7213	Bearing-Sleeve	419-4667
4K-3004	Bearing-Trun Sup	314-8632
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4P-5433	Compressor As	419-4728
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5T-0735	Chain Gp	390-5262

9YR		
Original Part Number	Part Name	Classic Part Number
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-7213	Carrier-Planet	396-9936
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-1099	Manifold-Exh	424-6366
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025

9YR		
Original Part Number	Part Name	Classic Part Number
7D-5861	Adapter	243-0364
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8J-6384	Bearing-Sleeve	472-8034

Sales Model 120H (Cont'd.)

9YR		
Original Part Number	Part Name	Classic Part Number
8M-3368	Valve-Check	388-6599
8S-0248	Breather As	325-6033
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2307	Shaft-Planet	275-5284
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1511	Bearing-Sleeve	333-4943
9D-1512	Bearing-Sleeve	333-4944
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-2756	Insert	333-4949
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822

9YR		
Original Part Number	Part Name	Classic Part Number
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-2387	Rod As	393-5218
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-0017	Cylinder	416-2130
105-1738	Manifold-Exhaust	374-4692
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
112-5495	Joint Gp-Univ	297-4858
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3240	Pin	282-6548

9YR		
Original Part Number	Part Name	Classic Part Number
126-5875	Flywheel As.	374-4694
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
163-1387	Gear-Flywheel	374-4697
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
352-2153	Pump As-Water	433-0444

ADG		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272

ADG		
Original Part Number	Part Name	Classic Part Number
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147

Sales Model 120H (Cont'd.)

ADG		
Original Part Number	**Part Name**	**Classic Part Number**
1P-2662	Cone-Roller Brg	374-1851
1P-7115	Mount As	418-1936
1S-7057	Gasket	420-6384
1U-3998	Seal As	472-8005
1W-4369	Pulley-Alt	296-1340
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2858	Cap-Pivot	243-0345
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6377	Sprocket	275-5286
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-7464	Insert-Bolt	386-4918
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8616	Pin	282-6554
2G-8617	Pin	282-6555
2G-8620	Pin	282-6556
2G-8621	Pin	282-6557
2G-8628	Pin	282-6559
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8736	Bearing-Sleeve	299-1959
2G-8769	Pin	282-6562
2G-9097	Cap	418-1926
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350

ADG		
Original Part Number	**Part Name**	**Classic Part Number**
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-8907	Spider As-Fan	330-9289
2P-8986	Cup-Rlr Bearing	415-1912
2S-5100	Valve-Ball	386-3049
2W-7213	Bearing-Sleeve	419-4667
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5K-0990	Pin	299-2035
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5T-0735	Chain Gp	390-5262
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6D-5415	Plate	382-8043
6F-2956	Cup-Spl Tapered	420-6538
6G-1908	Housing As-Drive	297-7198

ADG		
Original Part Number	**Part Name**	**Classic Part Number**
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-7213	Carrier-Planet	396-9936
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-1099	Manifold-Exh	424-6366
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-5861	Adapter	243-0364
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922

Sales Model 120H (Cont'd.)

ADG		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8S-0248	Breather As	325-6033
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2307	Shaft-Planet	275-5284
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629

ADG		
Original Part Number	Part Name	Classic Part Number
8W-8628	Spindle-Fr Axle	282-6571
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1511	Bearing-Sleeve	333-4943
9D-1512	Bearing-Sleeve	333-4944
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-2756	Insert	333-4949
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-2387	Rod As	393-5218
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-0017	Cylinder	416-2130
105-1738	Manifold-Exhaust	374-4692
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565

ADG		
Original Part Number	Part Name	Classic Part Number
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
110-4652	Housing	302-2683
112-5495	Joint Gp-Univ	297-4858
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3240	Pin	282-6548
126-5875	Flywheel As.	374-4694
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
163-1387	Gear-Flywheel	374-4697
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
300-9500	Kit-Gasket-Sch	387-2914

Sales Model 120H (Cont'd.)

ADG		
Original Part Number	**Part Name**	**Classic Part Number**
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

ADG		
Original Part Number	**Part Name**	**Classic Part Number**
319-2228	Shoe-Circle Gde	419-4706
352-2151	Pump Gp-Water -B	434-6107

ADG		
Original Part Number	**Part Name**	**Classic Part Number**
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

CAF		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273
2D-9454	Cup-Roller Brg	415-1914
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6377	Sprocket	275-5286
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911

CAF		
Original Part Number	**Part Name**	**Classic Part Number**
2S-5100	Valve-Ball	386-3049
2W-7213	Bearing-Sleeve	419-4667
3J-6575	Trunnion	297-7265
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4S-8472	Hood As-Preclnr	296-1355
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5T-0735	Chain Gp	390-5262
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-8367	Strip-Wear	297-7263
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-7213	Carrier-Planet	396-9936
6H-2577	Spider Gp-Brg&	333-4954

CAF		
Original Part Number	**Part Name**	**Classic Part Number**
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6Y-9960	Mount As.	376-3639
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7W-5095	Gear-Flywheel	425-9190
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9296	Bearing	330-9253

Sales Model 120H (Cont'd.)

CAF		
Original Part Number	Part Name	Classic Part Number
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2307	Shaft-Planet	275-5284
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659

CAF		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-6147	Body As	369-9499
9T-2387	Rod As	393-5218
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
115-4072	Bearing	397-5069
124-3240	Pin	282-6548
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
133-4995	Gasket-Cyl Head	434-2445
135-7393	Head	382-6895
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

CAF		
Original Part Number	Part Name	Classic Part Number
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549
148-2593	Head	383-1591
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985
153-3580	Shaft	299-2055
154-8030	Gasket	394-0894
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
246-5916	Kit-Seal-H.Cyl-1	472-8026
252-5650	Rim As	397-5067
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

Sales Model 120K

E9C		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2G-4011	Collar	330-9269

E9C		
Original Part Number	Part Name	Classic Part Number
2G-6157	Pin	282-6550
2G-7309	Shaft	393-3682
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350

E9C		
Original Part Number	Part Name	Classic Part Number
2S-5100	Valve-Ball	386-3049
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5K-0984	Bearing-Sleeve	330-9262

Motor Graders

Sales Model 120K (Cont'd.)

E9C		
Original Part Number	**Part Name**	**Classic Part Number**
6F-6992	Cap-Ballsocket	297-7160
6G-1914	Shim	434-1864
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6Y-9960	Mount As.	376-3639
7G-0437	Plate-Clutch	417-9466
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384

E9C		
Original Part Number	**Part Name**	**Classic Part Number**
8D-9815	Pin-Cylinder	297-7220
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500

E9C		
Original Part Number	**Part Name**	**Classic Part Number**
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
124-3240	Pin	282-6548
148-2593	Head	383-1591
153-3580	Shaft	299-2055
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
319-2228	Shoe-Circle Gde	419-4706

E9H		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010

E9H		
Original Part Number	**Part Name**	**Classic Part Number**
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-1362	Univ Joint As-5C	325-6011
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1914	Shim	434-1864
6G-7213	Carrier-Planet	396-9936
6H-2577	Spider Gp-Brg&	333-4954
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6Y-9960	Mount As.	376-3639
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018

E9H		
Original Part Number	**Part Name**	**Classic Part Number**
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-9296	Bearing	330-9253
8D-9815	Pin-Cylinder	297-7220
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2307	Shaft-Planet	275-5284
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-8285	Cap	391-9822
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
005-8639	Bearing-Aligning	415-1925

Sales Model 120K (Cont'd.)

E9H		
Original Part Number	**Part Name**	**Classic Part Number**
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
124-3240	Pin	282-6548
148-2593	Head	383-1591

E9H		
Original Part Number	**Part Name**	**Classic Part Number**
153-3580	Shaft	299-2055
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

E9H		
Original Part Number	**Part Name**	**Classic Part Number**
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
319-2228	Shoe-Circle Gde	419-4706

E9N		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-7309	Shaft	393-3682
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2S-5100	Valve-Ball	386-3049
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5K-0984	Bearing-Sleeve	330-9262
6F-6992	Cap-Ballsocket	297-7160
6G-1914	Shim	434-1864
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161

E9N		
Original Part Number	**Part Name**	**Classic Part Number**
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6Y-9960	Mount As.	376-3639
7G-0437	Plate-Clutch	417-9466
7P-1577	Pin As	375-9969
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9296	Bearing	330-9253
8D-9815	Pin-Cylinder	297-7220
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-6324	Kit-Wear Strip	424-0739
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121

E9N		
Original Part Number	**Part Name**	**Classic Part Number**
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-8285	Cap	391-9822
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
124-3240	Pin	282-6548
148-2593	Head	383-1591
153-3580	Shaft	299-2055
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
319-2228	Shoe-Circle Gde	419-4706

JAP		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834

JAP		
Original Part Number	**Part Name**	**Classic Part Number**
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
2A-4429	Lock-Retainer	379-0174

JAP		
Original Part Number	**Part Name**	**Classic Part Number**
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-4011	Collar	330-9269

Sales Model 120K (Cont'd.)

JAP		
Original Part Number	**Part Name**	**Classic Part Number**
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6377	Sprocket	275-5286
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930

JAP		
Original Part Number	**Part Name**	**Classic Part Number**
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-9514	Bearing-Ball	417-9467
5T-0735	Chain Gp	390-5262
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-5704	Piston	394-9838
6G-7213	Carrier-Planet	396-9936
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276

JAP		
Original Part Number	**Part Name**	**Classic Part Number**
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7W-5095	Gear-Flywheel	425-9190
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734

Sales Model 120K (Cont'd.)

JAP		
Original Part Number	Part Name	Classic Part Number
8W-2307	Shaft-Planet	275-5284
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
8Y-0809	Spider Gp-Brg&	417-4526
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-8285	Cap	391-9822
9M-1328	Bearing-Aligning	325-6018

JAP		
Original Part Number	Part Name	Classic Part Number
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-2387	Rod As	393-5218
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
104-8655	Bearing-Sleeve	391-9892
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
115-4072	Bearing	397-5069
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
133-4995	Gasket-Cyl Head	434-2445
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
147-3309	Spindle	282-6628

JAP		
Original Part Number	Part Name	Classic Part Number
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
200-7929	Housing	416-5489
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

N9H		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1T-0043	Bearing-Ball	390-5294

N9H		
Original Part Number	Part Name	Classic Part Number
1U-3998	Seal As	472-8005
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2G-4011	Collar	330-9269

N9H		
Original Part Number	Part Name	Classic Part Number
2G-6157	Pin	282-6550
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350

Sales Model 120K (Cont'd.)

N9H		
Original Part Number	**Part Name**	**Classic Part Number**
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-1362	Univ Joint As-5C	325-6011
6F-2956	Cup-Spl Tapered	420-6538
6G-1914	Shim	434-1864
6G-7213	Carrier-Planet	396-9936
6H-2577	Spider Gp-Brg&	333-4954
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161

N9H		
Original Part Number	**Part Name**	**Classic Part Number**
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
8D-5949	Stud	416-5492
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-9296	Bearing	330-9253
8D-9815	Pin-Cylinder	297-7220
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-2307	Shaft-Planet	275-5284
8W-6324	Kit-Wear Strip	424-0739
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-8285	Cap	391-9822

N9H		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9W-9930	Mount As	295-6437
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
124-3240	Pin	282-6548
148-2593	Head	383-1591
153-3580	Shaft	299-2055
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
319-2228	Shoe-Circle Gde	419-4706

N9N		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8631	Bearing-Sleeve	391-9811

N9N		
Original Part Number	**Part Name**	**Classic Part Number**
2G-8633	Pin	282-6561
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
6F-2956	Cup-Spl Tapered	420-6538

N9N		
Original Part Number	**Part Name**	**Classic Part Number**
6F-6992	Cap-Ballsocket	297-7160
6G-1914	Shim	434-1864
6G-7213	Carrier-Planet	396-9936
6H-2577	Spider Gp-Brg&	333-4954
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7P-1577	Pin As	375-9969
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384

Sales Model 120K (Cont'd.)

N9N		
Original Part Number	Part Name	Classic Part Number
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-9296	Bearing	330-9253
8W-1749	Plate	380-7403
8W-2307	Shaft-Planet	275-5284
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-9566	Flange As	376-9073
8X-3434	Arm As-Leaning	438-1816

N9N		
Original Part Number	Part Name	Classic Part Number
8X-3435	Arm As-Leaning	438-1814
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-3242	Cone-Roller Brg	453-3659
9D-8285	Cap	391-9822
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547

N9N		
Original Part Number	Part Name	Classic Part Number
107-8375	Shaft As	439-1134
124-3240	Pin	282-6548
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
147-3400	Spindle	282-6549
153-3580	Shaft	299-2055
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
319-2228	Shoe-Circle Gde	419-4706

N9W		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049

N9W		
Original Part Number	Part Name	Classic Part Number
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-1362	Univ Joint As-5C	325-6011
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1914	Shim	434-1864
6G-7213	Carrier-Planet	396-9936
6H-2577	Spider Gp-Brg&	333-4954
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
7G-0437	Plate-Clutch	417-9466
7P-1577	Pin As	375-9969
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251

N9W		
Original Part Number	Part Name	Classic Part Number
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-9296	Bearing	330-9253
8D-9815	Pin-Cylinder	297-7220
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-2307	Shaft-Planet	275-5284
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-8285	Cap	391-9822
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500

Motor Graders

Sales Model 120K (Cont'd.)

N9W		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9930	Mount As	295-6437
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134

N9W		
Original Part Number	**Part Name**	**Classic Part Number**
124-3240	Pin	282-6548
148-2593	Head	383-1591
153-3580	Shaft	299-2055
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

N9W		
Original Part Number	**Part Name**	**Classic Part Number**
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
319-2228	Shoe-Circle Gde	419-4706

SZN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7115	Mount As	418-1936
1U-3998	Seal As	472-8005
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6377	Sprocket	275-5286
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469

SZN		
Original Part Number	**Part Name**	**Classic Part Number**
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
2W-7213	Bearing-Sleeve	419-4667
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-9514	Bearing-Ball	417-9467
5T-0735	Chain Gp	390-5262
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-8367	Strip-Wear	297-7263
6D-5415	Plate	382-8043
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-7213	Carrier-Planet	396-9936

SZN		
Original Part Number	**Part Name**	**Classic Part Number**
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-9960	Mount As.	376-3639
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7W-5095	Gear-Flywheel	425-9190
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018

Sales Model 120K (Cont'd.)

SZN		
Original Part Number	Part Name	Classic Part Number
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2307	Shaft-Planet	275-5284
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335

SZN		
Original Part Number	Part Name	Classic Part Number
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-8285	Cap	391-9822
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-2387	Rod As	393-5218
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
104-8655	Bearing-Sleeve	391-9892
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
115-4072	Bearing	397-5069
124-3240	Pin	282-6548
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627

SZN		
Original Part Number	Part Name	Classic Part Number
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

SZS		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486

SZS		
Original Part Number	Part Name	Classic Part Number
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-4693	Cup-Rlr Bearing	377-7398

SZS		
Original Part Number	Part Name	Classic Part Number
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005

Sales Model 120K (Cont'd.)

SZS		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6377	Sprocket	275-5286
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158

SZS		
Original Part Number	**Part Name**	**Classic Part Number**
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-3490	Cone-Rlr Bearing	380-7518
5T-0735	Chain Gp	390-5262
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1914	Shim	434-1864
6G-2947	Shaft	243-0346
6G-5704	Piston	394-9838
6G-7213	Carrier-Planet	396-9936
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6V-3831	Seal-O-Ring	436-2657
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8354	Sprocket	398-8335

SZS		
Original Part Number	**Part Name**	**Classic Part Number**
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7W-5095	Gear-Flywheel	425-9190
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4766	Pin-Cylinder	365-8832
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9296	Bearing	330-9253
8D-9815	Pin-Cylinder	297-7220
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2307	Shaft-Planet	275-5284
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569

Sales Model 120K (Cont'd.)

SZS		
Original Part Number	**Part Name**	**Classic Part Number**
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
8Y-0809	Spider Gp-Brg&	417-4526
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-8285	Cap	391-9822
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

SZS		
Original Part Number	**Part Name**	**Classic Part Number**
9T-2387	Rod As	393-5218
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
104-8655	Bearing-Sleeve	391-9892
105-3196	Motor Gp-Grtr	282-6547
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
115-4072	Bearing	397-5069
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
133-4995	Gasket-Cyl Head	434-2445
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
147-3309	Spindle	282-6628
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696

SZS		
Original Part Number	**Part Name**	**Classic Part Number**
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
200-7929	Housing	416-5489
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

SZZ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7115	Mount As	418-1936
1U-3998	Seal As	472-8005
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488

SZZ		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9454	Cup-Roller Brg	415-1914
2G-1034	Valve-Safety	380-7555
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6377	Sprocket	275-5286
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258

SZZ		
Original Part Number	**Part Name**	**Classic Part Number**
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469

Sales Model 120K (Cont'd.)

SZZ		
Original Part Number	Part Name	Classic Part Number
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
2W-7213	Bearing-Sleeve	419-4667
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-0735	Chain Gp	390-5262
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1914	Shim	434-1864
6G-2947	Shaft	243-0346
6G-7213	Carrier-Planet	396-9936
6H-2577	Spider Gp-Brg&	333-4954
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6V-3831	Seal-O-Ring	436-2657
6Y-9960	Mount As.	376-3639
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449

SZZ		
Original Part Number	Part Name	Classic Part Number
7E-8926	Head Kt-Cyl	377-5847
7G-0437	Plate-Clutch	417-9466
7W-5095	Gear-Flywheel	425-9190
8D-2429	Pin As	319-3445
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9815	Pin-Cylinder	297-7220
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2307	Shaft-Planet	275-5284
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-9566	Flange As	376-9073
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500

SZZ		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-2387	Rod As	393-5218
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
105-3196	Motor Gp-Grtr	282-6547
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
115-4072	Bearing	397-5069
124-3240	Pin	282-6548
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

Sales Model 120K (Cont'd.)

SZZ		
Original Part Number	Part Name	Classic Part Number
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032

SZZ		
Original Part Number	Part Name	Classic Part Number
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

Sales Model 120M

B9C		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
3J-6575	Trunnion	297-7265
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262

B9C		
Original Part Number	Part Name	Classic Part Number
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6I-8642	Race-Brg Outer	396-9898
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-0347	Cone-Spl Tapered	420-6537
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-5344	Gear-Worm	243-0341
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9296	Bearing	330-9253

B9C		
Original Part Number	Part Name	Classic Part Number
8D-9804	Housing-Drive	302-2682
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-2754	Insert	333-4948
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
9T-5729	Cyl Gp-0038 0158	422-2486
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
135-7393	Head	382-6895
148-2593	Head	383-1591
152-6485	Cyl Gp-102 472 Y	390-0985
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

Motor Graders

Sales Model 120M (Cont'd.)

B9N		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614

B9N		
Original Part Number	**Part Name**	**Classic Part Number**
5L-2031	Cup-Roller Brg	384-5927
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6I-8642	Race-Brg Outer	396-9898
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-0347	Cone-Spl Tapered	420-6537
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-5344	Gear-Worm	243-0341
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019

B9N		
Original Part Number	**Part Name**	**Classic Part Number**
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-2754	Insert	333-4948
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
9T-5729	Cyl Gp-0038 0158	422-2486
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
148-2593	Head	383-1591
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

B9W		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-9110	Bearing-Needle	420-2497

B9W		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488

B9W		
Original Part Number	**Part Name**	**Classic Part Number**
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811

Sales Model 120M (Cont'd.)

B9W		
Original Part Number	Part Name	Classic Part Number
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898

B9W		
Original Part Number	Part Name	Classic Part Number
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-0347	Cone-Spl Tapered	420-6537
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9296	Bearing	330-9253
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569

B9W		
Original Part Number	Part Name	Classic Part Number
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
148-2593	Head	383-1591
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

CBS		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811

CBS		
Original Part Number	Part Name	Classic Part Number
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
4B-7270	Cone-Bearing	399-4439
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160

CBS		
Original Part Number	Part Name	Classic Part Number
6I-8642	Race-Brg Outer	396-9898
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-0347	Cone-Spl Tapered	420-6537
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7D-8437	Cone-Roller Brg	380-1502
7M-7219	Bearing-Thrust	384-4816
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511

Motor Graders

Sales Model 120M (Cont'd.)

CBS		
Original Part Number	**Part Name**	**Classic Part Number**
8D-8572	Bearing-Sleeve	380-7384
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335

CBS		
Original Part Number	**Part Name**	**Classic Part Number**
9D-1491	Coupling	416-2121
9M-2042	Race-Roller Brg	417-9500
002-1212	Cup-Roller Brg	399-4446
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
148-2593	Head	383-1591
178-3086	Ballstud	374-1453

CBS		
Original Part Number	**Part Name**	**Classic Part Number**
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

D9W		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
3J-6575	Trunnion	297-7265
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262

D9W		
Original Part Number	**Part Name**	**Classic Part Number**
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-0347	Cone-Spl Tapered	420-6537
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384

D9W		
Original Part Number	**Part Name**	**Classic Part Number**
8D-9296	Bearing	330-9253
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
135-7393	Head	382-6895
148-2593	Head	383-1591
152-6485	Cyl Gp-102 472 Y	390-0985
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

Sales Model 120M (Cont'd.)

M92		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
4B-7270	Cone-Bearing	399-4439
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614

M92		
Original Part Number	Part Name	Classic Part Number
5L-2031	Cup-Roller Brg	384-5927
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6I-8642	Race-Brg Outer	396-9898
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-0347	Cone-Spl Tapered	420-6537
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511

M92		
Original Part Number	Part Name	Classic Part Number
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-2042	Race-Roller Brg	417-9500
9W-9931	Mount As.	360-2354
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
148-2593	Head	383-1591
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

M9C		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270

M9C		
Original Part Number	Part Name	Classic Part Number
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538

M9C		
Original Part Number	Part Name	Classic Part Number
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-0347	Cone-Spl Tapered	420-6537
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657

Motor Graders

Sales Model 120M (Cont'd.)

M9C		
Original Part Number	**Part Name**	**Classic Part Number**
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9296	Bearing	330-9253
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739

M9C		
Original Part Number	**Part Name**	**Classic Part Number**
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
9W-9931	Mount As.	360-2354
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134

M9C		
Original Part Number	**Part Name**	**Classic Part Number**
148-2593	Head	383-1591
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

M9H		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262

M9H		
Original Part Number	**Part Name**	**Classic Part Number**
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-0347	Cone-Spl Tapered	420-6537
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384

M9H		
Original Part Number	**Part Name**	**Classic Part Number**
8D-9296	Bearing	330-9253
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
9W-9931	Mount As.	360-2354
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
148-2593	Head	383-1591
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

Sales Model 120M (Cont'd.)

M9W		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262

M9W		
Original Part Number	Part Name	Classic Part Number
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-0347	Cone-Spl Tapered	420-6537
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384

M9W		
Original Part Number	Part Name	Classic Part Number
8D-9296	Bearing	330-9253
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
9W-9931	Mount As.	360-2354
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
148-2593	Head	383-1591
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

NJD		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7309	Shaft	393-3682

NJD		
Original Part Number	Part Name	Classic Part Number
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
4B-7270	Cone-Bearing	399-4439
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614

NJD		
Original Part Number	Part Name	Classic Part Number
5L-2031	Cup-Roller Brg	384-5927
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-0347	Cone-Spl Tapered	420-6537
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502

Sales Model 120M (Cont'd.)

NJD		
Original Part Number	**Part Name**	**Classic Part Number**
7M-7219	Bearing-Thrust	384-4816
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569

NJD		
Original Part Number	**Part Name**	**Classic Part Number**
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9M-2042	Race-Roller Brg	417-9500
002-1212	Cup-Roller Brg	399-4446
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
148-2593	Head	383-1591

NJD		
Original Part Number	**Part Name**	**Classic Part Number**
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

PJB		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
4B-7270	Cone-Bearing	399-4439
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011

PJB		
Original Part Number	**Part Name**	**Classic Part Number**
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-0347	Cone-Spl Tapered	420-6537
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7M-7219	Bearing-Thrust	384-4816
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384

PJB		
Original Part Number	**Part Name**	**Classic Part Number**
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9M-2042	Race-Roller Brg	417-9500
002-1212	Cup-Roller Brg	399-4446
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
148-2593	Head	383-1591
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

R9A		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486

R9A		
Original Part Number	**Part Name**	**Classic Part Number**
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344

Sales Model 120M (Cont'd.)

R9A		
Original Part Number	Part Name	Classic Part Number
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-0906	Cover	282-6625

R9A		
Original Part Number	Part Name	Classic Part Number
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6I-8642	Race-Brg Outer	396-9898
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-0347	Cone-Spl Tapered	420-6537
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-5344	Gear-Worm	243-0341
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9296	Bearing	330-9253

R9A		
Original Part Number	Part Name	Classic Part Number
8D-9804	Housing-Drive	302-2682
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-2754	Insert	333-4948
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
9T-5729	Cyl Gp-0038 0158	422-2486
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
148-2593	Head	383-1591
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

R9C		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020

R9C		
Original Part Number	Part Name	Classic Part Number
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811

R9C		
Original Part Number	Part Name	Classic Part Number
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788

Motor Graders

Sales Model 120M (Cont'd.)

R9C		
Original Part Number	**Part Name**	**Classic Part Number**
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-0347	Cone-Spl Tapered	420-6537
6Y-9960	Mount As.	376-3639

R9C		
Original Part Number	**Part Name**	**Classic Part Number**
7C-1371	Coupling-Exhaust	369-9490
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9296	Bearing	330-9253
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335

R9C		
Original Part Number	**Part Name**	**Classic Part Number**
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
148-2593	Head	383-1591
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

R9N		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439

R9N		
Original Part Number	**Part Name**	**Classic Part Number**
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6K-4191	Cap-Upper	300-2576

R9N		
Original Part Number	**Part Name**	**Classic Part Number**
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-0347	Cone-Spl Tapered	420-6537
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384

Sales Model 120M (Cont'd.)

R9N		
Original Part Number	Part Name	Classic Part Number
8D-9296	Bearing	330-9253
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018

R9N		
Original Part Number	Part Name	Classic Part Number
9M-2042	Race-Roller Brg	417-9500
9W-9931	Mount As.	360-2354
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
148-2593	Head	383-1591
178-3086	Ballstud	374-1453

R9N		
Original Part Number	Part Name	Classic Part Number
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

R9W		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262

R9W		
Original Part Number	Part Name	Classic Part Number
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-0347	Cone-Spl Tapered	420-6537
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384

R9W		
Original Part Number	Part Name	Classic Part Number
8D-9296	Bearing	330-9253
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
9W-9931	Mount As.	360-2354
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
148-2593	Head	383-1591
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

RMY		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988

Motor Graders

Sales Model 120M (Cont'd.)

RMY		
Original Part Number	Part Name	Classic Part Number
1M-4095	Bearing-Inner	417-9486
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
4B-7270	Cone-Bearing	399-4439
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262

RMY		
Original Part Number	Part Name	Classic Part Number
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-0347	Cone-Spl Tapered	420-6537
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7D-8437	Cone-Roller Brg	380-1502
7M-7219	Bearing-Thrust	384-4816
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384

RMY		
Original Part Number	Part Name	Classic Part Number
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9M-2042	Race-Roller Brg	417-9500
002-1212	Cup-Roller Brg	399-4446
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
148-2593	Head	383-1591
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

Sales Model 120N

E94		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2G-1034	Valve-Safety	380-7555
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550

E94		
Original Part Number	Part Name	Classic Part Number
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
4K-7463	Seal-Lip Type	472-8007

E94		
Original Part Number	Part Name	Classic Part Number
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
6F-2956	Cup-Spl Tapered	420-6538

Sales Model 120N (Cont'd.)

E94		
Original Part Number	Part Name	Classic Part Number
6F-6992	Cap-Ballsocket	297-7160
6G-1914	Shim	434-1864
6G-7213	Carrier-Planet	396-9936
6H-2577	Spider Gp-Brg&	333-4954
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018

E94		
Original Part Number	Part Name	Classic Part Number
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-9296	Bearing	330-9253
8D-9815	Pin-Cylinder	297-7220
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-2307	Shaft-Planet	275-5284
8W-6324	Kit-Wear Strip	424-0739
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-8285	Cap	391-9822
9M-1328	Bearing-Aligning	325-6018

E94		
Original Part Number	Part Name	Classic Part Number
9M-2042	Race-Roller Brg	417-9500
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
124-3240	Pin	282-6548
148-2593	Head	383-1591
153-3580	Shaft	299-2055
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
319-2228	Shoe-Circle Gde	419-4706

E95		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1T-0043	Bearing-Ball	390-5294
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2G-1034	Valve-Safety	380-7555
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350

E95		
Original Part Number	Part Name	Classic Part Number
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-1362	Univ Joint As-5C	325-6011
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1914	Shim	434-1864
6G-7213	Carrier-Planet	396-9936
6H-2577	Spider Gp-Brg&	333-4954

E95		
Original Part Number	Part Name	Classic Part Number
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6Y-9960	Mount As.	376-3639
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-9296	Bearing	330-9253
8D-9815	Pin-Cylinder	297-7220
8J-6384	Bearing-Sleeve	472-8034

Motor Graders

Sales Model 120N (Cont'd.)

E95		
Original Part Number	**Part Name**	**Classic Part Number**
8W-1749	Plate	380-7403
8W-2307	Shaft-Planet	275-5284
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-8285	Cap	391-9822
9M-1328	Bearing-Aligning	325-6018

E95		
Original Part Number	**Part Name**	**Classic Part Number**
9M-2042	Race-Roller Brg	417-9500
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
124-3240	Pin	282-6548
148-2593	Head	383-1591
153-3580	Shaft	299-2055
178-3086	Ballstud	374-1453
184-9843	Head	347-0461

E95		
Original Part Number	**Part Name**	**Classic Part Number**
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
319-2228	Shoe-Circle Gde	419-4706

Y9C		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614

Y9C		
Original Part Number	**Part Name**	**Classic Part Number**
5L-2031	Cup-Roller Brg	384-5927
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1914	Shim	434-1864
6G-7213	Carrier-Planet	396-9936
6H-2577	Spider Gp-Brg&	333-4954
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277

Y9C		
Original Part Number	**Part Name**	**Classic Part Number**
8D-9296	Bearing	330-9253
8D-9815	Pin-Cylinder	297-7220
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-2307	Shaft-Planet	275-5284
8W-6324	Kit-Wear Strip	424-0739
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-8285	Cap	391-9822
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
124-3240	Pin	282-6548
148-2593	Head	383-1591
153-3580	Shaft	299-2055
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

Sales Model 120N (Cont'd.)

Y9C		
Original Part Number	Part Name	Classic Part Number
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028

Y9C		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031

Y9C		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032
319-2228	Shoe-Circle Gde	419-4706

Y9D		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1T-0043	Bearing-Ball	390-5294
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614

Y9D		
Original Part Number	Part Name	Classic Part Number
5L-2031	Cup-Roller Brg	384-5927
5T-1362	Univ Joint As-5C	325-6011
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1914	Shim	434-1864
6G-7213	Carrier-Planet	396-9936
6H-2577	Spider Gp-Brg&	333-4954
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-9296	Bearing	330-9253
8D-9815	Pin-Cylinder	297-7220
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-2307	Shaft-Planet	275-5284

Y9D		
Original Part Number	Part Name	Classic Part Number
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-8285	Cap	391-9822
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
124-3240	Pin	282-6548
148-2593	Head	383-1591
153-3580	Shaft	299-2055
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
319-2228	Shoe-Circle Gde	419-4706

Motor Graders

Sales Model 130G

09Y		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1N-3574	Block Gp-Cyl	460-8298
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-5480	Cover As.-End	299-1998
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1U-4661	Lever Gp	396-7267
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-6810	Pipe-Outlet	472-8036
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899

09Y		
Original Part Number	**Part Name**	**Classic Part Number**
2G-2858	Cap-Pivot	243-0345
2G-5768	Gear-Bevel	388-0646
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-7464	Insert-Bolt	386-4918
2G-8238	Yoke As	282-6631
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8739	Retainer	389-6314
2G-9098	Cap	300-2573
2M-8714	Cone-Roller Brg	420-2492
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4364	Housing As-Cl	396-9928
2P-4432	Gear-Ring	418-9583
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-4611	Pipe-Exhaust	365-8821
2P-5769	Coupling	394-9812
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356

09Y		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7678	Gear-Water Pump	325-6088
3G-1853	Cyl Gp-076 406 Y	415-1895
3G-4752	Cyl Gp-035-060-Y	390-0987
3G-5223	Cyl Gp-0083-1016	399-8557
3G-5224	Cyl Gp-0083-0459	425-9375
3L-1425	Bearing-Ball	311-9356
3P-0114	Elbow-Exhaust	314-8516
3P-0165	Pulley-Fan Drive	298-2775
3P-0296	Gear	416-2149
3P-0297	Shaft As	275-5297
3P-0298	Carrier-Input	384-5922
3P-0329	Drum As-Gear	380-7484
3P-0726	Shaft As	275-5298
3P-0786	Coupling	433-0440
3P-0801	Plate-Clutch	383-2119
3P-0951	Bearing-Spl Ball	416-2159
3P-3424	Shaft	416-5526
3P-5349	Piston As	275-5292
3P-5737	Shaft As-Clutch	275-5273
3P-5955	Disc-Friction	428-7205
3T-2095	Bearing-Sleeve	384-3459
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-2619	Bearing	417-4494
4K-7463	Seal-Lip Type	472-8007
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362

Sales Model 130G (Cont'd.)

09Y		
Original Part Number	Part Name	Classic Part Number
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
5D-0470	Valve Gp-Qrel	314-8549
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5T-0906	Cover	282-6625
5T-0925	Actuator Gp-Bk	379-0198
5T-1362	Univ Joint As-5C	325-6011

09Y		
Original Part Number	Part Name	Classic Part Number
5T-7129	Housing	472-8013
5T-8500	Shoe-Circle Dr	243-0359
5T-8501	Shoe-Circle Dr	243-0358
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-8425	Valve Gp-Cont -K	367-6086
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-2090	Base-Xmsn O Fil	397-5049
6V-2202	Bearing-Spl Ball	380-1574
6Y-0305	Cage As-Bearing	297-7150
6Y-0306	Bearing-Sleeve	391-1104
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
6Y-7916	Disc-Friction	428-7204
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-5861	Adapter	243-0364
7D-7889	Gear-Ring	275-5276

09Y		
Original Part Number	Part Name	Classic Part Number
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-9918	Repair Kit-Major	388-0655
7G-3451	Gear-Planet	297-7188
7G-3452	Gear-Planet	275-5290
7G-3461	Gear-Planet	275-5291
7J-3351	Head	380-1515
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-8576	Bearing As	435-4848

Sales Model 130G (Cont'd.)

09Y		
Original Part Number	**Part Name**	**Classic Part Number**
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-9647	Piston-Clutch	275-5294
7W-0508	Gear-Fp Drive	296-1351
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8D-0983	Mounting	384-3470
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-2469	Shaft-Drive	275-5280
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-3744	Shaft-Drive	275-5283
8D-3877	Gear-Sun	275-5278
8D-3949	Ring-Wear	330-9283
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7693	Housing	384-4830
8D-7996	Bearing-Sleeve	472-8018
8D-8159	Retainer	419-8661
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8E-5284	Bearing	388-0582
8H-9789	Bearing-Ball	374-8342
8J-0546	Cyl Gp-076 276 Y	430-8116
8J-1616	Lever	330-9271
8J-1624	Valve As	390-0997
8J-2022	Piston As-Pump	367-6073
8J-6296	Shaft	419-6072
8J-6322	Cup-Roller Brg	399-4447
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0002	Trunnion As	314-8728

09Y		
Original Part Number	**Part Name**	**Classic Part Number**
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1656	Plate-Clutch	367-6071
8P-5961	Gear-Ring	385-6137
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831

09Y		
Original Part Number	**Part Name**	**Classic Part Number**
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8W-1749	Plate	380-7403
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2308	Shaft-Planet	275-5285
8W-3589	Link As-Spring	380-7389
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9587	Flange As	373-5394
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
9B-1320	Valve-Check	377-5832
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3288	Bolt-Draft	333-4941
9D-9665	Bracket-Cyl Mtg	299-1980
9D-9968	Washer-Thrust	391-9890
9M-1853	Mount As.	376-3638
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833

Sales Model 130G (Cont'd.)

09Y		
Original Part Number	Part Name	Classic Part Number
9Y-2992	Bearing-Sleeve	325-6032
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
109-5562	Shaft-Pin (Bev)	275-5272
110-4652	Housing	302-2683
112-3249	Muffler As	247-2661
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
143-7356	Bearing As	380-1483
147-3310	Spindle-Wheel	383-2111

09Y		
Original Part Number	Part Name	Classic Part Number
147-3400	Spindle	282-6549
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901

09Y		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
236-7724	Retainer	299-2048
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6556	Kit-Liner-Cla	250-6564
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

12W		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398

12W		
Original Part Number	Part Name	Classic Part Number
1P-4694	Cone-Roller Brg	380-7504
1P-5480	Cover As.-End	299-1998
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
1U-4661	Lever Gp	396-7267
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715

12W		
Original Part Number	Part Name	Classic Part Number
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382

Sales Model 130G (Cont'd.)

12W		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-5768	Gear-Bevel	388-0646
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8739	Retainer	389-6314
2G-9098	Cap	300-2573
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4364	Housing As-Cl	396-9928
2P-4432	Gear-Ring	418-9583
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-4611	Pipe-Exhaust	365-8821
2P-5769	Coupling	394-9812

12W		
Original Part Number	**Part Name**	**Classic Part Number**
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-1853	Cyl Gp-076 406 Y	415-1895
3G-4752	Cyl Gp-035-060-Y	390-0987
3G-5223	Cyl Gp-0083-1016	399-8557
3G-5224	Cyl Gp-0083-0459	425-9375
3L-1425	Bearing-Ball	311-9356
3P-0114	Elbow-Exhaust	314-8516
3P-0165	Pulley-Fan Drive	298-2775
3P-0296	Gear	416-2149
3P-0297	Shaft As	275-5297
3P-0298	Carrier-Input	384-5922
3P-0329	Drum As-Gear	380-7484
3P-0726	Shaft As	275-5298
3P-0786	Coupling	433-0440
3P-0801	Plate-Clutch	383-2119
3P-0951	Bearing-Spl Ball	416-2159
3P-3424	Shaft	416-5526
3P-5349	Piston As	275-5292
3P-5737	Shaft As-Clutch	275-5273
3P-5955	Disc-Friction	428-7205
3T-2095	Bearing-Sleeve	384-3459
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-2619	Bearing	417-4494
4K-3004	Bearing-Trun Sup	314-8632

12W		
Original Part Number	**Part Name**	**Classic Part Number**
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8942	Muffler As	298-2786
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778

Sales Model 130G (Cont'd.)

12W		
Original Part Number	Part Name	Classic Part Number
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-0925	Actuator Gp-Bk	379-0198
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535

12W		
Original Part Number	Part Name	Classic Part Number
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-8425	Valve Gp-Cont -K	367-6086
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-2090	Base-Xmsn O Fil	397-5049
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200
6Y-0305	Cage As-Bearing	297-7150
6Y-0306	Bearing-Sleeve	391-1104
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
6Y-7916	Disc-Friction	428-7204
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017

12W		
Original Part Number	Part Name	Classic Part Number
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-3451	Gear-Planet	297-7188
7G-3452	Gear-Planet	275-5290
7G-3461	Gear-Planet	275-5291
7J-3351	Head	380-1515
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994

Sales Model 130G (Cont'd.)

12W		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-8576	Bearing As	435-4848
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-9647	Piston-Clutch	275-5294
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8D-0983	Mounting	384-3470
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-2469	Shaft-Drive	275-5280
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-3744	Shaft-Drive	275-5283
8D-3877	Gear-Sun	275-5278
8D-3949	Ring-Wear	330-9283
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7693	Housing	384-4830
8D-7996	Bearing-Sleeve	472-8018
8D-8159	Retainer	419-8661
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-0546	Cyl Gp-076 276 Y	430-8116
8J-1616	Lever	330-9271
8J-1624	Valve As	390-0997

12W		
Original Part Number	Part Name	Classic Part Number
8J-2022	Piston As-Pump	367-6073
8J-6296	Shaft	419-6072
8J-6322	Cup-Roller Brg	399-4447
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377

12W		
Original Part Number	Part Name	Classic Part Number
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1656	Plate-Clutch	367-6071
8P-5961	Gear-Ring	385-6137
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8W-0328	Cylinder-Damper	419-4715
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-3589	Link As-Spring	380-7389
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814

Sales Model 130G (Cont'd.)

12W		
Original Part Number	Part Name	Classic Part Number
9B-1320	Valve-Check	377-5832
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9J-3466	Cyl Gp-028 121 Y	393-0913
9M-1853	Mount As.	376-3638
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565

59K		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988

12W		
Original Part Number	Part Name	Classic Part Number
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
109-5562	Shaft-Pin (Bev)	275-5272
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
139-0683	Gasket Kit	390-5290
143-7356	Bearing As	380-1483
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687

12W		
Original Part Number	Part Name	Classic Part Number
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
184-9843	Head	347-0461
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-3986	Gasket Kit	390-5275
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
234-8013	Kit-Gasket-Sch	437-8650
236-7724	Retainer	299-2048
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
246-5916	Kit-Seal-H.Cyl-1	472-8026
250-6556	Kit-Liner-Cla	250-6564
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
288-2552	Kit-Gasket-Txg	391-9884
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 130G (Cont'd.)

59K		
Original Part Number	**Part Name**	**Classic Part Number**
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-5480	Cover As.-End	299-1998
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1U-4661	Lever Gp	396-7267
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036

59K		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-2858	Cap-Pivot	243-0345
2G-5768	Gear-Bevel	388-0646
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-7464	Insert-Bolt	386-4918
2G-8238	Yoke As	282-6631
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8739	Retainer	389-6314
2G-9098	Cap	300-2573
2M-8714	Cone-Roller Brg	420-2492
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

59K		
Original Part Number	**Part Name**	**Classic Part Number**
2P-2719	Pipe-Oil Filler	363-7454
2P-4364	Housing As-Cl	396-9928
2P-4432	Gear-Ring	418-9583
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-4611	Pipe-Exhaust	365-8821
2P-5769	Coupling	394-9812
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-1853	Cyl Gp-076 406 Y	415-1895
3G-4752	Cyl Gp-035-060-Y	390-0987
3G-5223	Cyl Gp-0083-1016	399-8557
3G-5224	Cyl Gp-0083-0459	425-9375
3L-1425	Bearing-Ball	311-9356
3P-0114	Elbow-Exhaust	314-8516
3P-0165	Pulley-Fan Drive	298-2775
3P-0296	Gear	416-2149
3P-0297	Shaft As	275-5297
3P-0298	Carrier-Input	384-5922
3P-0329	Drum As-Gear	380-7484
3P-0726	Shaft As	275-5298
3P-0786	Coupling	433-0440
3P-0801	Plate-Clutch	383-2119
3P-0951	Bearing-Spl Ball	416-2159
3P-3424	Shaft	416-5526
3P-5349	Piston As	275-5292
3P-5737	Shaft As-Clutch	275-5273

Sales Model 130G (Cont'd.)

59K		
Original Part Number	Part Name	Classic Part Number
3P-5955	Disc-Friction	428-7205
3T-2095	Bearing-Sleeve	384-3459
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-2619	Bearing	417-4494
4K-7463	Seal-Lip Type	472-8007
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534

59K		
Original Part Number	Part Name	Classic Part Number
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-3490	Cone-Rlr Bearing	380-7518
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5T-0906	Cover	282-6625
5T-0925	Actuator Gp-Bk	379-0198
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8500	Shoe-Circle Dr	243-0359
5T-8501	Shoe-Circle Dr	243-0358
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337

59K		
Original Part Number	Part Name	Classic Part Number
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-8425	Valve Gp-Cont -K	367-6086
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-2090	Base-Xmsn O Fil	397-5049
6V-2202	Bearing-Spl Ball	380-1574
6Y-0305	Cage As-Bearing	297-7150
6Y-0306	Bearing-Sleeve	391-1104
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
6Y-7916	Disc-Friction	428-7204
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-5861	Adapter	243-0364
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607

Sales Model 130G (Cont'd.)

59K		
Original Part Number	**Part Name**	**Classic Part Number**
7D-9267	Yoke	330-9297
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-3451	Gear-Planet	297-7188
7G-3452	Gear-Planet	275-5290
7G-3461	Gear-Planet	275-5291
7J-3351	Head	380-1515
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-2834	Kit-Repair	374-4723
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-8576	Bearing As	435-4848
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-9647	Piston-Clutch	275-5294
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8D-0983	Mounting	384-3470
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-2469	Shaft-Drive	275-5280

59K		
Original Part Number	**Part Name**	**Classic Part Number**
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-3744	Shaft-Drive	275-5283
8D-3877	Gear-Sun	275-5278
8D-3949	Ring-Wear	330-9283
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7083	Bearing	386-4930
8D-7086	Bearing	330-9251
8D-7096	Pin-Axle Leaning	297-7219
8D-7167	Pin	389-6319
8D-7284	Bearing	330-9252
8D-7427	Shaft-Dr Pinion	282-6568
8D-7693	Housing	384-4830
8D-7996	Bearing-Sleeve	472-8018
8D-8159	Retainer	419-8661
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-0546	Cyl Gp-076 276 Y	430-8116
8J-1616	Lever	330-9271
8J-1624	Valve As	390-0997
8J-2022	Piston As-Pump	367-6073
8J-6296	Shaft	419-6072
8J-6322	Cup-Roller Brg	399-4447
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

59K		
Original Part Number	**Part Name**	**Classic Part Number**
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1656	Plate-Clutch	367-6071
8P-5961	Gear-Ring	385-6137
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8W-0328	Cylinder-Damper	419-4715

Sales Model 130G (Cont'd.)

59K		
Original Part Number	Part Name	Classic Part Number
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-3589	Link As-Spring	380-7389
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3288	Bolt-Draft	333-4941
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9D-9968	Washer-Thrust	391-9890
9J-3466	Cyl Gp-028 121 Y	393-0913
9M-1853	Mount As.	376-3638
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

59K		
Original Part Number	Part Name	Classic Part Number
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
105-0017	Cylinder	416-2130
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
109-5562	Shaft-Pin (Bev)	275-5272
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
143-7356	Bearing As	380-1483
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126

74V		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988

59K		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
236-7724	Retainer	299-2048
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 130G (Cont'd.)

74V		
Original Part Number	Part Name	Classic Part Number
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-4695	Cup-Rlr Bearing	374-1842
1P-5480	Cover As.-End	299-1998
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
1U-4661	Lever Gp	396-7267
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150

74V		
Original Part Number	Part Name	Classic Part Number
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-2858	Cap-Pivot	243-0345
2G-5768	Gear-Bevel	388-0646
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-7464	Insert-Bolt	386-4918
2G-8238	Yoke As	282-6631
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8739	Retainer	389-6314
2G-9098	Cap	300-2573
2K-6413	Pin	360-2270
2M-8714	Cone-Roller Brg	420-2492
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

74V		
Original Part Number	Part Name	Classic Part Number
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4364	Housing As-Cl	396-9928
2P-4432	Gear-Ring	418-9583
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-4611	Pipe-Exhaust	365-8821
2P-5769	Coupling	394-9812
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3E-8905	Gasket Kit	393-3617
3G-1853	Cyl Gp-076 406 Y	415-1895
3G-4752	Cyl Gp-035-060-Y	390-0987
3G-5223	Cyl Gp-0083-1016	399-8557
3G-5224	Cyl Gp-0083-0459	425-9375
3L-1425	Bearing-Ball	311-9356
3P-0114	Elbow-Exhaust	314-8516
3P-0165	Pulley-Fan Drive	298-2775
3P-0296	Gear	416-2149
3P-0297	Shaft As	275-5297
3P-0298	Carrier-Input	384-5922
3P-0329	Drum As-Gear	380-7484
3P-0726	Shaft As	275-5298

Sales Model 130G (Cont'd.)

74V		
Original Part Number	Part Name	Classic Part Number
3P-0786	Coupling	433-0440
3P-0801	Plate-Clutch	383-2119
3P-0951	Bearing-Spl Ball	416-2159
3P-3424	Shaft	416-5526
3P-5349	Piston As	275-5292
3P-5737	Shaft As-Clutch	275-5273
3P-5955	Disc-Friction	428-7205
3T-2095	Bearing-Sleeve	384-3459
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-2619	Bearing	417-4494
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8942	Muffler As	298-2786
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838

74V		
Original Part Number	Part Name	Classic Part Number
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

74V		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-0925	Actuator Gp-Bk	379-0198
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8500	Shoe-Circle Dr	243-0359
5T-8501	Shoe-Circle Dr	243-0358
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-8425	Valve Gp-Cont -K	367-6086
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422

Motor Graders

Sales Model 130G (Cont'd.)

74V		
Original Part Number	**Part Name**	**Classic Part Number**
6N-1878	Muffler As	360-7883
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-2090	Base-Xmsn O Fil	397-5049
6V-0600	Gasket Kit	437-4583
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6V-5976	Kit-Gasket (Rs)	393-5200
6Y-0305	Cage As-Bearing	297-7150
6Y-0306	Bearing-Sleeve	391-1104
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
6Y-7916	Disc-Friction	428-7204
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-5861	Adapter	243-0364
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-9547	Pin As.-Drawbar	295-0414
7G-3451	Gear-Planet	297-7188
7G-3452	Gear-Planet	275-5290
7G-3461	Gear-Planet	275-5291
7J-3351	Head	380-1515
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492

74V		
Original Part Number	**Part Name**	**Classic Part Number**
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-8576	Bearing As	435-4848
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-9647	Piston-Clutch	275-5294
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8D-0983	Mounting	384-3470
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-2469	Shaft-Drive	275-5280
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876

74V		
Original Part Number	**Part Name**	**Classic Part Number**
8D-3744	Shaft-Drive	275-5283
8D-3877	Gear-Sun	275-5278
8D-3949	Ring-Wear	330-9283
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7083	Bearing	386-4930
8D-7086	Bearing	330-9251
8D-7096	Pin-Axle Leaning	297-7219
8D-7167	Pin	389-6319
8D-7284	Bearing	330-9252
8D-7427	Shaft-Dr Pinion	282-6568
8D-7693	Housing	384-4830
8D-7996	Bearing-Sleeve	472-8018
8D-8159	Retainer	419-8661
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-0546	Cyl Gp-076 276 Y	430-8116
8J-1616	Lever	330-9271
8J-1624	Valve As	390-0997
8J-2022	Piston As-Pump	367-6073
8J-6296	Shaft	419-6072
8J-6322	Cup-Roller Brg	399-4447
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436

Sales Model 130G (Cont'd.)

74V		
Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1656	Plate-Clutch	367-6071
8P-5961	Gear-Ring	385-6137
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198

74V		
Original Part Number	Part Name	Classic Part Number
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8T-1606	Kit-Gskt-Sch	386-3046
8T-9486	Gasket Kt	393-5197
8W-0328	Cylinder-Damper	419-4715
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2308	Shaft-Planet	275-5285
8W-3589	Link As-Spring	380-7389
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
9B-1320	Valve-Check	377-5832
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3288	Bolt-Draft	333-4941
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980

74V		
Original Part Number	Part Name	Classic Part Number
9D-9968	Washer-Thrust	391-9890
9J-3466	Cyl Gp-028 121 Y	393-0913
9M-1853	Mount As.	376-3638
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
109-5562	Shaft-Pin (Bev)	275-5272
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300

Sales Model 130G (Cont'd.)

74V		
Original Part Number	Part Name	Classic Part Number
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
139-0683	Gasket Kit	390-5290
143-7356	Bearing As	380-1483
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0556	Kit-Rebuild-Pump	383-3712
170-0560	Rebuild Kit-Pump	363-7458

74V		
Original Part Number	Part Name	Classic Part Number
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7772	Pump Gp-Water -B	438-2009
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
174-6822	Bearing-Sleeve	387-2901
184-9843	Head	347-0461
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-3986	Gasket Kit	390-5275
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
234-7996	Kit-Gasket-Sch	437-8665
234-8013	Kit-Gasket-Sch	437-8650

74V		
Original Part Number	Part Name	Classic Part Number
236-7724	Retainer	299-2048
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
246-5916	Kit-Seal-H.Cyl-1	472-8026
250-6556	Kit-Liner-Cla	250-6564
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
288-2552	Kit-Gasket-Txg	391-9884
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

7GB		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147

7GB		
Original Part Number	Part Name	Classic Part Number
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1U-4661	Lever Gp	396-7267
1W-1219	Trunnion As	314-8724

7GB		
Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150

Sales Model 130G (Cont'd.)

7GB		
Original Part Number	Part Name	Classic Part Number
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-5768	Gear-Bevel	388-0646
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8739	Retainer	389-6314
2G-9098	Cap	300-2573
2M-8714	Cone-Roller Brg	420-2492
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

7GB		
Original Part Number	Part Name	Classic Part Number
2P-2719	Pipe-Oil Filler	363-7454
2P-4364	Housing As-Cl	396-9928
2P-4432	Gear-Ring	418-9583
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-4611	Pipe-Exhaust	365-8821
2P-5769	Coupling	394-9812
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3F-6523	Pin-Clevis	256-4818
3G-1853	Cyl Gp-076 406 Y	415-1895
3G-4752	Cyl Gp-035-060-Y	390-0987
3G-5223	Cyl Gp-0083-1016	399-8557
3G-5224	Cyl Gp-0083-0459	425-9375
3L-1425	Bearing-Ball	311-9356
3P-0114	Elbow-Exhaust	314-8516
3P-0165	Pulley-Fan Drive	298-2775
3P-0296	Gear	416-2149
3P-0297	Shaft As	275-5297
3P-0298	Carrier-Input	384-5922
3P-0329	Drum As-Gear	380-7484
3P-0726	Shaft As	275-5298
3P-0786	Coupling	433-0440
3P-0801	Plate-Clutch	383-2119
3P-0951	Bearing-Spl Ball	416-2159
3P-3424	Shaft	416-5526
3P-5349	Piston As	275-5292

7GB		
Original Part Number	Part Name	Classic Part Number
3P-5737	Shaft As-Clutch	275-5273
3P-5955	Disc-Friction	428-7205
3T-2095	Bearing-Sleeve	384-3459
4B-7270	Cone-Bearing	399-4439
4D-2619	Bearing	417-4494
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5J-7010	Seal As	472-8011

Sales Model 130G (Cont'd.)

7GB		
Original Part Number	Part Name	Classic Part Number
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-0925	Actuator Gp-Bk	379-0198
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337

7GB		
Original Part Number	Part Name	Classic Part Number
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-8425	Valve Gp-Cont -K	367-6086
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6P-2090	Base-Xmsn O Fil	397-5049
6V-2202	Bearing-Spl Ball	380-1574
6Y-0305	Cage As-Bearing	297-7150
6Y-0306	Bearing-Sleeve	391-1104
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
6Y-7916	Disc-Friction	428-7204
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607

7GB		
Original Part Number	Part Name	Classic Part Number
7D-9267	Yoke	330-9297
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-9547	Pin As.-Drawbar	295-0414
7G-3451	Gear-Planet	297-7188
7G-3452	Gear-Planet	275-5290
7G-3461	Gear-Planet	275-5291
7J-3351	Head	380-1515
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-8576	Bearing As	435-4848
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-9647	Piston-Clutch	275-5294
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8D-0983	Mounting	384-3470
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-2469	Shaft-Drive	275-5280
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876

Sales Model 130G (Cont'd.)

7GB		
Original Part Number	Part Name	Classic Part Number
8D-3744	Shaft-Drive	275-5283
8D-3877	Gear-Sun	275-5278
8D-3949	Ring-Wear	330-9283
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7693	Housing	384-4830
8D-7996	Bearing-Sleeve	472-8018
8D-8159	Retainer	419-8661
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-0546	Cyl Gp-076 276 Y	430-8116
8J-1616	Lever	330-9271
8J-1624	Valve As	390-0997
8J-2022	Piston As-Pump	367-6073
8J-6296	Shaft	419-6072
8J-6322	Cup-Roller Brg	399-4447
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

7GB		
Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1656	Plate-Clutch	367-6071
8P-5961	Gear-Ring	385-6137
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8W-0328	Cylinder-Damper	419-4715
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-3589	Link As-Spring	380-7389
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214

7GB		
Original Part Number	Part Name	Classic Part Number
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9D-9968	Washer-Thrust	391-9890
9J-3466	Cyl Gp-028 121 Y	393-0913
9M-1853	Mount As.	376-3638
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
105-0017	Cylinder	416-2130
105-3196	Motor Gp-Grtr	282-6547

Motor Graders

Sales Model 130G (Cont'd.)

7GB		
Original Part Number	**Part Name**	**Classic Part Number**
106-7131	Shaft	288-8714
109-5562	Shaft-Pin (Bev)	275-5272
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
143-7356	Bearing As	380-1483
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
164-6560	Body As-Piston	477-7125

7GB		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024

7GB		
Original Part Number	**Part Name**	**Classic Part Number**
232-3233	Bearing-Main	376-9085
236-7724	Retainer	299-2048
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 135H

3YK		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7115	Mount As	418-1936
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-4369	Pulley-Alt	296-1340
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488

3YK		
Original Part Number	**Part Name**	**Classic Part Number**
2D-6341	Pin	330-9273
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2858	Cap-Pivot	243-0345
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-7464	Insert-Bolt	386-4918

3YK		
Original Part Number	**Part Name**	**Classic Part Number**
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8628	Pin	282-6559
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8769	Pin	282-6562
2G-9097	Cap	418-1926
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911

Sales Model 135H (Cont'd.)

3YK		
Original Part Number	Part Name	Classic Part Number
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2W-7213	Bearing-Sleeve	419-4667
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5K-0990	Pin	299-2035
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6D-5415	Plate	382-8043
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624

3YK		
Original Part Number	Part Name	Classic Part Number
6G-7213	Carrier-Planet	396-9936
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-1099	Manifold-Exh	424-6366
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-5861	Adapter	243-0364
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986

3YK		
Original Part Number	Part Name	Classic Part Number
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8S-0248	Breather As	325-6033
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2307	Shaft-Planet	275-5284
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8289	Sprocket	282-6629
8W-9566	Flange As	376-9073

Motor Graders

Sales Model 135H (Cont'd.)

3YK		
Original Part Number	**Part Name**	**Classic Part Number**
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1511	Bearing-Sleeve	333-4943
9D-1512	Bearing-Sleeve	333-4944
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-2756	Insert	333-4949
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-2387	Rod As	393-5218
9T-5729	Cyl Gp-0038 0158	422-2486
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925

3YK		
Original Part Number	**Part Name**	**Classic Part Number**
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-0017	Cylinder	416-2130
105-1738	Manifold-Exhaust	374-4692
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
112-5495	Joint Gp-Univ	297-4858
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3240	Pin	282-6548
126-5875	Flywheel As.	374-4694
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-3309	Spindle	282-6628

3YK		
Original Part Number	**Part Name**	**Classic Part Number**
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
163-1387	Gear-Flywheel	374-4697
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

7MM		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7115	Mount As	418-1936
1S-7057	Gasket	420-6384

7MM		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354

7MM		
Original Part Number	**Part Name**	**Classic Part Number**
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551

Sales Model 135H (Cont'd.)

7MM		
Original Part Number	Part Name	Classic Part Number
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2W-7213	Bearing-Sleeve	419-4667
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-8367	Strip-Wear	297-7263

7MM		
Original Part Number	Part Name	Classic Part Number
5T-8739	Spider Gp-Brg&	373-5386
6D-5415	Plate	382-8043
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-7213	Carrier-Planet	396-9936
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-1099	Manifold-Exh	424-6366
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449

7MM		
Original Part Number	Part Name	Classic Part Number
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7K-2135	Bearing-Roller	417-4492
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8S-0248	Breather As	325-6033
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2307	Shaft-Planet	275-5284
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215

Sales Model 135H (Cont'd.)

7MM		
Original Part Number	**Part Name**	**Classic Part Number**
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8289	Sprocket	282-6629
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-2387	Rod As	393-5218
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671

7MM		
Original Part Number	**Part Name**	**Classic Part Number**
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-0017	Cylinder	416-2130
105-1738	Manifold-Exhaust	374-4692
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
112-5495	Joint Gp-Univ	297-4858
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3240	Pin	282-6548
126-5875	Flywheel As.	374-4694
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388

7MM		
Original Part Number	**Part Name**	**Classic Part Number**
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

8WN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7115	Mount As	418-1936
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294

8WN		
Original Part Number	**Part Name**	**Classic Part Number**
1U-3998	Seal As	472-8005
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434

8WN		
Original Part Number	**Part Name**	**Classic Part Number**
2G-1034	Valve-Safety	380-7555
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258

Sales Model 135H (Cont'd.)

8WN		
Original Part Number	Part Name	Classic Part Number
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2W-7213	Bearing-Sleeve	419-4667
4K-3004	Bearing-Trun Sup	314-8632
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-8367	Strip-Wear	297-7263

8WN		
Original Part Number	Part Name	Classic Part Number
5T-8739	Spider Gp-Brg&	373-5386
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-7213	Carrier-Planet	396-9936
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-1099	Manifold-Exh	424-6366
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297

8WN		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7K-2135	Bearing-Roller	417-4492
7P-1577	Pin As	375-9969
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8S-0248	Breather As	325-6033
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734

Motor Graders

Sales Model 135H (Cont'd.)

8WN		
Original Part Number	**Part Name**	**Classic Part Number**
8W-2307	Shaft-Planet	275-5284
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8289	Sprocket	282-6629
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-2387	Rod As	393-5218

8WN		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-0017	Cylinder	416-2130
105-1738	Manifold-Exhaust	374-4692
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
112-5495	Joint Gp-Univ	297-4858
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3240	Pin	282-6548
126-5875	Flywheel As.	374-4694
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388

8WN		
Original Part Number	**Part Name**	**Classic Part Number**
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

AMX		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851

AMX		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955

AMX		
Original Part Number	**Part Name**	**Classic Part Number**
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273
2D-9454	Cup-Roller Brg	415-1914
2F-8509	Cone-Roller Brg	399-4434

Sales Model 135H (Cont'd.)

AMX		
Original Part Number	Part Name	Classic Part Number
2G-1034	Valve-Safety	380-7555
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
2W-7213	Bearing-Sleeve	419-4667
4K-3004	Bearing-Trun Sup	314-8632
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4S-8472	Hood As-Preclnr	296-1355
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-8367	Strip-Wear	297-7263
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160

AMX		
Original Part Number	Part Name	Classic Part Number
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-7213	Carrier-Planet	396-9936
6H-2577	Spider Gp-Brg&	333-4954
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7W-5095	Gear-Flywheel	425-9190
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277

AMX		
Original Part Number	Part Name	Classic Part Number
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2307	Shaft-Planet	275-5284
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8289	Sprocket	282-6629
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-6147	Body As	369-9499
9T-2387	Rod As	393-5218

Sales Model 135H (Cont'd.)

AMX		
Original Part Number	**Part Name**	**Classic Part Number**
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
115-4072	Bearing	397-5069
124-3240	Pin	282-6548
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627

AMX		
Original Part Number	**Part Name**	**Classic Part Number**
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549
148-2593	Head	383-1591
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
154-8030	Gasket	394-0894
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024

AMX		
Original Part Number	**Part Name**	**Classic Part Number**
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

BDJ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7115	Mount As	418-1936
1S-7057	Gasket	420-6384
1U-3998	Seal As	472-8005
1W-4369	Pulley-Alt	296-1340
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2858	Cap-Pivot	243-0345
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570

BDJ		
Original Part Number	**Part Name**	**Classic Part Number**
2G-6336	Hub-Brake	282-6551
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-7464	Insert-Bolt	386-4918
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8628	Pin	282-6559
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8769	Pin	282-6562
2G-9097	Cap	418-1926
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-8907	Spider As-Fan	330-9289

BDJ		
Original Part Number	**Part Name**	**Classic Part Number**
2S-5100	Valve-Ball	386-3049
2W-7213	Bearing-Sleeve	419-4667
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0984	Bearing-Sleeve	330-9262
5K-0990	Pin	299-2035
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467

Sales Model 135H (Cont'd.)

BDJ		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6D-5415	Plate	382-8043
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-7213	Carrier-Planet	396-9936
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-1099	Manifold-Exh	424-6366
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

BDJ		
Original Part Number	Part Name	Classic Part Number
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-5861	Adapter	243-0364
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8D-9973	Housing	391-9825

BDJ		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8S-0248	Breather As	325-6033
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2307	Shaft-Planet	275-5284
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8289	Sprocket	282-6629
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1511	Bearing-Sleeve	333-4943
9D-1512	Bearing-Sleeve	333-4944
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-2756	Insert	333-4949
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500

Motor Graders

Sales Model 135H (Cont'd.)

BDJ		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-2387	Rod As	393-5218
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-0017	Cylinder	416-2130
105-1738	Manifold-Exhaust	374-4692
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683

BDJ		
Original Part Number	**Part Name**	**Classic Part Number**
112-5495	Joint Gp-Univ	297-4858
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3240	Pin	282-6548
126-5875	Flywheel As.	374-4694
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
163-1387	Gear-Flywheel	374-4697
178-3086	Ballstud	374-1453
184-9843	Head	347-0461

BDJ		
Original Part Number	**Part Name**	**Classic Part Number**
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

CBC		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273
2D-9454	Cup-Roller Brg	415-1914
2F-8509	Cone-Roller Brg	399-4434

CBC		
Original Part Number	**Part Name**	**Classic Part Number**
2G-1034	Valve-Safety	380-7555
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350

CBC		
Original Part Number	**Part Name**	**Classic Part Number**
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
2W-7213	Bearing-Sleeve	419-4667
4K-3004	Bearing-Trun Sup	314-8632
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4S-8472	Hood As-Preclnr	296-1355
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011

Sales Model 135H (Cont'd.)

CBC		
Original Part Number	Part Name	Classic Part Number
5K-0984	Bearing-Sleeve	330-9262
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-8367	Strip-Wear	297-7263
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-7213	Carrier-Planet	396-9936
6H-2577	Spider Gp-Brg&	333-4954
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7W-5095	Gear-Flywheel	425-9190

CBC		
Original Part Number	Part Name	Classic Part Number
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2307	Shaft-Planet	275-5284
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8289	Sprocket	282-6629
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659

CBC		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-6147	Body As	369-9499
9T-2387	Rod As	393-5218
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
115-4072	Bearing	397-5069
124-3240	Pin	282-6548
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549
148-2593	Head	383-1591
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
154-8030	Gasket	394-0894
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370

Motor Graders

Sales Model 135H (Cont'd.)

CBC		
Original Part Number	Part Name	Classic Part Number
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
246-5916	Kit-Seal-H.Cyl-1	472-8026

CBC		
Original Part Number	Part Name	Classic Part Number
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

CBC		
Original Part Number	Part Name	Classic Part Number
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

Sales Model 140

11R		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1S-0057	Plate-Clutch	377-7404
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1W-3900	Gasket	472-8006
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505

11R		
Original Part Number	Part Name	Classic Part Number
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1757	Hub-Fan Pulley	296-1357
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-5608	Pipe-Extension	367-6066
2P-5609	Muffler As.	247-2665
2P-6128	Pulley	264-5872
2P-7830	Pump Gp	314-8533
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3V-4046	Plate-Pressure	380-7470
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494

11R		
Original Part Number	Part Name	Classic Part Number
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
4N-4864	Pump Gp-F Tfr	242-3442
4N-7693	Crankshaft As	269-8763
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
5D-4799	Bearing-Roller	416-2160
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5D-9906	Shaft-Axle	228-9413
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

Sales Model 140 (Cont'd.)

11R		
Original Part Number	Part Name	Classic Part Number
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-3158	Shoe-Yoke Lh	243-0357
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
7C-4297	Seal As-Cshaft	325-6192
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2957	Cover-Rad Cap	361-1722
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417

11R		
Original Part Number	Part Name	Classic Part Number
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-5344	Gear-Worm	243-0341
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033

11R		
Original Part Number	Part Name	Classic Part Number
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
9D-2716	Spindle-Wheel	228-9463
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-2685	Rod End	419-1866
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085

Sales Model 140 (Cont'd.)

11R		
Original Part Number	**Part Name**	**Classic Part Number**
236-8675	Disc-Friction	428-7202
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438

11R		
Original Part Number	**Part Name**	**Classic Part Number**
255-2899	Pipe As-Tail	301-5246
328-5572	Bearing-Rod	419-6349

11R		
Original Part Number	**Part Name**	**Classic Part Number**
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005

14U		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1W-3900	Gasket	472-8006
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-9295	Bearing-Cone	422-6480
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229

14U		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-5608	Pipe-Extension	367-6066
2P-5609	Muffler As.	247-2665
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3B-4124	Cup-Spl Tapered	422-6481
3D-4718	Bearing-Sleeve	245-5795
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-8393	Plate-Clutch	388-0592
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405

14U		
Original Part Number	**Part Name**	**Classic Part Number**
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4N-4864	Pump Gp-F Tfr	242-3442
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4S-6707	Piston-Clutch	215-1686
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5F-8651	Bearing-Ball	420-3223
5H-0047	Disc-Cl Drive	388-0576
5L-6326	Bearing-Ball	420-3222
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247

Sales Model 140 (Cont'd.)

14U		
Original Part Number	**Part Name**	**Classic Part Number**
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-3158	Shoe-Yoke Lh	243-0357
6B-7469	Spacer	417-4535
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7C-4297	Seal As-Cshaft	325-6192
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994

14U		
Original Part Number	**Part Name**	**Classic Part Number**
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-5344	Gear-Worm	243-0341
8F-6058	Bearing-Sleeve	416-5494
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-8623	Gear-Sun	213-8755
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291

14U		
Original Part Number	**Part Name**	**Classic Part Number**
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
9D-2716	Spindle-Wheel	228-9463

Motor Graders

Sales Model 140 (Cont'd.)

14U		
Original Part Number	**Part Name**	**Classic Part Number**
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891

14U		
Original Part Number	**Part Name**	**Classic Part Number**
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202

14U		
Original Part Number	**Part Name**	**Classic Part Number**
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420

55F		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1W-3900	Gasket	472-8006
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273

55F		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1757	Hub-Fan Pulley	296-1357
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-7830	Pump Gp	314-8533
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439

55F		
Original Part Number	**Part Name**	**Classic Part Number**
3B-6218	Muffler As	247-2672
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
4N-4864	Pump Gp-F Tfr	242-3442
4N-7693	Crankshaft As	269-8763
4P-0660	Muffler As	298-2787
4W-2061	Pan As-Oil Sump	416-5519
5D-4799	Bearing-Roller	416-2160

Sales Model 140 (Cont'd.)

55F		
Original Part Number	Part Name	Classic Part Number
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5D-9906	Shaft-Axle	228-9413
5H-0047	Disc-Cl Drive	388-0576
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-3158	Shoe-Yoke Lh	243-0357
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-2202	Bearing-Spl Ball	380-1574
7C-4297	Seal As-Cshaft	325-6192
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348

55F		
Original Part Number	Part Name	Classic Part Number
7M-4926	Retainer-Piston	314-8538
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8D-5344	Gear-Worm	243-0341
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

55F		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
8W-9587	Flange As	373-5394
9D-2716	Spindle-Wheel	228-9463
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-2685	Rod End	419-1866
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6129	Pulley-Alt Drive	264-5891
9S-7534	Pipe-Exh Ext	398-2950
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165

Motor Graders

Sales Model 140 (Cont'd.)

55F		
Original Part Number	**Part Name**	**Classic Part Number**
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202

55F		
Original Part Number	**Part Name**	**Classic Part Number**
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
250-6555	Kit-Liner-Cla	250-6563

55F		
Original Part Number	**Part Name**	**Classic Part Number**
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005

Sales Model 140B

33C		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822

33C		
Original Part Number	**Part Name**	**Classic Part Number**
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7830	Pump Gp	314-8533
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892

33C		
Original Part Number	**Part Name**	**Classic Part Number**
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3D-4343	Chain-Tandem Dr	394-0214
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4D-6664	Coupling-Shaft	243-0338
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053

Sales Model 140B (Cont'd.)

33C		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-2061	Pan As-Oil Sump	416-5519
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5D-6201	Shoe-Yoke	243-0356
5D-9745	Shoe-Guide	330-9285
5H-0047	Disc-Cl Drive	388-0576
5L-6326	Bearing-Ball	420-3222
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5T-8500	Shoe-Circle Dr	243-0359
6B-3158	Shoe-Yoke Lh	243-0357
6B-7469	Spacer	417-4535
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-2947	Shaft	243-0346
6G-4525	Strip-Wear	282-6624
6H-3566	Cone-Bearing	415-1918

33C		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-8860	Cup-Roller Brg	380-7495
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-2202	Bearing-Spl Ball	380-1574
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7M-1154	Bearing-Spl	417-4515
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8D-5344	Gear-Worm	243-0341
8H-2810	Case As-Filter	314-8512

33C		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198

Motor Graders

Sales Model 140B (Cont'd.)

33C		
Original Part Number	**Part Name**	**Classic Part Number**
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8W-6324	Kit-Wear Strip	424-0739
8W-9587	Flange As	373-5394
9D-2716	Spindle-Wheel	228-9463
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977

33C		
Original Part Number	**Part Name**	**Classic Part Number**
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

33C		
Original Part Number	**Part Name**	**Classic Part Number**
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005

61S		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4478	Pin	330-9272
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173

61S		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-6413	Pin	360-2270
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

61S		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1738	Plate As-Oil Pan	325-6164
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7830	Pump Gp	314-8533
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055

Sales Model 140B (Cont'd.)

61S		
Original Part Number	Part Name	Classic Part Number
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3D-4343	Chain-Tandem Dr	394-0214
3D-4718	Bearing-Sleeve	245-5795
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-7064	Shaft-Worm	245-5803
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4D-6926	Segment-Control	228-9455
4F-2041	Cup-Roller Brg	418-9609
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986

61S		
Original Part Number	Part Name	Classic Part Number
4P-9386	Line As-Fuel Inj	279-4987
4W-2061	Pan As-Oil Sump	416-5519
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5H-0047	Disc-Cl Drive	388-0576
5L-6326	Bearing-Ball	420-3222
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5T-8500	Shoe-Circle Dr	243-0359
6B-7469	Spacer	417-4535
6D-2348	Disc-Friction	380-7489
6D-6859	Bearing	330-9248
6F-6992	Cap-Ballsocket	297-7160
6G-4525	Strip-Wear	282-6624
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-8860	Cup-Roller Brg	380-7495
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-2202	Bearing-Spl Ball	380-1574
7C-3862	Camshaft	458-0151
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7M-1154	Bearing-Spl	417-4515

61S		
Original Part Number	Part Name	Classic Part Number
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8D-5344	Gear-Worm	243-0341
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

Motor Graders

Sales Model 140B (Cont'd.)

61S		
Original Part Number	**Part Name**	**Classic Part Number**
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

61S		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8W-6324	Kit-Wear Strip	424-0739
8W-9587	Flange As	373-5394
9B-1320	Valve-Check	377-5832
9D-2716	Spindle-Wheel	228-9463
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

61S		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 140G

13W		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-5480	Cover As.-End	299-1998
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
1U-4661	Lever Gp	396-7267
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513

13W		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-5768	Gear-Bevel	388-0646
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8739	Retainer	389-6314
2G-9098	Cap	300-2573
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

13W		
Original Part Number	Part Name	Classic Part Number
2P-2719	Pipe-Oil Filler	363-7454
2P-4364	Housing As-Cl	396-9928
2P-4432	Gear-Ring	418-9583
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-4611	Pipe-Exhaust	365-8821
2P-5769	Coupling	394-9812
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3G-1853	Cyl Gp-076 406 Y	415-1895
3G-4752	Cyl Gp-035-060-Y	390-0987
3G-5223	Cyl Gp-0083-1016	399-8557
3G-5224	Cyl Gp-0083-0459	425-9375
3J-6575	Trunnion	297-7265
3L-1425	Bearing-Ball	311-9356
3P-0165	Pulley-Fan Drive	298-2775
3P-0296	Gear	416-2149
3P-0297	Shaft As	275-5297
3P-0298	Carrier-Input	384-5922
3P-0329	Drum As-Gear	380-7484
3P-0726	Shaft As	275-5298
3P-0786	Coupling	433-0440
3P-0801	Plate-Clutch	383-2119
3P-0951	Bearing-Spl Ball	416-2159
3P-3424	Shaft	416-5526

Sales Model 140G (Cont'd.)

13W		
Original Part Number	Part Name	Classic Part Number
3P-5349	Piston As	275-5292
3P-5737	Shaft As-Clutch	275-5273
3P-5955	Disc-Friction	428-7205
3T-2095	Bearing-Sleeve	384-3459
3Y-2768	Ring	439-4544
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-2619	Bearing	417-4494
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988

13W		
Original Part Number	Part Name	Classic Part Number
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-0470	Valve Gp-Qrel	314-8549
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-0925	Actuator Gp-Bk	379-0198
5T-1362	Univ Joint As-5C	325-6011

13W		
Original Part Number	Part Name	Classic Part Number
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-8425	Valve Gp-Cont -K	367-6086
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0622	Elbow-Exhaust	380-7534
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-2090	Base-Xmsn O Fil	397-5049
6V-2202	Bearing-Spl Ball	380-1574
6Y-0305	Cage As-Bearing	297-7150
6Y-0306	Bearing-Sleeve	391-1104

Sales Model 140G (Cont'd.)

13W		
Original Part Number	Part Name	Classic Part Number
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
6Y-7916	Disc-Friction	428-7204
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-3451	Gear-Planet	297-7188
7G-3452	Gear-Planet	275-5290
7G-3461	Gear-Planet	275-5291
7J-3351	Head	380-1515
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7K-9348	Pin	252-6872
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779

13W		
Original Part Number	Part Name	Classic Part Number
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-8576	Bearing As	435-4848
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-9647	Piston-Clutch	275-5294
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8D-0983	Mounting	384-3470
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-2469	Shaft-Drive	275-5280
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-3744	Shaft-Drive	275-5283
8D-3877	Gear-Sun	275-5278
8D-3949	Ring-Wear	330-9283
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492

13W		
Original Part Number	Part Name	Classic Part Number
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7693	Housing	384-4830
8D-7996	Bearing-Sleeve	472-8018
8D-8159	Retainer	419-8661
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-0546	Cyl Gp-076 276 Y	430-8116
8J-1616	Lever	330-9271
8J-1624	Valve As	390-0997
8J-2022	Piston As-Pump	367-6073
8J-6296	Shaft	419-6072
8J-6322	Cup-Roller Brg	399-4447
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711

Sales Model 140G (Cont'd.)

13W		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1656	Plate-Clutch	367-6071
8P-5961	Gear-Ring	385-6137
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8W-0328	Cylinder-Damper	419-4715
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-3589	Link As-Spring	380-7389

13W		
Original Part Number	**Part Name**	**Classic Part Number**
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
9B-1320	Valve-Check	377-5832
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9J-3466	Cyl Gp-028 121 Y	393-0913
9M-1853	Mount As.	376-3638
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124

13W		
Original Part Number	**Part Name**	**Classic Part Number**
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
109-5562	Shaft-Pin (Bev)	275-5272
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
139-0683	Gasket Kit	390-5290
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046

Sales Model 140G (Cont'd.)

13W		
Original Part Number	**Part Name**	**Classic Part Number**
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
155-1379	Gasket Kit - Sch	386-3815
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

13W		
Original Part Number	**Part Name**	**Classic Part Number**
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
184-9843	Head	347-0461
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-3986	Gasket Kit	390-5275
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
246-5916	Kit-Seal-H.Cyl-1	472-8026
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246

13W		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
288-2552	Kit-Gasket-Txg	391-9884
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

50H		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1B-5675	Bearing	377-7396
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-5480	Cover As.-End	299-1998
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1U-4661	Lever Gp	396-7267

50H		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

50H		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-5383	Gasket	445-7709
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2G-5768	Gear-Bevel	388-0646
2G-6285	Valve Kt	383-1570
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214

Sales Model 140G (Cont'd.)

50H		
Original Part Number	**Part Name**	**Classic Part Number**
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4364	Housing As-Cl	396-9928
2P-4432	Gear-Ring	418-9583
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-5769	Coupling	394-9812
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3P-0296	Gear	416-2149
3P-0297	Shaft As	275-5297
3P-0298	Carrier-Input	384-5922
3P-0329	Drum As-Gear	380-7484
3P-0726	Shaft As	275-5298
3P-0786	Coupling	433-0440
3P-0801	Plate-Clutch	383-2119
3P-0951	Bearing-Spl Ball	416-2159
3P-3424	Shaft	416-5526
3P-5349	Piston As	275-5292
3P-5737	Shaft As-Clutch	275-5273
3P-5955	Disc-Friction	428-7205
3T-2095	Bearing-Sleeve	384-3459
4B-7270	Cone-Bearing	399-4439
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059

50H		
Original Part Number	**Part Name**	**Classic Part Number**
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-0470	Valve Gp-Qrel	314-8549
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-3490	Cone-Rlr Bearing	380-7518
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5T-0925	Actuator Gp-Bk	379-0198

50H		
Original Part Number	**Part Name**	**Classic Part Number**
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6G-1908	Housing As-Drive	297-7198
6G-8425	Valve Gp-Cont -K	367-6086
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8088	Bearing-Roller	399-4428
6N-0622	Elbow-Exhaust	380-7534
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-2090	Base-Xmsn O Fil	397-5049
6V-2202	Bearing-Spl Ball	380-1574
6Y-0305	Cage As-Bearing	297-7150
6Y-0306	Bearing-Sleeve	391-1104
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
6Y-7916	Disc-Friction	428-7204
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847

Sales Model 140G (Cont'd.)

50H		
Original Part Number	Part Name	Classic Part Number
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-3451	Gear-Planet	297-7188
7G-3452	Gear-Planet	275-5290
7G-3461	Gear-Planet	275-5291
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2834	Kit-Repair	374-4723
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-8576	Bearing As	435-4848
7S-8631	Shaft As	275-5296
7T-9647	Piston-Clutch	275-5294
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8D-2469	Shaft-Drive	275-5280
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-3744	Shaft-Drive	275-5283
8D-3877	Gear-Sun	275-5278

50H		
Original Part Number	Part Name	Classic Part Number
8D-3949	Ring-Wear	330-9283
8D-5344	Gear-Worm	243-0341
8D-7427	Shaft-Dr Pinion	282-6568
8D-7693	Housing	384-4830
8D-8168	Bearing	453-6511
8D-9804	Housing-Drive	302-2682
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-1616	Lever	330-9271
8J-1624	Valve As	390-0997
8J-2022	Piston As-Pump	367-6073
8J-6296	Shaft	419-6072
8J-6322	Cup-Roller Brg	399-4447
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860

50H		
Original Part Number	Part Name	Classic Part Number
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1656	Plate-Clutch	367-6071
8P-5961	Gear-Ring	385-6137
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8W-0328	Cylinder-Damper	419-4715
8W-2308	Shaft-Planet	275-5285
8W-5092	Pinion-Circle Dr	282-6569
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9587	Flange As	373-5394
9D-1491	Coupling	416-2121
9D-3288	Bolt-Draft	333-4941
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561

Sales Model 140G (Cont'd.)

50H		
Original Part Number	Part Name	Classic Part Number
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
105-3196	Motor Gp-Grtr	282-6547
109-5562	Shaft-Pin (Bev)	275-5272
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp-Univ	297-4858
126-7130	Shaft As	275-5300
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554

50H		
Original Part Number	Part Name	Classic Part Number
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7772	Pump Gp-Water -B	438-2009

50H		
Original Part Number	Part Name	Classic Part Number
174-6822	Bearing-Sleeve	387-2901
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
232-3233	Bearing-Main	376-9085
236-7724	Retainer	299-2048
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
312-0782	Worm-Circ Drv	282-6623
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

5MD		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-4695	Cup-Rlr Bearing	374-1842

5MD		
Original Part Number	Part Name	Classic Part Number
1P-4696	Cone-Rlr Bearing	374-1843
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
1U-4661	Lever Gp	396-7267
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

5MD		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

Sales Model 140G (Cont'd.)

5MD		
Original Part Number	Part Name	Classic Part Number
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-2858	Cap-Pivot	243-0345
2G-5768	Gear-Bevel	388-0646
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-7464	Insert-Bolt	386-4918
2G-8238	Yoke As	282-6631
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8739	Retainer	389-6314
2G-9098	Cap	300-2573
2K-6413	Pin	360-2270
2M-8714	Cone-Roller Brg	420-2492
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229

5MD		
Original Part Number	Part Name	Classic Part Number
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4364	Housing As-Cl	396-9928
2P-4432	Gear-Ring	418-9583
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-4611	Pipe-Exhaust	365-8821
2P-5608	Pipe-Extension	367-6066
2P-5609	Muffler As.	247-2665
2P-5769	Coupling	394-9812
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3D-9126	Cup-Roller Brg	399-4435
3G-4752	Cyl Gp-035-060-Y	390-0987
3G-5223	Cyl Gp-0083-1016	399-8557
3G-5224	Cyl Gp-0083-0459	425-9375
3L-1425	Bearing-Ball	311-9356
3P-0165	Pulley-Fan Drive	298-2775
3P-0296	Gear	416-2149
3P-0297	Shaft As	275-5297
3P-0298	Carrier-Input	384-5922

5MD		
Original Part Number	Part Name	Classic Part Number
3P-0329	Drum As-Gear	380-7484
3P-0726	Shaft As	275-5298
3P-0786	Coupling	433-0440
3P-0801	Plate-Clutch	383-2119
3P-0951	Bearing-Spl Ball	416-2159
3P-3424	Shaft	416-5526
3P-5349	Piston As	275-5292
3P-5737	Shaft As-Clutch	275-5273
3P-5955	Disc-Friction	428-7205
3T-2095	Bearing-Sleeve	384-3459
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-2619	Bearing	417-4494
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355

Sales Model 140G (Cont'd.)

5MD		
Original Part Number	Part Name	Classic Part Number
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-0470	Valve Gp-Qrel	314-8549
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-0925	Actuator Gp-Bk	379-0198
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8500	Shoe-Circle Dr	243-0359
5T-8501	Shoe-Circle Dr	243-0358
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535

5MD		
Original Part Number	Part Name	Classic Part Number
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-8425	Valve Gp-Cont -K	367-6086
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0622	Elbow-Exhaust	380-7534
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-2090	Base-Xmsn O Fil	397-5049
6S-3051	Cup-Rlr Brg	415-1928
6V-2202	Bearing-Spl Ball	380-1574
6Y-0305	Cage As-Bearing	297-7150
6Y-0306	Bearing-Sleeve	391-1104
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
6Y-7916	Disc-Friction	428-7204
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-5861	Adapter	243-0364
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017

5MD		
Original Part Number	Part Name	Classic Part Number
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-3451	Gear-Planet	297-7188
7G-3452	Gear-Planet	275-5290
7G-3461	Gear-Planet	275-5291
7J-3351	Head	380-1515
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-8576	Bearing As	435-4848
7S-8631	Shaft As	275-5296

Sales Model 140G (Cont'd.)

5MD		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7T-9647	Piston-Clutch	275-5294
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-2469	Shaft-Drive	275-5280
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-3744	Shaft-Drive	275-5283
8D-3877	Gear-Sun	275-5278
8D-3949	Ring-Wear	330-9283
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7083	Bearing	386-4930
8D-7086	Bearing	330-9251
8D-7096	Pin-Axle Leaning	297-7219
8D-7167	Pin	389-6319
8D-7284	Bearing	330-9252
8D-7427	Shaft-Dr Pinion	282-6568
8D-7693	Housing	384-4830
8D-7996	Bearing-Sleeve	472-8018
8D-8159	Retainer	419-8661
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-0546	Cyl Gp-076 276 Y	430-8116
8J-1616	Lever	330-9271
8J-1624	Valve As	390-0997
8J-2022	Piston As-Pump	367-6073

5MD		
Original Part Number	Part Name	Classic Part Number
8J-6296	Shaft	419-6072
8J-6322	Cup-Roller Brg	399-4447
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084

5MD		
Original Part Number	Part Name	Classic Part Number
8P-1656	Plate-Clutch	367-6071
8P-5961	Gear-Ring	385-6137
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8W-0328	Cylinder-Damper	419-4715
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2308	Shaft-Planet	275-5285
8W-3589	Link As-Spring	380-7389
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3288	Bolt-Draft	333-4941
9D-7924	Mount As	360-2356

Sales Model 140G (Cont'd.)

5MD		
Original Part Number	**Part Name**	**Classic Part Number**
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9D-9968	Washer-Thrust	391-9890
9M-1853	Mount As.	376-3638
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
109-5562	Shaft-Pin (Bev)	275-5272
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977

5MD		
Original Part Number	**Part Name**	**Classic Part Number**
112-3249	Muffler As	247-2661
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
139-0683	Gasket Kit	390-5290
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
155-1379	Gasket Kit - Sch	386-3815
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687

5MD		
Original Part Number	**Part Name**	**Classic Part Number**
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
184-9843	Head	347-0461
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-3986	Gasket Kit	390-5275
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
246-5916	Kit-Seal-H.Cyl-1	472-8026
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
288-2552	Kit-Gasket-Txg	391-9884
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model 140G (Cont'd.)

72V		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-4695	Cup-Rlr Bearing	374-1842
1P-4696	Cone-Rlr Bearing	374-1843
1P-5480	Cover As.-End	299-1998
1P-7115	Mount As	418-1936
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
1U-4661	Lever Gp	396-7267
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221

72V		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-2858	Cap-Pivot	243-0345
2G-5768	Gear-Bevel	388-0646
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-7464	Insert-Bolt	386-4918
2G-8238	Yoke As	282-6631
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8739	Retainer	389-6314
2G-9098	Cap	300-2573
2K-6413	Pin	360-2270
2M-8714	Cone-Roller Brg	420-2492
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1738	Plate As-Oil Pan	325-6164

72V		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4364	Housing As-Cl	396-9928
2P-4432	Gear-Ring	418-9583
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-4611	Pipe-Exhaust	365-8821
2P-5608	Pipe-Extension	367-6066
2P-5609	Muffler As.	247-2665
2P-5769	Coupling	394-9812
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3D-9126	Cup-Roller Brg	399-4435
3G-1853	Cyl Gp-076 406 Y	415-1895
3G-4752	Cyl Gp-035-060-Y	390-0987
3G-5223	Cyl Gp-0083-1016	399-8557

Sales Model 140G (Cont'd.)

72V		
Original Part Number	**Part Name**	**Classic Part Number**
3G-5224	Cyl Gp-0083-0459	425-9375
3L-1425	Bearing-Ball	311-9356
3P-0165	Pulley-Fan Drive	298-2775
3P-0296	Gear	416-2149
3P-0297	Shaft As	275-5297
3P-0298	Carrier-Input	384-5922
3P-0329	Drum As-Gear	380-7484
3P-0726	Shaft As	275-5298
3P-0786	Coupling	433-0440
3P-0801	Plate-Clutch	383-2119
3P-0951	Bearing-Spl Ball	416-2159
3P-3424	Shaft	416-5526
3P-5349	Piston As	275-5292
3P-5737	Shaft As-Clutch	275-5273
3P-5955	Disc-Friction	428-7205
3T-2095	Bearing-Sleeve	384-3459
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-2619	Bearing	417-4494
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366

72V		
Original Part Number	**Part Name**	**Classic Part Number**
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-0470	Valve Gp-Qrel	314-8549
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024

72V		
Original Part Number	**Part Name**	**Classic Part Number**
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-0925	Actuator Gp-Bk	379-0198
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8500	Shoe-Circle Dr	243-0359
5T-8501	Shoe-Circle Dr	243-0358
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-8425	Valve Gp-Cont -K	367-6086
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

Sales Model 140G (Cont'd.)

72V		
Original Part Number	**Part Name**	**Classic Part Number**
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0622	Elbow-Exhaust	380-7534
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-2090	Base-Xmsn O Fil	397-5049
6S-3051	Cup-Rlr Brg	415-1928
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
6Y-0305	Cage As-Bearing	297-7150
6Y-0306	Bearing-Sleeve	391-1104
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
6Y-7916	Disc-Friction	428-7204
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-5861	Adapter	243-0364
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847

72V		
Original Part Number	**Part Name**	**Classic Part Number**
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-3451	Gear-Planet	297-7188
7G-3452	Gear-Planet	275-5290
7G-3461	Gear-Planet	275-5291
7J-3351	Head	380-1515
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656

72V		
Original Part Number	**Part Name**	**Classic Part Number**
7S-8576	Bearing As	435-4848
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-9647	Piston-Clutch	275-5294
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5095	Gear-Flywheel	425-9190
7W-5696	Hub-Cshft	424-5887
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8D-0983	Mounting	384-3470
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-2469	Shaft-Drive	275-5280
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-3744	Shaft-Drive	275-5283
8D-3877	Gear-Sun	275-5278
8D-3949	Ring-Wear	330-9283
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7083	Bearing	386-4930
8D-7086	Bearing	330-9251
8D-7096	Pin-Axle Leaning	297-7219
8D-7167	Pin	389-6319
8D-7284	Bearing	330-9252
8D-7427	Shaft-Dr Pinion	282-6568
8D-7693	Housing	384-4830
8D-7996	Bearing-Sleeve	472-8018
8D-8159	Retainer	419-8661
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512

Sales Model 140G (Cont'd.)

72V		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
8J-0546	Cyl Gp-076 276 Y	430-8116
8J-1616	Lever	330-9271
8J-1624	Valve As	390-0997
8J-2022	Piston As-Pump	367-6073
8J-6296	Shaft	419-6072
8J-6322	Cup-Roller Brg	399-4447
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349

72V		
Original Part Number	**Part Name**	**Classic Part Number**
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1656	Plate-Clutch	367-6071
8P-5961	Gear-Ring	385-6137
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8W-0328	Cylinder-Damper	419-4715
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2308	Shaft-Planet	275-5285
8W-3589	Link As-Spring	380-7389
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214

72V		
Original Part Number	**Part Name**	**Classic Part Number**
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
9B-1320	Valve-Check	377-5832
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3288	Bolt-Draft	333-4941
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9D-9968	Washer-Thrust	391-9890
9F-3212	Bearing-Ball	384-5953
9J-3466	Cyl Gp-028 121 Y	393-0913
9M-1853	Mount As.	376-3638
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124

Sales Model 140G (Cont'd.)

72V		
Original Part Number	**Part Name**	**Classic Part Number**
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
109-5562	Shaft-Pin (Bev)	275-5272
110-1337	Ring Kit-Pstn	377-5834
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp-Univ	297-4858
115-4072	Bearing	397-5069
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
133-4995	Gasket-Cyl Head	434-2445

72V		
Original Part Number	**Part Name**	**Classic Part Number**
134-4200	Manifold-Exhaust	443-2060
139-0683	Gasket Kit	390-5290
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
154-8030	Gasket	394-0894
155-1379	Gasket Kit - Sch	386-3815
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
170-0560	Rebuild Kit-Pump	363-7458
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7772	Pump Gp-Water -B	438-2009

72V		
Original Part Number	**Part Name**	**Classic Part Number**
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
174-6822	Bearing-Sleeve	387-2901
184-9843	Head	347-0461
190-0649	Tightener-Belt	434-1407
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-3986	Gasket Kit	390-5275
200-7929	Housing	416-5489
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
236-7724	Retainer	299-2048
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
246-5916	Kit-Seal-H.Cyl-1	472-8026
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
288-2552	Kit-Gasket-Txg	391-9884
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

Motor Graders

Sales Model 140G (Cont'd.)

72V		
Original Part Number	**Part Name**	**Classic Part Number**
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

72V		
Original Part Number	**Part Name**	**Classic Part Number**
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

72V		
Original Part Number	**Part Name**	**Classic Part Number**
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

81V		
Original Part Number	**Part Name**	**Classic Part Number**
1B-5675	Bearing	377-7396
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
3P-0951	Bearing-Spl Ball	416-2159
3T-2095	Bearing-Sleeve	384-3459
5M-2054	Bearing	380-7510

81V		
Original Part Number	**Part Name**	**Classic Part Number**
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
6K-8088	Bearing-Roller	399-4428
6N-7263	Gasket-Cyl Head	380-7386
6Y-0306	Bearing-Sleeve	391-1104
7S-8576	Bearing As	435-4848
8J-6322	Cup-Roller Brg	399-4447

81V		
Original Part Number	**Part Name**	**Classic Part Number**
9D-1589	Mounting	387-2928
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
139-0683	Gasket Kit	390-5290
196-3986	Gasket Kit	390-5275
288-2552	Kit-Gasket-Txg	391-9884

Sales Model 140H

126		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488

126		
Original Part Number	**Part Name**	**Classic Part Number**
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
3J-6575	Trunnion	297-7265
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632

126		
Original Part Number	**Part Name**	**Classic Part Number**
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927

Sales Model 140H (Cont'd.)

126		
Original Part Number	**Part Name**	**Classic Part Number**
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
6E-0775	Head	425-9373
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6H-2577	Spider Gp-Brg&	333-4954
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6V-3831	Seal-O-Ring	436-2657
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7N-7435	Kit-Major Repair	374-4724

126		
Original Part Number	**Part Name**	**Classic Part Number**
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356

126		
Original Part Number	**Part Name**	**Classic Part Number**
9D-8285	Cap	391-9822
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9T-2387	Rod As	393-5218
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
104-8655	Bearing-Sleeve	391-9892
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
110-4652	Housing	302-2683
111-2645	Valve-Pump Byp	441-1561
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
135-7393	Head	382-6895
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3310	Spindle-Wheel	383-2111

Sales Model 140H (Cont'd.)

126		
Original Part Number	**Part Name**	**Classic Part Number**
147-3400	Spindle	282-6549
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-2593	Head	383-1591
152-6485	Cyl Gp-102 472 Y	390-0985
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
166-6352	Tube As.	432-4223
174-6822	Bearing-Sleeve	387-2901
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600

126		
Original Part Number	**Part Name**	**Classic Part Number**
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
200-7929	Housing	416-5489
216-4781	Gasket Kit	437-8144
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

126		
Original Part Number	**Part Name**	**Classic Part Number**
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
315-6671	Kit-Gasket(Op)	438-0139
319-2228	Shoe-Circle Gde	419-4706
352-2077	Pump Gp-Water -B	434-6108

2ZK		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006

2ZK		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682

2ZK		
Original Part Number	**Part Name**	**Classic Part Number**
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8739	Retainer	389-6314
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

Sales Model 140H (Cont'd.)

2ZK		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

2ZK		
Original Part Number	Part Name	Classic Part Number
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011

2ZK		
Original Part Number	Part Name	Classic Part Number
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335

Sales Model 140H (Cont'd.)

2ZK		
Original Part Number	Part Name	Classic Part Number
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989

2ZK		
Original Part Number	Part Name	Classic Part Number
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290

2ZK		
Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816

Sales Model 140H (Cont'd.)

2ZK		
Original Part Number	Part Name	Classic Part Number
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
8X-8067	Mounting	394-0205
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9T-5729	Cyl Gp-0038 0158	422-2486
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134

2ZK		
Original Part Number	Part Name	Classic Part Number
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
130-1455	Gasket Kit	437-4604
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

2ZK		
Original Part Number	Part Name	Classic Part Number
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model 140H (Cont'd.)

3AS		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488

3AS		
Original Part Number	Part Name	Classic Part Number
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203

3AS		
Original Part Number	Part Name	Classic Part Number
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158

Sales Model 140H (Cont'd.)

3AS		
Original Part Number	**Part Name**	**Classic Part Number**
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263

3AS		
Original Part Number	**Part Name**	**Classic Part Number**
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670

3AS		
Original Part Number	**Part Name**	**Classic Part Number**
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512

Sales Model 140H (Cont'd.)

3AS		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415

3AS		
Original Part Number	Part Name	Classic Part Number
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042

3AS		
Original Part Number	Part Name	Classic Part Number
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-4200	Manifold-Exhaust	443-2060

Sales Model 140H (Cont'd.)

3AS		
Original Part Number	**Part Name**	**Classic Part Number**
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127

3AS		
Original Part Number	**Part Name**	**Classic Part Number**
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048

3AS		
Original Part Number	**Part Name**	**Classic Part Number**
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

3FR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1W-1669	Piston	325-6158

3FR		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555

3FR		
Original Part Number	**Part Name**	**Classic Part Number**
2G-6285	Valve Kt	383-1570
2H-6489	Race-Brg Outer	374-8350
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2S-5100	Valve-Ball	386-3049

Sales Model 140H (Cont'd.)

3FR		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930

3FR		
Original Part Number	**Part Name**	**Classic Part Number**
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
6B-7469	Spacer	417-4535
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-5704	Piston	394-9838
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502

3FR		
Original Part Number	**Part Name**	**Classic Part Number**
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-3591	Carrier-Planet	301-4769
8D-9804	Housing-Drive	302-2682
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893

Sales Model 140H (Cont'd.)

3FR		
Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8W-2308	Shaft-Planet	275-5285

3FR		
Original Part Number	Part Name	Classic Part Number
8W-5092	Pinion-Circle Dr	282-6569
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-2754	Insert	333-4948
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
105-3196	Motor Gp-Grtr	282-6547
111-8015	Gasket As-Head	279-4977
112-5495	Joint Gp-Univ	297-4858
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
148-7455	Valve - Exhaust	270-4361

5HM		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988

3FR		
Original Part Number	Part Name	Classic Part Number
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
232-3233	Bearing-Main	376-9085
236-7724	Retainer	299-2048
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
312-0782	Worm-Circ Drv	282-6623
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model 140H (Cont'd.)

5HM		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354

5HM		
Original Part Number	**Part Name**	**Classic Part Number**
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7213	Bearing-Sleeve	419-4667

5HM		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-7688	Valve As-Check	420-6216
4P-7790	Shaft As-Arm	457-4596
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8577	Rod As-Injector	455-5513
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

Sales Model 140H (Cont'd.)

5HM		
Original Part Number	Part Name	Classic Part Number
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160

5HM		
Original Part Number	Part Name	Classic Part Number
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-7213	Carrier-Planet	396-9936
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1099	Manifold-Exh	424-6366
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016

5HM		
Original Part Number	Part Name	Classic Part Number
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-3773	Pulley-Cshaft	383-1583

Sales Model 140H (Cont'd.)

5HM		
Original Part Number	**Part Name**	**Classic Part Number**
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8064	Valve-Inlet	384-8705
7W-9020	Bell As-Pump Suc	378-3989
7W-9027	Base-Oil Cooler	399-8545
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291

5HM		
Original Part Number	**Part Name**	**Classic Part Number**
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2307	Shaft-Planet	275-5284
8W-2308	Shaft-Planet	275-5285
8W-4652	Housing-Spindle	385-7215

5HM		
Original Part Number	**Part Name**	**Classic Part Number**
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8289	Sprocket	282-6629
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
002-1212	Cup-Roller Brg	399-4446

Sales Model 140H (Cont'd.)

5HM		
Original Part Number	Part Name	Classic Part Number
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-6267	Plate As-Idler	375-9983
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-1738	Manifold-Exhaust	374-4692
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3240	Pin	282-6548
126-5875	Flywheel As.	374-4694
129-2381	Gear-Planet	275-5274
130-1455	Gasket Kit	437-4604
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
136-0819	Valve-Exhaust	384-8697
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312

5HM		
Original Part Number	Part Name	Classic Part Number
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-3309	Spindle	282-6628
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
163-1387	Gear-Flywheel	374-4697
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259

5HM		
Original Part Number	Part Name	Classic Part Number
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model 140H (Cont'd.)

8JM		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2F-5721	Bearing-Ball	311-9354

8JM		
Original Part Number	**Part Name**	**Classic Part Number**
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983

8JM		
Original Part Number	**Part Name**	**Classic Part Number**
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614

Sales Model 140H (Cont'd.)

8JM		
Original Part Number	Part Name	Classic Part Number
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538

8JM		
Original Part Number	Part Name	Classic Part Number
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686

8JM		
Original Part Number	Part Name	Classic Part Number
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037

Sales Model 140H (Cont'd.)

8JM		
Original Part Number	Part Name	Classic Part Number
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733

8JM		
Original Part Number	Part Name	Classic Part Number
8W-1753	Bracket-Rail	288-8734
8W-2308	Shaft-Planet	275-5285
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925

8JM		
Original Part Number	Part Name	Classic Part Number
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
130-1455	Gasket Kit	437-4604
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

Sales Model 140H (Cont'd.)

8JM		
Original Part Number	**Part Name**	**Classic Part Number**
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461

8JM		
Original Part Number	**Part Name**	**Classic Part Number**
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351

8JM		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

8KM		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

8KM		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-6285	Valve Kt	383-1570

8KM		
Original Part Number	**Part Name**	**Classic Part Number**
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

Sales Model 140H (Cont'd.)

8KM		
Original Part Number	Part Name	Classic Part Number
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687

8KM		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043

8KM		
Original Part Number	Part Name	Classic Part Number
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847

Sales Model 140H (Cont'd.)

8KM		
Original Part Number	Part Name	Classic Part Number
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492

8KM		
Original Part Number	Part Name	Classic Part Number
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

8KM		
Original Part Number	Part Name	Classic Part Number
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822

Sales Model 140H (Cont'd.)

8KM		
Original Part Number	**Part Name**	**Classic Part Number**
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626

8KM		
Original Part Number	**Part Name**	**Classic Part Number**
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3038	Gasket Kit	437-3228
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484

9TN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988

8KM		
Original Part Number	**Part Name**	**Classic Part Number**
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model 140H (Cont'd.)

9TN		
Original Part Number	Part Name	Classic Part Number
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-5383	Gasket	445-7709

9TN		
Original Part Number	Part Name	Classic Part Number
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8739	Retainer	389-6314
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049

9TN		
Original Part Number	Part Name	Classic Part Number
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563

Sales Model 140H (Cont'd.)

9TN		
Original Part Number	**Part Name**	**Classic Part Number**
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373

9TN		
Original Part Number	**Part Name**	**Classic Part Number**
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847

9TN		
Original Part Number	**Part Name**	**Classic Part Number**
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341

Sales Model 140H (Cont'd.)

9TN		
Original Part Number	Part Name	Classic Part Number
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

9TN		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
8X-8067	Mounting	394-0205
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948

9TN		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548

Sales Model 140H (Cont'd.)

9TN		
Original Part Number	**Part Name**	**Classic Part Number**
129-2381	Gear-Planet	275-5274
130-1455	Gasket Kit	437-4604
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591

9TN		
Original Part Number	**Part Name**	**Classic Part Number**
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

9TN		
Original Part Number	**Part Name**	**Classic Part Number**
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

9ZN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834

9ZN		
Original Part Number	**Part Name**	**Classic Part Number**
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

9ZN		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513

Sales Model 140H (Cont'd.)

9ZN		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8739	Retainer	389-6314
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230

9ZN		
Original Part Number	Part Name	Classic Part Number
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3J-6575	Trunnion	297-7265
3Y-2768	Ring	439-4544
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

9ZN		
Original Part Number	Part Name	Classic Part Number
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011

Sales Model 140H (Cont'd.)

9ZN		
Original Part Number	**Part Name**	**Classic Part Number**
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335

9ZN		
Original Part Number	**Part Name**	**Classic Part Number**
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7J-3351	Head	380-1515
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7K-9348	Pin	252-6872
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187

9ZN		
Original Part Number	**Part Name**	**Classic Part Number**
7W-9020	Bell As-Pump Suc	378-3989
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349

Sales Model 140H (Cont'd.)

9ZN		
Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105

9ZN		
Original Part Number	Part Name	Classic Part Number
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683

9ZN		
Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As-Head	279-4977
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
130-1455	Gasket Kit	437-4604
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
135-7393	Head	382-6895
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
152-6485	Cyl Gp-102 472 Y	390-0985
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687

Sales Model 140H (Cont'd.)

9ZN		
Original Part Number	**Part Name**	**Classic Part Number**
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085

9ZN		
Original Part Number	**Part Name**	**Classic Part Number**
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988

9ZN		
Original Part Number	**Part Name**	**Classic Part Number**
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

APM		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-6810	Pipe-Outlet	472-8036
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555

APM		
Original Part Number	**Part Name**	**Classic Part Number**
2G-2411	Ballstud As	387-2899
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236

APM		
Original Part Number	**Part Name**	**Classic Part Number**
4S-8472	Hood As-Preclnr	296-1355
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6D-4671	Ballstud	420-6530

Sales Model 140H (Cont'd.)

APM		
Original Part Number	Part Name	Classic Part Number
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6V-3831	Seal-O-Ring	436-2657
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7N-7435	Kit-Major Repair	374-4724
7P-1577	Pin As	375-9969
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8D-1784	Pin	282-6567

APM		
Original Part Number	Part Name	Classic Part Number
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121

APM		
Original Part Number	Part Name	Classic Part Number
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
104-8655	Bearing-Sleeve	391-9892
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-2645	Valve-Pump Byp	441-1561
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

Sales Model 140H (Cont'd.)

APM		
Original Part Number	**Part Name**	**Classic Part Number**
118-2800	Housing As.-Rglt	419-4719
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-2593	Head	383-1591
151-5349	Head	383-1592

APM		
Original Part Number	**Part Name**	**Classic Part Number**
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
166-6352	Tube As.	432-4223
174-6822	Bearing-Sleeve	387-2901
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
200-7929	Housing	416-5489

APM		
Original Part Number	**Part Name**	**Classic Part Number**
216-4781	Gasket Kit	437-8144
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
315-6671	Kit-Gasket(Op)	438-0139
319-2228	Shoe-Circle Gde	419-4706
352-2077	Pump Gp-Water -B	434-6108

CCA		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-6810	Pipe-Outlet	472-8036
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955

CCA		
Original Part Number	**Part Name**	**Classic Part Number**
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
3J-6575	Trunnion	297-7265
4B-7270	Cone-Bearing	399-4439

CCA		
Original Part Number	**Part Name**	**Classic Part Number**
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4S-8472	Hood As-Preclnr	296-1355
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614

Sales Model 140H (Cont'd.)

CCA		
Original Part Number	Part Name	Classic Part Number
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6H-2577	Spider Gp-Brg&	333-4954
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6V-3831	Seal-O-Ring	436-2657
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297

CCA		
Original Part Number	Part Name	Classic Part Number
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7N-7435	Kit-Major Repair	374-4724
7P-1577	Pin As	375-9969
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105

CCA		
Original Part Number	Part Name	Classic Part Number
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9T-2387	Rod As	393-5218
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
104-8655	Bearing-Sleeve	391-9892
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-2645	Valve-Pump Byp	441-1561
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259

Sales Model 140H (Cont'd.)

CCA		
Original Part Number	**Part Name**	**Classic Part Number**
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
135-7393	Head	382-6895
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154

CCA		
Original Part Number	**Part Name**	**Classic Part Number**
148-2593	Head	383-1591
151-5349	Head	383-1592
152-6485	Cyl Gp-102 472 Y	390-0985
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
166-6352	Tube As.	432-4223
174-6822	Bearing-Sleeve	387-2901
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407

CCA		
Original Part Number	**Part Name**	**Classic Part Number**
197-9251	Pin As.-Piston	454-6110
200-7929	Housing	416-5489
216-4781	Gasket Kit	437-8144
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
315-6671	Kit-Gasket(Op)	438-0139
319-2228	Shoe-Circle Gde	419-4706
352-2077	Pump Gp-Water -B	434-6108

XZH		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

XZH		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555

XZH		
Original Part Number	**Part Name**	**Classic Part Number**
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214

Sales Model 140H (Cont'd.)

XZH		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987

XZH		
Original Part Number	Part Name	Classic Part Number
4S-8472	Hood As-Preclnr	296-1355
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535

XZH		
Original Part Number	Part Name	Classic Part Number
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607

Sales Model 140H (Cont'd.)

XZH		
Original Part Number	Part Name	Classic Part Number
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511

XZH		
Original Part Number	Part Name	Classic Part Number
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033

XZH		
Original Part Number	Part Name	Classic Part Number
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1753	Bracket-Rail	288-8734
8W-2308	Shaft-Planet	275-5285
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891

Sales Model 140H (Cont'd.)

XZH		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627

XZH		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009

XZH		
Original Part Number	Part Name	Classic Part Number
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model 140K

JPA		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840

JPA		
Original Part Number	Part Name	Classic Part Number
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851

JPA		
Original Part Number	Part Name	Classic Part Number
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504

Sales Model 140K (Cont'd.)

JPA		
Original Part Number	Part Name	Classic Part Number
1P-7115	Mount As	418-1936
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158

JPA		
Original Part Number	Part Name	Classic Part Number
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-9514	Bearing-Ball	417-9467
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-8642	Race-Brg Outer	396-9898
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016

JPA		
Original Part Number	Part Name	Classic Part Number
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7W-5095	Gear-Flywheel	425-9190
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2308	Shaft-Planet	275-5285
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569

Sales Model 140K (Cont'd.)

JPA		
Original Part Number	Part Name	Classic Part Number
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
8Y-0809	Spider Gp-Brg&	417-4526
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-8285	Cap	391-9822
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-2387	Rod As	393-5218
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925

JPA		
Original Part Number	Part Name	Classic Part Number
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
104-8655	Bearing-Sleeve	391-9892
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
115-4072	Bearing	397-5069
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
133-4995	Gasket-Cyl Head	434-2445
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
154-8030	Gasket	394-0894

JPA		
Original Part Number	Part Name	Classic Part Number
163-1387	Gear-Flywheel	374-4697
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
200-7929	Housing	416-5489
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

SZL		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834

SZL		
Original Part Number	Part Name	Classic Part Number
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382

SZL		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-4011	Collar	330-9269
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551

Sales Model 140K (Cont'd.)

SZL		
Original Part Number	Part Name	Classic Part Number
2G-6377	Sprocket	275-5286
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518

SZL		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5T-0735	Chain Gp	390-5262
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-7213	Carrier-Planet	396-9936
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-8642	Race-Brg Outer	396-9898
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016

SZL		
Original Part Number	Part Name	Classic Part Number
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7W-5095	Gear-Flywheel	425-9190
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9296	Bearing	330-9253
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2307	Shaft-Planet	275-5284

Sales Model 140K (Cont'd.)

SZL		
Original Part Number	Part Name	Classic Part Number
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
8Y-0809	Spider Gp-Brg&	417-4526
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-8285	Cap	391-9822
9M-1328	Bearing-Aligning	325-6018

SZL		
Original Part Number	Part Name	Classic Part Number
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-2387	Rod As	393-5218
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
104-8655	Bearing-Sleeve	391-9892
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
115-4072	Bearing	397-5069
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
133-4995	Gasket-Cyl Head	434-2445
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
147-3309	Spindle	282-6628

SZL		
Original Part Number	Part Name	Classic Part Number
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
200-7929	Housing	416-5489
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

SZW		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147

SZW		
Original Part Number	Part Name	Classic Part Number
1P-2662	Cone-Roller Brg	374-1851
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936

SZW		
Original Part Number	Part Name	Classic Part Number
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955

Sales Model 140K (Cont'd.)

SZW		
Original Part Number	Part Name	Classic Part Number
2D-2654	Ring-Lock	380-1488
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-3490	Cone-Rlr Bearing	380-7518
5P-9514	Bearing-Ball	417-9467

SZW		
Original Part Number	Part Name	Classic Part Number
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1914	Shim	434-1864
6G-2947	Shaft	243-0346
6G-5704	Piston	394-9838
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-8642	Race-Brg Outer	396-9898
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7W-5095	Gear-Flywheel	425-9190
8D-2429	Pin As	319-3445

SZW		
Original Part Number	Part Name	Classic Part Number
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4766	Pin-Cylinder	365-8832
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
8Y-0809	Spider Gp-Brg&	417-4526
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-8285	Cap	391-9822
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500

Sales Model 140K (Cont'd.)

SZW		
Original Part Number	Part Name	Classic Part Number
9T-2387	Rod As	393-5218
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
104-8655	Bearing-Sleeve	391-9892
105-3196	Motor Gp-Grtr	282-6547
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
115-4072	Bearing	397-5069
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626

SZW		
Original Part Number	Part Name	Classic Part Number
131-3738	Socket As	282-6627
133-4995	Gasket-Cyl Head	434-2445
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
200-7929	Housing	416-5489
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870

SZW		
Original Part Number	Part Name	Classic Part Number
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

Sales Model 140M

B9D		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

B9D		
Original Part Number	Part Name	Classic Part Number
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
3J-6575	Trunnion	297-7265
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007

B9D		
Original Part Number	Part Name	Classic Part Number
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160

Sales Model 140M (Cont'd.)

B9D		
Original Part Number	Part Name	Classic Part Number
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8J-6384	Bearing-Sleeve	472-8034

B9D		
Original Part Number	Part Name	Classic Part Number
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-2754	Insert	333-4948
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
9T-5729	Cyl Gp-0038 0158	422-2486
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
115-4072	Bearing	397-5069
131-3736	Socket Gp-Basic	325-6211
133-4995	Gasket-Cyl Head	434-2445
135-7393	Head	382-6895
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380

B9D		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985
154-8030	Gasket	394-0894
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
246-5916	Kit-Seal-H.Cyl-1	472-8026
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

B9G		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294

B9G		
Original Part Number	Part Name	Classic Part Number
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

B9G		
Original Part Number	Part Name	Classic Part Number
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350

Sales Model 140M (Cont'd.)

B9G		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8437	Cone-Roller Brg	380-1502

B9G		
Original Part Number	Part Name	Classic Part Number
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
105-3196	Motor Gp-Grtr	282-6547
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134

B9G		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

B9M		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497

B9M		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

B9M		
Original Part Number	Part Name	Classic Part Number
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555

Sales Model 140M (Cont'd.)

B9M		
Original Part Number	Part Name	Classic Part Number
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

B9M		
Original Part Number	Part Name	Classic Part Number
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-2754	Insert	333-4948
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
9T-5729	Cyl Gp-0038 0158	422-2486
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382

B9M		
Original Part Number	Part Name	Classic Part Number
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
115-4072	Bearing	397-5069
131-3736	Socket Gp-Basic	325-6211
133-4995	Gasket-Cyl Head	434-2445
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
246-5916	Kit-Seal-H.Cyl-1	472-8026
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

Sales Model 140M (Cont'd.)

D9G		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
3J-6575	Trunnion	297-7265
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262

D9G		
Original Part Number	Part Name	Classic Part Number
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500

D9G		
Original Part Number	Part Name	Classic Part Number
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
105-3196	Motor Gp-Grtr	282-6547
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
135-7393	Head	382-6895
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985
154-8030	Gasket	394-0894
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

Sales Model 140M (Cont'd.)

E9A		
Original Part Number	**Part Name**	**Classic Part Number**
2D-2654	Ring-Lock	380-1488
2K-6413	Pin	360-2270

E9A		
Original Part Number	**Part Name**	**Classic Part Number**
4T-8054	Seal As	472-8010
8W-9566	Flange As	376-9073

E9M		
Original Part Number	**Part Name**	**Classic Part Number**
2D-2654	Ring-Lock	380-1488
2K-6413	Pin	360-2270

E9M		
Original Part Number	**Part Name**	**Classic Part Number**
4T-8054	Seal As	472-8010
8W-9566	Flange As	376-9073

M9D		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010

M9D		
Original Part Number	**Part Name**	**Classic Part Number**
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6V-3831	Seal-O-Ring	436-2657
6Y-9960	Mount As.	376-3639
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018

M9D		
Original Part Number	**Part Name**	**Classic Part Number**
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
105-3196	Motor Gp-Grtr	282-6547
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
148-2593	Head	383-1591
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870

Sales Model 140M (Cont'd.)

M9D		
Original Part Number	Part Name	Classic Part Number
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

M9D		
Original Part Number	Part Name	Classic Part Number
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028

M9D		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

M9G		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507

M9G		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7G-0437	Plate-Clutch	417-9466
7J-5131	Trunnion	296-1371
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511

M9G		
Original Part Number	Part Name	Classic Part Number
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

M9J		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840

M9J		
Original Part Number	Part Name	Classic Part Number
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294

M9J		
Original Part Number	Part Name	Classic Part Number
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174

Sales Model 140M (Cont'd.)

M9J		
Original Part Number	**Part Name**	**Classic Part Number**
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012

M9J		
Original Part Number	**Part Name**	**Classic Part Number**
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034

M9J		
Original Part Number	**Part Name**	**Classic Part Number**
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
115-4072	Bearing	397-5069
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

M9M		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

M9M		
Original Part Number	**Part Name**	**Classic Part Number**
2F-8509	Cone-Roller Brg	399-4434
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007

M9M		
Original Part Number	**Part Name**	**Classic Part Number**
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065

Sales Model 140M (Cont'd.)

M9M		
Original Part Number	Part Name	Classic Part Number
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6V-3831	Seal-O-Ring	436-2657
6Y-9960	Mount As.	376-3639
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7J-5131	Trunnion	296-1371
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511

M9M		
Original Part Number	Part Name	Classic Part Number
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
105-3196	Motor Gp-Grtr	282-6547
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380

M9M		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

N9D		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682

N9D		
Original Part Number	Part Name	Classic Part Number
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283

N9D		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898

Sales Model 140M (Cont'd.)

N9D		
Original Part Number	**Part Name**	**Classic Part Number**
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384

N9D		
Original Part Number	**Part Name**	**Classic Part Number**
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547

N9D		
Original Part Number	**Part Name**	**Classic Part Number**
107-8375	Shaft As	439-1134
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

N9G		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007

N9G		
Original Part Number	**Part Name**	**Classic Part Number**
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969

N9G		
Original Part Number	**Part Name**	**Classic Part Number**
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
161-3411	Gasket	394-0896

Sales Model 140M (Cont'd.)

N9G		
Original Part Number	Part Name	Classic Part Number
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

N9G		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031

N9G		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

N9J		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283

N9J		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384

N9J		
Original Part Number	Part Name	Classic Part Number
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

N9M		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840

N9M		
Original Part Number	Part Name	Classic Part Number
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1W-4738	Bearing-Sleeve	325-6020

N9M		
Original Part Number	Part Name	Classic Part Number
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914

Sales Model 140M (Cont'd.)

N9M		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433

N9M		
Original Part Number	**Part Name**	**Classic Part Number**
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034

N9M		
Original Part Number	**Part Name**	**Classic Part Number**
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

R9G		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682

R9G		
Original Part Number	**Part Name**	**Classic Part Number**
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010

R9G		
Original Part Number	**Part Name**	**Classic Part Number**
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639

Sales Model 140M (Cont'd.)

R9G		
Original Part Number	Part Name	Classic Part Number
7D-8437	Cone-Roller Brg	380-1502
7G-0437	Plate-Clutch	417-9466
7J-5131	Trunnion	296-1371
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384

R9G		
Original Part Number	Part Name	Classic Part Number
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
105-3196	Motor Gp-Grtr	282-6547

R9G		
Original Part Number	Part Name	Classic Part Number
107-8375	Shaft As	439-1134
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

R9M		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-8509	Cone-Roller Brg	399-4434
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632

R9M		
Original Part Number	Part Name	Classic Part Number
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6V-3831	Seal-O-Ring	436-2657
6Y-9960	Mount As.	376-3639
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

R9M		
Original Part Number	Part Name	Classic Part Number
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7J-5131	Trunnion	296-1371
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018

Motor Graders

Sales Model 140M (Cont'd.)

R9M		
Original Part Number	Part Name	Classic Part Number
9M-2042	Race-Roller Brg	417-9500
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
105-3196	Motor Gp-Grtr	282-6547
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
143-7356	Bearing As	380-1483

R9M		
Original Part Number	Part Name	Classic Part Number
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024

R9M		
Original Part Number	Part Name	Classic Part Number
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

Sales Model 143H

1AL		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-4695	Cup-Rlr Bearing	374-1842
1P-4696	Cone-Rlr Bearing	374-1843
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294

1AL		
Original Part Number	Part Name	Classic Part Number
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273

1AL		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8609	Pin	319-3450
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

Sales Model 143H (Cont'd.)

1AL		
Original Part Number	Part Name	Classic Part Number
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3D-9126	Cup-Roller Brg	399-4435
4B-7270	Cone-Bearing	399-4439
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008

1AL		
Original Part Number	Part Name	Classic Part Number
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247

1AL		
Original Part Number	Part Name	Classic Part Number
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204

Sales Model 143H (Cont'd.)

1AL		
Original Part Number	Part Name	Classic Part Number
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935

1AL		
Original Part Number	Part Name	Classic Part Number
7W-5696	Hub-Cshft	424-5887
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623

1AL		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482

Sales Model 143H (Cont'd.)

1AL		
Original Part Number	Part Name	Classic Part Number
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
8X-8067	Mounting	394-0205
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9T-5729	Cyl Gp-0038 0158	422-2486
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547

1AL		
Original Part Number	Part Name	Classic Part Number
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
130-1455	Gasket Kit	437-4604
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3038	Gasket Kit	437-3228
134-3068	Kit-Gasket(F)	393-3636
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126

1AL		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005

Sales Model 143H (Cont'd.)

1AL		
Original Part Number	**Part Name**	**Classic Part Number**
391-8229	Kit-Gasket-Fs	398-2955

1AL		
Original Part Number	**Part Name**	**Classic Part Number**
391-8256	Kit-Gasket (Sch)	447-8653

APN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-6810	Pipe-Outlet	472-8036
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811

APN		
Original Part Number	**Part Name**	**Classic Part Number**
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
4B-7270	Cone-Bearing	399-4439
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4S-8472	Hood As-Preclnr	296-1355
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541

APN		
Original Part Number	**Part Name**	**Classic Part Number**
5P-3490	Cone-Rlr Bearing	380-7518
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6V-3831	Seal-O-Ring	436-2657
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502

Sales Model 143H (Cont'd.)

APN		
Original Part Number	Part Name	Classic Part Number
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7N-7435	Kit-Major Repair	374-4724
7P-1577	Pin As	375-9969
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287

APN		
Original Part Number	Part Name	Classic Part Number
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
104-8655	Bearing-Sleeve	391-9892
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-2645	Valve-Pump Byp	441-1561
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858

APN		
Original Part Number	Part Name	Classic Part Number
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3310	Spindle-Wheel	383-2111
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-2593	Head	383-1591
151-5349	Head	383-1592
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
166-6352	Tube As.	432-4223
174-6822	Bearing-Sleeve	387-2901
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
200-7929	Housing	416-5489
216-4781	Gasket Kit	437-8144
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

Sales Model 143H (Cont'd.)

APN		
Original Part Number	Part Name	Classic Part Number
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028

APN		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
315-6671	Kit-Gasket(Op)	438-0139

APN		
Original Part Number	Part Name	Classic Part Number
319-2228	Shoe-Circle Gde	419-4706
352-2077	Pump Gp-Water -B	434-6108

Sales Model 160G

4JD		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1B-5675	Bearing	377-7396
1H-4478	Pin	330-9272
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
1U-4661	Lever Gp	396-7267
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

4JD		
Original Part Number	Part Name	Classic Part Number
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-5768	Gear-Bevel	388-0646
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558

4JD		
Original Part Number	Part Name	Classic Part Number
2G-8629	Pin	282-6560
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8739	Retainer	389-6314
2G-9098	Cap	300-2573
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4364	Housing As-Cl	396-9928
2P-4432	Gear-Ring	418-9583
2P-4433	Gear-Ring	384-4787
2P-4510	Piston-Clutch	275-5293
2P-4611	Pipe-Exhaust	365-8821
2P-5769	Coupling	394-9812
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892

Sales Model 160G (Cont'd.)

4JD		
Original Part Number	Part Name	Classic Part Number
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3G-1853	Cyl Gp-076 406 Y	415-1895
3G-4752	Cyl Gp-035-060-Y	390-0987
3G-5223	Cyl Gp-0083-1016	399-8557
3G-5224	Cyl Gp-0083-0459	425-9375
3L-1425	Bearing-Ball	311-9356
3P-0165	Pulley-Fan Drive	298-2775
3P-0296	Gear	416-2149
3P-0297	Shaft As	275-5297
3P-0298	Carrier-Input	384-5922
3P-0329	Drum As-Gear	380-7484
3P-0726	Shaft As	275-5298
3P-0786	Coupling	433-0440
3P-0801	Plate-Clutch	383-2119
3P-0951	Bearing-Spl Ball	416-2159
3P-3424	Shaft	416-5526
3P-5349	Piston As	275-5292
3P-5737	Shaft As-Clutch	275-5273
3P-5955	Disc-Friction	428-7205
3T-2095	Bearing-Sleeve	384-3459
4B-7270	Cone-Bearing	399-4439
4D-2619	Bearing	417-4494
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009

4JD		
Original Part Number	Part Name	Classic Part Number
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-0470	Valve Gp-Qrel	314-8549
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

4JD		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-0925	Actuator Gp-Bk	379-0198
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-8425	Valve Gp-Cont -K	367-6086
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0622	Elbow-Exhaust	380-7534
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-2090	Base-Xmsn O Fil	397-5049
6V-2202	Bearing-Spl Ball	380-1574
6Y-0305	Cage As-Bearing	297-7150
6Y-0306	Bearing-Sleeve	391-1104

Sales Model 160G (Cont'd.)

4JD		
Original Part Number	Part Name	Classic Part Number
6Y-2027	Disc-Friction	377-7441
6Y-5914	Disc-Friction	390-5265
6Y-7916	Disc-Friction	428-7204
7C-4297	Seal As-Cshaft	325-6192
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-3451	Gear-Planet	297-7188
7G-3452	Gear-Planet	275-5290
7G-3461	Gear-Planet	275-5291
7J-3351	Head	380-1515
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656

4JD		
Original Part Number	Part Name	Classic Part Number
7S-8576	Bearing As	435-4848
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-9647	Piston-Clutch	275-5294
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-2469	Shaft-Drive	275-5280
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-3744	Shaft-Drive	275-5283
8D-3877	Gear-Sun	275-5278
8D-4009	Tube As	392-4496
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7693	Housing	384-4830
8D-7996	Bearing-Sleeve	472-8018
8D-8159	Retainer	419-8661
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-0546	Cyl Gp-076 276 Y	430-8116
8J-1616	Lever	330-9271
8J-1624	Valve As	390-0997
8J-2022	Piston As-Pump	367-6073
8J-6296	Shaft	419-6072
8J-6322	Cup-Roller Brg	399-4447
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599

4JD		
Original Part Number	Part Name	Classic Part Number
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1656	Plate-Clutch	367-6071
8P-5961	Gear-Ring	385-6137
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415

Sales Model 160G (Cont'd.)

4JD		
Original Part Number	Part Name	Classic Part Number
8S-7718	Manifold-Exhaust	295-0416
8W-0328	Cylinder-Damper	419-4715
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2308	Shaft-Planet	275-5285
8W-3589	Link As-Spring	380-7389
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
9D-1491	Coupling	416-2121
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9J-3466	Cyl Gp-028 121 Y	393-0913
9M-1853	Mount As.	376-3638
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

4JD		
Original Part Number	Part Name	Classic Part Number
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
109-5562	Shaft-Pin (Bev)	275-5272
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
139-0683	Gasket Kit	390-5290
143-7356	Bearing As	380-1483
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055

4JD		
Original Part Number	Part Name	Classic Part Number
155-1379	Gasket Kit - Sch	386-3815
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0560	Rebuild Kit-Pump	363-7458
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
184-9843	Head	347-0461
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-3986	Gasket Kit	390-5275
200-7929	Housing	416-5489
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
288-2552	Kit-Gasket-Txg	391-9884
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989

Motor Graders

Sales Model 160G (Cont'd.)

4JD		
Original Part Number	**Part Name**	**Classic Part Number**
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

4JD		
Original Part Number	**Part Name**	**Classic Part Number**
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005

Sales Model 160H

2FM		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036

2FM		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

2FM		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

Sales Model 160H (Cont'd.)

2FM		
Original Part Number	Part Name	Classic Part Number
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

2FM		
Original Part Number	Part Name	Classic Part Number
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017

2FM		
Original Part Number	Part Name	Classic Part Number
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989

Sales Model 160H (Cont'd.)

2FM		
Original Part Number	Part Name	Classic Part Number
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

2FM		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2308	Shaft-Planet	275-5285
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018

2FM		
Original Part Number	Part Name	Classic Part Number
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
130-1455	Gasket Kit	437-4604
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312

Sales Model 160H (Cont'd.)

2FM		
Original Part Number	Part Name	Classic Part Number
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194

2FM		
Original Part Number	Part Name	Classic Part Number
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026

2FM		
Original Part Number	Part Name	Classic Part Number
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

2HS		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497

2HS		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

2HS		
Original Part Number	Part Name	Classic Part Number
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561

Sales Model 160H (Cont'd.)

2HS		
Original Part Number	Part Name	Classic Part Number
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

2HS		
Original Part Number	Part Name	Classic Part Number
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247

2HS		
Original Part Number	Part Name	Classic Part Number
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639

Sales Model 160H (Cont'd.)

2HS		
Original Part Number	Part Name	Classic Part Number
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935

2HS		
Original Part Number	Part Name	Classic Part Number
7W-5696	Hub-Cshft	424-5887
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

2HS		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105

Sales Model 160H (Cont'd.)

2HS		
Original Part Number	Part Name	Classic Part Number
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977

2HS		
Original Part Number	Part Name	Classic Part Number
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3036	Gasket Kit	393-3629
134-3038	Gasket Kit	437-3228
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127

2HS		
Original Part Number	Part Name	Classic Part Number
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model 160H (Cont'd.)

3GM		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488

3GM		
Original Part Number	Part Name	Classic Part Number
2D-5383	Gasket	445-7709
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8739	Retainer	389-6314
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289

3GM		
Original Part Number	Part Name	Classic Part Number
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687

Sales Model 160H (Cont'd.)

3GM		
Original Part Number	**Part Name**	**Classic Part Number**
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530

3GM		
Original Part Number	**Part Name**	**Classic Part Number**
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851

3GM		
Original Part Number	**Part Name**	**Classic Part Number**
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568

Sales Model 160H (Cont'd.)

3GM		
Original Part Number	Part Name	Classic Part Number
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

3GM		
Original Part Number	Part Name	Classic Part Number
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8289	Sprocket	282-6629
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
8X-8067	Mounting	394-0205
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980

3GM		
Original Part Number	Part Name	Classic Part Number
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211

Sales Model 160H (Cont'd.)

3GM		
Original Part Number	Part Name	Classic Part Number
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3038	Gasket Kit	437-3228
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3309	Spindle	282-6628
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361

3GM		
Original Part Number	Part Name	Classic Part Number
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024

3GM		
Original Part Number	Part Name	Classic Part Number
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

3HR		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834

3HR		
Original Part Number	Part Name	Classic Part Number
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981

3HR		
Original Part Number	Part Name	Classic Part Number
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434

Sales Model 160H (Cont'd.)

3HR		
Original Part Number	Part Name	Classic Part Number
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2H-6489	Race-Brg Outer	374-8350
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2S-5100	Valve-Ball	386-3049
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984

3HR		
Original Part Number	Part Name	Classic Part Number
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
6B-7469	Spacer	417-4535
6G-1908	Housing As-Drive	297-7198
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475

3HR		
Original Part Number	Part Name	Classic Part Number
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351

Sales Model 160H (Cont'd.)

3HR		
Original Part Number	Part Name	Classic Part Number
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-3591	Carrier-Planet	301-4769
8D-9804	Housing-Drive	302-2682
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

3HR		
Original Part Number	Part Name	Classic Part Number
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8W-2308	Shaft-Planet	275-5285
8W-5092	Pinion-Circle Dr	282-6569
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-2754	Insert	333-4948
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
105-3196	Motor Gp-Grtr	282-6547
111-8015	Gasket As-Head	279-4977
112-5495	Joint Gp-Univ	297-4858
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554

3HR		
Original Part Number	Part Name	Classic Part Number
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
148-7455	Valve - Exhaust	270-4361
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
236-7724	Retainer	299-2048
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
312-0782	Worm-Circ Drv	282-6623
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model 160H (Cont'd.)

6WM		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488

6WM		
Original Part Number	Part Name	Classic Part Number
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203

6WM		
Original Part Number	Part Name	Classic Part Number
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158

Motor Graders

Sales Model 160H (Cont'd.)

6WM		
Original Part Number	**Part Name**	**Classic Part Number**
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5P-9568	Gasket Kit	393-3625
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954

6WM		
Original Part Number	**Part Name**	**Classic Part Number**
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531

6WM		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

Sales Model 160H (Cont'd.)

6WM		
Original Part Number	Part Name	Classic Part Number
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215

6WM		
Original Part Number	Part Name	Classic Part Number
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9L-5908	Gasket	433-8196
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892

6WM		
Original Part Number	Part Name	Classic Part Number
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3036	Gasket Kit	393-3629
134-3038	Gasket Kit	437-3228
134-4200	Manifold-Exhaust	443-2060
142-0228	Gasket Kit - Sch	393-1035
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361

Sales Model 160H (Cont'd.)

6WM		
Original Part Number	**Part Name**	**Classic Part Number**
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687

6WM		
Original Part Number	**Part Name**	**Classic Part Number**
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	270-4351

6WM		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

9EJ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158

9EJ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-5383	Gasket	445-7709

9EJ		
Original Part Number	**Part Name**	**Classic Part Number**
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561

Sales Model 160H (Cont'd.)

9EJ		
Original Part Number	Part Name	Classic Part Number
2G-8739	Retainer	389-6314
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053

9EJ		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502

9EJ		
Original Part Number	Part Name	Classic Part Number
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544

Sales Model 160H (Cont'd.)

9EJ		
Original Part Number	**Part Name**	**Classic Part Number**
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-9547	Pin As.-Drawbar	295-0414
7G-0437	Plate-Clutch	417-9466
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994

9EJ		
Original Part Number	**Part Name**	**Classic Part Number**
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

9EJ		
Original Part Number	**Part Name**	**Classic Part Number**
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570

Sales Model 160H (Cont'd.)

9EJ		
Original Part Number	Part Name	Classic Part Number
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8289	Sprocket	282-6629
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
8X-8067	Mounting	394-0205
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9L-5908	Gasket	433-8196
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9T-5729	Cyl Gp-0038 0158	422-2486
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605

9EJ		
Original Part Number	Part Name	Classic Part Number
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
130-1455	Gasket Kit	437-4604
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3038	Gasket Kit	437-3228
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3309	Spindle	282-6628

9EJ		
Original Part Number	Part Name	Classic Part Number
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
151-5349	Head	383-1592
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028

Sales Model 160H (Cont'd.)

9EJ		
Original Part Number	**Part Name**	**Classic Part Number**
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032

9EJ		
Original Part Number	**Part Name**	**Classic Part Number**
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

9EJ		
Original Part Number	**Part Name**	**Classic Part Number**
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

9JM		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221

9JM		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214

9JM		
Original Part Number	**Part Name**	**Classic Part Number**
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984

Sales Model 160H (Cont'd.)

9JM		
Original Part Number	Part Name	Classic Part Number
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437

9JM		
Original Part Number	Part Name	Classic Part Number
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074

9JM		
Original Part Number	Part Name	Classic Part Number
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-2429	Pin As	319-3445

Sales Model 160H (Cont'd.)

9JM		
Original Part Number	Part Name	Classic Part Number
8D-3591	Carrier-Planet	301-4769
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

9JM		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2308	Shaft-Planet	275-5285
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9L-5908	Gasket	433-8196

9JM		
Original Part Number	Part Name	Classic Part Number
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-3014	Gasket Kit	388-0656
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
130-1455	Gasket Kit	437-4604
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483

Sales Model 160H (Cont'd.)

9JM		
Original Part Number	**Part Name**	**Classic Part Number**
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194

9JM		
Original Part Number	**Part Name**	**Classic Part Number**
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026

9JM		
Original Part Number	**Part Name**	**Classic Part Number**
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

ASD		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-6810	Pipe-Outlet	472-8036

ASD		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561

ASD		
Original Part Number	**Part Name**	**Classic Part Number**
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4S-8472	Hood As-Preclnr	296-1355

Sales Model 160H (Cont'd.)

ASD		
Original Part Number	Part Name	Classic Part Number
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6V-3831	Seal-O-Ring	436-2657
6Y-7916	Disc-Friction	428-7204

ASD		
Original Part Number	Part Name	Classic Part Number
6Y-9960	Mount As.	376-3639
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7N-7435	Kit-Major Repair	374-4724
7P-1577	Pin As	375-9969
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735

ASD		
Original Part Number	Part Name	Classic Part Number
8W-4067	Bracket-Rail	288-8736
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
104-8655	Bearing-Sleeve	391-9892
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565

Sales Model 160H (Cont'd.)

ASD		
Original Part Number	**Part Name**	**Classic Part Number**
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-2645	Valve-Pump Byp	441-1561
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211

ASD		
Original Part Number	**Part Name**	**Classic Part Number**
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-2593	Head	383-1591
151-5349	Head	383-1592
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
166-6352	Tube As.	432-4223
174-6822	Bearing-Sleeve	387-2901
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367

ASD		
Original Part Number	**Part Name**	**Classic Part Number**
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
352-2077	Pump Gp-Water -B	434-6108

CCP		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294

CCP		
Original Part Number	**Part Name**	**Classic Part Number**
1U-3998	Seal As	472-8005
1W-6810	Pipe-Outlet	472-8036
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811

CCP		
Original Part Number	**Part Name**	**Classic Part Number**
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041

Sales Model 160H (Cont'd.)

CCP		
Original Part Number	Part Name	Classic Part Number
4P-8280	Manifold-Exhaust	430-7236
4S-8472	Hood As-Preclnr	296-1355
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6H-2577	Spider Gp-Brg&	333-4954
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6V-3831	Seal-O-Ring	436-2657
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639

CCP		
Original Part Number	Part Name	Classic Part Number
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7N-7435	Kit-Major Repair	374-4724
7P-1577	Pin As	375-9969
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569

CCP		
Original Part Number	Part Name	Classic Part Number
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9T-2387	Rod As	393-5218
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
104-8655	Bearing-Sleeve	391-9892
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-2645	Valve-Pump Byp	441-1561
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448

Sales Model 160H (Cont'd.)

CCP		
Original Part Number	Part Name	Classic Part Number
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3310	Spindle-Wheel	383-2111

CCP		
Original Part Number	Part Name	Classic Part Number
147-3400	Spindle	282-6549
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-2593	Head	383-1591
151-5349	Head	383-1592
154-2689	Spider	463-7670
166-6352	Tube As.	432-4223
174-6822	Bearing-Sleeve	387-2901
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-3307	Gasket As-Cyl	438-2022

CCP		
Original Part Number	Part Name	Classic Part Number
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
352-2077	Pump Gp-Water -B	434-6108

XZK		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

XZK		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555

XZK		
Original Part Number	Part Name	Classic Part Number
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214

Sales Model 160H (Cont'd.)

XZK		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987

XZK		
Original Part Number	Part Name	Classic Part Number
4S-8472	Hood As-Preclnr	296-1355
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535

XZK		
Original Part Number	Part Name	Classic Part Number
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466

Sales Model 160H (Cont'd.)

XZK		
Original Part Number	Part Name	Classic Part Number
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034

XZK		
Original Part Number	Part Name	Classic Part Number
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8V-1624	Lever	299-2019

XZK		
Original Part Number	Part Name	Classic Part Number
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2308	Shaft-Planet	275-5285
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
005-8639	Bearing-Aligning	415-1925

Motor Graders

Sales Model 160H (Cont'd.)

XZK		
Original Part Number	Part Name	Classic Part Number
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554

XZK		
Original Part Number	Part Name	Classic Part Number
144-0744	Compressor Gp -B	435-6046
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453

XZK		
Original Part Number	Part Name	Classic Part Number
184-9843	Head	347-0461
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model 160K

JBP		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834

JBP		
Original Part Number	Part Name	Classic Part Number
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005
2A-4429	Lock-Retainer	379-0174

JBP		
Original Part Number	Part Name	Classic Part Number
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682

Sales Model 160K (Cont'd.)

JBP		
Original Part Number	Part Name	Classic Part Number
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-9514	Bearing-Ball	417-9467
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011

JBP		
Original Part Number	Part Name	Classic Part Number
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-8642	Race-Brg Outer	396-9898
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7G-0437	Plate-Clutch	417-9466

JBP		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7W-5095	Gear-Flywheel	425-9190
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
8Y-0809	Spider Gp-Brg&	417-4526
9D-1491	Coupling	416-2121

Sales Model 160K (Cont'd.)

JBP		
Original Part Number	**Part Name**	**Classic Part Number**
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-8285	Cap	391-9822
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-2387	Rod As	393-5218
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
104-8655	Bearing-Sleeve	391-9892
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683

JBP		
Original Part Number	**Part Name**	**Classic Part Number**
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
115-4072	Bearing	397-5069
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
133-4995	Gasket-Cyl Head	434-2445
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453

JBP		
Original Part Number	**Part Name**	**Classic Part Number**
184-9843	Head	347-0461
200-7929	Housing	416-5489
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

SZM		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-9110	Bearing-Needle	420-2497
1U-3998	Seal As	472-8005

SZM		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561

SZM		
Original Part Number	**Part Name**	**Classic Part Number**
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010

Sales Model 160K (Cont'd.)

SZM		
Original Part Number	Part Name	Classic Part Number
4V-0015	Plate-Lock	282-6563
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-9514	Bearing-Ball	417-9467
5T-0906	Cover	282-6625
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-5704	Piston	394-9838
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-8642	Race-Brg Outer	396-9898
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639

SZM		
Original Part Number	Part Name	Classic Part Number
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7W-5095	Gear-Flywheel	425-9190
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8J-6384	Bearing-Sleeve	472-8034
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733

SZM		
Original Part Number	Part Name	Classic Part Number
8W-1753	Bracket-Rail	288-8734
8W-2308	Shaft-Planet	275-5285
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8124	Housing	472-8021
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
8Y-0809	Spider Gp-Brg&	417-4526
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-8285	Cap	391-9822
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-2387	Rod As	393-5218
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
104-8655	Bearing-Sleeve	391-9892
105-3196	Motor Gp-Grtr	282-6547

Sales Model 160K (Cont'd.)

SZM		
Original Part Number	**Part Name**	**Classic Part Number**
106-7131	Shaft	288-8714
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
115-4072	Bearing	397-5069
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
133-4995	Gasket-Cyl Head	434-2445
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

SZM		
Original Part Number	**Part Name**	**Classic Part Number**
147-3310	Spindle-Wheel	383-2111
147-3400	Spindle	282-6549
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
200-7929	Housing	416-5489
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024

SZM		
Original Part Number	**Part Name**	**Classic Part Number**
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706

Sales Model 160M

B9E		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-8509	Cone-Roller Brg	399-4434

B9E		
Original Part Number	**Part Name**	**Classic Part Number**
2G-1034	Valve-Safety	380-7555
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2M-8714	Cone-Roller Brg	420-2492
2W-7213	Bearing-Sleeve	419-4667
3J-6575	Trunnion	297-7265
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962

B9E		
Original Part Number	**Part Name**	**Classic Part Number**
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6I-8642	Race-Brg Outer	396-9898

Sales Model 160M (Cont'd.)

B9E		
Original Part Number	Part Name	Classic Part Number
6K-8275	Cone-Roller Brg	399-6070
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8J-6384	Bearing-Sleeve	472-8034

B9E		
Original Part Number	Part Name	Classic Part Number
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-2754	Insert	333-4948
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
9T-5729	Cyl Gp-0038 0158	422-2486
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683

B9E		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
131-3736	Socket Gp-Basic	325-6211
135-7393	Head	382-6895
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
151-5349	Head	383-1592
152-6485	Cyl Gp-102 472 Y	390-0985
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659
233-9204	Kit-Seal-H.Cyl-1	472-8025
246-5916	Kit-Seal-H.Cyl-1	472-8026
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

B9L		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914

B9L		
Original Part Number	Part Name	Classic Part Number
2D-9455	Cone-Roller Brg	415-1915
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2M-8714	Cone-Roller Brg	420-2492
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439

B9L		
Original Part Number	Part Name	Classic Part Number
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433

Sales Model 160M (Cont'd.)

B9L		
Original Part Number	**Part Name**	**Classic Part Number**
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6I-8642	Race-Brg Outer	396-9898
6K-8275	Cone-Roller Brg	399-6070
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-2429	Pin As	319-3445
8D-5344	Gear-Worm	243-0341
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511

B9L		
Original Part Number	**Part Name**	**Classic Part Number**
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-2754	Insert	333-4948
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
9T-5729	Cyl Gp-0038 0158	422-2486
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605

B9L		
Original Part Number	**Part Name**	**Classic Part Number**
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
115-4072	Bearing	397-5069
131-3736	Socket Gp-Basic	325-6211
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
151-5349	Head	383-1592
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659
233-9204	Kit-Seal-H.Cyl-1	472-8025
246-5916	Kit-Seal-H.Cyl-1	472-8026
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

B9T		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

B9T		
Original Part Number	**Part Name**	**Classic Part Number**
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007

B9T		
Original Part Number	**Part Name**	**Classic Part Number**
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160

Sales Model 160M (Cont'd.)

B9T		
Original Part Number	Part Name	Classic Part Number
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034

B9T		
Original Part Number	Part Name	Classic Part Number
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9M-2042	Race-Roller Brg	417-9500
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
105-3196	Motor Gp-Grtr	282-6547
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894

B9T		
Original Part Number	Part Name	Classic Part Number
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

D9T		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

D9T		
Original Part Number	Part Name	Classic Part Number
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
3J-6575	Trunnion	297-7265
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788

D9T		
Original Part Number	Part Name	Classic Part Number
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065

Sales Model 160M (Cont'd.)

D9T		
Original Part Number	**Part Name**	**Classic Part Number**
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019

D9T		
Original Part Number	**Part Name**	**Classic Part Number**
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
105-3196	Motor Gp-Grtr	282-6547
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
135-7393	Head	382-6895
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
148-2593	Head	383-1591

D9T		
Original Part Number	**Part Name**	**Classic Part Number**
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985
154-8030	Gasket	394-0894
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

E9L		
Original Part Number	**Part Name**	**Classic Part Number**
2D-2654	Ring-Lock	380-1488
2K-6413	Pin	360-2270

E9L		
Original Part Number	**Part Name**	**Classic Part Number**
4T-8054	Seal As	472-8010
8W-9566	Flange As	376-9073

E9T		
Original Part Number	**Part Name**	**Classic Part Number**
2D-2654	Ring-Lock	380-1488
2K-6413	Pin	360-2270

E9T		
Original Part Number	**Part Name**	**Classic Part Number**
4T-8054	Seal As	472-8010
8W-9566	Flange As	376-9073

M9E		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347

M9E		
Original Part Number	**Part Name**	**Classic Part Number**
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486

M9E		
Original Part Number	**Part Name**	**Classic Part Number**
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294

Sales Model 160M (Cont'd.)

M9E		
Original Part Number	Part Name	Classic Part Number
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630

M9E		
Original Part Number	Part Name	Classic Part Number
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019

M9E		
Original Part Number	Part Name	Classic Part Number
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
115-4072	Bearing	397-5069
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

M9K		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-2654	Ring-Lock	380-1488

M9K		
Original Part Number	Part Name	Classic Part Number
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439

M9K		
Original Part Number	Part Name	Classic Part Number
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012

Sales Model 160M (Cont'd.)

M9K		
Original Part Number	Part Name	Classic Part Number
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8437	Cone-Roller Brg	380-1502
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018

M9K		
Original Part Number	Part Name	Classic Part Number
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
101-1530	Bearing-Main	419-6382
105-3196	Motor Gp-Grtr	282-6547
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

M9K		
Original Part Number	Part Name	Classic Part Number
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

M9L		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914

M9L		
Original Part Number	Part Name	Classic Part Number
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007

M9L		
Original Part Number	Part Name	Classic Part Number
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065

Sales Model 160M (Cont'd.)

M9L		
Original Part Number	Part Name	Classic Part Number
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7J-5131	Trunnion	296-1371
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511

M9L		
Original Part Number	Part Name	Classic Part Number
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
105-3196	Motor Gp-Grtr	282-6547
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

M9L		
Original Part Number	Part Name	Classic Part Number
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

M9T		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

M9T		
Original Part Number	Part Name	Classic Part Number
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962

M9T		
Original Part Number	Part Name	Classic Part Number
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898

Sales Model 160M (Cont'd.)

M9T		
Original Part Number	Part Name	Classic Part Number
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8437	Cone-Roller Brg	380-1502
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7J-5131	Trunnion	296-1371
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019

M9T		
Original Part Number	Part Name	Classic Part Number
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
101-1530	Bearing-Main	419-6382
105-3196	Motor Gp-Grtr	282-6547
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696

M9T		
Original Part Number	Part Name	Classic Part Number
154-8030	Gasket	394-0894
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

N9E		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350

N9E		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158

N9E		
Original Part Number	Part Name	Classic Part Number
5K-0991	Cap-Lower	319-3433
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251

Sales Model 160M (Cont'd.)

N9E		
Original Part Number	**Part Name**	**Classic Part Number**
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073

N9E		
Original Part Number	**Part Name**	**Classic Part Number**
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
161-3411	Gasket	394-0896

N9E		
Original Part Number	**Part Name**	**Classic Part Number**
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

N9K		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507

N9K		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
6B-3223	Cup-Bearing	399-6065
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384

N9K		
Original Part Number	**Part Name**	**Classic Part Number**
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

Sales Model 160M (Cont'd.)

N9L		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010

N9L		
Original Part Number	**Part Name**	**Classic Part Number**
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384

N9L		
Original Part Number	**Part Name**	**Classic Part Number**
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

N9T		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914

N9T		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632

N9T		
Original Part Number	**Part Name**	**Classic Part Number**
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012

Sales Model 160M (Cont'd.)

N9T		
Original Part Number	Part Name	Classic Part Number
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7D-8437	Cone-Roller Brg	380-1502
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657

N9T		
Original Part Number	Part Name	Classic Part Number
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018

N9T		
Original Part Number	Part Name	Classic Part Number
9M-2042	Race-Roller Brg	417-9500
105-3196	Motor Gp-Grtr	282-6547
107-8375	Shaft As	439-1134
143-7356	Bearing As	380-1483
148-2593	Head	383-1591
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

R9L		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667

R9L		
Original Part Number	Part Name	Classic Part Number
4B-7270	Cone-Bearing	399-4439
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5T-0906	Cover	282-6625
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898

R9L		
Original Part Number	Part Name	Classic Part Number
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7J-5131	Trunnion	296-1371
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384

Sales Model 160M (Cont'd.)

R9L		
Original Part Number	Part Name	Classic Part Number
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
105-3196	Motor Gp-Grtr	282-6547

R9L		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870

R9L		
Original Part Number	Part Name	Classic Part Number
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

R9T		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-7309	Shaft	393-3682
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
4B-7270	Cone-Bearing	399-4439

R9T		
Original Part Number	Part Name	Classic Part Number
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4K-8734	Bearing-Sleeve	299-1962
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
6B-3223	Cup-Bearing	399-6065
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6Y-9960	Mount As.	376-3639
7C-5403	Tube As	374-4673

R9T		
Original Part Number	Part Name	Classic Part Number
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8437	Cone-Roller Brg	380-1502
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7J-5131	Trunnion	296-1371
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-5426	Cone-Roller Brg	453-3657
8D-7086	Bearing	330-9251
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8J-6384	Bearing-Sleeve	472-8034
8W-5092	Pinion-Circle Dr	282-6569

Sales Model 160M (Cont'd.)

R9T		
Original Part Number	Part Name	Classic Part Number
8W-6324	Kit-Wear Strip	424-0739
8W-9566	Flange As	376-9073
9D-1491	Coupling	416-2121
9M-1328	Bearing-Aligning	325-6018
9M-2042	Race-Roller Brg	417-9500
101-1530	Bearing-Main	419-6382
105-3196	Motor Gp-Grtr	282-6547
107-7708	Bearing-Main	419-6381
107-8375	Shaft As	439-1134
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445

R9T		
Original Part Number	Part Name	Classic Part Number
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
148-2593	Head	383-1591
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
161-3411	Gasket	394-0896
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024

R9T		
Original Part Number	Part Name	Classic Part Number
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623

Sales Model 163H

5AK		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-4695	Cup-Rlr Bearing	374-1842
1P-4696	Cone-Rlr Bearing	374-1843
1P-7115	Mount As	418-1936
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497

5AK		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123

5AK		
Original Part Number	Part Name	Classic Part Number
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8609	Pin	319-3450
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270

Sales Model 163H (Cont'd.)

5AK		
Original Part Number	Part Name	Classic Part Number
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8907	Spider As-Fan	330-9289
2P-9632	Damper As	299-2004
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3D-9126	Cup-Roller Brg	399-4435
4B-7270	Cone-Bearing	399-4439
4F-2041	Cup-Roller Brg	418-9609
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236

5AK		
Original Part Number	Part Name	Classic Part Number
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024

5AK		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6Y-7916	Disc-Friction	428-7204

Sales Model 163H (Cont'd.)

5AK		
Original Part Number	Part Name	Classic Part Number
6Y-9960	Mount As.	376-3639
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5696	Hub-Cshft	424-5887

5AK		
Original Part Number	Part Name	Classic Part Number
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511
8D-8572	Bearing-Sleeve	380-7384
8D-8805	Cover	299-2002
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8D-9973	Housing	391-9825
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

5AK		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1624	Lever	299-2019
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-8289	Sprocket	282-6629
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8X-0576	Kit-Wear Strip	383-2105

Sales Model 163H (Cont'd.)

5AK		
Original Part Number	**Part Name**	**Classic Part Number**
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
8X-8067	Mounting	394-0205
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-3242	Cone-Roller Brg	453-3659
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9L-5908	Gasket	433-8196
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9T-5729	Cyl Gp-0038 0158	422-2486
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
064-3274	Mount	391-9834
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
104-8655	Bearing-Sleeve	391-9892
105-0017	Cylinder	416-2130
105-2094	Cyl Gp-0076 1194	423-7868

5AK		
Original Part Number	**Part Name**	**Classic Part Number**
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-8015	Gasket As-Head	279-4977
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
134-3036	Gasket Kit	393-3629
134-3038	Gasket Kit	437-3228
134-4200	Manifold-Exhaust	443-2060
142-0228	Gasket Kit - Sch	393-1035
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-3309	Spindle	282-6628
147-3310	Spindle-Wheel	383-2111
148-2593	Head	383-1591
148-7455	Valve - Exhaust	270-4361
151-5349	Head	383-1592
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127

5AK		
Original Part Number	**Part Name**	**Classic Part Number**
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7772	Pump Gp-Water -B	438-2009
174-6822	Bearing-Sleeve	387-2901
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
234-7988	Kit-Gasket-Sch	387-2925
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model 163H (Cont'd.)

ARL		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-4095	Bearing-Inner	417-9486
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7115	Mount As	418-1936
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-3998	Seal As	472-8005
1W-6810	Pipe-Outlet	472-8036
2A-4429	Lock-Retainer	379-0174
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-6341	Pin	330-9273
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-2411	Ballstud As	387-2899
2G-6285	Valve Kt	383-1570
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-8238	Yoke As	282-6631
2G-8609	Pin	319-3450
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2H-6489	Race-Brg Outer	374-8350
2K-6413	Pin	360-2270
2N-2139	Cone-Roller Brg	415-1911

ARL		
Original Part Number	Part Name	Classic Part Number
2S-5100	Valve-Ball	386-3049
2V-4331	Collar	387-2910
4B-7270	Cone-Bearing	399-4439
4F-2041	Cup-Roller Brg	418-9609
4K-3004	Bearing-Trun Sup	314-8632
4K-3150	Pin	385-3788
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4S-8472	Hood As-Preclnr	296-1355
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
5J-7010	Seal As	472-8011
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-3490	Cone-Rlr Bearing	380-7518
5T-1362	Univ Joint As-5C	325-6011
5T-7129	Housing	472-8013
5T-8367	Strip-Wear	297-7263
5T-8739	Spider Gp-Brg&	373-5386
6D-4671	Ballstud	420-6530
6D-5415	Plate	382-8043
6E-0775	Head	425-9373
6F-6992	Cap-Ballsocket	297-7160
6G-1908	Housing As-Drive	297-7198

ARL		
Original Part Number	Part Name	Classic Part Number
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6H-2577	Spider Gp-Brg&	333-4954
6I-1240	Governor As	380-7538
6I-8642	Race-Brg Outer	396-9898
6V-3831	Seal-O-Ring	436-2657
6Y-7916	Disc-Friction	428-7204
6Y-9960	Mount As.	376-3639
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-9267	Yoke	330-9297
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7M-7219	Bearing-Thrust	384-4816
7N-7435	Kit-Major Repair	374-4724
7P-1577	Pin As	375-9969
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-3591	Carrier-Planet	301-4769
8D-4766	Pin-Cylinder	365-8832
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6629	Bearing	418-1953
8D-7086	Bearing	330-9251
8D-7427	Shaft-Dr Pinion	282-6568
8D-7996	Bearing-Sleeve	472-8018
8D-8168	Bearing	453-6511

Sales Model 163H (Cont'd.)

ARL		
Original Part Number	Part Name	Classic Part Number
8D-8572	Bearing-Sleeve	380-7384
8D-9159	Bearing-Sleeve	472-8019
8D-9804	Housing-Drive	302-2682
8H-9789	Bearing-Ball	374-8342
8J-6384	Bearing-Sleeve	472-8034
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-2308	Shaft-Planet	275-5285
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6497	Pin	319-3465
8W-9566	Flange As	376-9073
8X-0576	Kit-Wear Strip	383-2105
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
9D-1491	Coupling	416-2121
9D-1589	Mounting	387-2928
9D-2754	Insert	333-4948
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-2042	Race-Roller Brg	417-9500
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930

ARL		
Original Part Number	Part Name	Classic Part Number
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
104-8655	Bearing-Sleeve	391-9892
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-3196	Motor Gp-Grtr	282-6547
106-7131	Shaft	288-8714
107-8375	Shaft As	439-1134
110-4652	Housing	302-2683
111-2645	Valve-Pump Byp	441-1561
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5495	Joint Gp-Univ	297-4858
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
124-3240	Pin	282-6548
129-2381	Gear-Planet	275-5274
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627

ARL		
Original Part Number	Part Name	Classic Part Number
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3310	Spindle-Wheel	383-2111
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-2593	Head	383-1591
151-5349	Head	383-1592
153-3580	Shaft	299-2055
154-2689	Spider	463-7670
166-6352	Tube As.	432-4223
174-6822	Bearing-Sleeve	387-2901
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
178-3086	Ballstud	374-1453
184-9843	Head	347-0461
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-7724	Retainer	299-2048
246-5916	Kit-Seal-H.Cyl-1	472-8026
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
312-0782	Worm-Circ Drv	282-6623
319-2228	Shoe-Circle Gde	419-4706
352-2077	Pump Gp-Water -B	434-6108

Sales Model 212

3JC		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-0479	Bearing-Cone	380-7506
6H-3957	Bearing-Ball	311-9358

3JC		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0832	Cone-Rlr Bearing	453-3654
7H-6967	Bearing-Ball	422-6489
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411

3JC		
Original Part Number	**Part Name**	**Classic Part Number**
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As	384-5959
121-7632	Disc-Clutch	394-9195
178-8608	Cone	422-6479

5DC		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2S-0479	Bearing-Cone	380-7506
6H-3957	Bearing-Ball	311-9358

5DC		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0832	Cone-Rlr Bearing	453-3654
7H-6967	Bearing-Ball	422-6489
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411

5DC		
Original Part Number	**Part Name**	**Classic Part Number**
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As	384-5959
121-7632	Disc-Clutch	394-9195
178-8608	Cone	422-6479

Cat Classic Parts for Pipelayers

Cat pipelayers are built to be heavy, strong, and durable. They are built to last many years. As. the machines age, owning and operating costs are often re-evaluated. To help you manage these costs, Caterpillar offers Classic parts for several models of pipelayers. Cat Classic parts are a Repair option targeted at the End of the product life cycle when lower cost options are more desired.

Cat Classic parts provide owners of older Cat products with low cost Repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts coverage for pipelayers includes:

- Engine
- Final Drive
- Flywheel Clutch
- Moving Undercarriage
- Non-Moving Undercarriage
- SteeRing
- Transmission
- ...and many more.

Sales Model 561B

62A		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1642	Hub-Gear	219-2976
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-0090	Gasket-Manifold	445-7701
1M-0176	Flange-Drum	223-4810
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1P-1367	Plunger-Valve	432-8913
1S-1888	Bracket-Lamp	297-7147
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1S-8764	Ring-Fly Clu Adj	226-8014

62A		
Original Part Number	**Part Name**	**Classic Part Number**
1S-9670	Univ Jt As	443-2017
1T-0210	Bearing-Ball	417-4498
1W-7073	Rebuild Kt-Pump	383-3677
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-7576	Shaft-Sprocket	226-6071
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532

62A		
Original Part Number	**Part Name**	**Classic Part Number**
2M-8340	Rod End-Yoke	374-4678
2P-7622	Bolt-Spring	226-4850
2P-9660	Gear	226-5995
2S-1477	Holder As-Cage	226-7985
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
3B-6218	Muffler As	247-2672
3F-1972	Retainer As	226-7988
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3P-5754	Hub-Gear	219-2976
3S-7153	Gear-Sliding	227-0024
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996

Sales Model 561B (Cont'd.)

62A		
Original Part Number	**Part Name**	**Classic Part Number**
4K-4780	Strip As-Wear	299-2063
4S-8005	Pinion-Fdr	226-6076
5A-9551	Gear-Finaldrive	226-7979
5F-2256	Cage-Bearing	226-7973
5F-8651	Bearing-Ball	420-3223
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5J-2528	Plunger	391-1318
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6P-0169	Hub-Fly Clutch	297-7204
6V-2202	Bearing-Spl Ball	380-1574
7B-5088	Drum-Steer Cl Dr	223-4813
7E-5085	Bushing	377-5829
7F-9547	Pin As.-Drawbar	295-0414
7G-6044	Cage As	216-7857
7H-1318	Coupling-Ster Cl	226-8002
7H-2424	Sleeve-Spring	226-4852
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919

62A		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7602	Pump Gp-Cl Oil	226-0174
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-6676	Cylinder-Adj	226-4960
8M-8068	Bearing-Spl Ball	417-4500
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081

62A		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-7670	Piston	226-4961
9M-4955	Pump Gp-F Tfr	242-3443
9M-5477	Bearing-Sleeve	374-6517
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7534	Pipe-Exh Ext	398-2950
9S-9696	Spider As-Fan	383-3707
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
169-4200	Gasket	472-8023
228-7325	Ster Cl Kit-Cla	230-7119
232-3233	Bearing-Main	376-9085
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 561C

85H		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1642	Hub-Gear	219-2976
1A-2846	Cap As-Filler	311-9368

85H		
Original Part Number	**Part Name**	**Classic Part Number**
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849

Sales Model 561C (Cont'd.)

85H		
Original Part Number	Part Name	Classic Part Number
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-0090	Gasket-Manifold	445-7701
1M-0176	Flange-Drum	223-4810
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1P-1367	Plunger-Valve	432-8913
1S-1888	Bracket-Lamp	297-7147
1S-6422	Pilot As-Spring	226-4849
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1U-2668	Cartridge Gp	422-8117
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-7576	Shaft-Sprocket	226-6071
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-7622	Bolt-Spring	226-4850
2S-1477	Holder As-Cage	226-7985
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-7931	Bearing-Sleeve	387-2904

85H		
Original Part Number	Part Name	Classic Part Number
3B-6218	Muffler As	247-2672
3F-1972	Retainer As	226-7988
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3P-5754	Hub-Gear	219-2976
3S-3875	Screen-Suction	435-4849
3S-5017	Elbow-Exhaust	369-9498
3S-7153	Gear-Sliding	227-0024
3S-7504	Gear-Idler	226-6084
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996
4K-4780	Strip As-Wear	299-2063
4S-6189	Pinion-Reverse	226-6077
4S-8005	Pinion-Fdr	226-6076
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161
5F-2256	Cage-Bearing	226-7973
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5L-7632	Support-Elbow	433-9854
5M-6709	Check As-Ball	380-7542
5M-7342	Flange-Shaft	215-1696
5P-7807	Bearing-Ball	314-8502
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-8767	Gear-First	226-6085
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6P-0169	Hub-Fly Clutch	297-7204

85H		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
7B-5088	Drum-Steer Cl Dr	223-4813
7E-5085	Bushing	377-5829
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7G-3815	Pump Gp-Gr 2 Bsc	226-0171
7G-6044	Cage As	216-7857
7H-1318	Coupling-Ster Cl	226-8002
7H-2424	Sleeve-Spring	226-4852
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-9146	Gear-Fly Starter	279-4995
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-5587	Rod Gp-Recoil	226-4954
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8M-8068	Bearing-Spl Ball	417-4500

Sales Model 561C (Cont'd.)

85H		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8S-1831	Guard As-Sprkt	226-4947
8S-2140	Trunnion-Gear	226-8020
8S-9686	Gasket Kit	393-5215

85H		
Original Part Number	**Part Name**	**Classic Part Number**
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9M-4955	Pump Gp-F Tfr	242-3443
9M-5477	Bearing-Sleeve	374-6517
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923

85H		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3582	Cone-Roller Brg	396-4144
9S-7534	Pipe-Exh Ext	398-2950
9S-9696	Spider As-Fan	383-3707
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
169-4200	Gasket	472-8023
228-7325	Ster Cl Kit-Cla	230-7119
232-3233	Bearing-Main	376-9085
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

92J		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1642	Hub-Gear	219-2976
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-0176	Flange-Drum	223-4810
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-6422	Pilot As-Spring	226-4849
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1U-2668	Cartridge Gp	422-8117

92J		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2F-7576	Shaft-Sprocket	226-6071
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

92J		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-7622	Bolt-Spring	226-4850
2S-1477	Holder As-Cage	226-7985
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203

Sales Model 561C (Cont'd.)

92J		
Original Part Number	Part Name	Classic Part Number
2W-7458	Crankshaft As	242-3439
3F-1972	Retainer As	226-7988
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3P-5754	Hub-Gear	219-2976
3S-3875	Screen-Suction	435-4849
3S-7153	Gear-Sliding	227-0024
3S-7504	Gear-Idler	226-6084
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996
4K-4780	Strip As-Wear	299-2063
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4N-8814	Line As-F Inj	247-3366
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-6189	Pinion-Reverse	226-6077
4S-8005	Pinion-Fdr	226-6076
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
5A-9551	Gear-Finaldrive	226-7979

92J		
Original Part Number	Part Name	Classic Part Number
5D-7449	Cup-Spl Tapered	416-2161
5F-2256	Cage-Bearing	226-7973
5G-3612	Cap Gp-Protn	295-6419
5H-5500	Collar-Fly Cl	302-2704
5L-6326	Bearing-Ball	420-3222
5M-6709	Check As-Ball	380-7542
5M-7342	Flange-Shaft	215-1696
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8767	Gear-First	226-6085
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7178	Fork-Band Adj	299-2009
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0169	Hub-Fly Clutch	297-7204
6V-1339	Gasket Kit	388-0651

92J		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
7B-5088	Drum-Steer Cl Dr	223-4813
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7G-3815	Pump Gp-Gr 2 Bsc	226-0171
7G-6044	Cage As	216-7857
7H-1318	Coupling-Ster Cl	226-8002
7H-2424	Sleeve-Spring	226-4852
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438

Sales Model 561C (Cont'd.)

92J		
Original Part Number	**Part Name**	**Classic Part Number**
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-5587	Rod Gp-Recoil	226-4954
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8M-8068	Bearing-Spl Ball	417-4500
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563

92J		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1831	Guard As-Sprkt	226-4947
8S-2140	Trunnion-Gear	226-8020
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042

92J		
Original Part Number	**Part Name**	**Classic Part Number**
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032

Sales Model 561C (Cont'd.)

92J		
Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

92J		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
228-7325	Ster Cl Kit-Cla	230-7119
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892

92J		
Original Part Number	Part Name	Classic Part Number
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 561H

6NL		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4493	Cone-Spl Tapered	386-4939
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0406	Wheel-Impeller	384-3854
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1691	Impeller-Conv	297-4863

6NL		
Original Part Number	Part Name	Classic Part Number
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354

6NL		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-3597	Muffler As	397-5044
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3E-8905	Gasket Kit	393-3617
3G-2720	Cartridge Gp-Rr	448-5051
3G-7655	Cartridge Gp	422-8119

Sales Model 561H (Cont'd.)

6NL		
Original Part Number	Part Name	Classic Part Number
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3W-2420	Bearing	417-4517
3W-7770	Tube As	385-7227
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4W-0452	Seal As -Cshaft	325-6191

6NL		
Original Part Number	Part Name	Classic Part Number
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5K-7995	Bearing-Sleeve	308-9820
5P-3930	Bearing As-Rlr	419-6022
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-1362	Univ Joint As-5C	325-6011
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492

6NL		
Original Part Number	Part Name	Classic Part Number
6Y-6382	Strip	419-0888
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4758	Gear-Planet	288-8723
7G-5444	Carrier-Planet	297-7165
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7J-2604	Bearing-Sleeve	380-7369
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-7858	Bearing-Sleeve	374-8362
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8G-3102	Piston	325-6162
8G-3733	Pin As	419-7636
8G-3965	Hub-Sprocket	424-4942
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037

Sales Model 561H (Cont'd.)

6NL		
Original Part Number	Part Name	Classic Part Number
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083

6NL		
Original Part Number	Part Name	Classic Part Number
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8T-1606	Kit-Gskt-Sch	386-3046
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9S-5279	Bearing-Inner	453-3661
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-5096	Flexplate	455-3271
9U-9198	Strip	388-0641
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193

6NL		
Original Part Number	Part Name	Classic Part Number
141-7274	Gasket Kit	418-1951
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-8176	Cover-Xmsn	420-3218
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
292-5516	Kit-Dt Gasket	391-9885
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 561M

1KW		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939

Sales Model 561M (Cont'd.)

1KW		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

1KW		
Original Part Number	Part Name	Classic Part Number
2P-2406	Pulley	264-5870
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-3597	Muffler As	397-5044
2W-5240	Pipe-Pump Outlet	376-9055
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-2720	Cartridge Gp-Rr	448-5051
3G-7655	Cartridge Gp	422-8119
3H-8726	Mount As	385-7208
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3W-2420	Bearing	417-4517
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7688	Valve As-Check	420-6216
4P-7790	Shaft As-Arm	457-4596
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

1KW		
Original Part Number	Part Name	Classic Part Number
4P-8577	Rod As-Injector	455-5513
4P-8915	Gasket-Cyl Head	377-5838
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5K-7995	Bearing-Sleeve	308-9820
5P-3930	Bearing As-Rlr	419-6022
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1099	Manifold-Exh	424-6366
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991

Sales Model 561M (Cont'd.)

1KW		
Original Part Number	Part Name	Classic Part Number
6N-7174	Shield-Oil	314-8544
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-4582	Bearing-Ball	380-1504
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-2880	Bell As-Suction	380-1520
7C-3760	Tube As-O Drain	375-5443
7C-3862	Camshaft	458-0151
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-9980	Camshaft	377-5851
7F-9547	Pin As.-Drawbar	295-0414
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4758	Gear-Planet	288-8723
7G-5444	Carrier-Planet	297-7165
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7J-2604	Bearing-Sleeve	380-7369
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816

1KW		
Original Part Number	Part Name	Classic Part Number
7N-0165	Core As-O Clr	295-5670
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-7858	Bearing-Sleeve	374-8362
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8064	Valve-Inlet	384-8705
8G-3102	Piston	325-6162
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518

1KW		
Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-0809	Spider Gp-Brg&	417-4526
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042

Sales Model 561M (Cont'd.)

1KW		
Original Part Number	Part Name	Classic Part Number
9T-5096	Flexplate	455-3271
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
109-1231	Strip	393-3683
111-8015	Gasket As-Head	279-4977
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
126-5875	Flywheel As.	374-4694

1KW		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
133-3919	Gasket Kit-Sch	393-1031
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
148-7455	Valve - Exhaust	270-4361
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

1KW		
Original Part Number	Part Name	Classic Part Number
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3233	Bearing-Main	376-9085
233-5001	Strip	393-3683
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
292-5516	Kit-Dt Gasket	391-9885
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

Sales Model 561N

CPH		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354

CPH		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
2W-7213	Bearing-Sleeve	419-4667
3H-8726	Mount As	385-7208
3J-9511	Bearing-Sleeve	385-3782
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3W-2420	Bearing	417-4517

CPH		
Original Part Number	Part Name	Classic Part Number
4F-2041	Cup-Roller Brg	418-9609
4M-5858	Bearing-Spl Ball	417-4495
4P-3683	Pump Gp-Water -B	374-7498
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4W-1203	Cup-Rlr Brg	418-9603

Sales Model 561N (Cont'd.)

CPH		
Original Part Number	Part Name	Classic Part Number
4W-2042	Spacer	325-6217
5K-7995	Bearing-Sleeve	308-9820
5P-3930	Bearing As-Rlr	419-6022
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-4582	Bearing-Ball	380-1504
6Y-0306	Bearing-Sleeve	391-1104
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7F-9547	Pin As.-Drawbar	295-0414
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4758	Gear-Planet	288-8723
7G-5444	Carrier-Planet	297-7165
7G-5614	Shaft-Planet	281-1697
7J-2604	Bearing-Sleeve	380-7369
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-7858	Bearing-Sleeve	374-8362
7S-4534	Bearing-Caged	417-9497
7W-3773	Pulley-Cshaft	383-1583

CPH		
Original Part Number	Part Name	Classic Part Number
7W-5095	Gear-Flywheel	425-9190
8G-3102	Piston	325-6162
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8T-0072	Cone-Rlr Brg	377-7448
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9W-9930	Mount As	295-6437
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
109-1231	Strip	393-3683
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
163-1387	Gear-Flywheel	374-4697
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-5001	Strip	393-3683
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107

CPH		
Original Part Number	Part Name	Classic Part Number
352-2160	Pump Gp-Water -B	433-0789
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-5069	Cup-Roller Brg	374-8346
2W-7213	Bearing-Sleeve	419-4667
3H-8726	Mount As	385-7208
3J-9511	Bearing-Sleeve	385-3782
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3W-2420	Bearing	417-4517
4M-5858	Bearing-Spl Ball	417-4495
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4W-2042	Spacer	325-6217
5K-7995	Bearing-Sleeve	308-9820
5P-3930	Bearing As-Rlr	419-6022
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-4582	Bearing-Ball	380-1504
6Y-0306	Bearing-Sleeve	391-1104

Sales Model 561N (Cont'd.)

CPH		
Original Part Number	Part Name	Classic Part Number
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7F-9547	Pin As.-Drawbar	295-0414
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4758	Gear-Planet	288-8723
7G-5444	Carrier-Planet	297-7165
7G-5614	Shaft-Planet	281-1697
7J-2604	Bearing-Sleeve	380-7369
7M-7219	Bearing-Thrust	384-4816

CPH		
Original Part Number	Part Name	Classic Part Number
7P-7858	Bearing-Sleeve	374-8362
7S-4534	Bearing-Caged	417-9497
7W-5095	Gear-Flywheel	425-9190
8G-3102	Piston	325-6162
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8T-0072	Cone-Rlr Brg	377-7448
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9W-9930	Mount As	295-6437
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
109-1231	Strip	393-3683

CPH		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-5001	Strip	393-3683
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710

TAD		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-5069	Cup-Roller Brg	374-8346
2W-7213	Bearing-Sleeve	419-4667
3H-8726	Mount As	385-7208
3J-9511	Bearing-Sleeve	385-3782
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3W-2420	Bearing	417-4517

TAD		
Original Part Number	Part Name	Classic Part Number
4M-5858	Bearing-Spl Ball	417-4495
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4W-2042	Spacer	325-6217
5K-7995	Bearing-Sleeve	308-9820
5P-3930	Bearing As-Rlr	419-6022
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0330	Cup-Rlr Brg	422-6487

TAD		
Original Part Number	Part Name	Classic Part Number
6V-0456	Bearing As-Rlr	435-4041
6V-4582	Bearing-Ball	380-1504
6Y-0306	Bearing-Sleeve	391-1104
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7F-9547	Pin As.-Drawbar	295-0414
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4758	Gear-Planet	288-8723

Sales Model 561N (Cont'd.)

TAD		
Original Part Number	Part Name	Classic Part Number
7G-5444	Carrier-Planet	297-7165
7G-5614	Shaft-Planet	281-1697
7J-2604	Bearing-Sleeve	380-7369
7M-7219	Bearing-Thrust	384-4816
7P-7858	Bearing-Sleeve	374-8362
7S-4534	Bearing-Caged	417-9497
7W-5095	Gear-Flywheel	425-9190
8G-3102	Piston	325-6162
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8T-0072	Cone-Rlr Brg	377-7448
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620

TAD		
Original Part Number	Part Name	Classic Part Number
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9W-9930	Mount As	295-6437
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
109-1231	Strip	393-3683
115-4072	Bearing	397-5069
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445

TAD		
Original Part Number	Part Name	Classic Part Number
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-5001	Strip	393-3683
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710

Sales Model 571A

64A		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-3917	Shaft	386-4915
1M-5270	Pipe-Extension	367-6065
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046
1P-0005	Pump Gp-Fuel Tfr	256-4756
1P-0623	Bearing	420-3224
1P-1367	Plunger-Valve	432-8913
1P-4145	Valve Gp-Press	247-4436
1P-7590	Support As-Fr	213-4400
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188

64A		
Original Part Number	Part Name	Classic Part Number
1S-3926	Manifold-Exhaust	430-7622
1T-0256	Gear-Pump Drive	239-7930
2A-4429	Lock-Retainer	379-0174
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2K-4502	Bearing-Sleeve	299-1986
2K-5254	Bearing-Outer	377-7419
2L-5271	Bearing-Ball	371-4305
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-7116	Strip-Tapping	384-3480
2M-8340	Rod End-Yoke	374-4678
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2P-2811	Race-Spl Rlr Brg	417-4528
2P-3424	Gear-First Red	215-1675

64A		
Original Part Number	Part Name	Classic Part Number
2P-3425	Pinion-Sec Red	217-7697
2S-3946	Gear-Final Drive	215-1678
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6401	Cup-Roller Brg	380-7497
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2S-7873	Pump Gp	226-0162
2S-7917	Gear-Pump Dr	247-4119
2S-7931	Bearing-Sleeve	387-2904
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3H-0881	Ring-Piston	465-8998

Sales Model 571A (Cont'd.)

64A		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1885	Spring-Recoil	375-5449
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3P-3623	Lock-Adj Nut	226-7989
3P-6560	Stop-Rec Spring	226-0232
3P-6561	Stop-Rec Spring	226-0233
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-5017	Elbow-Exhaust	369-9498
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4F-5003	Spring As-Arm	383-2127
4H-9640	Bearing-Sleeve	386-4921
4M-0410	Gear-Oil Pump Dr	428-6660
4M-9183	Bearing-Sleeve	386-4924
4M-9215	Gear-Pump Idler	311-9391
4N-3875	Ring-Piston	465-8997
4S-5367	Mount As	375-9986
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-8651	Bearing-Ball	420-3223
5G-3612	Cap Gp-Protn	295-6419
5H-7071	Director-Water	388-0555
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-2054	Bearing	380-7510
5M-3499	Shaft-Planet	319-3475
5M-3941	Shaft-Planet	215-1691
5M-3942	Shaft-Planet	215-1692

64A		
Original Part Number	Part Name	Classic Part Number
5M-5018	Bearing-Roller	380-7509
5M-5894	Cover-Bearing	448-2438
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5P-9553	Gasket Kit - Wp	393-3624
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5S-1684	Gasket Kt-V Gr	393-5224
5S-4863	Holder As-Cage	215-1732
5S-9080	Pulley-Alt Drive	264-5883
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6K-4442	Rod End-Special	373-5388
6L-7816	Seal-O-Ring	314-8542
6N-5987	Shaft-Water Pump	390-0998
6N-9211	Core As-O Clr	435-6049
6N-9653	Core As-Oil Clr	386-3056
6P-0236	Guide-Lever	422-6475
6P-6653	Plate-Guide	226-0208
6T-1980	Collar-Idler End	226-0210
6V-2202	Bearing-Spl Ball	380-1574
6V-9228	Gasket Kt-Cyl Hd	438-0159
7F-9541	Pin As-Drawbar	296-1361
7G-2517	Gear-Planet	213-8747
7G-2521	Gear-Planet	213-8749
7G-6576	Cage As	216-7859
7H-4566	Cup-Roller Brg	399-6068
7H-6967	Bearing-Ball	422-6489
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538

64A		
Original Part Number	Part Name	Classic Part Number
7M-5692	Impeller-Pump	433-0791
7N-0128	Core As-Oil Clr	299-1994
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-7639	Rotator-Valve	383-1582
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7S-7973	Guard-Fd Wear	213-9110
7T-0119	Support As	299-2066
7T-0204	Bearing-Brace	247-4126
7T-2036	Cap As-Fuel	361-1721
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-1383	Rod-Tie	299-2051
8H-1994	Valve-Exhaust	443-1206
8H-2810	Case As-Filter	314-8512
8H-5026	Cover-Adj Pulley	445-7698
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8M-7166	Housing-Screen	297-7192
8N-7923	Bearing-Main	419-7275
8N-7924	Bearing-Main	419-7276
8N-7933	Bearing-Conn Rod	419-7280
8N-7934	Bearing-Conn Rod	419-6308
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8S-0905	Muffler As	302-2690
8S-1061	Pilot As-Spring	226-0227
8S-7818	Bracket	226-0211
8S-9686	Gasket Kit	393-5215

Sales Model 571A (Cont'd.)

64A		
Original Part Number	**Part Name**	**Classic Part Number**
9G-0007	Hub	224-1311
9H-6236	Rod As	390-0999
9M-5350	Spring-Valve	380-7573
9P-0620	Cage-Pinion Brg	221-1052
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

64A		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5771	Bushing As	385-7219
9S-6875	Pinion-Final Dr	217-7705
9S-9696	Spider As-Fan	383-3707
112-3249	Muffler As	247-2661

64A		
Original Part Number	**Part Name**	**Classic Part Number**
128-3935	Bearing-Race	396-9897
156-8206	Kit-Dt Gasket	451-3112
230-7116	Ster Cl Kit-Cla	229-8227
308-1845	Seal-Wiper	472-8032

Sales Model 571F

95N		
Original Part Number	**Part Name**	**Classic Part Number**
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-3917	Shaft	386-4915
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1P-0579	Housing As	219-9678
1P-0623	Bearing	420-3224
1P-1367	Plunger-Valve	432-8913
1P-2187	Pump Gp-Gr 1 Bsc	299-2044
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1P-7590	Support As-Fr	213-4400
1P-8835	Shaft As	215-1672
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582

95N		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2H-9192	Bearing-Ball	394-8236

95N		
Original Part Number	**Part Name**	**Classic Part Number**
2K-4502	Bearing-Sleeve	299-1986
2K-5254	Bearing-Outer	377-7419
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-7116	Strip-Tapping	384-3480
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2784	Ejector As-Exh	367-6063
2P-2788	Adapter-Fan	390-0984
2P-2811	Race-Spl Rlr Brg	417-4528
2P-3424	Gear-First Red	215-1675

Sales Model 571F (Cont'd.)

95N		
Original Part Number	Part Name	Classic Part Number
2P-3425	Pinion-Sec Red	217-7697
2P-3598	Shaft-Output	215-1676
2P-3669	Pinion-Bevel	215-1677
2P-3767	Tube-Disposal	377-5850
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6245	Shaft As-Pump	325-6197
2S-3946	Gear-Final Drive	215-1678
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6401	Cup-Roller Brg	380-7497
2S-6739	Pulley-Tightener	298-2794
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-0395	Cage-Carrier Brg	217-7723
3P-1885	Spring-Recoil	375-5449
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3P-6560	Stop-Rec Spring	226-0232
3P-6561	Stop-Rec Spring	226-0233
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188

95N		
Original Part Number	Part Name	Classic Part Number
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4F-5003	Spring As-Arm	383-2127
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4864	Pump Gp-F Tfr	242-3442
4N-4878	Pump Gp-F Tfr	390-0995
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-6707	Piston-Clutch	215-1686
4S-8472	Hood As-Preclnr	296-1355
4S-8708	Housing-Clutch	216-3557
4W-0452	Seal As -Cshaft	325-6191
4W-7188	Core As-Oclr	374-7501
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-8651	Bearing-Ball	420-3223
5G-3612	Cap Gp-Protn	295-6419
5L-6326	Bearing-Ball	420-3222
5M-1988	Piston-Steer Cl	219-9691

95N		
Original Part Number	Part Name	Classic Part Number
5M-1990	Pilot-Cl Piston	229-8233
5M-2054	Bearing	380-7510
5M-3499	Shaft-Planet	319-3475
5M-3941	Shaft-Planet	215-1691
5M-3942	Shaft-Planet	215-1692
5M-5822	Gear-Pump Drive	247-4120
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6709	Check As-Ball	380-7542
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1168	Spider & Brg As	377-7435
6B-7469	Spacer	417-4535
6H-2577	Spider Gp-Brg&	333-4954

Sales Model 571F (Cont'd.)

95N		
Original Part Number	Part Name	Classic Part Number
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6L-7751	Rod End-Spher	472-8015
6N-0714	Pulley-Alt	264-5884
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0236	Guide-Lever	422-6475
6P-6653	Plate-Guide	226-0208
6T-1980	Collar-Idler End	226-0210
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7G-2037	Joint Gp-Univ	226-8017
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-2517	Gear-Planet	213-8747
7G-2521	Gear-Planet	213-8749
7G-6576	Cage As	216-7859
7H-4566	Cup-Roller Brg	399-6068
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816

95N		
Original Part Number	Part Name	Classic Part Number
7N-0165	Core As-O Clr	295-5670
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417
7S-7973	Guard-Fd Wear	213-9110
7T-0119	Support As	299-2066
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-1927	Ring-Retainer	387-2935
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782

95N		
Original Part Number	Part Name	Classic Part Number
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

Sales Model 571F (Cont'd.)

95N		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
9B-1320	Valve-Check	377-5832
9G-0007	Hub	224-1311
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-5080	Pump Gp-Vn Bsc-A	422-8141
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517

95N		
Original Part Number	**Part Name**	**Classic Part Number**
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9S-1267	Ejector As-Exh	397-5059
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-6875	Pinion-Final Dr	217-7705
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032

95N		
Original Part Number	**Part Name**	**Classic Part Number**
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
128-3935	Bearing-Race	396-9897
131-3815	Seal Gp-Basic	325-6193
147-9670	Fan As-Rev	435-9912
155-8698	Gasket Kit	394-0914
156-8206	Kit-Dt Gasket	451-3112
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
297-7245	Shaft-Cla	215-1694
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

Sales Model 571G

16W		
Original Part Number	**Part Name**	**Classic Part Number**
1A-3987	Disc-Ster Cl Dr	230-7119

Sales Model 571G (Cont'd.)

16W		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0623	Bearing	420-3224
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7590	Support As-Fr	213-4400
1P-8554	Coupling-Exhaust	325-6052
1P-8835	Shaft As	215-1672
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543

16W		
Original Part Number	Part Name	Classic Part Number
1U-2135	Cyl Gp-0121 0955	395-1304
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2H-9192	Bearing-Ball	394-8236
2K-4502	Bearing-Sleeve	299-1986
2K-5254	Bearing-Outer	377-7419
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-7116	Strip-Tapping	384-3480
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230

16W		
Original Part Number	Part Name	Classic Part Number
2P-2697	Tube As-Air Vent	382-6901
2P-2784	Ejector As-Exh	367-6063
2P-2788	Adapter-Fan	390-0984
2P-2811	Race-Spl Rlr Brg	417-4528
2P-2922	Gear-Transfer	219-9679
2P-2923	Gear-Transfer	219-9680
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2P-3598	Shaft-Output	215-1676
2P-3669	Pinion-Bevel	215-1677
2P-3767	Tube-Disposal	377-5850
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-5608	Pipe-Extension	367-6066
2P-6245	Shaft As-Pump	325-6197
2S-3946	Gear-Final Drive	215-1678
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6401	Cup-Roller Brg	380-7497
2S-6739	Pulley-Tightener	298-2794
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2443	Bearing	383-2125
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-0395	Cage-Carrier Brg	217-7723

Sales Model 571G (Cont'd.)

16W		
Original Part Number	Part Name	Classic Part Number
3P-1885	Spring-Recoil	375-5449
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3P-4157	Yoke As-Idler	226-0221
3P-6560	Stop-Rec Spring	226-0232
3P-6561	Stop-Rec Spring	226-0233
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4F-5003	Spring As-Arm	383-2127
4J-6167	Bearing-Sleeve	325-6009
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008

16W		
Original Part Number	Part Name	Classic Part Number
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-6707	Piston-Clutch	215-1686
4S-8472	Hood As-Preclnr	296-1355
4S-8708	Housing-Clutch	216-3557
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-8651	Bearing-Ball	420-3223
5G-3612	Cap Gp-Protn	295-6419
5J-2528	Plunger	391-1318
5L-6326	Bearing-Ball	420-3222
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-5822	Gear-Pump Drive	247-4120
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684

16W		
Original Part Number	Part Name	Classic Part Number
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1168	Spider & Brg As	377-7435
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6K-4442	Rod End-Special	373-5388
6N-0714	Pulley-Alt	264-5884
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-1218	Core As-Radiator	379-0181
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544

Sales Model 571G (Cont'd.)

16W		
Original Part Number	Part Name	Classic Part Number
6N-7263	Gasket-Cyl Head	380-7386
6P-0236	Guide-Lever	422-6475
6P-6653	Plate-Guide	226-0208
6T-1980	Collar-Idler End	226-0210
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7G-2037	Joint Gp-Univ	226-8017
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-6576	Cage As	216-7859
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3338	Rod As	394-0906
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758

16W		
Original Part Number	Part Name	Classic Part Number
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417
7S-7973	Guard-Fd Wear	213-9110
7T-0119	Support As	299-2066
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782

16W		
Original Part Number	Part Name	Classic Part Number
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

Sales Model 571G (Cont'd.)

16W		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
9B-1320	Valve-Check	377-5832
9G-0007	Hub	224-1311
9K-8757	Rod End-Special	311-9361
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904

16W		
Original Part Number	Part Name	Classic Part Number
9S-1267	Ejector As-Exh	397-5059
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6147	Body As	369-9499
9S-6875	Pinion-Final Dr	217-7705
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
131-3815	Seal Gp-Basic	325-6193
147-9670	Fan As-Rev	435-9912
148-7455	Valve - Exhaust	270-4361
155-8698	Gasket Kit	394-0914
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006

16W		
Original Part Number	Part Name	Classic Part Number
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
234-8016	Kit-Gasket-Sch	393-0919
235-0913	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

Sales Model 571G (Cont'd.)

5ZD		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0623	Bearing	420-3224
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7590	Support As-Fr	213-4400
1P-8835	Shaft As	215-1672
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724

5ZD		
Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2H-9192	Bearing-Ball	394-8236
2K-4502	Bearing-Sleeve	299-1986
2K-5254	Bearing-Outer	377-7419
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-7116	Strip-Tapping	384-3480
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2784	Ejector As-Exh	367-6063

5ZD		
Original Part Number	Part Name	Classic Part Number
2P-2788	Adapter-Fan	390-0984
2P-2811	Race-Spl Rlr Brg	417-4528
2P-2922	Gear-Transfer	219-9679
2P-2923	Gear-Transfer	219-9680
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2P-3598	Shaft-Output	215-1676
2P-3669	Pinion-Bevel	215-1677
2P-3767	Tube-Disposal	377-5850
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6245	Shaft As-Pump	325-6197
2S-3946	Gear-Final Drive	215-1678
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6401	Cup-Roller Brg	380-7497
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-0395	Cage-Carrier Brg	217-7723
3P-1885	Spring-Recoil	375-5449
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3P-4157	Yoke As-Idler	226-0221
3P-6560	Stop-Rec Spring	226-0232

Sales Model 571G (Cont'd.)

5ZD		
Original Part Number	Part Name	Classic Part Number
3P-6561	Stop-Rec Spring	226-0233
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4F-5003	Spring As-Arm	383-2127
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0432	Bearing-Ball	417-4499
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-6707	Piston-Clutch	215-1686
4S-8472	Hood As-Preclnr	296-1355
4S-8708	Housing-Clutch	216-3557
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990

5ZD		
Original Part Number	Part Name	Classic Part Number
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-8651	Bearing-Ball	420-3223
5L-6326	Bearing-Ball	420-3222
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-5822	Gear-Pump Drive	247-4120
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883

5ZD		
Original Part Number	Part Name	Classic Part Number
5V-1168	Spider & Brg As	377-7435
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6N-0714	Pulley-Alt	264-5884
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0236	Guide-Lever	422-6475
6P-6653	Plate-Guide	226-0208
6T-1980	Collar-Idler End	226-0210
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7G-2037	Joint Gp-Univ	226-8017
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-6576	Cage As	216-7859
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531

Sales Model 571G (Cont'd.)

5ZD		
Original Part Number	Part Name	Classic Part Number
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417
7S-7973	Guard-Fd Wear	213-9110
7T-0119	Support As	299-2066
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449

5ZD		
Original Part Number	Part Name	Classic Part Number
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0187	Nut-Adjusting	219-9676

5ZD		
Original Part Number	Part Name	Classic Part Number
8P-1653	Nut-Sprocket Adj	449-4734
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
9G-0007	Hub	224-1311
9K-8757	Rod End-Special	311-9361
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9S-1267	Ejector As-Exh	397-5059
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512

Sales Model 571G (Cont'd.)

5ZD		
Original Part Number	Part Name	Classic Part Number
9S-6147	Body As	369-9499
9S-6875	Pinion-Final Dr	217-7705
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
131-3815	Seal Gp-Basic	325-6193
147-9670	Fan As-Rev	435-9912
148-7455	Valve - Exhaust	270-4361

5ZD		
Original Part Number	Part Name	Classic Part Number
155-8698	Gasket Kit	394-0914
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

5ZD		
Original Part Number	Part Name	Classic Part Number
172-7767	Pump Gp-Water -B	296-1365
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

Sales Model 572C

21A		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2K-1386	Bearing	423-6991
2K-3632	Yoke As	297-4866
2K-5254	Bearing-Outer	377-7419

21A		
Original Part Number	Part Name	Classic Part Number
2K-5804	Rod End-Spher	416-2151
2L-5271	Bearing-Ball	371-4305
2M-8340	Rod End-Yoke	374-4678
2P-0483	Chamber As	256-4760
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3H-0881	Ring-Piston	465-8998
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3P-3623	Lock-Adj Nut	226-7989
4B-1455	Cap As-Filler	361-1719

21A		
Original Part Number	Part Name	Classic Part Number
4F-2393	Bearing-Ball	380-1499
4F-5003	Spring As-Arm	383-2127
4H-9640	Bearing-Sleeve	386-4921
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5F-2256	Cage-Bearing	226-7973
5H-7071	Director-Water	388-0555
5M-2824	Coupling-Exhaust	431-5270
5M-6709	Check As-Ball	380-7542
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9553	Gasket Kit - Wp	393-3624

Sales Model 572C (Cont'd.)

21A		
Original Part Number	Part Name	Classic Part Number
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5T-8739	Spider Gp-Brg&	373-5386
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6N-5987	Shaft-Water Pump	390-0998
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
7H-4566	Cup-Roller Brg	399-6068

21A		
Original Part Number	Part Name	Classic Part Number
7H-6967	Bearing-Ball	422-6489
7K-5448	Cup-Bearing	415-1922
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701

21A		
Original Part Number	Part Name	Classic Part Number
8H-1383	Rod-Tie	299-2051
8H-1994	Valve-Exhaust	443-1206
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-8068	Bearing-Spl Ball	417-4500
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8217	Bolt-Spring	469-4672
121-7746	Pre-Cleaner As	360-2311
228-7325	Ster Cl Kit-Cla	230-7119

Sales Model 572D

21A		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2K-1386	Bearing	423-6991
2K-3632	Yoke As	297-4866
2K-5254	Bearing-Outer	377-7419
2K-5804	Rod End-Spher	416-2151
2L-5271	Bearing-Ball	371-4305
2M-8340	Rod End-Yoke	374-4678
2P-0483	Chamber As	256-4760
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438

21A		
Original Part Number	Part Name	Classic Part Number
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3H-0881	Ring-Piston	465-8998
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3P-3623	Lock-Adj Nut	226-7989
4B-1455	Cap As-Filler	361-1719
4F-2393	Bearing-Ball	380-1499
4F-5003	Spring As-Arm	383-2127
4H-9640	Bearing-Sleeve	386-4921
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5F-2256	Cage-Bearing	226-7973
5H-7071	Director-Water	388-0555
5M-2824	Coupling-Exhaust	431-5270
5M-6709	Check As-Ball	380-7542
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139

21A		
Original Part Number	Part Name	Classic Part Number
5P-9553	Gasket Kit - Wp	393-3624
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5T-8739	Spider Gp-Brg&	373-5386
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6N-5987	Shaft-Water Pump	390-0998
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
7H-4566	Cup-Roller Brg	399-6068
7H-6967	Bearing-Ball	422-6489
7K-5448	Cup-Bearing	415-1922
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348

Sales Model 572D (Cont'd.)

21A		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494

21A		
Original Part Number	**Part Name**	**Classic Part Number**
8F-8523	Bearing-Sleeve	383-3701
8H-1383	Rod-Tie	299-2051
8H-1994	Valve-Exhaust	443-1206
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-8068	Bearing-Spl Ball	417-4500
9H-6236	Rod As	390-0999

21A		
Original Part Number	**Part Name**	**Classic Part Number**
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8217	Bolt-Spring	469-4672
121-7746	Pre-Cleaner As	360-2311
228-7325	Ster Cl Kit-Cla	230-7119

Sales Model 572E

65A		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-3917	Shaft	386-4915
1M-5270	Pipe-Extension	367-6065
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046
1P-0005	Pump Gp-Fuel Tfr	256-4756
1P-0623	Bearing	420-3224
1P-1367	Plunger-Valve	432-8913
1P-4145	Valve Gp-Press	247-4436
1P-7590	Support As-Fr	213-4400
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188
1S-3926	Manifold-Exhaust	430-7622
1T-0043	Bearing-Ball	390-5294
1T-0256	Gear-Pump Drive	239-7930
2A-4429	Lock-Retainer	379-0174

65A		
Original Part Number	**Part Name**	**Classic Part Number**
2D-5658	Bearing-Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2K-1386	Bearing	423-6991
2K-3632	Yoke As	297-4866
2K-5254	Bearing-Outer	377-7419
2L-5271	Bearing-Ball	371-4305
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-7116	Strip-Tapping	384-3480
2M-8340	Rod End-Yoke	374-4678
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2P-2811	Race-Spl Rlr Brg	417-4528
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2S-3946	Gear-Final Drive	215-1678
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979

65A		
Original Part Number	**Part Name**	**Classic Part Number**
2S-6150	Cover-Pulley	428-8817
2S-6401	Cup-Roller Brg	380-7497
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2S-7873	Pump Gp	226-0162
2S-7917	Gear-Pump Dr	247-4119
2S-7931	Bearing-Sleeve	387-2904
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3G-2720	Cartridge Gp-Rr	448-5051
3G-2749	Cartridge Gp-Rr	422-8125
3H-0881	Ring-Piston	465-8998
3H-8726	Mount As	385-7208
3J-9325	Piston	390-0993
3K-4290	Rod End	374-1823
3P-1885	Spring-Recoil	375-5449
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3P-3623	Lock-Adj Nut	226-7989
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188

Sales Model 572E (Cont'd.)

65A		
Original Part Number	Part Name	Classic Part Number
3S-3918	Guard As-Sprkt	226-4950
3S-5017	Elbow-Exhaust	369-9498
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4F-2393	Bearing-Ball	380-1499
4F-5003	Spring As-Arm	383-2127
4H-9640	Bearing-Sleeve	386-4921
4M-0410	Gear-Oil Pump Dr	428-6660
4M-9183	Bearing-Sleeve	386-4924
4M-9215	Gear-Pump Idler	311-9391
4N-3875	Ring-Piston	465-8997
4S-5367	Mount As	375-9986
4T-1893	Cartridge Gp	422-8110
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5G-3612	Cap Gp-Protn	295-6419
5H-7071	Director-Water	388-0555
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-2054	Bearing	380-7510
5M-3499	Shaft-Planet	319-3475
5M-3941	Shaft-Planet	215-1691
5M-3942	Shaft-Planet	215-1692
5M-5018	Bearing-Roller	380-7509
5M-5894	Cover-Bearing	448-2438
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5P-9553	Gasket Kit - Wp	393-3624
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5S-1684	Gasket Kt-V Gr	393-5224
5S-4863	Holder As-Cage	215-1732
5S-9080	Pulley-Alt Drive	264-5883

65A		
Original Part Number	Part Name	Classic Part Number
5T-8739	Spider Gp-Brg&	373-5386
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6L-7816	Seal-O-Ring	314-8542
6N-5987	Shaft-Water Pump	390-0998
6N-9211	Core As-O Clr	435-6049
6N-9653	Core As-Oil Clr	386-3056
6P-0236	Guide-Lever	422-6475
6P-6653	Plate-Guide	226-0208
6T-1980	Collar-Idler End	226-0210
6V-2202	Bearing-Spl Ball	380-1574
6V-9228	Gasket Kt-Cyl Hd	438-0159
7G-2517	Gear-Planet	213-8747
7G-2521	Gear-Planet	213-8749
7G-6576	Cage As	216-7859
7H-4566	Cup-Roller Brg	399-6068
7H-6967	Bearing-Ball	422-6489
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7N-0128	Core As-Oil Clr	299-1994
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-7639	Rotator-Valve	383-1582
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7S-7973	Guard-Fd Wear	213-9110
7T-0119	Support As	299-2066
7T-2036	Cap As-Fuel	361-1721
8F-5104	Screen As-Se Pan	314-8539

65A		
Original Part Number	Part Name	Classic Part Number
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-1383	Rod-Tie	299-2051
8H-1994	Valve-Exhaust	443-1206
8H-2810	Case As-Filter	314-8512
8H-5026	Cover-Adj Pulley	445-7698
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8M-7166	Housing-Screen	297-7192
8N-7923	Bearing-Main	419-7275
8N-7924	Bearing-Main	419-7276
8N-7933	Bearing-Conn Rod	419-7280
8N-7934	Bearing-Conn Rod	419-6308
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734
8S-0905	Muffler As	302-2690
8S-1061	Pilot As-Spring	226-0227
8S-7818	Bracket	226-0211
8S-9686	Gasket Kit	393-5215
9G-0007	Hub	224-1311
9H-6236	Rod As	390-0999
9M-5350	Spring-Valve	380-7573
9P-0620	Cage-Pinion Brg	221-1052
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5771	Bushing As	385-7219
9S-6875	Pinion-Final Dr	217-7705
9S-9696	Spider As-Fan	383-3707
9T-2200	Cartridgr Gp	422-8114
9T-5096	Flexplate	455-3271
112-3249	Muffler As	247-2661
128-3935	Bearing-Race	396-9897

Sales Model 572E (Cont'd.)

65A		
Original Part Number	**Part Name**	**Classic Part Number**
156-8206	Kit-Dt Gasket	451-3112

65A		
Original Part Number	**Part Name**	**Classic Part Number**
230-7116	Ster Cl Kit-Cla	229-8227

65A		
Original Part Number	**Part Name**	**Classic Part Number**
308-1845	Seal-Wiper	472-8032

Sales Model 572F

96N		
Original Part Number	**Part Name**	**Classic Part Number**
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-3917	Shaft	386-4915
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1P-0579	Housing As	219-9678
1P-0623	Bearing	420-3224
1P-1367	Plunger-Valve	432-8913
1P-2187	Pump Gp-Gr 1 Bsc	299-2044
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1P-7590	Support As-Fr	213-4400
1P-8835	Shaft As	215-1672
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410

96N		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2K-1386	Bearing	423-6991
2K-3632	Yoke As	297-4866
2K-5254	Bearing-Outer	377-7419
2L-5271	Bearing-Ball	371-4305
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-7116	Strip-Tapping	384-3480
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927

96N		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2784	Ejector As-Exh	367-6063
2P-2788	Adapter-Fan	390-0984
2P-2811	Race-Spl Rlr Brg	417-4528
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2P-3598	Shaft-Output	215-1676
2P-3669	Pinion-Bevel	215-1677
2P-3767	Tube-Disposal	377-5850
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6245	Shaft As-Pump	325-6197
2S-3946	Gear-Final Drive	215-1678
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6401	Cup-Roller Brg	380-7497
2S-6739	Pulley-Tightener	298-2794

Sales Model 572F (Cont'd.)

96N		
Original Part Number	**Part Name**	**Classic Part Number**
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
3G-2720	Cartridge Gp-Rr	448-5051
3G-2749	Cartridge Gp-Rr	422-8125
3H-8726	Mount As	385-7208
3J-9325	Piston	390-0993
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-0395	Cage-Carrier Brg	217-7723
3P-1885	Spring-Recoil	375-5449
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4F-2393	Bearing-Ball	380-1499
4F-5003	Spring As-Arm	383-2127
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362

96N		
Original Part Number	**Part Name**	**Classic Part Number**
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4864	Pump Gp-F Tfr	242-3442
4N-4878	Pump Gp-F Tfr	390-0995
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-6707	Piston-Clutch	215-1686
4S-8472	Hood As-Preclnr	296-1355
4S-8708	Housing-Clutch	216-3557
4T-1893	Cartridge Gp	422-8110
4W-0452	Seal As -Cshaft	325-6191
4W-7188	Core As-Oclr	374-7501
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5G-3612	Cap Gp-Protn	295-6419
5L-6326	Bearing-Ball	420-3222
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-2054	Bearing	380-7510
5M-3499	Shaft-Planet	319-3475
5M-3941	Shaft-Planet	215-1691
5M-3942	Shaft-Planet	215-1692
5M-5822	Gear-Pump Drive	247-4120
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6709	Check As-Ball	380-7542
5M-7841	Gear-Ring	214-0525

96N		
Original Part Number	**Part Name**	**Classic Part Number**
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6H-2577	Spider Gp-Brg&	333-4954
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0714	Pulley-Alt	264-5884
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544

Sales Model 572F (Cont'd.)

96N		
Original Part Number	Part Name	Classic Part Number
6N-7263	Gasket-Cyl Head	380-7386
6P-0236	Guide-Lever	422-6475
6P-6653	Plate-Guide	226-0208
6T-1980	Collar-Idler End	226-0210
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-2517	Gear-Planet	213-8747
7G-2521	Gear-Planet	213-8749
7G-6576	Cage As	216-7859
7H-4566	Cup-Roller Brg	399-6068
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-6964	Gear-Ring	214-0532

96N		
Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As-Radiator	295-6417
7S-7973	Guard-Fd Wear	213-9110
7T-0119	Support As	299-2066
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-1927	Ring-Retainer	387-2935
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441

96N		
Original Part Number	Part Name	Classic Part Number
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211

Sales Model 572F (Cont'd.)

96N		
Original Part Number	Part Name	Classic Part Number
9B-1320	Valve-Check	377-5832
9G-0007	Hub	224-1311
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-5080	Pump Gp-Vn Bsc-A	422-8141
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9S-1267	Ejector As-Exh	397-5059
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891

96N		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-6875	Pinion-Final Dr	217-7705
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9T-2200	Cartridgr Gp	422-8114
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
128-3935	Bearing-Race	396-9897

96N		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
147-9670	Fan As-Rev	435-9912
155-8698	Gasket Kit	394-0914
156-8206	Kit-Dt Gasket	451-3112
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
297-7245	Shaft-Cla	215-1694
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

Sales Model 572G

40U		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046

40U		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0623	Bearing	420-3224
1P-1367	Plunger-Valve	432-8913
1P-2187	Pump Gp-Gr 1 Bsc	299-2044

40U		
Original Part Number	Part Name	Classic Part Number
1P-4110	Disc-Friction	433-9858
1P-7590	Support As-Fr	213-4400
1P-8554	Coupling-Exhaust	325-6052
1P-8835	Shaft As	215-1672
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224

Sales Model 572G (Cont'd.)

40U		
Original Part Number	Part Name	Classic Part Number
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236

40U		
Original Part Number	Part Name	Classic Part Number
2K-1386	Bearing	423-6991
2K-3632	Yoke As	297-4866
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5254	Bearing-Outer	377-7419
2L-5271	Bearing-Ball	371-4305
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-7116	Strip-Tapping	384-3480
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2784	Ejector As-Exh	367-6063
2P-2788	Adapter-Fan	390-0984
2P-2811	Race-Spl Rlr Brg	417-4528
2P-2922	Gear-Transfer	219-9679
2P-2923	Gear-Transfer	219-9680
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2P-3598	Shaft-Output	215-1676
2P-3669	Pinion-Bevel	215-1677
2P-3767	Tube-Disposal	377-5850
2P-4698	Bearing-Sleeve	389-6318

40U		
Original Part Number	Part Name	Classic Part Number
2P-4701	Shaft As-Gear	297-7257
2P-5608	Pipe-Extension	367-6066
2P-6245	Shaft As-Pump	325-6197
2S-3946	Gear-Final Drive	215-1678
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6401	Cup-Roller Brg	380-7497
2S-6739	Pulley-Tightener	298-2794
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-9325	Piston	390-0993
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-0395	Cage-Carrier Brg	217-7723
3P-1885	Spring-Recoil	375-5449
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248

Sales Model 572G (Cont'd.)

40U		
Original Part Number	Part Name	Classic Part Number
4D-2619	Bearing	417-4494
4F-2393	Bearing-Ball	380-1499
4F-5003	Spring As-Arm	383-2127
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-6707	Piston-Clutch	215-1686
4S-8472	Hood As-Preclnr	296-1355

40U		
Original Part Number	Part Name	Classic Part Number
4S-8708	Housing-Clutch	216-3557
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5G-3612	Cap Gp-Protn	295-6419
5L-6326	Bearing-Ball	420-3222
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-5822	Gear-Pump Drive	247-4120
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6709	Check As-Ball	380-7542
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247

40U		
Original Part Number	Part Name	Classic Part Number
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0714	Pulley-Alt	264-5884
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-1218	Core As-Radiator	379-0181
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0236	Guide-Lever	422-6475
6P-6653	Plate-Guide	226-0208
6T-1980	Collar-Idler End	226-0210
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-6576	Cage As	216-7859
7M-1296	Valve-Relief	390-0990

Sales Model 572G (Cont'd.)

40U		
Original Part Number	Part Name	Classic Part Number
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417
7S-7973	Guard-Fd Wear	213-9110
7T-0119	Support As	299-2066
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684

40U		
Original Part Number	Part Name	Classic Part Number
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623

40U		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
9B-1320	Valve-Check	377-5832
9G-0007	Hub	224-1311
9J-5080	Pump Gp-Vn Bsc-A	422-8141
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756

Sales Model 572G (Cont'd.)

40U		
Original Part Number	Part Name	Classic Part Number
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9S-1267	Ejector As-Exh	397-5059
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6147	Body As	369-9499
9S-6875	Pinion-Final Dr	217-7705
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042

40U		
Original Part Number	Part Name	Classic Part Number
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9T-2200	Cartridgr Gp	422-8114
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
131-3815	Seal Gp-Basic	325-6193
147-9670	Fan As-Rev	435-9912
148-7455	Valve - Exhaust	270-4361
155-8698	Gasket Kit	394-0914
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-0566	Kit-Rebuild-Pump	377-5835

40U		
Original Part Number	Part Name	Classic Part Number
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
234-8016	Kit-Gasket-Sch	393-0919
235-0913	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

8PC		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046

8PC		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0623	Bearing	420-3224
1P-1367	Plunger-Valve	432-8913
1P-2187	Pump Gp-Gr 1 Bsc	299-2044

8PC		
Original Part Number	Part Name	Classic Part Number
1P-4110	Disc-Friction	433-9858
1P-7590	Support As-Fr	213-4400
1P-8835	Shaft As	215-1672
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147

Sales Model 572G (Cont'd.)

8PC		
Original Part Number	Part Name	Classic Part Number
1S-2233	Bearing-Sleeve	379-0188
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-2135	Cyl Gp-0121 0955	395-1304
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354

8PC		
Original Part Number	Part Name	Classic Part Number
2H-9192	Bearing-Ball	394-8236
2K-1386	Bearing	423-6991
2K-3632	Yoke As	297-4866
2K-5254	Bearing-Outer	377-7419
2L-5271	Bearing-Ball	371-4305
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-7116	Strip-Tapping	384-3480
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2784	Ejector As-Exh	367-6063
2P-2788	Adapter-Fan	390-0984
2P-2811	Race-Spl Rlr Brg	417-4528
2P-2922	Gear-Transfer	219-9679
2P-2923	Gear-Transfer	219-9680
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2P-3598	Shaft-Output	215-1676
2P-3669	Pinion-Bevel	215-1677
2P-3767	Tube-Disposal	377-5850
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6245	Shaft As-Pump	325-6197
2S-3946	Gear-Final Drive	215-1678
2S-5100	Valve-Ball	386-3049

8PC		
Original Part Number	Part Name	Classic Part Number
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6401	Cup-Roller Brg	380-7497
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2443	Bearing	383-2125
3J-9325	Piston	390-0993
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-0395	Cage-Carrier Brg	217-7723
3P-1885	Spring-Recoil	375-5449
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4F-2393	Bearing-Ball	380-1499
4F-5003	Spring As-Arm	383-2127
4J-6167	Bearing-Sleeve	325-6009
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952

Sales Model 572G (Cont'd.)

8PC		
Original Part Number	Part Name	Classic Part Number
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8204	Mount As	374-1449
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-6707	Piston-Clutch	215-1686
4S-8472	Hood As-Preclnr	296-1355
4S-8708	Housing-Clutch	216-3557
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5J-2528	Plunger	391-1318
5L-6326	Bearing-Ball	420-3222
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-5822	Gear-Pump Drive	247-4120

8PC		
Original Part Number	Part Name	Classic Part Number
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6709	Check As-Ball	380-7542
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-8739	Spider Gp-Brg&	373-5386
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015

8PC		
Original Part Number	Part Name	Classic Part Number
6N-0714	Pulley-Alt	264-5884
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0236	Guide-Lever	422-6475
6P-6653	Plate-Guide	226-0208
6T-1980	Collar-Idler End	226-0210
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-6576	Cage As	216-7859
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3338	Rod As	394-0906
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438

Sales Model 572G (Cont'd.)

8PC		
Original Part Number	Part Name	Classic Part Number
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417
7S-7973	Guard-Fd Wear	213-9110
7T-0119	Support As	299-2066
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-2880	Cap-Bearing	295-6420
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893

8PC		
Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734
8P-7790	Valve Gp-Press	247-4437

8PC		
Original Part Number	Part Name	Classic Part Number
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
9G-0007	Hub	224-1311
9J-5080	Pump Gp-Vn Bsc-A	422-8141
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9S-1267	Ejector As-Exh	397-5059
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6147	Body As	369-9499
9S-6875	Pinion-Final Dr	217-7705
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531

Sales Model 572G (Cont'd.)

8PC		
Original Part Number	Part Name	Classic Part Number
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9T-2200	Cartridgr Gp	422-8114
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
131-3815	Seal Gp-Basic	325-6193
147-9670	Fan As-Rev	435-9912
148-7455	Valve - Exhaust	270-4361
155-8698	Gasket Kit	394-0914
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351

8PC		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
190-3832	Core As-Oclr	438-3251

8PC		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

Sales Model 572R

2HZ		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410

2HZ		
Original Part Number	Part Name	Classic Part Number
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

2HZ		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

Sales Model 572R (Cont'd.)

2HZ		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
3Y-9984	Manifold-Exhaust	325-6123
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

2HZ		
Original Part Number	Part Name	Classic Part Number
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5F-2465	Cup-Roller Brg	447-8060
5K-7995	Bearing-Sleeve	308-9820
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

2HZ		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0145	Plate-Locking	419-8801
6Y-5692	Plate-Brake	380-7492
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7K-9639	Bearing-Sleeve	314-8643

Sales Model 572R (Cont'd.)

2HZ		
Original Part Number	Part Name	Classic Part Number
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-6427	Pin	319-3462
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8G-4510	Plate-Clutch	383-2113
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

2HZ		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923

2HZ		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-2344	Coupling-Pump Dr	314-8666
9W-8270	Gear-Ring	308-9859
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
127-5537	Core As-Oclr	325-6045
130-3139	Bearing-Sleeve	391-9875
131-3815	Seal Gp-Basic	325-6193
140-8435	Flange	451-9015
141-4689	Bar Gp-Equalizer	443-3570
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

Sales Model 572R (Cont'd.)

2HZ		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
191-9323	Kit-Bearing	464-9064
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
258-2308	Bearing-Sleeve	325-6019

2HZ		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

2HZ		
Original Part Number	Part Name	Classic Part Number
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	376-3636
464-9064	Kit-Dt Brg-Cla	384-5932

AAC		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

AAC		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230

AAC		
Original Part Number	Part Name	Classic Part Number
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
3Y-9984	Manifold-Exhaust	325-6123
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499

Sales Model 572R (Cont'd.)

AAC		
Original Part Number	Part Name	Classic Part Number
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5F-2465	Cup-Roller Brg	447-8060
5K-7995	Bearing-Sleeve	308-9820
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

AAC		
Original Part Number	Part Name	Classic Part Number
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0145	Plate-Locking	419-8801
6Y-5692	Plate-Brake	380-7492
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530

AAC		
Original Part Number	Part Name	Classic Part Number
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-6427	Pin	319-3462
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8G-4510	Plate-Clutch	383-2113
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

Sales Model 572R (Cont'd.)

AAC		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468

AAC		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-2344	Coupling-Pump Dr	314-8666
9W-8270	Gear-Ring	308-9859
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
127-5537	Core As-Oclr	325-6045
130-3139	Bearing-Sleeve	391-9875
131-3815	Seal Gp-Basic	325-6193
140-8435	Flange	451-9015
141-4689	Bar Gp-Equalizer	443-3570
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127

AAC		
Original Part Number	Part Name	Classic Part Number
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
191-9323	Kit-Bearing	464-9064
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
258-2308	Bearing-Sleeve	325-6019
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	376-3636
464-9064	Kit-Dt Brg-Cla	415-1917

Sales Model 572R (Cont'd.)

DSC		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-9229	Muffler As	302-4282
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2P-1370	Cup-Rlr Brg	384-5921
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4M-5858	Bearing-Spl Ball	417-4495
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016

DSC		
Original Part Number	Part Name	Classic Part Number
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5K-7995	Bearing-Sleeve	308-9820
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-6721	Coupling	377-5830
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-5692	Plate-Brake	380-7492
6Y-5812	Bearing-Sleeve	325-6019
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450

DSC		
Original Part Number	Part Name	Classic Part Number
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7T-6427	Pin	319-3462
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8G-4510	Plate-Clutch	383-2113
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994

Sales Model 572R (Cont'd.)

DSC		
Original Part Number	Part Name	Classic Part Number
9W-2344	Coupling-Pump Dr	314-8666
9W-8270	Gear-Ring	308-9859
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
104-1706	Valve-Regulating	432-8281
108-7754	Housing As.	433-9856
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447

DSC		
Original Part Number	Part Name	Classic Part Number
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-8458	Spider As-Fan	395-1306
130-3139	Bearing-Sleeve	391-9875
140-8435	Flange	451-9015
141-4689	Bar Gp-Equalizer	443-3570
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
155-2819	Ejector As-Exh	325-6078
165-7211	Strip	325-6219
176-4168	Bridge As-Valve	419-4727

DSC		
Original Part Number	Part Name	Classic Part Number
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
208-5026	Pin	325-6133
216-4781	Gasket Kit	437-8144
258-2303	Bearing-Sleeve	307-1524
258-2308	Bearing-Sleeve	325-6019
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

Sales Model 578

8HB		
Original Part Number	Part Name	Classic Part Number
1L-7319	Cup-Roller Brg	380-7499
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1S-9209	Shaft-Tightener	374-6499
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180

8HB		
Original Part Number	Part Name	Classic Part Number
1T-0679	Roller-Freewheel	384-4797
1T-0699	Impeller-Conv	235-1808
1T-0807	Race-Thrust Brg	453-3651
1T-0902	Bearing-Sleeve	389-6326
1T-1386	Yoke-Univ Joint	325-6239
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846

8HB		
Original Part Number	Part Name	Classic Part Number
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5910	Tappet As-Guide&	383-1569
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-1005	Bearing-Sleeve	296-1342
2P-1370	Cup-Rlr Brg	384-5921
2P-4370	Plate-Clutch	325-6166
2S-6097	Tang	375-9979

Sales Model 578 (Cont'd.)

8HB		
Original Part Number	Part Name	Classic Part Number
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7455	Gear As	396-9957
2W-9978	Core As-Oclr	279-4983
3E-4880	Coupling As	417-9465
3E-6772	Seal-Water	382-8017
3G-4292	Bearing	425-6439
3K-2511	Dowel-Reaction	383-2126
3P-8845	Bearing-Inner	416-5491
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-5929	Gear	288-8718
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
4D-4065	Rod End-Spher	374-1824
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812

8HB		
Original Part Number	Part Name	Classic Part Number
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4S-8670	Shaft-Planet	300-2590
4T-1684	Bearing	377-7428
4T-4073	Valve Gp-Shtl -B	439-1138
4W-0255	Spider As-Fan	382-5052
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-7382	Core As-Oclr	380-1514
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7802	Bearing-Aligning	420-2496
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467

8HB		
Original Part Number	Part Name	Classic Part Number
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-8088	Bearing-Roller	399-4428
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6P-0593	Bearing-Roller	386-4959
6P-5404	Plate-Cl	325-6168
6P-7704	Carrier-Ring	314-8658
6P-8829	Retainer	380-7407
6S-2828	Cup-Roller Brg	384-5932
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl	325-6170
6T-7882	Gear-Planet	296-1352
6T-8249	Pin	399-8542
6T-8250	Retainer	319-3473
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-0210	Bearing-Sleeve	453-6506
6Y-2065	Mount As-650 Cup	377-5844
6Y-4819	Carrier-Planet	296-1348
6Y-7946	Disc-Friction	384-4801
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6628	Pulley-Alt	396-9894

Sales Model 578 (Cont'd.)

8HB		
Original Part Number	Part Name	Classic Part Number
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9595	Core As-Radiator	396-9926
7E-9907	Spacer-Fp Timing	394-0222
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-3454	Gear-Planet	300-2578
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-0113	Core As-Oclr	388-0564
7N-1275	Pulley-Fan	380-7535
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7S-3002	Bearing-Spl Ball	386-4961
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721

8HB		
Original Part Number	Part Name	Classic Part Number
7T-5510	Pad As-Resilient	367-6090
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8N-8983	Hub-Fan Pulley	421-7227
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7038	Pin	396-0665
9L-5839	Coupling-Exhaust	374-7480

8HB		
Original Part Number	Part Name	Classic Part Number
9M-3025	Cover As	299-2001
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9P-0863	Pin	389-6321
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-2344	Coupling-Pump Dr	314-8666
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-7919	Bearing-Sleeve	425-3647
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
107-8106	Manifold-Exh	374-7487
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744

Sales Model 578 (Cont'd.)

8HB		
Original Part Number	Part Name	Classic Part Number
108-6633	Pump Gp-Fuel Inj	420-6215
108-7754	Housing As.	433-9856
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
110-8368	Bearing-Cup	416-2172
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813

8HB		
Original Part Number	Part Name	Classic Part Number
139-6850	Gasket Kit	384-4809
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
156-8208	Kit-Gasket-Trans	434-7275
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
184-4395	Guide	393-1042
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012

8HB		
Original Part Number	Part Name	Classic Part Number
191-7946	Line As-Fuel Inj	378-4013
200-3199	Muffler As-Eject	396-1565
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-3294	Gage As-O Level	398-2930
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
234-1874	Kit-Gasket-Fs	437-8668
253-1752	Plate-Thrust	379-0170
258-2305	Bearing-Sleeve	325-6029
290-2060	Kit-Gasket-Sch	438-0149
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812

Sales Model 583C

16A		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-5675	Bearing	377-7396
1B-6577	Cone-Spl Tapered	374-1839
1M-7250	Bowl	360-2296
1M-9444	Retainer-Spring	299-2046
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354

16A		
Original Part Number	Part Name	Classic Part Number
2K-1386	Bearing	423-6991
2K-3632	Yoke As	297-4866
2L-5271	Bearing-Ball	371-4305
2M-8340	Rod End-Yoke	374-4678
2P-0483	Chamber As	256-4760
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3B-8845	Bearing-Inner	417-4509
3H-0881	Ring-Piston	465-8998
3H-8726	Mount As	385-7208

16A		
Original Part Number	Part Name	Classic Part Number
3K-4290	Rod End	374-1823
4B-1455	Cap As-Filler	361-1719
4F-2393	Bearing-Ball	380-1499
4F-5003	Spring As-Arm	383-2127
4H-9640	Bearing-Sleeve	386-4921
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5H-7071	Director-Water	388-0555
5M-6709	Check As-Ball	380-7542
5P-9553	Gasket Kit - Wp	393-3624
5S-1211	Cover-Valve	314-8665

Sales Model 583C (Cont'd.)

16A		
Original Part Number	Part Name	Classic Part Number
5S-1220	Lifter As-Valve	387-2926
5T-8739	Spider Gp-Brg&	373-5386
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-7816	Seal-O-Ring	314-8542
6N-5987	Shaft-Water Pump	390-0998
7H-6967	Bearing-Ball	422-6489
7K-5448	Cup-Bearing	415-1922
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538

16A		
Original Part Number	Part Name	Classic Part Number
7M-5692	Impeller-Pump	433-0791
7N-3352	Plate-Spacer	386-3062
7N-4170	Pump Gp-Eng Oil	379-0169
7N-4407	Gasket-Rod Comp	433-9853
7N-7639	Rotator-Valve	383-1582
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494

16A		
Original Part Number	Part Name	Classic Part Number
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8N-4810	Gasket-Cyl Head	437-2046
9H-6236	Rod As	390-0999
9M-5350	Spring-Valve	380-7573
9S-8217	Bolt-Spring	469-4672
9V-7710	Univ Joint As	394-8234

Sales Model 583E

16A		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-5675	Bearing	377-7396
1B-6577	Cone-Spl Tapered	374-1839
1M-7250	Bowl	360-2296
1M-9444	Retainer-Spring	299-2046
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2K-1386	Bearing	423-6991
2K-3632	Yoke As	297-4866
2L-5271	Bearing-Ball	371-4305
2M-8340	Rod End-Yoke	374-4678
2P-0483	Chamber As	256-4760
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099

16A		
Original Part Number	Part Name	Classic Part Number
3B-8845	Bearing-Inner	417-4509
3H-0881	Ring-Piston	465-8998
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
4B-1455	Cap As-Filler	361-1719
4F-2393	Bearing-Ball	380-1499
4F-5003	Spring As-Arm	383-2127
4H-9640	Bearing-Sleeve	386-4921
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5H-7071	Director-Water	388-0555
5M-6709	Check As-Ball	380-7542
5P-9553	Gasket Kit - Wp	393-3624
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5T-8739	Spider Gp-Brg&	373-5386
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6L-7816	Seal-O-Ring	314-8542
6N-5987	Shaft-Water Pump	390-0998

16A		
Original Part Number	Part Name	Classic Part Number
7H-6967	Bearing-Ball	422-6489
7K-5448	Cup-Bearing	415-1922
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7N-3352	Plate-Spacer	386-3062
7N-4170	Pump Gp-Eng Oil	379-0169
7N-4407	Gasket-Rod Comp	433-9853
7N-7639	Rotator-Valve	383-1582
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206

Sales Model 583E (Cont'd.)

16A		
Original Part Number	Part Name	Classic Part Number
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8N-4810	Gasket-Cyl Head	437-2046

16A		
Original Part Number	Part Name	Classic Part Number
9H-6236	Rod As	390-0999
9M-5350	Spring-Valve	380-7573

16A		
Original Part Number	Part Name	Classic Part Number
9S-8217	Bolt-Spring	469-4672
9V-7710	Univ Joint As	394-8234

Sales Model 583H

38A		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1M-1994	Bearing As-Rlr	399-6066
1M-9444	Retainer-Spring	299-2046
1P-3318	Strip	385-7206
1S-1888	Bracket-Lamp	297-7147
1S-2269	Sleeve	226-2720
1S-7056	Bearing-Ball	422-6483
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6421	Bearing-Outer	417-4510
2K-1386	Bearing	423-6991
2K-3632	Yoke As	297-4866
2K-5254	Bearing-Outer	377-7419
2L-5271	Bearing-Ball	371-4305
2M-1149	Race-Brg Outer	418-9615
2M-8340	Rod End-Yoke	374-4678
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2P-1604	Piston-Ster Cl	219-9694
2P-1605	Pilot-Cl Piston	219-9695
2P-9038	Drum-Cl Driven	216-7821
2S-3913	Cage-Gear Brg	217-7722
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-4357	Pinion-Fdr	217-7706
2S-8884	Ring-Piston	465-8995

38A		
Original Part Number	Part Name	Classic Part Number
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3B-8845	Bearing-Inner	417-4509
3G-2720	Cartridge Gp-Rr	448-5051
3G-2749	Cartridge Gp-Rr	422-8125
3H-0881	Ring-Piston	465-8998
3H-8726	Mount As	385-7208
3J-9325	Piston	390-0993
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3S-6989	Nut-Spanner	219-9701
3S-7308	Cage-Pinion Brg	219-9702
3S-9669	Bearing	416-2168
3T-3150	Guide-Frt Idler	394-0191
4B-7255	Cone-Bearing	386-4951
4F-2393	Bearing-Ball	380-1499
4F-5003	Spring As-Arm	383-2127
4H-9640	Bearing-Sleeve	386-4921
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
4S-9325	Race-Spl Rlr Brg	418-9590
4S-9326	Bearing	417-4506
4S-9782	Race & Roller As	385-3779
4S-9783	Race-Rlr Bearing	418-9589
4T-1893	Cartridge Gp	422-8110
5H-1719	Pump Gp-Fd Oil	226-0168

38A		
Original Part Number	Part Name	Classic Part Number
5H-7071	Director-Water	388-0555
5M-6674	Guard-F Idler Lh	226-2736
5M-6709	Check As-Ball	380-7542
5M-7306	Cylinder	226-2737
5N-8501	Head As-Cyl	256-4762
5P-9553	Gasket Kit - Wp	393-3624
5S-0464	Gear-First Red	216-7852
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5T-8739	Spider Gp-Brg&	373-5386
6B-6224	Ferrule	419-4738
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6K-8088	Bearing-Roller	399-4428
6L-7816	Seal-O-Ring	314-8542
6N-5987	Shaft-Water Pump	390-0998
6P-0549	Guard-Fdr Wear	223-4812
6P-2776	Gear-Final Drive	217-7718
6P-3593	Support	229-8231
6P-3597	Retainer	222-1770
6P-8829	Retainer	380-7407
6T-8886	Disc-Ster Cl	380-7517
6Y-7652	Cup-Rlr Brg	399-6067
7K-5448	Cup-Bearing	415-1922
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791

Sales Model 583H (Cont'd.)

38A		
Original Part Number	Part Name	Classic Part Number
7N-3352	Plate-Spacer	386-3062
7N-4170	Pump Gp-Eng Oil	379-0169
7N-4407	Gasket-Rod Comp	433-9853
7N-7639	Rotator-Valve	383-1582
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
8F-5104	Screen As-Se Pan	314-8539
8F-8523	Bearing-Sleeve	383-3701
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442

38A		
Original Part Number	Part Name	Classic Part Number
8H-1994	Valve-Exhaust	443-1206
8H-2434	Drum-Ster Cl Dr	216-7862
8H-4320	Bearing-Ball	419-2301
8H-5026	Cover-Adj Pulley	445-7698
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8N-4810	Gasket-Cyl Head	437-2046
8N-6004	Head As-Cyl	247-3369
8P-8221	Plate-Guide	226-2748
8S-2123	Cage-Fdr Bearing	217-7726

38A		
Original Part Number	Part Name	Classic Part Number
8S-2126	Spacer-Hub Brg	222-1767
9F-8074	Bearing-Outer	452-3180
9H-6236	Rod As	390-0999
9M-5350	Spring-Valve	380-7573
9S-1026	Cage-Gear Brg	216-7873
9S-4829	Race-Brg Inner	423-9668
9S-7534	Pipe-Exh Ext	398-2950
9S-8217	Bolt-Spring	469-4672
9T-2200	Cartridgr Gp	422-8114
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
308-1845	Seal-Wiper	472-8032
374-1849	Brg-Rlr-Cla	399-4442

61A		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1M-3917	Shaft	386-4915
1M-4095	Bearing-Inner	417-9486
1M-4167	Shaft-Planet	219-9700
1M-9444	Retainer-Spring	299-2046
1P-0005	Pump Gp-Fuel Tfr	256-4756
1P-1367	Plunger-Valve	432-8913
1P-3318	Strip	385-7206
1P-4145	Valve Gp-Press	247-4436
1P-6400	Plunger As-Pump	383-1568
1P-7295	Shaft-Acc Drive	431-5261
1S-1888	Bracket-Lamp	297-7147
1S-2269	Sleeve	226-2720
1S-7056	Bearing-Ball	422-6483
1S-8607	Baffle	380-7540
1S-8754	Joint Gp-Univ	308-9873

61A		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1T-0221	Wheel-Turbine	390-5268
1T-0224	Carrier-Ring	239-7928
1T-0231	Retainer-Bearing	319-3471
1T-0237	Flange As-Output	239-7929
1T-0256	Gear-Pump Drive	239-7930
1T-0278	Bearing-Sleeve	394-0213
1T-0589	Cup-Roller Brg	386-4942
1T-0595	Carrier-Wheel	239-7939
1T-0610	Bearing-Ball	396-4136
1T-0611	Converter As-Tor	235-1804
1T-0633	Impeller-Conv	390-5266
1T-1389	Carrier-Bearing	247-4124
1T-1399	Impeller-Conv	391-9829
1T-1562	Wheel As-Guide	388-6580
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6421	Bearing-Outer	417-4510
2F-5721	Bearing-Ball	311-9354

61A		
Original Part Number	Part Name	Classic Part Number
2H-3712	Bearing-Ball	392-4488
2K-1386	Bearing	423-6991
2K-3632	Yoke As	297-4866
2K-5065	Cone-Roller Brg	416-2157
2K-5254	Bearing-Outer	377-7419
2L-5271	Bearing-Ball	371-4305
2M-1149	Race-Brg Outer	418-9615
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2P-1604	Piston-Ster Cl	219-9694
2P-1605	Pilot-Cl Piston	219-9695
2P-2656	Line As-Fuel Inj	430-9650
2P-4611	Pipe-Exhaust	365-8821
2P-9038	Drum-Cl Driven	216-7821
2S-3913	Cage-Gear Brg	217-7722
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-4357	Pinion-Fdr	217-7706

Sales Model 583H (Cont'd.)

61A		
Original Part Number	Part Name	Classic Part Number
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-7873	Pump Gp	226-0162
2S-7917	Gear-Pump Dr	247-4119
2S-7931	Bearing-Sleeve	387-2904
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3B-8845	Bearing-Inner	417-4509
3G-2720	Cartridge Gp-Rr	448-5051
3G-2749	Cartridge Gp-Rr	422-8125
3H-0881	Ring-Piston	465-8998
3H-8726	Mount As	385-7208
3J-9325	Piston	390-0993
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3P-1687	Plate-Clutch	428-6658
3P-9394	Shaft-Planet	215-1680
3S-1262	Retainer	308-9915
3S-1404	Bearing-Outer	417-4508
3S-2252	Manifold-Exhaust	261-0887
3S-3875	Screen-Suction	435-4849
3S-6989	Nut-Spanner	219-9701
3S-7308	Cage-Pinion Brg	219-9702
3S-7517	Pulley-Belt Adj	264-5876
3S-9669	Bearing	416-2168
3S-9919	Shaft As	239-7959
3T-3150	Guide-Frt Idler	394-0191
4B-7255	Cone-Bearing	386-4951
4F-2393	Bearing-Ball	380-1499
4F-5003	Spring As-Arm	383-2127
4H-9640	Bearing-Sleeve	386-4921
4M-0410	Gear-Oil Pump Dr	428-6660
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4M-9183	Bearing-Sleeve	386-4924

61A		
Original Part Number	Part Name	Classic Part Number
4M-9215	Gear-Pump Idler	311-9391
4N-3875	Ring-Piston	465-8997
4N-4577	Muffler As.	308-9877
4N-4880	Pump Gp-F Tfr	256-4758
4P-7731	Core Gp-O Clr	385-7228
4S-7793	Thrower-Cshft O	367-6085
4S-8472	Hood As-Preclnr	296-1355
4S-8855	Coupling-Exhaust	369-9488
4S-9325	Race-Spl Rlr Brg	418-9590
4S-9326	Bearing	417-4506
4S-9782	Race & Roller As	385-3779
4S-9783	Race-Rlr Bearing	418-9589
4T-1893	Cartridge Gp	422-8110
5G-3612	Cap Gp-Protn	295-6419
5H-1719	Pump Gp-Fd Oil	226-0168
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5L-8856	Coupling-Exhaust	311-9379
5M-0549	Gear-Trans	215-1689
5M-2051	Bearing-Caged	380-7467
5M-3996	Gear-Ring	214-0527
5M-4427	Gear-Sun	214-0529
5M-6674	Guard-F Idler Lh	226-2736
5M-6709	Check As-Ball	380-7542
5M-7306	Cylinder	226-2737
5M-7955	Shaft As-Planet	364-5273
5N-8501	Head As-Cyl	256-4762
5N-8657	Manifold-Exhaust	261-0886
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9553	Gasket Kit - Wp	393-3624
5S-0464	Gear-First Red	216-7852
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5S-4557	Bearing	311-9360

61A		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
5T-8739	Spider Gp-Brg&	373-5386
6B-6224	Ferrule	419-4738
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6K-8088	Bearing-Roller	399-4428
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-5987	Shaft-Water Pump	390-0998
6N-6015	Pump Gp-Water	453-6502
6P-0236	Guide-Lever	422-6475
6P-0549	Guard-Fdr Wear	223-4812
6P-2776	Gear-Final Drive	217-7718
6P-3593	Support	229-8231
6P-3597	Retainer	222-1770
6P-8829	Retainer	380-7407
6T-4481	Shaft-Planet	221-7946
6T-8886	Disc-Ster Cl	380-7517
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7E-5085	Bushing	377-5829
7G-2492	Gear-Planet	239-7933
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7N-0113	Core As-Oclr	388-0564
7N-2957	Cover-Rad Cap	361-1722
7N-3352	Plate-Spacer	386-3062
7N-4170	Pump Gp-Eng Oil	379-0169
7N-4407	Gasket-Rod Comp	433-9853

Sales Model 583H (Cont'd.)

61A		
Original Part Number	Part Name	Classic Part Number
7N-7091	Line As-Fuel Inj	396-9938
7N-7092	Line As-Fuel Inj	396-9937
7N-7386	Gasket-Cyl Head	392-4519
7N-7639	Rotator-Valve	383-1582
7N-9352	Gasket	433-8188
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7S-7400	Pump Gp	226-0173
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8E-7455	Gear-Planet	221-7947
8E-7456	Gear-Planet	221-7948
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-1994	Valve-Exhaust	443-1206
8H-2434	Drum-Ster Cl Dr	216-7862

61A		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8H-5026	Cover-Adj Pulley	445-7698
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8N-4810	Gasket-Cyl Head	437-2046
8N-6004	Head As-Cyl	247-3369
8N-7923	Bearing-Main	419-7275
8N-7924	Bearing-Main	419-7276
8N-7933	Bearing-Conn Rod	419-7280
8N-7934	Bearing-Conn Rod	419-6308
8P-8221	Plate-Guide	226-2748
8S-2123	Cage-Fdr Bearing	217-7726
8S-2126	Spacer-Hub Brg	222-1767
8S-3653	Bonnet-Valve	374-4728
8S-6782	Adapter-Exhaust	383-1586
8S-9686	Gasket Kit	393-5215
9F-8074	Bearing-Outer	452-3180

61A		
Original Part Number	Part Name	Classic Part Number
9H-5233	Piston-Clutch	219-9708
9H-6236	Rod As	390-0999
9M-2042	Race-Roller Brg	417-9500
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5350	Spring-Valve	380-7573
9P-3663	Carrier-Planet	213-6939
9P-6592	Gear-Planet	215-1915
9S-1026	Cage-Gear Brg	216-7873
9S-4829	Race-Brg Inner	423-9668
9S-5771	Bushing As	385-7219
9S-7148	Cap As-Rain	378-3994
9S-8217	Bolt-Spring	469-4672
9S-9696	Spider As-Fan	383-3707
9T-2200	Cartridgr Gp	422-8114
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
162-3904	Pump As-F Prm	391-1102
255-2899	Pipe As-Tail	301-5246
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
374-1849	Brg-Rlr-Cla	399-4442

Sales Model 583K

78V		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-0744	Screw-Rocker Adj	379-0167
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1M-3917	Shaft	386-4915
1M-4095	Bearing-Inner	417-9486
1M-4167	Shaft-Planet	219-9700
1M-9444	Retainer-Spring	299-2046

78V		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-3318	Strip	385-7206
1P-4145	Valve Gp-Press	247-4436
1P-6400	Plunger As-Pump	383-1568
1P-7295	Shaft-Acc Drive	431-5261
1S-1888	Bracket-Lamp	297-7147

78V		
Original Part Number	Part Name	Classic Part Number
1S-2269	Sleeve	226-2720
1S-8607	Baffle	380-7540
1T-0043	Bearing-Ball	390-5294
1T-0221	Wheel-Turbine	390-5268
1T-0224	Carrier-Ring	239-7928
1T-0231	Retainer-Bearing	319-3471
1T-0237	Flange As-Output	239-7929

Sales Model 583K (Cont'd.)

78V		
Original Part Number	Part Name	Classic Part Number
1T-0256	Gear-Pump Drive	239-7930
1T-0278	Bearing-Sleeve	394-0213
1T-0589	Cup-Roller Brg	386-4942
1T-0595	Carrier-Wheel	239-7939
1T-0610	Bearing-Ball	396-4136
1T-0611	Converter As-Tor	235-1804
1T-0633	Impeller-Conv	390-5266
1T-1389	Carrier-Bearing	247-4124
1T-1399	Impeller-Conv	391-9829
1T-1562	Wheel As-Guide	388-6580
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6421	Bearing-Outer	417-4510
2F-5721	Bearing-Ball	311-9354
2K-1386	Bearing	423-6991
2K-3632	Yoke As	297-4866
2K-5065	Cone-Roller Brg	416-2157
2K-5254	Bearing-Outer	377-7419
2L-5271	Bearing-Ball	371-4305
2M-1149	Race-Brg Outer	418-9615
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-0484	Chamber As	247-3296
2P-1126	Pulley-Cshft	264-5868
2P-1129	Pulley-Tightener	264-5869
2P-1131	Arm As-Tightener	430-8132
2P-1604	Piston-Ster Cl	219-9694
2P-1605	Pilot-Cl Piston	219-9695
2P-2656	Line As-Fuel Inj	430-9650
2P-9037	Drum-Ster Clutch	219-9696
2P-9038	Drum-Cl Driven	216-7821
2S-3913	Cage-Gear Brg	217-7722
2S-3966	Ring-Seal	297-7237
2S-4357	Pinion-Fdr	217-7706
2S-5100	Valve-Ball	386-3049

78V		
Original Part Number	Part Name	Classic Part Number
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-7917	Gear-Pump Dr	247-4119
2S-7931	Bearing-Sleeve	387-2904
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3B-8845	Bearing-Inner	417-4509
3G-2720	Cartridge Gp-Rr	448-5051
3G-2749	Cartridge Gp-Rr	422-8125
3H-0881	Ring-Piston	465-8998
3J-9325	Piston	390-0993
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3P-1687	Plate-Clutch	428-6658
3P-9394	Shaft-Planet	215-1680
3S-1262	Retainer	308-9915
3S-1404	Bearing-Outer	417-4508
3S-2252	Manifold-Exhaust	261-0887
3S-3875	Screen-Suction	435-4849
3S-6989	Nut-Spanner	219-9701
3S-7308	Cage-Pinion Brg	219-9702
3S-9669	Bearing	416-2168
3S-9919	Shaft As	239-7959
3T-3150	Guide-Frt Idler	394-0191
4B-7255	Cone-Bearing	386-4951
4F-2393	Bearing-Ball	380-1499
4F-5003	Spring As-Arm	383-2127
4H-9640	Bearing-Sleeve	386-4921
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
4N-4577	Muffler As.	308-9877
4N-4880	Pump Gp-F Tfr	256-4758
4N-5390	Pulley-Alt Drive	264-5879

78V		
Original Part Number	Part Name	Classic Part Number
4N-5572	Gasket	433-8192
4S-5367	Mount As	375-9986
4S-7793	Thrower-Cshft O	367-6085
4S-8472	Hood As-Preclnr	296-1355
4S-9782	Race & Roller As	385-3779
4S-9783	Race-Rlr Bearing	418-9589
4T-1893	Cartridge Gp	422-8110
5G-3612	Cap Gp-Protn	295-6419
5H-1719	Pump Gp-Fd Oil	226-0168
5H-7071	Director-Water	388-0555
5L-6326	Bearing-Ball	420-3222
5M-0549	Gear-Trans	215-1689
5M-2051	Bearing-Caged	380-7467
5M-3996	Gear-Ring	214-0527
5M-4427	Gear-Sun	214-0529
5M-6674	Guard-F Idler Lh	226-2736
5M-7306	Cylinder	226-2737
5M-7955	Shaft As-Planet	364-5273
5N-8501	Head As-Cyl	256-4762
5N-8657	Manifold-Exhaust	261-0886
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9552	Gasket Kt	393-3623
5P-9553	Gasket Kit - Wp	393-3624
5S-0464	Gear-First Red	216-7852
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-8739	Spider Gp-Brg&	373-5386
6B-6224	Ferrule	419-4738
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015

Sales Model 583K (Cont'd.)

78V		
Original Part Number	Part Name	Classic Part Number
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-0957	Core As-Radiator	398-2938
6N-5435	Ejector As-Exh	443-2663
6N-5437	Muffler As.	247-2674
6N-5967	Elbow	394-9825
6N-5978	Coupling-Exhaust	369-9487
6N-5987	Shaft-Water Pump	390-0998
6N-6015	Pump Gp-Water	453-6502
6N-9653	Core As-Oil Clr	386-3056
6P-0236	Guide-Lever	422-6475
6P-0549	Guard-Fdr Wear	223-4812
6P-2776	Gear-Final Drive	217-7718
6P-3593	Support	229-8231
6P-3597	Retainer	222-1770
6P-8829	Retainer	380-7407
6T-1933	Collar-Idler End	226-2746
6T-4481	Shaft-Planet	221-7946
6T-8886	Disc-Ster Cl	380-7517
6V-2202	Bearing-Spl Ball	380-1574
6V-3709	Gasket Kit	393-5223
6V-3710	Gasket Kit	447-8646
6Y-0145	Plate-Locking	419-8801
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571
7E-5085	Bushing	377-5829
7G-2492	Gear-Planet	239-7933
7H-7628	Bearing	453-3655
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816

78V		
Original Part Number	Part Name	Classic Part Number
7N-2957	Cover-Rad Cap	361-1722
7N-3349	Shaft As-Drive	394-0889
7N-3350	Gear As-Pump Dr	319-3437
7N-3352	Plate-Spacer	386-3062
7N-4170	Pump Gp-Eng Oil	379-0169
7N-4407	Gasket-Rod Comp	433-9853
7N-4618	Ejector As-Exh	397-5060
7N-7091	Line As-Fuel Inj	396-9938
7N-7092	Line As-Fuel Inj	396-9937
7N-7628	Gasket	419-1811
7N-7639	Rotator-Valve	383-1582
7N-7878	Cover-Plate	434-2401
7N-9352	Gasket	433-8188
7S-7400	Pump Gp	226-0173
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0205	Core As-Oclr	379-0183
7W-1927	Ring-Retainer	387-2935
8E-7455	Gear-Planet	221-7947
8E-7456	Gear-Planet	221-7948
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-1994	Valve-Exhaust	443-1206
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8N-4810	Gasket-Cyl Head	437-2046

78V		
Original Part Number	Part Name	Classic Part Number
8N-6004	Head As-Cyl	247-3369
8N-7923	Bearing-Main	419-7275
8N-7924	Bearing-Main	419-7276
8N-7933	Bearing-Conn Rod	419-7280
8N-7934	Bearing-Conn Rod	419-6308
8P-8221	Plate-Guide	226-2748
8S-2123	Cage-Fdr Bearing	217-7726
8S-2126	Spacer-Hub Brg	222-1767
8S-3487	Gear As-Ring	221-7949
8S-3653	Bonnet-Valve	374-4728
9G-6774	Gear-Transfer	398-8343
9H-5233	Piston-Clutch	219-9708
9H-6236	Rod As	390-0999
9M-2042	Race-Roller Brg	417-9500
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5350	Spring-Valve	380-7573
9P-3663	Carrier-Planet	213-6939
9P-6592	Gear-Planet	215-1915
9S-1026	Cage-Gear Brg	216-7873
9S-4829	Race-Brg Inner	423-9668
9S-5771	Bushing As	385-7219
9S-7148	Cap As-Rain	378-3994
9S-8217	Bolt-Spring	469-4672
9T-2200	Cartridgr Gp	422-8114
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
155-8688	Gasket Kit	434-7273
162-3904	Pump As-F Prm	391-1102
230-7117	Ster Cl Kit-Cla	219-9696
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
374-1849	Brg-Rlr-Cla	399-4442

Sales Model 583R

2XS		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1S-9209	Shaft-Tightener	374-6499
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0447	Carrier-Ring	295-0409
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1386	Yoke-Univ Joint	325-6239
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5910	Tappet As-Guide&	383-1569
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-1370	Cup-Rlr Brg	384-5921

2XS		
Original Part Number	Part Name	Classic Part Number
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-7455	Gear As	396-9957
2W-9978	Core As-Oclr	279-4983
3E-4880	Coupling As	417-9465
3E-6772	Seal-Water	382-8017
3G-4292	Bearing	425-6439
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-5929	Gear	288-8718
4D-4065	Rod End-Spher	374-1824
4M-5858	Bearing-Spl Ball	417-4495
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4S-8538	Bearing-Spl Ball	417-4502
4S-8670	Shaft-Planet	300-2590
4T-4073	Valve Gp-Shtl -B	439-1138

2XS		
Original Part Number	Part Name	Classic Part Number
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-8088	Bearing-Roller	399-4428
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-8250	Retainer	319-3473
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539

Sales Model 583R (Cont'd.)

2XS		
Original Part Number	Part Name	Classic Part Number
6V-0664	Cone-Rlr Brg	423-6990
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-5692	Plate-Brake	380-7492
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-3557	Spider As-Fan	430-4471
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7G-2830	Ring-Seal	295-6441
7G-3454	Gear-Planet	300-2578
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1275	Pulley-Fan	380-7535
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7S-4411	Cap As-Rain	373-1912

2XS		
Original Part Number	Part Name	Classic Part Number
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-1817	Cup-Roller Brg	434-3296
8F-6058	Bearing-Sleeve	416-5494
8G-4510	Plate-Clutch	383-2113
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-6511	Bearing-Sleeve	380-7372
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7038	Pin	396-0665
9J-3206	Bearing-Spher	360-2275
9L-5839	Coupling-Exhaust	374-7480
9M-3025	Cover As	299-2001
9M-4370	Bearing-Sleeve	453-6515
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718

2XS		
Original Part Number	Part Name	Classic Part Number
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7754	Housing As.	433-9856
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
118-8458	Spider As-Fan	395-1306
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
128-2922	Kit-Gasket (Wp)	386-3814

Sales Model 583R (Cont'd.)

2XS		
Original Part Number	Part Name	Classic Part Number
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
156-8208	Kit-Gasket-Trans	434-7275
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
163-4063	Core As-Rdtr	391-9826
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
184-4395	Guide	393-1042
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699

2XS		
Original Part Number	Part Name	Classic Part Number
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
191-9323	Kit-Bearing	464-9064
200-3199	Muffler As-Eject	396-1565
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-3294	Gage As-O Level	398-2930
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
234-1874	Kit-Gasket-Fs	437-8668
253-1752	Plate-Thrust	379-0170
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
321-5746	Bearing-Main	419-6367

2XS		
Original Part Number	Part Name	Classic Part Number
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	376-3636
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	384-5932

Sales Model 583T

CMX		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0679	Roller-Freewheel	384-4797
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-4738	Bearing-Sleeve	325-6020

CMX		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3E-6772	Seal-Water	382-8017
3G-4292	Bearing	425-6439
3H-1996	Bearing-Ball	380-1498

CMX		
Original Part Number	Part Name	Classic Part Number
3K-2511	Dowel-Reaction	383-2126
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5929	Gear	288-8718
4N-0685	Bearing-Sleeve	379-0191

Sales Model 583T (Cont'd.)

CMX		
Original Part Number	Part Name	Classic Part Number
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1931	Plunger	379-0171
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-2065	Mount As-650 Cup	377-5844
6Y-5812	Bearing-Sleeve	325-6019
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196

CMX		
Original Part Number	Part Name	Classic Part Number
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7M-7219	Bearing-Thrust	384-4816
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4411	Cap As-Rain	373-1912
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7W-3145	Plate	422-7894
8D-1817	Cup-Roller Brg	434-3296
8H-5352	Bearing-Ball	453-3658
8N-2104	Bell As-Suction	380-1521
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
9G-0284	Housing-Clutch	283-5214
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-3206	Bearing-Spher	360-2275
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9P-8626	Gear-Sun	283-5219
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716

CMX		
Original Part Number	Part Name	Classic Part Number
005-4834	Cone-Rlr Bearing	422-6490
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
110-8368	Bearing-Cup	416-2172
112-5585	Shaft-Planet	308-9932
116-7885	Pan-Oil (Front)	379-0173
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
157-5075	Gear-Planet	394-9821
160-9874	Kit-Gasket-Scl	386-3048
164-4413	Mount	419-0876
167-8126	Damper As	382-8019
184-4395	Guide	393-1042
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
258-0768	Bearing Sleeve	394-0201
258-2308	Bearing-Sleeve	325-6019
278-1365	Arm As-Ui Rkr	433-7507
325-6012	Brg-Cla	325-6019
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model 587R

BXL		
Original Part Number	Part Name	Classic Part Number
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-9209	Shaft-Tightener	374-6499
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0447	Carrier-Ring	295-0409
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1386	Yoke-Univ Joint	325-6239
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2S-6150	Cover-Pulley	428-8817

BXL		
Original Part Number	Part Name	Classic Part Number
2S-6196	Shaft-Pulley	438-9541
2W-7455	Gear As	396-9957
2W-9978	Core As-Oclr	279-4983
3E-4880	Coupling As	417-9465
3E-6772	Seal-Water	382-8017
3G-4292	Bearing	425-6439
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
4D-4065	Rod End-Spher	374-1824
4M-5858	Bearing-Spl Ball	417-4495
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4S-8538	Bearing-Spl Ball	417-4502
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5363	Core Gp-O Clr	380-7531

BXL		
Original Part Number	Part Name	Classic Part Number
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6K-8088	Bearing-Roller	399-4428
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844

Sales Model 587R (Cont'd.)

BXL		
Original Part Number	Part Name	Classic Part Number
6Y-5692	Plate-Brake	380-7492
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-3557	Spider As-Fan	430-4471
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7G-2830	Ring-Seal	295-6441
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1275	Pulley-Fan	380-7535
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4411	Cap As-Rain	373-1912
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-1817	Cup-Roller Brg	434-3296
8F-6058	Bearing-Sleeve	416-5494
8G-4510	Plate-Clutch	383-2113
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-7577	Plate-Locking	392-4486

BXL		
Original Part Number	Part Name	Classic Part Number
8H-8175	Bearing-Sleeve	376-3636
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-6511	Bearing-Sleeve	380-7372
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7038	Pin	396-0665
9J-3206	Bearing-Spher	360-2275
9L-5839	Coupling-Exhaust	374-7480
9M-3025	Cover As	299-2001
9M-4370	Bearing-Sleeve	453-6515
9N-1545	Race-Thrust	394-9205
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
102-8608	Manifold-Exhaust	376-9062

BXL		
Original Part Number	Part Name	Classic Part Number
104-5283	Manifold-Exhaust	394-9831
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
110-8368	Bearing-Cup	416-2172
112-5585	Shaft-Planet	308-9932
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
118-8458	Spider As-Fan	395-1306
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-8412	Piston-Clutch	394-0910
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
157-5075	Gear-Planet	394-9821
160-9874	Kit-Gasket-Scl	386-3048
163-4063	Core As-Rdtr	391-9826
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
184-4395	Guide	393-1042
185-2831	Line As	380-1516
190-3832	Core As-Oclr	438-3251
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699

Sales Model 587R (Cont'd.)

BXL		
Original Part Number	**Part Name**	**Classic Part Number**
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
200-3199	Muffler As-Eject	396-1565
202-3572	Shaft As-Drive	426-0037

BXL		
Original Part Number	**Part Name**	**Classic Part Number**
211-0592	Bearing - Main	419-6368
213-3294	Gage As-O Level	398-2930
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
321-5746	Bearing-Main	419-6367

BXL		
Original Part Number	**Part Name**	**Classic Part Number**
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812

Sales Model 587T

FAT		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4106	Pin As-Drawbar	325-6126
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0447	Carrier-Ring	295-0409
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1386	Yoke-Univ Joint	325-6239
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1W-4738	Bearing-Sleeve	325-6020

FAT		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4746	Retainer-Gear	295-5690
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
3E-4880	Coupling As	417-9465
3E-6772	Seal-Water	382-8017
3G-4292	Bearing	425-6439
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
4M-5858	Bearing-Spl Ball	417-4495
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4S-8538	Bearing-Spl Ball	417-4502
4W-5698	Bearing-Main	419-6323

FAT		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1931	Plunger	379-0171
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-5692	Plate-Brake	380-7492
6Y-5812	Bearing-Sleeve	325-6019

Sales Model 587T (Cont'd.)

FAT		
Original Part Number	**Part Name**	**Classic Part Number**
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7G-2830	Ring-Seal	295-6441
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7W-3145	Plate	422-7894
8D-1817	Cup-Roller Brg	434-3296
8G-4510	Plate-Clutch	383-2113
8H-5352	Bearing-Ball	453-3658
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-6511	Bearing-Sleeve	380-7372
9G-0284	Housing-Clutch	283-5214
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217

FAT		
Original Part Number	**Part Name**	**Classic Part Number**
9G-6744	Bearing-Sleeve	418-1931
9G-7038	Pin	396-0665
9J-3206	Bearing-Spher	360-2275
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-8626	Gear-Sun	283-5219
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-7930	Bearing As	377-7463
110-8368	Bearing-Cup	416-2172
112-5585	Shaft-Planet	308-9932
116-7885	Pan-Oil (Front)	379-0173
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813

FAT		
Original Part Number	**Part Name**	**Classic Part Number**
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
157-5075	Gear-Planet	394-9821
160-9874	Kit-Gasket-Scl	386-3048
164-4413	Mount	419-0876
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
184-4395	Guide	393-1042
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
278-1365	Arm As-Ui Rkr	433-7507
325-6012	Brg-Cla	325-6019
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model 589

31Z		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-5675	Bearing	377-7396
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401

31Z		
Original Part Number	**Part Name**	**Classic Part Number**
1S-9110	Bearing-Needle	420-2497
1S-9209	Shaft-Tightener	374-6499
1T-0043	Bearing-Ball	390-5294
1T-0278	Bearing-Sleeve	394-0213
1T-0610	Bearing-Ball	396-4136
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704

31Z		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354

Sales Model 589 (Cont'd.)

31Z		
Original Part Number	Part Name	Classic Part Number
2J-1227	Retainer	440-0850
2K-5103	Cone-Roller Brg	380-7505
2K-5254	Bearing-Outer	377-7419
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2N-5842	Screw-Bridge Adj	418-1934
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-3391	Body As-F Inj V	383-3687
2W-4087	Gear As-Idler	418-9582
2W-6965	Coupling	416-5490
2W-6967	Elbow As	420-6385
2W-7610	Gear-Hyd Pump Dr	418-1940
2W-7614	Gear-Crankshaft	425-7752
2W-7980	Camshaft As	378-3972
2W-8038	Gear-Camshaft	425-7751
2W-9978	Core As-Oclr	279-4983
3D-9133	Cup-Roller Brg	418-9601
3E-4880	Coupling As	417-9465
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3P-2685	Piston-Clutch	308-9908
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3245	Shaft-Planet	308-9924
3P-3738	Housing As	385-7196
3P-7489	Plate-Clutch	377-7423
3P-8845	Bearing-Inner	416-5491
3R-8530	Boss	425-3454
3S-3875	Screen-Suction	435-4849
3S-9669	Bearing	416-2168
3T-0300	Pump Gp-Gr 2Bsc	421-1557
3T-2139	Housing As-Cl	394-2583

31Z		
Original Part Number	Part Name	Classic Part Number
3T-5355	Flange	386-3052
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4M-5858	Bearing-Spl Ball	417-4495
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1186	Bearing-Sleeve	417-4519
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4S-8670	Shaft-Planet	300-2590
4T-4073	Valve Gp-Shtl -B	439-1138
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975

31Z		
Original Part Number	Part Name	Classic Part Number
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-8485	Muffler As	430-4472
5F-7404	Nut-Bearing Lock	308-9878
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-1370	Bearing As-Rlr	416-2164
5P-6254	Bearing	420-2495
5P-7802	Bearing-Aligning	420-2496
5P-7807	Bearing-Ball	314-8502
5P-8876	Cup-Rlr Bearing	416-2170
5P-9301	Bearing-Spl Ball	417-4496
5P-9505	Cone-Roller Brg	420-6540
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1032	Line As-Fuel Inj	390-0931
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922

Sales Model 589 (Cont'd.)

31Z		
Original Part Number	Part Name	Classic Part Number
6I-1038	Line As-Fuel Inj	390-0923
6I-4613	Plate-Spacer	380-7405
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0977	Bearing-Sleeve	417-4524
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-0593	Bearing-Roller	386-4959
6P-3904	Retainer-Bearing	396-0644
6P-5404	Plate-Cl & Brake	325-6168
6P-6739	Shaft-Planet	308-9929
6P-7564	Carrier-Ring	384-3850
6P-8340	Sleeve	422-7895
6P-8829	Retainer	380-7407
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-1261	Insert	418-1937
6T-3726	Carrier As	390-5269
6T-9564	Guide As	416-5530
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
6Y-0210	Bearing-Sleeve	453-6506
6Y-2878	Retainer	424-0740
6Y-3484	Bearing-Spl Ball	416-2166

31Z		
Original Part Number	Part Name	Classic Part Number
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5287	Elbow As-Ex	430-4470
7E-5996	Rod As-Conn	379-8864
7G-2262	Pump Gp-Gr 2 Bsc	421-1552
7G-2476	Gear-Planet	223-4816
7G-3454	Gear-Planet	300-2578
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7G-5749	Piston-Clutch	416-2132
7G-6059	Carrier-Ring	393-0911
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7H-7628	Bearing	453-3655
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1275	Pulley-Fan	380-7535
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2957	Cover-Rad Cap	361-1722
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-5003	Cap As-Rain	379-0184
7S-7809	Cap As-Radiator	295-6417
7T-1776	Slide	396-0659
7T-2036	Cap As-Fuel	361-1721
7T-4053	Shaft As-Output	398-2940
7T-8336	Hub	418-9580
7T-8337	Shaft	416-2138
7W-0182	Plunger & Bbl As	391-9893
7W-0205	Core As-Oclr	379-0183

31Z		
Original Part Number	Part Name	Classic Part Number
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5524	Ejector As-Exh	397-5056
8C-0580	Gasket Kit - T	393-1023
8D-1817	Cup-Roller Brg	434-3296
8E-5001	Shaft As.	434-2400
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-0935	Gear-Pump Drive	399-8569
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3304	Pulley-Tightener	419-4708
8N-4550	Shaft-Pulley	445-9247
8N-7257	Mount As	396-0660
8N-8983	Hub-Fan Pulley	421-7227
8P-4047	Shaft-Planet	373-5390
8P-5229	Carrier-Stator	395-1309
8P-6083	Yoke-U Joint	446-3073

Sales Model 589 (Cont'd.)

31Z		
Original Part Number	Part Name	Classic Part Number
8P-7788	Retainer-Cl Pstn	417-9476
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
8T-2500	Kit-Gasket	393-1028
9G-1499	Gear-Pump (Oil)	295-6424
9G-1919	Gear-Planet	371-4307
9J-2290	Pin As	423-3538
9K-8757	Rod End-Special	311-9361
9M-1990	Dowel-Reaction	386-4963
9M-3025	Cover As	299-2001
9M-4370	Bearing-Sleeve	453-6515
9N-1161	Line As-Fuel Inj	383-3705
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9P-3757	Gear	394-9196
9P-3758	Gear-Planet	419-8805
9P-3803	Carrier-Planet	468-5013
9S-5279	Bearing-Inner	453-3661
9W-2344	Coupling-Pump Dr	314-8666
9W-2977	Hub As	423-6985
9W-5768	Gear-Ring	380-7474
9W-5936	Hub	430-7617
9W-6099	Piston-Clutch	391-9828
9W-7458	Piston-Clutch	391-9862
9W-7919	Bearing-Sleeve	425-3647
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482

31Z		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
104-3133	Carrier-Planet	435-2897
106-7098	Flange Assm	390-5271
106-7099	Carrier-Planet	388-6585
106-7798	Bearing-Ball	417-9494
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-2665	Shaft-Planet	391-9871
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0023	Kit-Bearing-Tc	464-9061
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504

31Z		
Original Part Number	Part Name	Classic Part Number
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
147-1007	Kit-Dt Gasket	388-6587
155-6057	Kit-Gasket-Trans	388-6588
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
165-5634	Shaft As.-Output	421-7067
166-6930	Cone-Spl Tapered	399-4443
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
221-9356	Flywheel As	435-2575
232-2672	Kit-Gasket-Fs	393-0922
233-8681	Kit-Gasket-Mch	393-0920
233-9748	Disc-Friction	417-9502
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

Sales Model 594

62H		
Original Part Number	**Part Name**	**Classic Part Number**
0R-5013	Plate-Clutch	388-0586
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1M-3917	Shaft	386-4915
1M-4095	Bearing-Inner	417-9486
1M-4167	Shaft-Planet	219-9700
1N-4317	Bearing-Main	419-7253
1N-4336	Bearing-Conn Rod	419-6329
1N-4337	Bearing-Conn Rod	419-6328
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-4145	Valve Gp-Press	247-4436
1S-1888	Bracket-Lamp	297-7147
1S-7056	Bearing-Ball	422-6483
1S-8607	Baffle	380-7540
1S-8754	Joint Gp-Univ	308-9873
1S-9209	Shaft-Tightener	374-6499
1T-0043	Bearing-Ball	390-5294
1T-0221	Wheel-Turbine	390-5268
1T-0224	Carrier-Ring	239-7928
1T-0231	Retainer-Bearing	319-3471
1T-0237	Flange As-Output	239-7929
1T-0256	Gear-Pump Drive	239-7930
1T-0278	Bearing-Sleeve	394-0213
1T-0589	Cup-Roller Brg	386-4942
1T-0595	Carrier-Wheel	239-7939
1T-0610	Bearing-Ball	396-4136
1T-0611	Converter As-Tor	235-1804
1T-1389	Carrier-Bearing	247-4124
1T-1399	Impeller-Conv	391-9829
1T-1562	Wheel As-Guide	388-6580

62H		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1822	Valve-Exhaust	443-1205
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp-Piston	311-9446
1W-6440	Gasket-Cyl Head	449-9548
1W-8606	Valve-Inlet	443-1204
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-2330	Bearing-Sleeve	452-9554
2H-3069	Lifter As-Valve	387-2927
2K-0227	Bearing-Sleeve	384-4780
2K-1386	Bearing	423-6991
2K-3632	Yoke As	297-4866
2K-5065	Cone-Roller Brg	416-2157
2K-5254	Bearing-Outer	377-7419
2L-5271	Bearing-Ball	371-4305
2M-1149	Race-Brg Outer	418-9615
2M-6960	Cage-Gear Brg	239-7971
2M-6984	Drum-Cl Driven	239-7946
2M-8340	Rod End-Yoke	374-4678
2M-8714	Cone-Roller Brg	420-2492
2M-8912	Disc-Ster Cl Dr	393-3649
2S-2430	Thrower-Chsft O	380-7543
2S-3966	Ring-Seal	297-7237
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-7264	Pump As-Fuel Inj	395-1318
2S-7873	Pump Gp	226-0162
2S-7917	Gear-Pump Dr	247-4119
2S-7931	Bearing-Sleeve	387-2904
2S-8961	Pulley-Tightener	264-5875
3B-1142	Retainer-Spring	391-1099
3B-8845	Bearing-Inner	417-4509
3H-5867	Retainer-Spring	390-0992

62H		
Original Part Number	**Part Name**	**Classic Part Number**
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3P-1686	Plate-Clutch	388-0586
3P-1687	Plate-Clutch	428-6658
3P-9394	Shaft-Planet	215-1680
3S-1262	Retainer	308-9915
3S-1404	Bearing-Outer	417-4508
3S-3875	Screen-Suction	435-4849
3S-9919	Shaft As	239-7959
4F-2393	Bearing-Ball	380-1499
4F-5003	Spring As-Arm	383-2127
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1001	Pump Gp-Fd Oil	226-0166
4M-3915	Bearing-Caged	377-7427
4M-4431	Shaft-Pump Dr	390-0994
4M-5858	Bearing-Spl Ball	417-4495
4M-9214	Shaft-Pump Drive	314-8543
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4N-3664	Guide-Valve	314-8524
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4W-0419	Core As-Oclr	379-0182
5F-2465	Cup-Roller Brg	447-8060
5G-3612	Cap Gp-Protn	295-6419
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5K-2294	Bearing	396-9912
5L-6326	Bearing-Ball	420-3222
5M-0549	Gear-Trans	215-1689
5M-2051	Bearing-Caged	380-7467
5M-3996	Gear-Ring	214-0527
5M-4427	Gear-Sun	214-0529
5M-7701	Cylinder	385-7229
5M-7955	Shaft As-Planet	364-5273
5N-8879	Manifold-Exhaust	261-0898

Sales Model 594 (Cont'd.)

62H		
Original Part Number	Part Name	Classic Part Number
5N-9055	Manifold-Exhaust	261-0890
5P-7807	Bearing-Ball	314-8502
5P-8970	Gasket Kt-Liner	383-1576
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1757	Insert-Seat	311-9401
5S-9080	Pulley-Alt Drive	264-5883
5T-8739	Spider Gp-Brg&	373-5386
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6H-5843	Thrower-Chsft O	393-3612
6H-5845	Baffle-Oil	390-0926
6L-7816	Seal-O-Ring	314-8542
6N-1813	Pump Gp-Bft 1 Gr	330-9279
6N-6969	Chamber As	247-3299
6N-7295	Manifold-Exhaust	261-0903
6N-8645	Ejector As	388-0560
6N-9654	Core As-Oil Clr	435-4787
6P-0236	Guide-Lever	422-6475
6P-8829	Retainer	380-7407
6T-4481	Shaft-Planet	221-7946
6V-1395	Gasket Kt-Vg	438-0173
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
7G-2492	Gear-Planet	239-7933
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4603	Body-Fuel Valve	311-9348

62H		
Original Part Number	Part Name	Classic Part Number
7M-4926	Retainer-Piston	314-8538
7M-5334	Cone-Roller Brg	420-2505
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-7628	Gasket	419-1811
7N-7639	Rotator-Valve	383-1582
7N-7878	Cover-Plate	434-2401
7N-9647	Muffler As	386-3050
7N-9810	Pin-Piston	311-9432
7S-3206	Seal-O-Ring	436-2656
7S-5003	Cap As-Rain	379-0184
7S-5787	Chamber As	247-3300
7S-7400	Pump Gp	226-0173
7S-7809	Cap As-Radiator	295-6417
7S-7975	Guard-Fd Wear	239-7966
7T-2036	Cap As-Fuel	361-1721
7W-6459	Core As-Oclr	395-1313
8E-7455	Gear-Planet	221-7947
8E-7456	Gear-Planet	221-7948
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8N-1300	Bushing As-Spt	394-0193

62H		
Original Part Number	Part Name	Classic Part Number
8N-2275	Bearing-Sleeve	311-9365
8N-3451	Line As-Fuel Inj	390-0927
8N-3452	Line As-Fuel Inj	390-0928
8N-3453	Line As-Fuel Inj	390-0940
8N-3454	Line As-Fuel Inj	390-0930
8N-3455	Line As-Fuel Inj	390-0920
8N-3723	Valve-Exhaust	311-9472
8P-7396	Hub-Planet Gear	239-7967
8S-3487	Gear As-Ring	221-7949
8S-3617	Chamber As	247-3302
8S-5438	Muffler As	360-7896
8S-9686	Gasket Kit	393-5215
9G-7993	Cage-Gr Brg Rh	239-7973
9H-5233	Piston-Clutch	219-9708
9L-5839	Coupling-Exhaust	374-7480
9M-2042	Race-Roller Brg	417-9500
9M-3025	Cover As	299-2001
9M-5350	Spring-Valve	380-7573
9P-3663	Carrier-Planet	213-6939
9P-6592	Gear-Planet	215-1915
9S-5279	Bearing-Inner	453-3661
9S-9696	Spider As-Fan	383-3707
9T-2200	Cartridgr Gp	422-8114
9V-7710	Univ Joint As	394-8234
102-1561	Lifter As-Valve	311-9402
132-6597	Cone-Spl	422-6477
141-4109	Core As-Oclr	416-5518
155-8690	Gasket Kit	434-7274
308-1845	Seal-Wiper	472-8032

Sales Model 594H

96V		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586

Sales Model 594H (Cont'd.)

96V		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-9252	Rod End-Yoke	377-5849
1M-3917	Shaft	386-4915
1M-4095	Bearing-Inner	417-9486
1M-4167	Shaft-Planet	219-9700
1N-4317	Bearing-Main	419-7253
1N-4336	Bearing-Conn Rod	419-6329
1N-4337	Bearing-Conn Rod	419-6328
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-4145	Valve Gp-Press	247-4436
1S-1888	Bracket-Lamp	297-7147
1S-8607	Baffle	380-7540
1S-8754	Joint Gp-Univ	308-9873
1S-9209	Shaft-Tightener	374-6499
1T-0043	Bearing-Ball	390-5294
1T-0221	Wheel-Turbine	390-5268
1T-0224	Carrier-Ring	239-7928
1T-0231	Retainer-Bearing	319-3471
1T-0237	Flange As-Output	239-7929
1T-0256	Gear-Pump Drive	239-7930
1T-0278	Bearing-Sleeve	394-0213
1T-0589	Cup-Roller Brg	386-4942
1T-0595	Carrier-Wheel	239-7939
1T-0610	Bearing-Ball	396-4136
1T-0611	Converter As-Tor	235-1804
1T-1389	Carrier-Bearing	247-4124
1T-1399	Impeller-Conv	391-9829
1T-1562	Wheel As-Guide	388-6580
1W-1822	Valve-Exhaust	443-1205
1W-3062	Retainer As	311-9445
1W-6440	Gasket-Cyl Head	449-9548
1W-8606	Valve-Inlet	443-1204

96V		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-2330	Bearing-Sleeve	452-9554
2H-3069	Lifter As-Valve	387-2927
2K-0227	Bearing-Sleeve	384-4780
2K-1386	Bearing	423-6991
2K-3632	Yoke As	297-4866
2K-5065	Cone-Roller Brg	416-2157
2K-5254	Bearing-Outer	377-7419
2L-5271	Bearing-Ball	371-4305
2M-1149	Race-Brg Outer	418-9615
2M-6960	Cage-Gear Brg	239-7971
2M-6984	Drum-Cl Driven	239-7946
2M-8340	Rod End-Yoke	374-4678
2M-8714	Cone-Roller Brg	420-2492
2M-8912	Disc-Ster Cl Dr	393-3649
2S-2430	Thrower-Chsft O	380-7543
2S-3966	Ring-Seal	297-7237
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-7264	Pump As-Fuel Inj	395-1318
2S-7917	Gear-Pump Dr	247-4119
2S-7931	Bearing-Sleeve	387-2904
2S-8961	Pulley-Tightener	264-5875
3B-1142	Retainer-Spring	391-1099
3B-8845	Bearing-Inner	417-4509
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3K-4290	Rod End	374-1823
3P-1686	Plate-Clutch	388-0586
3P-1687	Plate-Clutch	428-6658
3P-9394	Shaft-Planet	215-1680
3S-1262	Retainer	308-9915

96V		
Original Part Number	Part Name	Classic Part Number
3S-1404	Bearing-Outer	417-4508
3S-3875	Screen-Suction	435-4849
3S-9919	Shaft As	239-7959
4F-2393	Bearing-Ball	380-1499
4F-5003	Spring As-Arm	383-2127
4M-1001	Pump Gp-Fd Oil	226-0166
4M-3915	Bearing-Caged	377-7427
4M-4431	Shaft-Pump Dr	390-0994
4M-5858	Bearing-Spl Ball	417-4495
4M-9214	Shaft-Pump Drive	314-8543
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4N-3664	Guide-Valve	314-8524
4N-5184	Muffler As	360-7874
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4W-0419	Core As-Oclr	379-0182
5F-2465	Cup-Roller Brg	447-8060
5G-3612	Cap Gp-Protn	295-6419
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5K-2294	Bearing	396-9912
5L-6326	Bearing-Ball	420-3222
5M-0549	Gear-Trans	215-1689
5M-2051	Bearing-Caged	380-7467
5M-3996	Gear-Ring	214-0527
5M-4427	Gear-Sun	214-0529
5M-7701	Cylinder	385-7229
5M-7955	Shaft As-Planet	364-5273
5N-8879	Manifold-Exhaust	261-0898
5N-9055	Manifold-Exhaust	261-0890
5P-7807	Bearing-Ball	314-8502
5P-8950	Gasket Kit	393-3621
5P-8970	Gasket Kt-Liner	383-1576
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665

Sales Model 594H (Cont'd.)

96V		
Original Part Number	Part Name	Classic Part Number
5S-1757	Insert-Seat	311-9401
5S-9080	Pulley-Alt Drive	264-5883
5T-8739	Spider Gp-Brg&	373-5386
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6H-5843	Thrower-Chsft O	393-3612
6H-5845	Baffle-Oil	390-0926
6L-7816	Seal-O-Ring	314-8542
6N-1813	Pump Gp-Bft 1 Gr	330-9279
6N-6969	Chamber As	247-3299
6N-7295	Manifold-Exhaust	261-0903
6N-8645	Ejector As	388-0560
6N-9654	Core As-Oil Clr	435-4787
6P-0236	Guide-Lever	422-6475
6P-8829	Retainer	380-7407
6T-1935	Guide-Frt Idler	440-3257
6T-4481	Shaft-Planet	221-7946
6V-1395	Gasket Kt-Vg	438-0173
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
7G-2492	Gear-Planet	239-7933
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538

96V		
Original Part Number	Part Name	Classic Part Number
7M-5334	Cone-Roller Brg	420-2505
7M-7219	Bearing-Thrust	384-4816
7M-7817	Valve-Inlet	311-9474
7N-2957	Cover-Rad Cap	361-1722
7N-7628	Gasket	419-1811
7N-7639	Rotator-Valve	383-1582
7N-7878	Cover-Plate	434-2401
7N-9647	Muffler As	386-3050
7N-9810	Pin-Piston	311-9432
7S-5003	Cap As-Rain	379-0184
7S-5787	Chamber As	247-3300
7S-7400	Pump Gp	226-0173
7S-7809	Cap As-Radiator	295-6417
7S-7975	Guard-Fd Wear	239-7966
7T-2036	Cap As-Fuel	361-1721
8E-7455	Gear-Planet	221-7947
8E-7456	Gear-Planet	221-7948
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8898	Pin	385-3801
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8N-1300	Bushing As-Spt	394-0193
8N-2275	Bearing-Sleeve	311-9365
8N-3451	Line As-Fuel Inj	390-0927
8N-3452	Line As-Fuel Inj	390-0928

96V		
Original Part Number	Part Name	Classic Part Number
8N-3453	Line As-Fuel Inj	390-0940
8N-3454	Line As-Fuel Inj	390-0930
8N-3455	Line As-Fuel Inj	390-0920
8N-3723	Valve-Exhaust	311-9472
8P-7396	Hub-Planet Gear	239-7967
8S-3617	Chamber As	247-3302
9G-7993	Cage-Gr Brg Rh	239-7973
9H-5233	Piston-Clutch	219-9708
9L-5839	Coupling-Exhaust	374-7480
9M-2042	Race-Roller Brg	417-9500
9M-3025	Cover As	299-2001
9M-5350	Spring-Valve	380-7573
9P-3663	Carrier-Planet	213-6939
9P-6592	Gear-Planet	215-1915
9S-5279	Bearing-Inner	453-3661
9T-2200	Cartridgr Gp	422-8114
9V-7710	Univ Joint As	394-8234
102-1561	Lifter As-Valve	311-9402
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
127-6974	Gasket Kit	393-3638
132-6597	Cone-Spl	422-6477
141-4109	Core As-Oclr	416-5518
155-8690	Gasket Kit	434-7274
308-1845	Seal-Wiper	472-8032

Sales Model MD6

39C		
Original Part Number	Part Name	Classic Part Number
2H-3712	Bearing-Ball	392-4488

39C		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
8B-5972	Bearing-Ball	314-8503

Pipelayers

Sales Model MD7

40C		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
2H-3712	Bearing-Ball	392-4488
3L-1425	Bearing-Ball	311-9356

40C		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
289-2935	Seal As-Buffer	472-8028

40C		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model MD8

41C		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
2H-3712	Bearing-Ball	392-4488
3L-1425	Bearing-Ball	311-9356

41C		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
289-2935	Seal As-Buffer	472-8028

41C		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model MDW8

42C		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
2H-3712	Bearing-Ball	392-4488
3L-1425	Bearing-Ball	311-9356

42C		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
289-2935	Seal As-Buffer	472-8028

42C		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model PD4

38C		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305

38C		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
8H-9789	Bearing-Ball	374-8342

Sales Model PL61

WGS		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443

WGS		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2H-6489	Race-Brg Outer	374-8350

WGS		
Original Part Number	Part Name	Classic Part Number
3G-8932	Pin	325-6143
3W-5159	Plate-Parking Bk	391-9904

Sales Model PL61 (Cont'd.)

WGS		
Original Part Number	Part Name	Classic Part Number
4T-0231	Retainer	376-3641
5K-7995	Bearing-Sleeve	308-9820
6V-0327	Cup-Rlr Brg	399-4444

WGS		
Original Part Number	Part Name	Classic Part Number
6V-0328	Cone-Rlr Brg	399-4442
7J-9682	Bearing-Sleeve	360-2335
7P-7858	Bearing-Sleeve	374-8362

WGS		
Original Part Number	Part Name	Classic Part Number
9M-1328	Bearing-Aligning	325-6018
9W-9930	Mount As	295-6437
170-8714	Disc-Friction	456-9193

Sales Model PL72

P72		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3G-8932	Pin	325-6143
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701

P72		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4T-0231	Retainer	376-3641
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205

P72		
Original Part Number	Part Name	Classic Part Number
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7M-1296	Valve-Relief	390-0990
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8T-0072	Cone-Rlr Brg	377-7448
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-3206	Bearing-Spher	360-2275
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-8663	Spacer	422-9521
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

Sales Model PL72 (Cont'd.)

P72		
Original Part Number	**Part Name**	**Classic Part Number**
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716

P72		
Original Part Number	**Part Name**	**Classic Part Number**
005-4834	Cone-Rlr Bearing	422-6490
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
161-3411	Gasket	394-0896
258-2303	Bearing-Sleeve	307-1524

P72		
Original Part Number	**Part Name**	**Classic Part Number**
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

P73		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3G-8932	Pin	325-6143
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
4N-2514	Gear-Flywheel	421-7283

P73		
Original Part Number	**Part Name**	**Classic Part Number**
4T-0231	Retainer	376-3641
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068

P73		
Original Part Number	**Part Name**	**Classic Part Number**
7H-7628	Bearing	453-3655
7M-1296	Valve-Relief	390-0990
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8T-0072	Cone-Rlr Brg	377-7448
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-3206	Bearing-Spher	360-2275
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-8663	Spacer	422-9521
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554

Sales Model PL72 (Cont'd.)

P73		
Original Part Number	Part Name	Classic Part Number
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490

P73		
Original Part Number	Part Name	Classic Part Number
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
161-3411	Gasket	394-0896
258-2303	Bearing-Sleeve	307-1524

P73		
Original Part Number	Part Name	Classic Part Number
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model PL83

CB2		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3G-4292	Bearing	425-6439
3G-8932	Pin	325-6143
3H-1996	Bearing-Ball	380-1498
3K-2511	Dowel-Reaction	383-2126
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4T-0231	Retainer	376-3641
4W-5698	Bearing-Main	419-6323

CB2		
Original Part Number	Part Name	Classic Part Number
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
6I-8500	Plate-Clutch	377-7436
6N-1931	Plunger	379-0171
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-2065	Mount As-650 Cup	377-5844
6Y-4819	Carrier-Planet	296-1348
7C-0307	Gasket	399-8571
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7H-4566	Cup-Roller Brg	399-6068

CB2		
Original Part Number	Part Name	Classic Part Number
7H-7628	Bearing	453-3655
7N-2156	Bearing-Sleeve	380-7373
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7038	Pin	396-0665
9J-3206	Bearing-Spher	360-2275
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-8663	Spacer	422-9521
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463

Sales Model PL83 (Cont'd.)

CB2		
Original Part Number	**Part Name**	**Classic Part Number**
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
116-7885	Pan-Oil (Front)	379-0173
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813

CB2		
Original Part Number	**Part Name**	**Classic Part Number**
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
157-5075	Gear-Planet	394-9821
160-9874	Kit-Gasket-Scl	386-3048
184-4395	Guide	393-1042
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368

CB2		
Original Part Number	**Part Name**	**Classic Part Number**
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

DLW		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4106	Pin As-Drawbar	325-6126
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3G-4292	Bearing	425-6439
3G-8932	Pin	325-6143
3H-1996	Bearing-Ball	380-1498
3K-2511	Dowel-Reaction	383-2126
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700

DLW		
Original Part Number	**Part Name**	**Classic Part Number**
3T-5200	Carrier-Planet	295-5701
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4T-0231	Retainer	376-3641
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
6I-8500	Plate-Clutch	377-7436
6N-1931	Plunger	379-0171
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442

DLW		
Original Part Number	**Part Name**	**Classic Part Number**
6T-7882	Gear-Planet	296-1352
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-2065	Mount As-650 Cup	377-5844
6Y-4819	Carrier-Planet	296-1348
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-3145	Plate	422-7894
8D-1817	Cup-Roller Brg	434-3296
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209

Sales Model PL83 (Cont'd.)

DLW		
Original Part Number	Part Name	Classic Part Number
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7038	Pin	396-0665
9J-3206	Bearing-Spher	360-2275
9M-1853	Mount As.	376-3638
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-8663	Spacer	422-9521
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490

DLW		
Original Part Number	Part Name	Classic Part Number
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
116-7885	Pan-Oil (Front)	379-0173
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599

DLW		
Original Part Number	Part Name	Classic Part Number
157-5075	Gear-Planet	394-9821
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
184-4395	Guide	393-1042
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

KSD		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-4738	Bearing-Sleeve	325-6020
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480

KSD		
Original Part Number	Part Name	Classic Part Number
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3E-6772	Seal-Water	382-8017
3G-4292	Bearing	425-6439
3G-8932	Pin	325-6143
3H-1996	Bearing-Ball	380-1498
3K-2511	Dowel-Reaction	383-2126
3S-3875	Screen-Suction	435-4849
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271

KSD		
Original Part Number	Part Name	Classic Part Number
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4T-0231	Retainer	376-3641
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917

Sales Model PL83 (Cont'd.)

KSD		
Original Part Number	Part Name	Classic Part Number
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6N-1931	Plunger	379-0171
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-2065	Mount As-650 Cup	377-5844
6Y-4819	Carrier-Planet	296-1348
6Y-5812	Bearing-Sleeve	325-6019
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7M-7219	Bearing-Thrust	384-4816
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354

KSD		
Original Part Number	Part Name	Classic Part Number
7T-9370	Gear-Sun	283-5207
7W-3145	Plate	422-7894
8D-1817	Cup-Roller Brg	434-3296
8H-5352	Bearing-Ball	453-3658
8N-2104	Bell As-Suction	380-1521
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-3206	Bearing-Spher	360-2275
9M-1853	Mount As.	376-3638
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
116-7885	Pan-Oil (Front)	379-0173
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814

KSD		
Original Part Number	Part Name	Classic Part Number
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
157-5075	Gear-Planet	394-9821
160-9874	Kit-Gasket-Scl	386-3048
164-4413	Mount	419-0876
167-8126	Damper As	382-8019
184-4395	Guide	393-1042
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
258-0768	Bearing Sleeve	394-0201
258-2308	Bearing-Sleeve	325-6019
278-1365	Arm As-Ui Rkr	433-7507
325-6012	Brg-Cla	325-6019
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model PL87

KKJ		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126

Sales Model PL87 (Cont'd.)

KKJ		
Original Part Number	Part Name	Classic Part Number
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
3E-4880	Coupling As	417-9465
3E-6772	Seal-Water	382-8017
3G-4292	Bearing	425-6439
3G-8932	Pin	325-6143
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
4M-5858	Bearing-Spl Ball	417-4495
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641

KKJ		
Original Part Number	Part Name	Classic Part Number
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6N-1931	Plunger	379-0171
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-5692	Plate-Brake	380-7492
6Y-5812	Bearing-Sleeve	325-6019
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7G-2830	Ring-Seal	295-6441
7H-7628	Bearing	453-3655
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7W-3145	Plate	422-7894
8D-1817	Cup-Roller Brg	434-3296
8G-4510	Plate-Clutch	383-2113
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

KKJ		
Original Part Number	Part Name	Classic Part Number
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7038	Pin	396-0665
9J-3206	Bearing-Spher	360-2275
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-8626	Gear-Sun	283-5219
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
101-3125	Gasket	420-8567
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-7930	Bearing As	377-7463
112-5585	Shaft-Planet	308-9932
116-7885	Pan-Oil (Front)	379-0173
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
157-5075	Gear-Planet	394-9821
160-9874	Kit-Gasket-Scl	386-3048
164-4413	Mount	419-0876
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
184-4395	Guide	393-1042
186-2001	Rotocoil As	397-5055

Sales Model PL87 (Cont'd.)

KKJ		
Original Part Number	Part Name	Classic Part Number
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508

KKJ		
Original Part Number	Part Name	Classic Part Number
253-1752	Plate-Thrust	379-0170
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
278-1365	Arm As-Ui Rkr	433-7507

KKJ		
Original Part Number	Part Name	Classic Part Number
325-6012	Brg-Cla	325-6019
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

TEC		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0679	Roller-Freewheel	384-4797
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3G-4292	Bearing	425-6439
3G-8932	Pin	325-6143
3H-1996	Bearing-Ball	380-1498
3K-2511	Dowel-Reaction	383-2126
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4T-0231	Retainer	376-3641
4W-5698	Bearing-Main	419-6323

TEC		
Original Part Number	Part Name	Classic Part Number
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1931	Plunger	379-0171
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-2065	Mount As-650 Cup	377-5844
6Y-4819	Carrier-Planet	296-1348
7C-0307	Gasket	399-8571
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7H-4566	Cup-Roller Brg	399-6068

TEC		
Original Part Number	Part Name	Classic Part Number
7H-7628	Bearing	453-3655
7N-2156	Bearing-Sleeve	380-7373
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7038	Pin	396-0665
9J-3206	Bearing-Spher	360-2275
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-8663	Spacer	422-9521
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681

Sales Model PL87 (Cont'd.)

TEC		
Original Part Number	**Part Name**	**Classic Part Number**
116-7885	Pan-Oil (Front)	379-0173
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813

TEC		
Original Part Number	**Part Name**	**Classic Part Number**
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
157-5075	Gear-Planet	394-9821
160-9874	Kit-Gasket-Scl	386-3048
184-4395	Guide	393-1042
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368

TEC		
Original Part Number	**Part Name**	**Classic Part Number**
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

ZAC		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4106	Pin As-Drawbar	325-6126
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0679	Roller-Freewheel	384-4797
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3G-4292	Bearing	425-6439
3G-8932	Pin	325-6143
3H-1996	Bearing-Ball	380-1498
3K-2511	Dowel-Reaction	383-2126
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700

ZAC		
Original Part Number	**Part Name**	**Classic Part Number**
3T-5200	Carrier-Planet	295-5701
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4T-0231	Retainer	376-3641
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1931	Plunger	379-0171
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932

ZAC		
Original Part Number	**Part Name**	**Classic Part Number**
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-2065	Mount As-650 Cup	377-5844
6Y-4819	Carrier-Planet	296-1348
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-3145	Plate	422-7894
8D-1817	Cup-Roller Brg	434-3296
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209

Sales Model PL87 (Cont'd.)

ZAC		
Original Part Number	Part Name	Classic Part Number
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7038	Pin	396-0665
9J-3206	Bearing-Spher	360-2275
9M-1853	Mount As.	376-3638
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-8663	Spacer	422-9521
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490

ZAC		
Original Part Number	Part Name	Classic Part Number
101-3125	Gasket	420-8567
108-7930	Bearing As	377-7463
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
116-7885	Pan-Oil (Front)	379-0173
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599

ZAC		
Original Part Number	Part Name	Classic Part Number
157-5075	Gear-Planet	394-9821
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
184-4395	Guide	393-1042
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Cat Classic Parts for Scrapers

Scrapers have long, productive lives. They are designed to Load, haul, dump, and compact at maximum efficiency. Maintenance costs, to keep the machines running efficiently at all times, need to be re-evaluated As. the machine ages. To help you manage your maintenance costs, Caterpillar offers Classic parts for several models of scrapers.

Cat Classic parts provide owners of older Cat products with low cost Repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts coverage for scrapers includes:

- Differential
- Engine
- Final Drive
- Hitch
- Moving Undercarriage
- Transmission
- ...and many more.

Sales Model 10

19C		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158

19C		
Original Part Number	**Part Name**	**Classic Part Number**
3F-3049	Cone-Roller Brg	418-9600
6B-3223	Cup-Bearing	399-6065

Sales Model 15

04W		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1B-3937	Cup-Roller Brg	377-7394

04W		
Original Part Number	**Part Name**	**Classic Part Number**
4F-1252	Pin	295-5704
5D-0470	Valve Gp-Qrel	314-8549
5F-2830	Bearing-Needle	384-5925

04W		
Original Part Number	**Part Name**	**Classic Part Number**
5F-7958	Shaft-Roller	434-1865
5T-5682	Driver	418-9579
8F-9365	Pin	319-3463

Scrapers

Sales Model 20

11C		
Original Part Number	**Part Name**	**Classic Part Number**
8F-7278	Diaphragm	392-4485

Sales Model 21

08J		
Original Part Number	**Part Name**	**Classic Part Number**
8F-7278	Diaphragm	392-4485

Sales Model 60

01D, 02W		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
3F-3049	Cone-Roller Brg	418-9600

01D, 02W		
Original Part Number	**Part Name**	**Classic Part Number**
6B-3223	Cup-Bearing	399-6065
1B-3922	Cup-Roller Brg	416-2158
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836

01D, 02W		
Original Part Number	**Part Name**	**Classic Part Number**
3F-3049	Cone-Roller Brg	418-9600
5F-7958	Shaft-Roller	434-1865
6B-3223	Cup-Bearing	399-6065

Sales Model 70

03W		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1B-3937	Cup-Roller Brg	377-7394
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
3F-3049	Cone-Roller Brg	418-9600

03W		
Original Part Number	**Part Name**	**Classic Part Number**
4F-1252	Pin	295-5704
5F-7958	Shaft-Roller	434-1865
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
1B-3922	Cup-Roller Brg	416-2158
1B-3937	Cup-Roller Brg	377-7394

03W		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
3F-3049	Cone-Roller Brg	418-9600
6B-3223	Cup-Bearing	399-6065

Sales Model 90

09V		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443

Sales Model 308E

EC2		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433

EC2		
Original Part Number	**Part Name**	**Classic Part Number**
347-6081	Gauge As	360-2348
357-7540	Valve-Fill	360-2292

Sales Model 428, 428B

44D		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-2860	Cup-Spl Tapered	374-8347

Sales Model 435, 435C, 435D, 435F

45D		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3937	Cup-Roller Brg	377-7394
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443

45D		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4043	Cone-Roller Brg	377-7395
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840

45D		
Original Part Number	**Part Name**	**Classic Part Number**
5F-7958	Shaft-Roller	434-1865
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065

Scrapers

Sales Model 435E

85F		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443

85F		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840

85F		
Original Part Number	Part Name	Classic Part Number
5F-7958	Shaft-Roller	434-1865
6B-3223	Cup-Bearing	399-6065

Sales Model 442B

83E		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
5D-0470	Valve Gp-Qrel	314-8549

83E		
Original Part Number	Part Name	Classic Part Number
5F-2830	Bearing-Needle	384-5925
5F-7958	Shaft-Roller	434-1865
5T-5682	Driver	418-9579

83E		
Original Part Number	Part Name	Classic Part Number
8F-9365	Pin	319-3463
308-1845	Seal-Wiper	472-8032

Sales Model 456, 456B

61C		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5T-5682	Driver	418-9579

61C		
Original Part Number	Part Name	Classic Part Number
8F-7278	Diaphragm	392-4485
5D-0470	Valve Gp-Qrel	314-8549

61C		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
8F-7278	Diaphragm	392-4485

Sales Model 463, 463C

62C		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1B-3978	Cup-Roller Brg	399-4437

62C		
Original Part Number	Part Name	Classic Part Number
1B-3980	Cone-Roller Brg	399-4443
3J-4778	Roller As	394-2582
5T-5682	Driver	418-9579

Sales Model 463E

86F		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1B-3978	Cup-Roller Brg	399-4437

86F		
Original Part Number	Part Name	Classic Part Number
1B-3980	Cone-Roller Brg	399-4443
3J-4778	Roller As	394-2582
5T-5682	Driver	418-9579

Sales Model 463F

62C		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1B-3978	Cup-Roller Brg	399-4437

62C		
Original Part Number	Part Name	Classic Part Number
1B-3980	Cone-Roller Brg	399-4443
3J-4778	Roller As	394-2582
5T-5682	Driver	418-9579

Sales Model 470, 470B

60C		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5F-2830	Bearing-Needle	384-5925
5T-5682	Driver	418-9579
7F-7780	Pin-Anchor	384-4825

60C		
Original Part Number	Part Name	Classic Part Number
8F-7278	Diaphragm	392-4485
5D-0470	Valve Gp-Qrel	314-8549
5F-2830	Bearing-Needle	384-5925
5T-5682	Driver	418-9579

60C		
Original Part Number	Part Name	Classic Part Number
7F-7780	Pin-Anchor	384-4825
8F-7278	Diaphragm	392-4485

Sales Model 482B, 482C

72E		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2J-2152	Cup-Roller Brg	374-1852

72E		
Original Part Number	Part Name	Classic Part Number
3J-4778	Roller As	394-2582
5D-0470	Valve Gp-Qrel	314-8549

72E		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
8F-7278	Diaphragm	392-4485

Sales Model 482B, 482C (Cont'd.)

72E		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2J-2152	Cup-Roller Brg	374-1852

72E		
Original Part Number	Part Name	Classic Part Number
3J-4778	Roller As	394-2582
5D-0470	Valve Gp-Qrel	314-8549

72E		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
8F-7278	Diaphragm	392-4485

Sales Model 491

09A, 98C		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
6V-3831	Seal-O-Ring	436-2657

Sales Model 491B, 491C

47E		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
2J-2152	Cup-Roller Brg	374-1852

47E		
Original Part Number	Part Name	Classic Part Number
3J-4778	Roller As	394-2582
5T-5682	Driver	418-9579
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443

47E		
Original Part Number	Part Name	Classic Part Number
2J-2152	Cup-Roller Brg	374-1852
3J-4778	Roller As	394-2582
5T-5682	Driver	418-9579

Sales Model 611

6SZ		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786

6SZ		
Original Part Number	Part Name	Classic Part Number
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

6SZ		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358

Sales Model 611 (Cont'd.)

6SZ		
Original Part Number	Part Name	Classic Part Number
1W-4506	Adapter-Seal	372-7515
1W-4738	Bearing-Sleeve	325-6020
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2788	Adapter-Fan	390-0984

6SZ		
Original Part Number	Part Name	Classic Part Number
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-2752	Cartridge Gp-Rr	422-8127
3G-7661	Cartridge Gp	422-8113
3G-7667	Cartridge Gp	422-8107
3J-2903	Cover	422-6922
3J-9133	Bearing-Sleeve	361-1691
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4J-5693	Bearing-Sleeve	385-3790

6SZ		
Original Part Number	Part Name	Classic Part Number
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4K-9598	Retainer	297-7235
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-6869	Cartridge Gp	422-8104
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4W-0452	Seal As -Cshaft	325-6191

Sales Model 611 (Cont'd.)

6SZ		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5F-7958	Shaft-Roller	434-1865
5J-1806	Pin	396-0662
5J-1825	Pin	367-6080
5J-6611	Bearing-Sleeve	383-2140
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-6212	Tube	390-0996
5P-2526	Cup-Rlr Bearing	380-7498
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5411	Race-Brg Outer	417-9481
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

6SZ		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6E-4730	Pump Gp-Vn Bsc-B	426-1925
6E-6483	Pump Gp-Vn Bsc-B	422-8176
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-5003	Bearing-Aligning	420-2498
6Y-1690	Carrier-Ring	384-3849
7C-4297	Seal As-Cshaft	325-6192
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-9547	Pin As.-Drawbar	295-0414

6SZ		
Original Part Number	Part Name	Classic Part Number
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7J-1309	Bearing-Aligning	360-2275
7J-6869	Ring	389-6329
7J-8893	Cone-Roller Brg	374-1846
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172

Sales Model 611 (Cont'd.)

6SZ		
Original Part Number	Part Name	Classic Part Number
8D-8829	Bearing-Sleeve	361-1692
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377

6SZ		
Original Part Number	Part Name	Classic Part Number
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9523	Elbow	425-2566
8P-0953	Turbine-Conv	297-7269
8P-0961	Impeller-Conv	433-9204
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8V-6390	Drum-Brake	377-7449
8W-4523	Bearing-Sleeve	385-3798
9C-5852	Hub As	297-7208
9G-0280	Piston	283-5213
9L-5908	Gasket	433-8196
9P-8517	Case-Xmsn	394-0909

6SZ		
Original Part Number	Part Name	Classic Part Number
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9T-7916	Pump Gp-Vn Bsc-B	426-1697
9V-5160	Plunger Kt-Adj	385-7218
9W-3605	Carrier-Ring	314-8662
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-7689	Yoke As	422-7245
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
115-4072	Bearing	397-5069
131-3815	Seal Gp-Basic	325-6193
134-2659	Rod As	388-6568
136-7813	Bearing-Race	460-8296
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
144-7299	Roller As	434-1991
147-1206	Gear Planet	418-9597
148-3465	Pin	383-2112
148-7455	Valve - Exhaust	270-4361
161-3411	Gasket	394-0896
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351

Sales Model 611 (Cont'd.)

6SZ		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484

6SZ		
Original Part Number	Part Name	Classic Part Number
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
174-7432	Head	388-0660
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085

6SZ		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
282-4348	Kit-Dt Gasket	419-8665
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
325-3291	Roller As	434-1918
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

7WZ		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3J-2903	Cover	422-6922
3J-9133	Bearing-Sleeve	361-1691
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4F-2041	Cup-Roller Brg	418-9609

7WZ		
Original Part Number	Part Name	Classic Part Number
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
5F-7958	Shaft-Roller	434-1865
5G-3612	Cap Gp-Protn	295-6419
7T-2036	Cap As-Fuel	361-1721

7WZ		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8V-6390	Drum-Brake	377-7449
9V-5160	Plunger Kt-Adj	385-7218
134-2659	Rod As	388-6568
144-7299	Roller As	434-1991
174-7432	Head	388-0660
325-3291	Roller As	434-1918

Sales Model 613

71M		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3924	Cone-Roller Brg	422-6482

Sales Model 613 (Cont'd.)

71M		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7125	Governor As	383-3672
1T-0020	Wheel-Turbine	297-4862
1T-0576	Bearing-Sleeve	379-0186
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1V-0188	Disc	386-4943
1V-1080	Housing-Brg Spt	260-0775
1V-5724	Diff Gp -A	260-0776
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

71M		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-0227	Bearing-Sleeve	384-4780
2K-0535	Nut	299-2026
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505
2K-5804	Rod End-Spher	416-2151
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2P-4404	Housing As-Cl	226-8027
2P-4611	Pipe-Exhaust	365-8821
2P-5081	Muffler As	360-7872
2S-6097	Tang	375-9979
2V-6220	Shaft-Planet	221-9073
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
3B-4124	Cup-Spl Tapered	422-6481
3G-7640	Pump Gp-Vn Bsc-B	422-8172
3G-7653	Cartridge Gp	422-8099
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3G-7659	Cartridge Gp	422-8102
3J-9133	Bearing-Sleeve	361-1691
3J-9325	Piston	390-0993

71M		
Original Part Number	Part Name	Classic Part Number
3K-2511	Dowel-Reaction	383-2126
3K-7020	Gear-Planet	221-9074
3P-5672	Yoke	223-6313
3P-8393	Plate-Clutch	388-0592
3S-7987	Shaft-Planet	226-6074
4B-1455	Cap As-Filler	361-1719
4D-2619	Bearing	417-4494
4E-8534	Retainer-Seal	300-2588
4K-6212	Shaft-Bev Pinion	223-4806
4K-9598	Retainer	297-7235
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4S-5891	Plate-Clutch	388-0575
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

Sales Model 613 (Cont'd.)

71M		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5J-9348	Bearing As	416-2162
5K-1068	Retainer-Seal	260-0786
5K-5933	Cover As	247-4125
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5L-6326	Bearing-Ball	420-3222
5M-5856	Pipe-Extension	373-1913
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-8545	Gasket Kit	437-8626
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5917	Screw-Rock-er Adj	380-7537
5S-7877	Bearing-Spl Ball	392-4491
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-5917	Pinion-Diff	297-7224
6K-4599	Yoke As	385-6111
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-6894	Rebuild Kt-Pump	383-3696
6Y-5348	Disc-Friction	384-4827
6Y-5915	Disc-Friction	384-5936
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092

71M		
Original Part Number	Part Name	Classic Part Number
7G-2830	Ring-Seal	295-6441
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-5242	Spider & Brg As	450-7548
7J-5356	Guide Lh	416-5503
7J-6250	Bearing-Sleeve	385-3803
7J-6869	Ring	389-6329
7J-6884	Shaft	387-2937
7J-9434	Shaft	380-7557
7M-7219	Bearing-Thrust	384-4816
7N-2957	Cover-Rad Cap	361-1722
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8576	Bearing As	435-4848
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7W-2059	Gasket-Cyl Hd	380-1548
8B-5972	Bearing-Ball	314-8503
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8I-1098	Shaft	396-7275
8J-5014	Pin	384-4773
8K-6283	Gear-Sun	221-9077
8M-3368	Valve-Check	388-6599
8N-0701	Bearing-Sleeve	419-4745
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788

71M		
Original Part Number	Part Name	Classic Part Number
9B-1320	Valve-Check	377-5832
9C-8205	Gear-Bevel	319-8175
9J-0105	Hub	415-1894
9J-3206	Bearing-Spher	360-2275
9J-3741	Shaft	386-4933
9J-5061	Pump Gp-Vn Bsc-B	422-8171
9K-3413	Gear-Bevel	223-4807
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-3345	Pulley As-Idler	398-8341
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-5920	Bearing-Conn Rod	419-6383
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9S-1768	Pipe-Ext Exhaust	380-7544
9S-8184	Pin-Drawbar	398-8345
9T-2200	Cartridgr Gp	422-8114
9T-5096	Flexplate	455-3271
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
005-8639	Bearing-Aligning	415-1925

Sales Model 613 (Cont'd.)

71M		
Original Part Number	Part Name	Classic Part Number
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311

71M		
Original Part Number	Part Name	Classic Part Number
234-7989	Kit-Gasket-Sch	437-8122
289-2935	Seal As-Buffer	472-8028

71M		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

72M		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7125	Governor As	383-3672
1T-0020	Wheel-Turbine	297-4862
1T-0576	Bearing-Sleeve	379-0186
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1V-0188	Disc	386-4943
1V-1080	Housing-Brg Spt	260-0775
1V-5724	Diff Gp -A	260-0776
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944

72M		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2H-3517	Bearing-Inner	417-4505
2K-0227	Bearing-Sleeve	384-4780
2K-0535	Nut	299-2026
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505
2K-5804	Rod End-Spher	416-2151
2L-5271	Bearing-Ball	371-4305
2P-4404	Housing As-Cl	226-8027
2P-5081	Muffler As	360-7872
2V-6220	Shaft-Planet	221-9073
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912

72M		
Original Part Number	Part Name	Classic Part Number
3G-7640	Pump Gp-Vn Bsc-B	422-8172
3G-7653	Cartridge Gp	422-8099
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3G-7659	Cartridge Gp	422-8102
3J-9133	Bearing-Sleeve	361-1691
3J-9325	Piston	390-0993
3K-2511	Dowel-Reaction	383-2126
3K-7020	Gear-Planet	221-9074
3P-8393	Plate-Clutch	388-0592
3S-7987	Shaft-Planet	226-6074
4B-1455	Cap As-Filler	361-1719
4D-2619	Bearing	417-4494
4K-6212	Shaft-Bev Pinion	223-4806
4K-9598	Retainer	297-7235
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903

Sales Model 613 (Cont'd.)

72M		
Original Part Number	Part Name	Classic Part Number
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4S-5891	Plate-Clutch	388-0575
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5D-0470	Valve Gp-Qrel	314-8549
5G-3612	Cap Gp-Protn	295-6419
5J-9348	Bearing As	416-2162
5K-1068	Retainer-Seal	260-0786
5K-5933	Cover As	247-4125
5L-6326	Bearing-Ball	420-3222
5M-5856	Pipe-Extension	373-1913
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5917	Screw-Rocker Adj	380-7537
5S-7877	Bearing-Spl Ball	392-4491
5V-1274	Spider	385-6110
6K-4599	Yoke As	385-6111
6P-7704	Carrier-Ring	314-8658
6S-3051	Cup-Rlr Brg	415-1928
6V-2202	Bearing-Spl Ball	380-1574

72M		
Original Part Number	Part Name	Classic Part Number
6V-6894	Rebuild Kt-Pump	383-3696
6Y-5348	Disc-Friction	384-4827
6Y-5915	Disc-Friction	384-5936
6Y-7652	Cup-Rlr Brg	399-6067
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-5242	Spider & Brg As	450-7548
7J-5356	Guide Lh	416-5503
7J-6250	Bearing-Sleeve	385-3803
7J-6869	Ring	389-6329
7J-6884	Shaft	387-2937
7J-8210	Cone-Roller Brg	423-6987
7J-9434	Shaft	380-7557
7M-7219	Bearing-Thrust	384-4816
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8576	Bearing As	435-4848
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7W-2059	Gasket-Cyl Hd	380-1548
8B-5972	Bearing-Ball	314-8503
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636

72M		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8I-1098	Shaft	396-7275
8J-5014	Pin	384-4773
8K-6283	Gear-Sun	221-9077
8M-3368	Valve-Check	388-6599
8N-0701	Bearing-Sleeve	419-4745
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
9B-1320	Valve-Check	377-5832
9J-0105	Hub	415-1894
9J-3206	Bearing-Spher	360-2275
9J-3741	Shaft	386-4933
9J-5061	Pump Gp-Vn Bsc-B	422-8171
9K-3413	Gear-Bevel	223-4807
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-3345	Pulley As-Idler	398-8341
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9S-1768	Pipe-Ext Exhaust	380-7544
9S-8184	Pin-Drawbar	398-8345
9T-2200	Cartridgr Gp	422-8114
9T-5096	Flexplate	455-3271
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935

Sales Model 613 (Cont'd.)

72M		
Original Part Number	Part Name	Classic Part Number
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
005-8639	Bearing-Aligning	415-1925

72M		
Original Part Number	Part Name	Classic Part Number
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311

72M		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 613B

38W		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3924	Cone-Roller Brg	422-6482
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0020	Wheel-Turbine	297-4862
1T-0576	Bearing-Sleeve	379-0186
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482

38W		
Original Part Number	Part Name	Classic Part Number
1V-0188	Disc	386-4943
1V-1080	Housing-Brg Spt	260-0775
1V-5724	Diff Gp -A	260-0776
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2H-3517	Bearing-Inner	417-4505
2K-0227	Bearing-Sleeve	384-4780
2K-0535	Nut	299-2026
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989

38W		
Original Part Number	Part Name	Classic Part Number
2K-5103	Cone-Roller Brg	380-7505
2K-5804	Rod End-Spher	416-2151
2K-9295	Bearing-Cone	422-6480
2P-4404	Housing As-Cl	226-8027
2P-5081	Muffler As	360-7872
2V-6220	Shaft-Planet	221-9073
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
3B-4124	Cup-Spl Tapered	422-6481
3G-7640	Pump Gp-Vn Bsc-B	422-8172
3G-7653	Cartridge Gp	422-8099
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3G-7659	Cartridge Gp	422-8102
3J-9325	Piston	390-0993
3K-2511	Dowel-Reaction	383-2126
3K-7020	Gear-Planet	221-9074

Sales Model 613B (Cont'd.)

38W		
Original Part Number	Part Name	Classic Part Number
3P-5672	Yoke	223-6313
3P-8393	Plate-Clutch	388-0592
3S-7987	Shaft-Planet	226-6074
4B-1455	Cap As-Filler	361-1719
4D-2619	Bearing	417-4494
4E-8534	Retainer-Seal	300-2588
4K-6212	Shaft-Bev Pinion	223-4806
4K-9598	Retainer	297-7235
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4S-5891	Plate-Clutch	388-0575
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5K-1068	Retainer-Seal	260-0786
5K-5933	Cover As	247-4125
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927

38W		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
5M-5856	Pipe-Extension	373-1913
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-8545	Gasket Kit	437-8626
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5917	Screw-Rocker Adj	380-7537
5S-7877	Bearing-Spl Ball	392-4491
5V-1274	Spider	385-6110
5V-5917	Pinion-Diff	297-7224
6K-4599	Yoke As	385-6111
6P-7704	Carrier-Ring	314-8658
6S-3051	Cup-Rlr Brg	415-1928
6V-2202	Bearing-Spl Ball	380-1574
6V-2909	Gasket Kit - F	388-0652
6V-6894	Rebuild Kt-Pump	383-3696
6Y-5348	Disc-Friction	384-4827
6Y-5915	Disc-Friction	384-5936
6Y-7652	Cup-Rlr Brg	399-6067
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7H-4566	Cup-Roller Brg	399-6068
7J-5242	Spider & Brg As	450-7548
7J-6250	Bearing-Sleeve	385-3803

38W		
Original Part Number	Part Name	Classic Part Number
7J-6869	Ring	389-6329
7J-6884	Shaft	387-2937
7J-8210	Cone-Roller Brg	423-6987
7J-9434	Shaft	380-7557
7M-7219	Bearing-Thrust	384-4816
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8576	Bearing As	435-4848
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7W-2059	Gasket-Cyl Hd	380-1548
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-5014	Pin	384-4773
8K-6283	Gear-Sun	221-9077
8M-3368	Valve-Check	388-6599
8N-0701	Bearing-Sleeve	419-4745
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
9B-1320	Valve-Check	377-5832
9C-8205	Gear-Bevel	319-8175
9J-3206	Bearing-Spher	360-2275
9J-3741	Shaft	386-4933
9J-5061	Pump Gp-Vn Bsc-B	422-8171
9K-3413	Gear-Bevel	223-4807
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9N-3345	Pulley As-Idler	398-8341

Sales Model 613B (Cont'd.)

38W		
Original Part Number	Part Name	Classic Part Number
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-5920	Bearing-Conn Rod	419-6383
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9S-1768	Pipe-Ext Exhaust	380-7544
9S-8184	Pin-Drawbar	398-8345
9T-5096	Flexplate	455-3271

38W		
Original Part Number	Part Name	Classic Part Number
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605

38W		
Original Part Number	Part Name	Classic Part Number
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
234-7989	Kit-Gasket-Sch	437-8122
234-7994	Kit-Gasket-Sch	437-8120
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

4WG		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1H-5338	Cup-Roller Brg	374-8345
1V-0188	Disc	386-4943
2G-1034	Valve-Safety	380-7555
2K-0227	Bearing-Sleeve	384-4780
3J-9133	Bearing-Sleeve	361-1691
3J-9325	Piston	390-0993
4T-8054	Seal As	472-8010

4WG		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5J-9348	Bearing As	416-2162
6S-3051	Cup-Rlr Brg	415-1928
6Y-7652	Cup-Rlr Brg	399-6067
7J-5356	Guide Lh	416-5503
7J-6250	Bearing-Sleeve	385-3803
7J-8210	Cone-Roller Brg	423-6987
7T-2036	Cap As-Fuel	361-1721
8B-5972	Bearing-Ball	314-8503

4WG		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8I-1098	Shaft	396-7275
9J-0105	Hub	415-1894
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

5XF		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3924	Cone-Roller Brg	422-6482
1H-5338	Cup-Roller Brg	374-8345

5XF		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883

5XF		
Original Part Number	Part Name	Classic Part Number
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535

Sales Model 613B (Cont'd.)

5XF		
Original Part Number	Part Name	Classic Part Number
1P-3935	Cone-Roller Brg	377-7397
1T-0020	Wheel-Turbine	297-4862
1T-0576	Bearing-Sleeve	379-0186
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1V-0188	Disc	386-4943
1V-1080	Housing-Brg Spt	260-0775
1V-5724	Diff Gp -A	260-0776
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2D-5658	Bearing-Ball	301-4628
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-1034	Valve-Safety	380-7555
2H-3517	Bearing-Inner	417-4505
2K-0535	Nut	299-2026
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505
2K-5804	Rod End-Spher	416-2151
2K-9295	Bearing-Cone	422-6480
2P-4404	Housing As-Cl	226-8027
2P-5081	Muffler As	360-7872

5XF		
Original Part Number	Part Name	Classic Part Number
2V-6220	Shaft-Planet	221-9073
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
3B-4124	Cup-Spl Tapered	422-6481
3G-7640	Pump Gp-Vn Bsc-B	422-8172
3G-7653	Cartridge Gp	422-8099
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3G-7659	Cartridge Gp	422-8102
3J-9325	Piston	390-0993
3K-2511	Dowel-Reaction	383-2126
3K-7020	Gear-Planet	221-9074
3P-5672	Yoke	223-6313
3P-8393	Plate-Clutch	388-0592
3S-7987	Shaft-Planet	226-6074
4D-2619	Bearing	417-4494
4E-8534	Retainer-Seal	300-2588
4K-6212	Shaft-Bev Pinion	223-4806
4K-9598	Retainer	297-7235
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059

5XF		
Original Part Number	Part Name	Classic Part Number
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4S-5891	Plate-Clutch	388-0575
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5K-1068	Retainer-Seal	260-0786
5K-5933	Cover As	247-4125
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5L-6326	Bearing-Ball	420-3222
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-7877	Bearing-Spl Ball	392-4491
5V-1274	Spider	385-6110
5V-5917	Pinion-Diff	297-7224
6K-4599	Yoke As	385-6111
6P-7704	Carrier-Ring	314-8658
6S-3051	Cup-Rlr Brg	415-1928
6V-2202	Bearing-Spl Ball	380-1574
6V-6894	Rebuild Kt-Pump	383-3696
6Y-5348	Disc-Friction	384-4827
6Y-5915	Disc-Friction	384-5936
6Y-7652	Cup-Rlr Brg	399-6067

Sales Model 613B (Cont'd.)

5XF		
Original Part Number	Part Name	Classic Part Number
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7H-4566	Cup-Roller Brg	399-6068
7J-5242	Spider & Brg As	450-7548
7J-6250	Bearing-Sleeve	385-3803
7J-6869	Ring	389-6329
7J-6884	Shaft	387-2937
7J-8210	Cone-Roller Brg	423-6987
7J-9434	Shaft	380-7557
7M-7219	Bearing-Thrust	384-4816
7S-8443	Muffler	247-2675
7S-8576	Bearing As	435-4848
7W-2059	Gasket-Cyl Hd	380-1548
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636

5XF		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8J-5014	Pin	384-4773
8K-6283	Gear-Sun	221-9077
8M-3368	Valve-Check	388-6599
8N-0701	Bearing-Sleeve	419-4745
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
9B-1320	Valve-Check	377-5832
9C-8205	Gear-Bevel	319-8175
9J-3206	Bearing-Spher	360-2275
9J-3741	Shaft	386-4933
9J-5061	Pump Gp-Vn Bsc-B	422-8171
9K-3413	Gear-Bevel	223-4807
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9N-3345	Pulley As-Idler	398-8341
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914

5XF		
Original Part Number	Part Name	Classic Part Number
9N-6500	Rod-Valve Push	383-3706
9T-5096	Flexplate	455-3271
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
103-0887	Pulley-Idler	449-9546
105-7535	Bearing-Dbl Row	417-9496
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

72M		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883

72M		
Original Part Number	Part Name	Classic Part Number
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7125	Governor As	383-3672
1T-0020	Wheel-Turbine	297-4862
1T-0576	Bearing-Sleeve	379-0186

72M		
Original Part Number	Part Name	Classic Part Number
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1V-0188	Disc	386-4943
1V-1080	Housing-Brg Spt	260-0775
1V-5724	Diff Gp -A	260-0776
2A-4429	Lock-Retainer	379-0174

Sales Model 613B (Cont'd.)

72M		
Original Part Number	Part Name	Classic Part Number
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2H-3517	Bearing-Inner	417-4505
2K-0227	Bearing-Sleeve	384-4780
2K-0535	Nut	299-2026
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505
2K-5804	Rod End-Spher	416-2151
2L-5271	Bearing-Ball	371-4305
2P-4404	Housing As-Cl	226-8027
2P-5081	Muffler As	360-7872
2V-6220	Shaft-Planet	221-9073
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
3G-7640	Pump Gp-Vn Bsc-B	422-8172
3G-7653	Cartridge Gp	422-8099
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3G-7659	Cartridge Gp	422-8102
3J-9133	Bearing-Sleeve	361-1691

72M		
Original Part Number	Part Name	Classic Part Number
3J-9325	Piston	390-0993
3K-2511	Dowel-Reaction	383-2126
3K-7020	Gear-Planet	221-9074
3P-8393	Plate-Clutch	388-0592
3S-7987	Shaft-Planet	226-6074
4B-1455	Cap As-Filler	361-1719
4D-2619	Bearing	417-4494
4K-6212	Shaft-Bev Pinion	223-4806
4K-9598	Retainer	297-7235
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4S-5891	Plate-Clutch	388-0575
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5D-0470	Valve Gp-Qrel	314-8549
5G-3612	Cap Gp-Protn	295-6419
5J-9348	Bearing As	416-2162

72M		
Original Part Number	Part Name	Classic Part Number
5K-1068	Retainer-Seal	260-0786
5K-5933	Cover As	247-4125
5L-6326	Bearing-Ball	420-3222
5M-5856	Pipe-Extension	373-1913
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5917	Screw-Rocker Adj	380-7537
5S-7877	Bearing-Spl Ball	392-4491
5V-1274	Spider	385-6110
6K-4599	Yoke As	385-6111
6P-7704	Carrier-Ring	314-8658
6S-3051	Cup-Rlr Brg	415-1928
6V-2202	Bearing-Spl Ball	380-1574
6V-6894	Rebuild Kt-Pump	383-3696
6Y-5348	Disc-Friction	384-4827
6Y-5915	Disc-Friction	384-5936
6Y-7652	Cup-Rlr Brg	399-6067
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-5242	Spider & Brg As	450-7548
7J-5356	Guide Lh	416-5503

Sales Model 613B (Cont'd.)

72M		
Original Part Number	Part Name	Classic Part Number
7J-6250	Bearing-Sleeve	385-3803
7J-6869	Ring	389-6329
7J-6884	Shaft	387-2937
7J-8210	Cone-Roller Brg	423-6987
7J-9434	Shaft	380-7557
7M-7219	Bearing-Thrust	384-4816
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8576	Bearing As	435-4848
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7W-2059	Gasket-Cyl Hd	380-1548
8B-5972	Bearing-Ball	314-8503
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8I-1098	Shaft	396-7275
8J-5014	Pin	384-4773
8K-6283	Gear-Sun	221-9077

72M		
Original Part Number	Part Name	Classic Part Number
8M-3368	Valve-Check	388-6599
8N-0701	Bearing-Sleeve	419-4745
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
9B-1320	Valve-Check	377-5832
9J-0105	Hub	415-1894
9J-3206	Bearing-Spher	360-2275
9J-3741	Shaft	386-4933
9J-5061	Pump Gp-Vn Bsc-B	422-8171
9K-3413	Gear-Bevel	223-4807
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-3345	Pulley As-Idler	398-8341
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9S-1768	Pipe-Ext Exhaust	380-7544

72M		
Original Part Number	Part Name	Classic Part Number
9S-8184	Pin-Drawbar	398-8345
9T-2200	Cartridgr Gp	422-8114
9T-5096	Flexplate	455-3271
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 613C

8LJ		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1B-3934	Cup-Roller Brg	392-4487
1H-5338	Cup-Roller Brg	374-8345

8LJ		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3706	Pipe-Extension	434-6497

8LJ		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786

Sales Model 613C (Cont'd.)

8LJ		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1W-1064	Gear-Flywheel	374-4703
1W-4623	Muffler As	360-9622
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5103	Cone-Roller Brg	380-7505
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2N-1599	Gear	378-3970
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2T-0374	Pin	418-1952
2T-1581	Bearing-Sleeve	399-6051
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510

8LJ		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-2717	Cartridge Gp	439-1132
3G-7658	Cartridge Gp	426-0427
3G-7663	Cartridge Gp	422-8120
3G-8136	Retainer	425-3585
3J-2903	Cover	422-6922
3J-9133	Bearing-Sleeve	361-1691
3P-5672	Yoke	223-6313
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4D-2619	Bearing	417-4494
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4K-9598	Retainer	297-7235
4N-4942	Rod-Eye	421-8919
4P-5433	Compressor As	419-4728
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-6869	Cartridge Gp	422-8104
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-4852	Piston	433-0452
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669

8LJ		
Original Part Number	Part Name	Classic Part Number
4V-8538	Gear-Ring	288-8720
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5D-0470	Valve Gp-Qrel	314-8549
5G-3612	Cap Gp-Protn	295-6419
5J-9348	Bearing As	416-2162
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-0578	Bearing	419-7775
5P-3930	Bearing As-Rlr	419-6022
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-9080	Pulley-Alt Drive	264-5883
5T-1362	Univ Joint As-5C	325-6011
5T-5682	Driver	418-9579
5T-8739	Spider Gp-Brg	373-5386
5V-1274	Spider	385-6110
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
5V-6327	Yoke-Flange Bk	391-1086
6E-0775	Head	425-9373
6E-6482	Pump Gp-Vn Bsc-B	422-8164
6H-2577	Spider Gp-Brg	333-4954
6I-1099	Manifold-Exh	424-6366
6L-7751	Rod End-Spher	472-8015

Sales Model 613C (Cont'd.)

8LJ		
Original Part Number	Part Name	Classic Part Number
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-2202	Bearing-Spl Ball	380-1574
6Y-1690	Carrier-Ring	384-3849
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7G-3454	Gear-Planet	300-2578
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692

8LJ		
Original Part Number	Part Name	Classic Part Number
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-5356	Guide Lh	416-5503
7J-6250	Bearing-Sleeve	385-3803
7J-6869	Ring	389-6329
7J-6884	Shaft	387-2937
7J-8893	Cone-Roller Brg	374-1846
7J-9434	Shaft	380-7557
7J-9884	Bearing-Sleeve	325-6016
7S-4534	Bearing-Caged	417-9497
7T-2036	Cap As-Fuel	361-1721
7T-4754	Impeller-Conv	385-7231
7V-5645	Rod-Indicator	397-5061
7V-8640	Spindle	424-4945
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8B-5972	Bearing-Ball	314-8503
8H-2810	Case As-Filter	314-8512
8I-1098	Shaft	396-7275
8J-5014	Pin	384-4773
8K-6282	Gear-Sun	281-1698
8M-3368	Valve-Check	388-6599
8P-0953	Turbine-Conv	297-7269
8P-3563	Cage-Bearing	451-0747

8LJ		
Original Part Number	Part Name	Classic Part Number
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8S-0248	Breather As	325-6033
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8Y-0809	Spider Gp-Brg	417-4526
9C-8205	Gear-Bevel	319-8175
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9J-0105	Hub	415-1894
9J-3206	Bearing-Spher	360-2275
9J-3741	Shaft	386-4933
9L-2685	Rod End	419-1866
9N-3345	Pulley As-Idler	398-8341
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9V-8693	Actuator Gp-Bk	375-2629
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

Sales Model 613C (Cont'd.)

8LJ		
Original Part Number	Part Name	Classic Part Number
101-7689	Yoke As	422-7245
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
136-7813	Bearing-Race	460-8296
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336

8LJ		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-1740	Gear-Planet	377-7466
152-3952	Impeller-Pump	374-4696
154-5682	Gasket Kit	434-7264
155-6648	Cone Spl Rol Brg	418-9599
156-6237	Elbow As	396-1567
163-1387	Gear-Flywheel	374-4697
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371

8LJ		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
300-9500	Kit-Gasket-Sch	387-2914
308-1845	Seal-Wiper	472-8032
352-2153	Pump As-Water	433-0444
441-9566	Gear-Flywheel	374-4703

8TB		
Original Part Number	Part Name	Classic Part Number
4V-4852	Piston	433-0452
5V-4573	Disc	388-0591

8TB		
Original Part Number	Part Name	Classic Part Number
7V-5645	Rod-Indicator	397-5061
8H-2810	Case As-Filter	314-8512

8TB		
Original Part Number	Part Name	Classic Part Number
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605

92X		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1B-3934	Cup-Roller Brg	392-4487
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347

92X		
Original Part Number	Part Name	Classic Part Number
1J-4757	Cone-Bearing	374-1840
1N-3165	Plunger-Rlf V	373-1883
1N-3706	Pipe-Extension	434-6497
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

92X		
Original Part Number	Part Name	Classic Part Number
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864

Sales Model 613C (Cont'd.)

92X		
Original Part Number	Part Name	Classic Part Number
1W-4623	Muffler As	360-9622
1W-6987	Valve As-Check	420-6221
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5103	Cone-Roller Brg	380-7505
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2P-8986	Cup-Rlr Bearing	415-1912
2T-0374	Pin	418-1952
2T-1581	Bearing-Sleeve	399-6051
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2W-1225	Pump Gp-Water	380-7532
2W-8271	Arm As-Rocker	432-8912
3B-4124	Cup-Spl Tapered	422-6481
3G-7653	Cartridge Gp	422-8099
3G-7658	Cartridge Gp	426-0427
3G-7663	Cartridge Gp	422-8120
3J-9133	Bearing-Sleeve	361-1691
3P-5672	Yoke	223-6313
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4D-2619	Bearing	417-4494

92X		
Original Part Number	Part Name	Classic Part Number
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4K-9598	Retainer	297-7235
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4T-6869	Cartridge Gp	422-8104
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5D-0470	Valve Gp-Qrel	314-8549
5G-3612	Cap Gp-Protn	295-6419
5J-9348	Bearing As	416-2162
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-0578	Bearing	419-7775
5P-7807	Bearing-Ball	314-8502

92X		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5T-1362	Univ Joint As-5C	325-6011
5T-5682	Driver	418-9579
5T-8739	Spider Gp-Brg	373-5386
5V-1274	Spider	385-6110
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6E-0775	Head	425-9373
6H-2577	Spider Gp-Brg	333-4954
6K-4599	Yoke As	385-6111
6L-7751	Rod End-Spher	472-8015
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6V-2202	Bearing-Spl Ball	380-1574
6V-5413	Gasket Kit	390-5291
6V-6894	Rebuild Kt-Pump	383-3696
6V-9729	Gasket Kit - F	393-5195
6Y-3484	Bearing-Spl Ball	416-2166
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-7894	Bearing-Rod	419-7260
7G-0437	Plate-Clutch	417-9466
7G-3454	Gear-Planet	300-2578

Sales Model 613C (Cont'd.)

92X		
Original Part Number	Part Name	Classic Part Number
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4990	Case-Xmsn	388-6561
7G-5445	Carrier-Planet	469-4669
7J-5356	Guide Lh	416-5503
7J-6250	Bearing-Sleeve	385-3803
7J-6461	Crown	325-6054
7J-6869	Ring	389-6329
7J-6884	Shaft	387-2937
7J-9434	Shaft	380-7557
7M-7219	Bearing-Thrust	384-4816
7S-4534	Bearing-Caged	417-9497
7T-2036	Cap As-Fuel	361-1721
7V-5645	Rod-Indicator	397-5061
7V-8640	Spindle	424-4945
7W-2059	Gasket-Cyl Hd	380-1548
8B-5972	Bearing-Ball	314-8503
8D-0983	Mounting	384-3470
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8I-1098	Shaft	396-7275
8J-5014	Pin	384-4773
8K-6282	Gear-Sun	281-1698
8M-3368	Valve-Check	388-6599
8N-0701	Bearing-Sleeve	419-4745

92X		
Original Part Number	Part Name	Classic Part Number
8N-3666	Repair Kt-Major	377-5842
8P-3563	Cage-Bearing	451-0747
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
9C-8205	Gear-Bevel	319-8175
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9J-0105	Hub	415-1894
9J-3206	Bearing-Spher	360-2275
9J-3741	Shaft	386-4933
9J-5061	Pump Gp-Vn Bsc-B	422-8171
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9N-3345	Pulley As-Idler	398-8341
9N-4460	Housing As-Cl	297-7203
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9T-5096	Flexplate	455-3271
9V-8693	Actuator Gp-Bk	375-2629

92X		
Original Part Number	Part Name	Classic Part Number
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
103-0887	Pulley-Idler	449-9546
105-7535	Bearing-Dbl Row	417-9496
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
124-3237	Precleaner As	432-4220
147-1740	Gear-Planet	377-7466
154-5682	Gasket Kit	434-7264
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
226-8202	Seal-Wiper	472-8024
234-8019	Kit-Gasket-Sch	437-8639
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

93X		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482

Sales Model 613C (Cont'd.)

93X		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3165	Plunger-Rlf V	373-1883
1N-3706	Pipe-Extension	434-6497
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7057	Gasket	420-6384
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1W-1064	Gear-Flywheel	374-4703
1W-4623	Muffler As	360-9622
1W-6987	Valve As-Check	420-6221
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5103	Cone-Roller Brg	380-7505

93X		
Original Part Number	Part Name	Classic Part Number
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2N-1599	Gear	378-3970
2P-8986	Cup-Rlr Bearing	415-1912
2T-0374	Pin	418-1952
2T-1581	Bearing-Sleeve	399-6051
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2W-1225	Pump Gp-Water	380-7532
2W-7213	Bearing-Sleeve	419-4667
2W-8271	Arm As-Rocker	432-8912
3B-4124	Cup-Spl Tapered	422-6481
3G-2717	Cartridge Gp	439-1132
3G-7653	Cartridge Gp	422-8099
3G-7658	Cartridge Gp	426-0427
3G-7663	Cartridge Gp	422-8120
3J-2903	Cover	422-6922
3J-9133	Bearing-Sleeve	361-1691
3P-5672	Yoke	223-6313
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4D-2619	Bearing	417-4494
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4K-9598	Retainer	297-7235
4N-0406	Gear-Tfr Pump	373-1903

93X		
Original Part Number	Part Name	Classic Part Number
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-5433	Compressor As	419-4728
4P-5435	Compressor As	396-9942
4P-7688	Valve As-Check	420-6216
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-6869	Cartridge Gp	422-8104
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5D-0470	Valve Gp-Qrel	314-8549
5G-3612	Cap Gp-Protn	295-6419
5J-9348	Bearing As	416-2162
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-0578	Bearing	419-7775
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467

Sales Model 613C (Cont'd.)

93X		
Original Part Number	Part Name	Classic Part Number
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5T-1362	Univ Joint As-5C	325-6011
5T-5682	Driver	418-9579
5T-8739	Spider Gp-Brg&	373-5386
5V-1274	Spider	385-6110
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6E-0775	Head	425-9373
6E-6482	Pump Gp-Vn Bsc-B	422-8164
6H-2577	Spider Gp-Brg&	333-4954
6I-1099	Manifold-Exh	424-6366
6L-7751	Rod End-Spher	472-8015
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6V-2202	Bearing-Spl Ball	380-1574
6V-6894	Rebuild Kt-Pump	383-3696
6Y-3484	Bearing-Spl Ball	416-2166
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025

93X		
Original Part Number	Part Name	Classic Part Number
7E-2888	Gear-Fuel Pump	397-5062
7E-4728	Rod As-Conn	379-8863
7E-6794	Arm As-Injector	433-0449
7E-7894	Bearing-Rod	419-7260
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7G-3454	Gear-Planet	300-2578
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4990	Case-Xmsn	388-6561
7G-5445	Carrier-Planet	469-4669
7J-5356	Guide Lh	416-5503
7J-6250	Bearing-Sleeve	385-3803
7J-6461	Crown	325-6054
7J-6869	Ring	389-6329
7J-6884	Shaft	387-2937
7J-9434	Shaft	380-7557
7J-9884	Bearing-Sleeve	325-6016
7M-7219	Bearing-Thrust	384-4816
7S-4534	Bearing-Caged	417-9497
7T-2036	Cap As-Fuel	361-1721
7V-5645	Rod-Indicator	397-5061
7V-8640	Spindle	424-4945
7W-2059	Gasket-Cyl Hd	380-1548
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986

93X		
Original Part Number	Part Name	Classic Part Number
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8B-5972	Bearing-Ball	314-8503
8D-0983	Mounting	384-3470
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8I-1098	Shaft	396-7275
8J-5014	Pin	384-4773
8K-6282	Gear-Sun	281-1698
8M-3368	Valve-Check	388-6599
8N-0701	Bearing-Sleeve	419-4745
8N-3666	Repair Kt-Major	377-5842
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
9C-8205	Gear-Bevel	319-8175
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9J-0105	Hub	415-1894
9J-3206	Bearing-Spher	360-2275
9J-3741	Shaft	386-4933
9J-5061	Pump Gp-Vn Bsc-B	422-8171
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9N-3345	Pulley As-Idler	398-8341
9N-4460	Housing As-Cl	297-7203

Sales Model 613C (Cont'd.)

93X		
Original Part Number	Part Name	Classic Part Number
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9T-5096	Flexplate	455-3271
9V-8693	Actuator Gp-Bk	375-2629
9W-9930	Mount As	295-6437
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

93X		
Original Part Number	Part Name	Classic Part Number
103-0887	Pulley-Idler	449-9546
105-1738	Manifold-Exhaust	374-4692
105-7535	Bearing-Dbl Row	417-9496
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-1337	Ring Kit-Pstn	377-5834
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
119-6772	Valve-Exhaust	384-8699
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-1740	Gear-Planet	377-7466
152-3952	Impeller-Pump	374-4696

93X		
Original Part Number	Part Name	Classic Part Number
155-6648	Cone Spl Rol Brg	418-9599
156-6237	Elbow As	396-1567
163-1387	Gear-Flywheel	374-4697
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2153	Pump As-Water	433-0444
441-9566	Gear-Flywheel	374-4703

9FM		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3706	Pipe-Extension	434-6497

9FM		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7057	Gasket	420-6384
1T-0020	Wheel-Turbine	297-4862

9FM		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864

Sales Model 613C (Cont'd.)

9FM		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
1W-4623	Muffler As	360-9622
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5103	Cone-Roller Brg	380-7505
2K-9295	Bearing-Cone	422-6480
2N-1599	Gear	378-3970
2P-8986	Cup-Rlr Bearing	415-1912
2T-0374	Pin	418-1952
2T-1581	Bearing-Sleeve	399-6051
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-2717	Cartridge Gp	439-1132
3G-7658	Cartridge Gp	426-0427
3P-5672	Yoke	223-6313
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4D-2619	Bearing	417-4494
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4K-9598	Retainer	297-7235
4P-5433	Compressor As	419-4728

9FM		
Original Part Number	Part Name	Classic Part Number
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-0578	Bearing	419-7775
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5T-1362	Univ Joint As-5C	325-6011
5T-5682	Driver	418-9579
5T-8739	Spider Gp-Brg	373-5386
5V-1274	Spider	385-6110
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6E-6482	Pump Gp-Vn Bsc-B	422-8164
6H-2577	Spider Gp-Brg	333-4954
6I-1099	Manifold-Exh	424-6366

9FM		
Original Part Number	Part Name	Classic Part Number
6L-7751	Rod End-Spher	472-8015
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7G-3454	Gear-Planet	300-2578
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4990	Case-Xmsn	388-6561
7G-5445	Carrier-Planet	469-4669
7J-6250	Bearing-Sleeve	385-3803
7J-6869	Ring	389-6329
7J-6884	Shaft	387-2937
7J-9434	Shaft	380-7557
7J-9884	Bearing-Sleeve	325-6016

Sales Model 613C (Cont'd.)

9FM		
Original Part Number	Part Name	Classic Part Number
7S-4534	Bearing-Caged	417-9497
7V-8640	Spindle	424-4945
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8J-5014	Pin	384-4773
8K-6282	Gear-Sun	281-1698
8M-3368	Valve-Check	388-6599
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
9C-8205	Gear-Bevel	319-8175
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9J-3206	Bearing-Spher	360-2275

9FM		
Original Part Number	Part Name	Classic Part Number
9J-3741	Shaft	386-4933
9L-2685	Rod End	419-1866
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9V-8693	Actuator Gp-Bk	375-2629
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336

9FM		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-1740	Gear-Planet	377-7466
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
163-1387	Gear-Flywheel	374-4697
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2153	Pump As-Water	433-0444
441-9566	Gear-Flywheel	374-4703

9GM		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1H-5338	Cup-Roller Brg	374-8345

9GM		
Original Part Number	Part Name	Classic Part Number
2K-0227	Bearing-Sleeve	384-4780
2K-4502	Bearing-Sleeve	299-1986
4V-4852	Piston	433-0452

9GM		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5G-3612	Cap Gp-Protn	295-6419
5V-4573	Disc	388-0591
7T-2036	Cap As-Fuel	361-1721

Sales Model 613C (Cont'd.)

9GM		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
9W-3120	Pin As	393-3641

9GM		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028

9GM		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

KEH		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1B-3934	Cup-Roller Brg	392-4487
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3706	Pipe-Extension	434-6497
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7057	Gasket	420-6384
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1W-1064	Gear-Flywheel	374-4703
1W-4623	Muffler As	360-9622
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-5066	Cone-Roller Brg	396-4142

KEH		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
2K-5103	Cone-Roller Brg	380-7505
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2N-1599	Gear	378-3970
2P-8986	Cup-Rlr Bearing	415-1912
2T-0374	Pin	418-1952
2T-1581	Bearing-Sleeve	399-6051
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-2717	Cartridge Gp	439-1132
3G-7658	Cartridge Gp	426-0427
3G-7663	Cartridge Gp	422-8120
3J-2903	Cover	422-6922
3J-9133	Bearing-Sleeve	361-1691
3P-5672	Yoke	223-6313
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4D-2619	Bearing	417-4494
4E-8534	Retainer-Seal	300-2588

KEH		
Original Part Number	Part Name	Classic Part Number
4F-2041	Cup-Roller Brg	418-9609
4K-9598	Retainer	297-7235
4P-5433	Compressor As	419-4728
4P-5435	Compressor As	396-9942
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-6869	Cartridge Gp	422-8104
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5D-0470	Valve Gp-Qrel	314-8549
5J-9348	Bearing As	416-2162
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-0578	Bearing	419-7775
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467

Sales Model 613C (Cont'd.)

KEH		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
5T-1362	Univ Joint As-5C	325-6011
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6E-0775	Head	425-9373
6E-6482	Pump Gp-Vn Bsc-B	422-8164
6I-1099	Manifold-Exh	424-6366
6L-7751	Rod End-Spher	472-8015
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7G-3454	Gear-Planet	300-2578

KEH		
Original Part Number	Part Name	Classic Part Number
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4990	Case-Xmsn	388-6561
7G-5445	Carrier-Planet	469-4669
7J-5356	Guide Lh	416-5503
7J-6250	Bearing-Sleeve	385-3803
7J-6869	Ring	389-6329
7J-6884	Shaft	387-2937
7J-9434	Shaft	380-7557
7J-9884	Bearing-Sleeve	325-6016
7S-4534	Bearing-Caged	417-9497
7T-2036	Cap As-Fuel	361-1721
7V-5645	Rod-Indicator	397-5061
7V-8640	Spindle	424-4945
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8B-5972	Bearing-Ball	314-8503
8H-2810	Case As-Filter	314-8512
8I-1098	Shaft	396-7275
8J-5014	Pin	384-4773
8K-6282	Gear-Sun	281-1698
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
9C-8205	Gear-Bevel	319-8175
9G-1231	Plate	297-7232

KEH		
Original Part Number	Part Name	Classic Part Number
9G-1488	Housing-Clutch	430-7620
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9J-0105	Hub	415-1894
9J-3206	Bearing-Spher	360-2275
9J-3741	Shaft	386-4933
9L-2685	Rod End	419-1866
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9V-8693	Actuator Gp-Bk	375-2629
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336

Sales Model 613C (Cont'd.)

KEH		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-1740	Gear-Planet	377-7466
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
156-6237	Elbow As	396-1567
163-1387	Gear-Flywheel	374-4697

KEH		
Original Part Number	Part Name	Classic Part Number
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

KEH		
Original Part Number	Part Name	Classic Part Number
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2153	Pump As-Water	433-0444
441-9566	Gear-Flywheel	374-4703

TJK		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1B-3934	Cup-Roller Brg	392-4487
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3706	Pipe-Extension	434-6497
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7057	Gasket	420-6384
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864

TJK		
Original Part Number	Part Name	Classic Part Number
1W-1064	Gear-Flywheel	374-4703
1W-4623	Muffler As	360-9622
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5103	Cone-Roller Brg	380-7505
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2N-1599	Gear	378-3970
2P-8986	Cup-Rlr Bearing	415-1912
2T-0374	Pin	418-1952
2T-1581	Bearing-Sleeve	399-6051
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510

TJK		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-2717	Cartridge Gp	439-1132
3G-7658	Cartridge Gp	426-0427
3G-7663	Cartridge Gp	422-8120
3J-2903	Cover	422-6922
3J-9133	Bearing-Sleeve	361-1691
3P-5672	Yoke	223-6313
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4D-2619	Bearing	417-4494
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4K-9598	Retainer	297-7235
4P-5433	Compressor As	419-4728
4P-5435	Compressor As	396-9942

Sales Model 613C (Cont'd.)

TJK		
Original Part Number	Part Name	Classic Part Number
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-6869	Cartridge Gp	422-8104
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5D-0470	Valve Gp-Qrel	314-8549
5J-9348	Bearing As	416-2162
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-0578	Bearing	419-7775
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5T-1362	Univ Joint As-5C	325-6011
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6E-0775	Head	425-9373
6E-6482	Pump Gp-Vn Bsc-B	422-8164
6I-1099	Manifold-Exh	424-6366
6L-7751	Rod End-Spher	472-8015

TJK		
Original Part Number	Part Name	Classic Part Number
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7G-3454	Gear-Planet	300-2578
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4990	Case-Xmsn	388-6561
7G-5445	Carrier-Planet	469-4669
7J-5356	Guide Lh	416-5503
7J-6250	Bearing-Sleeve	385-3803
7J-6869	Ring	389-6329
7J-6884	Shaft	387-2937
7J-9434	Shaft	380-7557
7J-9884	Bearing-Sleeve	325-6016

TJK		
Original Part Number	Part Name	Classic Part Number
7S-4534	Bearing-Caged	417-9497
7T-2036	Cap As-Fuel	361-1721
7V-8640	Spindle	424-4945
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8B-5972	Bearing-Ball	314-8503
8I-1098	Shaft	396-7275
8J-5014	Pin	384-4773
8K-6282	Gear-Sun	281-1698
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
9C-8205	Gear-Bevel	319-8175
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9J-0105	Hub	415-1894
9J-3206	Bearing-Spher	360-2275
9J-3741	Shaft	386-4933
9L-2685	Rod End	419-1866
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9V-8693	Actuator Gp-Bk	375-2629
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756

Sales Model 613C (Cont'd.)

TJK		
Original Part Number	Part Name	Classic Part Number
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220

TJK		
Original Part Number	Part Name	Classic Part Number
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-1740	Gear-Planet	377-7466
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
156-6237	Elbow As	396-1567
163-1387	Gear-Flywheel	374-4697
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372

TJK		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2153	Pump As-Water	433-0444
441-9566	Gear-Flywheel	374-4703

Sales Model 613G

DBE		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1B-3934	Cup-Roller Brg	392-4487
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

DBE		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
2K-0535	Nut	299-2026
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5103	Cone-Roller Brg	380-7505
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2P-8986	Cup-Rlr Bearing	415-1912
2T-0374	Pin	418-1952

DBE		
Original Part Number	Part Name	Classic Part Number
2T-1581	Bearing-Sleeve	399-6051
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
3B-4124	Cup-Spl Tapered	422-6481
3G-2717	Cartridge Gp	439-1132
3G-7658	Cartridge Gp	426-0427
3G-7663	Cartridge Gp	422-8120
3J-2903	Cover	422-6922
3P-5672	Yoke	223-6313

Sales Model 613G (Cont'd.)

DBE		
Original Part Number	Part Name	Classic Part Number
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4K-9598	Retainer	297-7235
4T-6869	Cartridge Gp	422-8104
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-9348	Bearing As	416-2162
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-0578	Bearing	419-7775
5T-1362	Univ Joint As-5C	325-6011
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6E-0775	Head	425-9373

DBE		
Original Part Number	Part Name	Classic Part Number
6L-7751	Rod End-Spher	472-8015
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7G-0437	Plate-Clutch	417-9466
7G-3454	Gear-Planet	300-2578
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4990	Case-Xmsn	388-6561
7G-5445	Carrier-Planet	469-4669
7J-5356	Guide Lh	416-5503
7J-6250	Bearing-Sleeve	385-3803
7J-6869	Ring	389-6329
7J-6884	Shaft	387-2937
7J-9434	Shaft	380-7557
7J-9884	Bearing-Sleeve	325-6016
7S-4534	Bearing-Caged	417-9497
7V-8640	Spindle	424-4945
8B-5972	Bearing-Ball	314-8503
8J-5014	Pin	384-4773
8J-6536	Bearing	425-6444

DBE		
Original Part Number	Part Name	Classic Part Number
8K-6282	Gear-Sun	281-1698
8P-3563	Cage-Bearing	451-0747
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8Y-0809	Spider Gp-Brg	417-4526
9C-8205	Gear-Bevel	319-8175
9D-7924	Mount As	360-2356
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9J-3206	Bearing-Spher	360-2275
9J-3741	Shaft	386-4933
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
147-1740	Gear-Planet	377-7466
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

DBJ		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487

Sales Model 613G (Cont'd.)

DBJ		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
3J-9133	Bearing-Sleeve	361-1691
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
5J-9348	Bearing As	416-2162
5T-5682	Driver	418-9579
5V-4573	Disc	388-0591
6E-0775	Head	425-9373

DBJ		
Original Part Number	Part Name	Classic Part Number
7J-5356	Guide Lh	416-5503
7J-6250	Bearing-Sleeve	385-3803
7J-9884	Bearing-Sleeve	325-6016
8B-5972	Bearing-Ball	314-8503
8H-2810	Case As-Filter	314-8512
8I-1098	Shaft	396-7275
8J-6536	Bearing	425-6444
9J-0105	Hub	415-1894

DBJ		
Original Part Number	Part Name	Classic Part Number
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
156-6237	Elbow As	396-1567
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

DXA		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1B-3934	Cup-Roller Brg	392-4487
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
2K-0535	Nut	299-2026
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5103	Cone-Roller Brg	380-7505
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305

DXA		
Original Part Number	Part Name	Classic Part Number
2P-8986	Cup-Rlr Bearing	415-1912
2T-0374	Pin	418-1952
2T-1581	Bearing-Sleeve	399-6051
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
3B-4124	Cup-Spl Tapered	422-6481
3G-2717	Cartridge Gp	439-1132
3G-7658	Cartridge Gp	426-0427
3G-7663	Cartridge Gp	422-8120
3J-2903	Cover	422-6922
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4K-9598	Retainer	297-7235
4T-6869	Cartridge Gp	422-8104
4T-8054	Seal As	472-8010

DXA		
Original Part Number	Part Name	Classic Part Number
4V-4852	Piston	433-0452
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-0578	Bearing	419-7775
5T-1362	Univ Joint As-5C	325-6011
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6L-7751	Rod End-Spher	472-8015

Sales Model 613G (Cont'd.)

DXA		
Original Part Number	Part Name	Classic Part Number
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7G-0437	Plate-Clutch	417-9466
7G-3454	Gear-Planet	300-2578
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4990	Case-Xmsn	388-6561
7G-5445	Carrier-Planet	469-4669
7J-6250	Bearing-Sleeve	385-3803

DXA		
Original Part Number	Part Name	Classic Part Number
7J-6869	Ring	389-6329
7J-6884	Shaft	387-2937
7J-9434	Shaft	380-7557
7J-9884	Bearing-Sleeve	325-6016
7S-4534	Bearing-Caged	417-9497
7V-8640	Spindle	424-4945
8J-5014	Pin	384-4773
8K-6282	Gear-Sun	281-1698
8P-3563	Cage-Bearing	451-0747
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8Y-0809	Spider Gp-Brg	417-4526
9C-8205	Gear-Bevel	319-8175
9D-7924	Mount As	360-2356

DXA		
Original Part Number	Part Name	Classic Part Number
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-8117	Housing As-Cl	302-2686
9J-3206	Bearing-Spher	360-2275
9J-3741	Shaft	386-4933
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9W-9930	Mount As	295-6437
147-1740	Gear-Planet	377-7466
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

ESB		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1B-3934	Cup-Roller Brg	392-4487
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
2K-0535	Nut	299-2026

ESB		
Original Part Number	Part Name	Classic Part Number
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5103	Cone-Roller Brg	380-7505
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2P-8986	Cup-Rlr Bearing	415-1912
2T-0374	Pin	418-1952
2T-1581	Bearing-Sleeve	399-6051
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510

ESB		
Original Part Number	Part Name	Classic Part Number
3B-4124	Cup-Spl Tapered	422-6481
3G-2717	Cartridge Gp	439-1132
3G-7658	Cartridge Gp	426-0427
3G-7663	Cartridge Gp	422-8120
3J-2903	Cover	422-6922
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4K-9598	Retainer	297-7235
4T-6869	Cartridge Gp	422-8104

Sales Model 613G (Cont'd.)

ESB		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-9348	Bearing As	416-2162
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-0578	Bearing	419-7775
5T-1362	Univ Joint As-5C	325-6011
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6E-0775	Head	425-9373
6L-7751	Rod End-Spher	472-8015
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689

ESB		
Original Part Number	Part Name	Classic Part Number
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7G-0437	Plate-Clutch	417-9466
7G-3454	Gear-Planet	300-2578
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4990	Case-Xmsn	388-6561
7G-5445	Carrier-Planet	469-4669
7J-5356	Guide Lh	416-5503
7J-6250	Bearing-Sleeve	385-3803
7J-6869	Ring	389-6329
7J-6884	Shaft	387-2937
7J-9434	Shaft	380-7557
7J-9884	Bearing-Sleeve	325-6016
7S-4534	Bearing-Caged	417-9497
7V-8640	Spindle	424-4945
8B-5972	Bearing-Ball	314-8503
8H-2810	Case As-Filter	314-8512
8J-5014	Pin	384-4773
8J-6536	Bearing	425-6444
8K-6282	Gear-Sun	281-1698
8P-3563	Cage-Bearing	451-0747
8T-0072	Cone-Rlr Brg	377-7448

ESB		
Original Part Number	Part Name	Classic Part Number
8V-3134	Pinion-Bevel	260-0788
8Y-0809	Spider Gp-Brg	417-4526
9C-8205	Gear-Bevel	319-8175
9D-7924	Mount As	360-2356
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9J-3206	Bearing-Spher	360-2275
9J-3741	Shaft	386-4933
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
147-1740	Gear-Planet	377-7466
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

YCB		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482

Sales Model 613G (Cont'd.)

YCB		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
2K-0535	Nut	299-2026
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5103	Cone-Roller Brg	380-7505
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2T-0374	Pin	418-1952
2T-1581	Bearing-Sleeve	399-6051
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
3B-4124	Cup-Spl Tapered	422-6481
3G-2717	Cartridge Gp	439-1132
3G-7659	Cartridge Gp	422-8102
3J-2903	Cover	422-6922
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609

YCB		
Original Part Number	Part Name	Classic Part Number
4K-9598	Retainer	297-7235
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-0578	Bearing	419-7775
5T-1362	Univ Joint As-5C	325-6011
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6L-7751	Rod End-Spher	472-8015
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7G-0437	Plate-Clutch	417-9466
7G-3454	Gear-Planet	300-2578
7G-3707	Piston-Clutch	302-2691

YCB		
Original Part Number	Part Name	Classic Part Number
7G-4281	Housing As-Spt	297-7201
7G-4990	Case-Xmsn	388-6561
7G-5445	Carrier-Planet	469-4669
7J-4983	Cap-Bearing	384-3460
7J-6250	Bearing-Sleeve	385-3803
7J-6869	Ring	389-6329
7J-6884	Shaft	387-2937
7J-9434	Shaft	380-7557
7J-9884	Bearing-Sleeve	325-6016
7S-4534	Bearing-Caged	417-9497
7V-8640	Spindle	424-4945
8D-7086	Bearing	330-9251
8J-5014	Pin	384-4773
8K-6282	Gear-Sun	281-1698
8P-3563	Cage-Bearing	451-0747
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8Y-0809	Spider Gp-Brg	417-4526
9C-8205	Gear-Bevel	319-8175
9D-7924	Mount As	360-2356
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-8117	Housing As-Cl	302-2686
9J-3206	Bearing-Spher	360-2275
9J-3741	Shaft	386-4933
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9W-9930	Mount As	295-6437
147-1740	Gear-Planet	377-7466

Sales Model 613G (Cont'd.)

YCB		
Original Part Number	Part Name	Classic Part Number
155-6648	Cone Spl Rol Brg	418-9599

YCB		
Original Part Number	Part Name	Classic Part Number
176-9273	Piston	297-4860
289-2935	Seal As-Buffer	472-8028

YCB		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 613H

XLM		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2K-0535	Nut	299-2026
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5103	Cone-Roller Brg	380-7505
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2T-0374	Pin	418-1952
2T-1581	Bearing-Sleeve	399-6051
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
3B-4124	Cup-Spl Tapered	422-6481

XLM		
Original Part Number	Part Name	Classic Part Number
3J-2903	Cover	422-6922
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4K-9598	Retainer	297-7235
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7543	Retainer	281-1699
4V-7545	Gear-Ring	394-9823
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-9348	Bearing As	416-2162
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-0578	Bearing	419-7775
5T-1362	Univ Joint As-5C	325-6011

XLM		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6E-0775	Head	425-9373
6L-7751	Rod End-Spher	472-8015
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7G-3454	Gear-Planet	300-2578
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4990	Case-Xmsn	388-6561
7G-5445	Carrier-Planet	469-4669
7J-5356	Guide Lh	416-5503
7J-6250	Bearing-Sleeve	385-3803

Sales Model 613H (Cont'd.)

XLM		
Original Part Number	Part Name	Classic Part Number
7J-6869	Ring	389-6329
7J-6884	Shaft	387-2937
7J-9434	Shaft	380-7557
7J-9884	Bearing-Sleeve	325-6016
7S-4534	Bearing-Caged	417-9497
7V-8640	Spindle	424-4945
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8J-5014	Pin	384-4773
8J-6536	Bearing	425-6444
8K-6282	Gear-Sun	281-1698
8P-3563	Cage-Bearing	451-0747

XLM		
Original Part Number	Part Name	Classic Part Number
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8Y-0809	Spider Gp-Brg	417-4526
9C-8205	Gear-Bevel	319-8175
9D-7924	Mount As	360-2356
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-8117	Housing As-Cl	302-2686
9J-3206	Bearing-Spher	360-2275
9J-3741	Shaft	386-4933
9N-4460	Housing As-Cl	297-7203
9W-9930	Mount As	295-6437

XLM		
Original Part Number	Part Name	Classic Part Number
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
138-2317	Wheel	396-9948
147-1740	Gear-Planet	377-7466
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 615

46Z		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147

46Z		
Original Part Number	Part Name	Classic Part Number
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340

46Z		
Original Part Number	Part Name	Classic Part Number
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-4738	Bearing-Sleeve	325-6020
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221

Sales Model 615 (Cont'd.)

46Z		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0227	Bearing-Sleeve	384-4780
2K-0535	Nut	299-2026
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230

46Z		
Original Part Number	Part Name	Classic Part Number
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5714	Gear-Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5536	Core As-Radiator	380-7554
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3G-2752	Cartridge Gp-Rr	422-8127
3G-4704	Bearing-Sleeve	379-0185
3G-7412	Pump Gp-Vn Bsc-B	422-8167
3G-7661	Cartridge Gp	422-8113

46Z		
Original Part Number	Part Name	Classic Part Number
3J-2373	Bearing-Sleeve	380-7562
3J-9133	Bearing-Sleeve	361-1691
3K-2511	Dowel-Reaction	383-2126
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
3Y-2768	Ring	439-4544
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4E-3456	Lever As	367-6081
4E-8534	Retainer-Seal	300-2588
4E-8535	Retainer-Seal	300-2589
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4J-5694	Bearing-Sleeve	379-0190
4K-7270	Support-Trunnion	373-5384
4K-7463	Seal-Lip Type	472-8007
4K-9598	Retainer	297-7235
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-8344	Spider As-Fan	416-5520
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

Sales Model 615 (Cont'd.)

46Z		
Original Part Number	Part Name	Classic Part Number
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4T-6869	Cartridge Gp	422-8104
4T-8054	Seal As	472-8010
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-5454	Link	299-2025
4V-7543	Retainer	281-1699
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534

46Z		
Original Part Number	Part Name	Classic Part Number
5D-2989	Bearing	380-7511
5F-7958	Shaft-Roller	434-1865
5G-3612	Cap Gp-Protn	295-6419
5J-1806	Pin	396-0662
5J-1825	Pin	367-6080
5J-6611	Bearing-Sleeve	383-2140
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-2051	Bearing-Caged	380-7467
5M-6212	Tube	390-0996
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5411	Race-Brg Outer	417-9481
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437

46Z		
Original Part Number	Part Name	Classic Part Number
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3617	Support-Trunnion	374-4712
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574

Sales Model 615 (Cont'd.)

46Z		
Original Part Number	Part Name	Classic Part Number
6V-5003	Bearing-Aligning	420-2498
6W-5119	Housing-Support	450-8051
6Y-1690	Carrier-Ring	384-3849
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-6869	Ring	389-6329
7J-8893	Cone-Roller Brg	374-1846
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848

46Z		
Original Part Number	Part Name	Classic Part Number
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7T-3370	Yoke As	302-2702
7T-9542	Gear-Ring	384-4822
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8C-3111	Rod End-Spher	392-4523
8C-8741	Kit-Gasket-(Rs)	438-0172
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512

46Z		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-0278	Bearing-Sleeve	385-3808
8J-7596	Bearing-Sleeve	361-1693
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585

Sales Model 615 (Cont'd.)

46Z		
Original Part Number	Part Name	Classic Part Number
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9523	Elbow	425-2566
8P-0953	Turbine-Conv	297-7269
8P-0961	Impeller-Conv	433-9204
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-0931	Housing-Pinion	302-4300
8R-0942	Plate-Reaction	380-1484
8R-1015	Support-Trunnion	374-4712
8R-1088	Bearing-Sleeve	419-0885
8R-3252	Shaft-Planet	297-7259
8R-8335	Gear-Bevel	368-0105
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501

46Z		
Original Part Number	Part Name	Classic Part Number
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-6390	Drum-Brake	377-7449
8V-7659	Pin As	361-1702
8W-4523	Bearing-Sleeve	385-3798
9C-4007	Bearing-Sleeve	374-1459
9C-5852	Hub As	297-7208
9C-6029	Bearing-Planet	375-9982
9C-8205	Gear-Bevel	319-8175
9C-8669	Shaft-Bev Pinion	368-0107
9C-9191	Trunnion	302-2701
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9L-2685	Rod End	419-1866
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9P-8517	Case-Xmsn	394-0909
9S-7079	Muffler As	247-2669

46Z		
Original Part Number	Part Name	Classic Part Number
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9T-7916	Pump Gp-Vn Bsc-B	426-1697
9U-2787	Gear-Planet	367-6093
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-5160	Plunger Kt-Adj	385-7218
9W-3605	Carrier-Ring	314-8662
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-3596	Piston	380-1511
100-3597	Plate-Reaction	380-1501
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-7689	Yoke As	422-7245
110-1337	Ring Kit-Pstn	377-5834
110-1488	Gear-Ring	394-0882
111-8015	Gasket As-Head	279-4977
115-4072	Bearing	397-5069
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
139-9175	Gasket Kit	377-7464

Sales Model 615 (Cont'd.)

46Z		
Original Part Number	**Part Name**	**Classic Part Number**
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-1206	Gear Planet	418-9597
148-7455	Valve - Exhaust	270-4361
148-9288	Case As-Diff	380-1496
151-4836	Diff Gp -A	416-2120
160-1400	Yoke (1710)	319-3479
161-3411	Gasket	394-0896
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194

46Z		
Original Part Number	**Part Name**	**Classic Part Number**
169-4200	Gasket	472-8023
170-0560	Rebuild Kit-Pump	363-7458
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
190-3832	Core As-Oclr	438-3251

46Z		
Original Part Number	**Part Name**	**Classic Part Number**
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1370	Bearing-Sleeve	380-7370
228-0419	Seal As	443-3571
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
282-4348	Kit-Dt Gasket	419-8665
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-1032	Disc-Friction	440-3116
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

47Z		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114

47Z		
Original Part Number	**Part Name**	**Classic Part Number**
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924

47Z		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1282	Race-Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006

Sales Model 615 (Cont'd.)

47Z		
Original Part Number	Part Name	Classic Part Number
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2K-0227	Bearing-Sleeve	384-4780
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454

47Z		
Original Part Number	Part Name	Classic Part Number
2P-2788	Adapter-Fan	390-0984
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2T-3885	Housing	448-4967
2V-5656	Ring-Snap	374-1454
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-7482	Sleeve	425-3455
3J-2373	Bearing-Sleeve	380-7562
3J-9133	Bearing-Sleeve	361-1691
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4J-5693	Bearing-Sleeve	385-3790

47Z		
Original Part Number	Part Name	Classic Part Number
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4K-9598	Retainer	297-7235
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4W-0452	Seal As -Cshaft	325-6191
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511

Sales Model 615 (Cont'd.)

47Z		
Original Part Number	Part Name	Classic Part Number
5F-7958	Shaft-Roller	434-1865
5G-3612	Cap Gp-Protn	295-6419
5J-1825	Pin	367-6080
5J-6611	Bearing-Sleeve	383-2140
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-2051	Bearing-Caged	380-7467
5M-6212	Tube	390-0996
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5411	Race-Brg Outer	417-9481
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rock-er Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-5917	Pinion-Diff	297-7224

47Z		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6Y-1690	Carrier-Ring	384-3849
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7724	Piston-Clutch	283-5206
7J-8893	Cone-Roller Brg	374-1846
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435

47Z		
Original Part Number	Part Name	Classic Part Number
7N-1164	Mount As	295-5451
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7T-9542	Gear-Ring	384-4822
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5972	Bearing-Ball	314-8503
8C-8741	Kit-Gasket-(Rs)	438-0172
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-6536	Bearing	425-6444
8J-6552	Carrier-Bearing	399-6055

Sales Model 615 (Cont'd.)

47Z		
Original Part Number	Part Name	Classic Part Number
8J-7211	Guide-Lh	428-8815
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

47Z		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8V-6390	Drum-Brake	377-7449
9C-5852	Hub As	297-7208
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214

47Z		
Original Part Number	Part Name	Classic Part Number
9G-0285	Piston	283-5215
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9P-8517	Case-Xmsn	394-0909
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9V-5160	Plunger Kt-Adj	385-7218
9W-3605	Carrier-Ring	314-8662
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-7689	Yoke As	422-7245
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Brg Kt	380-1554
144-0744	Compressor Gp -B	435-6046
144-7299	Roller As	434-1991
147-1206	Gear Planet	418-9597
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

Sales Model 615 (Cont'd.)

47Z		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0560	Rebuild Kit-Pump	363-7458
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201

47Z		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259

47Z		
Original Part Number	Part Name	Classic Part Number
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
310-3510	Roller As.	434-1919
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 615C

2XG		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786

2XG		
Original Part Number	Part Name	Classic Part Number
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358

2XG		
Original Part Number	Part Name	Classic Part Number
1W-4506	Adapter-Seal	372-7515
1W-4738	Bearing-Sleeve	325-6020
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

Sales Model 615C (Cont'd.)

2XG		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0227	Bearing-Sleeve	384-4780
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2T-3885	Housing	448-4967
2V-5656	Ring-Snap	374-1454

2XG		
Original Part Number	Part Name	Classic Part Number
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2752	Cartridge Gp-Rr	422-8127
3G-7482	Sleeve	425-3455
3G-7661	Cartridge Gp	422-8113
3G-7667	Cartridge Gp	422-8107
3J-2373	Bearing-Sleeve	380-7562
3J-9133	Bearing-Sleeve	361-1691
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922

2XG		
Original Part Number	Part Name	Classic Part Number
4K-7463	Seal-Lip Type	472-8007
4K-9598	Retainer	297-7235
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-6869	Cartridge Gp	422-8104
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5363	Core Gp-O Clr	380-7531

Sales Model 615C (Cont'd.)

2XG		
Original Part Number	Part Name	Classic Part Number
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5F-7958	Shaft-Roller	434-1865
5G-3612	Cap Gp-Protn	295-6419
5J-1806	Pin	396-0662
5J-1825	Pin	367-6080
5J-6611	Bearing-Sleeve	383-2140
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-2051	Bearing-Caged	380-7467
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5411	Race-Brg Outer	417-9481
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

2XG		
Original Part Number	Part Name	Classic Part Number
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6E-4730	Pump Gp-Vn Bsc-B	426-1925
6E-6483	Pump Gp-Vn Bsc-B	422-8176
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-5003	Bearing-Aligning	420-2498
6Y-1690	Carrier-Ring	384-3849

2XG		
Original Part Number	Part Name	Classic Part Number
6Y-3484	Bearing-Spl Ball	416-2166
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7J-1309	Bearing-Aligning	360-2275
7J-6869	Ring	389-6329
7J-8893	Cone-Roller Brg	374-1846
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994

Sales Model 615C (Cont'd.)

2XG		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7T-9542	Gear-Ring	384-4822
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8B-5972	Bearing-Ball	314-8503
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-8829	Bearing-Sleeve	361-1692
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-6536	Bearing	425-6444
8J-6552	Carrier-Bearing	399-6055
8J-7211	Guide-Lh	428-8815
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8M-3368	Valve-Check	388-6599

2XG		
Original Part Number	Part Name	Classic Part Number
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

2XG		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9523	Elbow	425-2566
8P-0953	Turbine-Conv	297-7269
8P-0961	Impeller-Conv	433-9204
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8V-6390	Drum-Brake	377-7449
8W-4523	Bearing-Sleeve	385-3798

Sales Model 615C (Cont'd.)

2XG		
Original Part Number	Part Name	Classic Part Number
9C-5852	Hub As	297-7208
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9K-1171	Cup-Rlr Bearing	430-3339
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9P-8517	Case-Xmsn	394-0909
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9T-7916	Pump Gp-Vn Bsc-B	426-1697
9V-5160	Plunger Kt-Adj	385-7218
9W-3605	Carrier-Ring	314-8662
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-7689	Yoke As	422-7245
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
115-4072	Bearing	397-5069
128-3935	Bearing-Race	396-9897
131-3815	Seal Gp-Basic	325-6193

2XG		
Original Part Number	Part Name	Classic Part Number
136-7813	Bearing-Race	460-8296
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
144-7299	Roller As	434-1991
147-1206	Gear Planet	418-9597
148-3465	Pin	383-2112
148-7455	Valve - Exhaust	270-4361
161-3411	Gasket	394-0896
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687

2XG		
Original Part Number	Part Name	Classic Part Number
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
223-1101	Kit-Dt Gasket	451-1505
232-3233	Bearing-Main	376-9085
262-4338	Kit - Dt Gasket	451-1508
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
310-3510	Roller As.	434-1919
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 615C (Cont'd.)

5TF		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-4738	Bearing-Sleeve	325-6020
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036

5TF		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0227	Bearing-Sleeve	384-4780
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197

5TF		
Original Part Number	Part Name	Classic Part Number
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2T-3885	Housing	448-4967
2V-5656	Ring-Snap	374-1454
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2752	Cartridge Gp-Rr	422-8127
3G-7482	Sleeve	425-3455
3G-7661	Cartridge Gp	422-8113
3G-7667	Cartridge Gp	422-8107
3J-2373	Bearing-Sleeve	380-7562
3J-9133	Bearing-Sleeve	361-1691
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4F-2041	Cup-Roller Brg	418-9609

Sales Model 615C (Cont'd.)

5TF		
Original Part Number	Part Name	Classic Part Number
4F-2393	Bearing-Ball	380-1499
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4K-9598	Retainer	297-7235
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-6869	Cartridge Gp	422-8104
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177

5TF		
Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5F-7958	Shaft-Roller	434-1865
5G-3612	Cap Gp-Protn	295-6419
5J-1806	Pin	396-0662
5J-1825	Pin	367-6080
5J-6611	Bearing-Sleeve	383-2140
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-2051	Bearing-Caged	380-7467
5M-6212	Tube	390-0996
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5411	Race-Brg Outer	417-9481
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467

5TF		
Original Part Number	Part Name	Classic Part Number
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6E-4730	Pump Gp-Vn Bsc-B	426-1925
6E-6483	Pump Gp-Vn Bsc-B	422-8176
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574

Sales Model 615C (Cont'd.)

5TF		
Original Part Number	Part Name	Classic Part Number
6V-5003	Bearing-Aligning	420-2498
6Y-1690	Carrier-Ring	384-3849
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7J-1309	Bearing-Aligning	360-2275
7J-6869	Ring	389-6329
7J-8893	Cone-Roller Brg	374-1846
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964

5TF		
Original Part Number	Part Name	Classic Part Number
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7T-9542	Gear-Ring	384-4822
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8B-5972	Bearing-Ball	314-8503
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-8829	Bearing-Sleeve	361-1692
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-6536	Bearing	425-6444
8J-6552	Carrier-Bearing	399-6055
8J-7211	Guide-Lh	428-8815
8J-7596	Bearing-Sleeve	361-1693

5TF		
Original Part Number	Part Name	Classic Part Number
8J-7727	Pin	380-7552
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

Sales Model 615C (Cont'd.)

5TF		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9523	Elbow	425-2566
8P-0953	Turbine-Conv	297-7269
8P-0961	Impeller-Conv	433-9204
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448

5TF		
Original Part Number	Part Name	Classic Part Number
8T-1622	Gasket Kit - Sch	436-8388
8V-6390	Drum-Brake	377-7449
8W-4523	Bearing-Sleeve	385-3798
9C-5852	Hub As	297-7208
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9P-8517	Case-Xmsn	394-0909
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9T-7916	Pump Gp-Vn Bsc-B	426-1697
9V-5160	Plunger Kt-Adj	385-7218
9W-3605	Carrier-Ring	314-8662
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-7689	Yoke As	422-7245
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
115-4072	Bearing	397-5069
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
139-9175	Gasket Kit	377-7464

5TF		
Original Part Number	Part Name	Classic Part Number
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
144-7299	Roller As	434-1991
147-1206	Gear Planet	418-9597
148-3465	Pin	383-2112
148-7455	Valve - Exhaust	270-4361
161-3411	Gasket	394-0896
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574

Sales Model 615C (Cont'd.)

5TF		
Original Part Number	Part Name	Classic Part Number
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259

5TF		
Original Part Number	Part Name	Classic Part Number
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
282-4348	Kit-Dt Gasket	419-8665
296-1359	Line As-Cla	279-4988

5TF		
Original Part Number	Part Name	Classic Part Number
296-1360	Line As-Cla	279-4989
310-3510	Roller As.	434-1919
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

9XG		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

9XG		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-4738	Bearing-Sleeve	325-6020
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354

9XG		
Original Part Number	Part Name	Classic Part Number
2G-1034	Valve-Safety	380-7555
2K-0227	Bearing-Sleeve	384-4780
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

Sales Model 615C (Cont'd.)

9XG		
Original Part Number	Part Name	Classic Part Number
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2T-3885	Housing	448-4967
2V-5656	Ring-Snap	374-1454
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2752	Cartridge Gp-Rr	422-8127
3G-7482	Sleeve	425-3455
3G-7661	Cartridge Gp	422-8113
3G-7667	Cartridge Gp	422-8107
3G-8136	Retainer	425-3585
3J-2373	Bearing-Sleeve	380-7562
3J-9133	Bearing-Sleeve	361-1691
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356

9XG		
Original Part Number	Part Name	Classic Part Number
3P-3208	Flange-Joint	301-4647
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4E-3456	Lever As	367-6081
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4K-9598	Retainer	297-7235
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009

9XG		
Original Part Number	Part Name	Classic Part Number
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-6869	Cartridge Gp	422-8104
4T-8054	Seal As	472-8010
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2541	Shaft-Gov Cont	399-8580
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5F-7958	Shaft-Roller	434-1865
5G-3612	Cap Gp-Protn	295-6419
5J-1806	Pin	396-0662
5J-1825	Pin	367-6080

Sales Model 615C (Cont'd.)

9XG		
Original Part Number	Part Name	Classic Part Number
5J-6611	Bearing-Sleeve	383-2140
5K-8591	Bearing-Outer	380-7502
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-3490	Cone-Rlr Bearing	380-7518
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247

9XG		
Original Part Number	Part Name	Classic Part Number
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5V-5917	Pinion-Diff	297-7224
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6E-2387	Cartridge Gp	422-8132
6E-2396	Cartridge Gp	422-8122
6E-4730	Pump Gp-Vn Bsc-B	426-1925
6E-6483	Pump Gp-Vn Bsc-B	422-8176
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544

9XG		
Original Part Number	Part Name	Classic Part Number
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6V-5003	Bearing-Aligning	420-2498
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
7C-4297	Seal As-Cshaft	325-6192
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7J-1309	Bearing-Aligning	360-2275
7J-6250	Bearing-Sleeve	385-3803
7J-6869	Ring	389-6329
7J-8893	Cone-Roller Brg	374-1846
7J-9884	Bearing-Sleeve	325-6016
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816

Sales Model 615C (Cont'd.)

9XG		
Original Part Number	Part Name	Classic Part Number
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7T-3370	Yoke As	302-2702
7T-4754	Impeller-Conv	385-7231
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8B-5972	Bearing-Ball	314-8503
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-8829	Bearing-Sleeve	361-1692

9XG		
Original Part Number	Part Name	Classic Part Number
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-6536	Bearing	425-6444
8J-6552	Carrier-Bearing	399-6055
8J-7211	Guide-Lh	428-8815
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8L-4282	Hub	444-0573
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842

9XG		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9523	Elbow	425-2566
8P-0953	Turbine-Conv	297-7269
8P-0961	Impeller-Conv	433-9204
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212

Sales Model 615C (Cont'd.)

9XG		
Original Part Number	Part Name	Classic Part Number
8R-3921	Collet	308-9839
8R-3943	Collet	308-9840
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8T-1622	Gasket Kit - Sch	436-8388
8V-6390	Drum-Brake	377-7449
8W-4523	Bearing-Sleeve	385-3798
9C-5852	Hub As	297-7208
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-1676	Bearing-Sleeve	380-7378
9J-9427	Bearing-Sleeve	361-1695

9XG		
Original Part Number	Part Name	Classic Part Number
9L-2685	Rod End	419-1866
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9T-7916	Pump Gp-Vn Bsc-B	426-1697
9V-5160	Plunger Kt-Adj	385-7218
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605

9XG		
Original Part Number	Part Name	Classic Part Number
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-7689	Yoke As	422-7245
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
131-3815	Seal Gp-Basic	325-6193
134-3038	Gasket Kit	437-3228
136-7813	Bearing-Race	460-8296
139-9175	Gasket Kit	377-7464
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
144-7299	Roller As	434-1991
147-1206	Gear Planet	418-9597
148-3465	Pin	383-2112
148-7455	Valve - Exhaust	270-4361
161-3411	Gasket	394-0896
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127

Sales Model 615C (Cont'd.)

9XG		
Original Part Number	Part Name	Classic Part Number
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

9XG		
Original Part Number	Part Name	Classic Part Number
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
187-0605	Gasket Kit - Cl	382-5055
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351

9XG		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
282-4348	Kit-Dt Gasket	419-8665
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-3510	Roller As.	434-1919
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 615D

BAE		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

BAE		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

BAE		
Original Part Number	Part Name	Classic Part Number
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346

Sales Model 615D (Cont'd.)

BAE		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2788	Adapter-Fan	390-0984
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2V-5656	Ring-Snap	374-1454
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3K-2511	Dowel-Reaction	383-2126
3P-3208	Flange-Joint	301-4647
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499

BAE		
Original Part Number	Part Name	Classic Part Number
4K-9598	Retainer	297-7235
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511

BAE		
Original Part Number	Part Name	Classic Part Number
5J-6611	Bearing-Sleeve	383-2140
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-6212	Tube	390-0996
5P-2526	Cup-Rlr Bearing	380-7498
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5411	Race-Brg Outer	417-9481
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475

Sales Model 615D (Cont'd.)

BAE		
Original Part Number	Part Name	Classic Part Number
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6Y-1690	Carrier-Ring	384-3849
7C-4297	Seal As-Cshaft	325-6192
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7724	Piston-Clutch	283-5206
7J-8893	Cone-Roller Brg	374-1846
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964

BAE		
Original Part Number	Part Name	Classic Part Number
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349

BAE		
Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9523	Elbow	425-2566
8P-0953	Turbine-Conv	297-7269
8P-0961	Impeller-Conv	433-9204
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8V-6390	Drum-Brake	377-7449

Sales Model 615D (Cont'd.)

BAE		
Original Part Number	Part Name	Classic Part Number
9C-5852	Hub As	297-7208
9G-0280	Piston	283-5213
9L-5908	Gasket	433-8196
9P-8517	Case-Xmsn	394-0909
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-5160	Plunger Kt-Adj	385-7218
9W-3605	Carrier-Ring	314-8662
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-7689	Yoke As	422-7245
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
144-0502	Ring Kit-Piston	395-1312

BAE		
Original Part Number	Part Name	Classic Part Number
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-1206	Gear Planet	418-9597
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

BAE		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

BBK		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
2B-0941	Spacer	418-1955
2T-3885	Housing	448-4967
3G-7482	Sleeve	425-3455
3J-2903	Cover	422-6922
3J-9133	Bearing-Sleeve	361-1691

BBK		
Original Part Number	Part Name	Classic Part Number
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4F-2041	Cup-Roller Brg	418-9609
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922

BBK		
Original Part Number	Part Name	Classic Part Number
5F-7958	Shaft-Roller	434-1865
5M-9644	Bearing-Outer	384-5929
7K-5448	Cup-Bearing	415-1922
7T-2036	Cap As-Fuel	361-1721
8H-2810	Case As-Filter	314-8512
8J-6552	Carrier-Bearing	399-6055
8J-7211	Guide-Lh	428-8815

Sales Model 615D (Cont'd.)

BBK		
Original Part Number	Part Name	Classic Part Number
8V-6390	Drum-Brake	377-7449
9S-8184	Pin-Drawbar	398-8345
9V-5160	Plunger Kt-Adj	385-7218

BBK		
Original Part Number	Part Name	Classic Part Number
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
325-3291	Roller As	434-1918

Sales Model 619C

61F		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-0090	Gasket-Manifold	445-7701
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
1U-2669	Cartridge Gp	422-8118
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-9130	Washer-Thrust	308-9943
2D-9191	Cone-Roller Brg	374-1837
2H-3517	Bearing-Inner	417-4505
2L-5271	Bearing-Ball	371-4305
2M-8340	Rod End-Yoke	374-4678
2S-3966	Ring-Seal	297-7237
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979

61F		
Original Part Number	Part Name	Classic Part Number
3D-5315	Pinion-Dif Bevel	308-9856
3D-9126	Cup-Roller Brg	399-4435
3G-2720	Cartridge Gp-Rr	448-5051
3G-2749	Cartridge Gp-Rr	422-8125
3G-7662	Cartridge Gp	422-8105
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3S-5017	Elbow-Exhaust	369-9498
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-3882	Cone-Roller Brg	399-6060
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391

61F		
Original Part Number	Part Name	Classic Part Number
4S-5367	Mount As	375-9986
4T-1893	Cartridge Gp	422-8110
4T-6869	Cartridge Gp	422-8104
5D-0470	Valve Gp-Qrel	314-8549
5D-7449	Cup-Spl Tapered	416-2161
5D-9675	Spider	394-9203
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-7958	Shaft-Roller	434-1865
5F-8651	Bearing-Ball	420-3223
5M-2054	Bearing	380-7510
5M-2824	Coupling-Exhaust	431-5270
5M-3560	Bearing-Sleeve	392-4521
5M-7925	Bearing-Roller	419-7774
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635

Sales Model 619C (Cont'd.)

61F		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
5T-8739	Spider Gp-Brg	373-5386
6H-2577	Spider Gp-Brg	333-4954
6N-9211	Core As-O Clr	435-6049
6V-2202	Bearing-Spl Ball	380-1574
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2496	Gear-Planet	446-3071
7H-6967	Bearing-Ball	422-6489
7M-4358	Manifold-Exhaust	261-0907
7M-7219	Bearing-Thrust	384-4816

61F		
Original Part Number	Part Name	Classic Part Number
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8H-5026	Cover-Adj Pulley	445-7698
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439

61F		
Original Part Number	Part Name	Classic Part Number
8M-3368	Valve-Check	388-6599
8N-4445	Pipe-Exhaust Ext	386-3061
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3517	Bearing-Spl Ball	417-4501
8S-9686	Gasket Kit	393-5215
9M-8395	Bearing-Sleeve	391-1103
9T-2200	Cartridgr Gp	422-8114
9T-5096	Flexplate	455-3271
101-1504	Shaft	373-5379
128-3935	Bearing-Race	396-9897

62F		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-0090	Gasket-Manifold	445-7701
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-9130	Washer-Thrust	308-9943
2D-9191	Cone-Roller Brg	374-1837
2L-5271	Bearing-Ball	371-4305

62F		
Original Part Number	Part Name	Classic Part Number
2M-8340	Rod End-Yoke	374-4678
2S-3966	Ring-Seal	297-7237
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
3D-5315	Pinion-Dif Bevel	308-9856
3G-2720	Cartridge Gp-Rr	448-5051
3G-2749	Cartridge Gp-Rr	422-8125
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3S-5017	Elbow-Exhaust	369-9498
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334

62F		
Original Part Number	Part Name	Classic Part Number
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4F-2041	Cup-Roller Brg	418-9609
4M-9215	Gear-Pump Idler	311-9391
4S-5367	Mount As	375-9986
4T-1893	Cartridge Gp	422-8110
4T-6869	Cartridge Gp	422-8104
5D-0470	Valve Gp-Qrel	314-8549
5D-7449	Cup-Spl Tapered	416-2161
5D-9675	Spider	394-9203
5F-2465	Cup-Roller Brg	447-8060

Sales Model 619C (Cont'd.)

62F		
Original Part Number	Part Name	Classic Part Number
5F-2830	Bearing-Needle	384-5925
5F-7958	Shaft-Roller	434-1865
5M-2824	Coupling-Exhaust	431-5270
5M-3560	Bearing-Sleeve	392-4521
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635
5T-5682	Driver	418-9579
5T-8739	Spider Gp-Brg	373-5386
6H-2577	Spider Gp-Brg	333-4954

62F		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7M-4358	Manifold-Exhaust	261-0907
7M-7219	Bearing-Thrust	384-4816
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250

62F		
Original Part Number	Part Name	Classic Part Number
8H-5026	Cover-Adj Pulley	445-7698
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8N-4445	Pipe-Exhaust Ext	386-3061
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-9686	Gasket Kit	393-5215
9T-2200	Cartridgr Gp	422-8114
9T-5096	Flexplate	455-3271
101-1504	Shaft	373-5379

68F		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
2K-0227	Bearing-Sleeve	384-4780

68F		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925

68F		
Original Part Number	Part Name	Classic Part Number
5F-7958	Shaft-Roller	434-1865
5T-5682	Driver	418-9579
7F-7780	Pin-Anchor	384-4825
8W-1708	Pin	388-0643
308-1845	Seal-Wiper	472-8032

Sales Model 621

15U		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913

15U		
Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572

15U		
Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

Sales Model 621 (Cont'd.)

15U		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197

15U		
Original Part Number	Part Name	Classic Part Number
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3L-1425	Bearing-Ball	311-9356
4D-2619	Bearing	417-4494
4N-0432	Bearing-Ball	417-4499
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986

15U		
Original Part Number	Part Name	Classic Part Number
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rock-er Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-2202	Bearing-Spl Ball	380-1574
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192

Sales Model 621 (Cont'd.)

15U		
Original Part Number	Part Name	Classic Part Number
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-3536	Gear-Fuel	279-4993
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512

15U		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585

15U		
Original Part Number	Part Name	Classic Part Number
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
9H-5797	Plunger As-Pump	391-9891
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165

Sales Model 621 (Cont'd.)

15U		
Original Part Number	Part Name	Classic Part Number
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

15U		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698

15U		
Original Part Number	Part Name	Classic Part Number
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

23H		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1J-6746	Pin	256-4817
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401

23H		
Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797

23H		
Original Part Number	Part Name	Classic Part Number
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

Sales Model 621 (Cont'd.)

23H		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-5233	Bearing-Thrust	388-0578
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2719	Pipe-Oil Filler	363-7454

23H		
Original Part Number	Part Name	Classic Part Number
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3G-7660	Cartridge Gp	422-8103
3G-7666	Cartridge Gp	422-8098
3H-7161	Pin	256-4819
3H-8726	Mount As	385-7208
3J-3953	Bearing-Sleeve	384-4778
3J-5190	Cap-Brg	256-4837
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3R-5327	Pipe-Extension	383-1571

23H		
Original Part Number	Part Name	Classic Part Number
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-9215	Gear-Pump Idler	311-9391
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763

Sales Model 621 (Cont'd.)

23H		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5367	Mount As	375-9986
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5J-0778	Cyl Gp-184 597 Y	399-8544

23H		
Original Part Number	Part Name	Classic Part Number
5J-1449	Pin As	393-3671
5J-1806	Pin	396-0662
5J-1825	Pin	367-6080
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-6611	Bearing-Sleeve	383-2140
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5K-2294	Bearing	396-9912
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

23H		
Original Part Number	Part Name	Classic Part Number
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6H-2577	Spider Gp-Brg	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7H-6967	Bearing-Ball	422-6489
7J-1770	Cap-Bearing	396-0664
7J-8458	Bearing-Sleeve	380-7374

Sales Model 621 (Cont'd.)

23H		
Original Part Number	Part Name	Classic Part Number
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417

23H		
Original Part Number	Part Name	Classic Part Number
7W-0205	Core As-Oclr	379-0183
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

23H		
Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198

Sales Model 621 (Cont'd.)

23H		
Original Part Number	Part Name	Classic Part Number
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9H-5797	Plunger As-Pump	391-9891
9J-9427	Bearing-Sleeve	361-1695
9M-3914	Bearing-Aligning	420-2501
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9W-4662	Disc-Friction	428-7203
9Y-1798	Seal-Water	379-0165

23H		
Original Part Number	Part Name	Classic Part Number
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
118-7805	Pinion-Bevel	394-9197
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201

23H		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
187-0605	Gasket Kit - Cl	382-5055
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 621 (Cont'd.)

37G		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1J-6746	Pin	256-4817
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-5233	Bearing-Thrust	388-0578
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532

37G		
Original Part Number	Part Name	Classic Part Number
2S-4900	Shaft As	384-4792
2S-5551	Coupling-Exhaust	398-2934
2S-6150	Cover-Pulley	428-8817
3G-7660	Cartridge Gp	422-8103
3G-7666	Cartridge Gp	422-8098
3H-7161	Pin	256-4819
3H-8726	Mount As	385-7208
3J-3953	Bearing-Sleeve	384-4778
3J-5190	Cap-Brg	256-4837
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3R-5327	Pipe-Extension	383-1571
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922

37G		
Original Part Number	Part Name	Classic Part Number
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-9215	Gear-Pump Idler	311-9391
4S-5367	Mount As	375-9986
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-5363	Core Gp-O Clr	380-7531
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1806	Pin	396-0662
5J-1825	Pin	367-6080
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-6611	Bearing-Sleeve	383-2140
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5K-2294	Bearing	396-9912
5L-6326	Bearing-Ball	420-3222

Sales Model 621 (Cont'd.)

37G		
Original Part Number	Part Name	Classic Part Number
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-4557	Bearing	311-9360
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829

37G		
Original Part Number	Part Name	Classic Part Number
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7H-6967	Bearing-Ball	422-6489
7J-1770	Cap-Bearing	396-0664
7J-8458	Bearing-Sleeve	380-7374
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-7386	Gasket-Cyl Head	392-4519
7N-9146	Gear-Fly Starter	279-4995
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781

37G		
Original Part Number	Part Name	Classic Part Number
8J-0632	Pin	396-7280
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8P-4520	Piston-Clutch	394-0908
8S-6782	Adapter-Exhaust	383-1586
8S-9151	Cup-Spl Tapered	374-8348
8S-9686	Gasket Kit	393-5215
9J-9427	Bearing-Sleeve	361-1695
9M-3914	Bearing-Aligning	420-2501
9M-8395	Bearing-Sleeve	391-1103
9S-8789	Plate-Clutch	302-2712
9W-4662	Disc-Friction	428-7203
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
118-7805	Pinion-Bevel	394-9197
132-6597	Cone-Spl	422-6477
190-3832	Core As-Oclr	438-3251
368-0297	Plate-Clutch	377-7420

Sales Model 621B

2DB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400

2DB		
Original Part Number	Part Name	Classic Part Number
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409

2DB		
Original Part Number	Part Name	Classic Part Number
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108

Sales Model 621B (Cont'd.)

2DB		
Original Part Number	Part Name	Classic Part Number
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-0408	Cyl Gp-0165 1549	415-1898
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017

2DB		
Original Part Number	Part Name	Classic Part Number
3G-1239	Pump Gp-Vn Bsc-B	439-1135
3G-2834	Cartridge Gp-Rr	426-0025
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3H-8726	Mount As	385-7208
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952

2DB		
Original Part Number	Part Name	Classic Part Number
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-5958	Tube-Exhaust Ext	385-3811
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355

Sales Model 621B (Cont'd.)

2DB		
Original Part Number	Part Name	Classic Part Number
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5B-9169	Plug-Drain	419-4736
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1825	Pin	367-6080
5J-1968	Shaft-Roller	386-4928
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012

2DB		
Original Part Number	Part Name	Classic Part Number
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-3030	Pin As	389-6308
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6J-6043	Bearing-Sleeve	374-1456
6L-7751	Rod End-Spher	472-8015

2DB		
Original Part Number	Part Name	Classic Part Number
6N-1931	Plunger	379-0171
6N-4184	Muffler As	385-7226
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-3509	Pipe As-Ex Ext	373-1907
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451

Sales Model 621B (Cont'd.)

2DB		
Original Part Number	Part Name	Classic Part Number
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-7596	Bearing-Sleeve	361-1693
8J-7694	Bearing	431-5264
8J-7727	Pin	380-7552

2DB		
Original Part Number	Part Name	Classic Part Number
8M-0874	Plunger As-Valve	311-9439
8M-8652	Shaft	297-7252
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-8258	Bearing-Sleeve	452-1077
8N-9622	Bracket As-Fan	433-2024
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9L-5839	Coupling-Exhaust	374-7480
9M-3914	Bearing-Aligning	420-2501
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923

2DB		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700

Sales Model 621B (Cont'd.)

2DB		
Original Part Number	Part Name	Classic Part Number
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035

2DB		
Original Part Number	Part Name	Classic Part Number
148-3465	Pin	383-2112
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
188-2886	Gasket Kit	434-7281
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700

2DB		
Original Part Number	Part Name	Classic Part Number
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

2GB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499

2GB		
Original Part Number	Part Name	Classic Part Number
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802

2GB		
Original Part Number	Part Name	Classic Part Number
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2491	Muffler As-Eject	360-7871
1W-5910	Tappet As-Guide&	383-1569

Sales Model 621B (Cont'd.)

2GB		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7455	Gear As	396-9957
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-1239	Pump Gp-Vn Bsc-B	439-1135
3G-2834	Cartridge Gp-Rr	426-0025
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130

2GB		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5694	Bearing-Sleeve	379-0190
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509

2GB		
Original Part Number	Part Name	Classic Part Number
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-5958	Tube-Exhaust Ext	385-3811
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571

Sales Model 621B (Cont'd.)

2GB		
Original Part Number	Part Name	Classic Part Number
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5B-9169	Plug-Drain	419-4736
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-1825	Pin	367-6080
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5L-6326	Bearing-Ball	420-3222
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025

2GB		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
5T-3030	Pin As	389-6308
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-3907	Adapter-Pilot	398-8348
6I-4024	Gasket-Plate	377-5839
6J-6043	Bearing-Sleeve	374-1456
6L-7751	Rod End-Spher	472-8015
6N-1931	Plunger	379-0171
6N-4184	Muffler As	385-7226
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6N-9743	Support-Muffler	308-9940
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574

2GB		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-3509	Pipe As-Ex Ext	373-1907
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531

Sales Model 621B (Cont'd.)

2GB		
Original Part Number	Part Name	Classic Part Number
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0140	Gear-Drive	399-8546
7W-0182	Plunger & Bbl As	391-9893
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-4402	Yoke	365-8823
8D-5048	Yoke As	415-1899
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-7596	Bearing-Sleeve	361-1693
8J-7694	Bearing	431-5264
8J-7727	Pin	380-7552

2GB		
Original Part Number	Part Name	Classic Part Number
8M-0874	Plunger As-Valve	311-9439
8M-8652	Shaft	297-7252
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077
8N-8983	Hub-Fan Pulley	421-7227
8N-9622	Bracket As-Fan	433-2024
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9L-5839	Coupling-Exhaust	374-7480
9M-3914	Bearing-Aligning	420-2501
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923

2GB		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166

Sales Model 621B (Cont'd.)

2GB		
Original Part Number	Part Name	Classic Part Number
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0482	Gasket	420-8547

2GB		
Original Part Number	Part Name	Classic Part Number
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
148-3465	Pin	383-2112
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700

31V		
Original Part Number	Part Name	Classic Part Number
1P-9593	Cone-Rlr Brg	377-7400

2GB		
Original Part Number	Part Name	Classic Part Number
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

Sales Model 621B (Cont'd.)

31V		
Original Part Number	Part Name	Classic Part Number
1P-9594	Bearing-Cup	377-7401
1U-0408	Cyl Gp-0165 1549	415-1898
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190

31V		
Original Part Number	Part Name	Classic Part Number
4J-5695	Bearing-Sleeve	386-4922
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1968	Shaft-Roller	386-4928
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965

31V		
Original Part Number	Part Name	Classic Part Number
5J-2453	Rod As.	394-8214
6J-6043	Bearing-Sleeve	374-1456
7F-7780	Pin-Anchor	384-4825
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
8W-3613	Bearing	418-1960
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713

35V		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409

35V		
Original Part Number	Part Name	Classic Part Number
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-3900	Gasket	472-8006

35V		
Original Part Number	Part Name	Classic Part Number
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532

Sales Model 621B (Cont'd.)

35V		
Original Part Number	Part Name	Classic Part Number
2M-8340	Rod End-Yoke	374-4678
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7455	Gear As	396-9957
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3E-6772	Seal-Water	382-8017
3G-5192	Cyl Gp-0126 1128	399-8577

35V		
Original Part Number	Part Name	Classic Part Number
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3H-8726	Mount As	385-7208
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5694	Bearing-Sleeve	379-0190
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502

35V		
Original Part Number	Part Name	Classic Part Number
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-4864	Pump Gp-F Tfr	242-3442
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-5958	Tube-Exhaust Ext	385-3811
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-8915	Gasket-Cyl Head	377-5838
4S-5367	Mount As	375-9986

Sales Model 621B (Cont'd.)

35V		
Original Part Number	Part Name	Classic Part Number
4S-8472	Hood As-Preclnr	296-1355
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-0452	Seal As -Cshaft	325-6191
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-7188	Core As-Oclr	374-7501
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-1825	Pin	367-6080
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5L-8856	Coupling-Exhaust	311-9379
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467

35V		
Original Part Number	Part Name	Classic Part Number
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rock-er Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-3030	Pin As	389-6308
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518

35V		
Original Part Number	Part Name	Classic Part Number
6I-4024	Gasket-Plate	377-5839
6J-6043	Bearing-Sleeve	374-1456
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1931	Plunger	379-0171
6N-4184	Muffler As	385-7226
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7653	Gage As-O Level	428-7206
6N-9743	Support-Muffler	308-9940
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-3862	Camshaft	458-0151
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-3509	Pipe As-Ex Ext	373-1907
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222

Sales Model 621B (Cont'd.)

35V		
Original Part Number	Part Name	Classic Part Number
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7J-8458	Bearing-Sleeve	380-7374
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417

35V		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7W-0140	Gear-Drive	399-8546
7W-0182	Plunger & Bbl As	391-9893
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-4402	Yoke	365-8823
8D-5048	Yoke As	415-1899
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7694	Bearing	431-5264
8J-7727	Pin	380-7552
8M-0874	Plunger As-Valve	311-9439

35V		
Original Part Number	Part Name	Classic Part Number
8M-8652	Shaft	297-7252
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1726	Rod As-Conn	379-8866
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377

Sales Model 621B (Cont'd.)

35V		
Original Part Number	Part Name	Classic Part Number
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8258	Bearing-Sleeve	452-1077
8N-9622	Bracket As-Fan	433-2024
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9H-5797	Plunger As-Pump	391-9891
9J-1676	Bearing-Sleeve	380-7378
9J-9427	Bearing-Sleeve	361-1695
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895

35V		
Original Part Number	Part Name	Classic Part Number
9L-5839	Coupling-Exhaust	374-7480
9M-3914	Bearing-Aligning	420-2501
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9N-5403	Body As-Piston	250-6558
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9W-4662	Disc-Friction	428-7203
9Y-1798	Seal-Water	379-0165
9Y-2988	Breather As	361-1716
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690

35V		
Original Part Number	Part Name	Classic Part Number
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
111-8015	Gasket As-Head	279-4977
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813

Sales Model 621B (Cont'd.)

35V		
Original Part Number	Part Name	Classic Part Number
143-3321	Bearing-Sleeve	425-3583
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
145-8503	Shaft As-Idler	426-0035
148-3465	Pin	383-2112
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
166-9142	Gasket	420-8546
167-8123	Damper As	299-2006
167-8126	Damper As	382-8019
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

35V		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
188-2886	Gasket Kit	434-7281
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013

35V		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3233	Bearing-Main	376-9085
232-6574	Kit-Gasket-Rs	437-2034
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6558	Liner Kit-Cla	295-6438
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
343-4836	Mount As	424-6369
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

36V		
Original Part Number	Part Name	Classic Part Number
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1U-0408	Cyl Gp-0165 1549	415-1898

36V		
Original Part Number	Part Name	Classic Part Number
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124

36V		
Original Part Number	Part Name	Classic Part Number
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920

Sales Model 621B (Cont'd.)

36V		
Original Part Number	Part Name	Classic Part Number
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1968	Shaft-Roller	386-4928

36V		
Original Part Number	Part Name	Classic Part Number
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
6J-6043	Bearing-Sleeve	374-1456
7F-7780	Pin-Anchor	384-4825
7J-1770	Cap-Bearing	396-0664

36V		
Original Part Number	Part Name	Classic Part Number
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
8W-3613	Bearing	418-1960
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713

40W		
Original Part Number	Part Name	Classic Part Number
1U-0408	Cyl Gp-0165 1549	415-1898

45P		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797

45P		
Original Part Number	Part Name	Classic Part Number
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2491	Muffler As-Eject	360-7871

45P		
Original Part Number	Part Name	Classic Part Number
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678

Sales Model 621B (Cont'd.)

45P		
Original Part Number	Part Name	Classic Part Number
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1757	Hub-Fan Pulley	296-1357
2P-5680	Turbine-Conv	308-9942
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2P-9314	Disc As-Clutch	384-4791
2S-4900	Shaft As	384-4792
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7455	Gear As	396-9957
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-1239	Pump Gp-Vn Bsc-B	439-1135
3G-2834	Cartridge Gp-Rr	426-0025
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3H-8726	Mount As	385-7208
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550

45P		
Original Part Number	Part Name	Classic Part Number
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-5100	Hub-Impeller	451-9022
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5694	Bearing-Sleeve	379-0190
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716

45P		
Original Part Number	Part Name	Classic Part Number
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-5958	Tube-Exhaust Ext	385-3811
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320

Sales Model 621B (Cont'd.)

45P		
Original Part Number	Part Name	Classic Part Number
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5B-9169	Plug-Drain	419-4736
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-1806	Pin	396-0662
5J-1825	Pin	367-6080
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5L-6326	Bearing-Ball	420-3222
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-8053	Kit-Gasket (Sch)	415-1901
5P-8366	Gasket Kit - Sch	387-2911
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025

45P		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
5T-3030	Pin As	389-6308
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-0400	Shaft-Drive	399-4403
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-3907	Adapter-Pilot	398-8348
6I-4024	Gasket-Plate	377-5839
6I-9509	Plate	398-2960
6J-6043	Bearing-Sleeve	374-1456
6L-7751	Rod End-Spher	472-8015
6N-1931	Plunger	379-0171
6N-4184	Muffler As	385-7226
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6N-9743	Support-Muffler	308-9940

45P		
Original Part Number	Part Name	Classic Part Number
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-3509	Pipe As-Ex Ext	373-1907
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7J-8458	Bearing-Sleeve	380-7374
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373

Sales Model 621B (Cont'd.)

45P		
Original Part Number	Part Name	Classic Part Number
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8371	Line As-Fuel Inj	373-1901
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0140	Gear-Drive	399-8546
7W-0182	Plunger & Bbl As	391-9893
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-4402	Yoke	365-8823
8D-5048	Yoke As	415-1899
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636

45P		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7694	Bearing	431-5264
8J-7727	Pin	380-7552
8M-0874	Plunger As-Valve	311-9439
8M-8652	Shaft	297-7252
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077
8N-8983	Hub-Fan Pulley	421-7227
8N-9622	Bracket As-Fan	433-2024
8P-4520	Piston-Clutch	394-0908
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-9427	Bearing-Sleeve	361-1695

45P		
Original Part Number	Part Name	Classic Part Number
9L-5839	Coupling-Exhaust	374-7480
9M-1853	Mount As.	376-3638
9M-3914	Bearing-Aligning	420-2501
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9N-5529	Body-F Inj Valve	378-3993
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9W-4702	Stator-Converter	308-9939
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691

Sales Model 621B (Cont'd.)

45P		
Original Part Number	Part Name	Classic Part Number
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589

45P		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
148-3465	Pin	383-2112
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516

45P		
Original Part Number	Part Name	Classic Part Number
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
188-2886	Gasket Kit	434-7281
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
232-6574	Kit-Gasket-Rs	437-2034
233-7083	Kit-Gasket-Fs	387-2919
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387

Sales Model 621B (Cont'd.)

45P		
Original Part Number	Part Name	Classic Part Number
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369

45P		
Original Part Number	Part Name	Classic Part Number
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

6XB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-0408	Cyl Gp-0165 1549	415-1898
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-5910	Tappet As-Guide&	383-1569

6XB		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3G-1239	Pump Gp-Vn Bsc-B	439-1135
3G-2834	Cartridge Gp-Rr	426-0025
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306

6XB		
Original Part Number	Part Name	Classic Part Number
3G-6098	Pin As	383-2124
3H-8726	Mount As	385-7208
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952

Sales Model 621B (Cont'd.)

6XB		
Original Part Number	Part Name	Classic Part Number
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-5958	Tube-Exhaust Ext	385-3811
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355

6XB		
Original Part Number	Part Name	Classic Part Number
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5B-9169	Plug-Drain	419-4736
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1825	Pin	367-6080
5J-1968	Shaft-Roller	386-4928
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510

6XB		
Original Part Number	Part Name	Classic Part Number
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-3030	Pin As	389-6308
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6J-6043	Bearing-Sleeve	374-1456
6L-7751	Rod End-Spher	472-8015
6N-1931	Plunger	379-0171

Sales Model 621B (Cont'd.)

6XB		
Original Part Number	Part Name	Classic Part Number
6N-4184	Muffler As	385-7226
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-3509	Pipe As-Ex Ext	373-1907
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854

6XB		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-7596	Bearing-Sleeve	361-1693
8J-7694	Bearing	431-5264
8J-7727	Pin	380-7552
8M-0874	Plunger As-Valve	311-9439

6XB		
Original Part Number	Part Name	Classic Part Number
8M-8652	Shaft	297-7252
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-8258	Bearing-Sleeve	452-1077
8N-9622	Bracket As-Fan	433-2024
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9L-5839	Coupling-Exhaust	374-7480
9M-3914	Bearing-Aligning	420-2501
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

Sales Model 621B (Cont'd.)

6XB		
Original Part Number	Part Name	Classic Part Number
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463

6XB		
Original Part Number	Part Name	Classic Part Number
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
148-3465	Pin	383-2112
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502

7KC		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913

6XB		
Original Part Number	Part Name	Classic Part Number
161-7128	Spring As.	419-4726
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

Sales Model 621B (Cont'd.)

7KC		
Original Part Number	Part Name	Classic Part Number
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2L-5271	Bearing-Ball	371-4305

7KC		
Original Part Number	Part Name	Classic Part Number
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3G-1239	Pump Gp-Vn Bsc-B	439-1135
3G-2834	Cartridge Gp-Rr	426-0025
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6098	Pin As	383-2124
3H-8726	Mount As	385-7208
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781

7KC		
Original Part Number	Part Name	Classic Part Number
4J-5694	Bearing-Sleeve	379-0190
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-5958	Tube-Exhaust Ext	385-3811
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030

Sales Model 621B (Cont'd.)

7KC		
Original Part Number	Part Name	Classic Part Number
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5B-9169	Plug-Drain	419-4736
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-1825	Pin	367-6080
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467

7KC		
Original Part Number	Part Name	Classic Part Number
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-3030	Pin As	389-6308
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6J-6043	Bearing-Sleeve	374-1456
6L-7751	Rod End-Spher	472-8015
6N-1931	Plunger	379-0171
6N-4184	Muffler As	385-7226
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603

7KC		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-3509	Pipe As-Ex Ext	373-1907
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721

Sales Model 621B (Cont'd.)

7KC		
Original Part Number	Part Name	Classic Part Number
7W-0182	Plunger & Bbl As	391-9893
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-7596	Bearing-Sleeve	361-1693
8J-7694	Bearing	431-5264
8J-7727	Pin	380-7552
8M-0874	Plunger As-Valve	311-9439
8M-8652	Shaft	297-7252
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-8258	Bearing-Sleeve	452-1077

7KC		
Original Part Number	Part Name	Classic Part Number
8N-9622	Bracket As-Fan	433-2024
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9L-5839	Coupling-Exhaust	374-7480
9M-3914	Bearing-Aligning	420-2501
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690

7KC		
Original Part Number	Part Name	Classic Part Number
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312

Sales Model 621B (Cont'd.)

7KC		
Original Part Number	Part Name	Classic Part Number
144-0503	Piston Kt	380-1554
145-8503	Shaft As-Idler	426-0035
148-3465	Pin	383-2112
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956

7KC		
Original Part Number	Part Name	Classic Part Number
185-2831	Line As	380-1516
188-2886	Gasket Kit	434-7281
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037

7KC		
Original Part Number	Part Name	Classic Part Number
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

8HC		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803

8HC		
Original Part Number	Part Name	Classic Part Number
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059

8HC		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979

Sales Model 621B (Cont'd.)

8HC		
Original Part Number	Part Name	Classic Part Number
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3G-1239	Pump Gp-Vn Bsc-B	439-1135
3G-2834	Cartridge Gp-Rr	426-0025
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6098	Pin As	383-2124
3H-8726	Mount As	385-7208
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5694	Bearing-Sleeve	379-0190
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722

8HC		
Original Part Number	Part Name	Classic Part Number
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-5958	Tube-Exhaust Ext	385-3811
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323

8HC		
Original Part Number	Part Name	Classic Part Number
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5B-9169	Plug-Drain	419-4736
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-1825	Pin	367-6080
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-3030	Pin As	389-6308
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270

Sales Model 621B (Cont'd.)

8HC		
Original Part Number	Part Name	Classic Part Number
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6J-6043	Bearing-Sleeve	374-1456
6L-7751	Rod End-Spher	472-8015
6N-1931	Plunger	379-0171
6N-4184	Muffler As	385-7226
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-3509	Pipe As-Ex Ext	373-1907
7E-5085	Bushing	377-5829

8HC		
Original Part Number	Part Name	Classic Part Number
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572

8HC		
Original Part Number	Part Name	Classic Part Number
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-7596	Bearing-Sleeve	361-1693
8J-7694	Bearing	431-5264
8J-7727	Pin	380-7552
8M-0874	Plunger As-Valve	311-9439
8M-8652	Shaft	297-7252
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-8258	Bearing-Sleeve	452-1077
8N-9622	Bracket As-Fan	433-2024
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378

Sales Model 621B (Cont'd.)

8HC		
Original Part Number	Part Name	Classic Part Number
9L-5839	Coupling-Exhaust	374-7480
9M-3914	Bearing-Aligning	420-2501
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947

8HC		
Original Part Number	Part Name	Classic Part Number
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
145-8503	Shaft As-Idler	426-0035
148-3465	Pin	383-2112
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048

8HC		
Original Part Number	Part Name	Classic Part Number
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
188-2886	Gasket Kit	434-7281
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

Sales Model 621B (Cont'd.)

9AC		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-0408	Cyl Gp-0165 1549	415-1898
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533

9AC		
Original Part Number	Part Name	Classic Part Number
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3G-1239	Pump Gp-Vn Bsc-B	439-1135
3G-2834	Cartridge Gp-Rr	426-0025
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3H-8726	Mount As	385-7208
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-2619	Bearing	417-4494

9AC		
Original Part Number	Part Name	Classic Part Number
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-5958	Tube-Exhaust Ext	385-3811

Sales Model 621B (Cont'd.)

9AC		
Original Part Number	Part Name	Classic Part Number
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5B-9169	Plug-Drain	419-4736
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1825	Pin	367-6080
5J-1968	Shaft-Roller	386-4928
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965

9AC		
Original Part Number	Part Name	Classic Part Number
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-3030	Pin As	389-6308
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6J-6043	Bearing-Sleeve	374-1456

9AC		
Original Part Number	Part Name	Classic Part Number
6L-7751	Rod End-Spher	472-8015
6N-1931	Plunger	379-0171
6N-4184	Muffler As	385-7226
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-3509	Pipe As-Ex Ext	373-1907
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7S-7809	Cap As-Radiator	295-6417

Sales Model 621B (Cont'd.)

9AC		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-5733	Gasket	421-7333
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-7596	Bearing-Sleeve	361-1693
8J-7694	Bearing	431-5264
8J-7727	Pin	380-7552
8M-0874	Plunger As-Valve	311-9439
8M-8652	Shaft	297-7252
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-9622	Bracket As-Fan	433-2024
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372

9AC		
Original Part Number	Part Name	Classic Part Number
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9M-3914	Bearing-Aligning	420-2501
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947

9AC		
Original Part Number	Part Name	Classic Part Number
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
148-3465	Pin	383-2112
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037

Sales Model 621B (Cont'd.)

9AC		
Original Part Number	Part Name	Classic Part Number
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
253-1752	Plate-Thrust	379-0170

9AC		
Original Part Number	Part Name	Classic Part Number
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387

9AC		
Original Part Number	Part Name	Classic Part Number
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

Sales Model 621E

2PD		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-3743	Bearing-Ball	384-4786
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152

2PD		
Original Part Number	Part Name	Classic Part Number
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1348	Support As-Carr	419-4049
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934

2PD		
Original Part Number	Part Name	Classic Part Number
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3E-7466	Gasket Kit	393-3615
3G-1239	Pump Gp-Vn Bsc-B	439-1135
3G-2834	Cartridge Gp-Rr	426-0025
3G-5192	Cyl Gp-0126 1128	399-8577
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550

Sales Model 621E (Cont'd.)

2PD		
Original Part Number	Part Name	Classic Part Number
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4E-0403	Gear-Planet	260-0781
4J-5694	Bearing-Sleeve	379-0190
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855

2PD		
Original Part Number	Part Name	Classic Part Number
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433

2PD		
Original Part Number	Part Name	Classic Part Number
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-6043	Bearing-Sleeve	374-1456
6K-4442	Rod End-Special	373-5388

Sales Model 621E (Cont'd.)

2PD		
Original Part Number	Part Name	Classic Part Number
6N-1931	Plunger	379-0171
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6628	Pulley-Alt	396-9894
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-8458	Bearing-Sleeve	380-7374

2PD		
Original Part Number	Part Name	Classic Part Number
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-7809	Cap As-Radiator	295-6417
7T-2336	Disc-Friction	433-7096
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636

2PD		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077
8N-8983	Hub-Fan Pulley	421-7227
8P-2051	Plate-Clutch	385-6116
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-9427	Bearing-Sleeve	361-1695
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468

Sales Model 621E (Cont'd.)

2PD		
Original Part Number	Part Name	Classic Part Number
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9T-6123	Pump Gp-Vn Bsc-B	422-8147
9W-4662	Disc-Friction	428-7203
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744

2PD		
Original Part Number	Part Name	Classic Part Number
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
111-3895	Yoke	421-3080
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
143-3321	Bearing-Sleeve	425-3583
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-4229	Gasket Kit - Sch	437-4599
148-3465	Pin	383-2112
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054

2PD		
Original Part Number	Part Name	Classic Part Number
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
188-2887	Kit-Dt Gasket	394-8244
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
234-1874	Kit-Gasket-Fs	437-8668

Sales Model 621E (Cont'd.)

2PD		
Original Part Number	Part Name	Classic Part Number
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-5573	Bearing-Conn Rod	419-6387

2PD		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369

2PD		
Original Part Number	Part Name	Classic Part Number
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

2TF		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-3062	Director-Water	418-9572
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-0408	Cyl Gp-0165 1549	415-1898

2TF		
Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229

2TF		
Original Part Number	Part Name	Classic Part Number
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8494	Pulley-Alt	295-5692
3G-2837	Cartridge Gp-Rr	422-8123
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306

Sales Model 621E (Cont'd.)

2TF		
Original Part Number	Part Name	Classic Part Number
3G-6098	Pin As	383-2124
3G-8136	Retainer	425-3585
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236

2TF		
Original Part Number	Part Name	Classic Part Number
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800

2TF		
Original Part Number	Part Name	Classic Part Number
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0975	Camshaft-Brake	422-4935
5T-0999	Camshaft-Brake	422-4934
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269

Sales Model 621E (Cont'd.)

2TF		
Original Part Number	Part Name	Classic Part Number
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6J-6043	Bearing-Sleeve	374-1456
6K-4442	Rod End-Special	373-5388
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655

2TF		
Original Part Number	Part Name	Classic Part Number
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-0675	Core As-Oclr	434-4016
7W-1927	Ring-Retainer	387-2935
7W-4473	Manifold-Ex	443-2095
7W-5698	Pulley-Cshaft	295-5679

2TF		
Original Part Number	Part Name	Classic Part Number
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842

Sales Model 621E (Cont'd.)

2TF		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5385	Manifold-Exhaust	391-9835
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960

2TF		
Original Part Number	Part Name	Classic Part Number
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9L-6371	Rod-Eye	363-7459
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9W-4662	Disc-Friction	428-7203
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
111-8015	Gasket As-Head	279-4977
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
148-7455	Valve - Exhaust	270-4361

2TF		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
177-7886	Cone	418-9605
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356

Sales Model 621E (Cont'd.)

2TF		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988

2TF		
Original Part Number	Part Name	Classic Part Number
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349

2TF		
Original Part Number	Part Name	Classic Part Number
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420

4LB		
Original Part Number	Part Name	Classic Part Number
1U-0408	Cyl Gp-0165 1549	415-1898
5T-0975	Camshaft-Brake	422-4935
5T-0999	Camshaft-Brake	422-4934

6AB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-3743	Bearing-Ball	384-4786
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152

6AB		
Original Part Number	Part Name	Classic Part Number
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1348	Support As-Carr	419-4049
1U-0408	Cyl Gp-0165 1549	415-1898
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2491	Muffler As-Eject	360-7871
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555

6AB		
Original Part Number	Part Name	Classic Part Number
2J-1227	Retainer	440-0850
2L-5271	Bearing-Ball	371-4305
2M-8340	Rod End-Yoke	374-4678
2N-5842	Screw-Bridge Adj	418-1934
2P-5680	Turbine-Conv	308-9942
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2P-9314	Disc As-Clutch	384-4791
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7455	Gear As	396-9957
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3E-7466	Gasket Kit	393-3615
3G-1239	Pump Gp-Vn Bsc-B	439-1135
3G-2834	Cartridge Gp-Rr	426-0025

Sales Model 621E (Cont'd.)

6AB		
Original Part Number	Part Name	Classic Part Number
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-5100	Hub-Impeller	451-9022
4D-0487	Valve As-Check	375-4334
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952

6AB		
Original Part Number	Part Name	Classic Part Number
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986

6AB		
Original Part Number	Part Name	Classic Part Number
4S-8472	Hood As-Preclnr	296-1355
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1806	Pin	396-0662
5J-1825	Pin	367-6080
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5L-7632	Support-Elbow	433-9854

Sales Model 621E (Cont'd.)

6AB		
Original Part Number	Part Name	Classic Part Number
5L-7634	Elbow-Turbo Exh	380-1555
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-0975	Camshaft-Brake	422-4935
5T-0999	Camshaft-Brake	422-4934
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-0400	Shaft-Drive	399-4403
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757

6AB		
Original Part Number	Part Name	Classic Part Number
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-3907	Adapter-Pilot	398-8348
6I-4024	Gasket-Plate	377-5839
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6I-9509	Plate	398-2960
6J-6043	Bearing-Sleeve	374-1456
6K-4442	Rod End-Special	373-5388
6L-7751	Rod End-Spher	472-8015
6N-1931	Plunger	379-0171
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-7476	Kit-Dt Gasket	390-5282
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6628	Pulley-Alt	396-9894
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303

6AB		
Original Part Number	Part Name	Classic Part Number
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531

Sales Model 621E (Cont'd.)

6AB		
Original Part Number	Part Name	Classic Part Number
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7694	Bearing	431-5264
8J-7727	Pin	380-7552
8N-0788	Cover	440-0849

6AB		
Original Part Number	Part Name	Classic Part Number
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077
8N-8983	Hub-Fan Pulley	421-7227
8P-2051	Plate-Clutch	385-6116
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718

6AB		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9T-6123	Pump Gp-Vn Bsc-B	422-8147
9W-4662	Disc-Friction	428-7203
9W-4702	Stator-Converter	308-9939
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
108-2102	Bonnet-Valve	455-3274

Sales Model 621E (Cont'd.)

6AB		
Original Part Number	Part Name	Classic Part Number
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
111-3895	Yoke	421-3080
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583

6AB		
Original Part Number	Part Name	Classic Part Number
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
146-4229	Gasket Kit - Sch	437-4599
148-3465	Pin	383-2112
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
188-2887	Kit-Dt Gasket	394-8244
191-7941	Line As-Fuel Inj	378-4011

6AB		
Original Part Number	Part Name	Classic Part Number
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
234-1874	Kit-Gasket-Fs	437-8668
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369

Sales Model 621E (Cont'd.)

6AB		
Original Part Number	Part Name	Classic Part Number
368-0297	Plate-Clutch	377-7420

6AB		
Original Part Number	Part Name	Classic Part Number
430-7619	Adapter-Cla	438-1812

6BB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-3743	Bearing-Ball	384-4786
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755

6BB		
Original Part Number	Part Name	Classic Part Number
1T-1348	Support As-Carr	419-4049
1U-0408	Cyl Gp-0165 1549	415-1898
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271

6BB		
Original Part Number	Part Name	Classic Part Number
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190

Sales Model 621E (Cont'd.)

6BB		
Original Part Number	Part Name	Classic Part Number
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115

6BB		
Original Part Number	Part Name	Classic Part Number
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-7449	Cup-Spl Tapered	416-2161
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-0578	Bearing	419-7775

6BB		
Original Part Number	Part Name	Classic Part Number
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-0975	Camshaft-Brake	422-4935
5T-0999	Camshaft-Brake	422-4934
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8849	Cone-Rlr Bearing	415-1919

Sales Model 621E (Cont'd.)

6BB		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
6J-6043	Bearing-Sleeve	374-1456
6K-4442	Rod End-Special	373-5388
6N-1931	Plunger	379-0171
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6628	Pulley-Alt	396-9894
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825

6BB		
Original Part Number	Part Name	Classic Part Number
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333

6BB		
Original Part Number	Part Name	Classic Part Number
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077
8N-8983	Hub-Fan Pulley	421-7227
8P-2051	Plate-Clutch	385-6116
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613

Sales Model 621E (Cont'd.)

6BB		
Original Part Number	Part Name	Classic Part Number
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-8184	Pin-Drawbar	398-8345
9T-6123	Pump Gp-Vn Bsc-B	422-8147
9W-4662	Disc-Friction	428-7203
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690

6BB		
Original Part Number	Part Name	Classic Part Number
101-1818	Bridge As-Exh	374-4691
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
111-3895	Yoke	421-3080
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
143-3321	Bearing-Sleeve	425-3583

6BB		
Original Part Number	Part Name	Classic Part Number
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
145-8503	Shaft As-Idler	426-0035
148-3465	Pin	383-2112
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037

Sales Model 621E (Cont'd.)

6BB		
Original Part Number	Part Name	Classic Part Number
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3679	Kit-Gasket (Rs)	437-2039

6BB		
Original Part Number	Part Name	Classic Part Number
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387

6BB		
Original Part Number	Part Name	Classic Part Number
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

Sales Model 621F

4SK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049

4SK		
Original Part Number	Part Name	Classic Part Number
1U-0408	Cyl Gp-0165 1549	415-1898
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2491	Muffler As-Eject	360-7871
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6511	Cup-Roller Brg	377-7417
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2L-5271	Bearing-Ball	371-4305

4SK		
Original Part Number	Part Name	Classic Part Number
2M-8340	Rod End-Yoke	374-4678
2N-5842	Screw-Bridge Adj	418-1934
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7455	Gear As	396-9957
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778

Sales Model 621F (Cont'd.)

4SK		
Original Part Number	Part Name	Classic Part Number
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191

4SK		
Original Part Number	Part Name	Classic Part Number
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4V-7725	Piston	394-2581
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320

4SK		
Original Part Number	Part Name	Classic Part Number
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1806	Pin	396-0662
5J-1825	Pin	367-6080
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502

Sales Model 621F (Cont'd.)

4SK		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-0975	Camshaft-Brake	422-4935
5T-0999	Camshaft-Brake	422-4934
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-3907	Adapter-Pilot	398-8348
6I-4024	Gasket-Plate	377-5839
6J-6043	Bearing-Sleeve	374-1456
6L-7751	Rod End-Spher	472-8015

4SK		
Original Part Number	Part Name	Classic Part Number
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-7352	Retainer	424-0741
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9595	Core As-Radiator	396-9926
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655

4SK		
Original Part Number	Part Name	Classic Part Number
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187

Sales Model 621F (Cont'd.)

4SK		
Original Part Number	Part Name	Classic Part Number
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7694	Bearing	431-5264
8J-7727	Pin	380-7552
8M-3368	Valve-Check	388-6599
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798

4SK		
Original Part Number	Part Name	Classic Part Number
8W-8138	Shaft	377-7453
9C-4202	Ring	424-0127
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9T-6123	Pump Gp-Vn Bsc-B	422-8147
9V-1290	Wheel	396-9946
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689

4SK		
Original Part Number	Part Name	Classic Part Number
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-3012	Gasket Kit	437-3229
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589

Sales Model 621F (Cont'd.)

4SK		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
142-7526	Gasket Kit	393-0918
143-3321	Bearing-Sleeve	425-3583
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
159-9742	Kit-Gasket(F)	437-1996
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048

4SK		
Original Part Number	Part Name	Classic Part Number
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
162-0268	Hub As	426-3475
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
188-2887	Kit-Dt Gasket	394-8244
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368

4SK		
Original Part Number	Part Name	Classic Part Number
213-8621	Kit-Gasket-Wp	437-2003
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
232-3679	Kit-Gasket (Rs)	437-2039
233-9203	Kit-Gasket-Sch	437-2028
233-9456	Kit-Gasket-Sch	422-7510
234-1874	Kit-Gasket-Fs	437-8668
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

5JK		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345

5JK		
Original Part Number	Part Name	Classic Part Number
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401

Sales Model 621F (Cont'd.)

5JK		
Original Part Number	Part Name	Classic Part Number
1U-0408	Cyl Gp-0165 1549	415-1898
2B-0941	Spacer	418-1955
2J-1227	Retainer	440-0850
3E-6772	Seal-Water	382-8017
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-8136	Retainer	425-3585
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
4D-0487	Valve As-Check	375-4334
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4N-0685	Bearing-Sleeve	379-0191
4N-6658	Bearing-Sleeve	373-1885
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671

5JK		
Original Part Number	Part Name	Classic Part Number
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5P-9962	Bearing-Aligning	399-4397
5T-0975	Camshaft-Brake	422-4935
5T-0999	Camshaft-Brake	422-4934
5T-3323	Pin As	380-7394
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6G-5155	Bearing-Thrust	394-0220
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6J-6043	Bearing-Sleeve	374-1456
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7F-7780	Pin-Anchor	384-4825
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132

5JK		
Original Part Number	Part Name	Classic Part Number
7J-4983	Cap-Bearing	384-3460
7K-5448	Cup-Bearing	415-1922
7T-2036	Cap As-Fuel	361-1721
7W-5733	Gasket	421-7333
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
131-7123	Bearing-Sleeve	422-6919
143-3321	Bearing-Sleeve	425-3583
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
155-5619	Gasket	382-5054
166-9142	Gasket	420-8546
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387

8PL		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913

Sales Model 621F (Cont'd.)

8PL		
Original Part Number	Part Name	Classic Part Number
1P-4110	Disc-Friction	433-9858
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-0408	Cyl Gp-0165 1549	415-1898
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

8PL		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226

8PL		
Original Part Number	Part Name	Classic Part Number
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030

Sales Model 621F (Cont'd.)

8PL		
Original Part Number	Part Name	Classic Part Number
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012

8PL		
Original Part Number	Part Name	Classic Part Number
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-0975	Camshaft-Brake	422-4935
5T-0999	Camshaft-Brake	422-4934
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839

8PL		
Original Part Number	Part Name	Classic Part Number
6J-6043	Bearing-Sleeve	374-1456
6L-7751	Rod End-Spher	472-8015
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664

Sales Model 621F (Cont'd.)

8PL		
Original Part Number	Part Name	Classic Part Number
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692

8PL		
Original Part Number	Part Name	Classic Part Number
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8M-3368	Valve-Check	388-6599
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713

8PL		
Original Part Number	Part Name	Classic Part Number
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9T-6123	Pump Gp-Vn Bsc-B	422-8147
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947

Sales Model 621F (Cont'd.)

8PL		
Original Part Number	Part Name	Classic Part Number
107-8106	Manifold-Exh	374-7487
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813

9NL		
Original Part Number	Part Name	Classic Part Number
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401

8PL		
Original Part Number	Part Name	Classic Part Number
143-3321	Bearing-Sleeve	425-3583
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
145-8503	Shaft As-Idler	426-0035
148-3465	Pin	383-2112
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
188-2887	Kit-Dt Gasket	394-8244
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699

8PL		
Original Part Number	Part Name	Classic Part Number
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3679	Kit-Gasket (Rs)	437-2039
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

Sales Model 621F (Cont'd.)

9NL		
Original Part Number	Part Name	Classic Part Number
1U-0408	Cyl Gp-0165 1549	415-1898
2J-1227	Retainer	440-0850
3E-6772	Seal-Water	382-8017
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
4D-0487	Valve As-Check	375-4334
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4N-0685	Bearing-Sleeve	379-0191
4N-6658	Bearing-Sleeve	373-1885
5F-2830	Bearing-Needle	384-5925

9NL		
Original Part Number	Part Name	Classic Part Number
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5T-0975	Camshaft-Brake	422-4935
5T-0999	Camshaft-Brake	422-4934
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6J-6043	Bearing-Sleeve	374-1456
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7F-7780	Pin-Anchor	384-4825
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210

9NL		
Original Part Number	Part Name	Classic Part Number
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7K-5448	Cup-Bearing	415-1922
7T-2036	Cap As-Fuel	361-1721
7W-5733	Gasket	421-7333
8W-3613	Bearing	418-1960
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
131-7123	Bearing-Sleeve	422-6919
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
155-5619	Gasket	382-5054
166-9142	Gasket	420-8546
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387

Sales Model 621G

ALP		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401

ALP		
Original Part Number	Part Name	Classic Part Number
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797

ALP		
Original Part Number	Part Name	Classic Part Number
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715

Sales Model 621G (Cont'd.)

ALP		
Original Part Number	Part Name	Classic Part Number
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2G-1034	Valve-Safety	380-7555
2L-5271	Bearing-Ball	371-4305
2M-8340	Rod End-Yoke	374-4678
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6150	Cover-Pulley	428-8817
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063

ALP		
Original Part Number	Part Name	Classic Part Number
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5694	Bearing-Sleeve	379-0190
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0362	Cover As-Rgltr	419-4722
4N-0685	Bearing-Sleeve	379-0191
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320

ALP		
Original Part Number	Part Name	Classic Part Number
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-1806	Pin	396-0662
5J-1825	Pin	367-6080
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757

Sales Model 621G (Cont'd.)

ALP		
Original Part Number	Part Name	Classic Part Number
6I-3066	Gasket-Cyl Head	380-1518
6I-3907	Adapter-Pilot	398-8348
6I-4024	Gasket-Plate	377-5839
6J-6043	Bearing-Sleeve	374-1456
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-8458	Bearing-Sleeve	380-7374
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-2336	Disc-Friction	433-7096

ALP		
Original Part Number	Part Name	Classic Part Number
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-5733	Gasket	421-7333
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7694	Bearing	431-5264
8J-7727	Pin	380-7552
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-9427	Bearing-Sleeve	361-1695

ALP		
Original Part Number	Part Name	Classic Part Number
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052

Sales Model 621G (Cont'd.)

ALP		
Original Part Number	Part Name	Classic Part Number
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
166-6352	Tube As.	432-4223

ALP		
Original Part Number	Part Name	Classic Part Number
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
188-2887	Kit-Dt Gasket	394-8244
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
232-3679	Kit-Gasket (Rs)	437-2039

ALP		
Original Part Number	Part Name	Classic Part Number
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
347-6081	Gauge As	360-2348
352-1053	Kit-Dt Gasket	447-0829
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

ANG		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1U-0408	Cyl Gp-0165 1549	415-1898
2J-1227	Retainer	440-0850
3E-6772	Seal-Water	382-8017
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920

ANG		
Original Part Number	Part Name	Classic Part Number
4D-0487	Valve As-Check	375-4334
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4N-4668	Breather-Engine	396-7271
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563

ANG		
Original Part Number	Part Name	Classic Part Number
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5T-0975	Camshaft-Brake	422-4935
5T-0999	Camshaft-Brake	422-4934
6J-6043	Bearing-Sleeve	374-1456
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7F-7780	Pin-Anchor	384-4825
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210

Sales Model 621G (Cont'd.)

ANG		
Original Part Number	**Part Name**	**Classic Part Number**
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7K-5448	Cup-Bearing	415-1922
7T-2036	Cap As-Fuel	361-1721
8W-3613	Bearing	418-1960
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566

ANG		
Original Part Number	**Part Name**	**Classic Part Number**
9J-8323	Trunnion	361-1713
101-3125	Gasket	420-8567
131-7123	Bearing-Sleeve	422-6919
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048

ANG		
Original Part Number	**Part Name**	**Classic Part Number**
213-8621	Kit-Gasket-Wp	437-2003
216-5582	Bearing-Sleeve	390-0914
232-3679	Kit-Gasket (Rs)	437-2039
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387

CEN		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049

CEN		
Original Part Number	**Part Name**	**Classic Part Number**
1U-0408	Cyl Gp-0165 1549	415-1898
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2L-5271	Bearing-Ball	371-4305
2M-8340	Rod End-Yoke	374-4678
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6150	Cover-Pulley	428-8817
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017

CEN		
Original Part Number	**Part Name**	**Classic Part Number**
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226

Sales Model 621G (Cont'd.)

CEN		
Original Part Number	Part Name	Classic Part Number
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0362	Cover As-Rgltr	419-4722
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-5367	Mount As	375-9986
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

CEN		
Original Part Number	Part Name	Classic Part Number
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1806	Pin	396-0662
5J-1825	Pin	367-6080
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347

CEN		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6J-6043	Bearing-Sleeve	374-1456
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7E-9595	Core As-Radiator	396-9926
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655

Sales Model 621G (Cont'd.)

CEN		
Original Part Number	Part Name	Classic Part Number
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7694	Bearing	431-5264
8J-7727	Pin	380-7552
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263

CEN		
Original Part Number	Part Name	Classic Part Number
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9D-5444	Pin	380-7396
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966

CEN		
Original Part Number	Part Name	Classic Part Number
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546

Sales Model 621G (Cont'd.)

CEN		
Original Part Number	Part Name	Classic Part Number
167-8126	Damper As	382-8019
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003

CEN		
Original Part Number	Part Name	Classic Part Number
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
232-3679	Kit-Gasket (Rs)	437-2039
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443

CEN		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

CEP		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802

CEP		
Original Part Number	Part Name	Classic Part Number
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-0408	Cyl Gp-0165 1549	415-1898
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2L-5271	Bearing-Ball	371-4305
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6150	Cover-Pulley	428-8817
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271

CEP		
Original Part Number	Part Name	Classic Part Number
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424

Sales Model 621G (Cont'd.)

CEP		
Original Part Number	Part Name	Classic Part Number
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0362	Cover As-Rgltr	419-4722
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-5367	Mount As	375-9986
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

CEP		
Original Part Number	Part Name	Classic Part Number
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800

CEP		
Original Part Number	Part Name	Classic Part Number
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6J-6043	Bearing-Sleeve	374-1456
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374

Sales Model 621G (Cont'd.)

CEP		
Original Part Number	Part Name	Classic Part Number
7K-5448	Cup-Bearing	415-1922
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960

CEP		
Original Part Number	Part Name	Classic Part Number
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9D-5444	Pin	380-7396
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589

CEP		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003
216-5582	Bearing-Sleeve	390-0914

Sales Model 621G (Cont'd.)

CEP		
Original Part Number	Part Name	Classic Part Number
217-0578	Bearing-Rod	419-4665
232-3679	Kit-Gasket (Rs)	437-2039
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507

CEP		
Original Part Number	Part Name	Classic Part Number
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665

CEP		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-6387
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

DBX		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-0408	Cyl Gp-0165 1549	415-1898
1W-7238	Shaft As-Pump Dr	379-0164

DBX		
Original Part Number	Part Name	Classic Part Number
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-1227	Retainer	440-0850
2P-1373	Cup-Rlr Brg	382-5075
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965

DBX		
Original Part Number	Part Name	Classic Part Number
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812

Sales Model 621G (Cont'd.)

DBX		
Original Part Number	Part Name	Classic Part Number
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800

DBX		
Original Part Number	Part Name	Classic Part Number
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6J-6043	Bearing-Sleeve	374-1456
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-2036	Cap As-Fuel	361-1721

DBX		
Original Part Number	Part Name	Classic Part Number
7T-2336	Disc-Friction	433-7096
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-2104	Bell As-Suction	380-1521
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695

Sales Model 621G (Cont'd.)

DBX		
Original Part Number	Part Name	Classic Part Number
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589

DBX		
Original Part Number	Part Name	Classic Part Number
130-2621	Pin As	390-5273
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048

DBX		
Original Part Number	Part Name	Classic Part Number
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420

DBB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797

DBB		
Original Part Number	Part Name	Classic Part Number
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-0408	Cyl Gp-0165 1549	415-1898

DBB		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-1227	Retainer	440-0850
2P-1373	Cup-Rlr Brg	382-5075
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2W-6280	Bracket As-Fan	431-5271

Sales Model 621G (Cont'd.)

DBB		
Original Part Number	Part Name	Classic Part Number
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952

DBB		
Original Part Number	Part Name	Classic Part Number
4M-3915	Bearing-Caged	377-7427
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025

DBB		
Original Part Number	Part Name	Classic Part Number
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6J-6043	Bearing-Sleeve	374-1456
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210

Sales Model 621G (Cont'd.)

DBB		
Original Part Number	Part Name	Classic Part Number
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-2104	Bell As-Suction	380-1521
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613

DBB		
Original Part Number	Part Name	Classic Part Number
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589

DBB		
Original Part Number	Part Name	Classic Part Number
130-2621	Pin As	390-5273
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170

Sales Model 621G (Cont'd.)

DBB		
Original Part Number	Part Name	Classic Part Number
278-1365	Arm As-Ui Rkr	433-7507

DBB		
Original Part Number	Part Name	Classic Part Number
328-4240	Arm As-V Rocker	433-0443

DBB		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420

DXB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

DXB		
Original Part Number	Part Name	Classic Part Number
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2L-5271	Bearing-Ball	371-4305
2M-8340	Rod End-Yoke	374-4678
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6150	Cover-Pulley	428-8817
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063

DXB		
Original Part Number	Part Name	Classic Part Number
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0362	Cover As-Rgltr	419-4722
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904

Sales Model 621G (Cont'd.)

DXB		
Original Part Number	Part Name	Classic Part Number
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-5367	Mount As	375-9986
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579

DXB		
Original Part Number	Part Name	Classic Part Number
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6J-6043	Bearing-Sleeve	374-1456
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-3831	Seal-O-Ring	436-2657
6W-7352	Retainer	424-0741
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825

DXB		
Original Part Number	Part Name	Classic Part Number
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-8458	Bearing-Sleeve	380-7374
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-2336	Disc-Friction	433-7096
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-2104	Bell As-Suction	380-1521
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131

Sales Model 621G (Cont'd.)

DXB		
Original Part Number	Part Name	Classic Part Number
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966

DXB		
Original Part Number	Part Name	Classic Part Number
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726

DXB		
Original Part Number	Part Name	Classic Part Number
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
232-3679	Kit-Gasket (Rs)	437-2039
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

Sales Model 621G (Cont'd.)

KJW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-0408	Cyl Gp-0165 1549	415-1898
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-1227	Retainer	440-0850
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-5192	Cyl Gp-0126 1128	399-8577

KJW		
Original Part Number	Part Name	Classic Part Number
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904

KJW		
Original Part Number	Part Name	Classic Part Number
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800

Sales Model 621G (Cont'd.)

KJW		
Original Part Number	Part Name	Classic Part Number
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6J-6043	Bearing-Sleeve	374-1456
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-2336	Disc-Friction	433-7096
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313

KJW		
Original Part Number	Part Name	Classic Part Number
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-2104	Bell As-Suction	380-1521
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480

KJW		
Original Part Number	Part Name	Classic Part Number
9N-3167	Plate-Block Bot	430-4468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992

Sales Model 621G (Cont'd.)

KJW		
Original Part Number	Part Name	Classic Part Number
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019

KJW		
Original Part Number	Part Name	Classic Part Number
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735

KJW		
Original Part Number	Part Name	Classic Part Number
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420

KLK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-0408	Cyl Gp-0165 1549	415-1898

KLK		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-1227	Retainer	440-0850
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920

KLK		
Original Part Number	Part Name	Classic Part Number
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952

Sales Model 621G (Cont'd.)

KLK		
Original Part Number	Part Name	Classic Part Number
4M-3915	Bearing-Caged	377-7427
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579

KLK		
Original Part Number	Part Name	Classic Part Number
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6J-6043	Bearing-Sleeve	374-1456
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7N-2156	Bearing-Sleeve	380-7373

KLK		
Original Part Number	Part Name	Classic Part Number
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-2336	Disc-Friction	433-7096
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-2104	Bell As-Suction	380-1521
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9J-1676	Bearing-Sleeve	380-7378

Sales Model 621G (Cont'd.)

KLK		
Original Part Number	Part Name	Classic Part Number
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197

KLK		
Original Part Number	Part Name	Classic Part Number
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054

KLK		
Original Part Number	Part Name	Classic Part Number
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420

MEX		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409

MEX		
Original Part Number	Part Name	Classic Part Number
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802

MEX		
Original Part Number	Part Name	Classic Part Number
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-0408	Cyl Gp-0165 1549	415-1898
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174

Sales Model 621G (Cont'd.)

MEX		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2J-1227	Retainer	440-0850
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190

MEX		
Original Part Number	Part Name	Classic Part Number
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-9962	Bearing-Aligning	399-4397

MEX		
Original Part Number	Part Name	Classic Part Number
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6J-6043	Bearing-Sleeve	374-1456
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374

Sales Model 621G (Cont'd.)

MEX		
Original Part Number	Part Name	Classic Part Number
7K-5448	Cup-Bearing	415-1922
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-2336	Disc-Friction	433-7096
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-2104	Bell As-Suction	380-1521
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9D-5444	Pin	380-7396

MEX		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813

MEX		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420

Sales Model 621G (Cont'd.)

NEL		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-0408	Cyl Gp-0165 1549	415-1898
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-1227	Retainer	440-0850
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-5192	Cyl Gp-0126 1128	399-8577

NEL		
Original Part Number	Part Name	Classic Part Number
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904

NEL		
Original Part Number	Part Name	Classic Part Number
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800

Sales Model 621G (Cont'd.)

NEL		
Original Part Number	Part Name	Classic Part Number
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6J-6043	Bearing-Sleeve	374-1456
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-2336	Disc-Friction	433-7096
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313

NEL		
Original Part Number	Part Name	Classic Part Number
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-2104	Bell As-Suction	380-1521
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480

NEL		
Original Part Number	Part Name	Classic Part Number
9N-3167	Plate-Block Bot	430-4468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992

Sales Model 621G (Cont'd.)

NEL		
Original Part Number	Part Name	Classic Part Number
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019

NEL		
Original Part Number	Part Name	Classic Part Number
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735

NEL		
Original Part Number	Part Name	Classic Part Number
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420

Sales Model 621H

DBK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152

DBK		
Original Part Number	Part Name	Classic Part Number
1T-1348	Support As-Carr	419-4049
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2P-1373	Cup-Rlr Brg	382-5075
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-0034	Trunnion	361-1712
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130

DBK		
Original Part Number	Part Name	Classic Part Number
3G-8136	Retainer	425-3585
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849

Sales Model 621H (Cont'd.)

DBK		
Original Part Number	Part Name	Classic Part Number
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-1980	Pin	385-3805
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-9962	Bearing-Aligning	399-4397

DBK		
Original Part Number	Part Name	Classic Part Number
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6J-6043	Bearing-Sleeve	374-1456
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-2065	Mount As-650 Cup	377-5844
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7C-5665	Elbow-90 Deg	399-8547
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655

DBK		
Original Part Number	Part Name	Classic Part Number
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-3002	Bearing-Spl Ball	386-4961
7T-2336	Disc-Friction	433-7096
7T-8816	Bearing-Spl Ball	420-2491
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-2104	Bell As-Suction	380-1521
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227

Sales Model 621H (Cont'd.)

DBK		
Original Part Number	Part Name	Classic Part Number
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-5284	Bearing-Sleeve	380-7379
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9M-1328	Bearing-Aligning	325-6018
9N-3167	Plate-Block Bot	430-4468
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437

DBK		
Original Part Number	Part Name	Classic Part Number
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-2621	Pin As	390-5273
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
136-7813	Bearing-Race	460-8296
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-7289	Roller As	434-1862

DBK		
Original Part Number	Part Name	Classic Part Number
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420

EAZ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858

EAZ		
Original Part Number	Part Name	Classic Part Number
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400

EAZ		
Original Part Number	Part Name	Classic Part Number
1P-9594	Bearing-Cup	377-7401
1T-0334	Bearing-Ball	380-1476

Sales Model 621H (Cont'd.)

EAZ		
Original Part Number	Part Name	Classic Part Number
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
2A-4429	Lock-Retainer	379-0174
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
3G-0034	Trunnion	361-1712
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6098	Pin As	383-2124
3G-8136	Retainer	425-3585
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915

EAZ		
Original Part Number	Part Name	Classic Part Number
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-2514	Gear-Flywheel	421-7283
5D-9675	Spider	394-9203
5J-1980	Pin	385-3805
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6G-0078	Breather	435-4789

EAZ		
Original Part Number	Part Name	Classic Part Number
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6J-6043	Bearing-Sleeve	374-1456
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-5793	Ring-Seal	451-9028
7C-3567	Mount As	314-8689
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7S-3002	Bearing-Spl Ball	386-4961
7T-2336	Disc-Friction	433-7096
7T-8816	Bearing-Spl Ball	420-2491
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693

Sales Model 621H (Cont'd.)

EAZ		
Original Part Number	Part Name	Classic Part Number
8J-7727	Pin	380-7552
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378

EAZ		
Original Part Number	Part Name	Classic Part Number
9J-1679	Bearing-Sleeve	380-7566
9J-5284	Bearing-Sleeve	380-7379
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9M-1328	Bearing-Aligning	325-6018
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
101-1504	Shaft	373-5379

EAZ		
Original Part Number	Part Name	Classic Part Number
106-7799	Bearing-Ball	396-9947
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
136-7813	Bearing-Race	460-8296
143-3321	Bearing-Sleeve	425-3583
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
177-7886	Cone	418-9605
368-0297	Plate-Clutch	377-7420

HKK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152

HKK		
Original Part Number	Part Name	Classic Part Number
1T-1348	Support As-Carr	419-4049
2A-4429	Lock-Retainer	379-0174
2M-8340	Rod End-Yoke	374-4678
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6098	Pin As	383-2124
3G-8136	Retainer	425-3585
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-1210	Cone-Roller Brg	399-4433

HKK		
Original Part Number	Part Name	Classic Part Number
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-4065	Rod End-Spher	374-1824
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952

Sales Model 621H (Cont'd.)

HKK		
Original Part Number	Part Name	Classic Part Number
4M-3915	Bearing-Caged	377-7427
4N-2514	Gear-Flywheel	421-7283
5D-9675	Spider	394-9203
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6J-6043	Bearing-Sleeve	374-1456

HKK		
Original Part Number	Part Name	Classic Part Number
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-5793	Ring-Seal	451-9028
7C-3567	Mount As	314-8689
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7J-8458	Bearing-Sleeve	380-7374
7S-3002	Bearing-Spl Ball	386-4961
7T-2336	Disc-Friction	433-7096
7T-8816	Bearing-Spl Ball	420-2491
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8P-3512	Piston-Clutch	416-2131

HKK		
Original Part Number	Part Name	Classic Part Number
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-9427	Bearing-Sleeve	361-1695
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
136-7813	Bearing-Race	460-8296
143-3321	Bearing-Sleeve	425-3583
148-3465	Pin	383-2112
177-7886	Cone	418-9605
368-0297	Plate-Clutch	377-7420

NYY		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858

NYY		
Original Part Number	Part Name	Classic Part Number
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400

NYY		
Original Part Number	Part Name	Classic Part Number
1P-9594	Bearing-Cup	377-7401
1T-0334	Bearing-Ball	380-1476

Sales Model 621H (Cont'd.)

NYY		
Original Part Number	Part Name	Classic Part Number
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
2A-4429	Lock-Retainer	379-0174
2M-8340	Rod End-Yoke	374-4678
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6098	Pin As	383-2124
3G-8136	Retainer	425-3585
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226

NYY		
Original Part Number	Part Name	Classic Part Number
3S-3875	Screen-Suction	435-4849
4D-4065	Rod End-Spher	374-1824
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-2514	Gear-Flywheel	421-7283
5D-9675	Spider	394-9203
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579

NYY		
Original Part Number	Part Name	Classic Part Number
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6J-6043	Bearing-Sleeve	374-1456
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-5793	Ring-Seal	451-9028
7C-3567	Mount As	314-8689
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7J-8458	Bearing-Sleeve	380-7374
7S-3002	Bearing-Spl Ball	386-4961
7T-2336	Disc-Friction	433-7096
7T-8816	Bearing-Spl Ball	420-2491
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155

Sales Model 621H (Cont'd.)

NYY		
Original Part Number	Part Name	Classic Part Number
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566

NYY		
Original Part Number	Part Name	Classic Part Number
9J-9427	Bearing-Sleeve	361-1695
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
117-0019	Disc-Friction	417-9492

NYY		
Original Part Number	Part Name	Classic Part Number
118-7805	Pinion-Bevel	394-9197
136-7813	Bearing-Race	460-8296
143-3321	Bearing-Sleeve	425-3583
148-3465	Pin	383-2112
177-7886	Cone	418-9605
368-0297	Plate-Clutch	377-7420

Sales Model 621K

WTA		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049

WTA		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
3G-0034	Trunnion	361-1712
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6098	Pin As	383-2124
3G-8136	Retainer	425-3585
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796

WTA		
Original Part Number	Part Name	Classic Part Number
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-2514	Gear-Flywheel	421-7283
5D-9675	Spider	394-9203
5J-1980	Pin	385-3805
5J-6611	Bearing-Sleeve	383-2140

Sales Model 621K (Cont'd.)

WTA		
Original Part Number	Part Name	Classic Part Number
5K-0983	Seal-Lip Type	472-8012
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6J-6043	Bearing-Sleeve	374-1456
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-5793	Ring-Seal	451-9028
7C-3567	Mount As	314-8689
7G-2500	Gear-Planet	296-1350

WTA		
Original Part Number	Part Name	Classic Part Number
7H-7628	Bearing	453-3655
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7S-3002	Bearing-Spl Ball	386-4961
7T-2336	Disc-Friction	433-7096
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-9075	Bearing-Cone	418-9612

WTA		
Original Part Number	Part Name	Classic Part Number
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-5284	Bearing-Sleeve	380-7379
9J-9427	Bearing-Sleeve	361-1695
9M-1328	Bearing-Aligning	325-6018
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
136-7813	Bearing-Race	460-8296
143-3321	Bearing-Sleeve	425-3583
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
177-7886	Cone	418-9605
368-0297	Plate-Clutch	377-7420

WTE		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858

Sales Model 621K (Cont'd.)

WTE		
Original Part Number	Part Name	Classic Part Number
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
2A-4429	Lock-Retainer	379-0174
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
3G-6098	Pin As	383-2124
3K-0526	Bearing-Ball	386-4949
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849

WTE		
Original Part Number	Part Name	Classic Part Number
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-2514	Gear-Flywheel	421-7283
5D-9675	Spider	394-9203
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6J-6043	Bearing-Sleeve	374-1456
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-5793	Ring-Seal	451-9028
7C-3567	Mount As	314-8689
7G-2500	Gear-Planet	296-1350

WTE		
Original Part Number	Part Name	Classic Part Number
7H-7628	Bearing	453-3655
7J-8458	Bearing-Sleeve	380-7374
7S-3002	Bearing-Spl Ball	386-4961
7T-2336	Disc-Friction	433-7096
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-9427	Bearing-Sleeve	361-1695
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
101-1504	Shaft	373-5379

Sales Model 621K (Cont'd.)

WTE		
Original Part Number	Part Name	Classic Part Number
106-7799	Bearing-Ball	396-9947
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197

WTE		
Original Part Number	Part Name	Classic Part Number
136-7813	Bearing-Race	460-8296
143-3321	Bearing-Sleeve	425-3583

WTE		
Original Part Number	Part Name	Classic Part Number
148-3465	Pin	383-2112
177-7886	Cone	418-9605
368-0297	Plate-Clutch	377-7420

WTL		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
2A-4429	Lock-Retainer	379-0174
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
3G-0034	Trunnion	361-1712
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6098	Pin As	383-2124
3G-8136	Retainer	425-3585

WTL		
Original Part Number	Part Name	Classic Part Number
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-2514	Gear-Flywheel	421-7283

WTL		
Original Part Number	Part Name	Classic Part Number
5D-9675	Spider	394-9203
5J-1980	Pin	385-3805
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6J-6043	Bearing-Sleeve	374-1456
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603

Sales Model 621K (Cont'd.)

WTL		
Original Part Number	Part Name	Classic Part Number
6T-5611	Spacer	435-8520
6Y-5793	Ring-Seal	451-9028
7C-3567	Mount As	314-8689
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7S-3002	Bearing-Spl Ball	386-4961
7T-2336	Disc-Friction	433-7096
7T-8816	Bearing-Spl Ball	420-2491
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-8175	Bearing-Sleeve	376-3636

WTL		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-5284	Bearing-Sleeve	380-7379

WTL		
Original Part Number	Part Name	Classic Part Number
9J-9427	Bearing-Sleeve	361-1695
9M-1328	Bearing-Aligning	325-6018
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
136-7813	Bearing-Race	460-8296
143-3321	Bearing-Sleeve	425-3583
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
177-7886	Cone	418-9605
368-0297	Plate-Clutch	377-7420

WTP		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409

WTP		
Original Part Number	Part Name	Classic Part Number
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802

WTP		
Original Part Number	Part Name	Classic Part Number
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
2A-4429	Lock-Retainer	379-0174
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
3G-6098	Pin As	383-2124
3K-0526	Bearing-Ball	386-4949

Sales Model 621K (Cont'd.)

WTP		
Original Part Number	Part Name	Classic Part Number
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-2514	Gear-Flywheel	421-7283
5D-9675	Spider	394-9203
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5S-4442	Bearing-Spl Ball	419-6025

WTP		
Original Part Number	Part Name	Classic Part Number
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6J-6043	Bearing-Sleeve	374-1456
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-5793	Ring-Seal	451-9028
7C-3567	Mount As	314-8689
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7J-8458	Bearing-Sleeve	380-7374
7S-3002	Bearing-Spl Ball	386-4961
7T-2336	Disc-Friction	433-7096
7T-8816	Bearing-Spl Ball	420-2491
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342

WTP		
Original Part Number	Part Name	Classic Part Number
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-9427	Bearing-Sleeve	361-1695
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
136-7813	Bearing-Race	460-8296
143-3321	Bearing-Sleeve	425-3583
148-3465	Pin	383-2112
177-7886	Cone	418-9605
368-0297	Plate-Clutch	377-7420

Sales Model 621R

12Y		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2M-4208	Spacer-Timing	417-4533

12Y		
Original Part Number	Part Name	Classic Part Number
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2837	Cartridge Gp-Rr	422-8123
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6098	Pin As	383-2124

12Y		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3K-0526	Bearing-Ball	386-4949
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5694	Bearing-Sleeve	379-0190
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-8472	Hood As-Preclnr	296-1355

Sales Model 621R (Cont'd.)

12Y		
Original Part Number	Part Name	Classic Part Number
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-0452	Seal As -Cshaft	325-6191
4W-7188	Core As-Oclr	374-7501
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-1825	Pin	367-6080
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5L-8856	Coupling-Exhaust	311-9379
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rock-er Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5T-3030	Pin As	389-6308
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307

12Y		
Original Part Number	Part Name	Classic Part Number
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6J-6043	Bearing-Sleeve	374-1456
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
7C-3862	Camshaft	458-0151
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435

12Y		
Original Part Number	Part Name	Classic Part Number
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342

Sales Model 621R (Cont'd.)

12Y		
Original Part Number	Part Name	Classic Part Number
8J-7596	Bearing-Sleeve	361-1693
8J-7694	Bearing	431-5264
8J-7727	Pin	380-7552
8M-0874	Plunger As-Valve	311-9439
8M-8652	Shaft	297-7252
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377

12Y		
Original Part Number	Part Name	Classic Part Number
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9H-5797	Plunger As-Pump	391-9891
9J-1676	Bearing-Sleeve	380-7378
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9M-3914	Bearing-Aligning	420-2501
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517

12Y		
Original Part Number	Part Name	Classic Part Number
9N-5403	Body As-Piston	250-6558
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9W-4662	Disc-Friction	428-7203
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-3465	Pin	383-2112
167-8123	Damper As	299-2006
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

Sales Model 621R (Cont'd.)

12Y		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365

12Y		
Original Part Number	Part Name	Classic Part Number
172-7771	Pump Gp-Water -B	419-4646
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605
188-2886	Gasket Kit	434-7281
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085

12Y		
Original Part Number	Part Name	Classic Part Number
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 621S

8KD		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-3062	Director-Water	418-9572
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108

8KD		
Original Part Number	Part Name	Classic Part Number
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-0408	Cyl Gp-0165 1549	415-1898
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

8KD		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197

Sales Model 621S (Cont'd.)

8KD		
Original Part Number	Part Name	Classic Part Number
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8494	Pulley-Alt	295-5692
3G-2834	Cartridge Gp-Rr	426-0025
3G-2837	Cartridge Gp-Rr	422-8123
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-8136	Retainer	425-3585
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424

8KD		
Original Part Number	Part Name	Classic Part Number
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355

8KD		
Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025

Sales Model 621S (Cont'd.)

8KD		
Original Part Number	Part Name	Classic Part Number
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0975	Camshaft-Brake	422-4935
5T-0999	Camshaft-Brake	422-4934
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6J-6043	Bearing-Sleeve	374-1456
6K-4442	Rod End-Special	373-5388
6N-1036	Gear-Oil Pump	279-4991

8KD		
Original Part Number	Part Name	Classic Part Number
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686

8KD		
Original Part Number	Part Name	Classic Part Number
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-0675	Core As-Oclr	434-4016
7W-1927	Ring-Retainer	387-2935
7W-4473	Manifold-Ex	443-2095
7W-5698	Pulley-Cshaft	295-5679
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342

Sales Model 621S (Cont'd.)

8KD		
Original Part Number	Part Name	Classic Part Number
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5385	Manifold-Exhaust	391-9835
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

8KD		
Original Part Number	Part Name	Classic Part Number
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9L-2685	Rod End	419-1866
9L-6371	Rod-Eye	363-7459
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042

8KD		
Original Part Number	Part Name	Classic Part Number
9W-4662	Disc-Friction	428-7203
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
111-8015	Gasket As-Head	279-4977
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194

Sales Model 621S (Cont'd.)

8KD		
Original Part Number	Part Name	Classic Part Number
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

8KD		
Original Part Number	Part Name	Classic Part Number
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
177-7886	Cone	418-9605
188-2887	Kit-Dt Gasket	394-8244
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-8016	Kit-Gasket-Sch	393-0919

8KD		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 623

26U		
Original Part Number	Part Name	Classic Part Number
1J-6746	Pin	256-4817
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595

26U		
Original Part Number	Part Name	Classic Part Number
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-5233	Bearing-Thrust	388-0578

26U		
Original Part Number	Part Name	Classic Part Number
2K-0227	Bearing-Sleeve	384-4780
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4900	Shaft As	384-4792
2S-5551	Coupling-Exhaust	398-2934
2S-6150	Cover-Pulley	428-8817
2T-3885	Housing	448-4967
3G-2752	Cartridge Gp-Rr	422-8127
3G-7666	Cartridge Gp	422-8098
3H-7161	Pin	256-4819
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562

Sales Model 623 (Cont'd.)

26U		
Original Part Number	Part Name	Classic Part Number
3J-3953	Bearing-Sleeve	384-4778
3J-5190	Cap-Brg	256-4837
3J-9133	Bearing-Sleeve	361-1691
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3R-5327	Pipe-Extension	383-1571
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-9215	Gear-Pump Idler	311-9391
4S-5367	Mount As	375-9986
4T-1893	Cartridge Gp	422-8110
4T-7819	Cyl Gp-051 127 Y	426-0028

26U		
Original Part Number	Part Name	Classic Part Number
4W-5363	Core Gp-O Clr	380-7531
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-7958	Shaft-Roller	434-1865
5F-8651	Bearing-Ball	420-3223
5J-1806	Pin	396-0662
5J-1825	Pin	367-6080
5J-2445	Bearing-Sleeve	380-7563
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-6611	Bearing-Sleeve	383-2140
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-9348	Bearing As	416-2162
5K-2294	Bearing	396-9912
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5M-9644	Bearing-Outer	384-5929
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-4557	Bearing	311-9360

26U		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7H-6967	Bearing-Ball	422-6489
7J-1770	Cap-Bearing	396-0664
7J-8458	Bearing-Sleeve	380-7374
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-9146	Gear-Fly Starter	279-4995
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
8B-5972	Bearing-Ball	314-8503
8F-6058	Bearing-Sleeve	416-5494
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-6536	Bearing	425-6444
8J-6552	Carrier-Bearing	399-6055
8J-7211	Guide-Lh	428-8815

Sales Model 623 (Cont'd.)

26U		
Original Part Number	Part Name	Classic Part Number
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8P-4520	Piston-Clutch	394-0908
8S-6782	Adapter-Exhaust	383-1586
8S-9151	Cup-Spl Tapered	374-8348

26U		
Original Part Number	Part Name	Classic Part Number
9J-9427	Bearing-Sleeve	361-1695
9M-3914	Bearing-Aligning	420-2501
9M-8395	Bearing-Sleeve	391-1103
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712

26U		
Original Part Number	Part Name	Classic Part Number
9W-4662	Disc-Friction	428-7203
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
118-7805	Pinion-Bevel	394-9197
190-3832	Core As-Oclr	438-3251
368-0297	Plate-Clutch	377-7420

52U		
Original Part Number	Part Name	Classic Part Number
1J-6746	Pin	256-4817
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464

52U		
Original Part Number	Part Name	Classic Part Number
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-5233	Bearing-Thrust	388-0578
2K-0227	Bearing-Sleeve	384-4780
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533

52U		
Original Part Number	Part Name	Classic Part Number
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2S-5551	Coupling-Exhaust	398-2934
2S-6150	Cover-Pulley	428-8817

Sales Model 623 (Cont'd.)

52U		
Original Part Number	Part Name	Classic Part Number
2T-3885	Housing	448-4967
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2752	Cartridge Gp-Rr	422-8127
3G-7666	Cartridge Gp	422-8098
3H-7161	Pin	256-4819
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-3953	Bearing-Sleeve	384-4778
3J-5190	Cap-Brg	256-4837
3J-9133	Bearing-Sleeve	361-1691
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3R-5327	Pipe-Extension	383-1571
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494

52U		
Original Part Number	Part Name	Classic Part Number
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-9215	Gear-Pump Idler	311-9391
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4S-5367	Mount As	375-9986
4T-1893	Cartridge Gp	422-8110
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-0452	Seal As -Cshaft	325-6191
4W-5363	Core Gp-O Clr	380-7531
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925

52U		
Original Part Number	Part Name	Classic Part Number
5F-7958	Shaft-Roller	434-1865
5F-8651	Bearing-Ball	420-3223
5J-1806	Pin	396-0662
5J-1825	Pin	367-6080
5J-2445	Bearing-Sleeve	380-7563
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-6611	Bearing-Sleeve	383-2140
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-9348	Bearing As	416-2162
5K-2294	Bearing	396-9912
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

Sales Model 623 (Cont'd.)

52U		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6H-2577	Spider Gp-Brg	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7H-6967	Bearing-Ball	422-6489
7J-1770	Cap-Bearing	396-0664
7J-8458	Bearing-Sleeve	380-7374
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816

52U		
Original Part Number	Part Name	Classic Part Number
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-5910	Impeller-Pump	314-8686
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-0205	Core As-Oclr	379-0183
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5972	Bearing-Ball	314-8503
8F-6058	Bearing-Sleeve	416-5494
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781

52U		
Original Part Number	Part Name	Classic Part Number
8J-0632	Pin	396-7280
8J-6536	Bearing	425-6444
8J-6552	Carrier-Bearing	399-6055
8J-7211	Guide-Lh	428-8815
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

Sales Model 623 (Cont'd.)

52U		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
9B-1320	Valve-Check	377-5832
9J-9427	Bearing-Sleeve	361-1695
9M-3914	Bearing-Aligning	420-2501

52U		
Original Part Number	Part Name	Classic Part Number
9M-5477	Bearing-Sleeve	374-6517
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9W-4662	Disc-Friction	428-7203
9Y-1798	Seal-Water	379-0165
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
118-7805	Pinion-Bevel	394-9197
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194

52U		
Original Part Number	Part Name	Classic Part Number
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
187-0605	Gasket Kit - Cl	382-5055
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 623B

46P		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2491	Muffler As-Eject	360-7871
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

46P		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1757	Hub-Fan Pulley	296-1357
2P-5680	Turbine-Conv	308-9942
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2P-9314	Disc As-Clutch	384-4791
2S-4900	Shaft As	384-4792
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7455	Gear As	396-9957
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-2834	Cartridge Gp-Rr	426-0025
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6098	Pin As	383-2124
3G-7638	Pump Gp-Vn Bsc-B	422-8174

46P		
Original Part Number	Part Name	Classic Part Number
3G-7639	Pump Gp-Vn Bsc-B	422-8173
3G-7651	Cartridge Gp	422-8121
3G-7652	Cartridge Gp	426-0026
3G-7657	Cartridge Gp	422-8101
3G-7664	Cartridge Gp	422-8130
3H-8726	Mount As	385-7208
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-5100	Hub-Impeller	451-9022
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5694	Bearing-Sleeve	379-0190
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974

Sales Model 623B (Cont'd.)

46P		
Original Part Number	Part Name	Classic Part Number
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-5958	Tube-Exhaust Ext	385-3811
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217

46P		
Original Part Number	Part Name	Classic Part Number
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-4588	Sleeve	394-0218
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5B-9169	Plug-Drain	419-4736
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-1825	Pin	367-6080
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5L-6326	Bearing-Ball	420-3222
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5M-2054	Bearing	380-7510

46P		
Original Part Number	Part Name	Classic Part Number
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-8053	Kit-Gasket (Sch)	415-1901
5P-8366	Gasket Kit - Sch	387-2911
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-3030	Pin As	389-6308
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-0400	Shaft-Drive	399-4403
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518

Sales Model 623B (Cont'd.)

46P		
Original Part Number	Part Name	Classic Part Number
6I-3907	Adapter-Pilot	398-8348
6I-4024	Gasket-Plate	377-5839
6I-9509	Plate	398-2960
6J-6043	Bearing-Sleeve	374-1456
6L-7751	Rod End-Spher	472-8015
6N-1931	Plunger	379-0171
6N-4184	Muffler As	385-7226
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6N-9743	Support-Muffler	308-9940
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-3509	Pipe As-Ex Ext	373-1907
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847

46P		
Original Part Number	Part Name	Classic Part Number
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7J-8458	Bearing-Sleeve	380-7374
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8371	Line As-Fuel Inj	373-1901
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0140	Gear-Drive	399-8546
7W-0182	Plunger & Bbl As	391-9893
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333

46P		
Original Part Number	Part Name	Classic Part Number
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-4402	Yoke	365-8823
8D-5048	Yoke As	415-1899
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7694	Bearing	431-5264
8J-7727	Pin	380-7552
8M-0874	Plunger As-Valve	311-9439
8M-8652	Shaft	297-7252
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077

Sales Model 623B (Cont'd.)

46P		
Original Part Number	Part Name	Classic Part Number
8N-8983	Hub-Fan Pulley	421-7227
8N-9622	Bracket As-Fan	433-2024
8P-4520	Piston-Clutch	394-0908
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9M-1853	Mount As.	376-3638
9M-3914	Bearing-Aligning	420-2501
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9N-5529	Body-F Inj Valve	378-3993
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9W-4702	Stator-Converter	308-9939
9W-9930	Mount As	295-6437

46P		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215

46P		
Original Part Number	Part Name	Classic Part Number
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
148-3465	Pin	383-2112
150-4637	Pan-Oil	377-5843

Sales Model 623B (Cont'd.)

46P		
Original Part Number	Part Name	Classic Part Number
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656

46P		
Original Part Number	Part Name	Classic Part Number
188-2886	Gasket Kit	434-7281
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266

46P		
Original Part Number	Part Name	Classic Part Number
217-8938	Tightening-Belt	419-4735
232-6574	Kit-Gasket-Rs	437-2034
233-7083	Kit-Gasket-Fs	387-2919
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

61E		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
2K-0227	Bearing-Sleeve	384-4780
2T-3885	Housing	448-4967
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7482	Sleeve	425-3455
3J-2373	Bearing-Sleeve	380-7562

61E		
Original Part Number	Part Name	Classic Part Number
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
5F-2830	Bearing-Needle	384-5925
5F-7958	Shaft-Roller	434-1865
5J-2445	Bearing-Sleeve	380-7563
5J-9348	Bearing As	416-2162
5M-9644	Bearing-Outer	384-5929

61E		
Original Part Number	Part Name	Classic Part Number
6J-6043	Bearing-Sleeve	374-1456
7F-7780	Pin-Anchor	384-4825
7J-1770	Cap-Bearing	396-0664
8B-5972	Bearing-Ball	314-8503
8H-9789	Bearing-Ball	374-8342
8J-6536	Bearing	425-6444
8J-6552	Carrier-Bearing	399-6055
8J-7211	Guide-Lh	428-8815
9J-1676	Bearing-Sleeve	380-7378

Sales Model 623B (Cont'd.)

61E		
Original Part Number	Part Name	Classic Part Number
9J-1679	Bearing-Sleeve	380-7566

61E		
Original Part Number	Part Name	Classic Part Number
9J-8323	Trunnion	361-1713
9S-8184	Pin-Drawbar	398-8345

61E		
Original Part Number	Part Name	Classic Part Number
132-6597	Cone-Spl	422-6477

Sales Model 623E

5SG		
Original Part Number	Part Name	Classic Part Number
1S-9110	Bearing-Needle	420-2497
2K-0227	Bearing-Sleeve	384-4780
2T-3885	Housing	448-4967
2T-3890	Shaft As-Stub	425-9376
3E-6772	Seal-Water	382-8017
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7482	Sleeve	425-3455
3J-2373	Bearing-Sleeve	380-7562
4D-0487	Valve As-Check	375-4334
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4N-0685	Bearing-Sleeve	379-0191

5SG		
Original Part Number	Part Name	Classic Part Number
4N-6658	Bearing-Sleeve	373-1885
5F-2830	Bearing-Needle	384-5925
5F-7958	Shaft-Roller	434-1865
5J-2445	Bearing-Sleeve	380-7563
5M-6126	Bearing	377-7433
5M-9644	Bearing-Outer	384-5929
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6J-6043	Bearing-Sleeve	374-1456
6V-3831	Seal-O-Ring	436-2657
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7F-7780	Pin-Anchor	384-4825
7J-1770	Cap-Bearing	396-0664
7T-2036	Cap As-Fuel	361-1721
7W-5733	Gasket	421-7333

5SG		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8J-6536	Bearing	425-6444
8J-6552	Carrier-Bearing	399-6055
8J-7211	Guide-Lh	428-8815
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9S-8184	Pin-Drawbar	398-8345
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
144-7299	Roller As	434-1991
155-5619	Gasket	382-5054
166-9142	Gasket	420-8546
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665

6CB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913

Sales Model 623E (Cont'd.)

6CB		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-3743	Bearing-Ball	384-4786
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2491	Muffler As-Eject	360-7871
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059

6CB		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0227	Bearing-Sleeve	384-4780
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-5680	Turbine-Conv	308-9942
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2P-9314	Disc As-Clutch	384-4791
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2T-3885	Housing	448-4967
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7455	Gear As	396-9957
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-2834	Cartridge Gp-Rr	426-0025
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7482	Sleeve	425-3455
3G-7638	Pump Gp-Vn Bsc-B	422-8174
3G-7639	Pump Gp-Vn Bsc-B	422-8173
3G-7651	Cartridge Gp	422-8121

6CB		
Original Part Number	Part Name	Classic Part Number
3G-7652	Cartridge Gp	426-0026
3G-7657	Cartridge Gp	422-8101
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-2373	Bearing-Sleeve	380-7562
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-5100	Hub-Impeller	451-9022
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191

Sales Model 623E (Cont'd.)

6CB		
Original Part Number	Part Name	Classic Part Number
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320

6CB		
Original Part Number	Part Name	Classic Part Number
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5F-7958	Shaft-Roller	434-1865
5G-3612	Cap Gp-Protn	295-6419
5J-2445	Bearing-Sleeve	380-7563
5J-6611	Bearing-Sleeve	383-2140
5J-9348	Bearing As	416-2162
5K-0983	Seal-Lip Type	472-8012
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397

6CB		
Original Part Number	Part Name	Classic Part Number
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-0400	Shaft-Drive	399-4403
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-3907	Adapter-Pilot	398-8348
6I-4024	Gasket-Plate	377-5839
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6I-9509	Plate	398-2960
6J-6043	Bearing-Sleeve	374-1456
6K-4442	Rod End-Special	373-5388
6N-1931	Plunger	379-0171

Sales Model 623E (Cont'd.)

6CB		
Original Part Number	Part Name	Classic Part Number
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-7476	Kit-Dt Gasket	390-5282
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6628	Pulley-Alt	396-9894
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441

6CB		
Original Part Number	Part Name	Classic Part Number
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-8458	Bearing-Sleeve	380-7374
7K-2135	Bearing-Roller	417-4492
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7W-6459	Core As-Oclr	395-1313
8B-5972	Bearing-Ball	314-8503
8D-3669	Gear-Diff Ring	418-9581

6CB		
Original Part Number	Part Name	Classic Part Number
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-6536	Bearing	425-6444
8J-6552	Carrier-Bearing	399-6055
8J-7211	Guide-Lh	428-8815
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077
8N-8983	Hub-Fan Pulley	421-7227
8P-2051	Plate-Clutch	385-6116
8P-3512	Piston-Clutch	416-2131

Sales Model 623E (Cont'd.)

6CB		
Original Part Number	Part Name	Classic Part Number
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9W-4702	Stator-Converter	308-9939
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665

6CB		
Original Part Number	Part Name	Classic Part Number
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
111-3895	Yoke	421-3080
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704

6CB		
Original Part Number	Part Name	Classic Part Number
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
133-3359	Manifold-Exhaust	419-4730
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-7299	Roller As	434-1991
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
146-4229	Gasket Kit - Sch	437-4599
148-3465	Pin	383-2112
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106

Sales Model 623E (Cont'd.)

6CB		
Original Part Number	Part Name	Classic Part Number
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
188-2887	Kit-Dt Gasket	394-8244

6CB		
Original Part Number	Part Name	Classic Part Number
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
232-3679	Kit-Gasket (Rs)	437-2039

6CB		
Original Part Number	Part Name	Classic Part Number
232-6574	Kit-Gasket-Rs	437-2034
234-1874	Kit-Gasket-Fs	437-8668
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

6DB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672

6DB		
Original Part Number	Part Name	Classic Part Number
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-3743	Bearing-Ball	384-4786
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409

6DB		
Original Part Number	Part Name	Classic Part Number
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356

Sales Model 623E (Cont'd.)

6DB		
Original Part Number	Part Name	Classic Part Number
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0227	Bearing-Sleeve	384-4780
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-5680	Turbine-Conv	308-9942
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2P-9314	Disc As-Clutch	384-4791
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2T-3885	Housing	448-4967
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7482	Sleeve	425-3455

6DB		
Original Part Number	Part Name	Classic Part Number
3G-7638	Pump Gp-Vn Bsc-B	422-8174
3G-7639	Pump Gp-Vn Bsc-B	422-8173
3G-7651	Cartridge Gp	422-8121
3G-7652	Cartridge Gp	426-0026
3G-7657	Cartridge Gp	422-8101
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-2373	Bearing-Sleeve	380-7562
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-5100	Hub-Impeller	451-9022
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427

6DB		
Original Part Number	Part Name	Classic Part Number
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

Sales Model 623E (Cont'd.)

6DB		
Original Part Number	Part Name	Classic Part Number
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5F-7958	Shaft-Roller	434-1865
5G-3612	Cap Gp-Protn	295-6419
5J-2445	Bearing-Sleeve	380-7563
5J-6611	Bearing-Sleeve	383-2140
5J-9348	Bearing As	416-2162
5K-0983	Seal-Lip Type	472-8012
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025

6DB		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-0400	Shaft-Drive	399-4403
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6I-9509	Plate	398-2960
6J-6043	Bearing-Sleeve	374-1456
6K-4442	Rod End-Special	373-5388
6N-1931	Plunger	379-0171
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603

6DB		
Original Part Number	Part Name	Classic Part Number
6T-1996	Plate-Clutch	368-0117
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6628	Pulley-Alt	396-9894
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-8458	Bearing-Sleeve	380-7374
7K-2135	Bearing-Roller	417-4492
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816

Sales Model 623E (Cont'd.)

6DB		
Original Part Number	Part Name	Classic Part Number
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7W-6459	Core As-Oclr	395-1313
8B-5972	Bearing-Ball	314-8503
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342

6DB		
Original Part Number	Part Name	Classic Part Number
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-6536	Bearing	425-6444
8J-6552	Carrier-Bearing	399-6055
8J-7211	Guide-Lh	428-8815
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077
8N-8983	Hub-Fan Pulley	421-7227
8P-2051	Plate-Clutch	385-6116
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-2685	Rod End	419-1866

6DB		
Original Part Number	Part Name	Classic Part Number
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-7949	Cup-Roller Brg	420-6531
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9W-4702	Stator-Converter	308-9939
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
108-2102	Bonnet-Valve	455-3274

Sales Model 623E (Cont'd.)

6DB		
Original Part Number	Part Name	Classic Part Number
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
111-3895	Yoke	421-3080
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813

6DB		
Original Part Number	Part Name	Classic Part Number
143-3321	Bearing-Sleeve	425-3583
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-7299	Roller As	434-1991
145-8503	Shaft As-Idler	426-0035
148-3465	Pin	383-2112
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699

6DB		
Original Part Number	Part Name	Classic Part Number
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3679	Kit-Gasket (Rs)	437-2039
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812
1P-9593	Cone-Rlr Brg	377-7400

6YF		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858

6YF		
Original Part Number	Part Name	Classic Part Number
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145

6YF		
Original Part Number	Part Name	Classic Part Number
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499

Sales Model 623E (Cont'd.)

6YF		
Original Part Number	Part Name	Classic Part Number
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2491	Muffler As-Eject	360-7871
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-9313	Pump Gp-Gr 1 Bsc	418-1966

6YF		
Original Part Number	Part Name	Classic Part Number
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3G-2837	Cartridge Gp-Rr	422-8123
3G-5192	Cyl Gp-0126 1128	399-8577
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4E-0403	Gear-Planet	260-0781
4J-5694	Bearing-Sleeve	379-0190
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499

6YF		
Original Part Number	Part Name	Classic Part Number
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320

Sales Model 623E (Cont'd.)

6YF		
Original Part Number	Part Name	Classic Part Number
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269

6YF		
Original Part Number	Part Name	Classic Part Number
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-3907	Adapter-Pilot	398-8348
6I-4024	Gasket-Plate	377-5839
6J-6043	Bearing-Sleeve	374-1456
6K-4442	Rod End-Special	373-5388
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6N-9743	Support-Muffler	308-9940
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303

6YF		
Original Part Number	Part Name	Classic Part Number
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-8458	Bearing-Sleeve	380-7374
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-7809	Cap As-Radiator	295-6417
7T-2336	Disc-Friction	433-7096

Sales Model 623E (Cont'd.)

6YF		
Original Part Number	Part Name	Classic Part Number
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077

6YF		
Original Part Number	Part Name	Classic Part Number
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-9427	Bearing-Sleeve	361-1695
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9T-6123	Pump Gp-Vn Bsc-B	422-8147
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057

6YF		
Original Part Number	Part Name	Classic Part Number
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
111-3895	Yoke	421-3080
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587

Sales Model 623E (Cont'd.)

6YF		
Original Part Number	Part Name	Classic Part Number
118-7805	Pinion-Bevel	394-9197
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-3012	Gasket Kit	437-3229
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
142-7526	Gasket Kit	393-0918
143-3321	Bearing-Sleeve	425-3583
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-4229	Gasket Kit - Sch	437-4599
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106

6YF		
Original Part Number	Part Name	Classic Part Number
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
188-2887	Kit-Dt Gasket	394-8244
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012

6YF		
Original Part Number	Part Name	Classic Part Number
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
232-2922	Kit-Gasket-Rs	437-8671
232-3679	Kit-Gasket (Rs)	437-2039
233-9456	Kit-Gasket-Sch	422-7510
234-1874	Kit-Gasket-Fs	437-8668
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

Sales Model 623F

3XW		
Original Part Number	Part Name	Classic Part Number
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9110	Bearing-Needle	420-2497
2T-3885	Housing	448-4967
2T-3890	Shaft As-Stub	425-9376
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7482	Sleeve	425-3455
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
4D-0487	Valve As-Check	375-4334
4J-5693	Bearing-Sleeve	385-3790

3XW		
Original Part Number	Part Name	Classic Part Number
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
5F-2830	Bearing-Needle	384-5925
5F-7958	Shaft-Roller	434-1865
5J-2445	Bearing-Sleeve	380-7563
5M-6126	Bearing	377-7433
5M-9644	Bearing-Outer	384-5929
5T-0975	Camshaft-Brake	422-4935
5T-0999	Camshaft-Brake	422-4934
6J-6043	Bearing-Sleeve	374-1456
7B-7515	Bearing-Ball	399-6059

3XW		
Original Part Number	Part Name	Classic Part Number
7F-7780	Pin-Anchor	384-4825
7J-1770	Cap-Bearing	396-0664
7K-5448	Cup-Bearing	415-1922
7T-2036	Cap As-Fuel	361-1721
8J-6552	Carrier-Bearing	399-6055
8J-7211	Guide-Lh	428-8815
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9S-8184	Pin-Drawbar	398-8345
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
310-3510	Roller As.	434-1919
325-3291	Roller As	434-1918

5EW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464

5EW		
Original Part Number	Part Name	Classic Part Number
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2491	Muffler As-Eject	360-7871

5EW		
Original Part Number	Part Name	Classic Part Number
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-9313	Pump Gp-Gr 1 Bsc	418-1966

Sales Model 623F (Cont'd.)

5EW		
Original Part Number	Part Name	Classic Part Number
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3G-2837	Cartridge Gp-Rr	422-8123
3G-8136	Retainer	425-3585
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4E-0403	Gear-Planet	260-0781
4J-5694	Bearing-Sleeve	379-0190
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502

5EW		
Original Part Number	Part Name	Classic Part Number
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318

5EW		
Original Part Number	Part Name	Classic Part Number
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535

Sales Model 623F (Cont'd.)

5EW		
Original Part Number	Part Name	Classic Part Number
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-3907	Adapter-Pilot	398-8348
6I-4024	Gasket-Plate	377-5839
6L-7751	Rod End-Spher	472-8015
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6N-9743	Support-Muffler	308-9940
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523

5EW		
Original Part Number	Part Name	Classic Part Number
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9595	Core As-Radiator	396-9926
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-8458	Bearing-Sleeve	380-7374
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-7809	Cap As-Radiator	295-6417
7T-2336	Disc-Friction	433-7096
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493

5EW		
Original Part Number	Part Name	Classic Part Number
7W-5733	Gasket	421-7333
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8M-3368	Valve-Check	388-6599
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372

Sales Model 623F (Cont'd.)

5EW		
Original Part Number	Part Name	Classic Part Number
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691

5EW		
Original Part Number	Part Name	Classic Part Number
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193

5EW		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
145-8503	Shaft As-Idler	426-0035
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
188-2887	Kit-Dt Gasket	394-8244
191-7941	Line As-Fuel Inj	378-4011

Sales Model 623F (Cont'd.)

5EW		
Original Part Number	Part Name	Classic Part Number
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368

5EW		
Original Part Number	Part Name	Classic Part Number
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367

5EW		
Original Part Number	Part Name	Classic Part Number
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

5SG		
Original Part Number	Part Name	Classic Part Number
1S-9110	Bearing-Needle	420-2497
2K-0227	Bearing-Sleeve	384-4780
2T-3885	Housing	448-4967
2T-3890	Shaft As-Stub	425-9376
3E-6772	Seal-Water	382-8017
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7482	Sleeve	425-3455
3J-2373	Bearing-Sleeve	380-7562
4D-0487	Valve As-Check	375-4334
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922

5SG		
Original Part Number	Part Name	Classic Part Number
4N-0685	Bearing-Sleeve	379-0191
4N-6658	Bearing-Sleeve	373-1885
5F-2830	Bearing-Needle	384-5925
5F-7958	Shaft-Roller	434-1865
5J-2445	Bearing-Sleeve	380-7563
5M-6126	Bearing	377-7433
5M-9644	Bearing-Outer	384-5929
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6J-6043	Bearing-Sleeve	374-1456
6V-3831	Seal-O-Ring	436-2657
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7F-7780	Pin-Anchor	384-4825

5SG		
Original Part Number	Part Name	Classic Part Number
7J-1770	Cap-Bearing	396-0664
7T-2036	Cap As-Fuel	361-1721
7W-5733	Gasket	421-7333
8B-5972	Bearing-Ball	314-8503
8J-6536	Bearing	425-6444
8J-6552	Carrier-Bearing	399-6055
8J-7211	Guide-Lh	428-8815
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9S-8184	Pin-Drawbar	398-8345
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
144-7299	Roller As	434-1991
155-5619	Gasket	382-5054
166-9142	Gasket	420-8546

Sales Model 623F (Cont'd.)

5SG		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-6387

5SG		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-4665

6BK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2491	Muffler As-Eject	360-7871

6BK		
Original Part Number	Part Name	Classic Part Number
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3G-2837	Cartridge Gp-Rr	422-8123
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356

6BK		
Original Part Number	Part Name	Classic Part Number
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4E-0403	Gear-Planet	260-0781
4J-5694	Bearing-Sleeve	379-0190
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928

Sales Model 623F (Cont'd.)

6BK		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203

6BK		
Original Part Number	Part Name	Classic Part Number
5F-2830	Bearing-Needle	384-5925
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757

6BK		
Original Part Number	Part Name	Classic Part Number
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-3907	Adapter-Pilot	398-8348
6I-4024	Gasket-Plate	377-5839
6L-7751	Rod End-Spher	472-8015
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6N-9743	Support-Muffler	308-9940
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825

Sales Model 623F (Cont'd.)

6BK		
Original Part Number	Part Name	Classic Part Number
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-8458	Bearing-Sleeve	380-7374
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-7809	Cap As-Radiator	295-6417
7T-2336	Disc-Friction	433-7096
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494

6BK		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8M-3368	Valve-Check	388-6599
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480

6BK		
Original Part Number	Part Name	Classic Part Number
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9T-6123	Pump Gp-Vn Bsc-B	422-8147
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062

Sales Model 623F (Cont'd.)

6BK		
Original Part Number	Part Name	Classic Part Number
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-3012	Gasket Kit	437-3229
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813

6BK		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
145-8503	Shaft As-Idler	426-0035
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
188-2887	Kit-Dt Gasket	394-8244
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700

6BK		
Original Part Number	Part Name	Classic Part Number
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
232-3679	Kit-Gasket (Rs)	437-2039
233-9456	Kit-Gasket-Sch	422-7510
234-1874	Kit-Gasket-Fs	437-8668
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

Sales Model 623G

ARW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2G-1034	Valve-Safety	380-7555
2L-5271	Bearing-Ball	371-4305
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6150	Cover-Pulley	428-8817

ARW		
Original Part Number	Part Name	Classic Part Number
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-2837	Cartridge Gp-Rr	422-8123
3G-8136	Retainer	425-3585
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4E-0403	Gear-Planet	260-0781
4J-5694	Bearing-Sleeve	379-0190
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0362	Cover As-Rgltr	419-4722
4N-0685	Bearing-Sleeve	379-0191
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271

ARW		
Original Part Number	Part Name	Classic Part Number
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535

Sales Model 623G (Cont'd.)

ARW		
Original Part Number	Part Name	Classic Part Number
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3066	Gasket-Cyl Head	380-1518
6I-3907	Adapter-Pilot	398-8348
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-8458	Bearing-Sleeve	380-7374

ARW		
Original Part Number	Part Name	Classic Part Number
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-2336	Disc-Friction	433-7096
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-5733	Gasket	421-7333
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612

ARW		
Original Part Number	Part Name	Classic Part Number
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589

Sales Model 623G (Cont'd.)

ARW		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845

ARW		
Original Part Number	Part Name	Classic Part Number
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
188-2887	Kit-Dt Gasket	394-8244
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003
216-5582	Bearing-Sleeve	390-0914

ARW		
Original Part Number	Part Name	Classic Part Number
217-0578	Bearing-Rod	419-4665
232-3679	Kit-Gasket (Rs)	437-2039
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
347-6081	Gauge As	360-2348
352-1053	Kit-Dt Gasket	447-0829
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

AWB		
Original Part Number	Part Name	Classic Part Number
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9110	Bearing-Needle	420-2497
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
2T-3885	Housing	448-4967

AWB		
Original Part Number	Part Name	Classic Part Number
2T-3890	Shaft As-Stub	425-9376
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7482	Sleeve	425-3455
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3K-0526	Bearing-Ball	386-4949
3S-1292	Bearing-Sleeve	425-8226
4D-0487	Valve As-Check	375-4334
4J-5693	Bearing-Sleeve	385-3790

AWB		
Original Part Number	Part Name	Classic Part Number
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4M-3915	Bearing-Caged	377-7427
5F-2830	Bearing-Needle	384-5925
5F-7958	Shaft-Roller	434-1865
5J-2445	Bearing-Sleeve	380-7563
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-9644	Bearing-Outer	384-5929

Sales Model 623G (Cont'd.)

AWB		
Original Part Number	Part Name	Classic Part Number
5S-4442	Bearing-Spl Ball	419-6025
5T-0975	Camshaft-Brake	422-4935
5T-0999	Camshaft-Brake	422-4934
6J-6043	Bearing-Sleeve	374-1456
7B-7515	Bearing-Ball	399-6059
7F-7780	Pin-Anchor	384-4825

AWB		
Original Part Number	Part Name	Classic Part Number
7J-1770	Cap-Bearing	396-0664
7K-5448	Cup-Bearing	415-1922
7T-2036	Cap As-Fuel	361-1721
8J-6552	Carrier-Bearing	399-6055
8J-7211	Guide-Lh	428-8815
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566

AWB		
Original Part Number	Part Name	Classic Part Number
9J-8323	Trunnion	361-1713
9S-8184	Pin-Drawbar	398-8345
030-0060	Bearing-Cup	415-1926
106-7799	Bearing-Ball	396-9947
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
177-7886	Cone	418-9605
310-3510	Roller As.	434-1919
325-3291	Roller As	434-1918

CES		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9110	Bearing-Needle	420-2497
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802

CES		
Original Part Number	Part Name	Classic Part Number
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2G-1034	Valve-Safety	380-7555
2L-5271	Bearing-Ball	371-4305
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6150	Cover-Pulley	428-8817
2T-3885	Housing	448-4967
2T-3890	Shaft As-Stub	425-9376
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914

CES		
Original Part Number	Part Name	Classic Part Number
3E-6772	Seal-Water	382-8017
3G-2837	Cartridge Gp-Rr	422-8123
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7482	Sleeve	425-3455
3G-8136	Retainer	425-3585
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849

Sales Model 623G (Cont'd.)

CES		
Original Part Number	Part Name	Classic Part Number
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0362	Cover As-Rgltr	419-4722
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-5367	Mount As	375-9986
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549

CES		
Original Part Number	Part Name	Classic Part Number
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5F-7958	Shaft-Roller	434-1865
5J-2445	Bearing-Sleeve	380-7563
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757

CES		
Original Part Number	Part Name	Classic Part Number
6I-3907	Adapter-Pilot	398-8348
6J-6043	Bearing-Sleeve	374-1456
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7E-9595	Core As-Radiator	396-9926
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811

Sales Model 623G (Cont'd.)

CES		
Original Part Number	Part Name	Classic Part Number
7N-7878	Cover-Plate	434-2401
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-6552	Carrier-Bearing	399-6055
8J-7211	Guide-Lh	428-8815
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9D-5444	Pin	380-7396
9J-1676	Bearing-Sleeve	380-7378

CES		
Original Part Number	Part Name	Classic Part Number
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193

CES		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
232-3679	Kit-Gasket (Rs)	437-2039

Sales Model 623G (Cont'd.)

CES		
Original Part Number	Part Name	Classic Part Number
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
310-3510	Roller As.	434-1919
321-5746	Bearing-Main	419-6367

CES		
Original Part Number	Part Name	Classic Part Number
325-3291	Roller As	434-1918
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665

CES		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-6387
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

CEW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9110	Bearing-Needle	420-2497
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-7238	Shaft As-Pump Dr	379-0164

CEW		
Original Part Number	Part Name	Classic Part Number
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2G-1034	Valve-Safety	380-7555
2L-5271	Bearing-Ball	371-4305
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6150	Cover-Pulley	428-8817
2T-3885	Housing	448-4967
2T-3890	Shaft As-Stub	425-9376
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-2837	Cartridge Gp-Rr	422-8123
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7482	Sleeve	425-3455
3G-8136	Retainer	425-3585

CEW		
Original Part Number	Part Name	Classic Part Number
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427

Sales Model 623G (Cont'd.)

CEW		
Original Part Number	Part Name	Classic Part Number
4N-0362	Cover As-Rgltr	419-4722
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-5367	Mount As	375-9986
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5F-7958	Shaft-Roller	434-1865
5J-2445	Bearing-Sleeve	380-7563
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433

CEW		
Original Part Number	Part Name	Classic Part Number
5M-6212	Tube	390-0996
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6J-6043	Bearing-Sleeve	374-1456
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571

CEW		
Original Part Number	Part Name	Classic Part Number
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781

Sales Model 623G (Cont'd.)

CEW		
Original Part Number	Part Name	Classic Part Number
8J-0632	Pin	396-7280
8J-6552	Carrier-Bearing	399-6055
8J-7211	Guide-Lh	428-8815
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9D-5444	Pin	380-7396
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926

CEW		
Original Part Number	Part Name	Classic Part Number
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054

CEW		
Original Part Number	Part Name	Classic Part Number
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
232-3679	Kit-Gasket (Rs)	437-2039
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
310-3510	Roller As.	434-1919
321-5746	Bearing-Main	419-6367
325-3291	Roller As	434-1918
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

Sales Model 623G (Cont'd.)

DBC		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9110	Bearing-Needle	420-2497
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2P-1373	Cup-Rlr Brg	382-5075
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2T-3885	Housing	448-4967
2T-3890	Shaft As-Stub	425-9376
2W-6280	Bracket As-Fan	431-5271

DBC		
Original Part Number	Part Name	Classic Part Number
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-2837	Cartridge Gp-Rr	422-8123
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7482	Sleeve	425-3455
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952

DBC		
Original Part Number	Part Name	Classic Part Number
4M-3915	Bearing-Caged	377-7427
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5F-7958	Shaft-Roller	434-1865
5J-2445	Bearing-Sleeve	380-7563
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-9644	Bearing-Outer	384-5929
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269

Sales Model 623G (Cont'd.)

DBC		
Original Part Number	Part Name	Classic Part Number
5T-9430	Race-Seal Ring	398-8347
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6J-6043	Bearing-Sleeve	374-1456
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7N-2156	Bearing-Sleeve	380-7373

DBC		
Original Part Number	Part Name	Classic Part Number
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-6552	Carrier-Bearing	399-6055
8J-7211	Guide-Lh	428-8815
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-2104	Bell As-Suction	380-1521
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9D-5444	Pin	380-7396

DBC		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-2621	Pin As	390-5273
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

Sales Model 623G (Cont'd.)

DBC		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107

DBC		
Original Part Number	Part Name	Classic Part Number
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914

DBC		
Original Part Number	Part Name	Classic Part Number
217-8938	Tightening-Belt	419-4735
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
310-3510	Roller As.	434-1919
325-3291	Roller As	434-1918
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420

DBY		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9110	Bearing-Needle	420-2497
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715

DBY		
Original Part Number	Part Name	Classic Part Number
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2P-1373	Cup-Rlr Brg	382-5075
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2T-3885	Housing	448-4967
2T-3890	Shaft As-Stub	425-9376
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914

DBY		
Original Part Number	Part Name	Classic Part Number
3E-6772	Seal-Water	382-8017
3G-2837	Cartridge Gp-Rr	422-8123
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7482	Sleeve	425-3455
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063

Sales Model 623G (Cont'd.)

DBY		
Original Part Number	Part Name	Classic Part Number
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5F-7958	Shaft-Roller	434-1865
5J-2445	Bearing-Sleeve	380-7563
5J-6611	Bearing-Sleeve	383-2140

DBY		
Original Part Number	Part Name	Classic Part Number
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-9644	Bearing-Outer	384-5929
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6J-6043	Bearing-Sleeve	374-1456
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-2065	Mount As-650 Cup	377-5844
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547

DBY		
Original Part Number	Part Name	Classic Part Number
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-6552	Carrier-Bearing	399-6055
8J-7211	Guide-Lh	428-8815
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-2104	Bell As-Suction	380-1521

Sales Model 623G (Cont'd.)

DBY		
Original Part Number	Part Name	Classic Part Number
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605

DBY		
Original Part Number	Part Name	Classic Part Number
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-2621	Pin As	390-5273
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991

DBY		
Original Part Number	Part Name	Classic Part Number
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
310-3510	Roller As.	434-1919
325-3291	Roller As	434-1918
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420

Sales Model 623H

DBF		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913

Sales Model 623H (Cont'd.)

DBF		
Original Part Number	Part Name	Classic Part Number
1P-4110	Disc-Friction	433-9858
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9110	Bearing-Needle	420-2497
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2P-1373	Cup-Rlr Brg	382-5075
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2T-3885	Housing	448-4967
2T-3890	Shaft As-Stub	425-9376
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914

DBF		
Original Part Number	Part Name	Classic Part Number
3E-6772	Seal-Water	382-8017
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7482	Sleeve	425-3455
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-2373	Bearing-Sleeve	380-7562
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0913	Screen As-Bell	374-7489

DBF		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-2445	Bearing-Sleeve	380-7563
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-9644	Bearing-Outer	384-5929
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220

Sales Model 623H (Cont'd.)

DBF		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6J-6043	Bearing-Sleeve	374-1456
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-2065	Mount As-650 Cup	377-5844
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7C-5665	Elbow-90 Deg	399-8547
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-3216	Bearing	368-0104
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-2336	Disc-Friction	433-7096
7T-8816	Bearing-Spl Ball	420-2491

DBF		
Original Part Number	Part Name	Classic Part Number
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7211	Guide-Lh	428-8815
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-2104	Bell As-Suction	380-1521
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695

DBF		
Original Part Number	Part Name	Classic Part Number
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-2621	Pin As	390-5273
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992

Sales Model 623H (Cont'd.)

DBF		
Original Part Number	Part Name	Classic Part Number
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019

DBF		
Original Part Number	Part Name	Classic Part Number
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735

DBF		
Original Part Number	Part Name	Classic Part Number
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
325-3291	Roller As	434-1918
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420

EJD		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9110	Bearing-Needle	420-2497
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049

EJD		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2T-3885	Housing	448-4967
2T-3890	Shaft As-Stub	425-9376
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7482	Sleeve	425-3455
3G-8136	Retainer	425-3585
3J-2373	Bearing-Sleeve	380-7562
3K-0526	Bearing-Ball	386-4949
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796

EJD		
Original Part Number	Part Name	Classic Part Number
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-2514	Gear-Flywheel	421-7283
5D-9675	Spider	394-9203
5J-2445	Bearing-Sleeve	380-7563
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510

Sales Model 623H (Cont'd.)

EJD		
Original Part Number	Part Name	Classic Part Number
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-9644	Bearing-Outer	384-5929
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6J-6043	Bearing-Sleeve	374-1456
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
7B-7515	Bearing-Ball	399-6059
7C-3567	Mount As	314-8689
7G-2500	Gear-Planet	296-1350

EJD		
Original Part Number	Part Name	Classic Part Number
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-3216	Bearing	368-0104
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7T-2336	Disc-Friction	433-7096
7T-8816	Bearing-Spl Ball	420-2491
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7211	Guide-Lh	428-8815
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613

EJD		
Original Part Number	Part Name	Classic Part Number
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
143-3321	Bearing-Sleeve	425-3583
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
177-7886	Cone	418-9605
325-3291	Roller As	434-1918
368-0297	Plate-Clutch	377-7420

Sales Model 623K

WTB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7895	Cone-Roller Brg	396-4145

WTB		
Original Part Number	Part Name	Classic Part Number
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9110	Bearing-Needle	420-2497

WTB		
Original Part Number	Part Name	Classic Part Number
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409

Sales Model 623K (Cont'd.)

WTB		
Original Part Number	Part Name	Classic Part Number
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
2A-4429	Lock-Retainer	379-0174
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2T-3885	Housing	448-4967
2T-3890	Shaft As-Stub	425-9376
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7482	Sleeve	425-3455
3G-8136	Retainer	425-3585
3J-2373	Bearing-Sleeve	380-7562
3K-0526	Bearing-Ball	386-4949
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226

WTB		
Original Part Number	Part Name	Classic Part Number
3S-3875	Screen-Suction	435-4849
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-2514	Gear-Flywheel	421-7283
5D-9675	Spider	394-9203
5J-2445	Bearing-Sleeve	380-7563
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-9644	Bearing-Outer	384-5929
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579

WTB		
Original Part Number	Part Name	Classic Part Number
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6J-6043	Bearing-Sleeve	374-1456
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
7B-7515	Bearing-Ball	399-6059
7C-3567	Mount As	314-8689
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7T-2336	Disc-Friction	433-7096
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7211	Guide-Lh	428-8815
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378

Sales Model 623K (Cont'd.)

WTB		
Original Part Number	Part Name	Classic Part Number
9J-1679	Bearing-Sleeve	380-7566
9J-9427	Bearing-Sleeve	361-1695
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926

WTB		
Original Part Number	Part Name	Classic Part Number
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
143-3321	Bearing-Sleeve	425-3583
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992

WTB		
Original Part Number	Part Name	Classic Part Number
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
177-7886	Cone	418-9605
325-3291	Roller As	434-1918
368-0297	Plate-Clutch	377-7420

WTM		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9110	Bearing-Needle	420-2497
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
2A-4429	Lock-Retainer	379-0174
2P-9313	Pump Gp-Gr 1 Bsc	418-1966

WTM		
Original Part Number	Part Name	Classic Part Number
2S-4900	Shaft As	384-4792
2T-3885	Housing	448-4967
2T-3890	Shaft As-Stub	425-9376
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7482	Sleeve	425-3455
3G-8136	Retainer	425-3585
3J-2373	Bearing-Sleeve	380-7562
3K-0526	Bearing-Ball	386-4949
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4J-5693	Bearing-Sleeve	385-3790

WTM		
Original Part Number	Part Name	Classic Part Number
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-2514	Gear-Flywheel	421-7283
5D-9675	Spider	394-9203
5J-2445	Bearing-Sleeve	380-7563
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-9644	Bearing-Outer	384-5929
5P-9962	Bearing-Aligning	399-4397

Sales Model 623K (Cont'd.)

WTM		
Original Part Number	Part Name	Classic Part Number
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6J-6043	Bearing-Sleeve	374-1456
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
7B-7515	Bearing-Ball	399-6059
7C-3567	Mount As	314-8689
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-8458	Bearing-Sleeve	380-7374

WTM		
Original Part Number	Part Name	Classic Part Number
7K-5448	Cup-Bearing	415-1922
7T-2336	Disc-Friction	433-7096
7T-8816	Bearing-Spl Ball	420-2491
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7211	Guide-Lh	428-8815
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798

WTM		
Original Part Number	Part Name	Classic Part Number
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-9427	Bearing-Sleeve	361-1695
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
143-3321	Bearing-Sleeve	425-3583
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
177-7886	Cone	418-9605
325-3291	Roller As	434-1918
368-0297	Plate-Clutch	377-7420

Sales Model 627

50K		
Original Part Number	Part Name	Classic Part Number
1J-6746	Pin	256-4817
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434

50K		
Original Part Number	Part Name	Classic Part Number
1P-7115	Mount As	418-1936
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572

50K		
Original Part Number	Part Name	Classic Part Number
1S-3743	Bearing-Ball	384-4786
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464

Sales Model 627 (Cont'd.)

50K		
Original Part Number	Part Name	Classic Part Number
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0408	Cyl Gp-0165 1549	415-1898
1W-3900	Gasket	472-8006
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-5233	Bearing-Thrust	388-0578
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229

50K		
Original Part Number	Part Name	Classic Part Number
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3F-3049	Cone-Roller Brg	418-9600
3G-7660	Cartridge Gp	422-8103
3G-7666	Cartridge Gp	422-8098
3H-7161	Pin	256-4819
3H-8726	Mount As	385-7208
3J-3953	Bearing-Sleeve	384-4778
3J-5190	Cap-Brg	256-4837

50K		
Original Part Number	Part Name	Classic Part Number
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-3927	Compressor As	435-6051
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4S-8472	Hood As-Preclnr	296-1355
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-0452	Seal As -Cshaft	325-6191

Sales Model 627 (Cont'd.)

50K		
Original Part Number	Part Name	Classic Part Number
4W-2061	Pan As-Oil Sump	416-5519
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-9675	Spider	394-9203
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1806	Pin	396-0662
5J-1825	Pin	367-6080
5J-1968	Shaft-Roller	386-4928
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-6611	Bearing-Sleeve	383-2140
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5K-2294	Bearing	396-9912
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433

50K		
Original Part Number	Part Name	Classic Part Number
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9561	Gasket Kt-V G	437-8106
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rock-er Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

50K		
Original Part Number	Part Name	Classic Part Number
6L-2279	Plug-Ptf	419-4739
6N-1036	Gear-Oil Pump	279-4991
6N-2820	Pump Gp-Eng Oil	415-1903
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2476	Gear-Planet	223-4816
7G-2500	Gear-Planet	296-1350
7J-1770	Cap-Bearing	396-0664
7J-8458	Bearing-Sleeve	380-7374
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-2957	Cover-Rad Cap	361-1722
7N-7435	Kit-Major Repair	374-4724

Sales Model 627 (Cont'd.)

50K		
Original Part Number	Part Name	Classic Part Number
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8M-3368	Valve-Check	388-6599
8M-7166	Housing-Screen	297-7192
8M-8652	Shaft	297-7252
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

50K		
Original Part Number	Part Name	Classic Part Number
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033

50K		
Original Part Number	Part Name	Classic Part Number
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-9427	Bearing-Sleeve	361-1695
9M-3914	Bearing-Aligning	420-2501
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-5279	Bearing-Inner	453-3661

Sales Model 627 (Cont'd.)

50K		
Original Part Number	Part Name	Classic Part Number
9S-6129	Pulley-Alt Drive	264-5891
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9Y-1798	Seal-Water	379-0165
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
118-7805	Pinion-Bevel	394-9197
131-3815	Seal Gp-Basic	325-6193

50K		
Original Part Number	Part Name	Classic Part Number
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7775	Pump Gp-Water -B	398-2942

50K		
Original Part Number	Part Name	Classic Part Number
172-7776	Pump Gp-Water -B	395-1314
173-0888	Univ Jt As	394-0898
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420

54K		
Original Part Number	Part Name	Classic Part Number
1J-6746	Pin	256-4817
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1P-7115	Mount As	418-1936
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786

54K		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152

54K		
Original Part Number	Part Name	Classic Part Number
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0408	Cyl Gp-0165 1549	415-1898
1U-3953	Cartridge Gp	426-0024
1W-3900	Gasket	472-8006
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513

Sales Model 627 (Cont'd.)

54K		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934

54K		
Original Part Number	Part Name	Classic Part Number
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3F-3049	Cone-Roller Brg	418-9600
3G-7660	Cartridge Gp	422-8103
3G-7666	Cartridge Gp	422-8098
3H-7161	Pin	256-4819
3H-8726	Mount As	385-7208
3J-3953	Bearing-Sleeve	384-4778
3J-5190	Cap-Brg	256-4837
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3R-5327	Pipe-Extension	383-1571
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509

54K		
Original Part Number	Part Name	Classic Part Number
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-9215	Gear-Pump Idler	311-9391
4N-3927	Compressor As	435-6051
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-5363	Core Gp-O Clr	380-7531
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-9675	Spider	394-9203
5F-2465	Cup-Roller Brg	447-8060

Sales Model 627 (Cont'd.)

54K		
Original Part Number	Part Name	Classic Part Number
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1806	Pin	396-0662
5J-1825	Pin	367-6080
5J-1968	Shaft-Roller	386-4928
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-6611	Bearing-Sleeve	383-2140
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5K-2294	Bearing	396-9912
5L-6326	Bearing-Ball	420-3222
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306

54K		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9561	Gasket Kt-V G	437-8106
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-2577	Spider Gp-Brg	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6N-1036	Gear-Oil Pump	279-4991
6N-2820	Pump Gp-Eng Oil	415-1903
6N-7174	Shield-Oil	314-8544

54K		
Original Part Number	Part Name	Classic Part Number
6N-7263	Gasket-Cyl Head	380-7386
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2476	Gear-Planet	223-4816
7G-2500	Gear-Planet	296-1350
7H-6967	Bearing-Ball	422-6489
7J-1770	Cap-Bearing	396-0664
7J-8458	Bearing-Sleeve	380-7374
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-7435	Kit-Major Repair	374-4724
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995

Sales Model 627 (Cont'd.)

54K		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-7166	Housing-Screen	297-7192
8M-8652	Shaft	297-7252
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196

54K		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155

54K		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-9427	Bearing-Sleeve	361-1695
9M-3914	Bearing-Aligning	420-2501
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-8395	Bearing-Sleeve	391-1103
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-5279	Bearing-Inner	453-3661
9S-6129	Pulley-Alt Drive	264-5891
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707

Sales Model 627 (Cont'd.)

54K		
Original Part Number	Part Name	Classic Part Number
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9Y-1798	Seal-Water	379-0165
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
118-7805	Pinion-Bevel	394-9197
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046

54K		
Original Part Number	Part Name	Classic Part Number
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
173-0888	Univ Jt As	394-0898

54K		
Original Part Number	Part Name	Classic Part Number
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420

68M		
Original Part Number	Part Name	Classic Part Number
1J-6746	Pin	256-4817
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1P-7115	Mount As	418-1936
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797

68M		
Original Part Number	Part Name	Classic Part Number
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0408	Cyl Gp-0165 1549	415-1898
1W-3900	Gasket	472-8006
1W-5300	Rotocoil As	443-2659

68M		
Original Part Number	Part Name	Classic Part Number
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-5233	Bearing-Thrust	388-0578
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

Sales Model 627 (Cont'd.)

68M		
Original Part Number	Part Name	Classic Part Number
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3F-3049	Cone-Roller Brg	418-9600
3F-6185	Pin	295-5694
3G-7660	Cartridge Gp	422-8103

68M		
Original Part Number	Part Name	Classic Part Number
3G-7666	Cartridge Gp	422-8098
3H-7161	Pin	256-4819
3H-8726	Mount As	385-7208
3J-3953	Bearing-Sleeve	384-4778
3J-5190	Cap-Brg	256-4837
3J-6412	Bearing-Sleeve	386-4920
3J-6559	Cap-Bearing	296-1346
3J-9133	Bearing-Sleeve	361-1691
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-2414	Trunnion	296-1370
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-1641	Dowel-Reaction	386-4952

68M		
Original Part Number	Part Name	Classic Part Number
4M-3915	Bearing-Caged	377-7427
4N-3927	Compressor As	435-6051
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4S-8472	Hood As-Preclnr	296-1355
4T-7819	Cyl Gp-051 127 Y	426-0028
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-9675	Spider	394-9203
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1806	Pin	396-0662
5J-1825	Pin	367-6080
5J-1968	Shaft-Roller	386-4928
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-4929	Bearing	256-4796

Sales Model 627 (Cont'd.)

68M		
Original Part Number	Part Name	Classic Part Number
5J-6430	Bearing-Sleeve	379-0195
5J-6611	Bearing-Sleeve	383-2140
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5K-2294	Bearing	396-9912
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9561	Gasket Kt-V G	437-8106
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883

68M		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-2577	Spider Gp-Brg	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6N-1036	Gear-Oil Pump	279-4991
6N-2820	Pump Gp-Eng Oil	415-1903
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2476	Gear-Planet	223-4816
7G-2500	Gear-Planet	296-1350
7J-1309	Bearing-Aligning	360-2275

68M		
Original Part Number	Part Name	Classic Part Number
7J-1770	Cap-Bearing	396-0664
7J-8458	Bearing-Sleeve	380-7374
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-2957	Cover-Rad Cap	361-1722
7N-7435	Kit-Major Repair	374-4724
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-8175	Bearing-Sleeve	376-3636

Sales Model 627 (Cont'd.)

68M		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8M-3368	Valve-Check	388-6599
8M-7166	Housing-Screen	297-7192
8M-8652	Shaft	297-7252
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

68M		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-9427	Bearing-Sleeve	361-1695
9M-1328	Bearing-Aligning	325-6018
9M-3914	Bearing-Aligning	420-2501

68M		
Original Part Number	Part Name	Classic Part Number
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-5279	Bearing-Inner	453-3661
9S-6129	Pulley-Alt Drive	264-5891
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9Y-1798	Seal-Water	379-0165
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
118-7805	Pinion-Bevel	394-9197
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712

Sales Model 627 (Cont'd.)

68M		
Original Part Number	Part Name	Classic Part Number
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7775	Pump Gp-Water -B	398-2942

68M		
Original Part Number	Part Name	Classic Part Number
172-7776	Pump Gp-Water -B	395-1314
173-0888	Univ Jt As	394-0898
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438

68M		
Original Part Number	Part Name	Classic Part Number
255-2899	Pipe As-Tail	301-5246
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420

69M		
Original Part Number	Part Name	Classic Part Number
1J-6746	Pin	256-4817
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1P-7115	Mount As	418-1936
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152

69M		
Original Part Number	Part Name	Classic Part Number
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0408	Cyl Gp-0165 1549	415-1898
1W-3900	Gasket	472-8006
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-5233	Bearing-Thrust	388-0578
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532

69M		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817

Sales Model 627 (Cont'd.)

69M		
Original Part Number	Part Name	Classic Part Number
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3F-3049	Cone-Roller Brg	418-9600
3F-6185	Pin	295-5694
3G-7660	Cartridge Gp	422-8103
3G-7666	Cartridge Gp	422-8098
3H-7161	Pin	256-4819
3H-8726	Mount As	385-7208
3J-3953	Bearing-Sleeve	384-4778
3J-5190	Cap-Brg	256-4837
3J-6412	Bearing-Sleeve	386-4920
3J-6559	Cap-Bearing	296-1346
3J-9133	Bearing-Sleeve	361-1691
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494

69M		
Original Part Number	Part Name	Classic Part Number
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-2414	Trunnion	296-1370
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-3927	Compressor As	435-6051
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4S-8472	Hood As-Preclnr	296-1355
4T-7819	Cyl Gp-051 127 Y	426-0028
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-9675	Spider	394-9203
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544

69M		
Original Part Number	Part Name	Classic Part Number
5J-1449	Pin As	393-3671
5J-1806	Pin	396-0662
5J-1825	Pin	367-6080
5J-1968	Shaft-Roller	386-4928
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-6611	Bearing-Sleeve	383-2140
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5K-2294	Bearing	396-9912
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9561	Gasket Kt-V G	437-8106
5P-9962	Bearing-Aligning	399-4397

Sales Model 627 (Cont'd.)

69M		
Original Part Number	Part Name	Classic Part Number
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-2577	Spider Gp-Brg	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6N-1036	Gear-Oil Pump	279-4991
6N-2820	Pump Gp-Eng Oil	415-1903
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574

69M		
Original Part Number	Part Name	Classic Part Number
6Y-5793	Ring-Seal	451-9028
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2476	Gear-Planet	223-4816
7G-2500	Gear-Planet	296-1350
7J-1309	Bearing-Aligning	360-2275
7J-1770	Cap-Bearing	396-0664
7J-8458	Bearing-Sleeve	380-7374
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-2957	Cover-Rad Cap	361-1722
7N-7435	Kit-Major Repair	374-4724
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996

69M		
Original Part Number	Part Name	Classic Part Number
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8M-3368	Valve-Check	388-6599
8M-7166	Housing-Screen	297-7192
8M-8652	Shaft	297-7252
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464

Sales Model 627 (Cont'd.)

69M		
Original Part Number	Part Name	Classic Part Number
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894

69M		
Original Part Number	Part Name	Classic Part Number
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-9427	Bearing-Sleeve	361-1695
9M-1328	Bearing-Aligning	325-6018
9M-3914	Bearing-Aligning	420-2501
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-5279	Bearing-Inner	453-3661
9S-6129	Pulley-Alt Drive	264-5891
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9Y-1798	Seal-Water	379-0165
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
110-1337	Ring Kit-Pstn	377-5834

69M		
Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As-Head	279-4977
118-7805	Pinion-Bevel	394-9197
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
173-0888	Univ Jt As	394-0898
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420

Sales Model 627B

05A		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7936	Spider As-Fan	383-3673
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0408	Cyl Gp-0165 1549	415-1898
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

05A		
Original Part Number	Part Name	Classic Part Number
2D-9191	Cone-Roller Brg	374-1837
2H-9192	Bearing-Ball	394-8236
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203

05A		
Original Part Number	Part Name	Classic Part Number
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3F-3049	Cone-Roller Brg	418-9600
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4E-0403	Gear-Planet	260-0781
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838

Sales Model 627B (Cont'd.)

05A		
Original Part Number	Part Name	Classic Part Number
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5F-2830	Bearing-Needle	384-5925
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-7841	Gear-Ring	214-0525
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rock-er Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883

05A		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-6739	Shaft-Planet	308-9929
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-7780	Pin-Anchor	384-4825
7G-2476	Gear-Planet	223-4816
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435

05A		
Original Part Number	Part Name	Classic Part Number
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512

Sales Model 627B (Cont'd.)

05A		
Original Part Number	Part Name	Classic Part Number
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-7166	Housing-Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232

05A		
Original Part Number	Part Name	Classic Part Number
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
9B-1320	Valve-Check	377-5832
9M-1853	Mount As.	376-3638
9M-5477	Bearing-Sleeve	374-6517

05A		
Original Part Number	Part Name	Classic Part Number
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-7710	Univ Joint As	394-8234
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
101-1504	Shaft	373-5379
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

Sales Model 627B (Cont'd.)

05A		
Original Part Number	Part Name	Classic Part Number
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365

05A		
Original Part Number	Part Name	Classic Part Number
172-7776	Pump Gp-Water -B	395-1314
173-0888	Univ Jt As	394-0898
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438

05A		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420

14S		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476

14S		
Original Part Number	Part Name	Classic Part Number
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

14S		
Original Part Number	Part Name	Classic Part Number
1W-1700	Pump Gp-F Tfr	377-5846
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5910	Tappet As-Guide&	383-1569
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9302	Gear-Crankshaft	386-3059

Sales Model 627B (Cont'd.)

14S		
Original Part Number	Part Name	Classic Part Number
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-3767	Tube-Disposal	377-5850
2P-5680	Turbine-Conv	308-9942
2P-6245	Shaft As-Pump	325-6197
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2P-9314	Disc As-Clutch	384-4791
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817

14S		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5539	Core As-Rad	374-7492
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7455	Gear As	396-9957
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
3E-6772	Seal-Water	382-8017
3G-1239	Pump Gp-Vn Bsc-B	439-1135
3G-2834	Cartridge Gp-Rr	426-0025
3G-2837	Cartridge Gp-Rr	422-8123
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3H-8726	Mount As	385-7208
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424

14S		
Original Part Number	Part Name	Classic Part Number
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-5100	Hub-Impeller	451-9022
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5694	Bearing-Sleeve	379-0190
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1157	Coupling-Exhaust	379-0177
4N-1320	Gasket-Adapter	398-2928

Sales Model 627B (Cont'd.)

14S		
Original Part Number	Part Name	Classic Part Number
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-5958	Tube-Exhaust Ext	385-3811
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008

14S		
Original Part Number	Part Name	Classic Part Number
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168

14S		
Original Part Number	Part Name	Classic Part Number
4W-6150	Adapter-Support	432-4219
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5B-9169	Plug-Drain	419-4736
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-1825	Pin	367-6080
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883

Sales Model 627B (Cont'd.)

14S		
Original Part Number	Part Name	Classic Part Number
5T-3030	Pin As	389-6308
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-0400	Shaft-Drive	399-4403
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-9509	Plate	398-2960
6J-6043	Bearing-Sleeve	374-1456
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-1931	Plunger	379-0171

14S		
Original Part Number	Part Name	Classic Part Number
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-4184	Muffler As	385-7226
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6N-7653	Gage As-O Level	428-7206
6N-9743	Support-Muffler	308-9940
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-3862	Camshaft	458-0151
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-0853	Muffler As	360-7887
7E-3509	Pipe As-Ex Ext	373-1907
7E-5085	Bushing	377-5829
7E-5816	Shaft-Fan	399-8552
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520

14S		
Original Part Number	Part Name	Classic Part Number
7E-8830	Bracket As-Fan	383-3697
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-8458	Bearing-Sleeve	380-7374
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993

Sales Model 627B (Cont'd.)

14S		
Original Part Number	Part Name	Classic Part Number
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0140	Gear-Drive	399-8546
7W-0182	Plunger & Bbl As	391-9893
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-4473	Manifold-Ex	443-2095
7W-5435	Adapter-Nozzle	374-7493
7W-5687	Hub-Cshft	314-8684
7W-5698	Pulley-Cshaft	295-5679
7W-5733	Gasket	421-7333
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-3669	Gear-Diff Ring	418-9581

14S		
Original Part Number	Part Name	Classic Part Number
8D-4027	Housing-Diff	380-7522
8D-4402	Yoke	365-8823
8D-5048	Yoke As	415-1899
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7694	Bearing	431-5264
8J-7727	Pin	380-7552
8M-0874	Plunger As-Valve	311-9439
8M-8652	Shaft	297-7252
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1726	Rod As-Conn	379-8866

14S		
Original Part Number	Part Name	Classic Part Number
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081

Sales Model 627B (Cont'd.)

14S		
Original Part Number	Part Name	Classic Part Number
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8258	Bearing-Sleeve	452-1077
8N-9622	Bracket As-Fan	433-2024
8N-9733	Line As-F Inj	319-8174
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9B-1320	Valve-Check	377-5832
9J-1676	Bearing-Sleeve	380-7378
9J-9427	Bearing-Sleeve	361-1695
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5839	Coupling-Exhaust	374-7480
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1853	Mount As.	376-3638

14S		
Original Part Number	Part Name	Classic Part Number
9M-3914	Bearing-Aligning	420-2501
9M-5477	Bearing-Sleeve	374-6517
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9W-4662	Disc-Friction	428-7203
9W-4702	Stator-Converter	308-9939
9Y-1798	Seal-Water	379-0165
9Y-2988	Breather As	361-1716
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057

14S		
Original Part Number	Part Name	Classic Part Number
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-7860	Valve-Inlet	270-4360
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
111-8015	Gasket As-Head	279-4977
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566

Sales Model 627B (Cont'd.)

14S		
Original Part Number	Part Name	Classic Part Number
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
143-3321	Bearing-Sleeve	425-3583
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
145-8503	Shaft As-Idler	426-0035
148-3465	Pin	383-2112
148-7455	Valve - Exhaust	270-4361
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
166-9142	Gasket	420-8546

14S		
Original Part Number	Part Name	Classic Part Number
167-8123	Damper As	299-2006
167-8126	Damper As	382-8019
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
170-0560	Rebuild Kit-Pump	363-7458
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605

14S		
Original Part Number	Part Name	Classic Part Number
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
188-2886	Gasket Kit	434-7281
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3233	Bearing-Main	376-9085
232-6574	Kit-Gasket-Rs	437-2034
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
253-1752	Plate-Thrust	379-0170
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
321-5746	Bearing-Main	419-6367

Sales Model 627B (Cont'd.)

14S		
Original Part Number	Part Name	Classic Part Number
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387

14S		
Original Part Number	Part Name	Classic Part Number
328-5574	Bearing-Rod	419-7266
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

14S		
Original Part Number	Part Name	Classic Part Number
343-4836	Mount As	424-6369
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955
430-7619	Adapter-Cla	438-1812

15S		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152

15S		
Original Part Number	Part Name	Classic Part Number
1T-1348	Support As-Carr	419-4049
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164

15S		
Original Part Number	Part Name	Classic Part Number
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3F-6185	Pin	295-5694
3G-2834	Cartridge Gp-Rr	426-0025

Sales Model 627B (Cont'd.)

15S		
Original Part Number	Part Name	Classic Part Number
3G-2837	Cartridge Gp-Rr	422-8123
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6098	Pin As	383-2124
3H-8726	Mount As	385-7208
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5694	Bearing-Sleeve	379-0190
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915

15S		
Original Part Number	Part Name	Classic Part Number
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4S-8472	Hood As-Preclnr	296-1355
4T-7819	Cyl Gp-051 127 Y	426-0028
4T-8054	Seal As	472-8010

15S		
Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5B-9169	Plug-Drain	419-4736
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-1825	Pin	367-6080
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-3030	Pin As	389-6308
5T-3323	Pin As	380-7394

Sales Model 627B (Cont'd.)

15S		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6J-6043	Bearing-Sleeve	374-1456
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
7C-3862	Camshaft	458-0151
7E-5085	Bushing	377-5829

15S		
Original Part Number	Part Name	Classic Part Number
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7J-8458	Bearing-Sleeve	380-7374
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497

15S		
Original Part Number	Part Name	Classic Part Number
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-4402	Yoke	365-8823
8D-5048	Yoke As	415-1899
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7694	Bearing	431-5264
8J-7727	Pin	380-7552
8M-8652	Shaft	297-7252
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196

Sales Model 627B (Cont'd.)

15S		
Original Part Number	Part Name	Classic Part Number
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

15S		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9B-1320	Valve-Check	377-5832
9J-1676	Bearing-Sleeve	380-7378
9J-9427	Bearing-Sleeve	361-1695
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-3914	Bearing-Aligning	420-2501

15S		
Original Part Number	Part Name	Classic Part Number
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-4662	Disc-Friction	428-7203
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
131-3815	Seal Gp-Basic	325-6193
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554

Sales Model 627B (Cont'd.)

15S		
Original Part Number	Part Name	Classic Part Number
144-0744	Compressor Gp -B	435-6046
148-3465	Pin	383-2112
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
170-0560	Rebuild Kit-Pump	363-7458
170-7502	Shaft-Dr Idler	374-7484

15S		
Original Part Number	Part Name	Classic Part Number
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605
188-2886	Gasket Kit	434-7281
196-0028	Gear As-Idler	364-5259

15S		
Original Part Number	Part Name	Classic Part Number
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

2WC		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7936	Spider As-Fan	383-3673
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344

2WC		
Original Part Number	Part Name	Classic Part Number
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0408	Cyl Gp-0165 1549	415-1898

2WC		
Original Part Number	Part Name	Classic Part Number
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981

Sales Model 627B (Cont'd.)

2WC		
Original Part Number	Part Name	Classic Part Number
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9191	Cone-Roller Brg	374-1837
2H-9192	Bearing-Ball	394-8236
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979

2WC		
Original Part Number	Part Name	Classic Part Number
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3F-3049	Cone-Roller Brg	418-9600
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4E-0403	Gear-Planet	260-0781
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366

2WC		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5F-2830	Bearing-Needle	384-5925
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-7841	Gear-Ring	214-0525
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665

Sales Model 627B (Cont'd.)

2WC		
Original Part Number	Part Name	Classic Part Number
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-6739	Shaft-Planet	308-9929
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829

2WC		
Original Part Number	Part Name	Classic Part Number
7E-9980	Camshaft	377-5851
7F-7780	Pin-Anchor	384-4825
7G-2476	Gear-Planet	223-4816
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417

2WC		
Original Part Number	Part Name	Classic Part Number
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-7166	Housing-Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207

Sales Model 627B (Cont'd.)

2WC		
Original Part Number	Part Name	Classic Part Number
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372

2WC		
Original Part Number	Part Name	Classic Part Number
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
9B-1320	Valve-Check	377-5832
9M-1853	Mount As.	376-3638
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-7710	Univ Joint As	394-8234
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
101-1504	Shaft	373-5379
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353

2WC		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
173-0888	Univ Jt As	394-0898
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988

Sales Model 627B (Cont'd.)

2WC		
Original Part Number	Part Name	Classic Part Number
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

2WC		
Original Part Number	Part Name	Classic Part Number
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

2WC		
Original Part Number	Part Name	Classic Part Number
368-0297	Plate-Clutch	377-7420

32V, 33V		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
8H-9789	Bearing-Ball	374-8342
8N-5929	Cover-Water Pump	296-1349
131-3815	Seal Gp-Basic	325-6193
172-5188	Shaft-Water Pump	325-6202

32V, 33V		
Original Part Number	Part Name	Classic Part Number
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
6H-3957	Bearing-Ball	311-9358
8H-9789	Bearing-Ball	374-8342
8N-5929	Cover-Water Pump	296-1349

32V, 33V		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314

34V		
Original Part Number	Part Name	Classic Part Number
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
2W-7678	Gear-Water Pump	325-6088
3K-0526	Bearing-Ball	386-4949
3S-1292	Bearing-Sleeve	425-8226

34V		
Original Part Number	Part Name	Classic Part Number
4M-3915	Bearing-Caged	377-7427
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5S-4442	Bearing-Spl Ball	419-6025
6H-3957	Bearing-Ball	311-9358
7N-0110	Core As-Oil Clr	319-3435
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-5929	Cover-Water Pump	296-1349

34V		
Original Part Number	Part Name	Classic Part Number
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
106-7799	Bearing-Ball	396-9947
131-3815	Seal Gp-Basic	325-6193
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
177-7886	Cone	418-9605
188-2886	Gasket Kit	434-7281

Sales Model 627B (Cont'd.)

37V		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7936	Spider As-Fan	383-3673
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0408	Cyl Gp-0165 1549	415-1898
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

37V		
Original Part Number	Part Name	Classic Part Number
2D-9191	Cone-Roller Brg	374-1837
2H-9192	Bearing-Ball	394-8236
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203

37V		
Original Part Number	Part Name	Classic Part Number
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3F-3049	Cone-Roller Brg	418-9600
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3H-8726	Mount As	385-7208
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3L-1425	Bearing-Ball	311-9356
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363

Sales Model 627B (Cont'd.)

37V		
Original Part Number	Part Name	Classic Part Number
4N-3283	Line As-Fuel Inj	247-3364
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1968	Shaft-Roller	386-4928

37V		
Original Part Number	Part Name	Classic Part Number
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-7841	Gear-Ring	214-0525
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rock-er Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475

37V		
Original Part Number	Part Name	Classic Part Number
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6J-6043	Bearing-Sleeve	374-1456
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-6739	Shaft-Planet	308-9929
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-7780	Pin-Anchor	384-4825
7G-2476	Gear-Planet	223-4816
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435

Sales Model 627B (Cont'd.)

37V		
Original Part Number	Part Name	Classic Part Number
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-4473	Manifold-Ex	443-2095
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989

37V		
Original Part Number	Part Name	Classic Part Number
8C-8741	Kit-Gasket-(Rs)	438-0172
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-7166	Housing-Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349

37V		
Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416

Sales Model 627B (Cont'd.)

37V		
Original Part Number	Part Name	Classic Part Number
8W-3613	Bearing	418-1960
9B-1320	Valve-Check	377-5832
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9L-5908	Gasket	433-8196
9M-1853	Mount As.	376-3638
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-7710	Univ Joint As	394-8234
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
101-1504	Shaft	373-5379
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193

37V		
Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

37V		
Original Part Number	Part Name	Classic Part Number
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
173-0888	Univ Jt As	394-0898
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

38V		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978

Sales Model 627B (Cont'd.)

38V		
Original Part Number	Part Name	Classic Part Number
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7936	Spider As-Fan	383-3673
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0408	Cyl Gp-0165 1549	415-1898
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9191	Cone-Roller Brg	374-1837

38V		
Original Part Number	Part Name	Classic Part Number
2H-9192	Bearing-Ball	394-8236
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983

38V		
Original Part Number	Part Name	Classic Part Number
3F-3049	Cone-Roller Brg	418-9600
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3H-8726	Mount As	385-7208
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3L-1425	Bearing-Ball	311-9356
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364

Sales Model 627B (Cont'd.)

38V		
Original Part Number	Part Name	Classic Part Number
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1968	Shaft-Roller	386-4928
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563

38V		
Original Part Number	Part Name	Classic Part Number
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-7841	Gear-Ring	214-0525
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

38V		
Original Part Number	Part Name	Classic Part Number
6J-6043	Bearing-Sleeve	374-1456
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-6739	Shaft-Planet	308-9929
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-7780	Pin-Anchor	384-4825
7G-2476	Gear-Planet	223-4816
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172

Sales Model 627B (Cont'd.)

38V		
Original Part Number	Part Name	Classic Part Number
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-4473	Manifold-Ex	443-2095
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8H-2810	Case As-Filter	314-8512

38V		
Original Part Number	Part Name	Classic Part Number
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-7166	Housing-Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232

38V		
Original Part Number	Part Name	Classic Part Number
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8W-3613	Bearing	418-1960
9B-1320	Valve-Check	377-5832
9J-1676	Bearing-Sleeve	380-7378

Sales Model 627B (Cont'd.)

38V		
Original Part Number	Part Name	Classic Part Number
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9L-5908	Gasket	433-8196
9M-1853	Mount As.	376-3638
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-7710	Univ Joint As	394-8234
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
101-1504	Shaft	373-5379
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361

38V		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

38V		
Original Part Number	Part Name	Classic Part Number
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
173-0888	Univ Jt As	394-0898
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

56V		
Original Part Number	Part Name	Classic Part Number
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797

56V		
Original Part Number	Part Name	Classic Part Number
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108

56V		
Original Part Number	Part Name	Classic Part Number
1T-1078	Bearing-Thrust	384-4802
2W-7678	Gear-Water Pump	325-6088

Sales Model 627B (Cont'd.)

56V		
Original Part Number	Part Name	Classic Part Number
3K-0526	Bearing-Ball	386-4949
3S-1292	Bearing-Sleeve	425-8226
4M-3915	Bearing-Caged	377-7427
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5S-4442	Bearing-Spl Ball	419-6025
6H-3957	Bearing-Ball	311-9358

56V		
Original Part Number	Part Name	Classic Part Number
7N-0110	Core As-Oil Clr	319-3435
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-5929	Cover-Water Pump	296-1349
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
106-7799	Bearing-Ball	396-9947

56V		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
177-7886	Cone	418-9605
188-2886	Gasket Kit	434-7281

Sales Model 627E

3WJ		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1P-7936	Spider As-Fan	383-3673
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0408	Cyl Gp-0165 1549	415-1898

3WJ		
Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9191	Cone-Roller Brg	374-1837

3WJ		
Original Part Number	Part Name	Classic Part Number
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454

Sales Model 627E (Cont'd.)

3WJ		
Original Part Number	Part Name	Classic Part Number
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5539	Core As-Rad	374-7492
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-3049	Cone-Roller Brg	418-9600
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3L-1425	Bearing-Ball	311-9356
3P-7489	Plate-Clutch	377-7423
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190

3WJ		
Original Part Number	Part Name	Classic Part Number
4J-5695	Bearing-Sleeve	386-4922
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925

3WJ		
Original Part Number	Part Name	Classic Part Number
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-5167	Race-Brg Outer	417-4529
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0975	Camshaft-Brake	422-4935
5T-0999	Camshaft-Brake	422-4934
5T-5682	Driver	418-9579

Sales Model 627E (Cont'd.)

3WJ		
Original Part Number	Part Name	Classic Part Number
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6J-6043	Bearing-Sleeve	374-1456
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-6739	Shaft-Planet	308-9929
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
7C-4297	Seal As-Cshaft	325-6192
7E-0853	Muffler As	360-7887
7E-9980	Camshaft	377-5851
7F-7780	Pin-Anchor	384-4825
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816

3WJ		
Original Part Number	Part Name	Classic Part Number
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-0675	Core As-Oclr	434-4016
7W-1927	Ring-Retainer	387-2935
7W-3145	Plate	422-7894
7W-4473	Manifold-Ex	443-2095
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636

3WJ		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8M-7166	Housing-Screen	297-7192
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

Sales Model 627E (Cont'd.)

3WJ		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8W-3613	Bearing	418-1960
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124

6EB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849

3WJ		
Original Part Number	Part Name	Classic Part Number
9S-8679	Chamber As	325-6042
9V-7710	Univ Joint As	394-8234
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
101-1504	Shaft	373-5379
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811

3WJ		
Original Part Number	Part Name	Classic Part Number
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
173-0888	Univ Jt As	394-0898
174-6836	Gasket Kit - Tof	434-7280
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
220-4554	Kit-Dt Gasket	417-9469
221-6946	Kit-Dt Gasket	394-9208
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 627E (Cont'd.)

6EB		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1348	Support As-Carr	419-4049

6EB		
Original Part Number	Part Name	Classic Part Number
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0408	Cyl Gp-0165 1549	415-1898
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5910	Tappet As-Guide&	383-1569
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354

6EB		
Original Part Number	Part Name	Classic Part Number
2G-1034	Valve-Safety	380-7555
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2L-5271	Bearing-Ball	371-4305
2M-8340	Rod End-Yoke	374-4678
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-5680	Turbine-Conv	308-9942
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2P-9314	Disc As-Clutch	384-4791
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-1707	Ring-Piston Top	270-4356

Sales Model 627E (Cont'd.)

6EB		
Original Part Number	Part Name	Classic Part Number
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5539	Core As-Rad	374-7492
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7455	Gear As	396-9957
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-7774	Ejector As-Exh	393-0914
2W-8494	Pulley-Alt	295-5692
3E-6772	Seal-Water	382-8017
3F-3049	Cone-Roller Brg	418-9600
3F-6185	Pin	295-5694
3G-2834	Cartridge Gp-Rr	426-0025
3G-2837	Cartridge Gp-Rr	422-8123
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356

6EB		
Original Part Number	Part Name	Classic Part Number
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-5100	Hub-Impeller	451-9022
3Y-2768	Ring	439-4544
4D-0487	Valve As-Check	375-4334
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489

6EB		
Original Part Number	Part Name	Classic Part Number
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4N-7693	Crankshaft As	269-8763
4N-8434	Spider As-Fan	451-9030
4P-0893	Core As-Radiator	376-9057
4P-2383	Adapter-Inlet	438-1812
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986

Sales Model 627E (Cont'd.)

6EB		
Original Part Number	Part Name	Classic Part Number
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925

6EB		
Original Part Number	Part Name	Classic Part Number
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1806	Pin	396-0662
5J-1825	Pin	367-6080
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247

6EB		
Original Part Number	Part Name	Classic Part Number
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0975	Camshaft-Brake	422-4935
5T-0999	Camshaft-Brake	422-4934
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-0400	Shaft-Drive	399-4403
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757

Sales Model 627E (Cont'd.)

6EB		
Original Part Number	Part Name	Classic Part Number
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-3907	Adapter-Pilot	398-8348
6I-4024	Gasket-Plate	377-5839
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6I-9509	Plate	398-2960
6J-6043	Bearing-Sleeve	374-1456
6K-4442	Rod End-Special	373-5388
6N-1036	Gear-Oil Pump	279-4991
6N-1931	Plunger	379-0171
6N-2789	Pulley	264-5886
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7653	Gage As-O Level	428-7206
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-4297	Seal As-Cshaft	325-6192

6EB		
Original Part Number	Part Name	Classic Part Number
7C-5665	Elbow-90 Deg	399-8547
7C-6628	Pulley-Alt	396-9894
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-0853	Muffler As	360-7887
7E-5816	Shaft-Fan	399-8552
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8830	Bracket As-Fan	383-3697
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-3351	Head	380-1515
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922

6EB		
Original Part Number	Part Name	Classic Part Number
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0619	Pulley-Fan	383-1581
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096

Sales Model 627E (Cont'd.)

6EB		
Original Part Number	Part Name	Classic Part Number
7W-0140	Gear-Drive	399-8546
7W-0508	Gear-Fp Drive	296-1351
7W-0675	Core As-Oclr	434-4016
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-4473	Manifold-Ex	443-2095
7W-5435	Adapter-Nozzle	374-7493
7W-5687	Hub-Cshft	314-8684
7W-5698	Pulley-Cshaft	295-5679
7W-5733	Gasket	421-7333
7W-6459	Core As-Oclr	395-1313
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7694	Bearing	431-5264

6EB		
Original Part Number	Part Name	Classic Part Number
8J-7727	Pin	380-7552
8M-7166	Housing-Screen	297-7192
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1726	Rod As-Conn	379-8866
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835
8N-5579	Retainer	425-3451
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232

6EB		
Original Part Number	Part Name	Classic Part Number
8N-7486	Condenser As	436-2263
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8258	Bearing-Sleeve	452-1077
8N-8983	Hub-Fan Pulley	421-7227
8P-2051	Plate-Clutch	385-6116
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613

Sales Model 627E (Cont'd.)

6EB		
Original Part Number	Part Name	Classic Part Number
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9M-1990	Dowel-Reaction	386-4963
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9T-6123	Pump Gp-Vn Bsc-B	422-8147
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203

6EB		
Original Part Number	Part Name	Classic Part Number
9W-4702	Stator-Converter	308-9939
9Y-1798	Seal-Water	379-0165
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-7860	Valve-Inlet	270-4360
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215

6EB		
Original Part Number	Part Name	Classic Part Number
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
111-3895	Yoke	421-3080
111-8015	Gasket As-Head	279-4977
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
136-7813	Bearing-Race	460-8296
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
144-7289	Roller As	434-1862

Sales Model 627E (Cont'd.)

6EB		
Original Part Number	Part Name	Classic Part Number
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
148-3465	Pin	383-2112
148-7455	Valve - Exhaust	270-4361
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8123	Damper As	299-2006
167-8126	Damper As	382-8019
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811

6EB		
Original Part Number	Part Name	Classic Part Number
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
173-0888	Univ Jt As	394-0898
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
188-2887	Kit-Dt Gasket	394-8244
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-3572	Shaft As-Drive	426-0037

6EB		
Original Part Number	Part Name	Classic Part Number
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
232-3233	Bearing-Main	376-9085
232-3679	Kit-Gasket (Rs)	437-2039
234-8015	Kit-Gasket-Sch	437-8674
253-1752	Plate-Thrust	379-0170
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
278-1365	Arm As-Ui Rkr	433-7507
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
334-8389	Crankshaft As	242-3439
343-4836	Mount As	424-6369
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

Sales Model 627E (Cont'd.)

6FB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683

6FB		
Original Part Number	Part Name	Classic Part Number
1T-2069	Carrier-Bearing	439-4543
1U-0408	Cyl Gp-0165 1549	415-1898
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

6FB		
Original Part Number	Part Name	Classic Part Number
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5539	Core As-Rad	374-7492
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8494	Pulley-Alt	295-5692
3F-3049	Cone-Roller Brg	418-9600
3G-2837	Cartridge Gp-Rr	422-8123
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124

Sales Model 627E (Cont'd.)

6FB		
Original Part Number	Part Name	Classic Part Number
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-6413	Support-Alt	433-9855
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057

6FB		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-7449	Cup-Spl Tapered	416-2161
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925

6FB		
Original Part Number	Part Name	Classic Part Number
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

Sales Model 627E (Cont'd.)

6FB		
Original Part Number	Part Name	Classic Part Number
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0975	Camshaft-Brake	422-4935
5T-0999	Camshaft-Brake	422-4934
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-6043	Bearing-Sleeve	374-1456
6K-4442	Rod End-Special	373-5388
6N-1036	Gear-Oil Pump	279-4991

6FB		
Original Part Number	Part Name	Classic Part Number
6N-2789	Pulley	264-5886
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
7C-4297	Seal As-Cshaft	325-6192
7E-0853	Muffler As	360-7887
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922

6FB		
Original Part Number	Part Name	Classic Part Number
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0619	Pulley-Fan	383-1581
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-0675	Core As-Oclr	434-4016
7W-1927	Ring-Retainer	387-2935

Sales Model 627E (Cont'd.)

6FB		
Original Part Number	Part Name	Classic Part Number
7W-3145	Plate	422-7894
7W-4473	Manifold-Ex	443-2095
7W-5687	Hub-Cshft	314-8684
7W-5698	Pulley-Cshaft	295-5679
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8M-7166	Housing-Screen	297-7192
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196

6FB		
Original Part Number	Part Name	Classic Part Number
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7486	Condenser As	436-2263
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-2051	Plate-Clutch	385-6116
8P-3512	Piston-Clutch	416-2131

6FB		
Original Part Number	Part Name	Classic Part Number
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-2685	Rod End	419-1866
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1990	Dowel-Reaction	386-4963
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994

Sales Model 627E (Cont'd.)

6FB		
Original Part Number	Part Name	Classic Part Number
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9T-6123	Pump Gp-Vn Bsc-B	422-8147
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
111-8015	Gasket As-Head	279-4977
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
144-7289	Roller As	434-1862

6FB		
Original Part Number	Part Name	Classic Part Number
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

6FB		
Original Part Number	Part Name	Classic Part Number
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
173-0888	Univ Jt As	394-0898
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
220-4554	Kit-Dt Gasket	417-9469
221-6946	Kit-Dt Gasket	394-9208
232-3233	Bearing-Main	376-9085
234-8016	Kit-Gasket-Sch	393-0919
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

6GB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1N-3576	Block Gp-Cyl	279-4978

6GB		
Original Part Number	Part Name	Classic Part Number
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913

6GB		
Original Part Number	Part Name	Classic Part Number
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936

Sales Model 627E (Cont'd.)

6GB		
Original Part Number	Part Name	Classic Part Number
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543

6GB		
Original Part Number	Part Name	Classic Part Number
1U-0408	Cyl Gp-0165 1549	415-1898
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5910	Tappet As-Guide&	383-1569
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2L-5271	Bearing-Ball	371-4305

6GB		
Original Part Number	Part Name	Classic Part Number
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-5680	Turbine-Conv	308-9942
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2P-9314	Disc As-Clutch	384-4791
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5539	Core As-Rad	374-7492
2W-5540	Core As-Radiator	363-7452

Sales Model 627E (Cont'd.)

6GB		
Original Part Number	Part Name	Classic Part Number
2W-6280	Bracket As-Fan	431-5271
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7455	Gear As	396-9957
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-7774	Ejector As-Exh	393-0914
2W-8494	Pulley-Alt	295-5692
3E-6772	Seal-Water	382-8017
3F-3049	Cone-Roller Brg	418-9600
3F-6185	Pin	295-5694
3G-2834	Cartridge Gp-Rr	426-0025
3G-2837	Cartridge Gp-Rr	422-8123
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796

6GB		
Original Part Number	Part Name	Classic Part Number
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-5100	Hub-Impeller	451-9022
3Y-2768	Ring	439-4544
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271

6GB		
Original Part Number	Part Name	Classic Part Number
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4N-7693	Crankshaft As	269-8763
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4W-0452	Seal As -Cshaft	325-6191

Sales Model 627E (Cont'd.)

6GB		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140

6GB		
Original Part Number	Part Name	Classic Part Number
5K-0983	Seal-Lip Type	472-8012
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0975	Camshaft-Brake	422-4935
5T-0999	Camshaft-Brake	422-4934
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579

6GB		
Original Part Number	Part Name	Classic Part Number
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-0400	Shaft-Drive	399-4403
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-3907	Adapter-Pilot	398-8348
6I-4024	Gasket-Plate	377-5839
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6I-9509	Plate	398-2960
6J-6043	Bearing-Sleeve	374-1456
6K-4442	Rod End-Special	373-5388

Sales Model 627E (Cont'd.)

6GB		
Original Part Number	Part Name	Classic Part Number
6N-1036	Gear-Oil Pump	279-4991
6N-1931	Plunger	379-0171
6N-2789	Pulley	264-5886
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7653	Gage As-O Level	428-7206
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-4297	Seal As-Cshaft	325-6192
7C-5665	Elbow-90 Deg	399-8547
7C-6628	Pulley-Alt	396-9894
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-0853	Muffler As	360-7887
7E-5816	Shaft-Fan	399-8552
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522

6GB		
Original Part Number	Part Name	Classic Part Number
7E-6004	Bearing-Sleeve	417-4520
7E-8830	Bracket As-Fan	383-3697
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-3351	Head	380-1515
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0619	Pulley-Fan	383-1581
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722

6GB		
Original Part Number	Part Name	Classic Part Number
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0140	Gear-Drive	399-8546
7W-0508	Gear-Fp Drive	296-1351
7W-0675	Core As-Oclr	434-4016
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-4473	Manifold-Ex	443-2095
7W-5435	Adapter-Nozzle	374-7493
7W-5687	Hub-Cshft	314-8684
7W-5698	Pulley-Cshaft	295-5679
7W-5733	Gasket	421-7333

Sales Model 627E (Cont'd.)

6GB		
Original Part Number	Part Name	Classic Part Number
7W-6459	Core As-Oclr	395-1313
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8M-7166	Housing-Screen	297-7192
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1726	Rod As-Conn	379-8866
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-2516	Bonnet-Valve	377-5858

6GB		
Original Part Number	Part Name	Classic Part Number
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835
8N-5579	Retainer	425-3451
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7486	Condenser As	436-2263
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8258	Bearing-Sleeve	452-1077

6GB		
Original Part Number	Part Name	Classic Part Number
8N-8983	Hub-Fan Pulley	421-7227
8P-2051	Plate-Clutch	385-6116
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459

Sales Model 627E (Cont'd.)

6GB		
Original Part Number	Part Name	Classic Part Number
9M-1328	Bearing-Aligning	325-6018
9M-1990	Dowel-Reaction	386-4963
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-6123	Pump Gp-Vn Bsc-B	422-8147
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9W-4702	Stator-Converter	308-9939
9Y-1798	Seal-Water	379-0165
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-7860	Valve-Inlet	270-4360
101-1504	Shaft	373-5379

6GB		
Original Part Number	Part Name	Classic Part Number
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
111-3895	Yoke	421-3080
111-8015	Gasket As-Head	279-4977
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814

6GB		
Original Part Number	Part Name	Classic Part Number
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
136-7813	Bearing-Race	460-8296
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
148-3465	Pin	383-2112
148-7455	Valve - Exhaust	270-4361
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726

Sales Model 627E (Cont'd.)

6GB		
Original Part Number	**Part Name**	**Classic Part Number**
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8123	Damper As	299-2006
167-8126	Damper As	382-8019
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365

6GB		
Original Part Number	**Part Name**	**Classic Part Number**
172-7771	Pump Gp-Water -B	419-4646
173-0888	Univ Jt As	394-0898
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
188-2887	Kit-Dt Gasket	394-8244
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266

6HB		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849

6GB		
Original Part Number	**Part Name**	**Classic Part Number**
217-8938	Tightening-Belt	419-4735
232-3233	Bearing-Main	376-9085
232-3679	Kit-Gasket (Rs)	437-2039
234-8015	Kit-Gasket-Sch	437-8674
253-1752	Plate-Thrust	379-0170
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
278-1365	Arm As-Ui Rkr	433-7507
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
334-8389	Crankshaft As	242-3439
343-4836	Mount As	424-6369
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

Sales Model 627E (Cont'd.)

6HB		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543

6HB		
Original Part Number	Part Name	Classic Part Number
1U-0408	Cyl Gp-0165 1549	415-1898
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357

6HB		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5539	Core As-Rad	374-7492
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8494	Pulley-Alt	295-5692
3F-3049	Cone-Roller Brg	418-9600
3F-6185	Pin	295-5694
3G-2837	Cartridge Gp-Rr	422-8123
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130

Sales Model 627E (Cont'd.)

6HB		
Original Part Number	Part Name	Classic Part Number
3G-8136	Retainer	425-3585
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-6413	Support-Alt	433-9855
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057

6HB		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544

6HB		
Original Part Number	Part Name	Classic Part Number
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

Sales Model 627E (Cont'd.)

6HB		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0975	Camshaft-Brake	422-4935
5T-0999	Camshaft-Brake	422-4934
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-6043	Bearing-Sleeve	374-1456
6K-4442	Rod End-Special	373-5388
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886

6HB		
Original Part Number	Part Name	Classic Part Number
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
7C-4297	Seal As-Cshaft	325-6192
7E-0853	Muffler As	360-7887
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-3351	Head	380-1515
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922

6HB		
Original Part Number	Part Name	Classic Part Number
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0619	Pulley-Fan	383-1581
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-0675	Core As-Oclr	434-4016
7W-1927	Ring-Retainer	387-2935

Sales Model 627E (Cont'd.)

6HB		
Original Part Number	Part Name	Classic Part Number
7W-3145	Plate	422-7894
7W-4473	Manifold-Ex	443-2095
7W-5687	Hub-Cshft	314-8684
7W-5698	Pulley-Cshaft	295-5679
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8M-7166	Housing-Screen	297-7192
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196

6HB		
Original Part Number	Part Name	Classic Part Number
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7486	Condenser As	436-2263
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-2051	Plate-Clutch	385-6116
8P-3512	Piston-Clutch	416-2131

6HB		
Original Part Number	Part Name	Classic Part Number
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-2685	Rod End	419-1866
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9M-1990	Dowel-Reaction	386-4963
9N-5769	Cover-Housing	325-6050

Sales Model 627E (Cont'd.)

6HB		
Original Part Number	Part Name	Classic Part Number
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-6123	Pump Gp-Vn Bsc-B	422-8147
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
111-8015	Gasket As-Head	279-4977
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
144-7289	Roller As	434-1862

6HB		
Original Part Number	Part Name	Classic Part Number
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

6HB		
Original Part Number	Part Name	Classic Part Number
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
173-0888	Univ Jt As	394-0898
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
220-4554	Kit-Dt Gasket	417-9469
221-6946	Kit-Dt Gasket	394-9208
232-3233	Bearing-Main	376-9085
234-8016	Kit-Gasket-Sch	393-0919
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

7CG		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913

7CG		
Original Part Number	Part Name	Classic Part Number
1P-4110	Disc-Friction	433-9858
1P-7125	Governor As	383-3672

Sales Model 627E (Cont'd.)

7CG		
Original Part Number	Part Name	Classic Part Number
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-3743	Bearing-Ball	384-4786
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1348	Support As-Carr	419-4049
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2491	Muffler As-Eject	360-7871
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163

7CG		
Original Part Number	Part Name	Classic Part Number
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7455	Gear As	396-9957
2W-7774	Ejector As-Exh	393-0914
3E-3322	Gasket Kit - F	437-8114
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-5192	Cyl Gp-0126 1128	399-8577
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424

7CG		
Original Part Number	Part Name	Classic Part Number
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4E-0403	Gear-Planet	260-0781
4J-5694	Bearing-Sleeve	379-0190
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030

Sales Model 627E (Cont'd.)

7CG		
Original Part Number	Part Name	Classic Part Number
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510

7CG		
Original Part Number	Part Name	Classic Part Number
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-3907	Adapter-Pilot	398-8348
6I-4024	Gasket-Plate	377-5839
6I-8849	Cone-Rlr Bearing	415-1919

7CG		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
6J-6043	Bearing-Sleeve	374-1456
6K-4442	Rod End-Special	373-5388
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9595	Core As-Radiator	396-9926
7E-9907	Spacer-Fp Timing	394-0222

Sales Model 627E (Cont'd.)

7CG		
Original Part Number	Part Name	Classic Part Number
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-3351	Head	380-1515
7J-8458	Bearing-Sleeve	380-7374
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-7809	Cap As-Radiator	295-6417
7T-2336	Disc-Friction	433-7096
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522

7CG		
Original Part Number	Part Name	Classic Part Number
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077
8N-8983	Hub-Fan Pulley	421-7227
8P-2051	Plate-Clutch	385-6116
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798

7CG		
Original Part Number	Part Name	Classic Part Number
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-9427	Bearing-Sleeve	361-1695
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9M-1328	Bearing-Aligning	325-6018
9M-1990	Dowel-Reaction	386-4963
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9T-6123	Pump Gp-Vn Bsc-B	422-8147
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689

Sales Model 627E (Cont'd.)

7CG		
Original Part Number	Part Name	Classic Part Number
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
111-3895	Yoke	421-3080
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589

7CG		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
146-4229	Gasket Kit - Sch	437-4599
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605

7CG		
Original Part Number	Part Name	Classic Part Number
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
188-2887	Kit-Dt Gasket	394-8244
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
232-6574	Kit-Gasket-Rs	437-2034
234-1874	Kit-Gasket-Fs	437-8668
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443

Sales Model 627E (Cont'd.)

7CG		
Original Part Number	Part Name	Classic Part Number
328-4374	Disc-Friction	384-5966
328-5573	Bearing-Conn Rod	419-4665

7CG		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266

7CG		
Original Part Number	Part Name	Classic Part Number
343-4836	Mount As	424-6369
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

Sales Model 627F

1DL		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683

1DL		
Original Part Number	Part Name	Classic Part Number
1T-2069	Carrier-Bearing	439-4543
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-2491	Muffler As-Eject	360-7871
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2H-9192	Bearing-Ball	394-8236
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979

1DL		
Original Part Number	Part Name	Classic Part Number
2S-6150	Cover-Pulley	428-8817
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7455	Gear As	396-9957
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544

Sales Model 627F (Cont'd.)

1DL		
Original Part Number	Part Name	Classic Part Number
4E-0403	Gear-Planet	260-0781
4J-5694	Bearing-Sleeve	379-0190
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217

1DL		
Original Part Number	Part Name	Classic Part Number
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433

1DL		
Original Part Number	Part Name	Classic Part Number
5M-6212	Tube	390-0996
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-3907	Adapter-Pilot	398-8348
6I-4024	Gasket-Plate	377-5839
6L-7751	Rod End-Spher	472-8015

Sales Model 627F (Cont'd.)

1DL		
Original Part Number	Part Name	Classic Part Number
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9595	Core As-Radiator	396-9926
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911

1DL		
Original Part Number	Part Name	Classic Part Number
7H-7628	Bearing	453-3655
7J-8458	Bearing-Sleeve	380-7374
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-7809	Cap As-Radiator	295-6417
7T-2336	Disc-Friction	433-7096
7W-0140	Gear-Drive	399-8546
7W-0675	Core As-Oclr	434-4016
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692

1DL		
Original Part Number	Part Name	Classic Part Number
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8M-3368	Valve-Check	388-6599
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-9427	Bearing-Sleeve	361-1695

Sales Model 627F (Cont'd.)

1DL		
Original Part Number	Part Name	Classic Part Number
9L-5839	Coupling-Exhaust	374-7480
9M-1328	Bearing-Aligning	325-6018
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9T-6123	Pump Gp-Vn Bsc-B	422-8147
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966

1DL		
Original Part Number	Part Name	Classic Part Number
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-0456	Crankshaft As	394-2587
118-7805	Pinion-Bevel	394-9197
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-3012	Gasket Kit	437-3229
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813

1DL		
Original Part Number	Part Name	Classic Part Number
136-7813	Bearing-Race	460-8296
138-9381	Plate-Spacer	424-7052
142-7526	Gasket Kit	393-0918
143-3321	Bearing-Sleeve	425-3583
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
159-9742	Kit-Gasket(F)	437-1996
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
184-9843	Head	347-0461
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
188-2887	Kit-Dt Gasket	394-8244
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011

Sales Model 627F (Cont'd.)

1DL		
Original Part Number	Part Name	Classic Part Number
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914

1DL		
Original Part Number	Part Name	Classic Part Number
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
232-3679	Kit-Gasket (Rs)	437-2039
233-9203	Kit-Gasket-Sch	437-2028
233-9456	Kit-Gasket-Sch	422-7510
234-1874	Kit-Gasket-Fs	437-8668
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170

1DL		
Original Part Number	Part Name	Classic Part Number
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

4YK		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1P-7936	Spider As-Fan	383-3673
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0408	Cyl Gp-0165 1549	415-1898

4YK		
Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9191	Cone-Roller Brg	374-1837

4YK		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

Sales Model 627F (Cont'd.)

4YK		
Original Part Number	Part Name	Classic Part Number
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5539	Core As-Rad	374-7492
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
3F-3049	Cone-Roller Brg	418-9600
3F-6185	Pin	295-5694
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3L-1425	Bearing-Ball	311-9356
3P-7489	Plate-Clutch	377-7423
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4D-0487	Valve As-Check	375-4334

4YK		
Original Part Number	Part Name	Classic Part Number
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-6658	Bearing-Sleeve	373-1885
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4W-0452	Seal As -Cshaft	325-6191

4YK		
Original Part Number	Part Name	Classic Part Number
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

Sales Model 627F (Cont'd.)

4YK		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0975	Camshaft-Brake	422-4935
5T-0999	Camshaft-Brake	422-4934
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6J-6043	Bearing-Sleeve	374-1456
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-6739	Shaft-Planet	308-9929
6V-0347	Cone-Spl Tapered	420-6537

4YK		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-4297	Seal As-Cshaft	325-6192
7E-5996	Rod As-Conn	379-8864
7E-9980	Camshaft	377-5851
7F-7780	Pin-Anchor	384-4825
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656

4YK		
Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-0675	Core As-Oclr	434-4016
7W-1927	Ring-Retainer	387-2935
7W-3145	Plate	422-7894
7W-4473	Manifold-Ex	443-2095
7W-5687	Hub-Cshft	314-8684
7W-5733	Gasket	421-7333
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-7166	Housing-Screen	297-7192
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

Sales Model 627F (Cont'd.)

4YK		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894

4YK		
Original Part Number	Part Name	Classic Part Number
8S-7718	Manifold-Exhaust	295-0416
8W-3613	Bearing	418-1960
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-7710	Univ Joint As	394-8234
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
101-1504	Shaft	373-5379
111-8015	Gasket As-Head	279-4977
128-3132	Gasket Kit	437-4566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
134-3038	Gasket Kit	437-3228
136-7813	Bearing-Race	460-8296
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-7455	Valve - Exhaust	270-4361
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048

4YK		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
166-9142	Gasket	420-8546
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
173-0888	Univ Jt As	394-0898
174-6836	Gasket Kit - Tof	434-7280
184-9843	Head	347-0461
187-0605	Gasket Kit - Cl	382-5055

Sales Model 627F (Cont'd.)

4YK		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
220-4554	Kit-Dt Gasket	417-9469
221-6946	Kit-Dt Gasket	394-9208
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4356

4YK		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349

4YK		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 627G

AYK		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1P-7936	Spider As-Fan	383-3673
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0408	Cyl Gp-0165 1549	415-1898
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

AYK		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229

AYK		
Original Part Number	Part Name	Classic Part Number
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5539	Core As-Rad	374-7492
2W-6757	Trunnion As	295-5678

Sales Model 627G (Cont'd.)

AYK		
Original Part Number	Part Name	Classic Part Number
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-3049	Cone-Roller Brg	418-9600
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3L-1425	Bearing-Ball	311-9356
3P-7489	Plate-Clutch	377-7423
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

AYK		
Original Part Number	Part Name	Classic Part Number
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433

AYK		
Original Part Number	Part Name	Classic Part Number
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-0975	Camshaft-Brake	422-4935
5T-0999	Camshaft-Brake	422-4934
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6J-6043	Bearing-Sleeve	374-1456
6L-7751	Rod End-Spher	472-8015

Sales Model 627G (Cont'd.)

AYK		
Original Part Number	Part Name	Classic Part Number
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-6739	Shaft-Planet	308-9929
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7F-7780	Pin-Anchor	384-4825
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438

AYK		
Original Part Number	Part Name	Classic Part Number
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-0675	Core As-Oclr	434-4016
7W-1927	Ring-Retainer	387-2935
7W-3145	Plate	422-7894
7W-4473	Manifold-Ex	443-2095
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-7166	Housing-Screen	297-7192
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

AYK		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372

Sales Model 627G (Cont'd.)

AYK		
Original Part Number	Part Name	Classic Part Number
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8W-3613	Bearing	418-1960
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-7710	Univ Joint As	394-8234
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
101-1504	Shaft	373-5379
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296

AYK		
Original Part Number	Part Name	Classic Part Number
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

AYK		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
173-0888	Univ Jt As	394-0898
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
220-4554	Kit-Dt Gasket	417-9469
221-6946	Kit-Dt Gasket	394-9208
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

AXF		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401

AXF		
Original Part Number	Part Name	Classic Part Number
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797

AXF		
Original Part Number	Part Name	Classic Part Number
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715

Sales Model 627G (Cont'd.)

AXF		
Original Part Number	Part Name	Classic Part Number
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2G-1034	Valve-Safety	380-7555
2L-5271	Bearing-Ball	371-4305
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6150	Cover-Pulley	428-8817
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849

AXF		
Original Part Number	Part Name	Classic Part Number
3Y-2768	Ring	439-4544
4E-0403	Gear-Planet	260-0781
4J-5694	Bearing-Sleeve	379-0190
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0362	Cover As-Rgltr	419-4722
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509

AXF		
Original Part Number	Part Name	Classic Part Number
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256

Sales Model 627G (Cont'd.)

AXF		
Original Part Number	Part Name	Classic Part Number
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-8458	Bearing-Sleeve	380-7374
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-2336	Disc-Friction	433-7096
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-8829	Bearing-Sleeve	361-1692
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552

AXF		
Original Part Number	Part Name	Classic Part Number
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9M-1328	Bearing-Aligning	325-6018
9N-3167	Plate-Block Bot	430-4468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966

AXF		
Original Part Number	Part Name	Classic Part Number
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019

Sales Model 627G (Cont'd.)

AXF		
Original Part Number	Part Name	Classic Part Number
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
184-9843	Head	347-0461
186-2001	Rotocoil As	397-5055
188-2887	Kit-Dt Gasket	394-8244
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003

AXF		
Original Part Number	Part Name	Classic Part Number
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
232-3679	Kit-Gasket (Rs)	437-2039
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443

AXF		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
347-6081	Gauge As	360-2348
352-1053	Kit-Dt Gasket	447-0829
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

CEX		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802

CEX		
Original Part Number	Part Name	Classic Part Number
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0408	Cyl Gp-0165 1549	415-1898
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2G-1034	Valve-Safety	380-7555
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850

CEX		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6150	Cover-Pulley	428-8817
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7213	Bearing-Sleeve	419-4667
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3F-3049	Cone-Roller Brg	418-9600
3F-6185	Pin	295-5694
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585

Sales Model 627G (Cont'd.)

CEX		
Original Part Number	Part Name	Classic Part Number
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0362	Cover As-Rgltr	419-4722
4N-2514	Gear-Flywheel	421-7283

CEX		
Original Part Number	Part Name	Classic Part Number
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-5367	Mount As	375-9986
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214

CEX		
Original Part Number	Part Name	Classic Part Number
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538

Sales Model 627G (Cont'd.)

CEX		
Original Part Number	Part Name	Classic Part Number
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6J-6043	Bearing-Sleeve	374-1456
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7E-9595	Core As-Radiator	396-9926
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132

CEX		
Original Part Number	Part Name	Classic Part Number
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8M-7166	Housing-Screen	297-7192
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263

CEX		
Original Part Number	Part Name	Classic Part Number
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9D-5444	Pin	380-7396
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9M-1328	Bearing-Aligning	325-6018
9N-3167	Plate-Block Bot	430-4468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665

Sales Model 627G (Cont'd.)

CEX		
Original Part Number	Part Name	Classic Part Number
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
136-7813	Bearing-Race	460-8296
138-9381	Plate-Spacer	424-7052

CEX		
Original Part Number	Part Name	Classic Part Number
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
161-3411	Gasket	394-0896
161-7128	Spring As.	419-4726
163-1387	Gear-Flywheel	374-4697
164-4413	Mount	419-0876
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
173-0888	Univ Jt As	394-0898
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956

CEX		
Original Part Number	Part Name	Classic Part Number
184-9843	Head	347-0461
186-2001	Rotocoil As	397-5055
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
229-1490	Sleeve-Injector	393-3659
232-3679	Kit-Gasket (Rs)	437-2039
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
347-6081	Gauge As	360-2348
352-1053	Kit-Dt Gasket	447-0829
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

CEZ		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858

CEZ		
Original Part Number	Part Name	Classic Part Number
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145

CEZ		
Original Part Number	Part Name	Classic Part Number
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499

Sales Model 627G (Cont'd.)

CEZ		
Original Part Number	Part Name	Classic Part Number
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0408	Cyl Gp-0165 1549	415-1898
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2L-5271	Bearing-Ball	371-4305
2P-9313	Pump Gp-Gr 1 Bsc	418-1966

CEZ		
Original Part Number	Part Name	Classic Part Number
2S-4900	Shaft As	384-4792
2S-6150	Cover-Pulley	428-8817
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7213	Bearing-Sleeve	419-4667
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3F-3049	Cone-Roller Brg	418-9600
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849

CEZ		
Original Part Number	Part Name	Classic Part Number
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0362	Cover As-Rgltr	419-4722
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-8434	Spider As-Fan	451-9030
4P-2383	Adapter-Inlet	438-1812
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-5367	Mount As	375-9986
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320

Sales Model 627G (Cont'd.)

CEZ		
Original Part Number	Part Name	Classic Part Number
4W-5701	Bearing-Main	419-6333
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579

CEZ		
Original Part Number	Part Name	Classic Part Number
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6J-6043	Bearing-Sleeve	374-1456
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547

CEZ		
Original Part Number	Part Name	Classic Part Number
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692

Sales Model 627G (Cont'd.)

CEZ		
Original Part Number	Part Name	Classic Part Number
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8M-7166	Housing-Screen	297-7192
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9D-5444	Pin	380-7396
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468

CEZ		
Original Part Number	Part Name	Classic Part Number
9S-8184	Pin-Drawbar	398-8345
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
136-7813	Bearing-Race	460-8296
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312

CEZ		
Original Part Number	Part Name	Classic Part Number
144-0503	Piston & Ring Kt	380-1554
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
161-3411	Gasket	394-0896
161-7128	Spring As.	419-4726
163-1387	Gear-Flywheel	374-4697
164-4413	Mount	419-0876
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
173-0888	Univ Jt As	394-0898
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
220-4554	Kit-Dt Gasket	417-9469
221-6946	Kit-Dt Gasket	394-9208

Sales Model 627G (Cont'd.)

CEZ		
Original Part Number	Part Name	Classic Part Number
229-1490	Sleeve-Injector	393-3659
232-3679	Kit-Gasket (Rs)	437-2039
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507

CEZ		
Original Part Number	Part Name	Classic Part Number
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387

CEZ		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

DBD		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683

DBD		
Original Part Number	Part Name	Classic Part Number
1T-2069	Carrier-Bearing	439-4543
1U-0408	Cyl Gp-0165 1549	415-1898
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2P-1373	Cup-Rlr Brg	382-5075
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2W-6280	Bracket As-Fan	431-5271
2W-7213	Bearing-Sleeve	419-4667
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3F-3049	Cone-Roller Brg	418-9600
3F-6185	Pin	295-5694

DBD		
Original Part Number	Part Name	Classic Part Number
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544

Sales Model 627G (Cont'd.)

DBD		
Original Part Number	Part Name	Classic Part Number
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965

DBD		
Original Part Number	Part Name	Classic Part Number
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-5167	Race-Brg Outer	417-4529
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6J-6043	Bearing-Sleeve	374-1456
6N-1931	Plunger	379-0171

DBD		
Original Part Number	Part Name	Classic Part Number
6N-7653	Gage As-O Level	428-7206
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-2983	Pump Gp	450-2390

Sales Model 627G (Cont'd.)

DBD		
Original Part Number	Part Name	Classic Part Number
7S-3002	Bearing-Spl Ball	386-4961
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8M-7166	Housing-Screen	297-7192
8N-2104	Bell As-Suction	380-1521
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798

DBD		
Original Part Number	Part Name	Classic Part Number
8W-8138	Shaft	377-7453
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9M-1328	Bearing-Aligning	325-6018
9N-3167	Plate-Block Bot	430-4468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
115-4072	Bearing	397-5069
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814

DBD		
Original Part Number	Part Name	Classic Part Number
129-9907	Impeller-Pump	383-1589
130-2621	Pin As	390-5273
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
136-7813	Bearing-Race	460-8296
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
164-4413	Mount	419-0876
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
173-0888	Univ Jt As	394-0898
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
184-9843	Head	347-0461
186-2001	Rotocoil As	397-5055

Sales Model 627G (Cont'd.)

DBD		
Original Part Number	Part Name	Classic Part Number
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735

DBD		
Original Part Number	Part Name	Classic Part Number
229-1490	Sleeve-Injector	393-3659
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170

DBD		
Original Part Number	Part Name	Classic Part Number
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420

DBZ		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920

DBZ		
Original Part Number	Part Name	Classic Part Number
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0408	Cyl Gp-0165 1549	415-1898
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2P-1373	Cup-Rlr Brg	382-5075
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2W-6280	Bracket As-Fan	431-5271
2W-7213	Bearing-Sleeve	419-4667
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3F-3049	Cone-Roller Brg	418-9600
3G-5192	Cyl Gp-0126 1128	399-8577

DBZ		
Original Part Number	Part Name	Classic Part Number
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4E-0403	Gear-Planet	260-0781

Sales Model 627G (Cont'd.)

DBZ		
Original Part Number	Part Name	Classic Part Number
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-1449	Pin As	393-3671
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140

DBZ		
Original Part Number	Part Name	Classic Part Number
5K-0983	Seal-Lip Type	472-8012
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6J-6043	Bearing-Sleeve	374-1456
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-6739	Shaft-Planet	308-9929

DBZ		
Original Part Number	Part Name	Classic Part Number
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6Y-2065	Mount As-650 Cup	377-5844
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096

Sales Model 627G (Cont'd.)

DBZ		
Original Part Number	Part Name	Classic Part Number
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8M-7166	Housing-Screen	297-7192
8N-2104	Bell As-Suction	380-1521
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356

DBZ		
Original Part Number	Part Name	Classic Part Number
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
115-4072	Bearing	397-5069
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-2621	Pin As	390-5273
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
136-7813	Bearing-Race	460-8296

DBZ		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
164-4413	Mount	419-0876
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
173-0888	Univ Jt As	394-0898
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
220-4554	Kit-Dt Gasket	417-9469
221-6946	Kit-Dt Gasket	394-9208
229-1490	Sleeve-Injector	393-3659

Sales Model 627G (Cont'd.)

DBZ		
Original Part Number	Part Name	Classic Part Number
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170

DBZ		
Original Part Number	Part Name	Classic Part Number
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443

DBZ		
Original Part Number	Part Name	Classic Part Number
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420

Sales Model 627H

DBW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7125	Governor As	383-3672
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2069	Carrier-Bearing	439-4543
1U-0408	Cyl Gp-0165 1549	415-1898

DBW		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2H-9192	Bearing-Ball	394-8236
2P-1373	Cup-Rlr Brg	382-5075
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3F-3049	Cone-Roller Brg	418-9600
3G-0034	Trunnion	361-1712
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6098	Pin As	383-2124
3G-7664	Cartridge Gp	422-8130
3G-8136	Retainer	425-3585
3J-3953	Bearing-Sleeve	384-4778

DBW		
Original Part Number	Part Name	Classic Part Number
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4E-0403	Gear-Planet	260-0781
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952

Sales Model 627H (Cont'd.)

DBW		
Original Part Number	Part Name	Classic Part Number
4M-3915	Bearing-Caged	377-7427
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4S-8472	Hood As-Preclnr	296-1355
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-9675	Spider	394-9203
5F-2830	Bearing-Needle	384-5925
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-5167	Race-Brg Outer	417-4529

DBW		
Original Part Number	Part Name	Classic Part Number
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6J-6043	Bearing-Sleeve	374-1456
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-0347	Cone-Spl Tapered	420-6537
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7C-5665	Elbow-90 Deg	399-8547

DBW		
Original Part Number	Part Name	Classic Part Number
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2500	Gear-Planet	296-1350
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7T-2336	Disc-Friction	433-7096
7T-8816	Bearing-Spl Ball	420-2491
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781

Sales Model 627H (Cont'd.)

DBW		
Original Part Number	Part Name	Classic Part Number
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8M-7166	Housing-Screen	297-7192
8N-2104	Bell As-Suction	380-1521
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-5284	Bearing-Sleeve	380-7379
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9L-5839	Coupling-Exhaust	374-7480
9M-1328	Bearing-Aligning	325-6018

DBW		
Original Part Number	Part Name	Classic Part Number
9N-3167	Plate-Block Bot	430-4468
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
127-5537	Core As-Oclr	325-6045
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-2621	Pin As	390-5273
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
136-7813	Bearing-Race	460-8296
138-9381	Plate-Spacer	424-7052
143-3321	Bearing-Sleeve	425-3583
144-0502	Ring Kit-Piston	395-1312

DBW		
Original Part Number	Part Name	Classic Part Number
144-0503	Piston & Ring Kt	380-1554
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
173-0888	Univ Jt As	394-0898
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
347-6081	Gauge As	360-2348
368-0297	Plate-Clutch	377-7420

Sales Model 627H (Cont'd.)

LCT		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2069	Carrier-Bearing	439-4543
1U-0408	Cyl Gp-0165 1549	415-1898
2A-4429	Lock-Retainer	379-0174
2D-9191	Cone-Roller Brg	374-1837
2H-9192	Bearing-Ball	394-8236
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
3F-3049	Cone-Roller Brg	418-9600
3G-0034	Trunnion	361-1712
3G-5192	Cyl Gp-0126 1128	399-8577

LCT		
Original Part Number	Part Name	Classic Part Number
3G-6098	Pin As	383-2124
3G-8136	Retainer	425-3585
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
5D-9675	Spider	394-9203
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563

LCT		
Original Part Number	Part Name	Classic Part Number
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-5167	Race-Brg Outer	417-4529
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6J-6043	Bearing-Sleeve	374-1456
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-0347	Cone-Spl Tapered	420-6537

Sales Model 627H (Cont'd.)

LCT		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
6Y-5793	Ring-Seal	451-9028
7C-3567	Mount As	314-8689
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7T-2336	Disc-Friction	433-7096
7T-8816	Bearing-Spl Ball	420-2491
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342

LCT		
Original Part Number	Part Name	Classic Part Number
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8M-7166	Housing-Screen	297-7192
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-5284	Bearing-Sleeve	380-7379
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695

LCT		
Original Part Number	Part Name	Classic Part Number
9M-1328	Bearing-Aligning	325-6018
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
136-7813	Bearing-Race	460-8296
143-3321	Bearing-Sleeve	425-3583
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
173-0888	Univ Jt As	394-0898
177-7886	Cone	418-9605
368-0297	Plate-Clutch	377-7420

Sales Model 627K

WTC		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7895	Cone-Roller Brg	396-4145

WTC		
Original Part Number	Part Name	Classic Part Number
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0334	Bearing-Ball	380-1476

WTC		
Original Part Number	Part Name	Classic Part Number
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797

Sales Model 627K (Cont'd.)

WTC		
Original Part Number	Part Name	Classic Part Number
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2069	Carrier-Bearing	439-4543
1U-0408	Cyl Gp-0165 1549	415-1898
2A-4429	Lock-Retainer	379-0174
2D-9191	Cone-Roller Brg	374-1837
2H-9192	Bearing-Ball	394-8236
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
3F-3049	Cone-Roller Brg	418-9600
3G-0034	Trunnion	361-1712
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6098	Pin As	383-2124
3G-8136	Retainer	425-3585
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550

WTC		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
5D-9675	Spider	394-9203
5J-1980	Pin	385-3805
5J-2445	Bearing-Sleeve	380-7563
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510

WTC		
Original Part Number	Part Name	Classic Part Number
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-5167	Race-Brg Outer	417-4529
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6J-6043	Bearing-Sleeve	374-1456
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-0347	Cone-Spl Tapered	420-6537
6V-3831	Seal-O-Ring	436-2657
6Y-5793	Ring-Seal	451-9028
7C-3567	Mount As	314-8689
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132

Sales Model 627K (Cont'd.)

WTC		
Original Part Number	Part Name	Classic Part Number
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7T-2336	Disc-Friction	433-7096
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8M-7166	Housing-Screen	297-7192

WTC		
Original Part Number	Part Name	Classic Part Number
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-5284	Bearing-Sleeve	380-7379
9J-9427	Bearing-Sleeve	361-1695
9M-1328	Bearing-Aligning	325-6018
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203

WTC		
Original Part Number	Part Name	Classic Part Number
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197
136-7813	Bearing-Race	460-8296
143-3321	Bearing-Sleeve	425-3583
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
173-0888	Univ Jt As	394-0898
177-7886	Cone	418-9605
368-0297	Plate-Clutch	377-7420

WTN		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7895	Cone-Roller Brg	396-4145
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409

WTN		
Original Part Number	Part Name	Classic Part Number
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802

WTN		
Original Part Number	Part Name	Classic Part Number
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2069	Carrier-Bearing	439-4543
2A-4429	Lock-Retainer	379-0174
2D-9191	Cone-Roller Brg	374-1837

Sales Model 627K (Cont'd.)

WTN		
Original Part Number	Part Name	Classic Part Number
2H-9192	Bearing-Ball	394-8236
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
3F-3049	Cone-Roller Brg	418-9600
3G-0034	Trunnion	361-1712
3G-5192	Cyl Gp-0126 1128	399-8577
3G-6098	Pin As	383-2124
3G-8136	Retainer	425-3585
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3P-0203	Pump Gp-Gr Basic	418-1965
3P-0204	Pump Gp-Gr Basic	421-2550
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952

WTN		
Original Part Number	Part Name	Classic Part Number
4M-3915	Bearing-Caged	377-7427
4N-2514	Gear-Flywheel	421-7283
5D-9675	Spider	394-9203
5J-1980	Pin	385-3805
5J-6611	Bearing-Sleeve	383-2140
5K-0983	Seal-Lip Type	472-8012
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-5167	Race-Brg Outer	417-4529
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3323	Pin As	380-7394
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-5155	Bearing-Thrust	394-0220
6J-6043	Bearing-Sleeve	374-1456
6P-6739	Shaft-Planet	308-9929

WTN		
Original Part Number	Part Name	Classic Part Number
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-0347	Cone-Spl Tapered	420-6537
6V-3831	Seal-O-Ring	436-2657
6Y-5793	Ring-Seal	451-9028
7C-3567	Mount As	314-8689
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7T-2336	Disc-Friction	433-7096
7T-8816	Bearing-Spl Ball	420-2491
8D-3669	Gear-Diff Ring	418-9581
8D-4027	Housing-Diff	380-7522
8D-5059	Diff Gp -A	388-6572
8D-8829	Bearing-Sleeve	361-1692
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-0201	Bearing-Sleeve	384-4781
8J-0632	Pin	396-7280
8J-7596	Bearing-Sleeve	361-1693
8J-7727	Pin	380-7552
8M-7166	Housing-Screen	297-7192

Sales Model 627K (Cont'd.)

WTN		
Original Part Number	Part Name	Classic Part Number
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
8W-4523	Bearing-Sleeve	385-3798
8W-8138	Shaft	377-7453
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566

WTN		
Original Part Number	Part Name	Classic Part Number
9J-5284	Bearing-Sleeve	380-7379
9J-9427	Bearing-Sleeve	361-1695
9M-1328	Bearing-Aligning	325-6018
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
101-1504	Shaft	373-5379
106-7799	Bearing-Ball	396-9947
117-0019	Disc-Friction	417-9492
118-7805	Pinion-Bevel	394-9197

WTN		
Original Part Number	Part Name	Classic Part Number
136-7813	Bearing-Race	460-8296
143-3321	Bearing-Sleeve	425-3583
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
148-3465	Pin	383-2112
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
173-0888	Univ Jt As	394-0898
177-7886	Cone	418-9605
368-0297	Plate-Clutch	377-7420

Sales Model 630A

52F		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1S-9110	Bearing-Needle	420-2497
1T-0299	Cup-Roller Brg	422-6494
1T-0364	Flange-Joint	388-6567
1T-0365	Flange-Joint	434-1861
2A-4429	Lock-Retainer	379-0174
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572

52F		
Original Part Number	Part Name	Classic Part Number
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2H-3517	Bearing-Inner	417-4505
2K-4502	Bearing-Sleeve	299-1986
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469

52F		
Original Part Number	Part Name	Classic Part Number
2S-3966	Ring-Seal	297-7237
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3R-5327	Pipe-Extension	383-1571
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334

Sales Model 630A (Cont'd.)

52F		
Original Part Number	Part Name	Classic Part Number
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
5D-0470	Valve Gp-Qrel	314-8549
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5M-2054	Bearing	380-7510
5P-8789	Gasket Kt	393-3620
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635
5T-5682	Driver	418-9579

52F		
Original Part Number	Part Name	Classic Part Number
5T-8739	Spider Gp-Brg	373-5386
6D-0738	Pinion-Dif Bevel	394-9840
6N-9211	Core As-O Clr	435-6049
7D-7607	Gear-Dif Bevel	388-0595
7F-7780	Pin-Anchor	384-4825
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7M-7226	Gasket-Cam Cover	433-8189
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-2138	Bearing-Main	419-7250
8F-5104	Screen As-Se Pan	314-8539

52F		
Original Part Number	Part Name	Classic Part Number
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
128-3935	Bearing-Race	396-9897
208-8795	Retainer	430-5355
226-8202	Seal-Wiper	472-8024

Sales Model 630B

10G		
Original Part Number	Part Name	Classic Part Number
2D-6511	Cup-Roller Brg	377-7417
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3J-2373	Bearing-Sleeve	380-7562

10G		
Original Part Number	Part Name	Classic Part Number
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782

10G		
Original Part Number	Part Name	Classic Part Number
5F-2830	Bearing-Needle	384-5925
5J-1968	Shaft-Roller	386-4928
7F-7780	Pin-Anchor	384-4825
8F-7278	Diaphragm	392-4485
8W-1708	Pin	388-0643
9D-5444	Pin	380-7396

14G		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586

Sales Model 630B (Cont'd.)

14G		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1S-9110	Bearing-Needle	420-2497
1T-0299	Cup-Roller Brg	422-6494
1T-0364	Flange-Joint	388-6567
1T-0365	Flange-Joint	434-1861
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-4502	Bearing-Sleeve	299-1986
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2P-3839	Crankshaft As	398-2968

14G		
Original Part Number	Part Name	Classic Part Number
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-2717	Cartridge Gp	439-1132
3G-2752	Cartridge Gp-Rr	422-8127
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3R-5327	Pipe-Extension	383-1571
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609

14G		
Original Part Number	Part Name	Classic Part Number
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4S-5367	Mount As	375-9986
5D-0470	Valve Gp-Qrel	314-8549
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5J-1968	Shaft-Roller	386-4928
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6D-0738	Pinion-Dif Bevel	394-9840
6N-9211	Core As-O Clr	435-6049
6V-2202	Bearing-Spl Ball	380-1574
7D-7607	Gear-Dif Bevel	388-0595
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189

Sales Model 630B (Cont'd.)

14G		
Original Part Number	Part Name	Classic Part Number
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-5003	Cap As-Rain	379-0184
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485

14G		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-9686	Gasket Kit	393-5215
8W-1708	Pin	388-0643
9D-5444	Pin	380-7396
9M-8395	Bearing-Sleeve	391-1103

14G		
Original Part Number	Part Name	Classic Part Number
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
128-3935	Bearing-Race	396-9897
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

Sales Model 631A

51F		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1S-9110	Bearing-Needle	420-2497
1T-0299	Cup-Roller Brg	422-6494
1T-0364	Flange-Joint	388-6567
1T-0365	Flange-Joint	434-1861
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-6511	Cup-Roller Brg	377-7417

51F		
Original Part Number	Part Name	Classic Part Number
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2H-3517	Bearing-Inner	417-4505
2J-5233	Bearing-Thrust	388-0578

51F		
Original Part Number	Part Name	Classic Part Number
2J-5649	Pin-Cylinder	256-4782
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2S-3966	Ring-Seal	297-7237
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-2720	Cartridge Gp-Rr	448-5051
3G-2749	Cartridge Gp-Rr	422-8125
3H-8726	Mount As	385-7208

Sales Model 631A (Cont'd.)

51F		
Original Part Number	Part Name	Classic Part Number
3J-9133	Bearing-Sleeve	361-1691
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3R-5327	Pipe-Extension	383-1571
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4T-1893	Cartridge Gp	422-8110
4T-6869	Cartridge Gp	422-8104
5D-0470	Valve Gp-Qrel	314-8549

51F		
Original Part Number	Part Name	Classic Part Number
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5J-4929	Bearing	256-4796
5M-2054	Bearing	380-7510
5P-8789	Gasket Kt	393-3620
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635
5T-5682	Driver	418-9579
6D-0738	Pinion-Dif Bevel	394-9840
6N-9211	Core As-O Clr	435-6049
7D-7607	Gear-Dif Bevel	388-0595
7F-7780	Pin-Anchor	384-4825
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7M-7226	Gasket-Cam Cover	433-8189
7S-3206	Seal-O-Ring	436-2656

51F		
Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As-Radiator	295-6417
7W-2138	Bearing-Main	419-7250
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
9T-2200	Cartridgr Gp	422-8114
9T-5096	Flexplate	455-3271
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
128-3935	Bearing-Race	396-9897
208-8795	Retainer	430-5355

56F		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549

Sales Model 631B

05A		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409

05A		
Original Part Number	Part Name	Classic Part Number
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108

05A		
Original Part Number	Part Name	Classic Part Number
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
2A-4429	Lock-Retainer	379-0174

Sales Model 631B (Cont'd.)

05A		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2J-5233	Bearing-Thrust	388-0578
2J-5649	Pin-Cylinder	256-4782
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-7660	Cartridge Gp	422-8103
3G-7663	Cartridge Gp	422-8120

05A		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4P-7731	Core Gp-O Clr	385-7228
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488

05A		
Original Part Number	Part Name	Classic Part Number
4T-7819	Cyl Gp-051 127 Y	426-0028
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5F-2830	Bearing-Needle	384-5925
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347

Sales Model 631B (Cont'd.)

05A		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6Y-8675	Housing As	418-9584
7D-7607	Gear-Dif Bevel	388-0595
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-1164	Mount As	295-5451

05A		
Original Part Number	Part Name	Classic Part Number
7N-2957	Cover-Rad Cap	361-1722
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8D-3442	Gear-Bevel	433-2026
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-4550	Shaft-Pulley	445-9247
8P-3512	Piston-Clutch	416-2131

05A		
Original Part Number	Part Name	Classic Part Number
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-9151	Cup-Spl Tapered	374-8348
8W-1708	Pin	388-0643
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-9427	Bearing-Sleeve	361-1695
9M-3914	Bearing-Aligning	420-2501
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9W-4662	Disc-Friction	428-7203
101-7517	Housing	391-1094
106-7799	Bearing-Ball	396-9947
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

11G		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347

11G		
Original Part Number	Part Name	Classic Part Number
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913

11G		
Original Part Number	Part Name	Classic Part Number
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936

Sales Model 631B (Cont'd.)

11G		
Original Part Number	Part Name	Classic Part Number
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2J-5233	Bearing-Thrust	388-0578
2J-5649	Pin-Cylinder	256-4782
2K-0227	Bearing-Sleeve	384-4780
2L-5271	Bearing-Ball	371-4305

11G		
Original Part Number	Part Name	Classic Part Number
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-7660	Cartridge Gp	422-8103
3G-7663	Cartridge Gp	422-8120
3H-8726	Mount As	385-7208
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424

11G		
Original Part Number	Part Name	Classic Part Number
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4P-7731	Core Gp-O Clr	385-7228
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5F-2830	Bearing-Needle	384-5925
5F-7958	Shaft-Roller	434-1865
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-3560	Bearing-Sleeve	392-4521

Sales Model 631B (Cont'd.)

11G		
Original Part Number	Part Name	Classic Part Number
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6Y-8675	Housing As	418-9584
7D-7607	Gear-Dif Bevel	388-0595
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104

11G		
Original Part Number	Part Name	Classic Part Number
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8D-3442	Gear-Bevel	433-2026
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342

11G		
Original Part Number	Part Name	Classic Part Number
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-4550	Shaft-Pulley	445-9247
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-9151	Cup-Spl Tapered	374-8348
8W-1708	Pin	388-0643
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-9427	Bearing-Sleeve	361-1695
9M-3914	Bearing-Aligning	420-2501
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9W-4662	Disc-Friction	428-7203
101-7517	Housing	391-1094
106-7799	Bearing-Ball	396-9947
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
308-1845	Seal-Wiper	472-8032
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

Sales Model 631B (Cont'd.)

13G		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1S-9110	Bearing-Needle	420-2497
1T-0299	Cup-Roller Brg	422-6494
1T-0364	Flange-Joint	388-6567
1T-0365	Flange-Joint	434-1861
1U-2669	Cartridge Gp	422-8118
1U-3953	Cartridge Gp	426-0024
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2J-5649	Pin-Cylinder	256-4782
2L-5271	Bearing-Ball	371-4305

13G		
Original Part Number	Part Name	Classic Part Number
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2M-8340	Rod End-Yoke	374-4678
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-2720	Cartridge Gp-Rr	448-5051
3G-2752	Cartridge Gp-Rr	422-8127
3G-7660	Cartridge Gp	422-8103
3G-7662	Cartridge Gp	422-8105
3G-7663	Cartridge Gp	422-8120
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782

13G		
Original Part Number	Part Name	Classic Part Number
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3R-5327	Pipe-Extension	383-1571
4B-1455	Cap As-Filler	361-1719
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4S-5367	Mount As	375-9986
4T-7819	Cyl Gp-051 127 Y	426-0028
5D-0470	Valve Gp-Qrel	314-8549
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2054	Bearing	380-7510

Sales Model 631B (Cont'd.)

13G		
Original Part Number	Part Name	Classic Part Number
5M-3560	Bearing-Sleeve	392-4521
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6D-0738	Pinion-Dif Bevel	394-9840
6H-3957	Bearing-Ball	311-9358
6J-6043	Bearing-Sleeve	374-1456
6N-9211	Core As-O Clr	435-6049
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7D-7607	Gear-Dif Bevel	388-0595
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825

13G		
Original Part Number	Part Name	Classic Part Number
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-5003	Cap As-Rain	379-0184
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439

13G		
Original Part Number	Part Name	Classic Part Number
8M-3368	Valve-Check	388-6599
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-9686	Gasket Kit	393-5215
8W-1708	Pin	388-0643
9D-5444	Pin	380-7396
9M-3914	Bearing-Aligning	420-2501
9M-8395	Bearing-Sleeve	391-1103
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
128-3935	Bearing-Race	396-9897
160-6306	Cap-Bearing	325-6038
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
308-1845	Seal-Wiper	472-8032

28F		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409

28F		
Original Part Number	Part Name	Classic Part Number
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803

28F		
Original Part Number	Part Name	Classic Part Number
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152

Sales Model 631B (Cont'd.)

28F		
Original Part Number	Part Name	Classic Part Number
1T-1348	Support As-Carr	419-4049
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2J-5233	Bearing-Thrust	388-0578
2J-5649	Pin-Cylinder	256-4782
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601

28F		
Original Part Number	Part Name	Classic Part Number
3G-7660	Cartridge Gp	422-8103
3G-7663	Cartridge Gp	422-8120
3H-8726	Mount As	385-7208
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4P-7731	Core Gp-O Clr	385-7228
4S-5367	Mount As	375-9986

28F		
Original Part Number	Part Name	Classic Part Number
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5F-2830	Bearing-Needle	384-5925
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579

Sales Model 631B (Cont'd.)

28F		
Original Part Number	Part Name	Classic Part Number
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6Y-8675	Housing As	418-9584
7D-7607	Gear-Dif Bevel	388-0595
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189

28F		
Original Part Number	Part Name	Classic Part Number
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8D-3442	Gear-Bevel	433-2026
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-4550	Shaft-Pulley	445-9247

28F		
Original Part Number	Part Name	Classic Part Number
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-9151	Cup-Spl Tapered	374-8348
8W-1708	Pin	388-0643
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-9427	Bearing-Sleeve	361-1695
9M-3914	Bearing-Aligning	420-2501
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9W-4662	Disc-Friction	428-7203
101-7517	Housing	391-1094
106-7799	Bearing-Ball	396-9947
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

Sales Model 631C

05A		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2J-5233	Bearing-Thrust	388-0578

05A		
Original Part Number	Part Name	Classic Part Number
2J-5649	Pin-Cylinder	256-4782
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-7660	Cartridge Gp	422-8103
3G-7663	Cartridge Gp	422-8120
3H-8726	Mount As	385-7208
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356

05A		
Original Part Number	Part Name	Classic Part Number
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4P-7731	Core Gp-O Clr	385-7228
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5F-2830	Bearing-Needle	384-5925
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209

Sales Model 631C (Cont'd.)

05A		
Original Part Number	Part Name	Classic Part Number
5M-2051	Bearing-Caged	380-7467
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6Y-8675	Housing As	418-9584
7D-7607	Gear-Dif Bevel	388-0595
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7H-7628	Bearing	453-3655

05A		
Original Part Number	Part Name	Classic Part Number
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8D-3442	Gear-Bevel	433-2026
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636

05A		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-4550	Shaft-Pulley	445-9247
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-9151	Cup-Spl Tapered	374-8348
8W-1708	Pin	388-0643
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-9427	Bearing-Sleeve	361-1695
9M-3914	Bearing-Aligning	420-2501
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9W-4662	Disc-Friction	428-7203
101-7517	Housing	391-1094
106-7799	Bearing-Ball	396-9947
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

Sales Model 631C (Cont'd.)

11G		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488

11G		
Original Part Number	Part Name	Classic Part Number
2J-5233	Bearing-Thrust	388-0578
2J-5649	Pin-Cylinder	256-4782
2K-0227	Bearing-Sleeve	384-4780
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-7660	Cartridge Gp	422-8103
3G-7663	Cartridge Gp	422-8120
3H-8726	Mount As	385-7208
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782

11G		
Original Part Number	Part Name	Classic Part Number
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4P-7731	Core Gp-O Clr	385-7228
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5F-2830	Bearing-Needle	384-5925
5F-7958	Shaft-Roller	434-1865
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-8361	Bearing-Sleeve	384-4775

Sales Model 631C (Cont'd.)

11G		
Original Part Number	Part Name	Classic Part Number
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6Y-8675	Housing As	418-9584
7D-7607	Gear-Dif Bevel	388-0595
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825

11G		
Original Part Number	Part Name	Classic Part Number
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8D-3442	Gear-Bevel	433-2026
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512

11G		
Original Part Number	Part Name	Classic Part Number
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-4550	Shaft-Pulley	445-9247
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-9151	Cup-Spl Tapered	374-8348
8W-1708	Pin	388-0643
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-9427	Bearing-Sleeve	361-1695
9M-3914	Bearing-Aligning	420-2501
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9W-4662	Disc-Friction	428-7203
101-7517	Housing	391-1094
106-7799	Bearing-Ball	396-9947
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
308-1845	Seal-Wiper	472-8032

Sales Model 631C (Cont'd.)

11G		
Original Part Number	Part Name	Classic Part Number
358-9117	Gear-Planet	380-7490

11G		
Original Part Number	Part Name	Classic Part Number
368-0297	Plate-Clutch	377-7420

28F		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257

28F		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2J-5233	Bearing-Thrust	388-0578
2J-5649	Pin-Cylinder	256-4782
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-7660	Cartridge Gp	422-8103
3G-7663	Cartridge Gp	422-8120
3H-8726	Mount As	385-7208
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920

28F		
Original Part Number	Part Name	Classic Part Number
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4P-7731	Core Gp-O Clr	385-7228
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511

Sales Model 631C (Cont'd.)

28F		
Original Part Number	Part Name	Classic Part Number
5F-2830	Bearing-Needle	384-5925
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789

28F		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6Y-8675	Housing As	418-9584
7D-7607	Gear-Dif Bevel	388-0595
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296

28F		
Original Part Number	Part Name	Classic Part Number
7T-2336	Disc-Friction	433-7096
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8D-3442	Gear-Bevel	433-2026
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-4550	Shaft-Pulley	445-9247
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-9151	Cup-Spl Tapered	374-8348
8W-1708	Pin	388-0643
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-9427	Bearing-Sleeve	361-1695
9M-3914	Bearing-Aligning	420-2501
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493

Sales Model 631C (Cont'd.)

28F		
Original Part Number	Part Name	Classic Part Number
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9W-4662	Disc-Friction	428-7203
101-7517	Housing	391-1094

28F		
Original Part Number	Part Name	Classic Part Number
106-7799	Bearing-Ball	396-9947
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811

28F		
Original Part Number	Part Name	Classic Part Number
208-8795	Retainer	430-5355
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

67M		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1S-3743	Bearing-Ball	384-4786
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1348	Support As-Carr	419-4049
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704

67M		
Original Part Number	Part Name	Classic Part Number
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9490	Pulley-Alt	394-0885
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2H-3712	Bearing-Ball	392-4488
2J-5233	Bearing-Thrust	388-0578

67M		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-3839	Crankshaft As	398-2968
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-3966	Ring-Seal	297-7237
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-4087	Gear As-Idler	418-9582
2W-7774	Ejector As-Exh	393-0914
2W-7980	Camshaft As	378-3972
2W-8437	Muffler As	385-7198
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3G-3346	Bushing	385-3786

Sales Model 631C (Cont'd.)

67M		
Original Part Number	Part Name	Classic Part Number
3G-3347	Bushing	385-3792
3G-7660	Cartridge Gp	422-8103
3G-7663	Cartridge Gp	422-8120
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3H-8726	Mount As	385-7208
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534

67M		
Original Part Number	Part Name	Classic Part Number
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028

67M		
Original Part Number	Part Name	Classic Part Number
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5F-2830	Bearing-Needle	384-5925
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-3560	Bearing-Sleeve	392-4521

Sales Model 631C (Cont'd.)

67M		
Original Part Number	Part Name	Classic Part Number
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715

67M		
Original Part Number	Part Name	Classic Part Number
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-4613	Plate-Spacer	380-7405
6K-4442	Rod End-Special	373-5388
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-1320	Plate-Clutch	384-5935
6Y-2065	Mount As-650 Cup	377-5844
6Y-8675	Housing As	418-9584

67M		
Original Part Number	Part Name	Classic Part Number
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722

Sales Model 631C (Cont'd.)

67M		
Original Part Number	Part Name	Classic Part Number
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-6459	Core As-Oclr	395-1313
8D-3442	Gear-Bevel	433-2026
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115

67M		
Original Part Number	Part Name	Classic Part Number
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-0111	Mount As	374-1452
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8P-2051	Plate-Clutch	385-6116
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348

67M		
Original Part Number	Part Name	Classic Part Number
8W-0376	Shaft	394-9194
8W-1708	Pin	388-0643
8W-3881	Bearing	394-8224
8X-6738	Shaft-Planet	394-8225
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1187	Bearing-Sleeve	384-4785
9J-9427	Bearing-Sleeve	361-1695
9L-2685	Rod End	419-1866
9L-5961	Adapter-Compr Dr	416-5508
9M-1990	Dowel-Reaction	386-4963
9M-3914	Bearing-Aligning	420-2501
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271

Sales Model 631C (Cont'd.)

67M		
Original Part Number	Part Name	Classic Part Number
9T-7414	Pump Gp-Gr B	421-1564
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
102-8608	Manifold-Exhaust	376-9062
105-2070	Bushing	394-0221

67M		
Original Part Number	Part Name	Classic Part Number
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
112-2255	Gear-Bevel	446-3076
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813

67M		
Original Part Number	Part Name	Classic Part Number
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
145-8503	Shaft As-Idler	426-0035
149-5985	Stator-Converter	419-1865
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-3904	Pump As-F Prm	391-1102
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
208-8795	Retainer	430-5355
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
221-6985	Retainer	399-4406
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

Sales Model 631D

21X		
Original Part Number	Part Name	Classic Part Number
3J-2903	Cover	422-6922
8F-7278	Diaphragm	392-4485
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
2J-1227	Retainer	440-0850
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
4T-7640	Shaft As	393-3643
5F-2830	Bearing-Needle	384-5925
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
7F-7780	Pin-Anchor	384-4825
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104

21X		
Original Part Number	Part Name	Classic Part Number
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
8F-7278	Diaphragm	392-4485
8J-9926	Bearing-Sleeve	383-2115
8W-1708	Pin	388-0643
9D-5444	Pin	380-7396
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
2J-1227	Retainer	440-0850
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
4T-7640	Shaft As	393-3643

21X		
Original Part Number	Part Name	Classic Part Number
5F-2830	Bearing-Needle	384-5925
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
7F-7780	Pin-Anchor	384-4825
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
8F-7278	Diaphragm	392-4485
8J-9926	Bearing-Sleeve	383-2115
8W-1708	Pin	388-0643
9D-5444	Pin	380-7396
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
2J-1227	Retainer	440-0850
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-0027	Pin As	388-6601

Sales Model 631D (Cont'd.)

21X		
Original Part Number	Part Name	Classic Part Number
3G-0034	Trunnion	361-1712
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
4T-7640	Shaft As	393-3643

21X		
Original Part Number	Part Name	Classic Part Number
5F-2830	Bearing-Needle	384-5925
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
7F-7780	Pin-Anchor	384-4825
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132

21X		
Original Part Number	Part Name	Classic Part Number
7J-4983	Cap-Bearing	384-3460
8F-7278	Diaphragm	392-4485
8J-9926	Bearing-Sleeve	383-2115
8W-1708	Pin	388-0643
9D-5444	Pin	380-7396
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031

24W		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049

24W		
Original Part Number	Part Name	Classic Part Number
1W-5009	Crankshaft As	398-2969
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

24W		
Original Part Number	Part Name	Classic Part Number
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-8986	Cup-Rlr Bearing	415-1912
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792

Sales Model 631D (Cont'd.)

24W		
Original Part Number	Part Name	Classic Part Number
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-4087	Gear As-Idler	418-9582
2W-6280	Bracket As-Fan	431-5271
2W-7980	Camshaft As	378-3972
2W-8038	Gear-Camshaft	425-7751
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3H-8726	Mount As	385-7208
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156

24W		
Original Part Number	Part Name	Classic Part Number
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1186	Bearing-Sleeve	417-4519
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-1849	Pipe-Air	421-7143
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4T-7819	Cyl Gp-051 127 Y	426-0028

24W		
Original Part Number	Part Name	Classic Part Number
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5F-2830	Bearing-Needle	384-5925
5F-7404	Nut-Bearing Lock	308-9878
5J-6430	Bearing-Sleeve	379-0195
5L-6326	Bearing-Ball	420-3222
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9841	Gasket Kit - Vg	393-3626
5P-9962	Bearing-Aligning	399-4397
5P-9972	Gasket Kit	393-5207

Sales Model 631D (Cont'd.)

24W		
Original Part Number	Part Name	Classic Part Number
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1032	Line As-Fuel Inj	390-0931

24W		
Original Part Number	Part Name	Classic Part Number
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922
6I-1038	Line As-Fuel Inj	390-0923
6I-3907	Adapter-Pilot	398-8348
6I-4613	Plate-Spacer	380-7405
6N-0425	Coupling-Exhaust	394-9836
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-4597	Coupling-Exhaust	369-9489
6N-5300	Pulley-Cshaft	378-3979
6N-5354	Pipe-Extension	430-8130
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-7706	Carrier-Ring	388-6603
6V-0220	Kit-Gasket(Cl)	437-4588
6V-0241	Gasket Kit - F	393-3628
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
6V-5920	Gasket Kit - F	388-0653
6Y-2065	Mount As-650 Cup	377-5844

24W		
Original Part Number	Part Name	Classic Part Number
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7C-5665	Elbow-90 Deg	399-8547
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-3909	Tube-Exhaust	398-8339
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7H-7628	Bearing	453-3655
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5218	Manifold-Exhaust	435-4786
7N-5219	Manifold-Exhaust	425-2362
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg	444-1842

Sales Model 631D (Cont'd.)

24W		
Original Part Number	Part Name	Classic Part Number
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-6459	Core As-Oclr	395-1313
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8M-0874	Plunger As-Valve	311-9439
8M-8652	Shaft	297-7252
8N-0111	Mount As	374-1452
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0784	Manifold-Mount	393-1044
8N-1628	Shaft As-F Pump	383-3703

24W		
Original Part Number	Part Name	Classic Part Number
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-4520	Piston-Clutch	394-0908
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8W-0376	Shaft	394-9194
8X-6738	Shaft-Planet	394-8225
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1187	Bearing-Sleeve	384-4785
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508

24W		
Original Part Number	Part Name	Classic Part Number
9M-3914	Bearing-Aligning	420-2501
9N-1161	Line As-Fuel Inj	383-3705
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9N-5529	Body-F Inj Valve	378-3993
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9T-7414	Pump Gp-Gr B	421-1564
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3125	Gasket	420-8567
101-3374	Gear-Cam-shaft Dr	376-9069

Sales Model 631D (Cont'd.)

24W		
Original Part Number	Part Name	Classic Part Number
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-2255	Gear-Bevel	446-3076
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-4525	Gage As	386-3043
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455

24W		
Original Part Number	Part Name	Classic Part Number
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-4995	Gasket-Cyl Head	434-2445
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-9381	Plate-Spacer	424-7052
141-4109	Core As-Oclr	416-5518
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6048	Kit-Dt Gasket	434-7272
155-6637	Gear-Oil Drive	425-9189
155-6648	Cone Spl Rol Brg	418-9599
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-4109	Manifold-Exhaust	433-9857
166-6352	Tube As.	432-4223

24W		
Original Part Number	Part Name	Classic Part Number
167-8126	Damper As	382-8019
170-8541	Core As-Rdtr	379-0180
171-6696	Diaphragm	384-4811
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
232-1841	Kit-Gasket (Fs)	387-2922
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
272-1956	Gasket	419-4710
278-1365	Arm As-Ui Rkr	433-7507
283-5666	Gasket-Cyl Head	388-6565
307-1303	Muffler As.	361-6574
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

Sales Model 631D (Cont'd.)

24W		
Original Part Number	Part Name	Classic Part Number
358-9117	Gear-Planet	380-7490

24W		
Original Part Number	Part Name	Classic Part Number
368-0297	Plate-Clutch	377-7420

66W		
Original Part Number	Part Name	Classic Part Number
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802

66W		
Original Part Number	Part Name	Classic Part Number
3K-0526	Bearing-Ball	386-4949
3S-1292	Bearing-Sleeve	425-8226
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5S-4442	Bearing-Spl Ball	419-6025

66W		
Original Part Number	Part Name	Classic Part Number
7S-4534	Bearing-Caged	417-9497
8H-8175	Bearing-Sleeve	376-3636
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
106-7799	Bearing-Ball	396-9947
177-7886	Cone	418-9605

Sales Model 631E

1AB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1S-3743	Bearing-Ball	384-4786
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797

1AB		
Original Part Number	Part Name	Classic Part Number
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1348	Support As-Carr	419-4049
1W-4369	Pulley-Alt	296-1340

1AB		
Original Part Number	Part Name	Classic Part Number
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9490	Pulley-Alt	394-0885
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508

Sales Model 631E (Cont'd.)

1AB		
Original Part Number	Part Name	Classic Part Number
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1757	Hub-Fan Pulley	296-1357
2P-8986	Cup-Rlr Bearing	415-1912
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-4087	Gear As-Idler	418-9582
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
2W-7980	Camshaft As	378-3972
2W-8038	Gear-Camshaft	425-7751
2W-8437	Muffler As	385-7198

1AB		
Original Part Number	Part Name	Classic Part Number
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4324	Cone-Spl Tapered	420-6534

1AB		
Original Part Number	Part Name	Classic Part Number
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0432	Bearing-Ball	417-4499
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1186	Bearing-Sleeve	417-4519
4N-1767	Valve-Bypass	419-4716
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885

Sales Model 631E (Cont'd.)

1AB		
Original Part Number	Part Name	Classic Part Number
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4T-7640	Shaft As	393-3643
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5F-2830	Bearing-Needle	384-5925
5F-7404	Nut-Bearing Lock	308-9878
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784

1AB		
Original Part Number	Part Name	Classic Part Number
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579

1AB		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-3907	Adapter-Pilot	398-8348
6I-4613	Plate-Spacer	380-7405
6K-4442	Rod End-Special	373-5388
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117

Sales Model 631E (Cont'd.)

1AB		
Original Part Number	Part Name	Classic Part Number
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
6V-5920	Gasket Kit - F	388-0653
6Y-1320	Plate-Clutch	384-5935
6Y-2065	Mount As-650 Cup	377-5844
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-3909	Tube-Exhaust	398-8339
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4983	Cap-Bearing	384-3460

1AB		
Original Part Number	Part Name	Classic Part Number
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-6459	Core As-Oclr	395-1313
8C-0580	Gasket Kit - T	393-1023

1AB		
Original Part Number	Part Name	Classic Part Number
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8N-0111	Mount As	374-1452
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0784	Manifold-Mount	393-1044
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227

Sales Model 631E (Cont'd.)

1AB		
Original Part Number	Part Name	Classic Part Number
8P-2051	Plate-Clutch	385-6116
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8T-1643	Kit-Dt Gasket	388-6575
8T-6487	Kit-Gasket-Sch	436-8384
8W-0376	Shaft	394-9194
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
8W-3881	Bearing	394-8224
8X-6738	Shaft-Planet	394-8225
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480

1AB		
Original Part Number	Part Name	Classic Part Number
9L-5961	Adapter-Compr Dr	416-5508
9M-1990	Dowel-Reaction	386-4963
9M-3914	Bearing-Aligning	420-2501
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9T-7414	Pump Gp-Gr B	421-1564
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552

1AB		
Original Part Number	Part Name	Classic Part Number
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3125	Gasket	420-8567
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
112-2255	Gear-Bevel	446-3076
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
114-0915	Shield As.	394-0887
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704

Sales Model 631E (Cont'd.)

1AB		
Original Part Number	Part Name	Classic Part Number
115-6469	Spacer	425-3645
117-0019	Disc-Friction	417-9492
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
126-5057	Shield As-Man Lh	369-9493
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-2707	Kit-Gasket (Bsc)	392-4506
135-3225	Shaft As	399-8582

1AB		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-9381	Plate-Spacer	424-7052
140-2749	Gasket Kit	393-1033
141-1936	Kit-Gasket(F)	437-4614
141-1939	Gasket Kit	437-4613
141-1942	Gasket Kit	437-4612
141-4109	Core As-Oclr	416-5518
144-0502	Ring Kit-Piston	395-1312
144-0503	Gear-Cplg & Sun	380-1554
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
149-5985	Stator-Converter	419-1865
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6637	Gear-Oil Drive	425-9189
156-8578	Shaft	417-9490
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
163-4109	Manifold-Exhaust	433-9857
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019

1AB		
Original Part Number	Part Name	Classic Part Number
171-6696	Diaphragm	384-4811
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-1304	Kit-Dt Gasket	394-8231
213-1305	Kit-Dt Gasket	394-8230
216-5582	Bearing-Sleeve	390-0914
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
232-2672	Kit-Gasket-Fs	393-0922
233-8683	Kit-Gasket-Mch	393-1039
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
257-0424	Shaft	421-8170
278-1365	Arm As-Ui Rkr	433-7507
283-5666	Gasket-Cyl Head	388-6565
297-6870	Kit-Dt Gasket	451-1510
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

Sales Model 631E (Cont'd.)

1AB		
Original Part Number	Part Name	Classic Part Number
352-0209	Pump Gp-Water -B	375-4336

1AB		
Original Part Number	Part Name	Classic Part Number
358-9117	Gear-Planet	380-7490

1AB		
Original Part Number	Part Name	Classic Part Number
368-0297	Plate-Clutch	377-7420

1BB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-5338	Cup-Roller Brg	374-8345
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-3743	Bearing-Ball	384-4786
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0679	Roller-Freewheel	384-4797
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9490	Pulley-Alt	394-0885

1BB		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6516	Bearing As-Rlr	435-2572
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-4087	Gear As-Idler	418-9582
2W-7774	Ejector As-Exh	393-0914

1BB		
Original Part Number	Part Name	Classic Part Number
2W-7980	Camshaft As	378-3972
2W-8437	Muffler As	385-7198
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4324	Cone-Spl Tapered	420-6534

Sales Model 631E (Cont'd.)

1BB		
Original Part Number	Part Name	Classic Part Number
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4T-7640	Shaft As	393-3643
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

1BB		
Original Part Number	Part Name	Classic Part Number
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-6430	Bearing-Sleeve	379-0195
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883

1BB		
Original Part Number	Part Name	Classic Part Number
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-4613	Plate-Spacer	380-7405
6K-4442	Rod End-Special	373-5388
6N-0977	Bearing-Sleeve	417-4524

Sales Model 631E (Cont'd.)

1BB		
Original Part Number	Part Name	Classic Part Number
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-1320	Plate-Clutch	384-5935
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7F-7780	Pin-Anchor	384-4825
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655

1BB		
Original Part Number	Part Name	Classic Part Number
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4983	Cap-Bearing	384-3460
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-6459	Core As-Oclr	395-1313
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342

1BB		
Original Part Number	Part Name	Classic Part Number
8J-9926	Bearing-Sleeve	383-2115
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8N-0111	Mount As	374-1452
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-7486	Condenser As	436-2263
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8W-0376	Shaft	394-9194
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
8W-3881	Bearing	394-8224
8X-6738	Shaft-Planet	394-8225
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933

Sales Model 631E (Cont'd.)

1BB		
Original Part Number	Part Name	Classic Part Number
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9L-2685	Rod End	419-1866
9L-5961	Adapter-Compr Dr	416-5508
9M-1990	Dowel-Reaction	386-4963
9M-3914	Bearing-Aligning	420-2501
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9T-7414	Pump Gp-Gr B	421-1564
9W-9930	Mount As	295-6437
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481

1BB		
Original Part Number	Part Name	Classic Part Number
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
102-8608	Manifold-Exhaust	376-9062
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
112-2255	Gear-Bevel	446-3076

1BB		
Original Part Number	Part Name	Classic Part Number
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
145-8503	Shaft As-Idler	426-0035
149-5985	Stator-Converter	419-1865
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368

Sales Model 631E (Cont'd.)

1BB		
Original Part Number	Part Name	Classic Part Number
217-0586	Bearing-Rod	419-7266
221-6985	Retainer	399-4406
253-1752	Plate-Thrust	379-0170

1BB		
Original Part Number	Part Name	Classic Part Number
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367

1BB		
Original Part Number	Part Name	Classic Part Number
328-4374	Disc-Friction	384-5966
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

1NB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1S-3743	Bearing-Ball	384-4786
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1348	Support As-Carr	419-4049
1W-4369	Pulley-Alt	296-1340
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704

1NB		
Original Part Number	Part Name	Classic Part Number
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9490	Pulley-Alt	394-0885
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532

1NB		
Original Part Number	Part Name	Classic Part Number
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-4087	Gear As-Idler	418-9582
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
2W-7980	Camshaft As	378-3972
2W-8038	Gear-Camshaft	425-7751
2W-8437	Muffler As	385-7198
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3J-2333	Bearing-Sleeve	422-9525

Sales Model 631E (Cont'd.)

1NB		
Original Part Number	Part Name	Classic Part Number
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-2619	Bearing	417-4494
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1186	Bearing-Sleeve	417-4519
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271

1NB		
Original Part Number	Part Name	Classic Part Number
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5F-2830	Bearing-Needle	384-5925
5F-7404	Nut-Bearing Lock	308-9878
5J-6430	Bearing-Sleeve	379-0195

1NB		
Original Part Number	Part Name	Classic Part Number
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6H-3957	Bearing-Ball	311-9358

Sales Model 631E (Cont'd.)

1NB		
Original Part Number	Part Name	Classic Part Number
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-3907	Adapter-Pilot	398-8348
6I-4613	Plate-Spacer	380-7405
6K-4442	Rod End-Special	373-5388
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6T-2293	Piston-Load	426-0040

1NB		
Original Part Number	Part Name	Classic Part Number
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
6V-5920	Gasket Kit - F	388-0653
6Y-1320	Plate-Clutch	384-5935
6Y-2065	Mount As-650 Cup	377-5844
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451

1NB		
Original Part Number	Part Name	Classic Part Number
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-6459	Core As-Oclr	395-1313
8C-0580	Gasket Kit - T	393-1023
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301

Sales Model 631E (Cont'd.)

1NB		
Original Part Number	Part Name	Classic Part Number
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8N-0111	Mount As	374-1452
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-2051	Plate-Clutch	385-6116
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8T-1643	Kit-Dt Gasket	388-6575

1NB		
Original Part Number	Part Name	Classic Part Number
8W-0376	Shaft	394-9194
8W-3881	Bearing	394-8224
8X-6738	Shaft-Planet	394-8225
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-6260	Trunnion	426-0031
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9M-1990	Dowel-Reaction	386-4963
9M-3914	Bearing-Aligning	420-2501
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9S-3581	Cup-Roller Brg	415-1923

1NB		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9T-7414	Pump Gp-Gr B	421-1564
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3125	Gasket	420-8567
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062

Sales Model 631E (Cont'd.)

1NB		
Original Part Number	Part Name	Classic Part Number
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
112-2255	Gear-Bevel	446-3076
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
114-0915	Shield As.	394-0887
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-0019	Disc-Friction	417-9492
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492

1NB		
Original Part Number	Part Name	Classic Part Number
126-5057	Shield As-Man Lh	369-9493
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Gear-Cplg & Sun	380-1554
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
149-5985	Stator-Converter	419-1865
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6637	Gear-Oil Drive	425-9189

1NB		
Original Part Number	Part Name	Classic Part Number
156-8578	Shaft	417-9490
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-1304	Kit-Dt Gasket	394-8231
213-1305	Kit-Dt Gasket	394-8230
216-5582	Bearing-Sleeve	390-0914
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
233-8681	Kit-Gasket-Mch	393-0920
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
257-0424	Shaft	421-8170
278-1365	Arm As-Ui Rkr	433-7507
283-5666	Gasket-Cyl Head	388-6565

Sales Model 631E (Cont'd.)

1NB		
Original Part Number	Part Name	Classic Part Number
297-6870	Kit-Dt Gasket	451-1510
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443

1NB		
Original Part Number	Part Name	Classic Part Number
328-4374	Disc-Friction	384-5966
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

1NB		
Original Part Number	Part Name	Classic Part Number
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

3ND		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1S-3743	Bearing-Ball	384-4786
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1348	Support As-Carr	419-4049

3ND		
Original Part Number	Part Name	Classic Part Number
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9490	Pulley-Alt	394-0885
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305

3ND		
Original Part Number	Part Name	Classic Part Number
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-3839	Crankshaft As	398-2968
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-3966	Ring-Seal	297-7237
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-4087	Gear As-Idler	418-9582
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
2W-7980	Camshaft As	378-3972
2W-8437	Muffler As	385-7198
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601

Sales Model 631E (Cont'd.)

3ND		
Original Part Number	Part Name	Classic Part Number
3G-0034	Trunnion	361-1712
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191

3ND		
Original Part Number	Part Name	Classic Part Number
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4T-7640	Shaft As	393-3643
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975

3ND		
Original Part Number	Part Name	Classic Part Number
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5F-2830	Bearing-Needle	384-5925
5J-6430	Bearing-Sleeve	379-0195
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883

Sales Model 631E (Cont'd.)

3ND		
Original Part Number	Part Name	Classic Part Number
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-3907	Adapter-Pilot	398-8348
6I-4613	Plate-Spacer	380-7405
6K-4442	Rod End-Special	373-5388

3ND		
Original Part Number	Part Name	Classic Part Number
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
6V-5920	Gasket Kit - F	388-0653
6Y-1320	Plate-Clutch	384-5935
6Y-2065	Mount As-650 Cup	377-5844
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7D-7607	Gear-Dif Bevel	388-0595

3ND		
Original Part Number	Part Name	Classic Part Number
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4983	Cap-Bearing	384-3460
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799

Sales Model 631E (Cont'd.)

3ND		
Original Part Number	Part Name	Classic Part Number
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-6459	Core As-Oclr	395-1313
8C-0580	Gasket Kit - T	393-1023
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8N-0111	Mount As	374-1452
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886

3ND		
Original Part Number	Part Name	Classic Part Number
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-2051	Plate-Clutch	385-6116
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-6511	Bearing-Sleeve	380-7372
8W-0376	Shaft	394-9194
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
8W-3881	Bearing	394-8224
8X-6738	Shaft-Planet	394-8225
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933

3ND		
Original Part Number	Part Name	Classic Part Number
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9M-1990	Dowel-Reaction	386-4963
9M-3914	Bearing-Aligning	420-2501
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9S-1195	Pump As-Oil	390-1000
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5746	Ferrule-Seal	392-4493
9S-8184	Pin-Drawbar	398-8345

Sales Model 631E (Cont'd.)

3ND		
Original Part Number	Part Name	Classic Part Number
9S-8789	Plate-Clutch	302-2712
9T-7414	Pump Gp-Gr B	421-1564
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3125	Gasket	420-8567
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487

3ND		
Original Part Number	Part Name	Classic Part Number
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
112-2255	Gear-Bevel	446-3076
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0019	Disc-Friction	417-9492
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813

3ND		
Original Part Number	Part Name	Classic Part Number
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Gear-Cplg & Sun	380-1554
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
149-5985	Stator-Converter	419-1865
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
156-8578	Shaft	417-9490
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-3904	Pump As-F Prm	391-1102
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-1304	Kit-Dt Gasket	394-8231
213-1305	Kit-Dt Gasket	394-8230

Sales Model 631E (Cont'd.)

3ND		
Original Part Number	Part Name	Classic Part Number
216-5582	Bearing-Sleeve	390-0914
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
233-8681	Kit-Gasket-Mch	393-0920
246-3130	Shaft-Water Pump	392-4508

3ND		
Original Part Number	Part Name	Classic Part Number
253-1752	Plate-Thrust	379-0170
257-0424	Shaft	421-8170
278-1365	Arm As-Ui Rkr	433-7507
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443

3ND		
Original Part Number	Part Name	Classic Part Number
328-4374	Disc-Friction	384-5966
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

3XC		
Original Part Number	Part Name	Classic Part Number
5T-3288	Yoke	424-0743

3XC		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
221-6985	Retainer	399-4406

4LD		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
2J-1227	Retainer	440-0850
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-7752	Pin As	384-4779
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782

4LD		
Original Part Number	Part Name	Classic Part Number
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4T-7640	Shaft As	393-3643
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5F-2830	Bearing-Needle	384-5925
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5T-3288	Yoke	424-0743
7F-7780	Pin-Anchor	384-4825

4LD		
Original Part Number	Part Name	Classic Part Number
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4983	Cap-Bearing	384-3460
7T-2036	Cap As-Fuel	361-1721
8J-9926	Bearing-Sleeve	383-2115
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
9D-5444	Pin	380-7396
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031

Sales Model 631E (Cont'd.)

4LD		
Original Part Number	Part Name	Classic Part Number
144-7289	Roller As	434-1862

4LD		
Original Part Number	Part Name	Classic Part Number
144-7314	Roller As	434-8984

4LD		
Original Part Number	Part Name	Classic Part Number
221-6985	Retainer	399-4406

6PC		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
2J-1227	Retainer	440-0850
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-7752	Pin As	384-4779
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782

6PC		
Original Part Number	Part Name	Classic Part Number
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4T-7640	Shaft As	393-3643
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5F-2830	Bearing-Needle	384-5925
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5T-3288	Yoke	424-0743
7F-7780	Pin-Anchor	384-4825
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104

6PC		
Original Part Number	Part Name	Classic Part Number
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4983	Cap-Bearing	384-3460
7T-2036	Cap As-Fuel	361-1721
8J-9926	Bearing-Sleeve	383-2115
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
9D-5444	Pin	380-7396
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
221-6985	Retainer	399-4406

Sales Model 631G

AWK		
Original Part Number	Part Name	Classic Part Number
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858

AWK		
Original Part Number	Part Name	Classic Part Number
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476

AWK		
Original Part Number	Part Name	Classic Part Number
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797

Sales Model 631G (Cont'd.)

AWK		
Original Part Number	Part Name	Classic Part Number
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-4369	Pulley-Alt	296-1340
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
2A-4429	Lock-Retainer	379-0174
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6150	Cover-Pulley	428-8817
2W-4087	Gear As-Idler	418-9582
2W-8038	Gear-Camshaft	425-7751

AWK		
Original Part Number	Part Name	Classic Part Number
3E-6772	Seal-Water	382-8017
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-1186	Bearing-Sleeve	417-4519
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450

AWK		
Original Part Number	Part Name	Classic Part Number
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6302	Belt Set-Vee	314-8495
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-5367	Mount As	375-9986
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5D-0470	Valve Gp-Qrel	314-8549
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5F-2830	Bearing-Needle	384-5925
5F-7404	Nut-Bearing Lock	308-9878
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783

Sales Model 631G (Cont'd.)

AWK		
Original Part Number	Part Name	Classic Part Number
5J-7981	Pin	256-4784
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-3641	Pulley-Tightener	380-7536
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603

AWK		
Original Part Number	Part Name	Classic Part Number
6T-5611	Spacer	435-8520
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-5996	Rod As-Conn	379-8864
7E-9595	Core As-Radiator	396-9926
7F-7780	Pin-Anchor	384-4825
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8H-8175	Bearing-Sleeve	376-3636

AWK		
Original Part Number	Part Name	Classic Part Number
8J-9926	Bearing-Sleeve	383-2115
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1619	Shield As	377-5857
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-7486	Condenser As	436-2263
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8W-3881	Bearing	394-8224
8X-6738	Shaft-Planet	394-8225
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-5444	Pin	380-7396
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1187	Bearing-Sleeve	384-4785
9L-5961	Adapter-Compr Dr	416-5508
9S-3581	Cup-Roller Brg	415-1923

Sales Model 631G (Cont'd.)

AWK		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9T-7414	Pump Gp-Gr B	421-1564
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-2255	Gear-Bevel	446-3076

AWK		
Original Part Number	Part Name	Classic Part Number
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
114-0915	Shield As.	394-0887
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
126-5057	Shield As-Man Lh	369-9493
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813

AWK		
Original Part Number	Part Name	Classic Part Number
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
155-6637	Gear-Oil Drive	425-9189
156-8578	Shaft	417-9490
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
167-8126	Damper As	382-8019
170-8541	Core As-Rdtr	379-0180
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
211-0592	Bearing - Main	419-6368
213-1304	Kit-Dt Gasket	394-8231
217-0586	Bearing-Rod	419-7266
221-6985	Retainer	399-4406
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

Sales Model 631G (Cont'd.)

AXZ		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
2J-1227	Retainer	440-0850
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-7752	Pin As	384-4779
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
4D-0487	Valve As-Check	375-4334

AXZ		
Original Part Number	Part Name	Classic Part Number
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4T-7640	Shaft As	393-3643
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5F-2830	Bearing-Needle	384-5925
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5T-3288	Yoke	424-0743
7F-7780	Pin-Anchor	384-4825
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104

AXZ		
Original Part Number	Part Name	Classic Part Number
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4983	Cap-Bearing	384-3460
7T-2036	Cap As-Fuel	361-1721
8J-9926	Bearing-Sleeve	383-2115
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
9D-5444	Pin	380-7396
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
221-6985	Retainer	399-4406

CLR		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797

CLR		
Original Part Number	Part Name	Classic Part Number
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-4369	Pulley-Alt	296-1340
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705

CLR		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850

Sales Model 631G (Cont'd.)

CLR		
Original Part Number	Part Name	Classic Part Number
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6150	Cover-Pulley	428-8817
2W-4087	Gear As-Idler	418-9582
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226

CLR		
Original Part Number	Part Name	Classic Part Number
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-1186	Bearing-Sleeve	417-4519
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6302	Belt Set-Vee	314-8495
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-5367	Mount As	375-9986

CLR		
Original Part Number	Part Name	Classic Part Number
4T-7640	Shaft As	393-3643
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5D-0470	Valve Gp-Qrel	314-8549
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5F-2830	Bearing-Needle	384-5925
5F-7404	Nut-Bearing Lock	308-9878
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-5856	Pipe-Extension	373-1913
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502

Sales Model 631G (Cont'd.)

CLR		
Original Part Number	Part Name	Classic Part Number
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-3641	Pulley-Tightener	380-7536
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571

CLR		
Original Part Number	Part Name	Classic Part Number
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-5996	Rod As-Conn	379-8864
7E-9595	Core As-Radiator	396-9926
7F-7780	Pin-Anchor	384-4825
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-2315	Retainer	384-3475

CLR		
Original Part Number	Part Name	Classic Part Number
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8J-9926	Bearing-Sleeve	383-2115
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1619	Shield As	377-5857
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-7486	Condenser As	436-2263
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
8W-3881	Bearing	394-8224
8X-6738	Shaft-Planet	394-8225
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-5444	Pin	380-7396
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782

Sales Model 631G (Cont'd.)

CLR		
Original Part Number	Part Name	Classic Part Number
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9L-5961	Adapter-Compr Dr	416-5508
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9T-7414	Pump Gp-Gr B	421-1564
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947

CLR		
Original Part Number	Part Name	Classic Part Number
107-8106	Manifold-Exh	374-7487
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-2255	Gear-Bevel	446-3076
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
114-0915	Shield As.	394-0887
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
126-5057	Shield As-Man Lh	369-9493
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919

CLR		
Original Part Number	Part Name	Classic Part Number
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
155-6637	Gear-Oil Drive	425-9189
156-8578	Shaft	417-9490
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
167-8126	Damper As	382-8019
170-8541	Core As-Rdtr	379-0180
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
221-6985	Retainer	399-4406
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

Sales Model 631G (Cont'd.)

CMT		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-4369	Pulley-Alt	296-1340
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
2A-4429	Lock-Retainer	379-0174
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418

CMT		
Original Part Number	Part Name	Classic Part Number
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6150	Cover-Pulley	428-8817
2W-4087	Gear As-Idler	418-9582
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226

CMT		
Original Part Number	Part Name	Classic Part Number
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-1186	Bearing-Sleeve	417-4519
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6302	Belt Set-Vee	314-8495
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4S-5367	Mount As	375-9986
4T-7640	Shaft As	393-3643
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

Sales Model 631G (Cont'd.)

CMT		
Original Part Number	Part Name	Classic Part Number
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5D-0470	Valve Gp-Qrel	314-8549
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5F-2830	Bearing-Needle	384-5925
5F-7404	Nut-Bearing Lock	308-9878
5J-6430	Bearing-Sleeve	379-0195
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190

CMT		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-3641	Pulley-Tightener	380-7536
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-5996	Rod As-Conn	379-8864
7F-7780	Pin-Anchor	384-4825

CMT		
Original Part Number	Part Name	Classic Part Number
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8J-9926	Bearing-Sleeve	383-2115
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1619	Shield As	377-5857
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562

Sales Model 631G (Cont'd.)

CMT		
Original Part Number	Part Name	Classic Part Number
8N-2368	Shield As	449-9547
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-7486	Condenser As	436-2263
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
8W-3881	Bearing	394-8224
8X-6738	Shaft-Planet	394-8225
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-5444	Pin	380-7396
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9L-5961	Adapter-Compr Dr	416-5508
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9T-7414	Pump Gp-Gr B	421-1564

CMT		
Original Part Number	Part Name	Classic Part Number
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-2255	Gear-Bevel	446-3076
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
114-0915	Shield As.	394-0887
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042

CMT		
Original Part Number	Part Name	Classic Part Number
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
126-5057	Shield As-Man Lh	369-9493
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
155-6637	Gear-Oil Drive	425-9189
156-8578	Shaft	417-9490
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
167-8126	Damper As	382-8019
170-8541	Core As-Rdtr	379-0180

Sales Model 631G (Cont'd.)

CMT		
Original Part Number	Part Name	Classic Part Number
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
211-0592	Bearing - Main	419-6368

CMT		
Original Part Number	Part Name	Classic Part Number
217-0586	Bearing-Rod	419-7266
221-6985	Retainer	399-4406
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367

CMT		
Original Part Number	Part Name	Classic Part Number
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

DEM		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7125	Governor As	383-3672
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6516	Bearing As-Rlr	435-2572

DEM		
Original Part Number	Part Name	Classic Part Number
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2W-6280	Bracket As-Fan	431-5271
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562

DEM		
Original Part Number	Part Name	Classic Part Number
3J-2903	Cover	422-6922
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812

Sales Model 631G (Cont'd.)

DEM		
Original Part Number	Part Name	Classic Part Number
4T-7640	Shaft As	393-3643
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5F-2830	Bearing-Needle	384-5925
5J-6430	Bearing-Sleeve	379-0195
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
6D-0738	Pinion-Dif Bevel	394-9840

DEM		
Original Part Number	Part Name	Classic Part Number
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-2065	Mount As-650 Cup	377-5844
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7D-7607	Gear-Dif Bevel	388-0595
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190

DEM		
Original Part Number	Part Name	Classic Part Number
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8N-0111	Mount As	374-1452
8N-2104	Bell As-Suction	380-1521
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
8W-3881	Bearing	394-8224
8X-6738	Shaft-Planet	394-8225
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9J-0940	Pin	319-3467

Sales Model 631G (Cont'd.)

DEM		
Original Part Number	Part Name	Classic Part Number
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9S-8789	Plate-Clutch	302-2712
9T-7414	Pump Gp-Gr B	421-1564
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966

DEM		
Original Part Number	Part Name	Classic Part Number
102-8608	Manifold-Exhaust	376-9062
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
112-2255	Gear-Bevel	446-3076
117-0019	Disc-Friction	417-9492
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106

DEM		
Original Part Number	Part Name	Classic Part Number
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
156-8578	Shaft	417-9490
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
177-7886	Cone	418-9605
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
257-0424	Shaft	421-8170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

DFA		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-1367	Plunger-Valve	432-8913

DFA		
Original Part Number	Part Name	Classic Part Number
1P-4110	Disc-Friction	433-9858
1P-7125	Governor As	383-3672
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409

DFA		
Original Part Number	Part Name	Classic Part Number
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803

Sales Model 631G (Cont'd.)

DFA		
Original Part Number	Part Name	Classic Part Number
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2W-6280	Bracket As-Fan	431-5271
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3J-2333	Bearing-Sleeve	422-9525

DFA		
Original Part Number	Part Name	Classic Part Number
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4T-7640	Shaft As	393-3643
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6296	Cone-Spl Tapered	399-6062

DFA		
Original Part Number	Part Name	Classic Part Number
5D-6298	Cup-Spl Tapered	399-6063
5F-2830	Bearing-Needle	384-5925
5J-6430	Bearing-Sleeve	379-0195
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206

Sales Model 631G (Cont'd.)

DFA		
Original Part Number	Part Name	Classic Part Number
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-2065	Mount As-650 Cup	377-5844
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7D-7607	Gear-Dif Bevel	388-0595
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799

DFA		
Original Part Number	Part Name	Classic Part Number
7S-4534	Bearing-Caged	417-9497
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8N-0111	Mount As	374-1452
8N-2104	Bell As-Suction	380-1521
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
8W-3881	Bearing	394-8224
8X-6738	Shaft-Planet	394-8225
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667

DFA		
Original Part Number	Part Name	Classic Part Number
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8789	Plate-Clutch	302-2712
9T-7414	Pump Gp-Gr B	421-1564
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
112-2255	Gear-Bevel	446-3076
117-0019	Disc-Friction	417-9492
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814

Sales Model 631G (Cont'd.)

DFA		
Original Part Number	Part Name	Classic Part Number
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
145-8503	Shaft As-Idler	426-0035

DFA		
Original Part Number	Part Name	Classic Part Number
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
156-8578	Shaft	417-9490
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
177-7886	Cone	418-9605
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368

DFA		
Original Part Number	Part Name	Classic Part Number
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
257-0424	Shaft	421-8170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

DXE		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7125	Governor As	383-3672
1S-9110	Bearing-Needle	420-2497
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049

DXE		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2J-5233	Bearing-Thrust	388-0578
2P-9313	Pump Gp-Gr 1 Bsc	418-1966

DXE		
Original Part Number	Part Name	Classic Part Number
2S-4900	Shaft As	384-4792
2T-3885	Housing	448-4967
2T-3890	Shaft As-Stub	425-9376
2W-6280	Bracket As-Fan	431-5271
3E-6772	Seal-Water	382-8017
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3J-9511	Bearing-Sleeve	385-3782

Sales Model 631G (Cont'd.)

DXE		
Original Part Number	Part Name	Classic Part Number
3K-0526	Bearing-Ball	386-4949
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-7255	Cone-Bearing	386-4951
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5F-2830	Bearing-Needle	384-5925
5J-6430	Bearing-Sleeve	379-0195
5J-8361	Bearing-Sleeve	384-4775

DXE		
Original Part Number	Part Name	Classic Part Number
5J-8363	Bearing-Sleeve	394-0209
5J-9451	Bearing	374-8338
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-2065	Mount As-650 Cup	377-5844

DXE		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
6Y-8675	Housing As	418-9584
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7D-7607	Gear-Dif Bevel	388-0595
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313

Sales Model 631G (Cont'd.)

DXE		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8N-0111	Mount As	374-1452
8N-2104	Bell As-Suction	380-1521
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8W-1708	Pin	388-0643
8W-3881	Bearing	394-8224
8X-6738	Shaft-Planet	394-8225
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-6260	Trunnion	426-0031

DXE		
Original Part Number	Part Name	Classic Part Number
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8789	Plate-Clutch	302-2712
9T-7414	Pump Gp-Gr B	421-1564
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
112-2255	Gear-Bevel	446-3076
117-0019	Disc-Friction	417-9492
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

DXE		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
156-8578	Shaft	417-9490
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
177-7886	Cone	418-9605
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
257-0424	Shaft	421-8170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

Sales Model 631G (Cont'd.)

XBC		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923

XBC		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144

Sales Model 631K

WT4		
Original Part Number	Part Name	Classic Part Number
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2D-9457	Cone-Spl Tapered	377-7418
2S-4900	Shaft As	384-4792
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3G-3346	Bushing	385-3786

WT4		
Original Part Number	Part Name	Classic Part Number
3G-3347	Bushing	385-3792
3K-0526	Bearing-Ball	386-4949
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5S-4442	Bearing-Spl Ball	419-6025

WT4		
Original Part Number	Part Name	Classic Part Number
5T-3329	Pin As	380-7395
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
6G-0387	Disc	394-2579
6N-1931	Plunger	379-0171
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-8675	Housing As	418-9584
6Y-9885	Bearing-Rlr As	396-9906
7C-0145	Core As-Oclr	374-4720
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7N-2156	Bearing-Sleeve	380-7373
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
8K-0067	Spacer	396-1569
8N-0111	Mount As	374-1452

Sales Model 631K (Cont'd.)

WT4		
Original Part Number	Part Name	Classic Part Number
8N-2104	Bell As-Suction	380-1521
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8W-3881	Bearing	394-8224
9D-4094	Bearing-Sleeve	418-1933
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1187	Bearing-Sleeve	384-4785

WT4		
Original Part Number	Part Name	Classic Part Number
9M-2744	Cone-Spl Tapered	380-1480
9S-8789	Plate-Clutch	302-2712
9V-9840	Spider	417-9498
9W-4662	Disc-Friction	428-7203
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
127-6356	Cover As.-Pump	420-8566
131-7123	Bearing-Sleeve	422-6919

WT4		
Original Part Number	Part Name	Classic Part Number
133-3359	Manifold-Exhaust	419-4730
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
177-7886	Cone	418-9605
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
221-6985	Retainer	399-4406
253-1752	Plate-Thrust	379-0170
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

WT5		
Original Part Number	Part Name	Classic Part Number
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152

WT5		
Original Part Number	Part Name	Classic Part Number
1T-1348	Support As-Carr	419-4049
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2D-9457	Cone-Spl Tapered	377-7418
2S-4900	Shaft As	384-4792
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3J-2903	Cover	422-6922
3K-0526	Bearing-Ball	386-4949

WT5		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4W-5698	Bearing-Main	419-6323

Sales Model 631K (Cont'd.)

WT5		
Original Part Number	Part Name	Classic Part Number
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5S-4442	Bearing-Spl Ball	419-6025
5T-3329	Pin As	380-7395
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
6G-0387	Disc	394-2579
6N-1931	Plunger	379-0171
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-8675	Housing As	418-9584
6Y-9885	Bearing-Rlr As	396-9906
7C-0145	Core As-Oclr	374-4720
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7N-2156	Bearing-Sleeve	380-7373
7S-4497	Gear-Cplg	444-1842

WT5		
Original Part Number	Part Name	Classic Part Number
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
8K-0067	Spacer	396-1569
8N-0111	Mount As	374-1452
8N-2104	Bell As-Suction	380-1521
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8W-3881	Bearing	394-8224
9D-4094	Bearing-Sleeve	418-1933
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1187	Bearing-Sleeve	384-4785
9M-2744	Cone-Spl Tapered	380-1480
9S-8789	Plate-Clutch	302-2712
9V-9840	Spider	417-9498

WT5		
Original Part Number	Part Name	Classic Part Number
9W-4662	Disc-Friction	428-7203
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
127-6356	Cover As.-Pump	420-8566
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
177-7886	Cone	418-9605
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
221-6985	Retainer	399-4406
253-1752	Plate-Thrust	379-0170
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

WT7		
Original Part Number	Part Name	Classic Part Number
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858

WT7		
Original Part Number	Part Name	Classic Part Number
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409

WT7		
Original Part Number	Part Name	Classic Part Number
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464

Sales Model 631K (Cont'd.)

WT7		
Original Part Number	Part Name	Classic Part Number
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2D-9457	Cone-Spl Tapered	377-7418
2S-4900	Shaft As	384-4792
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3J-2903	Cover	422-6922
3K-0526	Bearing-Ball	386-4949
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283

WT7		
Original Part Number	Part Name	Classic Part Number
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5S-4442	Bearing-Spl Ball	419-6025
5T-3329	Pin As	380-7395
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
6G-0387	Disc	394-2579
6N-1931	Plunger	379-0171
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-8675	Housing As	418-9584
6Y-9885	Bearing-Rlr As	396-9906
7C-0145	Core As-Oclr	374-4720
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7N-2156	Bearing-Sleeve	380-7373
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
8K-0067	Spacer	396-1569

WT7		
Original Part Number	Part Name	Classic Part Number
8N-0111	Mount As	374-1452
8N-2104	Bell As-Suction	380-1521
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8W-3881	Bearing	394-8224
9D-4094	Bearing-Sleeve	418-1933
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1187	Bearing-Sleeve	384-4785
9M-2744	Cone-Spl Tapered	380-1480
9S-8789	Plate-Clutch	302-2712
9V-9840	Spider	417-9498
9W-4662	Disc-Friction	428-7203
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
127-6356	Cover As.-Pump	420-8566
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
138-9381	Plate-Spacer	424-7052

Sales Model 631K (Cont'd.)

WT7		
Original Part Number	Part Name	Classic Part Number
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
177-7886	Cone	418-9605
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656

WT7		
Original Part Number	Part Name	Classic Part Number
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508

WT7		
Original Part Number	Part Name	Classic Part Number
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

WTR		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2D-9457	Cone-Spl Tapered	377-7418

WTR		
Original Part Number	Part Name	Classic Part Number
2J-1227	Retainer	440-0850
2S-4900	Shaft As	384-4792
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226

WTR		
Original Part Number	Part Name	Classic Part Number
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5S-4442	Bearing-Spl Ball	419-6025
5T-3329	Pin As	380-7395
5T-5682	Driver	418-9579

Sales Model 631K (Cont'd.)

WTR		
Original Part Number	Part Name	Classic Part Number
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
6G-0387	Disc	394-2579
6N-1931	Plunger	379-0171
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-8675	Housing As	418-9584
6Y-9885	Bearing-Rlr As	396-9906
7C-0145	Core As-Oclr	374-4720
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-9365	Bearing-Sleeve	453-6507
7N-2156	Bearing-Sleeve	380-7373
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096

WTR		
Original Part Number	Part Name	Classic Part Number
8J-9926	Bearing-Sleeve	383-2115
8K-0067	Spacer	396-1569
8N-0111	Mount As	374-1452
8N-2104	Bell As-Suction	380-1521
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8W-1708	Pin	388-0643
8W-3881	Bearing	394-8224
9D-4094	Bearing-Sleeve	418-1933
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9M-2744	Cone-Spl Tapered	380-1480
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8789	Plate-Clutch	302-2712
9V-9840	Spider	417-9498
9W-4662	Disc-Friction	428-7203

WTR		
Original Part Number	Part Name	Classic Part Number
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
087-5548	Bearing-Sleeve	396-1568
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
127-6356	Cover As.-Pump	420-8566
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
138-9381	Plate-Spacer	424-7052
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
177-7886	Cone	418-9605
184-9843	Head	347-0461
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
221-6985	Retainer	399-4406
253-1752	Plate-Thrust	379-0170
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

Sales Model 631K (Cont'd.)

WTW		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2D-9457	Cone-Spl Tapered	377-7418
2J-1227	Retainer	440-0850
2S-4900	Shaft As	384-4792
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792

WTW		
Original Part Number	Part Name	Classic Part Number
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467

WTW		
Original Part Number	Part Name	Classic Part Number
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5S-4442	Bearing-Spl Ball	419-6025
5T-3329	Pin As	380-7395
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
6G-0387	Disc	394-2579
6N-1931	Plunger	379-0171
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6Y-8675	Housing As	418-9584
6Y-9885	Bearing-Rlr As	396-9906
7C-0145	Core As-Oclr	374-4720
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-9365	Bearing-Sleeve	453-6507
7N-2156	Bearing-Sleeve	380-7373
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799

Sales Model 631K (Cont'd.)

WTW		
Original Part Number	Part Name	Classic Part Number
7S-4534	Bearing-Caged	417-9497
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
8J-9926	Bearing-Sleeve	383-2115
8K-0067	Spacer	396-1569
8N-0111	Mount As	374-1452
8N-2104	Bell As-Suction	380-1521
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8W-1708	Pin	388-0643
8W-3881	Bearing	394-8224
9D-4094	Bearing-Sleeve	418-1933
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782

WTW		
Original Part Number	Part Name	Classic Part Number
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9M-2744	Cone-Spl Tapered	380-1480
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8789	Plate-Clutch	302-2712
9V-9840	Spider	417-9498
9W-4662	Disc-Friction	428-7203
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
087-5548	Bearing-Sleeve	396-1568
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
127-6356	Cover As.-Pump	420-8566

WTW		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
138-9381	Plate-Spacer	424-7052
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
177-7886	Cone	418-9605
184-9843	Head	347-0461
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

Sales Model 632

14G		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913

14G		
Original Part Number	Part Name	Classic Part Number
1S-9110	Bearing-Needle	420-2497
1T-0299	Cup-Roller Brg	422-6494

14G		
Original Part Number	Part Name	Classic Part Number
1T-0364	Flange-Joint	388-6567
1T-0365	Flange-Joint	434-1861
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709

Sales Model 632 (Cont'd.)

14G		
Original Part Number	Part Name	Classic Part Number
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-4502	Bearing-Sleeve	299-1986
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-2717	Cartridge Gp	439-1132

14G		
Original Part Number	Part Name	Classic Part Number
3G-2752	Cartridge Gp-Rr	422-8127
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3R-5327	Pipe-Extension	383-1571
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4S-5367	Mount As	375-9986
5D-0470	Valve Gp-Qrel	314-8549
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5J-1968	Shaft-Roller	386-4928
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521

14G		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6D-0738	Pinion-Dif Bevel	394-9840
6N-9211	Core As-O Clr	435-6049
6V-2202	Bearing-Spl Ball	380-1574
7D-7607	Gear-Dif Bevel	388-0595
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-5003	Cap As-Rain	379-0184
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8F-5104	Screen As-Se Pan	314-8539

Sales Model 632 (Cont'd.)

14G		
Original Part Number	Part Name	Classic Part Number
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565

14G		
Original Part Number	Part Name	Classic Part Number
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-9686	Gasket Kit	393-5215
8W-1708	Pin	388-0643
9D-5444	Pin	380-7396
9M-8395	Bearing-Sleeve	391-1103
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271

14G		
Original Part Number	Part Name	Classic Part Number
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
128-3935	Bearing-Race	396-9897
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

71G		
Original Part Number	Part Name	Classic Part Number
3G-2717	Cartridge Gp	439-1132
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922

71G		
Original Part Number	Part Name	Classic Part Number
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
5J-1968	Shaft-Roller	386-4928

71G		
Original Part Number	Part Name	Classic Part Number
8F-7278	Diaphragm	392-4485
9D-5444	Pin	380-7396
9T-5096	Flexplate	455-3271

79F		
Original Part Number	Part Name	Classic Part Number
3G-0034	Trunnion	361-1712
3G-2717	Cartridge Gp	439-1132
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582

79F		
Original Part Number	Part Name	Classic Part Number
3J-9133	Bearing-Sleeve	361-1691
5J-1968	Shaft-Roller	386-4928
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460

79F		
Original Part Number	Part Name	Classic Part Number
8F-7278	Diaphragm	392-4485
8W-3613	Bearing	418-1960
9D-5444	Pin	380-7396
9T-5096	Flexplate	455-3271

Sales Model 633

44J		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1S-9110	Bearing-Needle	420-2497
1T-0299	Cup-Roller Brg	422-6494
1T-0364	Flange-Joint	388-6567
1T-0365	Flange-Joint	434-1861
1U-2669	Cartridge Gp	422-8118
1U-3953	Cartridge Gp	426-0024
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305

44J		
Original Part Number	Part Name	Classic Part Number
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-2752	Cartridge Gp-Rr	422-8127
3G-7662	Cartridge Gp	422-8105
3G-7663	Cartridge Gp	422-8120
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3R-5327	Pipe-Extension	383-1571
4B-1455	Cap As-Filler	361-1719
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439

44J		
Original Part Number	Part Name	Classic Part Number
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4S-5367	Mount As	375-9986
5D-0470	Valve Gp-Qrel	314-8549
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579

Sales Model 633 (Cont'd.)

44J		
Original Part Number	Part Name	Classic Part Number
6D-0738	Pinion-Dif Bevel	394-9840
6H-3957	Bearing-Ball	311-9358
6J-6043	Bearing-Sleeve	374-1456
6N-9211	Core As-O Clr	435-6049
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7D-7607	Gear-Dif Bevel	388-0595
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519

44J		
Original Part Number	Part Name	Classic Part Number
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728

44J		
Original Part Number	Part Name	Classic Part Number
8S-3656	Plunger As-Pump	419-4750
8S-9686	Gasket Kit	393-5215
8W-1708	Pin	388-0643
9D-5444	Pin	380-7396
9M-8395	Bearing-Sleeve	391-1103
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-9696	Spider As-Fan	383-3707
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
128-3935	Bearing-Race	396-9897
160-6306	Cap-Bearing	325-6038
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
308-1845	Seal-Wiper	472-8032

86H		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1S-9110	Bearing-Needle	420-2497
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797

86H		
Original Part Number	Part Name	Classic Part Number
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-2669	Cartridge Gp	422-8118

86H		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914

Sales Model 633 (Cont'd.)

86H		
Original Part Number	Part Name	Classic Part Number
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2K-0227	Bearing-Sleeve	384-4780
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-7662	Cartridge Gp	422-8105
3G-7663	Cartridge Gp	422-8120
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3J-6559	Cap-Bearing	296-1346
3K-0526	Bearing-Ball	386-4949

86H		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4B-7255	Cone-Bearing	386-4951
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4P-7731	Core Gp-O Clr	385-7228
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5F-2830	Bearing-Needle	384-5925
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5K-2294	Bearing	396-9912

86H		
Original Part Number	Part Name	Classic Part Number
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6J-6043	Bearing-Sleeve	374-1456
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
6Y-8675	Housing As	418-9584
7D-7607	Gear-Dif Bevel	388-0595
7E-5085	Bushing	377-5829

Sales Model 633 (Cont'd.)

86H		
Original Part Number	Part Name	Classic Part Number
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7H-7628	Bearing	453-3655
7J-8458	Bearing-Sleeve	380-7374
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
7W-1927	Ring-Retainer	387-2935

86H		
Original Part Number	Part Name	Classic Part Number
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8D-3442	Gear-Bevel	433-2026
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-4550	Shaft-Pulley	445-9247
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750

86H		
Original Part Number	Part Name	Classic Part Number
8S-9151	Cup-Spl Tapered	374-8348
8W-1708	Pin	388-0643
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-9427	Bearing-Sleeve	361-1695
9M-3914	Bearing-Aligning	420-2501
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9W-4662	Disc-Friction	428-7203
101-7517	Housing	391-1094
106-7799	Bearing-Ball	396-9947
160-6306	Cap-Bearing	325-6038
162-3904	Pump As-F Prm	391-1102
208-8795	Retainer	430-5355
308-1845	Seal-Wiper	472-8032
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

Sales Model 633B

86H		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1S-9110	Bearing-Needle	420-2497
1T-0334	Bearing-Ball	380-1476

86H		
Original Part Number	Part Name	Classic Part Number
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803

86H		
Original Part Number	Part Name	Classic Part Number
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049

Sales Model 633B (Cont'd.)

86H		
Original Part Number	Part Name	Classic Part Number
1U-2669	Cartridge Gp	422-8118
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2K-0227	Bearing-Sleeve	384-4780
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601

86H		
Original Part Number	Part Name	Classic Part Number
3G-7662	Cartridge Gp	422-8105
3G-7663	Cartridge Gp	422-8120
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3J-6559	Cap-Bearing	296-1346
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4B-7255	Cone-Bearing	386-4951
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4P-7731	Core Gp-O Clr	385-7228
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511

86H		
Original Part Number	Part Name	Classic Part Number
5F-2830	Bearing-Needle	384-5925
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5K-2294	Bearing	396-9912
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388

Sales Model 633B (Cont'd.)

86H		
Original Part Number	Part Name	Classic Part Number
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6J-6043	Bearing-Sleeve	374-1456
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
6Y-8675	Housing As	418-9584
7D-7607	Gear-Dif Bevel	388-0595
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7H-7628	Bearing	453-3655
7J-8458	Bearing-Sleeve	380-7374
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497

86H		
Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8D-3442	Gear-Bevel	433-2026
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-4550	Shaft-Pulley	445-9247
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565

86H		
Original Part Number	Part Name	Classic Part Number
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-9151	Cup-Spl Tapered	374-8348
8W-1708	Pin	388-0643
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-9427	Bearing-Sleeve	361-1695
9M-3914	Bearing-Aligning	420-2501
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9W-4662	Disc-Friction	428-7203
101-7517	Housing	391-1094
106-7799	Bearing-Ball	396-9947
160-6306	Cap-Bearing	325-6038
162-3904	Pump As-F Prm	391-1102
208-8795	Retainer	430-5355
308-1845	Seal-Wiper	472-8032
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

Sales Model 633C

66M		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913

Sales Model 633C (Cont'd.)

66M		
Original Part Number	Part Name	Classic Part Number
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1S-9110	Bearing-Needle	420-2497
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-2669	Cartridge Gp	422-8118
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578

66M		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-7662	Cartridge Gp	422-8105
3G-7663	Cartridge Gp	422-8120
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4B-7255	Cone-Bearing	386-4951
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494

66M		
Original Part Number	Part Name	Classic Part Number
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4P-7731	Core Gp-O Clr	385-7228
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5F-2830	Bearing-Needle	384-5925
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5K-2294	Bearing	396-9912
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397

Sales Model 633C (Cont'd.)

66M		
Original Part Number	Part Name	Classic Part Number
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6J-6043	Bearing-Sleeve	374-1456
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
6Y-8675	Housing As	418-9584
7D-7607	Gear-Dif Bevel	388-0595
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7H-7628	Bearing	453-3655
7J-8458	Bearing-Sleeve	380-7374
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189

66M		
Original Part Number	Part Name	Classic Part Number
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8D-3442	Gear-Bevel	433-2026
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-4550	Shaft-Pulley	445-9247
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908

66M		
Original Part Number	Part Name	Classic Part Number
8S-0611	Cage-Bearing	451-0748
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-9151	Cup-Spl Tapered	374-8348
8W-1708	Pin	388-0643
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-9427	Bearing-Sleeve	361-1695
9M-3914	Bearing-Aligning	420-2501
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9W-4662	Disc-Friction	428-7203
101-7517	Housing	391-1094
106-7799	Bearing-Ball	396-9947
160-6306	Cap-Bearing	325-6038
162-3904	Pump As-F Prm	391-1102
208-8795	Retainer	430-5355
308-1845	Seal-Wiper	472-8032
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

Sales Model 633D

19W		
Original Part Number	Part Name	Classic Part Number
1S-9110	Bearing-Needle	420-2497
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
2J-1227	Retainer	440-0850
2K-0227	Bearing-Sleeve	384-4780
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3J-2373	Bearing-Sleeve	380-7562
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3J-6559	Cap-Bearing	296-1346

19W		
Original Part Number	Part Name	Classic Part Number
3K-0526	Bearing-Ball	386-4949
3S-1292	Bearing-Sleeve	425-8226
4B-7255	Cone-Bearing	386-4951
5F-2830	Bearing-Needle	384-5925
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5J-9451	Bearing	374-8338
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5S-4442	Bearing-Spl Ball	419-6025
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6J-6043	Bearing-Sleeve	374-1456

19W		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7F-7780	Pin-Anchor	384-4825
7J-1770	Cap-Bearing	396-0664
7S-4534	Bearing-Caged	417-9497
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636
8J-9926	Bearing-Sleeve	383-2115
8W-1708	Pin	388-0643
9D-5444	Pin	380-7396
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-8323	Trunnion	361-1713
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
106-7799	Bearing-Ball	396-9947
160-6306	Cap-Bearing	325-6038
177-7886	Cone	418-9605

25W		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7895	Cone-Roller Brg	396-4145
1S-9209	Shaft-Tightener	374-6499

25W		
Original Part Number	Part Name	Classic Part Number
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803

25W		
Original Part Number	Part Name	Classic Part Number
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1W-5009	Crankshaft As	398-2969
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221

Sales Model 633D (Cont'd.)

25W		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-5680	Turbine-Conv	308-9942
2P-8986	Cup-Rlr Bearing	415-1912
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2P-9314	Disc As-Clutch	384-4791
2S-4900	Shaft As	384-4792

25W		
Original Part Number	Part Name	Classic Part Number
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-4087	Gear As-Idler	418-9582
2W-6280	Bracket As-Fan	431-5271
2W-7980	Camshaft As	378-3972
2W-8038	Gear-Camshaft	425-7751
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7657	Cartridge Gp	422-8101
3G-7662	Cartridge Gp	422-8105
3G-7666	Cartridge Gp	422-8098
3G-7667	Cartridge Gp	422-8107
3G-7752	Pin As	384-4779
3H-8726	Mount As	385-7208
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-5100	Hub-Impeller	451-9022
3T-5102	Impeller-Conv	416-2125
4B-1455	Cap As-Filler	361-1719
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824

25W		
Original Part Number	Part Name	Classic Part Number
4F-2041	Cup-Roller Brg	418-9609
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1186	Bearing-Sleeve	417-4519
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-1849	Pipe-Air	421-7143
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6413	Support-Alt	433-9855

Sales Model 633D (Cont'd.)

25W		
Original Part Number	Part Name	Classic Part Number
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5F-2830	Bearing-Needle	384-5925
5F-7404	Nut-Bearing Lock	308-9878
5J-6430	Bearing-Sleeve	379-0195
5L-6326	Bearing-Ball	420-3222
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509

25W		
Original Part Number	Part Name	Classic Part Number
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9841	Gasket Kit - Vg	393-3626
5P-9962	Bearing-Aligning	399-4397
5P-9972	Gasket Kit	393-5207
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716

25W		
Original Part Number	Part Name	Classic Part Number
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1032	Line As-Fuel Inj	390-0931
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922
6I-1038	Line As-Fuel Inj	390-0923
6I-3907	Adapter-Pilot	398-8348
6I-4613	Plate-Spacer	380-7405
6I-9507	Piston-Clutch	417-9470
6I-9509	Plate	398-2960
6L-7751	Rod End-Spher	472-8015
6N-0425	Coupling-Exhaust	394-9836
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-4597	Coupling-Exhaust	369-9489
6N-5300	Pulley-Cshaft	378-3979
6N-5354	Pipe-Extension	430-8130
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371

Sales Model 633D (Cont'd.)

25W		
Original Part Number	Part Name	Classic Part Number
6N-9133	Gasket-Plate	398-2959
6P-7706	Carrier-Ring	388-6603
6T-3324	Housing As-Cl	391-9827
6V-0220	Kit-Gasket(Cl)	437-4588
6V-0241	Gasket Kit - F	393-3628
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
6V-5920	Gasket Kit - F	388-0653
6Y-2065	Mount As-650 Cup	377-5844
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7C-5665	Elbow-90 Deg	399-8547
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-3909	Tube-Exhaust	398-8339
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7H-7628	Bearing	453-3655
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535

25W		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5218	Manifold-Exhaust	435-4786
7N-5219	Manifold-Exhaust	425-2362
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-6459	Core As-Oclr	395-1313
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636

25W		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8M-0874	Plunger As-Valve	311-9439
8M-8652	Shaft	297-7252
8N-0111	Mount As	374-1452
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0784	Manifold-Mount	393-1044
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-4520	Piston-Clutch	394-0908
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8W-0376	Shaft	394-9194
8X-6738	Shaft-Planet	394-8225
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818

Sales Model 633D (Cont'd.)

25W		
Original Part Number	Part Name	Classic Part Number
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1187	Bearing-Sleeve	384-4785
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9M-3914	Bearing-Aligning	420-2501
9N-1161	Line As-Fuel Inj	383-3705
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9N-5529	Body-F Inj Valve	378-3993
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9S-8184	Pin-Drawbar	398-8345
9T-5096	Flexplate	455-3271
9W-1567	Impeller-Conv	391-9880
9W-4662	Disc-Friction	428-7203
9W-4702	Stator-Converter	308-9939

25W		
Original Part Number	Part Name	Classic Part Number
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3125	Gasket	420-8567
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-2255	Gear-Bevel	446-3076
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704

25W		
Original Part Number	Part Name	Classic Part Number
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-4525	Gage As	386-3043
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-4995	Gasket-Cyl Head	434-2445
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-9381	Plate-Spacer	424-7052
141-4109	Core As-Oclr	416-5518

Sales Model 633D (Cont'd.)

25W		
Original Part Number	Part Name	Classic Part Number
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6637	Gear-Oil Drive	425-9189
155-6648	Cone Spl Rol Brg	418-9599
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-4109	Manifold-Exhaust	433-9857
166-6352	Tube As.	432-4223

25W		
Original Part Number	Part Name	Classic Part Number
167-8126	Damper As	382-8019
170-8541	Core As-Rdtr	379-0180
171-6696	Diaphragm	384-4811
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735

25W		
Original Part Number	Part Name	Classic Part Number
232-1841	Kit-Gasket (Fs)	387-2922
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
272-1956	Gasket	419-4710
278-1365	Arm As-Ui Rkr	433-7507
283-5666	Gasket-Cyl Head	388-6565
307-1303	Muffler As.	361-6574
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

Sales Model 633E

1EB		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-9110	Bearing-Needle	420-2497
1U-0408	Cyl Gp-0165 1549	415-1898

1EB		
Original Part Number	Part Name	Classic Part Number
2J-1227	Retainer	440-0850
2K-0227	Bearing-Sleeve	384-4780
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-7752	Pin As	384-4779
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922

1EB		
Original Part Number	Part Name	Classic Part Number
3J-3953	Bearing-Sleeve	384-4778
3J-6412	Bearing-Sleeve	386-4920
3J-6559	Cap-Bearing	296-1346
3J-9133	Bearing-Sleeve	361-1691
4B-7255	Cone-Bearing	386-4951
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534

Sales Model 633E (Cont'd.)

1EB		
Original Part Number	Part Name	Classic Part Number
4D-4325	Cup-Spl Tapered	420-6533
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5F-2830	Bearing-Needle	384-5925
5F-7958	Shaft-Roller	434-1865
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5J-9451	Bearing	374-8338
5M-2054	Bearing	380-7510

1EB		
Original Part Number	Part Name	Classic Part Number
5M-6126	Bearing	377-7433
5T-3288	Yoke	424-0743
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6J-6043	Bearing-Sleeve	374-1456
6Y-7652	Cup-Rlr Brg	399-6067
7F-7780	Pin-Anchor	384-4825
7J-1770	Cap-Bearing	396-0664
7T-2036	Cap As-Fuel	361-1721
8B-5972	Bearing-Ball	314-8503
8J-6536	Bearing	425-6444
8J-6861	Bearing As	384-5950

1EB		
Original Part Number	Part Name	Classic Part Number
8J-7211	Guide-Lh	428-8815
8J-9926	Bearing-Sleeve	383-2115
8W-1708	Pin	388-0643
9D-5444	Pin	380-7396
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-6260	Trunnion	426-0031
9J-8323	Trunnion	361-1713
144-7299	Roller As	434-1991
221-6985	Retainer	399-4406

2PS		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152

2PS		
Original Part Number	Part Name	Classic Part Number
1T-1348	Support As-Carr	419-4049
1W-4369	Pulley-Alt	296-1340
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9490	Pulley-Alt	394-0885
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

2PS		
Original Part Number	Part Name	Classic Part Number
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1757	Hub-Fan Pulley	296-1357
2P-8986	Cup-Rlr Bearing	415-1912
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979

Sales Model 633E (Cont'd.)

2PS		
Original Part Number	Part Name	Classic Part Number
2S-6150	Cover-Pulley	428-8817
2W-4087	Gear As-Idler	418-9582
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
2W-8038	Gear-Camshaft	425-7751
2W-8437	Muffler As	385-7198
3E-6772	Seal-Water	382-8017
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525

2PS		
Original Part Number	Part Name	Classic Part Number
4N-1106	Shaft As-Rocker	377-5837
4N-1186	Bearing-Sleeve	417-4519
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5F-2830	Bearing-Needle	384-5925

2PS		
Original Part Number	Part Name	Classic Part Number
5F-7404	Nut-Bearing Lock	308-9878
5J-6430	Bearing-Sleeve	379-0195
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524

Sales Model 633E (Cont'd.)

2PS		
Original Part Number	Part Name	Classic Part Number
6N-1931	Plunger	379-0171
6N-3641	Pulley-Tightener	380-7536
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7K-2135	Bearing-Roller	417-4492
7N-1164	Mount As	295-5451

2PS		
Original Part Number	Part Name	Classic Part Number
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-3368	Valve-Check	388-6599
8N-0111	Mount As	374-1452
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725

2PS		
Original Part Number	Part Name	Classic Part Number
8N-1622	Shield As-Manf	374-4726
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8W-3881	Bearing	394-8224
8X-6738	Shaft-Planet	394-8225
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-5444	Pin	380-7396
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1187	Bearing-Sleeve	384-4785
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480

Sales Model 633E (Cont'd.)

2PS		
Original Part Number	Part Name	Classic Part Number
9L-5961	Adapter-Compr Dr	416-5508
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9T-7414	Pump Gp-Gr B	421-1564
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3125	Gasket	420-8567
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947

2PS		
Original Part Number	Part Name	Classic Part Number
107-8106	Manifold-Exh	374-7487
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
112-2255	Gear-Bevel	446-3076
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
114-0915	Shield As.	394-0887
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-0019	Disc-Friction	417-9492
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
126-5057	Shield As-Man Lh	369-9493
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589

2PS		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-2707	Kit-Gasket (Bsc)	392-4506
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-9381	Plate-Spacer	424-7052
140-2749	Gasket Kit	393-1033
141-1936	Kit-Gasket(F)	437-4614
141-1939	Gasket Kit	437-4613
141-1942	Gasket Kit	437-4612
141-4109	Core As-Oclr	416-5518
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
163-4109	Manifold-Exhaust	433-9857
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
177-7886	Cone	418-9605

Sales Model 633E (Cont'd.)

2PS		
Original Part Number	Part Name	Classic Part Number
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
213-1304	Kit-Dt Gasket	394-8231
216-5582	Bearing-Sleeve	390-0914

2PS		
Original Part Number	Part Name	Classic Part Number
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
283-5666	Gasket-Cyl Head	388-6565

2PS		
Original Part Number	Part Name	Classic Part Number
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

Sales Model 637

64M		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108

64M		
Original Part Number	Part Name	Classic Part Number
1T-1033	Plate-Cl Backing	431-4136
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

64M		
Original Part Number	Part Name	Classic Part Number
2D-5383	Gasket	445-7709
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2H-9192	Bearing-Ball	394-8236
2J-5233	Bearing-Thrust	388-0578

Sales Model 637 (Cont'd.)

64M		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3839	Crankshaft As	398-2968
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357

64M		
Original Part Number	Part Name	Classic Part Number
2W-2621	Valve-Inlet	247-6892
2W-7213	Bearing-Sleeve	419-4667
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-7660	Cartridge Gp	422-8103
3G-7663	Cartridge Gp	422-8120
3H-8726	Mount As	385-7208
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334

64M		
Original Part Number	Part Name	Classic Part Number
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4F-2041	Cup-Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7731	Core Gp-O Clr	385-7228
4P-8915	Gasket-Cyl Head	377-5838
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-7188	Core As-Oclr	374-7501

Sales Model 637 (Cont'd.)

64M		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-7841	Gear-Ring	214-0525
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8789	Gasket Kt	393-3620
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9561	Gasket Kt-V G	437-8106
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247

64M		
Original Part Number	Part Name	Classic Part Number
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603

64M		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-7607	Gear-Dif Bevel	388-0595
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2476	Gear-Planet	223-4816
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993

Sales Model 637 (Cont'd.)

64M		
Original Part Number	Part Name	Classic Part Number
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
7W-5687	Hub-Cshft	314-8684
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-3442	Gear-Bevel	433-2026
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636

64M		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-7166	Housing-Screen	297-7192
8M-8652	Shaft	297-7252
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349

64M		
Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0611	Cage-Bearing	451-0748
8S-0905	Muffler As	302-2690
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-2389	Body-Fuel Valve	377-5831
8S-3517	Bearing-Spl Ball	417-4501
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372

Sales Model 637 (Cont'd.)

64M		
Original Part Number	Part Name	Classic Part Number
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8W-1708	Pin	388-0643
8W-8462	Joint Gp-Univ	421-7829
9B-1320	Valve-Check	377-5832
9C-3095	Spider Gp-Brg&	394-8219
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-9427	Bearing-Sleeve	361-1695
9M-3914	Bearing-Aligning	420-2501
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-1195	Pump As-Oil	390-1000

64M		
Original Part Number	Part Name	Classic Part Number
9S-5746	Ferrule-Seal	392-4493
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
101-1504	Shaft	373-5379
101-7517	Housing	391-1094
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
115-4072	Bearing	397-5069
131-3815	Seal Gp-Basic	325-6193
149-5985	Stator-Converter	419-1865
161-3411	Gasket	394-0896
162-3904	Pump As-F Prm	391-1102
163-1387	Gear-Flywheel	374-4697
164-4413	Mount	419-0876
169-4199	Gasket-Oil Pan	433-8194

64M		
Original Part Number	Part Name	Classic Part Number
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8795	Retainer	430-5355
229-1490	Sleeve-Injector	393-3659
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

65M		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978

Sales Model 637 (Cont'd.)

65M		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1033	Plate-Cl Backing	431-4136
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513

65M		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2H-9192	Bearing-Ball	394-8236
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

65M		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3839	Crankshaft As	398-2968
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-7660	Cartridge Gp	422-8103
3G-7663	Cartridge Gp	422-8120
3H-8726	Mount As	385-7208
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920

Sales Model 637 (Cont'd.)

65M		
Original Part Number	Part Name	Classic Part Number
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4F-2041	Cup-Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364

65M		
Original Part Number	Part Name	Classic Part Number
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7731	Core Gp-O Clr	385-7228
4P-8915	Gasket-Cyl Head	377-5838
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-0452	Seal As -Cshaft	325-6191
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-7841	Gear-Ring	214-0525

65M		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8789	Gasket Kt	393-3620
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rock-er Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

Sales Model 637 (Cont'd.)

65M		
Original Part Number	Part Name	Classic Part Number
6L-2279	Plug-Ptf	419-4739
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6Y-8675	Housing As	418-9584
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-7607	Gear-Dif Bevel	388-0595
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2476	Gear-Planet	223-4816
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374

65M		
Original Part Number	Part Name	Classic Part Number
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250

65M		
Original Part Number	Part Name	Classic Part Number
7W-5687	Hub-Cshft	314-8684
7W-9020	Bell As-Pump Suc	378-3989
8D-3442	Gear-Bevel	433-2026
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-7166	Housing-Screen	297-7192
8M-8652	Shaft	297-7252
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-4550	Shaft-Pulley	445-9247

Sales Model 637 (Cont'd.)

65M		
Original Part Number	Part Name	Classic Part Number
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0611	Cage-Bearing	451-0748
8S-0905	Muffler As	302-2690
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-2389	Body-Fuel Valve	377-5831
8S-3517	Bearing-Spl Ball	417-4501
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042

65M		
Original Part Number	Part Name	Classic Part Number
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8W-1708	Pin	388-0643
8W-8462	Joint Gp-Univ	421-7829
9B-1320	Valve-Check	377-5832
9C-3095	Spider Gp-Brg	394-8219
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-9427	Bearing-Sleeve	361-1695
9M-3914	Bearing-Aligning	420-2501
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994

65M		
Original Part Number	Part Name	Classic Part Number
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
101-1504	Shaft	373-5379
101-7517	Housing	391-1094
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
149-5985	Stator-Converter	419-1865
162-3904	Pump As-F Prm	391-1102
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8795	Retainer	430-5355
232-3233	Bearing-Main	376-9085

Sales Model 637 (Cont'd.)

65M		
Original Part Number	Part Name	Classic Part Number
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438

65M		
Original Part Number	Part Name	Classic Part Number
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

65M		
Original Part Number	Part Name	Classic Part Number
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

79P		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1033	Plate-Cl Backing	431-4136
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683

79P		
Original Part Number	Part Name	Classic Part Number
1T-2069	Carrier-Bearing	439-4543
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2H-9192	Bearing-Ball	394-8236

79P		
Original Part Number	Part Name	Classic Part Number
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3839	Crankshaft As	398-2968
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-3966	Ring-Seal	297-7237

Sales Model 637 (Cont'd.)

79P		
Original Part Number	Part Name	Classic Part Number
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3F-6185	Pin	295-5694
3G-7660	Cartridge Gp	422-8103
3G-7663	Cartridge Gp	422-8120
3H-8726	Mount As	385-7208
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-6559	Cap-Bearing	296-1346
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949

79P		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4F-2041	Cup-Roller Brg	418-9609
4J-2414	Trunnion	296-1370
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-7463	Seal-Lip Type	472-8007
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-7692	Crankshaft As	269-8764

79P		
Original Part Number	Part Name	Classic Part Number
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7731	Core Gp-O Clr	385-7228
4P-8915	Gasket-Cyl Head	377-5838
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-7841	Gear-Ring	214-0525

Sales Model 637 (Cont'd.)

79P		
Original Part Number	Part Name	Classic Part Number
5M-7925	Bearing-Roller	419-7774
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8789	Gasket Kt	393-3620
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475

79P		
Original Part Number	Part Name	Classic Part Number
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6Y-8675	Housing As	418-9584
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-7607	Gear-Dif Bevel	388-0595
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2476	Gear-Planet	223-4816
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132

79P		
Original Part Number	Part Name	Classic Part Number
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
7W-1927	Ring-Retainer	387-2935

Sales Model 637 (Cont'd.)

79P		
Original Part Number	Part Name	Classic Part Number
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
7W-5687	Hub-Cshft	314-8684
7W-9020	Bell As-Pump Suc	378-3989
8D-3442	Gear-Bevel	433-2026
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-7166	Housing-Screen	297-7192
8M-8652	Shaft	297-7252
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

79P		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0611	Cage-Bearing	451-0748
8S-0905	Muffler As	302-2690
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-2389	Body-Fuel Valve	377-5831
8S-3517	Bearing-Spl Ball	417-4501
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750

79P		
Original Part Number	Part Name	Classic Part Number
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8W-1708	Pin	388-0643
8W-8462	Joint Gp-Univ	421-7829
9B-1320	Valve-Check	377-5832
9C-3095	Spider Gp-Brg	394-8219
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-9427	Bearing-Sleeve	361-1695
9M-3914	Bearing-Aligning	420-2501
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-1195	Pump As-Oil	390-1000

Sales Model 637 (Cont'd.)

79P		
Original Part Number	Part Name	Classic Part Number
9S-5746	Ferrule-Seal	392-4493
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
101-1504	Shaft	373-5379
101-7517	Housing	391-1094

79P		
Original Part Number	Part Name	Classic Part Number
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
149-5985	Stator-Converter	419-1865
162-3904	Pump As-F Prm	391-1102
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314

79P		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8795	Retainer	430-5355
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

91N		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797

91N		
Original Part Number	Part Name	Classic Part Number
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1033	Plate-Cl Backing	431-4136
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683

91N		
Original Part Number	Part Name	Classic Part Number
1T-2069	Carrier-Bearing	439-4543
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417

Sales Model 637 (Cont'd.)

91N		
Original Part Number	Part Name	Classic Part Number
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2H-9192	Bearing-Ball	394-8236
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3839	Crankshaft As	398-2968

91N		
Original Part Number	Part Name	Classic Part Number
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7213	Bearing-Sleeve	419-4667
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3F-6185	Pin	295-5694
3G-7660	Cartridge Gp	422-8103
3G-7663	Cartridge Gp	422-8120
3H-8726	Mount As	385-7208
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-6559	Cap-Bearing	296-1346

91N		
Original Part Number	Part Name	Classic Part Number
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4F-2041	Cup-Roller Brg	418-9609
4J-2414	Trunnion	296-1370
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-7463	Seal-Lip Type	472-8007
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059

Sales Model 637 (Cont'd.)

91N		
Original Part Number	Part Name	Classic Part Number
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7731	Core Gp-O Clr	385-7228
4P-8915	Gasket-Cyl Head	377-5838
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-8361	Bearing-Sleeve	384-4775

91N		
Original Part Number	Part Name	Classic Part Number
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-7841	Gear-Ring	214-0525
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8789	Gasket Kt	393-3620
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9561	Gasket Kt-V G	437-8106
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rock-er Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535

91N		
Original Part Number	Part Name	Classic Part Number
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-7607	Gear-Dif Bevel	388-0595
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2476	Gear-Planet	223-4816

Sales Model 637 (Cont'd.)

91N		
Original Part Number	Part Name	Classic Part Number
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656

91N		
Original Part Number	Part Name	Classic Part Number
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
7W-5687	Hub-Cshft	314-8684
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-3442	Gear-Bevel	433-2026
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-7166	Housing-Screen	297-7192
8M-8652	Shaft	297-7252
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

91N		
Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198

Sales Model 637 (Cont'd.)

91N		
Original Part Number	Part Name	Classic Part Number
8S-0611	Cage-Bearing	451-0748
8S-0905	Muffler As	302-2690
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-2389	Body-Fuel Valve	377-5831
8S-3517	Bearing-Spl Ball	417-4501
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8W-1708	Pin	388-0643
8W-8462	Joint Gp-Univ	421-7829
9B-1320	Valve-Check	377-5832
9C-3095	Spider Gp-Brg&	394-8219
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-9427	Bearing-Sleeve	361-1695
9M-3914	Bearing-Aligning	420-2501

91N		
Original Part Number	Part Name	Classic Part Number
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
101-1504	Shaft	373-5379
101-7517	Housing	391-1094
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
115-4072	Bearing	397-5069
131-3815	Seal Gp-Basic	325-6193
149-5985	Stator-Converter	419-1865
161-3411	Gasket	394-0896
162-3904	Pump As-F Prm	391-1102

91N		
Original Part Number	Part Name	Classic Part Number
163-1387	Gear-Flywheel	374-4697
164-4413	Mount	419-0876
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8795	Retainer	430-5355
229-1490	Sleeve-Injector	393-3659
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858

Sales Model 637 (Cont'd.)

91N		
Original Part Number	Part Name	Classic Part Number
1P-4303	Head As-Cylinder	242-3434
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1033	Plate-Cl Backing	431-4136
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-5658	Bearing-Ball	301-4628

91N		
Original Part Number	Part Name	Classic Part Number
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2H-9192	Bearing-Ball	394-8236
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

91N		
Original Part Number	Part Name	Classic Part Number
2P-2719	Pipe-Oil Filler	363-7454
2P-3839	Crankshaft As	398-2968
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7213	Bearing-Sleeve	419-4667
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-7660	Cartridge Gp	422-8103
3G-7663	Cartridge Gp	422-8120
3H-8726	Mount As	385-7208
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920

Sales Model 637 (Cont'd.)

91N		
Original Part Number	Part Name	Classic Part Number
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4F-2041	Cup-Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364

91N		
Original Part Number	Part Name	Classic Part Number
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7731	Core Gp-O Clr	385-7228
4P-8915	Gasket-Cyl Head	377-5838
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509

91N		
Original Part Number	Part Name	Classic Part Number
5M-6126	Bearing	377-7433
5M-7841	Gear-Ring	214-0525
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8789	Gasket Kt	393-3620
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9561	Gasket Kt-V G	437-8106
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rock-er Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358

Sales Model 637 (Cont'd.)

91N		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-7607	Gear-Dif Bevel	388-0595
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-2476	Gear-Planet	223-4816
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210

91N		
Original Part Number	Part Name	Classic Part Number
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-8458	Bearing-Sleeve	380-7374
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296

91N		
Original Part Number	Part Name	Classic Part Number
7T-2336	Disc-Friction	433-7096
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
7W-5687	Hub-Cshft	314-8684
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-3442	Gear-Bevel	433-2026
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-7166	Housing-Screen	297-7192
8M-8652	Shaft	297-7252
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3312	Shaft As-Rkr Arm	325-6200

Sales Model 637 (Cont'd.)

91N		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0611	Cage-Bearing	451-0748
8S-0905	Muffler As	302-2690
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-2389	Body-Fuel Valve	377-5831
8S-3517	Bearing-Spl Ball	417-4501

91N		
Original Part Number	Part Name	Classic Part Number
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8W-1708	Pin	388-0643
8W-8462	Joint Gp-Univ	421-7829
9B-1320	Valve-Check	377-5832
9C-3095	Spider Gp-Brg&	394-8219
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-9427	Bearing-Sleeve	361-1695
9M-3914	Bearing-Aligning	420-2501
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558

91N		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
101-1504	Shaft	373-5379
101-7517	Housing	391-1094
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
115-4072	Bearing	397-5069
131-3815	Seal Gp-Basic	325-6193
149-5985	Stator-Converter	419-1865
161-3411	Gasket	394-0896
162-3904	Pump As-F Prm	391-1102
163-1387	Gear-Flywheel	374-4697
164-4413	Mount	419-0876
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001

Sales Model 637 (Cont'd.)

91N		
Original Part Number	Part Name	Classic Part Number
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259

91N		
Original Part Number	Part Name	Classic Part Number
196-0029	Gear As-Idler	374-4674
208-8795	Retainer	430-5355
229-1490	Sleeve-Injector	393-3659
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438

91N		
Original Part Number	Part Name	Classic Part Number
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

Sales Model 637B

26R		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1033	Plate-Cl Backing	431-4136
1T-1078	Bearing-Thrust	384-4802
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681

26R		
Original Part Number	Part Name	Classic Part Number
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2F-5721	Bearing-Ball	311-9354
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

26R		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983

Sales Model 637B (Cont'd.)

26R		
Original Part Number	Part Name	Classic Part Number
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3H-8726	Mount As	385-7208
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4E-0403	Gear-Planet	260-0781
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763

26R		
Original Part Number	Part Name	Classic Part Number
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-7841	Gear-Ring	214-0525
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9561	Gasket Kt-V G	437-8106
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789

26R		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-2279	Plug-Ptf	419-4739
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-6739	Shaft-Planet	308-9929
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-7780	Pin-Anchor	384-4825
7G-2476	Gear-Planet	223-4816
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816

Sales Model 637B (Cont'd.)

26R		
Original Part Number	Part Name	Classic Part Number
7N-0110	Core As-Oil Clr	319-3435
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-7166	Housing-Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

26R		
Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690

26R		
Original Part Number	Part Name	Classic Part Number
8S-2389	Body-Fuel Valve	377-5831
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8W-1708	Pin	388-0643
8W-8462	Joint Gp-Univ	421-7829
9B-1320	Valve-Check	377-5832
9C-3095	Spider Gp-Brg&	394-8219
9D-5444	Pin	380-7396
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042

Sales Model 637B (Cont'd.)

26R		
Original Part Number	Part Name	Classic Part Number
9V-7710	Univ Joint As	394-8234
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
101-1504	Shaft	373-5379
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
149-5985	Stator-Converter	419-1865
169-4199	Gasket-Oil Pan	433-8194

26R		
Original Part Number	Part Name	Classic Part Number
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

26R		
Original Part Number	Part Name	Classic Part Number
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420

Sales Model 637D

20W		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0589	Cup-Roller Brg	386-4942
1T-0660	Impeller-Conv	388-6595
1T-0737	Race-Spl Thrust	384-4798

20W		
Original Part Number	Part Name	Classic Part Number
1T-1033	Plate-Cl Backing	431-4136
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659

20W		
Original Part Number	Part Name	Classic Part Number
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6516	Bearing As-Rlr	435-2572
2J-1227	Retainer	440-0850
2K-5065	Cone-Roller Brg	416-2157
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

Sales Model 637D (Cont'd.)

20W		
Original Part Number	Part Name	Classic Part Number
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3D-9132	Cone-Roller Brg	453-3652

20W		
Original Part Number	Part Name	Classic Part Number
3D-9133	Cup-Roller Brg	418-9601
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3H-8726	Mount As	385-7208
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-4778	Roller As	394-2582
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236

20W		
Original Part Number	Part Name	Classic Part Number
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5367	Mount As	375-9986
4T-7640	Shaft As	393-3643
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509

Sales Model 637D (Cont'd.)

20W		
Original Part Number	Part Name	Classic Part Number
5M-6126	Bearing	377-7433
5M-7841	Gear-Ring	214-0525
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rock-er Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536

20W		
Original Part Number	Part Name	Classic Part Number
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6N-8992	Adapter-Fan	394-9810
6P-6739	Shaft-Planet	308-9929
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-7780	Pin-Anchor	384-4825
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780

20W		
Original Part Number	Part Name	Classic Part Number
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-0675	Core As-Oclr	434-4016
7W-1927	Ring-Retainer	387-2935
7W-4473	Manifold-Ex	443-2095
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115

Sales Model 637D (Cont'd.)

20W		
Original Part Number	Part Name	Classic Part Number
8L-8867	Pulley	434-1409
8M-7166	Housing-Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

20W		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8W-1708	Pin	388-0643
8W-8462	Joint Gp-Univ	421-7829
8X-6738	Shaft-Planet	394-8225
9B-1320	Valve-Check	377-5832
9C-3095	Spider Gp-Brg&	394-8219
9D-0120	Gear-Planet	288-8737
9D-4413	Shaft-Axle	421-7983
9D-5444	Pin	380-7396
9J-1140	Bushing	384-4782

20W		
Original Part Number	Part Name	Classic Part Number
9J-1141	Bushing	384-4783
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9L-5908	Gasket	433-8196
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-7710	Univ Joint As	394-8234
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
111-8015	Gasket As-Head	279-4977
115-4072	Bearing	397-5069
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
149-5985	Stator-Converter	419-1865
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
164-4413	Mount	419-0876
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

Sales Model 637D (Cont'd.)

20W		
Original Part Number	Part Name	Classic Part Number
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201

20W		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
174-6836	Gasket Kit - Tof	434-7280
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
221-6949	Kit-Dt Gasket	419-8663

20W		
Original Part Number	Part Name	Classic Part Number
229-1490	Sleeve-Injector	393-3659
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420

21W		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0589	Cup-Roller Brg	386-4942
1T-0660	Impeller-Conv	388-6595
1T-0737	Race-Spl Thrust	384-4798

21W		
Original Part Number	Part Name	Classic Part Number
1T-1033	Plate-Cl Backing	431-4136
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659

21W		
Original Part Number	Part Name	Classic Part Number
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6516	Bearing As-Rlr	435-2572
2J-1227	Retainer	440-0850
2K-5065	Cone-Roller Brg	416-2157
2P-0220	Gasket-Pump	398-2927

Sales Model 637D (Cont'd.)

21W		
Original Part Number	Part Name	Classic Part Number
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983

21W		
Original Part Number	Part Name	Classic Part Number
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3H-8726	Mount As	385-7208
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-4778	Roller As	394-2582
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-7693	Crankshaft As	269-8763

21W		
Original Part Number	Part Name	Classic Part Number
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5367	Mount As	375-9986
4T-7640	Shaft As	393-3643
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209

Sales Model 637D (Cont'd.)

21W		
Original Part Number	Part Name	Classic Part Number
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-7841	Gear-Ring	214-0525
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

21W		
Original Part Number	Part Name	Classic Part Number
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6N-8992	Adapter-Fan	394-9810
6P-6739	Shaft-Planet	308-9929
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-7780	Pin-Anchor	384-4825
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173

21W		
Original Part Number	Part Name	Classic Part Number
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-0675	Core As-Oclr	434-4016
7W-1927	Ring-Retainer	387-2935
7W-4473	Manifold-Ex	443-2095
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512

Sales Model 637D (Cont'd.)

21W		
Original Part Number	Part Name	Classic Part Number
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8L-8867	Pulley	434-1409
8M-7166	Housing-Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585

21W		
Original Part Number	Part Name	Classic Part Number
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8W-1708	Pin	388-0643
8W-8462	Joint Gp-Univ	421-7829
8X-6738	Shaft-Planet	394-8225
9B-1320	Valve-Check	377-5832
9C-3095	Spider Gp-Brg&	394-8219

21W		
Original Part Number	Part Name	Classic Part Number
9D-0120	Gear-Planet	288-8737
9D-4413	Shaft-Axle	421-7983
9D-5444	Pin	380-7396
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9L-5908	Gasket	433-8196
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-7710	Univ Joint As	394-8234
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
111-8015	Gasket As-Head	279-4977
115-4072	Bearing	397-5069
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
149-5985	Stator-Converter	419-1865
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
164-4413	Mount	419-0876
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351

Sales Model 637D (Cont'd.)

21W		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811

21W		
Original Part Number	Part Name	Classic Part Number
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
174-6836	Gasket Kit - Tof	434-7280
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

21W		
Original Part Number	Part Name	Classic Part Number
221-6949	Kit-Dt Gasket	419-8663
229-1490	Sleeve-Injector	393-3659
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420

22W		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0589	Cup-Roller Brg	386-4942
1T-0660	Impeller-Conv	388-6595

22W		
Original Part Number	Part Name	Classic Part Number
1T-0737	Race-Spl Thrust	384-4798
1T-1033	Plate-Cl Backing	431-4136
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

22W		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6516	Bearing As-Rlr	435-2572

Sales Model 637D (Cont'd.)

22W		
Original Part Number	Part Name	Classic Part Number
2J-1227	Retainer	440-0850
2K-5065	Cone-Roller Brg	416-2157
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667

22W		
Original Part Number	Part Name	Classic Part Number
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3H-8726	Mount As	385-7208
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-4778	Roller As	394-2582
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363

22W		
Original Part Number	Part Name	Classic Part Number
4N-3283	Line As-Fuel Inj	247-3364
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5367	Mount As	375-9986
4T-7640	Shaft As	393-3643
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925

Sales Model 637D (Cont'd.)

22W		
Original Part Number	Part Name	Classic Part Number
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-7841	Gear-Ring	214-0525
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273

22W		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6N-8992	Adapter-Fan	394-9810
6P-6739	Shaft-Planet	308-9929
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-7780	Pin-Anchor	384-4825
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951

22W		
Original Part Number	Part Name	Classic Part Number
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-0675	Core As-Oclr	434-4016
7W-1927	Ring-Retainer	387-2935
7W-4473	Manifold-Ex	443-2095
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989

Sales Model 637D (Cont'd.)

22W		
Original Part Number	Part Name	Classic Part Number
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8L-8867	Pulley	434-1409
8M-7166	Housing-Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290

22W		
Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8W-1708	Pin	388-0643
8W-8462	Joint Gp-Univ	421-7829

22W		
Original Part Number	Part Name	Classic Part Number
8X-6738	Shaft-Planet	394-8225
9B-1320	Valve-Check	377-5832
9C-3095	Spider Gp-Brg&	394-8219
9D-0120	Gear-Planet	288-8737
9D-4413	Shaft-Axle	421-7983
9D-5444	Pin	380-7396
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9L-5908	Gasket	433-8196
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-7710	Univ Joint As	394-8234
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
111-8015	Gasket As-Head	279-4977
115-4072	Bearing	397-5069
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
149-5985	Stator-Converter	419-1865
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697

Sales Model 637D (Cont'd.)

22W		
Original Part Number	Part Name	Classic Part Number
164-4413	Mount	419-0876
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835

22W		
Original Part Number	Part Name	Classic Part Number
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
174-6836	Gasket Kit - Tof	434-7280
196-0028	Gear As-Idler	364-5259

22W		
Original Part Number	Part Name	Classic Part Number
196-0029	Gear As-Idler	374-4674
221-6949	Kit-Dt Gasket	419-8663
229-1490	Sleeve-Injector	393-3659
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420

23W		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572

23W		
Original Part Number	Part Name	Classic Part Number
1T-0589	Cup-Roller Brg	386-4942
1T-0660	Impeller-Conv	388-6595
1T-0737	Race-Spl Thrust	384-4798
1T-1033	Plate-Cl Backing	431-4136
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-1219	Trunnion As	314-8724

23W		
Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

Sales Model 637D (Cont'd.)

23W		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6516	Bearing As-Rlr	435-2572
2J-1227	Retainer	440-0850
2K-5065	Cone-Roller Brg	416-2157
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794

23W		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3H-8726	Mount As	385-7208
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-4778	Roller As	394-2582
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915

23W		
Original Part Number	Part Name	Classic Part Number
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5367	Mount As	375-9986
4T-7640	Shaft As	393-3643
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

Sales Model 637D (Cont'd.)

23W		
Original Part Number	Part Name	Classic Part Number
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-7841	Gear-Ring	214-0525
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395

23W		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6N-8992	Adapter-Fan	394-9810
6P-6739	Shaft-Planet	308-9929
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-7780	Pin-Anchor	384-4825
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132

23W		
Original Part Number	Part Name	Classic Part Number
7J-4983	Cap-Bearing	384-3460
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351

Sales Model 637D (Cont'd.)

23W		
Original Part Number	Part Name	Classic Part Number
7W-0675	Core As-Oclr	434-4016
7W-1927	Ring-Retainer	387-2935
7W-4473	Manifold-Ex	443-2095
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8L-8867	Pulley	434-1409
8M-7166	Housing-Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

23W		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372

23W		
Original Part Number	Part Name	Classic Part Number
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8W-1708	Pin	388-0643
8W-8462	Joint Gp-Univ	421-7829
8X-6738	Shaft-Planet	394-8225
9B-1320	Valve-Check	377-5832
9C-3095	Spider Gp-Brg&	394-8219
9D-0120	Gear-Planet	288-8737
9D-4413	Shaft-Axle	421-7983
9D-5444	Pin	380-7396
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9L-5908	Gasket	433-8196
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-7710	Univ Joint As	394-8234
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
111-8015	Gasket As-Head	279-4977
115-4072	Bearing	397-5069

Sales Model 637D (Cont'd.)

23W		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
149-5985	Stator-Converter	419-1865
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
164-4413	Mount	419-0876
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194

23W		
Original Part Number	Part Name	Classic Part Number
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314

23W		
Original Part Number	Part Name	Classic Part Number
174-6836	Gasket Kit - Tof	434-7280
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
221-6949	Kit-Dt Gasket	419-8663
229-1490	Sleeve-Injector	393-3659
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420

26W		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797

26W		
Original Part Number	Part Name	Classic Part Number
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-5009	Crankshaft As	398-2969

26W		
Original Part Number	Part Name	Classic Part Number
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709

Sales Model 637D (Cont'd.)

26W		
Original Part Number	Part Name	Classic Part Number
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-8986	Cup-Rlr Bearing	415-1912
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-4087	Gear As-Idler	418-9582
2W-6280	Bracket As-Fan	431-5271
2W-7980	Camshaft As	378-3972
2W-8038	Gear-Camshaft	425-7751
3D-9132	Cone-Roller Brg	453-3652

26W		
Original Part Number	Part Name	Classic Part Number
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3H-8726	Mount As	385-7208
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473

26W		
Original Part Number	Part Name	Classic Part Number
4N-1119	Gear-Tfr Pump	373-1884
4N-1186	Bearing-Sleeve	417-4519
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-1849	Pipe-Air	421-7143
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318

Sales Model 637D (Cont'd.)

26W		
Original Part Number	Part Name	Classic Part Number
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5F-2830	Bearing-Needle	384-5925
5F-7404	Nut-Bearing Lock	308-9878
5J-6430	Bearing-Sleeve	379-0195
5L-6326	Bearing-Ball	420-3222
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9841	Gasket Kit - Vg	393-3626
5P-9962	Bearing-Aligning	399-4397
5P-9972	Gasket Kit	393-5207
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395

26W		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1032	Line As-Fuel Inj	390-0931
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922
6I-1038	Line As-Fuel Inj	390-0923
6I-3907	Adapter-Pilot	398-8348
6I-4613	Plate-Spacer	380-7405
6N-0425	Coupling-Exhaust	394-9836

26W		
Original Part Number	Part Name	Classic Part Number
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-4597	Coupling-Exhaust	369-9489
6N-5300	Pulley-Cshaft	378-3979
6N-5354	Pipe-Extension	430-8130
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-7706	Carrier-Ring	388-6603
6V-0220	Kit-Gasket(Cl)	437-4588
6V-0241	Gasket Kit - F	393-3628
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
6V-5920	Gasket Kit - F	388-0653
6Y-2065	Mount As-650 Cup	377-5844
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7C-5665	Elbow-90 Deg	399-8547

Sales Model 637D (Cont'd.)

26W		
Original Part Number	Part Name	Classic Part Number
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-3909	Tube-Exhaust	398-8339
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7H-7628	Bearing	453-3655
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5218	Manifold-Exhaust	435-4786
7N-5219	Manifold-Exhaust	425-2362
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893

26W		
Original Part Number	Part Name	Classic Part Number
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-6459	Core As-Oclr	395-1313
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8M-0874	Plunger As-Valve	311-9439
8M-8652	Shaft	297-7252
8N-0111	Mount As	374-1452
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0784	Manifold-Mount	393-1044
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8N-7486	Condenser As	436-2263

26W		
Original Part Number	Part Name	Classic Part Number
8N-8983	Hub-Fan Pulley	421-7227
8P-4520	Piston-Clutch	394-0908
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8W-0376	Shaft	394-9194
8X-6738	Shaft-Planet	394-8225
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1187	Bearing-Sleeve	384-4785
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9M-3914	Bearing-Aligning	420-2501
9N-1161	Line As-Fuel Inj	383-3705
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005

Sales Model 637D (Cont'd.)

26W		
Original Part Number	Part Name	Classic Part Number
9N-5529	Body-F Inj Valve	378-3993
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9T-7414	Pump Gp-Gr B	421-1564
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3125	Gasket	420-8567
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487

26W		
Original Part Number	Part Name	Classic Part Number
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-2255	Gear-Bevel	446-3076
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-4525	Gage As	386-3043
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

26W		
Original Part Number	Part Name	Classic Part Number
133-4995	Gasket-Cyl Head	434-2445
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-9381	Plate-Spacer	424-7052
141-4109	Core As-Oclr	416-5518
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kit	380-1554
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6048	Kit-Dt Gasket	434-7272
155-6637	Gear-Oil Drive	425-9189
155-6648	Cone Spl Rol Brg	418-9599
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-4109	Manifold-Exhaust	433-9857
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
170-8541	Core As-Rdtr	379-0180
171-6696	Diaphragm	384-4811
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605

Sales Model 637D (Cont'd.)

26W		
Original Part Number	Part Name	Classic Part Number
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0586	Bearing-Rod	419-7266

26W		
Original Part Number	Part Name	Classic Part Number
217-8938	Tightening-Belt	419-4735
232-1841	Kit-Gasket (Fs)	387-2922
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
272-1956	Gasket	419-4710
278-1365	Arm As-Ui Rkr	433-7507
283-5666	Gasket-Cyl Head	388-6565

26W		
Original Part Number	Part Name	Classic Part Number
307-1303	Muffler As.	361-6574
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

27W		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-5009	Crankshaft As	398-2969

27W		
Original Part Number	Part Name	Classic Part Number
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354

27W		
Original Part Number	Part Name	Classic Part Number
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-8986	Cup-Rlr Bearing	415-1912
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-4087	Gear As-Idler	418-9582

Sales Model 637D (Cont'd.)

27W		
Original Part Number	Part Name	Classic Part Number
2W-6280	Bracket As-Fan	431-5271
2W-7980	Camshaft As	378-3972
2W-8038	Gear-Camshaft	425-7751
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3H-8726	Mount As	385-7208
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4B-1455	Cap As-Filler	361-1719
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191

27W		
Original Part Number	Part Name	Classic Part Number
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1186	Bearing-Sleeve	417-4519
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-1849	Pipe-Air	421-7143
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4T-7819	Cyl Gp-051 127 Y	426-0028
4T-8054	Seal As	472-8010

27W		
Original Part Number	Part Name	Classic Part Number
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5F-2830	Bearing-Needle	384-5925
5F-7404	Nut-Bearing Lock	308-9878
5J-6430	Bearing-Sleeve	379-0195
5L-6326	Bearing-Ball	420-3222
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9841	Gasket Kit - Vg	393-3626
5P-9962	Bearing-Aligning	399-4397
5P-9972	Gasket Kit	393-5207

Sales Model 637D (Cont'd.)

27W		
Original Part Number	Part Name	Classic Part Number
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1032	Line As-Fuel Inj	390-0931

27W		
Original Part Number	Part Name	Classic Part Number
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922
6I-1038	Line As-Fuel Inj	390-0923
6I-3907	Adapter-Pilot	398-8348
6I-4613	Plate-Spacer	380-7405
6N-0425	Coupling-Exhaust	394-9836
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-4597	Coupling-Exhaust	369-9489
6N-5300	Pulley-Cshaft	378-3979
6N-5354	Pipe-Extension	430-8130
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-7706	Carrier-Ring	388-6603
6V-0220	Kit-Gasket(CI)	437-4588
6V-0241	Gasket Kit - F	393-3628
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
6V-5920	Gasket Kit - F	388-0653
6Y-2065	Mount As-650 Cup	377-5844

27W		
Original Part Number	Part Name	Classic Part Number
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7C-5665	Elbow-90 Deg	399-8547
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-3909	Tube-Exhaust	398-8339
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5218	Manifold-Exhaust	435-4786
7N-5219	Manifold-Exhaust	425-2362
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401

Sales Model 637D (Cont'd.)

27W		
Original Part Number	Part Name	Classic Part Number
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-6459	Core As-Oclr	395-1313
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8M-0874	Plunger As-Valve	311-9439
8M-8652	Shaft	297-7252
8N-0111	Mount As	374-1452
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886

27W		
Original Part Number	Part Name	Classic Part Number
8N-0784	Manifold-Mount	393-1044
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-4520	Piston-Clutch	394-0908
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8W-0376	Shaft	394-9194
8X-6738	Shaft-Planet	394-8225
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1187	Bearing-Sleeve	384-4785

27W		
Original Part Number	Part Name	Classic Part Number
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9M-3914	Bearing-Aligning	420-2501
9N-1161	Line As-Fuel Inj	383-3705
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9N-5529	Body-F Inj Valve	378-3993
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-7414	Pump Gp-Gr B	421-1564
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984

Sales Model 637D (Cont'd.)

27W		
Original Part Number	Part Name	Classic Part Number
101-3125	Gasket	420-8567
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-2255	Gear-Bevel	446-3076
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-4525	Gage As	386-3043
127-6356	Cover As.-Pump	420-8566

27W		
Original Part Number	Part Name	Classic Part Number
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-4995	Gasket-Cyl Head	434-2445
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-9381	Plate-Spacer	424-7052
141-4109	Core As-Oclr	416-5518
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6048	Kit-Dt Gasket	434-7272
155-6637	Gear-Oil Drive	425-9189
155-6648	Cone Spl Rol Brg	418-9599
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048

27W		
Original Part Number	Part Name	Classic Part Number
162-0152	Bearing-Sleeve	422-9519
163-4109	Manifold-Exhaust	433-9857
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
170-8541	Core As-Rdtr	379-0180
171-6696	Diaphragm	384-4811
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
226-8202	Seal-Wiper	472-8024
232-1841	Kit-Gasket (Fs)	387-2922
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
272-1956	Gasket	419-4710
278-1365	Arm As-Ui Rkr	433-7507
283-5666	Gasket-Cyl Head	388-6565
307-1303	Muffler As.	361-6574
321-5746	Bearing-Main	419-6367

Sales Model 637D (Cont'd.)

27W		
Original Part Number	Part Name	Classic Part Number
328-4240	Arm As-V Rocker	433-0443
328-5574	Bearing-Rod	419-7266

27W		
Original Part Number	Part Name	Classic Part Number
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490

27W		
Original Part Number	Part Name	Classic Part Number
368-0297	Plate-Clutch	377-7420

4JB		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0589	Cup-Roller Brg	386-4942
1T-0660	Impeller-Conv	388-6595
1T-0737	Race-Spl Thrust	384-4798
1T-1033	Plate-Cl Backing	431-4136
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659

4JB		
Original Part Number	Part Name	Classic Part Number
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6516	Bearing As-Rlr	435-2572
2J-1227	Retainer	440-0850
2K-5065	Cone-Roller Brg	416-2157
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454

4JB		
Original Part Number	Part Name	Classic Part Number
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3H-8726	Mount As	385-7208
3J-2333	Bearing-Sleeve	422-9525

Sales Model 637D (Cont'd.)

4JB		
Original Part Number	Part Name	Classic Part Number
3J-2373	Bearing-Sleeve	380-7562
3J-4778	Roller As	394-2582
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5367	Mount As	375-9986
4T-7640	Shaft As	393-3643
4W-0452	Seal As -Cshaft	325-6191

4JB		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-7841	Gear-Ring	214-0525
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579

4JB		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-6739	Shaft-Planet	308-9929
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-7780	Pin-Anchor	384-4825
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435

Sales Model 637D (Cont'd.)

4JB		
Original Part Number	Part Name	Classic Part Number
7N-1152	Pulley-Fan	333-4951
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-0675	Core As-Oclr	434-4016
7W-1927	Ring-Retainer	387-2935
7W-4473	Manifold-Ex	443-2095
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8L-8867	Pulley	434-1409

4JB		
Original Part Number	Part Name	Classic Part Number
8M-7166	Housing-Screen	297-7192
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

4JB		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8W-1708	Pin	388-0643
8W-8462	Joint Gp-Univ	421-7829
8X-6738	Shaft-Planet	394-8225
9C-3095	Spider Gp-Brg&	394-8219
9D-0120	Gear-Planet	288-8737
9D-4413	Shaft-Axle	421-7983
9D-5444	Pin	380-7396
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9L-5908	Gasket	433-8196
9M-5477	Bearing-Sleeve	374-6517

Sales Model 637D (Cont'd.)

4JB		
Original Part Number	Part Name	Classic Part Number
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-7710	Univ Joint As	394-8234
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
111-8015	Gasket As-Head	279-4977
115-4072	Bearing	397-5069
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
149-5985	Stator-Converter	419-1865
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
164-4413	Mount	419-0876
164-6560	Body As-Piston	477-7125

4JB		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0564	Rebuild Kit-Pump	380-7576
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

4JB		
Original Part Number	Part Name	Classic Part Number
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
221-6949	Kit-Dt Gasket	419-8663
229-1490	Sleeve-Injector	393-3659
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420

60X		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572

60X		
Original Part Number	Part Name	Classic Part Number
1T-0589	Cup-Roller Brg	386-4942
1T-0660	Impeller-Conv	388-6595
1T-0737	Race-Spl Thrust	384-4798
1T-1033	Plate-Cl Backing	431-4136

60X		
Original Part Number	Part Name	Classic Part Number
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158

Sales Model 637D (Cont'd.)

60X		
Original Part Number	Part Name	Classic Part Number
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6516	Bearing As-Rlr	435-2572
2K-5065	Cone-Roller Brg	416-2157
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454

60X		
Original Part Number	Part Name	Classic Part Number
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059

60X		
Original Part Number	Part Name	Classic Part Number
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5367	Mount As	375-9986
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925

Sales Model 637D (Cont'd.)

60X		
Original Part Number	Part Name	Classic Part Number
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-7841	Gear-Ring	214-0525
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886

60X		
Original Part Number	Part Name	Classic Part Number
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6N-8992	Adapter-Fan	394-9810
6P-6739	Shaft-Planet	308-9929
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-7780	Pin-Anchor	384-4825
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496

60X		
Original Part Number	Part Name	Classic Part Number
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8M-7166	Housing-Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

Sales Model 637D (Cont'd.)

60X		
Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831

60X		
Original Part Number	Part Name	Classic Part Number
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8W-8462	Joint Gp-Univ	421-7829
8X-6738	Shaft-Planet	394-8225
9B-1320	Valve-Check	377-5832
9C-3095	Spider Gp-Brg&	394-8219
9D-0120	Gear-Planet	288-8737
9D-4413	Shaft-Axle	421-7983
9D-5444	Pin	380-7396
9L-5908	Gasket	433-8196
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-7710	Univ Joint As	394-8234
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
111-8015	Gasket As-Head	279-4977

60X		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
149-5985	Stator-Converter	419-1865
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259

Sales Model 637D (Cont'd.)

60X		
Original Part Number	Part Name	Classic Part Number
196-0029	Gear As-Idler	374-4674
221-6949	Kit-Dt Gasket	419-8663
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351

60X		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349

60X		
Original Part Number	Part Name	Classic Part Number
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420

70W		
Original Part Number	Part Name	Classic Part Number
1P-7115	Mount As	418-1936
2A-4429	Lock-Retainer	379-0174
2W-7213	Bearing-Sleeve	419-4667
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-7188	Core As-Oclr	374-7501

70W		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
6G-0078	Breather	435-4789
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
7J-4982	Bearing	383-2132
115-4072	Bearing	397-5069

70W		
Original Part Number	Part Name	Classic Part Number
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
164-4413	Mount	419-0876
221-6949	Kit-Dt Gasket	419-8663
229-1490	Sleeve-Injector	393-3659

71W		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163

71W		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2W-6280	Bracket As-Fan	431-5271
3E-6772	Seal-Water	382-8017
3K-0526	Bearing-Ball	386-4949
3S-1292	Bearing-Sleeve	425-8226
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812

71W		
Original Part Number	Part Name	Classic Part Number
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5S-4442	Bearing-Spl Ball	419-6025
6G-0078	Breather	435-4789

Sales Model 637D (Cont'd.)

71W		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4534	Bearing-Caged	417-9497
7W-6459	Core As-Oclr	395-1313
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-0111	Mount As	374-1452
8N-2104	Bell As-Suction	380-1521
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227

71W		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-4995	Gasket-Cyl Head	434-2445
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052

71W		
Original Part Number	Part Name	Classic Part Number
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
177-7886	Cone	418-9605
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
272-1956	Gasket	419-4710
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443

Sales Model 637E

1FB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849

Sales Model 637E (Cont'd.)

1FB		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3300	Shield As	374-4702
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7936	Spider As-Fan	383-3673
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0589	Cup-Roller Brg	386-4942
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0737	Race-Spl Thrust	384-4798
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1033	Plate-Cl Backing	431-4136
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924

1FB		
Original Part Number	Part Name	Classic Part Number
1T-1282	Race-Brg Thrust	373-1755
1T-1348	Support As-Carr	419-4049
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-5009	Crankshaft As	398-2969
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9490	Pulley-Alt	394-0885
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914

1FB		
Original Part Number	Part Name	Classic Part Number
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2K-5065	Cone-Roller Brg	416-2157
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872

Sales Model 637E (Cont'd.)

1FB		
Original Part Number	Part Name	Classic Part Number
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-4087	Gear As-Idler	418-9582
2W-5539	Core As-Rad	374-7492
2W-6280	Bracket As-Fan	431-5271
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-7774	Ejector As-Exh	393-0914
2W-7980	Camshaft As	378-3972
2W-8038	Gear-Camshaft	425-7751
2W-8437	Muffler As	385-7198
2W-9978	Core As-Oclr	279-4983
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694

1FB		
Original Part Number	Part Name	Classic Part Number
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609

1FB		
Original Part Number	Part Name	Classic Part Number
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1186	Bearing-Sleeve	417-4519
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4N-7693	Crankshaft As	269-8763
4P-2383	Adapter-Inlet	438-1812
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008

Sales Model 637E (Cont'd.)

1FB		
Original Part Number	Part Name	Classic Part Number
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5367	Mount As	375-9986
4T-7640	Shaft As	393-3643
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501

1FB		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5F-7404	Nut-Bearing Lock	308-9878
5J-6430	Bearing-Sleeve	379-0195
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-4557	Bearing	311-9360

1FB		
Original Part Number	Part Name	Classic Part Number
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716

Sales Model 637E (Cont'd.)

1FB		
Original Part Number	Part Name	Classic Part Number
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-3907	Adapter-Pilot	398-8348
6I-4613	Plate-Spacer	380-7405
6K-4442	Rod End-Special	373-5388
6N-0977	Bearing-Sleeve	417-4524
6N-1036	Gear-Oil Pump	279-4991
6N-1931	Plunger	379-0171
6N-2789	Pulley	264-5886
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-8992	Adapter-Fan	394-9810
6N-9133	Gasket-Plate	398-2959
6P-2090	Base-Xmsn O Fil	397-5049
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117

1FB		
Original Part Number	Part Name	Classic Part Number
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
6V-5920	Gasket Kit - F	388-0653
6Y-1320	Plate-Clutch	384-5935
6Y-2065	Mount As-650 Cup	377-5844
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369

1FB		
Original Part Number	Part Name	Classic Part Number
7J-3216	Bearing	368-0104
7J-3351	Head	380-1515
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4983	Cap-Bearing	384-3460
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8629	Coupling-Elbow	419-4664
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961

Sales Model 637E (Cont'd.)

1FB		
Original Part Number	Part Name	Classic Part Number
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0182	Plunger & Bbl As	391-9893
7W-0508	Gear-Fp Drive	296-1351
7W-0561	Pump Gp-F Inj -B	432-8278
7W-0675	Core As-Oclr	434-4016
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-4473	Manifold-Ex	443-2095
7W-5435	Adapter-Nozzle	374-7493
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-6459	Core As-Oclr	395-1313
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-0580	Gasket Kit - T	393-1023
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512

1FB		
Original Part Number	Part Name	Classic Part Number
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8L-8867	Pulley	434-1409
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-7166	Housing-Screen	297-7192
8N-0081	Trunnion	393-5196
8N-0111	Mount As	374-1452
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726
8N-1628	Shaft As-F Pump	383-3703
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562

1FB		
Original Part Number	Part Name	Classic Part Number
8N-2368	Shield As	449-9547
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7257	Mount As	396-0660
8N-7315	Tube As-Outlet	325-6232
8N-7486	Condenser As	436-2263
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081

Sales Model 637E (Cont'd.)

1FB		
Original Part Number	Part Name	Classic Part Number
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8983	Hub-Fan Pulley	421-7227
8P-2051	Plate-Clutch	385-6116
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8T-1643	Kit-Dt Gasket	388-6575
8T-6487	Kit-Gasket-Sch	436-8384
8W-0376	Shaft	394-9194
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
8W-3881	Bearing	394-8224
8W-8462	Joint Gp-Univ	421-7829
8X-6738	Shaft-Planet	394-8225
9C-3095	Spider Gp-Brg	394-8219

1FB		
Original Part Number	Part Name	Classic Part Number
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-4413	Shaft-Axle	421-7983
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9L-5908	Gasket	433-8196
9L-5961	Adapter-Compr Dr	416-5508
9M-1990	Dowel-Reaction	386-4963
9M-3914	Bearing-Aligning	420-2501
9M-5477	Bearing-Sleeve	374-6517
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005

1FB		
Original Part Number	Part Name	Classic Part Number
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9T-7414	Pump Gp-Gr B	421-1564
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
100-7860	Valve-Inlet	270-4360

Sales Model 637E (Cont'd.)

1FB		
Original Part Number	Part Name	Classic Part Number
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3125	Gasket	420-8567
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
102-8636	Gear-Drive	472-8035
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
111-8015	Gasket As-Head	279-4977
112-2255	Gear-Bevel	446-3076
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
114-0915	Shield As.	394-0887
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645

1FB		
Original Part Number	Part Name	Classic Part Number
117-0019	Disc-Friction	417-9492
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
126-5057	Shield As-Man Lh	369-9493
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-2707	Kit-Gasket (Bsc)	392-4506
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813

1FB		
Original Part Number	Part Name	Classic Part Number
136-7813	Bearing-Race	460-8296
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-9381	Plate-Spacer	424-7052
140-2749	Gasket Kit	393-1033
141-1936	Kit-Gasket(F)	437-4614
141-1939	Gasket Kit	437-4613
141-1942	Gasket Kit	437-4612
141-4109	Core As-Oclr	416-5518
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
148-7455	Valve - Exhaust	270-4361
149-5985	Stator-Converter	419-1865
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6637	Gear-Oil Drive	425-9189
156-8578	Shaft	417-9490
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
163-4109	Manifold-Exhaust	433-9857
164-6560	Body As-Piston	477-7125

Sales Model 637E (Cont'd.)

1FB		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
166-6352	Tube As.	432-4223
167-8123	Damper As	299-2006
167-8126	Damper As	382-8019
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698

1FB		
Original Part Number	Part Name	Classic Part Number
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-1304	Kit-Dt Gasket	394-8231
213-1305	Kit-Dt Gasket	394-8230
216-5582	Bearing-Sleeve	390-0914
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
232-2672	Kit-Gasket-Fs	393-0922
232-3233	Bearing-Main	376-9085
233-8683	Kit-Gasket-Mch	393-1039
237-2859	Bearing-Rlr	368-0125

1FB		
Original Part Number	Part Name	Classic Part Number
246-3130	Shaft-Water Pump	392-4508
250-6558	Liner Kit-Cla	295-6438
253-1752	Plate-Thrust	379-0170
257-0424	Shaft	421-8170
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
278-1365	Arm As-Ui Rkr	433-7507
283-5666	Gasket-Cyl Head	388-6565
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-6870	Kit-Dt Gasket	451-1510
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-5572	Bearing-Rod	419-6349
328-5574	Bearing-Rod	419-7266
334-8389	Crankshaft As	242-3439
352-0200	Pump Gp-Water -B	434-6109
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

1HB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437

1HB		
Original Part Number	Part Name	Classic Part Number
1B-3980	Cone-Roller Brg	399-4443
1H-5338	Cup-Roller Brg	374-8345

1HB		
Original Part Number	Part Name	Classic Part Number
1N-3300	Shield As	374-4702
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913

Sales Model 637E (Cont'd.)

1HB		
Original Part Number	Part Name	Classic Part Number
1P-7115	Mount As	418-1936
1P-7936	Spider As-Fan	383-3673
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0589	Cup-Roller Brg	386-4942
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0737	Race-Spl Thrust	384-4798
1T-1033	Plate-Cl Backing	431-4136
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5009	Crankshaft As	398-2969
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705

1HB		
Original Part Number	Part Name	Classic Part Number
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9490	Pulley-Alt	394-0885
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-6516	Bearing As-Rlr	435-2572
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2K-5065	Cone-Roller Brg	416-2157
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

1HB		
Original Part Number	Part Name	Classic Part Number
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-4087	Gear As-Idler	418-9582
2W-5539	Core As-Rad	374-7492
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203

Sales Model 637E (Cont'd.)

1HB		
Original Part Number	Part Name	Classic Part Number
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-7774	Ejector As-Exh	393-0914
2W-7980	Camshaft As	378-3972
2W-8437	Muffler As	385-7198
2W-9978	Core As-Oclr	279-4983
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-7489	Plate-Clutch	377-7423
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494

1HB		
Original Part Number	Part Name	Classic Part Number
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

1HB		
Original Part Number	Part Name	Classic Part Number
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-5367	Mount As	375-9986
4T-7640	Shaft As	393-3643
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975

Sales Model 637E (Cont'd.)

1HB		
Original Part Number	Part Name	Classic Part Number
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-6430	Bearing-Sleeve	379-0195
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467

1HB		
Original Part Number	Part Name	Classic Part Number
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rock-er Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262

1HB		
Original Part Number	Part Name	Classic Part Number
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-4613	Plate-Spacer	380-7405
6K-4442	Rod End-Special	373-5388
6L-7751	Rod End-Spher	472-8015
6N-0977	Bearing-Sleeve	417-4524
6N-1036	Gear-Oil Pump	279-4991
6N-1931	Plunger	379-0171
6N-2789	Pulley	264-5886
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-8992	Adapter-Fan	394-9810
6N-9133	Gasket-Plate	398-2959
6P-6739	Shaft-Planet	308-9929

Sales Model 637E (Cont'd.)

1HB		
Original Part Number	Part Name	Classic Part Number
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-1320	Plate-Clutch	384-5935
6Y-2065	Mount As-650 Cup	377-5844
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7D-7607	Gear-Dif Bevel	388-0595
7E-0853	Muffler As	360-7887
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-9980	Camshaft	377-5851
7F-7780	Pin-Anchor	384-4825
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4983	Cap-Bearing	384-3460

1HB		
Original Part Number	Part Name	Classic Part Number
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8629	Coupling-Elbow	419-4664
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-0508	Gear-Fp Drive	296-1351

1HB		
Original Part Number	Part Name	Classic Part Number
7W-0561	Pump Gp-F Inj -B	432-8278
7W-0675	Core As-Oclr	434-4016
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-4473	Manifold-Ex	443-2095
7W-5435	Adapter-Nozzle	374-7493
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-6459	Core As-Oclr	395-1313
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8L-8867	Pulley	434-1409
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-7166	Housing-Screen	297-7192
8N-0081	Trunnion	393-5196
8N-0111	Mount As	374-1452
8N-0560	Gear-O Pump Dr	378-3990

Sales Model 637E (Cont'd.)

1HB		
Original Part Number	Part Name	Classic Part Number
8N-0561	Gear-Pump Idler	373-1886
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726
8N-1628	Shaft As-F Pump	383-3703
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-4550	Shaft-Pulley	445-9247

1HB		
Original Part Number	Part Name	Classic Part Number
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7257	Mount As	396-0660
8N-7315	Tube As-Outlet	325-6232
8N-7486	Condenser As	436-2263
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-2051	Plate-Clutch	385-6116
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372

1HB		
Original Part Number	Part Name	Classic Part Number
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8W-0376	Shaft	394-9194
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
8W-3881	Bearing	394-8224
8W-8462	Joint Gp-Univ	421-7829
8X-6738	Shaft-Planet	394-8225
9C-3095	Spider Gp-Brg&	394-8219
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-4413	Shaft-Axle	421-7983
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9L-2685	Rod End	419-1866
9L-5908	Gasket	433-8196
9L-5961	Adapter-Compr Dr	416-5508

Sales Model 637E (Cont'd.)

1HB		
Original Part Number	Part Name	Classic Part Number
9M-1990	Dowel-Reaction	386-4963
9M-3914	Bearing-Aligning	420-2501
9M-5477	Bearing-Sleeve	374-6517
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9T-7414	Pump Gp-Gr B	421-1564
9V-7710	Univ Joint As	394-8234
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998

1HB		
Original Part Number	Part Name	Classic Part Number
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
100-7860	Valve-Inlet	270-4360
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
102-8608	Manifold-Exhaust	376-9062
102-8636	Gear-Drive	472-8035
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
111-8015	Gasket As-Head	279-4977
112-2255	Gear-Bevel	446-3076
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-4072	Bearing	397-5069
117-9712	Shaft-Dr Idler	425-7754

1HB		
Original Part Number	Part Name	Classic Part Number
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
128-3132	Gasket Kit	437-4566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
134-3038	Gasket Kit	437-3228
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
135-7989	Gasket Kit	393-3633
136-7813	Bearing-Race	460-8296
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
140-2246	Gasket Kit	383-3710
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
145-8503	Shaft As-Idler	426-0035
148-7455	Valve - Exhaust	270-4361
149-5985	Stator-Converter	419-1865
158-1441	Kit-Dt Gasket	394-9207
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697

Sales Model 637E (Cont'd.)

1HB		
Original Part Number	Part Name	Classic Part Number
164-4413	Mount	419-0876
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
167-8126	Damper As	382-8019
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0560	Rebuild Kit-Pump	363-7458
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

1HB		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266

1HB		
Original Part Number	Part Name	Classic Part Number
221-6985	Retainer	399-4406
229-1490	Sleeve-Injector	393-3659
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
250-6558	Liner Kit-Cla	295-6438
253-1752	Plate-Thrust	379-0170
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
283-5666	Gasket-Cyl Head	388-6565
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-5572	Bearing-Rod	419-6349
328-5574	Bearing-Rod	419-7266
334-8389	Crankshaft As	242-3439
352-0209	Pump Gp-Water -B	375-4336
391-8229	Kit-Gasket-Fs	398-2955

1JB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3300	Shield As	374-4702
1N-3576	Block Gp-Cyl	279-4978

1JB		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-7936	Spider As-Fan	383-3673
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786

1JB		
Original Part Number	Part Name	Classic Part Number
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0589	Cup-Roller Brg	386-4942
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797

Sales Model 637E (Cont'd.)

1JB		
Original Part Number	Part Name	Classic Part Number
1T-0737	Race-Spl Thrust	384-4798
1T-1033	Plate-Cl Backing	431-4136
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-5009	Crankshaft As	398-2969
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9490	Pulley-Alt	394-0885
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628

1JB		
Original Part Number	Part Name	Classic Part Number
2D-6516	Bearing As-Rlr	435-2572
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2K-5065	Cone-Roller Brg	416-2157
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

1JB		
Original Part Number	Part Name	Classic Part Number
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-4087	Gear As-Idler	418-9582
2W-5539	Core As-Rad	374-7492
2W-6280	Bracket As-Fan	431-5271
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-7774	Ejector As-Exh	393-0914
2W-7980	Camshaft As	378-3972
2W-8038	Gear-Camshaft	425-7751
2W-8437	Muffler As	385-7198
2W-9978	Core As-Oclr	279-4983
3D-9132	Cone-Roller Brg	453-3652

Sales Model 637E (Cont'd.)

1JB		
Original Part Number	Part Name	Classic Part Number
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-7489	Plate-Clutch	377-7423
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4N-0342	Plate-Cam Thrust	375-9974

1JB		
Original Part Number	Part Name	Classic Part Number
4N-0432	Bearing-Ball	417-4499
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1186	Bearing-Sleeve	417-4519
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4N-7693	Crankshaft As	269-8763
4P-2383	Adapter-Inlet	438-1812
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

1JB		
Original Part Number	Part Name	Classic Part Number
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5367	Mount As	375-9986
4T-7640	Shaft As	393-3643
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501

Sales Model 637E (Cont'd.)

1JB		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5F-7404	Nut-Bearing Lock	308-9878
5J-6430	Bearing-Sleeve	379-0195
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247

1JB		
Original Part Number	Part Name	Classic Part Number
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717

1JB		
Original Part Number	Part Name	Classic Part Number
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-3907	Adapter-Pilot	398-8348
6I-4613	Plate-Spacer	380-7405
6K-4442	Rod End-Special	373-5388
6N-0977	Bearing-Sleeve	417-4524
6N-1036	Gear-Oil Pump	279-4991
6N-1931	Plunger	379-0171
6N-2789	Pulley	264-5886
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-8992	Adapter-Fan	394-9810
6N-9133	Gasket-Plate	398-2959
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574

Sales Model 637E (Cont'd.)

1JB		
Original Part Number	Part Name	Classic Part Number
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
6V-5920	Gasket Kit - F	388-0653
6Y-1320	Plate-Clutch	384-5935
6Y-2065	Mount As-650 Cup	377-5844
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-3351	Head	380-1515
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4983	Cap-Bearing	384-3460

1JB		
Original Part Number	Part Name	Classic Part Number
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8629	Coupling-Elbow	419-4664
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893

1JB		
Original Part Number	Part Name	Classic Part Number
7W-0508	Gear-Fp Drive	296-1351
7W-0561	Pump Gp-F Inj -B	432-8278
7W-0675	Core As-Oclr	434-4016
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-4473	Manifold-Ex	443-2095
7W-5435	Adapter-Nozzle	374-7493
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-6459	Core As-Oclr	395-1313
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-0580	Gasket Kit - T	393-1023
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8L-8867	Pulley	434-1409
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-7166	Housing-Screen	297-7192
8N-0081	Trunnion	393-5196
8N-0111	Mount As	374-1452

Sales Model 637E (Cont'd.)

1JB		
Original Part Number	Part Name	Classic Part Number
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726
8N-1628	Shaft As-F Pump	383-3703
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207

1JB		
Original Part Number	Part Name	Classic Part Number
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7257	Mount As	396-0660
8N-7315	Tube As-Outlet	325-6232
8N-7486	Condenser As	436-2263
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8983	Hub-Fan Pulley	421-7227
8P-2051	Plate-Clutch	385-6116
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042

1JB		
Original Part Number	Part Name	Classic Part Number
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8T-1643	Kit-Dt Gasket	388-6575
8T-6487	Kit-Gasket-Sch	436-8384
8W-0376	Shaft	394-9194
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
8W-3881	Bearing	394-8224
8W-8462	Joint Gp-Univ	421-7829
8X-6738	Shaft-Planet	394-8225
9C-3095	Spider Gp-Brg	394-8219
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-4413	Shaft-Axle	421-7983
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783

Sales Model 637E (Cont'd.)

1JB		
Original Part Number	Part Name	Classic Part Number
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9L-5908	Gasket	433-8196
9L-5961	Adapter-Compr Dr	416-5508
9M-1990	Dowel-Reaction	386-4963
9M-3914	Bearing-Aligning	420-2501
9M-5477	Bearing-Sleeve	374-6517
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-7414	Pump Gp-Gr B	421-1564
9V-7710	Univ Joint As	394-8234
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2148	Tube As-Exhaust	378-3995

1JB		
Original Part Number	Part Name	Classic Part Number
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
100-7860	Valve-Inlet	270-4360
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3125	Gasket	420-8567
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
102-8636	Gear-Drive	472-8035
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063

1JB		
Original Part Number	Part Name	Classic Part Number
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
111-8015	Gasket As-Head	279-4977
112-2255	Gear-Bevel	446-3076
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
114-0915	Shield As.	394-0887
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-0019	Disc-Friction	417-9492
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
126-5057	Shield As-Man Lh	369-9493
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814

Sales Model 637E (Cont'd.)

1JB		
Original Part Number	Part Name	Classic Part Number
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
136-7813	Bearing-Race	460-8296
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-9381	Plate-Spacer	424-7052
141-4109	Core As-Oclr	416-5518
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
148-7455	Valve - Exhaust	270-4361
149-5985	Stator-Converter	419-1865
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048

1JB		
Original Part Number	Part Name	Classic Part Number
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
163-4109	Manifold-Exhaust	433-9857
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
166-6352	Tube As.	432-4223
167-8123	Damper As	299-2006
167-8126	Damper As	382-8019
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365

1JB		
Original Part Number	Part Name	Classic Part Number
172-7771	Pump Gp-Water -B	419-4646
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-1305	Kit-Dt Gasket	394-8230
216-5582	Bearing-Sleeve	390-0914
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024
232-2672	Kit-Gasket-Fs	393-0922
232-3233	Bearing-Main	376-9085
233-8683	Kit-Gasket-Mch	393-1039
237-2859	Bearing-Rlr	368-0125
246-3130	Shaft-Water Pump	392-4508
250-6558	Liner Kit-Cla	295-6438
253-1752	Plate-Thrust	379-0170
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
278-1365	Arm As-Ui Rkr	433-7507

Sales Model 637E (Cont'd.)

1JB		
Original Part Number	Part Name	Classic Part Number
283-5666	Gasket-Cyl Head	388-6565
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-6870	Kit-Dt Gasket	451-1510

1JB		
Original Part Number	Part Name	Classic Part Number
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-5572	Bearing-Rod	419-6349

1JB		
Original Part Number	Part Name	Classic Part Number
328-5574	Bearing-Rod	419-7266
334-8389	Crankshaft As	242-3439
352-0209	Pump Gp-Water -B	375-4336

1LB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3300	Shield As	374-4702
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-7936	Spider As-Fan	383-3673
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0589	Cup-Roller Brg	386-4942
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0737	Race-Spl Thrust	384-4798
1T-1033	Plate-Cl Backing	431-4136
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924

1LB		
Original Part Number	Part Name	Classic Part Number
1T-1282	Race-Brg Thrust	373-1755
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5009	Crankshaft As	398-2969
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9490	Pulley-Alt	394-0885
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

1LB		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2D-6516	Bearing As-Rlr	435-2572
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2K-5065	Cone-Roller Brg	416-2157
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164

Sales Model 637E (Cont'd.)

1LB		
Original Part Number	Part Name	Classic Part Number
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-4087	Gear As-Idler	418-9582
2W-5539	Core As-Rad	374-7492
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439

1LB		
Original Part Number	Part Name	Classic Part Number
2W-7678	Gear-Water Pump	325-6088
2W-7774	Ejector As-Exh	393-0914
2W-7980	Camshaft As	378-3972
2W-8437	Muffler As	385-7198
2W-9978	Core As-Oclr	279-4983
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-7489	Plate-Clutch	377-7423
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4D-0487	Valve As-Check	375-4334

1LB		
Original Part Number	Part Name	Classic Part Number
4D-2619	Bearing	417-4494
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

Sales Model 637E (Cont'd.)

1LB		
Original Part Number	Part Name	Classic Part Number
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-5367	Mount As	375-9986
4T-7640	Shaft As	393-3643
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255

1LB		
Original Part Number	Part Name	Classic Part Number
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-6430	Bearing-Sleeve	379-0195
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575

1LB		
Original Part Number	Part Name	Classic Part Number
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714

Sales Model 637E (Cont'd.)

1LB		
Original Part Number	Part Name	Classic Part Number
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-4613	Plate-Spacer	380-7405
6K-4442	Rod End-Special	373-5388
6N-0977	Bearing-Sleeve	417-4524
6N-1036	Gear-Oil Pump	279-4991
6N-1931	Plunger	379-0171
6N-2789	Pulley	264-5886
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-8992	Adapter-Fan	394-9810

1LB		
Original Part Number	Part Name	Classic Part Number
6N-9133	Gasket-Plate	398-2959
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-1320	Plate-Clutch	384-5935
6Y-2065	Mount As-650 Cup	377-5844
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7D-7607	Gear-Dif Bevel	388-0595
7E-0853	Muffler As	360-7887
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-9980	Camshaft	377-5851
7F-7780	Pin-Anchor	384-4825
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104

1LB		
Original Part Number	Part Name	Classic Part Number
7J-3351	Head	380-1515
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4983	Cap-Bearing	384-3460
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8629	Coupling-Elbow	419-4664
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417

Sales Model 637E (Cont'd.)

1LB		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-0508	Gear-Fp Drive	296-1351
7W-0561	Pump Gp-F Inj -B	432-8278
7W-0675	Core As-Oclr	434-4016
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-4473	Manifold-Ex	443-2095
7W-5435	Adapter-Nozzle	374-7493
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-6459	Core As-Oclr	395-1313
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8L-8867	Pulley	434-1409
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-7166	Housing-Screen	297-7192

1LB		
Original Part Number	Part Name	Classic Part Number
8N-0081	Trunnion	393-5196
8N-0111	Mount As	374-1452
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726
8N-1628	Shaft As-F Pump	383-3703
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842

1LB		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7257	Mount As	396-0660
8N-7315	Tube As-Outlet	325-6232
8N-7486	Condenser As	436-2263
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-2051	Plate-Clutch	385-6116
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042

Sales Model 637E (Cont'd.)

1LB		
Original Part Number	Part Name	Classic Part Number
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8W-0376	Shaft	394-9194
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
8W-3881	Bearing	394-8224
8W-8462	Joint Gp-Univ	421-7829
8X-6738	Shaft-Planet	394-8225
9C-3095	Spider Gp-Brg&	394-8219
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-4413	Shaft-Axle	421-7983
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031

1LB		
Original Part Number	Part Name	Classic Part Number
9L-2685	Rod End	419-1866
9L-5908	Gasket	433-8196
9L-5961	Adapter-Compr Dr	416-5508
9M-1990	Dowel-Reaction	386-4963
9M-3914	Bearing-Aligning	420-2501
9M-5477	Bearing-Sleeve	374-6517
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-7414	Pump Gp-Gr B	421-1564
9V-7710	Univ Joint As	394-8234
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996

1LB		
Original Part Number	Part Name	Classic Part Number
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
100-7860	Valve-Inlet	270-4360
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
102-8608	Manifold-Exhaust	376-9062
102-8636	Gear-Drive	472-8035
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
111-8015	Gasket As-Head	279-4977
112-2255	Gear-Bevel	446-3076
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704

Sales Model 637E (Cont'd.)

1LB		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
136-7813	Bearing-Race	460-8296
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
145-8503	Shaft As-Idler	426-0035
148-7455	Valve - Exhaust	270-4361
149-5985	Stator-Converter	419-1865
158-1441	Kit-Dt Gasket	394-9207
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
164-4413	Mount	419-0876

1LB		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
167-8126	Damper As	382-8019
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0560	Rebuild Kit-Pump	363-7458
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646

1LB		
Original Part Number	Part Name	Classic Part Number
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
250-6558	Liner Kit-Cla	295-6438
253-1752	Plate-Thrust	379-0170
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
283-5666	Gasket-Cyl Head	388-6565
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-5572	Bearing-Rod	419-6349
328-5574	Bearing-Rod	419-7266
334-8389	Crankshaft As	242-3439
352-0209	Pump Gp-Water -B	375-4336

Sales Model 637E (Cont'd.)

7CB		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1P-7936	Spider As-Fan	383-3673
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0589	Cup-Roller Brg	386-4942
1T-0660	Impeller-Conv	388-6595
1T-0737	Race-Spl Thrust	384-4798
1T-1033	Plate-Cl Backing	431-4136
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173

7CB		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6516	Bearing As-Rlr	435-2572
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2K-5065	Cone-Roller Brg	416-2157
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979

7CB		
Original Part Number	Part Name	Classic Part Number
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5539	Core As-Rad	374-7492
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-7752	Pin As	384-4779
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3P-7489	Plate-Clutch	377-7423
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849

Sales Model 637E (Cont'd.)

7CB		
Original Part Number	Part Name	Classic Part Number
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4N-0432	Bearing-Ball	417-4499
4N-6413	Support-Alt	433-9855
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-5367	Mount As	375-9986
4T-7640	Shaft As	393-3643
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

7CB		
Original Part Number	Part Name	Classic Part Number
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

7CB		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6N-9133	Gasket-Plate	398-2959
6P-6739	Shaft-Planet	308-9929
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-4297	Seal As-Cshaft	325-6192
7E-0853	Muffler As	360-7887
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-7780	Pin-Anchor	384-4825
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104

Sales Model 637E (Cont'd.)

7CB		
Original Part Number	Part Name	Classic Part Number
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-0675	Core As-Oclr	434-4016
7W-1927	Ring-Retainer	387-2935
7W-4473	Manifold-Ex	443-2095
7W-5687	Hub-Cshft	314-8684

7CB		
Original Part Number	Part Name	Classic Part Number
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger& Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8L-8867	Pulley	434-1409
8M-7166	Housing-Screen	297-7192
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207

7CB		
Original Part Number	Part Name	Classic Part Number
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7257	Mount As	396-0660
8N-7315	Tube As-Outlet	325-6232
8N-7486	Condenser As	436-2263
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415

Sales Model 637E (Cont'd.)

7CB		
Original Part Number	Part Name	Classic Part Number
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
8W-8462	Joint Gp-Univ	421-7829
8X-6738	Shaft-Planet	394-8225
9C-3095	Spider Gp-Brg&	394-8219
9D-0120	Gear-Planet	288-8737
9D-4413	Shaft-Axle	421-7983
9D-5444	Pin	380-7396
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9L-5908	Gasket	433-8196
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-7710	Univ Joint As	394-8234
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
111-8015	Gasket As-Head	279-4977
115-4072	Bearing	397-5069
128-3132	Gasket Kit	437-4566
131-3815	Seal Gp-Basic	325-6193

7CB		
Original Part Number	Part Name	Classic Part Number
134-3038	Gasket Kit	437-3228
135-2707	Kit-Gasket (Bsc)	392-4506
135-7989	Gasket Kit	393-3633
136-7813	Bearing-Race	460-8296
140-2246	Gasket Kit	383-3710
140-2749	Gasket Kit	393-1033
141-1936	Kit-Gasket(F)	437-4614
141-1939	Gasket Kit	437-4613
141-1942	Gasket Kit	437-4612
144-7289	Roller As	434-1862
148-7455	Valve - Exhaust	270-4361
149-5985	Stator-Converter	419-1865
158-1441	Kit-Dt Gasket	394-9207
160-9874	Kit-Gasket-Scl	386-3048
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
164-4413	Mount	419-0876
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577

7CB		
Original Part Number	Part Name	Classic Part Number
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
174-6836	Gasket Kit - Tof	434-7280
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
221-6985	Retainer	399-4406
229-1490	Sleeve-Injector	393-3659
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
283-5666	Gasket-Cyl Head	388-6565
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989

Sales Model 637E (Cont'd.)

7CB		
Original Part Number	Part Name	Classic Part Number
328-5572	Bearing-Rod	419-6349

7CB		
Original Part Number	Part Name	Classic Part Number
334-8389	Crankshaft As	242-3439

7CB		
Original Part Number	Part Name	Classic Part Number
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 637G

AWE		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1P-7936	Spider As-Fan	383-3673
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0589	Cup-Roller Brg	386-4942
1T-0660	Impeller-Conv	388-6595
1T-0737	Race-Spl Thrust	384-4798
1T-1033	Plate-Cl Backing	431-4136
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006

AWE		
Original Part Number	Part Name	Classic Part Number
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6516	Bearing As-Rlr	435-2572
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2K-5065	Cone-Roller Brg	416-2157
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

AWE		
Original Part Number	Part Name	Classic Part Number
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5539	Core As-Rad	374-7492
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-7752	Pin As	384-4779
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562

Sales Model 637G (Cont'd.)

AWE		
Original Part Number	Part Name	Classic Part Number
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3P-7489	Plate-Clutch	377-7423
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986

AWE		
Original Part Number	Part Name	Classic Part Number
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-7640	Shaft As	393-3643
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360

AWE		
Original Part Number	Part Name	Classic Part Number
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-6739	Shaft-Planet	308-9929
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-7780	Pin-Anchor	384-4825
7J-2604	Bearing-Sleeve	380-7369

Sales Model 637G (Cont'd.)

AWE		
Original Part Number	Part Name	Classic Part Number
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-0675	Core As-Oclr	434-4016
7W-1927	Ring-Retainer	387-2935
7W-4473	Manifold-Ex	443-2095
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277

AWE		
Original Part Number	Part Name	Classic Part Number
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8M-7166	Housing-Screen	297-7192
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290

AWE		
Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
8W-8462	Joint Gp-Univ	421-7829
8X-6738	Shaft-Planet	394-8225
9C-3095	Spider Gp-Brg&	394-8219
9D-0120	Gear-Planet	288-8737
9D-4413	Shaft-Axle	421-7983

Sales Model 637G (Cont'd.)

AWE		
Original Part Number	Part Name	Classic Part Number
9D-5444	Pin	380-7396
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-7710	Univ Joint As	394-8234
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
144-7289	Roller As	434-1862
148-7455	Valve - Exhaust	270-4361
149-5985	Stator-Converter	419-1865
158-1441	Kit-Dt Gasket	394-9207

AWE		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

AWE		
Original Part Number	Part Name	Classic Part Number
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
221-6985	Retainer	399-4406
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

AXT		
Original Part Number	Part Name	Classic Part Number
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409

AXT		
Original Part Number	Part Name	Classic Part Number
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802

AXT		
Original Part Number	Part Name	Classic Part Number
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-4369	Pulley-Alt	296-1340
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705

Sales Model 637G (Cont'd.)

AXT		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6150	Cover-Pulley	428-8817
2W-4087	Gear As-Idler	418-9582
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3K-0526	Bearing-Ball	386-4949
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226

AXT		
Original Part Number	Part Name	Classic Part Number
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-1186	Bearing-Sleeve	417-4519
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6302	Belt Set-Vee	314-8495
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4S-5367	Mount As	375-9986
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333

AXT		
Original Part Number	Part Name	Classic Part Number
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5D-0470	Valve Gp-Qrel	314-8549
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5F-2830	Bearing-Needle	384-5925
5F-7404	Nut-Bearing Lock	308-9878
5J-6430	Bearing-Sleeve	379-0195
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347

Sales Model 637G (Cont'd.)

AXT		
Original Part Number	Part Name	Classic Part Number
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-3641	Pulley-Tightener	380-7536
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-5996	Rod As-Conn	379-8864
7F-7780	Pin-Anchor	384-4825
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7N-2156	Bearing-Sleeve	380-7373

AXT		
Original Part Number	Part Name	Classic Part Number
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8H-8175	Bearing-Sleeve	376-3636
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1619	Shield As	377-5857
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-7486	Condenser As	436-2263
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-6511	Bearing-Sleeve	380-7372
8W-3881	Bearing	394-8224
8X-6738	Shaft-Planet	394-8225
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-5444	Pin	380-7396

AXT		
Original Part Number	Part Name	Classic Part Number
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1187	Bearing-Sleeve	384-4785
9L-5961	Adapter-Compr Dr	416-5508
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9T-7414	Pump Gp-Gr B	421-1564
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
105-2070	Bushing	394-0221

Sales Model 637G (Cont'd.)

AXT		
Original Part Number	Part Name	Classic Part Number
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-2255	Gear-Bevel	446-3076
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
114-0915	Shield As.	394-0887
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666

AXT		
Original Part Number	Part Name	Classic Part Number
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
126-5057	Shield As-Man Lh	369-9493
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
155-6637	Gear-Oil Drive	425-9189
156-8578	Shaft	417-9490
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519

AXT		
Original Part Number	Part Name	Classic Part Number
163-3103	Manifold-Exh	430-8992
167-8126	Damper As	382-8019
170-8541	Core As-Rdtr	379-0180
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
184-9843	Head	347-0461
211-0592	Bearing - Main	419-6368
213-1304	Kit-Dt Gasket	394-8231
217-0586	Bearing-Rod	419-7266
221-6985	Retainer	399-4406
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

AYN		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-7115	Mount As	418-1936
1P-7936	Spider As-Fan	383-3673

AYN		
Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0589	Cup-Roller Brg	386-4942
1T-0660	Impeller-Conv	388-6595
1T-0737	Race-Spl Thrust	384-4798

AYN		
Original Part Number	Part Name	Classic Part Number
1T-1033	Plate-Cl Backing	431-4136
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-1219	Trunnion As	314-8724

Sales Model 637G (Cont'd.)

AYN		
Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6516	Bearing As-Rlr	435-2572
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2K-5065	Cone-Roller Brg	416-2157
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230

AYN		
Original Part Number	Part Name	Classic Part Number
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5539	Core As-Rad	374-7492
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-7752	Pin As	384-4779
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3P-7489	Plate-Clutch	377-7423
3S-1262	Retainer	308-9915

AYN		
Original Part Number	Part Name	Classic Part Number
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-7640	Shaft As	393-3643
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534

Sales Model 637G (Cont'd.)

AYN		
Original Part Number	Part Name	Classic Part Number
4W-7188	Core As-Oclr	374-7501
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579

AYN		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-6739	Shaft-Planet	308-9929
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-7780	Pin-Anchor	384-4825
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4983	Cap-Bearing	384-3460
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435

AYN		
Original Part Number	Part Name	Classic Part Number
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-0675	Core As-Oclr	434-4016
7W-1927	Ring-Retainer	387-2935
7W-4473	Manifold-Ex	443-2095
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8M-7166	Housing-Screen	297-7192

Sales Model 637G (Cont'd.)

AYN		
Original Part Number	Part Name	Classic Part Number
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

AYN		
Original Part Number	Part Name	Classic Part Number
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
8W-8462	Joint Gp-Univ	421-7829
8X-6738	Shaft-Planet	394-8225
9C-3095	Spider Gp-Brg&	394-8219
9D-0120	Gear-Planet	288-8737
9D-4413	Shaft-Axle	421-7983
9D-5444	Pin	380-7396
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042

AYN		
Original Part Number	Part Name	Classic Part Number
9V-7710	Univ Joint As	394-8234
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
148-7455	Valve - Exhaust	270-4361
149-5985	Stator-Converter	419-1865
158-1441	Kit-Dt Gasket	394-9207
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687

Sales Model 637G (Cont'd.)

AYN		
Original Part Number	Part Name	Classic Part Number
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365

AYN		
Original Part Number	Part Name	Classic Part Number
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
221-6985	Retainer	399-4406
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
270-4353	Kit-Liner-Cla	270-4357

AYN		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

CEH		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0589	Cup-Roller Brg	386-4942
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0737	Race-Spl Thrust	384-4798
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108

CEH		
Original Part Number	Part Name	Classic Part Number
1T-0861	Impeller-Conv	421-1715
1T-1033	Plate-Cl Backing	431-4136
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1348	Support As-Carr	419-4049
1W-4369	Pulley-Alt	296-1340
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914

CEH		
Original Part Number	Part Name	Classic Part Number
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2K-5065	Cone-Roller Brg	416-2157
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6150	Cover-Pulley	428-8817
2W-4087	Gear As-Idler	418-9582
2W-7213	Bearing-Sleeve	419-4667
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694

Sales Model 637G (Cont'd.)

CEH		
Original Part Number	Part Name	Classic Part Number
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156

CEH		
Original Part Number	Part Name	Classic Part Number
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-1186	Bearing-Sleeve	417-4519
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6302	Belt Set-Vee	314-8495
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-5367	Mount As	375-9986
4T-7640	Shaft As	393-3643
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975

CEH		
Original Part Number	Part Name	Classic Part Number
4W-5998	Rod-Valve Push	379-0168
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5F-7404	Nut-Bearing Lock	308-9878
5J-6430	Bearing-Sleeve	379-0195
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190

Sales Model 637G (Cont'd.)

CEH		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-3641	Pulley-Tightener	380-7536
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6P-2090	Base-Xmsn O Fil	397-5049
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451

CEH		
Original Part Number	Part Name	Classic Part Number
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-5996	Rod As-Conn	379-8864
7E-9595	Core As-Radiator	396-9926
7F-7780	Pin-Anchor	384-4825
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0675	Core As-Oclr	434-4016

CEH		
Original Part Number	Part Name	Classic Part Number
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8H-8175	Bearing-Sleeve	376-3636
8J-9926	Bearing-Sleeve	383-2115
8M-7166	Housing-Screen	297-7192
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1619	Shield As	377-5857
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-7486	Condenser As	436-2263
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
8W-3881	Bearing	394-8224
8W-8462	Joint Gp-Univ	421-7829
8X-6738	Shaft-Planet	394-8225
9C-3095	Spider Gp-Brg	394-8219
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933

Sales Model 637G (Cont'd.)

CEH		
Original Part Number	Part Name	Classic Part Number
9D-4413	Shaft-Axle	421-7983
9D-5444	Pin	380-7396
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9L-5961	Adapter-Compr Dr	416-5508
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9T-7414	Pump Gp-Gr B	421-1564
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552

CEH		
Original Part Number	Part Name	Classic Part Number
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-2255	Gear-Bevel	446-3076
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
114-0915	Shield As.	394-0887
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703

CEH		
Original Part Number	Part Name	Classic Part Number
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
126-5057	Shield As-Man Lh	369-9493
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
136-7813	Bearing-Race	460-8296
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
149-5985	Stator-Converter	419-1865
155-6637	Gear-Oil Drive	425-9189
156-8578	Shaft	417-9490
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-3411	Gasket	394-0896
162-0152	Bearing-Sleeve	422-9519
163-1387	Gear-Flywheel	374-4697
163-3103	Manifold-Exh	430-8992
164-4413	Mount	419-0876
167-8126	Damper As	382-8019
170-8541	Core As-Rdtr	379-0180
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956

Sales Model 637G (Cont'd.)

CEH		
Original Part Number	Part Name	Classic Part Number
180-6645	Shaft As.	396-1566
184-9843	Head	347-0461
211-0592	Bearing - Main	419-6368
213-1304	Kit-Dt Gasket	394-8231
217-0586	Bearing-Rod	419-7266

CEH		
Original Part Number	Part Name	Classic Part Number
221-6985	Retainer	399-4406
229-1490	Sleeve-Injector	393-3659
237-2859	Bearing-Rlr	368-0125
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565

CEH		
Original Part Number	Part Name	Classic Part Number
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

CEJ		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0589	Cup-Roller Brg	386-4942
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0737	Race-Spl Thrust	384-4798
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1033	Plate-Cl Backing	431-4136

CEJ		
Original Part Number	Part Name	Classic Part Number
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1348	Support As-Carr	419-4049
1W-4369	Pulley-Alt	296-1340
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257

CEJ		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2K-5065	Cone-Roller Brg	416-2157
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2S-6150	Cover-Pulley	428-8817
2W-4087	Gear As-Idler	418-9582
2W-7213	Bearing-Sleeve	419-4667
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3J-2333	Bearing-Sleeve	422-9525

Sales Model 637G (Cont'd.)

CEJ		
Original Part Number	Part Name	Classic Part Number
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-1186	Bearing-Sleeve	417-4519

CEJ		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6302	Belt Set-Vee	314-8495
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4S-5367	Mount As	375-9986
4T-7640	Shaft As	393-3643
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925

CEJ		
Original Part Number	Part Name	Classic Part Number
5F-7404	Nut-Bearing Lock	308-9878
5J-6430	Bearing-Sleeve	379-0195
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-4613	Plate-Spacer	380-7405

Sales Model 637G (Cont'd.)

CEJ		
Original Part Number	Part Name	Classic Part Number
6N-0977	Bearing-Sleeve	417-4524
6N-3641	Pulley-Tightener	380-7536
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6P-2090	Base-Xmsn O Fil	397-5049
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-5996	Rod As-Conn	379-8864
7F-7780	Pin-Anchor	384-4825
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789

CEJ		
Original Part Number	Part Name	Classic Part Number
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0675	Core As-Oclr	434-4016
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8H-8175	Bearing-Sleeve	376-3636
8J-9926	Bearing-Sleeve	383-2115
8M-7166	Housing-Screen	297-7192
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1619	Shield As	377-5857
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562

CEJ		
Original Part Number	Part Name	Classic Part Number
8N-2368	Shield As	449-9547
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-7486	Condenser As	436-2263
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
8W-3881	Bearing	394-8224
8W-8462	Joint Gp-Univ	421-7829
8X-6738	Shaft-Planet	394-8225
9C-3095	Spider Gp-Brg&	394-8219
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-4413	Shaft-Axle	421-7983
9D-5444	Pin	380-7396
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303

Sales Model 637G (Cont'd.)

CEJ		
Original Part Number	Part Name	Classic Part Number
9J-6260	Trunnion	426-0031
9L-5961	Adapter-Compr Dr	416-5508
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9T-7414	Pump Gp-Gr B	421-1564
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-2255	Gear-Bevel	446-3076
112-7750	Manifold-Exhaust	390-0919

CEJ		
Original Part Number	Part Name	Classic Part Number
112-7751	Manifold-Exhaust	390-0917
114-0915	Shield As.	394-0887
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
126-5057	Shield As-Man Lh	369-9493
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
136-7813	Bearing-Race	460-8296
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053

CEJ		
Original Part Number	Part Name	Classic Part Number
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
149-5985	Stator-Converter	419-1865
155-6637	Gear-Oil Drive	425-9189
156-8578	Shaft	417-9490
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-3411	Gasket	394-0896
162-0152	Bearing-Sleeve	422-9519
163-1387	Gear-Flywheel	374-4697
163-3103	Manifold-Exh	430-8992
164-4413	Mount	419-0876
167-8126	Damper As	382-8019
170-8541	Core As-Rdtr	379-0180
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
221-6985	Retainer	399-4406
229-1490	Sleeve-Injector	393-3659
237-2859	Bearing-Rlr	368-0125
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

Sales Model 637G (Cont'd.)

CEM		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-7115	Mount As	418-1936
1T-0589	Cup-Roller Brg	386-4942
1T-0660	Impeller-Conv	388-6595
1T-0737	Race-Spl Thrust	384-4798
1T-0861	Impeller-Conv	421-1715
1T-1033	Plate-Cl Backing	431-4136
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6516	Bearing As-Rlr	435-2572
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2K-5065	Cone-Roller Brg	416-2157
2S-4900	Shaft As	384-4792
2W-7213	Bearing-Sleeve	419-4667
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-7752	Pin As	384-4779
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582
3J-8688	Bearing-Sleeve	380-1561

CEM		
Original Part Number	Part Name	Classic Part Number
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3P-7489	Plate-Clutch	377-7423
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4T-7640	Shaft As	393-3643
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-7188	Core As-Oclr	374-7501
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-9439	Bearing-Spl Ball	371-4306

CEM		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
6G-0078	Breather	435-4789
6P-6739	Shaft-Planet	308-9929
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
7F-7780	Pin-Anchor	384-4825
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7T-2036	Cap As-Fuel	361-1721
7W-0675	Core As-Oclr	434-4016
8H-8175	Bearing-Sleeve	376-3636
8J-9926	Bearing-Sleeve	383-2115
8M-7166	Housing-Screen	297-7192
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
8W-8462	Joint Gp-Univ	421-7829
8X-6738	Shaft-Planet	394-8225
9C-3095	Spider Gp-Brg&	394-8219
9D-0120	Gear-Planet	288-8737

Sales Model 637G (Cont'd.)

CEM		
Original Part Number	Part Name	Classic Part Number
9D-4413	Shaft-Axle	421-7983
9D-5444	Pin	380-7396
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9V-7710	Univ Joint As	394-8234

CEM		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
136-7813	Bearing-Race	460-8296
144-7289	Roller As	434-1862
149-5985	Stator-Converter	419-1865
161-3411	Gasket	394-0896

CEM		
Original Part Number	Part Name	Classic Part Number
163-1387	Gear-Flywheel	374-4697
164-4413	Mount	419-0876
221-6985	Retainer	399-4406
229-1490	Sleeve-Injector	393-3659
237-2859	Bearing-Rlr	368-0125

DEX		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1T-0334	Bearing-Ball	380-1476
1T-0589	Cup-Roller Brg	386-4942
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0737	Race-Spl Thrust	384-4798
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1033	Plate-Cl Backing	431-4136
1T-1078	Bearing-Thrust	384-4802

DEX		
Original Part Number	Part Name	Classic Part Number
1T-1079	Hub-Impeller	416-2152
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1348	Support As-Carr	419-4049
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354

DEX		
Original Part Number	Part Name	Classic Part Number
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2K-5065	Cone-Roller Brg	416-2157
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2W-6280	Bracket As-Fan	431-5271
2W-7213	Bearing-Sleeve	419-4667
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-8688	Bearing-Sleeve	380-1561

Sales Model 637G (Cont'd.)

DEX		
Original Part Number	Part Name	Classic Part Number
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4T-7640	Shaft As	393-3643
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549

DEX		
Original Part Number	Part Name	Classic Part Number
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-6430	Bearing-Sleeve	379-0195
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6D-0738	Pinion-Dif Bevel	394-9840

DEX		
Original Part Number	Part Name	Classic Part Number
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-2090	Base-Xmsn O Fil	397-5049
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6Y-2065	Mount As-650 Cup	377-5844
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7D-7607	Gear-Dif Bevel	388-0595
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460

Sales Model 637G (Cont'd.)

DEX		
Original Part Number	Part Name	Classic Part Number
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8M-7166	Housing-Screen	297-7192
8N-0111	Mount As	374-1452
8N-2104	Bell As-Suction	380-1521
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501

DEX		
Original Part Number	Part Name	Classic Part Number
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
8W-3881	Bearing	394-8224
8W-8462	Joint Gp-Univ	421-7829
8X-6738	Shaft-Planet	394-8225
9C-3095	Spider Gp-Brg&	394-8219
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-4413	Shaft-Axle	421-7983
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9S-8789	Plate-Clutch	302-2712
9T-7414	Pump Gp-Gr B	421-1564

DEX		
Original Part Number	Part Name	Classic Part Number
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
112-2255	Gear-Bevel	446-3076
115-4072	Bearing	397-5069
117-0019	Disc-Friction	417-9492
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
136-7813	Bearing-Race	460-8296
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
145-8503	Shaft As-Idler	426-0035

Sales Model 637G (Cont'd.)

DEX		
Original Part Number	Part Name	Classic Part Number
149-5985	Stator-Converter	419-1865
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
156-8578	Shaft	417-9490
160-9874	Kit-Gasket-Scl	386-3048
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
164-4413	Mount	419-0876
166-6352	Tube As.	432-4223

DEX		
Original Part Number	Part Name	Classic Part Number
177-7886	Cone	418-9605
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
229-1490	Sleeve-Injector	393-3659

DEX		
Original Part Number	Part Name	Classic Part Number
237-2859	Bearing-Rlr	368-0125
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
257-0424	Shaft	421-8170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

DEY		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-7115	Mount As	418-1936
1T-0334	Bearing-Ball	380-1476
1T-0589	Cup-Roller Brg	386-4942
1T-0737	Race-Spl Thrust	384-4798
1T-0861	Impeller-Conv	421-1715
1T-1033	Plate-Cl Backing	431-4136
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6516	Bearing As-Rlr	435-2572

DEY		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2K-5065	Cone-Roller Brg	416-2157
2S-4900	Shaft As	384-4792
2W-7213	Bearing-Sleeve	419-4667
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-7752	Pin As	384-4779
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782

DEY		
Original Part Number	Part Name	Classic Part Number
3P-7489	Plate-Clutch	377-7423
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4T-7640	Shaft As	393-3643
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-7188	Core As-Oclr	374-7501
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925

Sales Model 637G (Cont'd.)

DEY		
Original Part Number	Part Name	Classic Part Number
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6P-6739	Shaft-Planet	308-9929
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
7F-7780	Pin-Anchor	384-4825
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369

DEY		
Original Part Number	Part Name	Classic Part Number
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7T-2036	Cap As-Fuel	361-1721
8H-8175	Bearing-Sleeve	376-3636
8J-9926	Bearing-Sleeve	383-2115
8M-7166	Housing-Screen	297-7192
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
8W-8462	Joint Gp-Univ	421-7829
8X-6738	Shaft-Planet	394-8225
9C-3095	Spider Gp-Brg&	394-8219

DEY		
Original Part Number	Part Name	Classic Part Number
9D-0120	Gear-Planet	288-8737
9D-4413	Shaft-Axle	421-7983
9D-5444	Pin	380-7396
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9V-7710	Univ Joint As	394-8234
115-4072	Bearing	397-5069
117-0019	Disc-Friction	417-9492
136-7813	Bearing-Race	460-8296
144-7289	Roller As	434-1862
149-5985	Stator-Converter	419-1865
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
164-4413	Mount	419-0876
221-6985	Retainer	399-4406
229-1490	Sleeve-Injector	393-3659
237-2859	Bearing-Rlr	368-0125

DFJ		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672

DFJ		
Original Part Number	Part Name	Classic Part Number
1T-0334	Bearing-Ball	380-1476
1T-0589	Cup-Roller Brg	386-4942
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464

DFJ		
Original Part Number	Part Name	Classic Part Number
1T-0737	Race-Spl Thrust	384-4798
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0861	Impeller-Conv	421-1715
1T-1033	Plate-Cl Backing	431-4136
1T-1078	Bearing-Thrust	384-4802

Sales Model 637G (Cont'd.)

DFJ		
Original Part Number	Part Name	Classic Part Number
1T-1079	Hub-Impeller	416-2152
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1348	Support As-Carr	419-4049
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2K-5065	Cone-Roller Brg	416-2157
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2S-4900	Shaft As	384-4792
2W-6280	Bracket As-Fan	431-5271
2W-7213	Bearing-Sleeve	419-4667
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601

DFJ		
Original Part Number	Part Name	Classic Part Number
3G-0034	Trunnion	361-1712
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283

DFJ		
Original Part Number	Part Name	Classic Part Number
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4T-7640	Shaft As	393-3643
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-6430	Bearing-Sleeve	379-0195
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-5167	Race-Brg Outer	417-4529
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025

Sales Model 637G (Cont'd.)

DFJ		
Original Part Number	Part Name	Classic Part Number
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6H-3957	Bearing-Ball	311-9358
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
6P-2090	Base-Xmsn O Fil	397-5049
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6Y-2065	Mount As-650 Cup	377-5844
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7D-7607	Gear-Dif Bevel	388-0595

DFJ		
Original Part Number	Part Name	Classic Part Number
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721

DFJ		
Original Part Number	Part Name	Classic Part Number
7T-2336	Disc-Friction	433-7096
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8M-7166	Housing-Screen	297-7192
8N-0111	Mount As	374-1452
8N-2104	Bell As-Suction	380-1521
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8W-1708	Pin	388-0643
8W-3613	Bearing	418-1960
8W-3881	Bearing	394-8224
8W-8462	Joint Gp-Univ	421-7829
8X-6738	Shaft-Planet	394-8225
9C-3095	Spider Gp-Brg	394-8219
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-4413	Shaft-Axle	421-7983
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399

Sales Model 637G (Cont'd.)

DFJ		
Original Part Number	Part Name	Classic Part Number
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8789	Plate-Clutch	302-2712
9T-7414	Pump Gp-Gr B	421-1564
9V-7710	Univ Joint As	394-8234
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
105-2070	Bushing	394-0221

DFJ		
Original Part Number	Part Name	Classic Part Number
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
112-2255	Gear-Bevel	446-3076
115-4072	Bearing	397-5069
117-0019	Disc-Friction	417-9492
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
136-7813	Bearing-Race	460-8296
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
145-8503	Shaft As-Idler	426-0035
149-5985	Stator-Converter	419-1865
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
156-8578	Shaft	417-9490
160-9874	Kit-Gasket-Scl	386-3048
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
164-4413	Mount	419-0876
166-6352	Tube As.	432-4223

DFJ		
Original Part Number	Part Name	Classic Part Number
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
184-9843	Head	347-0461
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
190-0649	Tightener-Belt	434-1407
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
229-1490	Sleeve-Injector	393-3659
237-2859	Bearing-Rlr	368-0125
243-6718	Kit-Brg(Main)	469-1690
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
257-0424	Shaft	421-8170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
358-9117	Gear-Planet	380-7490

Sales Model 637G (Cont'd.)

DFJ		
Original Part Number	Part Name	Classic Part Number
368-0297	Plate-Clutch	377-7420

DFJ		
Original Part Number	Part Name	Classic Part Number
430-7619	Adapter-Cla	438-1812

Sales Model 637K

WTS		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1T-0334	Bearing-Ball	380-1476
1T-0589	Cup-Roller Brg	386-4942
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2069	Carrier-Bearing	439-4543
1W-7238	Shaft As-Pump Dr	379-0164

WTS		
Original Part Number	Part Name	Classic Part Number
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2D-9457	Cone-Spl Tapered	377-7418
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2K-5065	Cone-Roller Brg	416-2157
2S-4900	Shaft As	384-4792
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3P-1210	Cone-Roller Brg	399-4433

WTS		
Original Part Number	Part Name	Classic Part Number
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4D-7534	Bearing As-Rlr	441-5602
4E-0403	Gear-Planet	260-0781
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-7449	Cup-Spl Tapered	416-2161
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209

Sales Model 637K (Cont'd.)

WTS		
Original Part Number	Part Name	Classic Part Number
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-5167	Race-Brg Outer	417-4529
5S-4442	Bearing-Spl Ball	419-6025
5T-3329	Pin As	380-7395
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
6G-0387	Disc	394-2579
6N-1931	Plunger	379-0171
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-3831	Seal-O-Ring	436-2657
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
6Y-9885	Bearing-Rlr As	396-9906
7C-0145	Core As-Oclr	374-4720
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460

WTS		
Original Part Number	Part Name	Classic Part Number
7J-9365	Bearing-Sleeve	453-6507
7N-2156	Bearing-Sleeve	380-7373
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
8H-8175	Bearing-Sleeve	376-3636
8J-9926	Bearing-Sleeve	383-2115
8K-0067	Spacer	396-1569
8M-7166	Housing-Screen	297-7192
8N-0111	Mount As	374-1452
8N-2104	Bell As-Suction	380-1521
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8W-1708	Pin	388-0643
8W-3881	Bearing	394-8224
9D-4094	Bearing-Sleeve	418-1933
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667

WTS		
Original Part Number	Part Name	Classic Part Number
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9M-2744	Cone-Spl Tapered	380-1480
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8789	Plate-Clutch	302-2712
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4662	Disc-Friction	428-7203
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
087-5548	Bearing-Sleeve	396-1568
100-8010	Valve	423-5583
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
127-6356	Cover As.-Pump	420-8566
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
136-7813	Bearing-Race	460-8296

Sales Model 637K (Cont'd.)

WTS		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
161-3411	Gasket	394-0896

WTS		
Original Part Number	Part Name	Classic Part Number
163-1387	Gear-Flywheel	374-4697
173-0888	Univ Jt As	394-0898
177-7886	Cone	418-9605
184-9843	Head	347-0461
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368

WTS		
Original Part Number	Part Name	Classic Part Number
216-5582	Bearing-Sleeve	390-0914
221-6985	Retainer	399-4406
253-1752	Plate-Thrust	379-0170
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

WTT		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1T-0334	Bearing-Ball	380-1476
1T-0589	Cup-Roller Brg	386-4942
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920

WTT		
Original Part Number	Part Name	Classic Part Number
1T-2069	Carrier-Bearing	439-4543
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2D-9457	Cone-Spl Tapered	377-7418
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2K-5065	Cone-Roller Brg	416-2157
2S-4900	Shaft As	384-4792
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922

WTT		
Original Part Number	Part Name	Classic Part Number
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-7534	Bearing As-Rlr	441-5602
4E-0403	Gear-Planet	260-0781
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283

Sales Model 637K (Cont'd.)

WTT		
Original Part Number	Part Name	Classic Part Number
4S-8472	Hood As-Preclnr	296-1355
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-7449	Cup-Spl Tapered	416-2161
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-5167	Race-Brg Outer	417-4529
5S-4442	Bearing-Spl Ball	419-6025
5T-3329	Pin As	380-7395
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
6G-0387	Disc	394-2579
6N-1931	Plunger	379-0171
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-3831	Seal-O-Ring	436-2657
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
6Y-9885	Bearing-Rlr As	396-9906
7C-0145	Core As-Oclr	374-4720

WTT		
Original Part Number	Part Name	Classic Part Number
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-9365	Bearing-Sleeve	453-6507
7N-2156	Bearing-Sleeve	380-7373
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
8H-8175	Bearing-Sleeve	376-3636
8J-9926	Bearing-Sleeve	383-2115
8K-0067	Spacer	396-1569
8M-7166	Housing-Screen	297-7192
8N-0111	Mount As	374-1452
8N-2104	Bell As-Suction	380-1521
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501

WTT		
Original Part Number	Part Name	Classic Part Number
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8W-1708	Pin	388-0643
8W-3881	Bearing	394-8224
9D-4094	Bearing-Sleeve	418-1933
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9M-2744	Cone-Spl Tapered	380-1480
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8789	Plate-Clutch	302-2712
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4662	Disc-Friction	428-7203
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
087-5548	Bearing-Sleeve	396-1568
100-8010	Valve	423-5583
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567

Sales Model 637K (Cont'd.)

WTT		
Original Part Number	Part Name	Classic Part Number
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
127-6356	Cover As.-Pump	420-8566
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
136-7813	Bearing-Race	460-8296

WTT		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
173-0888	Univ Jt As	394-0898
177-7886	Cone	418-9605

WTT		
Original Part Number	Part Name	Classic Part Number
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
221-6985	Retainer	399-4406
253-1752	Plate-Thrust	379-0170
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

WTX		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1T-0334	Bearing-Ball	380-1476
1T-0589	Cup-Roller Brg	386-4942
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152

WTX		
Original Part Number	Part Name	Classic Part Number
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2069	Carrier-Bearing	439-4543
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2D-9457	Cone-Spl Tapered	377-7418
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2K-5065	Cone-Roller Brg	416-2157
2S-4900	Shaft As	384-4792
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712

WTX		
Original Part Number	Part Name	Classic Part Number
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-8688	Bearing-Sleeve	380-1561
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226

Sales Model 637K (Cont'd.)

WTX		
Original Part Number	Part Name	Classic Part Number
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4D-7534	Bearing As-Rlr	441-5602
4E-0403	Gear-Planet	260-0781
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-7449	Cup-Spl Tapered	416-2161
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-5167	Race-Brg Outer	417-4529
5S-4442	Bearing-Spl Ball	419-6025
5T-3329	Pin As	380-7395
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6N-1931	Plunger	379-0171

WTX		
Original Part Number	Part Name	Classic Part Number
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-3831	Seal-O-Ring	436-2657
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
6Y-9885	Bearing-Rlr As	396-9906
7C-0145	Core As-Oclr	374-4720
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-9365	Bearing-Sleeve	453-6507
7N-2156	Bearing-Sleeve	380-7373
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
8H-8175	Bearing-Sleeve	376-3636

WTX		
Original Part Number	Part Name	Classic Part Number
8J-9926	Bearing-Sleeve	383-2115
8K-0067	Spacer	396-1569
8M-7166	Housing-Screen	297-7192
8N-0111	Mount As	374-1452
8N-2104	Bell As-Suction	380-1521
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8W-1708	Pin	388-0643
8W-3881	Bearing	394-8224
9D-4094	Bearing-Sleeve	418-1933
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9M-2744	Cone-Spl Tapered	380-1480
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8789	Plate-Clutch	302-2712

Sales Model 637K (Cont'd.)

WTX		
Original Part Number	Part Name	Classic Part Number
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4662	Disc-Friction	428-7203
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
087-5548	Bearing-Sleeve	396-1568
100-8010	Valve	423-5583
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492

WTX		
Original Part Number	Part Name	Classic Part Number
127-6356	Cover As.-Pump	420-8566
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
136-7813	Bearing-Race	460-8296
138-9381	Plate-Spacer	424-7052
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697

WTX		
Original Part Number	Part Name	Classic Part Number
173-0888	Univ Jt As	394-0898
177-7886	Cone	418-9605
184-9843	Head	347-0461
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

WTY		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1T-0334	Bearing-Ball	380-1476
1T-0589	Cup-Roller Brg	386-4942
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803

WTY		
Original Part Number	Part Name	Classic Part Number
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2069	Carrier-Bearing	439-4543
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2D-9457	Cone-Spl Tapered	377-7418
2H-9192	Bearing-Ball	394-8236

WTY		
Original Part Number	Part Name	Classic Part Number
2J-1227	Retainer	440-0850
2K-5065	Cone-Roller Brg	416-2157
2S-4900	Shaft As	384-4792
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-8688	Bearing-Sleeve	380-1561

Sales Model 637K (Cont'd.)

WTY		
Original Part Number	Part Name	Classic Part Number
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3P-1210	Cone-Roller Brg	399-4433
3P-4265	Piston-Clutch	397-5063
3P-7489	Plate-Clutch	377-7423
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-7534	Bearing As-Rlr	441-5602
4E-0403	Gear-Planet	260-0781
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-7449	Cup-Spl Tapered	416-2161
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509

WTY		
Original Part Number	Part Name	Classic Part Number
5M-6126	Bearing	377-7433
5P-5167	Race-Brg Outer	417-4529
5S-4442	Bearing-Spl Ball	419-6025
5T-3329	Pin As	380-7395
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
6G-0387	Disc	394-2579
6N-1931	Plunger	379-0171
6P-6739	Shaft-Planet	308-9929
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-3831	Seal-O-Ring	436-2657
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
6Y-9885	Bearing-Rlr As	396-9906
7C-0145	Core As-Oclr	374-4720
7G-7431	Piston-Selector	432-8911
7H-7628	Bearing	453-3655
7J-2604	Bearing-Sleeve	380-7369
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7N-2156	Bearing-Sleeve	380-7373
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799

WTY		
Original Part Number	Part Name	Classic Part Number
7S-4534	Bearing-Caged	417-9497
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2336	Disc-Friction	433-7096
8H-8175	Bearing-Sleeve	376-3636
8J-9926	Bearing-Sleeve	383-2115
8K-0067	Spacer	396-1569
8N-0111	Mount As	374-1452
8N-2104	Bell As-Suction	380-1521
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-3517	Bearing-Spl Ball	417-4501
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8W-1708	Pin	388-0643
8W-3881	Bearing	394-8224
9D-4094	Bearing-Sleeve	418-1933
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303
9J-6260	Trunnion	426-0031
9M-2744	Cone-Spl Tapered	380-1480

Sales Model 637K (Cont'd.)

WTY		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8789	Plate-Clutch	302-2712
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4662	Disc-Friction	428-7203
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
087-5548	Bearing-Sleeve	396-1568
101-1504	Shaft	373-5379
101-3125	Gasket	420-8567
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947

WTY		
Original Part Number	Part Name	Classic Part Number
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
127-6356	Cover As.-Pump	420-8566
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
136-7813	Bearing-Race	460-8296
138-9381	Plate-Spacer	424-7052
144-7289	Roller As	434-1862
144-7314	Roller As	434-8984
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697

WTY		
Original Part Number	Part Name	Classic Part Number
173-0888	Univ Jt As	394-0898
177-7886	Cone	418-9605
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

Sales Model 639D

88X		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497

88X		
Original Part Number	Part Name	Classic Part Number
1T-0589	Cup-Roller Brg	386-4942
1T-0660	Impeller-Conv	388-6595
1T-0737	Race-Spl Thrust	384-4798
1T-1033	Plate-Cl Backing	431-4136
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-1219	Trunnion As	314-8724

88X		
Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

Sales Model 639D (Cont'd.)

88X		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6516	Bearing As-Rlr	435-2572
2K-0227	Bearing-Sleeve	384-4780
2K-5065	Cone-Roller Brg	416-2157
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794

88X		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3L-1425	Bearing-Ball	311-9356
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4B-1455	Cap As-Filler	361-1719
4B-7255	Cone-Bearing	386-4951
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236

88X		
Original Part Number	Part Name	Classic Part Number
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5367	Mount As	375-9986
4T-7640	Shaft As	393-3643
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-7449	Cup-Spl Tapered	416-2161
5F-2830	Bearing-Needle	384-5925
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5J-9451	Bearing	374-8338
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509

Sales Model 639D (Cont'd.)

88X		
Original Part Number	Part Name	Classic Part Number
5M-6126	Bearing	377-7433
5M-7841	Gear-Ring	214-0525
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rock-er Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6J-6043	Bearing-Sleeve	374-1456
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886

88X		
Original Part Number	Part Name	Classic Part Number
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6N-8992	Adapter-Fan	394-9810
6P-6739	Shaft-Planet	308-9929
6V-2202	Bearing-Spl Ball	380-1574
6Y-5793	Ring-Seal	451-9028
6Y-7652	Cup-Rlr Brg	399-6067
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-7780	Pin-Anchor	384-4825
7J-1770	Cap-Bearing	396-0664
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531

88X		
Original Part Number	Part Name	Classic Part Number
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8L-8867	Pulley	434-1409
8M-7166	Housing-Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

Sales Model 639D (Cont'd.)

88X		
Original Part Number	Part Name	Classic Part Number
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-4520	Piston-Clutch	394-0908

88X		
Original Part Number	Part Name	Classic Part Number
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6370	Yoke	431-2155
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8W-1708	Pin	388-0643
8W-8462	Joint Gp-Univ	421-7829
8X-6738	Shaft-Planet	394-8225
9B-1320	Valve-Check	377-5832
9C-3095	Spider Gp-Brg&	394-8219
9D-0120	Gear-Planet	288-8737
9D-4413	Shaft-Axle	421-7983
9D-5444	Pin	380-7396
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-8323	Trunnion	361-1713
9L-5908	Gasket	433-8196
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7079	Muffler As	247-2669

88X		
Original Part Number	Part Name	Classic Part Number
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-7710	Univ Joint As	394-8234
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
149-5985	Stator-Converter	419-1865
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
171-6696	Diaphragm	384-4811
172-5185	Shaft-Water Pump	325-6201

Sales Model 639D (Cont'd.)

88X		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365

88X		
Original Part Number	Part Name	Classic Part Number
172-7776	Pump Gp-Water -B	395-1314
174-6836	Gasket Kit - Tof	434-7280
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
221-6949	Kit-Dt Gasket	419-8663
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438

88X		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420

99X		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1P-7895	Cone-Roller Brg	396-4145
1S-9209	Shaft-Tightener	374-6499
1T-0334	Bearing-Ball	380-1476
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1W-5009	Crankshaft As	398-2969
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221

99X		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-6516	Bearing As-Rlr	435-2572
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-5233	Bearing-Thrust	388-0578

99X		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-5680	Turbine-Conv	308-9942
2P-8986	Cup-Rlr Bearing	415-1912
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2P-9314	Disc As-Clutch	384-4791
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-4087	Gear As-Idler	418-9582
2W-7980	Camshaft As	378-3972
2W-8038	Gear-Camshaft	425-7751

Sales Model 639D (Cont'd.)

99X		
Original Part Number	Part Name	Classic Part Number
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-7657	Cartridge Gp	422-8101
3G-7662	Cartridge Gp	422-8105
3G-7666	Cartridge Gp	422-8098
3G-7667	Cartridge Gp	422-8107
3G-7752	Pin As	384-4779
3H-8726	Mount As	385-7208
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-5100	Hub-Impeller	451-9022
3T-5102	Impeller-Conv	416-2125
4B-1455	Cap As-Filler	361-1719
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191

99X		
Original Part Number	Part Name	Classic Part Number
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1186	Bearing-Sleeve	417-4519
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-1849	Pipe-Air	421-7143
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6302	Belt Set-Vee	314-8495
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323

99X		
Original Part Number	Part Name	Classic Part Number
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5F-2830	Bearing-Needle	384-5925
5F-7404	Nut-Bearing Lock	308-9878
5J-6430	Bearing-Sleeve	379-0195
5L-6326	Bearing-Ball	420-3222
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5P-9972	Gasket Kit	393-5207
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883

Sales Model 639D (Cont'd.)

99X		
Original Part Number	Part Name	Classic Part Number
5T-3288	Yoke	424-0743
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5682	Driver	418-9579
5T-8525	Plate	389-6307
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-9430	Race-Seal Ring	398-8347
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6D-7788	Joint	380-7388
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1032	Line As-Fuel Inj	390-0931
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922
6I-1038	Line As-Fuel Inj	390-0923

99X		
Original Part Number	Part Name	Classic Part Number
6I-4613	Plate-Spacer	380-7405
6I-9507	Piston-Clutch	417-9470
6I-9509	Plate	398-2960
6L-7751	Rod End-Spher	472-8015
6N-0425	Coupling-Exhaust	394-9836
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-4597	Coupling-Exhaust	369-9489
6N-5300	Pulley-Cshaft	378-3979
6N-5354	Pipe-Extension	430-8130
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-7706	Carrier-Ring	388-6603
6T-1235	Gasket	433-8190
6T-3324	Housing As-Cl	391-9827
6V-0220	Kit-Gasket(Cl)	437-4588
6V-0241	Gasket Kit - F	393-3628
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
6V-5920	Gasket Kit - F	388-0653
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571

99X		
Original Part Number	Part Name	Classic Part Number
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7C-5665	Elbow-90 Deg	399-8547
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-3909	Tube-Exhaust	398-8339
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7F-7780	Pin-Anchor	384-4825
7H-7628	Bearing	453-3655
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5218	Manifold-Exhaust	435-4786
7N-5219	Manifold-Exhaust	425-2362
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296

Sales Model 639D (Cont'd.)

99X		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-6459	Core As-Oclr	395-1313
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-9926	Bearing-Sleeve	383-2115
8M-0874	Plunger As-Valve	311-9439
8M-8652	Shaft	297-7252
8N-0111	Mount As	374-1452
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0784	Manifold-Mount	393-1044
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247

99X		
Original Part Number	Part Name	Classic Part Number
8N-5305	Spacer	363-7464
8P-4520	Piston-Clutch	394-0908
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8W-0376	Shaft	394-9194
8X-6738	Shaft-Planet	394-8225
9D-0120	Gear-Planet	288-8737
9D-4094	Bearing-Sleeve	418-1933
9D-5444	Pin	380-7396
9D-6889	Plate As	394-9818
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1187	Bearing-Sleeve	384-4785
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9M-3914	Bearing-Aligning	420-2501
9N-1161	Line As-Fuel Inj	383-3705
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9N-5529	Body-F Inj Valve	378-3993

99X		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9S-8184	Pin-Drawbar	398-8345
9T-5096	Flexplate	455-3271
9W-1567	Impeller-Conv	391-9880
9W-4662	Disc-Friction	428-7203
9W-4702	Stator-Converter	308-9939
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
102-8608	Manifold-Exhaust	376-9062
105-2070	Bushing	394-0221
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8112	Manifold-Exh	376-9063

Sales Model 639D (Cont'd.)

99X		
Original Part Number	Part Name	Classic Part Number
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-2255	Gear-Bevel	446-3076
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-4525	Gage As	386-3043
127-6356	Cover As.-Pump	420-8566
129-3068	Rebuild Kit-Pump	363-7455

99X		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
141-4109	Core As-Oclr	416-5518
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
155-6637	Gear-Oil Drive	425-9189
155-6648	Cone Spl Rol Brg	418-9599
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-4109	Manifold-Exhaust	433-9857
167-8126	Damper As	382-8019
170-8541	Core As-Rdtr	379-0180

99X		
Original Part Number	Part Name	Classic Part Number
171-6696	Diaphragm	384-4811
174-6836	Gasket Kit - Tof	434-7280
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
232-1841	Kit-Gasket (Fs)	387-2922
253-1752	Plate-Thrust	379-0170
262-4339	Kit-Dt Gasket	451-1509
283-5666	Gasket-Cyl Head	388-6565
307-1303	Muffler As.	361-6574
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

Sales Model 641

41M		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1M-6573	Cup-Roller Brg	399-4438

41M		
Original Part Number	Part Name	Classic Part Number
1S-8607	Baffle	380-7540
1S-9110	Bearing-Needle	420-2497
1T-0299	Cup-Roller Brg	422-6494

41M		
Original Part Number	Part Name	Classic Part Number
1T-0365	Flange-Joint	434-1861
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709

Sales Model 641 (Cont'd.)

41M		
Original Part Number	Part Name	Classic Part Number
2D-9191	Cone-Roller Brg	374-1837
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
3G-2717	Cartridge Gp	439-1132
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356

41M		
Original Part Number	Part Name	Classic Part Number
3P-1686	Plate-Clutch	388-0586
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4S-5367	Mount As	375-9986
4T-7819	Cyl Gp-051 127 Y	426-0028
5D-0470	Valve Gp-Qrel	314-8549
5F-8651	Bearing-Ball	420-3223
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-6424	Bearing-Aligning	416-2135
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397

41M		
Original Part Number	Part Name	Classic Part Number
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6V-2202	Bearing-Spl Ball	380-1574
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7M-7219	Bearing-Thrust	384-4816
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-5026	Cover-Adj Pulley	445-7698
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-3368	Valve-Check	388-6599
8N-3666	Repair Kt-Major	377-5842
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-9686	Gasket Kit	393-5215
9D-5444	Pin	380-7396
9J-9487	Bearing-Sleeve	447-0822
9M-2744	Cone-Spl Tapered	380-1480

Sales Model 641 (Cont'd.)

41M		
Original Part Number	Part Name	Classic Part Number
9M-3914	Bearing-Aligning	420-2501
9M-8395	Bearing-Sleeve	391-1103
9S-5771	Bushing As	385-7219
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271

41M		
Original Part Number	Part Name	Classic Part Number
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
101-1503	Shaft	394-9199
110-1337	Ring Kit-Pstn	377-5834

41M		
Original Part Number	Part Name	Classic Part Number
128-3935	Bearing-Race	396-9897
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
208-8797	Retainer	432-8908
333-9877	Pin As	394-0217

42M		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1W-6005	Bearing-Sleeve	417-4521
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418

42M		
Original Part Number	Part Name	Classic Part Number
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492
2S-3966	Ring-Seal	297-7237
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
3G-0034	Trunnion	361-1712
3G-2717	Cartridge Gp	439-1132
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920

42M		
Original Part Number	Part Name	Classic Part Number
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-9215	Gear-Pump Idler	311-9391
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-5693	Bearing-Con Rod	419-6324

Sales Model 641 (Cont'd.)

42M		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5H-7071	Director-Water	388-0555
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-6424	Bearing-Aligning	416-2135
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5K-2294	Bearing	396-9912
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883

42M		
Original Part Number	Part Name	Classic Part Number
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636

43M		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839

42M		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-9489	Chamber As	247-3301
8S-3517	Bearing-Spl Ball	417-4501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
9D-5444	Pin	380-7396
9J-9487	Bearing-Sleeve	447-0822
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
101-1503	Shaft	394-9199
106-7799	Bearing-Ball	396-9947
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
208-8797	Retainer	432-8908
333-9877	Pin As	394-0217

Sales Model 641 (Cont'd.)

43M		
Original Part Number	Part Name	Classic Part Number
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1W-6005	Bearing-Sleeve	417-4521
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492
2S-3966	Ring-Seal	297-7237
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979

43M		
Original Part Number	Part Name	Classic Part Number
3G-0034	Trunnion	361-1712
3G-2717	Cartridge Gp	439-1132
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-9215	Gear-Pump Idler	311-9391
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-5693	Bearing-Con Rod	419-6324

43M		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5H-7071	Director-Water	388-0555
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-6424	Bearing-Aligning	416-2135
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5K-2294	Bearing	396-9912
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065

Sales Model 641 (Cont'd.)

43M		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649

43M		
Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As-Radiator	295-6417
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-9489	Chamber As	247-3301
8S-3517	Bearing-Spl Ball	417-4501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
9D-5444	Pin	380-7396
9J-9487	Bearing-Sleeve	447-0822

43M		
Original Part Number	Part Name	Classic Part Number
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
101-1503	Shaft	394-9199
106-7799	Bearing-Ball	396-9947
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
208-8797	Retainer	432-8908
333-9877	Pin As	394-0217

70G		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488

70G		
Original Part Number	Part Name	Classic Part Number
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1W-6005	Bearing-Sleeve	417-4521
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

70G		
Original Part Number	Part Name	Classic Part Number
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305

Sales Model 641 (Cont'd.)

70G		
Original Part Number	Part Name	Classic Part Number
2M-8714	Cone-Roller Brg	420-2492
2S-3966	Ring-Seal	297-7237
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
3G-0034	Trunnion	361-1712
3G-2717	Cartridge Gp	439-1132
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609

70G		
Original Part Number	Part Name	Classic Part Number
4M-9215	Gear-Pump Idler	311-9391
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-5693	Bearing-Con Rod	419-6324
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5H-7071	Director-Water	388-0555
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-6424	Bearing-Aligning	416-2135
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5K-2294	Bearing	396-9912
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883

70G		
Original Part Number	Part Name	Classic Part Number
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252

Sales Model 641 (Cont'd.)

70G		
Original Part Number	Part Name	Classic Part Number
8N-9489	Chamber As	247-3301
8S-3517	Bearing-Spl Ball	417-4501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
9D-5444	Pin	380-7396
9J-9487	Bearing-Sleeve	447-0822

70G		
Original Part Number	Part Name	Classic Part Number
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234

70G		
Original Part Number	Part Name	Classic Part Number
9V-9840	Spider	417-9498
101-1503	Shaft	394-9199
106-7799	Bearing-Ball	396-9947
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
208-8797	Retainer	432-8908
333-9877	Pin As	394-0217

80F		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1W-6005	Bearing-Sleeve	417-4521
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

80F		
Original Part Number	Part Name	Classic Part Number
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492
2S-3966	Ring-Seal	297-7237
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
3G-0034	Trunnion	361-1712
3G-2717	Cartridge Gp	439-1132
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922

80F		
Original Part Number	Part Name	Classic Part Number
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-7534	Bearing As-Rlr	441-5602

Sales Model 641 (Cont'd.)

80F		
Original Part Number	Part Name	Classic Part Number
4F-2041	Cup-Roller Brg	418-9609
4M-9215	Gear-Pump Idler	311-9391
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-5693	Bearing-Con Rod	419-6324
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5H-7071	Director-Water	388-0555
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-6424	Bearing-Aligning	416-2135
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5K-2294	Bearing	396-9912
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956

80F		
Original Part Number	Part Name	Classic Part Number
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
8F-6058	Bearing-Sleeve	416-5494

80F		
Original Part Number	Part Name	Classic Part Number
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-9489	Chamber As	247-3301
8S-3517	Bearing-Spl Ball	417-4501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
9D-5444	Pin	380-7396
9J-9487	Bearing-Sleeve	447-0822
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
101-1503	Shaft	394-9199
106-7799	Bearing-Ball	396-9947
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
208-8797	Retainer	432-8908
333-9877	Pin As	394-0217

Sales Model 641 (Cont'd.)

64F		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1M-6573	Cup-Roller Brg	399-4438
1S-8607	Baffle	380-7540
1S-9110	Bearing-Needle	420-2497
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
3G-2717	Cartridge Gp	439-1132
3G-2720	Cartridge Gp-Rr	448-5051

64F		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4S-5367	Mount As	375-9986
4T-7819	Cyl Gp-051 127 Y	426-0028
5D-0470	Valve Gp-Qrel	314-8549
5F-8651	Bearing-Ball	420-3223
5J-1968	Shaft-Roller	386-4928

64F		
Original Part Number	Part Name	Classic Part Number
5J-4929	Bearing	256-4796
5J-6424	Bearing-Aligning	416-2135
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6H-3957	Bearing-Ball	311-9358
6L-2279	Plug-Ptf	419-4739
6V-2202	Bearing-Spl Ball	380-1574
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7M-7219	Bearing-Thrust	384-4816
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485

Sales Model 641 (Cont'd.)

64F		
Original Part Number	Part Name	Classic Part Number
8H-5026	Cover-Adj Pulley	445-7698
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-3368	Valve-Check	388-6599
8N-3666	Repair Kt-Major	377-5842
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-9686	Gasket Kit	393-5215
9D-5444	Pin	380-7396

64F		
Original Part Number	Part Name	Classic Part Number
9J-9487	Bearing-Sleeve	447-0822
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9M-8395	Bearing-Sleeve	391-1103
9S-5771	Bushing As	385-7219
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234

64F		
Original Part Number	Part Name	Classic Part Number
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
101-1503	Shaft	394-9199
110-1337	Ring Kit-Pstn	377-5834
128-3935	Bearing-Race	396-9897
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
208-8797	Retainer	432-8908
333-9877	Pin As	394-0217

Sale Model 641B

42M		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058

42M		
Original Part Number	Part Name	Classic Part Number
1W-6005	Bearing-Sleeve	417-4521
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492

42M		
Original Part Number	Part Name	Classic Part Number
2S-3966	Ring-Seal	297-7237
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
3G-0034	Trunnion	361-1712
3G-2717	Cartridge Gp	439-1132
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782

Sale Model 641B (Cont'd.)

42M		
Original Part Number	Part Name	Classic Part Number
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-9215	Gear-Pump Idler	311-9391
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-5693	Bearing-Con Rod	419-6324
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5H-7071	Director-Water	388-0555
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-6424	Bearing-Aligning	416-2135
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018

42M		
Original Part Number	Part Name	Classic Part Number
5K-2294	Bearing	396-9912
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451

42M		
Original Part Number	Part Name	Classic Part Number
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-9489	Chamber As	247-3301
8S-3517	Bearing-Spl Ball	417-4501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
9D-5444	Pin	380-7396
9J-9487	Bearing-Sleeve	447-0822
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498

Sale Model 641B (Cont'd.)

42M		
Original Part Number	Part Name	Classic Part Number
101-1503	Shaft	394-9199
106-7799	Bearing-Ball	396-9947
162-3904	Pump As-F Prm	391-1102

42M		
Original Part Number	Part Name	Classic Part Number
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355

42M		
Original Part Number	Part Name	Classic Part Number
208-8797	Retainer	432-8908
333-9877	Pin As	394-0217

43M		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1W-6005	Bearing-Sleeve	417-4521
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354

43M		
Original Part Number	Part Name	Classic Part Number
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492
2S-3966	Ring-Seal	297-7237
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
3G-0034	Trunnion	361-1712
3G-2717	Cartridge Gp	439-1132
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356

43M		
Original Part Number	Part Name	Classic Part Number
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-9215	Gear-Pump Idler	311-9391
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-5693	Bearing-Con Rod	419-6324
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5H-7071	Director-Water	388-0555
5J-1968	Shaft-Roller	386-4928

Sale Model 641B (Cont'd.)

43M		
Original Part Number	Part Name	Classic Part Number
5J-4929	Bearing	256-4796
5J-6424	Bearing-Aligning	416-2135
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5K-2294	Bearing	396-9912
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6V-2202	Bearing-Spl Ball	380-1574

43M		
Original Part Number	Part Name	Classic Part Number
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599

43M		
Original Part Number	Part Name	Classic Part Number
8M-8652	Shaft	297-7252
8N-9489	Chamber As	247-3301
8S-3517	Bearing-Spl Ball	417-4501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
9D-5444	Pin	380-7396
9J-9487	Bearing-Sleeve	447-0822
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
101-1503	Shaft	394-9199
106-7799	Bearing-Ball	396-9947
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
208-8797	Retainer	432-8908
333-9877	Pin As	394-0217

65K		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839

65K		
Original Part Number	Part Name	Classic Part Number
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913

65K		
Original Part Number	Part Name	Classic Part Number
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936

Sale Model 641B (Cont'd.)

65K		
Original Part Number	Part Name	Classic Part Number
1P-7125	Governor As	383-3672
1S-9209	Shaft-Tightener	374-6499
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1W-6005	Bearing-Sleeve	417-4521
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492
2S-3966	Ring-Seal	297-7237

65K		
Original Part Number	Part Name	Classic Part Number
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
2W-8437	Muffler As	385-7198
3E-6772	Seal-Water	382-8017
3G-0034	Trunnion	361-1712
3G-2720	Cartridge Gp-Rr	448-5051
3G-6846	Pump Gp-Vn Bsc-A	422-8165
3G-7660	Cartridge Gp	422-8103
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-7534	Bearing As-Rlr	441-5602

65K		
Original Part Number	Part Name	Classic Part Number
4F-2041	Cup-Roller Brg	418-9609
4M-9215	Gear-Pump Idler	311-9391
4N-0362	Cover As-Rgltr	419-4722
4N-0913	Screen As-Bell	374-7489
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-5693	Bearing-Con Rod	419-6324
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5H-7071	Director-Water	388-0555
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-6424	Bearing-Aligning	416-2135
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018

Sale Model 641B (Cont'd.)

65K		
Original Part Number	Part Name	Classic Part Number
5K-2294	Bearing	396-9912
5L-6326	Bearing-Ball	420-3222
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6G-5343	Bearing-Sleeve	450-9169
6H-3957	Bearing-Ball	311-9358
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6V-2202	Bearing-Spl Ball	380-1574
6W-3662	Ring-Drive	446-3079
6Y-3484	Bearing-Spl Ball	416-2166

65K		
Original Part Number	Part Name	Classic Part Number
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7N-7435	Kit-Major Repair	374-4724
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636

65K		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-8983	Hub-Fan Pulley	421-7227
8N-9489	Chamber As	247-3301
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9D-5444	Pin	380-7396
9J-9487	Bearing-Sleeve	447-0822
9L-5839	Coupling-Exhaust	374-7480
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498

Sale Model 641B (Cont'd.)

65K		
Original Part Number	Part Name	Classic Part Number
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

65K		
Original Part Number	Part Name	Classic Part Number
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
162-3904	Pump As-F Prm	391-1102
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
174-6836	Gasket Kit - Tof	434-7280
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055

65K		
Original Part Number	Part Name	Classic Part Number
187-8979	Gear As	393-3656
208-8795	Retainer	430-5355
208-8797	Retainer	432-8908
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
333-9877	Pin As	394-0217

70G		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1T-0679	Roller-Freewheel	384-4797

70G		
Original Part Number	Part Name	Classic Part Number
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1W-6005	Bearing-Sleeve	417-4521

70G		
Original Part Number	Part Name	Classic Part Number
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850

Sale Model 641B (Cont'd.)

70G		
Original Part Number	Part Name	Classic Part Number
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492
2S-3966	Ring-Seal	297-7237
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
3G-0034	Trunnion	361-1712
3G-2717	Cartridge Gp	439-1132
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494

70G		
Original Part Number	Part Name	Classic Part Number
4D-4065	Rod End-Spher	374-1824
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-9215	Gear-Pump Idler	311-9391
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-5693	Bearing-Con Rod	419-6324
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5H-7071	Director-Water	388-0555
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-6424	Bearing-Aligning	416-2135
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5K-2294	Bearing	396-9912
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467

70G		
Original Part Number	Part Name	Classic Part Number
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485

Sale Model 641B (Cont'd.)

70G		
Original Part Number	Part Name	Classic Part Number
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-9489	Chamber As	247-3301
8S-3517	Bearing-Spl Ball	417-4501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613

70G		
Original Part Number	Part Name	Classic Part Number
8W-3613	Bearing	418-1960
9D-5444	Pin	380-7396
9J-9487	Bearing-Sleeve	447-0822
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9T-5096	Flexplate	455-3271

70G		
Original Part Number	Part Name	Classic Part Number
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
101-1503	Shaft	394-9199
106-7799	Bearing-Ball	396-9947
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
208-8797	Retainer	432-8908
333-9877	Pin As	394-0217

80F		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1W-6005	Bearing-Sleeve	417-4521
1W-8539	Bearing-Conn Rod	419-7251

80F		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492
2S-3966	Ring-Seal	297-7237
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
3G-0034	Trunnion	361-1712
3G-2717	Cartridge Gp	439-1132

80F		
Original Part Number	Part Name	Classic Part Number
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509

Sale Model 641B (Cont'd.)

80F		
Original Part Number	Part Name	Classic Part Number
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-9215	Gear-Pump Idler	311-9391
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-5693	Bearing-Con Rod	419-6324
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5H-7071	Director-Water	388-0555
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-6424	Bearing-Aligning	416-2135
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5K-2294	Bearing	396-9912
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433

80F		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417

80F		
Original Part Number	Part Name	Classic Part Number
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-9489	Chamber As	247-3301
8S-3517	Bearing-Spl Ball	417-4501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
9D-5444	Pin	380-7396
9J-9487	Bearing-Sleeve	447-0822
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
101-1503	Shaft	394-9199
106-7799	Bearing-Ball	396-9947
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
208-8797	Retainer	432-8908
333-9877	Pin As	394-0217

Sales Model 650

22G		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1W-6005	Bearing-Sleeve	417-4521
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492
2S-3966	Ring-Seal	297-7237
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
3G-0034	Trunnion	361-1712

22G		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-9215	Gear-Pump Idler	311-9391
4W-5693	Bearing-Con Rod	419-6324
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5F-8651	Bearing-Ball	420-3223

22G		
Original Part Number	Part Name	Classic Part Number
5H-7071	Director-Water	388-0555
5J-1968	Shaft-Roller	386-4928
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6G-0078	Breather	435-4789
6I-8860	Cup-Roller Brg	380-7495
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7J-0373	Shaft As	399-8578
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132

Sales Model 650 (Cont'd.)

22G		
Original Part Number	Part Name	Classic Part Number
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-9489	Chamber As	247-3301
8S-3517	Bearing-Spl Ball	417-4501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
9D-5444	Pin	380-7396
9M-2744	Cone-Spl Tapered	380-1480
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
101-1503	Shaft	394-9199

22G		
Original Part Number	Part Name	Classic Part Number
106-7799	Bearing-Ball	396-9947
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8797	Retainer	432-8908
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024
273-3160	Ballstud	396-9954
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1W-6005	Bearing-Sleeve	417-4521
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852

22G		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492
2S-3966	Ring-Seal	297-7237
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
3G-0034	Trunnion	361-1712
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-9215	Gear-Pump Idler	311-9391
4W-5693	Bearing-Con Rod	419-6324

Sales Model 650 (Cont'd.)

22G		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5J-1968	Shaft-Roller	386-4928
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065

22G		
Original Part Number	Part Name	Classic Part Number
6G-0078	Breather	435-4789
6I-8860	Cup-Roller Brg	380-7495
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7J-0373	Shaft As	399-8578
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636

22G		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-9489	Chamber As	247-3301
8S-3517	Bearing-Spl Ball	417-4501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
9D-5444	Pin	380-7396
9M-2744	Cone-Spl Tapered	380-1480
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
101-1503	Shaft	394-9199
106-7799	Bearing-Ball	396-9947
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8797	Retainer	432-8908
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024
273-3160	Ballstud	396-9954

23G		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839

23G		
Original Part Number	Part Name	Classic Part Number
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913

23G		
Original Part Number	Part Name	Classic Part Number
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936

Sales Model 650 (Cont'd.)

23G		
Original Part Number	Part Name	Classic Part Number
1P-7125	Governor As	383-3672
1S-9209	Shaft-Tightener	374-6499
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1W-6005	Bearing-Sleeve	417-4521
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492
2S-3966	Ring-Seal	297-7237
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979

23G		
Original Part Number	Part Name	Classic Part Number
2S-6150	Cover-Pulley	428-8817
2W-6280	Bracket As-Fan	431-5271
3E-6772	Seal-Water	382-8017
3G-0034	Trunnion	361-1712
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609

23G		
Original Part Number	Part Name	Classic Part Number
4M-9215	Gear-Pump Idler	311-9391
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-5693	Bearing-Con Rod	419-6324
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5H-7071	Director-Water	388-0555
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5K-2294	Bearing	396-9912
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433

Sales Model 650 (Cont'd.)

23G		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816

23G		
Original Part Number	Part Name	Classic Part Number
7N-1164	Mount As	295-5451
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7N-7435	Kit-Major Repair	374-4724
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-5579	Retainer	425-3451
8N-8983	Hub-Fan Pulley	421-7227
8N-9489	Chamber As	247-3301
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
9D-5444	Pin	380-7396
9J-8323	Trunnion	361-1713
9J-9487	Bearing-Sleeve	447-0822

23G		
Original Part Number	Part Name	Classic Part Number
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
153-7023	Valve-Inlet	391-1106

Sales Model 650 (Cont'd.)

23G		
Original Part Number	Part Name	Classic Part Number
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
162-3904	Pump As-F Prm	391-1102
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811

23G		
Original Part Number	Part Name	Classic Part Number
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
208-8797	Retainer	432-8908
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914

23G		
Original Part Number	Part Name	Classic Part Number
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
333-9877	Pin As	394-0217

45M		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1S-9209	Shaft-Tightener	374-6499
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1W-6005	Bearing-Sleeve	417-4521
1W-7238	Shaft As-Pump Dr	379-0164

45M		
Original Part Number	Part Name	Classic Part Number
1W-7239	Shaft As-Idler	379-0163
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492
2S-3966	Ring-Seal	297-7237
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-6280	Bracket As-Fan	431-5271

45M		
Original Part Number	Part Name	Classic Part Number
3E-6772	Seal-Water	382-8017
3G-0034	Trunnion	361-1712
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334

Sales Model 650 (Cont'd.)

45M		
Original Part Number	Part Name	Classic Part Number
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-9215	Gear-Pump Idler	311-9391
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-5693	Bearing-Con Rod	419-6324
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5H-7071	Director-Water	388-0555
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-8103	Bearing-Sleeve	389-6309

45M		
Original Part Number	Part Name	Classic Part Number
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5K-2294	Bearing	396-9912
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488

45M		
Original Part Number	Part Name	Classic Part Number
7G-2494	Gear-Planet	422-2490
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7N-7435	Kit-Major Repair	374-4724
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-5579	Retainer	425-3451
8N-8983	Hub-Fan Pulley	421-7227
8N-9489	Chamber As	247-3301
8S-3517	Bearing-Spl Ball	417-4501

Sales Model 650 (Cont'd.)

45M		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
9D-5444	Pin	380-7396
9J-8323	Trunnion	361-1713
9J-9487	Bearing-Sleeve	447-0822
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
101-9640	Gear-Air Compr	398-2966

45M		
Original Part Number	Part Name	Classic Part Number
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048

45M		
Original Part Number	Part Name	Classic Part Number
161-7128	Spring As.	419-4726
162-3904	Pump As-F Prm	391-1102
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
208-8797	Retainer	432-8908
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
333-9877	Pin As	394-0217

63F		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1M-6573	Cup-Roller Brg	399-4438
1S-8607	Baffle	380-7540
1S-9110	Bearing-Needle	420-2497

63F		
Original Part Number	Part Name	Classic Part Number
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2D-9457	Cone-Spl Tapered	377-7418

63F		
Original Part Number	Part Name	Classic Part Number
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469

Sales Model 650 (Cont'd.)

63F		
Original Part Number	Part Name	Classic Part Number
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
3G-2717	Cartridge Gp	439-1132
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3K-4290	Rod End	374-1823
3P-1686	Plate-Clutch	388-0586
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
5D-0470	Valve Gp-Qrel	314-8549

63F		
Original Part Number	Part Name	Classic Part Number
5F-8651	Bearing-Ball	420-3223
5J-1968	Shaft-Roller	386-4928
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6V-2202	Bearing-Spl Ball	380-1574
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7J-0373	Shaft As	399-8578
7M-7219	Bearing-Thrust	384-4816
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-5026	Cover-Adj Pulley	445-7698

63F		
Original Part Number	Part Name	Classic Part Number
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-3368	Valve-Check	388-6599
8N-3666	Repair Kt-Major	377-5842
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-9686	Gasket Kit	393-5215
9D-5444	Pin	380-7396
9M-2744	Cone-Spl Tapered	380-1480
9M-8395	Bearing-Sleeve	391-1103
9S-5771	Bushing As	385-7219
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
101-1503	Shaft	394-9199
110-1337	Ring Kit-Pstn	377-5834
128-3935	Bearing-Race	396-9897
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
208-8797	Retainer	432-8908
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024

Sales Model 650 (Cont'd.)

77F		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1S-8607	Baffle	380-7540
1S-9110	Bearing-Needle	420-2497
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
1U-2669	Cartridge Gp	422-8118
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533

77F		
Original Part Number	Part Name	Classic Part Number
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
3G-0034	Trunnion	361-1712
3G-2717	Cartridge Gp	439-1132
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3R-5327	Pipe-Extension	383-1571
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602

77F		
Original Part Number	Part Name	Classic Part Number
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
5D-0470	Valve Gp-Qrel	314-8549
5F-8651	Bearing-Ball	420-3223
5J-1968	Shaft-Roller	386-4928
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6N-9211	Core As-O Clr	435-6049
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488

Sales Model 650 (Cont'd.)

77F		
Original Part Number	Part Name	Classic Part Number
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7J-0373	Shaft As	399-8578
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8F-6058	Bearing-Sleeve	416-5494

77F		
Original Part Number	Part Name	Classic Part Number
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-5026	Cover-Adj Pulley	445-7698
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8N-3666	Repair Kt-Major	377-5842
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-5438	Muffler As	360-7896
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
9D-5444	Pin	380-7396
9M-2744	Cone-Spl Tapered	380-1480

77F		
Original Part Number	Part Name	Classic Part Number
9M-8395	Bearing-Sleeve	391-1103
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-5771	Bushing As	385-7219
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
101-1503	Shaft	394-9199
110-1337	Ring Kit-Pstn	377-5834
128-3935	Bearing-Race	396-9897
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
208-8797	Retainer	432-8908
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024

Sales Model 650B

58K		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507

58K		
Original Part Number	Part Name	Classic Part Number
1P-7125	Governor As	383-3672
1S-9209	Shaft-Tightener	374-6499
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107

58K		
Original Part Number	Part Name	Classic Part Number
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058

Sales Model 650B (Cont'd.)

58K		
Original Part Number	Part Name	Classic Part Number
1U-3953	Cartridge Gp	426-0024
1W-6005	Bearing-Sleeve	417-4521
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492
2S-3966	Ring-Seal	297-7237
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
2W-8437	Muffler As	385-7198
3E-6772	Seal-Water	382-8017
3G-0034	Trunnion	361-1712
3G-2717	Cartridge Gp	439-1132
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582

58K		
Original Part Number	Part Name	Classic Part Number
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-9215	Gear-Pump Idler	311-9391
4N-0362	Cover As-Rgltr	419-4722
4N-0913	Screen As-Bell	374-7489
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4W-5693	Bearing-Con Rod	419-6324
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

58K		
Original Part Number	Part Name	Classic Part Number
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5J-1968	Shaft-Roller	386-4928
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348

Sales Model 650B (Cont'd.)

58K		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6V-2202	Bearing-Spl Ball	380-1574
6W-3662	Ring-Drive	446-3079
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7J-0373	Shaft As	399-8578
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7N-7435	Kit-Major Repair	374-4724

58K		
Original Part Number	Part Name	Classic Part Number
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-8983	Hub-Fan Pulley	421-7227
8N-9489	Chamber As	247-3301
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9D-5444	Pin	380-7396
9L-5839	Coupling-Exhaust	374-7480
9M-2744	Cone-Spl Tapered	380-1480
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9S-9696	Spider As-Fan	383-3707

58K		
Original Part Number	Part Name	Classic Part Number
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
160-9874	Kit-Gasket-Scl	386-3048

Sales Model 650B (Cont'd.)

58K		
Original Part Number	Part Name	Classic Part Number
161-7128	Spring As.	419-4726
162-3904	Pump As-F Prm	391-1102
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
174-6836	Gasket Kit - Tof	434-7280
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656

58K		
Original Part Number	Part Name	Classic Part Number
208-8797	Retainer	432-8908
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024
246-3130	Shaft-Water Pump	392-4508

58K		
Original Part Number	Part Name	Classic Part Number
253-1752	Plate-Thrust	379-0170
273-3160	Ballstud	396-9954
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387

Sales Model 651

33G		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1M-6573	Cup-Roller Brg	399-4438
1S-8607	Baffle	380-7540
1S-9110	Bearing-Needle	420-2497
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257

33G		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208

33G		
Original Part Number	Part Name	Classic Part Number
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824

Sales Model 651 (Cont'd.)

33G		
Original Part Number	Part Name	Classic Part Number
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4S-5367	Mount As	375-9986
4T-7819	Cyl Gp-051 127 Y	426-0028
5D-0470	Valve Gp-Qrel	314-8549
5F-8651	Bearing-Ball	420-3223
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467

33G		
Original Part Number	Part Name	Classic Part Number
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6H-3957	Bearing-Ball	311-9358
6V-2202	Bearing-Spl Ball	380-1574
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7J-0373	Shaft As	399-8578
7M-7219	Bearing-Thrust	384-4816
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-5026	Cover-Adj Pulley	445-7698
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-3368	Valve-Check	388-6599

33G		
Original Part Number	Part Name	Classic Part Number
8N-3666	Repair Kt-Major	377-5842
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-9686	Gasket Kit	393-5215
9D-5444	Pin	380-7396
9J-9487	Bearing-Sleeve	447-0822
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9M-8395	Bearing-Sleeve	391-1103
9S-5771	Bushing As	385-7219
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
101-1503	Shaft	394-9199
110-1337	Ring Kit-Pstn	377-5834
128-3935	Bearing-Race	396-9897
171-6696	Diaphragm	384-4811
208-8797	Retainer	432-8908
221-6985	Retainer	399-4406
333-9877	Pin As	394-0217

44M		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-2846	Cap As-Filler	311-9368

44M		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-6573	Cup-Roller Brg	399-4438

44M		
Original Part Number	Part Name	Classic Part Number
1S-8607	Baffle	380-7540
1S-9110	Bearing-Needle	420-2497

Sales Model 651 (Cont'd.)

44M		
Original Part Number	Part Name	Classic Part Number
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691

44M		
Original Part Number	Part Name	Classic Part Number
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4S-5367	Mount As	375-9986
4T-7819	Cyl Gp-051 127 Y	426-0028
5D-0470	Valve Gp-Qrel	314-8549
5F-8651	Bearing-Ball	420-3223
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521

44M		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6H-3957	Bearing-Ball	311-9358
6V-2202	Bearing-Spl Ball	380-1574
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7J-0373	Shaft As	399-8578
7M-7219	Bearing-Thrust	384-4816
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-5026	Cover-Adj Pulley	445-7698
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-3368	Valve-Check	388-6599
8N-3666	Repair Kt-Major	377-5842
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565

Sales Model 651 (Cont'd.)

44M		
Original Part Number	Part Name	Classic Part Number
8S-9686	Gasket Kit	393-5215
9D-5444	Pin	380-7396
9J-9487	Bearing-Sleeve	447-0822
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9M-8395	Bearing-Sleeve	391-1103

44M		
Original Part Number	Part Name	Classic Part Number
9S-5771	Bushing As	385-7219
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202

44M		
Original Part Number	Part Name	Classic Part Number
101-1503	Shaft	394-9199
110-1337	Ring Kit-Pstn	377-5834
128-3935	Bearing-Race	396-9897
171-6696	Diaphragm	384-4811
208-8797	Retainer	432-8908
221-6985	Retainer	399-4406
333-9877	Pin As	394-0217

Sales Model 651B

23G		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1S-9209	Shaft-Tightener	374-6499
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058

23G		
Original Part Number	Part Name	Classic Part Number
1W-6005	Bearing-Sleeve	417-4521
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492

23G		
Original Part Number	Part Name	Classic Part Number
2S-3966	Ring-Seal	297-7237
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-6280	Bracket As-Fan	431-5271
3E-6772	Seal-Water	382-8017
3G-0034	Trunnion	361-1712
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949

Sales Model 651B (Cont'd.)

23G		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-9215	Gear-Pump Idler	311-9391
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-5693	Bearing-Con Rod	419-6324
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511

23G		
Original Part Number	Part Name	Classic Part Number
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5H-7071	Director-Water	388-0555
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5K-2294	Bearing	396-9912
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171

23G		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7N-7435	Kit-Major Repair	374-4724
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342

Sales Model 651B (Cont'd.)

23G		
Original Part Number	Part Name	Classic Part Number
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-5579	Retainer	425-3451
8N-8983	Hub-Fan Pulley	421-7227
8N-9489	Chamber As	247-3301
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
9D-5444	Pin	380-7396
9J-8323	Trunnion	361-1713
9J-9487	Bearing-Sleeve	447-0822
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234

23G		
Original Part Number	Part Name	Classic Part Number
9V-9840	Spider	417-9498
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
153-7023	Valve-Inlet	391-1106

23G		
Original Part Number	Part Name	Classic Part Number
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
162-3904	Pump As-F Prm	391-1102
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
208-8797	Retainer	432-8908
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
333-9877	Pin As	394-0217

45M		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913

45M		
Original Part Number	Part Name	Classic Part Number
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1S-9209	Shaft-Tightener	374-6499

45M		
Original Part Number	Part Name	Classic Part Number
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488

Sales Model 651B (Cont'd.)

45M		
Original Part Number	Part Name	Classic Part Number
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1W-6005	Bearing-Sleeve	417-4521
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492
2S-3966	Ring-Seal	297-7237
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-6280	Bracket As-Fan	431-5271
3E-6772	Seal-Water	382-8017
3G-0034	Trunnion	361-1712
3G-2720	Cartridge Gp-Rr	448-5051

45M		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-9215	Gear-Pump Idler	311-9391
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986

45M		
Original Part Number	Part Name	Classic Part Number
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-5693	Bearing-Con Rod	419-6324
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5H-7071	Director-Water	388-0555
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5K-2294	Bearing	396-9912
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397

Sales Model 651B (Cont'd.)

45M		
Original Part Number	Part Name	Classic Part Number
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450

45M		
Original Part Number	Part Name	Classic Part Number
7N-7435	Kit-Major Repair	374-4724
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-5579	Retainer	425-3451
8N-8983	Hub-Fan Pulley	421-7227
8N-9489	Chamber As	247-3301
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-3613	Bearing	418-1960
9D-5444	Pin	380-7396
9J-8323	Trunnion	361-1713
9J-9487	Bearing-Sleeve	447-0822
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345

45M		
Original Part Number	Part Name	Classic Part Number
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
162-3904	Pump As-F Prm	391-1102
167-8126	Damper As	382-8019

Sales Model 651B (Cont'd.)

45M		
Original Part Number	Part Name	Classic Part Number
171-6696	Diaphragm	384-4811
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
208-8797	Retainer	432-8908

45M		
Original Part Number	Part Name	Classic Part Number
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508

45M		
Original Part Number	Part Name	Classic Part Number
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443
333-9877	Pin As	394-0217

67K		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1S-9209	Shaft-Tightener	374-6499
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1W-5009	Crankshaft As	398-2969
1W-6005	Bearing-Sleeve	417-4521
1W-6185	Shield As	374-4704

67K		
Original Part Number	Part Name	Classic Part Number
1W-6186	Shield As	374-4705
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492
2N-5842	Screw-Bridge Adj	418-1934
2S-3966	Ring-Seal	297-7237
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979

67K		
Original Part Number	Part Name	Classic Part Number
2S-6150	Cover-Pulley	428-8817
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
2W-8038	Gear-Camshaft	425-7751
2W-8437	Muffler As	385-7198
3E-6772	Seal-Water	382-8017
3G-0034	Trunnion	361-1712
3G-2720	Cartridge Gp-Rr	448-5051
3G-6846	Pump Gp-Vn Bsc-A	422-8165
3G-7660	Cartridge Gp	422-8103
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356

Sales Model 651B (Cont'd.)

67K		
Original Part Number	Part Name	Classic Part Number
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-9215	Gear-Pump Idler	311-9391
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-1186	Bearing-Sleeve	417-4519
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450

67K		
Original Part Number	Part Name	Classic Part Number
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-0419	Core As-Oclr	379-0182
4W-5693	Bearing-Con Rod	419-6324
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5F-7404	Nut-Bearing Lock	308-9878

67K		
Original Part Number	Part Name	Classic Part Number
5H-7071	Director-Water	388-0555
5J-1968	Shaft-Roller	386-4928
5J-4929	Bearing	256-4796
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5K-2294	Bearing	396-9912
5L-6326	Bearing-Ball	420-3222
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6G-5343	Bearing-Sleeve	450-9169
6H-3957	Bearing-Ball	311-9358
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348

Sales Model 651B (Cont'd.)

67K		
Original Part Number	Part Name	Classic Part Number
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-3641	Pulley-Tightener	380-7536
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-3205	Manifold-Inlet	376-9060
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664

67K		
Original Part Number	Part Name	Classic Part Number
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599

67K		
Original Part Number	Part Name	Classic Part Number
8M-8652	Shaft	297-7252
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1619	Shield As	377-5857
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-8983	Hub-Fan Pulley	421-7227
8N-9489	Chamber As	247-3301
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9D-5444	Pin	380-7396
9J-8323	Trunnion	361-1713
9J-9487	Bearing-Sleeve	447-0822
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9S-3581	Cup-Roller Brg	415-1923

Sales Model 651B (Cont'd.)

67K		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1503	Shaft	394-9199
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3125	Gasket	420-8567
101-3374	Gear-Cam-shaft Dr	376-9069
101-7354	Manifold-Exhaust	386-3060
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
108-5603	Screw-Adj Arm	379-0166

67K		
Original Part Number	Part Name	Classic Part Number
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
114-0915	Shield As.	394-0887
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
126-5057	Shield As-Man Lh	369-9493
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-2151	Tensioner	419-4735
135-3225	Shaft As	399-8582

67K		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-9381	Plate-Spacer	424-7052
141-4109	Core As-Oclr	416-5518
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
162-0152	Bearing-Sleeve	422-9519
162-3904	Pump As-F Prm	391-1102
163-3103	Manifold-Exh	430-8992
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
174-6836	Gasket Kit - Tof	434-7280
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
208-8797	Retainer	432-8908
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914

Sales Model 651B (Cont'd.)

67K		
Original Part Number	Part Name	Classic Part Number
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170

67K		
Original Part Number	Part Name	Classic Part Number
278-1365	Arm As-Ui Rkr	433-7507
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387

67K		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
333-9877	Pin As	394-0217
352-0200	Pump Gp-Water -B	434-6109
352-0209	Pump Gp-Water -B	375-4336

Sales Model 651E

4YR		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1S-9209	Shaft-Tightener	374-6499
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058

4YR		
Original Part Number	Part Name	Classic Part Number
1U-0145	Bearing-Thrust	417-9482
1U-3969	Pump Gp-Vn Bsc-B	422-8150
1W-3397	Plate	391-9810
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-6183	Shield As-Manf	367-6083
1W-6184	Shield As	416-5524
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418

4YR		
Original Part Number	Part Name	Classic Part Number
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8714	Cone-Roller Brg	420-2492
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1757	Hub-Fan Pulley	296-1357
2S-5735	Plate-Clutch	398-2964

Sales Model 651E (Cont'd.)

4YR		
Original Part Number	Part Name	Classic Part Number
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
2W-6632	Core As-Rad	391-1096
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-2720	Cartridge Gp-Rr	448-5051
3G-6846	Pump Gp-Vn Bsc-A	422-8165
3G-7660	Cartridge Gp	422-8103
3G-8136	Retainer	425-3585
3G-8245	Bearing-Sleeve	399-8586
3G-8621	Cyl Gp-092 299 Y	399-8554
3J-2373	Bearing-Sleeve	380-7562
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-6107	Bearing-Roller	380-7507

4YR		
Original Part Number	Part Name	Classic Part Number
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1675	Manifold-Exhaust	443-2015
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894

4YR		
Original Part Number	Part Name	Classic Part Number
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4S-5367	Mount As	375-9986
4W-0419	Core As-Oclr	379-0182
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5J-4929	Bearing	256-4796
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018

Sales Model 651E (Cont'd.)

4YR		
Original Part Number	Part Name	Classic Part Number
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-6819	Pin	425-2563
5T-6820	Bearing	425-3447
5T-8525	Plate	389-6307
5T-8687	Pin As	423-3542
5T-9430	Race-Seal Ring	398-8347
5T-9536	Roller-Ejector	399-8559
5T-9594	Pin As	419-6069
6B-3223	Cup-Bearing	399-6065
6G-0078	Breather	435-4789
6G-2707	Shaft-Axle	422-2650
6G-2749	Camshaft	422-4933
6G-2750	Camshaft	422-4927
6G-3784	Bearing-Sleeve	425-6455
6G-3785	Bearing-Sleeve	425-6454
6G-6844	Bearing-Sleeve	419-6070

4YR		
Original Part Number	Part Name	Classic Part Number
6G-6847	Bearing-Sleeve	419-4723
6H-3957	Bearing-Ball	311-9358
6K-4442	Rod End-Special	373-5388
6N-0977	Bearing-Sleeve	417-4524
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-7476	Kit-Dt Gasket	390-5282
6W-3662	Ring-Drive	446-3079
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7G-2494	Gear-Planet	422-2490
7G-7431	Piston-Selector	432-8911

4YR		
Original Part Number	Part Name	Classic Part Number
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886

Sales Model 651E (Cont'd.)

4YR		
Original Part Number	Part Name	Classic Part Number
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3304	Pulley-Tightener	419-4708
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8N-7486	Condenser As	436-2263
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8T-0209	Race-Spl Rlr Brg	384-5951
8X-0962	Pin	423-3539
8X-0967	Pin As	425-6445
9D-5444	Pin	380-7396
9J-1379	Pin As	389-6303
9J-8323	Trunnion	361-1713
9L-2685	Rod End	419-1866
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005

4YR		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9T-5096	Flexplate	455-3271
9V-9840	Spider	417-9498
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1503	Shaft	394-9199
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Cam-shaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166

4YR		
Original Part Number	Part Name	Classic Part Number
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-2707	Kit-Gasket (Bsc)	392-4506
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813

Sales Model 651E (Cont'd.)

4YR		
Original Part Number	Part Name	Classic Part Number
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-4037	Kit-Gasket (Acl)	438-1797
141-1939	Gasket Kit	437-4613
141-4109	Core As-Oclr	416-5518
142-1699	Gasket Kit	392-4507
142-2303	Pin As	423-3537
155-6637	Gear-Oil Drive	425-9189

4YR		
Original Part Number	Part Name	Classic Part Number
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
176-1402	Pin	425-2562
180-6645	Shaft As.	396-1566
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
221-6985	Retainer	399-4406

4YR		
Original Part Number	Part Name	Classic Part Number
234-1630	Kit-Gasket (Rs)	393-1040
243-0731	Kit-Dt Gasket	451-1507
252-0168	Link Assembly	433-9210
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
333-9877	Pin As	394-0217
347-6081	Gauge As	360-2348
352-0200	Pump Gp-Water -B	434-6109

5XR		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1S-1888	Bracket-Lamp	297-7147
1S-9209	Shaft-Tightener	374-6499
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651

5XR		
Original Part Number	Part Name	Classic Part Number
1T-0876	Hub-Turbine	397-5058
1U-0145	Bearing-Thrust	417-9482
1U-3969	Pump Gp-Vn Bsc-B	422-8150
1W-4369	Pulley-Alt	296-1340
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2K-5069	Cup-Roller Brg	374-8346

5XR		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492
2N-5842	Screw-Bridge Adj	418-1934
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-6632	Core As-Rad	391-1096
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-2720	Cartridge Gp-Rr	448-5051
3G-8136	Retainer	425-3585
3G-8245	Bearing-Sleeve	399-8586
3G-8621	Cyl Gp-092 299 Y	399-8554

Sales Model 651E (Cont'd.)

5XR		
Original Part Number	Part Name	Classic Part Number
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4S-5367	Mount As	375-9986
4W-0419	Core As-Oclr	379-0182

5XR		
Original Part Number	Part Name	Classic Part Number
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-6819	Pin	425-2563

5XR		
Original Part Number	Part Name	Classic Part Number
5T-6820	Bearing	425-3447
5T-8525	Plate	389-6307
5T-8687	Pin As	423-3542
5T-9430	Race-Seal Ring	398-8347
5T-9536	Roller-Ejector	399-8559
5T-9594	Pin As	419-6069
6B-3223	Cup-Bearing	399-6065
6G-0078	Breather	435-4789
6G-2707	Shaft-Axle	422-2650
6G-2749	Camshaft	422-4933
6G-2750	Camshaft	422-4927
6G-3784	Bearing-Sleeve	425-6455
6G-3785	Bearing-Sleeve	425-6454
6G-6844	Bearing-Sleeve	419-6070
6G-6847	Bearing-Sleeve	419-4723
6H-3957	Bearing-Ball	311-9358
6K-4442	Rod End-Special	373-5388
6N-0977	Bearing-Sleeve	417-4524
6N-1572	Mount As	308-9876
6N-3641	Pulley-Tightener	380-7536
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6T-5611	Spacer	435-8520
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7C-0145	Core As-Oclr	374-4720

Sales Model 651E (Cont'd.)

5XR		
Original Part Number	Part Name	Classic Part Number
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-3205	Manifold-Inlet	376-9060
7E-5996	Rod As-Conn	379-8864
7G-2494	Gear-Planet	422-2490
7G-7431	Piston-Selector	432-8911
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7K-2135	Bearing-Roller	417-4492
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
8H-4320	Bearing-Ball	419-2301
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1619	Shield As	377-5857
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547

5XR		
Original Part Number	Part Name	Classic Part Number
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-7486	Condenser As	436-2263
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8T-0209	Race-Spl Rlr Brg	384-5951
8X-0962	Pin	423-3539
8X-0967	Pin As	425-6445
9D-5444	Pin	380-7396
9J-1379	Pin As	389-6303
9J-8323	Trunnion	361-1713
9L-2685	Rod End	419-1866
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9N-3668	Base As.-Coolant	419-4718
9S-8184	Pin-Drawbar	398-8345
9T-5096	Flexplate	455-3271
9V-9840	Spider	417-9498
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1503	Shaft	394-9199
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690

5XR		
Original Part Number	Part Name	Classic Part Number
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Cam-shaft Dr	376-9069
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193

Sales Model 651E (Cont'd.)

5XR		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
141-4109	Core As-Oclr	416-5518
142-2303	Pin As	423-3537

5XR		
Original Part Number	Part Name	Classic Part Number
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
176-1402	Pin	425-2562
180-6645	Shaft As.	396-1566
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266

5XR		
Original Part Number	Part Name	Classic Part Number
221-6985	Retainer	399-4406
234-1630	Kit-Gasket (Rs)	393-1040
252-0168	Link Assembly	433-9210
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
333-9877	Pin As	394-0217
347-6081	Gauge As	360-2348
352-0200	Pump Gp-Water -B	434-6109

88Z		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-1888	Bracket-Lamp	297-7147
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601

88Z		
Original Part Number	Part Name	Classic Part Number
3G-8245	Bearing-Sleeve	399-8586
3G-8621	Cyl Gp-092 299 Y	399-8554
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-9133	Bearing-Sleeve	361-1691
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4N-2514	Gear-Flywheel	421-7283
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4P-9942	Seal-End Tank	385-7217

88Z		
Original Part Number	Part Name	Classic Part Number
4P-9943	Seal-End Tank	385-7216
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5P-7807	Bearing-Ball	314-8502
5T-3288	Yoke	424-0743
5T-6820	Bearing	425-3447
5T-9536	Roller-Ejector	399-8559
5T-9594	Pin As	419-6069
6G-2749	Camshaft	422-4933
6G-2750	Camshaft	422-4927
6G-6847	Bearing-Sleeve	419-4723
6H-3957	Bearing-Ball	311-9358

Sales Model 651E (Cont'd.)

88Z		
Original Part Number	Part Name	Classic Part Number
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6N-7653	Gage As-O Level	428-7206
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-2036	Cap As-Fuel	361-1721
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8H-9789	Bearing-Ball	374-8342
8N-8983	Hub-Fan Pulley	421-7227

88Z		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
9D-5444	Pin	380-7396
9J-1379	Pin As	389-6303
9J-8323	Trunnion	361-1713
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312

88Z		
Original Part Number	Part Name	Classic Part Number
144-0503	Piston & Ring Kt	380-1554
146-2601	Cover	399-6054
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

89Z		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849

Sales Model 651E (Cont'd.)

89Z		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1S-9209	Shaft-Tightener	374-6499
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1U-0145	Bearing-Thrust	417-9482
1U-3969	Pump Gp-Vn Bsc-B	422-8150
1W-3397	Plate	391-9810
1W-4369	Pulley-Alt	296-1340
1W-6183	Shield As-Manf	367-6083
1W-6184	Shield As	416-5524
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707

89Z		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8714	Cone-Roller Brg	420-2492
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2S-5100	Valve-Ball	386-3049
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
2W-6632	Core As-Rad	391-1096
3E-6772	Seal-Water	382-8017
3G-2720	Cartridge Gp-Rr	448-5051
3G-6846	Pump Gp-Vn Bsc-A	422-8165
3G-7660	Cartridge Gp	422-8103

89Z		
Original Part Number	Part Name	Classic Part Number
3G-8136	Retainer	425-3585
3G-8245	Bearing-Sleeve	399-8586
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-2582	Bearing-Spl Ball	417-9478
3P-2685	Piston-Clutch	308-9908
3S-3875	Screen-Suction	435-4849
4D-2619	Bearing	417-4494
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1675	Manifold-Exhaust	443-2015
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710

Sales Model 651E (Cont'd.)

89Z		
Original Part Number	Part Name	Classic Part Number
4N-5858	Cap-Cshft Brg	448-9157
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4S-5367	Mount As	375-9986
4W-0419	Core As-Oclr	379-0182
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333

89Z		
Original Part Number	Part Name	Classic Part Number
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5J-4929	Bearing	256-4796
5J-8103	Bearing-Sleeve	389-6309
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774
5P-5044	Race-Brg Outer	417-9479
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883

89Z		
Original Part Number	Part Name	Classic Part Number
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-6819	Pin	425-2563
5T-6820	Bearing	425-3447
5T-8525	Plate	389-6307
5T-8687	Pin As	423-3542
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6G-0078	Breather	435-4789
6G-2707	Shaft-Axle	422-2650
6G-2749	Camshaft	422-4933
6G-2750	Camshaft	422-4927
6G-3784	Bearing-Sleeve	425-6455
6G-3785	Bearing-Sleeve	425-6454
6G-6844	Bearing-Sleeve	419-6070
6G-6847	Bearing-Sleeve	419-4723
6H-3957	Bearing-Ball	311-9358
6I-9808	Bearing-Ball	417-9484
6K-4442	Rod End-Special	373-5388
6N-0977	Bearing-Sleeve	417-4524
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371

Sales Model 651E (Cont'd.)

89Z		
Original Part Number	Part Name	Classic Part Number
6T-5611	Spacer	435-8520
6T-7882	Gear-Planet	296-1352
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-4540	Gasket Kit - Wp	393-1021
6V-7476	Kit-Dt Gasket	390-5282
6W-3662	Ring-Drive	446-3079
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7B-7515	Bearing-Ball	399-6059
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7G-2494	Gear-Planet	422-2490
7G-5749	Piston-Clutch	416-2132
7G-7431	Piston-Selector	432-8911
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-6839	Hub-Clutch	399-4407

89Z		
Original Part Number	Part Name	Classic Part Number
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3304	Pulley-Tightener	419-4708
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8N-7486	Condenser As	436-2263

89Z		
Original Part Number	Part Name	Classic Part Number
8P-1919	Gear-Planet	300-2579
8P-2051	Plate-Clutch	385-6116
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0209	Race-Spl Rlr Brg	384-5951
8X-0962	Pin	423-3539
8X-0967	Pin As	425-6445
9D-5444	Pin	380-7396
9L-2685	Rod End	419-1866
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9S-8597	Spring	399-8561
9T-5096	Flexplate	455-3271
9V-9840	Spider	417-9498
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716

Sales Model 651E (Cont'd.)

89Z		
Original Part Number	Part Name	Classic Part Number
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1503	Shaft	394-9199
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Cam-shaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645

89Z		
Original Part Number	Part Name	Classic Part Number
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7569	Gasket Kit	393-1041
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
127-6356	Cover As.-Pump	420-8566
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053

89Z		
Original Part Number	Part Name	Classic Part Number
138-4037	Kit-Gasket (Acl)	438-1797
141-1939	Gasket Kit	437-4613
141-4109	Core As-Oclr	416-5518
142-2303	Pin As	423-3537
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
171-6696	Diaphragm	384-4811
176-1402	Pin	425-2562
180-6645	Shaft As.	396-1566
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
221-6985	Retainer	399-4406
232-1841	Kit-Gasket (Fs)	387-2922
234-1630	Kit-Gasket (Rs)	393-1040
243-0731	Kit-Dt Gasket	451-1507
252-0168	Link Assembly	433-9210
253-1752	Plate-Thrust	379-0170
291-9117	Kit-Gasket (Sch)	438-0148
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
333-9877	Pin As	394-0217
352-0200	Pump Gp-Water -B	434-6109

Sales Model 651H

W1D		
Original Part Number	Part Name	Classic Part Number
2J-1227	Retainer	440-0850
3G-0027	Pin As	388-6601
3G-8245	Bearing-Sleeve	399-8586
3G-8621	Cyl Gp-092 299 Y	399-8554
3J-2373	Bearing-Sleeve	380-7562

W1D		
Original Part Number	Part Name	Classic Part Number
3J-9133	Bearing-Sleeve	361-1691
4D-0487	Valve As-Check	375-4334
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5T-3288	Yoke	424-0743

W1D		
Original Part Number	Part Name	Classic Part Number
5T-9536	Roller-Ejector	399-8559
5T-9594	Pin As	419-6069
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
9J-1379	Pin As	389-6303
9J-8323	Trunnion	361-1713

Sales Model 657

05A		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1B-3922	Cup-Roller Brg	416-2158
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-6577	Cone-Spl Tapered	374-1839
1L-7319	Cup-Roller Brg	380-7499
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1S-9110	Bearing-Needle	420-2497
1S-9209	Shaft-Tightener	374-6499

05A		
Original Part Number	Part Name	Classic Part Number
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0767	Bearing-Sleeve	383-2108
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152

05A		
Original Part Number	Part Name	Classic Part Number
1T-1348	Support As-Carr	419-4049
1W-6005	Bearing-Sleeve	417-4521
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-8539	Bearing-Conn Rod	419-7251
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418

Sales Model 657 (Cont'd.)

05A		
Original Part Number	Part Name	Classic Part Number
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2M-8714	Cone-Roller Brg	420-2492
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-0034	Trunnion	361-1712
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562

05A		
Original Part Number	Part Name	Classic Part Number
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3P-4265	Piston-Clutch	397-5063
3R-5327	Pipe-Extension	383-1571
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952

05A		
Original Part Number	Part Name	Classic Part Number
4M-9215	Gear-Pump Idler	311-9391
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2474	Rotocoil As	388-6571
4W-5693	Bearing-Con Rod	419-6324
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5J-4929	Bearing	256-4796
5J-8103	Bearing-Sleeve	389-6309

Sales Model 657 (Cont'd.)

05A		
Original Part Number	Part Name	Classic Part Number
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5K-2294	Bearing	396-9912
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757

05A		
Original Part Number	Part Name	Classic Part Number
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6N-9211	Core As-O Clr	435-6049
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6Y-2065	Mount As-650 Cup	377-5844
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189

05A		
Original Part Number	Part Name	Classic Part Number
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0205	Core As-Oclr	379-0183
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8F-6058	Bearing-Sleeve	416-5494

Sales Model 657 (Cont'd.)

05A		
Original Part Number	Part Name	Classic Part Number
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-2104	Bell As-Suction	380-1521
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8N-9489	Chamber As	247-3301
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3517	Bearing-Spl Ball	417-4501
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-5438	Muffler As	360-7896
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8W-3613	Bearing	418-1960
8W-9728	Gear	399-6045
9D-5444	Pin	380-7396
9J-8323	Trunnion	361-1713

05A		
Original Part Number	Part Name	Classic Part Number
9J-9487	Bearing-Sleeve	447-0822
9L-5839	Coupling-Exhaust	374-7480
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9M-8395	Bearing-Sleeve	391-1103
9N-3167	Plate-Block Bot	430-4468
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058

05A		
Original Part Number	Part Name	Classic Part Number
104-8584	Housing-Rgltr	419-4725
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
146-2601	Cover	399-6054
148-0885	Stator-Converter	379-0161
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
162-3904	Pump As-F Prm	391-1102
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811

Sales Model 657 (Cont'd.)

05A		
Original Part Number	Part Name	Classic Part Number
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
208-8797	Retainer	432-8908
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665

05A		
Original Part Number	Part Name	Classic Part Number
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367

05A		
Original Part Number	Part Name	Classic Part Number
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
333-9877	Pin As	394-0217
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

19G		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1B-3922	Cup-Roller Brg	416-2158
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-6577	Cone-Spl Tapered	374-1839
1L-7319	Cup-Roller Brg	380-7499
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1S-9110	Bearing-Needle	420-2497
1S-9209	Shaft-Tightener	374-6499
1T-0299	Cup-Roller Brg	422-6494

19G		
Original Part Number	Part Name	Classic Part Number
1T-0365	Flange-Joint	434-1861
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0767	Bearing-Sleeve	383-2108
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-6005	Bearing-Sleeve	417-4521

19G		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-8539	Bearing-Conn Rod	419-7251
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2J-1227	Retainer	440-0850

Sales Model 657 (Cont'd.)

19G		
Original Part Number	Part Name	Classic Part Number
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2M-8714	Cone-Roller Brg	420-2492
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-0034	Trunnion	361-1712
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920

19G		
Original Part Number	Part Name	Classic Part Number
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3P-4265	Piston-Clutch	397-5063
3R-5327	Pipe-Extension	383-1571
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283

19G		
Original Part Number	Part Name	Classic Part Number
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2474	Rotocoil As	388-6571
4W-5693	Bearing-Con Rod	419-6324
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5J-4929	Bearing	256-4796
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5K-2294	Bearing	396-9912

Sales Model 657 (Cont'd.)

19G		
Original Part Number	Part Name	Classic Part Number
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6N-9211	Core As-O Clr	435-6049

19G		
Original Part Number	Part Name	Classic Part Number
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6Y-2065	Mount As-650 Cup	377-5844
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854

19G		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0205	Core As-Oclr	379-0183
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636

Sales Model 657 (Cont'd.)

19G		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-2104	Bell As-Suction	380-1521
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8N-9489	Chamber As	247-3301
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3517	Bearing-Spl Ball	417-4501
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-5438	Muffler As	360-7896
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8W-3613	Bearing	418-1960
8W-9728	Gear	399-6045
9D-5444	Pin	380-7396
9J-8323	Trunnion	361-1713
9J-9487	Bearing-Sleeve	447-0822
9L-5839	Coupling-Exhaust	374-7480
9M-1853	Mount As.	376-3638

19G		
Original Part Number	Part Name	Classic Part Number
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9M-8395	Bearing-Sleeve	391-1103
9N-3167	Plate-Block Bot	430-4468
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566

19G		
Original Part Number	Part Name	Classic Part Number
128-2922	Kit-Gasket (Wp)	386-3814
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
146-2601	Cover	399-6054
148-0885	Stator-Converter	379-0161
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
162-3904	Pump As-F Prm	391-1102
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
208-8797	Retainer	432-8908
211-0592	Bearing - Main	419-6368

Sales Model 657 (Cont'd.)

19G		
Original Part Number	Part Name	Classic Part Number
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508

19G		
Original Part Number	Part Name	Classic Part Number
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387

19G		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-4665
333-9877	Pin As	394-0217
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

31G		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1S-8607	Baffle	380-7540
1S-9110	Bearing-Needle	420-2497
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914

31G		
Original Part Number	Part Name	Classic Part Number
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817

31G		
Original Part Number	Part Name	Classic Part Number
2S-6196	Shaft-Pulley	438-9541
3F-6185	Pin	295-5694
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-6559	Cap-Bearing	296-1346
3J-9133	Bearing-Sleeve	361-1691
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3R-5327	Pipe-Extension	383-1571
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334

Sales Model 657 (Cont'd.)

31G		
Original Part Number	Part Name	Classic Part Number
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4J-2414	Trunnion	296-1370
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
4T-8054	Seal As	472-8010
5D-0470	Valve Gp-Qrel	314-8549
5F-8651	Bearing-Ball	420-3223
5J-4929	Bearing	256-4796
5J-6424	Bearing-Aligning	416-2135
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521

31G		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6N-9211	Core As-O Clr	435-6049
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7J-0373	Shaft As	399-8578
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8F-6058	Bearing-Sleeve	416-5494

31G		
Original Part Number	Part Name	Classic Part Number
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-5026	Cover-Adj Pulley	445-7698
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8N-3666	Repair Kt-Major	377-5842
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-5438	Muffler As	360-7896
8S-9686	Gasket Kit	393-5215
9D-5444	Pin	380-7396
9J-9487	Bearing-Sleeve	447-0822
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9M-8395	Bearing-Sleeve	391-1103
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-5771	Bushing As	385-7219
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202

Sales Model 657 (Cont'd.)

31G		
Original Part Number	Part Name	Classic Part Number
101-1503	Shaft	394-9199
110-1337	Ring Kit-Pstn	377-5834
128-3935	Bearing-Race	396-9897

31G		
Original Part Number	Part Name	Classic Part Number
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8797	Retainer	432-8908

31G		
Original Part Number	Part Name	Classic Part Number
221-6985	Retainer	399-4406
308-1845	Seal-Wiper	472-8032
333-9877	Pin As	394-0217

46M		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1S-8607	Baffle	380-7540
1S-9110	Bearing-Needle	420-2497
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257

46M		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2J-1227	Retainer	440-0850
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
3F-6185	Pin	295-5694
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-3953	Bearing-Sleeve	384-4778

46M		
Original Part Number	Part Name	Classic Part Number
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-6559	Cap-Bearing	296-1346
3J-9133	Bearing-Sleeve	361-1691
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3R-5327	Pipe-Extension	383-1571
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4J-2414	Trunnion	296-1370
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407

Sales Model 657 (Cont'd.)

46M		
Original Part Number	Part Name	Classic Part Number
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
4T-8054	Seal As	472-8010
5D-0470	Valve Gp-Qrel	314-8549
5F-8651	Bearing-Ball	420-3223
5J-4929	Bearing	256-4796
5J-6424	Bearing-Aligning	416-2135
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6F-2956	Cup-Spl Tapered	420-6538

46M		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6N-9211	Core As-O Clr	435-6049
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7J-0373	Shaft As	399-8578
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-5026	Cover-Adj Pulley	445-7698
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8N-3666	Repair Kt-Major	377-5842

46M		
Original Part Number	Part Name	Classic Part Number
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-5438	Muffler As	360-7896
8S-9686	Gasket Kit	393-5215
9D-5444	Pin	380-7396
9J-9487	Bearing-Sleeve	447-0822
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9M-8395	Bearing-Sleeve	391-1103
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-5771	Bushing As	385-7219
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
101-1503	Shaft	394-9199
110-1337	Ring Kit-Pstn	377-5834
128-3935	Bearing-Race	396-9897
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8797	Retainer	432-8908
221-6985	Retainer	399-4406
308-1845	Seal-Wiper	472-8032
333-9877	Pin As	394-0217

Sales Model 657 (Cont'd.)

47M		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1B-3922	Cup-Roller Brg	416-2158
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-6577	Cone-Spl Tapered	374-1839
1L-7319	Cup-Roller Brg	380-7499
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1S-9110	Bearing-Needle	420-2497
1S-9209	Shaft-Tightener	374-6499
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0767	Bearing-Sleeve	383-2108
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131

47M		
Original Part Number	Part Name	Classic Part Number
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-6005	Bearing-Sleeve	417-4521
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-8539	Bearing-Conn Rod	419-7251
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305

47M		
Original Part Number	Part Name	Classic Part Number
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2M-8714	Cone-Roller Brg	420-2492
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-0034	Trunnion	361-1712
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586

Sales Model 657 (Cont'd.)

47M		
Original Part Number	Part Name	Classic Part Number
3P-4265	Piston-Clutch	397-5063
3R-5327	Pipe-Extension	383-1571
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-5857	Cap-Bearing	376-9086

47M		
Original Part Number	Part Name	Classic Part Number
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2474	Rotocoil As	388-6571
4W-5693	Bearing-Con Rod	419-6324
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5J-4929	Bearing	256-4796
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5K-2294	Bearing	396-9912
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510

47M		
Original Part Number	Part Name	Classic Part Number
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6N-9211	Core As-O Clr	435-6049
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6Y-2065	Mount As-650 Cup	377-5844

Sales Model 657 (Cont'd.)

47M		
Original Part Number	Part Name	Classic Part Number
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450

47M		
Original Part Number	Part Name	Classic Part Number
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0205	Core As-Oclr	379-0183
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252

47M		
Original Part Number	Part Name	Classic Part Number
8N-2104	Bell As-Suction	380-1521
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8N-9489	Chamber As	247-3301
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3517	Bearing-Spl Ball	417-4501
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-5438	Muffler As	360-7896
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8W-3613	Bearing	418-1960
8W-9728	Gear	399-6045
9D-5444	Pin	380-7396
9J-8323	Trunnion	361-1713
9J-9487	Bearing-Sleeve	447-0822
9L-5839	Coupling-Exhaust	374-7480
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9M-8395	Bearing-Sleeve	391-1103

Sales Model 657 (Cont'd.)

47M		
Original Part Number	Part Name	Classic Part Number
9N-3167	Plate-Block Bot	430-4468
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566

47M		
Original Part Number	Part Name	Classic Part Number
128-2922	Kit-Gasket (Wp)	386-3814
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
146-2601	Cover	399-6054
148-0885	Stator-Converter	379-0161
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
162-3904	Pump As-F Prm	391-1102
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811

47M		
Original Part Number	Part Name	Classic Part Number
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
208-8797	Retainer	432-8908
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
333-9877	Pin As	394-0217
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

53K		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586

Sales Model 657 (Cont'd.)

53K		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-6577	Cone-Spl Tapered	374-1839
1L-7319	Cup-Roller Brg	380-7499
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1S-9110	Bearing-Needle	420-2497
1S-9209	Shaft-Tightener	374-6499
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0767	Bearing-Sleeve	383-2108
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131

53K		
Original Part Number	Part Name	Classic Part Number
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-6005	Bearing-Sleeve	417-4521
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-8539	Bearing-Conn Rod	419-7251
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305

53K		
Original Part Number	Part Name	Classic Part Number
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2M-8714	Cone-Roller Brg	420-2492
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-0034	Trunnion	361-1712
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-4778	Roller As	394-2582
3J-6559	Cap-Bearing	296-1346
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3P-4265	Piston-Clutch	397-5063

Sales Model 657 (Cont'd.)

53K		
Original Part Number	Part Name	Classic Part Number
3R-5327	Pipe-Extension	383-1571
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
3Y-2768	Ring	439-4544
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4J-2414	Trunnion	296-1370
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283

53K		
Original Part Number	Part Name	Classic Part Number
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2474	Rotocoil As	388-6571
4W-5693	Bearing-Con Rod	419-6324
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5J-4929	Bearing	256-4796
5J-6424	Bearing-Aligning	416-2135
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018

53K		
Original Part Number	Part Name	Classic Part Number
5J-9451	Bearing	374-8338
5K-2294	Bearing	396-9912
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348

Sales Model 657 (Cont'd.)

53K		
Original Part Number	Part Name	Classic Part Number
6N-1931	Plunger	379-0171
6N-9211	Core As-O Clr	435-6049
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6Y-2065	Mount As-650 Cup	377-5844
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-1164	Mount As	295-5451

53K		
Original Part Number	Part Name	Classic Part Number
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0205	Core As-Oclr	379-0183
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485

53K		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-2104	Bell As-Suction	380-1521
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8N-9489	Chamber As	247-3301
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3517	Bearing-Spl Ball	417-4501
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-5438	Muffler As	360-7896
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8W-3613	Bearing	418-1960
8W-9728	Gear	399-6045
9D-5444	Pin	380-7396
9J-8323	Trunnion	361-1713
9J-9487	Bearing-Sleeve	447-0822

Sales Model 657 (Cont'd.)

53K		
Original Part Number	Part Name	Classic Part Number
9L-5839	Coupling-Exhaust	374-7480
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9M-8395	Bearing-Sleeve	391-1103
9N-3167	Plate-Block Bot	430-4468
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062

53K		
Original Part Number	Part Name	Classic Part Number
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
146-2601	Cover	399-6054
148-0885	Stator-Converter	379-0161
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
162-3904	Pump As-F Prm	391-1102
166-6352	Tube As.	432-4223

53K		
Original Part Number	Part Name	Classic Part Number
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
208-8797	Retainer	432-8908
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
333-9877	Pin As	394-0217
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

Sales Model 657B

05A		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1B-3922	Cup-Roller Brg	416-2158
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-6577	Cone-Spl Tapered	374-1839
1L-7319	Cup-Roller Brg	380-7499
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1S-9110	Bearing-Needle	420-2497
1S-9209	Shaft-Tightener	374-6499
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0767	Bearing-Sleeve	383-2108
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410

05A		
Original Part Number	Part Name	Classic Part Number
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-6005	Bearing-Sleeve	417-4521
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-8539	Bearing-Conn Rod	419-7251
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852

05A		
Original Part Number	Part Name	Classic Part Number
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2M-8714	Cone-Roller Brg	420-2492
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-0034	Trunnion	361-1712
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691

Sales Model 657B (Cont'd.)

05A		
Original Part Number	Part Name	Classic Part Number
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3P-4265	Piston-Clutch	397-5063
3R-5327	Pipe-Extension	383-1571
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056

05A		
Original Part Number	Part Name	Classic Part Number
4N-4534	Pulley-Crkshft	374-4709
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2474	Rotocoil As	388-6571
4W-5693	Bearing-Con Rod	419-6324
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5J-4929	Bearing	256-4796
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5K-2294	Bearing	396-9912
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467

05A		
Original Part Number	Part Name	Classic Part Number
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6N-9211	Core As-O Clr	435-6049
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574

Sales Model 657B (Cont'd.)

05A		
Original Part Number	Part Name	Classic Part Number
6Y-2065	Mount As-650 Cup	377-5844
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722

05A		
Original Part Number	Part Name	Classic Part Number
7N-5449	Spool-Press Rlf	434-2450
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0205	Core As-Oclr	379-0183
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439

05A		
Original Part Number	Part Name	Classic Part Number
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-2104	Bell As-Suction	380-1521
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8N-9489	Chamber As	247-3301
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3517	Bearing-Spl Ball	417-4501
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-5438	Muffler As	360-7896
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8W-3613	Bearing	418-1960
8W-9728	Gear	399-6045
9D-5444	Pin	380-7396
9J-8323	Trunnion	361-1713
9J-9487	Bearing-Sleeve	447-0822
9L-5839	Coupling-Exhaust	374-7480
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501

Sales Model 657B (Cont'd.)

05A		
Original Part Number	Part Name	Classic Part Number
9M-8395	Bearing-Sleeve	391-1103
9N-3167	Plate-Block Bot	430-4468
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463

05A		
Original Part Number	Part Name	Classic Part Number
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
146-2601	Cover	399-6054
148-0885	Stator-Converter	379-0161
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
162-3904	Pump As-F Prm	391-1102
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019

05A		
Original Part Number	Part Name	Classic Part Number
171-6696	Diaphragm	384-4811
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
208-8797	Retainer	432-8908
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
333-9877	Pin As	394-0217
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

19G		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586

Sales Model 657B (Cont'd.)

19G		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-6577	Cone-Spl Tapered	374-1839
1L-7319	Cup-Roller Brg	380-7499
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1S-9110	Bearing-Needle	420-2497
1S-9209	Shaft-Tightener	374-6499
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0767	Bearing-Sleeve	383-2108
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131

19G		
Original Part Number	Part Name	Classic Part Number
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-6005	Bearing-Sleeve	417-4521
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-8539	Bearing-Conn Rod	419-7251
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305

19G		
Original Part Number	Part Name	Classic Part Number
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2M-8714	Cone-Roller Brg	420-2492
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-0034	Trunnion	361-1712
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586

Sales Model 657B (Cont'd.)

19G		
Original Part Number	Part Name	Classic Part Number
3P-4265	Piston-Clutch	397-5063
3R-5327	Pipe-Extension	383-1571
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-5857	Cap-Bearing	376-9086

19G		
Original Part Number	Part Name	Classic Part Number
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2474	Rotocoil As	388-6571
4W-5693	Bearing-Con Rod	419-6324
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5J-4929	Bearing	256-4796
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5K-2294	Bearing	396-9912
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510

19G		
Original Part Number	Part Name	Classic Part Number
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6N-9211	Core As-O Clr	435-6049
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6Y-2065	Mount As-650 Cup	377-5844

Sales Model 657B (Cont'd.)

19G		
Original Part Number	Part Name	Classic Part Number
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450

19G		
Original Part Number	Part Name	Classic Part Number
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0205	Core As-Oclr	379-0183
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252

19G		
Original Part Number	Part Name	Classic Part Number
8N-2104	Bell As-Suction	380-1521
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8N-9489	Chamber As	247-3301
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3517	Bearing-Spl Ball	417-4501
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-5438	Muffler As	360-7896
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8W-3613	Bearing	418-1960
8W-9728	Gear	399-6045
9D-5444	Pin	380-7396
9J-8323	Trunnion	361-1713
9J-9487	Bearing-Sleeve	447-0822
9L-5839	Coupling-Exhaust	374-7480
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9M-8395	Bearing-Sleeve	391-1103

Sales Model 657B (Cont'd.)

19G		
Original Part Number	Part Name	Classic Part Number
9N-3167	Plate-Block Bot	430-4468
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566

19G		
Original Part Number	Part Name	Classic Part Number
128-2922	Kit-Gasket (Wp)	386-3814
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
146-2601	Cover	399-6054
148-0885	Stator-Converter	379-0161
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
162-3904	Pump As-F Prm	391-1102
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811

19G		
Original Part Number	Part Name	Classic Part Number
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
208-8797	Retainer	432-8908
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
333-9877	Pin As	394-0217
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

47M		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586

Sales Model 657B (Cont'd.)

47M		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-6577	Cone-Spl Tapered	374-1839
1L-7319	Cup-Roller Brg	380-7499
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1S-9110	Bearing-Needle	420-2497
1S-9209	Shaft-Tightener	374-6499
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0767	Bearing-Sleeve	383-2108
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131

47M		
Original Part Number	Part Name	Classic Part Number
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-6005	Bearing-Sleeve	417-4521
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-8539	Bearing-Conn Rod	419-7251
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305

47M		
Original Part Number	Part Name	Classic Part Number
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2M-8714	Cone-Roller Brg	420-2492
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-0034	Trunnion	361-1712
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-3953	Bearing-Sleeve	384-4778
3J-4778	Roller As	394-2582
3J-6412	Bearing-Sleeve	386-4920
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586

Sales Model 657B (Cont'd.)

47M		
Original Part Number	Part Name	Classic Part Number
3P-4265	Piston-Clutch	397-5063
3R-5327	Pipe-Extension	383-1571
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-5857	Cap-Bearing	376-9086

47M		
Original Part Number	Part Name	Classic Part Number
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2474	Rotocoil As	388-6571
4W-5693	Bearing-Con Rod	419-6324
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5J-4929	Bearing	256-4796
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5K-2294	Bearing	396-9912
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510

47M		
Original Part Number	Part Name	Classic Part Number
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6N-1931	Plunger	379-0171
6N-9211	Core As-O Clr	435-6049
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6Y-2065	Mount As-650 Cup	377-5844

Sales Model 657B (Cont'd.)

47M		
Original Part Number	Part Name	Classic Part Number
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450

47M		
Original Part Number	Part Name	Classic Part Number
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0205	Core As-Oclr	379-0183
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252

47M		
Original Part Number	Part Name	Classic Part Number
8N-2104	Bell As-Suction	380-1521
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8N-9489	Chamber As	247-3301
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3517	Bearing-Spl Ball	417-4501
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-5438	Muffler As	360-7896
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8W-3613	Bearing	418-1960
8W-9728	Gear	399-6045
9D-5444	Pin	380-7396
9J-8323	Trunnion	361-1713
9J-9487	Bearing-Sleeve	447-0822
9L-5839	Coupling-Exhaust	374-7480
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9M-8395	Bearing-Sleeve	391-1103

Sales Model 657B (Cont'd.)

47M		
Original Part Number	Part Name	Classic Part Number
9N-3167	Plate-Block Bot	430-4468
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566

47M		
Original Part Number	Part Name	Classic Part Number
128-2922	Kit-Gasket (Wp)	386-3814
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
146-2601	Cover	399-6054
148-0885	Stator-Converter	379-0161
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
162-3904	Pump As-F Prm	391-1102
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811

47M		
Original Part Number	Part Name	Classic Part Number
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
208-8797	Retainer	432-8908
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
333-9877	Pin As	394-0217
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

53K		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586

Sales Model 657B (Cont'd.)

53K		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-6577	Cone-Spl Tapered	374-1839
1L-7319	Cup-Roller Brg	380-7499
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1S-9110	Bearing-Needle	420-2497
1S-9209	Shaft-Tightener	374-6499
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0767	Bearing-Sleeve	383-2108
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131

53K		
Original Part Number	Part Name	Classic Part Number
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-6005	Bearing-Sleeve	417-4521
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-8539	Bearing-Conn Rod	419-7251
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305

53K		
Original Part Number	Part Name	Classic Part Number
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2M-8714	Cone-Roller Brg	420-2492
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-0034	Trunnion	361-1712
3G-2720	Cartridge Gp-Rr	448-5051
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-4778	Roller As	394-2582
3J-6559	Cap-Bearing	296-1346
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3P-4265	Piston-Clutch	397-5063

Sales Model 657B (Cont'd.)

53K		
Original Part Number	Part Name	Classic Part Number
3R-5327	Pipe-Extension	383-1571
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
3Y-2768	Ring	439-4544
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4J-2414	Trunnion	296-1370
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283

53K		
Original Part Number	Part Name	Classic Part Number
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2474	Rotocoil As	388-6571
4W-5693	Bearing-Con Rod	419-6324
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5J-4929	Bearing	256-4796
5J-6424	Bearing-Aligning	416-2135
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018

53K		
Original Part Number	Part Name	Classic Part Number
5J-9451	Bearing	374-8338
5K-2294	Bearing	396-9912
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348

Sales Model 657B (Cont'd.)

53K		
Original Part Number	Part Name	Classic Part Number
6N-1931	Plunger	379-0171
6N-9211	Core As-O Clr	435-6049
6P-7706	Carrier-Ring	388-6603
6V-2202	Bearing-Spl Ball	380-1574
6Y-2065	Mount As-650 Cup	377-5844
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-1164	Mount As	295-5451

53K		
Original Part Number	Part Name	Classic Part Number
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0205	Core As-Oclr	379-0183
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485

53K		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-2104	Bell As-Suction	380-1521
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8N-9489	Chamber As	247-3301
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3517	Bearing-Spl Ball	417-4501
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-5438	Muffler As	360-7896
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8W-3613	Bearing	418-1960
8W-9728	Gear	399-6045
9D-5444	Pin	380-7396
9J-8323	Trunnion	361-1713
9J-9487	Bearing-Sleeve	447-0822

Sales Model 657B (Cont'd.)

53K		
Original Part Number	Part Name	Classic Part Number
9L-5839	Coupling-Exhaust	374-7480
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9M-8395	Bearing-Sleeve	391-1103
9N-3167	Plate-Block Bot	430-4468
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062

53K		
Original Part Number	Part Name	Classic Part Number
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
146-2601	Cover	399-6054
148-0885	Stator-Converter	379-0161
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
162-3904	Pump As-F Prm	391-1102
166-6352	Tube As.	432-4223

53K		
Original Part Number	Part Name	Classic Part Number
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
208-8797	Retainer	432-8908
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
333-9877	Pin As	394-0217
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420
430-7619	Adapter-Cla	438-1812

Sales Model 657B (Cont'd.)

68K		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1S-9110	Bearing-Needle	420-2497
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0767	Bearing-Sleeve	383-2108
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1T-1078	Bearing-Thrust	384-4802

68K		
Original Part Number	Part Name	Classic Part Number
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-5009	Crankshaft As	398-2969
1W-6005	Bearing-Sleeve	417-4521
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469

68K		
Original Part Number	Part Name	Classic Part Number
2M-8714	Cone-Roller Brg	420-2492
2N-5842	Screw-Bridge Adj	418-1934
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-4087	Gear As-Idler	418-9582
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
2W-8038	Gear-Camshaft	425-7751
2W-8437	Muffler As	385-7198
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-0034	Trunnion	361-1712
3G-2720	Cartridge Gp-Rr	448-5051
3G-6846	Pump Gp-Vn Bsc-A	422-8165
3G-7660	Cartridge Gp	422-8103
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-4778	Roller As	394-2582
3J-6559	Cap-Bearing	296-1346
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949

Sales Model 657B (Cont'd.)

68K		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3P-4265	Piston-Clutch	397-5063
3R-5327	Pipe-Extension	383-1571
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
3Y-2768	Ring	439-4544
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4J-2414	Trunnion	296-1370
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4N-0342	Plate-Cam Thrust	375-9974

68K		
Original Part Number	Part Name	Classic Part Number
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-1186	Bearing-Sleeve	417-4519
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4T-7819	Cyl Gp-051 127 Y	426-0028
4T-8054	Seal As	472-8010
4W-5693	Bearing-Con Rod	419-6324
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333

68K		
Original Part Number	Part Name	Classic Part Number
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5F-7404	Nut-Bearing Lock	308-9878
5H-7071	Director-Water	388-0555
5J-4929	Bearing	256-4796
5J-6424	Bearing-Aligning	416-2135
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5K-2294	Bearing	396-9912
5L-6326	Bearing-Ball	420-3222
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467

Sales Model 657B (Cont'd.)

68K		
Original Part Number	Part Name	Classic Part Number
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6G-0078	Breather	435-4789
6G-5343	Bearing-Sleeve	450-9169
6H-3957	Bearing-Ball	311-9358
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-3641	Pulley-Tightener	380-7536
6N-6490	Bracket As-Fan	420-8569
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6N-9211	Core As-O Clr	435-6049
6P-7706	Carrier-Ring	388-6603

68K		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7G-2830	Ring-Seal	295-6441
7H-7628	Bearing	453-3655
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189

68K		
Original Part Number	Part Name	Classic Part Number
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-3206	Seal-O-Ring	436-2656
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8F-6058	Bearing-Sleeve	416-5494

Sales Model 657B (Cont'd.)

68K		
Original Part Number	Part Name	Classic Part Number
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1619	Shield As	377-5857
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-8983	Hub-Fan Pulley	421-7227
8N-9489	Chamber As	247-3301
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3517	Bearing-Spl Ball	417-4501
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-5438	Muffler As	360-7896
8S-6511	Bearing-Sleeve	380-7372

68K		
Original Part Number	Part Name	Classic Part Number
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
9D-5444	Pin	380-7396
9J-8323	Trunnion	361-1713
9J-9487	Bearing-Sleeve	447-0822
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9M-1853	Mount As.	376-3638
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9M-8395	Bearing-Sleeve	391-1103
9S-1195	Pump As-Oil	390-1000
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5746	Ferrule-Seal	392-4493
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716

68K		
Original Part Number	Part Name	Classic Part Number
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1503	Shaft	394-9199
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3125	Gasket	420-8567
101-3374	Gear-Cam-shaft Dr	376-9069
101-7354	Manifold-Exhaust	386-3060
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
106-7799	Bearing-Ball	396-9947
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
114-0915	Shield As.	394-0887
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042

Sales Model 657B (Cont'd.)

68K		
Original Part Number	Part Name	Classic Part Number
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
126-5057	Shield As-Man Lh	369-9493
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-2151	Tensioner	419-4735
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553

68K		
Original Part Number	Part Name	Classic Part Number
137-6500	Rotocoil As.	397-5053
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
148-0885	Stator-Converter	379-0161
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
162-0152	Bearing-Sleeve	422-9519
162-3904	Pump As-F Prm	391-1102
163-3103	Manifold-Exh	430-8992
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
174-6836	Gasket Kit - Tof	434-7280
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
208-8797	Retainer	432-8908

68K		
Original Part Number	Part Name	Classic Part Number
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
283-5666	Gasket-Cyl Head	388-6565
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
333-9877	Pin As	394-0217
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

Sales Model 657E

5YR		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849

Sales Model 657E (Cont'd.)

5YR		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1B-6577	Cone-Spl Tapered	374-1839
1L-7319	Cup-Roller Brg	380-7499
1M-6573	Cup-Roller Brg	399-4438
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0767	Bearing-Sleeve	383-2108
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049

5YR		
Original Part Number	Part Name	Classic Part Number
1U-0145	Bearing-Thrust	417-9482
1U-3969	Pump Gp-Vn Bsc-B	422-8150
1W-3397	Plate	391-9810
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-5009	Crankshaft As	398-2969
1W-6183	Shield As-Manf	367-6083
1W-6184	Shield As	416-5524
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492

5YR		
Original Part Number	Part Name	Classic Part Number
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1757	Hub-Fan Pulley	296-1357
2S-4900	Shaft As	384-4792
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-6280	Bracket As-Fan	431-5271
2W-6632	Core As-Rad	391-1096
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-0027	Pin As	388-6601
3G-2720	Cartridge Gp-Rr	448-5051
3G-6846	Pump Gp-Vn Bsc-A	422-8165
3G-7660	Cartridge Gp	422-8103
3G-8136	Retainer	425-3585
3G-8245	Bearing-Sleeve	399-8586
3G-8621	Cyl Gp-092 299 Y	399-8554
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063

Sales Model 657E (Cont'd.)

5YR		
Original Part Number	Part Name	Classic Part Number
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-1186	Bearing-Sleeve	417-4519
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157

5YR		
Original Part Number	Part Name	Classic Part Number
4N-5958	Tube-Exhaust Ext	385-3811
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4T-8054	Seal As	472-8010
4W-0419	Core As-Oclr	379-0182
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5F-7404	Nut-Bearing Lock	308-9878
5J-6424	Bearing-Aligning	416-2135
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775

5YR		
Original Part Number	Part Name	Classic Part Number
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-6819	Pin	425-2563
5T-6820	Bearing	425-3447
5T-8525	Plate	389-6307
5T-8687	Pin As	423-3542
5T-9430	Race-Seal Ring	398-8347
5T-9536	Roller-Ejector	399-8559
5T-9594	Pin As	419-6069
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-2707	Shaft-Axle	422-2650
6G-2749	Camshaft	422-4933
6G-2750	Camshaft	422-4927
6G-3784	Bearing-Sleeve	425-6455

Sales Model 657E (Cont'd.)

5YR		
Original Part Number	Part Name	Classic Part Number
6G-3785	Bearing-Sleeve	425-6454
6G-6844	Bearing-Sleeve	419-6070
6G-6847	Bearing-Sleeve	419-4723
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6I-4613	Plate-Spacer	380-7405
6K-4442	Rod End-Special	373-5388
6N-0977	Bearing-Sleeve	417-4524
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-3641	Pulley-Tightener	380-7536
6N-5300	Pulley-Cshaft	378-3979
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-7476	Kit-Dt Gasket	390-5282
6W-3662	Ring-Drive	446-3079
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571

5YR		
Original Part Number	Part Name	Classic Part Number
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7G-7431	Piston-Selector	432-8911
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7J-3351	Head	380-1515
7K-2135	Bearing-Roller	417-4492
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649

5YR		
Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
7W-9707	Muffler As-Eject	360-9626
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3304	Pulley-Tightener	419-4708
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-3517	Bearing-Spl Ball	417-4501

Sales Model 657E (Cont'd.)

5YR		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
8T-0209	Race-Spl Rlr Brg	384-5951
8W-9728	Gear	399-6045
8X-0962	Pin	423-3539
8X-0967	Pin As	425-6445
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9J-1379	Pin As	389-6303
9J-8323	Trunnion	361-1713
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9V-9840	Spider	417-9498
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-2988	Breather As	361-1716

5YR		
Original Part Number	Part Name	Classic Part Number
9Y-3317	Core As-Radiator	378-3996
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1503	Shaft	394-9199
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3125	Gasket	420-8567
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
114-0915	Shield As.	394-0887
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-0019	Disc-Friction	417-9492
117-9712	Shaft-Dr Idler	425-7754

5YR		
Original Part Number	Part Name	Classic Part Number
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
126-5057	Shield As-Man Lh	369-9493
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-2707	Kit-Gasket (Bsc)	392-4506
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-4037	Kit-Gasket (Acl)	438-1797

Sales Model 657E (Cont'd.)

5YR		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
140-2749	Gasket Kit	393-1033
141-1939	Gasket Kit	437-4613
141-4109	Core As-Oclr	416-5518
142-1699	Gasket Kit	392-4507
142-2303	Pin As	423-3537
142-5093	Kit-Gasket (Acl)	437-4605
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
166-6352	Tube As.	432-4223

5YR		
Original Part Number	Part Name	Classic Part Number
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
176-1402	Pin	425-2562
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024
234-1630	Kit-Gasket (Rs)	393-1040
243-0731	Kit-Dt Gasket	451-1507
246-3130	Shaft-Water Pump	392-4508

5YR		
Original Part Number	Part Name	Classic Part Number
252-0168	Link Assembly	433-9210
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5574	Bearing-Rod	419-7266
333-9877	Pin As	394-0217
347-6081	Gauge As	360-2348
352-0200	Pump Gp-Water -B	434-6109
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

6MB		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1L-7319	Cup-Roller Brg	380-7499
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1S-9209	Shaft-Tightener	374-6499

6MB		
Original Part Number	Part Name	Classic Part Number
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152

6MB		
Original Part Number	Part Name	Classic Part Number
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1348	Support As-Carr	419-4049
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221

Sales Model 657E (Cont'd.)

6MB		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-4087	Gear As-Idler	418-9582
2W-6632	Core As-Rad	391-1096
2W-7980	Camshaft As	378-3972
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-8245	Bearing-Sleeve	399-8586
3G-8621	Cyl Gp-092 299 Y	399-8554

6MB		
Original Part Number	Part Name	Classic Part Number
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473

6MB		
Original Part Number	Part Name	Classic Part Number
4N-1119	Gear-Tfr Pump	373-1884
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-5958	Tube-Exhaust Ext	385-3811
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-5367	Mount As	375-9986
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-6657	Race-Spl	417-4530

Sales Model 657E (Cont'd.)

6MB		
Original Part Number	Part Name	Classic Part Number
5D-6659	Bearing	417-4511
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-6820	Bearing	425-3447
5T-9430	Race-Seal Ring	398-8347
5T-9536	Roller-Ejector	399-8559
5T-9594	Pin As	419-6069
6B-3223	Cup-Bearing	399-6065
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6G-2749	Camshaft	422-4933
6G-2750	Camshaft	422-4927
6G-6847	Bearing-Sleeve	419-4723
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715

6MB		
Original Part Number	Part Name	Classic Part Number
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-5300	Pulley-Cshaft	378-3979
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-7476	Kit-Dt Gasket	390-5282
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980

6MB		
Original Part Number	Part Name	Classic Part Number
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7G-7431	Piston-Selector	432-8911
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278

Sales Model 657E (Cont'd.)

6MB		
Original Part Number	Part Name	Classic Part Number
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-6459	Core As-Oclr	395-1313
7W-9707	Muffler As-Eject	360-9626
8F-6058	Bearing-Sleeve	416-5494
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3304	Pulley-Tightener	419-4708
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8P-2051	Plate-Clutch	385-6116

6MB		
Original Part Number	Part Name	Classic Part Number
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
8T-0209	Race-Spl Rlr Brg	384-5951
8W-9728	Gear	399-6045
9D-5444	Pin	380-7396
9J-1379	Pin As	389-6303
9J-8323	Trunnion	361-1713
9M-1990	Dowel-Reaction	386-4963
9M-3914	Bearing-Aligning	420-2501
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9S-8789	Plate-Clutch	302-2712
9W-4662	Disc-Friction	428-7203
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926

6MB		
Original Part Number	Part Name	Classic Part Number
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1503	Shaft	394-9199
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3565	Tube As-Exhaust	374-4695

Sales Model 657E (Cont'd.)

6MB		
Original Part Number	Part Name	Classic Part Number
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
142-3035	Kit-Gasket (Wlg)	393-0926
143-2605	Kit-Gasket-Mch	393-0915
145-8503	Shaft As-Idler	426-0035

6MB		
Original Part Number	Part Name	Classic Part Number
155-8696	Kit-Dt Gasket	396-9944
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266

6MB		
Original Part Number	Part Name	Classic Part Number
221-6985	Retainer	399-4406
233-9200	Kit-Gasket-Sch	393-0927
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

6PR		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1B-6577	Cone-Spl Tapered	374-1839
1L-7319	Cup-Roller Brg	380-7499
1M-6573	Cup-Roller Brg	399-4438
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797

6PR		
Original Part Number	Part Name	Classic Part Number
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0767	Bearing-Sleeve	383-2108
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-0145	Bearing-Thrust	417-9482
1U-3969	Pump Gp-Vn Bsc-B	422-8150

6PR		
Original Part Number	Part Name	Classic Part Number
1W-4369	Pulley-Alt	296-1340
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354

Sales Model 657E (Cont'd.)

6PR		
Original Part Number	Part Name	Classic Part Number
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2S-4900	Shaft As	384-4792
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-6632	Core As-Rad	391-1096
2W-7774	Ejector As-Exh	393-0914
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-0027	Pin As	388-6601
3G-2720	Cartridge Gp-Rr	448-5051
3G-8136	Retainer	425-3585
3G-8245	Bearing-Sleeve	399-8586
3G-8621	Cyl Gp-092 299 Y	399-8554
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582

6PR		
Original Part Number	Part Name	Classic Part Number
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-1186	Bearing-Sleeve	417-4519
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450

6PR		
Original Part Number	Part Name	Classic Part Number
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-5958	Tube-Exhaust Ext	385-3811
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-5367	Mount As	375-9986
4T-8054	Seal As	472-8010
4W-0419	Core As-Oclr	379-0182
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511

Sales Model 657E (Cont'd.)

6PR		
Original Part Number	Part Name	Classic Part Number
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5F-7404	Nut-Bearing Lock	308-9878
5J-6424	Bearing-Aligning	416-2135
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-6819	Pin	425-2563
5T-6820	Bearing	425-3447
5T-8525	Plate	389-6307
5T-8687	Pin As	423-3542
5T-9430	Race-Seal Ring	398-8347
5T-9536	Roller-Ejector	399-8559
5T-9594	Pin As	419-6069
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535

6PR		
Original Part Number	Part Name	Classic Part Number
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6G-2707	Shaft-Axle	422-2650
6G-2749	Camshaft	422-4933
6G-2750	Camshaft	422-4927
6G-3784	Bearing-Sleeve	425-6455
6G-3785	Bearing-Sleeve	425-6454
6G-6844	Bearing-Sleeve	419-6070
6G-6847	Bearing-Sleeve	419-4723
6H-3957	Bearing-Ball	311-9358
6I-4613	Plate-Spacer	380-7405
6K-4442	Rod End-Special	373-5388
6N-0977	Bearing-Sleeve	417-4524
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-3641	Pulley-Tightener	380-7536
6N-5300	Pulley-Cshaft	378-3979
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-7476	Kit-Dt Gasket	390-5282
6W-3662	Ring-Drive	446-3079

6PR		
Original Part Number	Part Name	Classic Part Number
6Y-2065	Mount As-650 Cup	377-5844
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-5816	Shaft-Fan	399-8552
7E-5996	Rod As-Conn	379-8864
7G-2494	Gear-Planet	422-2490
7G-7431	Piston-Selector	432-8911
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7J-3351	Head	380-1515
7K-2135	Bearing-Roller	417-4492
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799

Sales Model 657E (Cont'd.)

6PR		
Original Part Number	Part Name	Classic Part Number
7S-4534	Bearing-Caged	417-9497
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
7W-9707	Muffler As-Eject	360-9626
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3304	Pulley-Tightener	419-4708
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247

6PR		
Original Part Number	Part Name	Classic Part Number
8N-5305	Spacer	363-7464
8N-7486	Condenser As	436-2263
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
8T-0209	Race-Spl Rlr Brg	384-5951
8W-9728	Gear	399-6045
8X-0962	Pin	423-3539
8X-0967	Pin As	425-6445
9D-5444	Pin	380-7396
9J-1379	Pin As	389-6303
9J-8323	Trunnion	361-1713
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9V-9840	Spider	417-9498
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437

6PR		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1503	Shaft	394-9199
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3125	Gasket	420-8567
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
114-0915	Shield As.	394-0887
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042

Sales Model 657E (Cont'd.)

6PR		
Original Part Number	Part Name	Classic Part Number
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
126-5057	Shield As-Man Lh	369-9493
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-2707	Kit-Gasket (Bsc)	392-4506
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813

6PR		
Original Part Number	Part Name	Classic Part Number
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-9381	Plate-Spacer	424-7052
141-0340	Kit-Gasket(F)	436-8402
141-4109	Core As-Oclr	416-5518
142-2303	Pin As	423-3537
142-3035	Kit-Gasket (Wlg)	393-0926
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6637	Gear-Oil Drive	425-9189
155-8696	Kit-Dt Gasket	396-9944
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
167-8126	Damper As	382-8019
176-1402	Pin	425-2562
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368

6PR		
Original Part Number	Part Name	Classic Part Number
216-5582	Bearing-Sleeve	390-0914
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024
246-3130	Shaft-Water Pump	392-4508
252-0168	Link Assembly	433-9210
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5574	Bearing-Rod	419-7266
333-9877	Pin As	394-0217
347-6081	Gauge As	360-2348
352-0200	Pump Gp-Water -B	434-6109
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

6TR		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158

Sales Model 657E (Cont'd.)

6TR		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1L-7319	Cup-Roller Brg	380-7499
1M-6573	Cup-Roller Brg	399-4438
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1S-7057	Gasket	420-6384
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0767	Bearing-Sleeve	383-2108
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-0145	Bearing-Thrust	417-9482

6TR		
Original Part Number	Part Name	Classic Part Number
1U-3969	Pump Gp-Vn Bsc-B	422-8150
1W-3397	Plate	391-9810
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-5009	Crankshaft As	398-2969
1W-6183	Shield As-Manf	367-6083
1W-6184	Shield As	416-5524
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927

6TR		
Original Part Number	Part Name	Classic Part Number
2P-1757	Hub-Fan Pulley	296-1357
2S-4900	Shaft As	384-4792
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-6280	Bracket As-Fan	431-5271
2W-6632	Core As-Rad	391-1096
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-2720	Cartridge Gp-Rr	448-5051
3G-6846	Pump Gp-Vn Bsc-A	422-8165
3G-7660	Cartridge Gp	422-8103
3G-8136	Retainer	425-3585
3G-8245	Bearing-Sleeve	399-8586
3G-8621	Cyl Gp-092 299 Y	399-8554
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226

Sales Model 657E (Cont'd.)

6TR		
Original Part Number	Part Name	Classic Part Number
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-1186	Bearing-Sleeve	417-4519
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-5958	Tube-Exhaust Ext	385-3811
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885

6TR		
Original Part Number	Part Name	Classic Part Number
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4W-0419	Core As-Oclr	379-0182
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5F-7404	Nut-Bearing Lock	308-9878
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956

6TR		
Original Part Number	Part Name	Classic Part Number
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-6819	Pin	425-2563
5T-6820	Bearing	425-3447
5T-8525	Plate	389-6307
5T-8687	Pin As	423-3542
5T-9430	Race-Seal Ring	398-8347
5T-9536	Roller-Ejector	399-8559
5T-9594	Pin As	419-6069
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-2707	Shaft-Axle	422-2650
6G-2749	Camshaft	422-4933
6G-2750	Camshaft	422-4927
6G-3784	Bearing-Sleeve	425-6455
6G-3785	Bearing-Sleeve	425-6454
6G-6844	Bearing-Sleeve	419-6070
6G-6847	Bearing-Sleeve	419-4723
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6I-4613	Plate-Spacer	380-7405
6K-4442	Rod End-Special	373-5388

Sales Model 657E (Cont'd.)

6TR		
Original Part Number	Part Name	Classic Part Number
6N-0977	Bearing-Sleeve	417-4524
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-3641	Pulley-Tightener	380-7536
6N-5300	Pulley-Cshaft	378-3979
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-7476	Kit-Dt Gasket	390-5282
6W-3662	Ring-Drive	446-3079
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488

6TR		
Original Part Number	Part Name	Classic Part Number
7G-2494	Gear-Planet	422-2490
7G-7431	Piston-Selector	432-8911
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7K-2135	Bearing-Roller	417-4492
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
7W-9707	Muffler As-Eject	360-9626

6TR		
Original Part Number	Part Name	Classic Part Number
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3304	Pulley-Tightener	419-4708
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8T-0209	Race-Spl Rlr Brg	384-5951
8W-9728	Gear	399-6045
8X-0962	Pin	423-3539
8X-0967	Pin As	425-6445
9D-5444	Pin	380-7396

Sales Model 657E (Cont'd.)

6TR		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
9J-1379	Pin As	389-6303
9J-8323	Trunnion	361-1713
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9V-9840	Spider	417-9498
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1503	Shaft	394-9199
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690

6TR		
Original Part Number	Part Name	Classic Part Number
101-2749	Adaptr-Water Pmp	375-9984
101-3125	Gasket	420-8567
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
114-0915	Shield As.	394-0887
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-0019	Disc-Friction	417-9492
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504

6TR		
Original Part Number	Part Name	Classic Part Number
126-5056	Shield As-Man Lh	369-9492
126-5057	Shield As-Man Lh	369-9493
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-2707	Kit-Gasket (Bsc)	392-4506
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-4037	Kit-Gasket (Acl)	438-1797
138-9381	Plate-Spacer	424-7052
141-1939	Gasket Kit	437-4613
141-4109	Core As-Oclr	416-5518
142-1699	Gasket Kit	392-4507
142-2303	Pin As	423-3537
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869

Sales Model 657E (Cont'd.)

6TR		
Original Part Number	Part Name	Classic Part Number
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
176-1402	Pin	425-2562
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368

6TR		
Original Part Number	Part Name	Classic Part Number
216-5582	Bearing-Sleeve	390-0914
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
234-1630	Kit-Gasket (Rs)	393-1040
243-0731	Kit-Dt Gasket	451-1507
246-3130	Shaft-Water Pump	392-4508
252-0168	Link Assembly	433-9210
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507

6TR		
Original Part Number	Part Name	Classic Part Number
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5574	Bearing-Rod	419-7266
333-9877	Pin As	394-0217
347-6081	Gauge As	360-2348
352-0200	Pump Gp-Water -B	434-6109
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

7KR		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1B-6577	Cone-Spl Tapered	374-1839
1L-7319	Cup-Roller Brg	380-7499
1M-6573	Cup-Roller Brg	399-4438
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409

7KR		
Original Part Number	Part Name	Classic Part Number
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0767	Bearing-Sleeve	383-2108
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152

7KR		
Original Part Number	Part Name	Classic Part Number
1T-1348	Support As-Carr	419-4049
1U-0145	Bearing-Thrust	417-9482
1U-3969	Pump Gp-Vn Bsc-B	422-8150
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709

Sales Model 657E (Cont'd.)

7KR		
Original Part Number	Part Name	Classic Part Number
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1757	Hub-Fan Pulley	296-1357
2S-4900	Shaft As	384-4792
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-6632	Core As-Rad	391-1096
2W-7774	Ejector As-Exh	393-0914
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601

7KR		
Original Part Number	Part Name	Classic Part Number
3G-2720	Cartridge Gp-Rr	448-5051
3G-8136	Retainer	425-3585
3G-8245	Bearing-Sleeve	399-8586
3G-8621	Cyl Gp-092 299 Y	399-8554
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489

7KR		
Original Part Number	Part Name	Classic Part Number
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-1186	Bearing-Sleeve	417-4519
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-5958	Tube-Exhaust Ext	385-3811
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-5367	Mount As	375-9986
4W-0419	Core As-Oclr	379-0182
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975

Sales Model 657E (Cont'd.)

7KR		
Original Part Number	Part Name	Classic Part Number
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5F-7404	Nut-Bearing Lock	308-9878
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-6819	Pin	425-2563
5T-6820	Bearing	425-3447
5T-8525	Plate	389-6307
5T-8687	Pin As	423-3542
5T-9430	Race-Seal Ring	398-8347

7KR		
Original Part Number	Part Name	Classic Part Number
5T-9536	Roller-Ejector	399-8559
5T-9594	Pin As	419-6069
6B-3223	Cup-Bearing	399-6065
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6G-2707	Shaft-Axle	422-2650
6G-2749	Camshaft	422-4933
6G-2750	Camshaft	422-4927
6G-3784	Bearing-Sleeve	425-6455
6G-3785	Bearing-Sleeve	425-6454
6G-6844	Bearing-Sleeve	419-6070
6G-6847	Bearing-Sleeve	419-4723
6H-3957	Bearing-Ball	311-9358
6I-4613	Plate-Spacer	380-7405
6K-4442	Rod End-Special	373-5388
6N-0977	Bearing-Sleeve	417-4524
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-3641	Pulley-Tightener	380-7536
6N-5300	Pulley-Cshaft	378-3979
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-9133	Gasket-Plate	398-2959
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574

7KR		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
6V-7476	Kit-Dt Gasket	390-5282
6W-3662	Ring-Drive	446-3079
6Y-2065	Mount As-650 Cup	377-5844
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-5816	Shaft-Fan	399-8552
7E-5996	Rod As-Conn	379-8864
7G-2494	Gear-Planet	422-2490
7G-7431	Piston-Selector	432-8911
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7K-2135	Bearing-Roller	417-4492
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664

Sales Model 657E (Cont'd.)

7KR		
Original Part Number	Part Name	Classic Part Number
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
7W-9707	Muffler As-Eject	360-9626
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3304	Pulley-Tightener	419-4708

7KR		
Original Part Number	Part Name	Classic Part Number
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8N-7486	Condenser As	436-2263
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
8T-0209	Race-Spl Rlr Brg	384-5951
8W-9728	Gear	399-6045
8X-0962	Pin	423-3539
8X-0967	Pin As	425-6445
9D-5444	Pin	380-7396
9J-1379	Pin As	389-6303
9J-8323	Trunnion	361-1713
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712

7KR		
Original Part Number	Part Name	Classic Part Number
9T-5096	Flexplate	455-3271
9V-9840	Spider	417-9498
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1503	Shaft	394-9199
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3125	Gasket	420-8567
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
114-0915	Shield As.	394-0887
115-2367	Valve-Exhaust	384-8700

Sales Model 657E (Cont'd.)

7KR		
Original Part Number	Part Name	Classic Part Number
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
126-5057	Shield As-Man Lh	369-9493
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-2707	Kit-Gasket (Bsc)	392-4506

7KR		
Original Part Number	Part Name	Classic Part Number
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-9381	Plate-Spacer	424-7052
141-0340	Kit-Gasket(F)	436-8402
141-4109	Core As-Oclr	416-5518
142-2303	Pin As	423-3537
142-3035	Kit-Gasket (Wlg)	393-0926
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6637	Gear-Oil Drive	425-9189
155-8696	Kit-Dt Gasket	396-9944
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
167-8126	Damper As	382-8019
176-1402	Pin	425-2562
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
186-2001	Rotocoil As	397-5055

7KR		
Original Part Number	Part Name	Classic Part Number
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508
252-0168	Link Assembly	433-9210
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5574	Bearing-Rod	419-7266
333-9877	Pin As	394-0217
347-6081	Gauge As	360-2348
352-0200	Pump Gp-Water -B	434-6109
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

86Z		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158

Sales Model 657E (Cont'd.)

86Z		
Original Part Number	Part Name	Classic Part Number
1L-7319	Cup-Roller Brg	380-7499
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1348	Support As-Carr	419-4049
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174

86Z		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-4087	Gear As-Idler	418-9582
2W-6632	Core As-Rad	391-1096
2W-7774	Ejector As-Exh	393-0914
2W-7980	Camshaft As	378-3972
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-8245	Bearing-Sleeve	399-8586
3G-8621	Cyl Gp-092 299 Y	399-8554
3J-2373	Bearing-Sleeve	380-7562

86Z		
Original Part Number	Part Name	Classic Part Number
3J-2903	Cover	422-6922
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1186	Bearing-Sleeve	417-4519

Sales Model 657E (Cont'd.)

86Z		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-5958	Tube-Exhaust Ext	385-3811
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-5367	Mount As	375-9986
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168

86Z		
Original Part Number	Part Name	Classic Part Number
4W-6150	Adapter-Support	432-4219
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5F-7404	Nut-Bearing Lock	308-9878
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5P-8054	Gasket Kit	437-8109
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-6820	Bearing	425-3447
5T-9430	Race-Seal Ring	398-8347
5T-9536	Roller-Ejector	399-8559
5T-9594	Pin As	419-6069
6B-3223	Cup-Bearing	399-6065
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6G-2749	Camshaft	422-4933
6G-2750	Camshaft	422-4927
6G-6847	Bearing-Sleeve	419-4723

86Z		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-5300	Pulley-Cshaft	378-3979
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-1996	Plate-Clutch	368-0117
6T-5611	Spacer	435-8520

Sales Model 657E (Cont'd.)

86Z		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-5920	Gasket Kit - F	388-0653
6V-7476	Kit-Dt Gasket	390-5282
6Y-2065	Mount As-650 Cup	377-5844
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5816	Shaft-Fan	399-8552
7E-5996	Rod As-Conn	379-8864
7G-7431	Piston-Selector	432-8911
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-4497	Gear-Cplg & Sun	444-1842

86Z		
Original Part Number	Part Name	Classic Part Number
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-6459	Core As-Oclr	395-1313
7W-9707	Muffler As-Eject	360-9626
8F-6058	Bearing-Sleeve	416-5494
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726

86Z		
Original Part Number	Part Name	Classic Part Number
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3304	Pulley-Tightener	419-4708
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8P-2051	Plate-Clutch	385-6116
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
8T-0209	Race-Spl Rlr Brg	384-5951
8T-2500	Kit-Gasket	393-1028
8W-9728	Gear	399-6045
9D-5444	Pin	380-7396
9J-1379	Pin As	389-6303
9J-8323	Trunnion	361-1713
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9M-3914	Bearing-Aligning	420-2501
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005

Sales Model 657E (Cont'd.)

86Z		
Original Part Number	Part Name	Classic Part Number
9S-8789	Plate-Clutch	302-2712
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1503	Shaft	394-9199
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3125	Gasket	420-8567
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488

86Z		
Original Part Number	Part Name	Classic Part Number
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
114-0915	Shield As.	394-0887
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
126-5057	Shield As-Man Lh	369-9493
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193

86Z		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-9381	Plate-Spacer	424-7052
142-3035	Kit-Gasket (Wlg)	393-0926
143-2605	Kit-Gasket-Mch	393-0915
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6637	Gear-Oil Drive	425-9189
155-8696	Kit-Dt Gasket	396-9944
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037

Sales Model 657E (Cont'd.)

86Z		
Original Part Number	Part Name	Classic Part Number
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
232-1841	Kit-Gasket (Fs)	387-2922
232-2672	Kit-Gasket-Fs	393-0922
233-8681	Kit-Gasket-Mch	393-0920
233-9200	Kit-Gasket-Sch	393-0927
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420
1B-3922	Cup-Roller Brg	416-2158
1L-7319	Cup-Roller Brg	380-7499
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7115	Mount As	418-1936

86Z		
Original Part Number	Part Name	Classic Part Number
1S-1888	Bracket-Lamp	297-7147
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2J-1227	Retainer	440-0850
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533

86Z		
Original Part Number	Part Name	Classic Part Number
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2S-4900	Shaft As	384-4792
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-4087	Gear As-Idler	418-9582
2W-7774	Ejector As-Exh	393-0914
2W-7980	Camshaft As	378-3972
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-8245	Bearing-Sleeve	399-8586
3G-8621	Cyl Gp-092 299 Y	399-8554
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534

Sales Model 657E (Cont'd.)

86Z		
Original Part Number	Part Name	Classic Part Number
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1186	Bearing-Sleeve	417-4519
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-5958	Tube-Exhaust Ext	385-3811
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216

86Z		
Original Part Number	Part Name	Classic Part Number
4S-5367	Mount As	375-9986
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5F-7404	Nut-Bearing Lock	308-9878
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579

86Z		
Original Part Number	Part Name	Classic Part Number
5T-9430	Race-Seal Ring	398-8347
5T-9536	Roller-Ejector	399-8559
5T-9594	Pin As	419-6069
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6G-2749	Camshaft	422-4933
6G-2750	Camshaft	422-4927
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-4613	Plate-Spacer	380-7405
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-5300	Pulley-Cshaft	378-3979
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564

Sales Model 657E (Cont'd.)

86Z		
Original Part Number	Part Name	Classic Part Number
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-5920	Gasket Kit - F	388-0653
6V-7476	Kit-Dt Gasket	390-5282
6Y-2065	Mount As-650 Cup	377-5844
6Y-8675	Housing As	418-9584
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5816	Shaft-Fan	399-8552
7E-5996	Rod As-Conn	379-8864
7G-7431	Piston-Selector	432-8911
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722

86Z		
Original Part Number	Part Name	Classic Part Number
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-6459	Core As-Oclr	395-1313
7W-9707	Muffler As-Eject	360-9626
8F-6058	Bearing-Sleeve	416-5494
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849

86Z		
Original Part Number	Part Name	Classic Part Number
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3304	Pulley-Tightener	419-4708
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8T-2500	Kit-Gasket	393-1028
8W-9728	Gear	399-6045
9D-5444	Pin	380-7396
9J-1379	Pin As	389-6303
9J-8323	Trunnion	361-1713
9L-5839	Coupling-Exhaust	374-7480
9M-3914	Bearing-Aligning	420-2501
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005

Sales Model 657E (Cont'd.)

86Z		
Original Part Number	Part Name	Classic Part Number
9S-8789	Plate-Clutch	302-2712
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1503	Shaft	394-9199
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3125	Gasket	420-8567
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
102-8608	Manifold-Exhaust	376-9062
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488

86Z		
Original Part Number	Part Name	Classic Part Number
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
114-0915	Shield As.	394-0887
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
126-5057	Shield As-Man Lh	369-9493
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193

86Z		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-9381	Plate-Spacer	424-7052
142-3035	Kit-Gasket (Wlg)	393-0926
143-2605	Kit-Gasket-Mch	393-0915
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6637	Gear-Oil Drive	425-9189
155-8696	Kit-Dt Gasket	396-9944
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037

Sales Model 657E (Cont'd.)

86Z		
Original Part Number	Part Name	Classic Part Number
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
232-1841	Kit-Gasket (Fs)	387-2922
232-2672	Kit-Gasket-Fs	393-0922

86Z		
Original Part Number	Part Name	Classic Part Number
233-8681	Kit-Gasket-Mch	393-0920
233-9200	Kit-Gasket-Sch	393-0927
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
283-5666	Gasket-Cyl Head	388-6565

86Z		
Original Part Number	Part Name	Classic Part Number
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

90Z		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1B-6577	Cone-Spl Tapered	374-1839
1L-7319	Cup-Roller Brg	380-7499
1M-6573	Cup-Roller Brg	399-4438
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797

90Z		
Original Part Number	Part Name	Classic Part Number
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0767	Bearing-Sleeve	383-2108
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-0145	Bearing-Thrust	417-9482
1U-3969	Pump Gp-Vn Bsc-B	422-8150
1W-3397	Plate	391-9810

90Z		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-5009	Crankshaft As	398-2969
1W-6183	Shield As-Manf	367-6083
1W-6184	Shield As	416-5524
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

Sales Model 657E (Cont'd.)

90Z		
Original Part Number	Part Name	Classic Part Number
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8714	Cone-Roller Brg	420-2492
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1757	Hub-Fan Pulley	296-1357
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
2W-6280	Bracket As-Fan	431-5271
2W-6632	Core As-Rad	391-1096
2W-7980	Camshaft As	378-3972
3E-6772	Seal-Water	382-8017
3G-2720	Cartridge Gp-Rr	448-5051
3G-6846	Pump Gp-Vn Bsc-A	422-8165

90Z		
Original Part Number	Part Name	Classic Part Number
3G-7660	Cartridge Gp	422-8103
3G-8136	Retainer	425-3585
3G-8245	Bearing-Sleeve	399-8586
3J-2903	Cover	422-6922
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-2582	Bearing-Spl Ball	417-9478
3P-2685	Piston-Clutch	308-9908
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-2619	Bearing	417-4494
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837

90Z		
Original Part Number	Part Name	Classic Part Number
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1675	Manifold-Exhaust	443-2015
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-5958	Tube-Exhaust Ext	385-3811
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895

Sales Model 657E (Cont'd.)

90Z		
Original Part Number	Part Name	Classic Part Number
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4S-5367	Mount As	375-9986
4W-0419	Core As-Oclr	379-0182
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467

90Z		
Original Part Number	Part Name	Classic Part Number
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774
5P-5044	Race-Brg Outer	417-9479
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-6819	Pin	425-2563
5T-6820	Bearing	425-3447
5T-8525	Plate	389-6307
5T-8687	Pin As	423-3542
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-2707	Shaft-Axle	422-2650
6G-2749	Camshaft	422-4933
6G-2750	Camshaft	422-4927
6G-3784	Bearing-Sleeve	425-6455
6G-3785	Bearing-Sleeve	425-6454

90Z		
Original Part Number	Part Name	Classic Part Number
6G-6844	Bearing-Sleeve	419-6070
6G-6847	Bearing-Sleeve	419-4723
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-3907	Adapter-Pilot	398-8348
6I-4613	Plate-Spacer	380-7405
6I-9808	Bearing-Ball	417-9484
6K-4442	Rod End-Special	373-5388
6N-0977	Bearing-Sleeve	417-4524
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-5300	Pulley-Cshaft	378-3979
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564

Sales Model 657E (Cont'd.)

90Z		
Original Part Number	Part Name	Classic Part Number
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6T-7882	Gear-Planet	296-1352
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-4540	Gasket Kit - Wp	393-1021
6V-7476	Kit-Dt Gasket	390-5282
6W-3662	Ring-Drive	446-3079
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7B-7515	Bearing-Ball	399-6059
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7D-7607	Gear-Dif Bevel	388-0595
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7G-5749	Piston-Clutch	416-2132
7G-7431	Piston-Selector	432-8911

90Z		
Original Part Number	Part Name	Classic Part Number
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493

90Z		
Original Part Number	Part Name	Classic Part Number
7W-6459	Core As-Oclr	395-1313
7W-9707	Muffler As-Eject	360-9626
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3304	Pulley-Tightener	419-4708
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-1919	Gear-Planet	300-2579
8P-2051	Plate-Clutch	385-6116

Sales Model 657E (Cont'd.)

90Z		
Original Part Number	Part Name	Classic Part Number
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8T-0209	Race-Spl Rlr Brg	384-5951
8W-9728	Gear	399-6045
8X-0962	Pin	423-3539
8X-0967	Pin As	425-6445
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9S-8597	Spring	399-8561
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271

90Z		
Original Part Number	Part Name	Classic Part Number
9V-9840	Spider	417-9498
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1503	Shaft	394-9199
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3125	Gasket	420-8567
101-3374	Gear-Cam-shaft Dr	376-9069
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
103-0887	Pulley-Idler	449-9546
105-7535	Bearing-Dbl Row	417-9496

90Z		
Original Part Number	Part Name	Classic Part Number
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-0019	Disc-Friction	417-9492
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7569	Gasket Kit	393-1041
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
127-6356	Cover As.-Pump	420-8566

Sales Model 657E (Cont'd.)

90Z		
Original Part Number	Part Name	Classic Part Number
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-4037	Kit-Gasket (Acl)	438-1797
138-9381	Plate-Spacer	424-7052
141-1939	Gasket Kit	437-4613
141-4109	Core As-Oclr	416-5518
142-2303	Pin As	423-3537
144-0502	Ring Kit-Piston	395-1312

90Z		
Original Part Number	Part Name	Classic Part Number
144-0503	Piston Kt	380-1554
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
171-6696	Diaphragm	384-4811
176-1402	Pin	425-2562
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735

90Z		
Original Part Number	Part Name	Classic Part Number
221-6985	Retainer	399-4406
232-1841	Kit-Gasket (Fs)	387-2922
234-1630	Kit-Gasket (Rs)	393-1040
243-0731	Kit-Dt Gasket	451-1507
246-3130	Shaft-Water Pump	392-4508
252-0168	Link Assembly	433-9210
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
283-5666	Gasket-Cyl Head	388-6565
291-9117	Kit-Gasket (Sch)	438-0148
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5574	Bearing-Rod	419-7266
333-9877	Pin As	394-0217
352-0200	Pump Gp-Water -B	434-6109
352-0209	Pump Gp-Water -B	375-4336
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

91Z		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839

91Z		
Original Part Number	Part Name	Classic Part Number
1M-6573	Cup-Roller Brg	399-4438
1N-3300	Shield As	374-4702

91Z		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507

Sales Model 657E (Cont'd.)

91Z		
Original Part Number	Part Name	Classic Part Number
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1S-9209	Shaft-Tightener	374-6499
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1U-0145	Bearing-Thrust	417-9482
1U-3969	Pump Gp-Vn Bsc-B	422-8150
1W-3397	Plate	391-9810
1W-4369	Pulley-Alt	296-1340
1W-6183	Shield As-Manf	367-6083
1W-6184	Shield As	416-5524
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354

91Z		
Original Part Number	Part Name	Classic Part Number
2G-1034	Valve-Safety	380-7555
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8714	Cone-Roller Brg	420-2492
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2S-5100	Valve-Ball	386-3049
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
2W-6280	Bracket As-Fan	431-5271
2W-6632	Core As-Rad	391-1096
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-2720	Cartridge Gp-Rr	448-5051
3G-6846	Pump Gp-Vn Bsc-A	422-8165
3G-7660	Cartridge Gp	422-8103
3G-8136	Retainer	425-3585
3G-8245	Bearing-Sleeve	399-8586
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356

91Z		
Original Part Number	Part Name	Classic Part Number
3P-2582	Bearing-Spl Ball	417-9478
3P-2685	Piston-Clutch	308-9908
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4D-2619	Bearing	417-4494
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1098	Shaft As	374-1455
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1675	Manifold-Exhaust	443-2015
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6257	Adapter	415-1904
4N-6413	Support-Alt	433-9855

Sales Model 657E (Cont'd.)

91Z		
Original Part Number	Part Name	Classic Part Number
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4S-5367	Mount As	375-9986
4T-8054	Seal As	472-8010
4W-0419	Core As-Oclr	379-0182
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333

91Z		
Original Part Number	Part Name	Classic Part Number
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5J-6424	Bearing-Aligning	416-2135
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774
5P-5044	Race-Brg Outer	417-9479
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883

91Z		
Original Part Number	Part Name	Classic Part Number
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-6819	Pin	425-2563
5T-6820	Bearing	425-3447
5T-8525	Plate	389-6307
5T-8687	Pin As	423-3542
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-2707	Shaft-Axle	422-2650
6G-3784	Bearing-Sleeve	425-6455
6G-3785	Bearing-Sleeve	425-6454
6G-6844	Bearing-Sleeve	419-6070
6G-6847	Bearing-Sleeve	419-4723
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6I-9808	Bearing-Ball	417-9484
6K-4442	Rod End-Special	373-5388
6N-0977	Bearing-Sleeve	417-4524
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564

Sales Model 657E (Cont'd.)

91Z		
Original Part Number	Part Name	Classic Part Number
6N-8441	Bearing-Sleeve	380-7371
6T-5611	Spacer	435-8520
6T-7882	Gear-Planet	296-1352
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-4540	Gasket Kit - Wp	393-1021
6V-7476	Kit-Dt Gasket	390-5282
6W-3662	Ring-Drive	446-3079
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7B-7515	Bearing-Ball	399-6059
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7G-5749	Piston-Clutch	416-2132
7G-7431	Piston-Selector	432-8911
7J-3351	Head	380-1515
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722

91Z		
Original Part Number	Part Name	Classic Part Number
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547

91Z		
Original Part Number	Part Name	Classic Part Number
8N-3304	Pulley-Tightener	419-4708
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8N-5305	Spacer	363-7464
8N-7486	Condenser As	436-2263
8N-8983	Hub-Fan Pulley	421-7227
8P-1919	Gear-Planet	300-2579
8P-2051	Plate-Clutch	385-6116
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8X-0962	Pin	423-3539
8X-0967	Pin As	425-6445
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9M-2744	Cone-Spl Tapered	380-1480
9M-3914	Bearing-Aligning	420-2501
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8597	Spring	399-8561

Sales Model 657E (Cont'd.)

91Z		
Original Part Number	Part Name	Classic Part Number
9T-5096	Flexplate	455-3271
9V-9840	Spider	417-9498
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1503	Shaft	394-9199
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3125	Gasket	420-8567
101-3374	Gear-Cam-shaft Dr	376-9069
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
103-0887	Pulley-Idler	449-9546
105-7535	Bearing-Dbl Row	417-9496
106-7799	Bearing-Ball	396-9947
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141

91Z		
Original Part Number	Part Name	Classic Part Number
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
111-3895	Yoke	421-3080
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-0019	Disc-Friction	417-9492
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7569	Gasket Kit	393-1041
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589

91Z		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-4037	Kit-Gasket (Acl)	438-1797
138-9381	Plate-Spacer	424-7052
141-1939	Gasket Kit	437-4613
141-4109	Core As-Oclr	416-5518
142-2303	Pin As	423-3537
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
166-6352	Tube As.	432-4223
170-4860	Bonnet-Oil Clr	430-5359
171-6696	Diaphragm	384-4811

Sales Model 657E (Cont'd.)

91Z		
Original Part Number	Part Name	Classic Part Number
176-1402	Pin	425-2562
180-6645	Shaft As.	396-1566
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735

91Z		
Original Part Number	Part Name	Classic Part Number
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024
232-1841	Kit-Gasket (Fs)	387-2922
234-1630	Kit-Gasket (Rs)	393-1040
243-0731	Kit-Dt Gasket	451-1507
246-3130	Shaft-Water Pump	392-4508
252-0168	Link Assembly	433-9210

91Z		
Original Part Number	Part Name	Classic Part Number
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
291-9117	Kit-Gasket (Sch)	438-0148
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5574	Bearing-Rod	419-7266
333-9877	Pin As	394-0217
352-0200	Pump Gp-Water -B	434-6109

Sales Model 657G

A4G		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1P-7125	Governor As	383-3672
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1U-0145	Bearing-Thrust	417-9482

A4G		
Original Part Number	Part Name	Classic Part Number
1U-3969	Pump Gp-Vn Bsc-B	422-8150
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2J-2152	Cup-Roller Brg	374-1852
2M-8714	Cone-Roller Brg	420-2492
2S-5735	Plate-Clutch	398-2964
2W-6280	Bracket As-Fan	431-5271
3E-6772	Seal-Water	382-8017
3G-2720	Cartridge Gp-Rr	448-5051

A4G		
Original Part Number	Part Name	Classic Part Number
3G-6846	Pump Gp-Vn Bsc-A	422-8165
3G-7660	Cartridge Gp	422-8103
3G-8136	Retainer	425-3585
3G-8245	Bearing-Sleeve	399-8586
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-3875	Screen-Suction	435-4849
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489

Sales Model 657G (Cont'd.)

A4G		
Original Part Number	Part Name	Classic Part Number
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-6819	Pin	425-2563
5T-6820	Bearing	425-3447
5T-8525	Plate	389-6307
5T-8687	Pin As	423-3542
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-2707	Shaft-Axle	422-2650
6G-3784	Bearing-Sleeve	425-6455

A4G		
Original Part Number	Part Name	Classic Part Number
6G-3785	Bearing-Sleeve	425-6454
6G-6844	Bearing-Sleeve	419-6070
6G-6847	Bearing-Sleeve	419-4723
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6T-5611	Spacer	435-8520
6W-3662	Ring-Drive	446-3079
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7G-7431	Piston-Selector	432-8911
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-8983	Hub-Fan Pulley	421-7227

A4G		
Original Part Number	Part Name	Classic Part Number
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8X-0962	Pin	423-3539
8X-0967	Pin As	425-6445
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9L-5839	Coupling-Exhaust	374-7480
9M-2744	Cone-Spl Tapered	380-1480
9N-3167	Plate-Block Bot	430-4468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9T-5096	Flexplate	455-3271
9V-9840	Spider	417-9498
9W-9930	Mount As	295-6437
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

Sales Model 657G (Cont'd.)

A4G		
Original Part Number	Part Name	Classic Part Number
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
141-4109	Core As-Oclr	416-5518
142-2303	Pin As	423-3537
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054

A4G		
Original Part Number	Part Name	Classic Part Number
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
170-4860	Bonnet-Oil Clr	430-5359
176-1402	Pin	425-2562
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406

A4G		
Original Part Number	Part Name	Classic Part Number
246-3130	Shaft-Water Pump	392-4508
252-0168	Link Assembly	433-9210
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
333-9877	Pin As	394-0217
347-6081	Gauge As	360-2348

DXG		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1P-7125	Governor As	383-3672
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1U-0145	Bearing-Thrust	417-9482

DXG		
Original Part Number	Part Name	Classic Part Number
1U-3969	Pump Gp-Vn Bsc-B	422-8150
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2J-2152	Cup-Roller Brg	374-1852
2M-8714	Cone-Roller Brg	420-2492
2S-5735	Plate-Clutch	398-2964
2W-6280	Bracket As-Fan	431-5271
3E-6772	Seal-Water	382-8017
3G-2720	Cartridge Gp-Rr	448-5051

DXG		
Original Part Number	Part Name	Classic Part Number
3G-6846	Pump Gp-Vn Bsc-A	422-8165
3G-7660	Cartridge Gp	422-8103
3G-8136	Retainer	425-3585
3G-8245	Bearing-Sleeve	399-8586
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489

Sales Model 657G (Cont'd.)

DXG		
Original Part Number	Part Name	Classic Part Number
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-6819	Pin	425-2563
5T-6820	Bearing	425-3447
5T-8525	Plate	389-6307
5T-8687	Pin As	423-3542
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-2707	Shaft-Axle	422-2650
6G-3784	Bearing-Sleeve	425-6455

DXG		
Original Part Number	Part Name	Classic Part Number
6G-3785	Bearing-Sleeve	425-6454
6G-6844	Bearing-Sleeve	419-6070
6G-6847	Bearing-Sleeve	419-4723
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6T-5611	Spacer	435-8520
6W-3662	Ring-Drive	446-3079
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7G-7431	Piston-Selector	432-8911
7J-3351	Head	380-1515
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521

DXG		
Original Part Number	Part Name	Classic Part Number
8N-8983	Hub-Fan Pulley	421-7227
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8X-0962	Pin	423-3539
8X-0967	Pin As	425-6445
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9L-5839	Coupling-Exhaust	374-7480
9M-2744	Cone-Spl Tapered	380-1480
9N-3167	Plate-Block Bot	430-4468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9T-5096	Flexplate	455-3271
9V-9840	Spider	417-9498
9W-9930	Mount As	295-6437
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589

Sales Model 657G (Cont'd.)

DXG		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
141-4109	Core As-Oclr	416-5518
142-2303	Pin As	423-3537
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107

DXG		
Original Part Number	Part Name	Classic Part Number
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
170-4860	Bonnet-Oil Clr	430-5359
176-1402	Pin	425-2562
184-9843	Head	347-0461
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735

DXG		
Original Part Number	Part Name	Classic Part Number
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508
252-0168	Link Assembly	433-9210
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
333-9877	Pin As	394-0217
347-6081	Gauge As	360-2348

GER		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1L-7319	Cup-Roller Brg	380-7499
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0767	Bearing-Sleeve	383-2108

GER		
Original Part Number	Part Name	Classic Part Number
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914

GER		
Original Part Number	Part Name	Classic Part Number
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2J-1227	Retainer	440-0850
2M-8714	Cone-Roller Brg	420-2492
2S-4900	Shaft As	384-4792
2S-5735	Plate-Clutch	398-2964
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-8245	Bearing-Sleeve	399-8586
3G-8621	Cyl Gp-092 299 Y	399-8554
3J-2373	Bearing-Sleeve	380-7562

Sales Model 657G (Cont'd.)

GER		
Original Part Number	Part Name	Classic Part Number
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467

GER		
Original Part Number	Part Name	Classic Part Number
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-9514	Bearing-Ball	417-9467
5S-4442	Bearing-Spl Ball	419-6025
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
5T-9536	Roller-Ejector	399-8559
5T-9594	Pin As	419-6069
6B-3223	Cup-Bearing	399-6065
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6G-2749	Camshaft	422-4933
6G-2750	Camshaft	422-4927
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571

GER		
Original Part Number	Part Name	Classic Part Number
7C-3039	Core As-Oclr	363-7451
7D-7607	Gear-Dif Bevel	388-0595
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7G-7431	Piston-Selector	432-8911
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7N-1164	Mount As	295-5451
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131

Sales Model 657G (Cont'd.)

GER		
Original Part Number	Part Name	Classic Part Number
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8W-9728	Gear	399-6045
9D-5444	Pin	380-7396
9J-1379	Pin As	389-6303
9J-8323	Trunnion	361-1713
9L-5839	Coupling-Exhaust	374-7480
9N-3167	Plate-Block Bot	430-4468
9S-8789	Plate-Clutch	302-2712
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-7517	Housing	391-1094

GER		
Original Part Number	Part Name	Classic Part Number
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
141-4109	Core As-Oclr	416-5518
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223

GER		
Original Part Number	Part Name	Classic Part Number
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

W1B		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1B-6577	Cone-Spl Tapered	374-1839
1L-7319	Cup-Roller Brg	380-7499
1M-6573	Cup-Roller Brg	399-4438

W1B		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672

W1B		
Original Part Number	Part Name	Classic Part Number
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803

Sales Model 657G (Cont'd.)

W1B		
Original Part Number	Part Name	Classic Part Number
1T-0766	Bearing-Sleeve	383-2107
1T-0767	Bearing-Sleeve	383-2108
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-0145	Bearing-Thrust	417-9482
1U-3969	Pump Gp-Vn Bsc-B	422-8150
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2M-8714	Cone-Roller Brg	420-2492

W1B		
Original Part Number	Part Name	Classic Part Number
2S-4900	Shaft As	384-4792
2S-5735	Plate-Clutch	398-2964
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-2720	Cartridge Gp-Rr	448-5051
3G-6846	Pump Gp-Vn Bsc-A	422-8165
3G-7660	Cartridge Gp	422-8103
3G-8136	Retainer	425-3585
3G-8245	Bearing-Sleeve	399-8586
3G-8621	Cyl Gp-092 299 Y	399-8554
3J-2373	Bearing-Sleeve	380-7562
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533

W1B		
Original Part Number	Part Name	Classic Part Number
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025

Sales Model 657G (Cont'd.)

W1B		
Original Part Number	Part Name	Classic Part Number
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-6819	Pin	425-2563
5T-6820	Bearing	425-3447
5T-8525	Plate	389-6307
5T-8687	Pin As	423-3542
5T-9430	Race-Seal Ring	398-8347
5T-9536	Roller-Ejector	399-8559
5T-9594	Pin As	419-6069
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-2707	Shaft-Axle	422-2650
6G-2749	Camshaft	422-4933
6G-2750	Camshaft	422-4927
6G-3784	Bearing-Sleeve	425-6455
6G-3785	Bearing-Sleeve	425-6454
6G-6844	Bearing-Sleeve	419-6070
6G-6847	Bearing-Sleeve	419-4723
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574

W1B		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-2065	Mount As-650 Cup	377-5844
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7D-7607	Gear-Dif Bevel	388-0595
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7G-7431	Piston-Selector	432-8911
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7J-3351	Head	380-1515
7N-1164	Mount As	295-5451
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-8577	Shaft-Planet	420-6529

W1B		
Original Part Number	Part Name	Classic Part Number
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8W-9728	Gear	399-6045
8X-0962	Pin	423-3539
8X-0967	Pin As	425-6445
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9J-1379	Pin As	389-6303
9J-8323	Trunnion	361-1713
9L-5839	Coupling-Exhaust	374-7480
9M-2744	Cone-Spl Tapered	380-1480
9N-3167	Plate-Block Bot	430-4468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

Sales Model 657G (Cont'd.)

W1B		
Original Part Number	Part Name	Classic Part Number
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9V-9840	Spider	417-9498
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589

W1B		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
141-4109	Core As-Oclr	416-5518
142-2303	Pin As	423-3537
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
176-1402	Pin	425-2562
177-9024	Adapter-Damper	299-1956
184-9843	Head	347-0461

W1B		
Original Part Number	Part Name	Classic Part Number
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508
252-0168	Link Assembly	433-9210
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
333-9877	Pin As	394-0217
347-6081	Gauge As	360-2348
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

W1C		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1B-6577	Cone-Spl Tapered	374-1839
1L-7319	Cup-Roller Brg	380-7499
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858

W1C		
Original Part Number	Part Name	Classic Part Number
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464

W1C		
Original Part Number	Part Name	Classic Part Number
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0767	Bearing-Sleeve	383-2108
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651

Sales Model 657G (Cont'd.)

W1C		
Original Part Number	Part Name	Classic Part Number
1T-0876	Hub-Turbine	397-5058
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-0145	Bearing-Thrust	417-9482
1U-3969	Pump Gp-Vn Bsc-B	422-8150
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2M-8714	Cone-Roller Brg	420-2492
2S-4900	Shaft As	384-4792
2S-5735	Plate-Clutch	398-2964
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-2720	Cartridge Gp-Rr	448-5051

W1C		
Original Part Number	Part Name	Classic Part Number
3G-6846	Pump Gp-Vn Bsc-A	422-8165
3G-7660	Cartridge Gp	422-8103
3G-8136	Retainer	425-3585
3G-8245	Bearing-Sleeve	399-8586
3G-8621	Cyl Gp-092 299 Y	399-8554
3J-2373	Bearing-Sleeve	380-7562
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812

W1C		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5J-6424	Bearing-Aligning	416-2135
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-6819	Pin	425-2563
5T-6820	Bearing	425-3447
5T-8525	Plate	389-6307
5T-8687	Pin As	423-3542

Sales Model 657G (Cont'd.)

W1C		
Original Part Number	Part Name	Classic Part Number
5T-9430	Race-Seal Ring	398-8347
5T-9536	Roller-Ejector	399-8559
5T-9594	Pin As	419-6069
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-2707	Shaft-Axle	422-2650
6G-2749	Camshaft	422-4933
6G-2750	Camshaft	422-4927
6G-3784	Bearing-Sleeve	425-6455
6G-3785	Bearing-Sleeve	425-6454
6G-6844	Bearing-Sleeve	419-6070
6G-6847	Bearing-Sleeve	419-4723
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-2065	Mount As-650 Cup	377-5844
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028

W1C		
Original Part Number	Part Name	Classic Part Number
6Y-8675	Housing As	418-9584
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7D-7607	Gear-Dif Bevel	388-0595
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7G-7431	Piston-Selector	432-8911
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7J-3351	Head	380-1515
7N-1164	Mount As	295-5451
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4497	Gear-Cplg	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8H-9789	Bearing-Ball	374-8342

W1C		
Original Part Number	Part Name	Classic Part Number
8N-2104	Bell As-Suction	380-1521
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8W-9728	Gear	399-6045
8X-0962	Pin	423-3539
8X-0967	Pin As	425-6445
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9J-1379	Pin As	389-6303
9J-8323	Trunnion	361-1713
9L-5839	Coupling-Exhaust	374-7480
9M-2744	Cone-Spl Tapered	380-1480
9N-3167	Plate-Block Bot	430-4468
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9V-9840	Spider	417-9498
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926

Sales Model 657G (Cont'd.)

W1C		
Original Part Number	Part Name	Classic Part Number
030-0061	Bearing-Cone	418-9605
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813

W1C		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
141-4109	Core As-Oclr	416-5518
142-2303	Pin As	423-3537
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
176-1402	Pin	425-2562
177-9024	Adapter-Damper	299-1956
184-9843	Head	347-0461
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656

W1C		
Original Part Number	Part Name	Classic Part Number
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508
252-0168	Link Assembly	433-9210
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
333-9877	Pin As	394-0217
347-6081	Gauge As	360-2348
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

W1E		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1B-6577	Cone-Spl Tapered	374-1839
1L-7319	Cup-Roller Brg	380-7499
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936

W1E		
Original Part Number	Part Name	Classic Part Number
1P-7125	Governor As	383-3672
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0767	Bearing-Sleeve	383-2108
1T-0781	Impeller	380-7488

W1E		
Original Part Number	Part Name	Classic Part Number
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-0145	Bearing-Thrust	417-9482

Sales Model 657G (Cont'd.)

W1E		
Original Part Number	Part Name	Classic Part Number
1U-3969	Pump Gp-Vn Bsc-B	422-8150
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2M-8714	Cone-Roller Brg	420-2492
2S-4900	Shaft As	384-4792
2S-5735	Plate-Clutch	398-2964
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-2720	Cartridge Gp-Rr	448-5051
3G-8136	Retainer	425-3585
3G-8245	Bearing-Sleeve	399-8586
3G-8621	Cyl Gp-092 299 Y	399-8554
3J-2373	Bearing-Sleeve	380-7562

W1E		
Original Part Number	Part Name	Classic Part Number
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3Y-2768	Ring	439-4544
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530

W1E		
Original Part Number	Part Name	Classic Part Number
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5J-6424	Bearing-Aligning	416-2135
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-6819	Pin	425-2563
5T-6820	Bearing	425-3447
5T-8525	Plate	389-6307
5T-8687	Pin As	423-3542
5T-9430	Race-Seal Ring	398-8347
5T-9536	Roller-Ejector	399-8559
5T-9594	Pin As	419-6069
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579

Sales Model 657G (Cont'd.)

W1E		
Original Part Number	Part Name	Classic Part Number
6G-2707	Shaft-Axle	422-2650
6G-2749	Camshaft	422-4933
6G-2750	Camshaft	422-4927
6G-3784	Bearing-Sleeve	425-6455
6G-3785	Bearing-Sleeve	425-6454
6G-6844	Bearing-Sleeve	419-6070
6G-6847	Bearing-Sleeve	419-4723
6H-3957	Bearing-Ball	311-9358
6I-3907	Adapter-Pilot	398-8348
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-2065	Mount As-650 Cup	377-5844
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7D-7607	Gear-Dif Bevel	388-0595
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488

W1E		
Original Part Number	Part Name	Classic Part Number
7G-2494	Gear-Planet	422-2490
7G-7431	Piston-Selector	432-8911
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7J-3351	Head	380-1515
7N-1164	Mount As	295-5451
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372

W1E		
Original Part Number	Part Name	Classic Part Number
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8W-9728	Gear	399-6045
8X-0962	Pin	423-3539
8X-0967	Pin As	425-6445
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9J-1379	Pin As	389-6303
9J-8323	Trunnion	361-1713
9L-5839	Coupling-Exhaust	374-7480
9M-2744	Cone-Spl Tapered	380-1480
9N-3167	Plate-Block Bot	430-4468
9S-8184	Pin-Drawbar	398-8345
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9V-9840	Spider	417-9498
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814

Sales Model 657G (Cont'd.)

W1E		
Original Part Number	Part Name	Classic Part Number
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
141-4109	Core As-Oclr	416-5518
142-2303	Pin As	423-3537
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054

W1E		
Original Part Number	Part Name	Classic Part Number
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
176-1402	Pin	425-2562
177-9024	Adapter-Damper	299-1956
184-9843	Head	347-0461
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406

W1E		
Original Part Number	Part Name	Classic Part Number
246-3130	Shaft-Water Pump	392-4508
252-0168	Link Assembly	433-9210
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
333-9877	Pin As	394-0217
347-6081	Gauge As	360-2348
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

W1F		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1B-6577	Cone-Spl Tapered	374-1839
1L-7319	Cup-Roller Brg	380-7499
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4147	Bearing-Needle	417-4507
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1T-0655	Bearing-Thrust	377-7409

W1F		
Original Part Number	Part Name	Classic Part Number
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0767	Bearing-Sleeve	383-2108
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1T-1078	Bearing-Thrust	384-4802

W1F		
Original Part Number	Part Name	Classic Part Number
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-0145	Bearing-Thrust	417-9482
1U-3969	Pump Gp-Vn Bsc-B	422-8150
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914

Sales Model 657G (Cont'd.)

W1F		
Original Part Number	Part Name	Classic Part Number
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2J-1227	Retainer	440-0850
2J-2152	Cup-Roller Brg	374-1852
2M-8714	Cone-Roller Brg	420-2492
2S-4900	Shaft As	384-4792
2S-5735	Plate-Clutch	398-2964
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
3E-6772	Seal-Water	382-8017
3G-0027	Pin As	388-6601
3G-2720	Cartridge Gp-Rr	448-5051
3G-8136	Retainer	425-3585
3G-8245	Bearing-Sleeve	399-8586
3G-8621	Cyl Gp-092 299 Y	399-8554
3J-2373	Bearing-Sleeve	380-7562
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849

W1F		
Original Part Number	Part Name	Classic Part Number
3Y-2768	Ring	439-4544
4D-0487	Valve As-Check	375-4334
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5J-6424	Bearing-Aligning	416-2135
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467

W1F		
Original Part Number	Part Name	Classic Part Number
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9962	Bearing-Aligning	399-4397
5S-4442	Bearing-Spl Ball	419-6025
5T-3288	Yoke	424-0743
5T-5682	Driver	418-9579
5T-6819	Pin	425-2563
5T-6820	Bearing	425-3447
5T-8525	Plate	389-6307
5T-8687	Pin As	423-3542
5T-9430	Race-Seal Ring	398-8347
5T-9536	Roller-Ejector	399-8559
5T-9594	Pin As	419-6069
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6D-0738	Pinion-Dif Bevel	394-9840
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-2707	Shaft-Axle	422-2650
6G-2749	Camshaft	422-4933
6G-2750	Camshaft	422-4927
6G-3784	Bearing-Sleeve	425-6455
6G-3785	Bearing-Sleeve	425-6454
6G-6844	Bearing-Sleeve	419-6070
6G-6847	Bearing-Sleeve	419-4723
6H-3957	Bearing-Ball	311-9358

Sales Model 657G (Cont'd.)

W1F		
Original Part Number	Part Name	Classic Part Number
6I-3907	Adapter-Pilot	398-8348
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6P-2090	Base-Xmsn O Fil	397-5049
6P-7706	Carrier-Ring	388-6603
6T-5611	Spacer	435-8520
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-3662	Ring-Drive	446-3079
6Y-2065	Mount As-650 Cup	377-5844
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-8675	Housing As	418-9584
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7D-7607	Gear-Dif Bevel	388-0595
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7G-7431	Piston-Selector	432-8911
7J-0373	Shaft As	399-8578
7J-1770	Cap-Bearing	396-0664
7J-3351	Head	380-1515
7N-1164	Mount As	295-5451
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811

W1F		
Original Part Number	Part Name	Classic Part Number
7N-7878	Cover-Plate	434-2401
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-3145	Plate	422-7894
7W-6459	Core As-Oclr	395-1313
8H-9789	Bearing-Ball	374-8342
8N-2104	Bell As-Suction	380-1521
8N-8983	Hub-Fan Pulley	421-7227
8P-3512	Piston-Clutch	416-2131
8P-4520	Piston-Clutch	394-0908
8S-0611	Cage-Bearing	451-0748
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8W-9728	Gear	399-6045
8X-0962	Pin	423-3539
8X-0967	Pin As	425-6445
9D-5444	Pin	380-7396
9D-7924	Mount As	360-2356
9J-1379	Pin As	389-6303

W1F		
Original Part Number	Part Name	Classic Part Number
9J-8323	Trunnion	361-1713
9L-5839	Coupling-Exhaust	374-7480
9M-2744	Cone-Spl Tapered	380-1480
9N-3167	Plate-Block Bot	430-4468
9S-8789	Plate-Clutch	302-2712
9T-5096	Flexplate	455-3271
9V-9840	Spider	417-9498
9W-4662	Disc-Friction	428-7203
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-7517	Housing	391-1094
101-9640	Gear-Air Compr	398-2966
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
117-0019	Disc-Friction	417-9492
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
141-4109	Core As-Oclr	416-5518
142-2303	Pin As	423-3537

Sales Model 657G (Cont'd.)

W1F		
Original Part Number	Part Name	Classic Part Number
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
176-1402	Pin	425-2562

W1F		
Original Part Number	Part Name	Classic Part Number
177-9024	Adapter-Damper	299-1956
184-9843	Head	347-0461
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
246-3130	Shaft-Water Pump	392-4508

W1F		
Original Part Number	Part Name	Classic Part Number
252-0168	Link Assembly	433-9210
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
333-9877	Pin As	394-0217
347-6081	Gauge As	360-2348
358-9117	Gear-Planet	380-7490
368-0297	Plate-Clutch	377-7420

Sales Model 660

18G		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058

18G		
Original Part Number	Part Name	Classic Part Number
1W-6005	Bearing-Sleeve	417-4521
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492
2S-3966	Ring-Seal	297-7237

18G		
Original Part Number	Part Name	Classic Part Number
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
3G-0034	Trunnion	361-1712
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719

Sales Model 660 (Cont'd.)

18G		
Original Part Number	Part Name	Classic Part Number
4D-0487	Valve As-Check	375-4334
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-9215	Gear-Pump Idler	311-9391
4W-5693	Bearing-Con Rod	419-6324
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5S-1211	Cover-Valve	314-8665

18G		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6G-0078	Breather	435-4789
6I-8860	Cup-Roller Brg	380-7495
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7J-0373	Shaft As	399-8578
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342

18G		
Original Part Number	Part Name	Classic Part Number
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-9489	Chamber As	247-3301
8S-3517	Bearing-Spl Ball	417-4501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9D-5444	Pin	380-7396
9M-2744	Cone-Spl Tapered	380-1480
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
101-1503	Shaft	394-9199
106-7799	Bearing-Ball	396-9947
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8797	Retainer	432-8908
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024
273-3160	Ballstud	396-9954
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410

Sales Model 660 (Cont'd.)

18G		
Original Part Number	Part Name	Classic Part Number
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1W-6005	Bearing-Sleeve	417-4521
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492
2S-3966	Ring-Seal	297-7237
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
3G-0034	Trunnion	361-1712
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509

18G		
Original Part Number	Part Name	Classic Part Number
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-9215	Gear-Pump Idler	311-9391
4W-5693	Bearing-Con Rod	419-6324
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956

18G		
Original Part Number	Part Name	Classic Part Number
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6G-0078	Breather	435-4789
6I-8860	Cup-Roller Brg	380-7495
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7J-0373	Shaft As	399-8578
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636

Sales Model 660 (Cont'd.)

18G		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-9489	Chamber As	247-3301
8S-3517	Bearing-Spl Ball	417-4501
8S-9075	Bearing-Cone	418-9612

18G		
Original Part Number	Part Name	Classic Part Number
8S-9076	Cup-Bearing	418-9613
9D-5444	Pin	380-7396
9M-2744	Cone-Spl Tapered	380-1480
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
101-1503	Shaft	394-9199

18G		
Original Part Number	Part Name	Classic Part Number
106-7799	Bearing-Ball	396-9947
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8797	Retainer	432-8908
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024
273-3160	Ballstud	396-9954

77F		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1S-8607	Baffle	380-7540
1S-9110	Bearing-Needle	420-2497
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
1U-2669	Cartridge Gp	422-8118
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914

77F		
Original Part Number	Part Name	Classic Part Number
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541

77F		
Original Part Number	Part Name	Classic Part Number
3G-0034	Trunnion	361-1712
3G-2717	Cartridge Gp	439-1132
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3R-5327	Pipe-Extension	383-1571
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534

Sales Model 660 (Cont'd.)

77F		
Original Part Number	Part Name	Classic Part Number
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
5D-0470	Valve Gp-Qrel	314-8549
5F-8651	Bearing-Ball	420-3223
5J-1968	Shaft-Roller	386-4928
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6N-9211	Core As-O Clr	435-6049

77F		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7J-0373	Shaft As	399-8578
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-5026	Cover-Adj Pulley	445-7698
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8N-3666	Repair Kt-Major	377-5842

77F		
Original Part Number	Part Name	Classic Part Number
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-5438	Muffler As	360-7896
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
9D-5444	Pin	380-7396
9M-2744	Cone-Spl Tapered	380-1480
9M-8395	Bearing-Sleeve	391-1103
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-5771	Bushing As	385-7219
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
101-1503	Shaft	394-9199
110-1337	Ring Kit-Pstn	377-5834
128-3935	Bearing-Race	396-9897
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
208-8797	Retainer	432-8908
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024

Sales Model 660 (Cont'd.)

90F		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1M-6573	Cup-Roller Brg	399-4438
1S-8607	Baffle	380-7540
1S-9110	Bearing-Needle	420-2497
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2S-3966	Ring-Seal	297-7237

90F		
Original Part Number	Part Name	Classic Part Number
2S-4015	Plunger As-Valve	311-9438
3G-0034	Trunnion	361-1712
3G-2717	Cartridge Gp	439-1132
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3S-1292	Bearing-Sleeve	425-8226
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4K-3150	Pin	385-3788
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
5D-0470	Valve Gp-Qrel	314-8549

90F		
Original Part Number	Part Name	Classic Part Number
5F-8651	Bearing-Ball	420-3223
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4442	Bearing-Spl Ball	419-6025
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6V-2202	Bearing-Spl Ball	380-1574
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7J-0373	Shaft As	399-8578
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-7219	Bearing-Thrust	384-4816
7N-7386	Gasket-Cyl Head	392-4519

Sales Model 660 (Cont'd.)

90F		
Original Part Number	Part Name	Classic Part Number
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-5026	Cover-Adj Pulley	445-7698
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-3368	Valve-Check	388-6599
8N-3666	Repair Kt-Major	377-5842

90F		
Original Part Number	Part Name	Classic Part Number
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-9151	Cup-Spl Tapered	374-8348
8S-9686	Gasket Kit	393-5215
9D-5444	Pin	380-7396
9M-1328	Bearing-Aligning	325-6018
9M-2744	Cone-Spl Tapered	380-1480
9M-8395	Bearing-Sleeve	391-1103
9S-5771	Bushing As	385-7219
9T-5096	Flexplate	455-3271

90F		
Original Part Number	Part Name	Classic Part Number
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
101-1503	Shaft	394-9199
106-7799	Bearing-Ball	396-9947
110-1337	Ring Kit-Pstn	377-5834
128-3935	Bearing-Race	396-9897
171-6696	Diaphragm	384-4811
208-8797	Retainer	432-8908
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024

Sales Model 660B

58K		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1P-7125	Governor As	383-3672
1S-9209	Shaft-Tightener	374-6499
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488

58K		
Original Part Number	Part Name	Classic Part Number
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1U-3953	Cartridge Gp	426-0024
1W-6005	Bearing-Sleeve	417-4521
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

58K		
Original Part Number	Part Name	Classic Part Number
2D-5383	Gasket	445-7709
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305
2M-8714	Cone-Roller Brg	420-2492
2S-3966	Ring-Seal	297-7237
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817

Sales Model 660B (Cont'd.)

58K		
Original Part Number	Part Name	Classic Part Number
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
2W-8437	Muffler As	385-7198
3E-6772	Seal-Water	382-8017
3G-0034	Trunnion	361-1712
3G-2717	Cartridge Gp	439-1132
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-9215	Gear-Pump Idler	311-9391
4N-0362	Cover As-Rgltr	419-4722

58K		
Original Part Number	Part Name	Classic Part Number
4N-0913	Screen As-Bell	374-7489
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4W-5693	Bearing-Con Rod	419-6324
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5J-1968	Shaft-Roller	386-4928
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956

58K		
Original Part Number	Part Name	Classic Part Number
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6I-8860	Cup-Roller Brg	380-7495
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6V-2202	Bearing-Spl Ball	380-1574
6W-3662	Ring-Drive	446-3079
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7J-0373	Shaft As	399-8578
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460

Sales Model 660B (Cont'd.)

58K		
Original Part Number	Part Name	Classic Part Number
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7N-7435	Kit-Major Repair	374-4724
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-8983	Hub-Fan Pulley	421-7227
8N-9489	Chamber As	247-3301
8S-3517	Bearing-Spl Ball	417-4501

58K		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9D-5444	Pin	380-7396
9L-5839	Coupling-Exhaust	374-7480
9M-2744	Cone-Spl Tapered	380-1480
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

58K		
Original Part Number	Part Name	Classic Part Number
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
162-3904	Pump As-F Prm	391-1102
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
174-6836	Gasket Kit - Tof	434-7280
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
208-8797	Retainer	432-8908
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
273-3160	Ballstud	396-9954

Sales Model 660B (Cont'd.)

58K		
Original Part Number	Part Name	Classic Part Number
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367

58K		
Original Part Number	Part Name	Classic Part Number
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665

58K		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-6387

Sales Model 666

20G		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1S-9110	Bearing-Needle	420-2497
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058

20G		
Original Part Number	Part Name	Classic Part Number
1W-6005	Bearing-Sleeve	417-4521
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532

20G		
Original Part Number	Part Name	Classic Part Number
2M-5685	Bearing-Needle	380-7469
2M-8714	Cone-Roller Brg	420-2492
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
3G-0034	Trunnion	361-1712
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3R-5327	Pipe-Extension	383-1571
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849

Sales Model 666 (Cont'd.)

20G		
Original Part Number	Part Name	Classic Part Number
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4W-5693	Bearing-Con Rod	419-6324
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467

20G		
Original Part Number	Part Name	Classic Part Number
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6I-8860	Cup-Roller Brg	380-7495
6N-9211	Core As-O Clr	435-6049
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7J-0373	Shaft As	399-8578
7J-4981	Trunnion	394-0210

20G		
Original Part Number	Part Name	Classic Part Number
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7S-3206	Seal-O-Ring	436-2656
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-9489	Chamber As	247-3301
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3517	Bearing-Spl Ball	417-4501
8S-3653	Bonnet-Valve	374-4728

Sales Model 666 (Cont'd.)

20G		
Original Part Number	Part Name	Classic Part Number
8S-3656	Plunger As-Pump	419-4750
8S-5438	Muffler As	360-7896
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9D-5444	Pin	380-7396
9M-2744	Cone-Spl Tapered	380-1480
9M-8395	Bearing-Sleeve	391-1103
9S-1195	Pump As-Oil	390-1000

20G		
Original Part Number	Part Name	Classic Part Number
9S-5746	Ferrule-Seal	392-4493
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
101-1503	Shaft	394-9199
106-7799	Bearing-Ball	396-9947

20G		
Original Part Number	Part Name	Classic Part Number
128-3935	Bearing-Race	396-9897
148-0885	Stator-Converter	379-0161
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8797	Retainer	432-8908
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024
273-3160	Ballstud	396-9954

32G		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-5270	Pipe-Extension	367-6065
1M-6573	Cup-Roller Brg	399-4438
1M-7250	Bowl	360-2296
1P-1367	Plunger-Valve	432-8913
1S-8607	Baffle	380-7540
1S-9110	Bearing-Needle	420-2497
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837

32G		
Original Part Number	Part Name	Classic Part Number
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438

32G		
Original Part Number	Part Name	Classic Part Number
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
3G-0034	Trunnion	361-1712
3G-2717	Cartridge Gp	439-1132
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3R-5327	Pipe-Extension	383-1571
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494

Sales Model 666 (Cont'd.)

32G		
Original Part Number	Part Name	Classic Part Number
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
5D-0470	Valve Gp-Qrel	314-8549
5F-8651	Bearing-Ball	420-3223
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6F-2956	Cup-Spl Tapered	420-6538
6H-3566	Cone-Bearing	415-1918

32G		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6N-9211	Core As-O Clr	435-6049
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7J-0373	Shaft As	399-8578
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-5026	Cover-Adj Pulley	445-7698
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342

32G		
Original Part Number	Part Name	Classic Part Number
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8N-3666	Repair Kt-Major	377-5842
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-5438	Muffler As	360-7896
8S-9686	Gasket Kit	393-5215
9D-5444	Pin	380-7396
9M-2744	Cone-Spl Tapered	380-1480
9M-8395	Bearing-Sleeve	391-1103
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-5771	Bushing As	385-7219
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
101-1503	Shaft	394-9199
110-1337	Ring Kit-Pstn	377-5834
121-7746	Pre-Cleaner As	360-2311
128-3935	Bearing-Race	396-9897
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8797	Retainer	432-8908
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024

Sales Model 666 (Cont'd.)

64H		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1S-8607	Baffle	380-7540
1S-9110	Bearing-Needle	420-2497
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469

64H		
Original Part Number	Part Name	Classic Part Number
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
3G-0034	Trunnion	361-1712
3G-2717	Cartridge Gp	439-1132
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3R-5327	Pipe-Extension	383-1571
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391

64H		
Original Part Number	Part Name	Classic Part Number
4M-9216	Gear-Pump Drive	311-9390
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
5D-0470	Valve Gp-Qrel	314-8549
5F-8651	Bearing-Ball	420-3223
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6N-9211	Core As-O Clr	435-6049
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7J-0373	Shaft As	399-8578
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132

Sales Model 666 (Cont'd.)

64H		
Original Part Number	Part Name	Classic Part Number
7J-4983	Cap-Bearing	384-3460
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-5026	Cover-Adj Pulley	445-7698

64H		
Original Part Number	Part Name	Classic Part Number
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8N-3666	Repair Kt-Major	377-5842
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-5438	Muffler As	360-7896
8S-9686	Gasket Kit	393-5215
9D-5444	Pin	380-7396
9M-2744	Cone-Spl Tapered	380-1480
9M-8395	Bearing-Sleeve	391-1103
9S-1195	Pump As-Oil	390-1000

64H		
Original Part Number	Part Name	Classic Part Number
9S-5746	Ferrule-Seal	392-4493
9S-5771	Bushing As	385-7219
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
101-1503	Shaft	394-9199
110-1337	Ring Kit-Pstn	377-5834
128-3935	Bearing-Race	396-9897
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8797	Retainer	432-8908
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024

77F		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1S-8607	Baffle	380-7540
1S-9110	Bearing-Needle	420-2497

77F		
Original Part Number	Part Name	Classic Part Number
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
1U-2669	Cartridge Gp	422-8118
2A-4429	Lock-Retainer	379-0174
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914

77F		
Original Part Number	Part Name	Classic Part Number
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533

Sales Model 666 (Cont'd.)

77F		
Original Part Number	Part Name	Classic Part Number
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
3G-0034	Trunnion	361-1712
3G-2717	Cartridge Gp	439-1132
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-2903	Cover	422-6922
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3R-5327	Pipe-Extension	383-1571
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602

77F		
Original Part Number	Part Name	Classic Part Number
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
5D-0470	Valve Gp-Qrel	314-8549
5F-8651	Bearing-Ball	420-3223
5J-1968	Shaft-Roller	386-4928
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6N-9211	Core As-O Clr	435-6049
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488

77F		
Original Part Number	Part Name	Classic Part Number
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7J-0373	Shaft As	399-8578
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-5026	Cover-Adj Pulley	445-7698
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8N-3666	Repair Kt-Major	377-5842
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728

Sales Model 666 (Cont'd.)

77F		
Original Part Number	Part Name	Classic Part Number
8S-3656	Plunger As-Pump	419-4750
8S-5438	Muffler As	360-7896
8S-9686	Gasket Kit	393-5215
8W-6324	Kit-Wear Strip	424-0739
9D-5444	Pin	380-7396
9M-2744	Cone-Spl Tapered	380-1480
9M-8395	Bearing-Sleeve	391-1103

77F		
Original Part Number	Part Name	Classic Part Number
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-5771	Bushing As	385-7219
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202

77F		
Original Part Number	Part Name	Classic Part Number
101-1503	Shaft	394-9199
110-1337	Ring Kit-Pstn	377-5834
128-3935	Bearing-Race	396-9897
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8795	Retainer	430-5355
208-8797	Retainer	432-8908
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024

Sales Model 666B

20G		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-4147	Bearing-Needle	417-4507
1S-9110	Bearing-Needle	420-2497
1T-0299	Cup-Roller Brg	422-6494
1T-0365	Flange-Joint	434-1861
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107

20G		
Original Part Number	Part Name	Classic Part Number
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1W-6005	Bearing-Sleeve	417-4521
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914

20G		
Original Part Number	Part Name	Classic Part Number
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2M-8714	Cone-Roller Brg	420-2492
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237

Sales Model 666B (Cont'd.)

20G		
Original Part Number	Part Name	Classic Part Number
2S-4015	Plunger As-Valve	311-9438
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
3G-0034	Trunnion	361-1712
3H-8726	Mount As	385-7208
3J-2373	Bearing-Sleeve	380-7562
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3R-5327	Pipe-Extension	383-1571
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609

20G		
Original Part Number	Part Name	Classic Part Number
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4W-5693	Bearing-Con Rod	419-6324
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883

20G		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6G-0078	Breather	435-4789
6I-8860	Cup-Roller Brg	380-7495
6N-9211	Core As-O Clr	435-6049
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7J-0373	Shaft As	399-8578
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7S-3206	Seal-O-Ring	436-2656
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649

Sales Model 666B (Cont'd.)

20G		
Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-9489	Chamber As	247-3301
8S-1522	Chamber As	390-1004

20G		
Original Part Number	Part Name	Classic Part Number
8S-1523	Chamber As	388-0565
8S-3517	Bearing-Spl Ball	417-4501
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-5438	Muffler As	360-7896
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9D-5444	Pin	380-7396
9M-2744	Cone-Spl Tapered	380-1480
9M-8395	Bearing-Sleeve	391-1103
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9V-7710	Univ Joint As	394-8234

20G		
Original Part Number	Part Name	Classic Part Number
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
101-1503	Shaft	394-9199
106-7799	Bearing-Ball	396-9947
128-3935	Bearing-Race	396-9897
148-0885	Stator-Converter	379-0161
162-3904	Pump As-F Prm	391-1102
171-6696	Diaphragm	384-4811
208-8797	Retainer	432-8908
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024
273-3160	Ballstud	396-9954

66K		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913

66K		
Original Part Number	Part Name	Classic Part Number
1P-4147	Bearing-Needle	417-4507
1P-7125	Governor As	383-3672
1S-9110	Bearing-Needle	420-2497
1S-9209	Shaft-Tightener	374-6499
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131

66K		
Original Part Number	Part Name	Classic Part Number
1T-0807	Race-Thrust Brg	453-3651
1T-0876	Hub-Turbine	397-5058
1W-6005	Bearing-Sleeve	417-4521
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-8539	Bearing-Conn Rod	419-7251
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5383	Gasket	445-7709
2D-9453	Cone-Roller Brg	380-7508

Sales Model 666B (Cont'd.)

66K		
Original Part Number	Part Name	Classic Part Number
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2M-8714	Cone-Roller Brg	420-2492
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-6280	Bracket As-Fan	431-5271
2W-7774	Ejector As-Exh	393-0914
2W-8437	Muffler As	385-7198
3E-6772	Seal-Water	382-8017
3G-0034	Trunnion	361-1712
3G-2717	Cartridge Gp	439-1132
3H-8726	Mount As	385-7208

66K		
Original Part Number	Part Name	Classic Part Number
3J-2373	Bearing-Sleeve	380-7562
3J-4778	Roller As	394-2582
3J-9133	Bearing-Sleeve	361-1691
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3R-5327	Pipe-Extension	383-1571
3S-1467	Pump Gp-F Inj -B	452-9555
3S-3875	Screen-Suction	435-4849
3S-9466	Bearing-Sleeve	314-8509
4B-1455	Cap As-Filler	361-1719
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-7534	Bearing As-Rlr	441-5602
4F-2041	Cup-Roller Brg	418-9609
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4N-0362	Cover As-Rgltr	419-4722
4N-0913	Screen As-Bell	374-7489
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709

66K		
Original Part Number	Part Name	Classic Part Number
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4W-5693	Bearing-Con Rod	419-6324
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-0470	Valve Gp-Qrel	314-8549
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5J-8118	Bearing-Sleeve	451-9018
5J-9451	Bearing	374-8338
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-3560	Bearing-Sleeve	392-4521
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635

Sales Model 666B (Cont'd.)

66K		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5T-9430	Race-Seal Ring	398-8347
6B-3223	Cup-Bearing	399-6065
6G-0078	Breather	435-4789
6H-3957	Bearing-Ball	311-9358
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6I-8860	Cup-Roller Brg	380-7495
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-6490	Bracket As-Fan	420-8569
6N-9211	Core As-O Clr	435-6049
6V-2202	Bearing-Spl Ball	380-1574
6W-3662	Ring-Drive	446-3079
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2494	Gear-Planet	422-2490
7G-2830	Ring-Seal	295-6441
7J-0373	Shaft As	399-8578
7J-4981	Trunnion	394-0210

66K		
Original Part Number	Part Name	Classic Part Number
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5449	Spool-Press Rlf	434-2450
7N-7435	Kit-Major Repair	374-4724
7S-3206	Seal-O-Ring	436-2656
7S-6839	Hub-Clutch	399-4407
7S-6976	Body As-Pump	419-4649
7S-7809	Cap As-Radiator	295-6417
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439

66K		
Original Part Number	Part Name	Classic Part Number
8M-3368	Valve-Check	388-6599
8M-8652	Shaft	297-7252
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-8983	Hub-Fan Pulley	421-7227
8N-9489	Chamber As	247-3301
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3517	Bearing-Spl Ball	417-4501
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-5438	Muffler As	360-7896
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9D-5444	Pin	380-7396
9L-5839	Coupling-Exhaust	374-7480
9M-2744	Cone-Spl Tapered	380-1480
9M-8395	Bearing-Sleeve	391-1103
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-6743	Chamber As	247-3303
9S-8184	Pin-Drawbar	398-8345
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
9V-9840	Spider	417-9498
9W-4162	Bearing	396-9899

Sales Model 666B (Cont'd.)

66K		
Original Part Number	Part Name	Classic Part Number
9W-4163	Race-Rlr Bearing	394-9202
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-1503	Shaft	394-9199
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
128-3935	Bearing-Race	396-9897
129-9907	Impeller-Pump	383-1589

66K		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
148-0885	Stator-Converter	379-0161
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
162-3904	Pump As-F Prm	391-1102
167-8126	Damper As	382-8019
171-6696	Diaphragm	384-4811
174-6836	Gasket Kit - Tof	434-7280
177-9024	Adapter-Damper	299-1956

66K		
Original Part Number	Part Name	Classic Part Number
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
208-8797	Retainer	432-8908
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
221-6985	Retainer	399-4406
226-8202	Seal-Wiper	472-8024
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
273-3160	Ballstud	396-9954
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387

Sales Model 814

14R		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1T-0210	Bearing-Ball	417-4498
1T-0576	Bearing-Sleeve	379-0186

14R		
Original Part Number	Part Name	Classic Part Number
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1W-3900	Gasket	472-8006
2A-4576	Cup-Roller Brg	386-4944

14R		
Original Part Number	Part Name	Classic Part Number
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-5065	Cone-Roller Brg	416-2157

Sales Model 814 (Cont'd.)

14R		
Original Part Number	Part Name	Classic Part Number
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505
2P-0220	Gasket-Pump	398-2927
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3T-2095	Bearing-Sleeve	384-3459
4K-7463	Seal-Lip Type	472-8007
4S-8538	Bearing-Spl Ball	417-4502
4W-0452	Seal As -Cshaft	325-6191

14R		
Original Part Number	Part Name	Classic Part Number
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5P-2526	Cup-Rlr Bearing	380-7498
5P-8768	Kit-Gasket (Scl)	393-1024
6N-7263	Gasket-Cyl Head	380-7386
6V-1339	Gasket Kit	388-0651
6Y-3484	Bearing-Spl Ball	416-2166
7C-4297	Seal As-Cshaft	325-6192
7F-2742	Bearing-Ball	422-6488
7S-3002	Bearing-Spl Ball	386-4961
7S-3206	Seal-O-Ring	436-2656

14R		
Original Part Number	Part Name	Classic Part Number
8C-8741	Kit-Gasket-(Rs)	438-0172
8H-9789	Bearing-Ball	374-8342
8T-0072	Cone-Rlr Brg	377-7448
8T-2466	Gasket Kit	393-5199
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
139-9176	Gasket Kit	390-5283
158-1433	Gasket Kit	393-1003
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
174-6836	Gasket Kit - Tof	434-7280
237-2859	Bearing-Rlr	368-0125

90P		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4231	Pump Gp-Gear	226-0156
1P-4303	Head As-Cylinder	242-3434
1P-8554	Coupling-Exhaust	325-6052

90P		
Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1T-0020	Wheel-Turbine	297-4862
1T-0210	Bearing-Ball	417-4498
1T-0406	Wheel-Impeller	384-3854
1T-0555	Carrier-Gde Whl	384-3853
1T-0576	Bearing-Sleeve	379-0186
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108

90P		
Original Part Number	Part Name	Classic Part Number
1T-1016	Carrier-Guide	388-6584
1T-1051	Impeller-Conv	388-6598
1T-1053	Turbine As-Conv	377-7412
1T-1331	Stator-Converter	229-8237
1T-1428	Retainer-Brg	300-2587
1T-1701	Carrier-Stator	384-3853
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1T-1988	Shaft-Output	428-6656
1U-2668	Cartridge Gp	422-8117
1V-1080	Housing-Brg Spt	260-0775

Sales Model 814 (Cont'd.)

90P		
Original Part Number	Part Name	Classic Part Number
1V-3995	Pin	319-3449
1V-5724	Diff Gp -A	260-0776
1V-6913	Tube As	435-4793
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-6473	Compressor Gp -B	448-9150
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532

90P		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-5608	Pipe-Extension	367-6066
2P-5609	Muffler As.	247-2665
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2V-6221	Shaft-Planet	221-9108
2V-6327	Support As-Front	391-9832
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055

90P		
Original Part Number	Part Name	Classic Part Number
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3G-2834	Cartridge Gp-Rr	426-0025
3G-7657	Cartridge Gp	422-8101
3G-7662	Cartridge Gp	422-8105
3H-8726	Mount As	385-7208
3J-2443	Bearing	383-2125
3J-9325	Piston	390-0993
3K-0526	Bearing-Ball	386-4949
3K-4290	Rod End	374-1823
3K-7020	Gear-Planet	221-9074
3L-1425	Bearing-Ball	311-9356
3P-5672	Yoke	223-6313
3P-5955	Disc-Friction	428-7205
3S-5017	Elbow-Exhaust	369-9498
3T-2095	Bearing-Sleeve	384-3459
3V-5762	Support As	389-6310
3V-7427	Housing As	297-7197
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4J-6167	Bearing-Sleeve	325-6009
4K-6212	Shaft-Bev Pinion	223-4806
4K-6558	Pin-Lower	302-2710
4K-6736	Drum-Brake	223-6320
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7269	Support-Trun-Frt	299-2067

Sales Model 814 (Cont'd.)

90P		
Original Part Number	Part Name	Classic Part Number
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4K-7556	Yoke	385-6118
4K-8225	Pin-Cylinder	297-7215
4K-8561	Pin	299-2036
4K-8734	Bearing-Sleeve	299-1962
4K-9598	Retainer	297-7235
4M-3915	Bearing-Caged	377-7427
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3927	Compressor As	435-6051
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4N-9941	Line As-Fuel Inj	380-1562

90P		
Original Part Number	Part Name	Classic Part Number
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572
4N-9944	Line As-Fuel Inj	380-1565
4P-3546	Valve As-Relief	325-6236
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4S-5891	Plate-Clutch	388-0575
4S-5943	Piston-Clutch	221-9112
4S-8530	Shaft-Planet	221-9111
4S-8534	Shaft As-Planet	221-9116
4S-8538	Bearing-Spl Ball	417-4502
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5G-3612	Cap Gp-Protn	295-6419
5K-0609	Cover	308-9843
5K-2294	Bearing	396-9912
5K-5933	Cover As	247-4125
5L-6326	Bearing-Ball	420-3222
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467

90P		
Original Part Number	Part Name	Classic Part Number
5M-5856	Pipe-Extension	373-1913
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4326	Housing-Screen	435-4790
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-6978	Shaft-Planet	221-9103
5S-7010	Shaft-Planet	221-9104
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
6B-7469	Spacer	417-4535
6H-2577	Spider Gp-Brg	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2034	Shaft	297-7249
6K-4442	Rod End-Special	373-5388
6K-4599	Yoke As	385-6111

Sales Model 814 (Cont'd.)

90P		
Original Part Number	Part Name	Classic Part Number
6K-4600	Yoke	226-5993
6K-8088	Bearing-Roller	399-4428
6K-8895	Cap	374-6500
6K-8897	Bracket As	299-1977
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
6Y-2027	Disc-Friction	377-7441
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5348	Disc-Friction	384-4827
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2487	Gear-Planet	221-9092
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015

90P		
Original Part Number	Part Name	Classic Part Number
7J-5131	Trunnion	296-1371
7K-0449	Yoke As	297-7271
7K-0450	Yoke As	297-7272
7K-0686	Trunnion-Rear	297-7266
7K-8890	Tube As	391-1098
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5511	Gear As-Idler	233-2180
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519

90P		
Original Part Number	Part Name	Classic Part Number
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-3170	Bearing-Roller	417-4504
8F-6058	Bearing-Sleeve	416-5494
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420

Sales Model 814 (Cont'd.)

90P		
Original Part Number	Part Name	Classic Part Number
8J-7978	Bearing-Spher	388-0581
8K-6282	Gear-Sun	281-1698
8M-3368	Valve-Check	388-6599
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349

90P		
Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1656	Plate-Clutch	367-6071
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3554	Yoke	448-9154
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6380	Tube As	452-0446
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
8T-0072	Cone-Rlr Brg	377-7448
8T-2466	Gasket Kit	393-5199
8V-3134	Pinion-Bevel	260-0788
9B-1320	Valve-Check	377-5832

90P		
Original Part Number	Part Name	Classic Part Number
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-5049	Pump Gp-Vn Bsc-B	422-8156
9K-1193	Gear-Sun	221-9099
9K-1773	Gear-Ring	221-9100
9K-3413	Gear-Bevel	223-4807
9M-1328	Bearing-Aligning	325-6018
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-8281	Gear As-Pump	325-6089
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834

Sales Model 814 (Cont'd.)

90P		
Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
139-9176	Gasket Kit	390-5283
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361
158-1433	Gasket Kit	393-1003
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

90P		
Original Part Number	Part Name	Classic Part Number
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
170-0560	Rebuild Kit-Pump	363-7458
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
174-6836	Gasket Kit - Tof	434-7280

90P		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

Sales Model 844K

KLS		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438

KLS		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114

Sales Model 844K (Cont'd.)

KLS		
Original Part Number	Part Name	Classic Part Number
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-4695	Cup-Rlr Bearing	374-1842
1P-4696	Cone-Rlr Bearing	374-1843
1S-9110	Bearing-Needle	420-2497
1T-0766	Bearing-Sleeve	383-2107
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-1401	Ring-Seal	384-4799
1U-3953	Cartridge Gp	426-0024
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-7663	Cartridge Gp	422-8120
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4D-7534	Bearing As-Rlr	441-5602
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-6658	Bearing-Sleeve	373-1885

KLS		
Original Part Number	Part Name	Classic Part Number
4T-0406	Rod As	394-8215
4T-4073	Valve Gp-Shtl -B	439-1138
4T-7534	Pin	433-9209
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-7404	Nut-Bearing Lock	308-9878
5J-1192	Bearing-Sleeve	374-8355
5J-2528	Plunger	391-1318
5L-5772	Race & Roller As	394-9200
5M-7925	Bearing-Roller	419-7774
5P-8043	Bearing-Cone	423-6989
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-5179	Retainer	380-7406
6W-7352	Retainer	424-0741
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7J-1335	Bearing-Sleeve	380-7567
7J-1336	Bearing-Sleeve	384-4776
7K-8877	Cone-Bearing	374-1847
7N-2156	Bearing-Sleeve	380-7373
7T-2879	Trunnion As	396-7262
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639

KLS		
Original Part Number	Part Name	Classic Part Number
8J-7466	Seat	385-3787
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9J-0123	Trunnion	325-6227
9J-2365	Retainer	325-6186
9J-5284	Bearing-Sleeve	380-7379
9M-2744	Cone-Spl Tapered	380-1480
9V-9840	Spider	417-9498
9W-9930	Mount As	295-6437
101-3374	Gear-Camshaft Dr	376-9069
108-7930	Bearing As	377-7463
117-9712	Shaft-Dr Idler	425-7754
126-8181	Cone-Spl Tapered	434-3295
127-6356	Cover As.-Pump	420-8566
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
157-0956	Pump Gp-Vn Bsc-B	422-8154
160-9874	Kit-Gasket-Scl	386-3048
173-0888	Univ Jt As	394-0898
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
238-0293	Adapter-Jacket	424-0742
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367

MBE		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438

MBE		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114

MBE		
Original Part Number	Part Name	Classic Part Number
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504

Sales Model 844K (Cont'd.)

MBE		
Original Part Number	Part Name	Classic Part Number
1P-4695	Cup-Rlr Bearing	374-1842
1P-4696	Cone-Rlr Bearing	374-1843
1S-9110	Bearing-Needle	420-2497
1T-0766	Bearing-Sleeve	383-2107
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-1401	Ring-Seal	384-4799
1U-3953	Cartridge Gp	426-0024
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-7663	Cartridge Gp	422-8120
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4D-7534	Bearing As-Rlr	441-5602
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-6658	Bearing-Sleeve	373-1885
4T-0406	Rod As	394-8215
4T-4073	Valve Gp-Shtl -B	439-1138

MBE		
Original Part Number	Part Name	Classic Part Number
4T-7534	Pin	433-9209
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-7404	Nut-Bearing Lock	308-9878
5J-1192	Bearing-Sleeve	374-8355
5J-2528	Plunger	391-1318
5L-5772	Race & Roller As	394-9200
5M-7925	Bearing-Roller	419-7774
5P-8043	Bearing-Cone	423-6989
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-5179	Retainer	380-7406
6W-7352	Retainer	424-0741
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7J-1335	Bearing-Sleeve	380-7567
7J-1336	Bearing-Sleeve	384-4776
7K-8877	Cone-Bearing	374-1847
7N-2156	Bearing-Sleeve	380-7373
7T-2879	Trunnion As	396-7262
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8J-7466	Seat	385-3787
8N-2104	Bell As-Suction	380-1521

MBE		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
9J-0123	Trunnion	325-6227
9J-2365	Retainer	325-6186
9J-5284	Bearing-Sleeve	380-7379
9M-2744	Cone-Spl Tapered	380-1480
9V-9840	Spider	417-9498
9W-9930	Mount As	295-6437
101-3374	Gear-Camshaft Dr	376-9069
108-7930	Bearing As	377-7463
117-9712	Shaft-Dr Idler	425-7754
126-8181	Cone-Spl Tapered	434-3295
127-6356	Cover As.-Pump	420-8566
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
157-0956	Pump Gp-Vn Bsc-B	422-8154
160-9874	Kit-Gasket-Scl	386-3048
173-0888	Univ Jt As	394-0898
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
238-0293	Adapter-Jacket	424-0742
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367

Sales Model DW10

01N		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368

Sales Model DW10 (Cont'd.)

01N		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354

01N		
Original Part Number	Part Name	Classic Part Number
2S-4015	Plunger As-Valve	311-9438
3K-3124	Muffler-Trap	247-2673
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555

01N		
Original Part Number	Part Name	Classic Part Number
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
9B-1320	Valve-Check	377-5832
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

01V		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1P-7125	Governor As	383-3672
1S-1967	Chamber As	247-3291
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-2978	Spider & Brg As	399-4424
2D-9130	Washer-Thrust	308-9943
2F-5721	Bearing-Ball	311-9354
2S-1273	Chamber As	319-3434
2S-4015	Plunger As-Valve	311-9438
3D-5315	Pinion-Dif Bevel	308-9856
4B-1455	Cap As-Filler	361-1719
4M-0410	Gear-Oil Pump Dr	428-6660

01V		
Original Part Number	Part Name	Classic Part Number
5D-7449	Cup-Spl Tapered	416-2161
5D-9675	Spider	394-9203
5F-1248	Cone-Roller Brg	399-4441
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7M-1154	Bearing-Spl	417-4515
7M-4603	Body-Fuel Valve	311-9348
7S-7809	Cap As-Radiator	295-6417
8H-9789	Bearing-Ball	374-8342
9B-1320	Valve-Check	377-5832
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
1A-2846	Cap As-Filler	311-9368

01V		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2S-4015	Plunger As-Valve	311-9438
3K-3124	Muffler-Trap	247-2673
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
9B-1320	Valve-Check	377-5832
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

Sales Model DW15

45C		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1J-0774	Bracket	369-9485
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-2978	Spider & Brg As	399-4424
2D-9130	Washer-Thrust	308-9943
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3D-5315	Pinion-Dif Bevel	308-9856
3F-4971	Pin	295-5693
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208

45C		
Original Part Number	Part Name	Classic Part Number
4B-1455	Cap As-Filler	361-1719
4J-1999	Ballstud	314-8625
5D-0470	Valve Gp-Qrel	314-8549
5D-7449	Cup-Spl Tapered	416-2161
5D-9675	Spider	394-9203
5F-1248	Cone-Roller Brg	399-4441
5F-2830	Bearing-Needle	384-5925
5F-7993	Pin	319-3454
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6F-2904	Bearing	295-5673
6H-2577	Spider Gp-Brg	333-4954
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495

45C		
Original Part Number	Part Name	Classic Part Number
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8B-5965	Race & Roller As	417-4512
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-9365	Pin	319-3463
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
160-6305	Cap-Bearing	295-5686

Sales Model DW15C

59C		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443

59C		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1P-7125	Governor As	383-3672
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
1S-9670	Univ Jt As	443-2017
1T-0210	Bearing-Ball	417-4498

59C		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2978	Spider & Brg As	399-4424
2D-9130	Washer-Thrust	308-9943
2F-5721	Bearing-Ball	311-9354

Sales Model DW15C (Cont'd.)

59C		
Original Part Number	Part Name	Classic Part Number
2S-1273	Chamber As	319-3434
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3D-5315	Pinion-Dif Bevel	308-9856
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-0410	Gear-Oil Pump Dr	428-6660
4M-9215	Gear-Pump Idler	311-9391
5B-9169	Plug-Drain	419-4736
5D-0470	Valve Gp-Qrel	314-8549
5D-7449	Cup-Spl Tapered	416-2161
5D-9675	Spider	394-9203
5F-1248	Cone-Roller Brg	399-4441
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg	333-4954
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495

59C		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
7F-9547	Pin As.-Drawbar	295-0414
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8B-5965	Race & Roller As	417-4512
8F-9365	Pin	319-3463
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9B-1320	Valve-Check	377-5832
9M-5350	Spring-Valve	380-7573
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-2978	Spider & Brg As	399-4424
2D-9130	Washer-Thrust	308-9943
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099

59C		
Original Part Number	Part Name	Classic Part Number
3D-5315	Pinion-Dif Bevel	308-9856
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-9215	Gear-Pump Idler	311-9391
5D-0470	Valve Gp-Qrel	314-8549
5D-7449	Cup-Spl Tapered	416-2161
5D-9675	Spider	394-9203
5F-1248	Cone-Roller Brg	399-4441
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg	333-4954
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
7F-9547	Pin As.-Drawbar	295-0414
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8B-5965	Race & Roller As	417-4512

Sales Model DW15C (Cont'd.)

59C		
Original Part Number	Part Name	Classic Part Number
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494

59C		
Original Part Number	Part Name	Classic Part Number
8F-9365	Pin	319-3463
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342

59C		
Original Part Number	Part Name	Classic Part Number
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

Sales Model DW15E

75D		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0210	Bearing-Ball	417-4498
2D-2978	Spider & Brg As	399-4424
2D-9130	Washer-Thrust	308-9943
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3D-5315	Pinion-Dif Bevel	308-9856
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719

75D		
Original Part Number	Part Name	Classic Part Number
4M-9215	Gear-Pump Idler	311-9391
5D-0470	Valve Gp-Qrel	314-8549
5D-7449	Cup-Spl Tapered	416-2161
5D-9675	Spider	394-9203
5F-1248	Cone-Roller Brg	399-4441
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg	333-4954
6H-3566	Cone-Bearing	415-1918

75D		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
6V-2202	Bearing-Spl Ball	380-1574
7F-9547	Pin As.-Drawbar	295-0414
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-9365	Pin	319-3463
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9M-5350	Spring-Valve	380-7573

76D		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849

Sales Model DW15E (Cont'd.)

76D		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-2978	Spider & Brg As	399-4424
2D-9130	Washer-Thrust	308-9943
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3D-5315	Pinion-Dif Bevel	308-9856
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356

76D		
Original Part Number	Part Name	Classic Part Number
4B-1455	Cap As-Filler	361-1719
4M-9215	Gear-Pump Idler	311-9391
5D-0470	Valve Gp-Qrel	314-8549
5D-7449	Cup-Spl Tapered	416-2161
5D-9675	Spider	394-9203
5F-1248	Cone-Roller Brg	399-4441
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg	333-4954
6H-3566	Cone-Bearing	415-1918

76D		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
7F-9547	Pin As.-Drawbar	295-0414
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-9365	Pin	319-3463
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9M-5350	Spring-Valve	380-7573

Sales Model DW15F

75D		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0210	Bearing-Ball	417-4498
2D-2978	Spider & Brg As	399-4424
2D-9130	Washer-Thrust	308-9943
2S-3966	Ring-Seal	297-7237

75D		
Original Part Number	Part Name	Classic Part Number
3B-1142	Retainer-Spring	391-1099
3D-5315	Pinion-Dif Bevel	308-9856
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-9215	Gear-Pump Idler	311-9391
5D-0470	Valve Gp-Qrel	314-8549

75D		
Original Part Number	Part Name	Classic Part Number
5D-7449	Cup-Spl Tapered	416-2161
5D-9675	Spider	394-9203
5F-1248	Cone-Roller Brg	399-4441
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467

Sales Model DW15F (Cont'd.)

75D		
Original Part Number	Part Name	Classic Part Number
5S-1211	Cover-Valve	314-8665
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg	333-4954
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6V-2202	Bearing-Spl Ball	380-1574

75D		
Original Part Number	Part Name	Classic Part Number
7F-9547	Pin As.-Drawbar	295-0414
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417

75D		
Original Part Number	Part Name	Classic Part Number
8F-9365	Pin	319-3463
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9M-5350	Spring-Valve	380-7573

76D		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-2978	Spider & Brg As	399-4424
2D-9130	Washer-Thrust	308-9943
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3D-5315	Pinion-Dif Bevel	308-9856
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823

76D		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-9215	Gear-Pump Idler	311-9391
5D-0470	Valve Gp-Qrel	314-8549
5D-7449	Cup-Spl Tapered	416-2161
5D-9675	Spider	394-9203
5F-1248	Cone-Roller Brg	399-4441
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg	333-4954
6H-3566	Cone-Bearing	415-1918

76D		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
7F-9547	Pin As.-Drawbar	295-0414
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-9365	Pin	319-3463
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9M-5350	Spring-Valve	380-7573

Sales Model DW20

06W		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1S-1888	Bracket-Lamp	297-7147
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
4B-1455	Cap As-Filler	361-1719

06W		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg	333-4954
7F-7780	Pin-Anchor	384-4825
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348

06W		
Original Part Number	Part Name	Classic Part Number
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-0901	Cup-Spl Tap Roll	399-4444
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
9F-3212	Bearing-Ball	384-5953
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

21C		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1H-5338	Cup-Roller Brg	374-8345
1S-1888	Bracket-Lamp	297-7147
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2S-3966	Ring-Seal	297-7237

21C		
Original Part Number	Part Name	Classic Part Number
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5H-7071	Director-Water	388-0555

21C		
Original Part Number	Part Name	Classic Part Number
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg	333-4954
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
7B-7515	Bearing-Ball	399-6059
7F-7780	Pin-Anchor	384-4825
7F-9541	Pin As-Drawbar	296-1361
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348

Sales Model DW20 (Cont'd.)

21C		
Original Part Number	Part Name	Classic Part Number
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539

21C		
Original Part Number	Part Name	Classic Part Number
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-0901	Cup-Spl Tap Roll	399-4444
8H-4320	Bearing-Ball	419-2301

21C		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

50C		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1H-5338	Cup-Roller Brg	374-8345
1S-1888	Bracket-Lamp	297-7147
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208

50C		
Original Part Number	Part Name	Classic Part Number
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg	333-4954
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
7B-7515	Bearing-Ball	399-6059
7F-7780	Pin-Anchor	384-4825
7F-9541	Pin As-Drawbar	296-1361
7H-6967	Bearing-Ball	422-6489

50C		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-0901	Cup-Spl Tap Roll	399-4444
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

Sales Model DW20E

57C		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1T-0210	Bearing-Ball	417-4498
2D-5658	Bearing-Ball	301-4628
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4M-9215	Gear-Pump Idler	311-9391

57C		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg	333-4954
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173

57C		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9M-5350	Spring-Valve	380-7573

67C		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5658	Bearing-Ball	301-4628
2D-5961	Pin-Axle Pivot	228-9438
2S-3966	Ring-Seal	297-7237

67C		
Original Part Number	Part Name	Classic Part Number
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6926	Segment-Control	228-9455
4M-9215	Gear-Pump Idler	311-9391

67C		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6F-6992	Cap-Ballsocket	297-7160

Sales Model DW20E (Cont'd.)

67C		
Original Part Number	Part Name	Classic Part Number
6H-2577	Spider Gp-Brg	333-4954
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825
7H-6967	Bearing-Ball	422-6489

67C		
Original Part Number	Part Name	Classic Part Number
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485

67C		
Original Part Number	Part Name	Classic Part Number
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8W-9587	Flange As	373-5394
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

87E		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1T-0210	Bearing-Ball	417-4498
2D-5658	Bearing-Ball	301-4628
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4M-9215	Gear-Pump Idler	311-9391

87E		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg	333-4954
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173

87E		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9M-5350	Spring-Valve	380-7573

88E		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368

Sales Model DW20E (Cont'd.)

88E		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5658	Bearing-Ball	301-4628
2D-5961	Pin-Axle Pivot	228-9438
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719

88E		
Original Part Number	Part Name	Classic Part Number
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6926	Segment-Control	228-9455
4M-9215	Gear-Pump Idler	311-9391
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6F-6992	Cap-Ballsocket	297-7160
6H-2577	Spider Gp-Brg	333-4954
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173

88E		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8W-9587	Flange As	373-5394
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

Sales Model DW20F

57C		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1T-0210	Bearing-Ball	417-4498
2D-5658	Bearing-Ball	301-4628
2S-3966	Ring-Seal	297-7237

57C		
Original Part Number	Part Name	Classic Part Number
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356

57C		
Original Part Number	Part Name	Classic Part Number
4B-1455	Cap As-Filler	361-1719
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4M-9215	Gear-Pump Idler	311-9391
5D-0470	Valve Gp-Qrel	314-8549

Sales Model DW20F (Cont'd.)

57C		
Original Part Number	Part Name	Classic Part Number
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738

57C		
Original Part Number	Part Name	Classic Part Number
6H-2577	Spider Gp-Brg	333-4954
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816

57C		
Original Part Number	Part Name	Classic Part Number
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9M-5350	Spring-Valve	380-7573

67C		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5658	Bearing-Ball	301-4628
2D-5961	Pin-Axle Pivot	228-9438
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823

67C		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6926	Segment-Control	228-9455
4M-9215	Gear-Pump Idler	311-9391
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6F-6992	Cap-Ballsocket	297-7160

67C		
Original Part Number	Part Name	Classic Part Number
6H-2577	Spider Gp-Brg	333-4954
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439

Sales Model DW20F (Cont'd.)

67C		
Original Part Number	Part Name	Classic Part Number
8W-9587	Flange As	373-5394

67C		
Original Part Number	Part Name	Classic Part Number
9L-2685	Rod End	419-1866

67C		
Original Part Number	Part Name	Classic Part Number
9M-5350	Spring-Valve	380-7573

87E		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1T-0210	Bearing-Ball	417-4498
2D-5658	Bearing-Ball	301-4628
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4M-9215	Gear-Pump Idler	311-9391

87E		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg	333-4954
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173

87E		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9M-5350	Spring-Valve	380-7573

88E		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424

88E		
Original Part Number	Part Name	Classic Part Number
2D-3188	Yoke	365-8822
2D-5658	Bearing-Ball	301-4628
2D-5961	Pin-Axle Pivot	228-9438
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992

88E		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6926	Segment-Control	228-9455
4M-9215	Gear-Pump Idler	311-9391

Sales Model DW20F (Cont'd.)

88E		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6F-6992	Cap-Ballsocket	297-7160

88E		
Original Part Number	Part Name	Classic Part Number
6H-2577	Spider Gp-Brg	333-4954
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417

88E		
Original Part Number	Part Name	Classic Part Number
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8W-9587	Flange As	373-5394
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

Sales Model DW20G

57C		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1T-0210	Bearing-Ball	417-4498
2D-5658	Bearing-Ball	301-4628
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4D-4661	Pump Gp-Vn Bsc-A	422-8162

57C		
Original Part Number	Part Name	Classic Part Number
4M-9215	Gear-Pump Idler	311-9391
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg	333-4954
6V-1013	Bearing	396-4140

57C		
Original Part Number	Part Name	Classic Part Number
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342

Sales Model DW20G (Cont'd.)

57C		
Original Part Number	Part Name	Classic Part Number
8M-0874	Plunger As-Valve	311-9439

57C		
Original Part Number	Part Name	Classic Part Number
9M-5350	Spring-Valve	380-7573

67C		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5658	Bearing-Ball	301-4628
2D-5961	Pin-Axle Pivot	228-9438
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356

67C		
Original Part Number	Part Name	Classic Part Number
4B-1455	Cap As-Filler	361-1719
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6926	Segment-Control	228-9455
4M-9215	Gear-Pump Idler	311-9391
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6F-6992	Cap-Ballsocket	297-7160
6H-2577	Spider Gp-Brg	333-4954
6V-1013	Bearing	396-4140

67C		
Original Part Number	Part Name	Classic Part Number
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8W-9587	Flange As	373-5394
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

87E		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1T-0210	Bearing-Ball	417-4498

87E		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099

87E		
Original Part Number	Part Name	Classic Part Number
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208

Sales Model DW20G (Cont'd.)

87E		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4M-9215	Gear-Pump Idler	311-9391
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555

87E		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg	333-4954
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825

87E		
Original Part Number	Part Name	Classic Part Number
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9M-5350	Spring-Valve	380-7573

88E		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5658	Bearing-Ball	301-4628
2D-5961	Pin-Axle Pivot	228-9438
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992

88E		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6926	Segment-Control	228-9455
4M-9215	Gear-Pump Idler	311-9391
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665

88E		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6F-6992	Cap-Ballsocket	297-7160
6H-2577	Spider Gp-Brg	333-4954
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-5104	Screen As-Se Pan	314-8539

Sales Model DW20G (Cont'd.)

88E		
Original Part Number	Part Name	Classic Part Number
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485

88E		
Original Part Number	Part Name	Classic Part Number
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439

88E		
Original Part Number	Part Name	Classic Part Number
8W-9587	Flange As	373-5394
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

Sales Model DW21

08W		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
2A-4429	Lock-Retainer	379-0174
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
4B-1455	Cap As-Filler	361-1719
4M-5226	Bearing-Ball	399-6061
5D-0470	Valve Gp-Qrel	314-8549

08W		
Original Part Number	Part Name	Classic Part Number
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
7F-7780	Pin-Anchor	384-4825
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417

08W		
Original Part Number	Part Name	Classic Part Number
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-0901	Cup-Spl Tap Roll	399-4444
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

Sales Model DW21C

58C		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
2S-3966	Ring-Seal	297-7237

58C		
Original Part Number	Part Name	Classic Part Number
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498

58C		
Original Part Number	Part Name	Classic Part Number
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208

Sales Model DW21C (Cont'd.)

58C		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-9215	Gear-Pump Idler	311-9391
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555

58C		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816

58C		
Original Part Number	Part Name	Classic Part Number
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9M-5350	Spring-Valve	380-7573

69C		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
2A-4429	Lock-Retainer	379-0174
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-9215	Gear-Pump Idler	311-9391

69C		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825
7H-6967	Bearing-Ball	422-6489

69C		
Original Part Number	Part Name	Classic Part Number
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

85E		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849

Sales Model DW21C (Cont'd.)

85E		
Original Part Number	Part Name	Classic Part Number
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-9215	Gear-Pump Idler	311-9391
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060

85E		
Original Part Number	Part Name	Classic Part Number
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825
7M-4603	Body-Fuel Valve	311-9348

85E		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9M-5350	Spring-Valve	380-7573

86E		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
2A-4429	Lock-Retainer	379-0174
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-9215	Gear-Pump Idler	311-9391

86E		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825
7H-6967	Bearing-Ball	422-6489

86E		
Original Part Number	Part Name	Classic Part Number
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

Sales Model DW21D

58C		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-9215	Gear-Pump Idler	311-9391
5D-0470	Valve Gp-Qrel	314-8549

58C		
Original Part Number	Part Name	Classic Part Number
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825

58C		
Original Part Number	Part Name	Classic Part Number
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9M-5350	Spring-Valve	380-7573

69C		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
2A-4429	Lock-Retainer	379-0174
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-9215	Gear-Pump Idler	311-9391

69C		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825
7H-6967	Bearing-Ball	422-6489

69C		
Original Part Number	Part Name	Classic Part Number
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

Sales Model DW21D (Cont'd.)

85E		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-9215	Gear-Pump Idler	311-9391
5D-0470	Valve Gp-Qrel	314-8549

85E		
Original Part Number	Part Name	Classic Part Number
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825

85E		
Original Part Number	Part Name	Classic Part Number
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9M-5350	Spring-Valve	380-7573

86E		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
2A-4429	Lock-Retainer	379-0174
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-9215	Gear-Pump Idler	311-9391

86E		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825
7H-6967	Bearing-Ball	422-6489

86E		
Original Part Number	Part Name	Classic Part Number
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

Sales Model DW21G

58C		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-9215	Gear-Pump Idler	311-9391
5D-0470	Valve Gp-Qrel	314-8549

58C		
Original Part Number	Part Name	Classic Part Number
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825

58C		
Original Part Number	Part Name	Classic Part Number
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9M-5350	Spring-Valve	380-7573

69C		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
2A-4429	Lock-Retainer	379-0174
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-9215	Gear-Pump Idler	311-9391

69C		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825
7H-6967	Bearing-Ball	422-6489

69C		
Original Part Number	Part Name	Classic Part Number
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

Sales Model DW21G (Cont'd.)

85E		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-9215	Gear-Pump Idler	311-9391
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825
7M-4603	Body-Fuel Valve	311-9348

85E		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9M-5350	Spring-Valve	380-7573
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
2A-4429	Lock-Retainer	379-0174
2S-3966	Ring-Seal	297-7237
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-9215	Gear-Pump Idler	311-9391
5D-0470	Valve Gp-Qrel	314-8549
5F-2465	Cup-Roller Brg	447-8060

85E		
Original Part Number	Part Name	Classic Part Number
5F-2830	Bearing-Needle	384-5925
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5T-5682	Driver	418-9579
6B-6224	Ferrule	419-4738
6V-2202	Bearing-Spl Ball	380-1574
7F-7780	Pin-Anchor	384-4825
7H-6967	Bearing-Ball	422-6489
7M-4603	Body-Fuel Valve	311-9348
7N-7639	Rotator-Valve	383-1582
7S-7809	Cap As-Radiator	295-6417
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573

Sales Model J619

43F		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347

Sales Model J619 (Cont'd.)

43F		
Original Part Number	Part Name	Classic Part Number
1J-4757	Cone-Bearing	374-1840
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
2D-5658	Bearing-Ball	301-4628
2K-0227	Bearing-Sleeve	384-4780

43F		
Original Part Number	Part Name	Classic Part Number
2T-3885	Housing	448-4967
5D-0470	Valve Gp-Qrel	314-8549
5F-2830	Bearing-Needle	384-5925
5F-7958	Shaft-Roller	434-1865
5J-9348	Bearing As	416-2162
5T-5682	Driver	418-9579

43F		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
7F-7780	Pin-Anchor	384-4825
8B-5972	Bearing-Ball	314-8503
8H-9789	Bearing-Ball	374-8342
8W-1708	Pin	388-0643
308-1845	Seal-Wiper	472-8032

Sales Model J621

43H		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
2D-5658	Bearing-Ball	301-4628
2K-0227	Bearing-Sleeve	384-4780
2T-3885	Housing	448-4967
3J-9133	Bearing-Sleeve	361-1691

43H		
Original Part Number	Part Name	Classic Part Number
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
5D-0470	Valve Gp-Qrel	314-8549
5F-2830	Bearing-Needle	384-5925

43H		
Original Part Number	Part Name	Classic Part Number
5F-7958	Shaft-Roller	434-1865
5J-9348	Bearing As	416-2162
6H-3957	Bearing-Ball	311-9358
7F-7780	Pin-Anchor	384-4825
8B-5972	Bearing-Ball	314-8503
8H-9789	Bearing-Ball	374-8342
8W-1708	Pin	388-0643
132-6597	Cone-Spl	422-6477

Sales Model 216

4NZ		
Original Part Number	Part Name	Classic Part Number
6T-5611	Spacer	435-8520
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

4NZ		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
142-8811	Muffler As	360-2297

4NZ		
Original Part Number	Part Name	Classic Part Number
142-8845	Muffler As	360-9619
176-3900	Accumulator	416-5513

Sales Model 216B

CD3		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420
1S-7056	Bearing-Ball	422-6483

CD3		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

CD3		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

Sales Model 226

5FZ		
Original Part Number	Part Name	Classic Part Number
6T-5611	Spacer	435-8520
6Y-7652	Cup-Rlr Brg	399-6067

5FZ		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

5FZ		
Original Part Number	Part Name	Classic Part Number
142-8811	Muffler As	360-2297
142-8845	Muffler As	360-9619

Sales Model 226B

AS2		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420
176-3900	Accumulator	416-5513
176-3900	Accumulator	416-5513
1S-7056	Bearing-Ball	422-6483

AS2		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420
176-3900	Accumulator	416-5513
1S-7056	Bearing-Ball	422-6483
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

AS2		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
176-3900	Accumulator	416-5513
1S-7056	Bearing-Ball	422-6483
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420
176-3900	Accumulator	416-5513

Skid Steer Loaders

Sales Model 228

6BZ		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
6T-5611	Spacer	435-8520
6Y-7652	Cup-Rlr Brg	399-6067

6BZ		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

6BZ		
Original Part Number	Part Name	Classic Part Number
142-8811	Muffler As	360-2297
142-8845	Muffler As	360-9619

Sales Model 232

CAB		
Original Part Number	Part Name	Classic Part Number
6T-5611	Spacer	435-8520
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

CAB		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
142-8845	Muffler As	360-9619

Sales Model 232B

SCH		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

SCH		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
176-3900	Accumulator	416-5513

Sales Model 232D

DPR, KXC		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
176-3900	Accumulator	416-5513

DPR, KXC		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
176-3900	Accumulator	416-5513

Sales Model 236

4YZ		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
6T-5611	Spacer	435-8520

4YZ		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

4YZ		
Original Part Number	Part Name	Classic Part Number
126-5984	Ring-Backup	419-4654
142-8845	Muffler As	360-9619
176-3900	Accumulator	416-5513

Sales Model 236B

A9H		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067

A9H		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

HEN		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513
6K-2899	Bearing-Sleeve	453-6505
6K-4148	Bearing-Sleeve	393-3670

HEN		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

HEN		
Original Part Number	Part Name	Classic Part Number
126-5984	Ring-Backup	419-4654
176-3900	Accumulator	416-5513

Sales Model 239D

BL9, CD4		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
176-3900	Accumulator	416-5513

BL9, CD4		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032
6K-4148	Bearing-Sleeve	393-3670

BL9, CD4		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513
308-1845	Seal-Wiper	472-8032

Sales Model 242

CMB		
Original Part Number	Part Name	Classic Part Number
6T-5611	Spacer	435-8520
6Y-7652	Cup-Rlr Brg	399-6067

CMB		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

CMB		
Original Part Number	Part Name	Classic Part Number
142-8845	Muffler As	360-9619
176-3900	Accumulator	416-5513

Sales Model 242B

BXM		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

BXM		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
176-3900	Accumulator	416-5513

Skid Steer Loaders

Sales Model 242B (Cont'd.)

SRS		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
6B-7469	Spacer	417-4535

SRS		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

SRS		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
176-3900	Accumulator	416-5513

Sales Model 242D

A9W, DML, DZT		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
6K-4148	Bearing-Sleeve	393-3670

A9W, DML, DZT		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

A9W, DML, DZT		
Original Part Number	Part Name	Classic Part Number
9M-1853	Mount As.	376-3638
176-3900	Accumulator	416-5513

Sales Model 246

5SZ		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
6T-5611	Spacer	435-8520

5SZ		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

5SZ		
Original Part Number	Part Name	Classic Part Number
126-5984	Ring-Backup	419-4654
142-8845	Muffler As	360-9619
176-3900	Accumulator	416-5513

Sales Model 246B

PAT		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067

PAT		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

PAT		
Original Part Number	Part Name	Classic Part Number
126-5984	Ring-Backup	419-4654
176-3900	Accumulator	416-5513

Sales Model 246C

JAY		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
6K-4148	Bearing-Sleeve	393-3670

JAY		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

JAY		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
176-3900	Accumulator	416-5513

Sales Model 246D

BYF		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433

BYF		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

BYF		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
9M-1853	Mount As.	376-3638
176-3900	Accumulator	416-5513

HMR		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433

HMR		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

HMR		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
9M-1853	Mount As.	376-3638
176-3900	Accumulator	416-5513

JSL		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433

JSL		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

JSL		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
9M-1853	Mount As.	376-3638
176-3900	Accumulator	416-5513

Sales Model 247

CML		
Original Part Number	Part Name	Classic Part Number
3N-6411	Cup-Rlr Bearing	423-7759
6T-5611	Spacer	435-8520

CML		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

CML		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
142-8845	Muffler As	360-9619

Sales Model 247B

ESL, KB3		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
3N-6411	Cup-Rlr Bearing	423-7759

ESL, KB3		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

ESL, KB3		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
176-3900	Accumulator	416-5513

Skid Steer Loaders

Sales Model 247B (Cont'd.)

MTL, TSL		
Original Part Number	Part Name	Classic Part Number
3N-6411	Cup-Rlr Bearing	423-7759

MTL, TSL		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

MTL, TSL		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
176-3900	Accumulator	416-5513

Sales Model 248

6LZ		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
6K-4148	Bearing-Sleeve	393-3670

6LZ		
Original Part Number	Part Name	Classic Part Number
6T-5611	Spacer	435-8520
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

6LZ		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
142-8845	Muffler As	360-9619

Sales Model 248B

SCL		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
6K-4148	Bearing-Sleeve	393-3670

SCL		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

SCL		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
176-3900	Accumulator	416-5513

Sales Model 249D

AH9, GWR		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670

AH9, GWR		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513
308-1845	Seal-Wiper	472-8032

Sales Model 252

FDG		
Original Part Number	Part Name	Classic Part Number
2G-8631	Bearing-Sleeve	391-9811
6K-2899	Bearing-Sleeve	453-6505
6K-4148	Bearing-Sleeve	393-3670

FDG		
Original Part Number	Part Name	Classic Part Number
6T-5611	Spacer	435-8520
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

FDG		
Original Part Number	Part Name	Classic Part Number
126-5984	Ring-Backup	419-4654
142-8845	Muffler As	360-9619
176-3900	Accumulator	416-5513

Sales Model 252B

SCP, TNK		
Original Part Number	Part Name	Classic Part Number
6K-2899	Bearing-Sleeve	453-6505
6K-4148	Bearing-Sleeve	393-3670

SCP, TNK		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

SCP, TNK		
Original Part Number	Part Name	Classic Part Number
126-5984	Ring-Backup	419-4654
176-3900	Accumulator	416-5513

Sales Model 256C

DWS		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
6K-2899	Bearing-Sleeve	453-6505

DWS		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067

DWS		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420
176-3900	Accumulator	416-5513

Sales Model 257

CMM		
Original Part Number	Part Name	Classic Part Number
3N-6411	Cup-Rlr Bearing	423-7759
6T-5611	Spacer	435-8520

CMM		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

CMM		
Original Part Number	Part Name	Classic Part Number
142-8845	Muffler As	360-9619
176-3900	Accumulator	416-5513

Sales Model 257B

B7H, SLK		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
3N-6411	Cup-Rlr Bearing	423-7759

B7H, SLK		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

B7H, SLK		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
176-3900	Accumulator	416-5513

Sales Model 257D

EML, EZW, FMR		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
3N-6411	Cup-Rlr Bearing	423-7759

Skid Steer Loaders

Sales Model 257D (Cont'd.)

EML, EZW, FMR		
Original Part Number	**Part Name**	**Classic Part Number**
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067

EML, EZW, FMR		
Original Part Number	**Part Name**	**Classic Part Number**
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

EML, EZW, FMR		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1853	Mount As.	376-3638
176-3900	Accumulator	416-5513

Sales Model 259B

YYZ		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
6B-7469	Spacer	417-4535
6Y-7652	Cup-Rlr Brg	399-6067

YYZ		
Original Part Number	**Part Name**	**Classic Part Number**
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420
9M-1328	Bearing-Aligning	325-6018

YYZ		
Original Part Number	**Part Name**	**Classic Part Number**
176-3900	Accumulator	416-5513
308-1845	Seal-Wiper	472-8032

Sales Model 259D

FTK, FTL, GTK		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067

FTK, FTL, GTK		
Original Part Number	**Part Name**	**Classic Part Number**
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420
9M-1328	Bearing-Aligning	325-6018

FTK, FTL, GTK		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1853	Mount As.	376-3638
176-3900	Accumulator	416-5513
308-1845	Seal-Wiper	472-8032

Sales Model 262

CED		
Original Part Number	**Part Name**	**Classic Part Number**
2G-8631	Bearing-Sleeve	391-9811
6K-2899	Bearing-Sleeve	453-6505
6K-4148	Bearing-Sleeve	393-3670

CED		
Original Part Number	**Part Name**	**Classic Part Number**
6T-5611	Spacer	435-8520
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

CED		
Original Part Number	**Part Name**	**Classic Part Number**
126-5984	Ring-Backup	419-4654
142-8845	Muffler As	360-9619
176-3900	Accumulator	416-5513

Sales Model 262B

PDT		
Original Part Number	**Part Name**	**Classic Part Number**
6K-2899	Bearing-Sleeve	453-6505

Sales Model 262B (Cont'd.)

PDT		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067

PDT		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

PDT		
Original Part Number	Part Name	Classic Part Number
126-5984	Ring-Backup	419-4654
176-3900	Accumulator	416-5513

Sales Model 262C

MST, TMW		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
6K-2899	Bearing-Sleeve	453-6505

MST, TMW		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067

MST, TMW		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

Sales Model 262D

DTB, KTS, LST		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
2B-0941	Spacer	418-1955
3P-1210	Cone-Roller Brg	399-4433

DTB, KTS, LST		
Original Part Number	Part Name	Classic Part Number
6K-2899	Bearing-Sleeve	453-6505
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067

DTB, KTS, LST		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420
9M-1853	Mount As.	376-3638
176-3900	Accumulator	416-5513

Sales Model 267

CMP		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
6T-5611	Spacer	435-8520

CMP		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8H-9789	Bearing-Ball	374-8342

CMP		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
176-3900	Accumulator	416-5513

Sales Model 267B

CYC		
Original Part Number	Part Name	Classic Part Number
6K-2899	Bearing-Sleeve	453-6505
6K-4148	Bearing-Sleeve	393-3670

CYC		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

Skid Steer Loaders

Sales Model 267B (Cont'd.)

CYC		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342

CYC		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420

CYC		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513

Sales Model 268B

LBA		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
6K-2899	Bearing-Sleeve	453-6505

LBA		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067

LBA		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420
176-3900	Accumulator	416-5513

Sales Model 272C

RED		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
6K-2899	Bearing-Sleeve	453-6505

RED		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067

RED		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420
176-3900	Accumulator	416-5513

Sales Model 272D

B5W, BL2, ETL, MD2		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
3P-1210	Cone-Roller Brg	399-4433
6K-4148	Bearing-Sleeve	393-3670

B5W, BL2, ETL, MD2		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

B5W, BL2, ETL, MD2		
Original Part Number	Part Name	Classic Part Number
9M-1853	Mount As.	376-3638
176-3900	Accumulator	416-5513

GSL, SHY		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
3P-1210	Cone-Roller Brg	399-4433
6K-2899	Bearing-Sleeve	453-6505

GSL, SHY		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

GSL, SHY		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
9M-1853	Mount As.	376-3638
176-3900	Accumulator	416-5513

Sales Model 277

CNC		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
6T-5611	Spacer	435-8520

CNC		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8H-9789	Bearing-Ball	374-8342

CNC		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
142-8845	Muffler As	360-9619
176-3900	Accumulator	416-5513

Sales Model 277B

MDH		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067

MDH		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
8H-9789	Bearing-Ball	374-8342

MDH		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
176-3900	Accumulator	416-5513

Sales Model 277C

JWF		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
2F-8509	Cone-Roller Brg	399-4434
6K-4148	Bearing-Sleeve	393-3670

JWF		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8H-9789	Bearing-Ball	374-8342

JWF		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
002-1212	Cup-Roller Brg	399-4446
176-3900	Accumulator	416-5513

KCC		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
2F-8509	Cone-Roller Brg	399-4434
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4V-2057	Bearing-Spher	419-6019
4V-8629	Bearing-Sleeve	379-0194
4V-8674	Bearing-Sleeve	307-1529

KCC		
Original Part Number	Part Name	Classic Part Number
5J-7010	Seal As	472-8011
5V-1274	Spider	385-6110
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4148	Bearing-Sleeve	393-3670
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
6Y-7652	Cup-Rlr Brg	399-6067
7J-9682	Bearing-Sleeve	360-2335

KCC		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
8H-9789	Bearing-Ball	374-8342
9D-7924	Mount As	360-2356
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
122-6381	Pin As	419-6073

Skid Steer Loaders

Sales Model 277C (Cont'd.)

KCC		
Original Part Number	**Part Name**	**Classic Part Number**
122-6387	Pin As	425-6448
151-5349	Head	383-1592

KCC		
Original Part Number	**Part Name**	**Classic Part Number**
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024

KCC		
Original Part Number	**Part Name**	**Classic Part Number**
233-9204	Kit-Seal-H.Cyl-1	472-8025

MET		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
2F-8509	Cone-Roller Brg	399-4434
6K-4148	Bearing-Sleeve	393-3670

MET		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8H-9789	Bearing-Ball	374-8342

MET		
Original Part Number	**Part Name**	**Classic Part Number**
8J-2880	Cap-Bearing	295-6420
002-1212	Cup-Roller Brg	399-4446
176-3900	Accumulator	416-5513

Sales Model 277D

FMT, MLT, NTL		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
2B-0941	Spacer	418-1955
2F-8509	Cone-Roller Brg	399-4434
3P-1210	Cone-Roller Brg	399-4433

FMT, MLT, NTL		
Original Part Number	**Part Name**	**Classic Part Number**
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8H-9789	Bearing-Ball	374-8342

FMT, MLT, NTL		
Original Part Number	**Part Name**	**Classic Part Number**
8J-2880	Cap-Bearing	295-6420
9M-1853	Mount As.	376-3638
002-1212	Cup-Roller Brg	399-4446
176-3900	Accumulator	416-5513

Sales Model 279C

KWB, MBT		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
6K-4148	Bearing-Sleeve	393-3670

KWB, MBT		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

KWB, MBT		
Original Part Number	**Part Name**	**Classic Part Number**
176-3900	Accumulator	416-5513
308-1845	Seal-Wiper	472-8032

Sales Model 279D

GTL, PPT, RCX		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
2B-0941	Spacer	418-1955
2F-8509	Cone-Roller Brg	399-4434

GTL, PPT, RCX		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
6K-4148	Bearing-Sleeve	393-3670

GTL, PPT, RCX		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8H-9789	Bearing-Ball	374-8342

Sales Model 279D (Cont'd.)

GTL, PPT, RCX		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
9M-1853	Mount As.	376-3638

GTL, PPT, RCX		
Original Part Number	Part Name	Classic Part Number
002-1212	Cup-Roller Brg	399-4446
176-3900	Accumulator	416-5513

GTL, PPT, RCX		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032

WEF		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
2B-0941	Spacer	418-1955
2F-8509	Cone-Roller Brg	399-4434
3P-1210	Cone-Roller Brg	399-4433

WEF		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
8H-9789	Bearing-Ball	374-8342
9M-1853	Mount As.	376-3638
002-1212	Cup-Roller Brg	399-4446

WEF		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513
308-1845	Seal-Wiper	472-8032

Sales Model 287

CNY		
Original Part Number	Part Name	Classic Part Number
2G-8631	Bearing-Sleeve	391-9811
6K-2899	Bearing-Sleeve	453-6505
6K-4148	Bearing-Sleeve	393-3670

CNY		
Original Part Number	Part Name	Classic Part Number
6T-5611	Spacer	435-8520
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8H-9789	Bearing-Ball	374-8342

CNY		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
142-8845	Muffler As	360-9619
176-3900	Accumulator	416-5513

Sales Model 287B

ZSA		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
6K-2899	Bearing-Sleeve	453-6505
6K-4148	Bearing-Sleeve	393-3670

ZSA		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8H-9789	Bearing-Ball	374-8342

ZSA		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
176-3900	Accumulator	416-5513

Sales Model 287C

MAS, SSB		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483

Skid Steer Loaders

Sales Model 287C (Cont'd.)

MAS, SSB		
Original Part Number	**Part Name**	**Classic Part Number**
2F-8509	Cone-Roller Brg	399-4434
6K-2899	Bearing-Sleeve	453-6505
6K-4148	Bearing-Sleeve	393-3670

MAS, SSB		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420

MAS, SSB		
Original Part Number	**Part Name**	**Classic Part Number**
002-1212	Cup-Roller Brg	399-4446
176-3900	Accumulator	416-5513

Sales Model 287D

HMT, STK, TLK		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
2B-0941	Spacer	418-1955
2F-8509	Cone-Roller Brg	399-4434
3P-1210	Cone-Roller Brg	399-4433

HMT, STK, TLK		
Original Part Number	**Part Name**	**Classic Part Number**
6K-2899	Bearing-Sleeve	453-6505
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

HMT, STK, TLK		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
9M-1853	Mount As.	376-3638
002-1212	Cup-Roller Brg	399-4446
176-3900	Accumulator	416-5513

Sales Model 289C

JMP, RTD		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
6K-2899	Bearing-Sleeve	453-6505
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

JMP, RTD		
Original Part Number	**Part Name**	**Classic Part Number**
8J-2880	Cap-Bearing	295-6420
176-3900	Accumulator	416-5513
308-1845	Seal-Wiper	472-8032
1S-7056	Bearing-Ball	422-6483
6K-2899	Bearing-Sleeve	453-6505

JMP, RTD		
Original Part Number	**Part Name**	**Classic Part Number**
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420
176-3900	Accumulator	416-5513
308-1845	Seal-Wiper	472-8032

Sales Model 289D

A9Z, TAW, WCT		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
2B-0941	Spacer	418-1955
2F-8509	Cone-Roller Brg	399-4434
3P-1210	Cone-Roller Brg	399-4433

A9Z, TAW, WCT		
Original Part Number	**Part Name**	**Classic Part Number**
6K-2899	Bearing-Sleeve	453-6505
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067

A9Z, TAW, WCT		
Original Part Number	**Part Name**	**Classic Part Number**
7L-7508	Bearing-Ball	420-6536
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
9M-1853	Mount As.	376-3638
002-1212	Cup-Roller Brg	399-4446

Sales Model 289D (Cont'd.)

A9Z, TAW, WCT		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513

A9Z, TAW, WCT		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032

Sales Model 297C

GCP		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
2F-8509	Cone-Roller Brg	399-4434
6K-2899	Bearing-Sleeve	453-6505

GCP		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8H-9789	Bearing-Ball	374-8342

GCP		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
002-1212	Cup-Roller Brg	399-4446
176-3900	Accumulator	416-5513

Sales Model 297D

BE7, BL7, HP2, HP7		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
2F-8509	Cone-Roller Brg	399-4434
3P-1210	Cone-Roller Brg	399-4433

BE7, BL7, HP2, HP7		
Original Part Number	Part Name	Classic Part Number
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8H-9789	Bearing-Ball	374-8342

BE7, BL7, HP2, HP7		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
9M-1853	Mount As.	376-3638
002-1212	Cup-Roller Brg	399-4446
176-3900	Accumulator	416-5513

Sales Model 299C

JSP		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
6K-2899	Bearing-Sleeve	453-6505
6K-4148	Bearing-Sleeve	393-3670

JSP		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

JSP		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513
308-1845	Seal-Wiper	472-8032

Sales Model 299D

DX2, FD2, GTC		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483

Sales Model 299D (Cont'd.)

DX2, FD2, GTC		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
6K-4148	Bearing-Sleeve	393-3670

DX2, FD2, GTC		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

DX2, FD2, GTC		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1853	Mount As.	376-3638
176-3900	Accumulator	416-5513
308-1845	Seal-Wiper	472-8032

HCL		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
3P-1210	Cone-Roller Brg	399-4433
6K-2899	Bearing-Sleeve	453-6505

HCL		
Original Part Number	**Part Name**	**Classic Part Number**
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

HCL		
Original Part Number	**Part Name**	**Classic Part Number**
8J-2880	Cap-Bearing	295-6420
9M-1853	Mount As.	376-3638
176-3900	Accumulator	416-5513
308-1845	Seal-Wiper	472-8032

JST		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
3P-1210	Cone-Roller Brg	399-4433
6K-4148	Bearing-Sleeve	393-3670

JST		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420

JST		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1853	Mount As.	376-3638
176-3900	Accumulator	416-5513
308-1845	Seal-Wiper	472-8032

NLC		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
3P-1210	Cone-Roller Brg	399-4433
6K-2899	Bearing-Sleeve	453-6505

NLC		
Original Part Number	**Part Name**	**Classic Part Number**
6K-4148	Bearing-Sleeve	393-3670
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

NLC		
Original Part Number	**Part Name**	**Classic Part Number**
8J-2880	Cap-Bearing	295-6420
9M-1853	Mount As.	376-3638
176-3900	Accumulator	416-5513
308-1845	Seal-Wiper	472-8032

Cat Classic Parts for Track Loaders

Track Loaders have long, productive lives. Their usage changes As. the machine ages, so maintenance costs need to be re-evaluated. Caterpillar offers Classic parts for several models of Track loaders to ensure a value priced Repair option is available.

Cat Classic parts provide owners of older Cat products with low cost Repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts coverage for Track loaders includes:

- Engine
- Final Drive
- Linkage Pins
- Moving Undercarriage
- Non-Moving Undercarriage
- SteeRing
- Torque Converter
- Transmission
- Trunnion/Blade Support
- ...and many more.

Sales Model 931

08N		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-5920	Bearing-Camshaft	421-1558
1W-9771	Crankshaft As	368-5913

08N		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
3B-3967	Race-Roller Brg	386-4947
4N-8809	Chamber As	247-3297
5J-9348	Bearing As	416-2162
5M-7936	Bearing-Outer	386-4953
5S-5917	Screw-Rocker Adj	380-7537
6S-6902	Spider & Brg As	390-5280

10N		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759

08N		
Original Part Number	**Part Name**	**Classic Part Number**
6V-6896	Rebuild Kit	390-1006
7W-2059	Gasket-Cyl Hd	380-1548
7X-2396	Gasket Kit	393-5194
7X-2397	Gasket Kit	393-5193
8N-0701	Bearing-Sleeve	419-4745
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
9N-5246	Bearing-Camshaft	384-4772
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

Sales Model 931 (Cont'd.)

10N		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-5920	Bearing-Camshaft	421-1558
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

10N		
Original Part Number	**Part Name**	**Classic Part Number**
2D-5658	Bearing-Ball	301-4628
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
3B-3967	Race-Roller Brg	386-4947
4N-8809	Chamber As	247-3297
5G-4381	Yoke As	469-4662
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5M-7936	Bearing-Outer	386-4953
5S-5917	Screw-Rocker Adj	380-7537
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006

10N		
Original Part Number	**Part Name**	**Classic Part Number**
7W-2059	Gasket-Cyl Hd	380-1548
7X-2396	Gasket Kit	393-5194
7X-2397	Gasket Kit	393-5193
8N-0701	Bearing-Sleeve	419-4745
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8Y-2735	Spring	383-2134
9N-5246	Bearing-Camshaft	384-4772
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199

78U		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-5920	Bearing-Camshaft	421-1558
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2K-0227	Bearing-Sleeve	384-4780

78U		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
3B-3967	Race-Roller Brg	386-4947
4J-5241	Retainer	434-1415
4N-8809	Chamber As	247-3297
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5M-7936	Bearing-Outer	386-4953
5S-5917	Screw-Rocker Adj	380-7537
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
7J-6461	Crown	325-6054
7W-2059	Gasket-Cyl Hd	380-1548
7X-2396	Gasket Kit	393-5194

78U		
Original Part Number	**Part Name**	**Classic Part Number**
7X-2397	Gasket Kit	393-5193
8N-0701	Bearing-Sleeve	419-4745
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8Y-2735	Spring	383-2134
9N-5246	Bearing-Camshaft	384-4772
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9Y-9431	Precleaner As	361-1718
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 931 (Cont'd.)

81U		
Original Part Number	Part Name	Classic Part Number
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-5920	Bearing-Camshaft	421-1558
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2K-0227	Bearing-Sleeve	384-4780
2W-1223	Pump Gp-Water	385-7197

81U		
Original Part Number	Part Name	Classic Part Number
2W-7590	Cooler As-Oil	378-3971
3B-3967	Race-Roller Brg	386-4947
4J-5241	Retainer	434-1415
4N-8809	Chamber As	247-3297
4T-8054	Seal As	472-8010
5J-9348	Bearing As	416-2162
5M-7936	Bearing-Outer	386-4953
5S-5917	Screw-Rocker Adj	380-7537
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-6902	Spider & Brg As	390-5280
6V-6896	Rebuild Kit	390-1006
7J-3351	Head	380-1515
7J-6461	Crown	325-6054

81U		
Original Part Number	Part Name	Classic Part Number
7K-9360	Pin	319-3461
7W-2059	Gasket-Cyl Hd	380-1548
7X-2396	Gasket Kit	393-5194
7X-2397	Gasket Kit	393-5193
8N-0701	Bearing-Sleeve	419-4745
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
9N-5246	Bearing-Camshaft	384-4772
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9Y-9431	Precleaner As	361-1718
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 931B

25Y		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900

25Y		
Original Part Number	Part Name	Classic Part Number
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023

25Y		
Original Part Number	Part Name	Classic Part Number
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
4J-5241	Retainer	434-1415
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449

Sales Model 931B (Cont'd.)

25Y		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-7936	Bearing-Outer	386-4953
5P-7807	Bearing-Ball	314-8502
5P-9439	Bearing-Spl Ball	371-4306
5S-5917	Screw-Rocker Adj	380-7537
5V-1168	Spider & Brg As	377-7435
6E-0775	Head	425-9373
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903

25Y		
Original Part Number	**Part Name**	**Classic Part Number**
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7E-5085	Bushing	377-5829
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2397	Gasket Kit	393-5193
7X-2846	Gasket Kit	437-8647
8H-8175	Bearing-Sleeve	376-3636
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

25Y		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3539	Plunger As-Pump	377-5861
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-4789	Shaft-Gov Cont	297-7256
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-2653	Pump Gp-Gr 1 Bsc	386-3057
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5211	Plate-Clutch	380-1493
9S-6917	Gear-Cplg Ring	446-3075
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

26Y		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535

26Y		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1T-0043	Bearing-Ball	390-5294
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079

26Y		
Original Part Number	**Part Name**	**Classic Part Number**
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173

Sales Model 931B (Cont'd.)

26Y		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-3803	Gear	226-6106
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5M-7936	Bearing-Outer	386-4953
5P-7807	Bearing-Ball	314-8502

26Y		
Original Part Number	Part Name	Classic Part Number
5P-9439	Bearing-Spl Ball	371-4306
5S-5917	Screw-Rocker Adj	380-7537
5V-1168	Spider & Brg As	377-7435
6E-0775	Head	425-9373
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7E-5085	Bushing	377-5829
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531

26Y		
Original Part Number	Part Name	Classic Part Number
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2397	Gasket Kit	393-5193
7X-2846	Gasket Kit	437-8647
8H-8175	Bearing-Sleeve	376-3636
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3539	Plunger As-Pump	377-5861
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-4789	Shaft-Gov Cont	297-7256
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-2653	Pump Gp-Gr 1 Bsc	386-3057
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5211	Plate-Clutch	380-1493
9S-6917	Gear-Cplg Ring	446-3075
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 931B (Cont'd.)

29Y		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971

29Y		
Original Part Number	**Part Name**	**Classic Part Number**
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
4J-5241	Retainer	434-1415
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5P-7807	Bearing-Ball	314-8502
5P-9439	Bearing-Spl Ball	371-4306
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider & Brg As	373-5386
5V-1168	Spider & Brg As	377-7435
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279

29Y		
Original Part Number	**Part Name**	**Classic Part Number**
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7E-5085	Bushing	377-5829
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2397	Gasket Kit	393-5193
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-8175	Bearing-Sleeve	376-3636
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

Sales Model 931B (Cont'd.)

29Y		
Original Part Number	Part Name	Classic Part Number
8N-3539	Plunger As-Pump	377-5861
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-4789	Shaft-Gov Cont	297-7256
9N-5246	Bearing-Camshaft	384-4772

29Y		
Original Part Number	Part Name	Classic Part Number
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199

29Y		
Original Part Number	Part Name	Classic Part Number
119-6772	Valve-Exhaust	384-8699
140-2382	Gasket Kit	390-5285
154-5676	Gasket Kit	447-0827
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

30Y		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

30Y		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502

30Y		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5P-7807	Bearing-Ball	314-8502
5P-9439	Bearing-Spl Ball	371-4306
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg&	373-5386
5V-1168	& Brg As	377-7435
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6I-1363	As	380-1517
6I-1364	As	391-9824
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590

Sales Model 931B (Cont'd.)

30Y		
Original Part Number	Part Name	Classic Part Number
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-6902	& Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7E-5085	Bushing	377-5829
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166

30Y		
Original Part Number	Part Name	Classic Part Number
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2397	Gasket Kit	393-5193
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-8175	Bearing-Sleeve	376-3636
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3539	Plunger As-Pump	377-5861
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033

30Y		
Original Part Number	Part Name	Classic Part Number
8Y-2735	Spring	383-2134
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-4789	Shaft-Gov Cont	297-7256
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
140-2382	Gasket Kit	390-5285
154-5676	Gasket Kit	447-0827
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

4SC		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080

4SC		
Original Part Number	Part Name	Classic Part Number
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-6936	Disc-Steer Cl Dr	380-7471

4SC		
Original Part Number	Part Name	Classic Part Number
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208

Sales Model 931B (Cont'd.)

4SC		
Original Part Number	**Part Name**	**Classic Part Number**
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
4D-4065	Rod End-Spher	374-1824
4J-5241	Retainer	434-1415
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5V-1168	& Brg As	377-7435
6E-0775	Head	425-9373
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428

4SC		
Original Part Number	**Part Name**	**Classic Part Number**
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531

4SC		
Original Part Number	**Part Name**	**Classic Part Number**
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8Y-2735	Spring	383-2134
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9S-7949	Cup-Roller Brg	420-6531
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

6EC		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936

6EC		
Original Part Number	**Part Name**	**Classic Part Number**
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

6EC		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970

Sales Model 931B (Cont'd.)

6EC		
Original Part Number	**Part Name**	**Classic Part Number**
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
4D-4065	Rod End-Spher	374-1824
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537

6EC		
Original Part Number	**Part Name**	**Classic Part Number**
5V-1168	Spider & Brg As	377-7435
6E-0775	Head	425-9373
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983

6EC		
Original Part Number	**Part Name**	**Classic Part Number**
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8Y-2735	Spring	383-2134
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9S-7949	Cup-Roller Brg	420-6531
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 931C

2AK		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076

2AK		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535

2AK		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1T-0043	Bearing-Ball	390-5294

Sales Model 931C (Cont'd.)

2AK		
Original Part Number	Part Name	Classic Part Number
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419

2AK		
Original Part Number	Part Name	Classic Part Number
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5M-7936	Bearing-Outer	386-4953
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg&	373-5386
5V-1168	Spider & Brg As	377-7435
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518

2AK		
Original Part Number	Part Name	Classic Part Number
7B-7515	Bearing-Ball	399-6059
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2846	Gasket Kit	437-8647
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-8175	Bearing-Sleeve	376-3636
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-2653	Pump Gp-Gr 1 Bsc	386-3057

Sales Model 931C (Cont'd.)

2AK		
Original Part Number	**Part Name**	**Classic Part Number**
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5211	Plate-Clutch	380-1493
9S-6917	Gear-Cplg Ring	446-3075

2AK		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7949	Cup-Roller Brg	420-6531
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-9431	Precleaner As	361-1718
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220

2AK		
Original Part Number	**Part Name**	**Classic Part Number**
140-2382	Gasket Kit	390-5285
154-5676	Gasket Kit	447-0827
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

2BJ		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-6936	Disc-Steer Cl Dr	380-7471

2BJ		
Original Part Number	**Part Name**	**Classic Part Number**
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
4D-4065	Rod End-Spher	374-1824
4J-5241	Retainer	434-1415
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010

2BJ		
Original Part Number	**Part Name**	**Classic Part Number**
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5M-9644	Bearing-Outer	384-5929
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg&	373-5386
5V-1168	Spider & Brg As	377-7435
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103

Sales Model 931C (Cont'd.)

2BJ		
Original Part Number	Part Name	Classic Part Number
6P-7968	Plate-Clutch	416-2133
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-2689	Coupler	422-3508
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7F-2742	Bearing-Ball	422-6488
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100

2BJ		
Original Part Number	Part Name	Classic Part Number
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-1154	Bearing-Spl	417-4515
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2846	Gasket Kit	437-8647
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267

2BJ		
Original Part Number	Part Name	Classic Part Number
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9Y-5168	Manifold-Exhaust	374-7483
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
154-5676	Gasket Kit	447-0827
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

5LG		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1W-0311	Bearing-Main	376-9078

5LG		
Original Part Number	Part Name	Classic Part Number
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

5LG		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970

Sales Model 931C (Cont'd.)

5LG		
Original Part Number	**Part Name**	**Classic Part Number**
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
4D-4065	Rod End-Spher	374-1824
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5M-9644	Bearing-Outer	384-5929
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5V-1168	Spider & Brg As	377-7435
6E-0775	Head	425-9373
6I-1363	Spider As	380-1517

5LG		
Original Part Number	**Part Name**	**Classic Part Number**
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6P-7968	Plate-Clutch	416-2133
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-2689	Coupler	422-3508
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7F-2742	Bearing-Ball	422-6488
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-1154	Bearing-Spl	417-4515
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531

5LG		
Original Part Number	**Part Name**	**Classic Part Number**
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2846	Gasket Kit	437-8647
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6903	Plate	368-0108
9S-7949	Cup-Roller Brg	420-6531
9Y-9431	Precleaner As	361-1718
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

6AJ		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759

Sales Model 931C (Cont'd.)

6AJ		
Original Part Number	Part Name	Classic Part Number
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208

6AJ		
Original Part Number	Part Name	Classic Part Number
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
4D-4065	Rod End-Spher	374-1824
4J-5241	Retainer	434-1415
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5M-7936	Bearing-Outer	386-4953
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg&	373-5386
5V-1168	Spider & Brg As	377-7435
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478

6AJ		
Original Part Number	Part Name	Classic Part Number
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2846	Gasket Kit	437-8647
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-5352	Bearing-Ball	453-3658

Sales Model 931C (Cont'd.)

6AJ		
Original Part Number	**Part Name**	**Classic Part Number**
8H-8175	Bearing-Sleeve	376-3636
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772

6AJ		
Original Part Number	**Part Name**	**Classic Part Number**
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-2653	Pump Gp-Gr 1 Bsc	386-3057
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5211	Plate-Clutch	380-1493
9S-6917	Gear-Cplg Ring	446-3075
9S-7949	Cup-Roller Brg	420-6531

6AJ		
Original Part Number	**Part Name**	**Classic Part Number**
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-9431	Precleaner As	361-1718
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
154-5676	Gasket Kit	447-0827
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

6RF		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913

6RF		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449

6RF		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg&	373-5386
5V-1168	Spider & Brg As	377-7435
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517

Sales Model 931C (Cont'd.)

6RF		
Original Part Number	Part Name	Classic Part Number
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6P-7968	Plate-Clutch	416-2133
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-2689	Coupler	422-3508
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7F-2742	Bearing-Ball	422-6488

6RF		
Original Part Number	Part Name	Classic Part Number
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-1154	Bearing-Spl	417-4515
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2846	Gasket Kit	437-8647
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

6RF		
Original Part Number	Part Name	Classic Part Number
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
154-5676	Gasket Kit	447-0827
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

7HF		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

7HF		
Original Part Number	Part Name	Classic Part Number
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558

7HF		
Original Part Number	Part Name	Classic Part Number
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628

Track Loaders

Sales Model 931C (Cont'd.)

7HF		
Original Part Number	**Part Name**	**Classic Part Number**
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
4J-5241	Retainer	434-1415
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5M-7936	Bearing-Outer	386-4953
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5V-1168	Spider & Brg As	377-7435
6E-0775	Head	425-9373

7HF		
Original Part Number	**Part Name**	**Classic Part Number**
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935

7HF		
Original Part Number	**Part Name**	**Classic Part Number**
7W-2059	Gasket-Cyl Hd	380-1548
7X-2846	Gasket Kit	437-8647
8H-8175	Bearing-Sleeve	376-3636
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-2653	Pump Gp-Gr 1 Bsc	386-3057
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5211	Plate-Clutch	380-1493
9S-6917	Gear-Cplg Ring	446-3075
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

8AF		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076

8AF		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535

8AF		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3935	Cone-Roller Brg	377-7397
1T-1401	Ring-Seal	384-4799

Sales Model 931C (Cont'd.)

8AF		
Original Part Number	Part Name	Classic Part Number
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794

8AF		
Original Part Number	Part Name	Classic Part Number
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5M-7936	Bearing-Outer	386-4953
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5V-1168	Spider & Brg As	377-7435
6E-0775	Head	425-9373
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531

8AF		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2846	Gasket Kit	437-8647
8H-8175	Bearing-Sleeve	376-3636
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-2653	Pump Gp-Gr 1 Bsc	386-3057
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5211	Plate-Clutch	380-1493
9S-6917	Gear-Cplg Ring	446-3075
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 931C (Cont'd.)

9AG		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208

9AG		
Original Part Number	Part Name	Classic Part Number
4J-5241	Retainer	434-1415
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5M-7936	Bearing-Outer	386-4953
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5V-1168	Spider & Brg As	377-7435
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-7220	Plate As	396-0657

9AG		
Original Part Number	Part Name	Classic Part Number
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2846	Gasket Kit	437-8647
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-8175	Bearing-Sleeve	376-3636
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607

Sales Model 931C (Cont'd.)

9AG		
Original Part Number	**Part Name**	**Classic Part Number**
9N-6500	Rod-Valve Push	383-3706
9P-2653	Pump Gp-Gr 1 Bsc	386-3057
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923

9AG		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3582	Cone-Roller Brg	396-4144
9S-5211	Plate-Clutch	380-1493
9S-6917	Gear-Cplg Ring	446-3075
9S-7949	Cup-Roller Brg	420-6531
9Y-9431	Precleaner As	361-1718
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199

9AG		
Original Part Number	**Part Name**	**Classic Part Number**
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 933

8FL		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
2B-0941	Spacer	418-1955
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3W-4363	Pin As	375-2634
4J-5241	Retainer	434-1415
4N-4539	Sleeve	314-8720

8FL		
Original Part Number	**Part Name**	**Classic Part Number**
4N-8204	Mount As	374-1449
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5T-8739	Spider Gp-Brg	373-5386
5V-1168	Spider & Brg As	377-7435
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147

8FL		
Original Part Number	**Part Name**	**Classic Part Number**
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6Y-6832	Bearing-Rlr As	421-8181
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-7219	Bearing-Thrust	384-4816
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512

Sales Model 933 (Cont'd.)

8FL		
Original Part Number	**Part Name**	**Classic Part Number**
8H-8175	Bearing-Sleeve	376-3636
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9K-8757	Rod End-Special	311-9361
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122

8FL		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7949	Cup-Roller Brg	420-6531
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-9431	Precleaner As	361-1718
107-7473	Muffler As.	385-7223
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
126-0734	Muffler As	397-5052
133-6597	Pipe-Extension	420-6220

8FL		
Original Part Number	**Part Name**	**Classic Part Number**
140-2382	Gasket Kit	390-5285
154-5676	Gasket Kit	447-0827
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

9EL		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
2B-0941	Spacer	418-1955
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3W-4363	Pin As	375-2634
4J-5241	Retainer	434-1415
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4S-8538	Bearing-Spl Ball	417-4502

9EL		
Original Part Number	**Part Name**	**Classic Part Number**
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5T-8739	Spider Gp-Brg&	373-5386
5V-1168	Spider & Brg As	377-7435
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629

9EL		
Original Part Number	**Part Name**	**Classic Part Number**
6S-3474	Pin As	375-9981
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6Y-6832	Bearing-Rlr As	421-8181
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9K-8757	Rod End-Special	311-9361
9P-6799	Piston-Clutch	469-4671

Sales Model 933 (Cont'd.)

9EL		
Original Part Number	Part Name	Classic Part Number
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-9431	Precleaner As	361-1718

9EL		
Original Part Number	Part Name	Classic Part Number
107-7473	Muffler As.	385-7223
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
126-0734	Muffler As	397-5052
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285

9EL		
Original Part Number	Part Name	Classic Part Number
154-5676	Gasket Kit	447-0827
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 933C

4MS		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
2H-6489	Race-Brg Outer	374-8350
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3W-4363	Pin As	375-2634
4J-5241	Retainer	434-1415
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662
5K-2754	Spring-Recoil	418-1956
5M-5856	Pipe-Extension	373-1913

4MS		
Original Part Number	Part Name	Classic Part Number
5P-5354	Cup-Rlr Bearing	399-4445
6E-0775	Head	425-9373
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3474	Pin As	375-9981
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
7G-4758	Gear-Planet	288-8723
7J-6461	Crown	325-6054
7M-7219	Bearing-Thrust	384-4816
8C-3111	Rod End-Spher	392-4523
8T-0072	Cone-Rlr Brg	377-7448

4MS		
Original Part Number	Part Name	Classic Part Number
8T-1177	Bearing-Rlr	419-1862
8Y-2735	Spring	383-2134
9K-8757	Rod End-Special	311-9361
9Y-9431	Precleaner As	361-1718
107-7473	Muffler As.	385-7223
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
126-0734	Muffler As	397-5052
133-6597	Pipe-Extension	420-6220
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

5JS		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
2H-6489	Race-Brg Outer	374-8350
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947

5JS		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3W-4363	Pin As	375-2634
4J-5241	Retainer	434-1415
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662
5K-2754	Spring-Recoil	418-1956
5M-5856	Pipe-Extension	373-1913
5P-5354	Cup-Rlr Bearing	399-4445
6E-0775	Head	425-9373

5JS		
Original Part Number	Part Name	Classic Part Number
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3474	Pin As	375-9981
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444

Track Loaders

Sales Model 933C (Cont'd.)

5JS		
Original Part Number	**Part Name**	**Classic Part Number**
7G-4758	Gear-Planet	288-8723
7J-6461	Crown	325-6054
7M-7219	Bearing-Thrust	384-4816
8C-3111	Rod End-Spher	392-4523
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-2735	Spring	383-2134

5JS		
Original Part Number	**Part Name**	**Classic Part Number**
9K-8757	Rod End-Special	311-9361
9Y-9431	Precleaner As	361-1718
107-7473	Muffler As.	385-7223
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
126-0734	Muffler As	397-5052

5JS		
Original Part Number	**Part Name**	**Classic Part Number**
133-6597	Pipe-Extension	420-6220
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 935B

3DF		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

3DF		
Original Part Number	**Part Name**	**Classic Part Number**
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
4J-5241	Retainer	434-1415
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585

3DF		
Original Part Number	**Part Name**	**Classic Part Number**
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-8591	Bearing-Outer	380-7502
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg	373-5386
5V-1168	Spider & Brg As	377-7435
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981

Sales Model 935B (Cont'd.)

3DF		
Original Part Number	Part Name	Classic Part Number
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910

3DF		
Original Part Number	Part Name	Classic Part Number
7N-7166	Race-Brg Thrust	417-4531
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-8175	Bearing-Sleeve	376-3636
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266

3DF		
Original Part Number	Part Name	Classic Part Number
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
140-2382	Gasket Kit	390-5285
154-5676	Gasket Kit	447-0827
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 935C

5DJ		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1W-0311	Bearing-Main	376-9078

5DJ		
Original Part Number	Part Name	Classic Part Number
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

5DJ		
Original Part Number	Part Name	Classic Part Number
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3W-4363	Pin As	375-2634
4J-5241	Retainer	434-1415

Sales Model 935C (Cont'd.)

5DJ		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg&	373-5386
5V-1168	Spider As	377-7435
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279

5DJ		
Original Part Number	**Part Name**	**Classic Part Number**
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-6902	Spider As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2846	Gasket Kit	437-8647
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122

5DJ		
Original Part Number	**Part Name**	**Classic Part Number**
8E-5284	Bearing	388-0582
8H-8175	Bearing-Sleeve	376-3636
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8T-2470	Gasket Kit	393-5219
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9Y-9431	Precleaner As	361-1718
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
154-5676	Gasket Kit	447-0827
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

8CF		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076

8CF		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535

8CF		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936

Sales Model 935C (Cont'd.)

8CF		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3T-9960	Disc-Friction	417-9487
4J-5241	Retainer	434-1415
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217

8CF		
Original Part Number	Part Name	Classic Part Number
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg&	373-5386
5V-1168	Spider As	377-7435
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6P-7968	Plate-Clutch	416-2133
6S-3158	Yoke	380-1478
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-6902	Spider & Brg As	390-5280

8CF		
Original Part Number	Part Name	Classic Part Number
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-2689	Coupler	422-3508
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7F-2742	Bearing-Ball	422-6488
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-1154	Bearing-Spl	417-4515
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2846	Gasket Kit	437-8647
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033

Sales Model 935C (Cont'd.)

8CF		
Original Part Number	**Part Name**	**Classic Part Number**
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671

8CF		
Original Part Number	**Part Name**	**Classic Part Number**
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220

8CF		
Original Part Number	**Part Name**	**Classic Part Number**
140-2382	Gasket Kit	390-5285
154-5676	Gasket Kit	447-0827
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 939

9GL		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
2B-0941	Spacer	418-1955
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3W-4363	Pin As	375-2634

9GL		
Original Part Number	**Part Name**	**Classic Part Number**
3W-8240	Bearing-Sleeve	425-6438
3W-8398	Bearing-Sleeve	379-0189
4J-5241	Retainer	434-1415
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5M-5856	Pipe-Extension	373-1913
5T-8739	Spider Gp-Brg	373-5386
5V-1168	Spider & Brg As	377-7435
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6K-8088	Bearing-Roller	399-4428
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6S-3397	Shaft-Ster Cl	388-6593
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903

9GL		
Original Part Number	**Part Name**	**Classic Part Number**
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-7220	Plate As	396-0657
6Y-6832	Bearing-Rlr As	421-8181
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
8E-5284	Bearing	388-0582
8H-8175	Bearing-Sleeve	376-3636
8Y-6659	Spring-Recoil	422-7893
9K-8757	Rod End-Special	311-9361
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505

Sales Model 939 (Cont'd.)

9GL		
Original Part Number	Part Name	Classic Part Number
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-9431	Precleaner As	361-1718

9GL		
Original Part Number	Part Name	Classic Part Number
107-7473	Muffler As.	385-7223
121-7746	Pre-Cleaner As	360-2311
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
176-3900	Accumulator	416-5513

9GL		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 939C

6DS		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
2H-6489	Race-Brg Outer	374-8350
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3W-4363	Pin As	375-2634
3W-8240	Bearing-Sleeve	425-6438
3W-8398	Bearing-Sleeve	379-0189
4J-5241	Retainer	434-1415

6DS		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
5M-5856	Pipe-Extension	373-1913
5P-5354	Cup-Rlr Bearing	399-4445
6E-0775	Head	425-9373
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3474	Pin As	375-9981
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
7G-4758	Gear-Planet	288-8723
7J-6461	Crown	325-6054
7M-7219	Bearing-Thrust	384-4816

6DS		
Original Part Number	Part Name	Classic Part Number
8C-3111	Rod End-Spher	392-4523
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-6659	Spring-Recoil	422-7893
9K-8757	Rod End-Special	311-9361
107-7473	Muffler As.	385-7223
121-7746	Pre-Cleaner As	360-2311
126-0734	Muffler As	397-5052
133-6597	Pipe-Extension	420-6220
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 941

16U		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1S-3062	Director-Water	418-9572
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659

16U		
Original Part Number	Part Name	Classic Part Number
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927

16U		
Original Part Number	Part Name	Classic Part Number
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-6245	Shaft As-Pump	325-6197
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356

Sales Model 941 (Cont'd.)

16U		
Original Part Number	Part Name	Classic Part Number
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4M-5858	Bearing-Spl Ball	417-4495
4N-7692	Crankshaft As	269-8764
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-2246	Gasket Kit	391-1091
7C-3862	Camshaft	458-0151
7G-2830	Ring-Seal	295-6441
7M-4046	Bearing-Sleeve	394-8206
7N-7386	Gasket-Cyl Head	392-4519

16U		
Original Part Number	Part Name	Classic Part Number
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0493	Shaft As-Pump	325-6198

16U		
Original Part Number	Part Name	Classic Part Number
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9S-7788	Ring-Piston	461-5124
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

70H		
Original Part Number	Part Name	Classic Part Number
0R-1635	Hub-Gear	222-1763

Sales Model 941 (Cont'd.)

70H		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0020	Wheel-Turbine	297-4862
1T-1991	Stator As-Conv	380-1482
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2H-3517	Bearing-Inner	417-4505
2H-6936	Disc-Steer Cl Dr	380-7471
2K-4442	Bearing-Sleeve	308-9812
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4404	Housing As-Cl	226-8027
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691

70H		
Original Part Number	Part Name	Classic Part Number
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-8393	Plate-Clutch	388-0592
3S-7987	Shaft-Planet	226-6074
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-8660	Pump Gp-Trans	226-0167
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008

70H		
Original Part Number	Part Name	Classic Part Number
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
5K-2294	Bearing	396-9912
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5S-7893	Joint-Drive	380-7387
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6J-6043	Bearing-Sleeve	374-1456
6K-3937	Pin	241-2557
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-2237	Gasket Kit	437-3212
6V-2246	Gasket Kit	391-1091
6Y-5915	Disc-Friction	384-5936
6Y-7914	Disc-Friction	390-5264
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151

Sales Model 941 (Cont'd.)

70H		
Original Part Number	**Part Name**	**Classic Part Number**
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7J-9682	Bearing-Sleeve	360-2335
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9360	Pin	319-3461
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8F-6058	Bearing-Sleeve	416-5494
8H-1174	Drum-Ster Cl Dr	226-6101
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342

70H		
Original Part Number	**Part Name**	**Classic Part Number**
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083

70H		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-4996	Muffler	390-0909
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-5080	Pump Gp-Vn Bsc-A	422-8141
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

Sales Model 941 (Cont'd.)

70H		
Original Part Number	**Part Name**	**Classic Part Number**
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365

70H		
Original Part Number	**Part Name**	**Classic Part Number**
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
231-1937	Kit-Strg Cl-Cla	226-6101
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564

70H		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

75H		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1W-9812	Gear-Crankshaft	380-1513
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494

75H		
Original Part Number	**Part Name**	**Classic Part Number**
4N-7692	Crankshaft As	269-8764
6B-3223	Cup-Bearing	399-6065
7C-4297	Seal As-Cshaft	325-6192
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

75H		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
121-7746	Pre-Cleaner As	360-2311

80H		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147

80H		
Original Part Number	**Part Name**	**Classic Part Number**
1S-3062	Director-Water	418-9572
1T-0020	Wheel-Turbine	297-4862
1T-1991	Stator As-Conv	380-1482
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7082	Rebuild Kt-Pump	383-3681

80H		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-6936	Disc-Steer Cl Dr	380-7471
2K-4442	Bearing-Sleeve	308-9812
2K-4502	Bearing-Sleeve	299-1986
2K-6413	Pin	360-2270
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

Sales Model 941 (Cont'd.)

80H		
Original Part Number	Part Name	Classic Part Number
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4404	Housing As-Cl	226-8027
2P-5081	Muffler As	360-7872
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3J-9325	Piston	390-0993
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-8393	Plate-Clutch	388-0592
3S-7987	Shaft-Planet	226-6074
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4K-0255	Retainer As	226-6102
4K-0300	Bearing-Sleeve	308-9817

80H		
Original Part Number	Part Name	Classic Part Number
4K-1328	Drum-Ster Cl Dr	216-7840
4K-4780	Strip As-Wear	299-2063
4K-4894	Cage-Bearing	453-0968
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8204	Mount As	374-1449
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

80H		
Original Part Number	Part Name	Classic Part Number
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8660	Pump Gp-Trans	226-0167
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5K-2294	Bearing	396-9912
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5S-7893	Joint-Drive	380-7387
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475

Sales Model 941 (Cont'd.)

80H		
Original Part Number	Part Name	Classic Part Number
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6J-6043	Bearing-Sleeve	374-1456
6K-3937	Pin	241-2557
6K-4442	Rod End-Special	373-5388
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6V-2237	Gasket Kit	437-3212
6V-2246	Gasket Kit	391-1091
6Y-5915	Disc-Friction	384-5936
6Y-7914	Disc-Friction	390-5264
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7J-0583	Pump Gp-Vn Bsc-A	426-1698
7J-9682	Bearing-Sleeve	360-2335
7K-4458	Gear-Final Drive	226-6093
7K-4512	Pinion-Fdr	226-6081
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9360	Pin	319-3461
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348

80H		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-8117	Muffler As	247-2668
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8F-6058	Bearing-Sleeve	416-5494
8H-1174	Drum-Ster Cl Dr	226-6101
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636

80H		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860

Sales Model 941 (Cont'd.)

80H		
Original Part Number	Part Name	Classic Part Number
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
8S-4996	Muffler	390-0909
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-5080	Pump Gp-Vn Bsc-A	422-8141
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050

80H		
Original Part Number	Part Name	Classic Part Number
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

80H		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
230-7112	Ster Cl Kit-Cla	216-7840
231-1937	Kit-Strg Cl-Cla	226-6101
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 941B

16U		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761

16U		
Original Part Number	Part Name	Classic Part Number
1S-3062	Director-Water	418-9572
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981

16U		
Original Part Number	Part Name	Classic Part Number
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681

Sales Model 941B (Cont'd.)

16U		
Original Part Number	Part Name	Classic Part Number
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-6245	Shaft As-Pump	325-6197
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4M-5858	Bearing-Spl Ball	417-4495
4N-7692	Crankshaft As	269-8764
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475

16U		
Original Part Number	Part Name	Classic Part Number
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-2246	Gasket Kit	391-1091
7C-3862	Camshaft	458-0151
7G-2830	Ring-Seal	295-6441
7M-4046	Bearing-Sleeve	394-8206
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7W-0508	Gear-Fp Drive	296-1351
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

16U		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9S-7788	Ring-Piston	461-5124
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

Sales Model 941B (Cont'd.)

70H		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0020	Wheel-Turbine	297-4862
1T-1991	Stator As-Conv	380-1482
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2H-3517	Bearing-Inner	417-4505
2H-6936	Disc-Steer Cl Dr	380-7471
2K-4442	Bearing-Sleeve	308-9812
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4404	Housing As-Cl	226-8027
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197

70H		
Original Part Number	**Part Name**	**Classic Part Number**
2P-7828	Pan-Oil	314-8691
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-8393	Plate-Clutch	388-0592
3S-7987	Shaft-Planet	226-6074
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-8660	Pump Gp-Trans	226-0167
4S-8670	Shaft-Planet	300-2590

70H		
Original Part Number	**Part Name**	**Classic Part Number**
4S-8687	Piston-Clutch	226-8008
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
5K-2294	Bearing	396-9912
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5S-7893	Joint-Drive	380-7387
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6J-6043	Bearing-Sleeve	374-1456
6K-3937	Pin	241-2557
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-2237	Gasket Kit	437-3212
6V-2246	Gasket Kit	391-1091
6Y-5915	Disc-Friction	384-5936
6Y-7914	Disc-Friction	390-5264
7C-2880	Bell As-Suction	380-1520

Sales Model 941B (Cont'd.)

70H		
Original Part Number	Part Name	Classic Part Number
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7J-9682	Bearing-Sleeve	360-2335
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9360	Pin	319-3461
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8F-6058	Bearing-Sleeve	416-5494
8H-1174	Drum-Ster Cl Dr	226-6101
8H-8175	Bearing-Sleeve	376-3636

70H		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

70H		
Original Part Number	Part Name	Classic Part Number
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-4996	Muffler	390-0909
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-5080	Pump Gp-Vn Bsc-A	422-8141
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353

Sales Model 941B (Cont'd.)

70H		
Original Part Number	**Part Name**	**Classic Part Number**
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365

70H		
Original Part Number	**Part Name**	**Classic Part Number**
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
231-1937	Kit-Strg Cl-Cla	226-6101
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564

70H		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

80H		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1T-0020	Wheel-Turbine	297-4862
1T-1991	Stator As-Conv	380-1482
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716

80H		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7082	Rebuild Kt-Pump	383-3681
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-6936	Disc-Steer Cl Dr	380-7471
2K-4442	Bearing-Sleeve	308-9812
2K-4502	Bearing-Sleeve	299-1986
2K-6413	Pin	360-2270
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357

80H		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4404	Housing As-Cl	226-8027
2P-5081	Muffler As	360-7872
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3J-9325	Piston	390-0993

Sales Model 941B (Cont'd.)

80H		
Original Part Number	Part Name	Classic Part Number
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-8393	Plate-Clutch	388-0592
3S-7987	Shaft-Planet	226-6074
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4K-0255	Retainer As	226-6102
4K-0300	Bearing-Sleeve	308-9817
4K-1328	Drum-Ster Cl Dr	216-7840
4K-4780	Strip As-Wear	299-2063
4K-4894	Cage-Bearing	453-0968
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8204	Mount As	374-1449
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

80H		
Original Part Number	Part Name	Classic Part Number
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8660	Pump Gp-Trans	226-0167
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5K-2294	Bearing	396-9912
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

80H		
Original Part Number	Part Name	Classic Part Number
5S-7877	Bearing-Spl Ball	392-4491
5S-7893	Joint-Drive	380-7387
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6J-6043	Bearing-Sleeve	374-1456
6K-3937	Pin	241-2557
6K-4442	Rod End-Special	373-5388
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6V-2237	Gasket Kit	437-3212
6V-2246	Gasket Kit	391-1091
6Y-5915	Disc-Friction	384-5936
6Y-7914	Disc-Friction	390-5264
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7J-0583	Pump Gp-Vn Bsc-A	426-1698
7J-9682	Bearing-Sleeve	360-2335

Sales Model 941B (Cont'd.)

80H		
Original Part Number	Part Name	Classic Part Number
7K-4458	Gear-Final Drive	226-6093
7K-4512	Pinion-Fdr	226-6081
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9360	Pin	319-3461
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-8117	Muffler As	247-2668
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8576	Bearing As	435-4848

80H		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8F-6058	Bearing-Sleeve	416-5494
8H-1174	Drum-Ster Cl Dr	226-6101
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

80H		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
8S-4996	Muffler	390-0909
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-5080	Pump Gp-Vn Bsc-A	422-8141
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050

Sales Model 941B (Cont'd.)

80H		
Original Part Number	Part Name	Classic Part Number
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126

80H		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7776	Pump Gp-Water -B	395-1314

80H		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
230-7112	Ster Cl Kit-Cla	216-7840
231-1937	Kit-Strg Cl-Cla	226-6101
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
247-2670	Muffler-Classic	247-2675
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 943

03Y		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1W-9832	Muffler As	416-5493
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
3G-2580	Bearing-Sleeve	422-9526
3K-4290	Rod End	374-1823
4T-8054	Seal As	472-8010
5G-3612	Cap Gp-Protn	295-6419
6Y-7652	Cup-Rlr Brg	399-6067
7C-7955	Gasket-Cover	382-6899
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7M-1154	Bearing-Spl	417-4515

03Y		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7W-2059	Gasket-Cyl Hd	380-1548
8T-0072	Cone-Rlr Brg	377-7448
9M-1853	Mount As.	376-3638
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076

03Y		
Original Part Number	Part Name	Classic Part Number
1N-3822	Bearing-Conn Rod	376-9077
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173

Sales Model 943 (Cont'd.)

03Y		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
1W-9832	Muffler As	416-5493
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-1757	Hub-Fan Pulley	296-1357
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3G-2580	Bearing-Sleeve	422-9526
3G-6910	Bearing-Plate	419-4733
3J-9511	Bearing-Sleeve	385-3782
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3W-4363	Pin As	375-2634
3W-8409	Bearing	398-8336
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-8344	Spider As-Fan	416-5520
4P-7688	Valve As-Check	420-6216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419

03Y		
Original Part Number	**Part Name**	**Classic Part Number**
5P-7807	Bearing-Ball	314-8502
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
6E-2928	Pump Gp-Vn Bsc-A	426-1701
6L-7751	Rod End-Spher	472-8015
6N-5482	Plate-Friction	376-3637
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-7652	Cup-Rlr Brg	399-6067
7C-7955	Gasket-Cover	382-6899
7E-5085	Bushing	377-5829
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-2135	Bearing-Roller	417-4492
7M-1154	Bearing-Spl	417-4515
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-3536	Gear-Fuel	279-4993
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7P-1577	Pin As	375-9969
7P-2372	Joint As	367-6072
7P-6596	Bearing-Sleeve	295-6409
7P-6984	Pin	393-3674
7P-7245	Valve	386-3811
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8G-0935	Cap	425-3584
8G-4189	Bearing-Aligning	295-6411

03Y		
Original Part Number	**Part Name**	**Classic Part Number**
8G-4190	Seal-Ebar	296-1366
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0701	Bearing-Sleeve	419-4745
8N-1214	Mount As	325-6125
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3539	Plunger As-Pump	377-5861
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-1853	Strip	428-7633
9G-9086	Bearing-Sleeve	416-5528
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9M-4789	Shaft-Gov Cont	297-7256
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9S-8597	Spring	399-8561
9T-1697	Cartridge Gp-	422-8137
9Y-5168	Manifold-Exhaust	374-7483
119-6772	Valve-Exhaust	384-8699
130-6856	Pre-Cleaner As	361-1717
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076

Sales Model 943 (Cont'd.)

03Y		
Original Part Number	Part Name	Classic Part Number
1N-3822	Bearing-Conn Rod	376-9077
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
1W-9832	Muffler As	416-5493
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
2M-8340	Rod End-Yoke	374-4678
2P-1757	Hub-Fan Pulley	296-1357
2W-1223	Pump Gp-Water	385-7197
2W-8271	Arm As-Rocker	432-8912
3G-2580	Bearing-Sleeve	422-9526
3G-6910	Bearing-Plate	419-4733
3J-9511	Bearing-Sleeve	385-3782
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3W-4363	Pin As	375-2634
3W-8409	Bearing	398-8336
4N-0432	Bearing-Ball	417-4499
4N-8344	Spider As-Fan	416-5520
4P-7688	Valve As-Check	420-6216

03Y		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
6E-2928	Pump Gp-Vn Bsc-A	426-1701
6L-7751	Rod End-Spher	472-8015
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-7652	Cup-Rlr Brg	399-6067
7C-7955	Gasket-Cover	382-6899
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-2135	Bearing-Roller	417-4492
7M-1154	Bearing-Spl	417-4515
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7P-1577	Pin As	375-9969
7P-2372	Joint As	367-6072
7P-6596	Bearing-Sleeve	295-6409
7P-6984	Pin	393-3674
7P-7245	Valve	386-3811
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8G-0935	Cap	425-3584
8G-4189	Bearing-Aligning	295-6411

03Y		
Original Part Number	Part Name	Classic Part Number
8G-4190	Seal-Ebar	296-1366
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-1214	Mount As	325-6125
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-1853	Strip	428-7633
9G-9086	Bearing-Sleeve	416-5528
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9T-1697	Cartridge Gp-	422-8137
9Y-5168	Manifold-Exhaust	374-7483
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
130-6856	Pre-Cleaner As	361-1717
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1W-0311	Bearing-Main	376-9078

Sales Model 943 (Cont'd.)

03Y		
Original Part Number	**Part Name**	**Classic Part Number**
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
1W-9832	Muffler As	416-5493
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-1757	Hub-Fan Pulley	296-1357
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3G-2580	Bearing-Sleeve	422-9526
3G-6910	Bearing-Plate	419-4733
3J-9511	Bearing-Sleeve	385-3782
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3W-4363	Pin As	375-2634
3W-8409	Bearing	398-8336
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499

03Y		
Original Part Number	**Part Name**	**Classic Part Number**
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-8344	Spider As-Fan	416-5520
4P-7688	Valve As-Check	420-6216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
6E-2928	Pump Gp-Vn Bsc-A	426-1701
6L-7751	Rod End-Spher	472-8015
6N-5482	Plate-Friction	376-3637
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-7652	Cup-Rlr Brg	399-6067
7C-7955	Gasket-Cover	382-6899
7E-5085	Bushing	377-5829
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-2135	Bearing-Roller	417-4492
7K-8877	Cone-Bearing	374-1847
7M-1154	Bearing-Spl	417-4515
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-3536	Gear-Fuel	279-4993
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531

03Y		
Original Part Number	**Part Name**	**Classic Part Number**
7P-1577	Pin As	375-9969
7P-2372	Joint As	367-6072
7P-6596	Bearing-Sleeve	295-6409
7P-7245	Valve	386-3811
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8G-0935	Cap	425-3584
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0701	Bearing-Sleeve	419-4745
8N-1214	Mount As	325-6125
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3539	Plunger As-Pump	377-5861
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9M-4789	Shaft-Gov Cont	297-7256
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9S-8597	Spring	399-8561
9T-1697	Cartridge Gp-	422-8137
9Y-5168	Manifold-Exhaust	374-7483
119-6772	Valve-Exhaust	384-8699
130-6856	Pre-Cleaner As	361-1717
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 943B

8WF		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384
2F-5721	Bearing-Ball	311-9354
2K-5069	Cup-Roller Brg	374-8346
2W-7213	Bearing-Sleeve	419-4667
3B-3967	Race-Roller Brg	386-4947
3G-2580	Bearing-Sleeve	422-9526
3J-9511	Bearing-Sleeve	385-3782
3W-4363	Pin As	375-2634
3W-5159	Plate-Parking Bk	391-9904
3W-8409	Bearing	398-8336
4N-8344	Spider As-Fan	416-5520
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6I-4689	Gasket-Cyl Head	377-5840
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6W-1958	Element	390-5284

8WF		
Original Part Number	**Part Name**	**Classic Part Number**
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7P-1577	Pin As	375-9969
7P-6596	Bearing-Sleeve	295-6409
7P-6984	Pin	393-3674
7P-7245	Valve	386-3811
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8F-6058	Bearing-Sleeve	416-5494
8G-0935	Cap	425-3584
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
8T-0072	Cone-Rlr Brg	377-7448

8WF		
Original Part Number	**Part Name**	**Classic Part Number**
8T-1177	Bearing-Rlr	419-1862
8Y-1853	Strip	428-7633
9G-9086	Bearing-Sleeve	416-5528
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
130-6856	Pre-Cleaner As	361-1717
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

Track Loaders

Sales Model 951

63K, 89A		
Original Part Number	**Part Name**	**Classic Part Number**
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494

63K, 89A		
Original Part Number	**Part Name**	**Classic Part Number**
6B-3223	Cup-Bearing	399-6065
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440

63K, 89A		
Original Part Number	**Part Name**	**Classic Part Number**
4B-9374	Bearing-Cup	380-7494
6B-3223	Cup-Bearing	399-6065

92A		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7074	Kit-Rebuild-Pump	419-4712
2L-5271	Bearing-Ball	371-4305

Sales Model 951B

15F		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1W-7074	Kit-Rebuild-Pump	419-4712
2L-5271	Bearing-Ball	371-4305

15F		
Original Part Number	**Part Name**	**Classic Part Number**
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494

15F		
Original Part Number	**Part Name**	**Classic Part Number**
6B-3223	Cup-Bearing	399-6065
7G-2830	Ring-Seal	295-6441
121-7746	Pre-Cleaner As	360-2311

32F		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1S-3062	Director-Water	418-9572
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-6245	Shaft As-Pump	325-6197

32F		
Original Part Number	**Part Name**	**Classic Part Number**
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4M-5858	Bearing-Spl Ball	417-4495
4N-7692	Crankshaft As	269-8764
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024

32F		
Original Part Number	**Part Name**	**Classic Part Number**
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732

Sales Model 951B (Cont'd.)

32F		
Original Part Number	Part Name	Classic Part Number
7C-3862	Camshaft	458-0151
7G-2830	Ring-Seal	295-6441
7M-4046	Bearing-Sleeve	394-8206
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711

32F		
Original Part Number	Part Name	Classic Part Number
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9S-7788	Ring-Piston	461-5124
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032

32F		
Original Part Number	Part Name	Classic Part Number
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

69H		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
2D-5658	Bearing-Ball	301-4628
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2P-0220	Gasket-Pump	398-2927
2S-7931	Bearing-Sleeve	387-2904
3P-2564	Race-Brg Outer	417-9480
3P-2582	Bearing-Spl Ball	417-9478

69H		
Original Part Number	Part Name	Classic Part Number
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4M-5858	Bearing-Spl Ball	417-4495
4W-0452	Seal As -Cshaft	325-6191
5P-2526	Cup-Rlr Bearing	380-7498
5P-8768	Kit-Gasket (Scl)	393-1024

69H		
Original Part Number	Part Name	Classic Part Number
5S-7877	Bearing-Spl Ball	392-4491
6B-3223	Cup-Bearing	399-6065
6V-2466	Kit-Gasket-Fs	437-3211
7G-2830	Ring-Seal	295-6441
8H-8175	Bearing-Sleeve	376-3636
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
131-3815	Seal Gp-Basic	325-6193

Sales Model 951B (Cont'd.)

78J		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7074	Kit-Rebuild-Pump	419-4712
2L-5271	Bearing-Ball	371-4305

78J		
Original Part Number	**Part Name**	**Classic Part Number**
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440

78J		
Original Part Number	**Part Name**	**Classic Part Number**
4B-9374	Bearing-Cup	380-7494
6B-3223	Cup-Bearing	399-6065

79H		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1635	Hub-Gear	222-1763
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1M-0090	Gasket-Manifold	445-7701
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-1888	Bracket-Lamp	297-7147
1S-6422	Pilot As-Spring	226-4849
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-1991	Stator As-Conv	380-1482
1U-2668	Cartridge Gp	422-8117
1W-7074	Kit-Rebuild-Pump	419-4712
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2H-3517	Bearing-Inner	417-4505
2K-4442	Bearing-Sleeve	308-9812
2K-4502	Bearing-Sleeve	299-1986
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-4404	Housing As-Cl	226-8027

79H		
Original Part Number	**Part Name**	**Classic Part Number**
2P-5081	Muffler As	360-7872
2P-7622	Bolt-Spring	226-4850
2S-5551	Coupling-Exhaust	398-2934
2S-7931	Bearing-Sleeve	387-2904
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3K-4290	Rod End	374-1823
3P-1465	Spring-Recoil	384-3479
3P-8393	Plate-Clutch	388-0592
3S-7987	Shaft-Planet	226-6074
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4F-5004	Spring As-Arm	383-2128
4K-0255	Retainer As	226-6102
4K-0300	Bearing-Sleeve	308-9817
4K-1328	Drum-Ster Cl Dr	216-7840
4K-4780	Strip As-Wear	299-2063
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495
4N-4864	Pump Gp-F Tfr	242-3442
4S-8660	Pump Gp-Trans	226-0167
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4V-3396	Hub-Gear	222-1763
5H-7071	Director-Water	388-0555
5K-2294	Bearing	396-9912
5K-8591	Bearing-Outer	380-7502
5P-9514	Bearing-Ball	417-9467
5S-1822	Chamber As	248-5406

79H		
Original Part Number	**Part Name**	**Classic Part Number**
5S-4557	Bearing	311-9360
5S-7877	Bearing-Spl Ball	392-4491
5S-7893	Joint-Drive	380-7387
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6J-6043	Bearing-Sleeve	374-1456
6K-3937	Pin	241-2557
6K-4442	Rod End-Special	373-5388
6K-8088	Bearing-Roller	399-4428
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6Y-5915	Disc-Friction	384-5936
6Y-7914	Disc-Friction	390-5264
7E-5085	Bushing	377-5829
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7H-2424	Sleeve-Spring	226-4852
7J-0583	Pump Gp-Vn Bsc-A	426-1698
7J-9682	Bearing-Sleeve	360-2335
7K-4458	Gear-Final Drive	226-6093
7K-4512	Pinion-Fdr	226-6081
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9360	Pin	319-3461
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4358	Manifold-Exhaust	261-0907

Sales Model 951B (Cont'd.)

79H		
Original Part Number	Part Name	Classic Part Number
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7N-7386	Gasket-Cyl Head	392-4519
7N-8117	Muffler As	247-2668
7N-9146	Gear-Fly Starter	279-4995
7S-1234	Bushing As-Spt	394-0192
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342

79H		
Original Part Number	Part Name	Classic Part Number
8K-5587	Rod Gp-Recoil	226-4954
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-2809	Muffler	247-2677
8S-9686	Gasket Kit	393-5215
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9K-9271	Holder As-Cage	217-7730

79H		
Original Part Number	Part Name	Classic Part Number
9K-9273	Nut-Adjusting	226-7998
9M-5477	Bearing-Sleeve	374-6517
9S-1768	Pipe-Ext Exhaust	380-7544
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-9696	Spider As-Fan	383-3707
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
230-7112	Ster Cl Kit-Cla	216-7840
232-3233	Bearing-Main	376-9085
247-2670	Muffler-Classic	247-2675
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

86J		
Original Part Number	Part Name	Classic Part Number
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-6422	Pilot As-Spring	226-4849

86J		
Original Part Number	Part Name	Classic Part Number
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-1991	Stator As-Conv	380-1482
1U-2668	Cartridge Gp	422-8117
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

86J		
Original Part Number	Part Name	Classic Part Number
1W-7082	Rebuild Kt-Pump	383-3681
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-4442	Bearing-Sleeve	308-9812
2K-4502	Bearing-Sleeve	299-1986
2K-6413	Pin	360-2270
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357

Sales Model 951B (Cont'd.)

86J		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4404	Housing As-Cl	226-8027
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7622	Bolt-Spring	226-4850
2P-7828	Pan-Oil	314-8691
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3J-9325	Piston	390-0993
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3P-8393	Plate-Clutch	388-0592
3S-7987	Shaft-Planet	226-6074
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4F-5004	Spring As-Arm	383-2128
4K-0255	Retainer As	226-6102
4K-0300	Bearing-Sleeve	308-9817
4K-1328	Drum-Ster Cl Dr	216-7840

86J		
Original Part Number	**Part Name**	**Classic Part Number**
4K-4780	Strip As-Wear	299-2063
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8204	Mount As	374-1449
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116

86J		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8660	Pump Gp-Trans	226-0167
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5K-2294	Bearing	396-9912
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5S-7893	Joint-Drive	380-7387
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6J-6043	Bearing-Sleeve	374-1456

Sales Model 951B (Cont'd.)

86J		
Original Part Number	Part Name	Classic Part Number
6K-3937	Pin	241-2557
6K-4442	Rod End-Special	373-5388
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6V-2237	Gasket Kit	437-3212
6V-2246	Gasket Kit	391-1091
6V-2466	Kit-Gasket-Fs	437-3211
6Y-5915	Disc-Friction	384-5936
6Y-7914	Disc-Friction	390-5264
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7H-2424	Sleeve-Spring	226-4852
7J-0583	Pump Gp-Vn Bsc-A	426-1698
7J-9682	Bearing-Sleeve	360-2335
7K-4458	Gear-Final Drive	226-6093
7K-4512	Pinion-Fdr	226-6081
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9360	Pin	319-3461
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951

86J		
Original Part Number	Part Name	Classic Part Number
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7809	Cap As-Radiator	295-6417
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-5587	Rod Gp-Recoil	226-4954
8K-9661	Gear-Bevel	213-8218
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196

86J		
Original Part Number	Part Name	Classic Part Number
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

Sales Model 951B (Cont'd.)

86J		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-4996	Muffler	390-0909
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-5080	Pump Gp-Vn Bsc-A	422-8141
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

86J		
Original Part Number	**Part Name**	**Classic Part Number**
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

86J		
Original Part Number	**Part Name**	**Classic Part Number**
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
230-7112	Ster Cl Kit-Cla	216-7840
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 951C

19H		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1S-3062	Director-Water	418-9572

19H		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

19H		
Original Part Number	**Part Name**	**Classic Part Number**
2F-5721	Bearing-Ball	311-9354
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-6245	Shaft As-Pump	325-6197

Sales Model 951C (Cont'd.)

19H		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4N-7692	Crankshaft As	269-8764
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6I-1345	Shaft As-O Pump	374-7475
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7C-3862	Camshaft	458-0151
7M-4046	Bearing-Sleeve	394-8206

19H		
Original Part Number	Part Name	Classic Part Number
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

19H		
Original Part Number	Part Name	Classic Part Number
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9S-7788	Ring-Piston	461-5124
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
170-7502	Shaft-Dr Idler	374-7484
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

32F		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1S-3062	Director-Water	418-9572
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981

32F		
Original Part Number	Part Name	Classic Part Number
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628

32F		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214

Sales Model 951C (Cont'd.)

32F		
Original Part Number	**Part Name**	**Classic Part Number**
2P-6245	Shaft As-Pump	325-6197
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4M-5858	Bearing-Spl Ball	417-4495
4N-7692	Crankshaft As	269-8764
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732

32F		
Original Part Number	**Part Name**	**Classic Part Number**
7C-3862	Camshaft	458-0151
7G-2830	Ring-Seal	295-6441
7M-4046	Bearing-Sleeve	394-8206
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

32F		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9S-7788	Ring-Piston	461-5124
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

Sales Model 951C (Cont'd.)

69H		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
2D-5658	Bearing-Ball	301-4628
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2P-0220	Gasket-Pump	398-2927
2S-7931	Bearing-Sleeve	387-2904
3P-2564	Race-Brg Outer	417-9480
3P-2582	Bearing-Spl Ball	417-9478

69H		
Original Part Number	**Part Name**	**Classic Part Number**
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4M-5858	Bearing-Spl Ball	417-4495
4W-0452	Seal As -Cshaft	325-6191
5P-2526	Cup-Rlr Bearing	380-7498
5P-8768	Kit-Gasket (Scl)	393-1024

69H		
Original Part Number	**Part Name**	**Classic Part Number**
5S-7877	Bearing-Spl Ball	392-4491
6B-3223	Cup-Bearing	399-6065
6V-2466	Kit-Gasket-Fs	437-3211
7G-2830	Ring-Seal	295-6441
8H-8175	Bearing-Sleeve	376-3636
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
131-3815	Seal Gp-Basic	325-6193

86J		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-6422	Pilot As-Spring	226-4849
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-1991	Stator As-Conv	380-1482
1U-2668	Cartridge Gp	422-8117
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

86J		
Original Part Number	**Part Name**	**Classic Part Number**
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7082	Rebuild Kt-Pump	383-3681
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-4442	Bearing-Sleeve	308-9812
2K-4502	Bearing-Sleeve	299-1986
2K-6413	Pin	360-2270
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

86J		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4404	Housing As-Cl	226-8027
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7622	Bolt-Spring	226-4850
2P-7828	Pan-Oil	314-8691
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3J-9325	Piston	390-0993
3K-2511	Dowel-Reaction	383-2126

Sales Model 951C (Cont'd.)

86J		
Original Part Number	**Part Name**	**Classic Part Number**
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3P-8393	Plate-Clutch	388-0592
3S-7987	Shaft-Planet	226-6074
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4F-5004	Spring As-Arm	383-2128
4K-0255	Retainer As	226-6102
4K-0300	Bearing-Sleeve	308-9817
4K-1328	Drum-Ster Cl Dr	216-7840
4K-4780	Strip As-Wear	299-2063
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8204	Mount As	374-1449
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

86J		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8660	Pump Gp-Trans	226-0167
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5K-2294	Bearing	396-9912
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5M-6126	Bearing	377-7433
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

86J		
Original Part Number	**Part Name**	**Classic Part Number**
5S-7877	Bearing-Spl Ball	392-4491
5S-7893	Joint-Drive	380-7387
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6J-6043	Bearing-Sleeve	374-1456
6K-3937	Pin	241-2557
6K-4442	Rod End-Special	373-5388
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6V-2237	Gasket Kit	437-3212
6V-2246	Gasket Kit	391-1091
6V-2466	Kit-Gasket-Fs	437-3211
6Y-5915	Disc-Friction	384-5936
6Y-7914	Disc-Friction	390-5264
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7H-2424	Sleeve-Spring	226-4852
7J-0583	Pump Gp-Vn Bsc-A	426-1698
7J-9682	Bearing-Sleeve	360-2335

Sales Model 951C (Cont'd.)

86J		
Original Part Number	Part Name	Classic Part Number
7K-4458	Gear-Final Drive	226-6093
7K-4512	Pinion-Fdr	226-6081
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9360	Pin	319-3461
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7809	Cap As-Radiator	295-6417
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351

86J		
Original Part Number	Part Name	Classic Part Number
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-5587	Rod Gp-Recoil	226-4954
8K-9661	Gear-Bevel	213-8218
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207

86J		
Original Part Number	Part Name	Classic Part Number
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-4996	Muffler	390-0909
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-5080	Pump Gp-Vn Bsc-A	422-8141
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905

Track Loaders

Sales Model 951C (Cont'd.)

86J		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126

86J		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7776	Pump Gp-Water -B	395-1314

86J		
Original Part Number	**Part Name**	**Classic Part Number**
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
230-7112	Ster Cl Kit-Cla	216-7840
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 953

05Z		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-4695	Cup-Rlr Bearing	374-1842
1P-4696	Cone-Rlr Bearing	374-1843
1W-0311	Bearing-Main	376-9078

05Z		
Original Part Number	**Part Name**	**Classic Part Number**
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9519	Muffler As	397-5043
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513

05Z		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9832	Muffler As	416-5493
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-1757	Hub-Fan Pulley	296-1357
2P-8986	Cup-Rlr Bearing	415-1912
2W-1223	Pump Gp-Water	385-7197

Sales Model 953 (Cont'd.)

05Z		
Original Part Number	Part Name	Classic Part Number
2W-8271	Arm As-Rocker	432-8912
3G-2580	Bearing-Sleeve	422-9526
3G-5750	Bearing-Plate	419-4734
3J-8688	Bearing-Sleeve	380-1561
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3W-5159	Plate-Parking Bk	391-9904
3W-7559	Pin As	419-4731
3W-8409	Bearing	398-8336
4N-0432	Bearing-Ball	417-4499
4N-8344	Spider As-Fan	416-5520
4P-7688	Valve As-Check	420-6216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-2928	Pump Gp-Vn Bsc-A	426-1701
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
7C-7955	Gasket-Cover	382-6899

20Z		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849

05Z		
Original Part Number	Part Name	Classic Part Number
7E-5085	Bushing	377-5829
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-3536	Gear-Fuel	279-4993
7N-5206	Mount As	374-1451
7N-5539	Muffler As	360-7891
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7P-2372	Joint As	367-6072
7P-3466	Bearing-Sleeve	422-9523
7P-3472	Pin	374-8366
7P-6348	Bearing	399-6042
7P-6596	Bearing-Sleeve	295-6409
7P-6984	Pin	393-3674
7P-7245	Valve	386-3811
7P-7734	Rod As	376-3643
7P-9568	Gear-Planet	446-3072
7P-9578	Shaft	470-3787
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-5450	Seal-Ebar	325-6190
8G-0935	Cap	425-3584
8G-4022	Bearing	422-6920
8G-4027	Pin As	393-3677
8G-4372	Support As	376-3645
8G-8331	Pin As	443-2971
8H-0901	Cup-Spl Tap Roll	399-4444

05Z		
Original Part Number	Part Name	Classic Part Number
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-1214	Mount As	325-6125
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3539	Plunger As-Pump	377-5861
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8T-1177	Bearing-Rlr	419-1862
8Y-1853	Strip	428-7633
9G-9086	Bearing-Sleeve	416-5528
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9M-4789	Shaft-Gov Cont	297-7256
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-1697	Cartridge Gp-	422-8137
9Y-5168	Manifold-Exhaust	374-7483
119-6772	Valve-Exhaust	384-8699
130-6856	Pre-Cleaner As	361-1717
226-8202	Seal-Wiper	472-8024
268-5569	Pin As	415-1905
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
374-1849	Brg-Rlr-Cla	399-4442

Sales Model 953 (Cont'd.)

20Z		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9519	Muffler As	397-5043
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
1W-9832	Muffler As	416-5493
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2M-8340	Rod End-Yoke	374-4678
2P-1757	Hub-Fan Pulley	296-1357
2W-1223	Pump Gp-Water	385-7197
2W-8271	Arm As-Rocker	432-8912
3G-2580	Bearing-Sleeve	422-9526
3G-5750	Bearing-Plate	419-4734
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433

20Z		
Original Part Number	Part Name	Classic Part Number
3W-5159	Plate-Parking Bk	391-9904
3W-7559	Pin As	419-4731
3W-8409	Bearing	398-8336
4N-0432	Bearing-Ball	417-4499
4N-8344	Spider As-Fan	416-5520
4P-7688	Valve As-Check	420-6216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-2928	Pump Gp-Vn Bsc-A	426-1701
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
7C-7955	Gasket-Cover	382-6899
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-5539	Muffler As	360-7891
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7P-2372	Joint As	367-6072
7P-3466	Bearing-Sleeve	422-9523
7P-3472	Pin	374-8366

20Z		
Original Part Number	Part Name	Classic Part Number
7P-6596	Bearing-Sleeve	295-6409
7P-6984	Pin	393-3674
7P-7245	Valve	386-3811
7P-7734	Rod As	376-3643
7P-9568	Gear-Planet	446-3072
7P-9578	Shaft	470-3787
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-5450	Seal-Ebar	325-6190
8G-0935	Cap	425-3584
8G-4022	Bearing	422-6920
8G-4027	Pin As	393-3677
8G-4372	Support As	376-3645
8G-8331	Pin As	443-2971
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-1214	Mount As	325-6125
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8T-1177	Bearing-Rlr	419-1862
8Y-1853	Strip	428-7633
9G-9086	Bearing-Sleeve	416-5528
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-1697	Cartridge Gp-	422-8137
9Y-5168	Manifold-Exhaust	374-7483

Sales Model 953 (Cont'd.)

20Z		
Original Part Number	Part Name	Classic Part Number
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
130-6856	Pre-Cleaner As	361-1717
226-8202	Seal-Wiper	472-8024

20Z		
Original Part Number	Part Name	Classic Part Number
268-5569	Pin As	415-1905
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

20Z		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032
374-1849	Brg-Rlr-Cla	399-4442

2RB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9519	Muffler As	397-5043
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2M-8340	Rod End-Yoke	374-4678
2P-1757	Hub-Fan Pulley	296-1357
2W-1223	Pump Gp-Water	385-7197
2W-8271	Arm As-Rocker	432-8912
3G-5750	Bearing-Plate	419-4734

2RB		
Original Part Number	Part Name	Classic Part Number
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3W-5159	Plate-Parking Bk	391-9904
3W-8409	Bearing	398-8336
4N-0432	Bearing-Ball	417-4499
4N-8344	Spider As-Fan	416-5520
4P-7688	Valve As-Check	420-6216
4W-6869	Spacer-Fuel Pump	417-4534
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-2928	Pump Gp-Vn Bsc-A	426-1701
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
7C-7955	Gasket-Cover	382-6899
7J-2604	Bearing-Sleeve	380-7369
7J-8893	Cone-Roller Brg	374-1846
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983

2RB		
Original Part Number	Part Name	Classic Part Number
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7P-2372	Joint As	367-6072
7P-3466	Bearing-Sleeve	422-9523
7P-6596	Bearing-Sleeve	295-6409
7P-6984	Pin	393-3674
7P-7245	Valve	386-3811
7P-9568	Gear-Planet	446-3072
7P-9578	Shaft	470-3787
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8G-0935	Cap	425-3584
8G-4022	Bearing	422-6920
8G-4027	Pin As	393-3677
8G-4372	Support As	376-3645
8G-8331	Pin As	443-2971
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8T-1177	Bearing-Rlr	419-1862
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-5246	Bearing-Camshaft	384-4772

Sales Model 953 (Cont'd.)

2RB		
Original Part Number	**Part Name**	**Classic Part Number**
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

2RB		
Original Part Number	**Part Name**	**Classic Part Number**
9T-1697	Cartridge Gp-	422-8137
9Y-5168	Manifold-Exhaust	374-7483
119-6772	Valve-Exhaust	384-8699
130-6856	Pre-Cleaner As	361-1717

2RB		
Original Part Number	**Part Name**	**Classic Part Number**
268-5569	Pin As	415-1905
275-0120	Pin As	419-7245
374-1849	Brg-Rlr-Cla	399-4442

44Z		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1U-2668	Cartridge Gp	422-8117
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9519	Muffler As	397-5043
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2M-8340	Rod End-Yoke	374-4678
2P-1757	Hub-Fan Pulley	296-1357

44Z		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1223	Pump Gp-Water	385-7197
2W-8271	Arm As-Rocker	432-8912
3G-2580	Bearing-Sleeve	422-9526
3G-5750	Bearing-Plate	419-4734
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3W-5159	Plate-Parking Bk	391-9904
3W-8409	Bearing	398-8336
4N-0432	Bearing-Ball	417-4499
4N-8344	Spider As-Fan	416-5520
4P-7688	Valve As-Check	420-6216
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5F-0736	Pin-Pivot	256-4823
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6D-0217	Bearing-Sleeve	325-6022

44Z		
Original Part Number	**Part Name**	**Classic Part Number**
6E-2928	Pump Gp-Vn Bsc-A	426-1701
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
7C-7955	Gasket-Cover	382-6899
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-5539	Muffler As	360-7891
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7P-2372	Joint As	367-6072
7P-3466	Bearing-Sleeve	422-9523
7P-3472	Pin	374-8366
7P-6596	Bearing-Sleeve	295-6409
7P-6984	Pin	393-3674
7P-7245	Valve	386-3811
7P-7734	Rod As	376-3643
7P-9568	Gear-Planet	446-3072
7P-9578	Shaft	470-3787
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351

Sales Model 953 (Cont'd.)

44Z		
Original Part Number	Part Name	Classic Part Number
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-6221	Pin	325-6155
8G-0935	Cap	425-3584
8G-4022	Bearing	422-6920
8G-4027	Pin As	393-3677
8G-4372	Support As	376-3645
8G-8331	Pin As	443-2971
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-1214	Mount As	325-6125

44Z		
Original Part Number	Part Name	Classic Part Number
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8T-1177	Bearing-Rlr	419-1862
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923

44Z		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9T-1697	Cartridge Gp-	422-8137
9Y-5168	Manifold-Exhaust	374-7483
119-6772	Valve-Exhaust	384-8699
127-5537	Core As-Oclr	325-6045
130-6856	Pre-Cleaner As	361-1717
226-8202	Seal-Wiper	472-8024
268-5569	Pin As	415-1905
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
374-1849	Brg-Rlr-Cla	399-4442

76Y		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9519	Muffler As	397-5043
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
1W-9832	Muffler As	416-5493

76Y		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-1757	Hub-Fan Pulley	296-1357
2W-1223	Pump Gp-Water	385-7197
2W-8271	Arm As-Rocker	432-8912
3G-2580	Bearing-Sleeve	422-9526
3G-5750	Bearing-Plate	419-4734
3J-6167	Bearing-Sleeve	299-1960
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3W-5159	Plate-Parking Bk	391-9904
3W-8409	Bearing	398-8336

76Y		
Original Part Number	Part Name	Classic Part Number
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4N-0432	Bearing-Ball	417-4499
4N-8344	Spider As-Fan	416-5520
4P-7688	Valve As-Check	420-6216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-2928	Pump Gp-Vn Bsc-A	426-1701
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006

Sales Model 953 (Cont'd.)

76Y		
Original Part Number	**Part Name**	**Classic Part Number**
7C-7955	Gasket-Cover	382-6899
7E-5085	Bushing	377-5829
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-2135	Bearing-Roller	417-4492
7K-9528	Bearing-Sleeve	308-9828
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-3536	Gear-Fuel	279-4993
7N-5206	Mount As	374-1451
7N-5539	Muffler As	360-7891
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7P-2372	Joint As	367-6072
7P-3466	Bearing-Sleeve	422-9523
7P-3472	Pin	374-8366
7P-6596	Bearing-Sleeve	295-6409
7P-6984	Pin	393-3674
7P-7245	Valve	386-3811
7P-7734	Rod As	376-3643

76Y		
Original Part Number	**Part Name**	**Classic Part Number**
7P-9568	Gear-Planet	446-3072
7P-9578	Shaft	470-3787
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8G-0935	Cap	425-3584
8G-4022	Bearing	422-6920
8G-4027	Pin As	393-3677
8G-4372	Support As	376-3645
8G-8331	Pin As	443-2971
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-1214	Mount As	325-6125
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3539	Plunger As-Pump	377-5861
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267

76Y		
Original Part Number	**Part Name**	**Classic Part Number**
8S-0248	Breather As	325-6033
8T-1177	Bearing-Rlr	419-1862
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9M-4789	Shaft-Gov Cont	297-7256
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-1697	Cartridge Gp-	422-8137
9Y-5168	Manifold-Exhaust	374-7483
119-6772	Valve-Exhaust	384-8699
130-6856	Pre-Cleaner As	361-1717
134-8951	Plate	382-5061
226-8202	Seal-Wiper	472-8024
268-5569	Pin As	415-1905
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
374-1849	Brg-Rlr-Cla	399-4442

77Y		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080

77Y		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9519	Muffler As	397-5043
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
1W-9832	Muffler As	416-5493
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944

77Y		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2M-8340	Rod End-Yoke	374-4678
2P-1757	Hub-Fan Pulley	296-1357
2W-1223	Pump Gp-Water	385-7197
2W-8271	Arm As-Rocker	432-8912
3G-2580	Bearing-Sleeve	422-9526
3G-5750	Bearing-Plate	419-4734
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356

Sales Model 953 (Cont'd.)

77Y		
Original Part Number	Part Name	Classic Part Number
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3W-5159	Plate-Parking Bk	391-9904
3W-8409	Bearing	398-8336
4N-0432	Bearing-Ball	417-4499
4N-8344	Spider As-Fan	416-5520
4P-7688	Valve As-Check	420-6216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-2928	Pump Gp-Vn Bsc-A	426-1701
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
7C-7955	Gasket-Cover	382-6899
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846

77Y		
Original Part Number	Part Name	Classic Part Number
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7P-2372	Joint As	367-6072
7P-3466	Bearing-Sleeve	422-9523
7P-3472	Pin	374-8366
7P-6596	Bearing-Sleeve	295-6409
7P-6984	Pin	393-3674
7P-7245	Valve	386-3811
7P-7734	Rod As	376-3643
7P-9568	Gear-Planet	446-3072
7P-9578	Shaft	470-3787
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8G-0935	Cap	425-3584
8G-4022	Bearing	422-6920
8G-4027	Pin As	393-3677
8G-4372	Support As	376-3645
8G-8331	Pin As	443-2971
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342

77Y		
Original Part Number	Part Name	Classic Part Number
8N-1214	Mount As	325-6125
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8T-1177	Bearing-Rlr	419-1862
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-1697	Cartridge Gp-	422-8137
9Y-5168	Manifold-Exhaust	374-7483
119-6772	Valve-Exhaust	384-8699
130-6856	Pre-Cleaner As	361-1717
226-8202	Seal-Wiper	472-8024
268-5569	Pin As	415-1905
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
374-1849	Brg-Rlr-Cla	399-4442

78Y		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077

78Y		
Original Part Number	Part Name	Classic Part Number
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0370	Muffler As.	360-7869
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080

78Y		
Original Part Number	Part Name	Classic Part Number
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

Sales Model 953 (Cont'd.)

78Y		
Original Part Number	Part Name	Classic Part Number
1W-9519	Muffler As	397-5043
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2M-8340	Rod End-Yoke	374-4678
2P-1757	Hub-Fan Pulley	296-1357
2W-1223	Pump Gp-Water	385-7197
2W-8271	Arm As-Rocker	432-8912
3G-2580	Bearing-Sleeve	422-9526
3G-5750	Bearing-Plate	419-4734
3J-6167	Bearing-Sleeve	299-1960
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3W-5159	Plate-Parking Bk	391-9904
3W-8409	Bearing	398-8336
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4N-0432	Bearing-Ball	417-4499
4N-8344	Spider As-Fan	416-5520
4P-7688	Valve As-Check	420-6216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537

78Y		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-2928	Pump Gp-Vn Bsc-A	426-1701
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
7C-7955	Gasket-Cover	382-6899
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-2135	Bearing-Roller	417-4492
7K-9528	Bearing-Sleeve	308-9828
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-5539	Muffler As	360-7891
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7P-2372	Joint As	367-6072
7P-3466	Bearing-Sleeve	422-9523
7P-3472	Pin	374-8366
7P-6596	Bearing-Sleeve	295-6409
7P-6984	Pin	393-3674
7P-7245	Valve	386-3811
7P-7734	Rod As	376-3643
7P-9568	Gear-Planet	446-3072
7P-9578	Shaft	470-3787
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935

78Y		
Original Part Number	Part Name	Classic Part Number
7W-2059	Gasket-Cyl Hd	380-1548
8G-0935	Cap	425-3584
8G-4022	Bearing	422-6920
8G-4027	Pin As	393-3677
8G-4372	Support As	376-3645
8G-8331	Pin As	443-2971
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-1214	Mount As	325-6125
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8T-1177	Bearing-Rlr	419-1862
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-1697	Cartridge Gp-	422-8137
9Y-5168	Manifold-Exhaust	374-7483
119-6772	Valve-Exhaust	384-8699
130-6856	Pre-Cleaner As	361-1717
226-8202	Seal-Wiper	472-8024
268-5569	Pin As	415-1905
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
374-1849	Brg-Rlr-Cla	399-4442

Sales Model 953B

5MK		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1S-7057	Gasket	420-6384
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2M-8340	Rod End-Yoke	374-4678
2W-7213	Bearing-Sleeve	419-4667
3G-2580	Bearing-Sleeve	422-9526
3G-5750	Bearing-Plate	419-4734
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3W-5159	Plate-Parking Bk	391-9904
3W-7559	Pin As	419-4731
3W-8409	Bearing	398-8336
4N-8344	Spider As-Fan	416-5520
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-2928	Pump Gp-Vn Bsc-A	426-1701
6E-5831	Pump Gp-Vn Bsc-A	426-1699

5MK		
Original Part Number	Part Name	Classic Part Number
6I-1099	Manifold-Exh	424-6366
6L-7751	Rod End-Spher	472-8015
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7P-2372	Joint As	367-6072
7P-3466	Bearing-Sleeve	422-9523
7P-3472	Pin	374-8366
7P-6596	Bearing-Sleeve	295-6409
7P-6984	Pin	393-3674
7P-7245	Valve	386-3811
7P-9568	Gear-Planet	446-3072
7P-9578	Shaft	470-3787
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545

5MK		
Original Part Number	Part Name	Classic Part Number
8E-5450	Seal-Ebar	325-6190
8G-0935	Cap	425-3584
8G-4022	Bearing	422-6920
8G-4027	Pin As	393-3677
8G-8331	Pin As	443-2971
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
8T-1177	Bearing-Rlr	419-1862
8Y-1853	Strip	428-7633
9G-9086	Bearing-Sleeve	416-5528
9M-1853	Mount As.	376-3638
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-1697	Cartridge Gp-	422-8137
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-2941	Gasket Kit	393-1020
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
126-5875	Flywheel As.	374-4694
130-6856	Pre-Cleaner As	361-1717
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697

Track Loaders

Sales Model 953B (Cont'd.)

5MK		
Original Part Number	Part Name	Classic Part Number
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
264-6898	Kit-Gasket-Sch	382-5069

5MK		
Original Part Number	Part Name	Classic Part Number
268-5569	Pin As	415-1905
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578
286-2494	Kit-Gasket-Sch	387-2920
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

5MK		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
374-1849	Brg-Rlr-Cla	399-4442
460-5395	Kit-Gasket (Sch)	436-8395

Sales Model 953C

2ZN		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2W-7213	Bearing-Sleeve	419-4667
3G-2580	Bearing-Sleeve	422-9526
3H-8726	Mount As	385-7208
3J-9511	Bearing-Sleeve	385-3782
3W-5159	Plate-Parking Bk	391-9904
3W-7559	Pin As	419-4731
3W-8409	Bearing	398-8336
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
6I-1099	Manifold-Exh	424-6366

2ZN		
Original Part Number	Part Name	Classic Part Number
6L-7751	Rod End-Spher	472-8015
6P-0593	Bearing-Roller	386-4959
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-6461	Crown	325-6054
7J-9344	Bearing-Sleeve	360-2334
7K-2135	Bearing-Roller	417-4492
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7P-2372	Joint As	367-6072
7P-3466	Bearing-Sleeve	422-9523

2ZN		
Original Part Number	Part Name	Classic Part Number
7P-3472	Pin	374-8366
7P-6596	Bearing-Sleeve	295-6409
7P-6984	Pin	393-3674
7P-7245	Valve	386-3811
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8D-0983	Mounting	384-3470
8E-5450	Seal-Ebar	325-6190
8G-0935	Cap	425-3584
8G-4022	Bearing	422-6920
8G-4027	Pin As	393-3677
8G-8331	Pin As	443-2971
8H-2810	Case As-Filter	314-8512
8J-5778	Bearing-Sleeve	374-8359
8S-0248	Breather As	325-6033
8Y-1853	Strip	428-7633
9G-9086	Bearing-Sleeve	416-5528
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756

Sales Model 953C (Cont'd.)

2ZN		
Original Part Number	Part Name	Classic Part Number
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
109-9323	Muffler As	369-9491
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
130-6856	Pre-Cleaner As	361-1717

2ZN		
Original Part Number	Part Name	Classic Part Number
133-3919	Gasket Kit-Sch	393-1031
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
146-9733	Muffler As	435-6045
151-5911	Manifold As.-Exh	441-5604
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
170-8714	Disc-Friction	456-9193
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
222-0458	Muffler As	393-0929

2ZN		
Original Part Number	Part Name	Classic Part Number
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
255-2899	Pipe As-Tail	301-5246
268-5569	Pin As	415-1905
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

BBX		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2W-7213	Bearing-Sleeve	419-4667
3G-2580	Bearing-Sleeve	422-9526
3J-9511	Bearing-Sleeve	385-3782
3W-5159	Plate-Parking Bk	391-9904
3W-7559	Pin As	419-4731
3W-8409	Bearing	398-8336
4T-8054	Seal As	472-8010
4W-2042	Spacer	325-6217
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
6P-0593	Bearing-Roller	386-4959
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

BBX		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-6461	Crown	325-6054
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7P-2372	Joint As	367-6072
7P-3466	Bearing-Sleeve	422-9523
7P-6596	Bearing-Sleeve	295-6409
7P-6984	Pin	393-3674
7P-7245	Valve	386-3811
7T-2036	Cap As-Fuel	361-1721
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8D-0983	Mounting	384-3470
8E-5450	Seal-Ebar	325-6190
8G-0935	Cap	425-3584
8G-4022	Bearing	422-6920
8G-4027	Pin As	393-3677

BBX		
Original Part Number	Part Name	Classic Part Number
8G-8331	Pin As	443-2971
8J-5778	Bearing-Sleeve	374-8359
8Y-1853	Strip	428-7633
9G-9086	Bearing-Sleeve	416-5528
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
121-7746	Pre-Cleaner As	360-2311
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
170-8714	Disc-Friction	456-9193
208-0421	Muffler As	360-9624
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870

Track Loaders

Sales Model 953C (Cont'd.)

BBX		
Original Part Number	**Part Name**	**Classic Part Number**
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

BBX		
Original Part Number	**Part Name**	**Classic Part Number**
255-2899	Pipe As-Tail	301-5246
268-5569	Pin As	415-1905
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
275-0120	Pin As	419-7245

BBX		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 953D

LBP		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
2B-0941	Spacer	418-1955
3G-2580	Bearing-Sleeve	422-9526
3J-9511	Bearing-Sleeve	385-3782
3P-1210	Cone-Roller Brg	399-4433
3W-5159	Plate-Parking Bk	391-9904
3W-7559	Pin As	419-4731
3W-8409	Bearing	398-8336
4T-8054	Seal As	472-8010
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442

LBP		
Original Part Number	**Part Name**	**Classic Part Number**
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-6461	Crown	325-6054
7P-3466	Bearing-Sleeve	422-9523
7P-6596	Bearing-Sleeve	295-6409
7P-6984	Pin	393-3674
7P-7245	Valve	386-3811
8E-5450	Seal-Ebar	325-6190
8G-0935	Cap	425-3584
8G-4022	Bearing	422-6920
8G-4027	Pin As	393-3677
8G-8331	Pin As	443-2971
8Y-1853	Strip	428-7633
9F-3212	Bearing-Ball	384-5953

LBP		
Original Part Number	**Part Name**	**Classic Part Number**
9G-9086	Bearing-Sleeve	416-5528
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-9930	Mount As	295-6437
170-8714	Disc-Friction	456-9193
223-3095	Gauge As	360-2295
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658
268-5569	Pin As	415-1905
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 953K

LJT		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
2B-0941	Spacer	418-1955
3W-5159	Plate-Parking Bk	391-9904
3W-7559	Pin As	419-4731
3W-8409	Bearing	398-8336
6V-0327	Cup-Rlr Brg	399-4444

LJT		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0328	Cone-Rlr Brg	399-4442
6Y-9960	Mount As.	376-3639
7J-3216	Bearing	368-0104
7J-6461	Crown	325-6054
7P-6596	Bearing-Sleeve	295-6409
7P-6984	Pin	393-3674
7P-7245	Valve	386-3811
8E-5450	Seal-Ebar	325-6190

LJT		
Original Part Number	**Part Name**	**Classic Part Number**
8G-0935	Cap	425-3584
8Y-1853	Strip	428-7633
9G-9086	Bearing-Sleeve	416-5528
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355

Sales Model 953K (Cont'd.)

LJT		
Original Part Number	Part Name	Classic Part Number
170-8714	Disc-Friction	456-9193
176-3900	Accumulator	416-5513

LJT		
Original Part Number	Part Name	Classic Part Number
235-9832	Head	419-4658
289-2935	Seal As-Buffer	472-8028

LJT		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 955H

60A		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1M-0090	Gasket-Manifold	445-7701
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-8776	Bearing-Roller	417-4516
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-1888	Bracket-Lamp	297-7147
1S-6422	Pilot As-Spring	226-4849
1S-9670	Univ Jt As	443-2017
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1W-7074	Kit-Rebuild-Pump	419-4712
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2B-8824	Drum	216-7817
2D-6421	Bearing-Outer	417-4510
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2K-4502	Bearing-Sleeve	299-1986

60A		
Original Part Number	Part Name	Classic Part Number
2K-4513	Bearing-Sleeve	308-9814
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-2811	Race-Spl Rlr Brg	417-4528
2P-7622	Bolt-Spring	226-4850
2S-1477	Holder As-Cage	226-7985
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934
2S-6150	Cover-Pulley	428-8817
3B-3967	Race-Roller Brg	386-4947
3F-1972	Retainer As	226-7988
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3S-5017	Elbow-Exhaust	369-9498
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4F-5004	Spring As-Arm	383-2128
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4K-1328	Drum-Ster Cl Dr	216-7840
4K-4780	Strip As-Wear	299-2063
4S-5367	Mount As	375-9986
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441

60A		
Original Part Number	Part Name	Classic Part Number
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5K-2294	Bearing	396-9912
5K-7995	Bearing-Sleeve	308-9820
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5M-2824	Coupling-Exhaust	431-5270
5M-5856	Pipe-Extension	373-1913
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7G-6044	Cage As	216-7857
7H-2424	Sleeve-Spring	226-4852
7J-9682	Bearing-Sleeve	360-2335
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4358	Manifold-Exhaust	261-0907
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774

Sales Model 955H (Cont'd.)

60A		
Original Part Number	**Part Name**	**Classic Part Number**
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8B-5972	Bearing-Ball	314-8503
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-5587	Rod Gp-Recoil	226-4954
8M-6676	Cylinder-Adj	226-4960
8N-8220	Bearing-Conn Rod	377-5860

60A		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-3517	Bearing-Spl Ball	417-4501
8S-9686	Gasket Kit	393-5215
9F-3212	Bearing-Ball	384-5953
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891

60A		
Original Part Number	**Part Name**	**Classic Part Number**
9H-7670	Piston	226-4961
9M-4955	Pump Gp-F Tfr	242-3443
9M-5477	Bearing-Sleeve	374-6517
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-9696	Spider As-Fan	383-3707
9W-1677	Bearing	297-7145
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
160-6306	Cap-Bearing	325-6038
226-8202	Seal-Wiper	472-8024
230-7112	Ster Cl Kit-Cla	216-7840
232-3233	Bearing-Main	376-9085
308-1845	Seal-Wiper	472-8032

93A		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1W-7074	Kit-Rebuild-Pump	419-4712

93A		
Original Part Number	**Part Name**	**Classic Part Number**
2L-5271	Bearing-Ball	371-4305
121-7746	Pre-Cleaner As	360-2311

Sales Model 955K

31J		
Original Part Number	**Part Name**	**Classic Part Number**
1S-3743	Bearing-Ball	384-4786
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-0969	Bearing-Sleeve	453-6497
1W-7074	Kit-Rebuild-Pump	419-4712
2L-5271	Bearing-Ball	371-4305

31J		
Original Part Number	**Part Name**	**Classic Part Number**
2S-7931	Bearing-Sleeve	387-2904
3B-3967	Race-Roller Brg	386-4947
4S-8538	Bearing-Spl Ball	417-4502
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5K-8591	Bearing-Outer	380-7502
5M-2051	Bearing-Caged	380-7467

31J		
Original Part Number	**Part Name**	**Classic Part Number**
5S-4557	Bearing	311-9360
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6Y-3484	Bearing-Spl Ball	416-2166
7F-2742	Bearing-Ball	422-6488
9M-4370	Bearing-Sleeve	453-6515
237-2859	Bearing-Rlr	368-0125

Sales Model 955K (Cont'd.)

48H		
Original Part Number	**Part Name**	**Classic Part Number**
1S-3743	Bearing-Ball	384-4786
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-0969	Bearing-Sleeve	453-6497
2S-7931	Bearing-Sleeve	387-2904

48H		
Original Part Number	**Part Name**	**Classic Part Number**
3B-3967	Race-Roller Brg	386-4947
4S-8538	Bearing-Spl Ball	417-4502
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5K-8591	Bearing-Outer	380-7502
5M-2051	Bearing-Caged	380-7467

48H		
Original Part Number	**Part Name**	**Classic Part Number**
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6Y-3484	Bearing-Spl Ball	416-2166
7F-2742	Bearing-Ball	422-6488
9M-4370	Bearing-Sleeve	453-6515
237-2859	Bearing-Rlr	368-0125

53H		
Original Part Number	**Part Name**	**Classic Part Number**
1S-3743	Bearing-Ball	384-4786
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326

53H		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0969	Bearing-Sleeve	453-6497
2S-7931	Bearing-Sleeve	387-2904
4S-8538	Bearing-Spl Ball	417-4502
5M-2051	Bearing-Caged	380-7467

53H		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-3484	Bearing-Spl Ball	416-2166
7F-2742	Bearing-Ball	422-6488
9M-4370	Bearing-Sleeve	453-6515
237-2859	Bearing-Rlr	368-0125

57J		
Original Part Number	**Part Name**	**Classic Part Number**
1S-3743	Bearing-Ball	384-4786
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326

57J		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0969	Bearing-Sleeve	453-6497
2S-7931	Bearing-Sleeve	387-2904
4S-8538	Bearing-Spl Ball	417-4502
5M-2051	Bearing-Caged	380-7467

57J		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-3484	Bearing-Spl Ball	416-2166
7F-2742	Bearing-Ball	422-6488
9M-4370	Bearing-Sleeve	453-6515
237-2859	Bearing-Rlr	368-0125

61H		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1J-6746	Pin	256-4817
1J-6749	Screw-Adj	256-4824
1M-0090	Gasket-Manifold	445-7701
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913

61H		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-3743	Bearing-Ball	384-4786
1S-6422	Pilot As-Spring	226-4849
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-0969	Bearing-Sleeve	453-6497

61H		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1331	Stator-Converter	229-8237
1W-7074	Kit-Rebuild-Pump	419-4712
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817
2D-6421	Bearing-Outer	417-4510
2J-8489	Bearing-Sleeve	295-5691

Sales Model 955K (Cont'd.)

61H		
Original Part Number	**Part Name**	**Classic Part Number**
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-5081	Muffler As	360-7872
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-7931	Bearing-Sleeve	387-2904
3B-3967	Race-Roller Brg	386-4947
3F-6185	Pin	295-5694
3H-8726	Mount As	385-7208
3P-3623	Lock-Adj Nut	226-7989
3P-5955	Disc-Friction	428-7205
3S-3875	Screen-Suction	435-4849
3S-5017	Elbow-Exhaust	369-9498
4D-4065	Rod End-Spher	374-1824
4F-5004	Spring As-Arm	383-2128
4K-1328	Drum-Ster Cl Dr	216-7840
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4K-4780	Strip As-Wear	299-2063
4S-5367	Mount As	375-9986
4S-5943	Piston-Clutch	221-9112
4S-8530	Shaft-Planet	221-9111
4S-8534	Shaft As-Planet	221-9116
4S-8538	Bearing-Spl Ball	417-4502
4T-1893	Cartridge Gp	422-8110
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441

61H		
Original Part Number	**Part Name**	**Classic Part Number**
5F-7993	Pin	319-3454
5H-7071	Director-Water	388-0555
5K-2294	Bearing	396-9912
5K-8591	Bearing-Outer	380-7502
5K-8628	Cage	449-4732
5M-2051	Bearing-Caged	380-7467
5M-5856	Pipe-Extension	373-1913
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1822	Chamber As	248-5406
5S-4557	Bearing	311-9360
5S-6978	Shaft-Planet	221-9103
5S-7010	Shaft-Planet	221-9104
5S-7893	Joint-Drive	380-7387
5S-7894	Flange As	216-7854
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6J-2326	Pin	319-3458
6J-6604	Pin	419-6071
6J-7500	Retainer	383-2104
6J-7563	Pin	319-3459
6K-4442	Rod End-Special	373-5388
6K-8088	Bearing-Roller	399-4428
6K-8895	Cap	374-6500
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
6Y-2027	Disc-Friction	377-7441
6Y-3484	Bearing-Spl Ball	416-2166
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7G-2487	Gear-Planet	221-9092
7J-9346	Bearing-Sleeve	374-8357
7J-9708	Bearing-Sleeve	299-1964
7K-1127	Nut-Adjusting	451-0744
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9506	Pin	241-2584
7K-9515	Pin	241-2589

61H		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9640	Bearing-Sleeve	389-6328
7K-9642	Bearing-Sleeve	360-2340
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4358	Manifold-Exhaust	261-0907
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7N-0128	Core As-Oil Clr	299-1994
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-8117	Muffler As	247-2668
7N-9146	Gear-Fly Starter	279-4995
7S-1234	Bushing As-Spt	394-0192
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7T-2036	Cap As-Fuel	361-1721
7T-4971	Cap-Bearing	428-8816
7W-1927	Ring-Retainer	387-2935
8B-5972	Bearing-Ball	314-8503
8G-1682	Pin	241-2585
8H-9789	Bearing-Ball	374-8342
8J-7978	Bearing-Spher	388-0581
8M-6676	Cylinder-Adj	226-4960
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1656	Plate-Clutch	367-6071
8S-2809	Muffler	247-2677
8S-9686	Gasket Kit	393-5215
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891

Sales Model 955K (Cont'd.)

61H		
Original Part Number	**Part Name**	**Classic Part Number**
9H-7670	Piston	226-4961
9J-5048	Pump Gp-Vn Bsc-A	422-8166
9M-4370	Bearing-Sleeve	453-6515
9M-4955	Pump Gp-F Tfr	242-3443
9M-5477	Bearing-Sleeve	374-6517
9S-1768	Pipe-Ext Exhaust	380-7544

61H		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-9696	Spider As-Fan	383-3707
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
230-7112	Ster Cl Kit-Cla	216-7840

61H		
Original Part Number	**Part Name**	**Classic Part Number**
232-3233	Bearing-Main	376-9085
235-1806	Tc Kit-Cla	229-8237
237-2859	Bearing-Rlr	368-0125
247-2670	Muffler-Classic	247-2675
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

64J		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1J-6746	Pin	256-4817
1J-6749	Screw-Adj	256-4824
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-6422	Pilot As-Spring	226-4849
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-0969	Bearing-Sleeve	453-6497
1T-1331	Stator-Converter	229-8237
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513

64J		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817
2D-6421	Bearing-Outer	417-4510
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-5081	Muffler As	360-7872
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
3B-3967	Race-Roller Brg	386-4947
3F-6185	Pin	295-5694
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3P-3623	Lock-Adj Nut	226-7989
3P-5955	Disc-Friction	428-7205
3S-3875	Screen-Suction	435-4849

64J		
Original Part Number	**Part Name**	**Classic Part Number**
4D-4065	Rod End-Spher	374-1824
4F-5004	Spring As-Arm	383-2128
4K-1328	Drum-Ster Cl Dr	216-7840
4K-4780	Strip As-Wear	299-2063
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-5943	Piston-Clutch	221-9112
4S-8530	Shaft-Planet	221-9111
4S-8534	Shaft As-Planet	221-9116
4S-8538	Bearing-Spl Ball	417-4502
4T-1893	Cartridge Gp	422-8110
4W-0452	Seal As -Cshaft	325-6191
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-7993	Pin	319-3454
5K-2294	Bearing	396-9912
5K-8591	Bearing-Outer	380-7502
5K-8628	Cage	449-4732
5L-6326	Bearing-Ball	420-3222
5M-2051	Bearing-Caged	380-7467
5P-8768	Kit-Gasket (Scl)	393-1024

Sales Model 955K (Cont'd.)

64J		
Original Part Number	**Part Name**	**Classic Part Number**
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-6978	Shaft-Planet	221-9103
5S-7010	Shaft-Planet	221-9104
5S-7630	Bearing-Sleeve	394-0219
5S-7893	Joint-Drive	380-7387
5S-7894	Flange As	216-7854
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-2326	Pin	319-3458
6J-6604	Pin	419-6071
6J-7500	Retainer	383-2104
6J-7563	Pin	319-3459
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6V-0600	Gasket Kit	437-4583
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
6V-2466	Kit-Gasket-Fs	437-3211
6Y-2027	Disc-Friction	377-7441
6Y-3484	Bearing-Spl Ball	416-2166
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7G-2487	Gear-Planet	221-9092

64J		
Original Part Number	**Part Name**	**Classic Part Number**
7J-9346	Bearing-Sleeve	374-8357
7K-1127	Nut-Adjusting	451-0744
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9506	Pin	241-2584
7K-9515	Pin	241-2589
7K-9642	Bearing-Sleeve	360-2340
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-8117	Muffler As	247-2668
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7T-2036	Cap As-Fuel	361-1721
7T-4971	Cap-Bearing	428-8816
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8F-6058	Bearing-Sleeve	416-5494
8G-1682	Pin	241-2585
8H-9789	Bearing-Ball	374-8342
8J-7978	Bearing-Spher	388-0581
8K-9661	Gear-Bevel	213-8218
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037

64J		
Original Part Number	**Part Name**	**Classic Part Number**
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1656	Plate-Clutch	367-6071
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372

Sales Model 955K (Cont'd.)

64J		
Original Part Number	**Part Name**	**Classic Part Number**
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-5048	Pump Gp-Vn Bsc-A	422-8166
9M-4370	Bearing-Sleeve	453-6515
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891

64J		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7788	Ring-Piston	461-5124
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202

64J		
Original Part Number	**Part Name**	**Classic Part Number**
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7112	Ster Cl Kit-Cla	216-7840
232-3233	Bearing-Main	376-9085
235-1806	Tc Kit-Cla	229-8237
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
247-2670	Muffler-Classic	247-2675
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

71J		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1S-3743	Bearing-Ball	384-4786
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-0969	Bearing-Sleeve	453-6497
1W-3900	Gasket	472-8006
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2S-7931	Bearing-Sleeve	387-2904
3B-3967	Race-Roller Brg	386-4947
4K-4780	Strip As-Wear	299-2063
4N-7692	Crankshaft As	269-8764

71J		
Original Part Number	**Part Name**	**Classic Part Number**
4S-8538	Bearing-Spl Ball	417-4502
4W-0452	Seal As -Cshaft	325-6191
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5G-3612	Cap Gp-Protn	295-6419
5K-8591	Bearing-Outer	380-7502
5M-2051	Bearing-Caged	380-7467
5P-8768	Kit-Gasket (Scl)	393-1024
5S-4557	Bearing	311-9360
6H-3957	Bearing-Ball	311-9358
6V-0600	Gasket Kit	437-4583
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2466	Kit-Gasket-Fs	437-3211
6Y-3484	Bearing-Spl Ball	416-2166

71J		
Original Part Number	**Part Name**	**Classic Part Number**
7F-2742	Bearing-Ball	422-6488
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
8H-9789	Bearing-Ball	374-8342
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
9G-8302	Guide	226-4853
9M-4370	Bearing-Sleeve	453-6515
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
170-0558	Kit-Rebuild-Pump	390-1001

Sales Model 955K (Cont'd.)

71J		
Original Part Number	**Part Name**	**Classic Part Number**
172-5188	Shaft-Water Pump	325-6202

71J		
Original Part Number	**Part Name**	**Classic Part Number**
172-6712	Impeller-Pump	325-6112

71J		
Original Part Number	**Part Name**	**Classic Part Number**
237-2859	Bearing-Rlr	368-0125

85J		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1J-6746	Pin	256-4817
1J-6749	Screw-Adj	256-4824
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1N-3574	Block Gp-Cyl	460-8298
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-0963	Guard As-Roller	226-0179
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-5331	Cylinder-Adj	226-0214
1S-6422	Pilot As-Spring	226-4849
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-0969	Bearing-Sleeve	453-6497
1T-1331	Stator-Converter	229-8237
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513

85J		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817
2D-6421	Bearing-Outer	417-4510
2F-5721	Bearing-Ball	311-9354
2J-8489	Bearing-Sleeve	295-5691
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2744	Muffler As.	247-2664
2P-5081	Muffler As	360-7872
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2S-5551	Coupling-Exhaust	398-2934
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203

85J		
Original Part Number	**Part Name**	**Classic Part Number**
2W-9978	Core As-Oclr	279-4983
3B-3967	Race-Roller Brg	386-4947
3F-6185	Pin	295-5694
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3P-3623	Lock-Adj Nut	226-7989
3P-5955	Disc-Friction	428-7205
3S-3875	Screen-Suction	435-4849
4D-4065	Rod End-Spher	374-1824
4F-5004	Spring As-Arm	383-2128
4K-1328	Drum-Ster Cl Dr	216-7840
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4K-4780	Strip As-Wear	299-2063
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710

Sales Model 955K (Cont'd.)

85J		
Original Part Number	Part Name	Classic Part Number
4N-8204	Mount As	374-1449
4N-8344	Spider As-Fan	416-5520
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-5943	Piston-Clutch	221-9112
4S-8530	Shaft-Planet	221-9111
4S-8534	Shaft As-Planet	221-9116
4S-8538	Bearing-Spl Ball	417-4502
4T-1893	Cartridge Gp	422-8110
4W-0452	Seal As -Cshaft	325-6191
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-7993	Pin	319-3454
5G-3612	Cap Gp-Protn	295-6419
5K-2294	Bearing	396-9912
5K-8591	Bearing-Outer	380-7502
5K-8628	Cage	449-4732
5L-6326	Bearing-Ball	420-3222
5M-2051	Bearing-Caged	380-7467
5M-5856	Pipe-Extension	373-1913
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-6978	Shaft-Planet	221-9103
5S-7010	Shaft-Planet	221-9104
5S-7630	Bearing-Sleeve	394-0219
5S-7893	Joint-Drive	380-7387
5S-7894	Flange As	216-7854
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918

85J		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-2326	Pin	319-3458
6J-6604	Pin	419-6071
6J-7500	Retainer	383-2104
6J-7563	Pin	319-3459
6K-4442	Rod End-Special	373-5388
6K-8088	Bearing-Roller	399-4428
6K-8895	Cap	374-6500
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6V-0600	Gasket Kit	437-4583
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
6V-2246	Gasket Kit	391-1091
6V-2466	Kit-Gasket-Fs	437-3211
6Y-2027	Disc-Friction	377-7441
6Y-3484	Bearing-Spl Ball	416-2166
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7G-2487	Gear-Planet	221-9092
7J-9346	Bearing-Sleeve	374-8357
7J-9708	Bearing-Sleeve	299-1964
7K-1127	Nut-Adjusting	451-0744
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9506	Pin	241-2584

85J		
Original Part Number	Part Name	Classic Part Number
7K-9515	Pin	241-2589
7K-9640	Bearing-Sleeve	389-6328
7K-9642	Bearing-Sleeve	360-2340
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-8117	Muffler As	247-2668
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656

Sales Model 955K (Cont'd.)

85J		
Original Part Number	**Part Name**	**Classic Part Number**
7S-7070	Head As-Cylinder	325-6107
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7T-4971	Cap-Bearing	428-8816
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8B-5972	Bearing-Ball	314-8503
8F-6058	Bearing-Sleeve	416-5494
8G-1682	Pin	241-2585
8H-7980	Piston	226-0249
8H-9789	Bearing-Ball	374-8342
8J-7978	Bearing-Spher	388-0581
8K-9661	Gear-Bevel	213-8218
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623

85J		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1656	Plate-Clutch	367-6071
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
8S-9698	Gasket Kit	393-5221
9B-1320	Valve-Check	377-5832
9G-8302	Guide	226-4853
9G-8303	Collar-Idler End	226-0242
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-5048	Pump Gp-Vn Bsc-A	422-8166
9M-4370	Bearing-Sleeve	453-6515
9M-4789	Shaft-Gov Cont	297-7256

85J		
Original Part Number	**Part Name**	**Classic Part Number**
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-8711	Elbow-Exhaust	383-3709
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
169-1750	Seal Gp-Basic	472-8022
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314

Sales Model 955K (Cont'd.)

85J		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7112	Ster Cl Kit-Cla	216-7840
232-3233	Bearing-Main	376-9085
235-1806	Tc Kit-Cla	229-8237
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6892

85J		
Original Part Number	Part Name	Classic Part Number
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357

85J		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

Sales Model 955L

08Y		
Original Part Number	Part Name	Classic Part Number
1S-3743	Bearing-Ball	384-4786
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-0969	Bearing-Sleeve	453-6497
1W-3900	Gasket	472-8006
2P-0220	Gasket-Pump	398-2927
2S-7931	Bearing-Sleeve	387-2904
3B-3967	Race-Roller Brg	386-4947
4P-8915	Gasket-Cyl Head	377-5838

08Y		
Original Part Number	Part Name	Classic Part Number
4S-8538	Bearing-Spl Ball	417-4502
4W-0452	Seal As -Cshaft	325-6191
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5K-8591	Bearing-Outer	380-7502
5M-2051	Bearing-Caged	380-7467
5P-8768	Kit-Gasket (Scl)	393-1024
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173

08Y		
Original Part Number	Part Name	Classic Part Number
6V-2209	Gasket Kit	419-4732
6Y-3484	Bearing-Spl Ball	416-2166
7F-2742	Bearing-Ball	422-6488
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8022	Gasket-Cyl Head	378-3985
9M-4370	Bearing-Sleeve	453-6515
9Y-1798	Seal-Water	379-0165
131-3815	Seal Gp-Basic	325-6193
237-2859	Bearing-Rlr	368-0125

13X		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1J-6746	Pin	256-4817
1J-6749	Screw-Adj	256-4824
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-0963	Guard As-Roller	226-0179

13X		
Original Part Number	Part Name	Classic Part Number
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-5331	Cylinder-Adj	226-0214
1T-0737	Race-Spl Thrust	384-4798

13X		
Original Part Number	Part Name	Classic Part Number
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-0969	Bearing-Sleeve	453-6497
1T-1331	Stator-Converter	229-8237
1W-1219	Trunnion As	314-8724
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716

Sales Model 955L (Cont'd.)

13X		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2744	Muffler As.	247-2664
2P-5081	Muffler As	360-7872
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3B-3967	Race-Roller Brg	386-4947

13X		
Original Part Number	Part Name	Classic Part Number
3F-6185	Pin	295-5694
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3P-5955	Disc-Friction	428-7205
3S-3875	Screen-Suction	435-4849
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-5004	Spring As-Arm	383-2128
4K-1328	Drum-Ster Cl Dr	216-7840
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8204	Mount As	374-1449
4N-8344	Spider As-Fan	416-5520
4P-3546	Valve As-Relief	325-6236
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4S-5943	Piston-Clutch	221-9112
4S-8530	Shaft-Planet	221-9111

13X		
Original Part Number	Part Name	Classic Part Number
4S-8534	Shaft As-Planet	221-9116
4S-8538	Bearing-Spl Ball	417-4502
4T-1893	Cartridge Gp	422-8110
4W-0452	Seal As -Cshaft	325-6191
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-7993	Pin	319-3454
5G-3612	Cap Gp-Protn	295-6419
5K-2294	Bearing	396-9912
5K-8591	Bearing-Outer	380-7502
5K-8628	Cage	449-4732
5L-6326	Bearing-Ball	420-3222
5M-2051	Bearing-Caged	380-7467
5M-5856	Pipe-Extension	373-1913
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-6978	Shaft-Planet	221-9103
5S-7010	Shaft-Planet	221-9104
5S-7630	Bearing-Sleeve	394-0219
5S-7893	Joint-Drive	380-7387
5S-7894	Flange As	216-7854
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-2326	Pin	319-3458
6J-6604	Pin	419-6071

Sales Model 955L (Cont'd.)

13X		
Original Part Number	Part Name	Classic Part Number
6J-7500	Retainer	383-2104
6J-7563	Pin	319-3459
6K-4442	Rod End-Special	373-5388
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6Y-2027	Disc-Friction	377-7441
6Y-3484	Bearing-Spl Ball	416-2166
6Y-7914	Disc-Friction	390-5264
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-5085	Bushing	377-5829
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2487	Gear-Planet	221-9092
7J-9346	Bearing-Sleeve	374-8357
7J-9708	Bearing-Sleeve	299-1964
7K-2135	Bearing-Roller	417-4492
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9515	Pin	241-2589
7K-9642	Bearing-Sleeve	360-2340
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228

13X		
Original Part Number	Part Name	Classic Part Number
7M-1862	Stop-Spring Lh	226-0229
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-8117	Muffler As	247-2668
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7T-4971	Cap-Bearing	428-8816
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042

13X		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8F-6058	Bearing-Sleeve	416-5494
8G-1682	Pin	241-2585
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-9789	Bearing-Ball	374-8342
8J-7978	Bearing-Spher	388-0581
8K-9661	Gear-Bevel	213-8218
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585

Sales Model 955L (Cont'd.)

13X		
Original Part Number	Part Name	Classic Part Number
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1656	Plate-Clutch	367-6071
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9G-8303	Collar-Idler End	226-0242
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-5048	Pump Gp-Vn Bsc-A	422-8166
9L-2685	Rod End	419-1866
9M-3025	Cover As	299-2001
9M-4370	Bearing-Sleeve	453-6515
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517

13X		
Original Part Number	Part Name	Classic Part Number
9M-6692	Strip	386-4934
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001

13X		
Original Part Number	Part Name	Classic Part Number
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7112	Ster Cl Kit-Cla	216-7840
232-3233	Bearing-Main	376-9085
235-1806	Tc Kit-Cla	229-8237
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

57J		
Original Part Number	Part Name	Classic Part Number
1S-3743	Bearing-Ball	384-4786
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108

57J		
Original Part Number	Part Name	Classic Part Number
1T-0902	Bearing-Sleeve	389-6326
1T-0969	Bearing-Sleeve	453-6497

57J		
Original Part Number	Part Name	Classic Part Number
2S-7931	Bearing-Sleeve	387-2904
4S-8538	Bearing-Spl Ball	417-4502
5M-2051	Bearing-Caged	380-7467

Sales Model 955L (Cont'd.)

57J		
Original Part Number	Part Name	Classic Part Number
6Y-3484	Bearing-Spl Ball	416-2166

57J		
Original Part Number	Part Name	Classic Part Number
7F-2742	Bearing-Ball	422-6488
9M-4370	Bearing-Sleeve	453-6515

57J		
Original Part Number	Part Name	Classic Part Number
237-2859	Bearing-Rlr	368-0125

57M		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-5331	Cylinder-Adj	226-0214
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-0969	Bearing-Sleeve	453-6497
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-5081	Muffler As	360-7872
2P-6245	Shaft As-Pump	325-6197
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
3B-3967	Race-Roller Brg	386-4947
4F-5004	Spring As-Arm	383-2128
4J-2414	Trunnion	296-1370
4N-7692	Crankshaft As	269-8764
4P-3546	Valve As-Relief	325-6236

57M		
Original Part Number	Part Name	Classic Part Number
4P-8915	Gasket-Cyl Head	377-5838
4S-8538	Bearing-Spl Ball	417-4502
4W-0452	Seal As -Cshaft	325-6191
5D-7449	Cup-Spl Tapered	416-2161
5F-0736	Pin-Pivot	256-4823
5F-1248	Cone-Roller Brg	399-4441
5G-3612	Cap Gp-Protn	295-6419
5K-8591	Bearing-Outer	380-7502
5M-2051	Bearing-Caged	380-7467
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6I-1345	Shaft As-O Pump	374-7475
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-0600	Gasket Kit	437-4583
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6V-2466	Kit-Gasket-Fs	437-3211
6Y-3484	Bearing-Spl Ball	416-2166

57M		
Original Part Number	Part Name	Classic Part Number
7C-3862	Camshaft	458-0151
7F-2742	Bearing-Ball	422-6488
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-4046	Bearing-Sleeve	394-8206
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-8117	Muffler As	247-2668
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-8443	Muffler	247-2675
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
8H-7980	Piston	226-0249
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200

Sales Model 955L (Cont'd.)

57M		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0493	Shaft As-Pump	325-6198
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372

57M		
Original Part Number	**Part Name**	**Classic Part Number**
9G-8303	Collar-Idler End	226-0242
9M-4370	Bearing-Sleeve	453-6515
9M-6692	Strip	386-4934
9S-1768	Pipe-Ext Exhaust	380-7544
9S-7788	Ring-Piston	461-5124
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351

57M		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
170-7502	Shaft-Dr Idler	374-7484
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
247-2670	Muffler-Classic	247-2675
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

64J		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1J-6746	Pin	256-4817
1J-6749	Screw-Adj	256-4824
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-6422	Pilot As-Spring	226-4849

64J		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-0969	Bearing-Sleeve	453-6497
1T-1331	Stator-Converter	229-8237
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817
2D-6421	Bearing-Outer	417-4510
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532

64J		
Original Part Number	**Part Name**	**Classic Part Number**
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-5081	Muffler As	360-7872
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
3B-3967	Race-Roller Brg	386-4947

Sales Model 955L (Cont'd.)

64J		
Original Part Number	Part Name	Classic Part Number
3F-6185	Pin	295-5694
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3P-3623	Lock-Adj Nut	226-7989
3P-5955	Disc-Friction	428-7205
3S-3875	Screen-Suction	435-4849
4D-4065	Rod End-Spher	374-1824
4F-5004	Spring As-Arm	383-2128
4K-1328	Drum-Ster Cl Dr	216-7840
4K-4780	Strip As-Wear	299-2063
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-5943	Piston-Clutch	221-9112
4S-8530	Shaft-Planet	221-9111
4S-8534	Shaft As-Planet	221-9116
4S-8538	Bearing-Spl Ball	417-4502
4T-1893	Cartridge Gp	422-8110
4W-0452	Seal As -Cshaft	325-6191
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-7993	Pin	319-3454
5K-2294	Bearing	396-9912
5K-8591	Bearing-Outer	380-7502
5K-8628	Cage	449-4732
5L-6326	Bearing-Ball	420-3222
5M-2051	Bearing-Caged	380-7467
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

64J		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-6978	Shaft-Planet	221-9103
5S-7010	Shaft-Planet	221-9104
5S-7630	Bearing-Sleeve	394-0219
5S-7893	Joint-Drive	380-7387
5S-7894	Flange As	216-7854
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-2326	Pin	319-3458
6J-6604	Pin	419-6071
6J-7500	Retainer	383-2104
6J-7563	Pin	319-3459
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6V-0600	Gasket Kit	437-4583
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
6V-2466	Kit-Gasket-Fs	437-3211
6Y-2027	Disc-Friction	377-7441
6Y-3484	Bearing-Spl Ball	416-2166
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7G-2487	Gear-Planet	221-9092
7J-9346	Bearing-Sleeve	374-8357
7K-1127	Nut-Adjusting	451-0744
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9506	Pin	241-2584

64J		
Original Part Number	Part Name	Classic Part Number
7K-9515	Pin	241-2589
7K-9642	Bearing-Sleeve	360-2340
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-8117	Muffler As	247-2668
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7T-2036	Cap As-Fuel	361-1721
7T-4971	Cap-Bearing	428-8816
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8F-6058	Bearing-Sleeve	416-5494
8G-1682	Pin	241-2585
8H-9789	Bearing-Ball	374-8342
8J-7978	Bearing-Spher	388-0581
8K-9661	Gear-Bevel	213-8218
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196

Sales Model 955L (Cont'd.)

64J		
Original Part Number	Part Name	Classic Part Number
8N-1984	Rod As-Conn	242-3441
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1656	Plate-Clutch	367-6071
8S-0248	Breather As	325-6033

64J		
Original Part Number	Part Name	Classic Part Number
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-5048	Pump Gp-Vn Bsc-A	422-8166
9M-4370	Bearing-Sleeve	453-6515
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360

64J		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7112	Ster Cl Kit-Cla	216-7840
232-3233	Bearing-Main	376-9085
235-1806	Tc Kit-Cla	229-8237
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

71J		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1S-3743	Bearing-Ball	384-4786
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-0969	Bearing-Sleeve	453-6497

71J		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2S-7931	Bearing-Sleeve	387-2904

71J		
Original Part Number	Part Name	Classic Part Number
3B-3967	Race-Roller Brg	386-4947
4K-4780	Strip As-Wear	299-2063
4N-7692	Crankshaft As	269-8764
4S-8538	Bearing-Spl Ball	417-4502
4W-0452	Seal As -Cshaft	325-6191
5D-7449	Cup-Spl Tapered	416-2161

Sales Model 955L (Cont'd.)

71J		
Original Part Number	**Part Name**	**Classic Part Number**
5F-1248	Cone-Roller Brg	399-4441
5G-3612	Cap Gp-Protn	295-6419
5K-8591	Bearing-Outer	380-7502
5M-2051	Bearing-Caged	380-7467
5P-8768	Kit-Gasket (Scl)	393-1024
5S-4557	Bearing	311-9360
6H-3957	Bearing-Ball	311-9358
6V-0600	Gasket Kit	437-4583
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2466	Kit-Gasket-Fs	437-3211

71J		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-3484	Bearing-Spl Ball	416-2166
7F-2742	Bearing-Ball	422-6488
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
8H-9789	Bearing-Ball	374-8342
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

71J		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
9G-8302	Guide	226-4853
9M-4370	Bearing-Sleeve	453-6515
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
170-0558	Kit-Rebuild-Pump	390-1001
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
237-2859	Bearing-Rlr	368-0125

85J		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1J-6746	Pin	256-4817
1J-6749	Screw-Adj	256-4824
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1N-3574	Block Gp-Cyl	460-8298
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-0963	Guard As-Roller	226-0179
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-5331	Cylinder-Adj	226-0214
1S-6422	Pilot As-Spring	226-4849
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108

85J		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0902	Bearing-Sleeve	389-6326
1T-0969	Bearing-Sleeve	453-6497
1T-1331	Stator-Converter	229-8237
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817
2D-6421	Bearing-Outer	417-4510
2F-5721	Bearing-Ball	311-9354
2J-8489	Bearing-Sleeve	295-5691
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867

85J		
Original Part Number	**Part Name**	**Classic Part Number**
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2744	Muffler As.	247-2664
2P-5081	Muffler As	360-7872
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2S-5551	Coupling-Exhaust	398-2934
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-9978	Core As-Oclr	279-4983

Sales Model 955L (Cont'd.)

85J		
Original Part Number	Part Name	Classic Part Number
3B-3967	Race-Roller Brg	386-4947
3F-6185	Pin	295-5694
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3P-3623	Lock-Adj Nut	226-7989
3P-5955	Disc-Friction	428-7205
3S-3875	Screen-Suction	435-4849
4D-4065	Rod End-Spher	374-1824
4F-5004	Spring As-Arm	383-2128
4K-1328	Drum-Ster Cl Dr	216-7840
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4K-4780	Strip As-Wear	299-2063
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8204	Mount As	374-1449
4N-8344	Spider As-Fan	416-5520
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-5943	Piston-Clutch	221-9112
4S-8530	Shaft-Planet	221-9111
4S-8534	Shaft As-Planet	221-9116

85J		
Original Part Number	Part Name	Classic Part Number
4S-8538	Bearing-Spl Ball	417-4502
4T-1893	Cartridge Gp	422-8110
4W-0452	Seal As -Cshaft	325-6191
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-7993	Pin	319-3454
5G-3612	Cap Gp-Protn	295-6419
5K-2294	Bearing	396-9912
5K-8591	Bearing-Outer	380-7502
5K-8628	Cage	449-4732
5L-6326	Bearing-Ball	420-3222
5M-2051	Bearing-Caged	380-7467
5M-5856	Pipe-Extension	373-1913
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-6978	Shaft-Planet	221-9103
5S-7010	Shaft-Planet	221-9104
5S-7630	Bearing-Sleeve	394-0219
5S-7893	Joint-Drive	380-7387
5S-7894	Flange As	216-7854
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-2326	Pin	319-3458
6J-6604	Pin	419-6071
6J-7500	Retainer	383-2104

85J		
Original Part Number	Part Name	Classic Part Number
6J-7563	Pin	319-3459
6K-4442	Rod End-Special	373-5388
6K-8088	Bearing-Roller	399-4428
6K-8895	Cap	374-6500
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6V-0600	Gasket Kit	437-4583
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
6V-2246	Gasket Kit	391-1091
6V-2466	Kit-Gasket-Fs	437-3211
6Y-2027	Disc-Friction	377-7441
6Y-3484	Bearing-Spl Ball	416-2166
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7G-2487	Gear-Planet	221-9092
7J-9346	Bearing-Sleeve	374-8357
7J-9708	Bearing-Sleeve	299-1964
7K-1127	Nut-Adjusting	451-0744
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9506	Pin	241-2584
7K-9515	Pin	241-2589
7K-9640	Bearing-Sleeve	389-6328
7K-9642	Bearing-Sleeve	360-2340
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327

Sales Model 955L (Cont'd.)

85J		
Original Part Number	Part Name	Classic Part Number
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-8117	Muffler As	247-2668
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7T-4971	Cap-Bearing	428-8816

85J		
Original Part Number	Part Name	Classic Part Number
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8B-5972	Bearing-Ball	314-8503
8F-6058	Bearing-Sleeve	416-5494
8G-1682	Pin	241-2585
8H-7980	Piston	226-0249
8H-9789	Bearing-Ball	374-8342
8J-7978	Bearing-Spher	388-0581
8K-9661	Gear-Bevel	213-8218
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585

85J		
Original Part Number	Part Name	Classic Part Number
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1656	Plate-Clutch	367-6071
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
8S-9698	Gasket Kit	393-5221
9B-1320	Valve-Check	377-5832
9G-8302	Guide	226-4853
9G-8303	Collar-Idler End	226-0242
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-5048	Pump Gp-Vn Bsc-A	422-8166
9M-4370	Bearing-Sleeve	453-6515
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

Sales Model 955L (Cont'd.)

85J		
Original Part Number	**Part Name**	**Classic Part Number**
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-8711	Elbow-Exhaust	383-3709
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351

85J		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
169-1750	Seal Gp-Basic	472-8022
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259

85J		
Original Part Number	**Part Name**	**Classic Part Number**
196-0029	Gear As-Idler	374-4674
230-7112	Ster Cl Kit-Cla	216-7840
232-3233	Bearing-Main	376-9085
235-1806	Tc Kit-Cla	229-8237
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

Sales Model 963

06Z		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344

06Z		
Original Part Number	**Part Name**	**Classic Part Number**
1P-2696	Cone-Bearing	374-1834
1P-4695	Cup-Rlr Bearing	374-1842
1P-4696	Cone-Rlr Bearing	374-1843
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1T-0299	Cup-Roller Brg	422-6494
1U-3953	Cartridge Gp	426-0024
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006

06Z		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2K-6413	Pin	360-2270

Sales Model 963 (Cont'd.)

06Z		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-0222	Bearing-Sleeve	374-6512
3G-5750	Bearing-Plate	419-4734
3G-6910	Bearing-Plate	419-4733
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3P-1459	Spring-Recoil	375-5448
3V-5257	Bracket-Carr Rlr	297-7149
3V-5317	Gear	231-0010
3W-0241	Pin As	393-3676
3W-2196	Housing As	396-0661
3W-2197	Plate As	416-5511
3W-5159	Plate-Parking Bk	391-9904
3W-5501	Gear-Planet	288-8719
3W-6144	Hub-Sprocket	396-7277
3W-8398	Bearing-Sleeve	379-0189
3W-8403	Sleeve	393-3673
3W-8406	Cap	416-5534
4E-7717	Shaft-Sprocket	432-6606

06Z		
Original Part Number	Part Name	Classic Part Number
4E-9426	Collar	231-0000
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-0998	Lever	314-8687
4T-1893	Cartridge Gp	422-8110
4T-4073	Valve Gp-Shtl -B	439-1138
4T-6869	Cartridge Gp	422-8104
4T-9311	Housing	396-0652
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4W-9989	Gear As-Idler	302-2677
5C-0857	Plate-Mating	376-3624
5C-1834	Gear	231-0002

06Z		
Original Part Number	Part Name	Classic Part Number
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5V-7222	Gear-Final Drive	231-0237
6C-0739	Carrier As	231-0012
6E-2929	Pump Gp-Vn Bsc-A	422-8157
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-5392	Manifold-Exhaust	394-0905
6N-7174	Shield-Oil	314-8544
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-7909	Disc-Friction	374-4676
6Y-7956	Disc-Friction	374-4677
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7J-2604	Bearing-Sleeve	380-7369

Sales Model 963 (Cont'd.)

06Z		
Original Part Number	Part Name	Classic Part Number
7J-8893	Cone-Roller Brg	374-1846
7J-9344	Bearing-Sleeve	360-2334
7J-9708	Bearing-Sleeve	299-1964
7K-2135	Bearing-Roller	417-4492
7K-8877	Cone-Bearing	374-1847
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-2957	Cover-Rad Cap	361-1722
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-4695	Tube	424-0860
7P-6348	Bearing	399-6042
7P-6596	Bearing-Sleeve	295-6409
7P-6768	Rod As	469-4670
7P-6770	Support As	389-6299
7P-6773	Pilot	470-3785
7P-7858	Bearing-Sleeve	374-8362
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7V-3719	Collet As	376-3644
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8D-2256	Cone-Roller Brg	374-1848
8G-4259	Bearing-Aligning	374-8341

06Z		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-0509	Plate-Mating	382-5053
8K-1754	Spacer	231-0247
8K-4850	Cage-Bearing	451-0745
8M-6191	Sleeve-Bolt	226-0234
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

06Z		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8T-1177	Bearing-Rlr	419-1862
8Y-0395	Pin As	393-3678
9J-8006	Piston	449-4736
9K-1171	Cup-Rlr Bearing	430-3339
9K-8423	Bearing-Sleeve	421-9043
9K-8757	Rod End-Special	311-9361
9L-6371	Rod-Eye	363-7459
9M-1853	Mount As.	376-3638
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9T-0486	Pump Gp-Vn Bsc-A	422-8144
9V-9408	Spring	425-9369
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
126-7134	Pipe As-Exhaust	451-9032
131-3815	Seal Gp-Basic	325-6193
131-6001	Pin As	376-3646

Sales Model 963 (Cont'd.)

06Z		
Original Part Number	**Part Name**	**Classic Part Number**
137-4097	Muffler As.	360-7866
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0564	Rebuild Kit-Pump	380-7576

06Z		
Original Part Number	**Part Name**	**Classic Part Number**
170-7502	Shaft-Dr Idler	374-7484
170-8714	Disc-Friction	456-9193
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-8009	Kit-Gasket-Sch	382-5056

06Z		
Original Part Number	**Part Name**	**Classic Part Number**
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

11Z		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-4695	Cup-Rlr Bearing	374-1842
1P-4696	Cone-Rlr Bearing	374-1843
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1U-3953	Cartridge Gp	426-0024
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716

11Z		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-3767	Tube-Disposal	377-5850

11Z		
Original Part Number	**Part Name**	**Classic Part Number**
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-0222	Bearing-Sleeve	374-6512
3G-5750	Bearing-Plate	419-4734
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3P-1459	Spring-Recoil	375-5448
3W-0241	Pin As	393-3676
3W-2196	Housing As	396-0661
3W-2197	Plate As	416-5511
3W-5159	Plate-Parking Bk	391-9904
3W-5501	Gear-Planet	288-8719
3W-6144	Hub-Sprocket	396-7277

Sales Model 963 (Cont'd.)

11Z		
Original Part Number	Part Name	Classic Part Number
3W-8160	Piston As	393-1051
3W-8177	Retainer	428-7634
3W-8339	Plate	397-5047
3W-8398	Bearing-Sleeve	379-0189
3W-8403	Sleeve	393-3673
3W-8406	Cap	416-5534
3W-8570	Bearing	416-2136
3W-8572	Pin As	393-3672
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-0998	Lever	314-8687
4T-1893	Cartridge Gp	422-8110
4T-4073	Valve Gp-Shtl -B	439-1138
4T-6869	Cartridge Gp	422-8104
4T-9311	Housing	396-0652
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529

11Z		
Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4W-9989	Gear As-Idler	302-2677
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6E-2929	Pump Gp-Vn Bsc-A	422-8157
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-5392	Manifold-Exhaust	394-0905
6N-7174	Shield-Oil	314-8544
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7J-2604	Bearing-Sleeve	380-7369
7J-8893	Cone-Roller Brg	374-1846

11Z		
Original Part Number	Part Name	Classic Part Number
7J-9344	Bearing-Sleeve	360-2334
7J-9708	Bearing-Sleeve	299-1964
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-2957	Cover-Rad Cap	361-1722
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-4695	Tube	424-0860
7P-6348	Bearing	399-6042
7P-6531	Shaft-Sun Gear	430-5352
7P-6596	Bearing-Sleeve	295-6409
7P-6768	Rod As	469-4670
7P-6770	Support As	389-6299
7P-6773	Pilot	470-3785
7P-7245	Valve	386-3811
7P-7858	Bearing-Sleeve	374-8362
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7V-3719	Collet As	376-3644
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8G-4259	Bearing-Aligning	374-8341
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037

Sales Model 963 (Cont'd.)

11Z		
Original Part Number	Part Name	Classic Part Number
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084

11Z		
Original Part Number	Part Name	Classic Part Number
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
8Y-0035	Yoke As	393-1057
8Y-0395	Pin As	393-3678
9J-8006	Piston	449-4736
9K-8423	Bearing-Sleeve	421-9043
9L-6371	Rod-Eye	363-7459
9M-1853	Mount As.	376-3638
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9T-0486	Pump Gp-Vn Bsc-A	422-8144
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
126-7134	Pipe As-Exhaust	451-9032
131-3815	Seal Gp-Basic	325-6193
131-6001	Pin As	376-3646
137-4097	Muffler As.	360-7866
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126

11Z		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0564	Rebuild Kit-Pump	380-7576
170-7502	Shaft-Dr Idler	374-7484
170-8714	Disc-Friction	456-9193
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
215-9365	Bearing	422-6917
232-3233	Bearing-Main	376-9085
234-8009	Kit-Gasket-Sch	382-5056
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
269-6989	Pin	425-2559
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

18Z		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849

Sales Model 963 (Cont'd.)

18Z		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-4695	Cup-Rlr Bearing	374-1842
1P-4696	Cone-Rlr Bearing	374-1843
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1U-3953	Cartridge Gp	426-0024
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354

18Z		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-0222	Bearing-Sleeve	374-6512
3G-5750	Bearing-Plate	419-4734
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3P-1459	Spring-Recoil	375-5448
3W-0241	Pin As	393-3676
3W-2196	Housing As	396-0661
3W-2197	Plate As	416-5511
3W-5159	Plate-Parking Bk	391-9904
3W-5501	Gear-Planet	288-8719
3W-6144	Hub-Sprocket	396-7277
3W-8398	Bearing-Sleeve	379-0189
3W-8403	Sleeve	393-3673
3W-8406	Cap	416-5534
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710

18Z		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-1893	Cartridge Gp	422-8110
4T-4073	Valve Gp-Shtl -B	439-1138
4T-6869	Cartridge Gp	422-8104
4T-9311	Housing	396-0652
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4W-9989	Gear As-Idler	302-2677
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

Sales Model 963 (Cont'd.)

18Z		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6E-2929	Pump Gp-Vn Bsc-A	422-8157
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-5392	Manifold-Exhaust	394-0905
6N-7174	Shield-Oil	314-8544
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7J-2604	Bearing-Sleeve	380-7369
7J-8893	Cone-Roller Brg	374-1846
7J-9708	Bearing-Sleeve	299-1964
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-2957	Cover-Rad Cap	361-1722
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985

18Z		
Original Part Number	Part Name	Classic Part Number
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-4695	Tube	424-0860
7P-6348	Bearing	399-6042
7P-6596	Bearing-Sleeve	295-6409
7P-6768	Rod As	469-4670
7P-6770	Support As	389-6299
7P-6773	Pilot	470-3785
7P-7858	Bearing-Sleeve	374-8362
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7V-3719	Collet As	376-3644
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8G-4259	Bearing-Aligning	374-8341
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623

18Z		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
8Y-0395	Pin As	393-3678
9J-8006	Piston	449-4736
9K-8423	Bearing-Sleeve	421-9043
9L-6371	Rod-Eye	363-7459
9M-1853	Mount As.	376-3638
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9T-0486	Pump Gp-Vn Bsc-A	422-8144
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032

Sales Model 963 (Cont'd.)

18Z		
Original Part Number	Part Name	Classic Part Number
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
126-7134	Pipe As-Exhaust	451-9032
131-3815	Seal Gp-Basic	325-6193
131-6001	Pin As	376-3646
137-4097	Muffler As.	360-7866
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

18Z		
Original Part Number	Part Name	Classic Part Number
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
170-8714	Disc-Friction	456-9193
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085

18Z		
Original Part Number	Part Name	Classic Part Number
234-8009	Kit-Gasket-Sch	382-5056
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

21Z		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-4695	Cup-Rlr Bearing	374-1842
1P-4696	Cone-Rlr Bearing	374-1843
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1U-3953	Cartridge Gp	426-0024
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

21Z		
Original Part Number	Part Name	Classic Part Number
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305

21Z		
Original Part Number	Part Name	Classic Part Number
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-0222	Bearing-Sleeve	374-6512
3G-5750	Bearing-Plate	419-4734
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436

Sales Model 963 (Cont'd.)

21Z		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
3P-1459	Spring-Recoil	375-5448
3W-0241	Pin As	393-3676
3W-2196	Housing As	396-0661
3W-2197	Plate As	416-5511
3W-5159	Plate-Parking Bk	391-9904
3W-5501	Gear-Planet	288-8719
3W-6144	Hub-Sprocket	396-7277
3W-8160	Piston As	393-1051
3W-8177	Retainer	428-7634
3W-8339	Plate	397-5047
3W-8398	Bearing-Sleeve	379-0189
3W-8403	Sleeve	393-3673
3W-8406	Cap	416-5534
3W-8570	Bearing	416-2136
3W-8572	Pin As	393-3672
4D-4065	Rod End-Spher	374-1824
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777

21Z		
Original Part Number	Part Name	Classic Part Number
4P-9964	Line As-Fuel Inj	298-2778
4T-0998	Lever	314-8687
4T-1893	Cartridge Gp	422-8110
4T-4073	Valve Gp-Shtl -B	439-1138
4T-6869	Cartridge Gp	422-8104
4T-9311	Housing	396-0652
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4W-9989	Gear As-Idler	302-2677
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6E-2929	Pump Gp-Vn Bsc-A	422-8157
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-5392	Manifold-Exhaust	394-0905

21Z		
Original Part Number	Part Name	Classic Part Number
6N-7174	Shield-Oil	314-8544
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7J-2604	Bearing-Sleeve	380-7369
7J-8893	Cone-Roller Brg	374-1846
7J-9708	Bearing-Sleeve	299-1964
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-2957	Cover-Rad Cap	361-1722
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-4695	Tube	424-0860
7P-6348	Bearing	399-6042
7P-6531	Shaft-Sun Gear	430-5352
7P-6596	Bearing-Sleeve	295-6409
7P-6768	Rod As	469-4670
7P-6770	Support As	389-6299
7P-6773	Pilot	470-3785
7P-7245	Valve	386-3811
7P-7858	Bearing-Sleeve	374-8362
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721

Sales Model 963 (Cont'd.)

21Z		
Original Part Number	Part Name	Classic Part Number
7V-3719	Collet As	376-3644
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8G-4259	Bearing-Aligning	374-8341
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

21Z		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
8Y-0035	Yoke As	393-1057
8Y-0395	Pin As	393-3678
9J-8006	Piston	449-4736
9K-8423	Bearing-Sleeve	421-9043
9L-6371	Rod-Eye	363-7459
9M-1853	Mount As.	376-3638
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9T-0486	Pump Gp-Vn Bsc-A	422-8144
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
126-7134	Pipe As-Exhaust	451-9032
131-3815	Seal Gp-Basic	325-6193
131-6001	Pin As	376-3646
137-4097	Muffler As.	360-7866
148-7455	Valve - Exhaust	270-4361

21Z		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
170-8714	Disc-Friction	456-9193
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
215-9365	Bearing	422-6917
232-3233	Bearing-Main	376-9085
234-8009	Kit-Gasket-Sch	382-5056
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
269-6989	Pin	425-2559
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 963 (Cont'd.)

29S		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-4695	Cup-Rlr Bearing	374-1842
1P-4696	Cone-Rlr Bearing	374-1843
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1U-3953	Cartridge Gp	426-0024
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837

29S		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-0222	Bearing-Sleeve	374-6512
3G-5750	Bearing-Plate	419-4734
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3P-1459	Spring-Recoil	375-5448
3W-0241	Pin As	393-3676
3W-2196	Housing As	396-0661
3W-2197	Plate As	416-5511
3W-5159	Plate-Parking Bk	391-9904
3W-5501	Gear-Planet	288-8719
3W-6144	Hub-Sprocket	396-7277
3W-8398	Bearing-Sleeve	379-0189
3W-8403	Sleeve	393-3673
3W-8406	Cap	416-5534
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709

29S		
Original Part Number	Part Name	Classic Part Number
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-1893	Cartridge Gp	422-8110
4T-4073	Valve Gp-Shtl -B	439-1138
4T-6869	Cartridge Gp	422-8104
4T-9311	Housing	396-0652
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4W-9989	Gear As-Idler	302-2677
5G-3612	Cap Gp-Protn	295-6419
5J-1192	Bearing-Sleeve	374-8355
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665

Sales Model 963 (Cont'd.)

29S		
Original Part Number	**Part Name**	**Classic Part Number**
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6E-2929	Pump Gp-Vn Bsc-A	422-8157
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-5392	Manifold-Exhaust	394-0905
6N-7174	Shield-Oil	314-8544
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9980	Camshaft	377-5851
7J-2604	Bearing-Sleeve	380-7369
7J-8893	Cone-Roller Brg	374-1846
7J-9708	Bearing-Sleeve	299-1964
7K-2135	Bearing-Roller	417-4492
7K-9528	Bearing-Sleeve	308-9828
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-2957	Cover-Rad Cap	361-1722
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686

29S		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-4695	Tube	424-0860
7P-6348	Bearing	399-6042
7P-6596	Bearing-Sleeve	295-6409
7P-6768	Rod As	469-4670
7P-6770	Support As	389-6299
7P-6773	Pilot	470-3785
7P-7858	Bearing-Sleeve	374-8362
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7V-3719	Collet As	376-3644
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8G-4259	Bearing-Aligning	374-8341
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858

29S		
Original Part Number	**Part Name**	**Classic Part Number**
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
8Y-0395	Pin As	393-3678
9J-8006	Piston	449-4736
9K-8423	Bearing-Sleeve	421-9043
9L-6371	Rod-Eye	363-7459
9M-1853	Mount As.	376-3638
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

Sales Model 963 (Cont'd.)

29S		
Original Part Number	Part Name	Classic Part Number
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9T-0486	Pump Gp-Vn Bsc-A	422-8144
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
126-7134	Pipe As-Exhaust	451-9032
131-3815	Seal Gp-Basic	325-6193
131-6001	Pin As	376-3646
137-4097	Muffler As.	360-7866
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125

29S		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
170-8714	Disc-Friction	456-9193
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259

29S		
Original Part Number	Part Name	Classic Part Number
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-8009	Kit-Gasket-Sch	382-5056
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

48Z		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-4695	Cup-Rlr Bearing	374-1842
1P-4696	Cone-Rlr Bearing	374-1843
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483

48Z		
Original Part Number	Part Name	Classic Part Number
1U-3953	Cartridge Gp	426-0024
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221

48Z		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357

Sales Model 963 (Cont'd.)

48Z		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-0222	Bearing-Sleeve	374-6512
3G-5750	Bearing-Plate	419-4734
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3P-1459	Spring-Recoil	375-5448
3W-0241	Pin As	393-3676
3W-2196	Housing As	396-0661
3W-2197	Plate As	416-5511
3W-5159	Plate-Parking Bk	391-9904
3W-5501	Gear-Planet	288-8719
3W-6144	Hub-Sprocket	396-7277
3W-8398	Bearing-Sleeve	379-0189
3W-8403	Sleeve	393-3673
3W-8406	Cap	416-5534
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716

48Z		
Original Part Number	Part Name	Classic Part Number
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572
4N-9944	Line As-Fuel Inj	380-1565
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-0231	Retainer	376-3641
4T-1893	Cartridge Gp	422-8110
4T-4073	Valve Gp-Shtl -B	439-1138
4T-6869	Cartridge Gp	422-8104
4T-9311	Housing	396-0652
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529

48Z		
Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4W-9989	Gear As-Idler	302-2677
5G-3612	Cap Gp-Protn	295-6419
5H-5553	Screw-Tappet Adj	311-9451
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-2928	Pump Gp-Vn Bsc-A	426-1701
6E-2929	Pump Gp-Vn Bsc-A	422-8157
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-5392	Manifold-Exhaust	394-0905
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6V-1033	Rod End-Spher	375-5444

Sales Model 963 (Cont'd.)

48Z		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7J-2604	Bearing-Sleeve	380-7369
7J-8893	Cone-Roller Brg	374-1846
7J-9708	Bearing-Sleeve	299-1964
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-4695	Tube	424-0860
7P-6348	Bearing	399-6042
7P-6531	Shaft-Sun Gear	430-5352
7P-6596	Bearing-Sleeve	295-6409
7P-6768	Rod As	469-4670
7P-6770	Support As	389-6299
7P-6773	Pilot	470-3785
7P-7858	Bearing-Sleeve	374-8362
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656

48Z		
Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As-Radiator	295-6417
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7V-3719	Collet As	376-3644
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8G-4259	Bearing-Aligning	374-8341
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464

48Z		
Original Part Number	Part Name	Classic Part Number
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
8Y-0395	Pin As	393-3678
9B-1320	Valve-Check	377-5832
9J-8006	Piston	449-4736
9K-8423	Bearing-Sleeve	421-9043
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042

Track Loaders

Sales Model 963 (Cont'd.)

48Z		
Original Part Number	Part Name	Classic Part Number
9T-0486	Pump Gp-Vn Bsc-A	422-8144
9T-1697	Cartridge Gp-	422-8137
9T-5729	Cyl Gp-0038 0158	422-2486
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
126-7134	Pipe As-Exhaust	451-9032
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
131-6001	Pin As	376-3646
137-4097	Muffler As.	360-7866
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046

48Z		
Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
170-8714	Disc-Friction	456-9193
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698

48Z		
Original Part Number	Part Name	Classic Part Number
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-8009	Kit-Gasket-Sch	382-5056
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 963B

9BL		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-4695	Cup-Rlr Bearing	374-1842
1P-4696	Cone-Rlr Bearing	374-1843
1S-7057	Gasket	420-6384
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354

9BL		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
2M-8340	Rod End-Yoke	374-4678
2S-6097	Tang	375-9979
2W-7213	Bearing-Sleeve	419-4667
3G-0222	Bearing-Sleeve	374-6512
3G-5750	Bearing-Plate	419-4734
3H-8726	Mount As	385-7208
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3P-1459	Spring-Recoil	375-5448
3W-0241	Pin As	393-3676
3W-2196	Housing As	396-0661

9BL		
Original Part Number	Part Name	Classic Part Number
3W-2197	Plate As	416-5511
3W-5159	Plate-Parking Bk	391-9904
3W-5501	Gear-Planet	288-8719
3W-6144	Hub-Sprocket	396-7277
3W-8160	Piston As	393-1051
3W-8177	Retainer	428-7634
3W-8339	Plate	397-5047
3W-8398	Bearing-Sleeve	379-0189
3W-8403	Sleeve	393-3673
3W-8406	Cap	416-5534
3W-8570	Bearing	416-2136
3W-8572	Pin As	393-3672
4P-3683	Pump Gp-Water -B	374-7498

Sales Model 963B (Cont'd.)

9BL		
Original Part Number	Part Name	Classic Part Number
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-4073	Valve Gp-Shtl -B	439-1138
4T-9311	Housing	396-0652
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
6I-1099	Manifold-Exh	424-6366
6L-7751	Rod End-Spher	472-8015
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-9960	Mount As.	376-3639
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7J-2604	Bearing-Sleeve	380-7369
7J-8893	Cone-Roller Brg	374-1846
7J-9708	Bearing-Sleeve	299-1964

9BL		
Original Part Number	Part Name	Classic Part Number
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-2957	Cover-Rad Cap	361-1722
7P-2372	Joint As	367-6072
7P-4695	Tube	424-0860
7P-6348	Bearing	399-6042
7P-6531	Shaft-Sun Gear	430-5352
7P-7245	Valve	386-3811
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7V-3719	Collet As	376-3644
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
8T-1177	Bearing-Rlr	419-1862
8Y-0035	Yoke As	393-1057
8Y-0395	Pin As	393-3678
9J-8006	Piston	449-4736
9K-8423	Bearing-Sleeve	421-9043
9M-1853	Mount As.	376-3638
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-4594	Muffler As	360-7862
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692

9BL		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5200	Spider As-Fan	428-8686
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
131-6001	Pin As	376-3646
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
155-5619	Gasket	382-5054
163-1387	Gear-Flywheel	374-4697
170-8714	Disc-Friction	456-9193
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
215-9365	Bearing	422-6917
222-0458	Muffler As	393-0929
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3679	Kit-Gasket (Rs)	437-2039
269-6989	Pin	425-2559
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

2DS		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
2B-0941	Spacer	418-1955
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2S-6097	Tang	375-9979
2W-7213	Bearing-Sleeve	419-4667
3G-0222	Bearing-Sleeve	374-6512
3H-8726	Mount As	385-7208
3P-1459	Spring-Recoil	375-5448
3W-0241	Pin As	393-3676
3W-2196	Housing As	396-0661
3W-2197	Plate As	416-5511
3W-5159	Plate-Parking Bk	391-9904
3W-5501	Gear-Planet	288-8719
3W-8160	Piston As	393-1051
3W-8177	Retainer	428-7634
3W-8398	Bearing-Sleeve	379-0189
3W-8403	Sleeve	393-3673
3W-8406	Cap	416-5534
3W-8570	Bearing	416-2136
3W-8572	Pin As	393-3672
3W-8679	Yoke As	425-1384
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-4073	Valve Gp-Shtl -B	439-1138
4T-9311	Housing	396-0652
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6I-1099	Manifold-Exh	424-6366
6L-7751	Rod End-Spher	472-8015
6P-0593	Bearing-Roller	386-4959

2DS		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7J-2604	Bearing-Sleeve	380-7369
7J-9344	Bearing-Sleeve	360-2334
7J-9708	Bearing-Sleeve	299-1964
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-2957	Cover-Rad Cap	361-1722
7P-2372	Joint As	367-6072
7P-4695	Tube	424-0860
7P-6348	Bearing	399-6042
7P-7245	Valve	386-3811
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7V-3719	Collet As	376-3644
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8D-0983	Mounting	384-3470
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-5778	Bearing-Sleeve	374-8359
8S-0248	Breather As	325-6033

2DS		
Original Part Number	**Part Name**	**Classic Part Number**
8Y-0035	Yoke As	393-1057
8Y-0395	Pin As	393-3678
9J-8006	Piston	449-4736
9K-8423	Bearing-Sleeve	421-9043
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5200	Spider As-Fan	428-8686
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
131-6001	Pin As	376-3646
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
170-8714	Disc-Friction	456-9193
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
215-9365	Bearing	422-6917
222-0458	Muffler As	393-0929
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
255-2899	Pipe As-Tail	301-5246
269-6989	Pin	425-2559
271-5658	Crankshaft As.	368-5912

Sales Model 963C (Cont'd.)

2DS		
Original Part Number	Part Name	Classic Part Number
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
318-9013	Kit-Gasket (Sch)	437-8128
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
3G-0222	Bearing-Sleeve	374-6512
3P-1459	Spring-Recoil	375-5448
3W-0241	Pin As	393-3676
3W-2196	Housing As	396-0661
3W-2197	Plate As	416-5511
3W-5159	Plate-Parking Bk	391-9904
3W-5501	Gear-Planet	288-8719
3W-8160	Piston As	393-1051
3W-8177	Retainer	428-7634
3W-8398	Bearing-Sleeve	379-0189
3W-8403	Sleeve	393-3673
3W-8406	Cap	416-5534
3W-8570	Bearing	416-2136
3W-8572	Pin As	393-3672
4T-4073	Valve Gp-Shtl -B	439-1138
4T-9311	Housing	396-0652
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
6P-0593	Bearing-Roller	386-4959

2DS		
Original Part Number	Part Name	Classic Part Number
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6Y-7652	Cup-Rlr Brg	399-6067
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7J-2604	Bearing-Sleeve	380-7369
7J-9344	Bearing-Sleeve	360-2334
7J-9708	Bearing-Sleeve	299-1964
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7P-2372	Joint As	367-6072
7P-4695	Tube	424-0860
7P-6348	Bearing	399-6042
7P-7245	Valve	386-3811
7T-2036	Cap As-Fuel	361-1721
7V-3719	Collet As	376-3644
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
8Y-0035	Yoke As	393-1057
8Y-0395	Pin As	393-3678
9J-8006	Piston	449-4736
9K-8423	Bearing-Sleeve	421-9043
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-9930	Mount As	295-6437

BBD		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174

2DS		
Original Part Number	Part Name	Classic Part Number
9W-9940	Mount As.	360-2355
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
114-0468	Pin-G.E.T.	443-1203
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5200	Spider As-Fan	428-8686
124-3237	Precleaner As	432-4220
127-3467	Manifold-Exhaust	394-9827
131-6001	Pin As	376-3646
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
170-8714	Disc-Friction	456-9193
208-0421	Muffler As	360-9624
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
215-9365	Bearing	422-6917
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
269-6989	Pin	425-2559
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441

Sales Model 963C (Cont'd.)

BBD		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
3G-0222	Bearing-Sleeve	374-6512
3P-1459	Spring-Recoil	375-5448
3W-0241	Pin As	393-3676
3W-2196	Housing As	396-0661
3W-2197	Plate As	416-5511
3W-5159	Plate-Parking Bk	391-9904
3W-5501	Gear-Planet	288-8719
3W-8160	Piston As	393-1051
3W-8177	Retainer	428-7634
3W-8398	Bearing-Sleeve	379-0189
3W-8403	Sleeve	393-3673
3W-8406	Cap	416-5534
3W-8570	Bearing	416-2136
3W-8572	Pin As	393-3672
4T-4073	Valve Gp-Shtl -B	439-1138
4T-9311	Housing	396-0652
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
6P-0593	Bearing-Roller	386-4959
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6Y-7652	Cup-Rlr Brg	399-6067
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

BBD		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7J-2604	Bearing-Sleeve	380-7369
7J-9344	Bearing-Sleeve	360-2334
7J-9708	Bearing-Sleeve	299-1964
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7P-2372	Joint As	367-6072
7P-4695	Tube	424-0860
7P-6348	Bearing	399-6042
7P-7245	Valve	386-3811
7T-2036	Cap As-Fuel	361-1721
7V-3719	Collet As	376-3644
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8D-0983	Mounting	384-3470
8H-9789	Bearing-Ball	374-8342
8Y-0035	Yoke As	393-1057
8Y-0395	Pin As	393-3678
9J-8006	Piston	449-4736
9K-8423	Bearing-Sleeve	421-9043
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381

BBD		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-5200	Spider As-Fan	428-8686
124-3237	Precleaner As	432-4220
127-3467	Manifold-Exhaust	394-9827
131-6001	Pin As	376-3646
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
170-8714	Disc-Friction	456-9193
208-0421	Muffler As	360-9624
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
215-9365	Bearing	422-6917
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
269-6989	Pin	425-2559
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441

Sales Model 963D

LCS		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437

Sales Model 963D (Cont'd.)

LCS		
Original Part Number	Part Name	Classic Part Number
1B-3980	Cone-Roller Brg	399-4443
2B-0941	Spacer	418-1955
2K-4502	Bearing-Sleeve	299-1986
2K-6413	Pin	360-2270
3G-0222	Bearing-Sleeve	374-6512
3P-1210	Cone-Roller Brg	399-4433
3W-0241	Pin As	393-3676
3W-2196	Housing As	396-0661
3W-2197	Plate As	416-5511
3W-5159	Plate-Parking Bk	391-9904
3W-8160	Piston As	393-1051
3W-8177	Retainer	428-7634
3W-8398	Bearing-Sleeve	379-0189
3W-8403	Sleeve	393-3673

LCS		
Original Part Number	Part Name	Classic Part Number
3W-8406	Cap	416-5534
3W-8570	Bearing	416-2136
3W-8572	Pin As	393-3672
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
7J-9708	Bearing-Sleeve	299-1964
7P-4695	Tube	424-0860
7P-6348	Bearing	399-6042
7P-7245	Valve	386-3811
8J-5778	Bearing-Sleeve	374-8359
8Y-0035	Yoke As	393-1057

LCS		
Original Part Number	Part Name	Classic Part Number
8Y-0395	Pin As	393-3678
9K-8423	Bearing-Sleeve	421-9043
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-9930	Mount As	295-6437
124-3237	Precleaner As	432-4220
166-6930	Cone-Spl Tapered	399-4443
170-8714	Disc-Friction	456-9193
215-9365	Bearing	422-6917
223-3095	Gauge As	360-2295
269-6989	Pin	425-2559
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 963K

LBL		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
2B-0941	Spacer	418-1955
2K-6413	Pin	360-2270
3G-0222	Bearing-Sleeve	374-6512
3W-0241	Pin As	393-3676
3W-2197	Plate As	416-5511
3W-5159	Plate-Parking Bk	391-9904
3W-8160	Piston As	393-1051
3W-8177	Retainer	428-7634
3W-8398	Bearing-Sleeve	379-0189
3W-8403	Sleeve	393-3673

LBL		
Original Part Number	Part Name	Classic Part Number
3W-8406	Cap	416-5534
3W-8570	Bearing	416-2136
3W-8572	Pin As	393-3672
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6Y-9960	Mount As.	376-3639
7J-9708	Bearing-Sleeve	299-1964
7P-4695	Tube	424-0860
7P-6348	Bearing	399-6042
7P-7245	Valve	386-3811
8Y-0035	Yoke As	393-1057

LBL		
Original Part Number	Part Name	Classic Part Number
9K-8423	Bearing-Sleeve	421-9043
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
166-6930	Cone-Spl Tapered	399-4443
170-8714	Disc-Friction	456-9193
176-3900	Accumulator	416-5513
215-9365	Bearing	422-6917
269-6989	Pin	425-2559
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

26Z		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1U-3953	Cartridge Gp	426-0024
1U-3998	Seal As	472-8005
1W-0370	Muffler As.	360-7869
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164

26Z		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-0222	Bearing-Sleeve	374-6512
3G-5750	Bearing-Plate	419-4734
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3N-5869	Support-Elbow	375-9973
3P-1210	Cone-Roller Brg	399-4433
3P-1885	Spring-Recoil	375-5449
3W-2214	Housing As	418-1947
3W-2215	Plate As	396-0655
3W-5159	Plate-Parking Bk	391-9904
3W-8177	Retainer	428-7634
3W-8238	Cap	425-3448
3W-8239	Sleeve-Wear	360-2342
3W-8240	Bearing-Sleeve	425-6438
3W-8339	Plate	397-5047
3W-8355	Pin As	425-2565
3W-8398	Bearing-Sleeve	379-0189

26Z		
Original Part Number	**Part Name**	**Classic Part Number**
3W-8679	Yoke As	425-1384
3Y-9984	Manifold-Exhaust	325-6123
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-4073	Valve Gp-Shtl -B	439-1138
4T-9311	Housing	396-0652
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-9989	Gear As-Idler	302-2677
5G-3612	Cap Gp-Protn	295-6419
5J-9451	Bearing	374-8338
5P-3489	Race-Brg Outer	396-9905
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

Sales Model 973 (Cont'd.)

26Z		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7J-8893	Cone-Roller Brg	374-1846
7J-9731	Bearing-Sleeve	308-9822
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994

26Z		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7P-2285	Pin As	393-3669
7P-3214	Pin	425-3452
7P-4777	Pin	416-5488
7P-5082	Pin As	374-8367
7P-6348	Bearing	399-6042
7P-7245	Valve	386-3811
7P-7858	Bearing-Sleeve	374-8362
7P-8076	Gear-Planet	390-5263
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8G-0890	Bearing-Align	374-8340
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835

26Z		
Original Part Number	Part Name	Classic Part Number
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8R-3943	Collet	308-9840
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8T-1177	Bearing-Rlr	419-1862
9C-0624	Pin As.	361-1709
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1853	Mount As.	376-3638
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9T-3866	Pump Gp-Vn Bsc-A	422-8145
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360

Sales Model 973 (Cont'd.)

26Z		
Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127

26Z		
Original Part Number	Part Name	Classic Part Number
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
170-8714	Disc-Friction	456-9193
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365

26Z		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

32Z		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2696	Cone-Bearing	374-1834
1P-7125	Governor As	383-3672
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0299	Cup-Roller Brg	422-6494
1U-3953	Cartridge Gp	426-0024
1U-3998	Seal As	472-8005
1W-0370	Muffler As.	360-7869
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

32Z		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305

32Z		
Original Part Number	Part Name	Classic Part Number
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892

Sales Model 973 (Cont'd.)

32Z		
Original Part Number	Part Name	Classic Part Number
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-0222	Bearing-Sleeve	374-6512
3G-5750	Bearing-Plate	419-4734
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3N-5869	Support-Elbow	375-9973
3P-1210	Cone-Roller Brg	399-4433
3P-1885	Spring-Recoil	375-5449
3V-4643	Rod As	389-6333
3W-2214	Housing As	418-1947
3W-2215	Plate As	396-0655
3W-5159	Plate-Parking Bk	391-9904
3W-8238	Cap	425-3448
3W-8239	Sleeve-Wear	360-2342
3W-8240	Bearing-Sleeve	425-6438
3Y-9984	Manifold-Exhaust	325-6123
4E-7717	Shaft-Sprocket	432-6606
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986

32Z		
Original Part Number	Part Name	Classic Part Number
4P-9386	Line As-Fuel Inj	279-4987
4T-4073	Valve Gp-Shtl -B	439-1138
4T-9311	Housing	396-0652
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-9989	Gear As-Idler	302-2677
5G-3612	Cap Gp-Protn	295-6419
5P-3489	Race-Brg Outer	396-9905
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544

32Z		
Original Part Number	Part Name	Classic Part Number
6N-8992	Adapter-Fan	394-9810
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-7956	Disc-Friction	374-4677
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7J-9731	Bearing-Sleeve	308-9822
7K-2135	Bearing-Roller	417-4492
7K-8877	Cone-Bearing	374-1847
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-2285	Pin As	393-3669
7P-3214	Pin	425-3452
7P-4777	Pin	416-5488
7P-5082	Pin As	374-8367
7P-8076	Gear-Planet	390-5263
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935

Sales Model 973 (Cont'd.)

32Z		
Original Part Number	Part Name	Classic Part Number
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8G-0890	Bearing-Align	374-8340
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-0509	Plate-Mating	382-5053
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-4850	Cage-Bearing	451-0745
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860

32Z		
Original Part Number	Part Name	Classic Part Number
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8R-3943	Collet	308-9840
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8T-1177	Bearing-Rlr	419-1862
9C-0624	Pin As.	361-1709
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1853	Mount As.	376-3638
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9T-3866	Pump Gp-Vn Bsc-A	422-8145
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
124-3237	Precleaner As	432-4220

32Z		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0564	Rebuild Kit-Pump	380-7576
170-7502	Shaft-Dr Idler	374-7484
170-8714	Disc-Friction	456-9193
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028

Sales Model 973 (Cont'd.)

32Z		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989

32Z		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349

32Z		
Original Part Number	Part Name	Classic Part Number
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

66G		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1U-3953	Cartridge Gp	426-0024
1U-3998	Seal As	472-8005
1W-0370	Muffler As.	360-7869
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955

66G		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-0222	Bearing-Sleeve	374-6512
3G-5750	Bearing-Plate	419-4734
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3P-1885	Spring-Recoil	375-5449

66G		
Original Part Number	Part Name	Classic Part Number
3W-2214	Housing As	418-1947
3W-2215	Plate As	396-0655
3W-5159	Plate-Parking Bk	391-9904
3W-8238	Cap	425-3448
3W-8239	Sleeve-Wear	360-2342
3W-8240	Bearing-Sleeve	425-6438
3Y-9984	Manifold-Exhaust	325-6123
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-4073	Valve Gp-Shtl -B	439-1138
4T-9311	Housing	396-0652
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-9989	Gear As-Idler	302-2677
5G-3612	Cap Gp-Protn	295-6419

Sales Model 973 (Cont'd.)

66G		
Original Part Number	**Part Name**	**Classic Part Number**
5P-3489	Race-Brg Outer	396-9905
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7J-8893	Cone-Roller Brg	374-1846
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722

66G		
Original Part Number	**Part Name**	**Classic Part Number**
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-2285	Pin As	393-3669
7P-3214	Pin	425-3452
7P-4777	Pin	416-5488
7P-5082	Pin As	374-8367
7P-8076	Gear-Planet	390-5263
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8G-0890	Bearing-Align	374-8340
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207

66G		
Original Part Number	**Part Name**	**Classic Part Number**
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8R-3943	Collet	308-9840
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8T-1177	Bearing-Rlr	419-1862
9C-0624	Pin As.	361-1709
9M-1853	Mount As.	376-3638
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9T-3866	Pump Gp-Vn Bsc-A	422-8145
9Y-1798	Seal-Water	379-0165

Sales Model 973 (Cont'd.)

66G		
Original Part Number	**Part Name**	**Classic Part Number**
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

66G		
Original Part Number	**Part Name**	**Classic Part Number**
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

66G		
Original Part Number	**Part Name**	**Classic Part Number**
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

86G		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1U-3953	Cartridge Gp	426-0024
1U-3998	Seal As	472-8005
1W-0370	Muffler As.	360-7869
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

86G		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

86G		
Original Part Number	**Part Name**	**Classic Part Number**
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3G-0222	Bearing-Sleeve	374-6512
3G-5750	Bearing-Plate	419-4734
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3P-1885	Spring-Recoil	375-5449
3W-2214	Housing As	418-1947
3W-2215	Plate As	396-0655

Sales Model 973 (Cont'd.)

86G		
Original Part Number	**Part Name**	**Classic Part Number**
3W-5159	Plate-Parking Bk	391-9904
3W-8177	Retainer	428-7634
3W-8238	Cap	425-3448
3W-8239	Sleeve-Wear	360-2342
3W-8240	Bearing-Sleeve	425-6438
3W-8339	Plate	397-5047
3W-8355	Pin As	425-2565
3W-8398	Bearing-Sleeve	379-0189
3W-8679	Yoke As	425-1384
3Y-9984	Manifold-Exhaust	325-6123
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-4073	Valve Gp-Shtl -B	439-1138
4T-9311	Housing	396-0652
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-9989	Gear As-Idler	302-2677
5G-3612	Cap Gp-Protn	295-6419
5P-3489	Race-Brg Outer	396-9905
5P-7807	Bearing-Ball	314-8502

86G		
Original Part Number	**Part Name**	**Classic Part Number**
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7J-8893	Cone-Roller Brg	374-1846
7J-9731	Bearing-Sleeve	308-9822
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451

86G		
Original Part Number	**Part Name**	**Classic Part Number**
7N-2957	Cover-Rad Cap	361-1722
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-2285	Pin As	393-3669
7P-3214	Pin	425-3452
7P-4777	Pin	416-5488
7P-5082	Pin As	374-8367
7P-6348	Bearing	399-6042
7P-7245	Valve	386-3811
7P-7858	Bearing-Sleeve	374-8362
7P-8076	Gear-Planet	390-5263
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5699	Pulley-Cshaft	378-3988
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8G-0890	Bearing-Align	374-8340
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210

Sales Model 973 (Cont'd.)

86G		
Original Part Number	Part Name	Classic Part Number
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8R-3943	Collet	308-9840
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416

86G		
Original Part Number	Part Name	Classic Part Number
8T-1177	Bearing-Rlr	419-1862
9C-0624	Pin As.	361-1709
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1853	Mount As.	376-3638
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9T-3866	Pump Gp-Vn Bsc-A	422-8145
9X-6560	Gasket Kit	382-5073
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126

86G		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
170-8714	Disc-Friction	456-9193
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

90L		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345

90L		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087

90L		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147

Sales Model 973 (Cont'd.)

90L		
Original Part Number	Part Name	Classic Part Number
1P-2662	Cone-Roller Brg	374-1851
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1U-3953	Cartridge Gp	426-0024
1U-3998	Seal As	472-8005
1W-0370	Muffler As.	360-7869
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230

90L		
Original Part Number	Part Name	Classic Part Number
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-0222	Bearing-Sleeve	374-6512
3G-5750	Bearing-Plate	419-4734
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3P-1885	Spring-Recoil	375-5449
3W-2214	Housing As	418-1947
3W-2215	Plate As	396-0655
3W-5159	Plate-Parking Bk	391-9904
3W-8238	Cap	425-3448
3W-8239	Sleeve-Wear	360-2342
3W-8240	Bearing-Sleeve	425-6438
3Y-9984	Manifold-Exhaust	325-6123
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985

90L		
Original Part Number	Part Name	Classic Part Number
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-4073	Valve Gp-Shtl -B	439-1138
4T-9311	Housing	396-0652
4V-8674	Bearing-Sleeve	307-1529
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-9989	Gear As-Idler	302-2677
5G-3612	Cap Gp-Protn	295-6419
5J-1192	Bearing-Sleeve	374-8355
5P-3489	Race-Brg Outer	396-9905
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

Sales Model 973 (Cont'd.)

90L		
Original Part Number	Part Name	Classic Part Number
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7J-8893	Cone-Roller Brg	374-1846
7J-9731	Bearing-Sleeve	308-9822
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-2285	Pin As	393-3669
7P-3214	Pin	425-3452
7P-4777	Pin	416-5488
7P-5082	Pin As	374-8367
7P-8076	Gear-Planet	390-5263
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187

90L		
Original Part Number	Part Name	Classic Part Number
7W-9020	Bell As-Pump Suc	378-3989
8G-0890	Bearing-Align	374-8340
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084

90L		
Original Part Number	Part Name	Classic Part Number
8R-3943	Collet	308-9840
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8T-1177	Bearing-Rlr	419-1862
9C-0624	Pin As.	361-1709
9L-6371	Rod-Eye	363-7459
9M-1853	Mount As.	376-3638
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9T-3866	Pump Gp-Vn Bsc-A	422-8145
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

Sales Model 973 (Cont'd.)

90L		
Original Part Number	**Part Name**	**Classic Part Number**
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
170-8714	Disc-Friction	456-9193
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

90L		
Original Part Number	**Part Name**	**Classic Part Number**
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438

90L		
Original Part Number	**Part Name**	**Classic Part Number**
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

91L		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1U-3953	Cartridge Gp	426-0024
1U-3998	Seal As	472-8005
1W-0370	Muffler As.	360-7869
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

91L		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055

91L		
Original Part Number	**Part Name**	**Classic Part Number**
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-0222	Bearing-Sleeve	374-6512
3G-5750	Bearing-Plate	419-4734
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3P-1885	Spring-Recoil	375-5449
3W-2214	Housing As	418-1947
3W-2215	Plate As	396-0655
3W-5159	Plate-Parking Bk	391-9904
3W-8238	Cap	425-3448
3W-8239	Sleeve-Wear	360-2342
3W-8240	Bearing-Sleeve	425-6438
3Y-9984	Manifold-Exhaust	325-6123
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984

Sales Model 973 (Cont'd.)

91L		
Original Part Number	Part Name	Classic Part Number
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-4073	Valve Gp-Shtl -B	439-1138
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-8643	Bearing-Sleeve	374-8354
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-9989	Gear As-Idler	302-2677
5G-3612	Cap Gp-Protn	295-6419
5P-3489	Race-Brg Outer	396-9905
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475

91L		
Original Part Number	Part Name	Classic Part Number
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6S-3474	Pin As	375-9981
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7J-8893	Cone-Roller Brg	374-1846
7J-9731	Bearing-Sleeve	308-9822
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-2285	Pin As	393-3669
7P-3214	Pin	425-3452
7P-4777	Pin	416-5488
7P-5082	Pin As	374-8367
7P-8076	Gear-Planet	390-5263
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721

91L		
Original Part Number	Part Name	Classic Part Number
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8G-0890	Bearing-Align	374-8340
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081

Sales Model 973 (Cont'd.)

91L		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8R-3943	Collet	308-9840
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8T-1177	Bearing-Rlr	419-1862
9C-0624	Pin As.	361-1709
9L-6371	Rod-Eye	363-7459
9M-1853	Mount As.	376-3638
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3866	Pump Gp-Vn Bsc-A	422-8145

91L		
Original Part Number	**Part Name**	**Classic Part Number**
9T-5729	Cyl Gp-0038 0158	422-2486
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
124-3237	Precleaner As	432-4220
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

91L		
Original Part Number	**Part Name**	**Classic Part Number**
170-7502	Shaft-Dr Idler	374-7484
170-8714	Disc-Friction	456-9193
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 973C

3RZ		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1W-0370	Muffler As.	360-7869
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

3RZ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

3RZ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229

Sales Model 973C (Cont'd.)

3RZ		
Original Part Number	Part Name	Classic Part Number
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3G-0222	Bearing-Sleeve	374-6512
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3P-1885	Spring-Recoil	375-5449
3W-2214	Housing As	418-1947
3W-2215	Plate As	396-0655
3W-5159	Plate-Parking Bk	391-9904
3W-8177	Retainer	428-7634
3W-8238	Cap	425-3448
3W-8239	Sleeve-Wear	360-2342
3W-8240	Bearing-Sleeve	425-6438
3W-8339	Plate	397-5047
3W-8355	Pin As	425-2565
3W-8398	Bearing-Sleeve	379-0189
3W-8679	Yoke As	425-1384
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984

3RZ		
Original Part Number	Part Name	Classic Part Number
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-4073	Valve Gp-Shtl -B	439-1138
4T-9311	Housing	396-0652
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5J-9451	Bearing	374-8338
5P-3489	Race-Brg Outer	396-9905
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6V-5976	Kit-Gasket (Rs)	393-5200

3RZ		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7J-9731	Bearing-Sleeve	308-9822
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-2285	Pin As	393-3669
7P-2372	Joint As	367-6072
7P-3214	Pin	425-3452
7P-4777	Pin	416-5488
7P-5082	Pin As	374-8367
7P-6348	Bearing	399-6042
7P-7245	Valve	386-3811
7P-7858	Bearing-Sleeve	374-8362
7P-8076	Gear-Planet	390-5263
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5699	Pulley-Cshaft	378-3988
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-3111	Rod End-Spher	392-4523
8D-0983	Mounting	384-3470
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

Sales Model 973C (Cont'd.)

3RZ		
Original Part Number	Part Name	Classic Part Number
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8R-3943	Collet	308-9840
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042

3RZ		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
9C-0624	Pin As.	361-1709
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8184	Pin-Drawbar	398-8345
9S-8679	Chamber As	325-6042
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-0468	Pin-G.E.T.	443-1203
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351

3RZ		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
170-8714	Disc-Friction	456-9193
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

LDX		
Original Part Number	Part Name	Classic Part Number
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955

LDX		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2W-7213	Bearing-Sleeve	419-4667
3G-0222	Bearing-Sleeve	374-6512
3P-1885	Spring-Recoil	375-5449
3W-2214	Housing As	418-1947

LDX		
Original Part Number	Part Name	Classic Part Number
3W-2215	Plate As	396-0655
3W-5159	Plate-Parking Bk	391-9904
3W-8177	Retainer	428-7634
3W-8238	Cap	425-3448
3W-8239	Sleeve-Wear	360-2342
3W-8240	Bearing-Sleeve	425-6438

Sales Model 973C (Cont'd.)

LDX		
Original Part Number	Part Name	Classic Part Number
3W-8339	Plate	397-5047
3W-8355	Pin As	425-2565
3W-8398	Bearing-Sleeve	379-0189
3W-8679	Yoke As	425-1384
4T-4073	Valve Gp-Shtl -B	439-1138
4T-9311	Housing	396-0652
4W-1203	Cup-Rlr Brg	418-9603
5P-3489	Race-Brg Outer	396-9905
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6P-0593	Bearing-Roller	386-4959
7F-2742	Bearing-Ball	422-6488

LDX		
Original Part Number	Part Name	Classic Part Number
7J-9731	Bearing-Sleeve	308-9822
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7P-2285	Pin As	393-3669
7P-3214	Pin	425-3452
7P-4777	Pin	416-5488
7P-5082	Pin As	374-8367
7P-6348	Bearing	399-6042
7P-7245	Valve	386-3811
7P-7858	Bearing-Sleeve	374-8362
7P-8076	Gear-Planet	390-5263
7P-8370	Bearing	295-6410
8C-3111	Rod End-Spher	392-4523
8D-0983	Mounting	384-3470

LDX		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-9940	Mount As.	360-2355
114-0468	Pin-G.E.T.	443-1203
115-4072	Bearing	397-5069
124-3237	Precleaner As	432-4220
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
170-8714	Disc-Friction	456-9193
229-1490	Sleeve-Injector	393-3659
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 973D

LCP		
Original Part Number	Part Name	Classic Part Number
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1W-4738	Bearing-Sleeve	325-6020
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2W-7213	Bearing-Sleeve	419-4667
3G-0222	Bearing-Sleeve	374-6512
3G-2580	Bearing-Sleeve	422-9526
3G-5285	Bearing-Sleeve	360-2312
3W-2215	Plate As	396-0655
3W-5159	Plate-Parking Bk	391-9904

LCP		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4Y-4905	Washer-Soft	416-5535
5P-3489	Race-Brg Outer	396-9905
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
7F-2742	Bearing-Ball	422-6488
7J-9731	Bearing-Sleeve	308-9822
7P-2285	Pin As	393-3669
7P-3214	Pin	425-3452
7P-8076	Gear-Planet	390-5263
7Y-2396	Bearing-Sleeve	314-8634
8E-6752	Bearing-Sleeve	388-6576

LCP		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8184	Pin-Drawbar	398-8345
9W-9940	Mount As.	360-2355
114-0468	Pin-G.E.T.	443-1203
115-4072	Bearing	397-5069
161-3411	Gasket	394-0896
170-8714	Disc-Friction	456-9193
229-1490	Sleeve-Injector	393-3659
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

11K		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1006	Strip-Guard	226-0245
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-5331	Cylinder-Adj	226-0214
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0969	Bearing-Sleeve	453-6497
1T-1078	Bearing-Thrust	384-4802
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2K-4442	Bearing-Sleeve	308-9812

11K		
Original Part Number	Part Name	Classic Part Number
2K-4507	Bearing-Sleeve	325-6021
2M-0369	Pilot-Spring R	226-0226
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-7116	Strip-Tapping	384-3480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2744	Muffler As.	247-2664
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-4611	Pipe-Exhaust	365-8821
2P-6245	Shaft As-Pump	325-6197
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-7637	Pump Gp-Vn Bsc-A	422-8148
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356

11K		
Original Part Number	Part Name	Classic Part Number
3P-1885	Spring-Recoil	375-5449
3P-2822	Retainer	422-3509
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-5003	Spring As-Arm	383-2127
4K-0300	Bearing-Sleeve	308-9817
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519

Sales Model 977K (Cont'd.)

11K		
Original Part Number	Part Name	Classic Part Number
4W-7188	Core As-Oclr	374-7501
5G-3612	Cap Gp-Protn	295-6419
5K-2294	Bearing	396-9912
5K-6377	Pin	241-2610
5K-6383	Pin	241-2612
5K-7995	Bearing-Sleeve	308-9820
5L-6326	Bearing-Ball	420-3222
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6670	Shaft-Sprocket	216-7847
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

11K		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4442	Rod End-Special	373-5388
6K-8088	Bearing-Roller	399-4428
6N-0622	Elbow-Exhaust	380-7534
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6T-1980	Collar-Idler End	226-0210
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9547	Pin As.-Drawbar	295-0414
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-6681	Cage As	216-7860
7H-4566	Cup-Roller Brg	399-6068
7J-9344	Bearing-Sleeve	360-2334

11K		
Original Part Number	Part Name	Classic Part Number
7J-9346	Bearing-Sleeve	374-8357
7J-9731	Bearing-Sleeve	308-9822
7K-5448	Cup-Bearing	415-1922
7K-9528	Bearing-Sleeve	308-9828
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066

Sales Model 977K (Cont'd.)

11K		
Original Part Number	**Part Name**	**Classic Part Number**
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-1383	Rod-Tie	299-2051
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-5778	Bearing-Sleeve	374-8359
8M-0874	Plunger As-Valve	311-9439
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441

11K		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-0621	Nut-Adjusting	451-0746
8P-4537	Pinion-Reduction	216-7867
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831

11K		
Original Part Number	**Part Name**	**Classic Part Number**
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2744	Cone-Spl Tapered	380-1480
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-3436	Holder As-Cage	216-7875
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-9000	Shaft-Ster Cl	217-7738
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2354	Manifold-Exhaust	261-0888

Sales Model 977K (Cont'd.)

11K		
Original Part Number	Part Name	Classic Part Number
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193

11K		
Original Part Number	Part Name	Classic Part Number
149-5985	Stator-Converter	419-1865
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

11K		
Original Part Number	Part Name	Classic Part Number
219-9693	Shaft-Classic	217-7738
219-9693	Shaft-Classic	216-7876
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

46H		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-0090	Gasket-Manifold	445-7701
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-9444	Retainer-Spring	299-2046
1P-1006	Strip-Guard	226-0245
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-4110	Disc-Friction	433-9858
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1S-5331	Cylinder-Adj	226-0214
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464

46H		
Original Part Number	Part Name	Classic Part Number
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0969	Bearing-Sleeve	453-6497
1T-1078	Bearing-Thrust	384-4802
1W-7072	Rebuild Kt-Pump	428-6657
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2K-4442	Bearing-Sleeve	308-9812
2K-4507	Bearing-Sleeve	325-6021
2M-0369	Pilot-Spring R	226-0226
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-7116	Strip-Tapping	384-3480
2P-3422	Gear-First Red	213-8451

46H		
Original Part Number	Part Name	Classic Part Number
2P-3423	Pinion-Sec Redc	216-3553
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
3G-7637	Pump Gp-Vn Bsc-A	422-8148
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3P-2822	Retainer	422-3509
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849

Sales Model 977K (Cont'd.)

46H		
Original Part Number	Part Name	Classic Part Number
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-5003	Spring As-Arm	383-2127
4K-0300	Bearing-Sleeve	308-9817
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
5H-7071	Director-Water	388-0555
5K-2294	Bearing	396-9912
5K-6377	Pin	241-2610
5K-6383	Pin	241-2612
5K-7995	Bearing-Sleeve	308-9820
5L-7632	Support-Elbow	433-9854
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6670	Shaft-Sprocket	216-7847
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467

46H		
Original Part Number	Part Name	Classic Part Number
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4442	Rod End-Special	373-5388
6K-8088	Bearing-Roller	399-4428
6T-1980	Collar-Idler End	226-0210
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
7E-5085	Bushing	377-5829
7F-9547	Pin As.-Drawbar	295-0414
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-6681	Cage As	216-7860
7H-4566	Cup-Roller Brg	399-6068
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
7J-9731	Bearing-Sleeve	308-9822
7K-5448	Cup-Bearing	415-1922
7K-9528	Bearing-Sleeve	308-9828
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-7358	Valve-Inlet	298-2774
7N-0113	Core As-Oclr	388-0564

46H		
Original Part Number	Part Name	Classic Part Number
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-9145	Gear-Flywheel	279-4994
7S-1234	Bushing As-Spt	394-0192
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-1927	Ring-Retainer	387-2935
8H-1383	Rod-Tie	299-2051
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-5778	Bearing-Sleeve	374-8359
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-6803	Shaft As	215-1842

Sales Model 977K (Cont'd.)

46H		
Original Part Number	**Part Name**	**Classic Part Number**
8P-7790	Valve Gp-Press	247-4437
8S-9686	Gasket Kit	393-5215
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2744	Cone-Spl Tapered	380-1480

46H		
Original Part Number	**Part Name**	**Classic Part Number**
9M-4955	Pump Gp-F Tfr	242-3443
9M-5477	Bearing-Sleeve	374-6517
9P-0620	Cage-Pinion Brg	221-1052
9P-3436	Holder As-Cage	216-7875
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-9000	Shaft-Ster Cl	217-7738
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1768	Pipe-Ext Exhaust	380-7544
9S-3581	Cup-Roller Brg	415-1923

46H		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3582	Cone-Roller Brg	396-4144
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
106-7799	Bearing-Ball	396-9947
108-5603	Screw-Adj Arm	379-0166
124-3237	Precleaner As	432-4220
149-5985	Stator-Converter	419-1865
169-4200	Gasket	472-8023
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
232-3233	Bearing-Main	376-9085
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
368-0297	Plate-Clutch	377-7420

48J		
Original Part Number	**Part Name**	**Classic Part Number**
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0969	Bearing-Sleeve	453-6497
1T-1078	Bearing-Thrust	384-4802
1W-3900	Gasket	472-8006
2P-0220	Gasket-Pump	398-2927
3L-1425	Bearing-Ball	311-9356
4W-0452	Seal As -Cshaft	325-6191
5M-6126	Bearing	377-7433

48J		
Original Part Number	**Part Name**	**Classic Part Number**
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
6N-7263	Gasket-Cyl Head	380-7386
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
7C-4297	Seal As-Cshaft	325-6192
7M-1154	Bearing-Spl	417-4515
7N-7386	Gasket-Cyl Head	392-4519

70J		
Original Part Number	**Part Name**	**Classic Part Number**
1M-4095	Bearing-Inner	417-9486

48J		
Original Part Number	**Part Name**	**Classic Part Number**
7S-3206	Seal-O-Ring	436-2656
8C-8741	Kit-Gasket-(Rs)	438-0172
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8S-9686	Gasket Kit	393-5215
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
9M-2744	Cone-Spl Tapered	380-1480
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 977K (Cont'd.)

70J		
Original Part Number	Part Name	Classic Part Number
1M-6573	Cup-Roller Brg	399-4438
1P-1006	Strip-Guard	226-0245
1S-3743	Bearing-Ball	384-4786
1S-5331	Cylinder-Adj	226-0214
1T-0043	Bearing-Ball	390-5294
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0969	Bearing-Sleeve	453-6497
1T-1078	Bearing-Thrust	384-4802
1W-3900	Gasket	472-8006
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2F-5721	Bearing-Ball	311-9354
2M-0369	Pilot-Spring R	226-0226
2M-7116	Strip-Tapping	384-3480
2P-0220	Gasket-Pump	398-2927
3G-7637	Pump Gp-Vn Bsc-A	422-8148
3L-1425	Bearing-Ball	311-9356
3P-2822	Retainer	422-3509
3T-4482	Guide-Frt Idler	226-0248
4D-4065	Rod End-Spher	374-1824
4F-5003	Spring As-Arm	383-2127
4K-0300	Bearing-Sleeve	308-9817
4N-7693	Crankshaft As	269-8763
4W-0452	Seal As -Cshaft	325-6191
5K-6377	Pin	241-2610
5K-6383	Pin	241-2612
5K-7995	Bearing-Sleeve	308-9820
5M-5856	Pipe-Extension	373-1913
5M-6126	Bearing	377-7433
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137

70J		
Original Part Number	Part Name	Classic Part Number
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
6H-3957	Bearing-Ball	311-9358
6N-7263	Gasket-Cyl Head	380-7386
6T-1980	Collar-Idler End	226-0210
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
7H-4566	Cup-Roller Brg	399-6068
7J-9346	Bearing-Sleeve	374-8357
7K-5448	Cup-Bearing	415-1922
7M-1154	Bearing-Spl	417-4515
7N-8018	Seal-Water	418-1964
7S-1234	Bushing As-Spt	394-0192
7S-3206	Seal-O-Ring	436-2656
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7W-7546	Gasket-Plate	433-8187
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-6191	Sleeve-Bolt	226-0234
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8P-7790	Valve Gp-Press	247-4437
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
9M-2744	Cone-Spl Tapered	380-1480

70J		
Original Part Number	Part Name	Classic Part Number
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1768	Pipe-Ext Exhaust	380-7544
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9Y-1798	Seal-Water	379-0165
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
391-8229	Kit-Gasket-Fs	398-2955
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0969	Bearing-Sleeve	453-6497
1T-1078	Bearing-Thrust	384-4802
5M-6126	Bearing	377-7433
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
7M-1154	Bearing-Spl	417-4515

Sales Model 977K (Cont'd.)

70J		
Original Part Number	Part Name	Classic Part Number
8H-8175	Bearing-Sleeve	376-3636
9M-1997	Bearing-Ball	384-5954

70J		
Original Part Number	Part Name	Classic Part Number
9M-2042	Race-Roller Brg	417-9500
9M-2744	Cone-Spl Tapered	380-1480

70J		
Original Part Number	Part Name	Classic Part Number
106-7799	Bearing-Ball	396-9947

Sales Model 977L

11K		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1006	Strip-Guard	226-0245
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-5331	Cylinder-Adj	226-0214
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0969	Bearing-Sleeve	453-6497
1T-1078	Bearing-Thrust	384-4802
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981

11K		
Original Part Number	Part Name	Classic Part Number
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2K-4442	Bearing-Sleeve	308-9812
2K-4507	Bearing-Sleeve	325-6021
2M-0369	Pilot-Spring R	226-0226
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-7116	Strip-Tapping	384-3480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2744	Muffler As.	247-2664
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553

11K		
Original Part Number	Part Name	Classic Part Number
2P-4611	Pipe-Exhaust	365-8821
2P-6245	Shaft As-Pump	325-6197
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-7637	Pump Gp-Vn Bsc-A	422-8148
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3P-1885	Spring-Recoil	375-5449
3P-2822	Retainer	422-3509
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-5003	Spring As-Arm	383-2127
4K-0300	Bearing-Sleeve	308-9817

Sales Model 977L (Cont'd.)

11K		
Original Part Number	**Part Name**	**Classic Part Number**
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-7188	Core As-Oclr	374-7501
5G-3612	Cap Gp-Protn	295-6419
5K-2294	Bearing	396-9912
5K-6377	Pin	241-2610
5K-6383	Pin	241-2612
5K-7995	Bearing-Sleeve	308-9820
5L-6326	Bearing-Ball	420-3222
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6210	Shaft-Planet	219-9683

11K		
Original Part Number	**Part Name**	**Classic Part Number**
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6670	Shaft-Sprocket	216-7847
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4442	Rod End-Special	373-5388

11K		
Original Part Number	**Part Name**	**Classic Part Number**
6K-8088	Bearing-Roller	399-4428
6N-0622	Elbow-Exhaust	380-7534
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6T-1980	Collar-Idler End	226-0210
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9547	Pin As.-Drawbar	295-0414
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-6681	Cage As	216-7860
7H-4566	Cup-Roller Brg	399-6068
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
7J-9731	Bearing-Sleeve	308-9822
7K-5448	Cup-Bearing	415-1922
7K-9528	Bearing-Sleeve	308-9828
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451

Sales Model 977L (Cont'd.)

11K		
Original Part Number	Part Name	Classic Part Number
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-1383	Rod-Tie	299-2051
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249

11K		
Original Part Number	Part Name	Classic Part Number
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-5778	Bearing-Sleeve	374-8359
8M-0874	Plunger As-Valve	311-9439
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

11K		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-0621	Nut-Adjusting	451-0746
8P-4537	Pinion-Reduction	216-7867
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875

Sales Model 977L (Cont'd.)

11K		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2744	Cone-Spl Tapered	380-1480
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-3436	Holder As-Cage	216-7875
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-9000	Shaft-Ster Cl	217-7738
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1768	Pipe-Ext Exhaust	380-7544

11K		
Original Part Number	**Part Name**	**Classic Part Number**
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
149-5985	Stator-Converter	419-1865
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

11K		
Original Part Number	**Part Name**	**Classic Part Number**
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

14X		
Original Part Number	**Part Name**	**Classic Part Number**
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1006	Strip-Guard	226-0245
1P-1367	Plunger-Valve	432-8913

14X		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1897	Gear-Final Drive	215-1670
1P-4110	Disc-Friction	433-9858
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-5331	Cylinder-Adj	226-0214
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0655	Bearing-Thrust	377-7409

14X		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0969	Bearing-Sleeve	453-6497
1T-1078	Bearing-Thrust	384-4802
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981

Sales Model 977L (Cont'd.)

14X		
Original Part Number	Part Name	Classic Part Number
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2K-4507	Bearing-Sleeve	325-6021
2M-0369	Pilot-Spring R	226-0226
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-7116	Strip-Tapping	384-3480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-6245	Shaft As-Pump	325-6197
2S-5551	Coupling-Exhaust	398-2934
2S-7603	Drum-Steer Cl Dr	213-6951
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088

14X		
Original Part Number	Part Name	Classic Part Number
2W-9978	Core As-Oclr	279-4983
3G-7637	Pump Gp-Vn Bsc-A	422-8148
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3P-1885	Spring-Recoil	375-5449
3P-2822	Retainer	422-3509
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-5003	Spring As-Arm	383-2127
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4S-8708	Housing-Clutch	216-3557

14X		
Original Part Number	Part Name	Classic Part Number
4S-8718	Cage-Carrier Brg	217-7724
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
5K-2294	Bearing	396-9912
5K-6383	Pin	241-2612
5K-7995	Bearing-Sleeve	308-9820
5L-6326	Bearing-Ball	420-3222
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6670	Shaft-Sprocket	216-7847
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437

Sales Model 977L (Cont'd.)

14X		
Original Part Number	Part Name	Classic Part Number
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4442	Rod End-Special	373-5388
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6T-1980	Collar-Idler End	226-0210
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9547	Pin As.-Drawbar	295-0414
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-6681	Cage As	216-7860
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357

14X		
Original Part Number	Part Name	Classic Part Number
7K-2135	Bearing-Roller	417-4492
7K-9528	Bearing-Sleeve	308-9828
7M-1154	Bearing-Spl	417-4515
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989

14X		
Original Part Number	Part Name	Classic Part Number
8F-6058	Bearing-Sleeve	416-5494
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-5778	Bearing-Sleeve	374-8359
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623

Sales Model 977L (Cont'd.)

14X		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0621	Nut-Adjusting	451-0746
8P-4537	Pinion-Reduction	216-7867
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9L-2685	Rod End	419-1866
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963

14X		
Original Part Number	Part Name	Classic Part Number
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2744	Cone-Spl Tapered	380-1480
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-3436	Holder As-Cage	216-7875
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891

14X		
Original Part Number	Part Name	Classic Part Number
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
149-5985	Stator-Converter	419-1865
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259

Sales Model 977L (Cont'd.)

14X		
Original Part Number	**Part Name**	**Classic Part Number**
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	217-7738
219-9693	Shaft-Classic	216-7876
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438

14X		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349

14X		
Original Part Number	**Part Name**	**Classic Part Number**
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
1M-4095	Bearing-Inner	417-9486

48J		
Original Part Number	**Part Name**	**Classic Part Number**
1M-6573	Cup-Roller Brg	399-4438
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0969	Bearing-Sleeve	453-6497
1T-1078	Bearing-Thrust	384-4802
1W-3900	Gasket	472-8006
2P-0220	Gasket-Pump	398-2927
3L-1425	Bearing-Ball	311-9356
4W-0452	Seal As -Cshaft	325-6191
5M-6126	Bearing	377-7433

48J		
Original Part Number	**Part Name**	**Classic Part Number**
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
6N-7263	Gasket-Cyl Head	380-7386
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
7C-4297	Seal As-Cshaft	325-6192
7M-1154	Bearing-Spl	417-4515
7N-7386	Gasket-Cyl Head	392-4519

48J		
Original Part Number	**Part Name**	**Classic Part Number**
7S-3206	Seal-O-Ring	436-2656
8C-8741	Kit-Gasket-(Rs)	438-0172
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8S-9686	Gasket Kit	393-5215
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
9M-2744	Cone-Spl Tapered	380-1480
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
391-8229	Kit-Gasket-Fs	398-2955

64X		
Original Part Number	**Part Name**	**Classic Part Number**
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1P-8554	Coupling-Exhaust	325-6052
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107

64X		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0969	Bearing-Sleeve	453-6497
1T-1078	Bearing-Thrust	384-4802
2P-2406	Pulley	264-5870
2P-2744	Muffler As.	247-2664
2P-2784	Ejector As-Exh	367-6063
2P-4611	Pipe-Exhaust	365-8821
2S-5551	Coupling-Exhaust	398-2934
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270

64X		
Original Part Number	**Part Name**	**Classic Part Number**
5M-5856	Pipe-Extension	373-1913
5M-6126	Bearing	377-7433
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
6N-0622	Elbow-Exhaust	380-7534

Sales Model 977L (Cont'd.)

64X		
Original Part Number	Part Name	Classic Part Number
6N-0731	Muffler As-Exh	382-8018
6N-2789	Pulley	264-5886
6N-7263	Gasket-Cyl Head	380-7386
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
7M-1154	Bearing-Spl	417-4515
7N-1164	Mount As	295-5451
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848

64X		
Original Part Number	Part Name	Classic Part Number
7N-8018	Seal-Water	418-1964
7S-4097	Adapter-Exh Man	383-3700
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7W-7546	Gasket-Plate	433-8187
8H-8175	Bearing-Sleeve	376-3636
8N-0111	Mount As	374-1452
9M-1997	Bearing-Ball	384-5954

64X		
Original Part Number	Part Name	Classic Part Number
9M-2042	Race-Roller Brg	417-9500
9M-2744	Cone-Spl Tapered	380-1480
9S-1768	Pipe-Ext Exhaust	380-7544
9Y-1798	Seal-Water	379-0165
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220

70J		
Original Part Number	Part Name	Classic Part Number
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1P-1006	Strip-Guard	226-0245
1S-3743	Bearing-Ball	384-4786
1S-5331	Cylinder-Adj	226-0214
1T-0043	Bearing-Ball	390-5294
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0969	Bearing-Sleeve	453-6497
1T-1078	Bearing-Thrust	384-4802
1W-3900	Gasket	472-8006
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2F-5721	Bearing-Ball	311-9354
2M-0369	Pilot-Spring R	226-0226
2M-7116	Strip-Tapping	384-3480
2P-0220	Gasket-Pump	398-2927
3G-7637	Pump Gp-Vn Bsc-A	422-8148
3L-1425	Bearing-Ball	311-9356
3P-2822	Retainer	422-3509
3T-4482	Guide-Frt Idler	226-0248
4D-4065	Rod End-Spher	374-1824
4F-5003	Spring As-Arm	383-2127

70J		
Original Part Number	Part Name	Classic Part Number
4K-0300	Bearing-Sleeve	308-9817
4N-7693	Crankshaft As	269-8763
4W-0452	Seal As -Cshaft	325-6191
5K-6377	Pin	241-2610
5K-6383	Pin	241-2612
5K-7995	Bearing-Sleeve	308-9820
5M-5856	Pipe-Extension	373-1913
5M-6126	Bearing	377-7433
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
6H-3957	Bearing-Ball	311-9358
6N-7263	Gasket-Cyl Head	380-7386
6T-1980	Collar-Idler End	226-0210
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
7H-4566	Cup-Roller Brg	399-6068
7J-9346	Bearing-Sleeve	374-8357

70J		
Original Part Number	Part Name	Classic Part Number
7K-5448	Cup-Bearing	415-1922
7M-1154	Bearing-Spl	417-4515
7N-8018	Seal-Water	418-1964
7S-1234	Bushing As-Spt	394-0192
7S-3206	Seal-O-Ring	436-2656
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7W-7546	Gasket-Plate	433-8187
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-6191	Sleeve-Bolt	226-0234
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8P-7790	Valve Gp-Press	247-4437
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
9M-2744	Cone-Spl Tapered	380-1480

Sales Model 977L (Cont'd.)

70J		
Original Part Number	**Part Name**	**Classic Part Number**
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1768	Pipe-Ext Exhaust	380-7544
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

70J		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-1798	Seal-Water	379-0165
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194

70J		
Original Part Number	**Part Name**	**Classic Part Number**
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
391-8229	Kit-Gasket-Fs	398-2955

95X		
Original Part Number	**Part Name**	**Classic Part Number**
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1N-3576	Block Gp-Cyl	279-4978
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0969	Bearing-Sleeve	453-6497
1T-1078	Bearing-Thrust	384-4802
1W-3900	Gasket	472-8006
1W-5300	Rotocoil As	443-2659
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2W-2621	Valve-Inlet	247-6892
3T-4482	Guide-Frt Idler	226-0248
4S-9062	Cap-Fd Bearing	226-0204
4W-0452	Seal As -Cshaft	325-6191
5M-6126	Bearing	377-7433
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929

95X		
Original Part Number	**Part Name**	**Classic Part Number**
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-6795	Chamber As	242-3437
5S-9080	Pulley-Alt Drive	264-5883
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7M-1154	Bearing-Spl	417-4515
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-8018	Seal-Water	418-1964
7S-3206	Seal-O-Ring	436-2656
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8H-8175	Bearing-Sleeve	376-3636

95X		
Original Part Number	**Part Name**	**Classic Part Number**
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585
8S-3970	Chamber As	242-3438
9H-5797	Plunger As-Pump	391-9891
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
9M-2744	Cone-Spl Tapered	380-1480
9M-4789	Shaft-Gov Cont	297-7256
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 983

38K		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1L-7319	Cup-Roller Brg	380-7499
1M-3917	Shaft	386-4915
1M-8776	Bearing-Roller	417-4516
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046
1P-1367	Plunger-Valve	432-8913
1P-3318	Strip	385-7206
1P-4145	Valve Gp-Press	247-4436
1P-7590	Support As-Fr	213-4400
1S-2233	Bearing-Sleeve	379-0188
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0861	Impeller-Conv	421-1715
1T-0969	Bearing-Sleeve	453-6497
1T-1078	Bearing-Thrust	384-4802
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-2811	Race-Spl Rlr Brg	417-4528
2P-3839	Crankshaft As	398-2968
2S-3946	Gear-Final Drive	215-1678
2S-3966	Ring-Seal	297-7237
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541

38K		
Original Part Number	Part Name	Classic Part Number
2S-6401	Cup-Roller Brg	380-7497
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2S-7931	Bearing-Sleeve	387-2904
3G-7660	Cartridge Gp	422-8103
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3S-3875	Screen-Suction	435-4849
3S-9669	Bearing	416-2168
3T-3150	Guide-Frt Idler	394-0191
4B-7255	Cone-Bearing	386-4951
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-5003	Spring As-Arm	383-2127
4J-1612	Pin	308-9896
4J-2379	Bearing-Sleeve	393-1014
4N-4864	Pump Gp-F Tfr	242-3442
4P-7731	Core Gp-O Clr	385-7228
4S-5367	Mount As	375-9986
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5G-3612	Cap Gp-Protn	295-6419
5K-2294	Bearing	396-9912
5L-6326	Bearing-Ball	420-3222
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-2054	Bearing	380-7510
5M-3499	Shaft-Planet	319-3475
5M-3560	Bearing-Sleeve	392-4521
5M-3941	Shaft-Planet	215-1691
5M-3942	Shaft-Planet	215-1692
5M-5822	Gear-Pump Drive	247-4120
5M-6674	Guard-F Idler Lh	226-2736

38K		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4863	Holder As-Cage	215-1732
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6K-4442	Rod End-Special	373-5388
6K-8088	Bearing-Roller	399-4428
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
7E-5085	Bushing	377-5829
7F-9547	Pin As.-Drawbar	295-0414
7G-2517	Gear-Planet	213-8747
7G-2521	Gear-Planet	213-8749
7G-6576	Cage As	216-7859
7J-9344	Bearing-Sleeve	360-2334
7K-5448	Cup-Bearing	415-1922
7M-2167	Ring-Gov Cont	308-9919
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-2957	Cover-Rad Cap	361-1722
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-7973	Guard-Fd Wear	213-9110
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512

Track Loaders

Sales Model 983 (Cont'd.)

38K		
Original Part Number	**Part Name**	**Classic Part Number**
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734
8P-8221	Plate-Guide	226-2748

38K		
Original Part Number	**Part Name**	**Classic Part Number**
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
9P-0620	Cage-Pinion Brg	221-1052
9S-1195	Pump As-Oil	390-1000
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5746	Ferrule-Seal	392-4493

38K		
Original Part Number	**Part Name**	**Classic Part Number**
9S-6875	Pinion-Final Dr	217-7705
9S-9696	Spider As-Fan	383-3707
114-0468	Pin-G.E.T.	443-1203
128-3935	Bearing-Race	396-9897
149-5985	Stator-Converter	419-1865
156-8206	Kit-Dt Gasket	451-3112
162-3904	Pump As-F Prm	391-1102

Sales Model 983B

58X		
Original Part Number	**Part Name**	**Classic Part Number**
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1L-7319	Cup-Roller Brg	380-7499
1M-8776	Bearing-Roller	417-4516
1M-9444	Retainer-Spring	299-2046
1P-1367	Plunger-Valve	432-8913
1P-3318	Strip	385-7206
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0861	Impeller-Conv	421-1715
1T-0969	Bearing-Sleeve	453-6497
1T-1078	Bearing-Thrust	384-4802
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174

58X		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9454	Cup-Roller Brg	415-1914
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-2811	Race-Spl Rlr Brg	417-4528
2P-8986	Cup-Rlr Bearing	415-1912
2S-5100	Valve-Ball	386-3049
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2S-6401	Cup-Roller Brg	380-7497
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2S-7931	Bearing-Sleeve	387-2904
2W-3391	Body As-F Inj V	383-3687
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017

58X		
Original Part Number	**Part Name**	**Classic Part Number**
3G-7660	Cartridge Gp	422-8103
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-2414	Housing-Clutch	391-9831
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3245	Shaft-Planet	308-9924
3P-3246	Shaft-Planet	308-9925
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-9366	Piston-Clutch	391-9861
3S-3875	Screen-Suction	435-4849
3S-9669	Bearing	416-2168
3T-2139	Housing As-Cl	394-2583
3T-3150	Guide-Frt Idler	394-0191
4B-7255	Cone-Bearing	386-4951
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-5003	Spring As-Arm	383-2127
4J-1612	Pin	308-9896
4M-0410	Gear-Oil Pump Dr	428-6660

Sales Model 983B (Cont'd.)

58X		
Original Part Number	Part Name	Classic Part Number
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5K-2294	Bearing	396-9912
5L-6326	Bearing-Ball	420-3222
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-5822	Gear-Pump Drive	247-4120

58X		
Original Part Number	Part Name	Classic Part Number
5M-6126	Bearing	377-7433
5M-6674	Guard-F Idler Lh	226-2736
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5P-8053	Kit-Gasket (Sch)	415-1901
5P-9301	Bearing-Spl Ball	417-4496
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5V-5866	Pin As.	361-1707
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8860	Cup-Roller Brg	380-7495
6K-4442	Rod End-Special	373-5388
6K-8088	Bearing-Roller	399-4428
6L-8968	Coupling-Exhaust	311-9381
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-2687	Spider As.-Fan	385-7199
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-8992	Adapter-Fan	394-9810
6P-6739	Shaft-Planet	308-9929
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451

58X		
Original Part Number	Part Name	Classic Part Number
7C-6697	Shaft - Idler	425-9370
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7F-9547	Pin As.-Drawbar	295-0414
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7G-6576	Cage As	216-7859
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1220	Plunger As-Pump	419-4743
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-8371	Line As-Fuel Inj	373-1901
7N-8957	Gear-Crankshaft	422-2652
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192

Sales Model 983B (Cont'd.)

58X		
Original Part Number	**Part Name**	**Classic Part Number**
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8N-9622	Bracket As-Fan	433-2024
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734
8P-8221	Plate-Guide	226-2748
8R-4265	Collet	384-3462
8R-4268	Collet	384-3461
8S-6511	Bearing-Sleeve	380-7372
9L-2685	Rod End	419-1866
9M-1990	Dowel-Reaction	386-4963
9M-3025	Cover As	299-2001
9N-3668	Base As.-Coolant	419-4718
9P-0620	Cage-Pinion Brg	221-1052
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-6875	Pinion-Final Dr	217-7705
9W-2977	Hub As	423-6985
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563

58X		
Original Part Number	**Part Name**	**Classic Part Number**
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
112-7309	Shaft-Planet	380-7521
114-0468	Pin-G.E.T.	443-1203
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
141-9792	Gasket Kit - Ocl	393-3632

58X		
Original Part Number	**Part Name**	**Classic Part Number**
145-8503	Shaft As-Idler	426-0035
149-5985	Stator-Converter	419-1865
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
164-4891	Plate As.	391-1093
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
233-7083	Kit-Gasket-Fs	387-2919
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812

Cat Classic Parts for Track-Type Tractors

Cat Track-Type tractors have always been built to provide maximum productivity and profitability in any application. Caterpillar has been setting industry standards with this product Line since its introduction. As. the machine ages, maintenance costs need to be re-evaluated to continue to ensure that maximum profitability. Cat Classic parts are offered for several models of Track-Type tractors As. a competitively priced alternative to aftermarket parts. This parts product Line is intended to help you manage these maintenance costs.

Cat Classic parts provide owners of older Cat products with low cost Repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts coverage for Track-Type tractors includes:

- Engine
- Final Drive
- Moving U/C
- Non-moving U/C
- SteeRing
- Transmission
- Trunnion Assembly
- Winch
- ...and many more.

Sales Model 6

10A		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1642	Hub-Gear	219-2976
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-0176	Flange-Drum	223-4810
1M-7250	Bowl	360-2296
1M-9177	Plate-Cl Press	226-6112
1S-1888	Bracket-Lamp	297-7147
1S-1967	Chamber As	247-3291
1S-5331	Cylinder-Adj	226-0214
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174

10A		
Original Part Number	**Part Name**	**Classic Part Number**
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2F-7576	Shaft-Sprocket	226-6071
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4507	Bearing-Sleeve	325-6021
2P-9660	Gear	226-5995
2S-1273	Chamber As	319-3434
2S-1477	Holder As-Cage	226-7985

10A		
Original Part Number	**Part Name**	**Classic Part Number**
2S-4015	Plunger As-Valve	311-9438
3B-8845	Bearing-Inner	417-4509
3F-1972	Retainer As	226-7988
3P-3623	Lock-Adj Nut	226-7989
3P-5754	Hub-Gear	219-2976
3S-7153	Gear-Sliding	227-0024
4B-1455	Cap As-Filler	361-1719
4F-1252	Pin	295-5704
4F-5003	Spring As-Arm	383-2127
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996
4M-0410	Gear-Oil Pump Dr	428-6660
4S-8005	Pinion-Fdr	226-6076
5A-9551	Gear-Finaldrive	226-7979

Sales Model 6 (Cont'd.)

10A		
Original Part Number	Part Name	Classic Part Number
5F-0736	Pin-Pivot	256-4823
5F-2256	Cage-Bearing	226-7973
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5M-6709	Check As-Ball	380-7542
5M-9644	Bearing-Outer	384-5929
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5S-1211	Cover-Valve	314-8665
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009
6H-3957	Bearing-Ball	311-9358
6P-0169	Hub-Fly Clutch	297-7204
7B-5088	Drum-Steer Cl Dr	223-4813
7F-9547	Pin As.-Drawbar	295-0414
7G-6044	Cage As	216-7857
7H-1318	Coupling-Ster Cl	226-8002

10A		
Original Part Number	Part Name	Classic Part Number
7H-4566	Cup-Roller Brg	399-6068
7H-6967	Bearing-Ball	422-6489
7K-5448	Cup-Bearing	415-1922
7M-1154	Bearing-Spl	417-4515
7M-4603	Body-Fuel Valve	311-9348
7M-9398	Plate-Guide	297-7230
7S-7602	Pump Gp-Cl Oil	226-0174
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7T-0206	Bearing-Brace	297-7144
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8H-1383	Rod-Tie	299-2051
8H-4320	Bearing-Ball	419-2301
8H-7980	Piston	226-0249
8M-8068	Bearing-Spl Ball	417-4500
8P-1182	Shaft	227-4771

10A		
Original Part Number	Part Name	Classic Part Number
8P-1183	Gear-Bevel	226-7980
9B-0399	Link As-Cl Drive	431-5268
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9J-9598	Pin	296-1362
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-1677	Bearing	297-7145
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
160-6306	Cap-Bearing	325-6038
228-7325	Ster Cl Kit-Cla	230-7119
308-1845	Seal-Wiper	472-8032

Sales Model 15

07C		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354

07C		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
3L-1425	Bearing-Ball	311-9356

07C		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
9L-2685	Rod End	419-1866

Sales Model 15HC

01D		
Original Part Number	Part Name	Classic Part Number
1T-0210	Bearing-Ball	417-4498
2F-5721	Bearing-Ball	311-9354

01D		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
7L-7508	Bearing-Ball	420-6536

Sales Model 20

00L		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482

00L		
Original Part Number	Part Name	Classic Part Number
1T-0210	Bearing-Ball	417-4498
2L-5271	Bearing-Ball	371-4305

00L		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
9L-2685	Rod End	419-1866

Sales Model 22

01J		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
2H-3712	Bearing-Ball	392-4488
7W-2731	Retainer	423-3541
8H-9789	Bearing-Ball	374-8342
9L-2685	Rod End	419-1866

01J		
Original Part Number	Part Name	Classic Part Number
108-5603	Screw-Adj Arm	379-0166
1A-2846	Cap As-Filler	311-9368
2H-3712	Bearing-Ball	392-4488
7W-2731	Retainer	423-3541

01J		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
9L-2685	Rod End	419-1866
108-5603	Screw-Adj Arm	379-0166

Sales Model 25

03C		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1T-0210	Bearing-Ball	417-4498

03C		
Original Part Number	Part Name	Classic Part Number
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305

03C		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
9L-2685	Rod End	419-1866

Sales Model 28

04F		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1B-3924	Cone-Roller Brg	422-6482

04F		
Original Part Number	Part Name	Classic Part Number
1T-0210	Bearing-Ball	417-4498
2H-3712	Bearing-Ball	392-4488
9L-2685	Rod End	419-1866

Sales Model 30

00S		
Original Part Number	Part Name	Classic Part Number
1T-0210	Bearing-Ball	417-4498
5F-8651	Bearing-Ball	420-3223

Sales Model 30/30

9XW		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
2A-4429	Lock-Retainer	379-0174
2S-7931	Bearing-Sleeve	387-2904
2W-7213	Bearing-Sleeve	419-4667
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3K-2511	Dowel-Reaction	383-2126
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3P-3208	Flange-Joint	301-4647
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
4F-2393	Bearing-Ball	380-1499
4K-0299	Bearing-Sleeve	308-9816
4M-3915	Bearing-Caged	377-7427
4S-8472	Hood As-PrecInr	296-1355
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502

9XW		
Original Part Number	Part Name	Classic Part Number
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
5T-1362	Univ Joint As-5C	325-6011
6D-0217	Bearing-Sleeve	325-6022
6I-1099	Manifold-Exh	424-6366
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-7500	Retainer	383-2104
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6S-3463	Bearing-Sleeve	374-6513
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6T-0064	Shaft-Planet	295-6442
6T-2293	Piston-Load	426-0040
6Y-1690	Carrier-Ring	384-3849
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7G-2830	Ring-Seal	295-6441
7G-7431	Piston-Selector	432-8911
7G-7724	Piston-Clutch	283-5206
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-8893	Cone-Roller Brg	374-1846
7J-9884	Bearing-Sleeve	325-6016

9XW		
Original Part Number	Part Name	Classic Part Number
7T-4754	Impeller-Conv	385-7231
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8D-1817	Cup-Roller Brg	434-3296
8D-2459	Gear-Planet	390-5293
8E-6221	Pin	325-6155
8H-5352	Bearing-Ball	453-3658
8P-0953	Turbine-Conv	297-7269
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8W-4523	Bearing-Sleeve	385-3798
9G-0280	Piston	283-5213
9J-3206	Bearing-Spher	360-2275
9M-1328	Bearing-Aligning	325-6018
9P-8517	Case-Xmsn	394-0909
9S-5279	Bearing-Inner	453-3661
9W-7481	Gear-Planet	295-6431
9W-9931	Mount As.	360-2354
100-4529	Piston As	424-6368
100-6174	Cyl Gp-0089 0421	425-9368
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
106-7799	Bearing-Ball	396-9947
107-7708	Bearing-Main	419-6381
112-5495	Joint Gp-Univ	297-4858
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5984	Ring-Backup	419-4654

Sales Model 30/30 (Cont'd.)

9XW		
Original Part Number	Part Name	Classic Part Number
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
136-7813	Bearing-Race	460-8296
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
176-3900	Accumulator	416-5513

9XW		
Original Part Number	Part Name	Classic Part Number
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
221-9755	Gear-Planet	390-5293
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

9XW		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441

Sales Model 35

05C		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-4043	Cone-Roller Brg	377-7395
1B-4102	Bearing-Ball	399-4426

05C		
Original Part Number	Part Name	Classic Part Number
1T-0210	Bearing-Ball	417-4498
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
3L-1425	Bearing-Ball	311-9356
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499

05C		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
8B-5972	Bearing-Ball	314-8503
9B-0399	Link As-Cl Drive	431-5268
9L-2685	Rod End	419-1866
108-5603	Screw-Adj Arm	379-0166

06E		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-4043	Cone-Roller Brg	377-7395
1B-4102	Bearing-Ball	399-4426
1T-0210	Bearing-Ball	417-4498

06E		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2H-3712	Bearing-Ball	392-4488
3B-1142	Retainer-Spring	391-1099
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
6H-3957	Bearing-Ball	311-9358

06E		
Original Part Number	Part Name	Classic Part Number
7M-4926	Retainer-Piston	314-8538
8B-5972	Bearing-Ball	314-8503
8F-8523	Bearing-Sleeve	383-3701
8H-4320	Bearing-Ball	419-2301
9B-0399	Link As-Cl Drive	431-5268
9L-2685	Rod End	419-1866
9Y-9431	Precleaner As	361-1718

1TJ		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1M-8736	Cup-Roller Brg	423-7759

1TJ		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2D-5658	Bearing-Ball	301-4628

1TJ		
Original Part Number	Part Name	Classic Part Number
2H-3712	Bearing-Ball	392-4488
2W-7213	Bearing-Sleeve	419-4667

Sales Model 35 (Cont'd.)

1TJ		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
4F-2393	Bearing-Ball	380-1499
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-7936	Bearing-Outer	386-4953
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
7C-3760	Tube As-O Drain	375-5443
7C-4349	Mount As	383-2117
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

1TJ		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8T-0209	Race-Spl Rlr Brg	384-5951
9S-3581	Cup-Roller Brg	415-1923
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381

1TJ		
Original Part Number	Part Name	Classic Part Number
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

3HS		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2W-7213	Bearing-Sleeve	419-4667
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
4B-7270	Cone-Bearing	399-4439

3HS		
Original Part Number	Part Name	Classic Part Number
4F-2393	Bearing-Ball	380-1499
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-7936	Bearing-Outer	386-4953
5P-6254	Bearing	420-2495

3HS		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
6B-3223	Cup-Bearing	399-6065
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
7C-3760	Tube As-O Drain	375-5443
7C-4349	Mount As	383-2117
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

Sales Model 35 (Cont'd.)

3HS		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8T-0209	Race-Spl Rlr Brg	384-5951

3HS		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
136-0819	Valve-Exhaust	384-8697

3HS		
Original Part Number	Part Name	Classic Part Number
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

8DN		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2W-7213	Bearing-Sleeve	419-4667
3T-4568	Shaft-Planet	314-8712
4B-7270	Cone-Bearing	399-4439
4D-3882	Cone-Roller Brg	399-6060
4F-2393	Bearing-Ball	380-1499
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603

8DN		
Original Part Number	Part Name	Classic Part Number
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-7936	Bearing-Outer	386-4953
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
6B-3223	Cup-Bearing	399-6065
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-2202	Bearing-Spl Ball	380-1574
7C-3760	Tube As-O Drain	375-5443
7C-4349	Mount As	383-2117
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449

8DN		
Original Part Number	Part Name	Classic Part Number
7E-7302	Bracket	416-5497
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
8T-0209	Race-Spl Rlr Brg	384-5951
9S-3581	Cup-Roller Brg	415-1923
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

Sales Model 35 (Cont'd.)

8DN		
Original Part Number	Part Name	Classic Part Number
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694

8DN		
Original Part Number	Part Name	Classic Part Number
126-5984	Ring-Backup	419-4654
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372

8DN		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

8RD		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2W-7213	Bearing-Sleeve	419-4667
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
4B-7270	Cone-Bearing	399-4439
4F-2393	Bearing-Ball	380-1499
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-7936	Bearing-Outer	386-4953
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
6B-3223	Cup-Bearing	399-6065
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919

8RD		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
7C-3760	Tube As-O Drain	375-5443
7C-4349	Mount As	383-2117
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8T-0209	Race-Spl Rlr Brg	384-5951
9S-3581	Cup-Roller Brg	415-1923
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671

8RD		
Original Part Number	Part Name	Classic Part Number
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

Sales Model 35 (Cont'd.)

9DF		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2W-7213	Bearing-Sleeve	419-4667
3T-4568	Shaft-Planet	314-8712
4B-7270	Cone-Bearing	399-4439
4D-3882	Cone-Roller Brg	399-6060
4F-2393	Bearing-Ball	380-1499
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-7936	Bearing-Outer	386-4953
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
6B-3223	Cup-Bearing	399-6065
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495

9DF		
Original Part Number	Part Name	Classic Part Number
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-2202	Bearing-Spl Ball	380-1574
7C-3760	Tube As-O Drain	375-5443
7C-4349	Mount As	383-2117
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8S-0248	Breather As	325-6033
8T-0209	Race-Spl Rlr Brg	384-5951
9S-3581	Cup-Roller Brg	415-1923
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756

9DF		
Original Part Number	Part Name	Classic Part Number
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

ADK		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2W-7213	Bearing-Sleeve	419-4667

ADK		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
4F-2393	Bearing-Ball	380-1499
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596

ADK		
Original Part Number	Part Name	Classic Part Number
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-7936	Bearing-Outer	386-4953
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
6I-1099	Manifold-Exh	424-6366

Sales Model 35 (Cont'd.)

ADK		
Original Part Number	**Part Name**	**Classic Part Number**
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
7C-3760	Tube As-O Drain	375-5443
7C-4349	Mount As	383-2117
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583

ADK		
Original Part Number	**Part Name**	**Classic Part Number**
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8T-0209	Race-Spl Rlr Brg	384-5951
9S-3581	Cup-Roller Brg	415-1923
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693

ADK		
Original Part Number	**Part Name**	**Classic Part Number**
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

Sales Model 40

03G		
Original Part Number	**Part Name**	**Classic Part Number**
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0210	Bearing-Ball	417-4498

03G		
Original Part Number	**Part Name**	**Classic Part Number**
2H-3712	Bearing-Ball	392-4488
3L-1425	Bearing-Ball	311-9356
4F-2041	Cup-Roller Brg	418-9609
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555

03G		
Original Part Number	**Part Name**	**Classic Part Number**
6H-3957	Bearing-Ball	311-9358
8B-5972	Bearing-Ball	314-8503
8H-4320	Bearing-Ball	419-2301

05G		
Original Part Number	**Part Name**	**Classic Part Number**
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443

05G		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0210	Bearing-Ball	417-4498
2H-3712	Bearing-Ball	392-4488
3L-1425	Bearing-Ball	311-9356

05G		
Original Part Number	**Part Name**	**Classic Part Number**
4F-2041	Cup-Roller Brg	418-9609
6H-3957	Bearing-Ball	311-9358
8B-5972	Bearing-Ball	314-8503

Sales Model 45

1DR		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2W-7213	Bearing-Sleeve	419-4667
3T-4568	Shaft-Planet	314-8712
4B-7270	Cone-Bearing	399-4439
4D-3882	Cone-Roller Brg	399-6060
4F-2393	Bearing-Ball	380-1499
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-7936	Bearing-Outer	386-4953
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
6B-3223	Cup-Bearing	399-6065
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495

1DR		
Original Part Number	Part Name	Classic Part Number
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-2202	Bearing-Spl Ball	380-1574
7C-3760	Tube As-O Drain	375-5443
7C-4349	Mount As	383-2117
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
8T-0209	Race-Spl Rlr Brg	384-5951
9S-3581	Cup-Roller Brg	415-1923

1DR		
Original Part Number	Part Name	Classic Part Number
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

3BK		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488

3BK		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
4F-2393	Bearing-Ball	380-1499
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498

3BK		
Original Part Number	Part Name	Classic Part Number
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775

Sales Model 45 (Cont'd.)

3BK		
Original Part Number	Part Name	Classic Part Number
5M-7936	Bearing-Outer	386-4953
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
7C-3760	Tube As-O Drain	375-5443
7C-4349	Mount As	383-2117
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847

3BK		
Original Part Number	Part Name	Classic Part Number
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8T-0209	Race-Spl Rlr Brg	384-5951
9S-3581	Cup-Roller Brg	415-1923
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219

3BK		
Original Part Number	Part Name	Classic Part Number
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
300-9500	Kit-Gasket-Sch	387-2914
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

4DZ		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2W-7213	Bearing-Sleeve	419-4667
3T-4568	Shaft-Planet	314-8712
4B-7270	Cone-Bearing	399-4439
4D-3882	Cone-Roller Brg	399-6060
4F-2393	Bearing-Ball	380-1499
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064

4DZ		
Original Part Number	Part Name	Classic Part Number
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-7936	Bearing-Outer	386-4953
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
6B-3223	Cup-Bearing	399-6065
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-2202	Bearing-Spl Ball	380-1574

4DZ		
Original Part Number	Part Name	Classic Part Number
7C-3760	Tube As-O Drain	375-5443
7C-4349	Mount As	383-2117
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551

Sales Model 45 (Cont'd.)

4DZ		
Original Part Number	Part Name	Classic Part Number
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8S-0248	Breather As	325-6033
8T-0209	Race-Spl Rlr Brg	384-5951
9S-3581	Cup-Roller Brg	415-1923
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

4DZ		
Original Part Number	Part Name	Classic Part Number
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376

4DZ		
Original Part Number	Part Name	Classic Part Number
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

4KW		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2W-7213	Bearing-Sleeve	419-4667
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
4B-7270	Cone-Bearing	399-4439
4F-2393	Bearing-Ball	380-1499
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-7936	Bearing-Outer	386-4953
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502

4KW		
Original Part Number	Part Name	Classic Part Number
6B-3223	Cup-Bearing	399-6065
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
7C-3760	Tube As-O Drain	375-5443
7C-4349	Mount As	383-2117
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705

4KW		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8T-0209	Race-Spl Rlr Brg	384-5951
9S-3581	Cup-Roller Brg	415-1923
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697

Sales Model 45 (Cont'd.)

4KW		
Original Part Number	Part Name	Classic Part Number
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370

4KW		
Original Part Number	Part Name	Classic Part Number
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

4KW		
Original Part Number	Part Name	Classic Part Number
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

4YL		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2W-7213	Bearing-Sleeve	419-4667
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
4F-2393	Bearing-Ball	380-1499
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-7936	Bearing-Outer	386-4953
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495

4YL		
Original Part Number	Part Name	Classic Part Number
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
7C-3760	Tube As-O Drain	375-5443
7C-4349	Mount As	383-2117
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8T-0209	Race-Spl Rlr Brg	384-5951
9S-3581	Cup-Roller Brg	415-1923
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671

4YL		
Original Part Number	Part Name	Classic Part Number
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

ABF		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1M-8736	Cup-Roller Brg	423-7759

ABF		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2D-5658	Bearing-Ball	301-4628

ABF		
Original Part Number	Part Name	Classic Part Number
2H-3712	Bearing-Ball	392-4488
2W-7213	Bearing-Sleeve	419-4667

Sales Model 45 (Cont'd.)

ABF		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
4B-7270	Cone-Bearing	399-4439
4F-2393	Bearing-Ball	380-1499
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-7936	Bearing-Outer	386-4953
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
6B-3223	Cup-Bearing	399-6065
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
7C-3760	Tube As-O Drain	375-5443
7C-4349	Mount As	383-2117
7C-5403	Tube As	374-4673

ABF		
Original Part Number	Part Name	Classic Part Number
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
7X-7975	Gasket Kit	437-3233
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8T-0209	Race-Spl Rlr Brg	384-5951
9S-3581	Cup-Roller Brg	415-1923
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

ABF		
Original Part Number	Part Name	Classic Part Number
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
300-9500	Kit-Gasket-Sch	387-2914
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

Sales Model 50

01E		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3937	Cup-Roller Brg	377-7394
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443

01E		
Original Part Number	Part Name	Classic Part Number
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
3B-1142	Retainer-Spring	391-1099
3H-1996	Bearing-Ball	380-1498
4B-1455	Cap As-Filler	361-1719

01E		
Original Part Number	Part Name	Classic Part Number
4F-2041	Cup-Roller Brg	418-9609
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
6H-3957	Bearing-Ball	311-9358
7M-4926	Retainer-Piston	314-8538
8F-8523	Bearing-Sleeve	383-3701
8H-4320	Bearing-Ball	419-2301

Sales Model 50 (Cont'd.)

01E		
Original Part Number	Part Name	Classic Part Number
8M-8068	Bearing-Spl Ball	417-4500

01E		
Original Part Number	Part Name	Classic Part Number
9B-0399	Link As-Cl Drive	431-5268

01E		
Original Part Number	Part Name	Classic Part Number
9L-2685	Rod End	419-1866

05A		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3937	Cup-Roller Brg	377-7394
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0210	Bearing-Ball	417-4498

05A		
Original Part Number	Part Name	Classic Part Number
2H-3712	Bearing-Ball	392-4488
3H-1996	Bearing-Ball	380-1498
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-5004	Spring As-Arm	383-2128
5F-8651	Bearing-Ball	420-3223

05A		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
8M-8068	Bearing-Spl Ball	417-4500
9B-0399	Link As-Cl Drive	431-5268
9L-2685	Rod End	419-1866

Sales Model 55

3SM		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2W-7213	Bearing-Sleeve	419-4667
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
4F-2393	Bearing-Ball	380-1499
4M-6107	Bearing-Roller	380-7507
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-7936	Bearing-Outer	386-4953
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919

3SM		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
7C-3760	Tube As-O Drain	375-5443
7C-4349	Mount As	383-2117
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8T-0209	Race-Spl Rlr Brg	384-5951
9S-3581	Cup-Roller Brg	415-1923

3SM		
Original Part Number	Part Name	Classic Part Number
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5984	Ring-Backup	419-4654
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912

Sales Model 55 (Cont'd.)

3SM		
Original Part Number	Part Name	Classic Part Number
277-7089	Shaft As	380-7578

3SM		
Original Part Number	Part Name	Classic Part Number
352-2151	Pump Gp-Water -B	434-6107

5DK		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2W-7213	Bearing-Sleeve	419-4667
3T-4568	Shaft-Planet	314-8712
4B-7270	Cone-Bearing	399-4439
4D-3882	Cone-Roller Brg	399-6060
4F-2393	Bearing-Ball	380-1499
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-7936	Bearing-Outer	386-4953
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
6B-3223	Cup-Bearing	399-6065
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495

5DK		
Original Part Number	Part Name	Classic Part Number
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-2202	Bearing-Spl Ball	380-1574
7C-3760	Tube As-O Drain	375-5443
7C-4349	Mount As	383-2117
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
8T-0209	Race-Spl Rlr Brg	384-5951
9S-3581	Cup-Roller Brg	415-1923
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756

5DK		
Original Part Number	Part Name	Classic Part Number
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

6NN		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482

6NN		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384

6NN		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174

Sales Model 55 (Cont'd.)

6NN		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2W-7213	Bearing-Sleeve	419-4667
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
4B-7270	Cone-Bearing	399-4439
4F-2393	Bearing-Ball	380-1499
4M-6107	Bearing-Roller	380-7507
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-7936	Bearing-Outer	386-4953
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
6B-3223	Cup-Bearing	399-6065
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921

6NN		
Original Part Number	Part Name	Classic Part Number
7C-3760	Tube As-O Drain	375-5443
7C-4349	Mount As	383-2117
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7X-7975	Gasket Kit	437-3233
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8T-0209	Race-Spl Rlr Brg	384-5951
9S-3581	Cup-Roller Brg	415-1923
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756

6NN		
Original Part Number	Part Name	Classic Part Number
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5984	Ring-Backup	419-4654
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107

7DM		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2W-7213	Bearing-Sleeve	419-4667
3T-4568	Shaft-Planet	314-8712
4B-7270	Cone-Bearing	399-4439
4D-3882	Cone-Roller Brg	399-6060

7DM		
Original Part Number	Part Name	Classic Part Number
4F-2393	Bearing-Ball	380-1499
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-7936	Bearing-Outer	386-4953
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502

7DM		
Original Part Number	Part Name	Classic Part Number
6B-3223	Cup-Bearing	399-6065
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-2202	Bearing-Spl Ball	380-1574
7C-3760	Tube As-O Drain	375-5443
7C-4349	Mount As	383-2117
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

Sales Model 55 (Cont'd.)

7DM		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8H-2810	Case As-Filter	314-8512
8S-0248	Breather As	325-6033
8T-0209	Race-Spl Rlr Brg	384-5951

7DM		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
127-3467	Manifold-Exhaust	394-9827
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380

7DM		
Original Part Number	Part Name	Classic Part Number
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
162-4012	Gasket Kit - F	437-8126
163-1387	Gear-Flywheel	374-4697
190-0649	Tightener-Belt	434-1407
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
239-4290	Kit-Gasket-Sch	435-2574
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

7TZ		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2W-7213	Bearing-Sleeve	419-4667
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
4B-7270	Cone-Bearing	399-4439
4F-2393	Bearing-Ball	380-1499
4M-6107	Bearing-Roller	380-7507
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513

7TZ		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-7936	Bearing-Outer	386-4953
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
6B-3223	Cup-Bearing	399-6065
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
7C-3760	Tube As-O Drain	375-5443
7C-4349	Mount As	383-2117
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

7TZ		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8T-0209	Race-Spl Rlr Brg	384-5951
9S-3581	Cup-Roller Brg	415-1923
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756

Sales Model 55 (Cont'd.)

7TZ		
Original Part Number	Part Name	Classic Part Number
9Y-8534	Support-Shft	463-7671
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693

7TZ		
Original Part Number	Part Name	Classic Part Number
119-2940	Gasket	378-4002
126-5984	Ring-Backup	419-4654
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697

7TZ		
Original Part Number	Part Name	Classic Part Number
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107

AEN		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2W-7213	Bearing-Sleeve	419-4667
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
4F-2393	Bearing-Ball	380-1499
4M-6107	Bearing-Roller	380-7507
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-7936	Bearing-Outer	386-4953
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495

AEN		
Original Part Number	Part Name	Classic Part Number
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
7C-3760	Tube As-O Drain	375-5443
7C-4349	Mount As	383-2117
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7F-2742	Bearing-Ball	422-6488
7J-8893	Cone-Roller Brg	374-1846
7K-8877	Cone-Bearing	374-1847
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8T-0209	Race-Spl Rlr Brg	384-5951
9S-3581	Cup-Roller Brg	415-1923
9W-9931	Mount As.	360-2354
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671

AEN		
Original Part Number	Part Name	Classic Part Number
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5984	Ring-Backup	419-4654
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107

Sales Model 65

01C		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1B-3934	Cup-Roller Brg	392-4487

01C		
Original Part Number	Part Name	Classic Part Number
1B-3941	Cone-Roller Brg	422-6486
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305

01C		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
9B-0399	Link As-Cl Drive	431-5268
9L-2685	Rod End	419-1866

7YC		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7115	Mount As	418-1936
1P-7522	Yoke As	382-6893
1P-8554	Coupling-Exhaust	325-6052
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342

7YC		
Original Part Number	Part Name	Classic Part Number
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5539	Core As-Rad	374-7492
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
3B-4124	Cup-Spl Tapered	422-6481
3F-6523	Pin-Clevis	256-4818
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436
3S-3875	Screen-Suction	435-4849
4M-1641	Dowel-Reaction	386-4952
4M-6107	Bearing-Roller	380-7507
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903

7YC		
Original Part Number	Part Name	Classic Part Number
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-9326	Bearing	417-4506
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603

Sales Model 65 (Cont'd.)

7YC		
Original Part Number	Part Name	Classic Part Number
4W-2042	Spacer	325-6217
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
5M-0578	Bearing	419-7775
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9531	Cone-Rlr Bearing	386-4956
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-6043	Bearing-Sleeve	374-1456
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6S-3051	Cup-Rlr Brg	415-1928
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-2202	Bearing-Spl Ball	380-1574
6V-4785	Gasket Kit - Fs	388-0661

7YC		
Original Part Number	Part Name	Classic Part Number
6Y-2027	Disc-Friction	377-7441
7E-5085	Bushing	377-5829
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7G-7431	Piston-Selector	432-8911
7H-4566	Cup-Roller Brg	399-6068
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0619	Pulley-Fan	383-1581
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger As	391-9895
7W-7546	Gasket-Plate	433-8187

7YC		
Original Part Number	Part Name	Classic Part Number
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084

Sales Model 65 (Cont'd.)

7YC		
Original Part Number	Part Name	Classic Part Number
8N-9733	Line As-F Inj	319-8174
8P-1656	Plate-Clutch	367-6071
8R-1693	Pin As	415-1906
8R-6631	Hub	443-2057
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
9B-1320	Valve-Check	377-5832
9D-7924	Mount As	360-2356
9L-5908	Gasket	433-8196
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9V-7710	Univ Joint As	394-8234

7YC		
Original Part Number	Part Name	Classic Part Number
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-4072	Bearing	397-5069
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

7YC		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
173-0888	Univ Jt As	394-0898
190-0649	Tightener-Belt	434-1407
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659
232-3233	Bearing-Main	376-9085
234-8016	Kit-Gasket-Sch	393-0919
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 65B

7YC		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7115	Mount As	418-1936
1P-7522	Yoke As	382-6893
1P-8554	Coupling-Exhaust	325-6052
1P-9593	Cone-Rlr Brg	377-7400

7YC		
Original Part Number	Part Name	Classic Part Number
1P-9594	Bearing-Cup	377-7401
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981

7YC		
Original Part Number	Part Name	Classic Part Number
1W-4506	Adapter-Seal	372-7515
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221

Sales Model 65B (Cont'd.)

7YC		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5539	Core As-Rad	374-7492
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
3B-4124	Cup-Spl Tapered	422-6481
3F-6523	Pin-Clevis	256-4818
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436
3S-3875	Screen-Suction	435-4849
4M-1641	Dowel-Reaction	386-4952
4M-6107	Bearing-Roller	380-7507
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903

7YC		
Original Part Number	Part Name	Classic Part Number
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-9326	Bearing	417-4506
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
5M-0578	Bearing	419-7775
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024

7YC		
Original Part Number	Part Name	Classic Part Number
5P-8772	Gasket Kit	383-1575
5P-9531	Cone-Rlr Bearing	386-4956
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-6043	Bearing-Sleeve	374-1456
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6S-3051	Cup-Rlr Brg	415-1928
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-2202	Bearing-Spl Ball	380-1574
6V-4785	Gasket Kit - Fs	388-0661
6Y-2027	Disc-Friction	377-7441
7E-5085	Bushing	377-5829
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7G-7431	Piston-Selector	432-8911
7H-4566	Cup-Roller Brg	399-6068
7K-2135	Bearing-Roller	417-4492

Sales Model 65B (Cont'd.)

7YC		
Original Part Number	Part Name	Classic Part Number
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0619	Pulley-Fan	383-1581
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

7YC		
Original Part Number	Part Name	Classic Part Number
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1656	Plate-Clutch	367-6071
8R-1693	Pin As	415-1906
8R-6631	Hub	443-2057
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042

7YC		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
9B-1320	Valve-Check	377-5832
9D-7924	Mount As	360-2356
9L-5908	Gasket	433-8196
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9V-7710	Univ Joint As	394-8234
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-4072	Bearing	397-5069
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

Sales Model 65B (Cont'd.)

7YC		
Original Part Number	**Part Name**	**Classic Part Number**
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
173-0888	Univ Jt As	394-0898
190-0649	Tightener-Belt	434-1407

7YC		
Original Part Number	**Part Name**	**Classic Part Number**
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659
232-3233	Bearing-Main	376-9085
234-8016	Kit-Gasket-Sch	393-0919
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357

7YC		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 65C, 65D

2ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1A-9252	Rod End-Yoke	377-5849
1J-2860	Cup-Spl Tapered	374-8347
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-1367	Plunger-Valve	432-8913
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-3958	Bearing-Needle	434-6114
1P-3958	Bearing-Needle	434-6114
1P-7115	Mount As	418-1936
1P-7115	Mount As	418-1936
1P-7522	Yoke As	382-6893
1P-7522	Yoke As	382-6893
1P-9593	Cone-Rlr Brg	377-7400
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9594	Bearing-Cup	377-7401
1S-3062	Director-Water	418-9572
1S-3062	Director-Water	418-9572

2ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
1T-0043	Bearing-Ball	390-5294
1W-1669	Piston	325-6158
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-6987	Valve As-Check	420-6221

2ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9171	Bonnet-Valve	374-4707
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2D-9453	Cone-Roller Brg	380-7508
2K-9295	Bearing-Cone	422-6480
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1738	Plate As-Oil Pan	325-6164
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229

Sales Model 65C, 65D (Cont'd.)

2ZJ		
Original Part Number	Part Name	Classic Part Number
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-2788	Adapter-Fan	390-0984
2P-6245	Shaft As-Pump	325-6197
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-2621	Valve-Inlet	247-6892
2W-5539	Core As-Rad	374-7492
2W-5539	Core As-Rad	374-7492
2W-7213	Bearing-Sleeve	419-4667
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
2W-9978	Core As-Oclr	279-4983
3B-4124	Cup-Spl Tapered	422-6481

2ZJ		
Original Part Number	Part Name	Classic Part Number
3B-4124	Cup-Spl Tapered	422-6481
3K-9608	Guard-Dirt	374-1447
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436
3L-9409	Cup-Roller Brg	399-4436
3S-3875	Screen-Suction	435-4849
3S-3875	Screen-Suction	435-4849
4M-6107	Bearing-Roller	380-7507
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9384	Line As-Fuel Inj	279-4989

2ZJ		
Original Part Number	Part Name	Classic Part Number
4P-9385	Line As-Fuel Inj	279-4986
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4P-9396	Line As-Fuel Inj	383-3691
4P-9942	Seal-End Tank	385-7217
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9943	Seal-End Tank	385-7216
4S-9326	Bearing	417-4506
4S-9326	Bearing	417-4506
4T-8054	Seal As	472-8010
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4W-0452	Seal As -Cshaft	325-6191
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2042	Spacer	325-6217
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-6869	Spacer-Fuel Pump	417-4534
5M-0578	Bearing	419-7775
5M-0578	Bearing	419-7775
5P-7807	Bearing-Ball	314-8502
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8768	Kit-Gasket (Scl)	393-1024

Sales Model 65C, 65D (Cont'd.)

2ZJ		
Original Part Number	Part Name	Classic Part Number
5P-8772	Gasket Kit	383-1575
5P-8772	Gasket Kit	383-1575
5P-9531	Cone-Rlr Bearing	386-4956
5P-9531	Cone-Rlr Bearing	386-4956
5S-4557	Bearing	311-9360
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6B-7469	Spacer	417-4535
6E-0775	Head	425-9373
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6I-8642	Race-Brg Outer	396-9898
6I-8849	Cone-Rlr Bearing	415-1919
6I-8849	Cone-Rlr Bearing	415-1919

2ZJ		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
6I-8860	Cup-Roller Brg	380-7495
6J-6043	Bearing-Sleeve	374-1456
6L-7751	Rod End-Spher	472-8015
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-7174	Shield-Oil	314-8544
6S-3051	Cup-Rlr Brg	415-1928
6S-3051	Cup-Rlr Brg	415-1928
6S-6031	Cup-Rlr Brg	415-1920
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6S-6032	Cone-Rlr Brg	415-1921
6V-2202	Bearing-Spl Ball	380-1574
6V-2202	Bearing-Spl Ball	380-1574
6Y-2027	Disc-Friction	377-7441
7E-5816	Shaft-Fan	399-8552
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7E-9980	Camshaft	377-5851
7G-7431	Piston-Selector	432-8911
7G-7431	Piston-Selector	432-8911
7H-4566	Cup-Roller Brg	399-6068
7H-4566	Cup-Roller Brg	399-6068
7K-2135	Bearing-Roller	417-4492
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-5910	Impeller-Pump	314-8686

2ZJ		
Original Part Number	Part Name	Classic Part Number
7N-7166	Race-Brg Thrust	417-4531
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7T-3343	Plate-Clutch	297-7231
7V-0638	Spacer	425-3651
7V-0638	Spacer	425-3651
7W-0508	Gear-Fp Drive	296-1351
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5698	Pulley-Cshaft	295-5679
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-8584	Manifold-Exhaust	396-9932

Sales Model 65C, 65D (Cont'd.)

2ZJ		
Original Part Number	Part Name	Classic Part Number
7W-9020	Bell As-Pump Suc	378-3989
7W-9020	Bell As-Pump Suc	378-3989
8G-4189	Bearing-Aligning	295-6411
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4190	Seal-Ebar	296-1366
8H-2810	Case As-Filter	314-8512
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207

2ZJ		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8229	Bearing-Main	376-9084
8P-1656	Plate-Clutch	367-6071
8R-1693	Pin As	415-1906
8R-1693	Pin As	415-1906
8R-6631	Hub	443-2057
8R-6631	Hub	443-2057
8S-0248	Breather As	325-6033
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372

2ZJ		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8679	Chamber As	325-6042
9V-7710	Univ Joint As	394-8234
9W-9930	Mount As	295-6437
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-1798	Seal-Water	379-0165
005-0469	Cup-Rlr Bearing	418-9610
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
005-0471	Cone-Spl Tapered	415-1924
100-7860	Valve-Inlet	270-4360
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
114-4680	Gear As-Pump	374-7485
115-4072	Bearing	397-5069
115-4072	Bearing	397-5069
126-5984	Ring-Backup	419-4654
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
132-6597	Cone-Spl	422-6477
148-7455	Valve - Exhaust	270-4361
148-7455	Valve - Exhaust	270-4361
161-3411	Gasket	394-0896
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
163-1387	Gear-Flywheel	374-4697

Sales Model 65C, 65D (Cont'd.)

2ZJ		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5185	Shaft-Water Pump	325-6201

2ZJ		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
172-7767	Pump Gp-Water -B	296-1365
173-0888	Univ Jt As	394-0898
173-0888	Univ Jt As	394-0898
176-3900	Accumulator	416-5513
176-3900	Accumulator	416-5513
187-0605	Gasket Kit - Cl	382-5055
190-0649	Tightener-Belt	434-1407
190-0649	Tightener-Belt	434-1407
196-0028	Gear As-Idler	364-5259
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
226-8202	Seal-Wiper	472-8024

2ZJ		
Original Part Number	Part Name	Classic Part Number
229-1490	Sleeve-Injector	393-3659
229-1490	Sleeve-Injector	393-3659
232-3233	Bearing-Main	376-9085
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model 65E

1GM		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344

1GM		
Original Part Number	Part Name	Classic Part Number
1P-3958	Bearing-Needle	434-6114
1P-7522	Yoke As	382-6893
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294

1GM		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2P-1005	Bearing-Sleeve	296-1342
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844

Sales Model 65E (Cont'd.)

1GM		
Original Part Number	Part Name	Classic Part Number
2W-5539	Core As-Rad	374-7492
2W-8494	Pulley-Alt	295-5692
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3S-3875	Screen-Suction	435-4849
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-9326	Bearing	417-4506
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5P-7807	Bearing-Ball	314-8502
5P-9531	Cone-Rlr Bearing	386-4956
6E-0775	Head	425-9373
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-3831	Seal-O-Ring	436-2657
6Y-2027	Disc-Friction	377-7441
7E-5816	Shaft-Fan	399-8552
7G-7431	Piston-Selector	432-8911
7H-4566	Cup-Roller Brg	399-6068
7J-5131	Trunnion	296-1371
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8G-4189	Bearing-Aligning	295-6411

1GM		
Original Part Number	Part Name	Classic Part Number
8G-4190	Seal-Ebar	296-1366
8H-9789	Bearing-Ball	374-8342
8P-1656	Plate-Clutch	367-6071
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
114-4680	Gear As-Pump	374-7485
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
126-5984	Ring-Backup	419-4654
132-6597	Cone-Spl	422-6477
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-6306	Cap-Bearing	325-6038
173-0888	Univ Jt As	394-0898
176-3900	Accumulator	416-5513
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

1GM		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032
352-2077	Pump Gp-Water -B	434-6108
1A-9252	Rod End-Yoke	377-5849
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-3958	Bearing-Needle	434-6114
1P-7522	Yoke As	382-6893
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2K-9295	Bearing-Cone	422-6480
2P-1005	Bearing-Sleeve	296-1342
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2W-5539	Core As-Rad	374-7492
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3S-3875	Screen-Suction	435-4849
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-9326	Bearing	417-4506
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019

Sales Model 65E (Cont'd.)

1GM		
Original Part Number	**Part Name**	**Classic Part Number**
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5P-7807	Bearing-Ball	314-8502
5P-9531	Cone-Rlr Bearing	386-4956
5S-4557	Bearing	311-9360
6E-0775	Head	425-9373
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-3831	Seal-O-Ring	436-2657
6Y-2027	Disc-Friction	377-7441
7E-5816	Shaft-Fan	399-8552
7G-7431	Piston-Selector	432-8911
7H-4566	Cup-Roller Brg	399-6068
7J-5131	Trunnion	296-1371
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650

1GM		
Original Part Number	**Part Name**	**Classic Part Number**
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-9789	Bearing-Ball	374-8342
8P-1656	Plate-Clutch	367-6071
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
114-4680	Gear As-Pump	374-7485
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

1GM		
Original Part Number	**Part Name**	**Classic Part Number**
118-2800	Housing As.-Rglt	419-4719
126-5984	Ring-Backup	419-4654
132-6597	Cone-Spl	422-6477
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-6306	Cap-Bearing	325-6038
173-0888	Univ Jt As	394-0898
176-3900	Accumulator	416-5513
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2077	Pump Gp-Water -B	434-6108

Sales Model 70

03E		
Original Part Number	**Part Name**	**Classic Part Number**
7L-7508	Bearing-Ball	420-6536

08D		
Original Part Number	**Part Name**	**Classic Part Number**
7L-7508	Bearing-Ball	420-6536
1B-6577	Cone-Spl Tapered	374-1839

08D		
Original Part Number	**Part Name**	**Classic Part Number**
1L-7205	Bearing-Ball	416-2167
1S-3743	Bearing-Ball	384-4786
3H-1996	Bearing-Ball	380-1498

Sales Model 70C

2YL		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1A-9252	Rod End-Yoke	377-5849
1J-2860	Cup-Spl Tapered	374-8347
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-3958	Bearing-Needle	434-6114
1P-7115	Mount As	418-1936
1P-7115	Mount As	418-1936
1P-7522	Yoke As	382-6893
1P-7522	Yoke As	382-6893
1P-9593	Cone-Rlr Brg	377-7400
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9594	Bearing-Cup	377-7401
1S-3062	Director-Water	418-9572
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0043	Bearing-Ball	390-5294
1W-1669	Piston	325-6158
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

2YL		
Original Part Number	Part Name	Classic Part Number
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2D-9453	Cone-Roller Brg	380-7508
2K-9295	Bearing-Cone	422-6480
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1738	Plate As-Oil Pan	325-6164
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230

2YL		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-2788	Adapter-Fan	390-0984
2P-6245	Shaft As-Pump	325-6197
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-2621	Valve-Inlet	247-6892
2W-5539	Core As-Rad	374-7492
2W-7255	Shaft-Water Pump	325-6203
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
2W-9978	Core As-Oclr	279-4983
3B-4124	Cup-Spl Tapered	422-6481
3B-4124	Cup-Spl Tapered	422-6481
3K-9608	Guard-Dirt	374-1447
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436
3L-9409	Cup-Roller Brg	399-4436
3S-3875	Screen-Suction	435-4849
3S-3875	Screen-Suction	435-4849
4M-6107	Bearing-Roller	380-7507
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-0432	Bearing-Ball	417-4499

Sales Model 70C (Cont'd.)

2YL		
Original Part Number	Part Name	Classic Part Number
4N-7693	Crankshaft As	269-8763
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4P-9396	Line As-Fuel Inj	383-3691

2YL		
Original Part Number	Part Name	Classic Part Number
4P-9942	Seal-End Tank	385-7217
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9943	Seal-End Tank	385-7216
4S-9326	Bearing	417-4506
4S-9326	Bearing	417-4506
4T-8054	Seal As	472-8010
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
4W-6869	Spacer-Fuel Pump	417-4534
5M-0578	Bearing	419-7775
5M-0578	Bearing	419-7775
5P-7807	Bearing-Ball	314-8502
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-8772	Gasket Kit	383-1575
5P-9531	Cone-Rlr Bearing	386-4956
5P-9531	Cone-Rlr Bearing	386-4956
5S-4557	Bearing	311-9360
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437

2YL		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6B-7469	Spacer	417-4535
6E-0775	Head	425-9373
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6I-8642	Race-Brg Outer	396-9898
6I-8849	Cone-Rlr Bearing	415-1919
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6I-8860	Cup-Roller Brg	380-7495
6L-7751	Rod End-Spher	472-8015
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-7174	Shield-Oil	314-8544
6S-3051	Cup-Rlr Brg	415-1928
6S-3051	Cup-Rlr Brg	415-1928
6S-6031	Cup-Rlr Brg	415-1920
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6S-6032	Cone-Rlr Brg	415-1921
6V-2202	Bearing-Spl Ball	380-1574
6V-2202	Bearing-Spl Ball	380-1574
6Y-2027	Disc-Friction	377-7441

Sales Model 70C (Cont'd.)

2YL		
Original Part Number	Part Name	Classic Part Number
6Y-2027	Disc-Friction	377-7441
7E-5816	Shaft-Fan	399-8552
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7E-9980	Camshaft	377-5851
7G-7431	Piston-Selector	432-8911
7G-7431	Piston-Selector	432-8911
7H-4566	Cup-Roller Brg	399-6068
7H-4566	Cup-Roller Brg	399-6068
7K-2135	Bearing-Roller	417-4492
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-4534	Bearing-Caged	417-9497

2YL		
Original Part Number	Part Name	Classic Part Number
7T-1285	Gear-Planet	297-7190
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7T-3343	Plate-Clutch	297-7231
7V-0638	Spacer	425-3651
7V-0638	Spacer	425-3651
7W-0508	Gear-Fp Drive	296-1351
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5698	Pulley-Cshaft	295-5679
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger As	391-9895
7W-5929	Plunger As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
7W-9020	Bell As-Pump Suc	378-3989
8G-4189	Bearing-Aligning	295-6411
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4190	Seal-Ebar	296-1366
8H-2810	Case As-Filter	314-8512
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1187	Head Gp-Cyl -A	242-3435

2YL		
Original Part Number	Part Name	Classic Part Number
8N-1721	Rod As-Conn	269-5291
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

Sales Model 70C (Cont'd.)

2YL		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8229	Bearing-Main	376-9084
8P-1656	Plate-Clutch	367-6071
8P-1656	Plate-Clutch	367-6071
8R-1693	Pin As	415-1906
8R-1693	Pin As	415-1906
8R-6631	Hub	443-2057
8R-6631	Hub	443-2057
8S-0248	Breather As	325-6033
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8679	Chamber As	325-6042
9W-9930	Mount As	295-6437
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-1798	Seal-Water	379-0165
005-0469	Cup-Rlr Bearing	418-9610
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

2YL		
Original Part Number	Part Name	Classic Part Number
005-0471	Cone-Spl Tapered	415-1924
100-7860	Valve-Inlet	270-4360
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
114-4680	Gear As-Pump	374-7485
126-5984	Ring-Backup	419-4654
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
132-6597	Cone-Spl	422-6477
148-7455	Valve - Exhaust	270-4361
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484

2YL		
Original Part Number	Part Name	Classic Part Number
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
172-7767	Pump Gp-Water -B	296-1365
173-0888	Univ Jt As	394-0898
173-0888	Univ Jt As	394-0898
176-3900	Accumulator	416-5513
176-3900	Accumulator	416-5513
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988

Sales Model 70C (Cont'd.)

2YL		
Original Part Number	Part Name	Classic Part Number
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
296-1360	Line As-Cla	279-4989

2YL		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349

2YL		
Original Part Number	Part Name	Classic Part Number
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
334-8389	Crankshaft As	242-3439

Sales Model 75

02E		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1B-6577	Cone-Spl Tapered	374-1839
1L-7205	Bearing-Ball	416-2167
1M-7250	Bowl	360-2296
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
3B-1142	Retainer-Spring	391-1099
3B-8845	Bearing-Inner	417-4509
3H-1996	Bearing-Ball	380-1498
4B-1455	Cap As-Filler	361-1719
4F-5003	Spring As-Arm	383-2127
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6T-8886	Disc-Ster Cl	380-7517
7F-9547	Pin As.-Drawbar	295-0414
7K-5448	Cup-Bearing	415-1922
7M-4926	Retainer-Piston	314-8538
7T-0204	Bearing-Brace	247-4126
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-8523	Bearing-Sleeve	383-3701
8H-2434	Drum-Ster Cl Dr	216-7862
9H-6236	Rod As	390-0999

02E		
Original Part Number	Part Name	Classic Part Number
9L-2685	Rod End	419-1866
121-7746	Pre-Cleaner As	360-2311
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7115	Mount As	418-1936
1P-7522	Yoke As	382-6893
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2K-9295	Bearing-Cone	422-6480
2P-1005	Bearing-Sleeve	296-1342
2W-5539	Core As-Rad	374-7492
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
3B-4124	Cup-Spl Tapered	422-6481
3E-4329	Kit-Gasket(Ocl)	437-8110
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436
3S-3875	Screen-Suction	435-4849
4M-1641	Dowel-Reaction	386-4952
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236

02E		
Original Part Number	Part Name	Classic Part Number
4S-9326	Bearing	417-4506
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5P-7807	Bearing-Ball	314-8502
5P-9531	Cone-Rlr Bearing	386-4956
6E-0775	Head	425-9373
6I-8642	Race-Brg Outer	396-9898
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-6043	Bearing-Sleeve	374-1456
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6S-3051	Cup-Rlr Brg	415-1928
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-2027	Disc-Friction	377-7441
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-7431	Piston-Selector	432-8911
7H-4566	Cup-Roller Brg	399-6068
7K-2135	Bearing-Roller	417-4492
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190

Sales Model 75 (Cont'd.)

02E		
Original Part Number	**Part Name**	**Classic Part Number**
7T-3343	Plate-Clutch	297-7231
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-5352	Bearing-Ball	453-3658
8N-3666	Repair Kt-Major	377-5842
8P-1656	Plate-Clutch	367-6071
8R-1693	Pin As	415-1906
8R-6631	Hub	443-2057
9V-7710	Univ Joint As	394-8234

02E		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
110-1337	Ring Kit-Pstn	377-5834
111-2645	Valve-Pump Byp	441-1561
114-4680	Gear As-Pump	374-7485
116-1102	Sleeve-Injector	451-9024
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
173-0888	Univ Jt As	394-0898

02E		
Original Part Number	**Part Name**	**Classic Part Number**
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
223-8228	Kit-Gasket (Sch)	437-8142
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2077	Pump Gp-Water -B	434-6108

Sales Model 75C

4KK		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1A-9252	Rod End-Yoke	377-5849
1J-2860	Cup-Spl Tapered	374-8347
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-1367	Plunger-Valve	432-8913
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-3958	Bearing-Needle	434-6114
1P-3958	Bearing-Needle	434-6114
1P-7115	Mount As	418-1936
1P-7115	Mount As	418-1936
1P-7522	Yoke As	382-6893
1P-7522	Yoke As	382-6893
1P-9593	Cone-Rlr Brg	377-7400
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9594	Bearing-Cup	377-7401

4KK		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2D-9453	Cone-Roller Brg	380-7508
2K-9295	Bearing-Cone	422-6480
2K-9295	Bearing-Cone	422-6480
2P-1005	Bearing-Sleeve	296-1342
2P-1005	Bearing-Sleeve	296-1342
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2W-5539	Core As-Rad	374-7492
2W-5539	Core As-Rad	374-7492
2W-8494	Pulley-Alt	295-5692
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
2W-9978	Core As-Oclr	279-4983

4KK		
Original Part Number	**Part Name**	**Classic Part Number**
3B-4124	Cup-Spl Tapered	422-6481
3B-4124	Cup-Spl Tapered	422-6481
3E-4329	Kit-Gasket(Ocl)	437-8110
3E-4329	Kit-Gasket(Ocl)	437-8110
3K-9608	Guard-Dirt	374-1447
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436
3L-9409	Cup-Roller Brg	399-4436
3S-3875	Screen-Suction	435-4849
3S-3875	Screen-Suction	435-4849
4M-6107	Bearing-Roller	380-7507
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236

Sales Model 75C (Cont'd.)

4KK		
Original Part Number	Part Name	Classic Part Number
4P-8280	Manifold-Exhaust	430-7236
4P-9942	Seal-End Tank	385-7217
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9943	Seal-End Tank	385-7216
4S-9326	Bearing	417-4506
4S-9326	Bearing	417-4506
4T-8054	Seal As	472-8010
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4W-1203	Cup-Rlr Brg	418-9603
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-0578	Bearing	419-7775
5P-7807	Bearing-Ball	314-8502
5P-7807	Bearing-Ball	314-8502
5P-9531	Cone-Rlr Bearing	386-4956
5P-9531	Cone-Rlr Bearing	386-4956
6E-0775	Head	425-9373
6E-0775	Head	425-9373
6I-8642	Race-Brg Outer	396-9898
6I-8642	Race-Brg Outer	396-9898
6I-8849	Cone-Rlr Bearing	415-1919
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6I-8860	Cup-Roller Brg	380-7495
6J-6043	Bearing-Sleeve	374-1456
6L-7751	Rod End-Spher	472-8015
6L-7751	Rod End-Spher	472-8015
6S-3051	Cup-Rlr Brg	415-1928
6S-3051	Cup-Rlr Brg	415-1928
6S-6031	Cup-Rlr Brg	415-1920
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6S-6032	Cone-Rlr Brg	415-1921
6V-2202	Bearing-Spl Ball	380-1574

4KK		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-3831	Seal-O-Ring	436-2657
6Y-2027	Disc-Friction	377-7441
6Y-2027	Disc-Friction	377-7441
7E-5816	Shaft-Fan	399-8552
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-2742	Bearing-Ball	422-6488
7G-7431	Piston-Selector	432-8911
7G-7431	Piston-Selector	432-8911
7H-4566	Cup-Roller Brg	399-6068
7H-4566	Cup-Roller Brg	399-6068
7K-2135	Bearing-Roller	417-4492
7K-2135	Bearing-Roller	417-4492
7S-4534	Bearing-Caged	417-9497
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7T-3343	Plate-Clutch	297-7231
7V-0638	Spacer	425-3651
7V-0638	Spacer	425-3651
7W-5164	Gasket	420-8568
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7X-7975	Gasket Kit	437-3233
8G-4189	Bearing-Aligning	295-6411
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4190	Seal-Ebar	296-1366
8H-9789	Bearing-Ball	374-8342
8H-9789	Bearing-Ball	374-8342
8N-3666	Repair Kt-Major	377-5842

4KK		
Original Part Number	Part Name	Classic Part Number
8N-3666	Repair Kt-Major	377-5842
8P-1656	Plate-Clutch	367-6071
8P-1656	Plate-Clutch	367-6071
8R-1693	Pin As	415-1906
8R-1693	Pin As	415-1906
8R-6631	Hub	443-2057
8R-6631	Hub	443-2057
9V-7710	Univ Joint As	394-8234
9W-9930	Mount As	295-6437
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
005-0471	Cone-Spl Tapered	415-1924
101-3125	Gasket	420-8567
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
104-1706	Valve-Regulating	432-8281
110-1337	Ring Kit-Pstn	377-5834
110-1337	Ring Kit-Pstn	377-5834
111-2645	Valve-Pump Byp	441-1561
111-2645	Valve-Pump Byp	441-1561
114-4680	Gear As-Pump	374-7485
114-4680	Gear As-Pump	374-7485
115-2989	Manifold-Exhaust	434-9635
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9399	Arm-Valve Rocker	433-0447

Sales Model 75C (Cont'd.)

4KK		
Original Part Number	Part Name	Classic Part Number
115-9400	Arm As-Ui Rocker	433-0446
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
118-2800	Housing As.-Rglt	419-4719
126-5984	Ring-Backup	419-4654
126-5984	Ring-Backup	419-4654
132-6597	Cone-Spl	422-6477
132-6597	Cone-Spl	422-6477
147-3781	Kit-Gasket(Wp)	422-2484
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048

4KK		
Original Part Number	Part Name	Classic Part Number
160-9874	Kit-Gasket-Scl	386-3048
173-0888	Univ Jt As	394-0898
173-0888	Univ Jt As	394-0898
176-3900	Accumulator	416-5513
176-3900	Accumulator	416-5513
176-4168	Bridge As-Valve	419-4727
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144

4KK		
Original Part Number	Part Name	Classic Part Number
216-4781	Gasket Kit	437-8144
221-0859	Kit-Gasket-T	437-8135
223-7811	Kit-Gasket (Sch)	437-8636
223-8228	Kit-Gasket (Sch)	437-8142
226-8202	Seal-Wiper	472-8024
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
308-1845	Seal-Wiper	472-8032
312-5931	Kit-Gasket (Sch)	438-0140
312-5931	Kit-Gasket (Sch)	438-0140
352-2077	Pump Gp-Water -B	434-6108
352-2077	Pump Gp-Water -B	434-6108

Sales Model 75D

5AR		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-3958	Bearing-Needle	434-6114
1P-7115	Mount As	418-1936
1P-7522	Yoke As	382-6893
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174

5AR		
Original Part Number	Part Name	Classic Part Number
2D-9453	Cone-Roller Brg	380-7508
2K-9295	Bearing-Cone	422-6480
2P-1005	Bearing-Sleeve	296-1342
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2W-5539	Core As-Rad	374-7492
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
3B-4124	Cup-Spl Tapered	422-6481
3E-4329	Kit-Gasket(Ocl)	437-8110
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436
3S-3875	Screen-Suction	435-4849

5AR		
Original Part Number	Part Name	Classic Part Number
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-9326	Bearing	417-4506
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5P-7807	Bearing-Ball	314-8502
5P-9531	Cone-Rlr Bearing	386-4956

Sales Model 75D (Cont'd.)

5AR		
Original Part Number	Part Name	Classic Part Number
6E-0775	Head	425-9373
6I-8642	Race-Brg Outer	396-9898
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6L-7751	Rod End-Spher	472-8015
6S-3051	Cup-Rlr Brg	415-1928
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-3831	Seal-O-Ring	436-2657
6Y-2027	Disc-Friction	377-7441
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-7431	Piston-Selector	432-8911
7H-4566	Cup-Roller Brg	399-6068
7K-2135	Bearing-Roller	417-4492
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7V-0638	Spacer	425-3651
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366

5AR		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8N-3666	Repair Kt-Major	377-5842
8P-1656	Plate-Clutch	367-6071
8R-1693	Pin As	415-1906
8R-6631	Hub	443-2057
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
110-1337	Ring Kit-Pstn	377-5834
111-2645	Valve-Pump Byp	441-1561
114-4680	Gear As-Pump	374-7485
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

5AR		
Original Part Number	Part Name	Classic Part Number
118-2800	Housing As.-Rglt	419-4719
126-5984	Ring-Backup	419-4654
132-6597	Cone-Spl	422-6477
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
173-0888	Univ Jt As	394-0898
176-3900	Accumulator	416-5513
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
221-0859	Kit-Gasket-T	437-8135
226-8202	Seal-Wiper	472-8024
252-7955	Kit-Gasket(Cl)	437-8654
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
316-4396	Kit-Gasket (Sch)	393-3661
352-2077	Pump Gp-Water -B	434-6108

Sales Model 75E

1HM		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-3958	Bearing-Needle	434-6114

1HM		
Original Part Number	Part Name	Classic Part Number
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2P-1005	Bearing-Sleeve	296-1342

1HM		
Original Part Number	Part Name	Classic Part Number
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2W-5539	Core As-Rad	374-7492
2W-8494	Pulley-Alt	295-5692
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433

Sales Model 75E (Cont'd.)

1HM		
Original Part Number	Part Name	Classic Part Number
3S-3875	Screen-Suction	435-4849
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-9326	Bearing	417-4506
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5P-7807	Bearing-Ball	314-8502
5P-9531	Cone-Rlr Bearing	386-4956
6E-0775	Head	425-9373
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-3831	Seal-O-Ring	436-2657
6Y-2027	Disc-Friction	377-7441
7E-5816	Shaft-Fan	399-8552
7G-7431	Piston-Selector	432-8911

1HM		
Original Part Number	Part Name	Classic Part Number
7H-4566	Cup-Roller Brg	399-6068
7J-5131	Trunnion	296-1371
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-9789	Bearing-Ball	374-8342
8P-1656	Plate-Clutch	367-6071
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
114-4680	Gear As-Pump	374-7485
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447

1HM		
Original Part Number	Part Name	Classic Part Number
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
126-5984	Ring-Backup	419-4654
132-6597	Cone-Spl	422-6477
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-6306	Cap-Bearing	325-6038
173-0888	Univ Jt As	394-0898
176-3900	Accumulator	416-5513
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2077	Pump Gp-Water -B	434-6108

6HS		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-3958	Bearing-Needle	434-6114
1P-7522	Yoke As	382-6893
1P-9593	Cone-Rlr Brg	377-7400

6HS		
Original Part Number	Part Name	Classic Part Number
1P-9594	Bearing-Cup	377-7401
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2K-9295	Bearing-Cone	422-6480
2P-1005	Bearing-Sleeve	296-1342
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844

6HS		
Original Part Number	Part Name	Classic Part Number
2W-5539	Core As-Rad	374-7492
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3S-3875	Screen-Suction	435-4849
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283

Sales Model 75E (Cont'd.)

6HS		
Original Part Number	Part Name	Classic Part Number
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-9326	Bearing	417-4506
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5P-7807	Bearing-Ball	314-8502
5P-9531	Cone-Rlr Bearing	386-4956
5S-4557	Bearing	311-9360
6E-0775	Head	425-9373
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-3831	Seal-O-Ring	436-2657
6Y-2027	Disc-Friction	377-7441
7E-5816	Shaft-Fan	399-8552
7G-7431	Piston-Selector	432-8911
7H-4566	Cup-Roller Brg	399-6068
7J-5131	Trunnion	296-1371

6HS		
Original Part Number	Part Name	Classic Part Number
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-9789	Bearing-Ball	374-8342
8P-1656	Plate-Clutch	367-6071
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
114-4680	Gear As-Pump	374-7485
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446

6HS		
Original Part Number	Part Name	Classic Part Number
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
126-5984	Ring-Backup	419-4654
132-6597	Cone-Spl	422-6477
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-6306	Cap-Bearing	325-6038
173-0888	Univ Jt As	394-0898
176-3900	Accumulator	416-5513
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
221-0859	Kit-Gasket-T	437-8135
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
316-4396	Kit-Gasket (Sch)	393-3661
352-2077	Pump Gp-Water -B	434-6108

Sales Model 85C

9TK		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1A-9252	Rod End-Yoke	377-5849
1J-2860	Cup-Spl Tapered	374-8347
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1J-4757	Cone-Bearing	374-1840

9TK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-1367	Plunger-Valve	432-8913
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-3958	Bearing-Needle	434-6114
1P-3958	Bearing-Needle	434-6114

9TK		
Original Part Number	Part Name	Classic Part Number
1P-7115	Mount As	418-1936
1P-7115	Mount As	418-1936
1P-7522	Yoke As	382-6893
1P-9593	Cone-Rlr Brg	377-7400
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9594	Bearing-Cup	377-7401
1S-7057	Gasket	420-6384

Sales Model 85C (Cont'd.)

9TK		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2D-9453	Cone-Roller Brg	380-7508
2K-9295	Bearing-Cone	422-6480
2K-9295	Bearing-Cone	422-6480
2P-1005	Bearing-Sleeve	296-1342
2P-1005	Bearing-Sleeve	296-1342
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2W-5539	Core As-Rad	374-7492
2W-5539	Core As-Rad	374-7492
2W-8494	Pulley-Alt	295-5692
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
2W-9978	Core As-Oclr	279-4983
3B-4124	Cup-Spl Tapered	422-6481
3B-4124	Cup-Spl Tapered	422-6481
3E-4329	Kit-Gasket(Ocl)	437-8110
3E-4329	Kit-Gasket(Ocl)	437-8110
3K-9608	Guard-Dirt	374-1447
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436
3L-9409	Cup-Roller Brg	399-4436
3S-3875	Screen-Suction	435-4849
3S-3875	Screen-Suction	435-4849
4M-6107	Bearing-Roller	380-7507
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8279	Manifold-Exhaust	430-8041

9TK		
Original Part Number	Part Name	Classic Part Number
4P-8280	Manifold-Exhaust	430-7236
4P-8280	Manifold-Exhaust	430-7236
4P-9942	Seal-End Tank	385-7217
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9943	Seal-End Tank	385-7216
4S-9326	Bearing	417-4506
4S-9326	Bearing	417-4506
4T-8054	Seal As	472-8010
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-0578	Bearing	419-7775
5P-7807	Bearing-Ball	314-8502
5P-7807	Bearing-Ball	314-8502
5P-9531	Cone-Rlr Bearing	386-4956
5P-9531	Cone-Rlr Bearing	386-4956
6E-0775	Head	425-9373
6E-0775	Head	425-9373
6I-8642	Race-Brg Outer	396-9898
6I-8642	Race-Brg Outer	396-9898
6I-8849	Cone-Rlr Bearing	415-1919
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6I-8860	Cup-Roller Brg	380-7495
6L-7751	Rod End-Spher	472-8015
6L-7751	Rod End-Spher	472-8015
6S-3051	Cup-Rlr Brg	415-1928
6S-3051	Cup-Rlr Brg	415-1928
6S-6031	Cup-Rlr Brg	415-1920
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6S-6032	Cone-Rlr Brg	415-1921
6V-2202	Bearing-Spl Ball	380-1574

9TK		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-3831	Seal-O-Ring	436-2657
6Y-2027	Disc-Friction	377-7441
6Y-2027	Disc-Friction	377-7441
7E-5816	Shaft-Fan	399-8552
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7F-2742	Bearing-Ball	422-6488
7G-7431	Piston-Selector	432-8911
7G-7431	Piston-Selector	432-8911
7H-4566	Cup-Roller Brg	399-6068
7H-4566	Cup-Roller Brg	399-6068
7K-2135	Bearing-Roller	417-4492
7K-2135	Bearing-Roller	417-4492
7S-4534	Bearing-Caged	417-9497
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7T-3343	Plate-Clutch	297-7231
7V-0638	Spacer	425-3651
7V-0638	Spacer	425-3651
7W-5164	Gasket	420-8568
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
7X-7975	Gasket Kit	437-3233
8G-4189	Bearing-Aligning	295-6411
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4190	Seal-Ebar	296-1366
8H-9789	Bearing-Ball	374-8342
8N-3666	Repair Kt-Major	377-5842
8N-3666	Repair Kt-Major	377-5842

Sales Model 85C (Cont'd.)

9TK		
Original Part Number	Part Name	Classic Part Number
8P-1656	Plate-Clutch	367-6071
8P-1656	Plate-Clutch	367-6071
8R-1693	Pin As	415-1906
8R-1693	Pin As	415-1906
8R-6631	Hub	443-2057
8R-6631	Hub	443-2057
9V-7710	Univ Joint As	394-8234
9W-9930	Mount As	295-6437
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
005-0471	Cone-Spl Tapered	415-1924
101-3125	Gasket	420-8567
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
104-1706	Valve-Regulating	432-8281
110-1337	Ring Kit-Pstn	377-5834
110-1337	Ring Kit-Pstn	377-5834
111-2645	Valve-Pump Byp	441-1561
111-2645	Valve-Pump Byp	441-1561
114-4680	Gear As-Pump	374-7485
114-4680	Gear As-Pump	374-7485

9TK		
Original Part Number	Part Name	Classic Part Number
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
126-5984	Ring-Backup	419-4654
126-5984	Ring-Backup	419-4654
132-6597	Cone-Spl	422-6477
132-6597	Cone-Spl	422-6477
133-3545	Tightener-Belt	434-1407
147-3781	Kit-Gasket(Wp)	422-2484
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
173-0888	Univ Jt As	394-0898
173-0888	Univ Jt As	394-0898
176-3900	Accumulator	416-5513
176-3900	Accumulator	416-5513
176-4168	Bridge As-Valve	419-4727
176-4168	Bridge As-Valve	419-4727

9TK		
Original Part Number	Part Name	Classic Part Number
176-4172	Bridge As-Valve	457-4600
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
221-0859	Kit-Gasket-T	437-8135
223-7811	Kit-Gasket (Sch)	437-8636
226-8202	Seal-Wiper	472-8024
226-8202	Seal-Wiper	472-8024
248-2987	Guide	419-4709
289-2935	Seal As-Buffer	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
308-1845	Seal-Wiper	472-8032
312-5931	Kit-Gasket (Sch)	438-0140
352-2077	Pump Gp-Water -B	434-6108
352-2077	Pump Gp-Water -B	434-6108

Sales Model 85D

4GR		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344

4GR		
Original Part Number	Part Name	Classic Part Number
1P-3958	Bearing-Needle	434-6114
1P-7115	Mount As	418-1936
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-7057	Gasket	420-6384

4GR		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2K-9295	Bearing-Cone	422-6480
2P-1005	Bearing-Sleeve	296-1342

Sales Model 85D (Cont'd.)

4GR		
Original Part Number	Part Name	Classic Part Number
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2W-5539	Core As-Rad	374-7492
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
3B-4124	Cup-Spl Tapered	422-6481
3E-4329	Kit-Gasket(Ocl)	437-8110
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436
3S-3875	Screen-Suction	435-4849
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-9326	Bearing	417-4506
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5P-7807	Bearing-Ball	314-8502
5P-9531	Cone-Rlr Bearing	386-4956
6I-8642	Race-Brg Outer	396-9898
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6L-7751	Rod End-Spher	472-8015
6S-3051	Cup-Rlr Brg	415-1928
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921

4GR		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
6Y-2027	Disc-Friction	377-7441
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-7431	Piston-Selector	432-8911
7H-4566	Cup-Roller Brg	399-6068
7K-2135	Bearing-Roller	417-4492
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7V-0638	Spacer	425-3651
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
7X-7975	Gasket Kit	437-3233
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-9789	Bearing-Ball	374-8342
8N-3666	Repair Kt-Major	377-5842
8P-1656	Plate-Clutch	367-6071
8R-1693	Pin As	415-1906
8R-6631	Hub	443-2057
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
110-1337	Ring Kit-Pstn	377-5834
111-2645	Valve-Pump Byp	441-1561

4GR		
Original Part Number	Part Name	Classic Part Number
114-4680	Gear As-Pump	374-7485
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
126-5984	Ring-Backup	419-4654
132-6597	Cone-Spl	422-6477
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
173-0888	Univ Jt As	394-0898
176-3900	Accumulator	416-5513
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
221-0859	Kit-Gasket-T	437-8135
316-4396	Kit-Gasket (Sch)	393-3661
352-2077	Pump Gp-Water -B	434-6108

Sales Model 85E

1NM		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347

Sales Model 85E (Cont'd.)

1NM		
Original Part Number	Part Name	Classic Part Number
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-3958	Bearing-Needle	434-6114
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2P-1005	Bearing-Sleeve	296-1342
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2W-8494	Pulley-Alt	295-5692
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3S-3875	Screen-Suction	435-4849
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-9326	Bearing	417-4506
4V-4852	Piston	433-0452
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-5018	Bearing-Roller	380-7509
5P-7807	Bearing-Ball	314-8502
5P-9531	Cone-Rlr Bearing	386-4956
5S-4557	Bearing	311-9360
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6S-6031	Cup-Rlr Brg	415-1920

1NM		
Original Part Number	Part Name	Classic Part Number
6S-6032	Cone-Rlr Brg	415-1921
6V-3831	Seal-O-Ring	436-2657
6Y-2027	Disc-Friction	377-7441
7E-5816	Shaft-Fan	399-8552
7G-7431	Piston-Selector	432-8911
7H-4566	Cup-Roller Brg	399-6068
7J-5131	Trunnion	296-1371
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5164	Gasket	420-8568
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-9789	Bearing-Ball	374-8342
8P-1656	Plate-Clutch	367-6071
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
114-4680	Gear As-Pump	374-7485
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
126-5984	Ring-Backup	419-4654
132-6597	Cone-Spl	422-6477
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154

1NM		
Original Part Number	Part Name	Classic Part Number
160-6306	Cap-Bearing	325-6038
160-9874	Kit-Gasket-Scl	386-3048
173-0888	Univ Jt As	394-0898
176-3900	Accumulator	416-5513
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
352-2077	Pump Gp-Water -B	434-6108
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-3958	Bearing-Needle	434-6114
1P-7522	Yoke As	382-6893
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2K-9295	Bearing-Cone	422-6480
2P-1005	Bearing-Sleeve	296-1342
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3S-3875	Screen-Suction	435-4849
4M-6107	Bearing-Roller	380-7507

Sales Model 85E (Cont'd.)

1NM		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-9326	Bearing	417-4506
4V-2057	Bearing-Spher	419-6019
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-5018	Bearing-Roller	380-7509
5P-7807	Bearing-Ball	314-8502
5P-9531	Cone-Rlr Bearing	386-4956
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-3831	Seal-O-Ring	436-2657
6Y-2027	Disc-Friction	377-7441
7E-5816	Shaft-Fan	399-8552
7G-7431	Piston-Selector	432-8911

1NM		
Original Part Number	**Part Name**	**Classic Part Number**
7H-4566	Cup-Roller Brg	399-6068
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-9789	Bearing-Ball	374-8342
8P-1656	Plate-Clutch	367-6071
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
114-4680	Gear As-Pump	374-7485
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448

1NM		
Original Part Number	**Part Name**	**Classic Part Number**
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
126-5984	Ring-Backup	419-4654
132-6597	Cone-Spl	422-6477
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-6306	Cap-Bearing	325-6038
160-9874	Kit-Gasket-Scl	386-3048
173-0888	Univ Jt As	394-0898
176-3900	Accumulator	416-5513
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
352-2077	Pump Gp-Water -B	434-6108

Sales Model 95E

1SM		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-3958	Bearing-Needle	434-6114
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-7057	Gasket	420-6384

1SM		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2P-1005	Bearing-Sleeve	296-1342
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2W-8494	Pulley-Alt	295-5692
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436

1SM		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
3S-3875	Screen-Suction	435-4849
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4P-9942	Seal-End Tank	385-7217

Sales Model 95E (Cont'd.)

1SM		
Original Part Number	Part Name	Classic Part Number
4P-9943	Seal-End Tank	385-7216
4S-9326	Bearing	417-4506
4V-4852	Piston	433-0452
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-5018	Bearing-Roller	380-7509
5P-7807	Bearing-Ball	314-8502
5P-9531	Cone-Rlr Bearing	386-4956
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-3831	Seal-O-Ring	436-2657
6Y-2027	Disc-Friction	377-7441
7E-5816	Shaft-Fan	399-8552
7G-7431	Piston-Selector	432-8911
7H-4566	Cup-Roller Brg	399-6068
7J-5131	Trunnion	296-1371
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231

1SM		
Original Part Number	Part Name	Classic Part Number
7W-5164	Gasket	420-8568
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-9789	Bearing-Ball	374-8342
8P-1656	Plate-Clutch	367-6071
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
114-4680	Gear As-Pump	374-7485
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446

1SM		
Original Part Number	Part Name	Classic Part Number
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
126-5984	Ring-Backup	419-4654
132-6597	Cone-Spl	422-6477
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-6306	Cap-Bearing	325-6038
160-9874	Kit-Gasket-Scl	386-3048
173-0888	Univ Jt As	394-0898
176-3900	Accumulator	416-5513
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
352-2077	Pump Gp-Water -B	434-6108

6KS		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-3958	Bearing-Needle	434-6114
1P-7522	Yoke As	382-6893
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508

6KS		
Original Part Number	Part Name	Classic Part Number
2K-9295	Bearing-Cone	422-6480
2P-1005	Bearing-Sleeve	296-1342
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436
3P-1210	Cone-Roller Brg	399-4433
3S-3875	Screen-Suction	435-4849
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283

6KS		
Original Part Number	Part Name	Classic Part Number
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-9326	Bearing	417-4506
4V-2057	Bearing-Spher	419-6019
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-5018	Bearing-Roller	380-7509
5P-7807	Bearing-Ball	314-8502
5P-9531	Cone-Rlr Bearing	386-4956

Sales Model 95E (Cont'd.)

6KS		
Original Part Number	**Part Name**	**Classic Part Number**
5S-4557	Bearing	311-9360
6I-8642	Race-Brg Outer	396-9898
6L-7751	Rod End-Spher	472-8015
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-3831	Seal-O-Ring	436-2657
6Y-2027	Disc-Friction	377-7441
7E-5816	Shaft-Fan	399-8552
7G-7431	Piston-Selector	432-8911
7H-4566	Cup-Roller Brg	399-6068
7J-5131	Trunnion	296-1371
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-9789	Bearing-Ball	374-8342

6KS		
Original Part Number	**Part Name**	**Classic Part Number**
8P-1656	Plate-Clutch	367-6071
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
114-4680	Gear As-Pump	374-7485
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

6KS		
Original Part Number	**Part Name**	**Classic Part Number**
118-2800	Housing As.-Rglt	419-4719
126-5984	Ring-Backup	419-4654
132-6597	Cone-Spl	422-6477
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-6306	Cap-Bearing	325-6038
160-9874	Kit-Gasket-Scl	386-3048
173-0888	Univ Jt As	394-0898
176-3900	Accumulator	416-5513
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
352-2077	Pump Gp-Water -B	434-6108

Sales Model 933C

09A		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-8736	Cup-Roller Brg	423-7759
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2H-4438	Stud-Cl Spring	431-5260
2K-0227	Bearing-Sleeve	384-4780
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021

09A		
Original Part Number	**Part Name**	**Classic Part Number**
2S-4015	Plunger As-Valve	311-9438
3B-3967	Race-Roller Brg	386-4947
3B-6217	Muffler As	247-2671
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-0410	Gear-Oil Pump Dr	428-6660
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5M-6709	Check As-Ball	380-7542
5S-1211	Cover-Valve	314-8665

09A		
Original Part Number	**Part Name**	**Classic Part Number**
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7M-1154	Bearing-Spl	417-4515
7M-4603	Body-Fuel Valve	311-9348
8H-4320	Bearing-Ball	419-2301
8M-6676	Cylinder-Adj	226-4960
9F-7101	Bushing-Collar	299-1988
9H-7670	Piston	226-4961
108-5603	Screw-Adj Arm	379-0166
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

Sales Model 933C (Cont'd.)

11A		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-8736	Cup-Roller Brg	423-7759
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2H-4438	Stud-Cl Spring	431-5260
2K-0227	Bearing-Sleeve	384-4780
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021

11A		
Original Part Number	Part Name	Classic Part Number
2S-4015	Plunger As-Valve	311-9438
3B-3967	Race-Roller Brg	386-4947
3B-6217	Muffler As	247-2671
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-0410	Gear-Oil Pump Dr	428-6660
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5M-6709	Check As-Ball	380-7542
5S-1211	Cover-Valve	314-8665

11A		
Original Part Number	Part Name	Classic Part Number
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7M-1154	Bearing-Spl	417-4515
7M-4603	Body-Fuel Valve	311-9348
8H-4320	Bearing-Ball	419-2301
8M-6676	Cylinder-Adj	226-4960
9F-7101	Bushing-Collar	299-1988
9H-7670	Piston	226-4961
108-5603	Screw-Adj Arm	379-0166
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

Sales Model 933E

09A		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-8736	Cup-Roller Brg	423-7759
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2H-4438	Stud-Cl Spring	431-5260
2K-0227	Bearing-Sleeve	384-4780
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021

09A		
Original Part Number	Part Name	Classic Part Number
2S-4015	Plunger As-Valve	311-9438
3B-3967	Race-Roller Brg	386-4947
3B-6217	Muffler As	247-2671
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-0410	Gear-Oil Pump Dr	428-6660
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5M-6709	Check As-Ball	380-7542
5S-1211	Cover-Valve	314-8665

09A		
Original Part Number	Part Name	Classic Part Number
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7M-1154	Bearing-Spl	417-4515
7M-4603	Body-Fuel Valve	311-9348
8H-4320	Bearing-Ball	419-2301
8M-6676	Cylinder-Adj	226-4960
9F-7101	Bushing-Collar	299-1988
9H-7670	Piston	226-4961
108-5603	Screw-Adj Arm	379-0166
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

11A		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443

11A		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2H-4438	Stud-Cl Spring	431-5260
2K-0227	Bearing-Sleeve	384-4780

11A		
Original Part Number	Part Name	Classic Part Number
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2S-4015	Plunger As-Valve	311-9438

Sales Model 933E (Cont'd.)

11A		
Original Part Number	**Part Name**	**Classic Part Number**
3B-3967	Race-Roller Brg	386-4947
3B-6217	Muffler As	247-2671
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-0410	Gear-Oil Pump Dr	428-6660
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555

11A		
Original Part Number	**Part Name**	**Classic Part Number**
5K-2754	Spring-Recoil	418-1956
5M-6709	Check As-Ball	380-7542
5S-1211	Cover-Valve	314-8665
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7M-1154	Bearing-Spl	417-4515
7M-4603	Body-Fuel Valve	311-9348
8H-4320	Bearing-Ball	419-2301

11A		
Original Part Number	**Part Name**	**Classic Part Number**
8M-6676	Cylinder-Adj	226-4960
9F-7101	Bushing-Collar	299-1988
9H-7670	Piston	226-4961
108-5603	Screw-Adj Arm	379-0166
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

Sales Model 933F

42A		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-8736	Cup-Roller Brg	423-7759
1W-7074	Kit-Rebuild-Pump	419-4712
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-4438	Stud-Cl Spring	431-5260
2K-0227	Bearing-Sleeve	384-4780
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2S-4015	Plunger As-Valve	311-9438
2V-7198	Pilot As-Rec Spg	302-2709

42A		
Original Part Number	**Part Name**	**Classic Part Number**
3B-3967	Race-Roller Brg	386-4947
3B-6217	Muffler As	247-2671
3L-1425	Bearing-Ball	311-9356
4K-4780	Strip As-Wear	299-2063
4M-0410	Gear-Oil Pump Dr	428-6660
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-6224	Ferrule	419-4738
6F-2956	Cup-Spl Tapered	420-6538
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206

42A		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4603	Body-Fuel Valve	311-9348
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8M-6676	Cylinder-Adj	226-4960
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9H-2256	Pump Gp-F Prm	311-9443
9H-7670	Piston	226-4961
9S-9696	Spider As-Fan	383-3707
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

Sales Model 933G

42A		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-8736	Cup-Roller Brg	423-7759
1W-7074	Kit-Rebuild-Pump	419-4712
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-4438	Stud-Cl Spring	431-5260
2K-0227	Bearing-Sleeve	384-4780
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2S-4015	Plunger As-Valve	311-9438
2V-7198	Pilot As-Rec Spg	302-2709

42A		
Original Part Number	Part Name	Classic Part Number
3B-3967	Race-Roller Brg	386-4947
3B-6217	Muffler As	247-2671
3L-1425	Bearing-Ball	311-9356
4K-4780	Strip As-Wear	299-2063
4M-0410	Gear-Oil Pump Dr	428-6660
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-6224	Ferrule	419-4738
6F-2956	Cup-Spl Tapered	420-6538
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206

42A		
Original Part Number	Part Name	Classic Part Number
7M-4603	Body-Fuel Valve	311-9348
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8M-6676	Cylinder-Adj	226-4960
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9H-2256	Pump Gp-F Prm	311-9443
9H-7670	Piston	226-4961
9S-9696	Spider As-Fan	383-3707
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

Sales Model 951B

72J		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440

72J		
Original Part Number	Part Name	Classic Part Number
4B-9374	Bearing-Cup	380-7494
6B-3223	Cup-Bearing	399-6065
7C-4297	Seal As-Cshaft	325-6192

72J		
Original Part Number	Part Name	Classic Part Number
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
121-7746	Pre-Cleaner As	360-2311

Sales Model 955C

12A		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426

Sales Model 955C (Cont'd.)

12A		
Original Part Number	Part Name	Classic Part Number
1H-8382	Gear-Oil Pump Dr	226-6103
1M-7912	Cone-Roller Brg	380-7503
1M-8736	Cup-Roller Brg	423-7759
1M-9177	Plate-Cl Press	226-6112
1S-1888	Bracket-Lamp	297-7147
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
1S-6422	Pilot As-Spring	226-4849
1S-8764	Ring-Fly Clu Adj	226-8014
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2B-8824	Drum	216-7817
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2H-5080	Gasket Kt-V Gr	438-0180
2H-6936	Disc-Steer Cl Dr	380-7471
2K-4502	Bearing-Sleeve	299-1986
2K-4513	Bearing-Sleeve	308-9814
2M-1086	Plate As-Press	226-8023
2P-7622	Bolt-Spring	226-4850
2S-1273	Chamber As	319-3434
2S-4015	Plunger As-Valve	311-9438
3B-3967	Race-Roller Brg	386-4947

12A		
Original Part Number	Part Name	Classic Part Number
3B-6218	Muffler As	247-2672
3K-3124	Muffler-Trap	247-2673
3P-1465	Spring-Recoil	384-3479
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4J-2414	Trunnion	296-1370
4K-0255	Retainer As	226-6102
4M-0410	Gear-Oil Pump Dr	428-6660
5F-8651	Bearing-Ball	420-3223
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5K-7995	Bearing-Sleeve	308-9820
5K-8591	Bearing-Outer	380-7502
5M-6709	Check As-Ball	380-7542
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6P-0169	Hub-Fly Clutch	297-7204
6V-2202	Bearing-Spl Ball	380-1574
6W-0240	Bearing-Brace	297-7143
7H-2424	Sleeve-Spring	226-4852
7H-6967	Bearing-Ball	422-6489
7J-9682	Bearing-Sleeve	360-2335
7L-7508	Bearing-Ball	420-6536
7M-1154	Bearing-Spl	417-4515
7M-4603	Body-Fuel Valve	311-9348

12A		
Original Part Number	Part Name	Classic Part Number
7M-9398	Plate-Guide	297-7230
7S-7809	Cap As-Radiator	295-6417
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3428	Bearing-Sleeve	314-8647
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503
8H-1174	Drum-Ster Cl Dr	226-6101
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-6676	Cylinder-Adj	226-4960
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9H-7670	Piston	226-4961
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7534	Pipe-Exh Ext	398-2950
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166
160-6306	Cap-Bearing	325-6038
226-8202	Seal-Wiper	472-8024
231-1937	Kit-Strg Cl-Cla	226-6101
308-1845	Seal-Wiper	472-8032

Sales Model 955E

12A		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1M-7912	Cone-Roller Brg	380-7503
1M-8736	Cup-Roller Brg	423-7759
1M-9177	Plate-Cl Press	226-6112
1S-1888	Bracket-Lamp	297-7147
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
1S-6422	Pilot As-Spring	226-4849
1S-8764	Ring-Fly Clu Adj	226-8014
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2B-8824	Drum	216-7817
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2H-5080	Gasket Kt-V Gr	438-0180
2H-6936	Disc-Steer Cl Dr	380-7471
2K-4502	Bearing-Sleeve	299-1986
2K-4513	Bearing-Sleeve	308-9814
2M-1086	Plate As-Press	226-8023
2P-7622	Bolt-Spring	226-4850
2S-1273	Chamber As	319-3434
2S-4015	Plunger As-Valve	311-9438

12A		
Original Part Number	**Part Name**	**Classic Part Number**
3B-3967	Race-Roller Brg	386-4947
3B-6218	Muffler As	247-2672
3K-3124	Muffler-Trap	247-2673
3P-1465	Spring-Recoil	384-3479
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4J-2414	Trunnion	296-1370
4K-0255	Retainer As	226-6102
4M-0410	Gear-Oil Pump Dr	428-6660
5F-8651	Bearing-Ball	420-3223
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5K-7995	Bearing-Sleeve	308-9820
5K-8591	Bearing-Outer	380-7502
5M-6709	Check As-Ball	380-7542
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6P-0169	Hub-Fly Clutch	297-7204
6V-2202	Bearing-Spl Ball	380-1574
6W-0240	Bearing-Brace	297-7143
7H-2424	Sleeve-Spring	226-4852
7H-6967	Bearing-Ball	422-6489
7J-9682	Bearing-Sleeve	360-2335
7L-7508	Bearing-Ball	420-6536
7M-1154	Bearing-Spl	417-4515

12A		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4603	Body-Fuel Valve	311-9348
7M-9398	Plate-Guide	297-7230
7S-7809	Cap As-Radiator	295-6417
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-3428	Bearing-Sleeve	314-8647
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
8B-5972	Bearing-Ball	314-8503
8H-1174	Drum-Ster Cl Dr	226-6101
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-6676	Cylinder-Adj	226-4960
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9H-7670	Piston	226-4961
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7534	Pipe-Exh Ext	398-2950
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166
160-6306	Cap-Bearing	325-6038
226-8202	Seal-Wiper	472-8024
231-1937	Kit-Strg Cl-Cla	226-6101
308-1845	Seal-Wiper	472-8032

20A		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1642	Hub-Gear	219-2976
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-0176	Flange-Drum	223-4810
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1P-0005	Pump Gp-Fuel Tfr	256-4756
1S-1888	Bracket-Lamp	297-7147
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
1S-5331	Cylinder-Adj	226-0214
1S-6422	Pilot As-Spring	226-4849
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2F-7576	Shaft-Sprocket	226-6071
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4442	Bearing-Sleeve	308-9812
2K-4507	Bearing-Sleeve	325-6021
2K-4513	Bearing-Sleeve	308-9814
2L-5271	Bearing-Ball	371-4305

20A		
Original Part Number	**Part Name**	**Classic Part Number**
2P-0483	Chamber As	256-4760
2P-7622	Bolt-Spring	226-4850
2P-9660	Gear	226-5995
2S-1273	Chamber As	319-3434
2S-1477	Holder As-Cage	226-7985
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3B-8845	Bearing-Inner	417-4509
3F-1972	Retainer As	226-7988
3H-0881	Ring-Piston	465-8998
3H-8726	Mount As	385-7208
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3P-5754	Hub-Gear	219-2976
3S-7153	Gear-Sliding	227-0024
4B-1455	Cap As-Filler	361-1719
4F-1252	Pin	295-5704
4F-5003	Spring As-Arm	383-2127
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996
4H-9640	Bearing-Sleeve	386-4921
4M-0410	Gear-Oil Pump Dr	428-6660
4M-9183	Bearing-Sleeve	386-4924
4M-9215	Gear-Pump Idler	311-9391
4N-3875	Ring-Piston	465-8997
4S-8005	Pinion-Fdr	226-6076
5A-9551	Gear-Finaldrive	226-7979
5F-0736	Pin-Pivot	256-4823
5F-2256	Cage-Bearing	226-7973
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5M-6709	Check As-Ball	380-7542
5M-9644	Bearing-Outer	384-5929
5P-9176	Bearing	396-4141

20A		
Original Part Number	**Part Name**	**Classic Part Number**
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6N-5987	Shaft-Water Pump	390-0998
6P-0169	Hub-Fly Clutch	297-7204
6V-2202	Bearing-Spl Ball	380-1574
7B-5088	Drum-Steer Cl Dr	223-4813
7F-9547	Pin As.-Drawbar	295-0414
7G-6044	Cage As	216-7857
7H-1318	Coupling-Ster Cl	226-8002
7H-2424	Sleeve-Spring	226-4852
7H-4566	Cup-Roller Brg	399-6068
7H-6967	Bearing-Ball	422-6489
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7L-7508	Bearing-Ball	420-6536
7M-1154	Bearing-Spl	417-4515
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-9398	Plate-Guide	297-7230
7N-7639	Rotator-Valve	383-1582
7S-7602	Pump Gp-Cl Oil	226-0174
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7T-0206	Bearing-Brace	297-7144
8B-5965	Race & Roller As	417-4512
8F-5104	Screen As-Se Pan	314-8539

Sales Model 977D, 977E (Cont'd.)

20A		
Original Part Number	Part Name	Classic Part Number
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-1383	Rod-Tie	299-2051
8H-1994	Valve-Exhaust	443-1206
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-7980	Piston	226-0249
8H-9789	Bearing-Ball	374-8342
8M-6676	Cylinder-Adj	226-4960
8M-8068	Bearing-Spl Ball	417-4500

20A		
Original Part Number	Part Name	Classic Part Number
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
9B-1320	Valve-Check	377-5832
9F-3212	Bearing-Ball	384-5953
9F-7101	Bushing-Collar	299-1988
9H-6236	Rod As	390-0999
9H-7670	Piston	226-4961
9M-5350	Spring-Valve	380-7573
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9S-3321	Cage-Pinion Brg	226-7974

20A		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-1677	Bearing	297-7145
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
160-6306	Cap-Bearing	325-6038
226-8202	Seal-Wiper	472-8024
228-7325	Ster Cl Kit-Cla	230-7119
308-1845	Seal-Wiper	472-8032

Sales Model 977H

53A		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-0090	Gasket-Manifold	445-7701
1M-0176	Flange-Drum	223-4810
1M-6573	Cup-Roller Brg	399-4438
1M-8776	Bearing-Roller	417-4516
1P-1367	Plunger-Valve	432-8913
1S-1888	Bracket-Lamp	297-7147
1S-5315	Cap As-Brace Brg	226-4848
1S-5331	Cylinder-Adj	226-0214
1T-0051	Wheel-Impeller	388-6582
1T-0699	Impeller-Conv	235-1808
1T-1993	Wheel-Turbine	235-0920
1T-2069	Carrier-Bearing	439-4543
1W-7072	Rebuild Kt-Pump	428-6657
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354

53A		
Original Part Number	Part Name	Classic Part Number
2H-3712	Bearing-Ball	392-4488
2H-9192	Bearing-Ball	394-8236
2K-4442	Bearing-Sleeve	308-9812
2K-4507	Bearing-Sleeve	325-6021
2K-4513	Bearing-Sleeve	308-9814
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-2811	Race-Spl Rlr Brg	417-4528
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934
2S-6150	Cover-Pulley	428-8817
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3P-3623	Lock-Adj Nut	226-7989
3S-5017	Elbow-Exhaust	369-9498
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494

53A		
Original Part Number	Part Name	Classic Part Number
4F-1252	Pin	295-5704
4F-2393	Bearing-Ball	380-1499
4F-5003	Spring As-Arm	383-2127
4K-4780	Strip As-Wear	299-2063
4M-6107	Bearing-Roller	380-7507
5F-0736	Pin-Pivot	256-4823
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5K-8591	Bearing-Outer	380-7502
5L-7632	Support-Elbow	433-9854
5M-2054	Bearing	380-7510
5M-2824	Coupling-Exhaust	431-5270
5M-5856	Pipe-Extension	373-1913
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009

Sales Model 977H (Cont'd.)

53A		
Original Part Number	**Part Name**	**Classic Part Number**
6H-2577	Spider Gp-Brg&	333-4954
6H-3566	Cone-Bearing	415-1918
6I-8642	Race-Brg Outer	396-9898
6I-8860	Cup-Roller Brg	380-7495
6V-2202	Bearing-Spl Ball	380-1574
7B-5088	Drum-Steer Cl Dr	223-4813
7E-5085	Bushing	377-5829
7F-9547	Pin As.-Drawbar	295-0414
7H-1318	Coupling-Ster Cl	226-8002
7H-4566	Cup-Roller Brg	399-6068
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7N-0113	Core As-Oclr	388-0564
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656

53A		
Original Part Number	**Part Name**	**Classic Part Number**
7S-7809	Cap As-Radiator	295-6417
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8H-1383	Rod-Tie	299-2051
8H-4320	Bearing-Ball	419-2301
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-8068	Bearing-Spl Ball	417-4500
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8S-3517	Bearing-Spl Ball	417-4501

53A		
Original Part Number	**Part Name**	**Classic Part Number**
8S-9686	Gasket Kit	393-5215
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-9598	Pin	296-1362
9M-2744	Cone-Spl Tapered	380-1480
9M-4370	Bearing-Sleeve	453-6515
9M-4955	Pump Gp-F Tfr	242-3443
9M-5477	Bearing-Sleeve	374-6517
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-9696	Spider As-Fan	383-3707
9W-1677	Bearing	297-7145
108-5603	Screw-Adj Arm	379-0166
160-6306	Cap-Bearing	325-6038
169-4200	Gasket	472-8023
226-8202	Seal-Wiper	472-8024
228-7325	Ster Cl Kit-Cla	230-7119
232-3233	Bearing-Main	376-9085
308-1845	Seal-Wiper	472-8032

Sales Model D2

03J		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1B-3922	Cup-Roller Brg	416-2158
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-8736	Cup-Roller Brg	423-7759
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498

03J		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2S-4015	Plunger As-Valve	311-9438
3B-3967	Race-Roller Brg	386-4947
3B-6217	Muffler As	247-2671
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356

03J		
Original Part Number	**Part Name**	**Classic Part Number**
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
8B-5972	Bearing-Ball	314-8503
8H-9789	Bearing-Ball	374-8342
108-5603	Screw-Adj Arm	379-0166

Sales Model D2 (Cont'd.)

04U		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-8736	Cup-Roller Brg	423-7759
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354

04U		
Original Part Number	Part Name	Classic Part Number
2H-4438	Stud-Cl Spring	431-5260
2S-4015	Plunger As-Valve	311-9438
3B-3967	Race-Roller Brg	386-4947
3B-6217	Muffler As	247-2671
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-0410	Gear-Oil Pump Dr	428-6660
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665

04U		
Original Part Number	Part Name	Classic Part Number
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7T-2036	Cap As-Fuel	361-1721
8B-5972	Bearing-Ball	314-8503
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
9F-7101	Bushing-Collar	299-1988
108-5603	Screw-Adj Arm	379-0166

05J		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1B-3922	Cup-Roller Brg	416-2158
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-8736	Cup-Roller Brg	423-7759
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498

05J		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2S-4015	Plunger As-Valve	311-9438
3B-3967	Race-Roller Brg	386-4947
3B-6217	Muffler As	247-2671
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356

05J		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7M-1154	Bearing-Spl	417-4515
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
8B-5972	Bearing-Ball	314-8503
8H-9789	Bearing-Ball	374-8342
108-5603	Screw-Adj Arm	379-0166

05U		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-8736	Cup-Roller Brg	423-7759
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354

05U		
Original Part Number	Part Name	Classic Part Number
2H-4438	Stud-Cl Spring	431-5260
2S-4015	Plunger As-Valve	311-9438
3B-3967	Race-Roller Brg	386-4947
3B-6217	Muffler As	247-2671
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4M-0410	Gear-Oil Pump Dr	428-6660
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665

05U		
Original Part Number	Part Name	Classic Part Number
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-1154	Bearing-Spl	417-4515
7M-4603	Body-Fuel Valve	311-9348
7T-2036	Cap As-Fuel	361-1721
8B-5972	Bearing-Ball	314-8503
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
9F-7101	Bushing-Collar	299-1988
108-5603	Screw-Adj Arm	379-0166

Sales Model D3

06N		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-5920	Bearing-Camshaft	421-1558
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513

06N		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
3B-3967	Race-Roller Brg	386-4947
4N-8809	Chamber As	247-3297
5J-9348	Bearing As	416-2162
5M-7936	Bearing-Outer	386-4953
5S-5917	Screw-Rocker Adj	380-7537
6S-6902	Spider & Brg As	390-5280
6V-6896	Rebuild Kit	390-1006
7W-2059	Gasket-Cyl Hd	380-1548

06N		
Original Part Number	**Part Name**	**Classic Part Number**
7X-2396	Gasket Kit	393-5194
7X-2397	Gasket Kit	393-5193
8J-8809	Pump Gp-Gr -A	419-4653
8N-0701	Bearing-Sleeve	419-4745
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
9N-5246	Bearing-Camshaft	384-4772
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

79U		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-5920	Bearing-Camshaft	421-1558
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2K-0227	Bearing-Sleeve	384-4780

79U		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
3B-3967	Race-Roller Brg	386-4947
4J-5241	Retainer	434-1415
4N-8809	Chamber As	247-3297
4T-8054	Seal As	472-8010
5J-9348	Bearing As	416-2162
5M-7936	Bearing-Outer	386-4953
5S-5917	Screw-Rocker Adj	380-7537
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6V-6896	Rebuild Kit	390-1006
7J-6461	Crown	325-6054
7W-2059	Gasket-Cyl Hd	380-1548
7X-2396	Gasket Kit	393-5194
7X-2397	Gasket Kit	393-5193

79U		
Original Part Number	**Part Name**	**Classic Part Number**
8J-8809	Pump Gp-Gr -A	419-4653
8N-0701	Bearing-Sleeve	419-4745
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
9N-5246	Bearing-Camshaft	384-4772
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9Y-9431	Precleaner As	361-1718
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

82U		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3821	Bearing-Conn Rod	376-9076

Sales Model D3 (Cont'd.)

82U		
Original Part Number	Part Name	Classic Part Number
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-5920	Bearing-Camshaft	421-1558
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2K-0227	Bearing-Sleeve	384-4780
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
3B-3967	Race-Roller Brg	386-4947
4J-5241	Retainer	434-1415
4N-8809	Chamber As	247-3297
4T-8054	Seal As	472-8010
5J-9348	Bearing As	416-2162
5M-7936	Bearing-Outer	386-4953
5S-5917	Screw-Rocker Adj	380-7537
6S-6902	Spider & Brg As	390-5280
6V-6896	Rebuild Kit	390-1006
7J-6461	Crown	325-6054

82U		
Original Part Number	Part Name	Classic Part Number
7W-2059	Gasket-Cyl Hd	380-1548
7X-2396	Gasket Kit	393-5194
7X-2397	Gasket Kit	393-5193
8J-8809	Pump Gp-Gr -A	419-4653
8N-0701	Bearing-Sleeve	419-4745
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
9N-5246	Bearing-Camshaft	384-4772
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9Y-9431	Precleaner As	361-1718
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-5920	Bearing-Camshaft	421-1558

82U		
Original Part Number	Part Name	Classic Part Number
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
3B-3967	Race-Roller Brg	386-4947
4N-8809	Chamber As	247-3297
5J-9348	Bearing As	416-2162
5M-7936	Bearing-Outer	386-4953
5S-5917	Screw-Rocker Adj	380-7537
6S-6902	Spider & Brg As	390-5280
6V-6896	Rebuild Kit	390-1006
7W-2059	Gasket-Cyl Hd	380-1548
7X-2396	Gasket Kit	393-5194
7X-2397	Gasket Kit	393-5193
8J-8809	Pump Gp-Gr -A	419-4653
8N-0701	Bearing-Sleeve	419-4745
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
9N-5246	Bearing-Camshaft	384-4772
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9Y-9431	Precleaner As	361-1718

Sales Model D3B

23Y		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076

23Y		
Original Part Number	Part Name	Classic Part Number
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

23Y		
Original Part Number	Part Name	Classic Part Number
1P-7115	Mount As	418-1936
1S-1888	Bracket-Lamp	297-7147
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078

Sales Model D3B (Cont'd.)

23Y		
Original Part Number	Part Name	Classic Part Number
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3J-6575	Trunnion	297-7265
3Y-2768	Ring	439-4544
4J-5241	Retainer	434-1415
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534

23Y		
Original Part Number	Part Name	Classic Part Number
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-7936	Bearing-Outer	386-4953
5P-7807	Bearing-Ball	314-8502
5P-9439	Bearing-Spl Ball	371-4306
5S-5917	Screw-Rocker Adj	380-7537
5V-1168	Spider & Brg As	377-7435
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7E-5085	Bushing	377-5829
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531

23Y		
Original Part Number	Part Name	Classic Part Number
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2397	Gasket Kit	393-5193
7X-2846	Gasket Kit	437-8647
8E-4026	Pin As	394-0902
8H-8175	Bearing-Sleeve	376-3636
8J-2880	Cap-Bearing	295-6420
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653
8N-0701	Bearing-Sleeve	419-4745
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3539	Plunger As-Pump	377-5861
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9M-4789	Shaft-Gov Cont	297-7256
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-2653	Pump Gp-Gr 1 Bsc	386-3057
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5211	Plate-Clutch	380-1493
9S-6917	Gear-Cplg Ring	446-3075
9W-1677	Bearing	297-7145
9W-3120	Pin As	393-3641
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197

Sales Model D3B (Cont'd.)

23Y		
Original Part Number	Part Name	Classic Part Number
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
150-0351	Spacer	396-7291

23Y		
Original Part Number	Part Name	Classic Part Number
160-6306	Cap-Bearing	325-6038
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028

23Y		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

24Y		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1T-0043	Bearing-Ball	390-5294
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-3803	Gear	226-6106
2W-1223	Pump Gp-Water	385-7197

24Y		
Original Part Number	Part Name	Classic Part Number
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6575	Trunnion	297-7265
3Y-2768	Ring	439-4544
4J-0121	Cap-Bearing	360-2344
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-7936	Bearing-Outer	386-4953
5P-7807	Bearing-Ball	314-8502
5P-9439	Bearing-Spl Ball	371-4306
5S-5917	Screw-Rocker Adj	380-7537
5V-1168	Spider & Brg As	377-7435
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428

24Y		
Original Part Number	Part Name	Classic Part Number
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7E-5085	Bushing	377-5829
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9884	Bearing-Sleeve	325-6016
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2397	Gasket Kit	393-5193
7X-2846	Gasket Kit	437-8647
8E-4026	Pin As	394-0902
8H-8175	Bearing-Sleeve	376-3636
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653

Sales Model D3B (Cont'd.)

24Y		
Original Part Number	Part Name	Classic Part Number
8N-0701	Bearing-Sleeve	419-4745
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3539	Plunger As-Pump	377-5861
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
9J-2759	Trunnion	394-0216
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361

24Y		
Original Part Number	Part Name	Classic Part Number
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9M-4789	Shaft-Gov Cont	297-7256
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-2653	Pump Gp-Gr 1 Bsc	386-3057
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5211	Plate-Clutch	380-1493

24Y		
Original Part Number	Part Name	Classic Part Number
9S-6917	Gear-Cplg Ring	446-3075
9W-1677	Bearing	297-7145
9W-3120	Pin As	393-3641
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
150-0351	Spacer	396-7291
160-6306	Cap-Bearing	325-6038
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

27Y		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

27Y		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899

27Y		
Original Part Number	Part Name	Classic Part Number
3Y-2768	Ring	439-4544
4D-4065	Rod End-Spher	374-1824
4J-5241	Retainer	434-1415
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5P-7807	Bearing-Ball	314-8502
5P-9439	Bearing-Spl Ball	371-4306
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg	373-5386

Sales Model D3B (Cont'd.)

27Y		
Original Part Number	Part Name	Classic Part Number
5V-1168	Spider & Brg As	377-7435
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7E-5085	Bushing	377-5829
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846

27Y		
Original Part Number	Part Name	Classic Part Number
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2397	Gasket Kit	393-5193
8E-4024	Carrier-Planet	398-8333
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-8175	Bearing-Sleeve	376-3636
8J-2880	Cap-Bearing	295-6420
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653
8N-0701	Bearing-Sleeve	419-4745
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3539	Plunger As-Pump	377-5861
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033

27Y		
Original Part Number	Part Name	Classic Part Number
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9M-4789	Shaft-Gov Cont	297-7256
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-1677	Bearing	297-7145
9W-3120	Pin As	393-3641
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
140-2382	Gasket Kit	390-5285
150-0351	Spacer	396-7291
154-5676	Gasket Kit	447-0827
160-6306	Cap-Bearing	325-6038
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

28Y		
Original Part Number	Part Name	Classic Part Number
1B-4102	Bearing-Ball	399-4426
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077

28Y		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294

28Y		
Original Part Number	Part Name	Classic Part Number
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859

Sales Model D3B (Cont'd.)

28Y		
Original Part Number	Part Name	Classic Part Number
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3J-6575	Trunnion	297-7265
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720

28Y		
Original Part Number	Part Name	Classic Part Number
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5P-9439	Bearing-Spl Ball	371-4306
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg	373-5386
5V-1168	Spider & Brg As	377-7435
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6N-3256	Mount As	314-8688
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444

28Y		
Original Part Number	Part Name	Classic Part Number
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7E-5085	Bushing	377-5829
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9884	Bearing-Sleeve	325-6016
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2397	Gasket Kit	393-5193
8E-4024	Carrier-Planet	398-8333
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653
8N-0701	Bearing-Sleeve	419-4745
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

Sales Model D3B (Cont'd.)

28Y		
Original Part Number	Part Name	Classic Part Number
8N-3539	Plunger As-Pump	377-5861
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9J-2759	Trunnion	394-0216
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018

28Y		
Original Part Number	Part Name	Classic Part Number
9M-4789	Shaft-Gov Cont	297-7256
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-1677	Bearing	297-7145
9W-3120	Pin As	393-3641
9W-6390	Sleeve	385-3795
9Y-9431	Precleaner As	361-1718

28Y		
Original Part Number	Part Name	Classic Part Number
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
140-2382	Gasket Kit	390-5285
150-0351	Spacer	396-7291
154-5676	Gasket Kit	447-0827
160-6306	Cap-Bearing	325-6038
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

2PC		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2H-6936	Disc-Steer Cl Dr	380-7471

2PC		
Original Part Number	Part Name	Classic Part Number
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3J-6575	Trunnion	297-7265
3J-9511	Bearing-Sleeve	385-3782
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4J-0121	Cap-Bearing	360-2344
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216

2PC		
Original Part Number	Part Name	Classic Part Number
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5G-4381	Yoke As	469-4662
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5M-9644	Bearing-Outer	384-5929
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg	373-5386
5V-1168	Spider & Brg As	377-7435
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279

Sales Model D3B (Cont'd.)

2PC		
Original Part Number	Part Name	Classic Part Number
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7J-2604	Bearing-Sleeve	380-7369
7J-8893	Cone-Roller Brg	374-1846
7K-2135	Bearing-Roller	417-4492
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-7166	Race-Brg Thrust	417-4531

2PC		
Original Part Number	Part Name	Classic Part Number
7P-7858	Bearing-Sleeve	374-8362
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
9J-2759	Trunnion	394-0216
9K-8757	Rod End-Special	311-9361

2PC		
Original Part Number	Part Name	Classic Part Number
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9S-7949	Cup-Roller Brg	420-6531
9W-1677	Bearing	297-7145
9Y-5168	Manifold-Exhaust	374-7483
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
160-6306	Cap-Bearing	325-6038
226-8202	Seal-Wiper	472-8024

3YC		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

3YC		
Original Part Number	Part Name	Classic Part Number
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208

3YC		
Original Part Number	Part Name	Classic Part Number
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4D-4065	Rod End-Spher	374-1824
4J-5241	Retainer	434-1415
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956

Sales Model D3B (Cont'd.)

3YC		
Original Part Number	Part Name	Classic Part Number
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg	373-5386
5V-1168	Spider & Brg As	377-7435
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054

3YC		
Original Part Number	Part Name	Classic Part Number
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4026	Pin As	394-0902
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8J-2880	Cap-Bearing	295-6420
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267

3YC		
Original Part Number	Part Name	Classic Part Number
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9S-7949	Cup-Roller Brg	420-6531
9W-3120	Pin As	393-3641
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
150-0351	Spacer	396-7291
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

5MC		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900

5MC		
Original Part Number	Part Name	Classic Part Number
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678

5MC		
Original Part Number	Part Name	Classic Part Number
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6575	Trunnion	297-7265

Sales Model D3B (Cont'd.)

5MC		
Original Part Number	**Part Name**	**Classic Part Number**
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg	373-5386
5V-1168	Spider & Brg As	377-7435
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6S-3158	Yoke	380-1478

5MC		
Original Part Number	**Part Name**	**Classic Part Number**
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9884	Bearing-Sleeve	325-6016
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4026	Pin As	394-0902
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653

5MC		
Original Part Number	**Part Name**	**Classic Part Number**
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
9J-2759	Trunnion	394-0216
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9S-7949	Cup-Roller Brg	420-6531
9W-1677	Bearing	297-7145
9W-3120	Pin As	393-3641
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
150-0351	Spacer	396-7291
160-6306	Cap-Bearing	325-6038
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model D3C

1PJ		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883

1PJ		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077

1PJ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

Sales Model D3C (Cont'd.)

1PJ		
Original Part Number	Part Name	Classic Part Number
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3J-6575	Trunnion	297-7265
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487

1PJ		
Original Part Number	Part Name	Classic Part Number
3Y-2768	Ring	439-4544
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5M-9644	Bearing-Outer	384-5929
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg&	373-5386
5V-1168	Spider & Brg As	377-7435
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103

1PJ		
Original Part Number	Part Name	Classic Part Number
6P-7968	Plate-Clutch	416-2133
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-2689	Coupler	422-3508
6Y-6832	Bearing-Rlr As	421-8181
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7F-2742	Bearing-Ball	422-6488
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9884	Bearing-Sleeve	325-6016
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9642	Bearing-Sleeve	360-2340
7M-1154	Bearing-Spl	417-4515
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548

Sales Model D3C (Cont'd.)

1PJ		
Original Part Number	Part Name	Classic Part Number
8E-4024	Carrier-Planet	398-8333
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501

1PJ		
Original Part Number	Part Name	Classic Part Number
9J-2759	Trunnion	394-0216
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-1677	Bearing	297-7145
9W-3120	Pin As	393-3641
9W-6044	Shaft-Planet	384-5957

1PJ		
Original Part Number	Part Name	Classic Part Number
9W-6046	Carrier As	388-0645
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
150-0351	Spacer	396-7291
154-5676	Gasket Kit	447-0827
160-6306	Cap-Bearing	325-6038
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

3RF		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

3RF		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208

3RF		
Original Part Number	Part Name	Classic Part Number
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4D-4065	Rod End-Spher	374-1824
4J-5241	Retainer	434-1415
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5K-2754	Spring-Recoil	418-1956

Sales Model D3C (Cont'd.)

3RF		
Original Part Number	Part Name	Classic Part Number
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5M-7936	Bearing-Outer	386-4953
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5V-1168	Spider & Brg As	377-7435
6E-0775	Head	425-9373
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846

3RF		
Original Part Number	Part Name	Classic Part Number
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4026	Pin As	394-0902
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9J-9812	Bearing	434-7258

3RF		
Original Part Number	Part Name	Classic Part Number
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-2653	Pump Gp-Gr 1 Bsc	386-3057
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5211	Plate-Clutch	380-1493
9S-6917	Gear-Cplg Ring	446-3075
9S-7949	Cup-Roller Brg	420-6531
9W-3120	Pin As	393-3641
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220
150-0351	Spacer	396-7291
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

4HJ		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936

4HJ		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900

4HJ		
Original Part Number	Part Name	Classic Part Number
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

Sales Model D3C (Cont'd.)

4HJ		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4D-4065	Rod End-Spher	374-1824
4J-5241	Retainer	434-1415
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5M-7936	Bearing-Outer	386-4953
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537

4HJ		
Original Part Number	Part Name	Classic Part Number
5T-8739	Spider Gp-Brg&	373-5386
5V-1168	Spider & Brg As	377-7435
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910

4HJ		
Original Part Number	Part Name	Classic Part Number
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2846	Gasket Kit	437-8647
8E-4024	Carrier-Planet	398-8333
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-2653	Pump Gp-Gr 1 Bsc	386-3057
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5211	Plate-Clutch	380-1493

Sales Model D3C (Cont'd.)

4HJ		
Original Part Number	Part Name	Classic Part Number
9S-6917	Gear-Cplg Ring	446-3075
9S-7949	Cup-Roller Brg	420-6531
9W-1677	Bearing	297-7145
9W-3120	Pin As	393-3641
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-9431	Precleaner As	361-1718

4HJ		
Original Part Number	Part Name	Classic Part Number
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
150-0351	Spacer	396-7291

4HJ		
Original Part Number	Part Name	Classic Part Number
154-5676	Gasket Kit	447-0827
160-6306	Cap-Bearing	325-6038
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

4KS		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
2H-6489	Race-Brg Outer	374-8350
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4J-5241	Retainer	434-1415
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5M-5856	Pipe-Extension	373-1913
5P-5354	Cup-Rlr Bearing	399-4445

4KS		
Original Part Number	Part Name	Classic Part Number
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
7G-4758	Gear-Planet	288-8723
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7K-9639	Bearing-Sleeve	314-8643
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816
8C-3111	Rod End-Spher	392-4523
8E-4026	Pin As	394-0902
8J-3443	Bearing	396-7281
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258

4KS		
Original Part Number	Part Name	Classic Part Number
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
9Y-9431	Precleaner As	361-1718
107-7473	Muffler As.	385-7223
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
126-0734	Muffler As	397-5052
133-6597	Pipe-Extension	420-6220
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
169-9527	Cyl Gp-0076-0352	430-5959
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

4TS		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
2H-6489	Race-Brg Outer	374-8350
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947

4TS		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4J-5241	Retainer	434-1415
4T-8054	Seal As	472-8010
5J-9348	Bearing As	416-2162
5M-5856	Pipe-Extension	373-1913
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657

4TS		
Original Part Number	Part Name	Classic Part Number
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
7G-4758	Gear-Planet	288-8723
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7M-7219	Bearing-Thrust	384-4816
8C-3111	Rod End-Spher	392-4523
8E-4026	Pin As	394-0902
8J-3443	Bearing	396-7281
8T-0072	Cone-Rlr Brg	377-7448

Sales Model D3C (Cont'd.)

4TS		
Original Part Number	Part Name	Classic Part Number
8T-1177	Bearing-Rlr	419-1862
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
9Y-9431	Precleaner As	361-1718

4TS		
Original Part Number	Part Name	Classic Part Number
107-7473	Muffler As.	385-7223
112-4297	Cylinder As	443-5199
126-0734	Muffler As	397-5052
133-6597	Pipe-Extension	420-6220
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
169-9527	Cyl Gp-0076-0352	430-5959

4TS		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

5CJ		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628

5CJ		
Original Part Number	Part Name	Classic Part Number
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3J-6575	Trunnion	297-7265
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502

5CJ		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5M-7936	Bearing-Outer	386-4953
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg&	373-5386
5V-1168	Spider & Brg As	377-7435
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590

Sales Model D3C (Cont'd.)

5CJ		
Original Part Number	Part Name	Classic Part Number
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9884	Bearing-Sleeve	325-6016
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721

5CJ		
Original Part Number	Part Name	Classic Part Number
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2846	Gasket Kit	437-8647
8E-4024	Carrier-Planet	398-8333
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9J-2759	Trunnion	394-0216
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607

5CJ		
Original Part Number	Part Name	Classic Part Number
9N-6500	Rod-Valve Push	383-3706
9P-2653	Pump Gp-Gr 1 Bsc	386-3057
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5211	Plate-Clutch	380-1493
9S-6917	Gear-Cplg Ring	446-3075
9S-7949	Cup-Roller Brg	420-6531
9W-1677	Bearing	297-7145
9W-3120	Pin As	393-3641
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-9431	Precleaner As	361-1718
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
150-0351	Spacer	396-7291
154-5676	Gasket Kit	447-0827
160-6306	Cap-Bearing	325-6038
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

5GS		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
2H-6489	Race-Brg Outer	374-8350
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970

5GS		
Original Part Number	Part Name	Classic Part Number
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4J-5241	Retainer	434-1415
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956

5GS		
Original Part Number	Part Name	Classic Part Number
5M-5856	Pipe-Extension	373-1913
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
7G-4758	Gear-Planet	288-8723
7J-5131	Trunnion	296-1371

Sales Model D3C (Cont'd.)

5GS		
Original Part Number	**Part Name**	**Classic Part Number**
7J-6461	Crown	325-6054
7M-7219	Bearing-Thrust	384-4816
8C-3111	Rod End-Spher	392-4523
8E-4026	Pin As	394-0902
8J-3443	Bearing	396-7281
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361

5GS		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1328	Bearing-Aligning	325-6018
9Y-9431	Precleaner As	361-1718
107-7473	Muffler As.	385-7223
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
126-0734	Muffler As	397-5052
133-6597	Pipe-Extension	420-6220
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291

5GS		
Original Part Number	**Part Name**	**Classic Part Number**
169-9527	Cyl Gp-0076-0352	430-5959
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

5KG		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

5KG		
Original Part Number	**Part Name**	**Classic Part Number**
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3Y-2768	Ring	439-4544
4D-4065	Rod End-Spher	374-1824
4J-5241	Retainer	434-1415
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216

5KG		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5M-9644	Bearing-Outer	384-5929
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg&	373-5386
5V-1168	Spider & Brg As	377-7435
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015

Sales Model D3C (Cont'd.)

5KG		
Original Part Number	Part Name	Classic Part Number
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6P-7968	Plate-Clutch	416-2133
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-2689	Coupler	422-3508
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7F-2742	Bearing-Ball	422-6488
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166

5KG		
Original Part Number	Part Name	Classic Part Number
7K-8877	Cone-Bearing	374-1847
7M-1154	Bearing-Spl	417-4515
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4024	Carrier-Planet	398-8333
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134

5KG		
Original Part Number	Part Name	Classic Part Number
8Y-6559	Hub	416-5501
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-3120	Pin As	393-3641
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
150-0351	Spacer	396-7291
154-5676	Gasket Kit	447-0827
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

5NS		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
2H-6489	Race-Brg Outer	374-8350
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970

5NS		
Original Part Number	Part Name	Classic Part Number
3B-3967	Race-Roller Brg	386-4947
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346

5NS		
Original Part Number	Part Name	Classic Part Number
3J-6575	Trunnion	297-7265
3Y-2768	Ring	439-4544
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010

Sales Model D3C (Cont'd.)

5NS		
Original Part Number	**Part Name**	**Classic Part Number**
5G-4381	Yoke As	469-4662
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-3474	Pin As	375-9981
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
7G-4758	Gear-Planet	288-8723
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016

5NS		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816
8C-3111	Rod End-Spher	392-4523
8E-4026	Pin As	394-0902
8J-3443	Bearing	396-7281
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-2735	Spring	383-2134
9J-2759	Trunnion	394-0216
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018

5NS		
Original Part Number	**Part Name**	**Classic Part Number**
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718
107-7473	Muffler As.	385-7223
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
160-6306	Cap-Bearing	325-6038
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

5ZG		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913

5ZG		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6575	Trunnion	297-7265
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344

5ZG		
Original Part Number	**Part Name**	**Classic Part Number**
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5V-1168	Spider & Brg As	377-7435
6H-3957	Bearing-Ball	311-9358

Sales Model D3C (Cont'd.)

5ZG		
Original Part Number	Part Name	Classic Part Number
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9884	Bearing-Sleeve	325-6016

5ZG		
Original Part Number	Part Name	Classic Part Number
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2846	Gasket Kit	437-8647
8E-4024	Carrier-Planet	398-8333
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9J-2759	Trunnion	394-0216

5ZG		
Original Part Number	Part Name	Classic Part Number
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-1677	Bearing	297-7145
9W-3120	Pin As	393-3641
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-9431	Precleaner As	361-1718
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220
150-0351	Spacer	396-7291
160-6306	Cap-Bearing	325-6038
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

6PF		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535

6PF		
Original Part Number	Part Name	Classic Part Number
1P-3935	Cone-Roller Brg	377-7397
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900

6PF		
Original Part Number	Part Name	Classic Part Number
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513

Sales Model D3C (Cont'd.)

6PF		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6575	Trunnion	297-7265
3Y-2768	Ring	439-4544
4J-0121	Cap-Bearing	360-2344
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5M-7936	Bearing-Outer	386-4953
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537

6PF		
Original Part Number	Part Name	Classic Part Number
5V-1168	Spider & Brg As	377-7435
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9884	Bearing-Sleeve	325-6016
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4026	Pin As	394-0902
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-3443	Bearing	396-7281

6SL		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849

6PF		
Original Part Number	Part Name	Classic Part Number
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9J-2759	Trunnion	394-0216
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-2653	Pump Gp-Gr 1 Bsc	386-3057
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5211	Plate-Clutch	380-1493
9S-6917	Gear-Cplg Ring	446-3075
9W-1677	Bearing	297-7145
9W-3120	Pin As	393-3641
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220
150-0351	Spacer	396-7291
160-6306	Cap-Bearing	325-6038
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model D3C (Cont'd.)

6SL		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
3B-3967	Race-Roller Brg	386-4947
3G-4704	Bearing-Sleeve	379-0185
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4J-5241	Retainer	434-1415
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956

6SL		
Original Part Number	Part Name	Classic Part Number
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5T-8739	Spider Gp-Brg&	373-5386
5V-1168	Spider & Brg As	377-7435
6E-4892	Cyl Gp-089 478 Y	394-9828
6H-3957	Bearing-Ball	311-9358
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444
6Y-6832	Bearing-Rlr As	421-8181
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509

6SL		
Original Part Number	Part Name	Classic Part Number
8D-9296	Bearing	330-9253
8E-4024	Carrier-Planet	398-8333
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-3443	Bearing	396-7281
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-1677	Bearing	297-7145
9W-3120	Pin As	393-3641
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-9431	Precleaner As	361-1718
107-7473	Muffler As.	385-7223
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
126-0734	Muffler As	397-5052
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
154-5676	Gasket Kit	447-0827
160-6306	Cap-Bearing	325-6038
174-6836	Gasket Kit - Tof	434-7280
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model D3C (Cont'd.)

7GS		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
2H-6489	Race-Brg Outer	374-8350
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4J-5241	Retainer	434-1415
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662
5J-9348	Bearing As	416-2162

7GS		
Original Part Number	Part Name	Classic Part Number
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
7G-4758	Gear-Planet	288-8723
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7M-7219	Bearing-Thrust	384-4816
8C-3111	Rod End-Spher	392-4523
8E-4026	Pin As	394-0902
8J-3443	Bearing	396-7281
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-2735	Spring	383-2134

7GS		
Original Part Number	Part Name	Classic Part Number
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
9Y-9431	Precleaner As	361-1718
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
169-9527	Cyl Gp-0076-0352	430-5959
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

7JF		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513

7JF		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3J-9511	Bearing-Sleeve	385-3782
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216

7JF		
Original Part Number	Part Name	Classic Part Number
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg&	373-5386
5V-1168	Spider & Brg As	377-7435
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593

Sales Model D3C (Cont'd.)

7JF		
Original Part Number	Part Name	Classic Part Number
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7J-2604	Bearing-Sleeve	380-7369
7J-5131	Trunnion	296-1371
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-7166	Race-Brg Thrust	417-4531

7JF		
Original Part Number	Part Name	Classic Part Number
7P-7858	Bearing-Sleeve	374-8362
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4026	Pin As	394-0902
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8J-2880	Cap-Bearing	295-6420
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501

7JF		
Original Part Number	Part Name	Classic Part Number
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9S-7949	Cup-Roller Brg	420-6531
9W-3120	Pin As	393-3641
9Y-5168	Manifold-Exhaust	374-7483
9Y-9431	Precleaner As	361-1718
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
150-0351	Spacer	396-7291
226-8202	Seal-Wiper	472-8024

7JG		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859

7JG		
Original Part Number	Part Name	Classic Part Number
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678

7JG		
Original Part Number	Part Name	Classic Part Number
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4J-5241	Retainer	434-1415
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010

Sales Model D3C (Cont'd.)

7JG		
Original Part Number	Part Name	Classic Part Number
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5M-7936	Bearing-Outer	386-4953
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5V-1168	Spider & Brg As	377-7435
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121

7JG		
Original Part Number	Part Name	Classic Part Number
7B-7515	Bearing-Ball	399-6059
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2846	Gasket Kit	437-8647
8E-4024	Carrier-Planet	398-8333
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267

7JG		
Original Part Number	Part Name	Classic Part Number
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-2653	Pump Gp-Gr 1 Bsc	386-3057
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5211	Plate-Clutch	380-1493
9S-6917	Gear-Cplg Ring	446-3075
9S-7949	Cup-Roller Brg	420-6531
9W-3120	Pin As	393-3641
9Y-9431	Precleaner As	361-1718
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220
150-0351	Spacer	396-7291
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

7XL		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535

7XL		
Original Part Number	Part Name	Classic Part Number
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894

7XL		
Original Part Number	Part Name	Classic Part Number
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413

Sales Model D3C (Cont'd.)

7XL		
Original Part Number	**Part Name**	**Classic Part Number**
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
3B-3967	Race-Roller Brg	386-4947
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3J-6575	Trunnion	297-7265
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5T-8739	Spider Gp-Brg&	373-5386
5V-1168	Spider & Brg As	377-7435
6H-3957	Bearing-Ball	311-9358
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389

7XL		
Original Part Number	**Part Name**	**Classic Part Number**
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9884	Bearing-Sleeve	325-6016
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7T-9989	Housing As-Cl	380-1509
8E-4024	Carrier-Planet	398-8333
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636

7XL		
Original Part Number	**Part Name**	**Classic Part Number**
8H-8898	Pin	385-3801
8J-3443	Bearing	396-7281
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9J-2759	Trunnion	394-0216
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-1677	Bearing	297-7145
9W-3120	Pin As	393-3641
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-9431	Precleaner As	361-1718
107-7473	Muffler As.	385-7223
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
126-0734	Muffler As	397-5052
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
154-5676	Gasket Kit	447-0827
160-6306	Cap-Bearing	325-6038
169-9527	Cyl Gp-0076-0352	430-5959
174-6836	Gasket Kit - Tof	434-7280
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

8BF		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759

8BF		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076

8BF		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535

Sales Model D3C (Cont'd.)

8BF		
Original Part Number	Part Name	Classic Part Number
1P-3935	Cone-Roller Brg	377-7397
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6575	Trunnion	297-7265
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3Y-2768	Ring	439-4544
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720

8BF		
Original Part Number	Part Name	Classic Part Number
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5M-9644	Bearing-Outer	384-5929
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5V-1168	Spider & Brg As	377-7435
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6P-7968	Plate-Clutch	416-2133
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-2689	Coupler	422-3508
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7F-2742	Bearing-Ball	422-6488
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846

8BF		
Original Part Number	Part Name	Classic Part Number
7J-9884	Bearing-Sleeve	325-6016
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-1154	Bearing-Spl	417-4515
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4026	Pin As	394-0902
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9J-2759	Trunnion	394-0216
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6903	Plate	368-0108
9S-7949	Cup-Roller Brg	420-6531

Sales Model D3C (Cont'd.)

8BF		
Original Part Number	Part Name	Classic Part Number
9W-1677	Bearing	297-7145
9W-3120	Pin As	393-3641
9Y-9431	Precleaner As	361-1718
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199

8BF		
Original Part Number	Part Name	Classic Part Number
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220
150-0351	Spacer	396-7291
160-6306	Cap-Bearing	325-6038

8BF		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

8DG		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970

8DG		
Original Part Number	Part Name	Classic Part Number
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6575	Trunnion	297-7265
3Y-2768	Ring	439-4544
4J-0121	Cap-Bearing	360-2344
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5M-7936	Bearing-Outer	386-4953
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5V-1168	Spider & Brg As	377-7435

8DG		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9884	Bearing-Sleeve	325-6016
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816

Sales Model D3C (Cont'd.)

8DG		
Original Part Number	Part Name	Classic Part Number
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2846	Gasket Kit	437-8647
8E-4024	Carrier-Planet	398-8333
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

8DG		
Original Part Number	Part Name	Classic Part Number
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9J-2759	Trunnion	394-0216
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-2653	Pump Gp-Gr 1 Bsc	386-3057
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122

8DG		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5211	Plate-Clutch	380-1493
9S-6917	Gear-Cplg Ring	446-3075
9S-7949	Cup-Roller Brg	420-6531
9W-1677	Bearing	297-7145
9W-3120	Pin As	393-3641
9Y-9431	Precleaner As	361-1718
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220
150-0351	Spacer	396-7291
160-6306	Cap-Bearing	325-6038
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

8DL		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
3B-3967	Race-Roller Brg	386-4947
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588

8DL		
Original Part Number	Part Name	Classic Part Number
3F-6612	Cap-Ball Joint	297-7155
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3J-6575	Trunnion	297-7265
3K-4290	Rod End	374-1823
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4S-8538	Bearing-Spl Ball	417-4502

8DL		
Original Part Number	Part Name	Classic Part Number
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-7010	Seal As	472-8011
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5T-8739	Spider Gp-Brg&	373-5386
5V-1168	Spider & Brg As	377-7435
6K-8088	Bearing-Roller	399-4428
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277

Sales Model D3C (Cont'd.)

8DL		
Original Part Number	Part Name	Classic Part Number
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444
6Y-6832	Bearing-Rlr As	421-8181
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-6450	Pipe Gp-Ext	377-5862
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9884	Bearing-Sleeve	325-6016
7K-8237	Drum	226-6100

8DL		
Original Part Number	Part Name	Classic Part Number
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7P-7858	Bearing-Sleeve	374-8362
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9J-2759	Trunnion	394-0216
9K-8757	Rod End-Special	311-9361
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531

8DL		
Original Part Number	Part Name	Classic Part Number
9T-4762	Head	325-6109
9W-1677	Bearing	297-7145
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-9431	Precleaner As	361-1718
100-4529	Piston As	424-6368
107-7473	Muffler As.	385-7223
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
126-0734	Muffler As	397-5052
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
150-0351	Spacer	396-7291
151-5349	Head	383-1592
160-6306	Cap-Bearing	325-6038
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

9CL		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970

9CL		
Original Part Number	Part Name	Classic Part Number
2S-7931	Bearing-Sleeve	387-2904
3B-3967	Race-Roller Brg	386-4947
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662

9CL		
Original Part Number	Part Name	Classic Part Number
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-7010	Seal As	472-8011
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5T-8739	Spider Gp-Brg&	373-5386
5V-1168	Spider & Brg As	377-7435
6H-3957	Bearing-Ball	311-9358
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478

Sales Model D3C (Cont'd.)

9CL		
Original Part Number	Part Name	Classic Part Number
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-3474	Pin As	375-9981
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444
6Y-6832	Bearing-Rlr As	421-8181
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166

9CL		
Original Part Number	Part Name	Classic Part Number
7K-8877	Cone-Bearing	374-1847
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
8E-4024	Carrier-Planet	398-8333
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-3443	Bearing	396-7281
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505

9CL		
Original Part Number	Part Name	Classic Part Number
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-1677	Bearing	297-7145
9W-3120	Pin As	393-3641
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-9431	Precleaner As	361-1718
107-7473	Muffler As.	385-7223
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
126-0734	Muffler As	397-5052
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
150-0351	Spacer	396-7291
160-6306	Cap-Bearing	325-6038
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
308-1845	Seal-Wiper	472-8032

9TS		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904

9TS		
Original Part Number	Part Name	Classic Part Number
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4J-5241	Retainer	434-1415
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5T-8739	Spider Gp-Brg&	373-5386

9TS		
Original Part Number	Part Name	Classic Part Number
5V-1168	Spider & Brg As	377-7435
6H-3957	Bearing-Ball	311-9358
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444

Sales Model D3C (Cont'd.)

9TS		
Original Part Number	Part Name	Classic Part Number
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7T-9989	Housing As-Cl	380-1509
8E-4024	Carrier-Planet	398-8333
8E-4026	Pin As	394-0902

9TS		
Original Part Number	Part Name	Classic Part Number
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-3443	Bearing	396-7281
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531

9TS		
Original Part Number	Part Name	Classic Part Number
9W-3120	Pin As	393-3641
9Y-9431	Precleaner As	361-1718
107-7473	Muffler As.	385-7223
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
126-0734	Muffler As	397-5052
133-6597	Pipe-Extension	420-6220
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
154-5676	Gasket Kit	447-0827
169-9527	Cyl Gp-0076-0352	430-5959
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model D3G

BYR		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947

BYR		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
7G-4758	Gear-Planet	288-8723
7M-7219	Bearing-Thrust	384-4816
8T-0072	Cone-Rlr Brg	377-7448

BYR		
Original Part Number	Part Name	Classic Part Number
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258
112-4297	Cylinder As	443-5199
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
164-4413	Mount	419-0876
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
231-1591	Muffler As.	360-9625

CFC		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535

CFC		
Original Part Number	Part Name	Classic Part Number
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786

CFC		
Original Part Number	Part Name	Classic Part Number
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970

Sales Model D3G (Cont'd.)

CFC		
Original Part Number	**Part Name**	**Classic Part Number**
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929

CFC		
Original Part Number	**Part Name**	**Classic Part Number**
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
7G-4758	Gear-Planet	288-8723
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816
8T-0072	Cone-Rlr Brg	377-7448
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258

CFC		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-9431	Precleaner As	361-1718
112-4297	Cylinder As	443-5199
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
164-4413	Mount	419-0876
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
231-1591	Muffler As.	360-9625

CFF		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947

CFF		
Original Part Number	**Part Name**	**Classic Part Number**
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
7G-4758	Gear-Planet	288-8723
7M-7219	Bearing-Thrust	384-4816
8T-0072	Cone-Rlr Brg	377-7448

CFF		
Original Part Number	**Part Name**	**Classic Part Number**
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258
9Y-9431	Precleaner As	361-1718
112-4297	Cylinder As	443-5199
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
164-4413	Mount	419-0876
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
231-1591	Muffler As.	360-9625

CKA		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947

CKA		
Original Part Number	**Part Name**	**Classic Part Number**
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
7G-4758	Gear-Planet	288-8723
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816

CKA		
Original Part Number	**Part Name**	**Classic Part Number**
8T-0072	Cone-Rlr Brg	377-7448
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258
9Y-9431	Precleaner As	361-1718
112-4297	Cylinder As	443-5199
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
164-4413	Mount	419-0876
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
231-1591	Muffler As.	360-9625

Sales Model D3G (Cont'd.)

CLB		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
1T-0210	Bearing-Ball	417-4498
2H-6489	Race-Brg Outer	374-8350
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947

CLB		
Original Part Number	**Part Name**	**Classic Part Number**
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-3474	Pin As	375-9981
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
7G-4758	Gear-Planet	288-8723
7J-6461	Crown	325-6054
7M-7219	Bearing-Thrust	384-4816
8H-9789	Bearing-Ball	374-8342

CLB		
Original Part Number	**Part Name**	**Classic Part Number**
8T-0072	Cone-Rlr Brg	377-7448
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258
9Y-9431	Precleaner As	361-1718
112-4297	Cylinder As	443-5199
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
164-4413	Mount	419-0876
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
231-1591	Muffler As.	360-9625
289-2935	Seal As-Buffer	472-8028
308-1845	Seal-Wiper	472-8032

CXT		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955
2H-6489	Race-Brg Outer	374-8350
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155

CXT		
Original Part Number	**Part Name**	**Classic Part Number**
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3J-6575	Trunnion	297-7265
3Y-2768	Ring	439-4544
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-3474	Pin As	375-9981
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
7G-4758	Gear-Planet	288-8723
7J-6461	Crown	325-6054
7K-9642	Bearing-Sleeve	360-2340

CXT		
Original Part Number	**Part Name**	**Classic Part Number**
7M-7219	Bearing-Thrust	384-4816
8T-0072	Cone-Rlr Brg	377-7448
8Y-2735	Spring	383-2134
9J-2759	Trunnion	394-0216
9J-9812	Bearing	434-7258
9W-1677	Bearing	297-7145
112-4297	Cylinder As	443-5199
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
160-6306	Cap-Bearing	325-6038
164-4413	Mount	419-0876
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
231-1591	Muffler As.	360-9625
289-2935	Seal As-Buffer	472-8028
308-1845	Seal-Wiper	472-8032

JMH		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4493	Cone-Spl Tapered	386-4939

JMH		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535

Sales Model D3G (Cont'd.)

JMH		
Original Part Number	Part Name	Classic Part Number
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208

JMH		
Original Part Number	Part Name	Classic Part Number
3Y-2768	Ring	439-4544
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
7G-4758	Gear-Planet	288-8723
7M-7219	Bearing-Thrust	384-4816
8T-0072	Cone-Rlr Brg	377-7448

JMH		
Original Part Number	Part Name	Classic Part Number
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258
112-4297	Cylinder As	443-5199
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
164-4413	Mount	419-0876
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
231-1591	Muffler As.	360-9625

ZDN		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947

ZDN		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
7G-4758	Gear-Planet	288-8723
7M-7219	Bearing-Thrust	384-4816
8T-0072	Cone-Rlr Brg	377-7448

ZDN		
Original Part Number	Part Name	Classic Part Number
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258
112-4297	Cylinder As	443-5199
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
164-4413	Mount	419-0876
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
231-1591	Muffler As.	360-9625

Sales Model D3K

FFF		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955
2K-5069	Cup-Roller Brg	374-8346

FFF		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6V-0330	Cup-Rlr Brg	422-6487
7K-9642	Bearing-Sleeve	360-2340
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
8T-0072	Cone-Rlr Brg	377-7448

FFF		
Original Part Number	Part Name	Classic Part Number
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

Sales Model D3K (Cont'd.)

FT3		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
2B-0941	Spacer	418-1955
2K-5069	Cup-Roller Brg	374-8346
6V-0330	Cup-Rlr Brg	422-6487

FT3		
Original Part Number	Part Name	Classic Part Number
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
8T-0072	Cone-Rlr Brg	377-7448
9J-9812	Bearing	434-7258

FT3		
Original Part Number	Part Name	Classic Part Number
150-0351	Spacer	396-7291
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

JPJ		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955

JPJ		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
4T-8054	Seal As	472-8010
6V-0330	Cup-Rlr Brg	422-6487
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
8T-0072	Cone-Rlr Brg	377-7448

JPJ		
Original Part Number	Part Name	Classic Part Number
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

JTD		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955

JTD		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6V-0330	Cup-Rlr Brg	422-6487
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571

JTD		
Original Part Number	Part Name	Classic Part Number
8T-0072	Cone-Rlr Brg	377-7448
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

KF2		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955
2K-5069	Cup-Roller Brg	374-8346
4T-8054	Seal As	472-8010
6V-0330	Cup-Rlr Brg	422-6487
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571

KF2		
Original Part Number	Part Name	Classic Part Number
8T-0072	Cone-Rlr Brg	377-7448
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955

KF2		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
4T-8054	Seal As	472-8010
6V-0330	Cup-Rlr Brg	422-6487
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
8T-0072	Cone-Rlr Brg	377-7448
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

LLL		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759

Sales Model D3K (Cont'd.)

LLL		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955
2K-0227	Bearing-Sleeve	384-4780

LLL		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5069	Cup-Roller Brg	374-8346
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6S-3474	Pin As	375-9981
6V-0330	Cup-Rlr Brg	422-6487
7K-9642	Bearing-Sleeve	360-2340
7Y-0223	Shaft-Planet	301-4625

LLL		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0225	Shaft-Planet	301-4571
8T-0072	Cone-Rlr Brg	377-7448
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

LT3		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
2B-0941	Spacer	418-1955
2K-5069	Cup-Roller Brg	374-8346
6V-0330	Cup-Rlr Brg	422-6487

LT3		
Original Part Number	**Part Name**	**Classic Part Number**
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
8T-0072	Cone-Rlr Brg	377-7448
9J-9812	Bearing	434-7258

LT3		
Original Part Number	**Part Name**	**Classic Part Number**
150-0351	Spacer	396-7291
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

Sales Model D3K2

GAE		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2K-5069	Cup-Roller Brg	374-8346

GAE		
Original Part Number	**Part Name**	**Classic Part Number**
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6V-0330	Cup-Rlr Brg	422-6487
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
8T-0072	Cone-Rlr Brg	377-7448

GAE		
Original Part Number	**Part Name**	**Classic Part Number**
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

KFF		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2K-5069	Cup-Roller Brg	374-8346

KFF		
Original Part Number	**Part Name**	**Classic Part Number**
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6V-0330	Cup-Rlr Brg	422-6487
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
8T-0072	Cone-Rlr Brg	377-7448

KFF		
Original Part Number	**Part Name**	**Classic Part Number**
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

KLL		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759

Sales Model D3K2 (Cont'd.)

KLL		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2K-5069	Cup-Roller Brg	374-8346
4T-8054	Seal As	472-8010

KLL		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6V-0330	Cup-Rlr Brg	422-6487
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
8T-0072	Cone-Rlr Brg	377-7448
9J-9812	Bearing	434-7258

KLL		
Original Part Number	Part Name	Classic Part Number
150-0351	Spacer	396-7291
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

Sales Model D4

02T		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1B-4102	Bearing-Ball	399-4426
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2H-6936	Disc-Steer Cl Dr	380-7471
2L-5271	Bearing-Ball	371-4305
2M-1086	Plate As-Press	226-8023
2S-4015	Plunger As-Valve	311-9438
3B-3967	Race-Roller Brg	386-4947

02T		
Original Part Number	Part Name	Classic Part Number
3B-6217	Muffler As	247-2671
3H-1996	Bearing-Ball	380-1498
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6W-0240	Bearing-Brace	297-7143
7H-6967	Bearing-Ball	422-6489

02T		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8H-1174	Drum-Ster Cl Dr	226-6101
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9W-1677	Bearing	297-7145
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
160-6306	Cap-Bearing	325-6038
231-1937	Kit-Strg Cl-Cla	226-6101

04G		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1B-4102	Bearing-Ball	399-4426
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488

04G		
Original Part Number	Part Name	Classic Part Number
2H-6936	Disc-Steer Cl Dr	380-7471
2L-5271	Bearing-Ball	371-4305
2M-1086	Plate As-Press	226-8023
2S-4015	Plunger As-Valve	311-9438
3B-3967	Race-Roller Brg	386-4947
3B-6217	Muffler As	247-2671
3H-1996	Bearing-Ball	380-1498
3L-1425	Bearing-Ball	311-9356

04G		
Original Part Number	Part Name	Classic Part Number
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358

Sales Model D4 (Cont'd.)

04G		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
6W-0240	Bearing-Brace	297-7143
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8H-1174	Drum-Ster Cl Dr	226-6101

04G		
Original Part Number	Part Name	Classic Part Number
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9W-1677	Bearing	297-7145
108-5603	Screw-Adj Arm	379-0166

04G		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
160-6306	Cap-Bearing	325-6038
231-1937	Kit-Strg Cl-Cla	226-6101

05T		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1B-4102	Bearing-Ball	399-4426
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2H-6936	Disc-Steer Cl Dr	380-7471
2L-5271	Bearing-Ball	371-4305
2M-1086	Plate As-Press	226-8023
2S-4015	Plunger As-Valve	311-9438
3B-3967	Race-Roller Brg	386-4947

05T		
Original Part Number	Part Name	Classic Part Number
3B-6217	Muffler As	247-2671
3H-1996	Bearing-Ball	380-1498
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6W-0240	Bearing-Brace	297-7143
7H-6967	Bearing-Ball	422-6489

05T		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8H-1174	Drum-Ster Cl Dr	226-6101
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9W-1677	Bearing	297-7145
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
160-6306	Cap-Bearing	325-6038
231-1937	Kit-Strg Cl-Cla	226-6101

06U		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1M-8736	Cup-Roller Brg	423-7759
1M-9177	Plate-Cl Press	226-6112
1S-1888	Bracket-Lamp	297-7147
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
1S-8764	Ring-Fly Clu Adj	226-8014

06U		
Original Part Number	Part Name	Classic Part Number
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260

06U		
Original Part Number	Part Name	Classic Part Number
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2H-5080	Gasket Kt-V Gr	438-0180
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2S-1273	Chamber As	319-3434
2S-4015	Plunger As-Valve	311-9438
2V-7198	Pilot As-Rec Spg	302-2709

Sales Model D4 (Cont'd.)

06U		
Original Part Number	Part Name	Classic Part Number
3B-3967	Race-Roller Brg	386-4947
3B-6218	Muffler As	247-2672
3H-1996	Bearing-Ball	380-1498
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4H-4021	Plate As-Loading	229-8219
4K-0255	Retainer As	226-6102
4M-0410	Gear-Oil Pump Dr	428-6660
5F-8651	Bearing-Ball	420-3223
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-6709	Check As-Ball	380-7542

06U		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6P-0169	Hub-Fly Clutch	297-7204
6V-2202	Bearing-Spl Ball	380-1574
6W-0240	Bearing-Brace	297-7143
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-1154	Bearing-Spl	417-4515
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
8B-5972	Bearing-Ball	314-8503

06U		
Original Part Number	Part Name	Classic Part Number
8H-1174	Drum-Ster Cl Dr	226-6101
8H-4320	Bearing-Ball	419-2301
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8M-6676	Cylinder-Adj	226-4960
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9H-7670	Piston	226-4961
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9S-7534	Pipe-Exh Ext	398-2950
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166
160-6306	Cap-Bearing	325-6038
231-1937	Kit-Strg Cl-Cla	226-6101

07J		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1B-4102	Bearing-Ball	399-4426
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2H-6936	Disc-Steer Cl Dr	380-7471
2L-5271	Bearing-Ball	371-4305
2M-1086	Plate As-Press	226-8023
2S-4015	Plunger As-Valve	311-9438
3B-3967	Race-Roller Brg	386-4947

07J		
Original Part Number	Part Name	Classic Part Number
3B-6217	Muffler As	247-2671
3H-1996	Bearing-Ball	380-1498
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6W-0240	Bearing-Brace	297-7143
7H-6967	Bearing-Ball	422-6489

07J		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8H-1174	Drum-Ster Cl Dr	226-6101
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9W-1677	Bearing	297-7145
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
160-6306	Cap-Bearing	325-6038
231-1937	Kit-Strg Cl-Cla	226-6101

07U		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368

Sales Model D4 (Cont'd.)

07U		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1M-8736	Cup-Roller Brg	423-7759
1M-9177	Plate-Cl Press	226-6112
1S-1888	Bracket-Lamp	297-7147
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
1S-8764	Ring-Fly Clu Adj	226-8014
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2H-5080	Gasket Kt-V Gr	438-0180
2H-6936	Disc-Steer Cl Dr	380-7471

07U		
Original Part Number	**Part Name**	**Classic Part Number**
2M-1086	Plate As-Press	226-8023
2S-1273	Chamber As	319-3434
2S-4015	Plunger As-Valve	311-9438
3B-3967	Race-Roller Brg	386-4947
3B-6218	Muffler As	247-2672
3H-1996	Bearing-Ball	380-1498
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
4H-4021	Plate As-Loading	229-8219
4K-0255	Retainer As	226-6102
4M-0410	Gear-Oil Pump Dr	428-6660
5F-8651	Bearing-Ball	420-3223
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495

07U		
Original Part Number	**Part Name**	**Classic Part Number**
6P-0169	Hub-Fly Clutch	297-7204
6V-2202	Bearing-Spl Ball	380-1574
6W-0240	Bearing-Brace	297-7143
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-1154	Bearing-Spl	417-4515
7M-4603	Body-Fuel Valve	311-9348
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
8B-5972	Bearing-Ball	314-8503
8H-1174	Drum-Ster Cl Dr	226-6101
8H-4320	Bearing-Ball	419-2301
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9S-7534	Pipe-Exh Ext	398-2950
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166
160-6306	Cap-Bearing	325-6038
231-1937	Kit-Strg Cl-Cla	226-6101

Sales Model D4B

1SG		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

1SG		
Original Part Number	**Part Name**	**Classic Part Number**
1P-7115	Mount As	418-1936
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859

1SG		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

Sales Model D4B (Cont'd.)

1SG		
Original Part Number	Part Name	Classic Part Number
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg&	373-5386

1SG		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122

1SG		
Original Part Number	Part Name	Classic Part Number
8E-5284	Bearing	388-0582
8H-8175	Bearing-Sleeve	376-3636
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-3120	Pin As	393-3641
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
140-2382	Gasket Kit	390-5285
150-0351	Spacer	396-7291
154-5676	Gasket Kit	447-0827
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model D4B (Cont'd.)

2XF		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912

2XF		
Original Part Number	Part Name	Classic Part Number
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4J-5241	Retainer	434-1415
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg&	373-5386
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006

2XF		
Original Part Number	Part Name	Classic Part Number
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-8175	Bearing-Sleeve	376-3636
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018

Sales Model D4B (Cont'd.)

2XF		
Original Part Number	Part Name	Classic Part Number
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122

2XF		
Original Part Number	Part Name	Classic Part Number
9S-7949	Cup-Roller Brg	420-6531
9W-3120	Pin As	393-3641
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
140-2382	Gasket Kit	390-5285

2XF		
Original Part Number	Part Name	Classic Part Number
150-0351	Spacer	396-7291
154-5676	Gasket Kit	447-0827
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model D4C

1FW		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
3H-8726	Mount As	385-7208
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4J-5241	Retainer	434-1415
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662

1FW		
Original Part Number	Part Name	Classic Part Number
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5T-8739	Spider Gp-Brg&	373-5386
6H-3957	Bearing-Ball	311-9358
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7G-2480	Gear-Planet	226-6091

1FW		
Original Part Number	Part Name	Classic Part Number
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7T-9989	Housing As-Cl	380-1509
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-3443	Bearing	396-7281
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9Y-9431	Precleaner As	361-1718

Sales Model D4C (Cont'd.)

1FW		
Original Part Number	Part Name	Classic Part Number
107-7473	Muffler As.	385-7223
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
126-0734	Muffler As	397-5052
133-6597	Pipe-Extension	420-6220

1FW		
Original Part Number	Part Name	Classic Part Number
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
154-5676	Gasket Kit	447-0827
169-9527	Cyl Gp-0076-0352	430-5959

1FW		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

1RJ		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678

1RJ		
Original Part Number	Part Name	Classic Part Number
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3Y-2768	Ring	439-4544
4D-4065	Rod End-Spher	374-1824
4J-5241	Retainer	434-1415
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162

1RJ		
Original Part Number	Part Name	Classic Part Number
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5M-9644	Bearing-Outer	384-5929
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg	373-5386
5V-1168	Spider & Brg As	377-7435
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6P-7968	Plate-Clutch	416-2133
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-2689	Coupler	422-3508
6Y-7914	Disc-Friction	390-5264

Sales Model D4C (Cont'd.)

1RJ		
Original Part Number	Part Name	Classic Part Number
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7F-2742	Bearing-Ball	422-6488
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9642	Bearing-Sleeve	360-2340
7M-1154	Bearing-Spl	417-4515
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351

1RJ		
Original Part Number	Part Name	Classic Part Number
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9N-5246	Bearing-Camshaft	384-4772

1RJ		
Original Part Number	Part Name	Classic Part Number
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-1677	Bearing	297-7145
9W-3120	Pin As	393-3641
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
150-0351	Spacer	396-7291
154-5676	Gasket Kit	447-0827
160-6306	Cap-Bearing	325-6038
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

2CJ		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476

2CJ		
Original Part Number	Part Name	Classic Part Number
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

2CJ		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197

Sales Model D4C (Cont'd.)

2CJ		
Original Part Number	Part Name	Classic Part Number
2W-5536	Core As-Radiator	380-7554
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3Y-2768	Ring	439-4544
4D-4065	Rod End-Spher	374-1824
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5M-9644	Bearing-Outer	384-5929
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg&	373-5386
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824

2CJ		
Original Part Number	Part Name	Classic Part Number
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6P-7968	Plate-Clutch	416-2133
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-6896	Rebuild Kit	390-1006
6Y-2689	Coupler	422-3508
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7F-2742	Bearing-Ball	422-6488
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-1154	Bearing-Spl	417-4515
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548

2CJ		
Original Part Number	Part Name	Classic Part Number
7X-2846	Gasket Kit	437-8647
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9J-2759	Trunnion	394-0216
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-3120	Pin As	393-3641
9Y-9431	Precleaner As	361-1718
112-1665	Muffler As.	435-4847
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
150-0351	Spacer	396-7291

Sales Model D4C (Cont'd.)

2CJ		
Original Part Number	Part Name	Classic Part Number
154-5676	Gasket Kit	447-0827

2CJ		
Original Part Number	Part Name	Classic Part Number
174-6836	Gasket Kit - Tof	434-7280

2CJ		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024

39A		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1M-0090	Gasket-Manifold	445-7701
1M-1947	Support As	226-6096
1M-1994	Bearing As-Rlr	399-6066
1M-8736	Cup-Roller Brg	423-7759
1M-9177	Plate-Cl Press	226-6112
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-1888	Bracket-Lamp	297-7147
1S-8764	Ring-Fly Clu Adj	226-8014
1T-0210	Bearing-Ball	417-4498
1W-7074	Kit-Rebuild-Pump	419-4712
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2H-6936	Disc-Steer Cl Dr	380-7471
2L-5271	Bearing-Ball	371-4305
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532

39A		
Original Part Number	Part Name	Classic Part Number
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2S-4015	Plunger As-Valve	311-9438
2V-7198	Pilot As-Rec Spg	302-2709
3B-6218	Muffler As	247-2672
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
4B-7270	Cone-Bearing	399-4439
4H-4021	Plate As-Loading	229-8219
4K-0255	Retainer As	226-6102
4K-4780	Strip As-Wear	299-2063
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6P-0169	Hub-Fly Clutch	297-7204
6V-2202	Bearing-Spl Ball	380-1574
6W-0240	Bearing-Brace	297-7143
7E-5085	Bushing	377-5829
7K-4458	Gear-Final Drive	226-6093
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348

39A		
Original Part Number	Part Name	Classic Part Number
7M-7358	Valve-Inlet	298-2774
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8H-1174	Drum-Ster Cl Dr	226-6101
8H-5352	Bearing-Ball	453-3658
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8M-6676	Cylinder-Adj	226-4960
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9H-2256	Pump Gp-F Prm	311-9443
9H-7670	Piston	226-4961
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-5477	Bearing-Sleeve	374-6517
9S-7534	Pipe-Exh Ext	398-2950
9S-9696	Spider As-Fan	383-3707
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

Sales Model D4C (Cont'd.)

39A		
Original Part Number	**Part Name**	**Classic Part Number**
231-1937	Kit-Strg Cl-Cla	226-6101

39A		
Original Part Number	**Part Name**	**Classic Part Number**
232-3233	Bearing-Main	376-9085

40A		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1M-0090	Gasket-Manifold	445-7701
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-1994	Bearing As-Rlr	399-6066
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1M-9177	Plate-Cl Press	226-6112
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-1888	Bracket-Lamp	297-7147
1S-8764	Ring-Fly Clu Adj	226-8014
1T-0210	Bearing-Ball	417-4498
1U-2668	Cartridge Gp	422-8117
1W-7074	Kit-Rebuild-Pump	419-4712
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2H-6936	Disc-Steer Cl Dr	380-7471

40A		
Original Part Number	**Part Name**	**Classic Part Number**
2L-5271	Bearing-Ball	371-4305
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934
2S-6150	Cover-Pulley	428-8817
2V-7198	Pilot As-Rec Spg	302-2709
3B-6218	Muffler As	247-2672
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3J-9325	Piston	390-0993
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3S-5017	Elbow-Exhaust	369-9498
4B-7270	Cone-Bearing	399-4439
4H-4021	Plate As-Loading	229-8219
4J-2414	Trunnion	296-1370
4K-0255	Retainer As	226-6102
4K-4780	Strip As-Wear	299-2063
4S-5367	Mount As	375-9986
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-2824	Coupling-Exhaust	431-5270
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298

40A		
Original Part Number	**Part Name**	**Classic Part Number**
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6P-0169	Hub-Fly Clutch	297-7204
6V-2202	Bearing-Spl Ball	380-1574
6W-0240	Bearing-Brace	297-7143
7E-5085	Bushing	377-5829
7K-4458	Gear-Final Drive	226-6093
7K-4512	Pinion-Fdr	226-6081
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4358	Manifold-Exhaust	261-0907
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8H-1174	Drum-Ster Cl Dr	226-6101
8H-5352	Bearing-Ball	453-3658
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8M-6676	Cylinder-Adj	226-4960
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

Sales Model D4C (Cont'd.)

40A		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9H-2256	Pump Gp-F Prm	311-9443

40A		
Original Part Number	Part Name	Classic Part Number
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-4955	Pump Gp-F Tfr	242-3443
9M-5477	Bearing-Sleeve	374-6517
9S-7534	Pipe-Exh Ext	398-2950

40A		
Original Part Number	Part Name	Classic Part Number
9S-9696	Spider As-Fan	383-3707
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
160-6306	Cap-Bearing	325-6038
231-1937	Kit-Strg Cl-Cla	226-6101
232-3233	Bearing-Main	376-9085
308-1845	Seal-Wiper	472-8032

4LS		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
2H-6489	Race-Brg Outer	374-8350
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4J-5241	Retainer	434-1415
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662
5J-9348	Bearing As	416-2162
5M-5856	Pipe-Extension	373-1913
5P-5354	Cup-Rlr Bearing	399-4445

4LS		
Original Part Number	Part Name	Classic Part Number
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
7G-4758	Gear-Planet	288-8723
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7M-7219	Bearing-Thrust	384-4816
8C-3111	Rod End-Spher	392-4523
8E-4026	Pin As	394-0902
8J-3443	Bearing	396-7281
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018

4LS		
Original Part Number	Part Name	Classic Part Number
9Y-9431	Precleaner As	361-1718
107-7473	Muffler As.	385-7223
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
126-0734	Muffler As	397-5052
133-6597	Pipe-Extension	420-6220
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
169-9527	Cyl Gp-0076-0352	430-5959
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

6BS		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
2H-6489	Race-Brg Outer	374-8350
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346

6BS		
Original Part Number	Part Name	Classic Part Number
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4J-5241	Retainer	434-1415
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662

6BS		
Original Part Number	Part Name	Classic Part Number
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5M-5856	Pipe-Extension	373-1913
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487

Sales Model D4C (Cont'd.)

6BS		
Original Part Number	Part Name	Classic Part Number
6V-1033	Rod End-Spher	375-5444
7G-4758	Gear-Planet	288-8723
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7M-7219	Bearing-Thrust	384-4816
8C-3111	Rod End-Spher	392-4523
8E-4026	Pin As	394-0902
8J-3443	Bearing	396-7281
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-2735	Spring	383-2134

6BS		
Original Part Number	Part Name	Classic Part Number
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
9Y-9431	Precleaner As	361-1718
107-7473	Muffler As.	385-7223
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
126-0734	Muffler As	397-5052
133-6597	Pipe-Extension	420-6220

6BS		
Original Part Number	Part Name	Classic Part Number
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
169-9527	Cyl Gp-0076-0352	430-5959
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

6FS		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
2H-6489	Race-Brg Outer	374-8350
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662
5J-9348	Bearing As	416-2162

6FS		
Original Part Number	Part Name	Classic Part Number
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-3474	Pin As	375-9981
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
7G-4758	Gear-Planet	288-8723
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7M-7219	Bearing-Thrust	384-4816
8C-3111	Rod End-Spher	392-4523
8E-4026	Pin As	394-0902
8J-3443	Bearing	396-7281
8T-0072	Cone-Rlr Brg	377-7448

6FS		
Original Part Number	Part Name	Classic Part Number
8T-1177	Bearing-Rlr	419-1862
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
9Y-9431	Precleaner As	361-1718
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
150-0351	Spacer	396-7291
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
308-1845	Seal-Wiper	472-8032

6YL		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894

6YL		
Original Part Number	Part Name	Classic Part Number
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904

6YL		
Original Part Number	Part Name	Classic Part Number
3G-4704	Bearing-Sleeve	379-0185
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370

Sales Model D4C (Cont'd.)

6YL		
Original Part Number	Part Name	Classic Part Number
4J-5241	Retainer	434-1415
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5T-8739	Spider Gp-Brg&	373-5386
6E-4892	Cyl Gp-089 478 Y	394-9828
6H-3957	Bearing-Ball	311-9358
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280

6YL		
Original Part Number	Part Name	Classic Part Number
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444
6Y-6832	Bearing-Rlr As	421-8181
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-3443	Bearing	396-7281
8Y-2735	Spring	383-2134

6YL		
Original Part Number	Part Name	Classic Part Number
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-1677	Bearing	297-7145
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-9431	Precleaner As	361-1718
107-7473	Muffler As.	385-7223
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
126-0734	Muffler As	397-5052
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
154-5676	Gasket Kit	447-0827
160-6306	Cap-Bearing	325-6038
169-9527	Cyl Gp-0076-0352	430-5959
174-6836	Gasket Kit - Tof	434-7280
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

7KG		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851

7KG		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799

7KG		
Original Part Number	Part Name	Classic Part Number
1T-1446	Impeller-Conv	377-7413
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558

Sales Model D4C (Cont'd.)

7KG		
Original Part Number	Part Name	Classic Part Number
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4D-4065	Rod End-Spher	374-1824
4J-5241	Retainer	434-1415
4K-7463	Seal-Lip Type	472-8007
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956

7KG		
Original Part Number	Part Name	Classic Part Number
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg&	373-5386
6E-0775	Head	425-9373
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444
6V-6896	Rebuild Kit	390-1006
6Y-6832	Bearing-Rlr As	421-8181
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166

7KG		
Original Part Number	Part Name	Classic Part Number
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2846	Gasket Kit	437-8647
8C-8555	Gasket Kit	434-7278
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108

Sales Model D4C (Cont'd.)

7KG		
Original Part Number	Part Name	Classic Part Number
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-3120	Pin As	393-3641
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-9431	Precleaner As	361-1718
112-4296	Cylinder As	443-5197

7KG		
Original Part Number	Part Name	Classic Part Number
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
150-0351	Spacer	396-7291
154-5676	Gasket Kit	447-0827

7KG		
Original Part Number	Part Name	Classic Part Number
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

7NS		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
2H-6489	Race-Brg Outer	374-8350
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4J-5241	Retainer	434-1415
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662
5J-9348	Bearing As	416-2162
5P-5354	Cup-Rlr Bearing	399-4445

7NS		
Original Part Number	Part Name	Classic Part Number
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
7G-4758	Gear-Planet	288-8723
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816
8C-3111	Rod End-Spher	392-4523
8E-4026	Pin As	394-0902
8J-3443	Bearing	396-7281
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-2735	Spring	383-2134
8Y-6659	Spring-Recoil	422-7893
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018

7NS		
Original Part Number	Part Name	Classic Part Number
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718
107-7473	Muffler As.	385-7223
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
126-0734	Muffler As	397-5052
133-6597	Pipe-Extension	420-6220
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
160-6306	Cap-Bearing	325-6038
169-9527	Cyl Gp-0076-0352	430-5959
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

7SL		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476

7SL		
Original Part Number	Part Name	Classic Part Number
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904

7SL		
Original Part Number	Part Name	Classic Part Number
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4J-0121	Cap-Bearing	360-2344
4N-4539	Sleeve	314-8720

Sales Model D4C (Cont'd.)

7SL		
Original Part Number	Part Name	Classic Part Number
4N-8204	Mount As	374-1449
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5T-8739	Spider Gp-Brg&	373-5386
6H-3957	Bearing-Ball	311-9358
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657

7SL		
Original Part Number	Part Name	Classic Part Number
6V-1033	Rod End-Spher	375-5444
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7T-9989	Housing As-Cl	380-1509
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-3443	Bearing	396-7281
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258

7SL		
Original Part Number	Part Name	Classic Part Number
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-9431	Precleaner As	361-1718
107-7473	Muffler As.	385-7223
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
126-0734	Muffler As	397-5052
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
154-5676	Gasket Kit	447-0827
169-9527	Cyl Gp-0076-0352	430-5959
174-6836	Gasket Kit - Tof	434-7280
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024

7SL		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678

7SL		
Original Part Number	Part Name	Classic Part Number
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4J-0121	Cap-Bearing	360-2344
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641

7SL		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5T-8739	Spider Gp-Brg&	373-5386
6H-3957	Bearing-Ball	311-9358
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479

Sales Model D4C (Cont'd.)

7SL		
Original Part Number	Part Name	Classic Part Number
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-8893	Cone-Roller Brg	374-1846

7SL		
Original Part Number	Part Name	Classic Part Number
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7T-9989	Housing As-Cl	380-1509
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-3443	Bearing	396-7281
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505

7SL		
Original Part Number	Part Name	Classic Part Number
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-9431	Precleaner As	361-1718
107-7473	Muffler As.	385-7223
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
126-0734	Muffler As	397-5052
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
154-5676	Gasket Kit	447-0827
169-9527	Cyl Gp-0076-0352	430-5959
174-6836	Gasket Kit - Tof	434-7280
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024

8CS		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
2H-6489	Race-Brg Outer	374-8350
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4J-5241	Retainer	434-1415
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5M-5856	Pipe-Extension	373-1913

8CS		
Original Part Number	Part Name	Classic Part Number
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
7G-4758	Gear-Planet	288-8723
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7M-7219	Bearing-Thrust	384-4816
8C-3111	Rod End-Spher	392-4523
8E-4026	Pin As	394-0902
8J-3443	Bearing	396-7281
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361

8CS		
Original Part Number	Part Name	Classic Part Number
9M-1328	Bearing-Aligning	325-6018
9Y-9431	Precleaner As	361-1718
107-7473	Muffler As.	385-7223
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
126-0734	Muffler As	397-5052
133-6597	Pipe-Extension	420-6220
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
169-9527	Cyl Gp-0076-0352	430-5959
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model D4C (Cont'd.)

8EL		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4J-2414	Trunnion	296-1370
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913

8EL		
Original Part Number	**Part Name**	**Classic Part Number**
5T-8739	Spider Gp-Brg&	373-5386
5V-1168	Spider & Brg As	377-7435
6K-8088	Bearing-Roller	399-4428
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444
6Y-6832	Bearing-Rlr As	421-8181
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9639	Bearing-Sleeve	314-8643
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816
7T-8174	Gear-Planet	388-0583

8EL		
Original Part Number	**Part Name**	**Classic Part Number**
7T-9989	Housing As-Cl	380-1509
8E-4026	Pin As	394-0902
8E-5284	Bearing	388-0582
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-3443	Bearing	396-7281
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-1677	Bearing	297-7145
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-9431	Precleaner As	361-1718
107-7473	Muffler As.	385-7223
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
126-0734	Muffler As	397-5052
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
150-0351	Spacer	396-7291
160-6306	Cap-Bearing	325-6038
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024

9BG		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-3934	Cup-Roller Brg	420-6535

9BG		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413

9BG		
Original Part Number	**Part Name**	**Classic Part Number**
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558

Sales Model D4C (Cont'd.)

9BG		
Original Part Number	Part Name	Classic Part Number
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2H-6936	Disc-Steer Cl Dr	380-7471
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3Y-2768	Ring	439-4544
4D-4065	Rod End-Spher	374-1824
4J-5241	Retainer	434-1415
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502

9BG		
Original Part Number	Part Name	Classic Part Number
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg&	373-5386
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444
6V-6896	Rebuild Kit	390-1006
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983

9BG		
Original Part Number	Part Name	Classic Part Number
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2846	Gasket Kit	437-8647
8E-4026	Pin As	394-0902
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
9J-2759	Trunnion	394-0216
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-3120	Pin As	393-3641
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645

Sales Model D4C (Cont'd.)

9BG		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-9431	Precleaner As	361-1718
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
119-6772	Valve-Exhaust	384-8699
133-6597	Pipe-Extension	420-6220

9BG		
Original Part Number	**Part Name**	**Classic Part Number**
140-2382	Gasket Kit	390-5285
150-0351	Spacer	396-7291
154-5676	Gasket Kit	447-0827
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024

9BG		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model D4D

07R		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
2D-5658	Bearing-Ball	301-4628
2P-0220	Gasket-Pump	398-2927
2S-7931	Bearing-Sleeve	387-2904
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4M-5858	Bearing-Spl Ball	417-4495

07R		
Original Part Number	**Part Name**	**Classic Part Number**
4W-0452	Seal As -Cshaft	325-6191
5P-8768	Kit-Gasket (Scl)	393-1024
5S-7877	Bearing-Spl Ball	392-4491
6B-3223	Cup-Bearing	399-6065
6V-2237	Gasket Kit	437-3212
6V-2246	Gasket Kit	391-1091
7C-4297	Seal As-Cshaft	325-6192

07R		
Original Part Number	**Part Name**	**Classic Part Number**
7G-2830	Ring-Seal	295-6441
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
8H-8175	Bearing-Sleeve	376-3636
8S-9686	Gasket Kit	393-5215
131-3815	Seal Gp-Basic	325-6193

18J		
Original Part Number	**Part Name**	**Classic Part Number**
1M-1994	Bearing As-Rlr	399-6066
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440

18J		
Original Part Number	**Part Name**	**Classic Part Number**
4B-9374	Bearing-Cup	380-7494
6B-3223	Cup-Bearing	399-6065
7M-1154	Bearing-Spl	417-4515

20J		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1M-0090	Gasket-Manifold	445-7701
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096

20J		
Original Part Number	**Part Name**	**Classic Part Number**
1M-1994	Bearing As-Rlr	399-6066
1M-8736	Cup-Roller Brg	423-7759
1M-9177	Plate-Cl Press	226-6112
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-1888	Bracket-Lamp	297-7147
1S-8764	Ring-Fly Clu Adj	226-8014

20J		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7074	Kit-Rebuild-Pump	419-4712
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259

Sales Model D4D (Cont'd.)

20J		
Original Part Number	Part Name	Classic Part Number
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2H-6936	Disc-Steer Cl Dr	380-7471
2L-5271	Bearing-Ball	371-4305
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2S-4015	Plunger As-Valve	311-9438
2V-7198	Pilot As-Rec Spg	302-2709
3H-8726	Mount As	385-7208
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4H-4021	Plate As-Loading	229-8219
4K-0255	Retainer As	226-6102
4K-1328	Drum-Ster Cl Dr	216-7840
4K-4780	Strip As-Wear	299-2063
4K-4894	Cage-Bearing	453-0968
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-6709	Check As-Ball	380-7542
5P-9514	Bearing-Ball	417-9467

20J		
Original Part Number	Part Name	Classic Part Number
5S-1822	Chamber As	248-5406
5V-1168	Spider & Brg As	377-7435
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6K-4617	Shaft-Sprocket	221-7951
6K-8088	Bearing-Roller	399-4428
6P-0169	Hub-Fly Clutch	297-7204
6V-2202	Bearing-Spl Ball	380-1574
6W-0240	Bearing-Brace	297-7143
6Y-7914	Disc-Friction	390-5264
7E-5085	Bushing	377-5829
7K-4458	Gear-Final Drive	226-6093
7K-4512	Pinion-Fdr	226-6081
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4358	Manifold-Exhaust	261-0907
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7602	Pump Gp-Cl Oil	226-0174
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721

20J		
Original Part Number	Part Name	Classic Part Number
7W-1927	Ring-Retainer	387-2935
8B-5965	Race & Roller As	417-4512
8H-1174	Drum-Ster Cl Dr	226-6101
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8M-6676	Cylinder-Adj	226-4960
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-9686	Gasket Kit	393-5215
9F-7101	Bushing-Collar	299-1988
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-4955	Pump Gp-F Tfr	242-3443
9M-5477	Bearing-Sleeve	374-6517
9S-9696	Spider As-Fan	383-3707
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166
230-7112	Ster Cl Kit-Cla	216-7840
231-1937	Kit-Strg Cl-Cla	226-6101
232-3233	Bearing-Main	376-9085

22C		
Original Part Number	Part Name	Classic Part Number
0R-1635	Hub-Gear	222-1763
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426

22C		
Original Part Number	Part Name	Classic Part Number
1M-0090	Gasket-Manifold	445-7701
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096

22C		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-1888	Bracket-Lamp	297-7147
1T-0020	Wheel-Turbine	297-4862

Sales Model D4D (Cont'd.)

22C		
Original Part Number	Part Name	Classic Part Number
1T-0022	Wheel-Impeller	430-8040
1T-1991	Stator As-Conv	380-1482
1U-2668	Cartridge Gp	422-8117
1W-7074	Kit-Rebuild-Pump	419-4712
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2H-3517	Bearing-Inner	417-4505
2H-6936	Disc-Steer Cl Dr	380-7471
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-4404	Housing As-Cl	226-8027
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709
3B-6218	Muffler As	247-2672
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3P-8393	Plate-Clutch	388-0592
3S-7987	Shaft-Planet	226-6074
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494

22C		
Original Part Number	Part Name	Classic Part Number
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-0255	Retainer As	226-6102
4K-1328	Drum-Ster Cl Dr	216-7840
4K-4780	Strip As-Wear	299-2063
4K-4894	Cage-Bearing	453-0968
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495
4S-8660	Pump Gp-Trans	226-0167
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4T-8054	Seal As	472-8010
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-7877	Bearing-Spl Ball	392-4491
5S-7893	Joint-Drive	380-7387
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6K-4617	Shaft-Sprocket	221-7951
6K-8088	Bearing-Roller	399-4428
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6W-0240	Bearing-Brace	297-7143
6Y-5915	Disc-Friction	384-5936

22C		
Original Part Number	Part Name	Classic Part Number
6Y-7914	Disc-Friction	390-5264
7E-5085	Bushing	377-5829
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7K-4458	Gear-Final Drive	226-6093
7K-4512	Pinion-Fdr	226-6081
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-9146	Gear-Fly Starter	279-4995
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8H-1174	Drum-Ster Cl Dr	226-6101
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-6676	Cylinder-Adj	226-4960
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-7670	Piston	226-4961

Sales Model D4D (Cont'd.)

22C		
Original Part Number	**Part Name**	**Classic Part Number**
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-4955	Pump Gp-F Tfr	242-3443
9M-5477	Bearing-Sleeve	374-6517

22C		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7534	Pipe-Exh Ext	398-2950
9S-9696	Spider As-Fan	383-3707
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

22C		
Original Part Number	**Part Name**	**Classic Part Number**
160-6306	Cap-Bearing	325-6038
230-7112	Ster Cl Kit-Cla	216-7840
231-1937	Kit-Strg Cl-Cla	226-6101
232-3233	Bearing-Main	376-9085
308-1845	Seal-Wiper	472-8032

44H		
Original Part Number	**Part Name**	**Classic Part Number**
1M-1994	Bearing As-Rlr	399-6066
1W-3900	Gasket	472-8006
2P-0220	Gasket-Pump	398-2927
2S-5100	Valve-Ball	386-3049
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440

44H		
Original Part Number	**Part Name**	**Classic Part Number**
4B-9374	Bearing-Cup	380-7494
5K-8591	Bearing-Outer	380-7502
5P-8768	Kit-Gasket (Scl)	393-1024
6B-3223	Cup-Bearing	399-6065
6V-2237	Gasket Kit	437-3212
6V-2246	Gasket Kit	391-1091

44H		
Original Part Number	**Part Name**	**Classic Part Number**
7C-4297	Seal As-Cshaft	325-6192
7M-1154	Bearing-Spl	417-4515
7N-7386	Gasket-Cyl Head	392-4519
7T-2036	Cap As-Fuel	361-1721
131-3815	Seal Gp-Basic	325-6193

47H		
Original Part Number	**Part Name**	**Classic Part Number**
1M-4095	Bearing-Inner	417-9486
1M-7250	Bowl	360-2296
1T-0441	Bearing-Ball	449-4738
1T-0902	Bearing-Sleeve	389-6326
1W-3900	Gasket	472-8006
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-2719	Pipe-Oil Filler	363-7454
2S-6097	Tang	375-9979
2S-7931	Bearing-Sleeve	387-2904
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494

47H		
Original Part Number	**Part Name**	**Classic Part Number**
4M-5858	Bearing-Spl Ball	417-4495
4N-7692	Crankshaft As	269-8764
5M-6126	Bearing	377-7433
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-8768	Kit-Gasket (Scl)	393-1024
5S-7877	Bearing-Spl Ball	392-4491
6B-3223	Cup-Bearing	399-6065
6H-3957	Bearing-Ball	311-9358
6V-2246	Gasket Kit	391-1091
6W-0240	Bearing-Brace	297-7143
7G-2830	Ring-Seal	295-6441
7M-1154	Bearing-Spl	417-4515
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417

47H		
Original Part Number	**Part Name**	**Classic Part Number**
8H-8175	Bearing-Sleeve	376-3636
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
106-7799	Bearing-Ball	396-9947
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
170-0556	Kit-Rebuild-Pump	383-3712
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112

Sales Model D4D (Cont'd.)

49J		
Original Part Number	**Part Name**	**Classic Part Number**
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440

49J		
Original Part Number	**Part Name**	**Classic Part Number**
4B-9374	Bearing-Cup	380-7494
6B-3223	Cup-Bearing	399-6065

58J		
Original Part Number	**Part Name**	**Classic Part Number**
7G-2830	Ring-Seal	295-6441

59J		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
2D-5658	Bearing-Ball	301-4628
2P-0220	Gasket-Pump	398-2927
2S-7931	Bearing-Sleeve	387-2904
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494

59J		
Original Part Number	**Part Name**	**Classic Part Number**
4M-5858	Bearing-Spl Ball	417-4495
4W-0452	Seal As -Cshaft	325-6191
5K-8591	Bearing-Outer	380-7502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-7877	Bearing-Spl Ball	392-4491
6B-3223	Cup-Bearing	399-6065

59J		
Original Part Number	**Part Name**	**Classic Part Number**
6V-2237	Gasket Kit	437-3212
6V-2246	Gasket Kit	391-1091
7G-2830	Ring-Seal	295-6441
7N-7386	Gasket-Cyl Head	392-4519
8H-8175	Bearing-Sleeve	376-3636
131-3815	Seal Gp-Basic	325-6193

60J		
Original Part Number	**Part Name**	**Classic Part Number**
1M-1994	Bearing As-Rlr	399-6066
1W-3900	Gasket	472-8006
2P-0220	Gasket-Pump	398-2927
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440

60J		
Original Part Number	**Part Name**	**Classic Part Number**
4B-9374	Bearing-Cup	380-7494
5P-8768	Kit-Gasket (Scl)	393-1024
6B-3223	Cup-Bearing	399-6065
6V-2237	Gasket Kit	437-3212
6V-2246	Gasket Kit	391-1091

60J		
Original Part Number	**Part Name**	**Classic Part Number**
7C-4297	Seal As-Cshaft	325-6192
7M-1154	Bearing-Spl	417-4515
7N-7386	Gasket-Cyl Head	392-4519
131-3815	Seal Gp-Basic	325-6193

61J		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-1994	Bearing As-Rlr	399-6066
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759

61J		
Original Part Number	**Part Name**	**Classic Part Number**
1M-9177	Plate-Cl Press	226-6112
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-8764	Ring-Fly Clu Adj	226-8014

61J		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-1991	Stator As-Conv	380-1482
1U-2668	Cartridge Gp	422-8117
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

Sales Model D4D (Cont'd.)

61J		
Original Part Number	Part Name	Classic Part Number
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2H-6936	Disc-Steer Cl Dr	380-7471
2K-5804	Rod End-Spher	416-2151
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4404	Housing As-Cl	226-8027
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7678	Gear-Water Pump	325-6088
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356

61J		
Original Part Number	Part Name	Classic Part Number
3P-8393	Plate-Clutch	388-0592
3S-7987	Shaft-Planet	226-6074
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4H-4021	Plate As-Loading	229-8219
4K-0255	Retainer As	226-6102
4K-4894	Cage-Bearing	453-0968
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-8660	Pump Gp-Trans	226-0167
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
5H-5500	Collar-Fly Cl	302-2704
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1601	Pump Gp-Gr 2 Bsc	386-3054
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491

61J		
Original Part Number	Part Name	Classic Part Number
5S-7893	Joint-Drive	380-7387
5V-1168	Spider & Brg As	377-7435
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0169	Hub-Fly Clutch	297-7204
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-2237	Gasket Kit	437-3212
6V-2246	Gasket Kit	391-1091
6W-0240	Bearing-Brace	297-7143
6Y-5915	Disc-Friction	384-5936
6Y-7914	Disc-Friction	390-5264
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7K-4458	Gear-Final Drive	226-6093
7K-4512	Pinion-Fdr	226-6081
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-7386	Gasket-Cyl Head	392-4519

Sales Model D4D (Cont'd.)

61J		
Original Part Number	Part Name	Classic Part Number
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7602	Pump Gp-Cl Oil	226-0174
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8B-5965	Race & Roller As	417-4512
8F-6058	Bearing-Sleeve	416-5494
8H-1174	Drum-Ster Cl Dr	226-6101
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-9661	Gear-Bevel	213-8218
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556

61J		
Original Part Number	Part Name	Classic Part Number
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
8T-1177	Bearing-Rlr	419-1862
9F-7101	Bushing-Collar	299-1988
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517

61J		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9V-4333	Gear-Oil Pump Ip	226-6105
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
231-1937	Kit-Strg Cl-Cla	226-6101
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

Sales Model D4D (Cont'd.)

65J		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1S-1888	Bracket-Lamp	297-7147
1W-3900	Gasket	472-8006
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2F-5721	Bearing-Ball	311-9354
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-2719	Pipe-Oil Filler	363-7454
2S-6097	Tang	375-9979
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440

65J		
Original Part Number	Part Name	Classic Part Number
4B-9374	Bearing-Cup	380-7494
4N-7692	Crankshaft As	269-8764
5P-8768	Kit-Gasket (Scl)	393-1024
6B-3223	Cup-Bearing	399-6065
6H-3957	Bearing-Ball	311-9358
6V-2246	Gasket Kit	391-1091
6W-0240	Bearing-Brace	297-7143
7C-4297	Seal As-Cshaft	325-6192
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417

65J		
Original Part Number	Part Name	Classic Part Number
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
170-0556	Kit-Rebuild-Pump	383-3712
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112

66J		
Original Part Number	Part Name	Classic Part Number
1M-1994	Bearing As-Rlr	399-6066
1M-7250	Bowl	360-2296
1S-1888	Bracket-Lamp	297-7147
1W-3900	Gasket	472-8006
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2F-5721	Bearing-Ball	311-9354
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-2719	Pipe-Oil Filler	363-7454
2S-6097	Tang	375-9979
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440

66J		
Original Part Number	Part Name	Classic Part Number
4B-9374	Bearing-Cup	380-7494
4N-7692	Crankshaft As	269-8764
5P-8768	Kit-Gasket (Scl)	393-1024
6B-3223	Cup-Bearing	399-6065
6H-3957	Bearing-Ball	311-9358
6V-2246	Gasket Kit	391-1091
7C-4297	Seal As-Cshaft	325-6192
7M-1154	Bearing-Spl	417-4515
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417

66J		
Original Part Number	Part Name	Classic Part Number
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
170-0556	Kit-Rebuild-Pump	383-3712
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112

67A		
Original Part Number	Part Name	Classic Part Number
1W-7074	Kit-Rebuild-Pump	419-4712
2L-5271	Bearing-Ball	371-4305

67A		
Original Part Number	Part Name	Classic Part Number
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440

67A		
Original Part Number	Part Name	Classic Part Number
4B-9374	Bearing-Cup	380-7494
6B-3223	Cup-Bearing	399-6065

Sales Model D4D (Cont'd.)

69K		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2S-7931	Bearing-Sleeve	387-2904

69K		
Original Part Number	Part Name	Classic Part Number
4M-5858	Bearing-Spl Ball	417-4495
5S-7877	Bearing-Spl Ball	392-4491

69K		
Original Part Number	Part Name	Classic Part Number
7G-2830	Ring-Seal	295-6441
8H-8175	Bearing-Sleeve	376-3636

74U		
Original Part Number	Part Name	Classic Part Number
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230

74U		
Original Part Number	Part Name	Classic Part Number
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3L-1425	Bearing-Ball	311-9356
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4M-5858	Bearing-Spl Ball	417-4495
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710

74U		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5K-8591	Bearing-Outer	380-7502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491

Sales Model D4D (Cont'd.)

74U		
Original Part Number	Part Name	Classic Part Number
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7W-0508	Gear-Fp Drive	296-1351

74U		
Original Part Number	Part Name	Classic Part Number
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377

74U		
Original Part Number	Part Name	Classic Part Number
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484

Sales Model D4D (Cont'd.)

74U		
Original Part Number	Part Name	Classic Part Number
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365

74U		
Original Part Number	Part Name	Classic Part Number
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893

74U		
Original Part Number	Part Name	Classic Part Number
250-6555	Kit-Liner-Cla	250-6563
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

78A		
Original Part Number	Part Name	Classic Part Number
0R-1635	Hub-Gear	222-1763
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1M-0090	Gasket-Manifold	445-7701
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-1994	Bearing As-Rlr	399-6066
1M-8736	Cup-Roller Brg	423-7759
1M-9177	Plate-Cl Press	226-6112
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-1888	Bracket-Lamp	297-7147
1S-8764	Ring-Fly Clu Adj	226-8014
1T-0210	Bearing-Ball	417-4498
1W-7074	Kit-Rebuild-Pump	419-4712
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488

78A		
Original Part Number	Part Name	Classic Part Number
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2H-6936	Disc-Steer Cl Dr	380-7471
2K-5254	Bearing-Outer	377-7419
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
2V-7198	Pilot As-Rec Spg	302-2709
3B-6218	Muffler As	247-2672
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3G-2806	Cartridge Gp	422-8128
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-3124	Muffler-Trap	247-2673

78A		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
3S-9466	Bearing-Sleeve	314-8509
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4H-4021	Plate As-Loading	229-8219
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-0255	Retainer As	226-6102
4K-1328	Drum-Ster Cl Dr	216-7840
4K-4780	Strip As-Wear	299-2063
4K-4894	Cage-Bearing	453-0968
4T-8054	Seal As	472-8010
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
5F-8651	Bearing-Ball	420-3223
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5L-7632	Support-Elbow	433-9854
5L-8856	Coupling-Exhaust	311-9379
5M-6709	Check As-Ball	380-7542

Sales Model D4D (Cont'd.)

78A		
Original Part Number	**Part Name**	**Classic Part Number**
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-9080	Pulley-Alt Drive	264-5883
5V-1168	Spider & Brg As	377-7435
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6K-4617	Shaft-Sprocket	221-7951
6K-8088	Bearing-Roller	399-4428
6L-8968	Coupling-Exhaust	311-9381
6P-0169	Hub-Fly Clutch	297-7204
6V-2202	Bearing-Spl Ball	380-1574
6W-0240	Bearing-Brace	297-7143
6Y-7914	Disc-Friction	390-5264
7E-5085	Bushing	377-5829
7K-4458	Gear-Final Drive	226-6093
7K-4512	Pinion-Fdr	226-6081
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7M-1154	Bearing-Spl	417-4515

78A		
Original Part Number	**Part Name**	**Classic Part Number**
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4358	Manifold-Exhaust	261-0907
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7602	Pump Gp-Cl Oil	226-0174
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8B-5965	Race & Roller As	417-4512
8F-6058	Bearing-Sleeve	416-5494
8H-1174	Drum-Ster Cl Dr	226-6101
8H-5352	Bearing-Ball	453-3658
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8K-9661	Gear-Bevel	213-8218
8M-6676	Cylinder-Adj	226-4960
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

78A		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-4955	Pump Gp-F Tfr	242-3443
9M-5477	Bearing-Sleeve	374-6517
9M-8119	Retainer-Inlet	226-8022
9S-7534	Pipe-Exh Ext	398-2950
9S-9696	Spider As-Fan	383-3707
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166
160-6306	Cap-Bearing	325-6038
230-7112	Ster Cl Kit-Cla	216-7840
231-1937	Kit-Strg Cl-Cla	226-6101
232-3233	Bearing-Main	376-9085
308-1845	Seal-Wiper	472-8032

82J		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-4493	Cone-Spl Tapered	386-4939
1H-8382	Gear-Oil Pump Dr	226-6103
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096

82J		
Original Part Number	**Part Name**	**Classic Part Number**
1M-1994	Bearing As-Rlr	399-6066
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1M-9177	Plate-Cl Press	226-6112
1N-3574	Block Gp-Cyl	460-8298
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913

82J		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572

Sales Model D4D (Cont'd.)

82J		
Original Part Number	Part Name	Classic Part Number
1S-8764	Ring-Fly Clu Adj	226-8014
1T-0210	Bearing-Ball	417-4498
1U-2668	Cartridge Gp	422-8117
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2B-8824	Drum	216-7817
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2H-6489	Race-Brg Outer	374-8350
2H-6936	Disc-Steer Cl Dr	380-7471
2K-6413	Pin	360-2270
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872

82J		
Original Part Number	Part Name	Classic Part Number
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-6097	Tang	375-9979
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7678	Gear-Water Pump	325-6088
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3G-2806	Cartridge Gp	422-8128
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3S-3875	Screen-Suction	435-4849
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4H-4021	Plate As-Loading	229-8219
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-0255	Retainer As	226-6102
4K-1328	Drum-Ster Cl Dr	216-7840
4K-4780	Strip As-Wear	299-2063
4K-4894	Cage-Bearing	453-0968
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903

82J		
Original Part Number	Part Name	Classic Part Number
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4782	Pulley	325-6176
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4T-8054	Seal As	472-8010
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
5G-3612	Cap Gp-Protn	295-6419
5H-5500	Collar-Fly Cl	302-2704
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1168	Spider & Brg As	377-7435

Sales Model D4D (Cont'd.)

82J		
Original Part Number	Part Name	Classic Part Number
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6K-4617	Shaft-Sprocket	221-7951
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-0169	Hub-Fly Clutch	297-7204
6V-2202	Bearing-Spl Ball	380-1574
6V-2237	Gasket Kit	437-3212
6V-2246	Gasket Kit	391-1091
6W-0240	Bearing-Brace	297-7143
6Y-7914	Disc-Friction	390-5264
6Y-7935	Disc-Friction	383-2121
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7K-4458	Gear-Final Drive	226-6093
7K-4512	Pinion-Fdr	226-6081
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-1152	Pulley-Fan	333-4951

82J		
Original Part Number	Part Name	Classic Part Number
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7602	Pump Gp-Cl Oil	226-0174
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8B-5965	Race & Roller As	417-4512
8F-6058	Bearing-Sleeve	416-5494
8H-1174	Drum-Ster Cl Dr	226-6101
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-9661	Gear-Bevel	213-8218
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960

82J		
Original Part Number	Part Name	Classic Part Number
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033

Sales Model D4D (Cont'd.)

82J		
Original Part Number	Part Name	Classic Part Number
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-2759	Trunnion	394-0216
9J-5082	Pump Gp-Vn Bsc-A	422-8142
9J-5083	Pump Gp-Vn Bsc-A	422-8143
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-1997	Bearing-Ball	384-5954
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124

82J		
Original Part Number	Part Name	Classic Part Number
9S-7949	Cup-Roller Brg	420-6531
9S-8597	Spring	399-8561
9S-9696	Spider As-Fan	383-3707
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
169-1750	Seal Gp-Basic	472-8022
170-0556	Kit-Rebuild-Pump	383-3712
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

82J		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7112	Ster Cl Kit-Cla	216-7840
231-1937	Kit-Strg Cl-Cla	226-6101
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

83J		
Original Part Number	Part Name	Classic Part Number
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-4493	Cone-Spl Tapered	386-4939
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-1994	Bearing As-Rlr	399-6066
1M-4095	Bearing-Inner	417-9486
1M-7250	Bowl	360-2296

83J		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

83J		
Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
1T-1991	Stator As-Conv	380-1482
1U-2668	Cartridge Gp	422-8117

Sales Model D4D (Cont'd.)

83J		
Original Part Number	Part Name	Classic Part Number
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-6489	Race-Brg Outer	374-8350
2H-6936	Disc-Steer Cl Dr	380-7471
2K-6413	Pin	360-2270
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4404	Housing As-Cl	226-8027
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-6097	Tang	375-9979
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357

83J		
Original Part Number	Part Name	Classic Part Number
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7678	Gear-Water Pump	325-6088
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3G-2806	Cartridge Gp	422-8128
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3N-6411	Cup-Rlr Bearing	423-7759
3P-8393	Plate-Clutch	388-0592
3S-3875	Screen-Suction	435-4849
3S-7987	Shaft-Planet	226-6074
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-0255	Retainer As	226-6102
4K-1328	Drum-Ster Cl Dr	216-7840
4K-4780	Strip As-Wear	299-2063
4K-4894	Cage-Bearing	453-0968
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915

83J		
Original Part Number	Part Name	Classic Part Number
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4782	Pulley	325-6176
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-8660	Pump Gp-Trans	226-0167
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4T-8054	Seal As	472-8010
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
5F-7958	Shaft-Roller	434-1865
5G-3612	Cap Gp-Protn	295-6419
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5M-2051	Bearing-Caged	380-7467
5M-6126	Bearing	377-7433
5M-6709	Check As-Ball	380-7542
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

Sales Model D4D (Cont'd.)

83J		
Original Part Number	Part Name	Classic Part Number
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5S-7893	Joint-Drive	380-7387
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6K-4617	Shaft-Sprocket	221-7951
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-2237	Gasket Kit	437-3212
6V-2246	Gasket Kit	391-1091
6W-0240	Bearing-Brace	297-7143
6Y-0145	Plate-Locking	419-8801
6Y-5915	Disc-Friction	384-5936
6Y-7914	Disc-Friction	390-5264
6Y-7935	Disc-Friction	383-2121
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7K-4458	Gear-Final Drive	226-6093

83J		
Original Part Number	Part Name	Classic Part Number
7K-4512	Pinion-Fdr	226-6081
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935

83J		
Original Part Number	Part Name	Classic Part Number
7W-5687	Hub-Cshft	314-8684
8F-6058	Bearing-Sleeve	416-5494
8H-1174	Drum-Ster Cl Dr	226-6101
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0111	Mount As	374-1452
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860

Sales Model D4D (Cont'd.)

83J		
Original Part Number	Part Name	Classic Part Number
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-2759	Trunnion	394-0216
9J-5082	Pump Gp-Vn Bsc-A	422-8142
9J-5083	Pump Gp-Vn Bsc-A	422-8143
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
9M-4789	Shaft-Gov Cont	297-7256

83J		
Original Part Number	Part Name	Classic Part Number
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8597	Spring	399-8561
9S-9696	Spider As-Fan	383-3707
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
169-1750	Seal Gp-Basic	472-8022
170-0556	Kit-Rebuild-Pump	383-3712
170-7502	Shaft-Dr Idler	374-7484

83J		
Original Part Number	Part Name	Classic Part Number
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7112	Ster Cl Kit-Cla	216-7840
231-1937	Kit-Strg Cl-Cla	226-6101
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

84J		
Original Part Number	Part Name	Classic Part Number
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103

84J		
Original Part Number	Part Name	Classic Part Number
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-1994	Bearing As-Rlr	399-6066

84J		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1M-9177	Plate-Cl Press	226-6112
1N-3574	Block Gp-Cyl	460-8298

Sales Model D4D (Cont'd.)

84J		
Original Part Number	Part Name	Classic Part Number
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-8764	Ring-Fly Clu Adj	226-8014
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850

84J		
Original Part Number	Part Name	Classic Part Number
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7678	Gear-Water Pump	325-6088
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4H-4021	Plate As-Loading	229-8219
4K-0255	Retainer As	226-6102
4K-1328	Drum-Ster Cl Dr	216-7840
4K-4780	Strip As-Wear	299-2063
4K-4894	Cage-Bearing	453-0968
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710

84J		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
5G-3612	Cap Gp-Protn	295-6419
5H-5500	Collar-Fly Cl	302-2704
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1168	Spider & Brg As	377-7435
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6K-4617	Shaft-Sprocket	221-7951
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-0169	Hub-Fly Clutch	297-7204
6V-2202	Bearing-Spl Ball	380-1574

Sales Model D4D (Cont'd.)

84J		
Original Part Number	Part Name	Classic Part Number
6V-2237	Gasket Kit	437-3212
6V-2246	Gasket Kit	391-1091
6W-0240	Bearing-Brace	297-7143
6Y-7914	Disc-Friction	390-5264
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7K-4458	Gear-Final Drive	226-6093
7K-4512	Pinion-Fdr	226-6081
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656

84J		
Original Part Number	Part Name	Classic Part Number
7S-7070	Head As-Cylinder	325-6107
7S-7602	Pump Gp-Cl Oil	226-0174
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8B-5965	Race & Roller As	417-4512
8F-6058	Bearing-Sleeve	416-5494
8H-1174	Drum-Ster Cl Dr	226-6101
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

84J		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-5083	Pump Gp-Vn Bsc-A	422-8143
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891

Sales Model D4D (Cont'd.)

84J		
Original Part Number	Part Name	Classic Part Number
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353

84J		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
170-0556	Kit-Rebuild-Pump	383-3712
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

84J		
Original Part Number	Part Name	Classic Part Number
230-7112	Ster Cl Kit-Cla	216-7840
231-1937	Kit-Strg Cl-Cla	226-6101
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

85A		
Original Part Number	Part Name	Classic Part Number
1M-1994	Bearing As-Rlr	399-6066
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-3062	Director-Water	418-9572
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357

85A		
Original Part Number	Part Name	Classic Part Number
2W-2621	Valve-Inlet	247-6892
3L-1425	Bearing-Ball	311-9356
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6I-1345	Shaft As-O Pump	374-7475
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574

85A		
Original Part Number	Part Name	Classic Part Number
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935

Sales Model D4D (Cont'd.)

85A		
Original Part Number	**Part Name**	**Classic Part Number**
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585

85A		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9S-2356	Manifold-Exhaust	261-0905
9S-7788	Ring-Piston	461-5124
9Y-1798	Seal-Water	379-0165

85A		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
170-7502	Shaft-Dr Idler	374-7484
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

86A, 88A		
Original Part Number	**Part Name**	**Classic Part Number**
1M-1994	Bearing As-Rlr	399-6066
7M-1154	Bearing-Spl	417-4515

91A		
Original Part Number	**Part Name**	**Classic Part Number**
1M-1994	Bearing As-Rlr	399-6066
1W-7074	Kit-Rebuild-Pump	419-4712

91A		
Original Part Number	**Part Name**	**Classic Part Number**
2L-5271	Bearing-Ball	371-4305
2M-4668	Retainer-Guard	297-4867
7M-1154	Bearing-Spl	417-4515

Sales Model D4D (Cont'd.)

97F		
Original Part Number	Part Name	Classic Part Number
0R-1635	Hub-Gear	222-1763
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-1994	Bearing As-Rlr	399-6066
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1M-9177	Plate-Cl Press	226-6112
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-8764	Ring-Fly Clu Adj	226-8014
1U-2668	Cartridge Gp	422-8117
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817

97F		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2806	Cartridge Gp	422-8128
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
4B-7270	Cone-Bearing	399-4439

97F		
Original Part Number	Part Name	Classic Part Number
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4H-4021	Plate As-Loading	229-8219
4J-2414	Trunnion	296-1370
4K-0255	Retainer As	226-6102
4K-1328	Drum-Ster Cl Dr	216-7840
4K-4780	Strip As-Wear	299-2063
4K-4894	Cage-Bearing	453-0968
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778

Sales Model D4D (Cont'd.)

97F		
Original Part Number	Part Name	Classic Part Number
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5H-5500	Collar-Fly Cl	302-2704
5K-8591	Bearing-Outer	380-7502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5V-1168	Spider & Brg As	377-7435
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6K-4617	Shaft-Sprocket	221-7951
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-0169	Hub-Fly Clutch	297-7204
6W-0240	Bearing-Brace	297-7143
6Y-7914	Disc-Friction	390-5264
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7K-4458	Gear-Final Drive	226-6093

97F		
Original Part Number	Part Name	Classic Part Number
7K-4512	Pinion-Fdr	226-6081
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7602	Pump Gp-Cl Oil	226-0174
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8B-5965	Race & Roller As	417-4512

97F		
Original Part Number	Part Name	Classic Part Number
8F-6058	Bearing-Sleeve	416-5494
8H-1174	Drum-Ster Cl Dr	226-6101
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-9661	Gear-Bevel	213-8218
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585

Sales Model D4D (Cont'd.)

97F		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-2759	Trunnion	394-0216
9J-5082	Pump Gp-Vn Bsc-A	422-8142
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-4789	Shaft-Gov Cont	297-7256

97F		
Original Part Number	**Part Name**	**Classic Part Number**
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

97F		
Original Part Number	**Part Name**	**Classic Part Number**
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7112	Ster Cl Kit-Cla	216-7840
231-1937	Kit-Strg Cl-Cla	226-6101
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model D4E

27X		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-4493	Cone-Spl Tapered	386-4939

27X		
Original Part Number	**Part Name**	**Classic Part Number**
1H-8382	Gear-Oil Pump Dr	226-6103
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096

27X		
Original Part Number	**Part Name**	**Classic Part Number**
1M-1994	Bearing As-Rlr	399-6066
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1M-9177	Plate-Cl Press	226-6112
1N-3574	Block Gp-Cyl	460-8298

Sales Model D4E (Cont'd.)

27X		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-8764	Ring-Fly Clu Adj	226-8014
1T-0210	Bearing-Ball	417-4498
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204

27X		
Original Part Number	Part Name	Classic Part Number
2H-5048	Link	389-6334
2H-6489	Race-Brg Outer	374-8350
2K-4507	Bearing-Sleeve	325-6021
2K-5804	Rod End-Spher	416-2151
2K-6413	Pin	360-2270
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-6097	Tang	375-9979
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3G-2806	Cartridge Gp	422-8128
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346

27X		
Original Part Number	Part Name	Classic Part Number
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3S-3875	Screen-Suction	435-4849
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4H-4021	Plate As-Loading	229-8219
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4K-4780	Strip As-Wear	299-2063
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710

Sales Model D4E (Cont'd.)

27X		
Original Part Number	Part Name	Classic Part Number
4N-8204	Mount As	374-1449
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-8054	Seal As	472-8010
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5H-5500	Collar-Fly Cl	302-2704
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1601	Pump Gp-Gr 2 Bsc	386-3054
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437

27X		
Original Part Number	Part Name	Classic Part Number
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1168	Spider & Brg As	377-7435
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6K-4617	Shaft-Sprocket	221-7951
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-0169	Hub-Fly Clutch	297-7204
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6W-0240	Bearing-Brace	297-7143
6Y-7914	Disc-Friction	390-5264
6Y-7935	Disc-Friction	383-2121
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994

27X		
Original Part Number	Part Name	Classic Part Number
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8B-5965	Race & Roller As	417-4512
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342

Sales Model D4E (Cont'd.)

27X		
Original Part Number	Part Name	Classic Part Number
8K-9661	Gear-Bevel	213-8218
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0111	Mount As	374-1452
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377

27X		
Original Part Number	Part Name	Classic Part Number
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-2759	Trunnion	394-0216
9J-5082	Pump Gp-Vn Bsc-A	422-8142
9J-5083	Pump Gp-Vn Bsc-A	422-8143
9K-8757	Rod End-Special	311-9361
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-1997	Bearing-Ball	384-5954
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124

27X		
Original Part Number	Part Name	Classic Part Number
9S-7949	Cup-Roller Brg	420-6531
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9V-4333	Gear-Oil Pump Ip	226-6105
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0556	Kit-Rebuild-Pump	383-3712
170-0560	Rebuild Kit-Pump	363-7458
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698

Sales Model D4E (Cont'd.)

27X		
Original Part Number	Part Name	Classic Part Number
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

27X		
Original Part Number	Part Name	Classic Part Number
232-3233	Bearing-Main	376-9085
234-7996	Kit-Gasket-Sch	437-8665
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438

27X		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

28X		
Original Part Number	Part Name	Classic Part Number
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-4493	Cone-Spl Tapered	386-4939
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0210	Bearing-Ball	417-4498
1T-1991	Stator As-Conv	380-1482
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

28X		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-6489	Race-Brg Outer	374-8350
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

28X		
Original Part Number	Part Name	Classic Part Number
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4404	Housing As-Cl	226-8027
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-6097	Tang	375-9979
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3G-2806	Cartridge Gp	422-8128
3H-8726	Mount As	385-7208

Sales Model D4E (Cont'd.)

28X		
Original Part Number	Part Name	Classic Part Number
3J-6559	Cap-Bearing	296-1346
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3N-6411	Cup-Rlr Bearing	423-7759
3P-8393	Plate-Clutch	388-0592
3S-3875	Screen-Suction	435-4849
3S-7987	Shaft-Planet	226-6074
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4K-4780	Strip As-Wear	299-2063
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365

28X		
Original Part Number	Part Name	Classic Part Number
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8204	Mount As	374-1449
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8660	Pump Gp-Trans	226-0167
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4T-8054	Seal As	472-8010
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222

28X		
Original Part Number	Part Name	Classic Part Number
5M-2051	Bearing-Caged	380-7467
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5S-7893	Joint-Drive	380-7387
5S-9080	Pulley-Alt Drive	264-5883
5V-1168	Spider & Brg As	377-7435
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6K-4617	Shaft-Sprocket	221-7951
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-0600	Gasket Kit	437-4583
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6W-0240	Bearing-Brace	297-7143
6Y-5915	Disc-Friction	384-5936
6Y-7914	Disc-Friction	390-5264
6Y-7935	Disc-Friction	383-2121

Sales Model D4E (Cont'd.)

28X		
Original Part Number	Part Name	Classic Part Number
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656

28X		
Original Part Number	Part Name	Classic Part Number
7S-7070	Head As-Cylinder	325-6107
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0111	Mount As	374-1452
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623

28X		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-2759	Trunnion	394-0216
9J-5082	Pump Gp-Vn Bsc-A	422-8142
9K-8757	Rod End-Special	311-9361

Sales Model D4E (Cont'd.)

28X		
Original Part Number	Part Name	Classic Part Number
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-1997	Bearing-Ball	384-5954
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193

28X		
Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0556	Kit-Rebuild-Pump	383-3712
170-0560	Rebuild Kit-Pump	363-7458
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365

28X		
Original Part Number	Part Name	Classic Part Number
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
174-6836	Gasket Kit - Tof	434-7280
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-7996	Kit-Gasket-Sch	437-8665
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

29X		
Original Part Number	Part Name	Classic Part Number
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-1994	Bearing As-Rlr	399-6066
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1M-9177	Plate-Cl Press	226-6112

29X		
Original Part Number	Part Name	Classic Part Number
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344

29X		
Original Part Number	Part Name	Classic Part Number
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-8764	Ring-Fly Clu Adj	226-8014
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716

Sales Model D4E (Cont'd.)

29X		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-5804	Rod End-Spher	416-2151
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2S-6097	Tang	375-9979
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357

29X		
Original Part Number	Part Name	Classic Part Number
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3G-2806	Cartridge Gp	422-8128
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4H-4021	Plate As-Loading	229-8219
4K-4780	Strip As-Wear	299-2063
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8204	Mount As	374-1449
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

29X		
Original Part Number	Part Name	Classic Part Number
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5H-5500	Collar-Fly Cl	302-2704
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5M-5856	Pipe-Extension	373-1913
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1601	Pump Gp-Gr 2 Bsc	386-3054
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883

Sales Model D4E (Cont'd.)

29X		
Original Part Number	Part Name	Classic Part Number
5V-1168	Spider & Brg As	377-7435
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6K-4617	Shaft-Sprocket	221-7951
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-0169	Hub-Fly Clutch	297-7204
6V-0600	Gasket Kit	437-4583
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6W-0240	Bearing-Brace	297-7143
6Y-7914	Disc-Friction	390-5264
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173

29X		
Original Part Number	Part Name	Classic Part Number
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8B-5965	Race & Roller As	417-4512
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8K-9661	Gear-Bevel	213-8218
8M-6676	Cylinder-Adj	226-4960
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381

29X		
Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-2430	Shaft As	297-7258

Sales Model D4E (Cont'd.)

29X		
Original Part Number	Part Name	Classic Part Number
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9H-7670	Piston	226-4961
9J-5082	Pump Gp-Vn Bsc-A	422-8142
9J-5083	Pump Gp-Vn Bsc-A	422-8143
9K-8757	Rod End-Special	311-9361
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-5477	Bearing-Sleeve	374-6517
9M-8395	Bearing-Sleeve	391-1103
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561

29X		
Original Part Number	Part Name	Classic Part Number
9S-8679	Chamber As	325-6042
9V-4333	Gear-Oil Pump Ip	226-6105
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0556	Kit-Rebuild-Pump	383-3712
170-0560	Rebuild Kit-Pump	363-7458
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

29X		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-7996	Kit-Gasket-Sch	437-8665
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

2CB		
Original Part Number	Part Name	Classic Part Number
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-1994	Bearing As-Rlr	399-6066
1M-7250	Bowl	360-2296

2CB		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1M-9177	Plate-Cl Press	226-6112
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913

2CB		
Original Part Number	Part Name	Classic Part Number
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-8764	Ring-Fly Clu Adj	226-8014
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158

Sales Model D4E (Cont'd.)

2CB		
Original Part Number	Part Name	Classic Part Number
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-5804	Rod End-Spher	416-2151
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709

2CB		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4H-4021	Plate As-Loading	229-8219
4K-4780	Strip As-Wear	299-2063
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984

2CB		
Original Part Number	Part Name	Classic Part Number
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5H-5500	Collar-Fly Cl	302-2704
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1601	Pump Gp-Gr 2 Bsc	386-3054
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1168	Spider & Brg As	377-7435
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358

Sales Model D4E (Cont'd.)

2CB		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6K-4617	Shaft-Sprocket	221-7951
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-0169	Hub-Fly Clutch	297-7204
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-7459	Gasket Kit	391-1095
6W-0240	Bearing-Brace	297-7143
6Y-7914	Disc-Friction	390-5264
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519

2CB		
Original Part Number	Part Name	Classic Part Number
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8B-5965	Race & Roller As	417-4512
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8K-9661	Gear-Bevel	213-8218
8M-6676	Cylinder-Adj	226-4960
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556

2CB		
Original Part Number	Part Name	Classic Part Number
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
8T-1606	Kit-Gskt-Sch	386-3046
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9H-7670	Piston	226-4961
9J-5083	Pump Gp-Vn Bsc-A	422-8143

Sales Model D4E (Cont'd.)

2CB		
Original Part Number	Part Name	Classic Part Number
9K-8757	Rod End-Special	311-9361
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9V-4333	Gear-Oil Pump Ip	226-6105
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311

2CB		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0560	Rebuild Kit-Pump	363-7458
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

2CB		
Original Part Number	Part Name	Classic Part Number
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
250-6556	Kit-Liner-Cla	250-6564
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

2DJ		
Original Part Number	Part Name	Classic Part Number
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-1994	Bearing As-Rlr	399-6066
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1M-9177	Plate-Cl Press	226-6112
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913

2DJ		
Original Part Number	Part Name	Classic Part Number
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-8764	Ring-Fly Clu Adj	226-8014
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659

2DJ		
Original Part Number	Part Name	Classic Part Number
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4507	Bearing-Sleeve	325-6021

Sales Model D4E (Cont'd.)

2DJ		
Original Part Number	Part Name	Classic Part Number
2K-5804	Rod End-Spher	416-2151
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2806	Cartridge Gp	422-8128
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3S-3875	Screen-Suction	435-4849
4B-7270	Cone-Bearing	399-4439
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4H-4021	Plate As-Loading	229-8219
4J-2414	Trunnion	296-1370
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407

2DJ		
Original Part Number	Part Name	Classic Part Number
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4K-4780	Strip As-Wear	299-2063
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-8054	Seal As	472-8010
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5H-5500	Collar-Fly Cl	302-2704
5K-2754	Spring-Recoil	418-1956

2DJ		
Original Part Number	Part Name	Classic Part Number
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1601	Pump Gp-Gr 2 Bsc	386-3054
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1168	Spider & Brg As	377-7435
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6K-4617	Shaft-Sprocket	221-7951
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0169	Hub-Fly Clutch	297-7204
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6W-0240	Bearing-Brace	297-7143
6Y-0145	Plate-Locking	419-8801
6Y-7914	Disc-Friction	390-5264
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7G-7681	Shaft As	307-1530

Sales Model D4E (Cont'd.)

2DJ		
Original Part Number	Part Name	Classic Part Number
7K-8238	Flange	213-8166
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7602	Pump Gp-Cl Oil	226-0174
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8B-5965	Race & Roller As	417-4512
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8K-9661	Gear-Bevel	213-8218
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

2DJ		
Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
8T-1606	Kit-Gskt-Sch	386-3046

2DJ		
Original Part Number	Part Name	Classic Part Number
9F-7101	Bushing-Collar	299-1988
9H-7670	Piston	226-4961
9J-2759	Trunnion	394-0216
9J-5082	Pump Gp-Vn Bsc-A	422-8142
9J-5083	Pump Gp-Vn Bsc-A	422-8143
9K-8757	Rod End-Special	311-9361
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-8119	Retainer-Inlet	226-8022
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-4333	Gear-Oil Pump Ip	226-6105
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
141-7274	Gasket Kit	418-1951
141-7955	Gasket Kit	437-4609
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0570	Rebuild Kit-Pump	380-7577

Sales Model D4E (Cont'd.)

2DJ		
Original Part Number	Part Name	Classic Part Number
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365

2DJ		
Original Part Number	Part Name	Classic Part Number
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356

2DJ		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

31C		
Original Part Number	Part Name	Classic Part Number
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-1991	Stator As-Conv	380-1482
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715

31C		
Original Part Number	Part Name	Classic Part Number
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4404	Housing As-Cl	226-8027

31C		
Original Part Number	Part Name	Classic Part Number
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3G-2806	Cartridge Gp	422-8128
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-8393	Plate-Clutch	388-0592
3S-7987	Shaft-Planet	226-6074
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440

Sales Model D4E (Cont'd.)

31C		
Original Part Number	Part Name	Classic Part Number
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4J-2414	Trunnion	296-1370
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4K-4780	Strip As-Wear	299-2063
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8660	Pump Gp-Trans	226-0167

31C		
Original Part Number	Part Name	Classic Part Number
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4T-8054	Seal As	472-8010
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5K-8591	Bearing-Outer	380-7502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5S-7893	Joint-Drive	380-7387
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6K-4617	Shaft-Sprocket	221-7951
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-1033	Rod End-Spher	375-5444
6V-2246	Gasket Kit	391-1091
6W-0240	Bearing-Brace	297-7143
6Y-5915	Disc-Friction	384-5936
6Y-7914	Disc-Friction	390-5264
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151

31C		
Original Part Number	Part Name	Classic Part Number
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-6676	Cylinder-Adj	226-4960

Sales Model D4E (Cont'd.)

31C		
Original Part Number	Part Name	Classic Part Number
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

31C		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9H-7670	Piston	226-4961
9J-2759	Trunnion	394-0216
9J-5082	Pump Gp-Vn Bsc-A	422-8142
9K-8757	Rod End-Special	311-9361
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038

31C		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
174-6836	Gasket Kit - Tof	434-7280
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-8009	Kit-Gasket-Sch	382-5056
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model D4E (Cont'd.)

34C		
Original Part Number	Part Name	Classic Part Number
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-1994	Bearing As-Rlr	399-6066
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1M-9177	Plate-Cl Press	226-6112
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-8764	Ring-Fly Clu Adj	226-8014
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513

34C		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4507	Bearing-Sleeve	325-6021
2K-5804	Rod End-Spher	416-2151
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2806	Cartridge Gp	422-8128
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-3124	Muffler-Trap	247-2673

34C		
Original Part Number	Part Name	Classic Part Number
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-0114	Elbow-Exhaust	314-8516
4B-7270	Cone-Bearing	399-4439
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4H-4021	Plate As-Loading	229-8219
4J-2414	Trunnion	296-1370
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4K-4780	Strip As-Wear	299-2063
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777

Sales Model D4E (Cont'd.)

34C		
Original Part Number	Part Name	Classic Part Number
4P-9964	Line As-Fuel Inj	298-2778
4T-8054	Seal As	472-8010
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5H-5500	Collar-Fly Cl	302-2704
5K-8591	Bearing-Outer	380-7502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-1601	Pump Gp-Gr 2 Bsc	386-3054
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5V-1168	Spider & Brg As	377-7435
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6K-4617	Shaft-Sprocket	221-7951
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6P-0169	Hub-Fly Clutch	297-7204
6V-1033	Rod End-Spher	375-5444
6V-2246	Gasket Kit	391-1091
6W-0240	Bearing-Brace	297-7143
6Y-7914	Disc-Friction	390-5264

34C		
Original Part Number	Part Name	Classic Part Number
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7K-8238	Flange	213-8166
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8B-5965	Race & Roller As	417-4512
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8K-9661	Gear-Bevel	213-8218
8M-6676	Cylinder-Adj	226-4960
8N-0081	Trunnion	393-5196

34C		
Original Part Number	Part Name	Classic Part Number
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

Sales Model D4E (Cont'd.)

34C		
Original Part Number	Part Name	Classic Part Number
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
9F-7101	Bushing-Collar	299-1988
9H-7670	Piston	226-4961
9J-2759	Trunnion	394-0216
9J-5082	Pump Gp-Vn Bsc-A	422-8142
9K-8757	Rod End-Special	311-9361
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124

34C		
Original Part Number	Part Name	Classic Part Number
9S-8679	Chamber As	325-6042
9V-4333	Gear-Oil Pump Ip	226-6105
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

34C		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-8009	Kit-Gasket-Sch	382-5056
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

50X		
Original Part Number	Part Name	Classic Part Number
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-1994	Bearing As-Rlr	399-6066
1M-7250	Bowl	360-2296

50X		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1M-9177	Plate-Cl Press	226-6112
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770

50X		
Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-8764	Ring-Fly Clu Adj	226-8014
1W-1219	Trunnion As	314-8724
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716

Sales Model D4E (Cont'd.)

50X		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4502	Bearing-Sleeve	299-1986
2K-5804	Rod End-Spher	416-2151
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-6097	Tang	375-9979
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356

50X		
Original Part Number	Part Name	Classic Part Number
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3G-2806	Cartridge Gp	422-8128
3G-2834	Cartridge Gp-Rr	426-0025
3G-4704	Bearing-Sleeve	379-0185
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4H-4021	Plate As-Loading	229-8219
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008

50X		
Original Part Number	Part Name	Classic Part Number
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4T-8054	Seal As	472-8010
4V-0381	Bearing-Sleeve	299-1963
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
5H-5500	Collar-Fly Cl	302-2704
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1601	Pump Gp-Gr 2 Bsc	386-3054
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1168	Spider & Brg As	377-7435
5V-5661	Bearing-Sleeve	299-1965
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6E-4892	Cyl Gp-089 478 Y	394-9828
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195

Sales Model D4E (Cont'd.)

50X		
Original Part Number	Part Name	Classic Part Number
6K-4617	Shaft-Sprocket	221-7951
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0169	Hub-Fly Clutch	297-7204
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6V-2246	Gasket Kit	391-1091
6W-0240	Bearing-Brace	297-7143
6Y-7914	Disc-Friction	390-5264
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7J-9842	Bearing-Sleeve	299-1968
7K-0085	Bearing-Sleeve	393-3646
7K-0087	Bearing-Sleeve	374-6514
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9642	Bearing-Sleeve	360-2340
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496

50X		
Original Part Number	Part Name	Classic Part Number
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8B-5965	Race & Roller As	417-4512
8F-6058	Bearing-Sleeve	416-5494
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8K-9661	Gear-Bevel	213-8218
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623

50X		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
9F-7101	Bushing-Collar	299-1988
9H-7670	Piston	226-4961
9J-2759	Trunnion	394-0216
9J-5082	Pump Gp-Vn Bsc-A	422-8142
9K-8757	Rod End-Special	311-9361
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905

Sales Model D4E (Cont'd.)

50X		
Original Part Number	Part Name	Classic Part Number
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-4333	Gear-Oil Pump Ip	226-6105
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125

50X		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0556	Kit-Rebuild-Pump	383-3712
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365

50X		
Original Part Number	Part Name	Classic Part Number
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
234-7996	Kit-Gasket-Sch	437-8665
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

51X		
Original Part Number	Part Name	Classic Part Number
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147

51X		
Original Part Number	Part Name	Classic Part Number
1S-3062	Director-Water	418-9572
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-1991	Stator As-Conv	380-1482
1W-1219	Trunnion As	314-8724
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354

51X		
Original Part Number	Part Name	Classic Part Number
2H-3517	Bearing-Inner	417-4505
2K-4502	Bearing-Sleeve	299-1986
2K-6413	Pin	360-2270
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4404	Housing As-Cl	226-8027
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197

Sales Model D4E (Cont'd.)

51X		
Original Part Number	Part Name	Classic Part Number
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2S-6097	Tang	375-9979
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3G-2806	Cartridge Gp	422-8128
3G-4704	Bearing-Sleeve	379-0185
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3N-6411	Cup-Rlr Bearing	423-7759
3P-8393	Plate-Clutch	388-0592
3S-7987	Shaft-Planet	226-6074
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407

51X		
Original Part Number	Part Name	Classic Part Number
4K-4780	Strip As-Wear	299-2063
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4S-8660	Pump Gp-Trans	226-0167
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4T-8054	Seal As	472-8010
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5M-2051	Bearing-Caged	380-7467
5M-5856	Pipe-Extension	373-1913
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5S-7893	Joint-Drive	380-7387

51X		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6E-4892	Cyl Gp-089 478 Y	394-9828
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6K-4617	Shaft-Sprocket	221-7951
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6V-2246	Gasket Kit	391-1091
6W-0240	Bearing-Brace	297-7143
6Y-5915	Disc-Friction	384-5936
6Y-7914	Disc-Friction	390-5264
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7J-6461	Crown	325-6054
7J-9842	Bearing-Sleeve	299-1968
7J-9884	Bearing-Sleeve	325-6016
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9642	Bearing-Sleeve	360-2340

Sales Model D4E (Cont'd.)

51X		
Original Part Number	Part Name	Classic Part Number
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8F-6058	Bearing-Sleeve	416-5494
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037

51X		
Original Part Number	Part Name	Classic Part Number
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9G-8302	Guide	226-4853

51X		
Original Part Number	Part Name	Classic Part Number
9H-7670	Piston	226-4961
9J-2759	Trunnion	394-0216
9J-5082	Pump Gp-Vn Bsc-A	422-8142
9K-8757	Rod End-Special	311-9361
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0556	Kit-Rebuild-Pump	383-3712
170-7502	Shaft-Dr Idler	374-7484

Sales Model D4E (Cont'd.)

51X		
Original Part Number	**Part Name**	**Classic Part Number**
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365

51X		
Original Part Number	**Part Name**	**Classic Part Number**
172-7771	Pump Gp-Water -B	419-4646
174-6836	Gasket Kit - Tof	434-7280
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
234-7996	Kit-Gasket-Sch	437-8665
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4351

51X		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

52X		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-1994	Bearing As-Rlr	399-6066
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1M-9177	Plate-Cl Press	226-6112
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-6422	Pilot As-Spring	226-4849
1S-8764	Ring-Fly Clu Adj	226-8014
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040

52X		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1991	Stator As-Conv	380-1482
1W-1219	Trunnion As	314-8724
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4502	Bearing-Sleeve	299-1986
2K-5804	Rod End-Spher	416-2151
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867

52X		
Original Part Number	**Part Name**	**Classic Part Number**
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4404	Housing As-Cl	226-8027
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2S-6097	Tang	375-9979
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983

Sales Model D4E (Cont'd.)

52X		
Original Part Number	Part Name	Classic Part Number
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3G-2806	Cartridge Gp	422-8128
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3P-8393	Plate-Clutch	388-0592
3S-7987	Shaft-Planet	226-6074
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4H-4021	Plate As-Loading	229-8219
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4S-8660	Pump Gp-Trans	226-0167

52X		
Original Part Number	Part Name	Classic Part Number
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4T-8054	Seal As	472-8010
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
5H-5500	Collar-Fly Cl	302-2704
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5M-5856	Pipe-Extension	373-1913
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1601	Pump Gp-Gr 2 Bsc	386-3054
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5S-7893	Joint-Drive	380-7387
5S-9080	Pulley-Alt Drive	264-5883
5V-1168	Spider & Brg As	377-7435
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422

52X		
Original Part Number	Part Name	Classic Part Number
6N-7174	Shield-Oil	314-8544
6P-0169	Hub-Fly Clutch	297-7204
6P-7704	Carrier-Ring	314-8658
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6V-2246	Gasket Kit	391-1091
6W-0240	Bearing-Brace	297-7143
6Y-5915	Disc-Friction	384-5936
6Y-7914	Disc-Friction	390-5264
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7H-2424	Sleeve-Spring	226-4852
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7J-9682	Bearing-Sleeve	360-2335
7J-9842	Bearing-Sleeve	299-1968
7J-9884	Bearing-Sleeve	325-6016
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9642	Bearing-Sleeve	360-2340
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722

Sales Model D4E (Cont'd.)

52X		
Original Part Number	Part Name	Classic Part Number
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8B-5965	Race & Roller As	417-4512
8F-6058	Bearing-Sleeve	416-5494
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-9661	Gear-Bevel	213-8218
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381

52X		
Original Part Number	Part Name	Classic Part Number
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
9F-7101	Bushing-Collar	299-1988
9H-7670	Piston	226-4961
9J-2007	Piston As	419-4714
9J-5082	Pump Gp-Vn Bsc-A	422-8142
9K-8757	Rod End-Special	311-9361

52X		
Original Part Number	Part Name	Classic Part Number
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9V-4333	Gear-Oil Pump Ip	226-6105
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0556	Kit-Rebuild-Pump	383-3712
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

Sales Model D4E (Cont'd.)

52X		
Original Part Number	**Part Name**	**Classic Part Number**
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259

52X		
Original Part Number	**Part Name**	**Classic Part Number**
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
234-7996	Kit-Gasket-Sch	437-8665
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357

52X		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

68X		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
2P-0220	Gasket-Pump	398-2927
3G-2806	Cartridge Gp	422-8128
4B-7270	Cone-Bearing	399-4439
4B-9374	Bearing-Cup	380-7494
4P-8915	Gasket-Cyl Head	377-5838
5K-8591	Bearing-Outer	380-7502
5P-8768	Kit-Gasket (Scl)	393-1024
6B-3223	Cup-Bearing	399-6065

68X		
Original Part Number	**Part Name**	**Classic Part Number**
6H-3957	Bearing-Ball	311-9358
6V-1033	Rod End-Spher	375-5444
7C-4297	Seal As-Cshaft	325-6192
7N-0165	Core As-O Clr	295-5670
7N-8018	Seal-Water	418-1964
7N-8022	Gasket-Cyl Head	378-3985
9J-5082	Pump Gp-Vn Bsc-A	422-8142
9J-5083	Pump Gp-Vn Bsc-A	422-8143

68X		
Original Part Number	**Part Name**	**Classic Part Number**
9K-8757	Rod End-Special	311-9361
9Y-1798	Seal-Water	379-0165
131-3815	Seal Gp-Basic	325-6193
170-0560	Rebuild Kit-Pump	363-7458
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
234-7996	Kit-Gasket-Sch	437-8665

69X		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
2D-5658	Bearing-Ball	301-4628
2P-0220	Gasket-Pump	398-2927
2S-7931	Bearing-Sleeve	387-2904
3G-2806	Cartridge Gp	422-8128
4B-7270	Cone-Bearing	399-4439
4B-9374	Bearing-Cup	380-7494
4M-5858	Bearing-Spl Ball	417-4495
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191
5K-8591	Bearing-Outer	380-7502

69X		
Original Part Number	**Part Name**	**Classic Part Number**
5P-8768	Kit-Gasket (Scl)	393-1024
5S-7877	Bearing-Spl Ball	392-4491
6B-3223	Cup-Bearing	399-6065
6H-3957	Bearing-Ball	311-9358
6V-1033	Rod End-Spher	375-5444
7G-2830	Ring-Seal	295-6441
7N-0165	Core As-O Clr	295-5670
7N-8018	Seal-Water	418-1964
7N-8022	Gasket-Cyl Head	378-3985
8H-8175	Bearing-Sleeve	376-3636
9J-5082	Pump Gp-Vn Bsc-A	422-8142

69X		
Original Part Number	**Part Name**	**Classic Part Number**
9J-5083	Pump Gp-Vn Bsc-A	422-8143
9K-8757	Rod End-Special	311-9361
9Y-1798	Seal-Water	379-0165
131-3815	Seal Gp-Basic	325-6193
170-0560	Rebuild Kit-Pump	363-7458
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
174-6836	Gasket Kit - Tof	434-7280
234-7996	Kit-Gasket-Sch	437-8665

Sales Model D4E (Cont'd.)

70X		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1M-1994	Bearing As-Rlr	399-6066
1W-3900	Gasket	472-8006
2P-0220	Gasket-Pump	398-2927
4B-7270	Cone-Bearing	399-4439
4B-9374	Bearing-Cup	380-7494
4P-8915	Gasket-Cyl Head	377-5838
5K-8591	Bearing-Outer	380-7502

70X		
Original Part Number	**Part Name**	**Classic Part Number**
5P-8768	Kit-Gasket (Scl)	393-1024
6B-3223	Cup-Bearing	399-6065
6V-1033	Rod End-Spher	375-5444
7C-4297	Seal As-Cshaft	325-6192
7M-1154	Bearing-Spl	417-4515
7N-0165	Core As-O Clr	295-5670
7N-8018	Seal-Water	418-1964
7N-8022	Gasket-Cyl Head	378-3985

70X		
Original Part Number	**Part Name**	**Classic Part Number**
9J-5083	Pump Gp-Vn Bsc-A	422-8143
9K-8757	Rod End-Special	311-9361
9Y-1798	Seal-Water	379-0165
131-3815	Seal Gp-Basic	325-6193
234-7996	Kit-Gasket-Sch	437-8665
391-8229	Kit-Gasket-Fs	398-2955

71X		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
2P-0220	Gasket-Pump	398-2927
3G-2806	Cartridge Gp	422-8128
4B-7270	Cone-Bearing	399-4439
4B-9374	Bearing-Cup	380-7494
4P-8915	Gasket-Cyl Head	377-5838
5P-8768	Kit-Gasket (Scl)	393-1024
6B-3223	Cup-Bearing	399-6065

71X		
Original Part Number	**Part Name**	**Classic Part Number**
6H-3957	Bearing-Ball	311-9358
6V-1033	Rod End-Spher	375-5444
7C-4297	Seal As-Cshaft	325-6192
7N-8018	Seal-Water	418-1964
7N-8022	Gasket-Cyl Head	378-3985
7T-2036	Cap As-Fuel	361-1721
9J-5082	Pump Gp-Vn Bsc-A	422-8142
9K-8757	Rod End-Special	311-9361

71X		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-1798	Seal-Water	379-0165
131-3815	Seal Gp-Basic	325-6193
170-0560	Rebuild Kit-Pump	363-7458
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
234-7996	Kit-Gasket-Sch	437-8665

72X		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
2D-5658	Bearing-Ball	301-4628
2P-0220	Gasket-Pump	398-2927
2S-7931	Bearing-Sleeve	387-2904
3G-2806	Cartridge Gp	422-8128
4B-7270	Cone-Bearing	399-4439
4B-9374	Bearing-Cup	380-7494
4M-5858	Bearing-Spl Ball	417-4495
4P-8915	Gasket-Cyl Head	377-5838
4W-0452	Seal As -Cshaft	325-6191

72X		
Original Part Number	**Part Name**	**Classic Part Number**
5P-8768	Kit-Gasket (Scl)	393-1024
5S-7877	Bearing-Spl Ball	392-4491
6B-3223	Cup-Bearing	399-6065
6H-3957	Bearing-Ball	311-9358
6V-1033	Rod End-Spher	375-5444
7G-2830	Ring-Seal	295-6441
7N-8018	Seal-Water	418-1964
7N-8022	Gasket-Cyl Head	378-3985
7T-2036	Cap As-Fuel	361-1721
8H-8175	Bearing-Sleeve	376-3636

76W		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1635	Hub-Gear	222-1763

72X		
Original Part Number	**Part Name**	**Classic Part Number**
9J-5082	Pump Gp-Vn Bsc-A	422-8142
9K-8757	Rod End-Special	311-9361
9Y-1798	Seal-Water	379-0165
131-3815	Seal Gp-Basic	325-6193
170-0560	Rebuild Kit-Pump	363-7458
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
174-6836	Gasket Kit - Tof	434-7280
234-7996	Kit-Gasket-Sch	437-8665

Sales Model D4E (Cont'd.)

76W		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-1994	Bearing As-Rlr	399-6066
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1M-9177	Plate-Cl Press	226-6112
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-8764	Ring-Fly Clu Adj	226-8014
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

76W		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4507	Bearing-Sleeve	325-6021
2K-5804	Rod End-Spher	416-2151
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588

76W		
Original Part Number	Part Name	Classic Part Number
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3G-2806	Cartridge Gp	422-8128
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4H-4021	Plate As-Loading	229-8219
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4K-4780	Strip As-Wear	299-2063
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

Sales Model D4E (Cont'd.)

76W		
Original Part Number	Part Name	Classic Part Number
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-8054	Seal As	472-8010
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5H-5500	Collar-Fly Cl	302-2704
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1601	Pump Gp-Gr 2 Bsc	386-3054
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1168	Spider & Brg As	377-7435

76W		
Original Part Number	Part Name	Classic Part Number
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6K-4617	Shaft-Sprocket	221-7951
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-0169	Hub-Fly Clutch	297-7204
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6W-0240	Bearing-Brace	297-7143
6Y-7914	Disc-Friction	390-5264
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993

76W		
Original Part Number	Part Name	Classic Part Number
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8B-5965	Race & Roller As	417-4512
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8K-9661	Gear-Bevel	213-8218
8M-6676	Cylinder-Adj	226-4960
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858

Sales Model D4E (Cont'd.)

76W		
Original Part Number	Part Name	Classic Part Number
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831

76W		
Original Part Number	Part Name	Classic Part Number
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
8T-1606	Kit-Gskt-Sch	386-3046
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9H-7670	Piston	226-4961
9J-2759	Trunnion	394-0216
9J-5082	Pump Gp-Vn Bsc-A	422-8142
9K-8757	Rod End-Special	311-9361
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9V-4333	Gear-Oil Pump Ip	226-6105
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126

76W		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
247-2670	Muffler-Classic	247-2675
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model D4E (Cont'd.)

77W		
Original Part Number	Part Name	Classic Part Number
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-1991	Stator As-Conv	380-1482
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628

77W		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4404	Housing As-Cl	226-8027
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3G-2806	Cartridge Gp	422-8128
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3P-8393	Plate-Clutch	388-0592

77W		
Original Part Number	Part Name	Classic Part Number
3S-7987	Shaft-Planet	226-6074
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4K-4780	Strip As-Wear	299-2063
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984

Sales Model D4E (Cont'd.)

77W		
Original Part Number	Part Name	Classic Part Number
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8660	Pump Gp-Trans	226-0167
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4T-8054	Seal As	472-8010
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5S-7893	Joint-Drive	380-7387
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918

77W		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6K-4617	Shaft-Sprocket	221-7951
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6W-0240	Bearing-Brace	297-7143
6Y-5915	Disc-Friction	384-5936
6Y-7914	Disc-Friction	390-5264
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686

77W		
Original Part Number	Part Name	Classic Part Number
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-6676	Cylinder-Adj	226-4960
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

Sales Model D4E (Cont'd.)

77W		
Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831

77W		
Original Part Number	Part Name	Classic Part Number
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1606	Kit-Gskt-Sch	386-3046
9B-1320	Valve-Check	377-5832
9H-7670	Piston	226-4961
9J-2759	Trunnion	394-0216
9J-5082	Pump Gp-Vn Bsc-A	422-8142
9K-8757	Rod End-Special	311-9361
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

77W		
Original Part Number	Part Name	Classic Part Number
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
174-6836	Gasket Kit - Tof	434-7280
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model D4E (Cont'd.)

7PB		
Original Part Number	Part Name	Classic Part Number
0R-1635	Hub-Gear	222-1763
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-1994	Bearing As-Rlr	399-6066
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1M-9177	Plate-Cl Press	226-6112
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-8764	Ring-Fly Clu Adj	226-8014
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513

7PB		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-5804	Rod End-Spher	416-2151
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2806	Cartridge Gp	422-8128
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
4B-7270	Cone-Bearing	399-4439
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494

7PB		
Original Part Number	Part Name	Classic Part Number
4H-4021	Plate As-Loading	229-8219
4K-4780	Strip As-Wear	299-2063
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5H-5500	Collar-Fly Cl	302-2704
5K-8591	Bearing-Outer	380-7502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-1601	Pump Gp-Gr 2 Bsc	386-3054
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

Sales Model D4E (Cont'd.)

7PB		
Original Part Number	Part Name	Classic Part Number
5V-1168	Spider & Brg As	377-7435
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8860	Cup-Roller Brg	380-7495
6K-4617	Shaft-Sprocket	221-7951
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0169	Hub-Fly Clutch	297-7204
6V-1033	Rod End-Spher	375-5444
6V-2466	Kit-Gasket-Fs	437-3211
6W-0240	Bearing-Brace	297-7143
6Y-7914	Disc-Friction	390-5264
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7K-8238	Flange	213-8166
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985

7PB		
Original Part Number	Part Name	Classic Part Number
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8B-5965	Race & Roller As	417-4512
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8K-9661	Gear-Bevel	213-8218
8M-6676	Cylinder-Adj	226-4960
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623

7PB		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
9F-7101	Bushing-Collar	299-1988
9H-7670	Piston	226-4961
9J-5082	Pump Gp-Vn Bsc-A	422-8142
9J-5083	Pump Gp-Vn Bsc-A	422-8143
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9S-1768	Pipe-Ext Exhaust	380-7544
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042

Sales Model D4E (Cont'd.)

7PB		
Original Part Number	Part Name	Classic Part Number
9V-4333	Gear-Oil Pump Ip	226-6105
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

7PB		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0560	Rebuild Kit-Pump	363-7458
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365

7PB		
Original Part Number	Part Name	Classic Part Number
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
234-8009	Kit-Gasket-Sch	382-5056
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
250-6556	Kit-Liner-Cla	250-6564
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model D4G

CFN		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947

CFN		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
7G-4758	Gear-Planet	288-8723
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816

CFN		
Original Part Number	Part Name	Classic Part Number
8T-0072	Cone-Rlr Brg	377-7448
8Y-2735	Spring	383-2134
8Y-6659	Spring-Recoil	422-7893
9J-9812	Bearing	434-7258
9Y-9431	Precleaner As	361-1718
112-4297	Cylinder As	443-5199
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
164-4413	Mount	419-0876
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
231-1591	Muffler As.	360-9625

FDC		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535

FDC		
Original Part Number	Part Name	Classic Part Number
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786

FDC		
Original Part Number	Part Name	Classic Part Number
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970

Sales Model D4G (Cont'd.)

FDC		
Original Part Number	Part Name	Classic Part Number
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929

FDC		
Original Part Number	Part Name	Classic Part Number
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
7G-4758	Gear-Planet	288-8723
7M-7219	Bearing-Thrust	384-4816
8T-0072	Cone-Rlr Brg	377-7448
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258
9Y-9431	Precleaner As	361-1718

FDC		
Original Part Number	Part Name	Classic Part Number
112-4297	Cylinder As	443-5199
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
164-4413	Mount	419-0876
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
231-1591	Muffler As.	360-9625

HYD		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
2B-0941	Spacer	418-1955
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544

HYD		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
7G-4758	Gear-Planet	288-8723
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816
8T-0072	Cone-Rlr Brg	377-7448

HYD		
Original Part Number	Part Name	Classic Part Number
8Y-2735	Spring	383-2134
8Y-6659	Spring-Recoil	422-7893
9J-9812	Bearing	434-7258
112-4297	Cylinder As	443-5199
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
164-4413	Mount	419-0876
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
231-1591	Muffler As.	360-9625

TLX		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
2B-0941	Spacer	418-1955
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4T-8054	Seal As	472-8010

TLX		
Original Part Number	Part Name	Classic Part Number
5J-7010	Seal As	472-8011
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-3465	Bearing-Sleeve	382-6903
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
7G-4758	Gear-Planet	288-8723
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816
8T-0072	Cone-Rlr Brg	377-7448

TLX		
Original Part Number	Part Name	Classic Part Number
8Y-2735	Spring	383-2134
9J-9812	Bearing	434-7258
9W-1677	Bearing	297-7145
112-4297	Cylinder As	443-5199
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
160-6306	Cap-Bearing	325-6038
164-4413	Mount	419-0876
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
231-1591	Muffler As.	360-9625

Sales Model D4H

2AC		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-4493	Cone-Spl Tapered	386-4939
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-1722	Gear-Balance	298-2770
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race-Thrust Brg	453-3651
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2K-5069	Cup-Roller Brg	374-8346
2K-6413	Pin	360-2270
2M-8340	Rod End-Yoke	374-4678
2P-1005	Bearing-Sleeve	296-1342
2P-1438	Pipe-Exh Ext	325-6157
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904

2AC		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8900	Pin	325-6140
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-9511	Bearing-Sleeve	385-3782
3K-4290	Rod End	374-1823
3W-2420	Bearing	417-4517
3W-7770	Tube As	385-7227
4D-3882	Cone-Roller Brg	399-6060
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7978	Shaft As-Balance	314-8710
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4Y-4905	Washer-Soft	416-5535
5G-3612	Cap Gp-Protn	295-6419
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883

2AC		
Original Part Number	**Part Name**	**Classic Part Number**
5T-1362	Univ Joint As-5C	325-6011
6D-0217	Bearing-Sleeve	325-6022
6J-7500	Retainer	383-2104
6K-8088	Bearing-Roller	399-4428
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-0145	Plate-Locking	419-8801
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014
6Y-6382	Strip	419-0888
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7935	Disc-Friction	383-2121
7C-7955	Gasket-Cover	382-6899
7D-8225	Seal-Ring	472-8016
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-4758	Gear-Planet	288-8723
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816

Sales Model D4H (Cont'd.)

2AC		
Original Part Number	Part Name	Classic Part Number
7N-0691	Elbow-Water Rglt	378-3983
7N-7166	Race-Brg Thrust	417-4531
7P-7858	Bearing-Sleeve	374-8362
7S-3002	Bearing-Spl Ball	386-4961
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-6221	Pin	325-6155
8G-3102	Piston	325-6162
8G-3733	Pin As	419-7636
8G-3965	Hub-Sprocket	424-4942
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

2AC		
Original Part Number	Part Name	Classic Part Number
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8W-4523	Bearing-Sleeve	385-3798
9J-0123	Trunnion	325-6227
9J-3206	Bearing-Spher	360-2275
9L-6371	Rod-Eye	363-7459
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5279	Bearing-Inner	453-3661

2AC		
Original Part Number	Part Name	Classic Part Number
9U-9198	Strip	388-0641
9W-9930	Mount As	295-6437
9Y-5168	Manifold-Exhaust	374-7483
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
030-1957	Cone-Bearing	420-2502
100-4529	Piston As	424-6368
100-6174	Cyl Gp-0089 0421	425-9368
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
106-7799	Bearing-Ball	396-9947
109-0380	Pin As	396-7276
112-1665	Muffler As.	435-4847
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
126-5984	Ring-Backup	419-4654
160-6306	Cap-Bearing	325-6038
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

3AC		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4493	Cone-Spl Tapered	386-4939
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race-Thrust Brg	453-3651
1W-0311	Bearing-Main	376-9078

3AC		
Original Part Number	Part Name	Classic Part Number
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2K-5069	Cup-Roller Brg	374-8346

3AC		
Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
2M-8340	Rod End-Yoke	374-4678
2P-1005	Bearing-Sleeve	296-1342
2P-1438	Pipe-Exh Ext	325-6157
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3G-0910	Cap-Bearing	325-6037

Sales Model D4H (Cont'd.)

3AC		
Original Part Number	Part Name	Classic Part Number
3G-8900	Pin	325-6140
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-6559	Cap-Bearing	296-1346
3J-9511	Bearing-Sleeve	385-3782
3K-4290	Rod End	374-1823
3W-2420	Bearing	417-4517
3W-7770	Tube As	385-7227
4D-3882	Cone-Roller Brg	399-6060
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4Y-4905	Washer-Soft	416-5535
5G-3612	Cap Gp-Protn	295-6419
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5T-1362	Univ Joint As-5C	325-6011
6D-0217	Bearing-Sleeve	325-6022
6J-7500	Retainer	383-2104
6K-8088	Bearing-Roller	399-4428
6N-6721	Coupling	377-5830

3AC		
Original Part Number	Part Name	Classic Part Number
6P-0593	Bearing-Roller	386-4959
6S-3442	Strip-Wear	386-4929
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-0145	Plate-Locking	419-8801
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014
6Y-6382	Strip	419-0888
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7935	Disc-Friction	383-2121
7C-7955	Gasket-Cover	382-6899
7D-8225	Seal-Ring	472-8016
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-4758	Gear-Planet	288-8723
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-7166	Race-Brg Thrust	417-4531
7P-7858	Bearing-Sleeve	374-8362
7S-3002	Bearing-Spl Ball	386-4961
7T-2036	Cap As-Fuel	361-1721

3AC		
Original Part Number	Part Name	Classic Part Number
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-6221	Pin	325-6155
8G-3102	Piston	325-6162
8G-3733	Pin As	419-7636
8G-3965	Hub-Sprocket	424-4942
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8W-4523	Bearing-Sleeve	385-3798
9J-0123	Trunnion	325-6227
9J-2759	Trunnion	394-0216
9J-3206	Bearing-Spher	360-2275
9L-6371	Rod-Eye	363-7459
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5279	Bearing-Inner	453-3661
9U-9198	Strip	388-0641
9W-1677	Bearing	297-7145
9W-9930	Mount As	295-6437
9Y-5168	Manifold-Exhaust	374-7483

Sales Model D4H (Cont'd.)

3AC		
Original Part Number	Part Name	Classic Part Number
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
030-1957	Cone-Bearing	420-2502
100-4529	Piston As	424-6368
100-6174	Cyl Gp-0089 0421	425-9368
101-5141	Disc-Friction	380-7473

3AC		
Original Part Number	Part Name	Classic Part Number
101-5144	Disc-Friction	380-7516
106-7799	Bearing-Ball	396-9947
109-0380	Pin As	396-7276
112-1665	Muffler As.	435-4847
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
126-5984	Ring-Backup	419-4654

3AC		
Original Part Number	Part Name	Classic Part Number
160-6306	Cap-Bearing	325-6038
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

4NK		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4493	Cone-Spl Tapered	386-4939
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0807	Race-Thrust Brg	453-3651
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659

4NK		
Original Part Number	Part Name	Classic Part Number
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-6413	Pin	360-2270
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-3597	Muffler As	397-5044
2W-5240	Pipe-Pump Outlet	376-9055

4NK		
Original Part Number	Part Name	Classic Part Number
2W-5536	Core As-Radiator	380-7554
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-6185	Pin	295-5694
3G-0910	Cap-Bearing	325-6037
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3W-2420	Bearing	417-4517
3W-7770	Tube As	385-7227
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838

Sales Model D4H (Cont'd.)

4NK		
Original Part Number	Part Name	Classic Part Number
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4Y-4905	Washer-Soft	416-5535
5G-3612	Cap Gp-Protn	295-6419
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-1362	Univ Joint As-5C	325-6011
6B-7469	Spacer	417-4535

4NK		
Original Part Number	Part Name	Classic Part Number
6D-0217	Bearing-Sleeve	325-6022
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6J-7500	Retainer	383-2104
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014
6Y-6382	Strip	419-0888
6Y-7652	Cup-Rlr Brg	399-6067
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8225	Seal-Ring	472-8016
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-9980	Camshaft	377-5851
7G-4758	Gear-Planet	288-8723
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9884	Bearing-Sleeve	325-6016

4NK		
Original Part Number	Part Name	Classic Part Number
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-8371	Line As-Fuel Inj	373-1901
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-7858	Bearing-Sleeve	374-8362
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7V-0638	Spacer	425-3651
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
8D-0983	Mounting	384-3470
8E-6221	Pin	325-6155
8G-3102	Piston	325-6162
8G-3733	Pin As	419-7636
8G-3965	Hub-Sprocket	424-4942
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442

Sales Model D4H (Cont'd.)

4NK		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048

4NK		
Original Part Number	Part Name	Classic Part Number
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8W-4523	Bearing-Sleeve	385-3798
9J-0123	Trunnion	325-6227
9J-2759	Trunnion	394-0216
9J-3206	Bearing-Spher	360-2275
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9N-5529	Body-F Inj Valve	378-3993
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5279	Bearing-Inner	453-3661
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-9198	Strip	388-0641
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
030-1957	Cone-Bearing	420-2502
100-4529	Piston As	424-6368
100-6174	Cyl Gp-0089 0421	425-9368
100-7860	Valve-Inlet	270-4360
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
106-7799	Bearing-Ball	396-9947
109-0380	Pin As	396-7276
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
126-5984	Ring-Backup	419-4654

4NK		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
174-6836	Gasket Kit - Tof	434-7280
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
374-1849	Brg-Rlr-Cla	399-4442

Sales Model D4H (Cont'd.)

8PB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4493	Cone-Spl Tapered	386-4939
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-1722	Gear-Balance	298-2770
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
1T-0576	Bearing-Sleeve	379-0186
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race-Thrust Brg	453-3651
1T-1428	Retainer-Brg	300-2587
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2K-5069	Cup-Roller Brg	374-8346
2K-6413	Pin	360-2270
2P-1005	Bearing-Sleeve	296-1342

8PB		
Original Part Number	Part Name	Classic Part Number
2P-1438	Pipe-Exh Ext	325-6157
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8900	Pin	325-6140
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-9511	Bearing-Sleeve	385-3782
3K-4290	Rod End	374-1823
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3W-2420	Bearing	417-4517
3W-7770	Tube As	385-7227
4D-3882	Cone-Roller Brg	399-6060
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7978	Shaft As-Balance	314-8710
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4Y-4905	Washer-Soft	416-5535
5G-3612	Cap Gp-Protn	295-6419
5P-5354	Cup-Rlr Bearing	399-4445

8PB		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5T-1362	Univ Joint As-5C	325-6011
6D-0217	Bearing-Sleeve	325-6022
6J-7500	Retainer	383-2104
6K-8088	Bearing-Roller	399-4428
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-0145	Plate-Locking	419-8801
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014
6Y-6382	Strip	419-0888
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7C-7955	Gasket-Cover	382-6899
7D-8225	Seal-Ring	472-8016
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-4758	Gear-Planet	288-8723
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925

Sales Model D4H (Cont'd.)

8PB		
Original Part Number	Part Name	Classic Part Number
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-7166	Race-Brg Thrust	417-4531
7P-7858	Bearing-Sleeve	374-8362
7S-3002	Bearing-Spl Ball	386-4961
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-5284	Bearing	388-0582
8E-6221	Pin	325-6155
8G-3102	Piston	325-6162
8G-3733	Pin As	419-7636
8G-3965	Hub-Sprocket	424-4942
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954

8PB		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8W-4523	Bearing-Sleeve	385-3798
9G-5525	Shaft-Planet	419-8662
9J-3206	Bearing-Spher	360-2275
9L-6371	Rod-Eye	363-7459
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9M-1997	Bearing-Ball	384-5954
9M-4370	Bearing-Sleeve	453-6515
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

8PB		
Original Part Number	Part Name	Classic Part Number
9S-5279	Bearing-Inner	453-3661
9U-9198	Strip	388-0641
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-9930	Mount As	295-6437
9Y-5168	Manifold-Exhaust	374-7483
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-4529	Piston As	424-6368
100-6174	Cyl Gp-0089 0421	425-9368
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
112-1665	Muffler As.	435-4847
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
126-5984	Ring-Backup	419-4654
139-9178	Gasket Kit	434-7262
155-8691	Kit-Dt Gasket	396-0650
160-6306	Cap-Bearing	325-6038
174-6836	Gasket Kit - Tof	434-7280
207-8176	Cover-Xmsn	420-3218
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

8PJ		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4493	Cone-Spl Tapered	386-4939
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298

8PJ		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770

8PJ		
Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0406	Wheel-Impeller	384-3854
1T-0576	Bearing-Sleeve	379-0186

Sales Model D4H (Cont'd.)

8PJ		
Original Part Number	Part Name	Classic Part Number
1T-0807	Race-Thrust Brg	453-3651
1T-1428	Retainer-Brg	300-2587
1T-1691	Impeller-Conv	297-4863
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-6413	Pin	360-2270
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912

8PJ		
Original Part Number	Part Name	Classic Part Number
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-3597	Muffler As	397-5044
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-9511	Bearing-Sleeve	385-3782
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3W-2420	Bearing	417-4517
3W-7770	Tube As	385-7227
4D-4065	Rod End-Spher	374-1824
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985

8PJ		
Original Part Number	Part Name	Classic Part Number
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4Y-4905	Washer-Soft	416-5535
5G-3612	Cap Gp-Protn	295-6419
5P-3930	Bearing As-Rlr	419-6022
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-1362	Univ Joint As-5C	325-6011
6B-7469	Spacer	417-4535
6D-0217	Bearing-Sleeve	325-6022

Sales Model D4H (Cont'd.)

8PJ		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6J-7500	Retainer	383-2104
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014
6Y-7652	Cup-Rlr Brg	399-6067
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8225	Seal-Ring	472-8016
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466

8PJ		
Original Part Number	Part Name	Classic Part Number
7G-3707	Piston-Clutch	302-2691
7G-4758	Gear-Planet	288-8723
7G-5444	Carrier-Planet	297-7165
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-8371	Line As-Fuel Inj	373-1901
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-7858	Bearing-Sleeve	374-8362
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7T-2036	Cap As-Fuel	361-1721
7V-0638	Spacer	425-3651
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935

8PJ		
Original Part Number	Part Name	Classic Part Number
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
8D-0983	Mounting	384-3470
8E-6221	Pin	325-6155
8G-3102	Piston	325-6162
8G-3733	Pin As	419-7636
8G-3965	Hub-Sprocket	424-4942
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349

Sales Model D4H (Cont'd.)

8PJ		
Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8W-4523	Bearing-Sleeve	385-3798
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-3206	Bearing-Spher	360-2275
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9N-5529	Body-F Inj Valve	378-3993
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

8PJ		
Original Part Number	Part Name	Classic Part Number
9S-5279	Bearing-Inner	453-3661
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-9198	Strip	388-0641
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
030-1957	Cone-Bearing	420-2502
100-4529	Piston As	424-6368
100-6174	Cyl Gp-0089 0421	425-9368
100-7860	Valve-Inlet	270-4360
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
106-7799	Bearing-Ball	396-9947
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
139-9179	Gasket Kit	390-5289
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

8PJ		
Original Part Number	Part Name	Classic Part Number
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
174-6836	Gasket Kit - Tof	434-7280
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-8176	Cover-Xmsn	420-3218
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
374-1849	Brg-Rlr-Cla	399-4442

9DB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443

9DB		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296

9DB		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076

Sales Model D4H (Cont'd.)

9DB		
Original Part Number	Part Name	Classic Part Number
1N-3822	Bearing-Conn Rod	376-9077
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
1T-0406	Wheel-Impeller	384-3854
1T-0576	Bearing-Sleeve	379-0186
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race-Thrust Brg	453-3651
1T-1428	Retainer-Brg	300-2587
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2K-5069	Cup-Roller Brg	374-8346
2K-6413	Pin	360-2270
2P-1005	Bearing-Sleeve	296-1342
2P-1438	Pipe-Exh Ext	325-6157
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554

9DB		
Original Part Number	Part Name	Classic Part Number
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3G-0910	Cap-Bearing	325-6037
3G-8900	Pin	325-6140
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-6559	Cap-Bearing	296-1346
3J-9511	Bearing-Sleeve	385-3782
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3W-2420	Bearing	417-4517
3W-7770	Tube As	385-7227
4D-3882	Cone-Roller Brg	399-6060
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4Y-4905	Washer-Soft	416-5535
5G-3612	Cap Gp-Protn	295-6419
5P-3930	Bearing As-Rlr	419-6022
5P-5354	Cup-Rlr Bearing	399-4445

9DB		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5T-1362	Univ Joint As-5C	325-6011
6D-0217	Bearing-Sleeve	325-6022
6J-7500	Retainer	383-2104
6K-8088	Bearing-Roller	399-4428
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6S-3442	Strip-Wear	386-4929
6T-5383	Gear-Ring	375-2624
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-0145	Plate-Locking	419-8801
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014
6Y-6382	Strip	419-0888

Sales Model D4H (Cont'd.)

9DB		
Original Part Number	Part Name	Classic Part Number
6Y-6832	Bearing-Rlr As	421-8181
6Y-7929	Disc-Friction	456-0555
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7D-8225	Seal-Ring	472-8016
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-4758	Gear-Planet	288-8723
7G-5444	Carrier-Planet	297-7165
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-1154	Bearing-Spl	417-4515
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-7166	Race-Brg Thrust	417-4531
7P-7858	Bearing-Sleeve	374-8362
7S-3002	Bearing-Spl Ball	386-4961
7S-4534	Bearing-Caged	417-9497
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583

9DB		
Original Part Number	Part Name	Classic Part Number
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-5284	Bearing	388-0582
8E-6221	Pin	325-6155
8G-3102	Piston	325-6162
8G-3733	Pin As	419-7636
8G-3965	Hub-Sprocket	424-4942
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8W-4523	Bearing-Sleeve	385-3798
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-5525	Shaft-Planet	419-8662
9J-0123	Trunnion	325-6227
9J-2759	Trunnion	394-0216
9J-3206	Bearing-Spher	360-2275
9L-6371	Rod-Eye	363-7459
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9M-1997	Bearing-Ball	384-5954
9M-4370	Bearing-Sleeve	453-6515
9N-4460	Housing As-Cl	297-7203
9N-5246	Bearing-Camshaft	384-4772

9DB		
Original Part Number	Part Name	Classic Part Number
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5279	Bearing-Inner	453-3661
9U-9198	Strip	388-0641
9W-0517	Carrier-Planet	281-1686
9W-1677	Bearing	297-7145
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-9930	Mount As	295-6437
9Y-5168	Manifold-Exhaust	374-7483
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-4529	Piston As	424-6368
100-6174	Cyl Gp-0089 0421	425-9368
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
112-1665	Muffler As.	435-4847
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
126-5984	Ring-Backup	419-4654
139-9178	Gasket Kit	434-7262
155-8691	Kit-Dt Gasket	396-0650
160-6306	Cap-Bearing	325-6038
174-6836	Gasket Kit - Tof	434-7280
207-8176	Cover-Xmsn	420-3218
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

9GJ		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849

Sales Model D4H (Cont'd.)

9GJ		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4493	Cone-Spl Tapered	386-4939
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0406	Wheel-Impeller	384-3854
1T-0576	Bearing-Sleeve	379-0186
1T-0807	Race-Thrust Brg	453-3651
1T-1428	Retainer-Brg	300-2587
1T-1691	Impeller-Conv	297-4863
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173

9GJ		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-3597	Muffler As	397-5044
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-6185	Pin	295-5694
3G-0910	Cap-Bearing	325-6037
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-9511	Bearing-Sleeve	385-3782
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356

9GJ		
Original Part Number	Part Name	Classic Part Number
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3W-2420	Bearing	417-4517
3W-7770	Tube As	385-7227
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010

Sales Model D4H (Cont'd.)

9GJ		
Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As -Cshaft	325-6191
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4Y-4905	Washer-Soft	416-5535
5G-3612	Cap Gp-Protn	295-6419
5P-3930	Bearing As-Rlr	419-6022
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-1362	Univ Joint As-5C	325-6011
6B-7469	Spacer	417-4535
6D-0217	Bearing-Sleeve	325-6022
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6J-7500	Retainer	383-2104
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0327	Cup-Rlr Brg	399-4444

9GJ		
Original Part Number	Part Name	Classic Part Number
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014
6Y-6382	Strip	419-0888
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8225	Seal-Ring	472-8016
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4758	Gear-Planet	288-8723
7G-5444	Carrier-Planet	297-7165
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670

9GJ		
Original Part Number	Part Name	Classic Part Number
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-8371	Line As-Fuel Inj	373-1901
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-7858	Bearing-Sleeve	374-8362
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7T-2036	Cap As-Fuel	361-1721
7V-0638	Spacer	425-3651
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
8D-0983	Mounting	384-3470
8E-6221	Pin	325-6155
8G-3102	Piston	325-6162
8G-3733	Pin As	419-7636
8G-3965	Hub-Sprocket	424-4942
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893

Sales Model D4H (Cont'd.)

9GJ		
Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372

9GJ		
Original Part Number	Part Name	Classic Part Number
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8W-4523	Bearing-Sleeve	385-3798
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-0123	Trunnion	325-6227
9J-2759	Trunnion	394-0216
9J-3206	Bearing-Spher	360-2275
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9N-5529	Body-F Inj Valve	378-3993
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5279	Bearing-Inner	453-3661
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-9198	Strip	388-0641
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-4529	Piston As	424-6368
100-6174	Cyl Gp-0089 0421	425-9368
100-7860	Valve-Inlet	270-4360
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
139-9179	Gasket Kit	390-5289
148-7455	Valve - Exhaust	270-4361

9GJ		
Original Part Number	Part Name	Classic Part Number
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
174-6836	Gasket Kit - Tof	434-7280
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-8176	Cover-Xmsn	420-3218
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
374-1849	Brg-Rlr-Cla	399-4442

Sales Model D4K

KM2		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955

KM2		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5069	Cup-Roller Brg	374-8346
4T-8054	Seal As	472-8010
6V-0330	Cup-Rlr Brg	422-6487
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
8T-0072	Cone-Rlr Brg	377-7448

KM2		
Original Part Number	**Part Name**	**Classic Part Number**
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

KR2		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955

KR2		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5069	Cup-Roller Brg	374-8346
4T-8054	Seal As	472-8010
6V-0330	Cup-Rlr Brg	422-6487
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
8T-0072	Cone-Rlr Brg	377-7448

KR2		
Original Part Number	**Part Name**	**Classic Part Number**
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

MMM		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955
2K-5069	Cup-Roller Brg	374-8346

MMM		
Original Part Number	**Part Name**	**Classic Part Number**
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6V-0330	Cup-Rlr Brg	422-6487
7K-9642	Bearing-Sleeve	360-2340
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571

MMM		
Original Part Number	**Part Name**	**Classic Part Number**
8T-0072	Cone-Rlr Brg	377-7448
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

MT3		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955

MT3		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5069	Cup-Roller Brg	374-8346
4T-8054	Seal As	472-8010
6V-0330	Cup-Rlr Brg	422-6487
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
8T-0072	Cone-Rlr Brg	377-7448

MT3		
Original Part Number	**Part Name**	**Classic Part Number**
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

RRR		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535

RRR		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786

RRR		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
2K-5069	Cup-Roller Brg	374-8346

Sales Model D4K (Cont'd.)

RRR		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6V-0330	Cup-Rlr Brg	422-6487
7K-9642	Bearing-Sleeve	360-2340

RRR		
Original Part Number	Part Name	Classic Part Number
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
8T-0072	Cone-Rlr Brg	377-7448
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291

RRR		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

RT3		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955

RT3		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
4T-8054	Seal As	472-8010
6V-0330	Cup-Rlr Brg	422-6487
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
8T-0072	Cone-Rlr Brg	377-7448

RT3		
Original Part Number	Part Name	Classic Part Number
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

Sales Model D4K2

KMM		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2K-5069	Cup-Roller Brg	374-8346

KMM		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6V-0330	Cup-Rlr Brg	422-6487
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
8T-0072	Cone-Rlr Brg	377-7448

KMM		
Original Part Number	Part Name	Classic Part Number
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

KRR		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2K-5069	Cup-Roller Brg	374-8346

KRR		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6V-0330	Cup-Rlr Brg	422-6487
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
8T-0072	Cone-Rlr Brg	377-7448

KRR		
Original Part Number	Part Name	Classic Part Number
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

Sales Model D5

06R		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
2P-0220	Gasket-Pump	398-2927
3L-1425	Bearing-Ball	311-9356
3S-1404	Bearing-Outer	417-4508
4F-2393	Bearing-Ball	380-1499
4S-8538	Bearing-Spl Ball	417-4502
4W-0452	Seal As -Cshaft	325-6191
5M-2051	Bearing-Caged	380-7467

06R		
Original Part Number	**Part Name**	**Classic Part Number**
5P-8768	Kit-Gasket (Scl)	393-1024
6N-7263	Gasket-Cyl Head	380-7386
6V-1339	Gasket Kit	388-0651
6Y-3484	Bearing-Spl Ball	416-2166
7C-4297	Seal As-Cshaft	325-6192
7F-2742	Bearing-Ball	422-6488
7S-3206	Seal-O-Ring	436-2656

06R		
Original Part Number	**Part Name**	**Classic Part Number**
8C-8741	Kit-Gasket-(Rs)	438-0172
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
131-3815	Seal Gp-Basic	325-6193
155-8694	Gasket Kit	451-1503
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

09M		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1B-3924	Cone-Roller Brg	422-6482
1B-4102	Bearing-Ball	399-4426
1M-8736	Cup-Roller Brg	423-7759
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023

09M		
Original Part Number	**Part Name**	**Classic Part Number**
2S-4015	Plunger As-Valve	311-9438
3B-3967	Race-Roller Brg	386-4947
3H-1996	Bearing-Ball	380-1498
4B-1455	Cap As-Filler	361-1719
5H-7071	Director-Water	388-0555
5K-8591	Bearing-Outer	380-7502
6B-6224	Ferrule	419-4738
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358

09M		
Original Part Number	**Part Name**	**Classic Part Number**
6I-8860	Cup-Roller Brg	380-7495
6W-0240	Bearing-Brace	297-7143
7H-6967	Bearing-Ball	422-6489
8B-5972	Bearing-Ball	314-8503
8H-1174	Drum-Ster Cl Dr	226-6101
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166
231-1937	Kit-Strg Cl-Cla	226-6101

12R		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
2P-0220	Gasket-Pump	398-2927
3L-1425	Bearing-Ball	311-9356
4W-0452	Seal As -Cshaft	325-6191
5P-8768	Kit-Gasket (Scl)	393-1024
6N-7263	Gasket-Cyl Head	380-7386

12R		
Original Part Number	**Part Name**	**Classic Part Number**
6V-1339	Gasket Kit	388-0651
7C-4297	Seal As-Cshaft	325-6192
7M-1154	Bearing-Spl	417-4515
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
8C-8741	Kit-Gasket-(Rs)	438-0172
8H-9789	Bearing-Ball	374-8342

12R		
Original Part Number	**Part Name**	**Classic Part Number**
8S-9686	Gasket Kit	393-5215
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

21J		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1642	Hub-Gear	219-2976
1A-3987	Disc-Ster Cl Dr	230-7119

21J		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103

21J		
Original Part Number	**Part Name**	**Classic Part Number**
1H-8937	Drum-Cl Brake	226-7993
1M-0090	Gasket-Manifold	445-7701

Sales Model D5 (Cont'd.)

21J		
Original Part Number	Part Name	Classic Part Number
1M-0176	Flange-Drum	223-4810
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1P-1367	Plunger-Valve	432-8913
1S-1888	Bracket-Lamp	297-7147
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1U-2668	Cartridge Gp	422-8117
1W-7073	Rebuild Kt-Pump	383-3677
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-7576	Shaft-Sprocket	226-6071
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2L-5271	Bearing-Ball	371-4305
2M-2416	Guard-Idler-Lh	226-4933
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-7622	Bolt-Spring	226-4850
2S-1477	Holder As-Cage	226-7985
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934
2S-7931	Bearing-Sleeve	387-2904
3F-1972	Retainer As	226-7988
3H-8726	Mount As	385-7208
3P-1465	Spring-Recoil	384-3479

21J		
Original Part Number	Part Name	Classic Part Number
3P-3623	Lock-Adj Nut	226-7989
3P-5754	Hub-Gear	219-2976
3S-3875	Screen-Suction	435-4849
3S-5017	Elbow-Exhaust	369-9498
3S-7153	Gear-Sliding	227-0024
3S-7504	Gear-Idler	226-6084
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996
4K-4780	Strip As-Wear	299-2063
4S-6189	Pinion-Reverse	226-6077
4S-6559	Tube	325-6234
4S-8005	Pinion-Fdr	226-6076
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161
5F-2256	Cage-Bearing	226-7973
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5L-7632	Support-Elbow	433-9854
5M-6709	Check As-Ball	380-7542
5M-7342	Flange-Shaft	215-1696
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-4557	Bearing	311-9360
5S-8767	Gear-First	226-6085
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6P-0169	Hub-Fly Clutch	297-7204
6V-2202	Bearing-Spl Ball	380-1574
7B-5088	Drum-Steer Cl Dr	223-4813
7E-5085	Bushing	377-5829
7F-9541	Pin As-Drawbar	296-1361
7G-2037	Joint Gp-Univ	226-8017

21J		
Original Part Number	Part Name	Classic Part Number
7G-3815	Pump Gp-Gr 2 Bsc	226-0171
7G-6044	Cage As	216-7857
7H-1318	Coupling-Ster Cl	226-8002
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994
7N-7386	Gasket-Cyl Head	392-4519
7N-9146	Gear-Fly Starter	279-4995
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8B-5965	Race & Roller As	417-4512
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-5587	Rod Gp-Recoil	226-4954
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8M-8068	Bearing-Spl Ball	417-4500
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

Sales Model D5 (Cont'd.)

21J		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8S-1831	Guard As-Sprkt	226-4947
8S-2140	Trunnion-Gear	226-8020
8S-9686	Gasket Kit	393-5215
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891

21J		
Original Part Number	**Part Name**	**Classic Part Number**
9H-7670	Piston	226-4961
9M-4955	Pump Gp-F Tfr	242-3443
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244

21J		
Original Part Number	**Part Name**	**Classic Part Number**
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9S-9696	Spider As-Fan	383-3707
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
169-4200	Gasket	472-8023
228-7325	Ster Cl Kit-Cla	230-7119
232-3233	Bearing-Main	376-9085

37J		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
121-7746	Pre-Cleaner As	360-2311

50J		
Original Part Number	**Part Name**	**Classic Part Number**
5D-7449	Cup-Spl Tapered	416-2161
5P-9176	Bearing	396-4141

50J		
Original Part Number	**Part Name**	**Classic Part Number**
5P-9177	Race-Brg Inner	396-4139
7M-1154	Bearing-Spl	417-4515

50J		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

52H		
Original Part Number	**Part Name**	**Classic Part Number**
3S-1404	Bearing-Outer	417-4508
4F-2393	Bearing-Ball	380-1499
4S-8538	Bearing-Spl Ball	417-4502

52H		
Original Part Number	**Part Name**	**Classic Part Number**
5M-2051	Bearing-Caged	380-7467
6Y-3484	Bearing-Spl Ball	416-2166

52H		
Original Part Number	**Part Name**	**Classic Part Number**
7F-2742	Bearing-Ball	422-6488
8H-8175	Bearing-Sleeve	376-3636

54J		
Original Part Number	**Part Name**	**Classic Part Number**
3S-1404	Bearing-Outer	417-4508
4F-2393	Bearing-Ball	380-1499

54J		
Original Part Number	**Part Name**	**Classic Part Number**
4S-8538	Bearing-Spl Ball	417-4502
5M-2051	Bearing-Caged	380-7467

54J		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-3484	Bearing-Spl Ball	416-2166
7F-2742	Bearing-Ball	422-6488

Sales Model D5 (Cont'd.)

54J		
Original Part Number	Part Name	Classic Part Number
8H-8175	Bearing-Sleeve	376-3636

54J		
Original Part Number	Part Name	Classic Part Number
155-8694	Gasket Kit	451-1503

62J		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
2P-0220	Gasket-Pump	398-2927
3L-1425	Bearing-Ball	311-9356
4W-0452	Seal As -Cshaft	325-6191
5D-7449	Cup-Spl Tapered	416-2161
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141

62J		
Original Part Number	Part Name	Classic Part Number
5P-9177	Race-Brg Inner	396-4139
6N-7263	Gasket-Cyl Head	380-7386
6V-1339	Gasket Kit	388-0651
7C-4297	Seal As-Cshaft	325-6192
7M-1154	Bearing-Spl	417-4515
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656

62J		
Original Part Number	Part Name	Classic Part Number
8C-8741	Kit-Gasket-(Rs)	438-0172
8H-9789	Bearing-Ball	374-8342
8S-9686	Gasket Kit	393-5215
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

63J		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
2P-0220	Gasket-Pump	398-2927
3L-1425	Bearing-Ball	311-9356
3S-1404	Bearing-Outer	417-4508
4F-2393	Bearing-Ball	380-1499
4S-8538	Bearing-Spl Ball	417-4502
4W-0452	Seal As -Cshaft	325-6191
5D-7449	Cup-Spl Tapered	416-2161
5M-2051	Bearing-Caged	380-7467

63J		
Original Part Number	Part Name	Classic Part Number
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
6N-7263	Gasket-Cyl Head	380-7386
6V-1339	Gasket Kit	388-0651
6Y-3484	Bearing-Spl Ball	416-2166
7C-4297	Seal As-Cshaft	325-6192
7F-2742	Bearing-Ball	422-6488

63J		
Original Part Number	Part Name	Classic Part Number
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
8C-8741	Kit-Gasket-(Rs)	438-0172
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8S-9686	Gasket Kit	393-5215
131-3815	Seal Gp-Basic	325-6193
155-8694	Gasket Kit	451-1503
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

67J		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1S-5315	Cap As-Brace Brg	226-4848
1W-3900	Gasket	472-8006
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2F-5721	Bearing-Ball	311-9354

67J		
Original Part Number	Part Name	Classic Part Number
2K-4507	Bearing-Sleeve	325-6021
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3J-6559	Cap-Bearing	296-1346

67J		
Original Part Number	Part Name	Classic Part Number
4F-1252	Pin	295-5704
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063
4N-7693	Crankshaft As	269-8763

Sales Model D5 (Cont'd.)

67J		
Original Part Number	Part Name	Classic Part Number
4S-6559	Tube	325-6234
5D-7449	Cup-Spl Tapered	416-2161
5F-0736	Pin-Pivot	256-4823
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
6H-3957	Bearing-Ball	311-9358
6J-8183	Bracket	394-0195
6N-7263	Gasket-Cyl Head	380-7386
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7M-1154	Bearing-Spl	417-4515

67J		
Original Part Number	Part Name	Classic Part Number
7S-3206	Seal-O-Ring	436-2656
7T-0206	Bearing-Brace	297-7144
8H-9789	Bearing-Ball	374-8342
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
9G-8302	Guide	226-4853
9J-2007	Piston As	419-4714
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244

67J		
Original Part Number	Part Name	Classic Part Number
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
160-6306	Cap-Bearing	325-6038
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112

68J		
Original Part Number	Part Name	Classic Part Number
0R-1642	Hub-Gear	219-2976
1M-0176	Flange-Drum	223-4810
1M-7250	Bowl	360-2296
1W-3900	Gasket	472-8006
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2F-5721	Bearing-Ball	311-9354
2F-7576	Shaft-Sprocket	226-6071
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2S-1477	Holder As-Cage	226-7985
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3J-6559	Cap-Bearing	296-1346

68J		
Original Part Number	Part Name	Classic Part Number
3P-3623	Lock-Adj Nut	226-7989
3P-5754	Hub-Gear	219-2976
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4N-7693	Crankshaft As	269-8763
4S-6559	Tube	325-6234
4S-8005	Pinion-Fdr	226-6076
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
6B-5163	Bearing	417-4514

68J		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6N-7263	Gasket-Cyl Head	380-7386
7B-5088	Drum-Steer Cl Dr	223-4813
7F-9547	Pin As.-Drawbar	295-0414
7G-6044	Cage As	216-7857
7H-4710	Bushing-Sleeve	299-1990
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7M-1154	Bearing-Spl	417-4515
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
8H-9789	Bearing-Ball	374-8342
8N-8221	Bearing-Conn Rod	419-6377

Sales Model D5 (Cont'd.)

68J		
Original Part Number	Part Name	Classic Part Number
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770

68J		
Original Part Number	Part Name	Classic Part Number
9J-2007	Piston As	419-4714
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
121-7746	Pre-Cleaner As	360-2311

68J		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
160-6306	Cap-Bearing	325-6038
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112

81H		
Original Part Number	Part Name	Classic Part Number
0R-1628	Hub-Gear	219-2977
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-0090	Gasket-Manifold	445-7701
1M-0176	Flange-Drum	223-4810
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1P-1367	Plunger-Valve	432-8913
1S-1888	Bracket-Lamp	297-7147
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1U-2668	Cartridge Gp	422-8117
1W-7073	Rebuild Kt-Pump	383-3677
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259

81H		
Original Part Number	Part Name	Classic Part Number
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2M-2416	Guard-Idler-Lh	226-4933
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-7622	Bolt-Spring	226-4850
2S-1477	Holder As-Cage	226-7985
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-7931	Bearing-Sleeve	387-2904
3B-6218	Muffler As	247-2672
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823

81H		
Original Part Number	Part Name	Classic Part Number
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3S-3875	Screen-Suction	435-4849
3S-5017	Elbow-Exhaust	369-9498
3S-7153	Gear-Sliding	227-0024
3S-7504	Gear-Idler	226-6084
3S-8634	Hub-Gear	219-2977
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4J-2592	Brace As	418-1928
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063
4S-6189	Pinion-Reverse	226-6077
4S-6559	Tube	325-6234
4S-8005	Pinion-Fdr	226-6076
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161
5F-0736	Pin-Pivot	256-4823
5F-2256	Cage-Bearing	226-7973
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5J-2528	Plunger	391-1318

Sales Model D5 (Cont'd.)

81H		
Original Part Number	**Part Name**	**Classic Part Number**
5L-7632	Support-Elbow	433-9854
5M-6709	Check As-Ball	380-7542
5M-7342	Flange-Shaft	215-1696
5P-7807	Bearing-Ball	314-8502
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-8767	Gear-First	226-6085
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6P-0169	Hub-Fly Clutch	297-7204
6V-2202	Bearing-Spl Ball	380-1574
7B-5088	Drum-Steer Cl Dr	223-4813
7E-5085	Bushing	377-5829
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7G-3815	Pump Gp-Gr 2 Bsc	226-0171
7G-6044	Cage As	216-7857
7H-1318	Coupling-Ster Cl	226-8002
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901

81H		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7M-9398	Plate-Guide	297-7230
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-9146	Gear-Fly Starter	279-4995
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8B-5965	Race & Roller As	417-4512
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-5587	Rod Gp-Recoil	226-4954
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8M-8068	Bearing-Spl Ball	417-4500
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8S-1831	Guard As-Sprkt	226-4947
8S-2140	Trunnion-Gear	226-8020

81H		
Original Part Number	**Part Name**	**Classic Part Number**
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-7670	Piston	226-4961
9J-9598	Pin	296-1362
9M-4955	Pump Gp-F Tfr	242-3443
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7534	Pipe-Exh Ext	398-2950
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9S-9696	Spider As-Fan	383-3707
9W-1677	Bearing	297-7145
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
160-6306	Cap-Bearing	325-6038
169-4200	Gasket	472-8023
228-7325	Ster Cl Kit-Cla	230-7119
232-3233	Bearing-Main	376-9085

Sales Model D5 (Cont'd.)

82H		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1642	Hub-Gear	219-2976
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-0090	Gasket-Manifold	445-7701
1M-0176	Flange-Drum	223-4810
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1P-1367	Plunger-Valve	432-8913
1S-1888	Bracket-Lamp	297-7147
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1U-2668	Cartridge Gp	422-8117
1W-7073	Rebuild Kt-Pump	383-3677
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-7576	Shaft-Sprocket	226-6071
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2M-2416	Guard-Idler-Lh	226-4933
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-7622	Bolt-Spring	226-4850

82H		
Original Part Number	**Part Name**	**Classic Part Number**
2S-1477	Holder As-Cage	226-7985
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-7931	Bearing-Sleeve	387-2904
3B-6218	Muffler As	247-2672
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3P-5754	Hub-Gear	219-2976
3S-3875	Screen-Suction	435-4849
3S-5017	Elbow-Exhaust	369-9498
3S-7153	Gear-Sliding	227-0024
3S-7504	Gear-Idler	226-6084
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063
4S-6189	Pinion-Reverse	226-6077
4S-6559	Tube	325-6234
4S-8005	Pinion-Fdr	226-6076
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161

82H		
Original Part Number	**Part Name**	**Classic Part Number**
5F-0736	Pin-Pivot	256-4823
5F-2256	Cage-Bearing	226-7973
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5J-2528	Plunger	391-1318
5L-7632	Support-Elbow	433-9854
5M-6709	Check As-Ball	380-7542
5M-7342	Flange-Shaft	215-1696
5P-7807	Bearing-Ball	314-8502
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-8767	Gear-First	226-6085
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6P-0169	Hub-Fly Clutch	297-7204
6V-2202	Bearing-Spl Ball	380-1574
7B-5088	Drum-Steer Cl Dr	223-4813
7E-5085	Bushing	377-5829
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7G-3815	Pump Gp-Gr 2 Bsc	226-0171
7G-6044	Cage As	216-7857
7H-1318	Coupling-Ster Cl	226-8002
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206

Sales Model D5 (Cont'd.)

82H		
Original Part Number	Part Name	Classic Part Number
7M-4204	Manifold-Exhaust	261-0901
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7M-9398	Plate-Guide	297-7230
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-9146	Gear-Fly Starter	279-4995
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8B-5965	Race & Roller As	417-4512
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-5587	Rod Gp-Recoil	226-4954
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8M-8068	Bearing-Spl Ball	417-4500

82H		
Original Part Number	Part Name	Classic Part Number
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8S-1831	Guard As-Sprkt	226-4947
8S-2140	Trunnion-Gear	226-8020
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-7670	Piston	226-4961
9J-9598	Pin	296-1362
9M-4955	Pump Gp-F Tfr	242-3443
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9M-8117	Shaft-Fly Clutch	226-6073

82H		
Original Part Number	Part Name	Classic Part Number
9M-8119	Retainer-Inlet	226-8022
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7534	Pipe-Exh Ext	398-2950
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9S-9696	Spider As-Fan	383-3707
9W-1677	Bearing	297-7145
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
160-6306	Cap-Bearing	325-6038
169-4200	Gasket	472-8023
228-7325	Ster Cl Kit-Cla	230-7119
232-3233	Bearing-Main	376-9085

83H		
Original Part Number	Part Name	Classic Part Number
0R-1628	Hub-Gear	219-2977
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-0090	Gasket-Manifold	445-7701
1M-0176	Flange-Drum	223-4810
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1S-1888	Bracket-Lamp	297-7147

83H		
Original Part Number	Part Name	Classic Part Number
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1T-0051	Wheel-Impeller	388-6582
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-2668	Cartridge Gp	422-8117

83H		
Original Part Number	Part Name	Classic Part Number
1W-7073	Rebuild Kt-Pump	383-3677
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2M-2416	Guard-Idler-Lh	226-4933
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867

Sales Model D5 (Cont'd.)

83H		
Original Part Number	Part Name	Classic Part Number
2P-7622	Bolt-Spring	226-4850
2S-1477	Holder As-Cage	226-7985
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
3B-6218	Muffler As	247-2672
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3P-5955	Disc-Friction	428-7205
3S-1404	Bearing-Outer	417-4508
3S-3875	Screen-Suction	435-4849
3S-5017	Elbow-Exhaust	369-9498
3S-8634	Hub-Gear	219-2977
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4F-5004	Spring As-Arm	383-2128
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4J-2592	Brace As	418-1928
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063
4S-5943	Piston-Clutch	221-9112
4S-6559	Tube	325-6234
4S-8005	Pinion-Fdr	226-6076
4S-8530	Shaft-Planet	221-9111
4S-8534	Shaft As-Planet	221-9116
4S-8538	Bearing-Spl Ball	417-4502

83H		
Original Part Number	Part Name	Classic Part Number
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161
5F-0736	Pin-Pivot	256-4823
5F-2256	Cage-Bearing	226-7973
5H-7071	Director-Water	388-0555
5J-2528	Plunger	391-1318
5L-7632	Support-Elbow	433-9854
5M-2051	Bearing-Caged	380-7467
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-6978	Shaft-Planet	221-9103
5S-7010	Shaft-Planet	221-9104
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6V-2202	Bearing-Spl Ball	380-1574
6Y-2027	Disc-Friction	377-7441
6Y-3484	Bearing-Spl Ball	416-2166
7B-5088	Drum-Steer Cl Dr	223-4813
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2487	Gear-Planet	221-9092
7G-6044	Cage As	216-7857
7H-1318	Coupling-Ster Cl	226-8002
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990

83H		
Original Part Number	Part Name	Classic Part Number
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7M-9398	Plate-Guide	297-7230
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-9146	Gear-Fly Starter	279-4995
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-5587	Rod Gp-Recoil	226-4954
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8M-8068	Bearing-Spl Ball	417-4500
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1656	Plate-Clutch	367-6071
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8S-1831	Guard As-Sprkt	226-4947
8S-9686	Gasket Kit	393-5215

Sales Model D5 (Cont'd.)

83H		
Original Part Number	**Part Name**	**Classic Part Number**
9B-1320	Valve-Check	377-5832
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-7670	Piston	226-4961
9J-9598	Pin	296-1362
9M-2049	Gear-Ring	214-0533
9M-4955	Pump Gp-F Tfr	242-3443
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9M-8281	Gear As-Pump	325-6089
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923

83H		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3582	Cone-Roller Brg	396-4144
9S-7534	Pipe-Exh Ext	398-2950
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855

83H		
Original Part Number	**Part Name**	**Classic Part Number**
9S-8358	Guard As-Guiding	226-4856
9S-9696	Spider As-Fan	383-3707
9W-1677	Bearing	297-7145
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
155-8694	Gasket Kit	451-1503
160-6306	Cap-Bearing	325-6038
169-4200	Gasket	472-8023
228-7325	Ster Cl Kit-Cla	230-7119
232-3233	Bearing-Main	376-9085
235-1802	Tc Kit-Cla	235-0920
235-1802	Tc Kit-Cla	235-1808

84H		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1642	Hub-Gear	219-2976
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-0090	Gasket-Manifold	445-7701
1M-0176	Flange-Drum	223-4810
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1S-1888	Bracket-Lamp	297-7147
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1T-0051	Wheel-Impeller	388-6582
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-2668	Cartridge Gp	422-8117
1W-7073	Rebuild Kt-Pump	383-3677

84H		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-7576	Shaft-Sprocket	226-6071
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2M-2416	Guard-Idler-Lh	226-4933
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-7622	Bolt-Spring	226-4850
2S-1477	Holder As-Cage	226-7985
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
3B-6218	Muffler As	247-2672
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208

84H		
Original Part Number	**Part Name**	**Classic Part Number**
3J-6559	Cap-Bearing	296-1346
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3P-5754	Hub-Gear	219-2976
3P-5955	Disc-Friction	428-7205
3S-1404	Bearing-Outer	417-4508
3S-3875	Screen-Suction	435-4849
3S-5017	Elbow-Exhaust	369-9498
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4F-5004	Spring As-Arm	383-2128
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063
4S-5943	Piston-Clutch	221-9112
4S-6559	Tube	325-6234
4S-8005	Pinion-Fdr	226-6076
4S-8530	Shaft-Planet	221-9111

Sales Model D5 (Cont'd.)

84H		
Original Part Number	Part Name	Classic Part Number
4S-8534	Shaft As-Planet	221-9116
4S-8538	Bearing-Spl Ball	417-4502
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161
5F-0736	Pin-Pivot	256-4823
5F-2256	Cage-Bearing	226-7973
5H-7071	Director-Water	388-0555
5J-2528	Plunger	391-1318
5L-7632	Support-Elbow	433-9854
5M-2051	Bearing-Caged	380-7467
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-6978	Shaft-Planet	221-9103
5S-7010	Shaft-Planet	221-9104
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6V-2202	Bearing-Spl Ball	380-1574
6Y-2027	Disc-Friction	377-7441
6Y-3484	Bearing-Spl Ball	416-2166
7B-5088	Drum-Steer Cl Dr	223-4813
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2487	Gear-Planet	221-9092
7G-6044	Cage As	216-7857
7H-1318	Coupling-Ster Cl	226-8002

84H		
Original Part Number	Part Name	Classic Part Number
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7M-9398	Plate-Guide	297-7230
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-9146	Gear-Fly Starter	279-4995
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-5587	Rod Gp-Recoil	226-4954
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8M-8068	Bearing-Spl Ball	417-4500
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1656	Plate-Clutch	367-6071
8P-1853	Nut-Adjusting	226-7997

84H		
Original Part Number	Part Name	Classic Part Number
8P-1855	Hub As-Sprocket	227-4770
8S-1831	Guard As-Sprkt	226-4947
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-7670	Piston	226-4961
9J-2007	Piston As	419-4714
9J-9598	Pin	296-1362
9M-2049	Gear-Ring	214-0533
9M-4955	Pump Gp-F Tfr	242-3443
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9M-8281	Gear As-Pump	325-6089
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7534	Pipe-Exh Ext	398-2950
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9S-9696	Spider As-Fan	383-3707
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
155-8694	Gasket Kit	451-1503
160-6306	Cap-Bearing	325-6038
169-4200	Gasket	472-8023
228-7325	Ster Cl Kit-Cla	230-7119

Sales Model D5 (Cont'd.)

84H		
Original Part Number	**Part Name**	**Classic Part Number**
232-3233	Bearing-Main	376-9085

84H		
Original Part Number	**Part Name**	**Classic Part Number**
235-1802	Tc Kit-Cla	235-0920

84H		
Original Part Number	**Part Name**	**Classic Part Number**
235-1802	Tc Kit-Cla	235-1808

93J		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1628	Hub-Gear	219-2977
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-0176	Flange-Drum	223-4810
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4303	Head As-Cylinder	242-3434
1P-6752	Pump Gp-Gr 1 Bsc	226-0161
1P-7895	Cone-Roller Brg	396-4145
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1U-2668	Cartridge Gp	422-8117
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513

93J		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2M-2416	Guard-Idler-Lh	226-4933
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2P-7622	Bolt-Spring	226-4850
2S-1477	Holder As-Cage	226-7985
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979

93J		
Original Part Number	**Part Name**	**Classic Part Number**
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-0526	Bearing-Ball	386-4949
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3R-8530	Boss	425-3454
3S-3875	Screen-Suction	435-4849
3S-7153	Gear-Sliding	227-0024
3S-7504	Gear-Idler	226-6084
3S-8634	Hub-Gear	219-2977
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4J-2592	Brace As	418-1928
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063

Sales Model D5 (Cont'd.)

93J		
Original Part Number	Part Name	Classic Part Number
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4N-8344	Spider As-Fan	416-5520
4N-8814	Line As-F Inj	247-3366
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-6189	Pinion-Reverse	226-6077
4S-6559	Tube	325-6234
4S-8005	Pinion-Fdr	226-6076
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161
5F-0736	Pin-Pivot	256-4823
5F-2256	Cage-Bearing	226-7973
5G-3612	Cap Gp-Protn	295-6419
5H-5500	Collar-Fly Cl	302-2704
5J-2528	Plunger	391-1318
5L-6326	Bearing-Ball	420-3222
5M-6709	Check As-Ball	380-7542
5M-7342	Flange-Shaft	215-1696
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141

93J		
Original Part Number	Part Name	Classic Part Number
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8767	Gear-First	226-6085
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7178	Fork-Band Adj	299-2009
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0169	Hub-Fly Clutch	297-7204
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
6Y-7935	Disc-Friction	383-2121
7B-5088	Drum-Steer Cl Dr	223-4813
7B-7515	Bearing-Ball	399-6059
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829

93J		
Original Part Number	Part Name	Classic Part Number
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7G-3815	Pump Gp-Gr 2 Bsc	226-0171
7G-6044	Cage As	216-7857
7H-1318	Coupling-Ster Cl	226-8002
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7J-9884	Bearing-Sleeve	325-6016
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497

Sales Model D5 (Cont'd.)

93J		
Original Part Number	Part Name	Classic Part Number
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8K-5587	Rod Gp-Recoil	226-4954
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8M-8068	Bearing-Spl Ball	417-4500
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441

93J		
Original Part Number	Part Name	Classic Part Number
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1831	Guard As-Sprkt	226-4947
8S-2140	Trunnion-Gear	226-8020
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042

93J		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-2007	Piston As	419-4714
9J-9598	Pin	296-1362
9M-1997	Bearing-Ball	384-5954
9M-4789	Shaft-Gov Cont	297-7256
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9S-8679	Chamber As	325-6042

Sales Model D5 (Cont'd.)

93J		
Original Part Number	**Part Name**	**Classic Part Number**
9S-9696	Spider As-Fan	383-3707
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
160-6306	Cap-Bearing	325-6038

93J		
Original Part Number	**Part Name**	**Classic Part Number**
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
228-7325	Ster Cl Kit-Cla	230-7119

93J		
Original Part Number	**Part Name**	**Classic Part Number**
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

94J		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1642	Hub-Gear	219-2976
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-0176	Flange-Drum	223-4810
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4303	Head As-Cylinder	242-3434
1P-6752	Pump Gp-Gr 1 Bsc	226-0161
1P-7895	Cone-Roller Brg	396-4145
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5315	Cap As-Brace Brg	226-4848

94J		
Original Part Number	**Part Name**	**Classic Part Number**
1S-6422	Pilot As-Spring	226-4849
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1U-2668	Cartridge Gp	422-8117
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-7576	Shaft-Sprocket	226-6071
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2M-2416	Guard-Idler-Lh	226-4933

94J		
Original Part Number	**Part Name**	**Classic Part Number**
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2P-7622	Bolt-Spring	226-4850
2S-1477	Holder As-Cage	226-7985
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357

Sales Model D5 (Cont'd.)

94J		
Original Part Number	**Part Name**	**Classic Part Number**
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-0526	Bearing-Ball	386-4949
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3P-5754	Hub-Gear	219-2976
3S-3875	Screen-Suction	435-4849
3S-7153	Gear-Sliding	227-0024
3S-7504	Gear-Idler	226-6084
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362

94J		
Original Part Number	**Part Name**	**Classic Part Number**
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4N-8344	Spider As-Fan	416-5520
4N-8814	Line As-F Inj	247-3366
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-6189	Pinion-Reverse	226-6077
4S-6559	Tube	325-6234
4S-8005	Pinion-Fdr	226-6076
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161
5F-0736	Pin-Pivot	256-4823
5F-2256	Cage-Bearing	226-7973
5G-3612	Cap Gp-Protn	295-6419
5H-5500	Collar-Fly Cl	302-2704
5J-2528	Plunger	391-1318
5L-6326	Bearing-Ball	420-3222
5M-6709	Check As-Ball	380-7542
5M-7342	Flange-Shaft	215-1696
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

94J		
Original Part Number	**Part Name**	**Classic Part Number**
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8767	Gear-First	226-6085
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7178	Fork-Band Adj	299-2009
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0169	Hub-Fly Clutch	297-7204
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
6Y-7935	Disc-Friction	383-2121
7B-5088	Drum-Steer Cl Dr	223-4813
7B-7515	Bearing-Ball	399-6059
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7G-3815	Pump Gp-Gr 2 Bsc	226-0171
7G-6044	Cage As	216-7857
7H-1318	Coupling-Ster Cl	226-8002

Sales Model D5 (Cont'd.)

94J		
Original Part Number	**Part Name**	**Classic Part Number**
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7J-9884	Bearing-Sleeve	325-6016
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7T-0206	Bearing-Brace	297-7144

94J		
Original Part Number	**Part Name**	**Classic Part Number**
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8K-5587	Rod Gp-Recoil	226-4954
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8M-8068	Bearing-Spl Ball	417-4500
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623

94J		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1831	Guard As-Sprkt	226-4947
8S-2140	Trunnion-Gear	226-8020
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961

Sales Model D5 (Cont'd.)

94J		
Original Part Number	Part Name	Classic Part Number
9J-2007	Piston As	419-4714
9J-9598	Pin	296-1362
9M-1997	Bearing-Ball	384-5954
9M-4789	Shaft-Gov Cont	297-7256
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238

94J		
Original Part Number	Part Name	Classic Part Number
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
160-6306	Cap-Bearing	325-6038
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001

94J		
Original Part Number	Part Name	Classic Part Number
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
228-7325	Ster Cl Kit-Cla	230-7119
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

95J		
Original Part Number	Part Name	Classic Part Number
0R-1628	Hub-Gear	219-2977
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1M-0176	Flange-Drum	223-4810
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4303	Head As-Cylinder	242-3434
1P-6752	Pump Gp-Gr 1 Bsc	226-0161

95J		
Original Part Number	Part Name	Classic Part Number
1P-7895	Cone-Roller Brg	396-4145
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-1993	Wheel-Turbine	235-0920

95J		
Original Part Number	Part Name	Classic Part Number
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-2668	Cartridge Gp	422-8117
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305

Sales Model D5 (Cont'd.)

95J		
Original Part Number	Part Name	Classic Part Number
2M-2416	Guard-Idler-Lh	226-4933
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2P-7622	Bolt-Spring	226-4850
2S-1477	Holder As-Cage	226-7985
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-0526	Bearing-Ball	386-4949
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989

95J		
Original Part Number	Part Name	Classic Part Number
3P-5955	Disc-Friction	428-7205
3S-1404	Bearing-Outer	417-4508
3S-3875	Screen-Suction	435-4849
3S-8634	Hub-Gear	219-2977
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4F-5004	Spring As-Arm	383-2128
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4J-2592	Brace As	418-1928
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4N-8344	Spider As-Fan	416-5520
4N-8814	Line As-F Inj	247-3366
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-5943	Piston-Clutch	221-9112
4S-6559	Tube	325-6234
4S-8005	Pinion-Fdr	226-6076
4S-8530	Shaft-Planet	221-9111

95J		
Original Part Number	Part Name	Classic Part Number
4S-8534	Shaft As-Planet	221-9116
4S-8538	Bearing-Spl Ball	417-4502
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161
5F-0736	Pin-Pivot	256-4823
5F-2256	Cage-Bearing	226-7973
5G-3612	Cap Gp-Protn	295-6419
5J-2528	Plunger	391-1318
5L-6326	Bearing-Ball	420-3222
5M-2051	Bearing-Caged	380-7467
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-6978	Shaft-Planet	221-9103
5S-7010	Shaft-Planet	221-9104
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7178	Fork-Band Adj	299-2009
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495

Sales Model D5 (Cont'd.)

95J		
Original Part Number	Part Name	Classic Part Number
6J-8183	Bracket	394-0195
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
6Y-2027	Disc-Friction	377-7441
6Y-3484	Bearing-Spl Ball	416-2166
6Y-7935	Disc-Friction	383-2121
7B-5088	Drum-Steer Cl Dr	223-4813
7B-7515	Bearing-Ball	399-6059
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2487	Gear-Planet	221-9092
7G-6044	Cage As	216-7857
7H-1318	Coupling-Ster Cl	226-8002
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7J-9884	Bearing-Sleeve	325-6016
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994

95J		
Original Part Number	Part Name	Classic Part Number
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7S-8660	Pump Gp-Trans	226-0175
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8K-5587	Rod Gp-Recoil	226-4954
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192

95J		
Original Part Number	Part Name	Classic Part Number
8M-8068	Bearing-Spl Ball	417-4500
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083

Sales Model D5 (Cont'd.)

95J		
Original Part Number	Part Name	Classic Part Number
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1656	Plate-Clutch	367-6071
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1831	Guard As-Sprkt	226-4947
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-2007	Piston As	419-4714
9J-9598	Pin	296-1362
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-4789	Shaft-Gov Cont	297-7256
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517

95J		
Original Part Number	Part Name	Classic Part Number
9M-8281	Gear As-Pump	325-6089
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833

95J		
Original Part Number	Part Name	Classic Part Number
9Y-2992	Bearing-Sleeve	325-6032
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
155-8694	Gasket Kit	451-1503
160-6306	Cap-Bearing	325-6038
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
228-7325	Ster Cl Kit-Cla	230-7119
232-3233	Bearing-Main	376-9085
235-0912	Tc Kit-Cla	235-0920
235-1802	Tc Kit-Cla	235-0920
235-1802	Tc Kit-Cla	235-1808
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

96J		
Original Part Number	Part Name	Classic Part Number
0R-1642	Hub-Gear	219-2976
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1M-0176	Flange-Drum	223-4810
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1N-3576	Block Gp-Cyl	279-4978

96J		
Original Part Number	Part Name	Classic Part Number
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4303	Head As-Cylinder	242-3434
1P-6752	Pump Gp-Gr 1 Bsc	226-0161

96J		
Original Part Number	Part Name	Classic Part Number
1P-7895	Cone-Roller Brg	396-4145
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849

Sales Model D5 (Cont'd.)

96J		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-2668	Cartridge Gp	422-8117
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-7576	Shaft-Sprocket	226-6071
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2M-2416	Guard-Idler-Lh	226-4933
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2P-7622	Bolt-Spring	226-4850

96J		
Original Part Number	Part Name	Classic Part Number
2S-1477	Holder As-Cage	226-7985
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-0526	Bearing-Ball	386-4949
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3P-5754	Hub-Gear	219-2976
3P-5955	Disc-Friction	428-7205
3S-1404	Bearing-Outer	417-4508
3S-3875	Screen-Suction	435-4849
3S-5017	Elbow-Exhaust	369-9498
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4F-5004	Spring As-Arm	383-2128
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630

96J		
Original Part Number	Part Name	Classic Part Number
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4N-8344	Spider As-Fan	416-5520
4N-8814	Line As-F Inj	247-3366
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-5943	Piston-Clutch	221-9112
4S-6559	Tube	325-6234
4S-8005	Pinion-Fdr	226-6076
4S-8530	Shaft-Planet	221-9111
4S-8534	Shaft As-Planet	221-9116
4S-8538	Bearing-Spl Ball	417-4502
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161
5F-0736	Pin-Pivot	256-4823
5F-2256	Cage-Bearing	226-7973
5G-3612	Cap Gp-Protn	295-6419
5J-2528	Plunger	391-1318
5L-6326	Bearing-Ball	420-3222

Sales Model D5 (Cont'd.)

96J		
Original Part Number	Part Name	Classic Part Number
5M-2051	Bearing-Caged	380-7467
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-6978	Shaft-Planet	221-9103
5S-7010	Shaft-Planet	221-9104
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7178	Fork-Band Adj	299-2009
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
6Y-2027	Disc-Friction	377-7441
6Y-3484	Bearing-Spl Ball	416-2166

96J		
Original Part Number	Part Name	Classic Part Number
6Y-7935	Disc-Friction	383-2121
7B-5088	Drum-Steer Cl Dr	223-4813
7B-7515	Bearing-Ball	399-6059
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2487	Gear-Planet	221-9092
7G-6044	Cage As	216-7857
7H-1318	Coupling-Ster Cl	226-8002
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7J-9884	Bearing-Sleeve	325-6016
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519

96J		
Original Part Number	Part Name	Classic Part Number
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7S-8660	Pump Gp-Trans	226-0175
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8K-5587	Rod Gp-Recoil	226-4954
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8M-8068	Bearing-Spl Ball	417-4500
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291

Sales Model D5 (Cont'd.)

96J		
Original Part Number	Part Name	Classic Part Number
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1656	Plate-Clutch	367-6071
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1831	Guard As-Sprkt	226-4947
8S-2389	Body-Fuel Valve	377-5831

96J		
Original Part Number	Part Name	Classic Part Number
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-2007	Piston As	419-4714
9J-9598	Pin	296-1362
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-4789	Shaft-Gov Cont	297-7256
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9M-8281	Gear As-Pump	325-6089
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856

96J		
Original Part Number	Part Name	Classic Part Number
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
155-8694	Gasket Kit	451-1503
160-6306	Cap-Bearing	325-6038
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
228-7325	Ster Cl Kit-Cla	230-7119
232-3233	Bearing-Main	376-9085
235-0912	Tc Kit-Cla	235-0920
235-1802	Tc Kit-Cla	235-0920
235-1802	Tc Kit-Cla	235-1808
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model D5 (Cont'd.)

97J		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1S-5315	Cap As-Brace Brg	226-4848
1W-3900	Gasket	472-8006
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2F-5721	Bearing-Ball	311-9354
2K-4507	Bearing-Sleeve	325-6021
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3J-6559	Cap-Bearing	296-1346
3S-1404	Bearing-Outer	417-4508
4F-1252	Pin	295-5704
4F-2393	Bearing-Ball	380-1499
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063
4N-7693	Crankshaft As	269-8763
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502
5D-7449	Cup-Spl Tapered	416-2161

97J		
Original Part Number	**Part Name**	**Classic Part Number**
5F-0736	Pin-Pivot	256-4823
5M-2051	Bearing-Caged	380-7467
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
6H-3957	Bearing-Ball	311-9358
6J-8183	Bracket	394-0195
6N-7263	Gasket-Cyl Head	380-7386
6Y-3484	Bearing-Spl Ball	416-2166
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7S-3206	Seal-O-Ring	436-2656
7T-0206	Bearing-Brace	297-7144
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

97J		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
9G-8302	Guide	226-4853
9J-2007	Piston As	419-4714
9J-9598	Pin	296-1362
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
155-8694	Gasket Kit	451-1503
160-6306	Cap-Bearing	325-6038
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112

98A		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
121-7746	Pre-Cleaner As	360-2311

98J		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1642	Hub-Gear	219-2976
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103

98J		
Original Part Number	**Part Name**	**Classic Part Number**
1H-8937	Drum-Cl Brake	226-7993
1L-7319	Cup-Roller Brg	380-7499
1M-0176	Flange-Drum	223-4810
1M-7250	Bowl	360-2296

98J		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1N-3576	Block Gp-Cyl	279-4978

Sales Model D5 (Cont'd.)

98J		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1U-2668	Cartridge Gp	422-8117
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2F-7576	Shaft-Sprocket	226-6071
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2M-2416	Guard-Idler-Lh	226-4933
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

98J		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-7622	Bolt-Spring	226-4850
2S-1477	Holder As-Cage	226-7985
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
3F-1972	Retainer As	226-7988
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3P-5754	Hub-Gear	219-2976
3S-3875	Screen-Suction	435-4849
3S-5017	Elbow-Exhaust	369-9498
3S-7153	Gear-Sliding	227-0024
3S-7504	Gear-Idler	226-6084
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996
4K-4780	Strip As-Wear	299-2063
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365

98J		
Original Part Number	Part Name	Classic Part Number
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4N-9213	Elbow-Exhaust	330-9270
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-6189	Pinion-Reverse	226-6077
4S-6559	Tube	325-6234
4S-8005	Pinion-Fdr	226-6076
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161
5F-2256	Cage-Bearing	226-7973
5G-3612	Cap Gp-Protn	295-6419
5H-5500	Collar-Fly Cl	302-2704
5L-6326	Bearing-Ball	420-3222
5M-6709	Check As-Ball	380-7542
5M-7342	Flange-Shaft	215-1696
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883

Sales Model D5 (Cont'd.)

98J		
Original Part Number	Part Name	Classic Part Number
6B-5163	Bearing	417-4514
6B-7178	Fork-Band Adj	299-2009
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0169	Hub-Fly Clutch	297-7204
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
7B-5088	Drum-Steer Cl Dr	223-4813
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7G-2037	Joint Gp-Univ	226-8017
7G-3815	Pump Gp-Gr 2 Bsc	226-0171
7G-6044	Cage As	216-7857
7H-1318	Coupling-Ster Cl	226-8002
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348

98J		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636

98J		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8K-5587	Rod Gp-Recoil	226-4954
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8M-8068	Bearing-Spl Ball	417-4500
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377

Sales Model D5 (Cont'd.)

98J		
Original Part Number	Part Name	Classic Part Number
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1831	Guard As-Sprkt	226-4947
8S-2140	Trunnion-Gear	226-8020
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891

98J		
Original Part Number	Part Name	Classic Part Number
9H-7670	Piston	226-4961
9M-4789	Shaft-Gov Cont	297-7256
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856

98J		
Original Part Number	Part Name	Classic Part Number
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
228-7325	Ster Cl Kit-Cla	230-7119
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model D5B

21Y		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-1367	Plunger-Valve	432-8913
1S-1888	Bracket-Lamp	297-7147
1W-3900	Gasket	472-8006
2D-6421	Bearing-Outer	417-4510

21Y		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
4W-0452	Seal As -Cshaft	325-6191
5D-7449	Cup-Spl Tapered	416-2161

21Y		
Original Part Number	Part Name	Classic Part Number
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
6N-7263	Gasket-Cyl Head	380-7386

Sales Model D5B (Cont'd.)

21Y		
Original Part Number	Part Name	Classic Part Number
6V-1033	Rod End-Spher	375-5444
7M-1154	Bearing-Spl	417-4515
7N-8018	Seal-Water	418-1964
7W-7546	Gasket-Plate	433-8187
9K-8757	Rod End-Special	311-9361

21Y		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9Y-1798	Seal-Water	379-0165
111-8015	Gasket As-Head	279-4977

21Y		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
391-8229	Kit-Gasket-Fs	398-2955

22X		
Original Part Number	Part Name	Classic Part Number
0R-1628	Hub-Gear	219-2977
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1L-7319	Cup-Roller Brg	380-7499
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-6752	Pump Gp-Gr 1 Bsc	226-0161
1P-7895	Cone-Roller Brg	396-4145
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017

22X		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1085	Housing As-Diff	393-0928
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5804	Rod End-Spher	416-2151
2M-2416	Guard-Idler-Lh	226-4933
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2N-2139	Cone-Roller Brg	415-1911

22X		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2P-7622	Bolt-Spring	226-4850
2S-1477	Holder As-Cage	226-7985
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208

Sales Model D5B (Cont'd.)

22X		
Original Part Number	Part Name	Classic Part Number
3J-6559	Cap-Bearing	296-1346
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3S-3875	Screen-Suction	435-4849
3S-7153	Gear-Sliding	227-0024
3S-7504	Gear-Idler	226-6084
3S-8634	Hub-Gear	219-2977
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4N-8344	Spider As-Fan	416-5520
4N-8814	Line As-F Inj	247-3366
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

22X		
Original Part Number	Part Name	Classic Part Number
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4S-6189	Pinion-Reverse	226-6077
4S-6559	Tube	325-6234
4W-0452	Seal As -Cshaft	325-6191
4Y-0709	Disc-Friction	377-7431
5A-5740	Gear-Sliding	229-8229
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161
5F-0736	Pin-Pivot	256-4823
5H-5500	Collar-Fly Cl	302-2704
5L-6326	Bearing-Ball	420-3222
5M-6709	Check As-Ball	380-7542
5M-7342	Flange-Shaft	215-1696
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8767	Gear-First	226-6085
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428

22X		
Original Part Number	Part Name	Classic Part Number
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0169	Hub-Fly Clutch	297-7204
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7G-6044	Cage As	216-7857
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7J-6250	Bearing-Sleeve	385-3803
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7J-9884	Bearing-Sleeve	325-6016
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451

Sales Model D5B (Cont'd.)

22X		
Original Part Number	Part Name	Classic Part Number
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8K-5587	Rod Gp-Recoil	226-4954
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8N-0002	Trunnion As	314-8728

22X		
Original Part Number	Part Name	Classic Part Number
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083

22X		
Original Part Number	Part Name	Classic Part Number
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1324	Cage-Gr Shft Brg	229-8239
8P-1325	Hub-Ster Cl Dr	226-8005
8P-1326	Pilot-Cl Piston	226-6097
8P-1327	Pinion-Fdr	226-8000
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8P-8570	Pilot As-Cl Pstn	226-6097
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1831	Guard As-Sprkt	226-4947
8S-2140	Trunnion-Gear	226-8020
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-2007	Piston As	419-4714
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-1997	Bearing-Ball	384-5954
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9N-5403	Body As-Piston	250-6558

Sales Model D5B (Cont'd.)

22X		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833

22X		
Original Part Number	Part Name	Classic Part Number
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484

22X		
Original Part Number	Part Name	Classic Part Number
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

23X		
Original Part Number	Part Name	Classic Part Number
0R-1642	Hub-Gear	219-2976
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1L-7319	Cup-Roller Brg	380-7499
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978

23X		
Original Part Number	Part Name	Classic Part Number
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-6752	Pump Gp-Gr 1 Bsc	226-0161
1P-7895	Cone-Roller Brg	396-4145
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147

23X		
Original Part Number	Part Name	Classic Part Number
1S-3062	Director-Water	418-9572
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1W-0777	Muffler As	247-2662
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659

Sales Model D5B (Cont'd.)

23X		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6421	Bearing-Outer	417-4510
2F-5721	Bearing-Ball	311-9354
2F-7576	Shaft-Sprocket	226-6071
2G-1085	Housing As-Diff	393-0928
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5804	Rod End-Spher	416-2151
2M-2416	Guard-Idler-Lh	226-4933
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230

23X		
Original Part Number	Part Name	Classic Part Number
2P-2697	Tube As-Air Vent	382-6901
2P-2744	Muffler As.	247-2664
2P-4370	Plate-Clutch	325-6166
2P-4611	Pipe-Exhaust	365-8821
2P-5081	Muffler As	360-7872
2P-6245	Shaft As-Pump	325-6197
2P-7622	Bolt-Spring	226-4850
2P-9660	Gear	226-5995
2P-9672	Cage-Pinion Brg	226-7972
2S-1477	Holder As-Cage	226-7985
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-0526	Bearing-Ball	386-4949
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3P-5754	Hub-Gear	219-2976
3S-3875	Screen-Suction	435-4849
3S-7153	Gear-Sliding	227-0024
3S-7504	Gear-Idler	226-6084
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219

23X		
Original Part Number	Part Name	Classic Part Number
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4N-8344	Spider As-Fan	416-5520
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4N-9213	Elbow-Exhaust	330-9270
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4S-6189	Pinion-Reverse	226-6077
4S-6559	Tube	325-6234
4W-0452	Seal As -Cshaft	325-6191
4Y-0709	Disc-Friction	377-7431
5A-5740	Gear-Sliding	229-8229
5A-9551	Gear-Finaldrive	226-7979

Sales Model D5B (Cont'd.)

23X		
Original Part Number	Part Name	Classic Part Number
5D-7449	Cup-Spl Tapered	416-2161
5F-0736	Pin-Pivot	256-4823
5H-5500	Collar-Fly Cl	302-2704
5L-6326	Bearing-Ball	420-3222
5M-5856	Pipe-Extension	373-1913
5M-6709	Check As-Ball	380-7542
5M-7342	Flange-Shaft	215-1696
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8767	Gear-First	226-6085
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0169	Hub-Fly Clutch	297-7204
6V-1033	Rod End-Spher	375-5444

23X		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7G-6044	Cage As	216-7857
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7J-6250	Bearing-Sleeve	385-3803
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7J-9884	Bearing-Sleeve	325-6016
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3486	Manifold-Exhaust	261-0899

23X		
Original Part Number	Part Name	Classic Part Number
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8117	Muffler As	247-2668
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8K-5587	Rod Gp-Recoil	226-4954
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

Sales Model D5B (Cont'd.)

23X		
Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1324	Cage-Gr Shft Brg	229-8239

23X		
Original Part Number	Part Name	Classic Part Number
8P-1325	Hub-Ster Cl Dr	226-8005
8P-1326	Pilot-Cl Piston	226-6097
8P-1327	Pinion-Fdr	226-8000
8P-1774	Pinion-Fdr	226-8001
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8P-8570	Pilot As-Cl Pstn	226-6097
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1831	Guard As-Sprkt	226-4947
8S-2140	Trunnion-Gear	226-8020
8S-2389	Body-Fuel Valve	377-5831
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-2007	Piston As	419-4714
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-1997	Bearing-Ball	384-5954
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891

23X		
Original Part Number	Part Name	Classic Part Number
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

Sales Model D5B (Cont'd.)

23X		
Original Part Number	Part Name	Classic Part Number
170-0558	Kit-Rebuild-Pump	390-1001
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

23X		
Original Part Number	Part Name	Classic Part Number
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892

23X		
Original Part Number	Part Name	Classic Part Number
247-2670	Muffler-Classic	247-2675
250-6555	Kit-Liner-Cla	250-6563
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

24X		
Original Part Number	Part Name	Classic Part Number
0R-1628	Hub-Gear	219-2977
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1L-7319	Cup-Roller Brg	380-7499
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-6752	Pump Gp-Gr 1 Bsc	226-0161
1P-7895	Cone-Roller Brg	396-4145
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1T-0043	Bearing-Ball	390-5294

24X		
Original Part Number	Part Name	Classic Part Number
1T-0521	Retainer-Bearing	325-6180
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1085	Housing As-Diff	393-0928
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2M-2416	Guard-Idler-Lh	226-4933
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927

24X		
Original Part Number	Part Name	Classic Part Number
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2P-7622	Bolt-Spring	226-4850
2S-1477	Holder As-Cage	226-7985
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694

Sales Model D5B (Cont'd.)

24X		
Original Part Number	Part Name	Classic Part Number
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3P-5955	Disc-Friction	428-7205
3S-1404	Bearing-Outer	417-4508
3S-3875	Screen-Suction	435-4849
3S-8634	Hub-Gear	219-2977
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2393	Bearing-Ball	380-1499
4F-5004	Spring As-Arm	383-2128
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4N-8344	Spider As-Fan	416-5520
4N-8814	Line As-F Inj	247-3366

24X		
Original Part Number	Part Name	Classic Part Number
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4S-5943	Piston-Clutch	221-9112
4S-6559	Tube	325-6234
4S-8530	Shaft-Planet	221-9111
4S-8534	Shaft As-Planet	221-9116
4S-8538	Bearing-Spl Ball	417-4502
4W-0452	Seal As -Cshaft	325-6191
4Y-0709	Disc-Friction	377-7431
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161
5F-0736	Pin-Pivot	256-4823
5L-6326	Bearing-Ball	420-3222
5M-2051	Bearing-Caged	380-7467
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-6978	Shaft-Planet	221-9103
5S-7010	Shaft-Planet	221-9104
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918

24X		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
6Y-2027	Disc-Friction	377-7441
6Y-3484	Bearing-Spl Ball	416-2166
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2487	Gear-Planet	221-9092
7G-6044	Cage As	216-7857
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7J-6250	Bearing-Sleeve	385-3803
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932

Sales Model D5B (Cont'd.)

24X		
Original Part Number	Part Name	Classic Part Number
7J-9884	Bearing-Sleeve	325-6016
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7S-8660	Pump Gp-Trans	226-0175
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636

24X		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8K-5587	Rod Gp-Recoil	226-4954
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860

24X		
Original Part Number	Part Name	Classic Part Number
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1324	Cage-Gr Shft Brg	229-8239
8P-1325	Hub-Ster Cl Dr	226-8005
8P-1326	Pilot-Cl Piston	226-6097
8P-1327	Pinion-Fdr	226-8000
8P-1656	Plate-Clutch	367-6071
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8P-8570	Pilot As-Cl Pstn	226-6097
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1831	Guard As-Sprkt	226-4947
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-2007	Piston As	419-4714
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361

Sales Model D5B (Cont'd.)

24X		
Original Part Number	Part Name	Classic Part Number
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-8281	Gear As-Pump	325-6089
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9S-8679	Chamber As	325-6042

24X		
Original Part Number	Part Name	Classic Part Number
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
155-8694	Gasket Kit	451-1503
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-0566	Kit-Rebuild-Pump	377-5835

24X		
Original Part Number	Part Name	Classic Part Number
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
174-6836	Gasket Kit - Tof	434-7280
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
235-0912	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

25X		
Original Part Number	Part Name	Classic Part Number
0R-1642	Hub-Gear	219-2976
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1L-7319	Cup-Roller Brg	380-7499
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978

25X		
Original Part Number	Part Name	Classic Part Number
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4695	Cup-Rlr Bearing	374-1842
1P-4696	Cone-Rlr Bearing	374-1843

25X		
Original Part Number	Part Name	Classic Part Number
1P-6752	Pump Gp-Gr 1 Bsc	226-0161
1P-7895	Cone-Roller Brg	396-4145
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1S-8734	Bracket-Roller	226-0212

Sales Model D5B (Cont'd.)

25X		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1T-0521	Retainer-Bearing	325-6180
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-0777	Muffler As	247-2662
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6421	Bearing-Outer	417-4510
2F-5721	Bearing-Ball	311-9354
2F-7576	Shaft-Sprocket	226-6071
2G-1085	Housing As-Diff	393-0928
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2M-2416	Guard-Idler-Lh	226-4933
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

25X		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2744	Muffler As.	247-2664
2P-4370	Plate-Clutch	325-6166
2P-4611	Pipe-Exhaust	365-8821
2P-5081	Muffler As	360-7872
2P-6245	Shaft As-Pump	325-6197
2P-7622	Bolt-Spring	226-4850
2P-8986	Cup-Rlr Bearing	415-1912
2P-9660	Gear	226-5995
2P-9672	Cage-Pinion Brg	226-7972
2S-1477	Holder As-Cage	226-7985
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3J-8688	Bearing-Sleeve	380-1561
3K-0526	Bearing-Ball	386-4949
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3P-5754	Hub-Gear	219-2976
3P-5955	Disc-Friction	428-7205
3P-8845	Bearing-Inner	416-5491
3R-8530	Boss	425-3454
3S-1404	Bearing-Outer	417-4508

25X		
Original Part Number	Part Name	Classic Part Number
3S-3875	Screen-Suction	435-4849
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-2393	Bearing-Ball	380-1499
4F-5004	Spring As-Arm	383-2128
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4N-8344	Spider As-Fan	416-5520
4N-8814	Line As-F Inj	247-3366
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4S-5943	Piston-Clutch	221-9112
4S-6559	Tube	325-6234
4S-8530	Shaft-Planet	221-9111

Sales Model D5B (Cont'd.)

25X		
Original Part Number	Part Name	Classic Part Number
4S-8534	Shaft As-Planet	221-9116
4S-8538	Bearing-Spl Ball	417-4502
4W-0452	Seal As -Cshaft	325-6191
4Y-0709	Disc-Friction	377-7431
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161
5F-0736	Pin-Pivot	256-4823
5L-6326	Bearing-Ball	420-3222
5M-2051	Bearing-Caged	380-7467
5M-5856	Pipe-Extension	373-1913
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-6978	Shaft-Planet	221-9103
5S-7010	Shaft-Planet	221-9104
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991

25X		
Original Part Number	Part Name	Classic Part Number
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
6Y-2027	Disc-Friction	377-7441
6Y-3484	Bearing-Spl Ball	416-2166
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2487	Gear-Planet	221-9092
7G-6044	Cage As	216-7857
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7J-6250	Bearing-Sleeve	385-3803
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7J-9884	Bearing-Sleeve	325-6016
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451

25X		
Original Part Number	Part Name	Classic Part Number
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8117	Muffler As	247-2668
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-7245	Valve	386-3811
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8660	Pump Gp-Trans	226-0175
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8K-5587	Rod Gp-Recoil	226-4954

Sales Model D5B (Cont'd.)

25X		
Original Part Number	Part Name	Classic Part Number
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

25X		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1324	Cage-Gr Shft Brg	229-8239
8P-1325	Hub-Ster Cl Dr	226-8005
8P-1326	Pilot-Cl Piston	226-6097
8P-1327	Pinion-Fdr	226-8000
8P-1656	Plate-Clutch	367-6071
8P-1774	Pinion-Fdr	226-8001
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8P-8570	Pilot As-Cl Pstn	226-6097
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1831	Guard As-Sprkt	226-4947
8S-2389	Body-Fuel Valve	377-5831
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-2007	Piston As	419-4714
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-1997	Bearing-Ball	384-5954

25X		
Original Part Number	Part Name	Classic Part Number
9M-2049	Gear-Ring	214-0533
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-8281	Gear As-Pump	325-6089
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
155-8694	Gasket Kit	451-1503
160-6306	Cap-Bearing	325-6038

Sales Model D5B (Cont'd.)

25X		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-0566	Kit-Rebuild-Pump	377-5835

25X		
Original Part Number	Part Name	Classic Part Number
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
174-6836	Gasket Kit - Tof	434-7280
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024

25X		
Original Part Number	Part Name	Classic Part Number
232-3233	Bearing-Main	376-9085
235-0912	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
247-2670	Muffler-Classic	247-2675
250-6555	Kit-Liner-Cla	250-6563
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

26X		
Original Part Number	Part Name	Classic Part Number
0R-1642	Hub-Gear	219-2976
0R-1643	Hub-Gear	219-2975
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1L-7319	Cup-Roller Brg	380-7499
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849

26X		
Original Part Number	Part Name	Classic Part Number
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6421	Bearing-Outer	417-4510
2F-5721	Bearing-Ball	311-9354
2F-7576	Shaft-Sprocket	226-6071
2G-1085	Housing As-Diff	393-0928

26X		
Original Part Number	Part Name	Classic Part Number
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-5804	Rod End-Spher	416-2151
2M-2416	Guard-Idler-Lh	226-4933
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

Sales Model D5B (Cont'd.)

26X		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-7622	Bolt-Spring	226-4850
2P-9660	Gear	226-5995
2P-9672	Cage-Pinion Brg	226-7972
2S-1477	Holder As-Cage	226-7985
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3F-1972	Retainer As	226-7988
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3P-5736	Hub-Gear	219-2975
3P-5754	Hub-Gear	219-2976
3S-3875	Screen-Suction	435-4849
3S-7504	Gear-Idler	226-6084
4D-2619	Bearing	417-4494
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996
4K-4780	Strip As-Wear	299-2063
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362

26X		
Original Part Number	Part Name	Classic Part Number
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4N-9213	Elbow-Exhaust	330-9270
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-6559	Tube	325-6234
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4Y-0709	Disc-Friction	377-7431
5A-4003	Shaft-Sprocket	229-8228
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161
5H-5500	Collar-Fly Cl	302-2704
5K-2294	Bearing	396-9912
5L-6326	Bearing-Ball	420-3222

26X		
Original Part Number	Part Name	Classic Part Number
5M-5856	Pipe-Extension	373-1913
5M-7342	Flange-Shaft	215-1696
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7178	Fork-Band Adj	299-2009
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0169	Hub-Fly Clutch	297-7204
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074

Sales Model D5B (Cont'd.)

26X		
Original Part Number	Part Name	Classic Part Number
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7G-2037	Joint Gp-Univ	226-8017
7G-6044	Cage As	216-7857
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066

26X		
Original Part Number	Part Name	Classic Part Number
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-5587	Rod Gp-Recoil	226-4954
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556

26X		
Original Part Number	Part Name	Classic Part Number
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1324	Cage-Gr Shft Brg	229-8239
8P-1325	Hub-Ster Cl Dr	226-8005
8P-1326	Pilot-Cl Piston	226-6097
8P-1327	Pinion-Fdr	226-8000
8P-1774	Pinion-Fdr	226-8001
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8P-8570	Pilot As-Cl Pstn	226-6097
8S-0248	Breather As	325-6033

Sales Model D5B (Cont'd.)

26X		
Original Part Number	Part Name	Classic Part Number
8S-0493	Shaft As-Pump	325-6198
8S-1831	Guard As-Sprkt	226-4947
8S-2140	Trunnion-Gear	226-8020
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-7670	Piston	226-4961
9K-8757	Rod End-Special	311-9361
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124

26X		
Original Part Number	Part Name	Classic Part Number
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

26X		
Original Part Number	Part Name	Classic Part Number
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

43X		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
2D-6421	Bearing-Outer	417-4510
2P-0220	Gasket-Pump	398-2927
4W-0452	Seal As -Cshaft	325-6191

43X		
Original Part Number	Part Name	Classic Part Number
5D-7449	Cup-Spl Tapered	416-2161
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141

43X		
Original Part Number	Part Name	Classic Part Number
5P-9177	Race-Brg Inner	396-4139
7M-1154	Bearing-Spl	417-4515
7N-8018	Seal-Water	418-1964
7W-7546	Gasket-Plate	433-8187

Sales Model D5B (Cont'd.)

43X		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9Y-1798	Seal-Water	379-0165

43X		
Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194

43X		
Original Part Number	Part Name	Classic Part Number
169-4200	Gasket	472-8023
391-8229	Kit-Gasket-Fs	398-2955

44X		
Original Part Number	Part Name	Classic Part Number
0R-1642	Hub-Gear	219-2976
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1L-7319	Cup-Roller Brg	380-7499
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1T-0521	Retainer-Bearing	325-6180
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6421	Bearing-Outer	417-4510
2F-5721	Bearing-Ball	311-9354
2F-7576	Shaft-Sprocket	226-6071

44X		
Original Part Number	Part Name	Classic Part Number
2M-2416	Guard-Idler-Lh	226-4933
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-7622	Bolt-Spring	226-4850
2P-9660	Gear	226-5995
2P-9672	Cage-Pinion Brg	226-7972
2S-1477	Holder As-Cage	226-7985
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3F-1972	Retainer As	226-7988
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479

44X		
Original Part Number	Part Name	Classic Part Number
3P-3623	Lock-Adj Nut	226-7989
3P-5754	Hub-Gear	219-2976
3P-5955	Disc-Friction	428-7205
3R-8530	Boss	425-3454
3S-1404	Bearing-Outer	417-4508
3S-3875	Screen-Suction	435-4849
4D-2619	Bearing	417-4494
4F-2393	Bearing-Ball	380-1499
4F-5004	Spring As-Arm	383-2128
4H-9040	Nut	226-7996
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4S-5943	Piston-Clutch	221-9112
4S-6559	Tube	325-6234
4S-8530	Shaft-Planet	221-9111
4S-8534	Shaft As-Planet	221-9116
4S-8538	Bearing-Spl Ball	417-4502

Sales Model D5B (Cont'd.)

44X		
Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As -Cshaft	325-6191
4Y-0709	Disc-Friction	377-7431
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161
5L-6326	Bearing-Ball	420-3222
5M-2051	Bearing-Caged	380-7467
5M-6709	Check As-Ball	380-7542
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-6978	Shaft-Planet	221-9103
5S-7010	Shaft-Planet	221-9104
5S-7630	Bearing-Sleeve	394-0219
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-2027	Disc-Friction	377-7441
6Y-3484	Bearing-Spl Ball	416-2166
7C-3862	Camshaft	458-0151
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851

44X		
Original Part Number	Part Name	Classic Part Number
7F-2742	Bearing-Ball	422-6488
7F-9547	Pin As.-Drawbar	295-0414
7G-2487	Gear-Planet	221-9092
7G-6044	Cage As	216-7857
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7S-8660	Pump Gp-Trans	226-0175
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-5587	Rod Gp-Recoil	226-4954
8M-0874	Plunger As-Valve	311-9439

44X		
Original Part Number	Part Name	Classic Part Number
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084

Sales Model D5B (Cont'd.)

44X		
Original Part Number	Part Name	Classic Part Number
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1324	Cage-Gr Shft Brg	229-8239
8P-1325	Hub-Ster Cl Dr	226-8005
8P-1326	Pilot-Cl Piston	226-6097
8P-1327	Pinion-Fdr	226-8000
8P-1656	Plate-Clutch	367-6071
8P-1774	Pinion-Fdr	226-8001
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8P-8570	Pilot As-Cl Pstn	226-6097
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1831	Guard As-Sprkt	226-4947
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-7670	Piston	226-4961
9J-2007	Piston As	419-4714
9K-8757	Rod End-Special	311-9361
9M-2049	Gear-Ring	214-0533
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-8281	Gear As-Pump	325-6089
9N-5403	Body As-Piston	250-6558

44X		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
155-8694	Gasket Kit	451-1503
164-6560	Body As-Piston	477-7125

44X		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
235-0912	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

45X		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
2B-0941	Spacer	418-1955
2D-6421	Bearing-Outer	417-4510
2M-8340	Rod End-Yoke	374-4678

45X		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
4D-4065	Rod End-Spher	374-1824
4W-0452	Seal As -Cshaft	325-6191

45X		
Original Part Number	Part Name	Classic Part Number
5D-7449	Cup-Spl Tapered	416-2161
5P-8768	Kit-Gasket (Scl)	393-1024
7M-1154	Bearing-Spl	417-4515

Sales Model D5B (Cont'd.)

45X		
Original Part Number	Part Name	Classic Part Number
7N-8018	Seal-Water	418-1964
7W-7546	Gasket-Plate	433-8187
8H-8175	Bearing-Sleeve	376-3636
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016

45X		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9Y-1798	Seal-Water	379-0165
111-8015	Gasket As-Head	279-4977

45X		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
391-8229	Kit-Gasket-Fs	398-2955

46X		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
2B-0941	Spacer	418-1955
2D-6421	Bearing-Outer	417-4510
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
3S-1404	Bearing-Outer	417-4508
4D-4065	Rod End-Spher	374-1824
4F-2393	Bearing-Ball	380-1499
4S-8538	Bearing-Spl Ball	417-4502
4W-0452	Seal As -Cshaft	325-6191

46X		
Original Part Number	Part Name	Classic Part Number
5D-7449	Cup-Spl Tapered	416-2161
5M-2051	Bearing-Caged	380-7467
5P-8768	Kit-Gasket (Scl)	393-1024
6Y-3484	Bearing-Spl Ball	416-2166
7F-2742	Bearing-Ball	422-6488
7N-8018	Seal-Water	418-1964
7W-7546	Gasket-Plate	433-8187
8H-8175	Bearing-Sleeve	376-3636

46X		
Original Part Number	Part Name	Classic Part Number
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
9Y-1798	Seal-Water	379-0165
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
155-8694	Gasket Kit	451-1503
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
391-8229	Kit-Gasket-Fs	398-2955

47X		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1L-7319	Cup-Roller Brg	380-7499
1M-7250	Bowl	360-2296
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849

47X		
Original Part Number	Part Name	Classic Part Number
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6421	Bearing-Outer	417-4510
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259

47X		
Original Part Number	Part Name	Classic Part Number
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2K-5804	Rod End-Spher	416-2151
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

Sales Model D5B (Cont'd.)

47X		
Original Part Number	Part Name	Classic Part Number
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-7622	Bolt-Spring	226-4850
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3S-3875	Screen-Suction	435-4849
3S-7153	Gear-Sliding	227-0024
3S-7504	Gear-Idler	226-6084
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763

47X		
Original Part Number	Part Name	Classic Part Number
4N-7982	Pulley	264-5880
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4S-6189	Pinion-Reverse	226-6077
4S-6559	Tube	325-6234
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4Y-0709	Disc-Friction	377-7431
5A-5740	Gear-Sliding	229-8229
5D-7449	Cup-Spl Tapered	416-2161
5F-0736	Pin-Pivot	256-4823
5H-5500	Collar-Fly Cl	302-2704
5L-6326	Bearing-Ball	420-3222
5M-7342	Flange-Shaft	215-1696
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8767	Gear-First	226-6085
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

47X		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0169	Hub-Fly Clutch	297-7204
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
7C-3862	Camshaft	458-0151
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-9842	Bearing-Sleeve	299-1968
7M-1154	Bearing-Spl	417-4515
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417

Sales Model D5B (Cont'd.)

47X		
Original Part Number	Part Name	Classic Part Number
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8F-6058	Bearing-Sleeve	416-5494
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8K-5587	Rod Gp-Recoil	226-4954
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464

47X		
Original Part Number	Part Name	Classic Part Number
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1324	Cage-Gr Shft Brg	229-8239
8P-1325	Hub-Ster Cl Dr	226-8005
8P-1326	Pilot-Cl Piston	226-6097
8P-1855	Hub As-Sprocket	227-4770
8P-3595	Mount	418-1950
8P-8570	Pilot As-Cl Pstn	226-6097
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1831	Guard As-Sprkt	226-4947
8S-2140	Trunnion-Gear	226-8020
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-7670	Piston	226-4961
9J-2007	Piston As	419-4714
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517

47X		
Original Part Number	Part Name	Classic Part Number
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126

Sales Model D5B (Cont'd.)

47X		
Original Part Number	Part Name	Classic Part Number
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

47X		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893

47X		
Original Part Number	Part Name	Classic Part Number
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

48X		
Original Part Number	Part Name	Classic Part Number
0R-1642	Hub-Gear	219-2976
0R-1643	Hub-Gear	219-2975
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1L-7319	Cup-Roller Brg	380-7499
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1S-8734	Bracket-Roller	226-0212
1T-0521	Retainer-Bearing	325-6180
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-0777	Muffler As	247-2662
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-6987	Valve As-Check	420-6221

48X		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6421	Bearing-Outer	417-4510
2F-5721	Bearing-Ball	311-9354
2F-7576	Shaft-Sprocket	226-6071
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2M-2416	Guard-Idler-Lh	226-4933
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2744	Muffler As.	247-2664
2P-5081	Muffler As	360-7872
2P-6245	Shaft As-Pump	325-6197

48X		
Original Part Number	Part Name	Classic Part Number
2P-7622	Bolt-Spring	226-4850
2P-9660	Gear	226-5995
2P-9672	Cage-Pinion Brg	226-7972
2S-1477	Holder As-Cage	226-7985
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3P-5736	Hub-Gear	219-2975
3P-5754	Hub-Gear	219-2976
3P-5955	Disc-Friction	428-7205
3S-1404	Bearing-Outer	417-4508

Sales Model D5B (Cont'd.)

48X		
Original Part Number	Part Name	Classic Part Number
3S-3875	Screen-Suction	435-4849
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-2393	Bearing-Ball	380-1499
4F-5004	Spring As-Arm	383-2128
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4N-8344	Spider As-Fan	416-5520
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4S-5943	Piston-Clutch	221-9112
4S-6559	Tube	325-6234
4S-8530	Shaft-Planet	221-9111
4S-8534	Shaft As-Planet	221-9116
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4Y-0709	Disc-Friction	377-7431
5A-4003	Shaft-Sprocket	229-8228
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161
5F-0736	Pin-Pivot	256-4823
5L-6326	Bearing-Ball	420-3222
5M-2051	Bearing-Caged	380-7467
5M-5856	Pipe-Extension	373-1913
5M-6709	Check As-Ball	380-7542

48X		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-6978	Shaft-Planet	221-9103
5S-7010	Shaft-Planet	221-9104
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
6Y-2027	Disc-Friction	377-7441
6Y-3484	Bearing-Spl Ball	416-2166
7C-3862	Camshaft	458-0151
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361

48X		
Original Part Number	Part Name	Classic Part Number
7F-9547	Pin As.-Drawbar	295-0414
7G-2487	Gear-Planet	221-9092
7G-6044	Cage As	216-7857
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-9842	Bearing-Sleeve	299-1968
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8117	Muffler As	247-2668
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8660	Pump Gp-Trans	226-0175
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494

Sales Model D5B (Cont'd.)

48X		
Original Part Number	Part Name	Classic Part Number
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8K-5587	Rod Gp-Recoil	226-4954
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

48X		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1324	Cage-Gr Shft Brg	229-8239
8P-1325	Hub-Ster Cl Dr	226-8005
8P-1326	Pilot-Cl Piston	226-6097
8P-1327	Pinion-Fdr	226-8000
8P-1656	Plate-Clutch	367-6071
8P-1774	Pinion-Fdr	226-8001
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8P-3595	Mount	418-1950
8P-8570	Pilot As-Cl Pstn	226-6097
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1831	Guard As-Sprkt	226-4947
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9G-8302	Guide	226-4853
9H-7670	Piston	226-4961
9J-2007	Piston As	419-4714
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-2049	Gear-Ring	214-0533
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-8281	Gear As-Pump	325-6089
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544

48X		
Original Part Number	Part Name	Classic Part Number
9S-2355	Manifold-Exhaust	261-0891
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
155-8694	Gasket Kit	451-1503
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127

Sales Model D5B (Cont'd.)

48X		
Original Part Number	**Part Name**	**Classic Part Number**
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

48X		
Original Part Number	**Part Name**	**Classic Part Number**
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
235-0912	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675

48X		
Original Part Number	**Part Name**	**Classic Part Number**
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

49X		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1642	Hub-Gear	219-2976
0R-1643	Hub-Gear	219-2975
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1L-7319	Cup-Roller Brg	380-7499
1M-7250	Bowl	360-2296
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

49X		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6421	Bearing-Outer	417-4510
2F-5721	Bearing-Ball	311-9354
2F-7576	Shaft-Sprocket	226-6071
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-5804	Rod End-Spher	416-2151
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230

49X		
Original Part Number	**Part Name**	**Classic Part Number**
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-7622	Bolt-Spring	226-4850
2P-9660	Gear	226-5995
2P-9672	Cage-Pinion Brg	226-7972
2S-1477	Holder As-Cage	226-7985
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3P-5736	Hub-Gear	219-2975
3P-5754	Hub-Gear	219-2976

Sales Model D5B (Cont'd.)

49X		
Original Part Number	Part Name	Classic Part Number
3S-3875	Screen-Suction	435-4849
3S-7153	Gear-Sliding	227-0024
3S-7504	Gear-Idler	226-6084
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4S-6189	Pinion-Reverse	226-6077
4S-6559	Tube	325-6234
4W-0452	Seal As -Cshaft	325-6191
4Y-0709	Disc-Friction	377-7431
5A-4003	Shaft-Sprocket	229-8228
5A-5740	Gear-Sliding	229-8229
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161
5H-5500	Collar-Fly Cl	302-2704
5L-6326	Bearing-Ball	420-3222
5M-5856	Pipe-Extension	373-1913
5M-7342	Flange-Shaft	215-1696

49X		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8767	Gear-First	226-6085
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0169	Hub-Fly Clutch	297-7204
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
7C-3862	Camshaft	458-0151
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7G-6044	Cage As	216-7857
7H-2424	Sleeve-Spring	226-4852

49X		
Original Part Number	Part Name	Classic Part Number
7H-4710	Bushing-Sleeve	299-1990
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8F-6058	Bearing-Sleeve	416-5494
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636

Sales Model D5B (Cont'd.)

49X		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

49X		
Original Part Number	Part Name	Classic Part Number
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1324	Cage-Gr Shft Brg	229-8239
8P-1325	Hub-Ster Cl Dr	226-8005
8P-1326	Pilot-Cl Piston	226-6097
8P-1327	Pinion-Fdr	226-8000
8P-1774	Pinion-Fdr	226-8001
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8P-8570	Pilot As-Cl Pstn	226-6097
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1831	Guard As-Sprkt	226-4947
8S-2140	Trunnion-Gear	226-8020
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-7670	Piston	226-4961
9J-2007	Piston As	419-4714
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923

49X		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

Sales Model D5B (Cont'd.)

49X		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259

49X		
Original Part Number	Part Name	Classic Part Number
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351

49X		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

5LD		
Original Part Number	Part Name	Classic Part Number
0R-1642	Hub-Gear	219-2976
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1L-7319	Cup-Roller Brg	380-7499
1M-7250	Bowl	360-2296
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173

5LD		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6421	Bearing-Outer	417-4510
2F-5721	Bearing-Ball	311-9354
2F-7576	Shaft-Sprocket	226-6071
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4507	Bearing-Sleeve	325-6021
2K-5804	Rod End-Spher	416-2151
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

5LD		
Original Part Number	Part Name	Classic Part Number
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7622	Bolt-Spring	226-4850
2P-9660	Gear	226-5995
2P-9672	Cage-Pinion Brg	226-7972
2S-1477	Holder As-Cage	226-7985
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3F-1972	Retainer As	226-7988
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3P-5754	Hub-Gear	219-2976
3S-3875	Screen-Suction	435-4849
3S-7153	Gear-Sliding	227-0024
3S-7504	Gear-Idler	226-6084
4D-2619	Bearing	417-4494

Sales Model D5B (Cont'd.)

5LD		
Original Part Number	Part Name	Classic Part Number
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-6189	Pinion-Reverse	226-6077
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4Y-0709	Disc-Friction	377-7431
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161
5F-0736	Pin-Pivot	256-4823
5H-5500	Collar-Fly Cl	302-2704
5L-6326	Bearing-Ball	420-3222

5LD		
Original Part Number	Part Name	Classic Part Number
5M-7342	Flange-Shaft	215-1696
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8767	Gear-First	226-6085
6B-5163	Bearing	417-4514
6B-7178	Fork-Band Adj	299-2009
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0169	Hub-Fly Clutch	297-7204
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7G-6044	Cage As	216-7857
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919

5LD		
Original Part Number	Part Name	Classic Part Number
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8K-5587	Rod Gp-Recoil	226-4954
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893

Sales Model D5B (Cont'd.)

5LD		
Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1324	Cage-Gr Shft Brg	229-8239
8P-1325	Hub-Ster Cl Dr	226-8005
8P-1326	Pilot-Cl Piston	226-6097
8P-1327	Pinion-Fdr	226-8000
8P-1774	Pinion-Fdr	226-8001
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950

5LD		
Original Part Number	Part Name	Classic Part Number
8P-8570	Pilot As-Cl Pstn	226-6097
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1831	Guard As-Sprkt	226-4947
8S-2140	Trunnion-Gear	226-8020
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-7670	Piston	226-4961
9J-2007	Piston As	419-4714
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-5477	Bearing-Sleeve	374-6517
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856

5LD		
Original Part Number	Part Name	Classic Part Number
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988

Sales Model D5B (Cont'd.)

5LD		
Original Part Number	**Part Name**	**Classic Part Number**
296-1360	Line As-Cla	279-4989

5LD		
Original Part Number	**Part Name**	**Classic Part Number**
328-5572	Bearing-Rod	419-6349

5LD		
Original Part Number	**Part Name**	**Classic Part Number**
334-8389	Crankshaft As	242-3439

8HD		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1642	Hub-Gear	219-2976
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1L-7319	Cup-Roller Brg	380-7499
1M-7250	Bowl	360-2296
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1T-0521	Retainer-Bearing	325-6180
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6421	Bearing-Outer	417-4510

8HD		
Original Part Number	**Part Name**	**Classic Part Number**
2F-5721	Bearing-Ball	311-9354
2F-7576	Shaft-Sprocket	226-6071
2K-4507	Bearing-Sleeve	325-6021
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7622	Bolt-Spring	226-4850
2P-9660	Gear	226-5995
2P-9672	Cage-Pinion Brg	226-7972
2S-1477	Holder As-Cage	226-7985
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3F-1972	Retainer As	226-7988
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989

8HD		
Original Part Number	**Part Name**	**Classic Part Number**
3P-5754	Hub-Gear	219-2976
3P-5955	Disc-Friction	428-7205
3S-1404	Bearing-Outer	417-4508
3S-3875	Screen-Suction	435-4849
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-2393	Bearing-Ball	380-1499
4F-5004	Spring As-Arm	383-2128
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5943	Piston-Clutch	221-9112
4S-8530	Shaft-Planet	221-9111
4S-8534	Shaft As-Planet	221-9116

Sales Model D5B (Cont'd.)

8HD		
Original Part Number	Part Name	Classic Part Number
4S-8538	Bearing-Spl Ball	417-4502
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4Y-0709	Disc-Friction	377-7431
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161
5F-0736	Pin-Pivot	256-4823
5L-6326	Bearing-Ball	420-3222
5M-2051	Bearing-Caged	380-7467
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-6978	Shaft-Planet	221-9103
5S-7010	Shaft-Planet	221-9104
5S-7630	Bearing-Sleeve	394-0219
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-2027	Disc-Friction	377-7441
6Y-3484	Bearing-Spl Ball	416-2166

8HD		
Original Part Number	Part Name	Classic Part Number
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-9547	Pin As.-Drawbar	295-0414
7G-2487	Gear-Planet	221-9092
7G-6044	Cage As	216-7857
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-9398	Plate-Guide	297-7230
7N-0165	Core As-O Clr	295-5670
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7S-8660	Pump Gp-Trans	226-0175
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016

8HD		
Original Part Number	Part Name	Classic Part Number
8K-5587	Rod Gp-Recoil	226-4954
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1324	Cage-Gr Shft Brg	229-8239
8P-1325	Hub-Ster Cl Dr	226-8005
8P-1326	Pilot-Cl Piston	226-6097
8P-1327	Pinion-Fdr	226-8000
8P-1656	Plate-Clutch	367-6071

Sales Model D5B (Cont'd.)

8HD		
Original Part Number	**Part Name**	**Classic Part Number**
8P-1774	Pinion-Fdr	226-8001
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8P-8570	Pilot As-Cl Pstn	226-6097
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1831	Guard As-Sprkt	226-4947
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9G-8302	Guide	226-4853
9H-7670	Piston	226-4961
9J-2007	Piston As	419-4714
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-2049	Gear-Ring	214-0533
9M-5477	Bearing-Sleeve	374-6517
9M-8281	Gear As-Pump	325-6089
9N-5403	Body As-Piston	250-6558
9S-2355	Manifold-Exhaust	261-0891
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

8HD		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
155-8694	Gasket Kit	451-1503
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353

8HD		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
235-0912	Tc Kit-Cla	235-0920
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

8MB		
Original Part Number	**Part Name**	**Classic Part Number**
3S-1404	Bearing-Outer	417-4508
4F-2393	Bearing-Ball	380-1499
4S-8538	Bearing-Spl Ball	417-4502
5D-7449	Cup-Spl Tapered	416-2161

8MB		
Original Part Number	**Part Name**	**Classic Part Number**
5M-2051	Bearing-Caged	380-7467
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
6Y-3484	Bearing-Spl Ball	416-2166

8MB		
Original Part Number	**Part Name**	**Classic Part Number**
7F-2742	Bearing-Ball	422-6488
8H-8175	Bearing-Sleeve	376-3636
155-8694	Gasket Kit	451-1503

Sales Model D5C

3MK		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947

3MK		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3W-8240	Bearing-Sleeve	425-6438
3W-8398	Bearing-Sleeve	379-0189
3Y-2768	Ring	439-4544
4D-4065	Rod End-Spher	374-1824
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5M-9644	Bearing-Outer	384-5929
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5V-1168	Spider & Brg As	377-7435
6H-3957	Bearing-Ball	311-9358
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-7968	Plate-Clutch	416-2133
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279

3MK		
Original Part Number	Part Name	Classic Part Number
6S-3442	Strip-Wear	386-4929
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444
6V-6896	Rebuild Kit	390-1006
6Y-2689	Coupler	422-3508
6Y-6832	Bearing-Rlr As	421-8181
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7F-2742	Bearing-Ball	422-6488
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-8893	Cone-Roller Brg	374-1846
7K-2135	Bearing-Roller	417-4492
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-1154	Bearing-Spl	417-4515
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4026	Pin As	394-0902
8E-5284	Bearing	388-0582
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-3443	Bearing	396-7281

Sales Model D5C (Cont'd.)

3MK		
Original Part Number	Part Name	Classic Part Number
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-6659	Spring-Recoil	422-7893
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266

3MK		
Original Part Number	Part Name	Classic Part Number
9M-1328	Bearing-Aligning	325-6018
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-6044	Shaft-Planet	384-5957

3MK		
Original Part Number	Part Name	Classic Part Number
9W-6046	Carrier As	388-0645
9Y-5168	Manifold-Exhaust	374-7483
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
150-0351	Spacer	396-7291
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

4WS		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384
2H-6489	Race-Brg Outer	374-8350
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3W-8240	Bearing-Sleeve	425-6438
3W-8398	Bearing-Sleeve	379-0189
3Y-2768	Ring	439-4544
4J-0121	Cap-Bearing	360-2344
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
5J-9348	Bearing As	416-2162
5M-5856	Pipe-Extension	373-1913

4WS		
Original Part Number	Part Name	Classic Part Number
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
6S-3442	Strip-Wear	386-4929
6S-3474	Pin As	375-9981
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
7G-4758	Gear-Planet	288-8723
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7K-9639	Bearing-Sleeve	314-8643
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816
7W-5164	Gasket	420-8568
8C-3111	Rod End-Spher	392-4523
8E-4026	Pin As	394-0902
8J-3443	Bearing	396-7281
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862

4WS		
Original Part Number	Part Name	Classic Part Number
8Y-6659	Spring-Recoil	422-7893
9J-2759	Trunnion	394-0216
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
9W-1677	Bearing	297-7145
101-3125	Gasket	420-8567
107-7473	Muffler As.	385-7223
121-7746	Pre-Cleaner As	360-2311
133-6597	Pipe-Extension	420-6220
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
160-6306	Cap-Bearing	325-6038
176-3900	Accumulator	416-5513
187-3307	Gasket As-Cyl	438-2022
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
308-1845	Seal-Wiper	472-8032
316-4396	Kit-Gasket (Sch)	393-3661

5HS		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939

Sales Model D5C (Cont'd.)

5HS		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
2H-6489	Race-Brg Outer	374-8350
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3W-8240	Bearing-Sleeve	425-6438
3W-8398	Bearing-Sleeve	379-0189
3Y-2768	Ring	439-4544
4J-5241	Retainer	434-1415
4T-8054	Seal As	472-8010
5J-9348	Bearing As	416-2162

5HS		
Original Part Number	**Part Name**	**Classic Part Number**
5M-5856	Pipe-Extension	373-1913
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
7G-4758	Gear-Planet	288-8723
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7M-7219	Bearing-Thrust	384-4816
8C-3111	Rod End-Spher	392-4523
8E-4026	Pin As	394-0902
8J-3443	Bearing	396-7281
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-6659	Spring-Recoil	422-7893

5HS		
Original Part Number	**Part Name**	**Classic Part Number**
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
107-7473	Muffler As.	385-7223
121-7746	Pre-Cleaner As	360-2311
133-6597	Pipe-Extension	420-6220
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
169-9527	Cyl Gp-0076-0352	430-5959
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

6CS		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4493	Cone-Spl Tapered	386-4939
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
2H-6489	Race-Brg Outer	374-8350
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3W-8240	Bearing-Sleeve	425-6438
3W-8398	Bearing-Sleeve	379-0189
3Y-2768	Ring	439-4544
4J-5241	Retainer	434-1415
4T-8054	Seal As	472-8010

6CS		
Original Part Number	**Part Name**	**Classic Part Number**
5J-9348	Bearing As	416-2162
5M-5856	Pipe-Extension	373-1913
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
7G-4758	Gear-Planet	288-8723
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7M-7219	Bearing-Thrust	384-4816
8C-3111	Rod End-Spher	392-4523
8E-4026	Pin As	394-0902
8J-3443	Bearing	396-7281
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-6659	Spring-Recoil	422-7893

6CS		
Original Part Number	**Part Name**	**Classic Part Number**
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
107-7473	Muffler As.	385-7223
121-7746	Pre-Cleaner As	360-2311
133-6597	Pipe-Extension	420-6220
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
169-9527	Cyl Gp-0076-0352	430-5959
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

6PJ		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849

Sales Model D5C (Cont'd.)

6PJ		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2H-6936	Disc-Steer Cl Dr	380-7471
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-8271	Arm As-Rocker	432-8912
3B-3967	Race-Roller Brg	386-4947
3G-8932	Pin	325-6143

6PJ		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3W-8240	Bearing-Sleeve	425-6438
3W-8398	Bearing-Sleeve	379-0189
3Y-2768	Ring	439-4544
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5V-1168	Spider & Brg As	377-7435
6H-3957	Bearing-Ball	311-9358
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-7968	Plate-Clutch	416-2133
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929

6PJ		
Original Part Number	Part Name	Classic Part Number
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444
6V-6896	Rebuild Kit	390-1006
6Y-2689	Coupler	422-3508
6Y-6832	Bearing-Rlr As	421-8181
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7C-7955	Gasket-Cover	382-6899
7F-2742	Bearing-Ball	422-6488
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9642	Bearing-Sleeve	360-2340
7M-1154	Bearing-Spl	417-4515
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4026	Pin As	394-0902
8E-5284	Bearing	388-0582
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-3443	Bearing	396-7281
8J-8809	Pump Gp-Gr -A	419-4653
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

Sales Model D5C (Cont'd.)

6PJ		
Original Part Number	Part Name	Classic Part Number
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8Y-6659	Spring-Recoil	422-7893
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9N-5246	Bearing-Camshaft	384-4772

6PJ		
Original Part Number	Part Name	Classic Part Number
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-1677	Bearing	297-7145
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645

6PJ		
Original Part Number	Part Name	Classic Part Number
9Y-5168	Manifold-Exhaust	374-7483
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
150-0351	Spacer	396-7291
160-6306	Cap-Bearing	325-6038
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

6ZL		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3W-8240	Bearing-Sleeve	425-6438
3W-8398	Bearing-Sleeve	379-0189
3Y-2768	Ring	439-4544

6ZL		
Original Part Number	Part Name	Classic Part Number
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5M-5856	Pipe-Extension	373-1913
5T-8739	Spider Gp-Brg&	373-5386
5V-1168	Spider & Brg As	377-7435
6H-3957	Bearing-Ball	311-9358
6K-8088	Bearing-Roller	399-4428
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6S-3397	Shaft-Ster Cl	388-6593
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444
6Y-6832	Bearing-Rlr As	421-8181
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925

6ZL		
Original Part Number	Part Name	Classic Part Number
7J-5131	Trunnion	296-1371
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
8E-4026	Pin As	394-0902
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-3443	Bearing	396-7281
8Y-6659	Spring-Recoil	422-7893
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-9431	Precleaner As	361-1718

Sales Model D5C (Cont'd.)

6ZL		
Original Part Number	Part Name	Classic Part Number
107-7473	Muffler As.	385-7223
121-7746	Pre-Cleaner As	360-2311
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285

6ZL		
Original Part Number	Part Name	Classic Part Number
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
169-9527	Cyl Gp-0076-0352	430-5959
176-3900	Accumulator	416-5513

6ZL		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

7PS		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
2H-6489	Race-Brg Outer	374-8350
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3W-8240	Bearing-Sleeve	425-6438
3W-8398	Bearing-Sleeve	379-0189
3Y-2768	Ring	439-4544
4J-5241	Retainer	434-1415
4T-8054	Seal As	472-8010

7PS		
Original Part Number	Part Name	Classic Part Number
5J-9348	Bearing As	416-2162
5M-5856	Pipe-Extension	373-1913
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
7G-4758	Gear-Planet	288-8723
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7M-7219	Bearing-Thrust	384-4816
8C-3111	Rod End-Spher	392-4523
8E-4026	Pin As	394-0902
8J-3443	Bearing	396-7281
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-6659	Spring-Recoil	422-7893

7PS		
Original Part Number	Part Name	Classic Part Number
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
107-7473	Muffler As.	385-7223
121-7746	Pre-Cleaner As	360-2311
133-6597	Pipe-Extension	420-6220
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
169-9527	Cyl Gp-0076-0352	430-5959
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

7YL		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413

7YL		
Original Part Number	Part Name	Classic Part Number
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
3B-3967	Race-Roller Brg	386-4947
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3W-8240	Bearing-Sleeve	425-6438

7YL		
Original Part Number	Part Name	Classic Part Number
3W-8398	Bearing-Sleeve	379-0189
3Y-2768	Ring	439-4544
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162

Sales Model D5C (Cont'd.)

7YL		
Original Part Number	Part Name	Classic Part Number
5M-5856	Pipe-Extension	373-1913
5T-8739	Spider Gp-Brg&	373-5386
5V-1168	Spider & Brg As	377-7435
6H-3957	Bearing-Ball	311-9358
6K-8088	Bearing-Roller	399-4428
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6S-3397	Shaft-Ster Cl	388-6593
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444
6Y-6832	Bearing-Rlr As	421-8181
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7G-7610	Gear-Ring	375-2625

7YL		
Original Part Number	Part Name	Classic Part Number
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
8E-4026	Pin As	394-0902
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-3443	Bearing	396-7281
8Y-6659	Spring-Recoil	422-7893
9J-9812	Bearing	434-7258

7YL		
Original Part Number	Part Name	Classic Part Number
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-1677	Bearing	297-7145
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-9431	Precleaner As	361-1718
107-7473	Muffler As.	385-7223
121-7746	Pre-Cleaner As	360-2311
133-6597	Pipe-Extension	420-6220
150-0351	Spacer	396-7291
160-6306	Cap-Bearing	325-6038
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

8ZS		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904

8ZS		
Original Part Number	Part Name	Classic Part Number
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3W-8240	Bearing-Sleeve	425-6438
3W-8398	Bearing-Sleeve	379-0189
3Y-2768	Ring	439-4544
4J-5241	Retainer	434-1415
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5M-5856	Pipe-Extension	373-1913
5T-8739	Spider Gp-Brg&	373-5386

8ZS		
Original Part Number	Part Name	Classic Part Number
5V-1168	Spider & Brg As	377-7435
6H-3957	Bearing-Ball	311-9358
6K-8088	Bearing-Roller	399-4428
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6S-3397	Shaft-Ster Cl	388-6593
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444
6Y-6832	Bearing-Rlr As	421-8181
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371

Sales Model D5C (Cont'd.)

8ZS		
Original Part Number	**Part Name**	**Classic Part Number**
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
8E-4026	Pin As	394-0902
8E-5284	Bearing	388-0582
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801

8ZS		
Original Part Number	**Part Name**	**Classic Part Number**
8J-3443	Bearing	396-7281
8Y-6659	Spring-Recoil	422-7893
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645

8ZS		
Original Part Number	**Part Name**	**Classic Part Number**
107-7473	Muffler As.	385-7223
121-7746	Pre-Cleaner As	360-2311
133-6597	Pipe-Extension	420-6220
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
169-9527	Cyl Gp-0076-0352	430-5959
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

9AS		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4493	Cone-Spl Tapered	386-4939
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
2H-6489	Race-Brg Outer	374-8350
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3W-8240	Bearing-Sleeve	425-6438
3W-8398	Bearing-Sleeve	379-0189
3Y-2768	Ring	439-4544
4J-5241	Retainer	434-1415
4T-8054	Seal As	472-8010

9AS		
Original Part Number	**Part Name**	**Classic Part Number**
5J-9348	Bearing As	416-2162
5M-5856	Pipe-Extension	373-1913
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
7G-4758	Gear-Planet	288-8723
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7M-7219	Bearing-Thrust	384-4816
8C-3111	Rod End-Spher	392-4523
8E-4026	Pin As	394-0902
8J-3443	Bearing	396-7281
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-6659	Spring-Recoil	422-7893

9AS		
Original Part Number	**Part Name**	**Classic Part Number**
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
107-7473	Muffler As.	385-7223
121-7746	Pre-Cleaner As	360-2311
133-6597	Pipe-Extension	420-6220
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
169-9527	Cyl Gp-0076-0352	430-5959
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

9DL		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1P-2636	Cup-Roller Brg	396-4147

9DL		
Original Part Number	**Part Name**	**Classic Part Number**
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

9DL		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413

Sales Model D5C (Cont'd.)

9DL		
Original Part Number	Part Name	Classic Part Number
2K-0227	Bearing-Sleeve	384-4780
2M-1086	Plate As-Press	226-8023
2M-8340	Rod End-Yoke	374-4678
2N-1599	Gear	378-3970
2S-7931	Bearing-Sleeve	387-2904
3B-3967	Race-Roller Brg	386-4947
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3W-8240	Bearing-Sleeve	425-6438
3W-8398	Bearing-Sleeve	379-0189
3Y-2768	Ring	439-4544
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4J-5241	Retainer	434-1415
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
5G-8708	Drum	384-4794
5J-9348	Bearing As	416-2162
5M-5856	Pipe-Extension	373-1913
5T-8739	Spider Gp-Brg&	373-5386
5V-1168	Spider & Brg As	377-7435

9DL		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6K-8088	Bearing-Roller	399-4428
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6S-3397	Shaft-Ster Cl	388-6593
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-1033	Rod End-Spher	375-5444
6Y-6832	Bearing-Rlr As	421-8181
6Y-7914	Disc-Friction	390-5264
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
8E-4026	Pin As	394-0902
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636

9DL		
Original Part Number	Part Name	Classic Part Number
8H-8898	Pin	385-3801
8J-3443	Bearing	396-7281
8Y-6659	Spring-Recoil	422-7893
9J-9812	Bearing	434-7258
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-7949	Cup-Roller Brg	420-6531
9W-1677	Bearing	297-7145
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-9431	Precleaner As	361-1718
107-7473	Muffler As.	385-7223
121-7746	Pre-Cleaner As	360-2311
133-6597	Pipe-Extension	420-6220
140-2382	Gasket Kit	390-5285
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
160-6306	Cap-Bearing	325-6038
169-9527	Cyl Gp-0076-0352	430-5959
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model D5E

9RG		
Original Part Number	Part Name	Classic Part Number
0R-1628	Hub-Gear	219-2977
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849

9RG		
Original Part Number	Part Name	Classic Part Number
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1L-7319	Cup-Roller Brg	380-7499

9RG		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046

Sales Model D5E (Cont'd.)

9RG		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4507	Bearing-Sleeve	325-6021
2K-5804	Rod End-Spher	416-2151
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

9RG		
Original Part Number	Part Name	Classic Part Number
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7622	Bolt-Spring	226-4850
2S-1477	Holder As-Cage	226-7985
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-1972	Retainer As	226-7988
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3S-3875	Screen-Suction	435-4849
3S-7153	Gear-Sliding	227-0024
3S-7504	Gear-Idler	226-6084
3S-8634	Hub-Gear	219-2977
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370

9RG		
Original Part Number	Part Name	Classic Part Number
4J-2592	Brace As	418-1928
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-4780	Strip As-Wear	299-2063
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-7982	Pulley	264-5880
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-6189	Pinion-Reverse	226-6077
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4Y-0709	Disc-Friction	377-7431
5A-9551	Gear-Finaldrive	226-7979
5D-7449	Cup-Spl Tapered	416-2161
5F-0736	Pin-Pivot	256-4823
5H-5500	Collar-Fly Cl	302-2704
5L-6326	Bearing-Ball	420-3222
5M-5856	Pipe-Extension	373-1913
5M-7342	Flange-Shaft	215-1696
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139

Sales Model D5E (Cont'd.)

9RG		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8767	Gear-First	226-6085
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0169	Hub-Fly Clutch	297-7204
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-3955	Bearing-Ball	417-9485
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7G-6044	Cage As	216-7857
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-9398	Plate-Guide	297-7230

9RG		
Original Part Number	Part Name	Classic Part Number
7N-0165	Core As-O Clr	295-5670
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-6868	Cyl Gp-040 405 X	430-5964
8K-5587	Rod Gp-Recoil	226-4954
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

9RG		
Original Part Number	Part Name	Classic Part Number
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1324	Cage-Gr Shft Brg	229-8239
8P-1325	Hub-Ster Cl Dr	226-8005
8P-1326	Pilot-Cl Piston	226-6097
8P-1327	Pinion-Fdr	226-8000
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8P-8570	Pilot As-Cl Pstn	226-6097
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198

Sales Model D5E (Cont'd.)

9RG		
Original Part Number	**Part Name**	**Classic Part Number**
8S-1831	Guard As-Sprkt	226-4947
8S-2140	Trunnion-Gear	226-8020
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-7670	Piston	226-4961
9J-2007	Piston As	419-4714
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244

9RG		
Original Part Number	**Part Name**	**Classic Part Number**
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
104-3014	Gasket Kit	388-0656
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
141-7277	Kit-Gasket-Fs	437-4610
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

9RG		
Original Part Number	**Part Name**	**Classic Part Number**
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model D5G

CLF		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4493	Cone-Spl Tapered	386-4939
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

CLF		
Original Part Number	**Part Name**	**Classic Part Number**
1S-3743	Bearing-Ball	384-4786
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947

CLF		
Original Part Number	**Part Name**	**Classic Part Number**
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5P-5354	Cup-Rlr Bearing	399-4445
6B-7469	Spacer	417-4535

Sales Model D5G (Cont'd.)

CLF		
Original Part Number	Part Name	Classic Part Number
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
7G-4758	Gear-Planet	288-8723
7K-9642	Bearing-Sleeve	360-2340

CLF		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
8T-0072	Cone-Rlr Brg	377-7448
8Y-6659	Spring-Recoil	422-7893
9J-9812	Bearing	434-7258
121-7746	Pre-Cleaner As	360-2311
141-2919	Rod As	399-8567

CLF		
Original Part Number	Part Name	Classic Part Number
150-0351	Spacer	396-7291
164-4413	Mount	419-0876
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
231-1591	Muffler As.	360-9625
308-1845	Seal-Wiper	472-8032

CLW		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947

CLW		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
7G-4758	Gear-Planet	288-8723
7M-7219	Bearing-Thrust	384-4816
8T-0072	Cone-Rlr Brg	377-7448
8Y-6659	Spring-Recoil	422-7893

CLW		
Original Part Number	Part Name	Classic Part Number
9J-9812	Bearing	434-7258
121-7746	Pre-Cleaner As	360-2311
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
164-4413	Mount	419-0876
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
231-1591	Muffler As.	360-9625
233-9204	Kit-Seal-H.Cyl-1	472-8025
308-1845	Seal-Wiper	472-8032

DKT		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947

DKT		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
7G-4758	Gear-Planet	288-8723
7K-9642	Bearing-Sleeve	360-2340

DKT		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
8T-0072	Cone-Rlr Brg	377-7448
8Y-6659	Spring-Recoil	422-7893
9J-9812	Bearing	434-7258
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
164-4413	Mount	419-0876
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
231-1591	Muffler As.	360-9625
308-1845	Seal-Wiper	472-8032

FDH		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939

FDH		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759

Sales Model D5G (Cont'd.)

FDH		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208

FDH		
Original Part Number	Part Name	Classic Part Number
3Y-2768	Ring	439-4544
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5P-5354	Cup-Rlr Bearing	399-4445
6B-7469	Spacer	417-4535
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
7G-4758	Gear-Planet	288-8723
7M-7219	Bearing-Thrust	384-4816

FDH		
Original Part Number	Part Name	Classic Part Number
8T-0072	Cone-Rlr Brg	377-7448
8Y-6659	Spring-Recoil	422-7893
9J-9812	Bearing	434-7258
121-7746	Pre-Cleaner As	360-2311
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
164-4413	Mount	419-0876
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
231-1591	Muffler As.	360-9625
308-1845	Seal-Wiper	472-8032

FDW		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947

FDW		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
7G-4758	Gear-Planet	288-8723
7M-7219	Bearing-Thrust	384-4816
8T-0072	Cone-Rlr Brg	377-7448
8Y-6659	Spring-Recoil	422-7893

FDW		
Original Part Number	Part Name	Classic Part Number
9J-9812	Bearing	434-7258
121-7746	Pre-Cleaner As	360-2311
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
164-4413	Mount	419-0876
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
231-1591	Muffler As.	360-9625
308-1845	Seal-Wiper	472-8032

RKG		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
2B-0941	Spacer	418-1955
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208

RKG		
Original Part Number	Part Name	Classic Part Number
3Y-2768	Ring	439-4544
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
7G-4758	Gear-Planet	288-8723
7M-7219	Bearing-Thrust	384-4816
8T-0072	Cone-Rlr Brg	377-7448

RKG		
Original Part Number	Part Name	Classic Part Number
8Y-6659	Spring-Recoil	422-7893
9J-9812	Bearing	434-7258
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
164-4413	Mount	419-0876
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
231-1591	Muffler As.	360-9625
308-1845	Seal-Wiper	472-8032

Sales Model D5G (Cont'd.)

RSC		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947

RSC		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
7G-4758	Gear-Planet	288-8723
7M-7219	Bearing-Thrust	384-4816
8T-0072	Cone-Rlr Brg	377-7448

RSC		
Original Part Number	Part Name	Classic Part Number
8Y-6659	Spring-Recoil	422-7893
9J-9812	Bearing	434-7258
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
164-4413	Mount	419-0876
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
231-1591	Muffler As.	360-9625
233-9204	Kit-Seal-H.Cyl-1	472-8025
308-1845	Seal-Wiper	472-8032

WGB		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
2H-6489	Race-Brg Outer	374-8350
2K-5069	Cup-Roller Brg	374-8346
2N-1599	Gear	378-3970
3B-3967	Race-Roller Brg	386-4947
3H-8726	Mount As	385-7208
3Y-2768	Ring	439-4544

WGB		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5P-5354	Cup-Rlr Bearing	399-4445
6S-3442	Strip-Wear	386-4929
6S-7220	Plate As	396-0657
6V-0330	Cup-Rlr Brg	422-6487
7G-4758	Gear-Planet	288-8723
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816

WGB		
Original Part Number	Part Name	Classic Part Number
8T-0072	Cone-Rlr Brg	377-7448
8Y-6659	Spring-Recoil	422-7893
9J-9812	Bearing	434-7258
141-2919	Rod As	399-8567
150-0351	Spacer	396-7291
164-4413	Mount	419-0876
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
231-1591	Muffler As.	360-9625
308-1845	Seal-Wiper	472-8032

Sales Model D5H

1DD		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761

1DD		
Original Part Number	Part Name	Classic Part Number
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0679	Roller-Freewheel	384-4797

1DD		
Original Part Number	Part Name	Classic Part Number
1T-0767	Bearing-Sleeve	383-2108
1T-0807	Race-Thrust Brg	453-3651
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-1625	Pump Gp-Gr A	421-1555
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

Sales Model D5H (Cont'd.)

1DD		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1438	Pipe-Exh Ext	325-6157
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356

1DD		
Original Part Number	Part Name	Classic Part Number
2W-1708	Ring-Piston	270-4357
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-3597	Muffler As	397-5044
2W-5540	Core As-Radiator	363-7452
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
3E-8905	Gasket Kit	393-3617
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8900	Pin	325-6140
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-2903	Cover	422-6922
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3T-2145	Carrier As	325-6041
3T-8904	Yoke As	443-2056
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3W-7770	Tube As	385-7227
4D-3882	Cone-Roller Brg	399-6060
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008

1DD		
Original Part Number	Part Name	Classic Part Number
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5G-3612	Cap Gp-Protn	295-6419
5K-8591	Bearing-Outer	380-7502
5P-3930	Bearing As-Rlr	419-6022
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

Sales Model D5H (Cont'd.)

1DD		
Original Part Number	Part Name	Classic Part Number
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6D-0217	Bearing-Sleeve	325-6022
6E-5449	Bearing-Sleeve	464-4048
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2899	Bearing-Sleeve	453-6505
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-1690	Carrier-Ring	384-3849
6Y-3484	Bearing-Spl Ball	416-2166

1DD		
Original Part Number	Part Name	Classic Part Number
6Y-4027	Pin	325-6148
6Y-5692	Plate-Brake	380-7492
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014
6Y-6236	Bearing-Sleeve	325-6024
6Y-6582	Plate-Wear	419-2307
6Y-6775	Pin	325-6151
6Y-8248	Pin	325-6154
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-8225	Seal-Ring	472-8016
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5444	Carrier-Planet	297-7165
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7G-9555	Univ Joint As	314-8721
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887

1DD		
Original Part Number	Part Name	Classic Part Number
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7T-2036	Cap As-Fuel	361-1721
7T-4752	Turbine-Conv	416-2148
7T-4753	Stator-Converter	384-5945
7T-4754	Impeller-Conv	385-7231
7V-0638	Spacer	425-3651
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8D-0983	Mounting	384-3470
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8G-3102	Piston	325-6162
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893

Sales Model D5H (Cont'd.)

1DD		
Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8P-8677	Hub-Impeller	297-7205
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372

1DD		
Original Part Number	Part Name	Classic Part Number
8T-1177	Bearing-Rlr	419-1862
8T-1606	Kit-Gskt-Sch	386-3046
8T-9486	Gasket Kt	393-5197
8Y-1198	Strip	325-6220
8Y-1199	Strip	325-6221
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9J-2365	Retainer	325-6186
9J-2759	Trunnion	394-0216
9J-3206	Bearing-Spher	360-2275
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9P-9507	Race-Thrust	371-4309
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5279	Bearing-Inner	453-3661
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-8384	Hub-Turbine	297-7207
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583

1DD		
Original Part Number	Part Name	Classic Part Number
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-8250	Carrier-Seal	421-7830
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
139-9179	Gasket Kit	390-5289
147-1012	Gasket Kit	434-7263
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
174-0739	Gasket Kit - F	437-2012
174-6836	Gasket Kit - Tof	434-7280
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-2380	Shaft As.-Input	399-4432
206-6405	Bearing-Spl Ball	420-2503
207-8176	Cover-Xmsn	420-3218
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
234-8013	Kit-Gasket-Sch	437-8650
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892

Sales Model D5H (Cont'd.)

1DD		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028

1DD		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032

1DD		
Original Part Number	Part Name	Classic Part Number
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
374-1849	Brg-Rlr-Cla	399-4442

1YD		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race-Thrust Brg	453-3651
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659

1YD		
Original Part Number	Part Name	Classic Part Number
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1438	Pipe-Exh Ext	325-6157
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-3597	Muffler As	397-5044

1YD		
Original Part Number	Part Name	Classic Part Number
2W-5536	Core As-Radiator	380-7554
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8900	Pin	325-6140
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-2903	Cover	422-6922
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3T-1162	Sleeve-Wear	325-6209
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-7770	Tube As	385-7227
4D-3882	Cone-Roller Brg	399-6060
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

Sales Model D5H (Cont'd.)

1YD		
Original Part Number	Part Name	Classic Part Number
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883

1YD		
Original Part Number	Part Name	Classic Part Number
5T-1362	Univ Joint As-5C	325-6011
6B-7469	Spacer	417-4535
6D-0217	Bearing-Sleeve	325-6022
6E-5449	Bearing-Sleeve	464-4048
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2899	Bearing-Sleeve	453-6505
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4027	Pin	325-6148
6Y-5692	Plate-Brake	380-7492
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014
6Y-6236	Bearing-Sleeve	325-6024
6Y-6582	Plate-Wear	419-2307
6Y-6775	Pin	325-6151
6Y-7652	Cup-Rlr Brg	399-6067
6Y-8037	Guide As	435-9915
6Y-8248	Pin	325-6154
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-8225	Seal-Ring	472-8016

1YD		
Original Part Number	Part Name	Classic Part Number
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7V-0638	Spacer	425-3651
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277

Sales Model D5H (Cont'd.)

1YD		
Original Part Number	Part Name	Classic Part Number
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
8D-0983	Mounting	384-3470
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8G-3102	Piston	325-6162
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464

1YD		
Original Part Number	Part Name	Classic Part Number
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
8T-1606	Kit-Gskt-Sch	386-3046
8Y-1198	Strip	325-6220
8Y-1199	Strip	325-6221
9J-2365	Retainer	325-6186
9J-2759	Trunnion	394-0216
9J-3206	Bearing-Spher	360-2275
9J-5284	Bearing-Sleeve	380-7379
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5279	Bearing-Inner	453-3661
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-1677	Bearing	297-7145
9W-9930	Mount As	295-6437

1YD		
Original Part Number	Part Name	Classic Part Number
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
030-1957	Cone-Bearing	420-2502
100-7860	Valve-Inlet	270-4360
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
141-7274	Gasket Kit	418-1951
141-7277	Kit-Gasket-Fs	437-4610
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
174-6836	Gasket Kit - Tof	434-7280

Sales Model D5H (Cont'd.)

1YD		
Original Part Number	**Part Name**	**Classic Part Number**
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	270-4351

1YD		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989

1YD		
Original Part Number	**Part Name**	**Classic Part Number**
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
374-1849	Brg-Rlr-Cla	399-4442

2SD		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race-Thrust Brg	453-3651
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5036	Bracket As-Fan	425-1210

2SD		
Original Part Number	**Part Name**	**Classic Part Number**
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1438	Pipe-Exh Ext	325-6157
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357

2SD		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-3597	Muffler As	397-5044
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3G-6313	Bearing	325-6007
3G-8900	Pin	325-6140
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-2903	Cover	422-6922
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961
3J-6559	Cap-Bearing	296-1346
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3W-7770	Tube As	385-7227
4D-3882	Cone-Roller Brg	399-6060
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-5241	Retainer	434-1415
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764

Sales Model D5H (Cont'd.)

2SD		
Original Part Number	Part Name	Classic Part Number
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4T-9290	Cyl Gp-0152 0495	399-8579
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502

2SD		
Original Part Number	Part Name	Classic Part Number
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-1362	Univ Joint As-5C	325-6011
6B-7469	Spacer	417-4535
6D-0217	Bearing-Sleeve	325-6022
6E-5449	Bearing-Sleeve	464-4048
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2899	Bearing-Sleeve	453-6505
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4027	Pin	325-6148
6Y-5692	Plate-Brake	380-7492
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014

2SD		
Original Part Number	Part Name	Classic Part Number
6Y-6236	Bearing-Sleeve	325-6024
6Y-6582	Plate-Wear	419-2307
6Y-6775	Pin	325-6151
6Y-7652	Cup-Rlr Brg	399-6067
6Y-8248	Pin	325-6154
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-8225	Seal-Ring	472-8016
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9842	Bearing-Sleeve	299-1968
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409

Sales Model D5H (Cont'd.)

2SD		
Original Part Number	Part Name	Classic Part Number
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7V-0638	Spacer	425-3651
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
8D-0983	Mounting	384-3470
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8G-3102	Piston	325-6162
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210

2SD		
Original Part Number	Part Name	Classic Part Number
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
8T-1606	Kit-Gskt-Sch	386-3046
8Y-1198	Strip	325-6220
8Y-1199	Strip	325-6221
9J-2365	Retainer	325-6186
9J-2759	Trunnion	394-0216
9J-3206	Bearing-Spher	360-2275
9J-5284	Bearing-Sleeve	380-7379
9J-5875	Bearing-Sleeve	308-9830
9M-1328	Bearing-Aligning	325-6018

2SD		
Original Part Number	Part Name	Classic Part Number
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5279	Bearing-Inner	453-3661
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-1677	Bearing	297-7145
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
030-1957	Cone-Bearing	420-2502
100-7860	Valve-Inlet	270-4360
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
141-7274	Gasket Kit	418-1951
141-7277	Kit-Gasket-Fs	437-4610
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

Sales Model D5H (Cont'd.)

2SD		
Original Part Number	Part Name	Classic Part Number
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365

2SD		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351

2SD		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
374-1849	Brg-Rlr-Cla	399-4442

3MD		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-7115	Mount As	418-1936
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0679	Roller-Freewheel	384-4797
1T-0767	Bearing-Sleeve	383-2108
1T-0807	Race-Thrust Brg	453-3651
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

3MD		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1438	Pipe-Exh Ext	325-6157
2P-1757	Hub-Fan Pulley	296-1357

3MD		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-3597	Muffler As	397-5044
2W-5536	Core As-Radiator	380-7554
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8900	Pin	325-6140
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-2903	Cover	422-6922
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436

Sales Model D5H (Cont'd.)

3MD		
Original Part Number	Part Name	Classic Part Number
3L-9410	Cone-Spl Tapered	391-9899
3T-2145	Carrier As	325-6041
3T-8904	Yoke As	443-2056
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3W-7770	Tube As	385-7227
4D-3882	Cone-Roller Brg	399-6060
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-6559	Tube	325-6234

3MD		
Original Part Number	Part Name	Classic Part Number
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-8643	Bearing-Sleeve	374-8354
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5G-3612	Cap Gp-Protn	295-6419
5K-8591	Bearing-Outer	380-7502
5P-3930	Bearing As-Rlr	419-6022
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6D-0217	Bearing-Sleeve	325-6022
6E-5449	Bearing-Sleeve	464-4048
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2899	Bearing-Sleeve	453-6505
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886

3MD		
Original Part Number	Part Name	Classic Part Number
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-1690	Carrier-Ring	384-3849
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4027	Pin	325-6148
6Y-5692	Plate-Brake	380-7492
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014
6Y-6236	Bearing-Sleeve	325-6024
6Y-6582	Plate-Wear	419-2307
6Y-6775	Pin	325-6151
6Y-8248	Pin	325-6154
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-8225	Seal-Ring	472-8016
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-9980	Camshaft	377-5851

Sales Model D5H (Cont'd.)

3MD		
Original Part Number	Part Name	Classic Part Number
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5444	Carrier-Planet	297-7165
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7G-9555	Univ Joint As	314-8721
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7T-2036	Cap As-Fuel	361-1721
7T-4752	Turbine-Conv	416-2148
7T-4753	Stator-Converter	384-5945
7T-4754	Impeller-Conv	385-7231
7V-0638	Spacer	425-3651

3MD		
Original Part Number	Part Name	Classic Part Number
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
8D-0983	Mounting	384-3470
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8G-3102	Piston	325-6162
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

3MD		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8P-8677	Hub-Impeller	297-7205
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
8T-1606	Kit-Gskt-Sch	386-3046
8Y-1198	Strip	325-6220
8Y-1199	Strip	325-6221
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9J-2365	Retainer	325-6186
9J-2759	Trunnion	394-0216
9J-3206	Bearing-Spher	360-2275
9J-5284	Bearing-Sleeve	380-7379
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050

Sales Model D5H (Cont'd.)

3MD		
Original Part Number	Part Name	Classic Part Number
9P-9507	Race-Thrust	371-4309
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5279	Bearing-Inner	453-3661
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-0517	Carrier-Planet	281-1686
9W-1677	Bearing	297-7145
9W-8384	Hub-Turbine	297-7207
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-8250	Carrier-Seal	421-7830
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311

3MD		
Original Part Number	Part Name	Classic Part Number
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
139-9179	Gasket Kit	390-5289
141-7274	Gasket Kit	418-1951
141-7277	Kit-Gasket-Fs	437-4610
147-1012	Gasket Kit	434-7263
148-7455	Valve - Exhaust	270-4361
148-9810	Gasket Kit	393-3631
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

3MD		
Original Part Number	Part Name	Classic Part Number
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-2380	Shaft As.-Input	399-4432
206-6405	Bearing-Spl Ball	420-2503
207-8176	Cover-Xmsn	420-3218
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
374-1849	Brg-Rlr-Cla	399-4442

4KD		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913

4KD		
Original Part Number	Part Name	Classic Part Number
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0679	Roller-Freewheel	384-4797
1T-0767	Bearing-Sleeve	383-2108
1T-0807	Race-Thrust Brg	453-3651
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924

4KD		
Original Part Number	Part Name	Classic Part Number
1T-1282	Race-Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5036	Bracket As-Fan	425-1210

Sales Model D5H (Cont'd.)

4KD		
Original Part Number	Part Name	Classic Part Number
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1438	Pipe-Exh Ext	325-6157
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-3597	Muffler As	397-5044
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818

4KD		
Original Part Number	Part Name	Classic Part Number
3F-6612	Cap-Ball Joint	297-7155
3G-6313	Bearing	325-6007
3G-8900	Pin	325-6140
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-2903	Cover	422-6922
3J-6559	Cap-Bearing	296-1346
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3T-2145	Carrier As	325-6041
3T-8904	Yoke As	443-2056
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3W-7770	Tube As	385-7227
4D-3882	Cone-Roller Brg	399-6060
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

4KD		
Original Part Number	Part Name	Classic Part Number
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5G-3612	Cap Gp-Protn	295-6419
5K-8591	Bearing-Outer	380-7502
5M-9644	Bearing-Outer	384-5929
5P-3930	Bearing As-Rlr	419-6022
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6D-0217	Bearing-Sleeve	325-6022
6E-5449	Bearing-Sleeve	464-4048

Sales Model D5H (Cont'd.)

4KD		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2899	Bearing-Sleeve	453-6505
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6S-3442	Strip-Wear	386-4929
6T-5383	Gear-Ring	375-2624
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-1690	Carrier-Ring	384-3849
6Y-2689	Coupler	422-3508
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4027	Pin	325-6148
6Y-5692	Plate-Brake	380-7492
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014
6Y-6236	Bearing-Sleeve	325-6024

4KD		
Original Part Number	Part Name	Classic Part Number
6Y-6582	Plate-Wear	419-2307
6Y-6775	Pin	325-6151
6Y-7934	Disc-Friction	384-5937
6Y-8248	Pin	325-6154
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-8225	Seal-Ring	472-8016
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5444	Carrier-Planet	297-7165
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7G-9555	Univ Joint As	314-8721
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-1154	Bearing-Spl	417-4515
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994

4KD		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7T-2036	Cap As-Fuel	361-1721
7T-4752	Turbine-Conv	416-2148
7T-4753	Stator-Converter	384-5945
7T-4754	Impeller-Conv	385-7231
7V-0638	Spacer	425-3651
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
8D-0983	Mounting	384-3470
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8G-3102	Piston	325-6162
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381

Sales Model D5H (Cont'd.)

4KD		
Original Part Number	Part Name	Classic Part Number
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8P-8677	Hub-Impeller	297-7205
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
8T-1606	Kit-Gskt-Sch	386-3046
8Y-1198	Strip	325-6220
8Y-1199	Strip	325-6221

4KD		
Original Part Number	Part Name	Classic Part Number
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9J-2365	Retainer	325-6186
9J-2759	Trunnion	394-0216
9J-3206	Bearing-Spher	360-2275
9J-5284	Bearing-Sleeve	380-7379
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9P-6903	Plate	368-0108
9P-9507	Race-Thrust	371-4309
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5279	Bearing-Inner	453-3661
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-0517	Carrier-Planet	281-1686
9W-8384	Hub-Turbine	297-7207
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-8250	Carrier-Seal	421-7830
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296

4KD		
Original Part Number	Part Name	Classic Part Number
139-9179	Gasket Kit	390-5289
141-7274	Gasket Kit	418-1951
141-7277	Kit-Gasket-Fs	437-4610
147-1012	Gasket Kit	434-7263
148-7455	Valve - Exhaust	270-4361
148-9810	Gasket Kit	393-3631
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-2380	Shaft As.-Input	399-4432
206-6405	Bearing-Spl Ball	420-2503
207-8176	Cover-Xmsn	420-3218
226-0930	Gear-Transfer	394-0888
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
296-1359	Line As-Cla	279-4988

Sales Model D5H (Cont'd.)

4KD		
Original Part Number	Part Name	Classic Part Number
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032

4KD		
Original Part Number	Part Name	Classic Part Number
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

4KD		
Original Part Number	Part Name	Classic Part Number
337-0872	Crankshaft As	242-3440
374-1849	Brg-Rlr-Cla	399-4442

7NC		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race-Thrust Brg	453-3651
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173

7NC		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1438	Pipe-Exh Ext	325-6157
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-3597	Muffler As	397-5044
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694

7NC		
Original Part Number	Part Name	Classic Part Number
3G-6313	Bearing	325-6007
3G-8900	Pin	325-6140
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-2903	Cover	422-6922
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3W-7770	Tube As	385-7227
4D-3882	Cone-Roller Brg	399-6060
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

Sales Model D5H (Cont'd.)

7NC		
Original Part Number	Part Name	Classic Part Number
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-1362	Univ Joint As-5C	325-6011
6B-7469	Spacer	417-4535
6D-0217	Bearing-Sleeve	325-6022
6E-5449	Bearing-Sleeve	464-4048
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475

7NC		
Original Part Number	Part Name	Classic Part Number
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2899	Bearing-Sleeve	453-6505
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4027	Pin	325-6148
6Y-5692	Plate-Brake	380-7492
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014
6Y-6236	Bearing-Sleeve	325-6024
6Y-6582	Plate-Wear	419-2307
6Y-6775	Pin	325-6151
6Y-7652	Cup-Rlr Brg	399-6067
6Y-8248	Pin	325-6154
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-8225	Seal-Ring	472-8016
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-6461	Crown	325-6054

7NC		
Original Part Number	Part Name	Classic Part Number
7J-8893	Cone-Roller Brg	374-1846
7J-9682	Bearing-Sleeve	360-2335
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7V-0638	Spacer	425-3651
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8D-0983	Mounting	384-3470
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8G-3102	Piston	325-6162
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113

Sales Model D5H (Cont'd.)

7NC		
Original Part Number	Part Name	Classic Part Number
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

7NC		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
8T-1606	Kit-Gskt-Sch	386-3046
8T-9486	Gasket Kt	393-5197
8Y-1198	Strip	325-6220
8Y-1199	Strip	325-6221
9J-2365	Retainer	325-6186
9J-2759	Trunnion	394-0216
9J-3206	Bearing-Spher	360-2275
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5279	Bearing-Inner	453-3661
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-0099	Bearing-Sleeve	314-8639
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926

7NC		
Original Part Number	Part Name	Classic Part Number
030-0061	Bearing-Cone	418-9605
030-1957	Cone-Bearing	420-2502
100-7860	Valve-Inlet	270-4360
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
174-0739	Gasket Kit - F	437-2012
174-6836	Gasket Kit - Tof	434-7280
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
234-8013	Kit-Gasket-Sch	437-8650
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357

Sales Model D5H (Cont'd.)

7NC		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988

7NC		
Original Part Number	Part Name	Classic Part Number
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349

7NC		
Original Part Number	Part Name	Classic Part Number
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
374-1849	Brg-Rlr-Cla	399-4442

8RC		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0679	Roller-Freewheel	384-4797
1T-0767	Bearing-Sleeve	383-2108
1T-0807	Race-Thrust Brg	453-3651
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981

8RC		
Original Part Number	Part Name	Classic Part Number
1W-4407	Hub-Fan Pulley	296-1358
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1438	Pipe-Exh Ext	325-6157
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357

8RC		
Original Part Number	Part Name	Classic Part Number
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-3597	Muffler As	397-5044
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8900	Pin	325-6140
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-2903	Cover	422-6922
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3T-2145	Carrier As	325-6041
3T-8904	Yoke As	443-2056
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3W-7770	Tube As	385-7227
4D-3882	Cone-Roller Brg	399-6060
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710

Sales Model D5H (Cont'd.)

8RC		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5G-3612	Cap Gp-Protn	295-6419
5K-8591	Bearing-Outer	380-7502
5P-3930	Bearing As-Rlr	419-6022
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467

8RC		
Original Part Number	Part Name	Classic Part Number
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6D-0217	Bearing-Sleeve	325-6022
6E-5449	Bearing-Sleeve	464-4048
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2899	Bearing-Sleeve	453-6505
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104

8RC		
Original Part Number	Part Name	Classic Part Number
6Y-1690	Carrier-Ring	384-3849
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4027	Pin	325-6148
6Y-5692	Plate-Brake	380-7492
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014
6Y-6236	Bearing-Sleeve	325-6024
6Y-6582	Plate-Wear	419-2307
6Y-6775	Pin	325-6151
6Y-8248	Pin	325-6154
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-8225	Seal-Ring	472-8016
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5444	Carrier-Planet	297-7165
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7G-9555	Univ Joint As	314-8721
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994

Sales Model D5H (Cont'd.)

8RC		
Original Part Number	Part Name	Classic Part Number
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7T-2036	Cap As-Fuel	361-1721
7T-4752	Turbine-Conv	416-2148
7T-4753	Stator-Converter	384-5945
7T-4754	Impeller-Conv	385-7231
7V-0638	Spacer	425-3651
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8D-0983	Mounting	384-3470
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8G-3102	Piston	325-6162
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801

8RC		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8P-8677	Hub-Impeller	297-7205

8RC		
Original Part Number	Part Name	Classic Part Number
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
8T-1606	Kit-Gskt-Sch	386-3046
8T-9486	Gasket Kt	393-5197
8Y-1198	Strip	325-6220
8Y-1199	Strip	325-6221
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9J-2365	Retainer	325-6186
9J-2759	Trunnion	394-0216
9J-3206	Bearing-Spher	360-2275
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9P-9507	Race-Thrust	371-4309
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5279	Bearing-Inner	453-3661
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-8384	Hub-Turbine	297-7207
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

Sales Model D5H (Cont'd.)

8RC		
Original Part Number	**Part Name**	**Classic Part Number**
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-8250	Carrier-Seal	421-7830
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
139-9179	Gasket Kit	390-5289
147-1012	Gasket Kit	434-7263
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

8RC		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
174-0739	Gasket Kit - F	437-2012
174-6836	Gasket Kit - Tof	434-7280
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-2380	Shaft As.-Input	399-4432
206-6405	Bearing-Spl Ball	420-2503

8RC		
Original Part Number	**Part Name**	**Classic Part Number**
207-8176	Cover-Xmsn	420-3218
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
234-8013	Kit-Gasket-Sch	437-8650
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
374-1849	Brg-Rlr-Cla	399-4442

8RJ		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294

8RJ		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0767	Bearing-Sleeve	383-2108
1T-0807	Race-Thrust Brg	453-3651
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5036	Bracket As-Fan	425-1210

8RJ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342

Sales Model D5H (Cont'd.)

8RJ		
Original Part Number	Part Name	Classic Part Number
2P-1170	Shaft As-Gear	296-1367
2P-1438	Pipe-Exh Ext	325-6157
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-3597	Muffler As	397-5044
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8900	Pin	325-6140
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-2903	Cover	422-6922
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3T-2145	Carrier As	325-6041
3T-8904	Yoke As	443-2056
3T-9960	Disc-Friction	417-9487
3W-7770	Tube As	385-7227
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633

8RJ		
Original Part Number	Part Name	Classic Part Number
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534

8RJ		
Original Part Number	Part Name	Classic Part Number
4W-9655	Support	419-0882
5G-3612	Cap Gp-Protn	295-6419
5K-8591	Bearing-Outer	380-7502
5P-3930	Bearing As-Rlr	419-6022
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6D-0217	Bearing-Sleeve	325-6022
6E-5449	Bearing-Sleeve	464-4048
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-1033	Rod End-Spher	375-5444

Sales Model D5H (Cont'd.)

8RJ		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-1690	Carrier-Ring	384-3849
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4027	Pin	325-6148
6Y-5692	Plate-Brake	380-7492
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014
6Y-6236	Bearing-Sleeve	325-6024
6Y-6582	Plate-Wear	419-2307
6Y-6775	Pin	325-6151
6Y-8248	Pin	325-6154
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8225	Seal-Ring	472-8016
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5444	Carrier-Planet	297-7165
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7G-9555	Univ Joint As	314-8721
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7J-9884	Bearing-Sleeve	325-6016

8RJ		
Original Part Number	Part Name	Classic Part Number
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7T-2036	Cap As-Fuel	361-1721
7T-4752	Turbine-Conv	416-2148
7T-4753	Stator-Converter	384-5945
7T-4754	Impeller-Conv	385-7231
7V-0638	Spacer	425-3651
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8D-0983	Mounting	384-3470
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8G-3102	Piston	325-6162
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442

8RJ		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048

Sales Model D5H (Cont'd.)

8RJ		
Original Part Number	Part Name	Classic Part Number
8P-8677	Hub-Impeller	297-7205
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
8T-1606	Kit-Gskt-Sch	386-3046
8T-9486	Gasket Kt	393-5197
8Y-1198	Strip	325-6220
8Y-1199	Strip	325-6221
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9J-2365	Retainer	325-6186
9J-2759	Trunnion	394-0216
9J-3206	Bearing-Spher	360-2275
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-9507	Race-Thrust	371-4309
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5279	Bearing-Inner	453-3661
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-2579	Plate	314-8701

8RJ		
Original Part Number	Part Name	Classic Part Number
9W-8384	Hub-Turbine	297-7207
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-8250	Carrier-Seal	421-7830
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
139-9179	Gasket Kit	390-5289
147-1012	Gasket Kit	434-7263
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127

8RJ		
Original Part Number	Part Name	Classic Part Number
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
174-6836	Gasket Kit - Tof	434-7280
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-2380	Shaft As.-Input	399-4432
206-6405	Bearing-Spl Ball	420-2503
207-8176	Cover-Xmsn	420-3218
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
374-1849	Brg-Rlr-Cla	399-4442

8SC		
Original Part Number	Part Name	Classic Part Number
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1282	Race-Brg Thrust	373-1755
3L-9410	Cone-Spl Tapered	391-9899

8SC		
Original Part Number	Part Name	Classic Part Number
5K-8591	Bearing-Outer	380-7502
5P-3930	Bearing As-Rlr	419-6022
5P-5167	Race-Brg Outer	417-4529
6V-0456	Bearing As-Rlr	435-4041

8SC		
Original Part Number	Part Name	Classic Part Number
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-0306	Bearing-Sleeve	391-1104
6Y-3484	Bearing-Spl Ball	416-2166

Sales Model D5H (Cont'd.)

8SC		
Original Part Number	Part Name	Classic Part Number
7B-7515	Bearing-Ball	399-6059
7F-2742	Bearing-Ball	422-6488
7S-4534	Bearing-Caged	417-9497
9M-4370	Bearing-Sleeve	453-6515

8SC		
Original Part Number	Part Name	Classic Part Number
9P-9507	Race-Thrust	371-4309
136-7813	Bearing-Race	460-8296
147-1012	Gasket Kit	434-7263

8SC		
Original Part Number	Part Name	Classic Part Number
206-6405	Bearing-Spl Ball	420-2503
292-5516	Kit-Dt Gasket	391-9885

9HC		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race-Thrust Brg	453-3651
1U-1625	Pump Gp-Gr A	421-1555
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5036	Bracket As-Fan	425-1210

9HC		
Original Part Number	Part Name	Classic Part Number
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1438	Pipe-Exh Ext	325-6157
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357

9HC		
Original Part Number	Part Name	Classic Part Number
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-3597	Muffler As	397-5044
2W-5540	Core As-Radiator	363-7452
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8900	Pin	325-6140
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-2903	Cover	422-6922
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3W-7770	Tube As	385-7227
4D-3882	Cone-Roller Brg	399-6060
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

Sales Model D5H (Cont'd.)

9HC		
Original Part Number	Part Name	Classic Part Number
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5G-3612	Cap Gp-Protn	295-6419
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437

9HC		
Original Part Number	Part Name	Classic Part Number
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-1362	Univ Joint As-5C	325-6011
6B-7469	Spacer	417-4535
6D-0217	Bearing-Sleeve	325-6022
6E-5449	Bearing-Sleeve	464-4048
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2899	Bearing-Sleeve	453-6505
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4027	Pin	325-6148
6Y-5692	Plate-Brake	380-7492
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014
6Y-6236	Bearing-Sleeve	325-6024
6Y-6582	Plate-Wear	419-2307
6Y-6775	Pin	325-6151
6Y-7652	Cup-Rlr Brg	399-6067
6Y-8248	Pin	325-6154
7C-0307	Gasket	399-8571
7C-2880	Bell As-Suction	380-1520

9HC		
Original Part Number	Part Name	Classic Part Number
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-8225	Seal-Ring	472-8016
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9682	Bearing-Sleeve	360-2335
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7V-0638	Spacer	425-3651
7W-0508	Gear-Fp Drive	296-1351

Sales Model D5H (Cont'd.)

9HC		
Original Part Number	Part Name	Classic Part Number
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8D-0983	Mounting	384-3470
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8G-3102	Piston	325-6162
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464

9HC		
Original Part Number	Part Name	Classic Part Number
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
8T-1606	Kit-Gskt-Sch	386-3046
8T-9486	Gasket Kt	393-5197
8Y-1198	Strip	325-6220
8Y-1199	Strip	325-6221
9J-2365	Retainer	325-6186
9J-2759	Trunnion	394-0216
9J-3206	Bearing-Spher	360-2275
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5279	Bearing-Inner	453-3661
9S-7788	Ring-Piston	461-5124

9HC		
Original Part Number	Part Name	Classic Part Number
9S-8679	Chamber As	325-6042
9W-0099	Bearing-Sleeve	314-8639
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
030-1957	Cone-Bearing	420-2502
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

Sales Model D5H (Cont'd.)

9HC		
Original Part Number	Part Name	Classic Part Number
172-7767	Pump Gp-Water -B	296-1365
174-0739	Gasket Kit - F	437-2012
174-6836	Gasket Kit - Tof	434-7280
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085

9HC		
Original Part Number	Part Name	Classic Part Number
234-8013	Kit-Gasket-Sch	437-8650
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028

9HC		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
374-1849	Brg-Rlr-Cla	399-4442

Sales Model D5K

JLF		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346

JLF		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6S-3474	Pin As	375-9981
6V-0330	Cup-Rlr Brg	422-6487
7K-9642	Bearing-Sleeve	360-2340
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1432	Carrier-Planet	314-8659

JLF		
Original Part Number	Part Name	Classic Part Number
8T-0072	Cone-Rlr Brg	377-7448
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

KW2		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955

KW2		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
4T-8054	Seal As	472-8010
6V-0330	Cup-Rlr Brg	422-6487
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
8T-0072	Cone-Rlr Brg	377-7448

KW2		
Original Part Number	Part Name	Classic Part Number
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

RRE		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955

RRE		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
4T-8054	Seal As	472-8010
6V-0330	Cup-Rlr Brg	422-6487
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
8T-0072	Cone-Rlr Brg	377-7448

RRE		
Original Part Number	Part Name	Classic Part Number
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

Sales Model D5K (Cont'd.)

WT3		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955

WT3		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
4T-8054	Seal As	472-8010
6V-0330	Cup-Rlr Brg	422-6487
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
8T-0072	Cone-Rlr Brg	377-7448

WT3		
Original Part Number	Part Name	Classic Part Number
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

WWW		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955
2K-5069	Cup-Roller Brg	374-8346

WWW		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6V-0330	Cup-Rlr Brg	422-6487
7K-9642	Bearing-Sleeve	360-2340
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1432	Carrier-Planet	314-8659

WWW		
Original Part Number	Part Name	Classic Part Number
8T-0072	Cone-Rlr Brg	377-7448
9J-9812	Bearing	434-7258
121-7746	Pre-Cleaner As	360-2311
150-0351	Spacer	396-7291
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

YT3		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955

YT3		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
4T-8054	Seal As	472-8010
6V-0330	Cup-Rlr Brg	422-6487
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
8T-0072	Cone-Rlr Brg	377-7448

YT3		
Original Part Number	Part Name	Classic Part Number
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

YYY		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955
2K-5069	Cup-Roller Brg	374-8346

YYY		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6V-0330	Cup-Rlr Brg	422-6487
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1432	Carrier-Planet	314-8659
8T-0072	Cone-Rlr Brg	377-7448

YYY		
Original Part Number	Part Name	Classic Part Number
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

Sales Model D5K2

KWW		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2K-5069	Cup-Roller Brg	374-8346

KWW		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6V-0330	Cup-Rlr Brg	422-6487
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1432	Carrier-Planet	314-8659

KWW		
Original Part Number	Part Name	Classic Part Number
8T-0072	Cone-Rlr Brg	377-7448
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

KYY		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2K-5069	Cup-Roller Brg	374-8346

KYY		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6V-0330	Cup-Rlr Brg	422-6487
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
7Y-1432	Carrier-Planet	314-8659

KYY		
Original Part Number	Part Name	Classic Part Number
8T-0072	Cone-Rlr Brg	377-7448
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

TRF		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2K-5069	Cup-Roller Brg	374-8346

TRF		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
6H-3957	Bearing-Ball	311-9358
6V-0330	Cup-Rlr Brg	422-6487
7Y-0223	Shaft-Planet	301-4625
7Y-0225	Shaft-Planet	301-4571
8T-0072	Cone-Rlr Brg	377-7448

TRF		
Original Part Number	Part Name	Classic Part Number
9J-9812	Bearing	434-7258
150-0351	Spacer	396-7291
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

Sales Model D5M

3CR		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4493	Cone-Spl Tapered	386-4939
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087

3CR		
Original Part Number	Part Name	Classic Part Number
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384

3CR		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715

Sales Model D5M (Cont'd.)

3CR		
Original Part Number	Part Name	Classic Part Number
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5069	Cup-Roller Brg	374-8346
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-3597	Muffler As	397-5044
2W-5240	Pipe-Pump Outlet	376-9055
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3L-9410	Cone-Spl Tapered	391-9899

3CR		
Original Part Number	Part Name	Classic Part Number
3T-9960	Disc-Friction	417-9487
3W-2420	Bearing	417-4517
4F-2041	Cup-Roller Brg	418-9609
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7688	Valve As-Check	420-6216
4P-7790	Shaft As-Arm	457-4596
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8577	Rod As-Injector	455-5513
4P-8915	Gasket-Cyl Head	377-5838
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4Y-4905	Washer-Soft	416-5535

3CR		
Original Part Number	Part Name	Classic Part Number
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1099	Manifold-Exh	424-6366
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-4582	Bearing-Ball	380-1504
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-2880	Bell As-Suction	380-1520

Sales Model D5M (Cont'd.)

3CR		
Original Part Number	Part Name	Classic Part Number
7C-3760	Tube As-O Drain	375-5443
7C-3862	Camshaft	458-0151
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4758	Gear-Planet	288-8723
7G-5444	Carrier-Planet	297-7165
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-7858	Bearing-Sleeve	374-8362
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613

3CR		
Original Part Number	Part Name	Classic Part Number
7W-1927	Ring-Retainer	387-2935
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8064	Valve-Inlet	384-8705
8D-0983	Mounting	384-3470
8G-3102	Piston	325-6162
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290

3CR		
Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8Y-0809	Spider Gp-Brg	417-4526
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-4529	Piston As	424-6368
100-6267	Plate As-Idler	375-9983
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
104-4747	Pin	392-4527
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381

Sales Model D5M (Cont'd.)

3CR		
Original Part Number	Part Name	Classic Part Number
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
109-1231	Strip	393-3683
111-8015	Gasket As-Head	279-4977
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-4358	Pin	419-6030
147-4359	Pin	393-0937
148-7455	Valve - Exhaust	270-4361
152-3952	Impeller-Pump	374-4696
160-0305	Bearing-Aligning	396-9945

3CR		
Original Part Number	Part Name	Classic Part Number
163-1387	Gear-Flywheel	374-4697
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371

3CR		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3233	Bearing-Main	376-9085
233-5001	Strip	393-3683
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
246-8883	Rod As	425-9364
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

3DR		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4493	Cone-Spl Tapered	386-4939
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902

3DR		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

3DR		
Original Part Number	Part Name	Classic Part Number
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513

Sales Model D5M (Cont'd.)

3DR		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5069	Cup-Roller Brg	374-8346
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-3597	Muffler As	397-5044
2W-5240	Pipe-Pump Outlet	376-9055
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3W-2420	Bearing	417-4517
4F-2041	Cup-Roller Brg	418-9609
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710

3DR		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7688	Valve As-Check	420-6216
4P-7790	Shaft As-Arm	457-4596
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8577	Rod As-Injector	455-5513
4P-8915	Gasket-Cyl Head	377-5838
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

3DR		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1099	Manifold-Exh	424-6366
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-4582	Bearing-Ball	380-1504
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-2880	Bell As-Suction	380-1520
7C-3760	Tube As-O Drain	375-5443
7C-3862	Camshaft	458-0151
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025

Sales Model D5M (Cont'd.)

3DR		
Original Part Number	Part Name	Classic Part Number
7E-6794	Arm As-Injector	433-0449
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4758	Gear-Planet	288-8723
7G-5444	Carrier-Planet	297-7165
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-7858	Bearing-Sleeve	374-8362
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187

3DR		
Original Part Number	Part Name	Classic Part Number
7W-8064	Valve-Inlet	384-8705
8D-0983	Mounting	384-3470
8G-3102	Piston	325-6162
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

3DR		
Original Part Number	Part Name	Classic Part Number
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-0809	Spider Gp-Brg	417-4526
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-4529	Piston As	424-6368
100-6267	Plate As-Idler	375-9983
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
104-4747	Pin	392-4527
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
109-1231	Strip	393-3683
111-8015	Gasket As-Head	279-4977
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002

Sales Model D5M (Cont'd.)

3DR		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-4358	Pin	419-6030
147-4359	Pin	393-0937
148-7455	Valve - Exhaust	270-4361
152-3952	Impeller-Pump	374-4696
160-0305	Bearing-Aligning	396-9945
163-1387	Gear-Flywheel	374-4697
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351

3DR		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

3DR		
Original Part Number	Part Name	Classic Part Number
232-3233	Bearing-Main	376-9085
233-5001	Strip	393-3683
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
246-8883	Rod As	425-9364
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

4BR		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4493	Cone-Spl Tapered	386-4939
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572

4BR		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

4BR		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5069	Cup-Roller Brg	374-8346
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872

Sales Model D5M (Cont'd.)

4BR		
Original Part Number	Part Name	Classic Part Number
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-3597	Muffler As	397-5044
2W-5240	Pipe-Pump Outlet	376-9055
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
3G-4704	Bearing-Sleeve	379-0185
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3W-2420	Bearing	417-4517
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7688	Valve As-Check	420-6216
4P-7790	Shaft As-Arm	457-4596
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

4BR		
Original Part Number	Part Name	Classic Part Number
4P-8577	Rod As-Injector	455-5513
4P-8915	Gasket-Cyl Head	377-5838
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-9901	Pin As	374-6508
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6E-4892	Cyl Gp-089 478 Y	394-9828
6H-3957	Bearing-Ball	311-9358
6I-1099	Manifold-Exh	424-6366

4BR		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-3831	Seal-O-Ring	436-2657
6V-4582	Bearing-Ball	380-1504
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7C-1371	Coupling-Exhaust	369-9490
7C-2880	Bell As-Suction	380-1520
7C-3760	Tube As-O Drain	375-5443
7C-3862	Camshaft	458-0151
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466

Sales Model D5M (Cont'd.)

4BR		
Original Part Number	Part Name	Classic Part Number
7G-3707	Piston-Clutch	302-2691
7G-4758	Gear-Planet	288-8723
7G-5444	Carrier-Planet	297-7165
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-7858	Bearing-Sleeve	374-8362
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8064	Valve-Inlet	384-8705
8D-0983	Mounting	384-3470

4BR		
Original Part Number	Part Name	Classic Part Number
8G-3102	Piston	325-6162
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084

4BR		
Original Part Number	Part Name	Classic Part Number
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8V-7659	Pin As	361-1702
8Y-0809	Spider Gp-Brg	417-4526
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-4529	Piston As	424-6368
100-6267	Plate As-Idler	375-9983
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
104-4747	Pin	392-4527
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
109-1231	Strip	393-3683
111-8015	Gasket As-Head	279-4977
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311

Sales Model D5M (Cont'd.)

4BR		
Original Part Number	Part Name	Classic Part Number
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
133-3919	Gasket Kit-Sch	393-1031
136-0819	Valve-Exhaust	384-8697
144-0482	Gasket	420-8547
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-4358	Pin	419-6030
147-4359	Pin	393-0937
148-7455	Valve - Exhaust	270-4361
151-5911	Manifold As.-Exh	441-5604
152-3952	Impeller-Pump	374-4696
160-0305	Bearing-Aligning	396-9945
163-1387	Gear-Flywheel	374-4697
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126

4BR		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024

4BR		
Original Part Number	Part Name	Classic Part Number
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3233	Bearing-Main	376-9085
233-5001	Strip	393-3683
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
246-8883	Rod As	425-9364
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
290-2060	Kit-Gasket-Sch	438-0149
292-5516	Kit-Dt Gasket	391-9885
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

4JS		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4493	Cone-Spl Tapered	386-4939
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344

4JS		
Original Part Number	Part Name	Classic Part Number
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358

4JS		
Original Part Number	Part Name	Classic Part Number
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5069	Cup-Roller Brg	374-8346
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

Sales Model D5M (Cont'd.)

4JS		
Original Part Number	Part Name	Classic Part Number
2P-2406	Pulley	264-5870
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-3597	Muffler As	397-5044
2W-5240	Pipe-Pump Outlet	376-9055
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-4704	Bearing-Sleeve	379-0185
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3W-2420	Bearing	417-4517
4F-2041	Cup-Roller Brg	418-9609
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7688	Valve As-Check	420-6216
4P-7790	Shaft As-Arm	457-4596
4P-7826	Gear-Camshaft	472-8008

4JS		
Original Part Number	Part Name	Classic Part Number
4P-7827	Gear-Crankshaft	380-7533
4P-8577	Rod As-Injector	455-5513
4P-8915	Gasket-Cyl Head	377-5838
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-9901	Pin As	374-6508
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6E-4892	Cyl Gp-089 478 Y	394-9828

4JS		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-1099	Manifold-Exh	424-6366
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-4582	Bearing-Ball	380-1504
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-2880	Bell As-Suction	380-1520
7C-3760	Tube As-O Drain	375-5443
7C-3862	Camshaft	458-0151
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4758	Gear-Planet	288-8723
7G-5444	Carrier-Planet	297-7165

Sales Model D5M (Cont'd.)

4JS		
Original Part Number	Part Name	Classic Part Number
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-7858	Bearing-Sleeve	374-8362
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8064	Valve-Inlet	384-8705
8D-0983	Mounting	384-3470
8G-3102	Piston	325-6162
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954

4JS		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198

4JS		
Original Part Number	Part Name	Classic Part Number
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8V-7659	Pin As	361-1702
8Y-0809	Spider Gp-Brg	417-4526
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-4529	Piston As	424-6368
100-6267	Plate As-Idler	375-9983
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
104-4747	Pin	392-4527
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
109-1231	Strip	393-3683
111-8015	Gasket As-Head	279-4977
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5875	Flywheel As.	374-4694

Sales Model D5M (Cont'd.)

4JS		
Original Part Number	Part Name	Classic Part Number
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-4358	Pin	419-6030
147-4359	Pin	393-0937
148-7455	Valve - Exhaust	270-4361
152-3952	Impeller-Pump	374-4696
160-0305	Bearing-Aligning	396-9945
163-1387	Gear-Flywheel	374-4697
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353

4JS		
Original Part Number	Part Name	Classic Part Number
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

4JS		
Original Part Number	Part Name	Classic Part Number
232-3233	Bearing-Main	376-9085
233-5001	Strip	393-3683
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
246-8883	Rod As	425-9364
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

5ES		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476

5ES		
Original Part Number	Part Name	Classic Part Number
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513

5ES		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5069	Cup-Roller Brg	374-8346
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1748	Elbow-Exhaust	447-0821

Sales Model D5M (Cont'd.)

5ES		
Original Part Number	Part Name	Classic Part Number
2W-2621	Valve-Inlet	247-6892
2W-3597	Muffler As	397-5044
2W-5240	Pipe-Pump Outlet	376-9055
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-4704	Bearing-Sleeve	379-0185
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3W-2420	Bearing	417-4517
4F-2041	Cup-Roller Brg	418-9609
4J-2414	Trunnion	296-1370
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7688	Valve As-Check	420-6216
4P-7790	Shaft As-Arm	457-4596
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8577	Rod As-Injector	455-5513
4P-8915	Gasket-Cyl Head	377-5838
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216

5ES		
Original Part Number	Part Name	Classic Part Number
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-9901	Pin As	374-6508
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6E-4892	Cyl Gp-089 478 Y	394-9828
6H-3957	Bearing-Ball	311-9358
6I-1099	Manifold-Exh	424-6366
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544

5ES		
Original Part Number	Part Name	Classic Part Number
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-4582	Bearing-Ball	380-1504
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-2880	Bell As-Suction	380-1520
7C-3760	Tube As-O Drain	375-5443
7C-3862	Camshaft	458-0151
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4758	Gear-Planet	288-8723
7G-5444	Carrier-Planet	297-7165
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-0087	Bearing-Sleeve	374-6514

Sales Model D5M (Cont'd.)

5ES		
Original Part Number	Part Name	Classic Part Number
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-7858	Bearing-Sleeve	374-8362
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8064	Valve-Inlet	384-8705
8D-0983	Mounting	384-3470
8G-3102	Piston	325-6162
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

5ES		
Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-7659	Pin As	361-1702
8Y-0809	Spider Gp-Brg	417-4526
9G-1231	Plate	297-7232

5ES		
Original Part Number	Part Name	Classic Part Number
9G-1488	Housing-Clutch	430-7620
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-4529	Piston As	424-6368
100-6267	Plate As-Idler	375-9983
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
104-4747	Pin	392-4527
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
109-1231	Strip	393-3683
111-8015	Gasket As-Head	279-4977
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-4358	Pin	419-6030

Sales Model D5M (Cont'd.)

5ES		
Original Part Number	**Part Name**	**Classic Part Number**
147-4359	Pin	393-0937
148-7455	Valve - Exhaust	270-4361
152-3952	Impeller-Pump	374-4696
160-0305	Bearing-Aligning	396-9945
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

5ES		
Original Part Number	**Part Name**	**Classic Part Number**
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3233	Bearing-Main	376-9085
233-5001	Strip	393-3683
241-3381	Valve Kit-Cla	247-6893

5ES		
Original Part Number	**Part Name**	**Classic Part Number**
241-3381	Valve Kit-Cla	247-6892
246-8883	Rod As	425-9364
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

5FS		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-4493	Cone-Spl Tapered	386-4939
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799

5FS		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1805	Turbine-Conv	380-1490
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

5FS		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5069	Cup-Roller Brg	374-8346
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-3597	Muffler As	397-5044
2W-5240	Pipe-Pump Outlet	376-9055

Sales Model D5M (Cont'd.)

5FS		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3W-2420	Bearing	417-4517
4F-2041	Cup-Roller Brg	418-9609
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7688	Valve As-Check	420-6216
4P-7790	Shaft As-Arm	457-4596
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8577	Rod As-Injector	455-5513
4P-8915	Gasket-Cyl Head	377-5838
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778

5FS		
Original Part Number	Part Name	Classic Part Number
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1099	Manifold-Exh	424-6366
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041

5FS		
Original Part Number	Part Name	Classic Part Number
6V-4582	Bearing-Ball	380-1504
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-2880	Bell As-Suction	380-1520
7C-3760	Tube As-O Drain	375-5443
7C-3862	Camshaft	458-0151
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4758	Gear-Planet	288-8723
7G-5444	Carrier-Planet	297-7165
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497

Sales Model D5M (Cont'd.)

5FS		
Original Part Number	Part Name	Classic Part Number
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-7858	Bearing-Sleeve	374-8362
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8064	Valve-Inlet	384-8705
8D-0983	Mounting	384-3470
8G-3102	Piston	325-6162
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

5FS		
Original Part Number	Part Name	Classic Part Number
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-0809	Spider Gp-Brg	417-4526
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032

5FS		
Original Part Number	Part Name	Classic Part Number
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-4529	Piston As	424-6368
100-6267	Plate As-Idler	375-9983
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
104-4747	Pin	392-4527
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
109-1231	Strip	393-3683
111-8015	Gasket As-Head	279-4977
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-4358	Pin	419-6030
147-4359	Pin	393-0937
148-7455	Valve - Exhaust	270-4361
152-3952	Impeller-Pump	374-4696
160-0305	Bearing-Aligning	396-9945
163-1387	Gear-Flywheel	374-4697
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353

Sales Model D5M (Cont'd.)

5FS		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259

5FS		
Original Part Number	**Part Name**	**Classic Part Number**
196-0029	Gear As-Idler	374-4674
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3233	Bearing-Main	376-9085
233-5001	Strip	393-3683
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
246-8883	Rod As	425-9364
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357

5FS		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

6AS		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4493	Cone-Spl Tapered	386-4939
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715

6AS		
Original Part Number	**Part Name**	**Classic Part Number**
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5069	Cup-Roller Brg	374-8346
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197

6AS		
Original Part Number	**Part Name**	**Classic Part Number**
2P-7828	Pan-Oil	314-8691
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-3597	Muffler As	397-5044
2W-5240	Pipe-Pump Outlet	376-9055
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3W-2420	Bearing	417-4517

Sales Model D5M (Cont'd.)

6AS		
Original Part Number	Part Name	Classic Part Number
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7688	Valve As-Check	420-6216
4P-7790	Shaft As-Arm	457-4596
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8577	Rod As-Injector	455-5513
4P-8915	Gasket-Cyl Head	377-5838
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4Y-4905	Washer-Soft	416-5535

6AS		
Original Part Number	Part Name	Classic Part Number
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1099	Manifold-Exh	424-6366
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-4582	Bearing-Ball	380-1504
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-2880	Bell As-Suction	380-1520
7C-3760	Tube As-O Drain	375-5443
7C-3862	Camshaft	458-0151

6AS		
Original Part Number	Part Name	Classic Part Number
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4758	Gear-Planet	288-8723
7G-5444	Carrier-Planet	297-7165
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-7858	Bearing-Sleeve	374-8362
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935

Sales Model D5M (Cont'd.)

6AS		
Original Part Number	Part Name	Classic Part Number
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8064	Valve-Inlet	384-8705
8D-0983	Mounting	384-3470
8G-3102	Piston	325-6162
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232

6AS		
Original Part Number	Part Name	Classic Part Number
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8Y-0809	Spider Gp-Brg	417-4526
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-1677	Bearing	297-7145
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-4529	Piston As	424-6368
100-6267	Plate As-Idler	375-9983
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
104-4747	Pin	392-4527
105-1738	Manifold-Exhaust	374-4692

6AS		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
109-1231	Strip	393-3683
111-8015	Gasket As-Head	279-4977
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-4358	Pin	419-6030
147-4359	Pin	393-0937
148-7455	Valve - Exhaust	270-4361
152-3952	Impeller-Pump	374-4696
160-0305	Bearing-Aligning	396-9945
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

Sales Model D5M (Cont'd.)

6AS		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024

6AS		
Original Part Number	Part Name	Classic Part Number
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3233	Bearing-Main	376-9085
233-5001	Strip	393-3683
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
246-8883	Rod As	425-9364
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
271-5658	Crankshaft As.	368-5912

6AS		
Original Part Number	Part Name	Classic Part Number
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

6GN		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006

6GN		
Original Part Number	Part Name	Classic Part Number
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5069	Cup-Roller Brg	374-8346
2K-6413	Pin	360-2270
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892

6GN		
Original Part Number	Part Name	Classic Part Number
2W-3597	Muffler As	397-5044
2W-5240	Pipe-Pump Outlet	376-9055
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-4704	Bearing-Sleeve	379-0185
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3W-2420	Bearing	417-4517
4F-2041	Cup-Roller Brg	418-9609
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-3683	Pump Gp-Water -B	374-7498

Sales Model D5M (Cont'd.)

6GN		
Original Part Number	Part Name	Classic Part Number
4P-7051	Pulley-Alt	376-9064
4P-7688	Valve As-Check	420-6216
4P-7790	Shaft As-Arm	457-4596
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8577	Rod As-Injector	455-5513
4P-8915	Gasket-Cyl Head	377-5838
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-9901	Pin As	374-6508
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437

6GN		
Original Part Number	Part Name	Classic Part Number
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6E-4892	Cyl Gp-089 478 Y	394-9828
6H-3957	Bearing-Ball	311-9358
6I-1099	Manifold-Exh	424-6366
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-4582	Bearing-Ball	380-1504
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-2880	Bell As-Suction	380-1520
7C-3760	Tube As-O Drain	375-5443
7C-3862	Camshaft	458-0151
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466

6GN		
Original Part Number	Part Name	Classic Part Number
7G-3707	Piston-Clutch	302-2691
7G-4758	Gear-Planet	288-8723
7G-5444	Carrier-Planet	297-7165
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-7858	Bearing-Sleeve	374-8362
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8064	Valve-Inlet	384-8705
8D-0983	Mounting	384-3470

Sales Model D5M (Cont'd.)

6GN		
Original Part Number	Part Name	Classic Part Number
8G-3102	Piston	325-6162
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084

6GN		
Original Part Number	Part Name	Classic Part Number
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-7659	Pin As	361-1702
8Y-0809	Spider Gp-Brg	417-4526
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-4529	Piston As	424-6368
100-6267	Plate As-Idler	375-9983
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
104-4747	Pin	392-4527
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
109-1231	Strip	393-3683
111-8015	Gasket As-Head	279-4977
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
124-5233	Pin	443-2664

6GN		
Original Part Number	Part Name	Classic Part Number
124-5741	Pin	394-0204
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-4358	Pin	419-6030
147-4359	Pin	393-0937
148-7455	Valve - Exhaust	270-4361
152-3952	Impeller-Pump	374-4696
160-0305	Bearing-Aligning	396-9945
163-1387	Gear-Flywheel	374-4697
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

Sales Model D5M (Cont'd.)

6GN		
Original Part Number	Part Name	Classic Part Number
232-3233	Bearing-Main	376-9085
233-5001	Strip	393-3683
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
246-8883	Rod As	425-9364
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357

6GN		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885

6GN		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

7LR		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513

7LR		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-0227	Bearing-Sleeve	384-4780
2K-5069	Cup-Roller Brg	374-8346
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3B-3967	Race-Roller Brg	386-4947
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818

7LR		
Original Part Number	Part Name	Classic Part Number
3F-6612	Cap-Ball Joint	297-7155
3G-0910	Cap-Bearing	325-6037
3G-6313	Bearing	325-6007
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3J-9511	Bearing-Sleeve	385-3782
3L-1425	Bearing-Ball	311-9356
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3W-2420	Bearing	417-4517
3Y-2768	Ring	439-4544
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7688	Valve As-Check	420-6216
4P-7790	Shaft As-Arm	457-4596
4P-7826	Gear-Camshaft	472-8008

Sales Model D5M (Cont'd.)

7LR		
Original Part Number	Part Name	Classic Part Number
4P-7827	Gear-Crankshaft	380-7533
4P-8577	Rod As-Injector	455-5513
4P-8915	Gasket-Cyl Head	377-5838
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1099	Manifold-Exh	424-6366

7LR		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6S-3474	Pin As	375-9981
6T-5383	Gear-Ring	375-2624
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
6Y-6234	Bearing-Sleeve	325-6014
6Y-6382	Strip	419-0888
6Y-7929	Disc-Friction	456-0555
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-2880	Bell As-Suction	380-1520
7C-3760	Tube As-O Drain	375-5443
7C-3862	Camshaft	458-0151
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229

7LR		
Original Part Number	Part Name	Classic Part Number
7G-4758	Gear-Planet	288-8723
7G-5444	Carrier-Planet	297-7165
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7J-9884	Bearing-Sleeve	325-6016
7K-0087	Bearing-Sleeve	374-6514
7K-5448	Cup-Bearing	415-1922
7K-9642	Bearing-Sleeve	360-2340
7M-1154	Bearing-Spl	417-4515
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-7858	Bearing-Sleeve	374-8362
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5928	Pump Gp-F Inj -B	432-8277

Sales Model D5M (Cont'd.)

7LR		
Original Part Number	Part Name	Classic Part Number
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8064	Valve-Inlet	384-8705
8G-3102	Piston	325-6162
8G-3965	Hub-Sprocket	424-4942
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8H-9789	Bearing-Ball	374-8342
8J-4411	Bearing-Aligning	384-4815
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

7LR		
Original Part Number	Part Name	Classic Part Number
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8Y-0809	Spider Gp-Brg	417-4526
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-0123	Trunnion	325-6227
9J-2759	Trunnion	394-0216
9K-8757	Rod End-Special	311-9361
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-4762	Head	325-6109
9U-9198	Strip	388-0641
9W-1677	Bearing	297-7145
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-4529	Piston As	424-6368
100-6267	Plate As-Idler	375-9983
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516

7LR		
Original Part Number	Part Name	Classic Part Number
104-4747	Pin	392-4527
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
109-1231	Strip	393-3683
111-8015	Gasket As-Head	279-4977
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
135-7393	Head	382-6895
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-4358	Pin	419-6030
147-4359	Pin	393-0937
148-7455	Valve - Exhaust	270-4361
150-0351	Spacer	396-7291
152-3952	Impeller-Pump	374-4696
160-0305	Bearing-Aligning	396-9945
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

Sales Model D5M (Cont'd.)

7LR		
Original Part Number	Part Name	Classic Part Number
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372

7LR		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3233	Bearing-Main	376-9085
233-5001	Strip	393-3683
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
246-8883	Rod As	425-9364
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351

7LR		
Original Part Number	Part Name	Classic Part Number
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

Sales Model D5N

AGG		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5069	Cup-Roller Brg	374-8346
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3J-9511	Bearing-Sleeve	385-3782
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3W-2420	Bearing	417-4517
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511

AGG		
Original Part Number	Part Name	Classic Part Number
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4M-5858	Bearing-Spl Ball	417-4495
4P-3683	Pump Gp-Water -B	374-7498
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695

AGG		
Original Part Number	Part Name	Classic Part Number
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-4582	Bearing-Ball	380-1504
6Y-0306	Bearing-Sleeve	391-1104
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691

Sales Model D5N (Cont'd.)

AGG		
Original Part Number	Part Name	Classic Part Number
7G-4758	Gear-Planet	288-8723
7G-5444	Carrier-Planet	297-7165
7G-5614	Shaft-Planet	281-1697
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-7858	Bearing-Sleeve	374-8362
7S-4534	Bearing-Caged	417-9497
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8J-4411	Bearing-Aligning	384-4815
8T-0072	Cone-Rlr Brg	377-7448
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9M-1328	Bearing-Aligning	325-6018
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967

AGG		
Original Part Number	Part Name	Classic Part Number
087-5806	Pin	301-7968
087-5845	Pin	301-7969
100-4529	Piston As	424-6368
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
104-4747	Pin	392-4527
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
109-1231	Strip	393-3683
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5984	Ring-Backup	419-4654
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-4995	Gasket-Cyl Head	434-2445
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
147-4358	Pin	419-6030
147-4359	Pin	393-0937
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
160-0305	Bearing-Aligning	396-9945
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505

AGG		
Original Part Number	Part Name	Classic Part Number
164-4413	Mount	419-0876
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-5001	Strip	393-3683
236-4413	Pump Gp-Water -B	434-6110
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
246-8883	Rod As	425-9364
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
1B-3978	Cup-Roller Brg	399-4437

AKD		
Original Part Number	Part Name	Classic Part Number
1B-3980	Cone-Roller Brg	399-4443
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
1S-7057	Gasket	420-6384

AKD		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

AKD		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208

Sales Model D5N (Cont'd.)

AKD		
Original Part Number	Part Name	Classic Part Number
3J-9511	Bearing-Sleeve	385-3782
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3W-2420	Bearing	417-4517
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4M-5858	Bearing-Spl Ball	417-4495
4P-3683	Pump Gp-Water -B	374-7498
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-4582	Bearing-Ball	380-1504
6Y-0306	Bearing-Sleeve	391-1104
6Y-3484	Bearing-Spl Ball	416-2166

AKD		
Original Part Number	Part Name	Classic Part Number
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4758	Gear-Planet	288-8723
7G-5444	Carrier-Planet	297-7165
7G-5614	Shaft-Planet	281-1697
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-7858	Bearing-Sleeve	374-8362
7S-4534	Bearing-Caged	417-9497
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8J-4411	Bearing-Aligning	384-4815
8T-0072	Cone-Rlr Brg	377-7448
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9M-1328	Bearing-Aligning	325-6018
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437

AKD		
Original Part Number	Part Name	Classic Part Number
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
100-4529	Piston As	424-6368
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
104-4747	Pin	392-4527
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
109-1231	Strip	393-3683
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5984	Ring-Backup	419-4654
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-4995	Gasket-Cyl Head	434-2445
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
147-4358	Pin	419-6030
147-4359	Pin	393-0937
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
160-0305	Bearing-Aligning	396-9945
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
164-4413	Mount	419-0876
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322

Sales Model D5N (Cont'd.)

AKD		
Original Part Number	Part Name	Classic Part Number
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-5001	Strip	393-3683
236-4413	Pump Gp-Water -B	434-6110
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436

AKD		
Original Part Number	Part Name	Classic Part Number
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
246-8883	Rod As	425-9364
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351

AKD		
Original Part Number	Part Name	Classic Part Number
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

CFH		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5069	Cup-Roller Brg	374-8346
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
3G-2797	Bearing-Sleeve	360-2329
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3J-9511	Bearing-Sleeve	385-3782
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3W-2420	Bearing	417-4517
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4M-5858	Bearing-Spl Ball	417-4495

CFH		
Original Part Number	Part Name	Classic Part Number
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-4582	Bearing-Ball	380-1504
6Y-0306	Bearing-Sleeve	391-1104
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059

CFH		
Original Part Number	Part Name	Classic Part Number
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4758	Gear-Planet	288-8723
7G-5444	Carrier-Planet	297-7165
7G-5614	Shaft-Planet	281-1697
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-7858	Bearing-Sleeve	374-8362
7S-4534	Bearing-Caged	417-9497
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626

Sales Model D5N (Cont'd.)

CFH		
Original Part Number	Part Name	Classic Part Number
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8J-4411	Bearing-Aligning	384-4815
8T-0072	Cone-Rlr Brg	377-7448
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9M-1328	Bearing-Aligning	325-6018
9T-4762	Head	325-6109
9V-0247	Plate	417-4527
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
100-4529	Piston As	424-6368
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
104-4747	Pin	392-4527
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
109-1231	Strip	393-3683

CFH		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5984	Ring-Backup	419-4654
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-4995	Gasket-Cyl Head	434-2445
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
147-4358	Pin	419-6030
147-4359	Pin	393-0937
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
160-0305	Bearing-Aligning	396-9945
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
164-4413	Mount	419-0876
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371

CFH		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-5001	Strip	393-3683
236-4413	Pump Gp-Water -B	434-6110
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
246-8883	Rod As	425-9364
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

CKT		
Original Part Number	Part Name	Classic Part Number
1H-4493	Cone-Spl Tapered	386-4939
1M-8736	Cup-Roller Brg	423-7759
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-0227	Bearing-Sleeve	384-4780

CKT		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
2K-6413	Pin	360-2270
2W-7213	Bearing-Sleeve	419-4667
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3G-0910	Cap-Bearing	325-6037
3G-6313	Bearing	325-6007
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143

CKT		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3J-9511	Bearing-Sleeve	385-3782
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
3W-2420	Bearing	417-4517
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332

Sales Model D5N (Cont'd.)

CKT		
Original Part Number	Part Name	Classic Part Number
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4M-5858	Bearing-Spl Ball	417-4495
4P-3683	Pump Gp-Water -B	374-7498
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-5354	Cup-Rlr Bearing	399-4445
5P-7807	Bearing-Ball	314-8502
6B-7469	Spacer	417-4535
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8005	Gear-Planet	281-1691
6S-3474	Pin As	375-9981
6T-5383	Gear-Ring	375-2624
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-4582	Bearing-Ball	380-1504
6Y-0306	Bearing-Sleeve	391-1104
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
6Y-6234	Bearing-Sleeve	325-6014
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

CKT		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4758	Gear-Planet	288-8723
7G-5444	Carrier-Planet	297-7165
7G-5614	Shaft-Planet	281-1697
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-2604	Bearing-Sleeve	380-7369
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7J-9884	Bearing-Sleeve	325-6016
7K-5448	Cup-Bearing	415-1922
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816
7P-7858	Bearing-Sleeve	374-8362
7S-4534	Bearing-Caged	417-9497
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4510	Plate-Clutch	383-2113
8G-8944	Sleeve-Wear	418-1954
8J-4411	Bearing-Aligning	384-4815
8T-0072	Cone-Rlr Brg	377-7448
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-0123	Trunnion	325-6227
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379

CKT		
Original Part Number	Part Name	Classic Part Number
9M-1328	Bearing-Aligning	325-6018
9T-4762	Head	325-6109
9W-1677	Bearing	297-7145
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
100-4529	Piston As	424-6368
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
104-4747	Pin	392-4527
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0380	Pin As	396-7276
109-1231	Strip	393-3683
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
124-3237	Precleaner As	432-4220
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5984	Ring-Backup	419-4654
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-4995	Gasket-Cyl Head	434-2445
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
147-4359	Pin	393-0937
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
160-0305	Bearing-Aligning	396-9945
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505

Sales Model D5N (Cont'd.)

CKT		
Original Part Number	Part Name	Classic Part Number
164-4413	Mount	419-0876
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

CKT		
Original Part Number	Part Name	Classic Part Number
233-5001	Strip	393-3683
236-4413	Pump Gp-Water -B	434-6110
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

CKT		
Original Part Number	Part Name	Classic Part Number
246-8883	Rod As	425-9364
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

Sales Model D5R

D5L		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-9960	Disc-Friction	417-9487
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344

D5L		
Original Part Number	Part Name	Classic Part Number
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428

D5L		
Original Part Number	Part Name	Classic Part Number
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7G-0437	Plate-Clutch	417-9466
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-9682	Bearing-Sleeve	360-2335
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8P-1916	Gear-Planet	283-5209

Sales Model D5R (Cont'd.)

D5L		
Original Part Number	Part Name	Classic Part Number
8T-0072	Cone-Rlr Brg	377-7448
9G-1488	Housing-Clutch	430-7620
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490

D5L		
Original Part Number	Part Name	Classic Part Number
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
108-8250	Carrier-Seal	421-7830
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
124-5741	Pin	394-0204
129-7768	Bearing-Sleeve	360-2316
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
163-3749	Bearing-Sleeve	433-7505
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432

D5L		
Original Part Number	Part Name	Classic Part Number
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693

D5X		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
1U-0725	Retainer	314-8707
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3L-9410	Cone-Spl Tapered	391-9899

D5X		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-9960	Disc-Friction	417-9487
4F-1252	Pin	295-5704
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-1203	Cup-Rlr Brg	418-9603

D5X		
Original Part Number	Part Name	Classic Part Number
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6E-5449	Bearing-Sleeve	464-4048
6F-2904	Bearing	295-5673
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562

Sales Model D5R (Cont'd.)

D5X		
Original Part Number	Part Name	Classic Part Number
6Y-3484	Bearing-Spl Ball	416-2166
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
7B-7515	Bearing-Ball	399-6059
7G-0437	Plate-Clutch	417-9466
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448

D5X		
Original Part Number	Part Name	Classic Part Number
9G-1488	Housing-Clutch	430-7620
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
108-8250	Carrier-Seal	421-7830
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
124-5741	Pin	394-0204
129-7768	Bearing-Sleeve	360-2316

D5X		
Original Part Number	Part Name	Classic Part Number
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
163-3749	Bearing-Sleeve	433-7505
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693

R5A		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
1U-0725	Retainer	314-8707
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481

R5A		
Original Part Number	Part Name	Classic Part Number
3E-4903	Mount As	396-7274
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
4F-1252	Pin	295-5704

R5A		
Original Part Number	Part Name	Classic Part Number
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0732	Bracket	314-8627

Sales Model D5R (Cont'd.)

R5A		
Original Part Number	Part Name	Classic Part Number
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166

R5A		
Original Part Number	Part Name	Classic Part Number
6Y-6751	Pin	325-6149
7B-7515	Bearing-Ball	399-6059
7G-0437	Plate-Clutch	417-9466
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9S-3581	Cup-Roller Brg	415-1923

R5A		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
005-4834	Cone-Rlr Bearing	422-6490
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
179-6152	Bearing	361-1704
202-2380	Shaft As.-Input	399-4432
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
321-5714	Piston-Clutch	281-1693

WDZ		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4903	Mount As	396-7274
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433

WDZ		
Original Part Number	Part Name	Classic Part Number
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695

WDZ		
Original Part Number	Part Name	Classic Part Number
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059

Sales Model D5R (Cont'd.)

WDZ		
Original Part Number	Part Name	Classic Part Number
7G-0437	Plate-Clutch	417-9466
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-9682	Bearing-Sleeve	360-2335
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366

WDZ		
Original Part Number	Part Name	Classic Part Number
8G-8311	Bearin - Sleeve	295-6412
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554

WDZ		
Original Part Number	Part Name	Classic Part Number
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
005-4834	Cone-Rlr Bearing	422-6490
108-8250	Carrier-Seal	421-7830
109-0958	Pin	394-0208
124-5741	Pin	394-0204
135-7393	Head	382-6895
202-2380	Shaft As.-Input	399-4432
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693

WRE		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4903	Mount As	396-7274
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5M-0578	Bearing	419-7775

WRE		
Original Part Number	Part Name	Classic Part Number
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7G-0437	Plate-Clutch	417-9466
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275

WRE		
Original Part Number	Part Name	Classic Part Number
7J-9682	Bearing-Sleeve	360-2335
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
005-4834	Cone-Rlr Bearing	422-6490

Sales Model D5R (Cont'd.)

WRE		
Original Part Number	Part Name	Classic Part Number
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0958	Pin	394-0208
124-5741	Pin	394-0204

WRE		
Original Part Number	Part Name	Classic Part Number
135-7393	Head	382-6895
202-2380	Shaft As.-Input	399-4432
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

WRE		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693

Sales Model D5T

P5T		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4903	Mount As	396-7274
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6E-5449	Bearing-Sleeve	464-4048

P5T		
Original Part Number	Part Name	Classic Part Number
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7G-0437	Plate-Clutch	417-9466
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-9682	Bearing-Sleeve	360-2335
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
8G-4189	Bearing-Aligning	295-6411

P5T		
Original Part Number	Part Name	Classic Part Number
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
005-4834	Cone-Rlr Bearing	422-6490
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0958	Pin	394-0208
124-5741	Pin	394-0204
135-7393	Head	382-6895
202-2380	Shaft As.-Input	399-4432
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693

Sales Model D6

02H		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-4043	Cone-Roller Brg	377-7395
1B-4102	Bearing-Ball	399-4426
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2H-3712	Bearing-Ball	392-4488
2S-4015	Plunger As-Valve	311-9438

02H		
Original Part Number	**Part Name**	**Classic Part Number**
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3B-8845	Bearing-Inner	417-4509
3H-0881	Ring-Piston	465-8998
3H-1996	Bearing-Ball	380-1498
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4N-3875	Ring-Piston	465-8997
5H-7071	Director-Water	388-0555
6H-3957	Bearing-Ball	311-9358

02H		
Original Part Number	**Part Name**	**Classic Part Number**
7M-1154	Bearing-Spl	417-4515
7M-4926	Retainer-Piston	314-8538
7N-9352	Gasket	433-8188
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-8523	Bearing-Sleeve	383-3701
8H-4320	Bearing-Ball	419-2301
8M-8068	Bearing-Spl Ball	417-4500
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
9Y-9431	Precleaner As	361-1718

04R		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1642	Hub-Gear	219-2976
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-0176	Flange-Drum	223-4810
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-7576	Shaft-Sprocket	226-6071
2H-3517	Bearing-Inner	417-4505

04R		
Original Part Number	**Part Name**	**Classic Part Number**
2H-3712	Bearing-Ball	392-4488
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2P-7622	Bolt-Spring	226-4850
2P-9660	Gear	226-5995
2S-1477	Holder As-Cage	226-7985
2S-4015	Plunger As-Valve	311-9438
3B-6217	Muffler As	247-2671
3B-8845	Bearing-Inner	417-4509
3F-1972	Retainer As	226-7988
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3P-5754	Hub-Gear	219-2976
3S-7153	Gear-Sliding	227-0024
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219

04R		
Original Part Number	**Part Name**	**Classic Part Number**
4H-9040	Nut	226-7996
4S-8005	Pinion-Fdr	226-6076
5A-9551	Gear-Finaldrive	226-7979
5F-2256	Cage-Bearing	226-7973
5F-8651	Bearing-Ball	420-3223
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5M-9644	Bearing-Outer	384-5929
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009
6H-3957	Bearing-Ball	311-9358
6P-0169	Hub-Fly Clutch	297-7204
7B-5088	Drum-Steer Cl Dr	223-4813
7F-9547	Pin As.-Drawbar	295-0414
7G-6044	Cage As	216-7857
7H-1318	Coupling-Ster Cl	226-8002
7H-2424	Sleeve-Spring	226-4852
7H-6967	Bearing-Ball	422-6489
7M-1154	Bearing-Spl	417-4515

Sales Model D6 (Cont'd.)

04R		
Original Part Number	**Part Name**	**Classic Part Number**
7M-9398	Plate-Guide	297-7230
7S-7602	Pump Gp-Cl Oil	226-0174
7S-7625	Support As	226-6095
7T-0206	Bearing-Brace	297-7144
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8H-4320	Bearing-Ball	419-2301
8M-8068	Bearing-Spl Ball	417-4500

04R		
Original Part Number	**Part Name**	**Classic Part Number**
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
9B-0399	Link As-Cl Drive	431-5268
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9S-3321	Cage-Pinion Brg	226-7974

04R		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166
160-6306	Cap-Bearing	325-6038
228-7325	Ster Cl Kit-Cla	230-7119

05E		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-4043	Cone-Roller Brg	377-7395
1B-4102	Bearing-Ball	399-4426
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2H-3712	Bearing-Ball	392-4488
2S-4015	Plunger As-Valve	311-9438

05E		
Original Part Number	**Part Name**	**Classic Part Number**
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3B-8845	Bearing-Inner	417-4509
3H-0881	Ring-Piston	465-8998
3H-1996	Bearing-Ball	380-1498
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4N-3875	Ring-Piston	465-8997
5H-7071	Director-Water	388-0555
6H-3957	Bearing-Ball	311-9358

05E		
Original Part Number	**Part Name**	**Classic Part Number**
7M-1154	Bearing-Spl	417-4515
7M-4926	Retainer-Piston	314-8538
7N-9352	Gasket	433-8188
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-8523	Bearing-Sleeve	383-3701
8H-4320	Bearing-Ball	419-2301
8M-8068	Bearing-Spl Ball	417-4500
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
9Y-9431	Precleaner As	361-1718

05R		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1628	Hub-Gear	219-2977
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-0176	Flange-Drum	223-4810
1M-7912	Cone-Roller Brg	380-7503

05R		
Original Part Number	**Part Name**	**Classic Part Number**
1M-9177	Plate-Cl Press	226-6112
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505

05R		
Original Part Number	**Part Name**	**Classic Part Number**
2H-3712	Bearing-Ball	392-4488
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2P-7622	Bolt-Spring	226-4850
2P-9660	Gear	226-5995
2S-1477	Holder As-Cage	226-7985

Sales Model D6 (Cont'd.)

05R		
Original Part Number	Part Name	Classic Part Number
2S-4015	Plunger As-Valve	311-9438
3B-6217	Muffler As	247-2671
3B-8845	Bearing-Inner	417-4509
3F-1972	Retainer As	226-7988
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3S-7153	Gear-Sliding	227-0024
3S-8634	Hub-Gear	219-2977
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996
4S-8005	Pinion-Fdr	226-6076
5A-9551	Gear-Finaldrive	226-7979
5F-2256	Cage-Bearing	226-7973
5F-8651	Bearing-Ball	420-3223
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5M-9644	Bearing-Outer	384-5929
5P-9176	Bearing	396-4141

05R		
Original Part Number	Part Name	Classic Part Number
5P-9177	Race-Brg Inner	396-4139
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6P-0169	Hub-Fly Clutch	297-7204
7B-5088	Drum-Steer Cl Dr	223-4813
7F-9547	Pin As.-Drawbar	295-0414
7G-6044	Cage As	216-7857
7H-1318	Coupling-Ster Cl	226-8002
7H-2424	Sleeve-Spring	226-4852
7H-6967	Bearing-Ball	422-6489
7M-1154	Bearing-Spl	417-4515
7M-9398	Plate-Guide	297-7230
7S-7602	Pump Gp-Cl Oil	226-0174
7S-7625	Support As	226-6095
7T-0206	Bearing-Brace	297-7144
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8H-4320	Bearing-Ball	419-2301

05R		
Original Part Number	Part Name	Classic Part Number
8M-8068	Bearing-Spl Ball	417-4500
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
9B-0399	Link As-Cl Drive	431-5268
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166
160-6306	Cap-Bearing	325-6038
228-7325	Ster Cl Kit-Cla	230-7119

08U		
Original Part Number	Part Name	Classic Part Number
0R-1628	Hub-Gear	219-2977
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-0176	Flange-Drum	223-4810
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1S-1888	Bracket-Lamp	297-7147
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849

08U		
Original Part Number	Part Name	Classic Part Number
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4507	Bearing-Sleeve	325-6021

08U		
Original Part Number	Part Name	Classic Part Number
2P-7622	Bolt-Spring	226-4850
2P-9660	Gear	226-5995
2S-1273	Chamber As	319-3434
2S-1477	Holder As-Cage	226-7985
2S-4015	Plunger As-Valve	311-9438
3B-6218	Muffler As	247-2672
3B-8845	Bearing-Inner	417-4509
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3S-7153	Gear-Sliding	227-0024

Sales Model D6 (Cont'd.)

08U		
Original Part Number	Part Name	Classic Part Number
3S-8634	Hub-Gear	219-2977
4B-1455	Cap As-Filler	361-1719
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996
4M-0410	Gear-Oil Pump Dr	428-6660
4S-8005	Pinion-Fdr	226-6076
5A-9551	Gear-Finaldrive	226-7979
5F-2256	Cage-Bearing	226-7973
5F-8651	Bearing-Ball	420-3223
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5M-6709	Check As-Ball	380-7542
5M-9644	Bearing-Outer	384-5929
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358

08U		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
6P-0169	Hub-Fly Clutch	297-7204
6V-2202	Bearing-Spl Ball	380-1574
7B-5088	Drum-Steer Cl Dr	223-4813
7F-9547	Pin As.-Drawbar	295-0414
7G-6044	Cage As	216-7857
7H-1318	Coupling-Ster Cl	226-8002
7H-2424	Sleeve-Spring	226-4852
7H-6967	Bearing-Ball	422-6489
7M-1154	Bearing-Spl	417-4515
7M-4603	Body-Fuel Valve	311-9348
7M-9398	Plate-Guide	297-7230
7S-7602	Pump Gp-Cl Oil	226-0174
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7T-0206	Bearing-Brace	297-7144
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8H-4320	Bearing-Ball	419-2301
8M-6676	Cylinder-Adj	226-4960

08U		
Original Part Number	Part Name	Classic Part Number
8M-8068	Bearing-Spl Ball	417-4500
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
9B-0399	Link As-Cl Drive	431-5268
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-7670	Piston	226-4961
9J-9598	Pin	296-1362
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7534	Pipe-Exh Ext	398-2950
9W-1677	Bearing	297-7145
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
160-6306	Cap-Bearing	325-6038
228-7325	Ster Cl Kit-Cla	230-7119
308-1845	Seal-Wiper	472-8032

09A		
Original Part Number	Part Name	Classic Part Number
0R-1628	Hub-Gear	219-2977
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-0176	Flange-Drum	223-4810
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1S-1888	Bracket-Lamp	297-7147
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292

09A		
Original Part Number	Part Name	Classic Part Number
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260

09A		
Original Part Number	Part Name	Classic Part Number
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4507	Bearing-Sleeve	325-6021
2P-7622	Bolt-Spring	226-4850
2P-9660	Gear	226-5995
2S-1273	Chamber As	319-3434
2S-1477	Holder As-Cage	226-7985
2S-4015	Plunger As-Valve	311-9438
3B-6218	Muffler As	247-2672
3B-8845	Bearing-Inner	417-4509
3F-1972	Retainer As	226-7988

Sales Model D6 (Cont'd.)

09A		
Original Part Number	**Part Name**	**Classic Part Number**
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3S-7153	Gear-Sliding	227-0024
3S-8634	Hub-Gear	219-2977
4B-1455	Cap As-Filler	361-1719
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996
4M-0410	Gear-Oil Pump Dr	428-6660
4S-8005	Pinion-Fdr	226-6076
5A-9551	Gear-Finaldrive	226-7979
5F-2256	Cage-Bearing	226-7973
5F-8651	Bearing-Ball	420-3223
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5M-6709	Check As-Ball	380-7542
5M-9644	Bearing-Outer	384-5929
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665

09A		
Original Part Number	**Part Name**	**Classic Part Number**
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6P-0169	Hub-Fly Clutch	297-7204
6V-2202	Bearing-Spl Ball	380-1574
7B-5088	Drum-Steer Cl Dr	223-4813
7F-9547	Pin As.-Drawbar	295-0414
7G-6044	Cage As	216-7857
7H-1318	Coupling-Ster Cl	226-8002
7H-2424	Sleeve-Spring	226-4852
7H-6967	Bearing-Ball	422-6489
7M-1154	Bearing-Spl	417-4515
7M-4603	Body-Fuel Valve	311-9348
7M-9398	Plate-Guide	297-7230
7S-7602	Pump Gp-Cl Oil	226-0174
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7T-0206	Bearing-Brace	297-7144
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503

09A		
Original Part Number	**Part Name**	**Classic Part Number**
8H-4320	Bearing-Ball	419-2301
8M-6676	Cylinder-Adj	226-4960
8M-8068	Bearing-Spl Ball	417-4500
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
9B-0399	Link As-Cl Drive	431-5268
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-7670	Piston	226-4961
9J-9598	Pin	296-1362
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7534	Pipe-Exh Ext	398-2950
9W-1677	Bearing	297-7145
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
160-6306	Cap-Bearing	325-6038
228-7325	Ster Cl Kit-Cla	230-7119
308-1845	Seal-Wiper	472-8032

09U		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1628	Hub-Gear	219-2977
0R-1642	Hub-Gear	219-2976
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-0176	Flange-Drum	223-4810
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112

09U		
Original Part Number	**Part Name**	**Classic Part Number**
1S-1888	Bracket-Lamp	297-7147
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628

09U		
Original Part Number	**Part Name**	**Classic Part Number**
2F-5721	Bearing-Ball	311-9354
2F-7576	Shaft-Sprocket	226-6071
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4507	Bearing-Sleeve	325-6021

Sales Model D6 (Cont'd.)

09U		
Original Part Number	Part Name	Classic Part Number
2P-7622	Bolt-Spring	226-4850
2P-9660	Gear	226-5995
2S-1273	Chamber As	319-3434
2S-1477	Holder As-Cage	226-7985
2S-4015	Plunger As-Valve	311-9438
3B-6218	Muffler As	247-2672
3B-8845	Bearing-Inner	417-4509
3F-1972	Retainer As	226-7988
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3P-5754	Hub-Gear	219-2976
3S-7153	Gear-Sliding	227-0024
3S-8634	Hub-Gear	219-2977
4B-1455	Cap As-Filler	361-1719
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996
4M-0410	Gear-Oil Pump Dr	428-6660
4S-8005	Pinion-Fdr	226-6076
5A-9551	Gear-Finaldrive	226-7979
5F-2256	Cage-Bearing	226-7973
5F-8651	Bearing-Ball	420-3223
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5M-6709	Check As-Ball	380-7542

09U		
Original Part Number	Part Name	Classic Part Number
5M-9644	Bearing-Outer	384-5929
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6P-0169	Hub-Fly Clutch	297-7204
6V-2202	Bearing-Spl Ball	380-1574
7B-5088	Drum-Steer Cl Dr	223-4813
7F-9547	Pin As.-Drawbar	295-0414
7G-6044	Cage As	216-7857
7H-1318	Coupling-Ster Cl	226-8002
7H-2424	Sleeve-Spring	226-4852
7H-6967	Bearing-Ball	422-6489
7M-1154	Bearing-Spl	417-4515
7M-4603	Body-Fuel Valve	311-9348
7M-9398	Plate-Guide	297-7230
7S-7602	Pump Gp-Cl Oil	226-0174
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417

09U		
Original Part Number	Part Name	Classic Part Number
7T-0206	Bearing-Brace	297-7144
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8H-4320	Bearing-Ball	419-2301
8M-6676	Cylinder-Adj	226-4960
8M-8068	Bearing-Spl Ball	417-4500
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
9B-0399	Link As-Cl Drive	431-5268
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-7670	Piston	226-4961
9J-9598	Pin	296-1362
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7534	Pipe-Exh Ext	398-2950
9W-1677	Bearing	297-7145
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
160-6306	Cap-Bearing	325-6038
228-7325	Ster Cl Kit-Cla	230-7119

Sales Model D6B

37A		
Original Part Number	Part Name	Classic Part Number
0R-1628	Hub-Gear	219-2977
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993

37A		
Original Part Number	Part Name	Classic Part Number
1L-7205	Bearing-Ball	416-2167
1M-0090	Gasket-Manifold	445-7701
1M-0176	Flange-Drum	223-4810
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503

37A		
Original Part Number	Part Name	Classic Part Number
1M-9177	Plate-Cl Press	226-6112
1P-1367	Plunger-Valve	432-8913
1S-1888	Bracket-Lamp	297-7147
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1S-8764	Ring-Fly Clu Adj	226-8014

Sales Model D6B (Cont'd.)

37A		
Original Part Number	Part Name	Classic Part Number
1S-9670	Univ Jt As	443-2017
1T-0210	Bearing-Ball	417-4498
1U-2668	Cartridge Gp	422-8117
1W-7073	Rebuild Kt-Pump	383-3677
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2M-2416	Guard-Idler-Lh	226-4933
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-7622	Bolt-Spring	226-4850
2P-9660	Gear	226-5995
2S-1477	Holder As-Cage	226-7985
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
3B-6218	Muffler As	247-2672
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3S-5017	Elbow-Exhaust	369-9498

37A		
Original Part Number	Part Name	Classic Part Number
3S-7153	Gear-Sliding	227-0024
3S-8634	Hub-Gear	219-2977
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996
4J-2592	Brace As	418-1928
4J-3583	Screw-Adjusting	297-7242
4K-4780	Strip As-Wear	299-2063
4S-6559	Tube	325-6234
4S-8005	Pinion-Fdr	226-6076
5A-9551	Gear-Finaldrive	226-7979
5F-0736	Pin-Pivot	256-4823
5F-2256	Cage-Bearing	226-7973
5F-8651	Bearing-Ball	420-3223
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5J-2528	Plunger	391-1318
5L-7632	Support-Elbow	433-9854
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6P-0169	Hub-Fly Clutch	297-7204
6V-2202	Bearing-Spl Ball	380-1574
7B-5088	Drum-Steer Cl Dr	223-4813
7E-5085	Bushing	377-5829
7F-9547	Pin As.-Drawbar	295-0414
7G-6044	Cage As	216-7857

37A		
Original Part Number	Part Name	Classic Part Number
7H-1318	Coupling-Ster Cl	226-8002
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7602	Pump Gp-Cl Oil	226-0174
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8B-5965	Race & Roller As	417-4512
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8M-6676	Cylinder-Adj	226-4960
8M-8068	Bearing-Spl Ball	417-4500
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1182	Shaft	227-4771

Sales Model D6B (Cont'd.)

37A		
Original Part Number	**Part Name**	**Classic Part Number**
8P-1183	Gear-Bevel	226-7980
8S-1831	Guard As-Sprkt	226-4947
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-7670	Piston	226-4961
9J-9598	Pin	296-1362
9M-4955	Pump Gp-F Tfr	242-3443
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9S-3321	Cage-Pinion Brg	226-7974

37A		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7534	Pipe-Exh Ext	398-2950
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9S-9696	Spider As-Fan	383-3707

37A		
Original Part Number	**Part Name**	**Classic Part Number**
9W-1677	Bearing	297-7145
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
160-6306	Cap-Bearing	325-6038
169-4200	Gasket	472-8023
228-7325	Ster Cl Kit-Cla	230-7119
232-3233	Bearing-Main	376-9085
308-1845	Seal-Wiper	472-8032
1M-7250	Bowl	360-2296
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
121-7746	Pre-Cleaner As	360-2311

38H		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
121-7746	Pre-Cleaner As	360-2311

44A		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1642	Hub-Gear	219-2976
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1L-7205	Bearing-Ball	416-2167
1M-0090	Gasket-Manifold	445-7701
1M-0176	Flange-Drum	223-4810
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1P-1367	Plunger-Valve	432-8913
1S-1888	Bracket-Lamp	297-7147

44A		
Original Part Number	**Part Name**	**Classic Part Number**
1S-5315	Cap As-Brace Brg	226-4848
1S-6422	Pilot As-Spring	226-4849
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1T-0210	Bearing-Ball	417-4498
1U-2668	Cartridge Gp	422-8117
1W-7073	Rebuild Kt-Pump	383-3677
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2F-7576	Shaft-Sprocket	226-6071
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259

44A		
Original Part Number	**Part Name**	**Classic Part Number**
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2M-2416	Guard-Idler-Lh	226-4933
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-7622	Bolt-Spring	226-4850
2P-9660	Gear	226-5995
2S-1477	Holder As-Cage	226-7985
2S-4015	Plunger As-Valve	311-9438

Sales Model D6B (Cont'd.)

44A		
Original Part Number	Part Name	Classic Part Number
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
3B-6218	Muffler As	247-2672
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3P-1465	Spring-Recoil	384-3479
3P-3623	Lock-Adj Nut	226-7989
3P-5754	Hub-Gear	219-2976
3S-5017	Elbow-Exhaust	369-9498
3S-7153	Gear-Sliding	227-0024
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-9040	Nut	226-7996
4J-3583	Screw-Adjusting	297-7242
4K-4780	Strip As-Wear	299-2063
4S-6559	Tube	325-6234
4S-8005	Pinion-Fdr	226-6076
5A-9551	Gear-Finaldrive	226-7979
5F-0736	Pin-Pivot	256-4823
5F-2256	Cage-Bearing	226-7973
5F-8651	Bearing-Ball	420-3223
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5J-2528	Plunger	391-1318
5L-7632	Support-Elbow	433-9854
5M-2824	Coupling-Exhaust	431-5270
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406

44A		
Original Part Number	Part Name	Classic Part Number
5S-1833	Chamber As	247-3298
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6P-0169	Hub-Fly Clutch	297-7204
6V-2202	Bearing-Spl Ball	380-1574
7B-5088	Drum-Steer Cl Dr	223-4813
7E-5085	Bushing	377-5829
7F-9547	Pin As.-Drawbar	295-0414
7G-6044	Cage As	216-7857
7H-1318	Coupling-Ster Cl	226-8002
7H-2424	Sleeve-Spring	226-4852
7H-4710	Bushing-Sleeve	299-1990
7M-1154	Bearing-Spl	417-4515
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7M-9398	Plate-Guide	297-7230
7N-0128	Core As-Oil Clr	299-1994
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-9146	Gear-Fly Starter	279-4995
7S-3206	Seal-O-Ring	436-2656
7S-7602	Pump Gp-Cl Oil	226-0174
7S-7625	Support As	226-6095
7S-7809	Cap As-Radiator	295-6417
7T-0206	Bearing-Brace	297-7144
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8B-5965	Race & Roller As	417-4512

44A		
Original Part Number	Part Name	Classic Part Number
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8M-6676	Cylinder-Adj	226-4960
8M-8068	Bearing-Spl Ball	417-4500
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8S-1831	Guard As-Sprkt	226-4947
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp-F Prm	311-9443
9H-7670	Piston	226-4961
9J-9598	Pin	296-1362
9M-4955	Pump Gp-F Tfr	242-3443
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7534	Pipe-Exh Ext	398-2950
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244

Sales Model D6B (Cont'd.)

44A		
Original Part Number	**Part Name**	**Classic Part Number**
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855

44A		
Original Part Number	**Part Name**	**Classic Part Number**
9S-8358	Guard As-Guiding	226-4856
9S-9696	Spider As-Fan	383-3707
9W-1677	Bearing	297-7145
108-5603	Screw-Adj Arm	379-0166

44A		
Original Part Number	**Part Name**	**Classic Part Number**
121-7746	Pre-Cleaner As	360-2311
160-6306	Cap-Bearing	325-6038
169-4200	Gasket	472-8023
228-7325	Ster Cl Kit-Cla	230-7119
232-3233	Bearing-Main	376-9085
308-1845	Seal-Wiper	472-8032

57A		
Original Part Number	**Part Name**	**Classic Part Number**
4J-2414	Trunnion	296-1370
5F-0736	Pin-Pivot	256-4823

57A		
Original Part Number	**Part Name**	**Classic Part Number**
9W-1677	Bearing	297-7145
160-6306	Cap-Bearing	325-6038

Sales Model D6C

10K		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1635	Hub-Gear	222-1763
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-1994	Bearing As-Rlr	399-6066
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-8736	Cup-Roller Brg	423-7759
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-4304	Head Gp-Cyl -A	269-8761
1P-0963	Guard As-Roller	226-0179

10K		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-1897	Gear-Final Drive	215-1670
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1P-6752	Pump Gp-Gr 1 Bsc	226-0161
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014

10K		
Original Part Number	**Part Name**	**Classic Part Number**
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-2668	Cartridge Gp	422-8117
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981

Sales Model D6C (Cont'd.)

10K		
Original Part Number	Part Name	Classic Part Number
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2B-8824	Drum	216-7817
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2H-6936	Disc-Steer Cl Dr	380-7471
2H-9192	Bearing-Ball	394-8236
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2M-1086	Plate As-Press	226-8023
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

10K		
Original Part Number	Part Name	Classic Part Number
2P-2719	Pipe-Oil Filler	363-7454
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-3767	Tube-Disposal	377-5850
2P-4370	Plate-Clutch	325-6166
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-4365	Retainer As	216-3554
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
2S-7931	Bearing-Sleeve	387-2904
2V-7198	Pilot As-Rec Spg	302-2709
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3G-7655	Cartridge Gp	422-8119
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922

10K		
Original Part Number	Part Name	Classic Part Number
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3K-0526	Bearing-Ball	386-4949
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6816	Pump Gp-Gr 1	226-0164
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3S-5017	Elbow-Exhaust	369-9498
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-4065	Rod End-Spher	374-1824
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242

Sales Model D6C (Cont'd.)

10K		
Original Part Number	Part Name	Classic Part Number
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-0255	Retainer As	226-6102
4K-4780	Strip As-Wear	299-2063
4K-4894	Cage-Bearing	453-0968
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4N-9213	Elbow-Exhaust	330-9270
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8708	Housing-Clutch	216-3557

10K		
Original Part Number	Part Name	Classic Part Number
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204
4T-1893	Cartridge Gp	422-8110
4T-6151	Trunnion	295-5671
4T-6869	Cartridge Gp	422-8104
4T-8054	Seal As	472-8010
4V-2744	Gear	224-1303
4V-3396	Hub-Gear	222-1763
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-7188	Core As-Oclr	374-7501
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5G-3612	Cap Gp-Protn	295-6419
5H-5500	Collar-Fly Cl	302-2704
5J-2528	Plunger	391-1318
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525

10K		
Original Part Number	Part Name	Classic Part Number
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1168	Spider & Brg As	377-7435
6B-3223	Cup-Bearing	399-6065
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8132	Pinion	226-6080
6I-8849	Cone-Rlr Bearing	415-1919

Sales Model D6C (Cont'd.)

10K		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-4617	Shaft-Sprocket	221-7951
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0622	Elbow-Exhaust	380-7534
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2549	Mount As	384-3467
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0169	Hub-Fly Clutch	297-7204
6T-0956	Pad As	367-6088
6T-1711	Plate	389-6324
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
6W-0240	Bearing-Brace	297-7143
6Y-5916	Disc-Friction	377-7442
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-4605	Support As	387-2938

10K		
Original Part Number	Part Name	Classic Part Number
7G-6042	Cage As	216-7856
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7J-9884	Bearing-Sleeve	325-6016
7K-4458	Gear-Final Drive	226-6093
7K-4512	Pinion-Fdr	226-6081
7K-4770	Pinion	226-6082
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-1154	Bearing-Spl	417-4515
7M-1296	Valve-Relief	390-0990
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779

10K		
Original Part Number	Part Name	Classic Part Number
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7602	Pump Gp-Cl Oil	226-0174
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-1174	Drum-Ster Cl Dr	226-6101
8H-7577	Plate-Locking	392-4486

Sales Model D6C (Cont'd.)

10K		
Original Part Number	Part Name	Classic Part Number
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8K-9661	Gear-Bevel	213-8218
8M-0874	Plunger As-Valve	311-9439
8M-6191	Sleeve-Bolt	226-0234
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556

10K		
Original Part Number	Part Name	Classic Part Number
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988

10K		
Original Part Number	Part Name	Classic Part Number
9G-8303	Collar-Idler End	226-0242
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9H-7670	Piston	226-4961
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-2759	Trunnion	394-0216
9J-5048	Pump Gp-Vn Bsc-A	422-8166
9J-9598	Pin	296-1362
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5045	Guard As-Wear	213-9111
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-9000	Shaft-Ster Cl	217-7738

Sales Model D6C (Cont'd.)

10K		
Original Part Number	Part Name	Classic Part Number
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-2356	Manifold-Exhaust	261-0905
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712

10K		
Original Part Number	Part Name	Classic Part Number
9S-9696	Spider As-Fan	383-3707
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202

10K		
Original Part Number	Part Name	Classic Part Number
172-6712	Impeller-Pump	325-6112
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
230-7114	Ster Cl Kit-Cla	219-9690
231-1937	Kit-Strg Cl-Cla	226-6101
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
235-1803	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
297-7245	Shaft-Cla	215-1694
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

17R		
Original Part Number	Part Name	Classic Part Number
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-6573	Cup-Roller Brg	399-4438
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046

17R		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-0963	Guard As-Roller	226-0179
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-1943	Gear-Idler	446-3067
1P-4303	Head As-Cylinder	242-3434

17R		
Original Part Number	Part Name	Classic Part Number
1P-7936	Spider As-Fan	383-3673
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212

Sales Model D6C (Cont'd.)

17R		
Original Part Number	Part Name	Classic Part Number
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-4365	Retainer As	216-3554
2S-5100	Valve-Ball	386-3049

17R		
Original Part Number	Part Name	Classic Part Number
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
3B-8845	Bearing-Inner	417-4509
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4864	Pump Gp-F Tfr	242-3442

17R		
Original Part Number	Part Name	Classic Part Number
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8472	Hood As-Preclnr	296-1355
4S-9062	Cap-Fd Bearing	226-0204
4W-0452	Seal As -Cshaft	325-6191
5G-3612	Cap Gp-Protn	295-6419
5H-5500	Collar-Fly Cl	302-2704
5L-6326	Bearing-Ball	420-3222
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7341	Cover-Bearing	452-0443
5M-7342	Flange-Shaft	215-1696
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

Sales Model D6C (Cont'd.)

17R		
Original Part Number	Part Name	Classic Part Number
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0169	Hub-Fly Clutch	297-7204
6T-0956	Pad As	367-6088
6T-1711	Plate	389-6324
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312

17R		
Original Part Number	Part Name	Classic Part Number
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-0859	Fork As-Shift	297-7172
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191

17R		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7T-9931	Countershaft	215-1760
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3312	Shaft As-Rkr Arm	325-6200

Sales Model D6C (Cont'd.)

17R		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8303	Collar-Idler End	226-0242
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891

17R		
Original Part Number	Part Name	Classic Part Number
9M-0701	Piston-Steer Cl	219-9692
9M-2744	Cone-Spl Tapered	380-1480
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8679	Chamber As	325-6042

17R		
Original Part Number	Part Name	Classic Part Number
9S-9696	Spider As-Fan	383-3707
9W-0550	Shaft-Xmsn Upper	226-6000
9W-0551	Shaft-Pinion	388-6592
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
131-3815	Seal Gp-Basic	325-6193
131-6091	Gear-Sliding	385-7201
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
226-8202	Seal-Wiper	472-8024
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

Sales Model D6C (Cont'd.)

23U		
Original Part Number	Part Name	Classic Part Number
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-6573	Cup-Roller Brg	399-4438
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260

23U		
Original Part Number	Part Name	Classic Part Number
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4507	Bearing-Sleeve	325-6021
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1503	Gear-First	213-8637
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-3803	Gear	226-6106
2S-3804	Gear-Sliding	226-6107
2S-4365	Retainer As	216-3554
2S-5100	Valve-Ball	386-3049
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055

23U		
Original Part Number	Part Name	Classic Part Number
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-4284	Cap-Brg	314-8656
3J-6559	Cap-Bearing	296-1346
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3241	Plate-Pressure	325-6167
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6814	Pump Gp-Gr 1	226-0163
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-4065	Rod End-Spher	374-1824
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499

Sales Model D6C (Cont'd.)

23U		
Original Part Number	**Part Name**	**Classic Part Number**
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-9062	Cap-Fd Bearing	226-0204
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5H-5500	Collar-Fly Cl	302-2704
5M-5073	Joint Gp-Univ	325-6113
5M-5856	Pipe-Extension	373-1913
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376

23U		
Original Part Number	**Part Name**	**Classic Part Number**
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7340	Cage-Bearing	325-6034
5M-7341	Cover-Bearing	452-0443
5M-7342	Flange-Shaft	215-1696
5M-7344	Gear-Fifth	213-8741
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386

23U		
Original Part Number	**Part Name**	**Classic Part Number**
6P-0169	Hub-Fly Clutch	297-7204
6T-0956	Pad As	367-6088
6T-1711	Plate	389-6324
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-0859	Fork As-Shift	297-7172
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173

Sales Model D6C (Cont'd.)

23U		
Original Part Number	Part Name	Classic Part Number
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-9931	Countershaft	215-1760
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8E-5993	Gear As-Idler	215-1903
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636

23U		
Original Part Number	Part Name	Classic Part Number
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585

23U		
Original Part Number	Part Name	Classic Part Number
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314
8P-3377	Tube As	392-4498
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8303	Collar-Idler End	226-0242
9J-2007	Piston As	419-4714
9J-9598	Pin	296-1362
9M-0701	Piston-Steer Cl	219-9692
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-3025	Cover As	299-2001
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558

Sales Model D6C (Cont'd.)

23U		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6590	Pump Gp-Cl Oil	226-0176
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-0550	Shaft-Xmsn Upper	226-6000
9W-0552	Shaft-Pinion	226-6001
9Y-1798	Seal-Water	379-0165

23U		
Original Part Number	Part Name	Classic Part Number
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

23U		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

24U		
Original Part Number	Part Name	Classic Part Number
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-4110	Disc-Friction	433-9858
1P-9945	Bracket As-Fan	296-1344

24U		
Original Part Number	Part Name	Classic Part Number
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685

24U		
Original Part Number	Part Name	Classic Part Number
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158

Sales Model D6C (Cont'd.)

24U		
Original Part Number	Part Name	Classic Part Number
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2K-4507	Bearing-Sleeve	325-6021
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-4365	Retainer As	216-3554
2S-5100	Valve-Ball	386-3049
2S-6263	Guard Gp-Spring	226-0192

24U		
Original Part Number	Part Name	Classic Part Number
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6816	Pump Gp-Gr 1	226-0164
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-4065	Rod End-Spher	374-1824
4F-5004	Spring As-Arm	383-2128
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764

24U		
Original Part Number	Part Name	Classic Part Number
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433

Sales Model D6C (Cont'd.)

24U		
Original Part Number	Part Name	Classic Part Number
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358

24U		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6T-0956	Pad As	367-6088
6T-1711	Plate	389-6324
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6Y-5916	Disc-Friction	377-7442
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-1154	Bearing-Spl	417-4515
7M-1296	Valve-Relief	390-0990
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207

24U		
Original Part Number	Part Name	Classic Part Number
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3521	Core As-O Clr	383-3699
7N-3536	Gear-Fuel	279-4993
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684

Sales Model D6C (Cont'd.)

24U		
Original Part Number	Part Name	Classic Part Number
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564

24U		
Original Part Number	Part Name	Classic Part Number
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372

24U		
Original Part Number	Part Name	Classic Part Number
9B-1320	Valve-Check	377-5832
9G-8303	Collar-Idler End	226-0242
9J-9598	Pin	296-1362
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-3025	Cover As	299-2001
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945

Sales Model D6C (Cont'd.)

24U		
Original Part Number	Part Name	Classic Part Number
9S-5267	Carrier As	392-4512
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351

24U		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876

24U		
Original Part Number	Part Name	Classic Part Number
219-9693	Shaft-Classic	217-7738
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
235-1803	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420

26K		
Original Part Number	Part Name	Classic Part Number
1M-6573	Cup-Roller Brg	399-4438
1M-7250	Bowl	360-2296
1W-3900	Gasket	472-8006
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2F-5721	Bearing-Ball	311-9354
2K-4507	Bearing-Sleeve	325-6021
2P-0220	Gasket-Pump	398-2927
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711

26K		
Original Part Number	Part Name	Classic Part Number
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4F-1252	Pin	295-5704
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267

26K		
Original Part Number	Part Name	Classic Part Number
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4N-7693	Crankshaft As	269-8763
4T-6151	Trunnion	295-5671
4T-8054	Seal As	472-8010
5M-6637	Bearing-Sleeve	380-7376
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5S-4557	Bearing	311-9360

Sales Model D6C (Cont'd.)

26K		
Original Part Number	Part Name	Classic Part Number
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6N-7263	Gasket-Cyl Head	380-7386
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
7C-4297	Seal As-Cshaft	325-6192
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932

26K		
Original Part Number	Part Name	Classic Part Number
7J-9344	Bearing-Sleeve	360-2334
7J-9842	Bearing-Sleeve	299-1968
7S-3206	Seal-O-Ring	436-2656
8H-9789	Bearing-Ball	374-8342
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9M-2744	Cone-Spl Tapered	380-1480

26K		
Original Part Number	Part Name	Classic Part Number
9M-5045	Guard As-Wear	213-9111
9T-4761	Head	325-6108
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
160-6305	Cap-Bearing	295-5686
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

41A		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296

41A		
Original Part Number	Part Name	Classic Part Number
9M-5045	Guard As-Wear	213-9111
121-7746	Pre-Cleaner As	360-2311

46J		
Original Part Number	Part Name	Classic Part Number
1M-6573	Cup-Roller Brg	399-4438
1W-3900	Gasket	472-8006
2P-0220	Gasket-Pump	398-2927
3B-8845	Bearing-Inner	417-4509
3J-6559	Cap-Bearing	296-1346
3L-1425	Bearing-Ball	311-9356
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4J-6326	Bearing-Half	376-3630
4W-0452	Seal As -Cshaft	325-6191
5M-6637	Bearing-Sleeve	380-7376
5P-5066	Bearing-Outer	416-2165

46J		
Original Part Number	Part Name	Classic Part Number
5P-5067	Race-Spl Rlr Brg	396-4137
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
6N-7263	Gasket-Cyl Head	380-7386
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1339	Gasket Kit	388-0651
7C-0307	Gasket	399-8571
7C-4297	Seal As-Cshaft	325-6192
7N-7386	Gasket-Cyl Head	392-4519

46J		
Original Part Number	Part Name	Classic Part Number
7N-8018	Seal-Water	418-1964
7S-3206	Seal-O-Ring	436-2656
7W-7546	Gasket-Plate	433-8187
8C-8741	Kit-Gasket-(Rs)	438-0172
8H-9789	Bearing-Ball	374-8342
8S-9686	Gasket Kit	393-5215
9M-2744	Cone-Spl Tapered	380-1480
9Y-1798	Seal-Water	379-0165
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
391-8229	Kit-Gasket-Fs	398-2955

Sales Model D6C (Cont'd.)

47J		
Original Part Number	Part Name	Classic Part Number
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1T-0043	Bearing-Ball	390-5294
1T-0441	Bearing-Ball	449-4738
1T-0902	Bearing-Sleeve	389-6326
1W-3900	Gasket	472-8006
2P-0220	Gasket-Pump	398-2927
3J-6559	Cap-Bearing	296-1346
3L-1425	Bearing-Ball	311-9356
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4J-6326	Bearing-Half	376-3630
4W-0452	Seal As -Cshaft	325-6191
5M-6126	Bearing	377-7433
5M-6637	Bearing-Sleeve	380-7376
5M-7936	Bearing-Outer	386-4953

47J		
Original Part Number	Part Name	Classic Part Number
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
6N-7263	Gasket-Cyl Head	380-7386
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1339	Gasket Kit	388-0651
7C-4297	Seal As-Cshaft	325-6192
7M-1154	Bearing-Spl	417-4515
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7S-3206	Seal-O-Ring	436-2656

47J		
Original Part Number	Part Name	Classic Part Number
7W-7546	Gasket-Plate	433-8187
8C-8741	Kit-Gasket-(Rs)	438-0172
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8S-9686	Gasket Kit	393-5215
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
9M-2744	Cone-Spl Tapered	380-1480
9Y-1798	Seal-Water	379-0165
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
391-8229	Kit-Gasket-Fs	398-2955

49W		
Original Part Number	Part Name	Classic Part Number
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1T-0441	Bearing-Ball	449-4738
1T-0902	Bearing-Sleeve	389-6326
1W-7082	Rebuild Kt-Pump	383-3681
2F-5721	Bearing-Ball	311-9354
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
5G-3612	Cap Gp-Protn	295-6419
5M-6126	Bearing	377-7433
5M-6637	Bearing-Sleeve	380-7376

49W		
Original Part Number	Part Name	Classic Part Number
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
6N-7263	Gasket-Cyl Head	380-7386
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
7F-9541	Pin As-Drawbar	296-1361

49W		
Original Part Number	Part Name	Classic Part Number
7F-9547	Pin As.-Drawbar	295-0414
7M-1154	Bearing-Spl	417-4515
7T-2036	Cap As-Fuel	361-1721
8H-8175	Bearing-Sleeve	376-3636
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
9M-2744	Cone-Spl Tapered	380-1480
106-7799	Bearing-Ball	396-9947
124-3237	Precleaner As	432-4220

55J		
Original Part Number	Part Name	Classic Part Number
1M-6573	Cup-Roller Brg	399-4438
3B-8845	Bearing-Inner	417-4509

Sales Model D6C (Cont'd.)

55J		
Original Part Number	Part Name	Classic Part Number
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
5M-6637	Bearing-Sleeve	380-7376
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
9M-2744	Cone-Spl Tapered	380-1480

55J		
Original Part Number	Part Name	Classic Part Number
1M-4095	Bearing-Inner	
1M-6573	Cup-Roller Brg	
1T-0441	Bearing-Ball	
1T-0902	Bearing-Sleeve	
4B-9373	Cone-Roller Brg	
4B-9374	Bearing-Cup	
5M-6126	Bearing	
5M-6637	Bearing-Sleeve	
5M-7936	Bearing-Outer	
5M-9644	Bearing-Outer	
5P-5066	Bearing-Outer	
5P-5067	Race-Spl Rlr Brg	

55J		
Original Part Number	Part Name	Classic Part Number
5P-9176	Bearing	
5P-9177	Race-Brg Inner	
6V-1013	Bearing	
6V-1014	Race-Spl Rlr Brg	
7M-1154	Bearing-Spl	
8H-8175	Bearing-Sleeve	
9M-1997	Bearing-Ball	
9M-2042	Race-Roller Brg	
9M-2744	Cone-Spl Tapered	
106-7799	Bearing-Ball	

69J		
Original Part Number	Part Name	Classic Part Number
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-7250	Bowl	360-2296
1T-0043	Bearing-Ball	390-5294
1T-0441	Bearing-Ball	449-4738
1T-0902	Bearing-Sleeve	389-6326
1W-3900	Gasket	472-8006
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2F-5721	Bearing-Ball	311-9354
2K-4507	Bearing-Sleeve	325-6021
2P-0220	Gasket-Pump	398-2927
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346

69J		
Original Part Number	Part Name	Classic Part Number
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4F-1252	Pin	295-5704
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407

69J		
Original Part Number	Part Name	Classic Part Number
4N-7693	Crankshaft As	269-8763
4T-6151	Trunnion	295-5671
4T-8054	Seal As	472-8010
5M-6126	Bearing	377-7433
5M-6637	Bearing-Sleeve	380-7376
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5S-4557	Bearing	311-9360
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6N-7263	Gasket-Cyl Head	380-7386
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173

Sales Model D6C (Cont'd.)

69J		
Original Part Number	Part Name	Classic Part Number
7C-4297	Seal As-Cshaft	325-6192
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7J-9344	Bearing-Sleeve	360-2334
7J-9842	Bearing-Sleeve	299-1968
7M-1154	Bearing-Spl	417-4515
7S-3206	Seal-O-Ring	436-2656
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-8221	Bearing-Conn Rod	419-6377

69J		
Original Part Number	Part Name	Classic Part Number
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8P-7790	Valve Gp-Press	247-4437
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
9M-2744	Cone-Spl Tapered	380-1480
9M-5045	Guard As-Wear	213-9111

69J		
Original Part Number	Part Name	Classic Part Number
9T-4761	Head	325-6108
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
160-6305	Cap-Bearing	295-5686
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

69U		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1P-0963	Guard As-Roller	226-0179
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1P-6752	Pump Gp-Gr 1 Bsc	226-0161
1P-7895	Cone-Roller Brg	396-4145

69U		
Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326

69U		
Original Part Number	Part Name	Classic Part Number
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927

Sales Model D6C (Cont'd.)

69U		
Original Part Number	Part Name	Classic Part Number
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-4365	Retainer As	216-3554
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-7603	Drum-Steer Cl Dr	213-6951
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-4284	Cap-Brg	314-8656
3J-6559	Cap-Bearing	296-1346
3K-0526	Bearing-Ball	386-4949
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165

69U		
Original Part Number	Part Name	Classic Part Number
3P-6816	Pump Gp-Gr 1	226-0164
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-4065	Rod End-Spher	374-1824
4F-5004	Spring As-Arm	383-2128
4J-1616	Bracket	299-1982
4J-1999	Ballstud	314-8625
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838

69U		
Original Part Number	Part Name	Classic Part Number
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-7188	Core As-Oclr	374-7501
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5A-7840	Shaft-Tr Sprkt	215-1687
5G-3612	Cap Gp-Protn	295-6419
5L-6326	Bearing-Ball	420-3222
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953

Sales Model D6C (Cont'd.)

69U		
Original Part Number	Part Name	Classic Part Number
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544

69U		
Original Part Number	Part Name	Classic Part Number
6N-7263	Gasket-Cyl Head	380-7386
6T-0956	Pad As	367-6088
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-1154	Bearing-Spl	417-4515
7M-1296	Valve-Relief	390-0990
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239

69U		
Original Part Number	Part Name	Classic Part Number
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249

Sales Model D6C (Cont'd.)

69U		
Original Part Number	Part Name	Classic Part Number
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-6868	Cyl Gp-040 405 X	430-5964
8M-0874	Plunger As-Valve	311-9439
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

69U		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1851	Hub As-Sprocket	224-1314
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9G-8303	Collar-Idler End	226-0242
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-2007	Piston As	419-4714
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875

69U		
Original Part Number	Part Name	Classic Part Number
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244

Sales Model D6C (Cont'd.)

69U		
Original Part Number	Part Name	Classic Part Number
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9T-4761	Head	325-6108
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193

69U		
Original Part Number	Part Name	Classic Part Number
160-6305	Cap-Bearing	295-5686
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
230-7114	Ster Cl Kit-Cla	219-9690

69U		
Original Part Number	Part Name	Classic Part Number
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
235-1803	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

71A		
Original Part Number	Part Name	Classic Part Number
7M-2531	Rod-Tie	297-7239

73A		
Original Part Number	Part Name	Classic Part Number
1M-4095	Bearing-Inner	417-9486
1T-0441	Bearing-Ball	449-4738
1T-0902	Bearing-Sleeve	389-6326
5M-6126	Bearing	377-7433

73A		
Original Part Number	Part Name	Classic Part Number
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
7M-1154	Bearing-Spl	417-4515
7M-2531	Rod-Tie	297-7239
8H-8175	Bearing-Sleeve	376-3636

73A		
Original Part Number	Part Name	Classic Part Number
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
106-7799	Bearing-Ball	396-9947

74A		
Original Part Number	Part Name	Classic Part Number
0R-1651	Hub-Gear	211-2135
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1L-7205	Bearing-Ball	416-2167
1M-0090	Gasket-Manifold	445-7701
1M-5270	Pipe-Extension	367-6065
1M-6573	Cup-Roller Brg	399-4438

74A		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1P-0963	Guard As-Roller	226-0179
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1S-1888	Bracket-Lamp	297-7147

74A		
Original Part Number	Part Name	Classic Part Number
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1U-3953	Cartridge Gp	426-0024
1W-7072	Rebuild Kt-Pump	428-6657
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944

Sales Model D6C (Cont'd.)

74A		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-3486	Gasket Kt-V G	438-0179
2S-3803	Gear	226-6106
2S-3804	Gear-Sliding	226-6107
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-4365	Retainer As	216-3554
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-6739	Pulley-Tightener	298-2794
2S-7603	Drum-Steer Cl Dr	213-6951
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588

74A		
Original Part Number	Part Name	Classic Part Number
3F-6612	Cap-Ball Joint	297-7155
3G-7655	Cartridge Gp	422-8119
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3241	Plate-Pressure	325-6167
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6814	Pump Gp-Gr 1	226-0163
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3S-5017	Elbow-Exhaust	369-9498
3T-1898	Drum	219-9674
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242

74A		
Original Part Number	Part Name	Classic Part Number
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-9062	Cap-Fd Bearing	226-0204
4T-6151	Trunnion	295-5671
5H-5500	Collar-Fly Cl	302-2704
5H-7071	Director-Water	388-0555
5J-2528	Plunger	391-1318
5L-7632	Support-Elbow	433-9854
5M-5073	Joint Gp-Univ	325-6113
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7340	Cage-Bearing	325-6034
5M-7341	Cover-Bearing	452-0443
5M-7342	Flange-Shaft	215-1696
5M-7344	Gear-Fifth	213-8741
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-6531	Holder As-Cage	214-2078
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738

Sales Model D6C (Cont'd.)

74A		
Original Part Number	Part Name	Classic Part Number
6F-2904	Bearing	295-5673
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6P-0169	Hub-Fly Clutch	297-7204
6T-0956	Pad As	367-6088
6T-1711	Plate	389-6324
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-0859	Fork As-Shift	297-7172
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7N-2957	Cover-Rad Cap	361-1722

74A		
Original Part Number	Part Name	Classic Part Number
7N-5511	Gear As-Idler	233-2180
7N-6677	Core As-O Clr	299-1995
7N-7386	Gasket-Cyl Head	392-4519
7N-9146	Gear-Fly Starter	279-4995
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-9931	Countershaft	215-1760
7W-1927	Ring-Retainer	387-2935
8B-5965	Race & Roller As	417-4512
8E-5993	Gear As-Idler	215-1903
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314

74A		
Original Part Number	Part Name	Classic Part Number
8S-9686	Gasket Kit	393-5215
9F-7101	Bushing-Collar	299-1988
9G-8303	Collar-Idler End	226-0242
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9M-0701	Piston-Steer Cl	219-9692
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-3025	Cover As	299-2001
9M-4955	Pump Gp-F Tfr	242-3443
9M-5045	Guard As-Wear	213-9111
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9M-8395	Bearing-Sleeve	391-1103
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6590	Pump Gp-Cl Oil	226-0176
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-9696	Spider As-Fan	383-3707

Sales Model D6C (Cont'd.)

74A		
Original Part Number	Part Name	Classic Part Number
9W-0550	Shaft-Xmsn Upper	226-6000
108-5603	Screw-Adj Arm	379-0166

74A		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
160-6305	Cap-Bearing	295-5686
169-4200	Gasket	472-8023
219-9693	Shaft-Classic	217-7738

74A		
Original Part Number	Part Name	Classic Part Number
219-9693	Shaft-Classic	216-7876
232-3233	Bearing-Main	376-9085
308-1845	Seal-Wiper	472-8032

76A		
Original Part Number	Part Name	Classic Part Number
0R-1651	Hub-Gear	211-2135
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1L-7205	Bearing-Ball	416-2167
1M-0090	Gasket-Manifold	445-7701
1M-4095	Bearing-Inner	417-9486
1M-5270	Pipe-Extension	367-6065
1M-6573	Cup-Roller Brg	399-4438
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9444	Retainer-Spring	299-2046
1P-0963	Guard As-Roller	226-0179
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-4110	Disc-Friction	433-9858
1S-1888	Bracket-Lamp	297-7147
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368

76A		
Original Part Number	Part Name	Classic Part Number
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-3953	Cartridge Gp	426-0024
1W-7072	Rebuild Kt-Pump	428-6657
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-3486	Gasket Kt-V G	438-0179
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-4365	Retainer As	216-3554
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6263	Guard Gp-Spring	226-0192

76A		
Original Part Number	Part Name	Classic Part Number
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-6739	Pulley-Tightener	298-2794
2S-7603	Drum-Steer Cl Dr	213-6951
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3G-7655	Cartridge Gp	422-8119
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6816	Pump Gp-Gr 1	226-0164
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849

Sales Model D6C (Cont'd.)

76A		
Original Part Number	Part Name	Classic Part Number
3S-5017	Elbow-Exhaust	369-9498
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-5004	Spring As-Arm	383-2128
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204
4T-6151	Trunnion	295-5671
4Y-0709	Disc-Friction	377-7431
5H-7071	Director-Water	388-0555
5J-2528	Plunger	391-1318
5L-7632	Support-Elbow	433-9854
5M-5822	Gear-Pump Drive	247-4120
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694

76A		
Original Part Number	Part Name	Classic Part Number
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-6531	Holder As-Cage	214-2078
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6F-2904	Bearing	295-5673
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844

76A		
Original Part Number	Part Name	Classic Part Number
6J-8183	Bracket	394-0195
6T-0956	Pad As	367-6088
6T-1711	Plate	389-6324
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
7E-5085	Bushing	377-5829
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-1154	Bearing-Spl	417-4515
7M-1296	Valve-Relief	390-0990
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7N-2957	Cover-Rad Cap	361-1722
7N-5511	Gear As-Idler	233-2180

Sales Model D6C (Cont'd.)

76A		
Original Part Number	Part Name	Classic Part Number
7N-6677	Core As-O Clr	299-1995
7N-7386	Gasket-Cyl Head	392-4519
7N-9146	Gear-Fly Starter	279-4995
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-1927	Ring-Retainer	387-2935
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083

76A		
Original Part Number	Part Name	Classic Part Number
8N-8229	Bearing-Main	376-9084
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-9686	Gasket Kit	393-5215
9G-8303	Collar-Idler End	226-0242
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2038	Gear-Tfr Driven	215-1876
9M-2039	Gear-Tfr Driving	219-9672
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-3025	Cover As	299-2001
9M-4955	Pump Gp-F Tfr	242-3443
9M-5045	Guard As-Wear	213-9111
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8395	Bearing-Sleeve	391-1103
9P-0566	Case-Fdr	419-1861

76A		
Original Part Number	Part Name	Classic Part Number
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
106-7799	Bearing-Ball	396-9947
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
160-6305	Cap-Bearing	295-5686
169-4200	Gasket	472-8023
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
235-1803	Tc Kit-Cla	235-0920
297-7245	Shaft-Cla	215-1694
308-1845	Seal-Wiper	472-8032
368-0297	Plate-Clutch	377-7420

Sales Model D6C (Cont'd.)

83A		
Original Part Number	**Part Name**	**Classic Part Number**
1M-4095	Bearing-Inner	417-9486
1T-0441	Bearing-Ball	449-4738
1T-0902	Bearing-Sleeve	389-6326
5M-6126	Bearing	377-7433

83A		
Original Part Number	**Part Name**	**Classic Part Number**
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
7M-1154	Bearing-Spl	417-4515
8H-8175	Bearing-Sleeve	376-3636

83A		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
106-7799	Bearing-Ball	396-9947

90B		
Original Part Number	**Part Name**	**Classic Part Number**
1M-6573	Cup-Roller Brg	399-4438
1W-3900	Gasket	472-8006
1W-9812	Gear-Crankshaft	380-1513
2P-0220	Gasket-Pump	398-2927
2P-1503	Gear-First	213-8637
2S-3803	Gear	226-6106
2S-3804	Gear-Sliding	226-6107
3B-8845	Bearing-Inner	417-4509
3P-7640	Gear-Ctrshft	325-6093
3P-7641	Gear-Ctrshft	325-6094
3P-7643	Gear-Pinion Shft	302-2669
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4N-7693	Crankshaft As	269-8763
5M-6637	Bearing-Sleeve	380-7376
5M-7340	Cage-Bearing	325-6034
5M-7341	Cover-Bearing	452-0443

90B		
Original Part Number	**Part Name**	**Classic Part Number**
5M-7342	Flange-Shaft	215-1696
5M-7344	Gear-Fifth	213-8741
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
6N-7263	Gasket-Cyl Head	380-7386
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
7C-4297	Seal As-Cshaft	325-6192
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7T-9931	Countershaft	215-1760
8E-5993	Gear As-Idler	215-1903

90B		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
9M-2744	Cone-Spl Tapered	380-1480
9W-0550	Shaft-Xmsn Upper	226-6000
9W-0552	Shaft-Pinion	226-6001
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

96A		
Original Part Number	**Part Name**	**Classic Part Number**
1M-4095	Bearing-Inner	417-9486
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296
1T-0043	Bearing-Ball	390-5294
1T-0441	Bearing-Ball	449-4738
1T-0902	Bearing-Sleeve	389-6326
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691

96A		
Original Part Number	**Part Name**	**Classic Part Number**
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
5M-6126	Bearing	377-7433
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
7M-1154	Bearing-Spl	417-4515
7N-6677	Core As-O Clr	299-1995
8H-8175	Bearing-Sleeve	376-3636

96A		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
9M-5045	Guard As-Wear	213-9111
106-7799	Bearing-Ball	396-9947
121-7746	Pre-Cleaner As	360-2311

Sales Model D6C (Cont'd.)

99J		
Original Part Number	Part Name	Classic Part Number
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-6573	Cup-Roller Brg	399-4438
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1P-0963	Guard As-Roller	226-0179
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4303	Head As-Cylinder	242-3434
1P-6752	Pump Gp-Gr 1 Bsc	226-0161
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513

99J		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1503	Gear-First	213-8637
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-3767	Tube-Disposal	377-5850
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-3803	Gear	226-6106
2S-3804	Gear-Sliding	226-6107
2S-4365	Retainer As	216-3554

99J		
Original Part Number	Part Name	Classic Part Number
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7458	Crankshaft As	242-3439
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3G-7655	Cartridge Gp	422-8119
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3K-0526	Bearing-Ball	386-4949
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448

Sales Model D6C (Cont'd.)

99J		
Original Part Number	Part Name	Classic Part Number
3P-3241	Plate-Pressure	325-6167
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6814	Pump Gp-Gr 1	226-0163
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3S-5017	Elbow-Exhaust	369-9498
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-4065	Rod End-Spher	374-1824
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364

99J		
Original Part Number	Part Name	Classic Part Number
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4N-9213	Elbow-Exhaust	330-9270
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-9062	Cap-Fd Bearing	226-0204
4T-1893	Cartridge Gp	422-8110
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5G-3612	Cap Gp-Protn	295-6419
5H-5500	Collar-Fly Cl	302-2704
5J-2528	Plunger	391-1318
5L-6326	Bearing-Ball	420-3222
5M-5073	Joint Gp-Univ	325-6113
5M-5856	Pipe-Extension	373-1913
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7340	Cage-Bearing	325-6034
5M-7341	Cover-Bearing	452-0443
5M-7342	Flange-Shaft	215-1696

99J		
Original Part Number	Part Name	Classic Part Number
5M-7344	Gear-Fifth	213-8741
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6L-7751	Rod End-Spher	472-8015
6N-0622	Elbow-Exhaust	380-7534
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2549	Mount As	384-3467
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903

Sales Model D6C (Cont'd.)

99J		
Original Part Number	Part Name	Classic Part Number
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0169	Hub-Fly Clutch	297-7204
6T-0956	Pad As	367-6088
6T-1711	Plate	389-6324
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7J-9884	Bearing-Sleeve	325-6016
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-0859	Fork As-Shift	297-7172
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225

99J		
Original Part Number	Part Name	Classic Part Number
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721

99J		
Original Part Number	Part Name	Classic Part Number
7T-9931	Countershaft	215-1760
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8C-8741	Kit-Gasket-(Rs)	438-0172
8E-5993	Gear As-Idler	215-1903
8F-6058	Bearing-Sleeve	416-5494
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8M-0874	Plunger As-Valve	311-9439
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564

Sales Model D6C (Cont'd.)

99J		
Original Part Number	Part Name	Classic Part Number
8N-3183	Piston Gp-Basic	250-6556
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8303	Collar-Idler End	226-0242
9H-2256	Pump Gp-F Prm	311-9443

99J		
Original Part Number	Part Name	Classic Part Number
9H-5797	Plunger As-Pump	391-9891
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-5048	Pump Gp-Vn Bsc-A	422-8166
9J-9598	Pin	296-1362
9M-0701	Piston-Steer Cl	219-9692
9M-1997	Bearing-Ball	384-5954
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5045	Guard As-Wear	213-9111
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

99J		
Original Part Number	Part Name	Classic Part Number
9S-6129	Pulley-Alt Drive	264-5891
9S-6590	Pump Gp-Cl Oil	226-0176
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9T-4761	Head	325-6108
9W-0550	Shaft-Xmsn Upper	226-6000
9W-0552	Shaft-Pinion	226-6001
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
160-6305	Cap-Bearing	295-5686
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893

Sales Model D6C (Cont'd.)

99J		
Original Part Number	**Part Name**	**Classic Part Number**
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438

99J		
Original Part Number	**Part Name**	**Classic Part Number**
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

99J		
Original Part Number	**Part Name**	**Classic Part Number**
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

Sales Model D6D

01Y		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-6573	Cup-Roller Brg	399-4438
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-1943	Gear-Idler	446-3067
1P-7936	Spider As-Fan	383-3673
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944

01Y		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-5804	Rod End-Spher	416-2151
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220

01Y		
Original Part Number	**Part Name**	**Classic Part Number**
2S-3188	Plate	299-2041
2S-4365	Retainer As	216-3554
2S-6097	Tang	375-9979
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3B-8845	Bearing-Inner	417-4509
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3241	Plate-Pressure	325-6167
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440

Sales Model D6D (Cont'd.)

01Y		
Original Part Number	Part Name	Classic Part Number
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8472	Hood As-Preclnr	296-1355
4S-9062	Cap-Fd Bearing	226-0204
4W-0452	Seal As -Cshaft	325-6191
5H-5500	Collar-Fly Cl	302-2704
5L-6326	Bearing-Ball	420-3222
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7341	Cover-Bearing	452-0443
5M-7342	Flange-Shaft	215-1696
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137

01Y		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0169	Hub-Fly Clutch	297-7204
6T-0956	Pad As	367-6088
6T-1702	Support As	299-2065
6T-1711	Plate	389-6324
6T-1724	Bar As-Equalizer	283-5223
6T-8907	Pad As	380-7391

01Y		
Original Part Number	Part Name	Classic Part Number
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
7C-3862	Camshaft	458-0151
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7G-8389	Guard	226-0202
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-0859	Fork As-Shift	297-7172
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964

Sales Model D6D (Cont'd.)

01Y		
Original Part Number	Part Name	Classic Part Number
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-9931	Countershaft	215-1760
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8F-6058	Bearing-Sleeve	416-5494
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436

01Y		
Original Part Number	Part Name	Classic Part Number
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372

01Y		
Original Part Number	Part Name	Classic Part Number
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8T-1177	Bearing-Rlr	419-1862
9F-7101	Bushing-Collar	299-1988
9G-8303	Collar-Idler End	226-0242
9H-2256	Pump Gp-F Prm	311-9443
9K-8757	Rod End-Special	311-9361
9M-0701	Piston-Steer Cl	219-9692
9M-2744	Cone-Spl Tapered	380-1480
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244

Sales Model D6D (Cont'd.)

01Y		
Original Part Number	Part Name	Classic Part Number
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9W-0550	Shaft-Xmsn Upper	226-6000
9W-0551	Shaft-Pinion	388-6592
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
131-3815	Seal Gp-Basic	325-6193
131-6091	Gear-Sliding	385-7201
134-4200	Manifold-Exhaust	443-2060
148-7455	Valve - Exhaust	270-4361

01Y		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365

01Y		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
226-8202	Seal-Wiper	472-8024
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

03X		
Original Part Number	Part Name	Classic Part Number
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0963	Guard As-Roller	226-0179
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670

03X		
Original Part Number	Part Name	Classic Part Number
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-6752	Pump Gp-Gr 1 Bsc	226-0161
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014

03X		
Original Part Number	Part Name	Classic Part Number
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683

Sales Model D6D (Cont'd.)

03X		
Original Part Number	Part Name	Classic Part Number
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1766	Muffler As.	298-2783
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1085	Housing As-Diff	393-0928
2H-3517	Bearing-Inner	417-4505
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2H-9192	Bearing-Ball	394-8236
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5804	Rod End-Spher	416-2151
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927

03X		
Original Part Number	Part Name	Classic Part Number
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1503	Gear-First	213-8637
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2744	Muffler As.	247-2664
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-3767	Tube-Disposal	377-5850
2P-4370	Plate-Clutch	325-6166
2P-4611	Pipe-Exhaust	365-8821
2P-5081	Muffler As	360-7872
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-3803	Gear	226-6106
2S-3804	Gear-Sliding	226-6107
2S-4365	Retainer As	216-3554
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356

03X		
Original Part Number	Part Name	Classic Part Number
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3K-0526	Bearing-Ball	386-4949
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3241	Plate-Pressure	325-6167
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6814	Pump Gp-Gr 1	226-0163
3P-6816	Pump Gp-Gr 1	226-0164
3P-7640	Gear-Ctrshft	325-6093
3P-7641	Gear-Ctrshft	325-6094
3P-7643	Gear-Pinion Shft	302-2669
3S-1691	Disc-Steer Cl Dr	302-2705

Sales Model D6D (Cont'd.)

03X		
Original Part Number	Part Name	Classic Part Number
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176

03X		
Original Part Number	Part Name	Classic Part Number
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4N-9213	Elbow-Exhaust	330-9270
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-6869	Spacer-Fuel Pump	417-4534
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677

03X		
Original Part Number	Part Name	Classic Part Number
4Y-0709	Disc-Friction	377-7431
5A-7840	Shaft-Tr Sprkt	215-1687
5H-5500	Collar-Fly Cl	302-2704
5L-6326	Bearing-Ball	420-3222
5M-5073	Joint Gp-Univ	325-6113
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7340	Cage-Bearing	325-6034
5M-7341	Cover-Bearing	452-0443
5M-7342	Flange-Shaft	215-1696
5M-7344	Gear-Fifth	213-8741
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139

Sales Model D6D (Cont'd.)

03X		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0622	Elbow-Exhaust	380-7534
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2549	Mount As	384-3467
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0169	Hub-Fly Clutch	297-7204
6T-0956	Pad As	367-6088

03X		
Original Part Number	Part Name	Classic Part Number
6T-1702	Support As	299-2065
6T-1711	Plate	389-6324
6T-1724	Bar As-Equalizer	283-5223
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7G-8389	Guard	226-0202
7J-6250	Bearing-Sleeve	385-3803
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7J-9884	Bearing-Sleeve	325-6016
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-0859	Fork As-Shift	297-7172
7M-1154	Bearing-Spl	417-4515

03X		
Original Part Number	Part Name	Classic Part Number
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8117	Muffler As	247-2668
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996

Sales Model D6D (Cont'd.)

03X		
Original Part Number	Part Name	Classic Part Number
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7T-9931	Countershaft	215-1760
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8E-5993	Gear As-Idler	215-1903
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-6868	Cyl Gp-040 405 X	430-5964
8M-0874	Plunger As-Valve	311-9439
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778

03X		
Original Part Number	Part Name	Classic Part Number
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

03X		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314
8P-2430	Shaft As	297-7258
8P-3377	Tube As	392-4498
8P-3595	Mount	418-1950
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-6476	Rod Gp-Idler Rec	226-0198
9G-8303	Collar-Idler End	226-0242
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963

Sales Model D6D (Cont'd.)

03X		
Original Part Number	Part Name	Classic Part Number
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2038	Gear-Tfr Driven	215-1876
9M-2039	Gear-Tfr Driving	219-9672
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-4789	Shaft-Gov Cont	297-7256
9M-5045	Guard As-Wear	213-9111
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891

03X		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891
9S-6590	Pump Gp-Cl Oil	226-0176
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-0550	Shaft-Xmsn Upper	226-6000
9W-0552	Shaft-Pinion	226-6001
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

03X		
Original Part Number	Part Name	Classic Part Number
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
226-8202	Seal-Wiper	472-8024
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
247-2670	Muffler-Classic	247-2675
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model D6D (Cont'd.)

03X		
Original Part Number	Part Name	Classic Part Number
341-2430	Damper As-Cshft	299-2005

03X		
Original Part Number	Part Name	Classic Part Number
368-0297	Plate-Clutch	377-7420

03X		
Original Part Number	Part Name	Classic Part Number
391-8229	Kit-Gasket-Fs	398-2955

04X		
Original Part Number	Part Name	Classic Part Number
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-7912	Cone-Roller Brg	380-7503
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-0963	Guard As-Roller	226-0179
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-6752	Pump Gp-Gr 1 Bsc	226-0161
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294

04X		
Original Part Number	Part Name	Classic Part Number
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1766	Muffler As.	298-2783
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354

04X		
Original Part Number	Part Name	Classic Part Number
2G-1085	Housing As-Diff	393-0928
2H-9192	Bearing-Ball	394-8236
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2744	Muffler As.	247-2664
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-3767	Tube-Disposal	377-5850
2P-4370	Plate-Clutch	325-6166
2P-4611	Pipe-Exhaust	365-8821
2P-5081	Muffler As	360-7872
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197

Sales Model D6D (Cont'd.)

04X		
Original Part Number	Part Name	Classic Part Number
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-4365	Retainer As	216-3554
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265

04X		
Original Part Number	Part Name	Classic Part Number
3J-6577	Pin-Brace	367-6077
3K-0526	Bearing-Ball	386-4949
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6816	Pump Gp-Gr 1	226-0164
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059

04X		
Original Part Number	Part Name	Classic Part Number
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4N-9213	Elbow-Exhaust	330-9270
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191

Sales Model D6D (Cont'd.)

04X		
Original Part Number	Part Name	Classic Part Number
4W-2061	Pan As-Oil Sump	416-5519
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5L-6326	Bearing-Ball	420-3222
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141

04X		
Original Part Number	Part Name	Classic Part Number
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0622	Elbow-Exhaust	380-7534
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2549	Mount As	384-3467
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386

04X		
Original Part Number	Part Name	Classic Part Number
6T-0956	Pad As	367-6088
6T-1702	Support As	299-2065
6T-1711	Plate	389-6324
6T-1724	Bar As-Equalizer	283-5223
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7G-8389	Guard	226-0202
7J-6250	Bearing-Sleeve	385-3803
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7J-9884	Bearing-Sleeve	325-6016
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123

Sales Model D6D (Cont'd.)

04X		
Original Part Number	**Part Name**	**Classic Part Number**
7M-1154	Bearing-Spl	417-4515
7M-1296	Valve-Relief	390-0990
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3521	Core As-O Clr	383-3699
7N-3536	Gear-Fuel	279-4993
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8117	Muffler As	247-2668
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995

04X		
Original Part Number	**Part Name**	**Classic Part Number**
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-6868	Cyl Gp-040 405 X	430-5964
8M-0874	Plunger As-Valve	311-9439
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449

04X		
Original Part Number	**Part Name**	**Classic Part Number**
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

Sales Model D6D (Cont'd.)

04X		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314
8P-2430	Shaft As	297-7258
8P-3377	Tube As	392-4498
8P-3595	Mount	418-1950
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9G-6476	Rod Gp-Idler Rec	226-0198
9G-8303	Collar-Idler End	226-0242
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2038	Gear-Tfr Driven	215-1876

04X		
Original Part Number	Part Name	Classic Part Number
9M-2039	Gear-Tfr Driving	219-9672
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-4789	Shaft-Gov Cont	297-7256
9M-5045	Guard As-Wear	213-9111
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891

04X		
Original Part Number	Part Name	Classic Part Number
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9T-4761	Head	325-6108
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835

Sales Model D6D (Cont'd.)

04X		
Original Part Number	**Part Name**	**Classic Part Number**
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7776	Pump Gp-Water -B	395-1314

04X		
Original Part Number	**Part Name**	**Classic Part Number**
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
226-8202	Seal-Wiper	472-8024
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
235-1803	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438

04X		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

05X		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-6573	Cup-Roller Brg	399-4438
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0963	Guard As-Roller	226-0179
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-1943	Gear-Idler	446-3067
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-7936	Spider As-Fan	383-3673
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344

05X		
Original Part Number	**Part Name**	**Classic Part Number**
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2G-1085	Housing As-Diff	393-0928

05X		
Original Part Number	**Part Name**	**Classic Part Number**
2H-3517	Bearing-Inner	417-4505
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-5804	Rod End-Spher	416-2151
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1438	Pipe-Exh Ext	325-6157
2P-1503	Gear-First	213-8637
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

Sales Model D6D (Cont'd.)

05X		
Original Part Number	Part Name	Classic Part Number
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-3767	Tube-Disposal	377-5850
2P-5608	Pipe-Extension	367-6066
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-3803	Gear	226-6106
2S-3804	Gear-Sliding	226-6107
2S-4365	Retainer As	216-3554
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-6739	Pulley-Tightener	298-2794
2S-7603	Drum-Steer Cl Dr	213-6951
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3B-8845	Bearing-Inner	417-4509
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823

05X		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3241	Plate-Pressure	325-6167
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4M-6107	Bearing-Roller	380-7507
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8204	Mount As	374-1449
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

05X		
Original Part Number	Part Name	Classic Part Number
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8472	Hood As-Preclnr	296-1355
4S-9062	Cap-Fd Bearing	226-0204
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-6869	Spacer-Fuel Pump	417-4534
4W-9989	Gear As-Idler	302-2677
5A-7840	Shaft-Tr Sprkt	215-1687
5H-5500	Collar-Fly Cl	302-2704
5K-2294	Bearing	396-9912
5L-6326	Bearing-Ball	420-3222
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7340	Cage-Bearing	325-6034
5M-7341	Cover-Bearing	452-0443
5M-7342	Flange-Shaft	215-1696
5M-7344	Gear-Fifth	213-8741
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502

Sales Model D6D (Cont'd.)

05X		
Original Part Number	Part Name	Classic Part Number
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2549	Mount As	384-3467
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0169	Hub-Fly Clutch	297-7204
6T-0956	Pad As	367-6088
6T-1702	Support As	299-2065

05X		
Original Part Number	Part Name	Classic Part Number
6T-1711	Plate	389-6324
6T-1724	Bar As-Equalizer	283-5223
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7G-8389	Guard	226-0202
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-0859	Fork As-Shift	297-7172
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994

05X		
Original Part Number	Part Name	Classic Part Number
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-9931	Countershaft	215-1760
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8E-5993	Gear As-Idler	215-1903
8F-6058	Bearing-Sleeve	416-5494

Sales Model D6D (Cont'd.)

05X		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207

05X		
Original Part Number	Part Name	Classic Part Number
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8T-1177	Bearing-Rlr	419-1862
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-6476	Rod Gp-Idler Rec	226-0198

05X		
Original Part Number	Part Name	Classic Part Number
9G-7412	Gear As-Pump	297-7183
9G-8303	Collar-Idler End	226-0242
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9K-8757	Rod End-Special	311-9361
9L-5908	Gasket	433-8196
9M-0701	Piston-Steer Cl	219-9692
9M-2744	Cone-Spl Tapered	380-1480
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124

Sales Model D6D (Cont'd.)

05X		
Original Part Number	**Part Name**	**Classic Part Number**
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9W-0550	Shaft-Xmsn Upper	226-6000
9W-0551	Shaft-Pinion	388-6592
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
131-3815	Seal Gp-Basic	325-6193
131-6091	Gear-Sliding	385-7201
134-4200	Manifold-Exhaust	443-2060
148-7455	Valve - Exhaust	270-4361

05X		
Original Part Number	**Part Name**	**Classic Part Number**
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365

05X		
Original Part Number	**Part Name**	**Classic Part Number**
172-7771	Pump Gp-Water -B	419-4646
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	217-7738
219-9693	Shaft-Classic	216-7876
226-8202	Seal-Wiper	472-8024
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

06X		
Original Part Number	**Part Name**	**Classic Part Number**
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-0963	Guard As-Roller	226-0179

06X		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-6752	Pump Gp-Gr 1 Bsc	226-0161
1P-7895	Cone-Roller Brg	396-4145

06X		
Original Part Number	**Part Name**	**Classic Part Number**
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442

Sales Model D6D (Cont'd.)

06X		
Original Part Number	Part Name	Classic Part Number
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-1766	Muffler As.	298-2783
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2G-1085	Housing As-Diff	393-0928
2H-9192	Bearing-Ball	394-8236
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

06X		
Original Part Number	Part Name	Classic Part Number
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2744	Muffler As.	247-2664
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-3767	Tube-Disposal	377-5850
2P-4370	Plate-Clutch	325-6166
2P-4611	Pipe-Exhaust	365-8821
2P-5081	Muffler As	360-7872
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-4365	Retainer As	216-3554
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-7603	Drum-Steer Cl Dr	213-6951
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-6559	Cap-Bearing	296-1346

06X		
Original Part Number	Part Name	Classic Part Number
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6816	Pump Gp-Gr 1	226-0164
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-5004	Spring As-Arm	383-2128
4J-1616	Bracket	299-1982
4J-1999	Ballstud	314-8625
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176

Sales Model D6D (Cont'd.)

06X		
Original Part Number	Part Name	Classic Part Number
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5A-7840	Shaft-Tr Sprkt	215-1687
5L-6326	Bearing-Ball	420-3222
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121

06X		
Original Part Number	Part Name	Classic Part Number
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273

06X		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0622	Elbow-Exhaust	380-7534
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2549	Mount As	384-3467
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6T-0956	Pad As	367-6088
6T-1702	Support As	299-2065
6T-1711	Plate	389-6324
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815

Sales Model D6D (Cont'd.)

06X		
Original Part Number	Part Name	Classic Part Number
7G-2476	Gear-Planet	223-4816
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7J-6250	Bearing-Sleeve	385-3803
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7J-9884	Bearing-Sleeve	325-6016
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-1154	Bearing-Spl	417-4515
7M-1296	Valve-Relief	390-0990
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722

06X		
Original Part Number	Part Name	Classic Part Number
7N-3486	Manifold-Exhaust	261-0899
7N-3521	Core As-O Clr	383-3699
7N-3536	Gear-Fuel	279-4993
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8117	Muffler As	247-2668
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-6868	Cyl Gp-040 405 X	430-5964

06X		
Original Part Number	Part Name	Classic Part Number
8M-0874	Plunger As-Valve	311-9439
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207

Sales Model D6D (Cont'd.)

06X		
Original Part Number	Part Name	Classic Part Number
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1851	Hub As-Sprocket	224-1314
8P-2430	Shaft As	297-7258
8P-3377	Tube As	392-4498
8P-3595	Mount	418-1950
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9G-8303	Collar-Idler End	226-0242
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-2007	Piston As	419-4714
9K-8757	Rod End-Special	311-9361

06X		
Original Part Number	Part Name	Classic Part Number
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2038	Gear-Tfr Driven	215-1876
9M-2039	Gear-Tfr Driving	219-9672
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923

06X		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9T-4761	Head	325-6108
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

Sales Model D6D (Cont'd.)

06X		
Original Part Number	Part Name	Classic Part Number
170-0558	Kit-Rebuild-Pump	390-1001
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698

06X		
Original Part Number	Part Name	Classic Part Number
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
226-8202	Seal-Wiper	472-8024
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
235-1803	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892

06X		
Original Part Number	Part Name	Classic Part Number
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

19B		
Original Part Number	Part Name	Classic Part Number
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-6573	Cup-Roller Brg	399-4438
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-1943	Gear-Idler	446-3067
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017

19B		
Original Part Number	Part Name	Classic Part Number
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334

19B		
Original Part Number	Part Name	Classic Part Number
2K-5804	Rod End-Spher	416-2151
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1438	Pipe-Exh Ext	325-6157
2P-1503	Gear-First	213-8637
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041

Sales Model D6D (Cont'd.)

19B		
Original Part Number	Part Name	Classic Part Number
2S-4365	Retainer As	216-3554
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3B-8845	Bearing-Inner	417-4509
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3241	Plate-Pressure	325-6167
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4J-6326	Bearing-Half	376-3630

19B		
Original Part Number	Part Name	Classic Part Number
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8472	Hood As-Preclnr	296-1355
4S-9062	Cap-Fd Bearing	226-0204
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5H-5500	Collar-Fly Cl	302-2704
5K-2294	Bearing	396-9912
5L-6326	Bearing-Ball	420-3222
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847

19B		
Original Part Number	Part Name	Classic Part Number
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7341	Cover-Bearing	452-0443
5M-7342	Flange-Shaft	215-1696
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386

Sales Model D6D (Cont'd.)

19B		
Original Part Number	Part Name	Classic Part Number
6P-0169	Hub-Fly Clutch	297-7204
6T-0956	Pad As	367-6088
6T-1711	Plate	389-6324
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7G-8389	Guard	226-0202
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-0859	Fork As-Shift	297-7172
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172

19B		
Original Part Number	Part Name	Classic Part Number
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-9931	Countershaft	215-1760
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192

19B		
Original Part Number	Part Name	Classic Part Number
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

Sales Model D6D (Cont'd.)

19B		
Original Part Number	Part Name	Classic Part Number
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-6476	Rod Gp-Idler Rec	226-0198
9G-8303	Collar-Idler End	226-0242
9K-8757	Rod End-Special	311-9361
9L-5908	Gasket	433-8196
9M-0701	Piston-Steer Cl	219-9692
9M-2744	Cone-Spl Tapered	380-1480
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861

19B		
Original Part Number	Part Name	Classic Part Number
9P-0620	Cage-Pinion Brg	221-1052
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8679	Chamber As	325-6042
9W-0550	Shaft-Xmsn Upper	226-6000
9W-0551	Shaft-Pinion	388-6592
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
131-3815	Seal Gp-Basic	325-6193
131-6091	Gear-Sliding	385-7201
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

19B		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
226-8202	Seal-Wiper	472-8024
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

Sales Model D6D (Cont'd.)

19X		
Original Part Number	Part Name	Classic Part Number
0R-1651	Hub-Gear	211-2135
0R-5013	Plate-Clutch	388-0586
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-6573	Cup-Roller Brg	399-4438
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0963	Guard As-Roller	226-0179
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-6752	Pump Gp-Gr 1 Bsc	226-0161
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9110	Bearing-Needle	420-2497
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981

19X		
Original Part Number	Part Name	Classic Part Number
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-4507	Bearing-Sleeve	325-6021
2K-5804	Rod End-Spher	416-2151
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-5685	Bearing-Needle	380-7469
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1503	Gear-First	213-8637
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454

19X		
Original Part Number	Part Name	Classic Part Number
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-3767	Tube-Disposal	377-5850
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-3803	Gear	226-6106
2S-3804	Gear-Sliding	226-6107
2S-4365	Retainer As	216-3554
2S-6097	Tang	375-9979
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346

Sales Model D6D (Cont'd.)

19X		
Original Part Number	Part Name	Classic Part Number
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-1686	Plate-Clutch	388-0586
3P-3241	Plate-Pressure	325-6167
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6814	Pump Gp-Gr 1	226-0163
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407

19X		
Original Part Number	Part Name	Classic Part Number
4M-1641	Dowel-Reaction	386-4952
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-9062	Cap-Fd Bearing	226-0204
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9771	Gear-Crankshaft	302-2674

19X		
Original Part Number	Part Name	Classic Part Number
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5H-5500	Collar-Fly Cl	302-2704
5L-6326	Bearing-Ball	420-3222
5M-5073	Joint Gp-Univ	325-6113
5M-5856	Pipe-Extension	373-1913
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7340	Cage-Bearing	325-6034
5M-7341	Cover-Bearing	452-0443
5M-7342	Flange-Shaft	215-1696
5M-7344	Gear-Fifth	213-8741
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358

Sales Model D6D (Cont'd.)

19X		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0169	Hub-Fly Clutch	297-7204
6T-0956	Pad As	367-6088
6T-1702	Support As	299-2065
6T-1711	Plate	389-6324
6T-1724	Bar As-Equalizer	283-5223
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7G-8389	Guard	226-0202

19X		
Original Part Number	Part Name	Classic Part Number
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7J-9884	Bearing-Sleeve	325-6016
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-0859	Fork As-Shift	297-7172
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995

19X		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-9931	Countershaft	215-1760
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8E-5993	Gear As-Idler	215-1903
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-6868	Cyl Gp-040 405 X	430-5964
8M-0874	Plunger As-Valve	311-9439
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893

Sales Model D6D (Cont'd.)

19X		
Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783

19X		
Original Part Number	Part Name	Classic Part Number
8P-1851	Hub As-Sprocket	224-1314
8P-2430	Shaft As	297-7258
8P-3377	Tube As	392-4498
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8T-1177	Bearing-Rlr	419-1862
9F-7101	Bushing-Collar	299-1988
9G-6476	Rod Gp-Idler Rec	226-0198
9G-8303	Collar-Idler End	226-0242
9H-2256	Pump Gp-F Prm	311-9443
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9L-5908	Gasket	433-8196
9M-0701	Piston-Steer Cl	219-9692
9M-1997	Bearing-Ball	384-5954
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-4789	Shaft-Gov Cont	297-7256
9M-5045	Guard As-Wear	213-9111
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558

19X		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-6590	Pump Gp-Cl Oil	226-0176
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-0550	Shaft-Xmsn Upper	226-6000
9W-0552	Shaft-Pinion	226-6001
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360

Sales Model D6D (Cont'd.)

19X		
Original Part Number	**Part Name**	**Classic Part Number**
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
128-3935	Bearing-Race	396-9897
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194

19X		
Original Part Number	**Part Name**	**Classic Part Number**
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	217-7738
219-9693	Shaft-Classic	216-7876

19X		
Original Part Number	**Part Name**	**Classic Part Number**
226-8202	Seal-Wiper	472-8024
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

20X		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1651	Hub-Gear	211-2135
0R-5013	Plate-Clutch	388-0586
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-7912	Cone-Roller Brg	380-7503
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-0963	Guard As-Roller	226-0179
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858

20X		
Original Part Number	**Part Name**	**Classic Part Number**
1P-6752	Pump Gp-Gr 1 Bsc	226-0161
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-9110	Bearing-Needle	420-2497
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410

20X		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-1766	Muffler As.	298-2783
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955

Sales Model D6D (Cont'd.)

20X		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2K-4507	Bearing-Sleeve	325-6021
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-5685	Bearing-Needle	380-7469
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2744	Muffler As.	247-2664
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-3767	Tube-Disposal	377-5850
2P-4370	Plate-Clutch	325-6166
2P-4611	Pipe-Exhaust	365-8821
2P-5081	Muffler As	360-7872
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-4365	Retainer As	216-3554
2S-6097	Tang	375-9979
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173

20X		
Original Part Number	Part Name	Classic Part Number
2S-7603	Drum-Steer Cl Dr	213-6951
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-1686	Plate-Clutch	388-0586
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6816	Pump Gp-Gr 1	226-0164
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440

20X		
Original Part Number	Part Name	Classic Part Number
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4S-5049	Guard As-Rh	226-0183

Sales Model D6D (Cont'd.)

20X		
Original Part Number	Part Name	Classic Part Number
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5L-6326	Bearing-Ball	420-3222
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165

20X		
Original Part Number	Part Name	Classic Part Number
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0622	Elbow-Exhaust	380-7534
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386

20X		
Original Part Number	Part Name	Classic Part Number
6T-0956	Pad As	367-6088
6T-1702	Support As	299-2065
6T-1711	Plate	389-6324
6T-1724	Bar As-Equalizer	283-5223
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-2527	Gasket Kit	387-2918
6Y-5916	Disc-Friction	377-7442
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7G-8389	Guard	226-0202
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7J-9884	Bearing-Sleeve	325-6016
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-1154	Bearing-Spl	417-4515
7M-1296	Valve-Relief	390-0990
7M-1776	Plate-Idler Gde	226-0222

Sales Model D6D (Cont'd.)

20X		
Original Part Number	Part Name	Classic Part Number
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3521	Core As-O Clr	383-3699
7N-3536	Gear-Fuel	279-4993
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8117	Muffler As	247-2668
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417

20X		
Original Part Number	Part Name	Classic Part Number
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-6868	Cyl Gp-040 405 X	430-5964
8M-0874	Plunger As-Valve	311-9439
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893

20X		
Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0605	Gear-First Red	213-8453

Sales Model D6D (Cont'd.)

20X		
Original Part Number	Part Name	Classic Part Number
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314
8P-2430	Shaft As	297-7258
8P-3377	Tube As	392-4498
8P-3595	Mount	418-1950
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9G-6476	Rod Gp-Idler Rec	226-0198
9G-8303	Collar-Idler End	226-0242
9H-2256	Pump Gp-F Prm	311-9443
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2038	Gear-Tfr Driven	215-1876
9M-2039	Gear-Tfr Driving	219-9672
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480

20X		
Original Part Number	Part Name	Classic Part Number
9M-4789	Shaft-Gov Cont	297-7256
9M-5045	Guard As-Wear	213-9111
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042

20X		
Original Part Number	Part Name	Classic Part Number
9S-8789	Plate-Clutch	302-2712
9T-4761	Head	325-6108
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
128-3935	Bearing-Race	396-9897
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738

Sales Model D6D (Cont'd.)

20X		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
235-1803	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675

20X		
Original Part Number	Part Name	Classic Part Number
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349

20X		
Original Part Number	Part Name	Classic Part Number
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

30X		
Original Part Number	Part Name	Classic Part Number
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-6573	Cup-Roller Brg	399-4438
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-6752	Pump Gp-Gr 1 Bsc	226-0161
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017

30X		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1766	Muffler As.	298-2783
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2J-1424	Rod As	469-4665
2J-5596	Pin-Pivot	297-7211
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021

30X		
Original Part Number	Part Name	Classic Part Number
2K-5804	Rod End-Spher	416-2151
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1503	Gear-First	213-8637
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-4370	Plate-Clutch	325-6166
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-3803	Gear	226-6106
2S-3804	Gear-Sliding	226-6107
2S-4365	Retainer As	216-3554
2S-6263	Guard Gp-Spring	226-0192

Sales Model D6D (Cont'd.)

30X		
Original Part Number	Part Name	Classic Part Number
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3241	Plate-Pressure	325-6167
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6814	Pump Gp-Gr 1	226-0163
3P-7640	Gear-Ctrshft	325-6093

30X		
Original Part Number	Part Name	Classic Part Number
3P-7643	Gear-Pinion Shft	302-2669
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-5003	Spring As-Arm	383-2127
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

30X		
Original Part Number	Part Name	Classic Part Number
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-9062	Cap-Fd Bearing	226-0204
4T-6151	Trunnion	295-5671
4T-8054	Seal As	472-8010
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5H-5500	Collar-Fly Cl	302-2704
5L-6326	Bearing-Ball	420-3222
5M-5073	Joint Gp-Univ	325-6113
5M-5856	Pipe-Extension	373-1913
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7340	Cage-Bearing	325-6034
5M-7341	Cover-Bearing	452-0443
5M-7342	Flange-Shaft	215-1696
5M-7344	Gear-Fifth	213-8741
5P-5066	Bearing-Outer	416-2165

Sales Model D6D (Cont'd.)

30X		
Original Part Number	Part Name	Classic Part Number
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0169	Hub-Fly Clutch	297-7204
6S-3472	Pin As.	421-9629

30X		
Original Part Number	Part Name	Classic Part Number
6S-3474	Pin As	375-9981
6T-0956	Pad As	367-6088
6T-1702	Support As	299-2065
6T-1711	Plate	389-6324
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7G-8389	Guard	226-0202
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7J-9344	Bearing-Sleeve	360-2334
7J-9842	Bearing-Sleeve	299-1968
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-0859	Fork As-Shift	297-7172
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207

30X		
Original Part Number	Part Name	Classic Part Number
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3521	Core As-O Clr	383-3699
7N-3536	Gear-Fuel	279-4993
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-9931	Countershaft	215-1760
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8E-5993	Gear As-Idler	215-1903

Sales Model D6D (Cont'd.)

30X		
Original Part Number	**Part Name**	**Classic Part Number**
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-6868	Cyl Gp-040 405 X	430-5964
8M-0874	Plunger As-Valve	311-9439
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207

30X		
Original Part Number	**Part Name**	**Classic Part Number**
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314
8P-2430	Shaft As	297-7258
8P-3377	Tube As	392-4498
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
9F-7101	Bushing-Collar	299-1988
9G-8303	Collar-Idler End	226-0242
9H-2256	Pump Gp-F Prm	311-9443
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-0701	Piston-Steer Cl	219-9692
9M-1997	Bearing-Ball	384-5954
9M-2417	Retainer-Gear	380-7409

30X		
Original Part Number	**Part Name**	**Classic Part Number**
9M-2744	Cone-Spl Tapered	380-1480
9M-4789	Shaft-Gov Cont	297-7256
9M-5045	Guard As-Wear	213-9111
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-6590	Pump Gp-Cl Oil	226-0176
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-0550	Shaft-Xmsn Upper	226-6000
9W-0552	Shaft-Pinion	226-6001
9W-6390	Sleeve	385-3795

Sales Model D6D (Cont'd.)

30X		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
104-3014	Gasket Kit	388-0656
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
141-7277	Kit-Gasket-Fs	437-4610
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

30X		
Original Part Number	**Part Name**	**Classic Part Number**
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
226-8202	Seal-Wiper	472-8024
230-7114	Ster Cl Kit-Cla	219-9690

30X		
Original Part Number	**Part Name**	**Classic Part Number**
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

31X		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1J-2860	Cup-Spl Tapered	374-8347
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-7912	Cone-Roller Brg	380-7503
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0963	Guard As-Roller	226-0179
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-3934	Cup-Roller Brg	420-6535

31X		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3935	Cone-Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114
1P-4110	Disc-Friction	433-9858
1P-6752	Pump Gp-Gr 1 Bsc	226-0161
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-7895	Cone-Roller Brg	396-4145
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582

31X		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916

Sales Model D6D (Cont'd.)

31X		
Original Part Number	Part Name	Classic Part Number
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1V-8604	Gear-Ring	308-9853
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1766	Muffler As.	298-2783
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9130	Washer-Thrust	308-9943
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-6489	Race-Brg Outer	374-8350
2H-9192	Bearing-Ball	394-8236
2J-1424	Rod As	469-4665
2J-5596	Pin-Pivot	297-7211
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5103	Cone-Roller Brg	380-7505
2K-5804	Rod End-Spher	416-2151
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678

31X		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2744	Muffler As.	247-2664
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-4370	Plate-Clutch	325-6166
2P-4611	Pipe-Exhaust	365-8821
2P-5680	Turbine-Conv	308-9942
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-4365	Retainer As	216-3554
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
2S-7931	Bearing-Sleeve	387-2904
2V-7170	Yoke	308-9948
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055

31X		
Original Part Number	Part Name	Classic Part Number
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3K-0526	Bearing-Ball	386-4949
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-2414	Housing-Clutch	391-9831
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3246	Shaft-Planet	308-9925
3P-3429	Cage-Bearing	452-0430
3P-3623	Lock-Adj Nut	226-7989
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-3739	Carrier As	431-4032
3P-6318	Flange-Drum	213-8165

Sales Model D6D (Cont'd.)

31X		
Original Part Number	Part Name	Classic Part Number
3P-6816	Pump Gp-Gr 1	226-0164
3P-7489	Plate-Clutch	377-7423
3P-9366	Piston-Clutch	391-9861
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
3T-4384	Housing As-Cl	435-2573
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350
3V-3855	Housing-Brg Spt	375-9980
3V-6697	Housing	424-4944
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4C-1335	Washer-Thrust	399-4425
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-5004	Spring As-Arm	383-2128
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-1999	Ballstud	314-8625
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176

31X		
Original Part Number	Part Name	Classic Part Number
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8472	Hood As-Preclnr	296-1355
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204
4T-1893	Cartridge Gp	422-8110
4T-6151	Trunnion	295-5671
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9771	Gear-Crankshaft	302-2674

31X		
Original Part Number	Part Name	Classic Part Number
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5A-7840	Shaft-Tr Sprkt	215-1687
5D-2989	Bearing	380-7511
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7925	Bearing-Roller	419-7774
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-5410	Bearing-Spl Ball	396-4134

Sales Model D6D (Cont'd.)

31X		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9301	Bearing-Spl Ball	417-4496
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0622	Elbow-Exhaust	380-7534
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467

31X		
Original Part Number	Part Name	Classic Part Number
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-2923	Yoke As	382-6891
6P-6739	Shaft-Planet	308-9929
6P-7704	Carrier-Ring	314-8658
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6T-0956	Pad As	367-6088
6T-1702	Support As	299-2065
6T-1711	Plate	389-6324
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6W-7290	Shaft-Planet	308-9930
6Y-1603	Housing-Clutch	438-1818
6Y-1604	Carrier As	468-9790
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-5916	Disc-Friction	377-7442
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-8437	Cone-Roller Brg	380-1502
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2474	Gear-Planet	300-2577

31X		
Original Part Number	Part Name	Classic Part Number
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-8389	Guard	226-0202
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7J-8893	Cone-Roller Brg	374-1846
7J-9344	Bearing-Sleeve	360-2334
7J-9842	Bearing-Sleeve	299-1968
7K-5448	Cup-Bearing	415-1922
7K-9360	Pin	319-3461
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-1154	Bearing-Spl	417-4515
7M-1296	Valve-Relief	390-0990
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951

Sales Model D6D (Cont'd.)

31X		
Original Part Number	Part Name	Classic Part Number
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3521	Core As-O Clr	383-3699
7N-3536	Gear-Fuel	279-4993
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636

31X		
Original Part Number	Part Name	Classic Part Number
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-6868	Cyl Gp-040 405 X	430-5964
8M-0874	Plunger As-Valve	311-9439
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200

31X		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0514	Yoke As	308-9947
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-2430	Shaft As	297-7258
8P-3377	Tube As	392-4498
8P-3595	Mount	418-1950
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437

Sales Model D6D (Cont'd.)

31X		
Original Part Number	Part Name	Classic Part Number
8P-9507	Piston-Clutch	283-5212
8R-4184	Bearing-Sleeve	374-6515
8R-4821	Carrier-Planet	308-9837
8R-7425	Retainer	308-9917
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-6382	Hub As	308-9868
8V-6384	Spacer As	308-9935
9C-2249	Yoke As	382-6890
9C-8074	Gear-Planet	308-9858
9C-8075	Gear-Sun	308-9864
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6476	Rod Gp-Idler Rec	226-0198
9G-6744	Bearing-Sleeve	418-1931
9G-8303	Collar-Idler End	226-0242
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-5048	Pump Gp-Vn Bsc-A	422-8166
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-0701	Piston-Steer Cl	219-9692
9M-1328	Bearing-Aligning	325-6018
9M-1500	Shaft-Planet	219-9685
9M-1853	Mount As.	376-3638

31X		
Original Part Number	Part Name	Classic Part Number
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2038	Gear-Tfr Driven	215-1876
9M-2039	Gear-Tfr Driving	219-9672
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-4789	Shaft-Gov Cont	297-7256
9M-5045	Guard As-Wear	213-9111
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9000	Shaft-Ster Cl	217-7738
9P-9031	Gear-Sun	283-5220
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876

31X		
Original Part Number	Part Name	Classic Part Number
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-5279	Bearing-Inner	453-3661
9S-6129	Pulley-Alt Drive	264-5891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9T-4761	Head	325-6108
9U-0971	Gear-Sun	368-0124
9U-0974	Bushing-Sleeve	374-1460
9U-0975	Hub As	390-5259
9V-6165	Plate-Outer	377-7460
9W-2977	Hub As	423-6985
9W-4175	Shaft-Xmsn Input	394-8241
9W-4702	Stator-Converter	308-9939
9W-6390	Sleeve	385-3795
9W-6433	Impeller-Conv	308-9871
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-7019	Disc-Friction	377-7461
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360

Sales Model D6D (Cont'd.)

31X		
Original Part Number	Part Name	Classic Part Number
102-4563	Gear-Transfer	399-4430
104-3014	Gasket Kit	388-0656
106-7798	Bearing-Ball	417-9494
106-7799	Bearing-Ball	396-9947
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8041	Carrier-Planet	295-5681
121-7583	Gear-Planet	364-5257
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
141-7277	Kit-Gasket-Fs	437-4610
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-4891	Plate As.	391-1093
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

31X		
Original Part Number	Part Name	Classic Part Number
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-8734	Cover-Transfer	420-3217
219-9693	Shaft-Classic	217-7738
219-9693	Shaft-Classic	216-7876
226-8202	Seal-Wiper	472-8024
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
233-9748	Disc-Friction	417-9502
235-0913	Tc Kit-Cla	235-0920

31X		
Original Part Number	Part Name	Classic Part Number
235-1803	Tc Kit-Cla	235-0920
237-9849	Cage-Bearing	443-1201
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

32X		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1J-2860	Cup-Spl Tapered	374-8347
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087

32X		
Original Part Number	Part Name	Classic Part Number
1P-0963	Guard As-Roller	226-0179
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-1943	Gear-Idler	446-3067
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-6752	Pump Gp-Gr 1 Bsc	226-0161
1P-7895	Cone-Roller Brg	396-4145
1P-9945	Bracket As-Fan	296-1344

32X		
Original Part Number	Part Name	Classic Part Number
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685

Sales Model D6D (Cont'd.)

32X		
Original Part Number	Part Name	Classic Part Number
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1V-8604	Gear-Ring	308-9853
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1766	Muffler As.	298-2783
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9130	Washer-Thrust	308-9943
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2H-9192	Bearing-Ball	394-8236
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691

32X		
Original Part Number	Part Name	Classic Part Number
2K-5103	Cone-Roller Brg	380-7505
2K-5804	Rod End-Spher	416-2151
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1503	Gear-First	213-8637
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-4370	Plate-Clutch	325-6166
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3803	Gear	226-6106
2S-3804	Gear-Sliding	226-6107
2S-4365	Retainer As	216-3554
2S-7603	Drum-Steer Cl Dr	213-6951
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203

32X		
Original Part Number	Part Name	Classic Part Number
2W-7458	Crankshaft As	242-3439
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-6559	Cap-Bearing	296-1346
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3241	Plate-Pressure	325-6167
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6814	Pump Gp-Gr 1	226-0163
3P-6816	Pump Gp-Gr 1	226-0164
3P-7640	Gear-Ctrshft	325-6093
3P-7641	Gear-Ctrshft	325-6094
3P-7643	Gear-Pinion Shft	302-2669
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
3V-3855	Housing-Brg Spt	375-9980
3V-6697	Housing	424-4944
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4C-1335	Washer-Thrust	399-4425
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4J-1616	Bracket	299-1982
4J-1999	Ballstud	314-8625
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157

Sales Model D6D (Cont'd.)

32X		
Original Part Number	Part Name	Classic Part Number
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204
4W-0452	Seal As -Cshaft	325-6191

32X		
Original Part Number	Part Name	Classic Part Number
4W-6869	Spacer-Fuel Pump	417-4534
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5A-7840	Shaft-Tr Sprkt	215-1687
5H-5500	Collar-Fly Cl	302-2704
5L-6326	Bearing-Ball	420-3222
5M-5073	Joint Gp-Univ	325-6113
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-7290	Cage-Bearing	216-7848
5M-7340	Cage-Bearing	325-6034
5M-7341	Cover-Bearing	452-0443
5M-7342	Flange-Shaft	215-1696
5M-7344	Gear-Fifth	213-8741
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024

32X		
Original Part Number	Part Name	Classic Part Number
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0169	Hub-Fly Clutch	297-7204
6T-0956	Pad As	367-6088
6T-1702	Support As	299-2065
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140

Sales Model D6D (Cont'd.)

32X		
Original Part Number	Part Name	Classic Part Number
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6W-7290	Shaft-Planet	308-9930
6Y-5916	Disc-Friction	377-7442
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-8437	Cone-Roller Brg	380-1502
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7K-2135	Bearing-Roller	417-4492
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-0859	Fork As-Shift	297-7172
7M-1154	Bearing-Spl	417-4515
7M-1296	Valve-Relief	390-0990
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816

32X		
Original Part Number	Part Name	Classic Part Number
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3521	Core As-O Clr	383-3699
7N-3536	Gear-Fuel	279-4993
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7T-9931	Countershaft	215-1760
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8E-5993	Gear As-Idler	215-1903
8F-6058	Bearing-Sleeve	416-5494
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442

32X		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-6868	Cyl Gp-040 405 X	430-5964
8M-0874	Plunger As-Valve	311-9439
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200

Sales Model D6D (Cont'd.)

32X		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0514	Yoke As	308-9947
8P-1851	Hub As-Sprocket	224-1314
8P-2430	Shaft As	297-7258
8P-3377	Tube As	392-4498
8P-3595	Mount	418-1950
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8R-4184	Bearing-Sleeve	374-6515
8R-4821	Carrier-Planet	308-9837
8R-7425	Retainer	308-9917
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612

32X		
Original Part Number	Part Name	Classic Part Number
8S-9076	Cup-Bearing	418-9613
8T-1177	Bearing-Rlr	419-1862
8V-6382	Hub As	308-9868
8V-6384	Spacer As	308-9935
9C-2249	Yoke As	382-6890
9C-8074	Gear-Planet	308-9858
9C-8075	Gear-Sun	308-9864
9F-7101	Bushing-Collar	299-1988
9G-8303	Collar-Idler End	226-0242
9J-2007	Piston As	419-4714
9K-8757	Rod End-Special	311-9361
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2038	Gear-Tfr Driven	215-1876
9M-2039	Gear-Tfr Driving	219-9672
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904

32X		
Original Part Number	Part Name	Classic Part Number
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891
9S-6590	Pump Gp-Cl Oil	226-0176
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9T-4761	Head	325-6108
9U-0971	Gear-Sun	368-0124
9U-0974	Bushing-Sleeve	374-1460
9U-0975	Hub As	390-5259
9V-6165	Plate-Outer	377-7460
9W-0550	Shaft-Xmsn Upper	226-6000
9W-0551	Shaft-Pinion	388-6592
9W-0552	Shaft-Pinion	226-6001
9W-6390	Sleeve	385-3795
9W-7019	Disc-Friction	377-7461
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032

Sales Model D6D (Cont'd.)

32X		
Original Part Number	Part Name	Classic Part Number
100-7860	Valve-Inlet	270-4360
104-3014	Gasket Kit	388-0656
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
121-7583	Gear-Planet	364-5257
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
131-6091	Gear-Sliding	385-7201
132-6597	Cone-Spl	422-6477
141-7277	Kit-Gasket-Fs	437-4610
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127

32X		
Original Part Number	Part Name	Classic Part Number
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
226-8202	Seal-Wiper	472-8024
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920

32X		
Original Part Number	Part Name	Classic Part Number
235-1803	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

33X		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0963	Guard As-Roller	226-0179
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-6752	Pump Gp-Gr 1 Bsc	226-0161

33X		
Original Part Number	Part Name	Classic Part Number
1P-7895	Cone-Roller Brg	396-4145
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410

33X		
Original Part Number	Part Name	Classic Part Number
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-1766	Muffler As.	298-2783
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513

Sales Model D6D (Cont'd.)

33X		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-4370	Plate-Clutch	325-6166
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-4365	Retainer As	216-3554
2S-7603	Drum-Steer Cl Dr	213-6951
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693

33X		
Original Part Number	Part Name	Classic Part Number
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-6559	Cap-Bearing	296-1346
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6816	Pump Gp-Gr 1	226-0164
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-5004	Spring As-Arm	383-2128
4J-1616	Bracket	299-1982
4J-1999	Ballstud	314-8625
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270

33X		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204
4W-0452	Seal As -Cshaft	325-6191
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5A-7840	Shaft-Tr Sprkt	215-1687
5L-6326	Bearing-Ball	420-3222
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495

Sales Model D6D (Cont'd.)

33X		
Original Part Number	Part Name	Classic Part Number
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544

33X		
Original Part Number	Part Name	Classic Part Number
6N-7263	Gasket-Cyl Head	380-7386
6T-0956	Pad As	367-6088
6T-1702	Support As	299-2065
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-1154	Bearing-Spl	417-4515
7M-1296	Valve-Relief	390-0990
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206

33X		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3521	Core As-O Clr	383-3699
7N-3536	Gear-Fuel	279-4993
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-6868	Cyl Gp-040 405 X	430-5964

Sales Model D6D (Cont'd.)

33X		
Original Part Number	Part Name	Classic Part Number
8M-0874	Plunger As-Valve	311-9439
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232

33X		
Original Part Number	Part Name	Classic Part Number
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1851	Hub As-Sprocket	224-1314
8P-2430	Shaft As	297-7258
8P-3377	Tube As	392-4498
8P-3595	Mount	418-1950
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9G-8303	Collar-Idler End	226-0242
9J-2007	Piston As	419-4714
9K-8757	Rod End-Special	311-9361
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2038	Gear-Tfr Driven	215-1876
9M-2039	Gear-Tfr Driving	219-9672
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533

33X		
Original Part Number	Part Name	Classic Part Number
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712

Sales Model D6D (Cont'd.)

33X		
Original Part Number	Part Name	Classic Part Number
9T-4761	Head	325-6108
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

33X		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738

33X		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
235-1803	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

36C		
Original Part Number	Part Name	Classic Part Number
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582

36C		
Original Part Number	Part Name	Classic Part Number
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

36C		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021

Sales Model D6D (Cont'd.)

36C		
Original Part Number	Part Name	Classic Part Number
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-4365	Retainer As	216-3554
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-7603	Drum-Steer Cl Dr	213-6951
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346

36C		
Original Part Number	Part Name	Classic Part Number
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6816	Pump Gp-Gr 1	226-0164
3S-3875	Screen-Suction	435-4849
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270

36C		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
5L-6326	Bearing-Ball	420-3222
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683

Sales Model D6D (Cont'd.)

36C		
Original Part Number	Part Name	Classic Part Number
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495

36C		
Original Part Number	Part Name	Classic Part Number
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6T-0956	Pad As	367-6088
6T-1711	Plate	389-6324
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7G-8389	Guard	226-0202
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-1154	Bearing-Spl	417-4515
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327

36C		
Original Part Number	Part Name	Classic Part Number
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3521	Core As-O Clr	383-3699
7N-3536	Gear-Fuel	279-4993
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486

Sales Model D6D (Cont'd.)

36C		
Original Part Number	Part Name	Classic Part Number
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464

36C		
Original Part Number	Part Name	Classic Part Number
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1851	Hub As-Sprocket	224-1314
8P-2430	Shaft As	297-7258
8P-3377	Tube As	392-4498
8P-3595	Mount	418-1950
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9G-8303	Collar-Idler End	226-0242
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875

36C		
Original Part Number	Part Name	Classic Part Number
9M-1997	Bearing-Ball	384-5954
9M-2038	Gear-Tfr Driven	215-1876
9M-2039	Gear-Tfr Driving	219-9672
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244

Sales Model D6D (Cont'd.)

36C		
Original Part Number	Part Name	Classic Part Number
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

36C		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365

36C		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

37C		
Original Part Number	Part Name	Classic Part Number
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-6573	Cup-Roller Brg	399-4438
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-1943	Gear-Idler	446-3067
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014

37C		
Original Part Number	Part Name	Classic Part Number
1S-9670	Univ Jt As	443-2017
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505

37C		
Original Part Number	Part Name	Classic Part Number
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5804	Rod End-Spher	416-2151
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1503	Gear-First	213-8637
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

Sales Model D6D (Cont'd.)

37C		
Original Part Number	Part Name	Classic Part Number
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-3803	Gear	226-6106
2S-3804	Gear-Sliding	226-6107
2S-4365	Retainer As	216-3554
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-7603	Drum-Steer Cl Dr	213-6951
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069

37C		
Original Part Number	Part Name	Classic Part Number
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3241	Plate-Pressure	325-6167
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6814	Pump Gp-Gr 1	226-0163
3S-3875	Screen-Suction	435-4849
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

37C		
Original Part Number	Part Name	Classic Part Number
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-9062	Cap-Fd Bearing	226-0204
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
5H-5500	Collar-Fly Cl	302-2704
5L-6326	Bearing-Ball	420-3222
5M-5073	Joint Gp-Univ	325-6113
5M-5856	Pipe-Extension	373-1913
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7340	Cage-Bearing	325-6034
5M-7341	Cover-Bearing	452-0443
5M-7342	Flange-Shaft	215-1696
5M-7344	Gear-Fifth	213-8741
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141

Sales Model D6D (Cont'd.)

37C		
Original Part Number	Part Name	Classic Part Number
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0169	Hub-Fly Clutch	297-7204
6T-0956	Pad As	367-6088
6T-1711	Plate	389-6324
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361

37C		
Original Part Number	Part Name	Classic Part Number
7F-9547	Pin As.-Drawbar	295-0414
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7G-8389	Guard	226-0202
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-0859	Fork As-Shift	297-7172
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995

37C		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-9931	Countershaft	215-1760
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8E-5993	Gear As-Idler	215-1903
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858

Sales Model D6D (Cont'd.)

37C		
Original Part Number	Part Name	Classic Part Number
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1851	Hub As-Sprocket	224-1314
8P-2430	Shaft As	297-7258
8P-3377	Tube As	392-4498
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862

37C		
Original Part Number	Part Name	Classic Part Number
9F-7101	Bushing-Collar	299-1988
9G-8303	Collar-Idler End	226-0242
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-0701	Piston-Steer Cl	219-9692
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9M-8395	Bearing-Sleeve	391-1103
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-6590	Pump Gp-Cl Oil	226-0176
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243

37C		
Original Part Number	Part Name	Classic Part Number
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-0550	Shaft-Xmsn Upper	226-6000
9W-0551	Shaft-Pinion	388-6592
9W-0552	Shaft-Pinion	226-6001
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
131-6091	Gear-Sliding	385-7201
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365

Sales Model D6D (Cont'd.)

37C		
Original Part Number	**Part Name**	**Classic Part Number**
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
250-6556	Kit-Liner-Cla	250-6564
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438

37C		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989

37C		
Original Part Number	**Part Name**	**Classic Part Number**
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

38C		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-6573	Cup-Roller Brg	399-4438
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-1943	Gear-Idler	446-3067
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

38C		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-5804	Rod End-Spher	416-2151
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1438	Pipe-Exh Ext	325-6157
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220

38C		
Original Part Number	**Part Name**	**Classic Part Number**
2S-3188	Plate	299-2041
2S-4365	Retainer As	216-3554
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-7603	Drum-Steer Cl Dr	213-6951
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3B-8845	Bearing-Inner	417-4509
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3241	Plate-Pressure	325-6167
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3S-3875	Screen-Suction	435-4849
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4F-5004	Spring As-Arm	383-2128

Sales Model D6D (Cont'd.)

38C		
Original Part Number	**Part Name**	**Classic Part Number**
4H-4021	Plate As-Loading	229-8219
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8472	Hood As-Preclnr	296-1355
4S-9062	Cap-Fd Bearing	226-0204
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5H-5500	Collar-Fly Cl	302-2704
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542

38C		
Original Part Number	**Part Name**	**Classic Part Number**
5M-7290	Cage-Bearing	216-7848
5M-7341	Cover-Bearing	452-0443
5M-7342	Flange-Shaft	215-1696
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0169	Hub-Fly Clutch	297-7204
6T-0956	Pad As	367-6088
6T-1711	Plate	389-6324
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140

38C		
Original Part Number	**Part Name**	**Classic Part Number**
6V-1014	Race-Spl Rlr Brg	416-2173
6V-4785	Gasket Kit - Fs	388-0661
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7G-8389	Guard	226-0202
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-0859	Fork As-Shift	297-7172
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887

Sales Model D6D (Cont'd.)

38C		
Original Part Number	Part Name	Classic Part Number
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-9931	Countershaft	215-1760
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291

38C		
Original Part Number	Part Name	Classic Part Number
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1851	Hub As-Sprocket	224-1314
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831

38C		
Original Part Number	Part Name	Classic Part Number
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8T-1622	Gasket Kit - Sch	436-8388
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-8303	Collar-Idler End	226-0242
9L-5908	Gasket	433-8196
9M-0701	Piston-Steer Cl	219-9692
9M-2744	Cone-Spl Tapered	380-1480
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6147	Body As	369-9499
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124

Sales Model D6D (Cont'd.)

38C		
Original Part Number	**Part Name**	**Classic Part Number**
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8679	Chamber As	325-6042
9W-0550	Shaft-Xmsn Upper	226-6000
9W-0551	Shaft-Pinion	388-6592
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
131-3815	Seal Gp-Basic	325-6193
131-6091	Gear-Sliding	385-7201
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126

38C		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698

38C		
Original Part Number	**Part Name**	**Classic Part Number**
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

5YB		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582

5YB		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981

5YB		
Original Part Number	**Part Name**	**Classic Part Number**
1W-5300	Rotocoil As	443-2659
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2H-9192	Bearing-Ball	394-8236
2J-1424	Rod As	469-4665
2J-5596	Pin-Pivot	297-7211
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164

Sales Model D6D (Cont'd.)

5YB		
Original Part Number	Part Name	Classic Part Number
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-4365	Retainer As	216-3554
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-7603	Drum-Steer Cl Dr	213-6951
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714

5YB		
Original Part Number	Part Name	Classic Part Number
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6816	Pump Gp-Gr 1	226-0164
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-4539	Sleeve	314-8720
4N-4679	Pulley-Fan	394-9837
4N-4782	Pulley	325-6176
4N-4864	Pump Gp-F Tfr	242-3442
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

5YB		
Original Part Number	Part Name	Classic Part Number
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5L-6326	Bearing-Ball	420-3222
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165

Sales Model D6D (Cont'd.)

5YB		
Original Part Number	Part Name	Classic Part Number
5P-5067	Race-Spl Rlr Brg	396-4137
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6T-0956	Pad As	367-6088
6T-1711	Plate	389-6324
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829

5YB		
Original Part Number	Part Name	Classic Part Number
7E-9980	Camshaft	377-5851
7F-9547	Pin As.-Drawbar	295-0414
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7G-8389	Guard	226-0202
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-1154	Bearing-Spl	417-4515
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3521	Core As-O Clr	383-3699
7N-3536	Gear-Fuel	279-4993
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995

5YB		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8M-0874	Plunger As-Valve	311-9439
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037

Sales Model D6D (Cont'd.)

5YB		
Original Part Number	Part Name	Classic Part Number
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1851	Hub As-Sprocket	224-1314
8P-2430	Shaft As	297-7258
8P-3377	Tube As	392-4498
8P-3595	Mount	418-1950
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9G-8303	Collar-Idler End	226-0242

5YB		
Original Part Number	Part Name	Classic Part Number
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2038	Gear-Tfr Driven	215-1876
9M-2039	Gear-Tfr Driving	219-9672
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923

5YB		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
250-6558	Liner Kit-Cla	295-6438
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

Sales Model D6D (Cont'd.)

5YB		
Original Part Number	**Part Name**	**Classic Part Number**
341-2430	Damper As-Cshft	299-2005

5YB		
Original Part Number	**Part Name**	**Classic Part Number**
368-0297	Plate-Clutch	377-7420

6HC		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-6573	Cup-Roller Brg	399-4438
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-6752	Pump Gp-Gr 1 Bsc	226-0161
1P-7895	Cone-Roller Brg	396-4145
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

6HC		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2J-5596	Pin-Pivot	297-7211
2K-4507	Bearing-Sleeve	325-6021
2K-5804	Rod End-Spher	416-2151
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1503	Gear-First	213-8637
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230

6HC		
Original Part Number	**Part Name**	**Classic Part Number**
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3803	Gear	226-6106
2S-3804	Gear-Sliding	226-6107
2S-4365	Retainer As	216-3554
2S-6265	Rod Gp-Recoil	226-0197
2S-7603	Drum-Steer Cl Dr	213-6951
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3B-8845	Bearing-Inner	417-4509
3F-6149	Pin	299-2033
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448

Sales Model D6D (Cont'd.)

6HC		
Original Part Number	Part Name	Classic Part Number
3P-3241	Plate-Pressure	325-6167
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6814	Pump Gp-Gr 1	226-0163
3P-7640	Gear-Ctrshft	325-6093
3P-7641	Gear-Ctrshft	325-6094
3P-7643	Gear-Pinion Shft	302-2669
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp-F Tfr	242-3442
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985

6HC		
Original Part Number	Part Name	Classic Part Number
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-9062	Cap-Fd Bearing	226-0204
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5H-5500	Collar-Fly Cl	302-2704
5L-6326	Bearing-Ball	420-3222
5M-5073	Joint Gp-Univ	325-6113
5M-5856	Pipe-Extension	373-1913
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7340	Cage-Bearing	325-6034
5M-7341	Cover-Bearing	452-0443
5M-7342	Flange-Shaft	215-1696
5M-7344	Gear-Fifth	213-8741
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139

6HC		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6P-0169	Hub-Fly Clutch	297-7204
6T-0956	Pad As	367-6088
6T-1702	Support As	299-2065
6T-1711	Plate	389-6324
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-7935	Disc-Friction	383-2121
7B-7515	Bearing-Ball	399-6059
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851

Sales Model D6D (Cont'd.)

6HC		
Original Part Number	Part Name	Classic Part Number
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-8389	Guard	226-0202
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-0859	Fork As-Shift	297-7172
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656

6HC		
Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-9931	Countershaft	215-1760
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8E-5993	Gear As-Idler	215-1903
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-6868	Cyl Gp-040 405 X	430-5964
8M-0874	Plunger As-Valve	311-9439
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196

6HC		
Original Part Number	Part Name	Classic Part Number
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1851	Hub As-Sprocket	224-1314
8P-2430	Shaft As	297-7258
8P-3377	Tube As	392-4498
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
9F-7101	Bushing-Collar	299-1988
9G-6476	Rod Gp-Idler Rec	226-0198
9G-8303	Collar-Idler End	226-0242

Sales Model D6D (Cont'd.)

6HC		
Original Part Number	Part Name	Classic Part Number
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-0701	Piston-Steer Cl	219-9692
9M-1997	Bearing-Ball	384-5954
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-4789	Shaft-Gov Cont	297-7256
9M-5045	Guard As-Wear	213-9111
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891

6HC		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-6590	Pump Gp-Cl Oil	226-0176
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-0550	Shaft-Xmsn Upper	226-6000
9W-0552	Shaft-Pinion	226-6001
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
104-3014	Gasket Kit	388-0656
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
141-7277	Kit-Gasket-Fs	437-4610
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

6HC		
Original Part Number	Part Name	Classic Part Number
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
226-8202	Seal-Wiper	472-8024
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8256	Kit-Gasket (Sch)	447-8653

74W		
Original Part Number	Part Name	Classic Part Number
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-6573	Cup-Roller Brg	399-4438

74W		
Original Part Number	Part Name	Classic Part Number
1M-7912	Cone-Roller Brg	380-7503
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978

74W		
Original Part Number	Part Name	Classic Part Number
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147

Sales Model D6D (Cont'd.)

74W		
Original Part Number	Part Name	Classic Part Number
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5804	Rod End-Spher	416-2151
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1503	Gear-First	213-8637
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229

74W		
Original Part Number	Part Name	Classic Part Number
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-3803	Gear	226-6106
2S-3804	Gear-Sliding	226-6107
2S-4365	Retainer As	216-3554
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922

74W		
Original Part Number	Part Name	Classic Part Number
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3241	Plate-Pressure	325-6167
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6814	Pump Gp-Gr 1	226-0163
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407

Sales Model D6D (Cont'd.)

74W		
Original Part Number	Part Name	Classic Part Number
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-9062	Cap-Fd Bearing	226-0204
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549

74W		
Original Part Number	Part Name	Classic Part Number
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5H-5500	Collar-Fly Cl	302-2704
5L-6326	Bearing-Ball	420-3222
5M-5073	Joint Gp-Univ	325-6113
5M-5856	Pipe-Extension	373-1913
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7340	Cage-Bearing	325-6034
5M-7341	Cover-Bearing	452-0443
5M-7342	Flange-Shaft	215-1696
5M-7344	Gear-Fifth	213-8741
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475

74W		
Original Part Number	Part Name	Classic Part Number
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0169	Hub-Fly Clutch	297-7204
6T-0956	Pad As	367-6088
6T-1702	Support As	299-2065
6T-1711	Plate	389-6324
6T-1724	Bar As-Equalizer	283-5223
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7G-8389	Guard	226-0202
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312

Sales Model D6D (Cont'd.)

74W		
Original Part Number	Part Name	Classic Part Number
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-0859	Fork As-Shift	297-7172
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995

74W		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-9931	Countershaft	215-1760
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8E-5993	Gear As-Idler	215-1903
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-6868	Cyl Gp-040 405 X	430-5964
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436

74W		
Original Part Number	Part Name	Classic Part Number
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314
8P-2430	Shaft As	297-7258

Sales Model D6D (Cont'd.)

74W		
Original Part Number	Part Name	Classic Part Number
8P-3377	Tube As	392-4498
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-6476	Rod Gp-Idler Rec	226-0198
9G-8303	Collar-Idler End	226-0242
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-0701	Piston-Steer Cl	219-9692
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-5045	Guard As-Wear	213-9111
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454

74W		
Original Part Number	Part Name	Classic Part Number
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-6590	Pump Gp-Cl Oil	226-0176
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-0550	Shaft-Xmsn Upper	226-6000
9W-0552	Shaft-Pinion	226-6001
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125

75W		
Original Part Number	Part Name	Classic Part Number
0R-1651	Hub-Gear	211-2135

74W		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

Sales Model D6D (Cont'd.)

75W		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-7912	Cone-Roller Brg	380-7503
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-4110	Disc-Friction	433-9858
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

75W		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-4365	Retainer As	216-3554

75W		
Original Part Number	Part Name	Classic Part Number
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6816	Pump Gp-Gr 1	226-0164
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849

Sales Model D6D (Cont'd.)

75W		
Original Part Number	Part Name	Classic Part Number
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

75W		
Original Part Number	Part Name	Classic Part Number
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5L-6326	Bearing-Ball	420-3222
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996

75W		
Original Part Number	Part Name	Classic Part Number
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919

Sales Model D6D (Cont'd.)

75W		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6T-0956	Pad As	367-6088
6T-1702	Support As	299-2065
6T-1711	Plate	389-6324
6T-1724	Bar As-Equalizer	283-5223
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7G-8389	Guard	226-0202
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841

75W		
Original Part Number	Part Name	Classic Part Number
7M-0699	Cap-Brace Brg	247-4123
7M-1154	Bearing-Spl	417-4515
7M-1296	Valve-Relief	390-0990
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3521	Core As-O Clr	383-3699
7N-3536	Gear-Fuel	279-4993
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995

75W		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-6868	Cyl Gp-040 405 X	430-5964
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037

Sales Model D6D (Cont'd.)

75W		
Original Part Number	Part Name	Classic Part Number
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174

75W		
Original Part Number	Part Name	Classic Part Number
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314
8P-2430	Shaft As	297-7258
8P-3377	Tube As	392-4498
8P-3595	Mount	418-1950
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
9B-1320	Valve-Check	377-5832
9G-6476	Rod Gp-Idler Rec	226-0198
9G-8303	Collar-Idler End	226-0242
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2038	Gear-Tfr Driven	215-1876
9M-2039	Gear-Tfr Driving	219-9672
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409

75W		
Original Part Number	Part Name	Classic Part Number
9M-2744	Cone-Spl Tapered	380-1480
9M-5045	Guard As-Wear	213-9111
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9T-4761	Head	325-6108
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165

Sales Model D6D (Cont'd.)

75W		
Original Part Number	Part Name	Classic Part Number
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

75W		
Original Part Number	Part Name	Classic Part Number
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876

75W		
Original Part Number	Part Name	Classic Part Number
219-9693	Shaft-Classic	217-7738
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
235-1803	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

7XF		
Original Part Number	Part Name	Classic Part Number
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-6573	Cup-Roller Brg	399-4438
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-1943	Gear-Idler	446-3067
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572

7XF		
Original Part Number	Part Name	Classic Part Number
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513

7XF		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691
2K-5804	Rod End-Spher	416-2151
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

Sales Model D6D (Cont'd.)

7XF		
Original Part Number	Part Name	Classic Part Number
2P-1503	Gear-First	213-8637
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-4365	Retainer As	216-3554
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588

7XF		
Original Part Number	Part Name	Classic Part Number
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3241	Plate-Pressure	325-6167
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6814	Pump Gp-Gr 1	226-0163
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157

7XF		
Original Part Number	Part Name	Classic Part Number
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-9062	Cap-Fd Bearing	226-0204
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
5H-5500	Collar-Fly Cl	302-2704
5L-6326	Bearing-Ball	420-3222
5M-5073	Joint Gp-Univ	325-6113
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376

Sales Model D6D (Cont'd.)

7XF		
Original Part Number	Part Name	Classic Part Number
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7341	Cover-Bearing	452-0443
5M-7342	Flange-Shaft	215-1696
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6P-0169	Hub-Fly Clutch	297-7204

7XF		
Original Part Number	Part Name	Classic Part Number
6T-0956	Pad As	367-6088
6T-1702	Support As	299-2065
6T-1711	Plate	389-6324
6T-1724	Bar As-Equalizer	283-5223
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7G-8389	Guard	226-0202
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994

7XF		
Original Part Number	Part Name	Classic Part Number
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-9931	Countershaft	215-1760
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8E-2890	Gear	422-2489
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016

Sales Model D6D (Cont'd.)

7XF		
Original Part Number	Part Name	Classic Part Number
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314

7XF		
Original Part Number	Part Name	Classic Part Number
8P-2430	Shaft As	297-7258
8P-3377	Tube As	392-4498
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8T-1177	Bearing-Rlr	419-1862
9F-7101	Bushing-Collar	299-1988
9G-6476	Rod Gp-Idler Rec	226-0198
9G-8303	Collar-Idler End	226-0242
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9K-8757	Rod End-Special	311-9361
9M-0701	Piston-Steer Cl	219-9692
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677

7XF		
Original Part Number	Part Name	Classic Part Number
9P-9575	Cage-Bev Gr Brg	216-7876
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-6590	Pump Gp-Cl Oil	226-0176
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-0550	Shaft-Xmsn Upper	226-6000
9W-0551	Shaft-Pinion	388-6592
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
104-3014	Gasket Kit	388-0656
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
131-3815	Seal Gp-Basic	325-6193
131-6091	Gear-Sliding	385-7201
134-4200	Manifold-Exhaust	443-2060
141-7277	Kit-Gasket-Fs	437-4610
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127

Sales Model D6D (Cont'd.)

7XF		
Original Part Number	**Part Name**	**Classic Part Number**
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

7XF		
Original Part Number	**Part Name**	**Classic Part Number**
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	217-7738
219-9693	Shaft-Classic	216-7876
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356

7XF		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8256	Kit-Gasket (Sch)	447-8653

9FK		
Original Part Number	**Part Name**	**Classic Part Number**
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-4110	Disc-Friction	433-9858
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738

9FK		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-1424	Rod As	469-4665

9FK		
Original Part Number	**Part Name**	**Classic Part Number**
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-4365	Retainer As	216-3554
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197

Sales Model D6D (Cont'd.)

9FK		
Original Part Number	Part Name	Classic Part Number
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6816	Pump Gp-Gr 1	226-0164
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494

9FK		
Original Part Number	Part Name	Classic Part Number
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183

9FK		
Original Part Number	Part Name	Classic Part Number
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5L-6326	Bearing-Ball	420-3222
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929

Sales Model D6D (Cont'd.)

9FK		
Original Part Number	Part Name	Classic Part Number
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6T-0956	Pad As	367-6088
6T-1711	Plate	389-6324
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574

9FK		
Original Part Number	Part Name	Classic Part Number
6Y-5916	Disc-Friction	377-7442
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7G-8389	Guard	226-0202
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-1154	Bearing-Spl	417-4515
7M-1296	Valve-Relief	390-0990
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3521	Core As-O Clr	383-3699
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686

9FK		
Original Part Number	Part Name	Classic Part Number
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-6868	Cyl Gp-040 405 X	430-5964
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782

Sales Model D6D (Cont'd.)

9FK		
Original Part Number	Part Name	Classic Part Number
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314

9FK		
Original Part Number	Part Name	Classic Part Number
8P-2430	Shaft As	297-7258
8P-3595	Mount	418-1950
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
9G-8303	Collar-Idler End	226-0242
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2038	Gear-Tfr Driven	215-1876
9M-2039	Gear-Tfr Driving	219-9672
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-5045	Guard As-Wear	213-9111
9M-6692	Strip	386-4934
9M-8395	Bearing-Sleeve	391-1103
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904

9FK		
Original Part Number	Part Name	Classic Part Number
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9T-4761	Head	325-6108
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

Sales Model D6D (Cont'd.)

9FK		
Original Part Number	Part Name	Classic Part Number
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

9FK		
Original Part Number	Part Name	Classic Part Number
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
235-1803	Tc Kit-Cla	235-0920
270-4353	Kit-Liner-Cla	295-6438

9FK		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420

Sales Model D6E

2MJ		
Original Part Number	Part Name	Classic Part Number
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-4110	Disc-Friction	433-9858
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367

2MJ		
Original Part Number	Part Name	Classic Part Number
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

2MJ		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

Sales Model D6E (Cont'd.)

2MJ		
Original Part Number	Part Name	Classic Part Number
2P-2719	Pipe-Oil Filler	363-7454
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-3767	Tube-Disposal	377-5850
2P-4611	Pipe-Exhaust	365-8821
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-4365	Retainer As	216-3554
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714

2MJ		
Original Part Number	Part Name	Classic Part Number
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6816	Pump Gp-Gr 1	226-0164
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

2MJ		
Original Part Number	Part Name	Classic Part Number
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5L-6326	Bearing-Ball	420-3222
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684

Sales Model D6E (Cont'd.)

2MJ		
Original Part Number	Part Name	Classic Part Number
5M-6212	Tube	390-0996
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475

2MJ		
Original Part Number	Part Name	Classic Part Number
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6N-0622	Elbow-Exhaust	380-7534
6N-1036	Gear-Oil Pump	279-4991
6N-1878	Muffler As	360-7883
6N-2549	Mount As	384-3467
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6T-0956	Pad As	367-6088
6T-1702	Support As	299-2065
6T-1711	Plate	389-6324
6T-1724	Bar As-Equalizer	283-5223
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-5916	Disc-Friction	377-7442
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7G-7681	Shaft As	307-1530
7G-8389	Guard	226-0202
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841

2MJ		
Original Part Number	Part Name	Classic Part Number
7M-0699	Cap-Brace Brg	247-4123
7M-1154	Bearing-Spl	417-4515
7M-1296	Valve-Relief	390-0990
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3521	Core As-O Clr	383-3699
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351

Sales Model D6E (Cont'd.)

2MJ		
Original Part Number	Part Name	Classic Part Number
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-6868	Cyl Gp-040 405 X	430-5964
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

2MJ		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314
8P-2430	Shaft As	297-7258
8P-3377	Tube As	392-4498
8P-3595	Mount	418-1950
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8T-1177	Bearing-Rlr	419-1862
9G-6476	Rod Gp-Idler Rec	226-0198

2MJ		
Original Part Number	Part Name	Classic Part Number
9G-8303	Collar-Idler End	226-0242
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2038	Gear-Tfr Driven	215-1876
9M-2039	Gear-Tfr Driving	219-9672
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-5045	Guard As-Wear	213-9111
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677

Sales Model D6E (Cont'd.)

2MJ		
Original Part Number	Part Name	Classic Part Number
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9T-4761	Head	325-6108
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
124-3237	Precleaner As	432-4220

2MJ		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687

2MJ		
Original Part Number	Part Name	Classic Part Number
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	217-7738
219-9693	Shaft-Classic	216-7876
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
235-1803	Tc Kit-Cla	235-0920
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

8FJ		
Original Part Number	Part Name	Classic Part Number
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087

8FJ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-1943	Gear-Idler & First	446-3067
1P-4110	Disc-Friction	433-9858
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-8764	Ring-Fly Clu Adj	226-8014

8FJ		
Original Part Number	Part Name	Classic Part Number
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738

Sales Model D6E (Cont'd.)

8FJ		
Original Part Number	Part Name	Classic Part Number
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2H-9192	Bearing-Ball	394-8236
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5804	Rod End-Spher	416-2151
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927

8FJ		
Original Part Number	Part Name	Classic Part Number
2P-1170	Shaft As-Gear	296-1367
2P-1503	Gear-First	213-8637
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-3767	Tube-Disposal	377-5850
2P-4611	Pipe-Exhaust	365-8821
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-3803	Gear	226-6106
2S-3804	Gear-Sliding	226-6107
2S-4365	Retainer As	216-3554
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-9978	Core As-Oclr	279-4983
3B-8845	Bearing-Inner	417-4509

8FJ		
Original Part Number	Part Name	Classic Part Number
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3241	Plate-Pressure	325-6167
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6814	Pump Gp-Gr 1	226-0163
3P-6816	Pump Gp-Gr 1	226-0164
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370

Sales Model D6E (Cont'd.)

8FJ		
Original Part Number	Part Name	Classic Part Number
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204

8FJ		
Original Part Number	Part Name	Classic Part Number
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5H-5500	Collar-Fly Cl	302-2704
5L-6326	Bearing-Ball	420-3222
5M-5073	Joint Gp-Univ	325-6113
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-7290	Cage-Bearing	216-7848
5M-7340	Cage-Bearing	325-6034
5M-7341	Cover-Bearing	452-0443
5M-7342	Flange-Shaft	215-1696
5M-7344	Gear-Fifth	213-8741
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929

8FJ		
Original Part Number	Part Name	Classic Part Number
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6N-0622	Elbow-Exhaust	380-7534
6N-1036	Gear-Oil Pump	279-4991
6N-1878	Muffler As	360-7883
6N-2549	Mount As	384-3467
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6P-0169	Hub-Fly Clutch	297-7204
6T-0956	Pad As	367-6088

Sales Model D6E (Cont'd.)

8FJ		
Original Part Number	Part Name	Classic Part Number
6T-1702	Support As	299-2065
6T-1711	Plate	389-6324
6T-1724	Bar As-Equalizer	283-5223
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7G-8389	Guard	226-0202
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-0859	Fork As-Shift	297-7172
7M-1154	Bearing-Spl	417-4515
7M-1296	Valve-Relief	390-0990
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228

8FJ		
Original Part Number	Part Name	Classic Part Number
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3521	Core As-O Clr	383-3699
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7T-9931	Countershaft	215-1760
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187

8FJ		
Original Part Number	Part Name	Classic Part Number
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8E-2890	Gear	422-2489
8E-5993	Gear As-Idler	215-1903
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-6868	Cyl Gp-040 405 X	430-5964
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623

Sales Model D6E (Cont'd.)

8FJ		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314
8P-2430	Shaft As	297-7258
8P-3377	Tube As	392-4498
8P-3595	Mount	418-1950
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8T-1177	Bearing-Rlr	419-1862
9F-7101	Bushing-Collar	299-1988
9G-6476	Rod Gp-Idler Rec	226-0198
9G-8303	Collar-Idler End	226-0242

8FJ		
Original Part Number	Part Name	Classic Part Number
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2038	Gear-Tfr Driven	215-1876
9M-2039	Gear-Tfr Driving	219-9672
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-5045	Guard As-Wear	213-9111
9M-6692	Strip	386-4934
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9M-8395	Bearing-Sleeve	391-1103
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876

8FJ		
Original Part Number	Part Name	Classic Part Number
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-6590	Pump Gp-Cl Oil	226-0176
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9T-4761	Head	325-6108
9W-0550	Shaft-Xmsn Upper	226-6000
9W-0551	Shaft-Pinion	388-6592
9W-0552	Shaft-Pinion	226-6001
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
104-3014	Gasket Kit	388-0656
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
131-6091	Gear-Sliding	385-7201
134-4200	Manifold-Exhaust	443-2060
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

Sales Model D6E (Cont'd.)

8FJ		
Original Part Number	**Part Name**	**Classic Part Number**
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

8FJ		
Original Part Number	**Part Name**	**Classic Part Number**
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	217-7738
219-9693	Shaft-Classic	216-7876
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
235-1803	Tc Kit-Cla	235-0920
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351

8FJ		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420

RBE		
Original Part Number	**Part Name**	**Classic Part Number**
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1W-4738	Bearing-Sleeve	325-6020
2S-6401	Cup-Roller Brg	380-7497
3G-0910	Cap-Bearing	325-6037
3H-1996	Bearing-Ball	380-1498
3T-1162	Sleeve-Wear	325-6209
4K-3004	Bearing-Trun Sup	314-8632

RBE		
Original Part Number	**Part Name**	**Classic Part Number**
5D-6659	Bearing	417-4511
5J-1192	Bearing-Sleeve	374-8355
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6Y-2065	Mount As-650 Cup	377-5844
7J-1309	Bearing-Aligning	360-2275
7S-3002	Bearing-Spl Ball	386-4961
7S-4534	Bearing-Caged	417-9497
8D-0983	Mounting	384-3470

RBE		
Original Part Number	**Part Name**	**Classic Part Number**
8G-4189	Bearing-Aligning	295-6411
9J-0123	Trunnion	325-6227
9J-5284	Bearing-Sleeve	380-7379
9M-1328	Bearing-Aligning	325-6018
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

RCR		
Original Part Number	**Part Name**	**Classic Part Number**
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1U-0873	Pin	325-6137
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
2S-6401	Cup-Roller Brg	380-7497
3G-0910	Cap-Bearing	325-6037

RCR		
Original Part Number	**Part Name**	**Classic Part Number**
3H-1996	Bearing-Ball	380-1498
3T-1162	Sleeve-Wear	325-6209
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
5D-6659	Bearing	417-4511
5J-1192	Bearing-Sleeve	374-8355
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495

RCR		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-2065	Mount As-650 Cup	377-5844
7J-5131	Trunnion	296-1371
7S-3002	Bearing-Spl Ball	386-4961
7S-4534	Bearing-Caged	417-9497
8D-0983	Mounting	384-3470
8G-4189	Bearing-Aligning	295-6411
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
9J-0123	Trunnion	325-6227

Sales Model D6E (Cont'd.)

RCR		
Original Part Number	Part Name	Classic Part Number
9J-5284	Bearing-Sleeve	380-7379
9S-3581	Cup-Roller Brg	415-1923

RCR		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
100-8010	Valve	423-5583

RCR		
Original Part Number	Part Name	Classic Part Number
160-6305	Cap-Bearing	295-5686
179-6152	Bearing	361-1704

TRC		
Original Part Number	Part Name	Classic Part Number
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1U-0873	Pin	325-6137
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
2S-6401	Cup-Roller Brg	380-7497
3G-0910	Cap-Bearing	325-6037
3H-1996	Bearing-Ball	380-1498
3T-1162	Sleeve-Wear	325-6209
4J-1641	Trunnion	314-8725

TRC		
Original Part Number	Part Name	Classic Part Number
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
5D-6659	Bearing	417-4511
5J-1192	Bearing-Sleeve	374-8355
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6Y-2065	Mount As-650 Cup	377-5844
7J-5131	Trunnion	296-1371
7S-3002	Bearing-Spl Ball	386-4961
7S-4534	Bearing-Caged	417-9497

TRC		
Original Part Number	Part Name	Classic Part Number
8D-0983	Mounting	384-3470
8G-4189	Bearing-Aligning	295-6411
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
9J-0123	Trunnion	325-6227
9J-5284	Bearing-Sleeve	380-7379
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
100-8010	Valve	423-5583
160-6305	Cap-Bearing	295-5686
179-6152	Bearing	361-1704

Sales Model D6G

2MJ		
Original Part Number	Part Name	Classic Part Number
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-4095	Bearing-Inner	417-9486
1M-6573	Cup-Roller Brg	399-4438
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-4110	Disc-Friction	433-9858
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214

2MJ		
Original Part Number	Part Name	Classic Part Number
1S-8734	Bracket-Roller	226-0212
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326

2MJ		
Original Part Number	Part Name	Classic Part Number
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

Sales Model D6G (Cont'd.)

2MJ		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-3767	Tube-Disposal	377-5850
2P-4611	Pipe-Exhaust	365-8821
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-3188	Plate	299-2041
2S-4365	Retainer As	216-3554
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951

2MJ		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3623	Lock-Adj Nut	226-7989
3P-6318	Flange-Drum	213-8165
3P-6816	Pump Gp-Gr 1	226-0164
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128

2MJ		
Original Part Number	Part Name	Classic Part Number
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-8708	Housing-Clutch	216-3557

Sales Model D6G (Cont'd.)

2MJ		
Original Part Number	Part Name	Classic Part Number
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5L-6326	Bearing-Ball	420-3222
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137

2MJ		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6N-0622	Elbow-Exhaust	380-7534
6N-1036	Gear-Oil Pump	279-4991
6N-1878	Muffler As	360-7883
6N-2549	Mount As	384-3467
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6T-0956	Pad As	367-6088
6T-1702	Support As	299-2065
6T-1711	Plate	389-6324
6T-1724	Bar As-Equalizer	283-5223
6T-8907	Pad As	380-7391

2MJ		
Original Part Number	Part Name	Classic Part Number
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-5916	Disc-Friction	377-7442
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-4605	Support As	387-2938
7G-6042	Cage As	216-7856
7G-7681	Shaft As	307-1530
7G-8389	Guard	226-0202
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-1154	Bearing-Spl	417-4515
7M-1296	Valve-Relief	390-0990
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951

Sales Model D6G (Cont'd.)

2MJ		
Original Part Number	Part Name	Classic Part Number
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-3521	Core As-O Clr	383-3699
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-6868	Cyl Gp-040 405 X	430-5964
8M-6191	Sleeve-Bolt	226-0234

2MJ		
Original Part Number	Part Name	Classic Part Number
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

2MJ		
Original Part Number	Part Name	Classic Part Number
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314
8P-2430	Shaft As	297-7258
8P-3377	Tube As	392-4498
8P-3595	Mount	418-1950
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8T-1177	Bearing-Rlr	419-1862
9G-6476	Rod Gp-Idler Rec	226-0198
9G-8303	Collar-Idler End	226-0242
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9K-8757	Rod End-Special	311-9361
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2038	Gear-Tfr Driven	215-1876
9M-2039	Gear-Tfr Driving	219-9672
9M-2042	Race-Roller Brg	417-9500

Sales Model D6G (Cont'd.)

2MJ		
Original Part Number	Part Name	Classic Part Number
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-5045	Guard As-Wear	213-9111
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8395	Bearing-Sleeve	391-1103
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512

2MJ		
Original Part Number	Part Name	Classic Part Number
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9T-4761	Head	325-6108
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194

2MJ		
Original Part Number	Part Name	Classic Part Number
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
235-1803	Tc Kit-Cla	235-0920
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

3SR		
Original Part Number	Part Name	Classic Part Number
0R-1651	Hub-Gear	211-2135
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-6573	Cup-Roller Brg	399-4438

3SR		
Original Part Number	Part Name	Classic Part Number
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087

3SR		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-1897	Gear-Final Drive	215-1670
1P-1943	Gear-Idler	446-3067

Sales Model D6G (Cont'd.)

3SR		
Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-9670	Univ Jt As	443-2017
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2M-4668	Retainer-Guard	297-4867
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1503	Gear-First	213-8637
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553

3SR		
Original Part Number	Part Name	Classic Part Number
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-4365	Retainer As	216-3554
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6344	Gear-Final Drive	297-7173
2S-7603	Drum-Steer Cl Dr	213-6951
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-3623	Lock-Adj Nut	226-7989

3SR		
Original Part Number	Part Name	Classic Part Number
3P-6318	Flange-Drum	213-8165
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1407	Disc-Friction	392-4516
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

Sales Model D6G (Cont'd.)

3SR		
Original Part Number	Part Name	Classic Part Number
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-6256	Nut-Brg Adj	235-8008
4S-9062	Cap-Fd Bearing	226-0204
4T-6151	Trunnion	295-5671
4V-2057	Bearing-Spher	419-6019
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
5L-6326	Bearing-Ball	420-3222
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-7290	Cage-Bearing	216-7848
5M-7341	Cover-Bearing	452-0443
5M-7342	Flange-Shaft	215-1696
5M-7882	Joint Gp-Univ	297-7210
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-0192	Pinion-Fdr	215-1698
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

3SR		
Original Part Number	Part Name	Classic Part Number
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-5163	Bearing	417-4514
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6N-0622	Elbow-Exhaust	380-7534
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6T-0956	Pad As	367-6088
6T-1702	Support As	299-2065
6T-1711	Plate	389-6324
6T-1724	Bar As-Equalizer	283-5223
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2824	Piston	295-6439
7G-2828	Plate-Clutch	325-6171

3SR		
Original Part Number	Part Name	Classic Part Number
7G-2830	Ring-Seal	295-6441
7G-6042	Cage As	216-7856
7G-7681	Shaft As	307-1530
7G-8389	Guard	226-0202
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2949	Pulley	264-5887
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-9931	Countershaft	215-1760
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277

Sales Model D6G (Cont'd.)

3SR		
Original Part Number	Part Name	Classic Part Number
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8E-2890	Gear	422-2489
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-6868	Cyl Gp-040 405 X	430-5964
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377

3SR		
Original Part Number	Part Name	Classic Part Number
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-1851	Hub As-Sprocket	224-1314
8P-3595	Mount	418-1950
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8T-1177	Bearing-Rlr	419-1862
9G-6476	Rod Gp-Idler Rec	226-0198
9G-8303	Collar-Idler End	226-0242
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9M-0701	Piston-Steer Cl	219-9692
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-5045	Guard As-Wear	213-9111
9M-6692	Strip	386-4934
9M-8395	Bearing-Sleeve	391-1103
9N-5769	Cover-Housing	325-6050
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454

3SR		
Original Part Number	Part Name	Classic Part Number
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-0550	Shaft-Xmsn Upper	226-6000
9W-0551	Shaft-Pinion	388-6592
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
104-3014	Gasket Kit	388-0656
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
131-3815	Seal Gp-Basic	325-6193
131-6091	Gear-Sliding	385-7201
134-4200	Manifold-Exhaust	443-2060
141-7277	Kit-Gasket-Fs	437-4610
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006

Sales Model D6G (Cont'd.)

3SR		
Original Part Number	**Part Name**	**Classic Part Number**
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

3SR		
Original Part Number	**Part Name**	**Classic Part Number**
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	217-7738
219-9693	Shaft-Classic	216-7876
230-7114	Ster Cl Kit-Cla	219-9690

3SR		
Original Part Number	**Part Name**	**Classic Part Number**
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8256	Kit-Gasket (Sch)	447-8653

BWJ		
Original Part Number	**Part Name**	**Classic Part Number**
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-4095	Bearing-Inner	417-9486
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326

BWJ		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2P-0220	Gasket-Pump	398-2927

BWJ		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-4365	Retainer As	216-3554
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-7603	Drum-Steer Cl Dr	213-6951
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203

Sales Model D6G (Cont'd.)

BWJ		
Original Part Number	Part Name	Classic Part Number
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-6318	Flange-Drum	213-8165
3P-6816	Pump Gp-Gr 1	226-0164
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1899	Drum	219-9690
4D-2619	Bearing	417-4494
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407

BWJ		
Original Part Number	Part Name	Classic Part Number
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5L-6326	Bearing-Ball	420-3222
5M-5822	Gear-Pump Drive	247-4120

BWJ		
Original Part Number	Part Name	Classic Part Number
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6637	Bearing-Sleeve	380-7376
5M-6670	Shaft-Sprocket	216-7847
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358

Sales Model D6G (Cont'd.)

BWJ		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6T-0956	Pad As	367-6088
6T-1702	Support As	299-2065
6T-1711	Plate	389-6324
6T-1724	Bar As-Equalizer	283-5223
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-5916	Disc-Friction	377-7442
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-7681	Shaft As	307-1530
7G-8389	Guard	226-0202
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-1154	Bearing-Spl	417-4515
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1851	Bolt-Spring	226-0223

BWJ		
Original Part Number	Part Name	Classic Part Number
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-3486	Manifold-Exhaust	261-0899
7N-3521	Core As-O Clr	383-3699
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2336	Disc-Friction	433-7096
7V-0638	Spacer	425-3651
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-6868	Cyl Gp-040 405 X	430-5964
8M-6191	Sleeve-Bolt	226-0234

BWJ		
Original Part Number	Part Name	Classic Part Number
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

Sales Model D6G (Cont'd.)

BWJ		
Original Part Number	Part Name	Classic Part Number
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3595	Mount	418-1950
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8T-1177	Bearing-Rlr	419-1862
9G-6476	Rod Gp-Idler Rec	226-0198
9G-8303	Collar-Idler End	226-0242
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2038	Gear-Tfr Driven	215-1876
9M-2039	Gear-Tfr Driving	219-9672
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409
9M-6692	Strip	386-4934
9M-8395	Bearing-Sleeve	391-1103

BWJ		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125

BWJ		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

Sales Model D6G (Cont'd.)

C6G		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-4095	Bearing-Inner	417-9486
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173

C6G		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2H-9192	Bearing-Ball	394-8236
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-4365	Retainer As	216-3554
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-7603	Drum-Steer Cl Dr	213-6951
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439

C6G		
Original Part Number	Part Name	Classic Part Number
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-6318	Flange-Drum	213-8165
3P-6816	Pump Gp-Gr 1	226-0164
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1899	Drum	219-9690
4D-2619	Bearing	417-4494
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407

Sales Model D6G (Cont'd.)

C6G		
Original Part Number	Part Name	Classic Part Number
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5L-6326	Bearing-Ball	420-3222
5M-5822	Gear-Pump Drive	247-4120

C6G		
Original Part Number	Part Name	Classic Part Number
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6637	Bearing-Sleeve	380-7376
5M-6670	Shaft-Sprocket	216-7847
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273

C6G		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6T-0956	Pad As	367-6088
6T-1702	Support As	299-2065
6T-1711	Plate	389-6324
6T-1724	Bar As-Equalizer	283-5223
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-5916	Disc-Friction	377-7442
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-7681	Shaft As	307-1530
7G-8389	Guard	226-0202
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-1154	Bearing-Spl	417-4515
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474

Sales Model D6G (Cont'd.)

C6G		
Original Part Number	Part Name	Classic Part Number
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-3486	Manifold-Exhaust	261-0899
7N-3521	Core As-O Clr	383-3699
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-6868	Cyl Gp-040 405 X	430-5964
8M-6191	Sleeve-Bolt	226-0234

C6G		
Original Part Number	Part Name	Classic Part Number
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

C6G		
Original Part Number	Part Name	Classic Part Number
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3595	Mount	418-1950
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8T-1177	Bearing-Rlr	419-1862
9G-6476	Rod Gp-Idler Rec	226-0198
9G-8303	Collar-Idler End	226-0242
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9J-9598	Pin	296-1362
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2038	Gear-Tfr Driven	215-1876
9M-2039	Gear-Tfr Driving	219-9672
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409
9M-5045	Guard As-Wear	213-9111
9M-6692	Strip	386-4934
9M-8395	Bearing-Sleeve	391-1103
9N-5769	Cover-Housing	325-6050

Sales Model D6G (Cont'd.)

C6G		
Original Part Number	Part Name	Classic Part Number
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108

C6G		
Original Part Number	Part Name	Classic Part Number
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

C6G		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	217-7738
219-9693	Shaft-Classic	216-7876
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

C6X		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-4095	Bearing-Inner	417-9486
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212

C6X		
Original Part Number	Part Name	Classic Part Number
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368

C6X		
Original Part Number	Part Name	Classic Part Number
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006

Sales Model D6G (Cont'd.)

C6X		
Original Part Number	Part Name	Classic Part Number
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2H-9192	Bearing-Ball	394-8236
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-4365	Retainer As	216-3554
2S-7603	Drum-Steer Cl Dr	213-6951
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208

C6X		
Original Part Number	Part Name	Classic Part Number
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-6559	Cap-Bearing	296-1346
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-6318	Flange-Drum	213-8165
3P-6816	Pump Gp-Gr 1	226-0164
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1899	Drum	219-9690
4D-2619	Bearing	417-4494
4F-5004	Spring As-Arm	383-2128
4J-1616	Bracket	299-1982
4J-1999	Ballstud	314-8625
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-7693	Crankshaft As	269-8763
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

C6X		
Original Part Number	Part Name	Classic Part Number
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5A-7840	Shaft-Tr Sprkt	215-1687
5L-6326	Bearing-Ball	420-3222
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6637	Bearing-Sleeve	380-7376
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953

Sales Model D6G (Cont'd.)

C6X		
Original Part Number	Part Name	Classic Part Number
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6T-0956	Pad As	367-6088
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-5916	Disc-Friction	377-7442
7C-4297	Seal As-Cshaft	325-6192

C6X		
Original Part Number	Part Name	Classic Part Number
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-4605	Support As	387-2938
7G-7681	Shaft As	307-1530
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-1154	Bearing-Spl	417-4515
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-3521	Core As-O Clr	383-3699
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127

C6X		
Original Part Number	Part Name	Classic Part Number
7T-0341	Support	425-9191
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-6868	Cyl Gp-040 405 X	430-5964
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207

Sales Model D6G (Cont'd.)

C6X		
Original Part Number	**Part Name**	**Classic Part Number**
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8T-1177	Bearing-Rlr	419-1862
9G-8303	Collar-Idler End	226-0242
9J-2007	Piston As	419-4714
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2038	Gear-Tfr Driven	215-1876
9M-2039	Gear-Tfr Driving	219-9672

C6X		
Original Part Number	**Part Name**	**Classic Part Number**
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409
9M-5045	Guard As-Wear	213-9111
9M-6692	Strip	386-4934
9M-8395	Bearing-Sleeve	391-1103
9N-5769	Cover-Housing	325-6050
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-9000	Shaft-Ster Cl	217-7738
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977

C6X		
Original Part Number	**Part Name**	**Classic Part Number**
124-3237	Precleaner As	432-4220
134-4200	Manifold-Exhaust	443-2060
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	217-7738
219-9693	Shaft-Classic	216-7876
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

Sales Model D6G (Cont'd.)

P6G		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-4095	Bearing-Inner	417-9486
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-5331	Cylinder-Adj	226-0214
1S-8734	Bracket-Roller	226-0212
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173

P6G		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2H-9192	Bearing-Ball	394-8236
2J-1424	Rod As	469-4665
2J-8489	Bearing-Sleeve	295-5691
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7984	Yoke As-Idler	226-0220
2S-4365	Retainer As	216-3554
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-7603	Drum-Steer Cl Dr	213-6951
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033

P6G		
Original Part Number	Part Name	Classic Part Number
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-5432	Pin-Pivot	361-1711
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3L-1425	Bearing-Ball	311-9356
3P-1459	Spring-Recoil	375-5448
3P-6318	Flange-Drum	213-8165
3P-6816	Pump Gp-Gr 1	226-0164
3S-1691	Disc-Steer Cl Dr	302-2705
3S-3875	Screen-Suction	435-4849
3T-1899	Drum	219-9690
4D-2619	Bearing	417-4494
4F-1252	Pin	295-5704
4F-5004	Spring As-Arm	383-2128
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0432	Bearing-Ball	417-4499

Sales Model D6G (Cont'd.)

P6G		
Original Part Number	Part Name	Classic Part Number
4N-4539	Sleeve	314-8720
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724
4S-9062	Cap-Fd Bearing	226-0204
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9771	Gear-Crankshaft	302-2674
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
5L-6326	Bearing-Ball	420-3222
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694

P6G		
Original Part Number	Part Name	Classic Part Number
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6637	Bearing-Sleeve	380-7376
5M-6670	Shaft-Sprocket	216-7847
5M-7290	Cage-Bearing	216-7848
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919

P6G		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-8183	Bracket	394-0195
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-2549	Mount As	384-3467
6N-3256	Mount As	314-8688
6N-7174	Shield-Oil	314-8544
6T-0956	Pad As	367-6088
6T-1702	Support As	299-2065
6T-1711	Plate	389-6324
6T-1724	Bar As-Equalizer	283-5223
6T-8907	Pad As	380-7391
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-5916	Disc-Friction	377-7442
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-7681	Shaft As	307-1530
7G-8389	Guard	226-0202
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-1154	Bearing-Spl	417-4515
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229

Sales Model D6G (Cont'd.)

P6G		
Original Part Number	Part Name	Classic Part Number
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-3486	Manifold-Exhaust	261-0899
7N-3521	Core As-O Clr	383-3699
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0205	Bearing-Brace	247-4127
7T-0341	Support	425-9191
7T-2336	Disc-Friction	433-7096
7V-0638	Spacer	425-3651
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8H-2810	Case As-Filter	314-8512
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-6868	Cyl Gp-040 405 X	430-5964
8M-6191	Sleeve-Bolt	226-0234
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236

P6G		
Original Part Number	Part Name	Classic Part Number
8M-7208	Guard As-Frame	226-0237
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083

P6G		
Original Part Number	Part Name	Classic Part Number
8N-8229	Bearing-Main	376-9084
8P-3595	Mount	418-1950
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8T-1177	Bearing-Rlr	419-1862
9G-6476	Rod Gp-Idler Rec	226-0198
9G-8303	Collar-Idler End	226-0242
9J-2007	Piston As	419-4714
9J-2332	Bearing-Pivot	299-1969
9M-0701	Piston-Steer Cl	219-9692
9M-1500	Shaft-Planet	219-9685
9M-1990	Dowel-Reaction	386-4963
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2038	Gear-Tfr Driven	215-1876
9M-2039	Gear-Tfr Driving	219-9672
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409
9M-5045	Guard As-Wear	213-9111
9M-6692	Strip	386-4934
9M-8395	Bearing-Sleeve	391-1103
9N-5769	Cover-Housing	325-6050
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-9000	Shaft-Ster Cl	217-7738

Sales Model D6G (Cont'd.)

P6G		
Original Part Number	Part Name	Classic Part Number
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9575	Cage-Bev Gr Brg	216-7876
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165

P6G		
Original Part Number	Part Name	Classic Part Number
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

P6G		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
230-7114	Ster Cl Kit-Cla	219-9690
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955

Sales Model D6H

1FJ		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145

1FJ		
Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1U-0725	Retainer	314-8707
1U-1625	Pump Gp-Gr A	421-1555
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981

1FJ		
Original Part Number	Part Name	Classic Part Number
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173

Sales Model D6H (Cont'd.)

1FJ		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2M-8340	Rod End-Yoke	374-4678
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055

1FJ		
Original Part Number	Part Name	Classic Part Number
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-6559	Cap-Bearing	296-1346
3J-6561	Screw-Adj	297-7241
3J-6573	Screw-Adjusting	302-2714
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1407	Disc-Friction	392-4516
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632

1FJ		
Original Part Number	Part Name	Classic Part Number
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5G-3612	Cap Gp-Protn	295-6419

Sales Model D6H (Cont'd.)

1FJ		
Original Part Number	Part Name	Classic Part Number
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-5404	Plate-Cl & Brake	325-6168
6P-7704	Carrier-Ring	314-8658
6T-0016	Pump Gp-Gr 4 Bsc	418-1957
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl & Brake	325-6170
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487

1FJ		
Original Part Number	Part Name	Classic Part Number
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-7946	Disc-Friction	384-4801
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2824	Piston	295-6439
7G-2828	Plate-Clutch	325-6171
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7681	Shaft As	307-1530
7G-9555	Univ Joint As	314-8721
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531

1FJ		
Original Part Number	Part Name	Classic Part Number
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

Sales Model D6H (Cont'd.)

1FJ		
Original Part Number	Part Name	Classic Part Number
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-7818	Bracket	226-0211
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9D-3242	Cone-Roller Brg	453-3659

1FJ		
Original Part Number	Part Name	Classic Part Number
9G-8638	Gear-Planet	295-6425
9G-9078	Sleeve	431-6618
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9T-5360	Plate-Pressure	424-4941
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
104-3014	Gasket Kit	388-0656
106-6540	Retainer	418-1941
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
136-7813	Bearing-Race	460-8296
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038

1FJ		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model D6H (Cont'd.)

1KD		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-1625	Pump Gp-Gr A	421-1555
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020

1KD		
Original Part Number	Part Name	Classic Part Number
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-9192	Bearing-Ball	394-8236
2J-8489	Bearing-Sleeve	295-5691
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356

1KD		
Original Part Number	Part Name	Classic Part Number
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-6561	Screw-Adj	297-7241
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982

Sales Model D6H (Cont'd.)

1KD		
Original Part Number	Part Name	Classic Part Number
4J-1641	Trunnion	314-8725
4J-1999	Ballstud	314-8625
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889

1KD		
Original Part Number	Part Name	Classic Part Number
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-5404	Plate-Cl & Brake	325-6168
6P-7704	Carrier-Ring	314-8658

1KD		
Original Part Number	Part Name	Classic Part Number
6S-2828	Cup-Roller Brg	384-5932
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl & Brake	325-6170
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-7946	Disc-Friction	384-4801
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206

Sales Model D6H (Cont'd.)

1KD		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366

1KD		
Original Part Number	Part Name	Classic Part Number
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

1KD		
Original Part Number	Part Name	Classic Part Number
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-7818	Bracket	226-0211
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219

Sales Model D6H (Cont'd.)

1KD		
Original Part Number	**Part Name**	**Classic Part Number**
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9T-5360	Plate-Pressure	424-4941
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932

1KD		
Original Part Number	**Part Name**	**Classic Part Number**
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
139-6850	Gasket Kit	384-4809
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687

1KD		
Original Part Number	**Part Name**	**Classic Part Number**
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
201-2078	Bar As-Equalizer	418-1946
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

1YL		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145

1YL		
Original Part Number	**Part Name**	**Classic Part Number**
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409

1YL		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158

Sales Model D6H (Cont'd.)

1YL		
Original Part Number	Part Name	Classic Part Number
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214

1YL		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700

1YL		
Original Part Number	Part Name	Classic Part Number
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217

Sales Model D6H (Cont'd.)

1YL		
Original Part Number	Part Name	Classic Part Number
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673

1YL		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450

1YL		
Original Part Number	Part Name	Classic Part Number
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935

Sales Model D6H (Cont'd.)

1YL		
Original Part Number	Part Name	Classic Part Number
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349

1YL		
Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364

1YL		
Original Part Number	Part Name	Classic Part Number
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
139-6850	Gasket Kit	384-4809

Sales Model D6H (Cont'd.)

1YL		
Original Part Number	Part Name	Classic Part Number
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

1YL		
Original Part Number	Part Name	Classic Part Number
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

1YL		
Original Part Number	Part Name	Classic Part Number
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

1KD		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180

1KD		
Original Part Number	Part Name	Classic Part Number
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-1625	Pump Gp-Gr A	421-1555
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689

1KD		
Original Part Number	Part Name	Classic Part Number
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-9192	Bearing-Ball	394-8236
2J-8489	Bearing-Sleeve	295-5691
2K-5066	Cone-Roller Brg	396-4142

Sales Model D6H (Cont'd.)

1KD		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-6561	Screw-Adj	297-7241
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524

1KD		
Original Part Number	Part Name	Classic Part Number
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-1999	Ballstud	314-8625
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988

1KD		
Original Part Number	Part Name	Classic Part Number
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

Sales Model D6H (Cont'd.)

1KD		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-5404	Plate-Cl & Brake	325-6168
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl & Brake	325-6170
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-7946	Disc-Friction	384-4801
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697

1KD		
Original Part Number	Part Name	Classic Part Number
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721

1KD		
Original Part Number	Part Name	Classic Part Number
7T-3566	Piston	394-9191
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

Sales Model D6H (Cont'd.)

1KD		
Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-7818	Bracket	226-0211
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215

1KD		
Original Part Number	Part Name	Classic Part Number
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9T-5360	Plate-Pressure	424-4941
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035

1KD		
Original Part Number	Part Name	Classic Part Number
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
139-6850	Gasket Kit	384-4809
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

Sales Model D6H (Cont'd.)

1KD		
Original Part Number	Part Name	Classic Part Number
201-2078	Bar As-Equalizer	418-1946
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351

1KD		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

1KD		
Original Part Number	Part Name	Classic Part Number
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

1YL		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543

1YL		
Original Part Number	Part Name	Classic Part Number
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354

1YL		
Original Part Number	Part Name	Classic Part Number
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892

Sales Model D6H (Cont'd.)

1YL		
Original Part Number	Part Name	Classic Part Number
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4D-4065	Rod End-Spher	374-1824

1YL		
Original Part Number	Part Name	Classic Part Number
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355

1YL		
Original Part Number	Part Name	Classic Part Number
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673

Sales Model D6H (Cont'd.)

1YL		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414

1YL		
Original Part Number	Part Name	Classic Part Number
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656

1YL		
Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As-Radiator	295-6417
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196

Sales Model D6H (Cont'd.)

1YL		
Original Part Number	Part Name	Classic Part Number
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213

1YL		
Original Part Number	Part Name	Classic Part Number
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414

1YL		
Original Part Number	Part Name	Classic Part Number
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
139-6850	Gasket Kit	384-4809
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

Sales Model D6H (Cont'd.)

1YL		
Original Part Number	**Part Name**	**Classic Part Number**
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835

1YL		
Original Part Number	**Part Name**	**Classic Part Number**
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351

1YL		
Original Part Number	**Part Name**	**Classic Part Number**
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

2BL		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347

2BL		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707

2BL		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-9192	Bearing-Ball	394-8236
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214

Sales Model D6H (Cont'd.)

2BL		
Original Part Number	Part Name	Classic Part Number
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341

2BL		
Original Part Number	Part Name	Classic Part Number
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987

2BL		
Original Part Number	Part Name	Classic Part Number
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273

Sales Model D6H (Cont'd.)

2BL		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0248	Ring-Seal	295-6440
6T-3080	Plate-Cl & Brake	325-6170
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-7946	Disc-Friction	384-4801
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450

2BL		
Original Part Number	Part Name	Classic Part Number
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660

2BL		
Original Part Number	Part Name	Classic Part Number
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290

Sales Model D6H (Cont'd.)

2BL		
Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050

2BL		
Original Part Number	Part Name	Classic Part Number
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9T-5360	Plate-Pressure	424-4941
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
139-6850	Gasket Kit	384-4809
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361

2BL		
Original Part Number	Part Name	Classic Part Number
155-1379	Gasket Kit - Sch	386-3815
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349

Sales Model D6H (Cont'd.)

2BL		
Original Part Number	Part Name	Classic Part Number
334-8389	Crankshaft As	242-3439

2BL		
Original Part Number	Part Name	Classic Part Number
374-1849	Brg-Rlr-Cla	399-4442

2BL		
Original Part Number	Part Name	Classic Part Number
391-8229	Kit-Gasket-Fs	398-2955

2DK		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981

2DK		
Original Part Number	Part Name	Classic Part Number
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

2DK		
Original Part Number	Part Name	Classic Part Number
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6561	Screw-Adj	297-7241
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341

Sales Model D6H (Cont'd.)

2DK		
Original Part Number	Part Name	Classic Part Number
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987

2DK		
Original Part Number	Part Name	Classic Part Number
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883

2DK		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205

Sales Model D6H (Cont'd.)

2DK		
Original Part Number	Part Name	Classic Part Number
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277

2DK		
Original Part Number	Part Name	Classic Part Number
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232

2DK		
Original Part Number	Part Name	Classic Part Number
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353

Sales Model D6H (Cont'd.)

2DK		
Original Part Number	Part Name	Classic Part Number
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583

2DK		
Original Part Number	Part Name	Classic Part Number
104-3014	Gasket Kit	388-0656
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484

2DK		
Original Part Number	Part Name	Classic Part Number
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

2KD		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

2KD		
Original Part Number	Part Name	Classic Part Number
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738

2KD		
Original Part Number	Part Name	Classic Part Number
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543

Sales Model D6H (Cont'd.)

2KD		
Original Part Number	Part Name	Classic Part Number
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-1625	Pump Gp-Gr A	421-1555
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-9192	Bearing-Ball	394-8236
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342

2KD		
Original Part Number	Part Name	Classic Part Number
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-2797	Bearing-Sleeve	360-2329
3G-8917	Pin	325-6141
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-6559	Cap-Bearing	296-1346
3J-6561	Screw-Adj	297-7241
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524

2KD		
Original Part Number	Part Name	Classic Part Number
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984

Sales Model D6H (Cont'd.)

2KD		
Original Part Number	Part Name	Classic Part Number
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4T-7534	Pin	433-9209
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024

2KD		
Original Part Number	Part Name	Classic Part Number
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-5404	Plate-Cl	325-6168
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl & Brake	325-6170
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574

2KD		
Original Part Number	Part Name	Classic Part Number
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-7946	Disc-Friction	384-4801
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531

Sales Model D6H (Cont'd.)

2KD		
Original Part Number	Part Name	Classic Part Number
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512

2KD		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212

2KD		
Original Part Number	Part Name	Classic Part Number
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9078	Sleeve	431-6618
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042

Sales Model D6H (Cont'd.)

2KD		
Original Part Number	**Part Name**	**Classic Part Number**
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9T-5360	Plate-Pressure	424-4941
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045

2KD		
Original Part Number	**Part Name**	**Classic Part Number**
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
139-6850	Gasket Kit	384-4809
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687

2KD		
Original Part Number	**Part Name**	**Classic Part Number**
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

2TG		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294

2TG		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347

2TG		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-1625	Pump Gp-Gr A	421-1555
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006

Sales Model D6H (Cont'd.)

2TG		
Original Part Number	Part Name	Classic Part Number
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-9192	Bearing-Ball	394-8236
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230

2TG		
Original Part Number	Part Name	Classic Part Number
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2903	Cover	422-6922
3J-6561	Screw-Adj	297-7241
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449

2TG		
Original Part Number	Part Name	Classic Part Number
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687

Sales Model D6H (Cont'd.)

2TG		
Original Part Number	Part Name	Classic Part Number
4T-1504	Trunnion	314-8727
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436

2TG		
Original Part Number	Part Name	Classic Part Number
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-5404	Plate-Cl & Brake	325-6168
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl & Brake	325-6170
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-7946	Disc-Friction	384-4801
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205

2TG		
Original Part Number	Part Name	Classic Part Number
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679

Sales Model D6H (Cont'd.)

2TG		
Original Part Number	Part Name	Classic Part Number
7W-5699	Pulley-Cshaft	378-3988
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207

2TG		
Original Part Number	Part Name	Classic Part Number
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-7818	Bracket	226-0211
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9078	Sleeve	431-6618
9G-9174	Gear-Sun	295-6430

2TG		
Original Part Number	Part Name	Classic Part Number
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9T-5360	Plate-Pressure	424-4941
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977

Sales Model D6H (Cont'd.)

2TG		
Original Part Number	Part Name	Classic Part Number
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
139-6850	Gasket Kit	384-4809
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

2TG		
Original Part Number	Part Name	Classic Part Number
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

2TG		
Original Part Number	Part Name	Classic Part Number
201-2078	Bar As-Equalizer	418-1946
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

2TL		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685

2TL		
Original Part Number	Part Name	Classic Part Number
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

2TL		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

Sales Model D6H (Cont'd.)

2TL		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481

2TL		
Original Part Number	Part Name	Classic Part Number
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919

2TL		
Original Part Number	Part Name	Classic Part Number
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4T-7534	Pin	433-9209
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433

Sales Model D6H (Cont'd.)

2TL		
Original Part Number	Part Name	Classic Part Number
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487

2TL		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899

2TL		
Original Part Number	Part Name	Classic Part Number
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512

Sales Model D6H (Cont'd.)

2TL		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212

2TL		
Original Part Number	Part Name	Classic Part Number
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431

2TL		
Original Part Number	Part Name	Classic Part Number
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
139-6850	Gasket Kit	384-4809
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

Sales Model D6H (Cont'd.)

2TL		
Original Part Number	Part Name	Classic Part Number
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

2TL		
Original Part Number	Part Name	Classic Part Number
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989

2TL		
Original Part Number	Part Name	Classic Part Number
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

3ED		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1U-0725	Retainer	314-8707
1U-1625	Pump Gp-Gr A	421-1555
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

3ED		
Original Part Number	Part Name	Classic Part Number
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2M-8340	Rod End-Yoke	374-4678
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230

3ED		
Original Part Number	Part Name	Classic Part Number
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6561	Screw-Adj	297-7241
3J-6573	Screw-Adjusting	302-2714
3L-9409	Cup-Roller Brg	399-4436
3T-0996	Bearing-Sleeve	295-5695

Sales Model D6H (Cont'd.)

3ED		
Original Part Number	Part Name	Classic Part Number
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1407	Disc-Friction	392-4516
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

3ED		
Original Part Number	Part Name	Classic Part Number
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5G-3612	Cap Gp-Protn	295-6419
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358

3ED		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-5404	Plate-Cl & Brake	325-6168
6P-7704	Carrier-Ring	314-8658
6T-0016	Pump Gp-Gr 4 Bsc	418-1957
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl & Brake	325-6170
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-7946	Disc-Friction	384-4801
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2824	Piston	295-6439
7G-2828	Plate-Clutch	325-6171

Sales Model D6H (Cont'd.)

3ED		
Original Part Number	Part Name	Classic Part Number
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7681	Shaft As	307-1530
7G-9555	Univ Joint As	314-8721
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895

3ED		
Original Part Number	Part Name	Classic Part Number
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

3ED		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9D-3242	Cone-Roller Brg	453-3659
9G-8638	Gear-Planet	295-6425
9G-9078	Sleeve	431-6618
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165

Sales Model D6H (Cont'd.)

3ED		
Original Part Number	Part Name	Classic Part Number
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
104-3014	Gasket Kit	388-0656
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
136-7813	Bearing-Race	460-8296
140-2246	Gasket Kit	383-3710
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

3ED		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055

3ED		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

3YG		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410

3YG		
Original Part Number	Part Name	Classic Part Number
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515

3YG		
Original Part Number	Part Name	Classic Part Number
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-8489	Bearing-Sleeve	295-5691

Sales Model D6H (Cont'd.)

3YG		
Original Part Number	Part Name	Classic Part Number
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-6561	Screw-Adj	297-7241
3K-2511	Dowel-Reaction	383-2126

3YG		
Original Part Number	Part Name	Classic Part Number
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
3W-6555	Shaft	295-5703
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

3YG		
Original Part Number	Part Name	Classic Part Number
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920

Sales Model D6H (Cont'd.)

3YG		
Original Part Number	Part Name	Classic Part Number
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-8037	Guide As	435-9915

3YG		
Original Part Number	Part Name	Classic Part Number
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5089	Gasket	394-0890
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290

3YG		
Original Part Number	Part Name	Classic Part Number
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-4526	Disc-Friction	417-9495
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801

Sales Model D6H (Cont'd.)

3YG		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438

3YG		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-7818	Bracket	226-0211
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9078	Sleeve	431-6618
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9J-9598	Pin	296-1362
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042

3YG		
Original Part Number	Part Name	Classic Part Number
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
134-4200	Manifold-Exhaust	443-2060
139-6850	Gasket Kit	384-4809
141-4974	Gasket Kit	388-0658
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686

Sales Model D6H (Cont'd.)

3YG		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

3YG		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
201-2078	Bar As-Equalizer	418-1946
208-8796	Retainer	417-9489

3YG		
Original Part Number	Part Name	Classic Part Number
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

3ZF		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180

3ZF		
Original Part Number	Part Name	Classic Part Number
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210

3ZF		
Original Part Number	Part Name	Classic Part Number
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927

Sales Model D6H (Cont'd.)

3ZF		
Original Part Number	Part Name	Classic Part Number
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6561	Screw-Adj	297-7241
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524

3ZF		
Original Part Number	Part Name	Classic Part Number
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008

3ZF		
Original Part Number	Part Name	Classic Part Number
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502

Sales Model D6H (Cont'd.)

3ZF		
Original Part Number	Part Name	Classic Part Number
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9568	Gasket Kit	393-3625
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427

3ZF		
Original Part Number	Part Name	Classic Part Number
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5089	Gasket	394-0890
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848

3ZF		
Original Part Number	Part Name	Classic Part Number
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-4526	Disc-Friction	417-9495
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444

Sales Model D6H (Cont'd.)

3ZF		
Original Part Number	Part Name	Classic Part Number
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209

3ZF		
Original Part Number	Part Name	Classic Part Number
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-7818	Bracket	226-0211
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9078	Sleeve	431-6618
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9J-9598	Pin	296-1362
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923

3ZF		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
134-4200	Manifold-Exhaust	443-2060
139-6850	Gasket Kit	384-4809
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361

Sales Model D6H (Cont'd.)

3ZF		
Original Part Number	Part Name	Classic Part Number
155-1379	Gasket Kit - Sch	386-3815
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

3ZF		
Original Part Number	Part Name	Classic Part Number
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

3ZF		
Original Part Number	Part Name	Classic Part Number
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

4GG		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409

4GG		
Original Part Number	Part Name	Classic Part Number
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689

4GG		
Original Part Number	Part Name	Classic Part Number
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-8489	Bearing-Sleeve	295-5691
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2N-2139	Cone-Roller Brg	415-1911

Sales Model D6H (Cont'd.)

4GG		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-4284	Cap-Brg	314-8656
3J-6561	Screw-Adj	297-7241
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051

4GG		
Original Part Number	Part Name	Classic Part Number
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6555	Shaft	295-5703
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988

4GG		
Original Part Number	Part Name	Classic Part Number
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

Sales Model D6H (Cont'd.)

4GG		
Original Part Number	Part Name	Classic Part Number
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414

4GG		
Original Part Number	Part Name	Classic Part Number
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354

4GG		
Original Part Number	Part Name	Classic Part Number
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-4526	Disc-Friction	417-9495
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

Sales Model D6H (Cont'd.)

4GG		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425

4GG		
Original Part Number	Part Name	Classic Part Number
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977

4GG		
Original Part Number	Part Name	Classic Part Number
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
139-6850	Gasket Kit	384-4809
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
201-2078	Bar As-Equalizer	418-1946
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085

Sales Model D6H (Cont'd.)

4GG		
Original Part Number	**Part Name**	**Classic Part Number**
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438

4GG		
Original Part Number	**Part Name**	**Classic Part Number**
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

4GG		
Original Part Number	**Part Name**	**Classic Part Number**
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

4LG		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-1625	Pump Gp-Gr A	421-1555

4LG		
Original Part Number	**Part Name**	**Classic Part Number**
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-9192	Bearing-Ball	394-8236
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142

4LG		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5069	Cup-Roller Brg	374-8346
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465

Sales Model D6H (Cont'd.)

4LG		
Original Part Number	Part Name	Classic Part Number
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-6559	Cap-Bearing	296-1346
3J-6561	Screw-Adj	297-7241
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633

4LG		
Original Part Number	Part Name	Classic Part Number
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5G-9075	Strip	295-0412

4LG		
Original Part Number	Part Name	Classic Part Number
5G-9076	Strip	295-0413
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-5404	Plate-Cl & Brake	325-6168
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0239	Piston	418-9591

Sales Model D6H (Cont'd.)

4LG		
Original Part Number	Part Name	Classic Part Number
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl & Brake	325-6170
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-7946	Disc-Friction	384-4801
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922

4LG		
Original Part Number	Part Name	Classic Part Number
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069

4LG		
Original Part Number	Part Name	Classic Part Number
8D-1817	Cup-Roller Brg	434-3296
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

Sales Model D6H (Cont'd.)

4LG		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-7818	Bracket	226-0211
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9078	Sleeve	431-6618
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050

4LG		
Original Part Number	Part Name	Classic Part Number
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9T-5360	Plate-Pressure	424-4941
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
139-6850	Gasket Kit	384-4809

4LG		
Original Part Number	Part Name	Classic Part Number
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966

Sales Model D6H (Cont'd.)

4LG		
Original Part Number	Part Name	Classic Part Number
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349

4LG		
Original Part Number	Part Name	Classic Part Number
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442

4LG		
Original Part Number	Part Name	Classic Part Number
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

4RC		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-1625	Pump Gp-Gr A	421-1555
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

4RC		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-9192	Bearing-Ball	394-8236
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342

4RC		
Original Part Number	Part Name	Classic Part Number
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-6559	Cap-Bearing	296-1346
3J-6561	Screw-Adj	297-7241
3J-6573	Screw-Adjusting	302-2714

Sales Model D6H (Cont'd.)

4RC		
Original Part Number	Part Name	Classic Part Number
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236

4RC		
Original Part Number	Part Name	Classic Part Number
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502

4RC		
Original Part Number	Part Name	Classic Part Number
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-5404	Plate-Cl & Brake	325-6168
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl & Brake	325-6170
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442

Sales Model D6H (Cont'd.)

4RC		
Original Part Number	Part Name	Classic Part Number
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6V-4785	Gasket Kit - Fs	388-0661
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-7946	Disc-Friction	384-4801
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581

4RC		
Original Part Number	Part Name	Classic Part Number
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366

4RC		
Original Part Number	Part Name	Classic Part Number
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

Sales Model D6H (Cont'd.)

4RC		
Original Part Number	Part Name	Classic Part Number
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-7818	Bracket	226-0211
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9078	Sleeve	431-6618
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9J-9598	Pin	296-1362
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719

4RC		
Original Part Number	Part Name	Classic Part Number
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9T-5360	Plate-Pressure	424-4941
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
134-4200	Manifold-Exhaust	443-2060
139-6850	Gasket Kit	384-4809
141-4974	Gasket Kit	388-0658
147-1010	Gasket Kit	390-5278

4RC		
Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

Sales Model D6H (Cont'd.)

4RC		
Original Part Number	Part Name	Classic Part Number
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966

4RC		
Original Part Number	Part Name	Classic Part Number
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442

4RC		
Original Part Number	Part Name	Classic Part Number
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

4YF		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680

4YF		
Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2N-2139	Cone-Roller Brg	415-1911

4YF		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346

Sales Model D6H (Cont'd.)

4YF		
Original Part Number	Part Name	Classic Part Number
3J-6561	Screw-Adj	297-7241
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633

4YF		
Original Part Number	Part Name	Classic Part Number
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413

4YF		
Original Part Number	Part Name	Classic Part Number
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444

Sales Model D6H (Cont'd.)

4YF		
Original Part Number	Part Name	Classic Part Number
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722

4YF		
Original Part Number	Part Name	Classic Part Number
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-4526	Disc-Friction	417-9495
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444

4YF		
Original Part Number	Part Name	Classic Part Number
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209

Sales Model D6H (Cont'd.)

4YF		
Original Part Number	Part Name	Classic Part Number
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9078	Sleeve	431-6618
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042

4YF		
Original Part Number	Part Name	Classic Part Number
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
139-6850	Gasket Kit	384-4809
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125

4YF		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model D6H (Cont'd.)

5HF		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020

5HF		
Original Part Number	Part Name	Classic Part Number
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084

5HF		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-6561	Screw-Adj	297-7241
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160

Sales Model D6H (Cont'd.)

5HF		
Original Part Number	Part Name	Classic Part Number
3W-0643	Cylinder	325-6061
3W-6555	Shaft	295-5703
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

5HF		
Original Part Number	Part Name	Classic Part Number
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991

5HF		
Original Part Number	Part Name	Classic Part Number
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016

Sales Model D6H (Cont'd.)

5HF		
Original Part Number	Part Name	Classic Part Number
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989

5HF		
Original Part Number	Part Name	Classic Part Number
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8E-4526	Disc-Friction	417-9495
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377

5HF		
Original Part Number	Part Name	Classic Part Number
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9078	Sleeve	431-6618
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218

Sales Model D6H (Cont'd.)

5HF		
Original Part Number	Part Name	Classic Part Number
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360

5HF		
Original Part Number	Part Name	Classic Part Number
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
139-6850	Gasket Kit	384-4809
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

5HF		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
201-2078	Bar As-Equalizer	418-1946
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

5KK		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087

5KK		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145

5KK		
Original Part Number	Part Name	Classic Part Number
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685

Sales Model D6H (Cont'd.)

5KK		
Original Part Number	Part Name	Classic Part Number
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-9192	Bearing-Ball	394-8236

5KK		
Original Part Number	Part Name	Classic Part Number
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922

5KK		
Original Part Number	Part Name	Classic Part Number
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919

Sales Model D6H (Cont'd.)

5KK		
Original Part Number	Part Name	Classic Part Number
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920

5KK		
Original Part Number	Part Name	Classic Part Number
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0248	Ring-Seal	295-6440
6T-3080	Plate-Cl & Brake	325-6170
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801

5KK		
Original Part Number	Part Name	Classic Part Number
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-7946	Disc-Friction	384-4801
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531

Sales Model D6H (Cont'd.)

5KK		
Original Part Number	Part Name	Classic Part Number
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420

5KK		
Original Part Number	Part Name	Classic Part Number
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372

5KK		
Original Part Number	Part Name	Classic Part Number
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9T-5360	Plate-Pressure	424-4941
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701

Sales Model D6H (Cont'd.)

5KK		
Original Part Number	Part Name	Classic Part Number
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
139-6850	Gasket Kit	384-4809
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361

5KK		
Original Part Number	Part Name	Classic Part Number
155-1379	Gasket Kit - Sch	386-3815
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

5KK		
Original Part Number	Part Name	Classic Part Number
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

6CF		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582

6CF		
Original Part Number	Part Name	Classic Part Number
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920

6CF		
Original Part Number	Part Name	Classic Part Number
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020

Sales Model D6H (Cont'd.)

6CF		
Original Part Number	Part Name	Classic Part Number
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084

6CF		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6561	Screw-Adj	297-7241
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449

6CF		
Original Part Number	Part Name	Classic Part Number
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355

Sales Model D6H (Cont'd.)

6CF		
Original Part Number	Part Name	Classic Part Number
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673

6CF		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441

6CF		
Original Part Number	Part Name	Classic Part Number
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491

Sales Model D6H (Cont'd.)

6CF		
Original Part Number	Part Name	Classic Part Number
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8E-4526	Disc-Friction	417-9495
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

6CF		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425

6CF		
Original Part Number	Part Name	Classic Part Number
9G-9078	Sleeve	431-6618
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490

Sales Model D6H (Cont'd.)

6CF		
Original Part Number	Part Name	Classic Part Number
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
139-6850	Gasket Kit	384-4809
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038

6CF		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835

6CF		
Original Part Number	Part Name	Classic Part Number
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

6CK		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442

6CK		
Original Part Number	Part Name	Classic Part Number
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158

6CK		
Original Part Number	Part Name	Classic Part Number
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707

Sales Model D6H (Cont'd.)

6CK		
Original Part Number	Part Name	Classic Part Number
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439

6CK		
Original Part Number	Part Name	Classic Part Number
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632

6CK		
Original Part Number	Part Name	Classic Part Number
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413

Sales Model D6H (Cont'd.)

6CK		
Original Part Number	Part Name	Classic Part Number
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442

6CK		
Original Part Number	Part Name	Classic Part Number
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451

6CK		
Original Part Number	Part Name	Classic Part Number
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444

Sales Model D6H (Cont'd.)

6CK		
Original Part Number	Part Name	Classic Part Number
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445

6CK		
Original Part Number	Part Name	Classic Part Number
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639

6CK		
Original Part Number	Part Name	Classic Part Number
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
139-6850	Gasket Kit	384-4809
141-4974	Gasket Kit	388-0658
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

Sales Model D6H (Cont'd.)

6CK		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

6CK		
Original Part Number	**Part Name**	**Classic Part Number**
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524

6CK		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

6FC		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347

6FC		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-1625	Pump Gp-Gr A	421-1555
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

6FC		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-9192	Bearing-Ball	394-8236
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

Sales Model D6H (Cont'd.)

6FC		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2903	Cover	422-6922
3J-6561	Screw-Adj	297-7241
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341

6FC		
Original Part Number	Part Name	Classic Part Number
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355

6FC		
Original Part Number	Part Name	Classic Part Number
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9568	Gasket Kit	393-3625
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475

Sales Model D6H (Cont'd.)

6FC		
Original Part Number	Part Name	Classic Part Number
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-5404	Plate-Cl	325-6168
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl & Brake	325-6170
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-7946	Disc-Friction	384-4801
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450

6FC		
Original Part Number	Part Name	Classic Part Number
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351

6FC		
Original Part Number	Part Name	Classic Part Number
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623

Sales Model D6H (Cont'd.)

6FC		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-7818	Bracket	226-0211
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424

6FC		
Original Part Number	Part Name	Classic Part Number
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9078	Sleeve	431-6618
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9J-9598	Pin	296-1362
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9T-5360	Plate-Pressure	424-4941
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446

6FC		
Original Part Number	Part Name	Classic Part Number
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
134-4200	Manifold-Exhaust	443-2060
139-6850	Gasket Kit	384-4809
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835

Sales Model D6H (Cont'd.)

6FC		
Original Part Number	**Part Name**	**Classic Part Number**
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
201-2078	Bar As-Equalizer	418-1946
208-8796	Retainer	417-9489

6FC		
Original Part Number	**Part Name**	**Classic Part Number**
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989

6FC		
Original Part Number	**Part Name**	**Classic Part Number**
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

7ED		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
2K-5066	Cone-Roller Brg	396-4142

7ED		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5069	Cup-Roller Brg	374-8346
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487

7ED		
Original Part Number	**Part Name**	**Classic Part Number**
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
374-1849	Brg-Rlr-Cla	399-4442

7PC		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180

7PC		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-1625	Pump Gp-Gr A	421-1555
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020

7PC		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142

Sales Model D6H (Cont'd.)

7PC		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6561	Screw-Adj	297-7241
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695

7PC		
Original Part Number	Part Name	Classic Part Number
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009

7PC		
Original Part Number	Part Name	Classic Part Number
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467

Sales Model D6H (Cont'd.)

7PC		
Original Part Number	Part Name	Classic Part Number
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-5404	Plate-Cl	325-6168
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl	325-6170
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-7946	Disc-Friction	384-4801

7PC		
Original Part Number	Part Name	Classic Part Number
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438

7PC		
Original Part Number	Part Name	Classic Part Number
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893

Sales Model D6H (Cont'd.)

7PC		
Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416

7PC		
Original Part Number	Part Name	Classic Part Number
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9078	Sleeve	431-6618
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9J-9598	Pin	296-1362
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437

7PC		
Original Part Number	Part Name	Classic Part Number
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
139-6850	Gasket Kit	384-4809
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259

Sales Model D6H (Cont'd.)

7PC		
Original Part Number	Part Name	Classic Part Number
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357

7PC		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

7PC		
Original Part Number	Part Name	Classic Part Number
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

7ZK		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680

7ZK		
Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-9192	Bearing-Ball	394-8236
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2N-2139	Cone-Roller Brg	415-1911

7ZK		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922

Sales Model D6H (Cont'd.)

7ZK		
Original Part Number	Part Name	Classic Part Number
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236

7ZK		
Original Part Number	Part Name	Classic Part Number
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4T-7534	Pin	433-9209
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920

7ZK		
Original Part Number	Part Name	Classic Part Number
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0248	Ring-Seal	295-6440
6T-3080	Plate-Cl & Brake	325-6170
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132

Sales Model D6H (Cont'd.)

7ZK		
Original Part Number	Part Name	Classic Part Number
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-7946	Disc-Friction	384-4801
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995

7ZK		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

7ZK		
Original Part Number	Part Name	Classic Part Number
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1177	Bearing-Rlr	419-1862
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216

Sales Model D6H (Cont'd.)

7ZK		
Original Part Number	Part Name	Classic Part Number
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9T-5360	Plate-Pressure	424-4941
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666

7ZK		
Original Part Number	Part Name	Classic Part Number
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
139-6850	Gasket Kit	384-4809
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127

7ZK		
Original Part Number	Part Name	Classic Part Number
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

8FC		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443

8FC		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535

8FC		
Original Part Number	Part Name	Classic Part Number
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572

Sales Model D6H (Cont'd.)

8FC		
Original Part Number	Part Name	Classic Part Number
1U-1625	Pump Gp-Gr A	421-1555
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2J-8489	Bearing-Sleeve	295-5691
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2M-8340	Rod End-Yoke	374-4678
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

8FC		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2903	Cover	422-6922
3J-4284	Cap-Brg	314-8656
3J-6561	Screw-Adj	297-7241
3L-9409	Cup-Roller Brg	399-4436
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1407	Disc-Friction	392-4516
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061

8FC		
Original Part Number	Part Name	Classic Part Number
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990

Sales Model D6H (Cont'd.)

8FC		
Original Part Number	Part Name	Classic Part Number
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
4Y-7089	Pin As-Rmte Lub	397-5042
5G-3612	Cap Gp-Protn	295-6419
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-5404	Plate-Cl & Brake	325-6168
6P-7704	Carrier-Ring	314-8658
6T-0016	Pump Gp-Gr 4 Bsc	418-1957
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl & Brake	325-6170

8FC		
Original Part Number	Part Name	Classic Part Number
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-1033	Rod End-Spher	375-5444
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-7946	Disc-Friction	384-4801
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2824	Piston	295-6439
7G-2828	Plate-Clutch	325-6171
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7681	Shaft As	307-1530
7G-9555	Univ Joint As	314-8721
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686

8FC		
Original Part Number	Part Name	Classic Part Number
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8N-0703	Bearing-Sleeve	472-8037

Sales Model D6H (Cont'd.)

8FC		
Original Part Number	Part Name	Classic Part Number
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-7818	Bracket	226-0211
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402

8FC		
Original Part Number	Part Name	Classic Part Number
9D-3242	Cone-Roller Brg	453-3659
9G-8638	Gear-Planet	295-6425
9G-9078	Sleeve	431-6618
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9M-1853	Mount As.	376-3638
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9T-5360	Plate-Pressure	424-4941
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
104-3014	Gasket Kit	388-0656
106-6540	Retainer	418-1941
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
136-7813	Bearing-Race	460-8296
140-2246	Gasket Kit	383-3710
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125

8FC		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
201-2078	Bar As-Equalizer	418-1946
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model D6H (Cont'd.)

8KB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1U-0725	Retainer	314-8707
1U-1625	Pump Gp-Gr A	421-1555
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

8KB		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2M-8340	Rod End-Yoke	374-4678
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692

8KB		
Original Part Number	Part Name	Classic Part Number
2W-9978	Core As-Oclr	279-4983
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-6559	Cap-Bearing	296-1346
3J-6561	Screw-Adj	297-7241
3J-6573	Screw-Adjusting	302-2714
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1407	Disc-Friction	392-4516
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499

Sales Model D6H (Cont'd.)

8KB		
Original Part Number	Part Name	Classic Part Number
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5G-3612	Cap Gp-Protn	295-6419
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024

8KB		
Original Part Number	Part Name	Classic Part Number
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-5404	Plate-Cl & Brake	325-6168
6P-7704	Carrier-Ring	314-8658
6S-6902	Spider & Brg As	390-5280
6T-0016	Pump Gp-Gr 4 Bsc	418-1957
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl & Brake	325-6170
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574

8KB		
Original Part Number	Part Name	Classic Part Number
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-7946	Disc-Friction	384-4801
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2824	Piston	295-6439
7G-2828	Plate-Clutch	325-6171
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7681	Shaft As	307-1530
7G-9555	Univ Joint As	314-8721
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290

Sales Model D6H (Cont'd.)

8KB		
Original Part Number	Part Name	Classic Part Number
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196

8KB		
Original Part Number	Part Name	Classic Part Number
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-7818	Bracket	226-0211
8T-1177	Bearing-Rlr	419-1862
8T-3383	Kit-Gasket-Mch	447-8648
8Y-0978	Plate As	434-1402
9D-3242	Cone-Roller Brg	453-3659
9G-8638	Gear-Planet	295-6425

8KB		
Original Part Number	Part Name	Classic Part Number
9G-9078	Sleeve	431-6618
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1853	Mount As.	376-3638
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9T-5360	Plate-Pressure	424-4941
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
106-6540	Retainer	418-1941
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
134-4200	Manifold-Exhaust	443-2060
136-7813	Bearing-Race	460-8296
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815

Sales Model D6H (Cont'd.)

8KB		
Original Part Number	**Part Name**	**Classic Part Number**
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577

8KB		
Original Part Number	**Part Name**	**Classic Part Number**
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8796	Retainer	417-9489

8KB		
Original Part Number	**Part Name**	**Classic Part Number**
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442

8KK		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326

8KK		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221

8KK		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-9192	Bearing-Ball	394-8236
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229

Sales Model D6H (Cont'd.)

8KK		
Original Part Number	Part Name	Classic Part Number
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444

8KK		
Original Part Number	Part Name	Classic Part Number
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

8KK		
Original Part Number	Part Name	Classic Part Number
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535

Sales Model D6H (Cont'd.)

8KK		
Original Part Number	Part Name	Classic Part Number
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0248	Ring-Seal	295-6440
6T-3080	Plate-Cl & Brake	325-6170
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-7946	Disc-Friction	384-4801
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350

8KK		
Original Part Number	Part Name	Classic Part Number
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679

8KK		
Original Part Number	Part Name	Classic Part Number
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349

Sales Model D6H (Cont'd.)

8KK		
Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9078	Sleeve	431-6618
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9J-9598	Pin	296-1362

8KK		
Original Part Number	Part Name	Classic Part Number
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9T-5360	Plate-Pressure	424-4941
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045

8KK		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
139-6850	Gasket Kit	384-4809
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357

Sales Model D6H (Cont'd.)

8KK		
Original Part Number	**Part Name**	**Classic Part Number**
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966

8KK		
Original Part Number	**Part Name**	**Classic Part Number**
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

8KK		
Original Part Number	**Part Name**	**Classic Part Number**
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955

8SK		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

8SK		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

8SK		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444

Sales Model D6H (Cont'd.)

8SK		
Original Part Number	Part Name	Classic Part Number
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988

8SK		
Original Part Number	Part Name	Classic Part Number
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

8SK		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350

Sales Model D6H (Cont'd.)

8SK		
Original Part Number	Part Name	Classic Part Number
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660

8SK		
Original Part Number	Part Name	Classic Part Number
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290

8SK		
Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446

Sales Model D6H (Cont'd.)

8SK		
Original Part Number	Part Name	Classic Part Number
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583

8SK		
Original Part Number	Part Name	Classic Part Number
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
139-6850	Gasket Kit	384-4809
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

8SK		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

8YC		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

8YC		
Original Part Number	Part Name	Classic Part Number
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410

8YC		
Original Part Number	Part Name	Classic Part Number
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920

Sales Model D6H (Cont'd.)

8YC		
Original Part Number	Part Name	Classic Part Number
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-1625	Pump Gp-Gr A	421-1555
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-8489	Bearing-Sleeve	295-5691
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367

8YC		
Original Part Number	Part Name	Classic Part Number
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-6561	Screw-Adj	297-7241
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698

8YC		
Original Part Number	Part Name	Classic Part Number
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727

Sales Model D6H (Cont'd.)

8YC		
Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991

8YC		
Original Part Number	Part Name	Classic Part Number
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-5404	Plate-Cl & Brake	325-6168
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl & Brake	325-6170
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-7946	Disc-Friction	384-4801
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408

8YC		
Original Part Number	Part Name	Classic Part Number
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187

Sales Model D6H (Cont'd.)

8YC		
Original Part Number	Part Name	Classic Part Number
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377

8YC		
Original Part Number	Part Name	Classic Part Number
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-7818	Bracket	226-0211
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9078	Sleeve	431-6618
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515

8YC		
Original Part Number	Part Name	Classic Part Number
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
139-6850	Gasket Kit	384-4809
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125

Sales Model D6H (Cont'd.)

8YC		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

8YC		
Original Part Number	**Part Name**	**Classic Part Number**
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
201-2078	Bar As-Equalizer	418-1946
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351

8YC		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

8ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326

8ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221

8ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-9192	Bearing-Ball	394-8236
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

Sales Model D6H (Cont'd.)

8ZJ		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341

8ZJ		
Original Part Number	Part Name	Classic Part Number
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987

8ZJ		
Original Part Number	Part Name	Classic Part Number
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475

Sales Model D6H (Cont'd.)

8ZJ		
Original Part Number	Part Name	Classic Part Number
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0248	Ring-Seal	295-6440
6T-3080	Plate-Cl & Brake	325-6170
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-7946	Disc-Friction	384-4801
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925

8ZJ		
Original Part Number	Part Name	Classic Part Number
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660

8ZJ		
Original Part Number	Part Name	Classic Part Number
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290

Sales Model D6H (Cont'd.)

8ZJ		
Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
8T-1177	Bearing-Rlr	419-1862
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050

8ZJ		
Original Part Number	Part Name	Classic Part Number
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9T-5360	Plate-Pressure	424-4941
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831

8ZJ		
Original Part Number	Part Name	Classic Part Number
134-3068	Kit-Gasket(F)	393-3636
139-6850	Gasket Kit	384-4809
141-4974	Gasket Kit	388-0658
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438

Sales Model D6H (Cont'd.)

8ZJ		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989

8ZJ		
Original Part Number	Part Name	Classic Part Number
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

8ZJ		
Original Part Number	Part Name	Classic Part Number
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

9KJ		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

9KJ		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164

9KJ		
Original Part Number	Part Name	Classic Part Number
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695

Sales Model D6H (Cont'd.)

9KJ		
Original Part Number	Part Name	Classic Part Number
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984

9KJ		
Original Part Number	Part Name	Classic Part Number
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

9KJ		
Original Part Number	Part Name	Classic Part Number
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697

Sales Model D6H (Cont'd.)

9KJ		
Original Part Number	Part Name	Classic Part Number
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-6596	Bearing-Sleeve	295-6409
7P-8370	Bearing	295-6410

9KJ		
Original Part Number	Part Name	Classic Part Number
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196

9KJ		
Original Part Number	Part Name	Classic Part Number
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931

Sales Model D6H (Cont'd.)

9KJ		
Original Part Number	Part Name	Classic Part Number
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491

9KJ		
Original Part Number	Part Name	Classic Part Number
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
139-6850	Gasket Kit	384-4809
141-4974	Gasket Kit	388-0658
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

9KJ		
Original Part Number	Part Name	Classic Part Number
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

9LK		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437

Sales Model D6H (Cont'd.)

9LK		
Original Part Number	Part Name	Classic Part Number
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210

9LK		
Original Part Number	Part Name	Classic Part Number
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055

9LK		
Original Part Number	Part Name	Classic Part Number
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370

Sales Model D6H (Cont'd.)

9LK		
Original Part Number	Part Name	Classic Part Number
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-PrecInr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927

9LK		
Original Part Number	Part Name	Classic Part Number
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544

9LK		
Original Part Number	Part Name	Classic Part Number
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016

Sales Model D6H (Cont'd.)

9LK		
Original Part Number	Part Name	Classic Part Number
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411

9LK		
Original Part Number	Part Name	Classic Part Number
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081

9LK		
Original Part Number	Part Name	Classic Part Number
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9078	Sleeve	431-6618
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124

Sales Model D6H (Cont'd.)

9LK		
Original Part Number	**Part Name**	**Classic Part Number**
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943

9LK		
Original Part Number	**Part Name**	**Classic Part Number**
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
139-6850	Gasket Kit	384-4809
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

9LK		
Original Part Number	**Part Name**	**Classic Part Number**
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

9RK		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7895	Cone-Roller Brg	396-4145

9RK		
Original Part Number	**Part Name**	**Classic Part Number**
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180

9RK		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408

Sales Model D6H (Cont'd.)

9RK		
Original Part Number	Part Name	Classic Part Number
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-9192	Bearing-Ball	394-8236
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2N-2139	Cone-Roller Brg	415-1911
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

9RK		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052

9RK		
Original Part Number	Part Name	Classic Part Number
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216

Sales Model D6H (Cont'd.)

9RK		
Original Part Number	Part Name	Classic Part Number
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436

9RK		
Original Part Number	Part Name	Classic Part Number
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0248	Ring-Seal	295-6440
6T-3080	Plate-Cl & Brake	325-6170
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-7946	Disc-Friction	384-4801
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408

9RK		
Original Part Number	Part Name	Classic Part Number
7J-5131	Trunnion	296-1371
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366

Sales Model D6H (Cont'd.)

9RK		
Original Part Number	Part Name	Classic Part Number
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083

9RK		
Original Part Number	Part Name	Classic Part Number
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
8T-1177	Bearing-Rlr	419-1862
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042

9RK		
Original Part Number	Part Name	Classic Part Number
9T-3884	Piston As	393-3639
9T-4762	Head	325-6109
9T-5360	Plate-Pressure	424-4941
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
139-6850	Gasket Kit	384-4809
147-1010	Gasket Kit	390-5278
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

Sales Model D6H (Cont'd.)

9RK		
Original Part Number	**Part Name**	**Classic Part Number**
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

9RK		
Original Part Number	**Part Name**	**Classic Part Number**
172-7767	Pump Gp-Water -B	296-1365
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	295-6438

9RK		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442

Sales Model D6K

DFR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955
2H-6489	Race-Brg Outer	374-8350
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
3G-8932	Pin	325-6143
3P-1210	Cone-Roller Brg	399-4433

DFR		
Original Part Number	**Part Name**	**Classic Part Number**
3W-5159	Plate-Parking Bk	391-9904
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
7J-1309	Bearing-Aligning	360-2275
7J-9682	Bearing-Sleeve	360-2335
7P-7858	Bearing-Sleeve	374-8362

DFR		
Original Part Number	**Part Name**	**Classic Part Number**
8G-4189	Bearing-Aligning	295-6411
9M-1328	Bearing-Aligning	325-6018
9W-0099	Bearing-Sleeve	314-8639
9W-9930	Mount As	295-6437
124-5741	Pin	394-0204
135-7393	Head	382-6895
170-8714	Disc-Friction	456-9193
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

DHA		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955

DHA		
Original Part Number	**Part Name**	**Classic Part Number**
2H-6489	Race-Brg Outer	374-8350
2K-0227	Bearing-Sleeve	384-4780
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
3F-6523	Pin-Clevis	256-4818
3G-8932	Pin	325-6143

DHA		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
3W-5159	Plate-Parking Bk	391-9904
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010

Sales Model D6K (Cont'd.)

DHA		
Original Part Number	**Part Name**	**Classic Part Number**
6S-3474	Pin As	375-9981
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
7J-1309	Bearing-Aligning	360-2275
7J-9682	Bearing-Sleeve	360-2335

DHA		
Original Part Number	**Part Name**	**Classic Part Number**
7P-7858	Bearing-Sleeve	374-8362
8V-7659	Pin As	361-1702
9M-1328	Bearing-Aligning	325-6018
9W-0099	Bearing-Sleeve	314-8639

DHA		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9930	Mount As	295-6437
124-3237	Precleaner As	432-4220
124-5741	Pin	394-0204
147-4359	Pin	393-0937
160-0305	Bearing-Aligning	396-9945
170-8714	Disc-Friction	456-9193

FBH		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-8736	Cup-Roller Brg	423-7759
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955
2H-6489	Race-Brg Outer	374-8350
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
3G-8932	Pin	325-6143

FBH		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
3W-5159	Plate-Parking Bk	391-9904
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
7J-1309	Bearing-Aligning	360-2275
7J-9682	Bearing-Sleeve	360-2335

FBH		
Original Part Number	**Part Name**	**Classic Part Number**
7P-7858	Bearing-Sleeve	374-8362
8V-7659	Pin As	361-1702
9M-1328	Bearing-Aligning	325-6018
9W-0099	Bearing-Sleeve	314-8639
9W-9930	Mount As	295-6437
124-3237	Precleaner As	432-4220
124-5741	Pin	394-0204
147-4359	Pin	393-0937
160-0305	Bearing-Aligning	396-9945
170-8714	Disc-Friction	456-9193

HMG		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955
2H-6489	Race-Brg Outer	374-8350
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
3G-8932	Pin	325-6143

HMG		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
3W-5159	Plate-Parking Bk	391-9904
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
7J-1309	Bearing-Aligning	360-2275
7J-9682	Bearing-Sleeve	360-2335

HMG		
Original Part Number	**Part Name**	**Classic Part Number**
7P-7858	Bearing-Sleeve	374-8362
8V-7659	Pin As	361-1702
9M-1328	Bearing-Aligning	325-6018
9W-0099	Bearing-Sleeve	314-8639
9W-9930	Mount As	295-6437
124-5741	Pin	394-0204
147-4359	Pin	393-0937
160-0305	Bearing-Aligning	396-9945
170-8714	Disc-Friction	456-9193

Sales Model D6K (Cont'd.)

JTR		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955
2H-6489	Race-Brg Outer	374-8350
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
3G-8932	Pin	325-6143

JTR		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
3W-5159	Plate-Parking Bk	391-9904
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
7J-1309	Bearing-Aligning	360-2275
7J-9682	Bearing-Sleeve	360-2335
7P-7858	Bearing-Sleeve	374-8362

JTR		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
9M-1328	Bearing-Aligning	325-6018
9W-0099	Bearing-Sleeve	314-8639
9W-9930	Mount As	295-6437
124-5741	Pin	394-0204
135-7393	Head	382-6895
170-8714	Disc-Friction	456-9193
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

MXK		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955
2H-6489	Race-Brg Outer	374-8350
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
3G-8932	Pin	325-6143

MXK		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
3W-5159	Plate-Parking Bk	391-9904
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
6E-5449	Bearing-Sleeve	464-4048
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
7J-1309	Bearing-Aligning	360-2275

MXK		
Original Part Number	Part Name	Classic Part Number
7J-9682	Bearing-Sleeve	360-2335
7P-7858	Bearing-Sleeve	374-8362
9M-1328	Bearing-Aligning	325-6018
9W-0099	Bearing-Sleeve	314-8639
9W-9930	Mount As	295-6437
124-5741	Pin	394-0204
170-8714	Disc-Friction	456-9193
176-3900	Accumulator	416-5513

NCF		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443

NCF		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

NCF		
Original Part Number	Part Name	Classic Part Number
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955
2H-6489	Race-Brg Outer	374-8350

Sales Model D6K (Cont'd.)

NCF		
Original Part Number	**Part Name**	**Classic Part Number**
2K-4507	Bearing-Sleeve	325-6021
3G-8932	Pin	325-6143
3P-1210	Cone-Roller Brg	399-4433
3W-5159	Plate-Parking Bk	391-9904
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633

NCF		
Original Part Number	**Part Name**	**Classic Part Number**
4T-0231	Retainer	376-3641
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
7J-1309	Bearing-Aligning	360-2275
7J-9682	Bearing-Sleeve	360-2335
7P-7858	Bearing-Sleeve	374-8362
8V-7659	Pin As	361-1702

NCF		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1328	Bearing-Aligning	325-6018
9W-0099	Bearing-Sleeve	314-8639
9W-9930	Mount As	295-6437
124-5741	Pin	394-0204
147-4359	Pin	393-0937
160-0305	Bearing-Aligning	396-9945
170-8714	Disc-Friction	456-9193

RPR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955
2H-6489	Race-Brg Outer	374-8350
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
3G-8932	Pin	325-6143

RPR		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
3W-5159	Plate-Parking Bk	391-9904
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
6E-5449	Bearing-Sleeve	464-4048
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
7J-1309	Bearing-Aligning	360-2275

RPR		
Original Part Number	**Part Name**	**Classic Part Number**
7J-9682	Bearing-Sleeve	360-2335
7P-7858	Bearing-Sleeve	374-8362
9M-1328	Bearing-Aligning	325-6018
9W-0099	Bearing-Sleeve	314-8639
9W-9930	Mount As	295-6437
124-5741	Pin	394-0204
170-8714	Disc-Friction	456-9193
176-3900	Accumulator	416-5513

RST		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955
2H-6489	Race-Brg Outer	374-8350
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
3G-8932	Pin	325-6143

RST		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
3W-5159	Plate-Parking Bk	391-9904
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
6E-5449	Bearing-Sleeve	464-4048
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
7J-1309	Bearing-Aligning	360-2275

RST		
Original Part Number	**Part Name**	**Classic Part Number**
7J-9682	Bearing-Sleeve	360-2335
7P-7858	Bearing-Sleeve	374-8362
9M-1328	Bearing-Aligning	325-6018
9W-0099	Bearing-Sleeve	314-8639
9W-9930	Mount As	295-6437
124-5741	Pin	394-0204
170-8714	Disc-Friction	456-9193
176-3900	Accumulator	416-5513

Sales Model D6K (Cont'd.)

WMR		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3743	Bearing-Ball	384-4786
2B-0941	Spacer	418-1955
2H-6489	Race-Brg Outer	374-8350
2K-4507	Bearing-Sleeve	325-6021
2K-6413	Pin	360-2270
3G-8932	Pin	325-6143

WMR		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
3W-5159	Plate-Parking Bk	391-9904
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
6E-5449	Bearing-Sleeve	464-4048
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
7J-1309	Bearing-Aligning	360-2275

WMR		
Original Part Number	Part Name	Classic Part Number
7J-9682	Bearing-Sleeve	360-2335
7P-7858	Bearing-Sleeve	374-8362
9M-1328	Bearing-Aligning	325-6018
9W-0099	Bearing-Sleeve	314-8639
9W-9930	Mount As	295-6437
124-5741	Pin	394-0204
170-8714	Disc-Friction	456-9193
176-3900	Accumulator	416-5513

Sales Model D6M

2RN		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2W-7213	Bearing-Sleeve	419-4667
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3T-1162	Sleeve-Wear	325-6209
3T-9960	Disc-Friction	417-9487
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061

2RN		
Original Part Number	Part Name	Classic Part Number
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

2RN		
Original Part Number	Part Name	Classic Part Number
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
6E-0775	Head	425-9373
6E-5449	Bearing-Sleeve	464-4048
6I-1099	Manifold-Exh	424-6366
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166

Sales Model D6M (Cont'd.)

2RN		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8D-0983	Mounting	384-3470
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-0901	Cup-Spl Tap Roll	399-4444

2RN		
Original Part Number	**Part Name**	**Classic Part Number**
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8S-0248	Breather As	325-6033
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
105-1738	Manifold-Exhaust	374-4692
106-0714	Shaft	364-5260
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
119-5727	Bearing-Spl Ball	417-9491
124-3237	Precleaner As	432-4220
124-5233	Pin	443-2664

2RN		
Original Part Number	**Part Name**	**Classic Part Number**
124-5741	Pin	394-0204
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
135-6160	Shaft-Sun Gear	394-8239
135-7393	Head	382-6895
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
222-0862	Housing	419-1860
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-0930	Gear-Transfer	394-0888
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
252-1152	Muffler As.	395-1307
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
308-1845	Seal-Wiper	472-8032
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653
352-2151	Pump Gp-Water -B	434-6107

Sales Model D6M (Cont'd.)

2RN		
Original Part Number	**Part Name**	**Classic Part Number**
352-2160	Pump Gp-Water -B	433-0789

2RN		
Original Part Number	**Part Name**	**Classic Part Number**
374-1849	Brg-Rlr-Cla	399-4442

2YS		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2W-7213	Bearing-Sleeve	419-4667
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502

2YS		
Original Part Number	**Part Name**	**Classic Part Number**
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4V-8629	Bearing-Sleeve	379-0194
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
6E-0775	Head	425-9373
6E-5449	Bearing-Sleeve	464-4048
6I-1099	Manifold-Exh	424-6366
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862

2YS		
Original Part Number	**Part Name**	**Classic Part Number**
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8D-0983	Mounting	384-3470
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512

Sales Model D6M (Cont'd.)

2YS		
Original Part Number	**Part Name**	**Classic Part Number**
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8S-0248	Breather As	325-6033
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
105-1738	Manifold-Exhaust	374-4692

2YS		
Original Part Number	**Part Name**	**Classic Part Number**
106-0714	Shaft	364-5260
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
119-5727	Bearing-Spl Ball	417-9491
124-3237	Precleaner As	432-4220
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
135-7393	Head	382-6895
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985

2YS		
Original Part Number	**Part Name**	**Classic Part Number**
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-0930	Gear-Transfer	394-0888
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
252-1152	Muffler As.	395-1307
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
308-1845	Seal-Wiper	472-8032
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
374-1849	Brg-Rlr-Cla	399-4442

3WN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346

3WN		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7213	Bearing-Sleeve	419-4667
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8900	Pin	325-6140
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344

3WN		
Original Part Number	**Part Name**	**Classic Part Number**
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217

Sales Model D6M (Cont'd.)

3WN		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9943	Seal-End Tank	385-7216
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
6E-0775	Head	425-9373
6E-5449	Bearing-Sleeve	464-4048
6I-1099	Manifold-Exh	424-6366
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

3WN		
Original Part Number	**Part Name**	**Classic Part Number**
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8D-0983	Mounting	384-3470
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8S-0248	Breather As	325-6033
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379

3WN		
Original Part Number	**Part Name**	**Classic Part Number**
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
105-1738	Manifold-Exhaust	374-4692
106-0714	Shaft	364-5260
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
119-5727	Bearing-Spl Ball	417-9491
124-3237	Precleaner As	432-4220
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
135-7393	Head	382-6895
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-3952	Impeller-Pump	374-4696

Sales Model D6M (Cont'd.)

3WN		
Original Part Number	**Part Name**	**Classic Part Number**
152-6485	Cyl Gp-102 472 Y	390-0985
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870

3WN		
Original Part Number	**Part Name**	**Classic Part Number**
222-0862	Housing	419-1860
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-0930	Gear-Transfer	394-0888
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
252-1152	Muffler As.	395-1307
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

3WN		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
308-1845	Seal-Wiper	472-8032
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
374-1849	Brg-Rlr-Cla	399-4442

4GS		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2W-7213	Bearing-Sleeve	419-4667
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513

4GS		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
6E-0775	Head	425-9373
6E-5449	Bearing-Sleeve	464-4048
6I-1099	Manifold-Exh	424-6366
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-1084	Impeller-Conv	380-1477

4GS		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922

Sales Model D6M (Cont'd.)

4GS		
Original Part Number	**Part Name**	**Classic Part Number**
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8D-0983	Mounting	384-3470
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8P-1916	Gear-Planet	283-5209
8S-0248	Breather As	325-6033
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756

4GS		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
105-1738	Manifold-Exhaust	374-4692
106-0714	Shaft	364-5260
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
119-5727	Bearing-Spl Ball	417-9491
124-3237	Precleaner As	432-4220
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
135-6160	Shaft-Sun Gear	394-8239
135-7393	Head	382-6895
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376

4GS		
Original Part Number	**Part Name**	**Classic Part Number**
145-0165	Bearing-Main	419-6388
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
163-1387	Gear-Flywheel	374-4697
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-0930	Gear-Transfer	394-0888
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
252-1152	Muffler As.	395-1307
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
308-1845	Seal-Wiper	472-8032
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
374-1849	Brg-Rlr-Cla	399-4442

4HS		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955

4HS		
Original Part Number	**Part Name**	**Classic Part Number**
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346

4HS		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7213	Bearing-Sleeve	419-4667
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208

Sales Model D6M (Cont'd.)

4HS		
Original Part Number	**Part Name**	**Classic Part Number**
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-8054	Seal As	472-8010
4V-8629	Bearing-Sleeve	379-0194
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4Y-4905	Washer-Soft	416-5535
5J-4321	Trunnion	302-2700
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
6E-0775	Head	425-9373
6E-5449	Bearing-Sleeve	464-4048
6F-7523	Cap-Bearing	325-6039
6I-1099	Manifold-Exh	424-6366
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133

4HS		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335
7J-9842	Bearing-Sleeve	299-1968
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497

4HS		
Original Part Number	**Part Name**	**Classic Part Number**
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8D-0983	Mounting	384-3470
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8S-0248	Breather As	325-6033
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-4762	Head	325-6109
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
105-1738	Manifold-Exhaust	374-4692

Sales Model D6M (Cont'd.)

4HS		
Original Part Number	**Part Name**	**Classic Part Number**
106-0714	Shaft	364-5260
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
119-5727	Bearing-Spl Ball	417-9491
124-3237	Precleaner As	432-4220
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
135-7393	Head	382-6895
136-0819	Valve-Exhaust	384-8697

4HS		
Original Part Number	**Part Name**	**Classic Part Number**
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371

4HS		
Original Part Number	**Part Name**	**Classic Part Number**
226-0930	Gear-Transfer	394-0888
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
252-1152	Muffler As.	395-1307
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
308-1845	Seal-Wiper	472-8032
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
374-1849	Brg-Rlr-Cla	399-4442

4JN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2W-7213	Bearing-Sleeve	419-4667
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3T-1162	Sleeve-Wear	325-6209

4JN		
Original Part Number	**Part Name**	**Classic Part Number**
3T-9960	Disc-Friction	417-9487
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502

4JN		
Original Part Number	**Part Name**	**Classic Part Number**
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
6E-0775	Head	425-9373
6E-5449	Bearing-Sleeve	464-4048
6I-1099	Manifold-Exh	424-6366
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442

Sales Model D6M (Cont'd.)

4JN		
Original Part Number	Part Name	Classic Part Number
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497

4JN		
Original Part Number	Part Name	Classic Part Number
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8D-0983	Mounting	384-3470
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8S-0248	Breather As	325-6033
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
105-1738	Manifold-Exhaust	374-4692
106-0714	Shaft	364-5260

4JN		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
119-5727	Bearing-Spl Ball	417-9491
124-3237	Precleaner As	432-4220
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
135-6160	Shaft-Sun Gear	394-8239
135-7393	Head	382-6895
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
222-0862	Housing	419-1860
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-0930	Gear-Transfer	394-0888
226-8202	Seal-Wiper	472-8024

Sales Model D6M (Cont'd.)

4JN		
Original Part Number	**Part Name**	**Classic Part Number**
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
252-1152	Muffler As.	395-1307
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028

4JN		
Original Part Number	**Part Name**	**Classic Part Number**
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
308-1845	Seal-Wiper	472-8032
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653

4JN		
Original Part Number	**Part Name**	**Classic Part Number**
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
374-1849	Brg-Rlr-Cla	399-4442

5NR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-0227	Bearing-Sleeve	384-4780
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2W-7213	Bearing-Sleeve	419-4667
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8900	Pin	325-6140
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633

5NR		
Original Part Number	**Part Name**	**Classic Part Number**
4M-5858	Bearing-Spl Ball	417-4495
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-1504	Trunnion	314-8727
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
6D-0217	Bearing-Sleeve	325-6022
6E-0775	Head	425-9373
6E-5449	Bearing-Sleeve	464-4048
6I-1099	Manifold-Exh	424-6366
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6S-3474	Pin As	375-9981
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142

5NR		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014
6Y-6236	Bearing-Sleeve	325-6024
6Y-6582	Plate-Wear	419-2307
6Y-6775	Pin	325-6151
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691

Sales Model D6M (Cont'd.)

5NR		
Original Part Number	**Part Name**	**Classic Part Number**
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7J-9884	Bearing-Sleeve	325-6016
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8D-0983	Mounting	384-3470
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8S-0248	Breather As	325-6033
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620

5NR		
Original Part Number	**Part Name**	**Classic Part Number**
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-2579	Plate	314-8701
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
105-1738	Manifold-Exhaust	374-4692
106-0714	Shaft	364-5260
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
119-5727	Bearing-Spl Ball	417-9491
124-3237	Precleaner As	432-4220
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654

5NR		
Original Part Number	**Part Name**	**Classic Part Number**
135-6160	Shaft-Sun Gear	394-8239
135-7393	Head	382-6895
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-0930	Gear-Transfer	394-0888
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
252-1152	Muffler As.	395-1307
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
308-1845	Seal-Wiper	472-8032
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
374-1849	Brg-Rlr-Cla	399-4442

5WR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437

Sales Model D6M (Cont'd.)

5WR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3980	Cone-Roller Brg	399-4443
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2W-7213	Bearing-Sleeve	419-4667
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135

5WR		
Original Part Number	**Part Name**	**Classic Part Number**
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
6E-0775	Head	425-9373
6E-5449	Bearing-Sleeve	464-4048
6I-1099	Manifold-Exh	424-6366
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408

5WR		
Original Part Number	**Part Name**	**Classic Part Number**
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8D-0983	Mounting	384-3470
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8S-0248	Breather As	325-6033
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610

Sales Model D6M (Cont'd.)

5WR		
Original Part Number	**Part Name**	**Classic Part Number**
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
105-1738	Manifold-Exhaust	374-4692
106-0714	Shaft	364-5260
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
119-5727	Bearing-Spl Ball	417-9491
124-3237	Precleaner As	432-4220
124-5233	Pin	443-2664

5WR		
Original Part Number	**Part Name**	**Classic Part Number**
124-5741	Pin	394-0204
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
135-7393	Head	382-6895
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432

5WR		
Original Part Number	**Part Name**	**Classic Part Number**
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-0930	Gear-Transfer	394-0888
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
252-1152	Muffler As.	395-1307
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
308-1845	Seal-Wiper	472-8032
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
374-1849	Brg-Rlr-Cla	399-4442

6LR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2W-7213	Bearing-Sleeve	419-4667
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899

6LR		
Original Part Number	**Part Name**	**Classic Part Number**
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502

6LR		
Original Part Number	**Part Name**	**Classic Part Number**
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
6E-0775	Head	425-9373
6E-5449	Bearing-Sleeve	464-4048
6I-1099	Manifold-Exh	424-6366
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442

Sales Model D6M (Cont'd.)

6LR		
Original Part Number	Part Name	Classic Part Number
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190

6LR		
Original Part Number	Part Name	Classic Part Number
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8D-0983	Mounting	384-3470
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8S-0248	Breather As	325-6033
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
105-1738	Manifold-Exhaust	374-4692
106-0714	Shaft	364-5260
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543

6LR		
Original Part Number	Part Name	Classic Part Number
109-0958	Pin	394-0208
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
119-5727	Bearing-Spl Ball	417-9491
124-3237	Precleaner As	432-4220
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
135-7393	Head	382-6895
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-0930	Gear-Transfer	394-0888
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
252-1152	Muffler As.	395-1307
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
308-1845	Seal-Wiper	472-8032
328-4266	Cylinder As.	393-3664

Sales Model D6M (Cont'd.)

6LR		
Original Part Number	**Part Name**	**Classic Part Number**
328-4267	Cyl Gp-140 114 Y	393-3653
352-2151	Pump Gp-Water -B	434-6107

6LR		
Original Part Number	**Part Name**	**Classic Part Number**
352-2160	Pump Gp-Water -B	433-0789
374-1849	Brg-Rlr-Cla	399-4442

9ZM		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2W-7213	Bearing-Sleeve	419-4667
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8900	Pin	325-6140
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3T-9960	Disc-Friction	417-9487
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217

9ZM		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9943	Seal-End Tank	385-7216
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
6E-0775	Head	425-9373
6E-5449	Bearing-Sleeve	464-4048
6I-1099	Manifold-Exh	424-6366
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0145	Plate-Locking	419-8801
6Y-0306	Bearing-Sleeve	391-1104
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490

9ZM		
Original Part Number	**Part Name**	**Classic Part Number**
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7G-7681	Shaft As	307-1530
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8D-0983	Mounting	384-3470
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411

Sales Model D6M (Cont'd.)

9ZM		
Original Part Number	Part Name	Classic Part Number
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8S-0248	Breather As	325-6033
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473

9ZM		
Original Part Number	Part Name	Classic Part Number
101-5144	Disc-Friction	380-7516
105-1738	Manifold-Exhaust	374-4692
106-0714	Shaft	364-5260
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
119-5727	Bearing-Spl Ball	417-9491
124-3237	Precleaner As	432-4220
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
133-3919	Gasket Kit-Sch	393-1031
135-7393	Head	382-6895
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985

9ZM		
Original Part Number	Part Name	Classic Part Number
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
222-0862	Housing	419-1860
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-0930	Gear-Transfer	394-0888
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
252-1152	Muffler As.	395-1307
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
292-5516	Kit-Dt Gasket	391-9885
308-1845	Seal-Wiper	472-8032
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
374-1849	Brg-Rlr-Cla	399-4442

Sales Model D6N

AKM		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174

AKM		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142

AKM		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481

Sales Model D6N (Cont'd.)

AKM		
Original Part Number	Part Name	Classic Part Number
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4P-3683	Pump Gp-Water -B	374-7498
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
6E-0775	Head	425-9373
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690

AKM		
Original Part Number	Part Name	Classic Part Number
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409

AKM		
Original Part Number	Part Name	Classic Part Number
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968

Sales Model D6N (Cont'd.)

AKM		
Original Part Number	**Part Name**	**Classic Part Number**
087-5845	Pin	301-7969
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5984	Ring-Backup	419-4654
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-4995	Gasket-Cyl Head	434-2445
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
142-8845	Muffler As	360-9619
145-0162	Bearing-Main	419-6380

AKM		
Original Part Number	**Part Name**	**Classic Part Number**
145-0164	Bearing-Main	419-6376
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985
154-8030	Gasket	394-0894
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
164-4413	Mount	419-0876
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

AKM		
Original Part Number	**Part Name**	**Classic Part Number**
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
374-1849	Brg-Rlr-Cla	399-4442

ALH		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2W-7213	Bearing-Sleeve	419-4667
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143

ALH		
Original Part Number	**Part Name**	**Classic Part Number**
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632

ALH		
Original Part Number	**Part Name**	**Classic Part Number**
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4P-3683	Pump Gp-Water -B	374-7498
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535

Sales Model D6N (Cont'd.)

ALH		
Original Part Number	Part Name	Classic Part Number
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
6E-0775	Head	425-9373
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0306	Bearing-Sleeve	391-1104
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335

ALH		
Original Part Number	Part Name	Classic Part Number
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
106-0714	Shaft	364-5260
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830

ALH		
Original Part Number	Part Name	Classic Part Number
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5984	Ring-Backup	419-4654
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-4995	Gasket-Cyl Head	434-2445
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985
154-8030	Gasket	394-0894
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
164-4413	Mount	419-0876
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-0930	Gear-Transfer	394-0888
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

Sales Model D6N (Cont'd.)

ALH		
Original Part Number	**Part Name**	**Classic Part Number**
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

ALH		
Original Part Number	**Part Name**	**Classic Part Number**
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

ALH		
Original Part Number	**Part Name**	**Classic Part Number**
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

ALR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2W-7213	Bearing-Sleeve	419-4667
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633

ALR		
Original Part Number	**Part Name**	**Classic Part Number**
4M-5858	Bearing-Spl Ball	417-4495
4P-3683	Pump Gp-Water -B	374-7498
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
6E-0775	Head	425-9373
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0306	Bearing-Sleeve	391-1104
6Y-1084	Impeller-Conv	380-1477

ALR		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7W-3773	Pulley-Cshaft	383-1583

Sales Model D6N (Cont'd.)

ALR		
Original Part Number	**Part Name**	**Classic Part Number**
7W-5095	Gear-Flywheel	425-9190
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516

ALR		
Original Part Number	**Part Name**	**Classic Part Number**
106-0714	Shaft	364-5260
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5984	Ring-Backup	419-4654
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-4995	Gasket-Cyl Head	434-2445
135-6160	Shaft-Sun Gear	394-8239
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985
154-8030	Gasket	394-0894
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
164-4413	Mount	419-0876

ALR		
Original Part Number	**Part Name**	**Classic Part Number**
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-0930	Gear-Transfer	394-0888
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

ALY		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294

ALY		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691

ALY		
Original Part Number	**Part Name**	**Classic Part Number**
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346

Sales Model D6N (Cont'd.)

ALY		
Original Part Number	Part Name	Classic Part Number
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-94101	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4P-3683	Pump Gp-Water -B	374-7498
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-6559	Tube	325-6234
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
6E-0775	Head	425-9373
6E-5449	Bearing-Sleeve	464-4048

ALY		
Original Part Number	Part Name	Classic Part Number
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409

ALY		
Original Part Number	Part Name	Classic Part Number
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969

Sales Model D6N (Cont'd.)

ALY		
Original Part Number	**Part Name**	**Classic Part Number**
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5984	Ring-Backup	419-4654
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-4995	Gasket-Cyl Head	434-2445
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905

ALY		
Original Part Number	**Part Name**	**Classic Part Number**
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985
154-8030	Gasket	394-0894
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
164-4413	Mount	419-0876
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6268	Bearing-Sleeve	453-6499

ALY		
Original Part Number	**Part Name**	**Classic Part Number**
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
374-1849	Brg-Rlr-Cla	399-4442

CBF		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2W-7213	Bearing-Sleeve	419-4667
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208

CBF		
Original Part Number	**Part Name**	**Classic Part Number**
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633

CBF		
Original Part Number	**Part Name**	**Classic Part Number**
4M-5858	Bearing-Spl Ball	417-4495
4P-3683	Pump Gp-Water -B	374-7498
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4V-8629	Bearing-Sleeve	379-0194
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535

Sales Model D6N (Cont'd.)

CBF		
Original Part Number	Part Name	Classic Part Number
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0306	Bearing-Sleeve	391-1104
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816

CBF		
Original Part Number	Part Name	Classic Part Number
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
106-0714	Shaft	364-5260
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208

CBF		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5984	Ring-Backup	419-4654
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-4995	Gasket-Cyl Head	434-2445
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985
154-8030	Gasket	394-0894
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
164-4413	Mount	419-0876
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-0930	Gear-Transfer	394-0888
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436

Sales Model D6N (Cont'd.)

CBF		
Original Part Number	**Part Name**	**Classic Part Number**
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351

CBF		
Original Part Number	**Part Name**	**Classic Part Number**
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4266	Cylinder As.	393-3664

CBF		
Original Part Number	**Part Name**	**Classic Part Number**
328-4267	Cyl Gp-140 114 Y	393-3653
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

CBJ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725

CBJ		
Original Part Number	**Part Name**	**Classic Part Number**
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4P-3683	Pump Gp-Water -B	374-7498
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-6559	Tube	325-6234
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
6E-0775	Head	425-9373
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142

CBJ		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335

Sales Model D6N (Cont'd.)

CBJ		
Original Part Number	Part Name	Classic Part Number
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490

CBJ		
Original Part Number	Part Name	Classic Part Number
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
106-0714	Shaft	364-5260
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5984	Ring-Backup	419-4654
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-4995	Gasket-Cyl Head	434-2445
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985
154-8030	Gasket	394-0894
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038

CBJ		
Original Part Number	Part Name	Classic Part Number
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
164-4413	Mount	419-0876
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-0930	Gear-Transfer	394-0888
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

CBL		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437

Sales Model D6N (Cont'd.)

CBL		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4P-3683	Pump Gp-Water -B	374-7498
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535

CBL		
Original Part Number	**Part Name**	**Classic Part Number**
5J-6424	Bearing-Aligning	416-2135
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371

CBL		
Original Part Number	**Part Name**	**Classic Part Number**
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968

Sales Model D6N (Cont'd.)

CBL		
Original Part Number	**Part Name**	**Classic Part Number**
087-5845	Pin	301-7969
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5984	Ring-Backup	419-4654
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-4995	Gasket-Cyl Head	434-2445
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

CBL		
Original Part Number	**Part Name**	**Classic Part Number**
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985
154-8030	Gasket	394-0894
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
164-4413	Mount	419-0876
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

CBL		
Original Part Number	**Part Name**	**Classic Part Number**
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

CBL		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3F-6185	Pin	295-5694

CBL		
Original Part Number	**Part Name**	**Classic Part Number**
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344

CBL		
Original Part Number	**Part Name**	**Classic Part Number**
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4P-3683	Pump Gp-Water -B	374-7498
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135

Sales Model D6N (Cont'd.)

CBL		
Original Part Number	Part Name	Classic Part Number
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922

CBL		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

CBL		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5984	Ring-Backup	419-4654
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-4995	Gasket-Cyl Head	434-2445
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985
154-8030	Gasket	394-0894
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
164-4413	Mount	419-0876
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

Sales Model D6N (Cont'd.)

CBL		
Original Part Number	**Part Name**	**Classic Part Number**
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

CBL		
Original Part Number	**Part Name**	**Classic Part Number**
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

CBL		
Original Part Number	**Part Name**	**Classic Part Number**
321-5714	Piston-Clutch	281-1693
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

CCG		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2W-7213	Bearing-Sleeve	419-4667
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8900	Pin	325-6140
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370

CCG		
Original Part Number	**Part Name**	**Classic Part Number**
4J-3583	Screw-Adjusting	297-7242
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4P-3683	Pump Gp-Water -B	374-7498
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
6D-0217	Bearing-Sleeve	325-6022
6E-0775	Head	425-9373
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142

CCG		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0306	Bearing-Sleeve	391-1104
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5692	Plate-Brake	380-7492
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014
6Y-6236	Bearing-Sleeve	325-6024
6Y-6582	Plate-Wear	419-2307
6Y-6775	Pin	325-6151
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229

Sales Model D6N (Cont'd.)

CCG		
Original Part Number	Part Name	Classic Part Number
7G-5614	Shaft-Planet	281-1697
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335
7J-9884	Bearing-Sleeve	325-6016
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-2579	Plate	314-8701

CCG		
Original Part Number	Part Name	Classic Part Number
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
106-0714	Shaft	364-5260
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5984	Ring-Backup	419-4654
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-4995	Gasket-Cyl Head	434-2445
135-6160	Shaft-Sun Gear	394-8239
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985
154-8030	Gasket	394-0894
160-0305	Bearing-Aligning	396-9945

CCG		
Original Part Number	Part Name	Classic Part Number
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
164-4413	Mount	419-0876
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-0930	Gear-Transfer	394-0888
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

Sales Model D6N (Cont'd.)

CCK		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4P-3683	Pump Gp-Water -B	374-7498
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-6559	Tube	325-6234
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-1203	Cup-Rlr Brg	418-9603

CCK		
Original Part Number	**Part Name**	**Classic Part Number**
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
6E-0775	Head	425-9373
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275

CCK		
Original Part Number	**Part Name**	**Classic Part Number**
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490

Sales Model D6N (Cont'd.)

CCK		
Original Part Number	**Part Name**	**Classic Part Number**
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5984	Ring-Backup	419-4654
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-4995	Gasket-Cyl Head	434-2445
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319

CCK		
Original Part Number	**Part Name**	**Classic Part Number**
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-3952	Impeller-Pump	374-4696
152-6485	Cyl Gp-102 472 Y	390-0985
154-8030	Gasket	394-0894
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
164-4413	Mount	419-0876
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

CCK		
Original Part Number	**Part Name**	**Classic Part Number**
236-4413	Pump Gp-Water -B	434-6110
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

CCS		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481

CCS		
Original Part Number	**Part Name**	**Classic Part Number**
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8900	Pin	325-6140
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511

CCS		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4P-3683	Pump Gp-Water -B	374-7498
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216

Sales Model D6N (Cont'd.)

CCS		
Original Part Number	Part Name	Classic Part Number
4T-0231	Retainer	376-3641
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
6D-0217	Bearing-Sleeve	325-6022
6E-0775	Head	425-9373
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014
6Y-6236	Bearing-Sleeve	325-6024
6Y-6582	Plate-Wear	419-2307
6Y-6775	Pin	325-6151
7B-7515	Bearing-Ball	399-6059
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

CCS		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335
7J-9884	Bearing-Sleeve	325-6016
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-5095	Gear-Flywheel	425-9190
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379

CCS		
Original Part Number	Part Name	Classic Part Number
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5984	Ring-Backup	419-4654
127-3467	Manifold-Exhaust	394-9827
129-7768	Bearing-Sleeve	360-2316
133-4995	Gasket-Cyl Head	434-2445
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-3952	Impeller-Pump	374-4696

Sales Model D6N (Cont'd.)

CCS		
Original Part Number	**Part Name**	**Classic Part Number**
152-6485	Cyl Gp-102 472 Y	390-0985
154-8030	Gasket	394-0894
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-1387	Gear-Flywheel	374-4697
163-3749	Bearing-Sleeve	433-7505
164-4413	Mount	419-0876
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870

CCS		
Original Part Number	**Part Name**	**Classic Part Number**
224-6638	Bearing-Rod	419-6371
227-6789	Bearing-Sleeve	360-2322
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325

CCS		
Original Part Number	**Part Name**	**Classic Part Number**
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

DJA		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332

DJA		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442

DJA		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335

Sales Model D6N (Cont'd.)

DJA		
Original Part Number	**Part Name**	**Classic Part Number**
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

DJA		
Original Part Number	**Part Name**	**Classic Part Number**
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5984	Ring-Backup	419-4654
129-7768	Bearing-Sleeve	360-2316
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-6485	Cyl Gp-102 472 Y	390-0985

DJA		
Original Part Number	**Part Name**	**Classic Part Number**
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-3749	Bearing-Sleeve	433-7505
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653

DJY		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481

DJY		
Original Part Number	**Part Name**	**Classic Part Number**
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511

DJY		
Original Part Number	**Part Name**	**Classic Part Number**
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535

Sales Model D6N (Cont'd.)

DJY		
Original Part Number	**Part Name**	**Classic Part Number**
5J-6424	Bearing-Aligning	416-2135
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409

DJY		
Original Part Number	**Part Name**	**Classic Part Number**
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543

DJY		
Original Part Number	**Part Name**	**Classic Part Number**
109-0958	Pin	394-0208
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5984	Ring-Backup	419-4654
129-7768	Bearing-Sleeve	360-2316
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-6485	Cyl Gp-102 472 Y	390-0985
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
163-3749	Bearing-Sleeve	433-7505
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653

GB6		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437

Sales Model D6N (Cont'd.)

GB6		
Original Part Number	Part Name	Classic Part Number
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4903	Mount As	396-7274
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4Y-4905	Washer-Soft	416-5535
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696

GB6		
Original Part Number	Part Name	Classic Part Number
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7G-0437	Plate-Clutch	417-9466
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018

GB6		
Original Part Number	Part Name	Classic Part Number
9M-1853	Mount As.	376-3638
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
005-4834	Cone-Rlr Bearing	422-6490
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0958	Pin	394-0208
124-5741	Pin	394-0204
129-7768	Bearing-Sleeve	360-2316
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
160-6306	Cap-Bearing	325-6038
163-3749	Bearing-Sleeve	433-7505
202-2380	Shaft As.-Input	399-4432
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
265-5287	Ring-Seal	472-8028

Sales Model D6N (Cont'd.)

GB6		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

GB6		
Original Part Number	**Part Name**	**Classic Part Number**
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693

GHS		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641

GHS		
Original Part Number	**Part Name**	**Classic Part Number**
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335

GHS		
Original Part Number	**Part Name**	**Classic Part Number**
7K-5448	Cup-Bearing	415-1922
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
087-5802	Link-Rh	301-7964

Sales Model D6N (Cont'd.)

GHS		
Original Part Number	**Part Name**	**Classic Part Number**
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
124-5233	Pin	443-2664
124-5741	Pin	394-0204
129-7768	Bearing-Sleeve	360-2316
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
145-0803	Pin	393-0936

GHS		
Original Part Number	**Part Name**	**Classic Part Number**
145-0804	Sleeve	391-9905
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-3749	Bearing-Sleeve	433-7505
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436

GHS		
Original Part Number	**Part Name**	**Classic Part Number**
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653

JAH		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332

JAH		
Original Part Number	**Part Name**	**Classic Part Number**
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444

JAH		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816

Sales Model D6N (Cont'd.)

JAH		
Original Part Number	**Part Name**	**Classic Part Number**
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639

JAH		
Original Part Number	**Part Name**	**Classic Part Number**
9W-0517	Carrier-Planet	281-1686
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5984	Ring-Backup	419-4654
129-7768	Bearing-Sleeve	360-2316
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-6485	Cyl Gp-102 472 Y	390-0985
160-0305	Bearing-Aligning	396-9945

JAH		
Original Part Number	**Part Name**	**Classic Part Number**
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-3749	Bearing-Sleeve	433-7505
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653

LJR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480

LJR		
Original Part Number	**Part Name**	**Classic Part Number**
3B-4124	Cup-Spl Tapered	422-6481
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699

LJR		
Original Part Number	**Part Name**	**Classic Part Number**
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633

Sales Model D6N (Cont'd.)

LJR		
Original Part Number	Part Name	Classic Part Number
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335

LJR		
Original Part Number	Part Name	Classic Part Number
7K-5448	Cup-Bearing	415-1922
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966

LJR		
Original Part Number	Part Name	Classic Part Number
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
124-5233	Pin	443-2664
124-5741	Pin	394-0204
129-7768	Bearing-Sleeve	360-2316
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-3749	Bearing-Sleeve	433-7505
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653

Sales Model D6N (Cont'd.)

MG5		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4903	Mount As	396-7274
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
4Y-4905	Washer-Soft	416-5535
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444

MG5		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7G-0437	Plate-Clutch	417-9466
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
9J-9598	Pin	296-1362
9M-1853	Mount As.	376-3638
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686

MG5		
Original Part Number	**Part Name**	**Classic Part Number**
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
005-4834	Cone-Rlr Bearing	422-6490
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
108-8250	Carrier-Seal	421-7830
109-0958	Pin	394-0208
124-5741	Pin	394-0204
129-7768	Bearing-Sleeve	360-2316
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
163-3749	Bearing-Sleeve	433-7505
202-2380	Shaft As.-Input	399-4432
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693

MLW		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437

Sales Model D6N (Cont'd.)

MLW		
Original Part Number	Part Name	Classic Part Number
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690

MLW		
Original Part Number	Part Name	Classic Part Number
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420

MLW		
Original Part Number	Part Name	Classic Part Number
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
124-5233	Pin	443-2664
124-5741	Pin	394-0204
129-7768	Bearing-Sleeve	360-2316
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038

Sales Model D6N (Cont'd.)

MLW		
Original Part Number	Part Name	Classic Part Number
163-3749	Bearing-Sleeve	433-7505
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499

MLW		
Original Part Number	Part Name	Classic Part Number
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047

MLW		
Original Part Number	Part Name	Classic Part Number
250-2402	Pin As	360-2351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653

PBA		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4903	Mount As	396-7274
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370

PBA		
Original Part Number	Part Name	Classic Part Number
4J-3583	Screw-Adjusting	297-7242
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059

PBA		
Original Part Number	Part Name	Classic Part Number
7G-0437	Plate-Clutch	417-9466
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
8V-7659	Pin As	361-1702
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639

Sales Model D6N (Cont'd.)

PBA		
Original Part Number	**Part Name**	**Classic Part Number**
9W-0517	Carrier-Planet	281-1686
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208

PBA		
Original Part Number	**Part Name**	**Classic Part Number**
124-5233	Pin	443-2664
124-5741	Pin	394-0204
129-7768	Bearing-Sleeve	360-2316
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-3749	Bearing-Sleeve	433-7505
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
227-6789	Bearing-Sleeve	360-2322

PBA		
Original Part Number	**Part Name**	**Classic Part Number**
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653

JAH		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-9960	Disc-Friction	417-9487

JAH		
Original Part Number	**Part Name**	**Classic Part Number**
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5J-6424	Bearing-Aligning	416-2135
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022

JAH		
Original Part Number	**Part Name**	**Classic Part Number**
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691

Sales Model D6N (Cont'd.)

JAH		
Original Part Number	**Part Name**	**Classic Part Number**
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216

JAH		
Original Part Number	**Part Name**	**Classic Part Number**
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
124-5233	Pin	443-2664
124-5741	Pin	394-0204
126-5984	Ring-Backup	419-4654
129-7768	Bearing-Sleeve	360-2316
135-7393	Head	382-6895

JAH		
Original Part Number	**Part Name**	**Classic Part Number**
137-2919	Bearing-Sleeve	360-2319
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
152-6485	Cyl Gp-102 472 Y	390-0985
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-3749	Bearing-Sleeve	433-7505
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653

LJR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021

LJR		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208

LJR		
Original Part Number	**Part Name**	**Classic Part Number**
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511

Sales Model D6N (Cont'd.)

LJR		
Original Part Number	Part Name	Classic Part Number
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068

LJR		
Original Part Number	Part Name	Classic Part Number
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490

LJR		
Original Part Number	Part Name	Classic Part Number
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
124-5233	Pin	443-2664
124-5741	Pin	394-0204
129-7768	Bearing-Sleeve	360-2316
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-3749	Bearing-Sleeve	433-7505
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653

Sales Model D6N (Cont'd.)

MG5		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4903	Mount As	396-7274
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
4Y-4905	Washer-Soft	416-5535
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444

MG5		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7G-0437	Plate-Clutch	417-9466
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
9J-9598	Pin	296-1362
9M-1853	Mount As.	376-3638
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686

MG5		
Original Part Number	**Part Name**	**Classic Part Number**
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
005-4834	Cone-Rlr Bearing	422-6490
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
108-8250	Carrier-Seal	421-7830
109-0958	Pin	394-0208
124-5741	Pin	394-0204
129-7768	Bearing-Sleeve	360-2316
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
163-3749	Bearing-Sleeve	433-7505
202-2380	Shaft As.-Input	399-4432
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
265-5287	Ring-Seal	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693

MLW		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437

Sales Model D6N (Cont'd.)

MLW		
Original Part Number	Part Name	Classic Part Number
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690

MLW		
Original Part Number	Part Name	Classic Part Number
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0456	Bearing As-Rlr	435-4041
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4306	Plate-Center	297-7229
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420

MLW		
Original Part Number	Part Name	Classic Part Number
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-5284	Bearing-Sleeve	380-7379
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
124-5233	Pin	443-2664
124-5741	Pin	394-0204
129-7768	Bearing-Sleeve	360-2316
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038

Sales Model D6N (Cont'd.)

MLW		
Original Part Number	**Part Name**	**Classic Part Number**
163-3749	Bearing-Sleeve	433-7505
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499

MLW		
Original Part Number	**Part Name**	**Classic Part Number**
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047

MLW		
Original Part Number	**Part Name**	**Classic Part Number**
250-2402	Pin As	360-2351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653

PBA		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4903	Mount As	396-7274
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370

PBA		
Original Part Number	**Part Name**	**Classic Part Number**
4J-3583	Screw-Adjusting	297-7242
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6E-5449	Bearing-Sleeve	464-4048
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059

PBA		
Original Part Number	**Part Name**	**Classic Part Number**
7G-0437	Plate-Clutch	417-9466
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
8V-7659	Pin As	361-1702
9G-1488	Housing-Clutch	430-7620
9J-2759	Trunnion	394-0216
9J-9598	Pin	296-1362
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639

Sales Model D6N (Cont'd.)

PBA		
Original Part Number	**Part Name**	**Classic Part Number**
9W-0517	Carrier-Planet	281-1686
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208

PBA		
Original Part Number	**Part Name**	**Classic Part Number**
124-5233	Pin	443-2664
124-5741	Pin	394-0204
129-7768	Bearing-Sleeve	360-2316
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-3749	Bearing-Sleeve	433-7505
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
227-6789	Bearing-Sleeve	360-2322

PBA		
Original Part Number	**Part Name**	**Classic Part Number**
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653

PER		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4903	Mount As	396-7274
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699

PER		
Original Part Number	**Part Name**	**Classic Part Number**
3T-9960	Disc-Friction	417-9487
4F-2041	Cup-Roller Brg	418-9609
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4T-0231	Retainer	376-3641
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-4905	Washer-Soft	416-5535
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6E-5449	Bearing-Sleeve	464-4048

PER		
Original Part Number	**Part Name**	**Classic Part Number**
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7G-0437	Plate-Clutch	417-9466
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275

Sales Model D6N (Cont'd.)

PER		
Original Part Number	**Part Name**	**Classic Part Number**
7J-5131	Trunnion	296-1371
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
7Y-3428	Bearing-Sleeve	314-8647
7Y-5131	Bearing-Sleeve	301-4626
8C-3111	Rod End-Spher	392-4523
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
8V-7659	Pin As	361-1702
9G-1488	Housing-Clutch	430-7620
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

PER		
Original Part Number	**Part Name**	**Classic Part Number**
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
108-8250	Carrier-Seal	421-7830
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0958	Pin	394-0208
124-5233	Pin	443-2664
124-5741	Pin	394-0204
129-7768	Bearing-Sleeve	360-2316
135-7393	Head	382-6895
137-2919	Bearing-Sleeve	360-2319
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905

PER		
Original Part Number	**Part Name**	**Classic Part Number**
160-0305	Bearing-Aligning	396-9945
160-5691	Pin	393-0931
160-6306	Cap-Bearing	325-6038
163-3749	Bearing-Sleeve	433-7505
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
227-6789	Bearing-Sleeve	360-2322
236-6268	Bearing-Sleeve	453-6499
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5714	Piston-Clutch	281-1693
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653

SC6		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4903	Mount As	396-7274
3H-8726	Mount As	385-7208
3L-9410	Cone-Spl Tapered	391-9899

SC6		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133

SC6		
Original Part Number	**Part Name**	**Classic Part Number**
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0306	Bearing-Sleeve	391-1104
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1084	Impeller-Conv	380-1477
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166

Sales Model D6N (Cont'd.)

SC6		
Original Part Number	**Part Name**	**Classic Part Number**
7B-7515	Bearing-Ball	399-6059
7G-0437	Plate-Clutch	417-9466
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7M-7219	Bearing-Thrust	384-4816
7P-6596	Bearing-Sleeve	295-6409
7S-4534	Bearing-Caged	417-9497
7T-8136	Shaft-Planet	314-8714
8G-3102	Piston	325-6162
8G-4189	Bearing-Aligning	295-6411

SC6		
Original Part Number	**Part Name**	**Classic Part Number**
8G-4190	Seal-Ebar	296-1366
8P-1916	Gear-Planet	283-5209
8T-0072	Cone-Rlr Brg	377-7448
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0517	Carrier-Planet	281-1686
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554

SC6		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
108-8250	Carrier-Seal	421-7830
109-0377	Pin As	399-8543
196-7078	Strip Wear Front	418-1968
202-2380	Shaft As.-Input	399-4432
321-5714	Piston-Clutch	281-1693

Sales Model D6R

1RW		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797

1RW		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020

1RW		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229

Sales Model D6R (Cont'd.)

1RW		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698

1RW		
Original Part Number	**Part Name**	**Classic Part Number**
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

1RW		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025

Sales Model D6R (Cont'd.)

1RW		
Original Part Number	**Part Name**	**Classic Part Number**
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414

1RW		
Original Part Number	**Part Name**	**Classic Part Number**
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187

1RW		
Original Part Number	**Part Name**	**Classic Part Number**
7W-9020	Bell As-Pump Suc	378-3989
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

Sales Model D6R (Cont'd.)

1RW		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891

1RW		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
134-4200	Manifold-Exhaust	443-2060
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275

1RW		
Original Part Number	**Part Name**	**Classic Part Number**
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model D6R (Cont'd.)

2HM		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0699	Impeller-Conv	235-1808
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680

2HM		
Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084

2HM		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344

Sales Model D6R (Cont'd.)

2HM		
Original Part Number	**Part Name**	**Classic Part Number**
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052

2HM		
Original Part Number	**Part Name**	**Classic Part Number**
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475

2HM		
Original Part Number	**Part Name**	**Classic Part Number**
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-5692	Plate-Brake	380-7492
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922

Sales Model D6R (Cont'd.)

2HM		
Original Part Number	Part Name	Classic Part Number
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636

2HM		
Original Part Number	Part Name	Classic Part Number
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372

2HM		
Original Part Number	Part Name	Classic Part Number
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-2759	Trunnion	394-0216
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859

Sales Model D6R (Cont'd.)

2HM		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008

2HM		
Original Part Number	**Part Name**	**Classic Part Number**
133-8996	Line As-Fuel Inj	378-4009
134-3056	Guard-Duo-Cone	421-7831
134-3068	Kit-Gasket(F)	393-3636
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
140-8435	Flange	451-9015
141-4974	Gasket Kit	388-0658
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577

2HM		
Original Part Number	**Part Name**	**Classic Part Number**
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

2YN		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453

2YN		
Original Part Number	**Part Name**	**Classic Part Number**
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595

2YN		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0699	Impeller-Conv	235-1808
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049

Sales Model D6R (Cont'd.)

2YN		
Original Part Number	Part Name	Classic Part Number
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

2YN		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444

2YN		
Original Part Number	Part Name	Classic Part Number
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

Sales Model D6R (Cont'd.)

2YN		
Original Part Number	Part Name	Classic Part Number
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956

2YN		
Original Part Number	Part Name	Classic Part Number
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-5692	Plate-Brake	380-7492
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414

2YN		
Original Part Number	Part Name	Classic Part Number
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989

Sales Model D6R (Cont'd.)

2YN		
Original Part Number	Part Name	Classic Part Number
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

2YN		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-2759	Trunnion	394-0216
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891

2YN		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007

Sales Model D6R (Cont'd.)

2YN		
Original Part Number	**Part Name**	**Classic Part Number**
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3056	Guard-Duo-Cone	421-7831
134-3068	Kit-Gasket(F)	393-3636
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
140-8435	Flange	451-9015
141-4974	Gasket Kit	388-0658
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
163-4063	Core As-Rdtr	391-9826
164-6560	Body As-Piston	477-7125

2YN		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704

2YN		
Original Part Number	**Part Name**	**Classic Part Number**
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

3ZN		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410

3ZN		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543

3ZN		
Original Part Number	**Part Name**	**Classic Part Number**
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513

Sales Model D6R (Cont'd.)

3ZN		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778

3ZN		
Original Part Number	**Part Name**	**Classic Part Number**
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633

3ZN		
Original Part Number	**Part Name**	**Classic Part Number**
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5J-4929	Bearing	256-4796

Sales Model D6R (Cont'd.)

3ZN		
Original Part Number	Part Name	Classic Part Number
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603

3ZN		
Original Part Number	Part Name	Classic Part Number
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899

3ZN		
Original Part Number	Part Name	Classic Part Number
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893

Sales Model D6R (Cont'd.)

3ZN		
Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448

3ZN		
Original Part Number	Part Name	Classic Part Number
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859

3ZN		
Original Part Number	Part Name	Classic Part Number
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3056	Guard-Duo-Cone	421-7831
134-3068	Kit-Gasket(F)	393-3636
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
140-8435	Flange	451-9015
141-4974	Gasket Kit	388-0658
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
163-4063	Core As-Rdtr	391-9826

Sales Model D6R (Cont'd.)

3ZN		
Original Part Number	**Part Name**	**Classic Part Number**
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577

3ZN		
Original Part Number	**Part Name**	**Classic Part Number**
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524

3ZN		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

4FM		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464

4FM		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690

4FM		
Original Part Number	**Part Name**	**Classic Part Number**
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

Sales Model D6R (Cont'd.)

4FM		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341

4FM		
Original Part Number	Part Name	Classic Part Number
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986

4FM		
Original Part Number	Part Name	Classic Part Number
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

Sales Model D6R (Cont'd.)

4FM		
Original Part Number	Part Name	Classic Part Number
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450

4FM		
Original Part Number	Part Name	Classic Part Number
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470

4FM		
Original Part Number	Part Name	Classic Part Number
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081

Sales Model D6R (Cont'd.)

4FM		
Original Part Number	Part Name	Classic Part Number
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

4FM		
Original Part Number	Part Name	Classic Part Number
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008

4FM		
Original Part Number	Part Name	Classic Part Number
133-8996	Line As-Fuel Inj	378-4009
134-3056	Guard-Duo-Cone	421-7831
134-3068	Kit-Gasket(F)	393-3636
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
140-8435	Flange	451-9015
141-4974	Gasket Kit	388-0658
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351

Sales Model D6R (Cont'd.)

4FM		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966

4FM		
Original Part Number	**Part Name**	**Classic Part Number**
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420

4FM		
Original Part Number	**Part Name**	**Classic Part Number**
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

4HN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0699	Impeller-Conv	235-1808
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038

4HN		
Original Part Number	**Part Name**	**Classic Part Number**
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927

4HN		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424

Sales Model D6R (Cont'd.)

4HN		
Original Part Number	**Part Name**	**Classic Part Number**
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985

4HN		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
5D-2989	Bearing	380-7511
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247

4HN		
Original Part Number	**Part Name**	**Classic Part Number**
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-5692	Plate-Brake	380-7492
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450

Sales Model D6R (Cont'd.)

4HN		
Original Part Number	Part Name	Classic Part Number
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296

4HN		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081

4HN		
Original Part Number	Part Name	Classic Part Number
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-2759	Trunnion	394-0216
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923

Sales Model D6R (Cont'd.)

4HN		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193

4HN		
Original Part Number	**Part Name**	**Classic Part Number**
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3056	Guard-Duo-Cone	421-7831
134-4200	Manifold-Exhaust	443-2060
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

4HN		
Original Part Number	**Part Name**	**Classic Part Number**
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
201-2078	Bar As-Equalizer	418-1946
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

4JR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535

4JR		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582

4JR		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409

Sales Model D6R (Cont'd.)

4JR		
Original Part Number	Part Name	Classic Part Number
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0699	Impeller-Conv	235-1808
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354

4JR		
Original Part Number	Part Name	Classic Part Number
2F-8509	Cone-Roller Brg	399-4434
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714

4JR		
Original Part Number	Part Name	Classic Part Number
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

Sales Model D6R (Cont'd.)

4JR		
Original Part Number	Part Name	Classic Part Number
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917

4JR		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-5692	Plate-Brake	380-7492
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915

4JR		
Original Part Number	Part Name	Classic Part Number
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656

Sales Model D6R (Cont'd.)

4JR		
Original Part Number	**Part Name**	**Classic Part Number**
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349

4JR		
Original Part Number	**Part Name**	**Classic Part Number**
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-2759	Trunnion	394-0216
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362

4JR		
Original Part Number	**Part Name**	**Classic Part Number**
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937

Sales Model D6R (Cont'd.)

4JR		
Original Part Number	**Part Name**	**Classic Part Number**
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3056	Guard-Duo-Cone	421-7831
134-4200	Manifold-Exhaust	443-2060
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686

4JR		
Original Part Number	**Part Name**	**Classic Part Number**
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835

4JR		
Original Part Number	**Part Name**	**Classic Part Number**
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

4MN		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685

4MN		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0699	Impeller-Conv	235-1808
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920

4MN		
Original Part Number	**Part Name**	**Classic Part Number**
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

Sales Model D6R (Cont'd.)

4MN		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465

4MN		
Original Part Number	Part Name	Classic Part Number
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952

4MN		
Original Part Number	Part Name	Classic Part Number
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5J-4929	Bearing	256-4796

Sales Model D6R (Cont'd.)

4MN		
Original Part Number	Part Name	Classic Part Number
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6T-7882	Gear-Planet	296-1352

4MN		
Original Part Number	Part Name	Classic Part Number
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-5692	Plate-Brake	380-7492
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686

4MN		
Original Part Number	Part Name	Classic Part Number
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291

Sales Model D6R (Cont'd.)

4MN		
Original Part Number	Part Name	Classic Part Number
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215

4MN		
Original Part Number	Part Name	Classic Part Number
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-2759	Trunnion	394-0216
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516

4MN		
Original Part Number	Part Name	Classic Part Number
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3056	Guard-Duo-Cone	421-7831
134-3068	Kit-Gasket(F)	393-3636
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
140-8435	Flange	451-9015
141-4974	Gasket Kit	388-0658
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
163-4063	Core As-Rdtr	391-9826
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

Sales Model D6R (Cont'd.)

4MN		
Original Part Number	**Part Name**	**Classic Part Number**
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

4MN		
Original Part Number	**Part Name**	**Classic Part Number**
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351

4MN		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

4TR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0699	Impeller-Conv	235-1808
1T-0762	Race-Thrust	384-4803

4TR		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221

4TR		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084

Sales Model D6R (Cont'd.)

4TR		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-3953	Bearing-Sleeve	384-4778
3J-4284	Cap-Brg	314-8656
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-6555	Shaft	295-5703
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344

4TR		
Original Part Number	**Part Name**	**Classic Part Number**
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423

4TR		
Original Part Number	**Part Name**	**Classic Part Number**
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544

Sales Model D6R (Cont'd.)

4TR		
Original Part Number	Part Name	Classic Part Number
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206

4TR		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252

4TR		
Original Part Number	Part Name	Classic Part Number
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416

Sales Model D6R (Cont'd.)

4TR		
Original Part Number	**Part Name**	**Classic Part Number**
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666

4TR		
Original Part Number	**Part Name**	**Classic Part Number**
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
134-3068	Kit-Gasket(F)	393-3636
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
140-8435	Flange	451-9015
141-4974	Gasket Kit	388-0658
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126

4TR		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
201-2078	Bar As-Equalizer	418-1946
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

4WR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437

Sales Model D6R (Cont'd.)

4WR		
Original Part Number	Part Name	Classic Part Number
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0699	Impeller-Conv	235-1808
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158

4WR		
Original Part Number	Part Name	Classic Part Number
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084

4WR		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982

Sales Model D6R (Cont'd.)

4WR		
Original Part Number	**Part Name**	**Classic Part Number**
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4T-7534	Pin	433-9209
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191

4WR		
Original Part Number	**Part Name**	**Classic Part Number**
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
5D-2989	Bearing	380-7511
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387

4WR		
Original Part Number	**Part Name**	**Classic Part Number**
6J-5179	Retainer	380-7406
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-5692	Plate-Brake	380-7492
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816

Sales Model D6R (Cont'd.)

4WR		
Original Part Number	Part Name	Classic Part Number
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342

4WR		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415

4WR		
Original Part Number	Part Name	Classic Part Number
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-2759	Trunnion	394-0216
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165

Sales Model D6R (Cont'd.)

4WR		
Original Part Number	**Part Name**	**Classic Part Number**
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361

4WR		
Original Part Number	**Part Name**	**Classic Part Number**
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

4WR		
Original Part Number	**Part Name**	**Classic Part Number**
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

5LN		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685

5LN		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049

5LN		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689

Sales Model D6R (Cont'd.)

5LN		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439

5LN		
Original Part Number	**Part Name**	**Classic Part Number**
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
3W-6555	Shaft	295-5703
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242

5LN		
Original Part Number	**Part Name**	**Classic Part Number**
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534

Sales Model D6R (Cont'd.)

5LN		
Original Part Number	**Part Name**	**Classic Part Number**
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5J-2528	Plunger	391-1318
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387

5LN		
Original Part Number	**Part Name**	**Classic Part Number**
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922

5LN		
Original Part Number	**Part Name**	**Classic Part Number**
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658

Sales Model D6R (Cont'd.)

5LN		
Original Part Number	**Part Name**	**Classic Part Number**
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438

5LN		
Original Part Number	**Part Name**	**Classic Part Number**
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031

5LN		
Original Part Number	**Part Name**	**Classic Part Number**
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3056	Guard-Duo-Cone	421-7831
134-3068	Kit-Gasket(F)	393-3636
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
140-8435	Flange	451-9015

Sales Model D6R (Cont'd.)

5LN		
Original Part Number	**Part Name**	**Classic Part Number**
141-4974	Gasket Kit	388-0658
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
163-4063	Core As-Rdtr	391-9826
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

5LN		
Original Part Number	**Part Name**	**Classic Part Number**
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
201-2078	Bar As-Equalizer	418-1946

5LN		
Original Part Number	**Part Name**	**Classic Part Number**
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

5PR		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409

5PR		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680

5PR		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-5233	Bearing-Thrust	388-0578

Sales Model D6R (Cont'd.)

5PR		
Original Part Number	Part Name	Classic Part Number
2J-8489	Bearing-Sleeve	295-5691
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796

5PR		
Original Part Number	Part Name	Classic Part Number
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008

5PR		
Original Part Number	Part Name	Classic Part Number
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4T-7534	Pin	433-9209
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022

Sales Model D6R (Cont'd.)

5PR		
Original Part Number	**Part Name**	**Classic Part Number**
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132

5PR		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410

5PR		
Original Part Number	**Part Name**	**Classic Part Number**
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623

Sales Model D6R (Cont'd.)

5PR		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425

5PR		
Original Part Number	Part Name	Classic Part Number
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9427	Bearing-Sleeve	361-1695
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-9162	Tube As	451-9023
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681

5PR		
Original Part Number	Part Name	Classic Part Number
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
134-3068	Kit-Gasket(F)	393-3636
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
140-8435	Flange	451-9015
141-4974	Gasket Kit	388-0658
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357

Sales Model D6R (Cont'd.)

5PR		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966

5PR		
Original Part Number	**Part Name**	**Classic Part Number**
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420

5PR		
Original Part Number	**Part Name**	**Classic Part Number**
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

5RR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920

5RR		
Original Part Number	**Part Name**	**Classic Part Number**
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480

5RR		
Original Part Number	**Part Name**	**Classic Part Number**
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126

Sales Model D6R (Cont'd.)

5RR		
Original Part Number	**Part Name**	**Classic Part Number**
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890

5RR		
Original Part Number	**Part Name**	**Classic Part Number**
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4T-7534	Pin	433-9209
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
5D-2989	Bearing	380-7511
5J-2528	Plunger	391-1318
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774

5RR		
Original Part Number	**Part Name**	**Classic Part Number**
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428

Sales Model D6R (Cont'd.)

5RR		
Original Part Number	Part Name	Classic Part Number
6Y-3896	Pin As	325-6132
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438

5RR		
Original Part Number	Part Name	Classic Part Number
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623

5RR		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436

Sales Model D6R (Cont'd.)

5RR		
Original Part Number	**Part Name**	**Classic Part Number**
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859

5RR		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
163-4063	Core As-Rdtr	391-9826
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351

5RR		
Original Part Number	**Part Name**	**Classic Part Number**
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

6FR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913

6FR		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572

6FR		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410

Sales Model D6R (Cont'd.)

6FR		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0699	Impeller-Conv	235-1808
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

6FR		
Original Part Number	**Part Name**	**Classic Part Number**
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346

6FR		
Original Part Number	**Part Name**	**Classic Part Number**
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499

Sales Model D6R (Cont'd.)

6FR		
Original Part Number	**Part Name**	**Classic Part Number**
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4T-7534	Pin	433-9209
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-2054	Bearing	380-7510

6FR		
Original Part Number	**Part Name**	**Classic Part Number**
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801

6FR		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-3896	Pin As	325-6132
6Y-5692	Plate-Brake	380-7492
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438

Sales Model D6R (Cont'd.)

6FR		
Original Part Number	**Part Name**	**Classic Part Number**
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623

6FR		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436

6FR		
Original Part Number	**Part Name**	**Classic Part Number**
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-2759	Trunnion	394-0216
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932

Sales Model D6R (Cont'd.)

6FR		
Original Part Number	**Part Name**	**Classic Part Number**
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
134-3068	Kit-Gasket(F)	393-3636
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
140-8435	Flange	451-9015
141-4974	Gasket Kit	388-0658
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353

6FR		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259

6FR		
Original Part Number	**Part Name**	**Classic Part Number**
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

6GR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464

6GR		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

6GR		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

Sales Model D6R (Cont'd.)

6GR		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3J-3953	Bearing-Sleeve	384-4778
3J-4284	Cap-Brg	314-8656
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609

6GR		
Original Part Number	**Part Name**	**Classic Part Number**
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8538	Bearing-Spl Ball	417-4502
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042

6GR		
Original Part Number	**Part Name**	**Classic Part Number**
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810

Sales Model D6R (Cont'd.)

6GR		
Original Part Number	Part Name	Classic Part Number
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-5692	Plate-Brake	380-7492
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816

6GR		
Original Part Number	Part Name	Classic Part Number
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291

6GR		
Original Part Number	Part Name	Classic Part Number
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215

Sales Model D6R (Cont'd.)

6GR		
Original Part Number	**Part Name**	**Classic Part Number**
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-2759	Trunnion	394-0216
9J-9427	Bearing-Sleeve	361-1695
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360

6GR		
Original Part Number	**Part Name**	**Classic Part Number**
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
131-3815	Seal Gp-Basic	325-6193
134-3068	Kit-Gasket(F)	393-3636
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194

6GR		
Original Part Number	**Part Name**	**Classic Part Number**
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
201-2078	Bar As-Equalizer	418-1946
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

6HR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535

6HR		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582

6HR		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738

Sales Model D6R (Cont'd.)

6HR		
Original Part Number	Part Name	Classic Part Number
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0699	Impeller-Conv	235-1808
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628

6HR		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-5999	Bearing-Sleeve	391-9813
3G-6313	Bearing	325-6007
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346

6HR		
Original Part Number	Part Name	Classic Part Number
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499

Sales Model D6R (Cont'd.)

6HR		
Original Part Number	Part Name	Classic Part Number
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4T-7534	Pin	433-9209
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5J-4321	Trunnion	302-2700
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783

6HR		
Original Part Number	Part Name	Classic Part Number
5J-7981	Pin	256-4784
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442

6HR		
Original Part Number	Part Name	Classic Part Number
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-5692	Plate-Brake	380-7492
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290

Sales Model D6R (Cont'd.)

6HR		
Original Part Number	Part Name	Classic Part Number
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196

6HR		
Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216

6HR		
Original Part Number	Part Name	Classic Part Number
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-2759	Trunnion	394-0216
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033

Sales Model D6R (Cont'd.)

6HR		
Original Part Number	**Part Name**	**Classic Part Number**
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351

6HR		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055

6HR		
Original Part Number	**Part Name**	**Classic Part Number**
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

6JN		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738

6JN		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0699	Impeller-Conv	235-1808
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543

6JN		
Original Part Number	**Part Name**	**Classic Part Number**
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513

Sales Model D6R (Cont'd.)

6JN		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3J-2682	Bracket	296-1345

6JN		
Original Part Number	Part Name	Classic Part Number
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427

6JN		
Original Part Number	Part Name	Classic Part Number
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195

Sales Model D6R (Cont'd.)

6JN		
Original Part Number	Part Name	Classic Part Number
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142

6JN		
Original Part Number	Part Name	Classic Part Number
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-5692	Plate-Brake	380-7492
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964

6JN		
Original Part Number	Part Name	Classic Part Number
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

Sales Model D6R (Cont'd.)

6JN		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931

6JN		
Original Part Number	Part Name	Classic Part Number
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-2759	Trunnion	394-0216
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507

6JN		
Original Part Number	Part Name	Classic Part Number
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3056	Guard-Duo-Cone	421-7831
134-3068	Kit-Gasket(F)	393-3636
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
140-8435	Flange	451-9015
141-4974	Gasket Kit	388-0658
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
163-4063	Core As-Rdtr	391-9826
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194

Sales Model D6R (Cont'd.)

6JN		
Original Part Number	**Part Name**	**Classic Part Number**
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704

6JN		
Original Part Number	**Part Name**	**Classic Part Number**
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988

6JN		
Original Part Number	**Part Name**	**Classic Part Number**
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

6MR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0699	Impeller-Conv	235-1808
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108

6MR		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513

6MR		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356

Sales Model D6R (Cont'd.)

6MR		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370

6MR		
Original Part Number	**Part Name**	**Classic Part Number**
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191

6MR		
Original Part Number	**Part Name**	**Classic Part Number**
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

Sales Model D6R (Cont'd.)

6MR		
Original Part Number	Part Name	Classic Part Number
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-5692	Plate-Brake	380-7492
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206

6MR		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037

6MR		
Original Part Number	Part Name	Classic Part Number
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348

Sales Model D6R (Cont'd.)

6MR		
Original Part Number	**Part Name**	**Classic Part Number**
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-2759	Trunnion	394-0216
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701

6MR		
Original Part Number	**Part Name**	**Classic Part Number**
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
134-4200	Manifold-Exhaust	443-2060
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351

6MR		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

7AR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443

7AR		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913

7AR		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

Sales Model D6R (Cont'd.)

7AR		
Original Part Number	**Part Name**	**Classic Part Number**
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0699	Impeller-Conv	235-1808
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659

7AR		
Original Part Number	**Part Name**	**Classic Part Number**
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692

7AR		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3J-3953	Bearing-Sleeve	384-4778
3J-4284	Cap-Brg	314-8656
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919

Sales Model D6R (Cont'd.)

7AR		
Original Part Number	Part Name	Classic Part Number
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917

7AR		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-5692	Plate-Brake	380-7492
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552

7AR		
Original Part Number	Part Name	Classic Part Number
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351

Sales Model D6R (Cont'd.)

7AR		
Original Part Number	**Part Name**	**Classic Part Number**
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377

7AR		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-2759	Trunnion	394-0216
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353

7AR		
Original Part Number	**Part Name**	**Classic Part Number**
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
134-3068	Kit-Gasket(F)	393-3636
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
140-8435	Flange	451-9015
141-4974	Gasket Kit	388-0658

Sales Model D6R (Cont'd.)

7AR		
Original Part Number	**Part Name**	**Classic Part Number**
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194

7AR		
Original Part Number	**Part Name**	**Classic Part Number**
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
201-2078	Bar As-Equalizer	418-1946
232-3233	Bearing-Main	376-9085

7AR		
Original Part Number	**Part Name**	**Classic Part Number**
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

7DR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595

7DR		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006

7DR		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480

Sales Model D6R (Cont'd.)

7DR		
Original Part Number	**Part Name**	**Classic Part Number**
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-5999	Bearing-Sleeve	391-9813
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226

7DR		
Original Part Number	**Part Name**	**Classic Part Number**
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

7DR		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4T-7534	Pin	433-9209
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774

Sales Model D6R (Cont'd.)

7DR		
Original Part Number	**Part Name**	**Classic Part Number**
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428

7DR		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-3896	Pin As	325-6132
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290

7DR		
Original Part Number	**Part Name**	**Classic Part Number**
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210

Sales Model D6R (Cont'd.)

7DR		
Original Part Number	Part Name	Classic Part Number
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216

7DR		
Original Part Number	Part Name	Classic Part Number
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856

7DR		
Original Part Number	Part Name	Classic Part Number
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524

Sales Model D6R (Cont'd.)

7DR		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988

7DR		
Original Part Number	**Part Name**	**Classic Part Number**
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

7DR		
Original Part Number	**Part Name**	**Classic Part Number**
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

7GR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049

7GR		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142

7GR		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714

Sales Model D6R (Cont'd.)

7GR		
Original Part Number	**Part Name**	**Classic Part Number**
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763

7GR		
Original Part Number	**Part Name**	**Classic Part Number**
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433

7GR		
Original Part Number	**Part Name**	**Classic Part Number**
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427

Sales Model D6R (Cont'd.)

7GR		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995

7GR		
Original Part Number	**Part Name**	**Classic Part Number**
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

7GR		
Original Part Number	**Part Name**	**Classic Part Number**
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791

Sales Model D6R (Cont'd.)

7GR		
Original Part Number	**Part Name**	**Classic Part Number**
9G-9183	Shaft	295-0417
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306

7GR		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
134-4200	Manifold-Exhaust	443-2060
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

7GR		
Original Part Number	**Part Name**	**Classic Part Number**
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

7KN		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913

7KN		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572

7KN		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410

Sales Model D6R (Cont'd.)

7KN		
Original Part Number	Part Name	Classic Part Number
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628

7KN		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714

7KN		
Original Part Number	Part Name	Classic Part Number
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499

Sales Model D6R (Cont'd.)

7KN		
Original Part Number	**Part Name**	**Classic Part Number**
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784

7KN		
Original Part Number	**Part Name**	**Classic Part Number**
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442

7KN		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686

Sales Model D6R (Cont'd.)

7KN		
Original Part Number	Part Name	Classic Part Number
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291

7KN		
Original Part Number	Part Name	Classic Part Number
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214

7KN		
Original Part Number	Part Name	Classic Part Number
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490

Sales Model D6R (Cont'd.)

7KN		
Original Part Number	**Part Name**	**Classic Part Number**
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3056	Guard-Duo-Cone	421-7831

7KN		
Original Part Number	**Part Name**	**Classic Part Number**
134-3068	Kit-Gasket(F)	393-3636
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
140-8435	Flange	451-9015
141-4974	Gasket Kit	388-0658
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
163-4063	Core As-Rdtr	391-9826
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484

7KN		
Original Part Number	**Part Name**	**Classic Part Number**
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

8LN		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572

8LN		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464

8LN		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0699	Impeller-Conv	235-1808
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543

Sales Model D6R (Cont'd.)

8LN		
Original Part Number	**Part Name**	**Classic Part Number**
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

8LN		
Original Part Number	**Part Name**	**Classic Part Number**
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3J-3953	Bearing-Sleeve	384-4778
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982

8LN		
Original Part Number	**Part Name**	**Classic Part Number**
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

Sales Model D6R (Cont'd.)

8LN		
Original Part Number	Part Name	Classic Part Number
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387

8LN		
Original Part Number	Part Name	Classic Part Number
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-5692	Plate-Brake	380-7492
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670

8LN		
Original Part Number	Part Name	Classic Part Number
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252

Sales Model D6R (Cont'd.)

8LN		
Original Part Number	**Part Name**	**Classic Part Number**
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416

8LN		
Original Part Number	**Part Name**	**Classic Part Number**
8S-9151	Cup-Spl Tapered	374-8348
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-2759	Trunnion	394-0216
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306

8LN		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3056	Guard-Duo-Cone	421-7831
134-4200	Manifold-Exhaust	443-2060
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
163-4063	Core As-Rdtr	391-9826
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126

Sales Model D6R (Cont'd.)

8LN		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

8LN		
Original Part Number	**Part Name**	**Classic Part Number**
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
201-2078	Bar As-Equalizer	418-1946
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351

8LN		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

8TM		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464

8TM		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0699	Impeller-Conv	235-1808
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659

8TM		
Original Part Number	**Part Name**	**Classic Part Number**
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230

Sales Model D6R (Cont'd.)

8TM		
Original Part Number	**Part Name**	**Classic Part Number**
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052

8TM		
Original Part Number	**Part Name**	**Classic Part Number**
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6555	Shaft	295-5703
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191

8TM		
Original Part Number	**Part Name**	**Classic Part Number**
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
5D-2989	Bearing	380-7511
5J-2528	Plunger	391-1318
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

Sales Model D6R (Cont'd.)

8TM		
Original Part Number	Part Name	Classic Part Number
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374

8TM		
Original Part Number	Part Name	Classic Part Number
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658

8TM		
Original Part Number	Part Name	Classic Part Number
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438

Sales Model D6R (Cont'd.)

8TM		
Original Part Number	**Part Name**	**Classic Part Number**
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666

8TM		
Original Part Number	**Part Name**	**Classic Part Number**
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3056	Guard-Duo-Cone	421-7831
134-3068	Kit-Gasket(F)	393-3636
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
140-8435	Flange	451-9015
141-4974	Gasket Kit	388-0658
148-7455	Valve - Exhaust	270-4361

8TM		
Original Part Number	**Part Name**	**Classic Part Number**
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
201-2078	Bar As-Equalizer	418-1946
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model D6R (Cont'd.)

8XN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0699	Impeller-Conv	235-1808
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680

8XN		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084

8XN		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-1252	Pin	295-5704

Sales Model D6R (Cont'd.)

8XN		
Original Part Number	**Part Name**	**Classic Part Number**
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-2514	Gear-Flywheel	421-7283
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-PrecInr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727

8XN		
Original Part Number	**Part Name**	**Classic Part Number**
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358

8XN		
Original Part Number	**Part Name**	**Classic Part Number**
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-5692	Plate-Brake	380-7492
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371

Sales Model D6R (Cont'd.)

8XN		
Original Part Number	Part Name	Classic Part Number
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442

8XN		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033

8XN		
Original Part Number	Part Name	Classic Part Number
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-2759	Trunnion	394-0216
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666

Sales Model D6R (Cont'd.)

8XN		
Original Part Number	**Part Name**	**Classic Part Number**
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006

8XN		
Original Part Number	**Part Name**	**Classic Part Number**
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3056	Guard-Duo-Cone	421-7831
134-4200	Manifold-Exhaust	443-2060
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577

8XN		
Original Part Number	**Part Name**	**Classic Part Number**
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
229-1490	Sleeve-Injector	393-3659
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

9BM		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858

9BM		
Original Part Number	**Part Name**	**Classic Part Number**
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410

9BM		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108

Sales Model D6R (Cont'd.)

9BM		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927

9BM		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695

9BM		
Original Part Number	**Part Name**	**Classic Part Number**
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984

Sales Model D6R (Cont'd.)

9BM		
Original Part Number	Part Name	Classic Part Number
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5J-2528	Plunger	391-1318
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024

9BM		
Original Part Number	Part Name	Classic Part Number
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192

9BM		
Original Part Number	Part Name	Classic Part Number
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656

Sales Model D6R (Cont'd.)

9BM		
Original Part Number	**Part Name**	**Classic Part Number**
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207

9BM		
Original Part Number	**Part Name**	**Classic Part Number**
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9427	Bearing-Sleeve	361-1695

9BM		
Original Part Number	**Part Name**	**Classic Part Number**
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932

Sales Model D6R (Cont'd.)

9BM		
Original Part Number	**Part Name**	**Classic Part Number**
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3056	Guard-Duo-Cone	421-7831
134-4200	Manifold-Exhaust	443-2060
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275

9BM		
Original Part Number	**Part Name**	**Classic Part Number**
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574

9BM		
Original Part Number	**Part Name**	**Classic Part Number**
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

9MN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685

9MN		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049

9MN		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689

Sales Model D6R (Cont'd.)

9MN		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203

9MN		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242

9MN		
Original Part Number	**Part Name**	**Classic Part Number**
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-2514	Gear-Flywheel	421-7283
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990

Sales Model D6R (Cont'd.)

9MN		
Original Part Number	**Part Name**	**Classic Part Number**
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436

9MN		
Original Part Number	**Part Name**	**Classic Part Number**
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922

9MN		
Original Part Number	**Part Name**	**Classic Part Number**
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636

Sales Model D6R (Cont'd.)

9MN		
Original Part Number	Part Name	Classic Part Number
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372

9MN		
Original Part Number	Part Name	Classic Part Number
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414

9MN		
Original Part Number	Part Name	Classic Part Number
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3056	Guard-Duo-Cone	421-7831
134-4200	Manifold-Exhaust	443-2060
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686

Sales Model D6R (Cont'd.)

9MN		
Original Part Number	**Part Name**	**Classic Part Number**
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577

9MN		
Original Part Number	**Part Name**	**Classic Part Number**
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
229-1490	Sleeve-Injector	393-3659
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524

9MN		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

9PN		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595

9PN		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0699	Impeller-Conv	235-1808
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006

9PN		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480

Sales Model D6R (Cont'd.)

9PN		
Original Part Number	**Part Name**	**Classic Part Number**
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-3953	Bearing-Sleeve	384-4778
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444

9PN		
Original Part Number	**Part Name**	**Classic Part Number**
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6555	Shaft	295-5703
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986

9PN		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5J-2528	Plunger	391-1318
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

Sales Model D6R (Cont'd.)

9PN		
Original Part Number	**Part Name**	**Classic Part Number**
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450

9PN		
Original Part Number	**Part Name**	**Classic Part Number**
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470

9PN		
Original Part Number	**Part Name**	**Classic Part Number**
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081

Sales Model D6R (Cont'd.)

9PN		
Original Part Number	Part Name	Classic Part Number
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923

9PN		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007

9PN		
Original Part Number	Part Name	Classic Part Number
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3056	Guard-Duo-Cone	421-7831
134-3068	Kit-Gasket(F)	393-3636
134-4200	Manifold-Exhaust	443-2060
140-2246	Gasket Kit	383-3710
140-8435	Flange	451-9015
141-4974	Gasket Kit	388-0658
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
163-4063	Core As-Rdtr	391-9826
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
201-2078	Bar As-Equalizer	418-1946
232-3233	Bearing-Main	376-9085

Sales Model D6R (Cont'd.)

9PN		
Original Part Number	**Part Name**	**Classic Part Number**
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438

9PN		
Original Part Number	**Part Name**	**Classic Part Number**
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

9PN		
Original Part Number	**Part Name**	**Classic Part Number**
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

9ZS		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0699	Impeller-Conv	235-1808
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152

9ZS		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2J-5233	Bearing-Thrust	388-0578

9ZS		
Original Part Number	**Part Name**	**Classic Part Number**
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-6313	Bearing	325-6007

Sales Model D6R (Cont'd.)

9ZS		
Original Part Number	**Part Name**	**Classic Part Number**
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495

9ZS		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783

9ZS		
Original Part Number	**Part Name**	**Classic Part Number**
5J-7981	Pin	256-4784
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487

Sales Model D6R (Cont'd.)

9ZS		
Original Part Number	Part Name	Classic Part Number
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-5692	Plate-Brake	380-7492
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995

9ZS		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

9ZS		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417

Sales Model D6R (Cont'd.)

9ZS		
Original Part Number	**Part Name**	**Classic Part Number**
9J-2759	Trunnion	394-0216
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473

9ZS		
Original Part Number	**Part Name**	**Classic Part Number**
101-5144	Disc-Friction	380-7516
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
134-4200	Manifold-Exhaust	443-2060
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127

9ZS		
Original Part Number	**Part Name**	**Classic Part Number**
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

A6M		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410

A6M		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408

A6M		
Original Part Number	**Part Name**	**Classic Part Number**
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628

Sales Model D6R (Cont'd.)

A6M		
Original Part Number	Part Name	Classic Part Number
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3G-2580	Bearing-Sleeve	422-9526
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283

A6M		
Original Part Number	Part Name	Classic Part Number
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5J-4321	Trunnion	302-2700
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371

A6M		
Original Part Number	Part Name	Classic Part Number
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923

Sales Model D6R (Cont'd.)

A6M		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491

A6M		
Original Part Number	**Part Name**	**Classic Part Number**
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038

A6M		
Original Part Number	**Part Name**	**Classic Part Number**
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

A9M		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480

A9M		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3G-2580	Bearing-Sleeve	422-9526
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283

A9M		
Original Part Number	**Part Name**	**Classic Part Number**
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414

Sales Model D6R (Cont'd.)

A9M		
Original Part Number	Part Name	Classic Part Number
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445

A9M		
Original Part Number	Part Name	Classic Part Number
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675

A9M		
Original Part Number	Part Name	Classic Part Number
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

AAX		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410

AAX		
Original Part Number	Part Name	Classic Part Number
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689

AAX		
Original Part Number	Part Name	Classic Part Number
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-0994	Body As-Preclnr	367-6084
2W-7213	Bearing-Sleeve	419-4667

Sales Model D6R (Cont'd.)

AAX		
Original Part Number	**Part Name**	**Classic Part Number**
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
3W-6555	Shaft	295-5703
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627

AAX		
Original Part Number	**Part Name**	**Classic Part Number**
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5J-2528	Plunger	391-1318
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6F-2904	Bearing	295-5673
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441

AAX		
Original Part Number	**Part Name**	**Classic Part Number**
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214

Sales Model D6R (Cont'd.)

AAX		
Original Part Number	**Part Name**	**Classic Part Number**
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023

AAX		
Original Part Number	**Part Name**	**Classic Part Number**
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681

AAX		
Original Part Number	**Part Name**	**Classic Part Number**
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
163-4063	Core As-Rdtr	391-9826
179-6152	Bearing	361-1704
201-2078	Bar As-Equalizer	418-1946
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
374-1849	Brg-Rlr-Cla	399-4442

ACJ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683

ACJ		
Original Part Number	**Part Name**	**Classic Part Number**
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-8509	Cone-Roller Brg	399-4434
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2W-0994	Body As-Preclnr	367-6084
2W-7213	Bearing-Sleeve	419-4667

ACJ		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-3583	Screw-Adjusting	297-7242

Sales Model D6R (Cont'd.)

ACJ		
Original Part Number	Part Name	Classic Part Number
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-5692	Plate-Brake	380-7492
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361

ACJ		
Original Part Number	Part Name	Classic Part Number
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7P-8370	Bearing	295-6410
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216

ACJ		
Original Part Number	Part Name	Classic Part Number
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
163-4063	Core As-Rdtr	391-9826
179-6152	Bearing	361-1704
201-2078	Bar As-Equalizer	418-1946

Sales Model D6R (Cont'd.)

ACJ		
Original Part Number	**Part Name**	**Classic Part Number**
229-1490	Sleeve-Injector	393-3659

ACJ		
Original Part Number	**Part Name**	**Classic Part Number**
258-2303	Bearing-Sleeve	307-1524

ACJ		
Original Part Number	**Part Name**	**Classic Part Number**
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

ADE		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346

ADE		
Original Part Number	**Part Name**	**Classic Part Number**
2K-9295	Bearing-Cone	422-6480
2W-0994	Body As-Preclnr	367-6084
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6555	Shaft	295-5703
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355

ADE		
Original Part Number	**Part Name**	**Classic Part Number**
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5J-2528	Plunger	391-1318
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414

Sales Model D6R (Cont'd.)

ADE		
Original Part Number	**Part Name**	**Classic Part Number**
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442

ADE		
Original Part Number	**Part Name**	**Classic Part Number**
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031

ADE		
Original Part Number	**Part Name**	**Classic Part Number**
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
163-4063	Core As-Rdtr	391-9826
179-6152	Bearing	361-1704
201-2078	Bar As-Equalizer	418-1946
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
374-1849	Brg-Rlr-Cla	399-4442

AEM		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

AEM		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685

AEM		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326

Sales Model D6R (Cont'd.)

AEM		
Original Part Number	Part Name	Classic Part Number
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-8509	Cone-Roller Brg	399-4434
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2W-0994	Body As-Preclnr	367-6084
2W-7213	Bearing-Sleeve	419-4667
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341

AEM		
Original Part Number	Part Name	Classic Part Number
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6F-2904	Bearing	295-5673
6I-8500	Plate-Clutch	377-7436

AEM		
Original Part Number	Part Name	Classic Part Number
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-3896	Pin As	325-6132
6Y-5692	Plate-Brake	380-7492
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7P-8370	Bearing	295-6410
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366

Sales Model D6R (Cont'd.)

AEM		
Original Part Number	**Part Name**	**Classic Part Number**
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436

AEM		
Original Part Number	**Part Name**	**Classic Part Number**
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583

AEM		
Original Part Number	**Part Name**	**Classic Part Number**
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
163-4063	Core As-Rdtr	391-9826
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
374-1849	Brg-Rlr-Cla	399-4442

AEP		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409

AEP		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628

AEP		
Original Part Number	**Part Name**	**Classic Part Number**
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-0994	Body As-Preclnr	367-6084
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714

Sales Model D6R (Cont'd.)

AEP		
Original Part Number	Part Name	Classic Part Number
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
3W-6555	Shaft	295-5703
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511

AEP		
Original Part Number	Part Name	Classic Part Number
5J-2528	Plunger	391-1318
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6F-2904	Bearing	295-5673
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408

AEP		
Original Part Number	Part Name	Classic Part Number
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218

Sales Model D6R (Cont'd.)

AEP		
Original Part Number	**Part Name**	**Classic Part Number**
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431

AEP		
Original Part Number	**Part Name**	**Classic Part Number**
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045

AEP		
Original Part Number	**Part Name**	**Classic Part Number**
127-8932	Cylinder As	422-4937
140-8435	Flange	451-9015
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
163-4063	Core As-Rdtr	391-9826
179-6152	Bearing	361-1704
201-2078	Bar As-Equalizer	418-1946
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

AFD		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-8509	Cone-Roller Brg	399-4434
2J-8489	Bearing-Sleeve	295-5691
2P-1370	Cup-Rlr Brg	384-5921
2W-0994	Body As-Preclnr	367-6084
2W-7213	Bearing-Sleeve	419-4667
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-4284	Cap-Brg	314-8656
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695

AFD		
Original Part Number	**Part Name**	**Classic Part Number**
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4M-5858	Bearing-Spl Ball	417-4495
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-7089	Pin As-Rmte Lub	397-5042

AFD		
Original Part Number	**Part Name**	**Classic Part Number**
5F-2465	Cup-Roller Brg	447-8060
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-3896	Pin As	325-6132
6Y-5692	Plate-Brake	380-7492
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724

Sales Model D6R (Cont'd.)

AFD		
Original Part Number	Part Name	Classic Part Number
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7P-8370	Bearing	295-6410
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366

AFD		
Original Part Number	Part Name	Classic Part Number
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-5352	Bearing-Ball	453-3658
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-2344	Coupling-Pump Dr	314-8666

AFD		
Original Part Number	Part Name	Classic Part Number
9W-2579	Plate	314-8701
9W-8270	Gear-Ring	308-9859
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
140-8435	Flange	451-9015
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
201-2078	Bar As-Equalizer	418-1946
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

AFM		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410

AFM		
Original Part Number	Part Name	Classic Part Number
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020

AFM		
Original Part Number	Part Name	Classic Part Number
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-0994	Body As-Preclnr	367-6084

Sales Model D6R (Cont'd.)

AFM		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283

AFM		
Original Part Number	Part Name	Classic Part Number
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6F-2904	Bearing	295-5673
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689

AFM		
Original Part Number	Part Name	Classic Part Number
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445

Sales Model D6R (Cont'd.)

AFM		
Original Part Number	Part Name	Classic Part Number
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219

AFM		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033

AFM		
Original Part Number	Part Name	Classic Part Number
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
163-4063	Core As-Rdtr	391-9826
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
374-1849	Brg-Rlr-Cla	399-4442

AGM		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326

AGM		
Original Part Number	Part Name	Classic Part Number
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-8509	Cone-Roller Brg	399-4434
2J-8489	Bearing-Sleeve	295-5691

AGM		
Original Part Number	Part Name	Classic Part Number
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2W-0994	Body As-Preclnr	367-6084
2W-7213	Bearing-Sleeve	419-4667
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209

Sales Model D6R (Cont'd.)

AGM		
Original Part Number	Part Name	Classic Part Number
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-2817	Ejector As	295-6423
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920

AGM		
Original Part Number	Part Name	Classic Part Number
5P-9439	Bearing-Spl Ball	371-4306
6F-2904	Bearing	295-5673
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-5692	Plate-Brake	380-7492
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7P-8370	Bearing	295-6410
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207

AGM		
Original Part Number	Part Name	Classic Part Number
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414

Sales Model D6R (Cont'd.)

AGM		
Original Part Number	Part Name	Classic Part Number
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681

AGM		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896

AGM		
Original Part Number	Part Name	Classic Part Number
163-4063	Core As-Rdtr	391-9826
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

BLE		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707

BLE		
Original Part Number	Part Name	Classic Part Number
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-8509	Cone-Roller Brg	399-4434
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927

BLE		
Original Part Number	Part Name	Classic Part Number
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714

Sales Model D6R (Cont'd.)

BLE		
Original Part Number	**Part Name**	**Classic Part Number**
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-2514	Gear-Flywheel	421-7283
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

BLE		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-7089	Pin As-Rmte Lub	397-5042
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387

BLE		
Original Part Number	**Part Name**	**Classic Part Number**
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-3896	Pin As	325-6132
6Y-5692	Plate-Brake	380-7492
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848

Sales Model D6R (Cont'd.)

BLE		
Original Part Number	**Part Name**	**Classic Part Number**
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196

BLE		
Original Part Number	**Part Name**	**Classic Part Number**
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425

BLE		
Original Part Number	**Part Name**	**Classic Part Number**
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
102-8636	Gear-Drive	472-8035
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045

Sales Model D6R (Cont'd.)

BLE		
Original Part Number	**Part Name**	**Classic Part Number**
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

BLE		
Original Part Number	**Part Name**	**Classic Part Number**
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
229-1490	Sleeve-Injector	393-3659

BLE		
Original Part Number	**Part Name**	**Classic Part Number**
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

BLT		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326

BLT		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

BLT		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197

Sales Model D6R (Cont'd.)

BLT		
Original Part Number	Part Name	Classic Part Number
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370

BLT		
Original Part Number	Part Name	Classic Part Number
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-0432	Bearing-Ball	417-4499
4N-2514	Gear-Flywheel	421-7283
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511

BLT		
Original Part Number	Part Name	Classic Part Number
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149

Sales Model D6R (Cont'd.)

BLT		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996

BLT		
Original Part Number	**Part Name**	**Classic Part Number**
7S-3206	Seal-O-Ring	436-2656
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290

BLT		
Original Part Number	**Part Name**	**Classic Part Number**
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446

Sales Model D6R (Cont'd.)

BLT		
Original Part Number	**Part Name**	**Classic Part Number**
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
108-7754	Housing As.	433-9856

BLT		
Original Part Number	**Part Name**	**Classic Part Number**
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194

BLT		
Original Part Number	**Part Name**	**Classic Part Number**
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
229-1490	Sleeve-Injector	393-3659
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

BMJ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572

BMJ		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326

BMJ		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

Sales Model D6R (Cont'd.)

BMJ		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-8509	Cone-Roller Brg	399-4434
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667

BMJ		
Original Part Number	Part Name	Classic Part Number
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-2514	Gear-Flywheel	421-7283
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

BMJ		
Original Part Number	Part Name	Classic Part Number
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

Sales Model D6R (Cont'd.)

BMJ		
Original Part Number	Part Name	Classic Part Number
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-5692	Plate-Brake	380-7492
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205

BMJ		
Original Part Number	Part Name	Classic Part Number
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113

BMJ		
Original Part Number	Part Name	Classic Part Number
8G-8311	Bearin - Sleeve	295-6412
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438

Sales Model D6R (Cont'd.)

BMJ		
Original Part Number	**Part Name**	**Classic Part Number**
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031

BMJ		
Original Part Number	**Part Name**	**Classic Part Number**
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
102-8636	Gear-Drive	472-8035
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126

BMJ		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
229-1490	Sleeve-Injector	393-3659
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

BMK		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

BMK		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685

BMK		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326

Sales Model D6R (Cont'd.)

BMK		
Original Part Number	Part Name	Classic Part Number
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-8509	Cone-Roller Brg	399-4434
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2W-0994	Body As-Preclnr	367-6084
2W-7213	Bearing-Sleeve	419-4667
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160

BMK		
Original Part Number	Part Name	Classic Part Number
3W-0643	Cylinder	325-6061
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-7089	Pin As-Rmte Lub	397-5042
5J-4321	Trunnion	302-2700
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6F-2904	Bearing	295-5673
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932

BMK		
Original Part Number	Part Name	Classic Part Number
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-3896	Pin As	325-6132
6Y-5692	Plate-Brake	380-7492
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7P-8370	Bearing	295-6410
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442

Sales Model D6R (Cont'd.)

BMK		
Original Part Number	**Part Name**	**Classic Part Number**
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515

BMK		
Original Part Number	**Part Name**	**Classic Part Number**
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-7754	Housing As.	433-9856
112-5585	Shaft-Planet	308-9932

BMK		
Original Part Number	**Part Name**	**Classic Part Number**
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
140-8435	Flange	451-9015
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
374-1849	Brg-Rlr-Cla	399-4442

BMY		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410

BMY		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020

BMY		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927

Sales Model D6R (Cont'd.)

BMY		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699

BMY		
Original Part Number	**Part Name**	**Classic Part Number**
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-0432	Bearing-Ball	417-4499
4N-2514	Gear-Flywheel	421-7283
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052

BMY		
Original Part Number	**Part Name**	**Classic Part Number**
4W-0452	Seal As-Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442

Sales Model D6R (Cont'd.)

BMY		
Original Part Number	Part Name	Classic Part Number
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686

BMY		
Original Part Number	Part Name	Classic Part Number
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210

BMY		
Original Part Number	Part Name	Classic Part Number
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7718	Manifold-Exhaust	295-0416
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425

Sales Model D6R (Cont'd.)

BMY		
Original Part Number	**Part Name**	**Classic Part Number**
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165

BMY		
Original Part Number	**Part Name**	**Classic Part Number**
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
109-6938	Bracket	451-9033
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
134-4200	Manifold-Exhaust	443-2060
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127

BMY		
Original Part Number	**Part Name**	**Classic Part Number**
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
201-2078	Bar As-Equalizer	418-1946
229-1490	Sleeve-Injector	393-3659
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

BNC		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582

BNC		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409

BNC		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408

Sales Model D6R (Cont'd.)

BNC		
Original Part Number	**Part Name**	**Classic Part Number**
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-0994	Body As-Preclnr	367-6084
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-6559	Cap-Bearing	296-1346
3J-9511	Bearing-Sleeve	385-3782
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6555	Shaft	295-5703
3W-7559	Pin As	419-4731
3W-8409	Bearing	398-8336
4F-2041	Cup-Roller Brg	418-9609

BNC		
Original Part Number	**Part Name**	**Classic Part Number**
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5J-2528	Plunger	391-1318
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132

BNC		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-4819	Carrier-Planet	296-1348
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7P-6596	Bearing-Sleeve	295-6409
7P-6984	Pin	393-3674
7P-7245	Valve	386-3811
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8G-0935	Cap	425-3584
8G-4022	Bearing	422-6920
8G-4189	Bearing-Aligning	295-6411

Sales Model D6R (Cont'd.)

BNC		
Original Part Number	**Part Name**	**Classic Part Number**
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8Y-1853	Strip	428-7633
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9086	Bearing-Sleeve	416-5528
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436

BNC		
Original Part Number	**Part Name**	**Classic Part Number**
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437

BNC		
Original Part Number	**Part Name**	**Classic Part Number**
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
140-8435	Flange	451-9015
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
201-2078	Bar As-Equalizer	418-1946
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

BNL		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409

BNL		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628

BNL		
Original Part Number	**Part Name**	**Classic Part Number**
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-0994	Body As-Preclnr	367-6084
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346

Sales Model D6R (Cont'd.)

BNL		
Original Part Number	Part Name	Classic Part Number
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-7089	Pin As-Rmte Lub	397-5042

BNL		
Original Part Number	Part Name	Classic Part Number
5D-2989	Bearing	380-7511
5J-4321	Trunnion	302-2700
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6F-2904	Bearing	295-5673
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408

BNL		
Original Part Number	Part Name	Classic Part Number
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515

Sales Model D6R (Cont'd.)

BNL		
Original Part Number	Part Name	Classic Part Number
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431

BNL		
Original Part Number	Part Name	Classic Part Number
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
134-3056	Guard-Duo-Cone	421-7831

BNL		
Original Part Number	Part Name	Classic Part Number
140-8435	Flange	451-9015
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
374-1849	Brg-Rlr-Cla	399-4442

BPM		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707

BPM		
Original Part Number	Part Name	Classic Part Number
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-0994	Body As-Preclnr	367-6084
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126

BPM		
Original Part Number	Part Name	Classic Part Number
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242

Sales Model D6R (Cont'd.)

BPM		
Original Part Number	Part Name	Classic Part Number
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6F-2904	Bearing	295-5673
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428

BPM		
Original Part Number	Part Name	Classic Part Number
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208

BPM		
Original Part Number	Part Name	Classic Part Number
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583

Sales Model D6R (Cont'd.)

BPM		
Original Part Number	**Part Name**	**Classic Part Number**
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045

BPM		
Original Part Number	**Part Name**	**Classic Part Number**
127-8932	Cylinder As	422-4937
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896

BPM		
Original Part Number	**Part Name**	**Classic Part Number**
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

BPP		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-8509	Cone-Roller Brg	399-4434

BPP		
Original Part Number	**Part Name**	**Classic Part Number**
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2W-0994	Body As-Preclnr	367-6084
2W-7213	Bearing-Sleeve	419-4667
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-4284	Cap-Brg	314-8656
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632

BPP		
Original Part Number	**Part Name**	**Classic Part Number**
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487

Sales Model D6R (Cont'd.)

BPP		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-5692	Plate-Brake	380-7492
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7P-8370	Bearing	295-6410
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411

BPP		
Original Part Number	**Part Name**	**Classic Part Number**
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

BPP		
Original Part Number	**Part Name**	**Classic Part Number**
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-8270	Gear-Ring	308-9859
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
140-8435	Flange	451-9015
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
201-2078	Bar As-Equalizer	418-1946
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

BPS		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582

BPS		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326

BPS		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020

Sales Model D6R (Cont'd.)

BPS		
Original Part Number	Part Name	Classic Part Number
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-8509	Cone-Roller Brg	399-4434
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2W-0994	Body As-Preclnr	367-6084
2W-7213	Bearing-Sleeve	419-4667
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-5999	Bearing-Sleeve	391-9813
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495

BPS		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-7534	Pin	433-9209
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5J-4321	Trunnion	302-2700
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-5692	Plate-Brake	380-7492
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450

BPS		
Original Part Number	Part Name	Classic Part Number
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7P-8370	Bearing	295-6410
7T-2036	Cap As-Fuel	361-1721
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425

Sales Model D6R (Cont'd.)

BPS		
Original Part Number	**Part Name**	**Classic Part Number**
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639

BPS		
Original Part Number	**Part Name**	**Classic Part Number**
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-8270	Gear-Ring	308-9859
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-7754	Housing As.	433-9856
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069

BPS		
Original Part Number	**Part Name**	**Classic Part Number**
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
140-8435	Flange	451-9015
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

BPZ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020

BPZ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-0994	Body As-Preclnr	367-6084
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-4284	Cap-Brg	314-8656
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444

BPZ		
Original Part Number	**Part Name**	**Classic Part Number**
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6555	Shaft	295-5703
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727

Sales Model D6R (Cont'd.)

BPZ		
Original Part Number	Part Name	Classic Part Number
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655

BPZ		
Original Part Number	Part Name	Classic Part Number
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515

BPZ		
Original Part Number	Part Name	Classic Part Number
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
124-3237	Precleaner As	432-4220
127-5537	Core As-Oclr	325-6045
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
201-2078	Bar As-Equalizer	418-1946
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model D6R (Cont'd.)

BRE		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-0994	Body As-Preclnr	367-6084
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-5999	Bearing-Sleeve	391-9813

BRE		
Original Part Number	**Part Name**	**Classic Part Number**
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-7534	Pin	433-9209
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387

BRE		
Original Part Number	**Part Name**	**Classic Part Number**
6J-5179	Retainer	380-7406
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639

Sales Model D6R (Cont'd.)

BRE		
Original Part Number	**Part Name**	**Classic Part Number**
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-5352	Bearing-Ball	453-3658
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436

BRE		
Original Part Number	**Part Name**	**Classic Part Number**
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859

BRE		
Original Part Number	**Part Name**	**Classic Part Number**
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
140-8435	Flange	451-9015
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

BRJ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920

BRJ		
Original Part Number	**Part Name**	**Classic Part Number**
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-8509	Cone-Roller Brg	399-4434
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021

BRJ		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2W-0994	Body As-Preclnr	367-6084
2W-7213	Bearing-Sleeve	419-4667
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-2481	Strip	295-5448

Sales Model D6R (Cont'd.)

BRJ		
Original Part Number	Part Name	Classic Part Number
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-7089	Pin As-Rmte Lub	397-5042
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920

BRJ		
Original Part Number	Part Name	Classic Part Number
5P-9439	Bearing-Spl Ball	371-4306
6F-2904	Bearing	295-5673
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-3896	Pin As	325-6132
6Y-5692	Plate-Brake	380-7492
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7P-8370	Bearing	295-6410
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470

BRJ		
Original Part Number	Part Name	Classic Part Number
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8Y-0978	Plate As	434-1402
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031

Sales Model D6R (Cont'd.)

BRJ		
Original Part Number	**Part Name**	**Classic Part Number**
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-7754	Housing As.	433-9856

BRJ		
Original Part Number	**Part Name**	**Classic Part Number**
109-6938	Bracket	451-9033
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
160-6305	Cap-Bearing	295-5686

BRJ		
Original Part Number	**Part Name**	**Classic Part Number**
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
374-1849	Brg-Rlr-Cla	399-4442

BRZ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690

BRZ		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-0994	Body As-Preclnr	367-6084
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-5999	Bearing-Sleeve	391-9813
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209

BRZ		
Original Part Number	**Part Name**	**Classic Part Number**
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627

Sales Model D6R (Cont'd.)

BRZ		
Original Part Number	Part Name	Classic Part Number
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4T-7534	Pin	433-9209
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6F-2904	Bearing	295-5673
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441

BRZ		
Original Part Number	Part Name	Classic Part Number
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214

BRZ		
Original Part Number	Part Name	Classic Part Number
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
140-8435	Flange	451-9015
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704

Sales Model D6R (Cont'd.)

BRZ		
Original Part Number	**Part Name**	**Classic Part Number**
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524

BRZ		
Original Part Number	**Part Name**	**Classic Part Number**
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
374-1849	Brg-Rlr-Cla	399-4442

C6Z		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3G-2580	Bearing-Sleeve	422-9526

C6Z		
Original Part Number	**Part Name**	**Classic Part Number**
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052

C6Z		
Original Part Number	**Part Name**	**Classic Part Number**
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408

Sales Model D6R (Cont'd.)

C6Z		
Original Part Number	**Part Name**	**Classic Part Number**
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448

C6Z		
Original Part Number	**Part Name**	**Classic Part Number**
8T-1177	Bearing-Rlr	419-1862
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639

C6Z		
Original Part Number	**Part Name**	**Classic Part Number**
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

CAD		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738

CAD		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690

CAD		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-8509	Cone-Roller Brg	399-4434
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2W-0994	Body As-Preclnr	367-6084
2W-7213	Bearing-Sleeve	419-4667
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694

Sales Model D6R (Cont'd.)

CAD		
Original Part Number	Part Name	Classic Part Number
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-5858	Bearing-Spl Ball	417-4495
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

CAD		
Original Part Number	Part Name	Classic Part Number
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6F-2904	Bearing	295-5673
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-5692	Plate-Brake	380-7492
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990

CAD		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7P-8370	Bearing	295-6410
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

Sales Model D6R (Cont'd.)

CAD		
Original Part Number	**Part Name**	**Classic Part Number**
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
002-1212	Cup-Roller Brg	399-4446

CAD		
Original Part Number	**Part Name**	**Classic Part Number**
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
134-3056	Guard-Duo-Cone	421-7831

CAD		
Original Part Number	**Part Name**	**Classic Part Number**
140-8435	Flange	451-9015
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

D6R		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691

D6R		
Original Part Number	**Part Name**	**Classic Part Number**
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3G-2580	Bearing-Sleeve	422-9526
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344

D6R		
Original Part Number	**Part Name**	**Classic Part Number**
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442

Sales Model D6R (Cont'd.)

D6R		
Original Part Number	**Part Name**	**Classic Part Number**
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470

D6R		
Original Part Number	**Part Name**	**Classic Part Number**
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719

D6R		
Original Part Number	**Part Name**	**Classic Part Number**
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

DAE		
Original Part Number	**Part Name**	**Classic Part Number**
140-8435	**Flange**	**451-9015**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582

DAE		
Original Part Number	**Part Name**	**Classic Part Number**
140-8435	**Flange**	**451-9015**
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409

DAE		
Original Part Number	**Part Name**	**Classic Part Number**
140-8435	**Flange**	**451-9015**
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408

Sales Model D6R (Cont'd.)

DAE		
Original Part Number	**Part Name**	**Classic Part Number**
140-8435	**Flange**	**451-9015**
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-0994	Body As-Preclnr	367-6084
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-6559	Cap-Bearing	296-1346
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-3583	Screw-Adjusting	297-7242

DAE		
Original Part Number	**Part Name**	**Classic Part Number**
140-8435	**Flange**	**451-9015**
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361

DAE		
Original Part Number	**Part Name**	**Classic Part Number**
140-8435	**Flange**	**451-9015**
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214

Sales Model D6R (Cont'd.)

DAE		
Original Part Number	**Part Name**	**Classic Part Number**
140-8435	**Flange**	**451-9015**
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

DAE		
Original Part Number	**Part Name**	**Classic Part Number**
140-8435	**Flange**	**451-9015**
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856

DAE		
Original Part Number	**Part Name**	**Classic Part Number**
140-8435	**Flange**	**451-9015**
109-6938	Bracket	451-9033
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
201-2078	Bar As-Equalizer	418-1946
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

DLM		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690

DLM		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444

DLM		
Original Part Number	**Part Name**	**Classic Part Number**
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603

Sales Model D6R (Cont'd.)

DLM		
Original Part Number	**Part Name**	**Classic Part Number**
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275

DLM		
Original Part Number	**Part Name**	**Classic Part Number**
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362

DLM		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
127-5537	Core As-Oclr	325-6045
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

DMK		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443

DMK		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

DMK		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738

Sales Model D6R (Cont'd.)

DMK		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407

DMK		
Original Part Number	**Part Name**	**Classic Part Number**
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721

DMK		
Original Part Number	**Part Name**	**Classic Part Number**
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923

Sales Model D6R (Cont'd.)

DMK		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491

DMK		
Original Part Number	**Part Name**	**Classic Part Number**
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
127-5537	Core As-Oclr	325-6045
160-6305	Cap-Bearing	295-5686

DMK		
Original Part Number	**Part Name**	**Classic Part Number**
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

DMP		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-4110	Disc-Friction	433-9858
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108

DMP		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0902	Bearing-Sleeve	389-6326
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1348	Support As-Carr	419-4049
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513

DMP		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2J-5233	Bearing-Thrust	388-0578
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-4900	Shaft As	384-4792
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055

Sales Model D6R (Cont'd.)

DMP		
Original Part Number	Part Name	Classic Part Number
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-3953	Bearing-Sleeve	384-4778
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3P-4265	Piston-Clutch	397-5063
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1292	Bearing-Sleeve	425-8226
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725

DMP		
Original Part Number	Part Name	Classic Part Number
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990

DMP		
Original Part Number	Part Name	Classic Part Number
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
5D-2989	Bearing	380-7511
5J-2528	Plunger	391-1318
5J-4929	Bearing	256-4796
5J-6430	Bearing-Sleeve	379-0195
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510
5M-5018	Bearing-Roller	380-7509
5M-6126	Bearing	377-7433
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9531	Cone-Rlr Bearing	386-4956
5S-4442	Bearing-Spl Ball	419-6025
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387

Sales Model D6R (Cont'd.)

DMP		
Original Part Number	Part Name	Classic Part Number
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-8458	Bearing-Sleeve	380-7374
7K-5448	Cup-Bearing	415-1922

DMP		
Original Part Number	Part Name	Classic Part Number
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold-Exhaust	261-0899
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342

DMP		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
8M-8652	Shaft	297-7252
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-4520	Piston-Clutch	394-0908
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415

Sales Model D6R (Cont'd.)

DMP		
Original Part Number	Part Name	Classic Part Number
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9427	Bearing-Sleeve	361-1695
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701

DMP		
Original Part Number	Part Name	Classic Part Number
9W-4662	Disc-Friction	428-7203
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-4200	Manifold-Exhaust	443-2060
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275

DMP		
Original Part Number	Part Name	Classic Part Number
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
163-4063	Core As-Rdtr	391-9826
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
179-6152	Bearing	361-1704
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
368-0297	Plate-Clutch	377-7420
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model D6R (Cont'd.)

DPS		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698

DPS		
Original Part Number	Part Name	Classic Part Number
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348

DPS		
Original Part Number	Part Name	Classic Part Number
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931

Sales Model D6R (Cont'd.)

DPS		
Original Part Number	**Part Name**	**Classic Part Number**
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639

DPS		
Original Part Number	**Part Name**	**Classic Part Number**
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069

DPS		
Original Part Number	**Part Name**	**Classic Part Number**
127-5537	Core As-Oclr	325-6045
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

EMM		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021

EMM		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3G-2580	Bearing-Sleeve	422-9526
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702

EMM		
Original Part Number	**Part Name**	**Classic Part Number**
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920

Sales Model D6R (Cont'd.)

EMM		
Original Part Number	**Part Name**	**Classic Part Number**
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207

EMM		
Original Part Number	**Part Name**	**Classic Part Number**
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515

EMM		
Original Part Number	**Part Name**	**Classic Part Number**
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

EXL		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410

EXL		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543

EXL		
Original Part Number	**Part Name**	**Classic Part Number**
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174

Sales Model D6R (Cont'd.)

EXL		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633

EXL		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-7534	Pin	433-9209
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5J-4321	Trunnion	302-2700
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205

EXL		
Original Part Number	Part Name	Classic Part Number
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638

Sales Model D6R (Cont'd.)

EXL		
Original Part Number	**Part Name**	**Classic Part Number**
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-4761	Head	325-6108
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414

EXL		
Original Part Number	**Part Name**	**Classic Part Number**
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
124-3237	Precleaner As	432-4220
160-6305	Cap-Bearing	295-5686

EXL		
Original Part Number	**Part Name**	**Classic Part Number**
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

EXW		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480

EXW		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283

EXW		
Original Part Number	**Part Name**	**Classic Part Number**
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428

Sales Model D6R (Cont'd.)

EXW		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658

EXW		
Original Part Number	**Part Name**	**Classic Part Number**
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675

EXW		
Original Part Number	**Part Name**	**Classic Part Number**
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

FDT		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685

FDT		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707

FDT		
Original Part Number	**Part Name**	**Classic Part Number**
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5066	Cone-Roller Brg	396-4142

Sales Model D6R (Cont'd.)

FDT		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-0994	Body As-Preclnr	367-6084
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5355	Flange	386-3052
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633

FDT		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-7089	Pin As-Rmte Lub	397-5042
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6F-2904	Bearing	295-5673
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-7471	Pin-Pivot	325-6152
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414

FDT		
Original Part Number	**Part Name**	**Classic Part Number**
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213

Sales Model D6R (Cont'd.)

FDT		
Original Part Number	**Part Name**	**Classic Part Number**
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675

FDT		
Original Part Number	**Part Name**	**Classic Part Number**
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
109-6938	Bracket	451-9033
112-5585	Shaft-Planet	308-9932

FDT		
Original Part Number	**Part Name**	**Classic Part Number**
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
374-1849	Brg-Rlr-Cla	399-4442

GJB		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707

GJB		
Original Part Number	**Part Name**	**Classic Part Number**
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714

GJB		
Original Part Number	**Part Name**	**Classic Part Number**
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242

Sales Model D6R (Cont'd.)

GJB		
Original Part Number	Part Name	Classic Part Number
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361

GJB		
Original Part Number	Part Name	Classic Part Number
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417

GJB		
Original Part Number	Part Name	Classic Part Number
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
109-6938	Bracket	451-9033
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
127-5537	Core As-Oclr	325-6045
127-8932	Cylinder As	422-4937
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model D6R (Cont'd.)

GMT		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695

GMT		
Original Part Number	Part Name	Classic Part Number
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920

GMT		
Original Part Number	Part Name	Classic Part Number
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658

Sales Model D6R (Cont'd.)

GMT		
Original Part Number	**Part Name**	**Classic Part Number**
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8Y-0978	Plate As	434-1402
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362

GMT		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490

GMT		
Original Part Number	**Part Name**	**Classic Part Number**
100-8010	Valve	423-5583
109-6938	Bracket	451-9033
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
127-5537	Core As-Oclr	325-6045
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

HCD		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408

HCD		
Original Part Number	**Part Name**	**Classic Part Number**
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465

HCD		
Original Part Number	**Part Name**	**Classic Part Number**
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160

Sales Model D6R (Cont'd.)

HCD		
Original Part Number	Part Name	Classic Part Number
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142

HCD		
Original Part Number	Part Name	Classic Part Number
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8Y-0978	Plate As	434-1402

HCD		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
109-6938	Bracket	451-9033
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
127-5537	Core As-Oclr	325-6045
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659

Sales Model D6R (Cont'd.)

HCD		
Original Part Number	**Part Name**	**Classic Part Number**
258-2303	Bearing-Sleeve	307-1524

HCD		
Original Part Number	**Part Name**	**Classic Part Number**
258-2305	Bearing-Sleeve	325-6029

HCD		
Original Part Number	**Part Name**	**Classic Part Number**
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

HDC		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695

HDC		
Original Part Number	**Part Name**	**Classic Part Number**
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352

HDC		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209

Sales Model D6R (Cont'd.)

HDC		
Original Part Number	**Part Name**	**Classic Part Number**
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018

HDC		
Original Part Number	**Part Name**	**Classic Part Number**
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490

HDC		
Original Part Number	**Part Name**	**Classic Part Number**
100-8010	Valve	423-5583
109-6938	Bracket	451-9033
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
127-5537	Core As-Oclr	325-6045
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

HKE		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690

HKE		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701

HKE		
Original Part Number	**Part Name**	**Classic Part Number**
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306

Sales Model D6R (Cont'd.)

HKE		
Original Part Number	**Part Name**	**Classic Part Number**
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990

HKE		
Original Part Number	**Part Name**	**Classic Part Number**
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018

HKE		
Original Part Number	**Part Name**	**Classic Part Number**
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
127-5537	Core As-Oclr	325-6045
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

JDL		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483

JDL		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543

JDL		
Original Part Number	**Part Name**	**Classic Part Number**
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

Sales Model D6R (Cont'd.)

JDL		
Original Part Number	**Part Name**	**Classic Part Number**
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627

JDL		
Original Part Number	**Part Name**	**Classic Part Number**
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922

JDL		
Original Part Number	**Part Name**	**Classic Part Number**
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701

Sales Model D6R (Cont'd.)

JDL		
Original Part Number	**Part Name**	**Classic Part Number**
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583

JDL		
Original Part Number	**Part Name**	**Classic Part Number**
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
127-5537	Core As-Oclr	325-6045
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704

JDL		
Original Part Number	**Part Name**	**Classic Part Number**
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

JEK		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667

JEK		
Original Part Number	**Part Name**	**Classic Part Number**
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633

JEK		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5J-4321	Trunnion	302-2700
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487

Sales Model D6R (Cont'd.)

JEK		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411

JEK		
Original Part Number	**Part Name**	**Classic Part Number**
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675

JEK		
Original Part Number	**Part Name**	**Classic Part Number**
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

JEN		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326

JEN		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690

JEN		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481

Sales Model D6R (Cont'd.)

JEN		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3G-2580	Bearing-Sleeve	422-9526
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022

JEN		
Original Part Number	**Part Name**	**Classic Part Number**
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658

JEN		
Original Part Number	**Part Name**	**Classic Part Number**
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490

Sales Model D6R (Cont'd.)

JEN		
Original Part Number	**Part Name**	**Classic Part Number**
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686

JEN		
Original Part Number	**Part Name**	**Classic Part Number**
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
258-2303	Bearing-Sleeve	307-1524

JEN		
Original Part Number	**Part Name**	**Classic Part Number**
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

LFM		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481

LFM		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727

LFM		
Original Part Number	**Part Name**	**Classic Part Number**
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205

Sales Model D6R (Cont'd.)

LFM		
Original Part Number	**Part Name**	**Classic Part Number**
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209

LFM		
Original Part Number	**Part Name**	**Classic Part Number**
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031

LFM		
Original Part Number	**Part Name**	**Classic Part Number**
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
127-5537	Core As-Oclr	325-6045
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

LGP		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920

LGP		
Original Part Number	**Part Name**	**Classic Part Number**
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691

LGP		
Original Part Number	**Part Name**	**Classic Part Number**
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-4284	Cap-Brg	314-8656
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695

Sales Model D6R (Cont'd.)

LGP		
Original Part Number	Part Name	Classic Part Number
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444

LGP		
Original Part Number	Part Name	Classic Part Number
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215

LGP		
Original Part Number	Part Name	Classic Part Number
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
124-3237	Precleaner As	432-4220
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model D6R (Cont'd.)

MRT		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695

MRT		
Original Part Number	Part Name	Classic Part Number
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932

MRT		
Original Part Number	Part Name	Classic Part Number
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116

Sales Model D6R (Cont'd.)

MRT		
Original Part Number	**Part Name**	**Classic Part Number**
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219

MRT		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
109-6938	Bracket	451-9033

MRT		
Original Part Number	**Part Name**	**Classic Part Number**
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
127-5537	Core As-Oclr	325-6045
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

MTJ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

MTJ		
Original Part Number	**Part Name**	**Classic Part Number**
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699

MTJ		
Original Part Number	**Part Name**	**Classic Part Number**
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022

Sales Model D6R (Cont'd.)

MTJ		
Original Part Number	**Part Name**	**Classic Part Number**
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371

MTJ		
Original Part Number	**Part Name**	**Classic Part Number**
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362

MTJ		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
127-5537	Core As-Oclr	325-6045
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

PPP		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

PPP		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326

PPP		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408

Sales Model D6R (Cont'd.)

PPP		
Original Part Number	Part Name	Classic Part Number
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3F-6185	Pin	295-5694
3G-2580	Bearing-Sleeve	422-9526
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4N-6302	Belt Set-Vee	314-8495
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727

PPP		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-1817	Cup-Roller Brg	434-3296

PPP		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

Sales Model D6R (Cont'd.)

RFC		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698

RFC		
Original Part Number	Part Name	Classic Part Number
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428

RFC		
Original Part Number	Part Name	Classic Part Number
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216

Sales Model D6R (Cont'd.)

RFC		
Original Part Number	**Part Name**	**Classic Part Number**
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

RFC		
Original Part Number	**Part Name**	**Classic Part Number**
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932

RFC		
Original Part Number	**Part Name**	**Classic Part Number**
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
127-5537	Core As-Oclr	325-6045
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

S6T		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628

S6T		
Original Part Number	**Part Name**	**Classic Part Number**
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3G-2580	Bearing-Sleeve	422-9526
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699

S6T		
Original Part Number	**Part Name**	**Classic Part Number**
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5J-4321	Trunnion	302-2700
5M-0578	Bearing	419-7775

Sales Model D6R (Cont'd.)

S6T		
Original Part Number	**Part Name**	**Classic Part Number**
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816

S6T		
Original Part Number	**Part Name**	**Classic Part Number**
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018

S6T		
Original Part Number	**Part Name**	**Classic Part Number**
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

S6X		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

S6X		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409

S6X		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683

Sales Model D6R (Cont'd.)

S6X		
Original Part Number	**Part Name**	**Classic Part Number**
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3G-2580	Bearing-Sleeve	422-9526
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704

S6X		
Original Part Number	**Part Name**	**Classic Part Number**
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361

S6X		
Original Part Number	**Part Name**	**Classic Part Number**
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425

Sales Model D6R (Cont'd.)

S6X		
Original Part Number	**Part Name**	**Classic Part Number**
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639

S6X		
Original Part Number	**Part Name**	**Classic Part Number**
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069

S6X		
Original Part Number	**Part Name**	**Classic Part Number**
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

S6Y		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

S6Y		
Original Part Number	**Part Name**	**Classic Part Number**
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3G-2580	Bearing-Sleeve	422-9526
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700

S6Y		
Original Part Number	**Part Name**	**Classic Part Number**
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4D-4065	Rod End-Spher	374-1824
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920

Sales Model D6R (Cont'd.)

S6Y		
Original Part Number	**Part Name**	**Classic Part Number**
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354

S6Y		
Original Part Number	**Part Name**	**Classic Part Number**
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515

S6Y		
Original Part Number	**Part Name**	**Classic Part Number**
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

SSS		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738

SSS		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543

SSS		
Original Part Number	**Part Name**	**Classic Part Number**
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628

Sales Model D6R (Cont'd.)

SSS		
Original Part Number	Part Name	Classic Part Number
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3F-6185	Pin	295-5694
3G-2580	Bearing-Sleeve	422-9526
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4N-6302	Belt Set-Vee	314-8495
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627

SSS		
Original Part Number	Part Name	Classic Part Number
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-1817	Cup-Roller Brg	434-3296

SSS		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9U-8481	Pin As.	295-5675
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

Sales Model D6R (Cont'd.)

TBC		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695

TBC		
Original Part Number	**Part Name**	**Classic Part Number**
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658

TBC		
Original Part Number	**Part Name**	**Classic Part Number**
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209

Sales Model D6R (Cont'd.)

TBC		
Original Part Number	**Part Name**	**Classic Part Number**
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8521	Gear-Ring	296-1353

TBC		
Original Part Number	**Part Name**	**Classic Part Number**
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583

TBC		
Original Part Number	**Part Name**	**Classic Part Number**
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
127-5537	Core As-Oclr	325-6045
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

TTT		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
2A-4429	Lock-Retainer	379-0174

TTT		
Original Part Number	**Part Name**	**Classic Part Number**
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3F-6185	Pin	295-5694
3G-2580	Bearing-Sleeve	422-9526
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698

TTT		
Original Part Number	**Part Name**	**Classic Part Number**
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4N-6302	Belt Set-Vee	314-8495
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727

Sales Model D6R (Cont'd.)

TTT		
Original Part Number	**Part Name**	**Classic Part Number**
4T-5495	Ballstud	314-8626
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205

TTT		
Original Part Number	**Part Name**	**Classic Part Number**
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9M-1328	Bearing-Aligning	325-6018

TTT		
Original Part Number	**Part Name**	**Classic Part Number**
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

WCB		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738

WCB		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689

WCB		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481

Sales Model D6R (Cont'd.)

WCB		
Original Part Number	**Part Name**	**Classic Part Number**
3E-4880	Coupling As	417-9465
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352

WCB		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356

WCB		
Original Part Number	**Part Name**	**Classic Part Number**
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
127-5537	Core As-Oclr	325-6045
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model D6R (Cont'd.)

WRG		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695

WRG		
Original Part Number	Part Name	Classic Part Number
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932

WRG		
Original Part Number	Part Name	Classic Part Number
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116

Sales Model D6R (Cont'd.)

WRG		
Original Part Number	**Part Name**	**Classic Part Number**
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719

WRG		
Original Part Number	**Part Name**	**Classic Part Number**
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490

WRG		
Original Part Number	**Part Name**	**Classic Part Number**
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
127-5537	Core As-Oclr	325-6045
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model D6T

B72		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0334	Bearing-Ball	380-1476
1U-0873	Pin	325-6137
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921
3B-4124	Cup-Spl Tapered	422-6481
3G-2580	Bearing-Sleeve	422-9526
3K-0526	Bearing-Ball	386-4949
3K-2511	Dowel-Reaction	383-2126
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699

B72		
Original Part Number	**Part Name**	**Classic Part Number**
3T-5200	Carrier-Planet	295-5701
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3128	Bearing-Sleeve	314-8633
4T-1504	Trunnion	314-8727
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6I-8500	Plate-Clutch	377-7436
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
7C-3567	Mount As	314-8689

B72		
Original Part Number	**Part Name**	**Classic Part Number**
7F-9547	Pin As.-Drawbar	295-0414
7G-0437	Plate-Clutch	417-9466
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-5131	Trunnion	296-1371
7S-3002	Bearing-Spl Ball	386-4961
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490

Sales Model D6T (Cont'd.)

B72		
Original Part Number	**Part Name**	**Classic Part Number**
161-3411	Gasket	394-0896

B72		
Original Part Number	**Part Name**	**Classic Part Number**
258-2303	Bearing-Sleeve	307-1524

B72		
Original Part Number	**Part Name**	**Classic Part Number**
258-2305	Bearing-Sleeve	325-6029

CG8		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3G-2580	Bearing-Sleeve	422-9526
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712

CG8		
Original Part Number	**Part Name**	**Classic Part Number**
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428

CG8		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362

Sales Model D6T (Cont'd.)

CG8		
Original Part Number	Part Name	Classic Part Number
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031

CG8		
Original Part Number	Part Name	Classic Part Number
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490

CG8		
Original Part Number	Part Name	Classic Part Number
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

CR3		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3G-2580	Bearing-Sleeve	422-9526
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695

CR3		
Original Part Number	Part Name	Classic Part Number
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442

CR3		
Original Part Number	Part Name	Classic Part Number
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411

Sales Model D6T (Cont'd.)

CR3		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018

CR3		
Original Part Number	Part Name	Classic Part Number
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554

CR3		
Original Part Number	Part Name	Classic Part Number
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
160-0305	Bearing-Aligning	396-9945
161-3411	Gasket	394-0896
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

D5M		
Original Part Number	Part Name	Classic Part Number
1T-0334	Bearing-Ball	380-1476
1W-4738	Bearing-Sleeve	325-6020
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3G-2580	Bearing-Sleeve	422-9526
3K-0526	Bearing-Ball	386-4949
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699

D5M		
Original Part Number	Part Name	Classic Part Number
3T-5200	Carrier-Planet	295-5701
4K-3128	Bearing-Sleeve	314-8633
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
6T-0064	Shaft-Planet	295-6442
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
7C-3567	Mount As	314-8689
7F-9547	Pin As.-Drawbar	295-0414
7H-4566	Cup-Roller Brg	399-6068

D5M		
Original Part Number	Part Name	Classic Part Number
7S-3002	Bearing-Spl Ball	386-4961
7T-8136	Shaft-Planet	314-8714
8D-0983	Mounting	384-3470
8G-4189	Bearing-Aligning	295-6411
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
160-0305	Bearing-Aligning	396-9945
161-3411	Gasket	394-0896

DJG		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410

DJG		
Original Part Number	Part Name	Classic Part Number
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-4738	Bearing-Sleeve	325-6020

DJG		
Original Part Number	Part Name	Classic Part Number
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480

Sales Model D6T (Cont'd.)

DJG		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658

DJG		
Original Part Number	Part Name	Classic Part Number
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212

DJG		
Original Part Number	Part Name	Classic Part Number
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model D6T (Cont'd.)

DTD		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632

DTD		
Original Part Number	Part Name	Classic Part Number
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7S-4411	Cap As-Rain	373-1912
7T-8136	Shaft-Planet	314-8714

DTD		
Original Part Number	Part Name	Classic Part Number
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681

Sales Model D6T (Cont'd.)

DTD		
Original Part Number	Part Name	Classic Part Number
161-3411	Gasket	394-0896
258-2303	Bearing-Sleeve	307-1524

DTD		
Original Part Number	Part Name	Classic Part Number
258-2305	Bearing-Sleeve	325-6029

DTD		
Original Part Number	Part Name	Classic Part Number
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

EJJ		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698

EJJ		
Original Part Number	Part Name	Classic Part Number
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427

EJJ		
Original Part Number	Part Name	Classic Part Number
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214

Sales Model D6T (Cont'd.)

EJJ		
Original Part Number	**Part Name**	**Classic Part Number**
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923

EJJ		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716

EJJ		
Original Part Number	**Part Name**	**Classic Part Number**
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

ES9		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0334	Bearing-Ball	380-1476
1U-0873	Pin	325-6137
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921
3B-4124	Cup-Spl Tapered	422-6481
3G-2580	Bearing-Sleeve	422-9526
3K-0526	Bearing-Ball	386-4949
3K-2511	Dowel-Reaction	383-2126
3T-1162	Sleeve-Wear	325-6209
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160

ES9		
Original Part Number	**Part Name**	**Classic Part Number**
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3128	Bearing-Sleeve	314-8633
4T-1504	Trunnion	314-8727
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6I-8500	Plate-Clutch	377-7436
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
7C-3567	Mount As	314-8689
7F-9547	Pin As.-Drawbar	295-0414
7G-0437	Plate-Clutch	417-9466
7H-4566	Cup-Roller Brg	399-6068

ES9		
Original Part Number	**Part Name**	**Classic Part Number**
7H-7628	Bearing	453-3655
7J-5131	Trunnion	296-1371
7S-3002	Bearing-Spl Ball	386-4961
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
161-3411	Gasket	394-0896
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

Sales Model D6T (Cont'd.)

GCT		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3G-2580	Bearing-Sleeve	422-9526
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524

GCT		
Original Part Number	Part Name	Classic Part Number
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932

GCT		
Original Part Number	Part Name	Classic Part Number
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212

Sales Model D6T (Cont'd.)

GCT		
Original Part Number	Part Name	Classic Part Number
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219

GCT		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583

GCT		
Original Part Number	Part Name	Classic Part Number
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

GMK		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691

GMK		
Original Part Number	Part Name	Classic Part Number
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609

GMK		
Original Part Number	Part Name	Classic Part Number
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306

Sales Model D6T (Cont'd.)

GMK		
Original Part Number	Part Name	Classic Part Number
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410

GMK		
Original Part Number	Part Name	Classic Part Number
7S-4411	Cap As-Rain	373-1912
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719

GMK		
Original Part Number	Part Name	Classic Part Number
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

HMH		
Original Part Number	Part Name	Classic Part Number
1T-0334	Bearing-Ball	380-1476
1W-4738	Bearing-Sleeve	325-6020
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3G-2580	Bearing-Sleeve	422-9526

HMH		
Original Part Number	Part Name	Classic Part Number
3K-0526	Bearing-Ball	386-4949
3T-1162	Sleeve-Wear	325-6209
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4K-3128	Bearing-Sleeve	314-8633
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
6T-0064	Shaft-Planet	295-6442

HMH		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
7C-3567	Mount As	314-8689
7F-9547	Pin As.-Drawbar	295-0414
7H-4566	Cup-Roller Brg	399-6068
7S-3002	Bearing-Spl Ball	386-4961
7T-8136	Shaft-Planet	314-8714
8D-0983	Mounting	384-3470

Sales Model D6T (Cont'd.)

HMH		
Original Part Number	**Part Name**	**Classic Part Number**
8G-4189	Bearing-Aligning	295-6411
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9S-3581	Cup-Roller Brg	415-1923

HMH		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3582	Cone-Roller Brg	396-4144
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490

HMH		
Original Part Number	**Part Name**	**Classic Part Number**
160-0305	Bearing-Aligning	396-9945
161-3411	Gasket	394-0896

HNK		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1U-0873	Pin	325-6137
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921
3B-4124	Cup-Spl Tapered	422-6481
3G-2580	Bearing-Sleeve	422-9526
3K-2511	Dowel-Reaction	383-2126
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5200	Carrier-Planet	295-5701
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725

HNK		
Original Part Number	**Part Name**	**Classic Part Number**
4J-6374	Bearing-Sleeve	295-6407
4K-3128	Bearing-Sleeve	314-8633
4T-1504	Trunnion	314-8727
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6I-8500	Plate-Clutch	377-7436
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
7C-3567	Mount As	314-8689
7F-9547	Pin As.-Drawbar	295-0414
7G-0437	Plate-Clutch	417-9466
7H-4566	Cup-Roller Brg	399-6068

HNK		
Original Part Number	**Part Name**	**Classic Part Number**
7H-7628	Bearing	453-3655
7J-5131	Trunnion	296-1371
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
161-3411	Gasket	394-0896
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

HTZ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409

HTZ		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689

HTZ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465

Sales Model D6T (Cont'd.)

HTZ		
Original Part Number	Part Name	Classic Part Number
3G-2580	Bearing-Sleeve	422-9526
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917

HTZ		
Original Part Number	Part Name	Classic Part Number
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411

HTZ		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

HYT		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437

Sales Model D6T (Cont'd.)

HYT		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-1078	Bearing-Thrust	384-4802
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3H-1996	Bearing-Ball	380-1498
3K-2511	Dowel-Reaction	383-2126
3T-1162	Sleeve-Wear	325-6209
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700

HYT		
Original Part Number	Part Name	Classic Part Number
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6N-8441	Bearing-Sleeve	380-7371
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
7C-3567	Mount As	314-8689
7G-0437	Plate-Clutch	417-9466
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7M-1296	Valve-Relief	390-0990

HYT		
Original Part Number	Part Name	Classic Part Number
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9Y-2991	Bearing-Sleeve	377-5833
005-4834	Cone-Rlr Bearing	422-6490
265-5287	Ring-Seal	472-8028

HZL		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0334	Bearing-Ball	380-1476
1U-0873	Pin	325-6137
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921
3B-4124	Cup-Spl Tapered	422-6481
3G-2580	Bearing-Sleeve	422-9526

HZL		
Original Part Number	Part Name	Classic Part Number
3K-0526	Bearing-Ball	386-4949
3K-2511	Dowel-Reaction	383-2126
3T-1162	Sleeve-Wear	325-6209
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3128	Bearing-Sleeve	314-8633
4T-1504	Trunnion	314-8727
5M-0578	Bearing	419-7775

HZL		
Original Part Number	Part Name	Classic Part Number
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6I-8500	Plate-Clutch	377-7436
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
7C-3567	Mount As	314-8689
7F-9547	Pin As.-Drawbar	295-0414
7G-0437	Plate-Clutch	417-9466

Sales Model D6T (Cont'd.)

HZL		
Original Part Number	Part Name	Classic Part Number
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-5131	Trunnion	296-1371
7S-3002	Bearing-Spl Ball	386-4961
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
8D-1817	Cup-Roller Brg	434-3296

HZL		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9S-3581	Cup-Roller Brg	415-1923

HZL		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
161-3411	Gasket	394-0896
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

JHB		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481

JHB		
Original Part Number	Part Name	Classic Part Number
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632

JHB		
Original Part Number	Part Name	Classic Part Number
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142

Sales Model D6T (Cont'd.)

JHB		
Original Part Number	Part Name	Classic Part Number
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296

JHB		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8Y-0978	Plate As	434-1402
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

JHB		
Original Part Number	Part Name	Classic Part Number
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
109-6938	Bracket	451-9033
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

JML		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464

JML		
Original Part Number	Part Name	Classic Part Number
1T-1078	Bearing-Thrust	384-4802
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465

JML		
Original Part Number	Part Name	Classic Part Number
3H-1996	Bearing-Ball	380-1498
3K-2511	Dowel-Reaction	383-2126
3T-1162	Sleeve-Wear	325-6209
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
5M-0578	Bearing	419-7775

Sales Model D6T (Cont'd.)

JML		
Original Part Number	Part Name	Classic Part Number
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6N-8441	Bearing-Sleeve	380-7371
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427

JML		
Original Part Number	Part Name	Classic Part Number
6Y-0984	Gear-Ring	295-6428
7C-3567	Mount As	314-8689
7G-0437	Plate-Clutch	417-9466
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7M-1296	Valve-Relief	390-0990
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8T-0072	Cone-Rlr Brg	377-7448

JML		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9Y-2991	Bearing-Sleeve	377-5833
005-4834	Cone-Rlr Bearing	422-6490
265-5287	Ring-Seal	472-8028

JNM		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-1078	Bearing-Thrust	384-4802
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3H-1996	Bearing-Ball	380-1498
3K-2511	Dowel-Reaction	383-2126
3T-1162	Sleeve-Wear	325-6209
3T-4568	Shaft-Planet	314-8712

JNM		
Original Part Number	Part Name	Classic Part Number
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6N-8441	Bearing-Sleeve	380-7371
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
7C-3567	Mount As	314-8689
7G-0437	Plate-Clutch	417-9466
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655

JNM		
Original Part Number	Part Name	Classic Part Number
7M-1296	Valve-Relief	390-0990
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9Y-2991	Bearing-Sleeve	377-5833
005-4834	Cone-Rlr Bearing	422-6490
265-5287	Ring-Seal	472-8028

Sales Model D6T (Cont'd.)

JRW		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-2041	Cup-Roller Brg	418-9609

JRW		
Original Part Number	Part Name	Classic Part Number
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275

JRW		
Original Part Number	Part Name	Classic Part Number
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701

Sales Model D6T (Cont'd.)

JRW		
Original Part Number	Part Name	Classic Part Number
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490

JRW		
Original Part Number	Part Name	Classic Part Number
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
258-2303	Bearing-Sleeve	307-1524

JRW		
Original Part Number	Part Name	Classic Part Number
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

JWD		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695

JWD		
Original Part Number	Part Name	Classic Part Number
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306

JWD		
Original Part Number	Part Name	Classic Part Number
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410

Sales Model D6T (Cont'd.)

JWD		
Original Part Number	Part Name	Classic Part Number
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216

JWD		
Original Part Number	Part Name	Classic Part Number
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-7481	Gear-Planet	295-6431

JWD		
Original Part Number	Part Name	Classic Part Number
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

JZC		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689

JZC		
Original Part Number	Part Name	Classic Part Number
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701

JZC		
Original Part Number	Part Name	Classic Part Number
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920

Sales Model D6T (Cont'd.)

JZC		
Original Part Number	Part Name	Classic Part Number
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922

JZC		
Original Part Number	Part Name	Classic Part Number
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018

JZC		
Original Part Number	Part Name	Classic Part Number
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

KEW		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1U-0873	Pin	325-6137
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480

KEW		
Original Part Number	Part Name	Classic Part Number
2P-1370	Cup-Rlr Brg	384-5921
3B-4124	Cup-Spl Tapered	422-6481
3G-2580	Bearing-Sleeve	422-9526
3K-2511	Dowel-Reaction	383-2126
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5200	Carrier-Planet	295-5701
4J-0121	Cap-Bearing	360-2344

KEW		
Original Part Number	Part Name	Classic Part Number
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3128	Bearing-Sleeve	314-8633
4T-1504	Trunnion	314-8727
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6I-8500	Plate-Clutch	377-7436

Sales Model D6T (Cont'd.)

KEW		
Original Part Number	Part Name	Classic Part Number
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
7C-3567	Mount As	314-8689
7F-9547	Pin As.-Drawbar	295-0414
7G-0437	Plate-Clutch	417-9466

KEW		
Original Part Number	Part Name	Classic Part Number
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-5131	Trunnion	296-1371
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801

KEW		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
161-3411	Gasket	394-0896
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

KJL		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346

KJL		
Original Part Number	Part Name	Classic Part Number
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407

KJL		
Original Part Number	Part Name	Classic Part Number
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442

Sales Model D6T (Cont'd.)

KJL		
Original Part Number	Part Name	Classic Part Number
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354

KJL		
Original Part Number	Part Name	Classic Part Number
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923

KJL		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

KMR		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409

KMR		
Original Part Number	Part Name	Classic Part Number
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689

KMR		
Original Part Number	Part Name	Classic Part Number
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481

Sales Model D6T (Cont'd.)

KMR		
Original Part Number	Part Name	Classic Part Number
3E-4880	Coupling As	417-9465
3G-2580	Bearing-Sleeve	422-9526
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917

KMR		
Original Part Number	Part Name	Classic Part Number
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296

KMT		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535

KMR		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

Sales Model D6T (Cont'd.)

KMT		
Original Part Number	Part Name	Classic Part Number
1P-3935	Cone-Roller Brg	377-7397
1U-0873	Pin	325-6137
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921
3B-4124	Cup-Spl Tapered	422-6481
3G-2580	Bearing-Sleeve	422-9526
3K-2511	Dowel-Reaction	383-2126
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5200	Carrier-Planet	295-5701
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725

KMT		
Original Part Number	Part Name	Classic Part Number
4J-6374	Bearing-Sleeve	295-6407
4K-3128	Bearing-Sleeve	314-8633
4T-1504	Trunnion	314-8727
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6I-8500	Plate-Clutch	377-7436
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
7C-3567	Mount As	314-8689
7F-9547	Pin As.-Drawbar	295-0414
7G-0437	Plate-Clutch	417-9466

KMT		
Original Part Number	Part Name	Classic Part Number
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-5131	Trunnion	296-1371
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
161-3411	Gasket	394-0896
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

KSB		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689

KSB		
Original Part Number	Part Name	Classic Part Number
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701

KSB		
Original Part Number	Part Name	Classic Part Number
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658

Sales Model D6T (Cont'd.)

KSB		
Original Part Number	Part Name	Classic Part Number
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816

KSB		
Original Part Number	Part Name	Classic Part Number
7P-8370	Bearing	295-6410
7S-4411	Cap As-Rain	373-1912
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018

KSB		
Original Part Number	Part Name	Classic Part Number
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
161-3411	Gasket	394-0896
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

KTW		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1W-4738	Bearing-Sleeve	325-6020
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921
3B-4124	Cup-Spl Tapered	422-6481
3G-2580	Bearing-Sleeve	422-9526

KTW		
Original Part Number	Part Name	Classic Part Number
3K-2511	Dowel-Reaction	383-2126
3T-1162	Sleeve-Wear	325-6209
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4K-3128	Bearing-Sleeve	314-8633
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6I-8500	Plate-Clutch	377-7436

KTW		
Original Part Number	Part Name	Classic Part Number
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
7C-3567	Mount As	314-8689
7F-9547	Pin As.-Drawbar	295-0414
7G-0437	Plate-Clutch	417-9466
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655

Sales Model D6T (Cont'd.)

KTW		
Original Part Number	Part Name	Classic Part Number
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411

KTW		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

KTW		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
160-0305	Bearing-Aligning	396-9945
161-3411	Gasket	394-0896

LAE		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481

LAE		
Original Part Number	Part Name	Classic Part Number
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355

LAE		
Original Part Number	Part Name	Classic Part Number
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361

Sales Model D6T (Cont'd.)

LAE		
Original Part Number	Part Name	Classic Part Number
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208

LAE		
Original Part Number	Part Name	Classic Part Number
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639

LAE		
Original Part Number	Part Name	Classic Part Number
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

LAY		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683

LAY		
Original Part Number	Part Name	Classic Part Number
1T-2069	Carrier-Bearing	439-4543
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021

LAY		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3G-2580	Bearing-Sleeve	422-9526
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126

Sales Model D6T (Cont'd.)

LAY		
Original Part Number	Part Name	Classic Part Number
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387

LAY		
Original Part Number	Part Name	Classic Part Number
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209

LAY		
Original Part Number	Part Name	Classic Part Number
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704

Sales Model D6T (Cont'd.)

LAY		
Original Part Number	Part Name	Classic Part Number
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524

LAY		
Original Part Number	Part Name	Classic Part Number
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966

LAY		
Original Part Number	Part Name	Classic Part Number
328-4375	Disc-Friction	443-1922

LBD		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524

LBD		
Original Part Number	Part Name	Classic Part Number
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387

LBD		
Original Part Number	Part Name	Classic Part Number
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411

Sales Model D6T (Cont'd.)

LBD		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417

LBD		
Original Part Number	Part Name	Classic Part Number
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859

LBD		
Original Part Number	Part Name	Classic Part Number
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

LKJ		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690

LKJ		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444

LKJ		
Original Part Number	Part Name	Classic Part Number
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603

Sales Model D6T (Cont'd.)

LKJ		
Original Part Number	Part Name	Classic Part Number
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655

LKJ		
Original Part Number	Part Name	Classic Part Number
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018

LKJ		
Original Part Number	Part Name	Classic Part Number
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

LNC		
Original Part Number	Part Name	Classic Part Number
1T-0334	Bearing-Ball	380-1476
1W-4738	Bearing-Sleeve	325-6020
2K-4507	Bearing-Sleeve	325-6021

LNC		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921

LNC		
Original Part Number	Part Name	Classic Part Number
3B-4124	Cup-Spl Tapered	422-6481
3G-2580	Bearing-Sleeve	422-9526

Sales Model D6T (Cont'd.)

LNC		
Original Part Number	Part Name	Classic Part Number
3K-0526	Bearing-Ball	386-4949
3T-1162	Sleeve-Wear	325-6209
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4J-1641	Trunnion	314-8725
4K-3128	Bearing-Sleeve	314-8633
4T-1504	Trunnion	314-8727
5M-0578	Bearing	419-7775
5M-7925	Bearing-Roller	419-7774
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444

LNC		
Original Part Number	Part Name	Classic Part Number
6V-0328	Cone-Rlr Brg	399-4442
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
7C-3567	Mount As	314-8689
7F-9547	Pin As.-Drawbar	295-0414
7H-4566	Cup-Roller Brg	399-6068
7J-5131	Trunnion	296-1371
7S-3002	Bearing-Spl Ball	386-4961
7T-8136	Shaft-Planet	314-8714
8D-0983	Mounting	384-3470
8G-4189	Bearing-Aligning	295-6411

LNC		
Original Part Number	Part Name	Classic Part Number
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
160-0305	Bearing-Aligning	396-9945
161-3411	Gasket	394-0896

MB5		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-1078	Bearing-Thrust	384-4802
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3H-1996	Bearing-Ball	380-1498
3K-2511	Dowel-Reaction	383-2126
3T-1162	Sleeve-Wear	325-6209
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699

MB5		
Original Part Number	Part Name	Classic Part Number
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6N-8441	Bearing-Sleeve	380-7371
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
7C-3567	Mount As	314-8689
7G-0437	Plate-Clutch	417-9466
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408

MB5		
Original Part Number	Part Name	Classic Part Number
7M-1296	Valve-Relief	390-0990
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9Y-2991	Bearing-Sleeve	377-5833
005-4834	Cone-Rlr Bearing	422-6490
265-5287	Ring-Seal	472-8028

Sales Model D6T (Cont'd.)

MEL		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3G-2580	Bearing-Sleeve	422-9526
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-2041	Cup-Roller Brg	418-9609

MEL		
Original Part Number	Part Name	Classic Part Number
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655

MEL		
Original Part Number	Part Name	Classic Part Number
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554

Sales Model D6T (Cont'd.)

MEL		
Original Part Number	Part Name	Classic Part Number
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583

MEL		
Original Part Number	Part Name	Classic Part Number
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704

MEL		
Original Part Number	Part Name	Classic Part Number
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

MH7		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-1078	Bearing-Thrust	384-4802
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3H-1996	Bearing-Ball	380-1498
3K-2511	Dowel-Reaction	383-2126
3T-1162	Sleeve-Wear	325-6209
3T-4568	Shaft-Planet	314-8712

MH7		
Original Part Number	Part Name	Classic Part Number
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6N-8441	Bearing-Sleeve	380-7371
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
7C-3567	Mount As	314-8689
7G-0437	Plate-Clutch	417-9466
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655

MH7		
Original Part Number	Part Name	Classic Part Number
7M-1296	Valve-Relief	390-0990
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9Y-2991	Bearing-Sleeve	377-5833
005-4834	Cone-Rlr Bearing	422-6490
265-5287	Ring-Seal	472-8028

NDY		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0655	Bearing-Thrust	377-7409

NDY		
Original Part Number	Part Name	Classic Part Number
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-1078	Bearing-Thrust	384-4802
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924

NDY		
Original Part Number	Part Name	Classic Part Number
1T-1282	Race-Brg Thrust	373-1755
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465

Sales Model D6T (Cont'd.)

NDY		
Original Part Number	Part Name	Classic Part Number
3H-1996	Bearing-Ball	380-1498
3K-2511	Dowel-Reaction	383-2126
3T-1162	Sleeve-Wear	325-6209
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6N-8441	Bearing-Sleeve	380-7371
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442

NDY		
Original Part Number	Part Name	Classic Part Number
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
7C-3567	Mount As	314-8689
7G-0437	Plate-Clutch	417-9466
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7M-1296	Valve-Relief	390-0990
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411

NDY		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9Y-2991	Bearing-Sleeve	377-5833
005-4834	Cone-Rlr Bearing	422-6490
265-5287	Ring-Seal	472-8028

PEZ		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690

PEZ		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695

PEZ		
Original Part Number	Part Name	Classic Part Number
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632

Sales Model D6T (Cont'd.)

PEZ		
Original Part Number	Part Name	Classic Part Number
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414

PEZ		
Original Part Number	Part Name	Classic Part Number
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425

PLR		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437

PEZ		
Original Part Number	Part Name	Classic Part Number
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model D6T (Cont'd.)

PLR		
Original Part Number	Part Name	Classic Part Number
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4N-2514	Gear-Flywheel	421-7283
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774

PLR		
Original Part Number	Part Name	Classic Part Number
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411

PLR		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
161-3411	Gasket	394-0896
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model D6T (Cont'd.)

RAD		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3G-2580	Bearing-Sleeve	422-9526
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632

RAD		
Original Part Number	Part Name	Classic Part Number
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491

RAD		
Original Part Number	Part Name	Classic Part Number
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
160-0305	Bearing-Aligning	396-9945
161-3411	Gasket	394-0896
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

Sales Model D6T (Cont'd.)

RBP		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1W-4738	Bearing-Sleeve	325-6020
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3G-2580	Bearing-Sleeve	422-9526
3K-2511	Dowel-Reaction	383-2126
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5200	Carrier-Planet	295-5701

RBP		
Original Part Number	Part Name	Classic Part Number
4K-3128	Bearing-Sleeve	314-8633
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6I-8500	Plate-Clutch	377-7436
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
7C-3567	Mount As	314-8689
7F-9547	Pin As.-Drawbar	295-0414
7G-0437	Plate-Clutch	417-9466
7H-4566	Cup-Roller Brg	399-6068

RBP		
Original Part Number	Part Name	Classic Part Number
7H-7628	Bearing	453-3655
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
160-0305	Bearing-Aligning	396-9945
161-3411	Gasket	394-0896

RCW		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346

RCW		
Original Part Number	Part Name	Classic Part Number
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
5D-2989	Bearing	380-7511

RCW		
Original Part Number	Part Name	Classic Part Number
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361

Sales Model D6T (Cont'd.)

RCW		
Original Part Number	Part Name	Classic Part Number
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7S-4411	Cap As-Rain	373-1912
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411

RCW		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

RCW		
Original Part Number	Part Name	Classic Part Number
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
161-3411	Gasket	394-0896
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

RDC		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1W-4738	Bearing-Sleeve	325-6020
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3G-2580	Bearing-Sleeve	422-9526
3K-2511	Dowel-Reaction	383-2126
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5200	Carrier-Planet	295-5701

RDC		
Original Part Number	Part Name	Classic Part Number
4K-3128	Bearing-Sleeve	314-8633
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
6I-8500	Plate-Clutch	377-7436
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
7C-3567	Mount As	314-8689
7F-9547	Pin As.-Drawbar	295-0414
7G-0437	Plate-Clutch	417-9466
7H-4566	Cup-Roller Brg	399-6068

RDC		
Original Part Number	Part Name	Classic Part Number
7H-7628	Bearing	453-3655
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
160-0305	Bearing-Aligning	396-9945
161-3411	Gasket	394-0896

Sales Model D6T (Cont'd.)

RLW		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609

RLW		
Original Part Number	Part Name	Classic Part Number
4J-0121	Cap-Bearing	360-2344
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721

RLW		
Original Part Number	Part Name	Classic Part Number
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675

Sales Model D6T (Cont'd.)

RLW		
Original Part Number	Part Name	Classic Part Number
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859

RLW		
Original Part Number	Part Name	Classic Part Number
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
161-3411	Gasket	394-0896
164-4413	Mount	419-0876

RLW		
Original Part Number	Part Name	Classic Part Number
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

RRK		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3K-2511	Dowel-Reaction	383-2126

RRK		
Original Part Number	Part Name	Classic Part Number
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306

RRK		
Original Part Number	Part Name	Classic Part Number
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714

Sales Model D6T (Cont'd.)

RRK		
Original Part Number	Part Name	Classic Part Number
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217

RRK		
Original Part Number	Part Name	Classic Part Number
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701

RRK		
Original Part Number	Part Name	Classic Part Number
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

SGA		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2K-4507	Bearing-Sleeve	325-6021

SGA		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3G-2580	Bearing-Sleeve	422-9526
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407

SGA		
Original Part Number	Part Name	Classic Part Number
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444

Sales Model D6T (Cont'd.)

SGA		
Original Part Number	Part Name	Classic Part Number
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714

SGA		
Original Part Number	Part Name	Classic Part Number
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719

SGA		
Original Part Number	Part Name	Classic Part Number
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
160-0305	Bearing-Aligning	396-9945
161-3411	Gasket	394-0896
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

SGT		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543

SGT		
Original Part Number	Part Name	Classic Part Number
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3G-2580	Bearing-Sleeve	422-9526
3K-2511	Dowel-Reaction	383-2126

SGT		
Original Part Number	Part Name	Classic Part Number
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632

Sales Model D6T (Cont'd.)

SGT		
Original Part Number	Part Name	Classic Part Number
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689

SGT		
Original Part Number	Part Name	Classic Part Number
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931

SGT		
Original Part Number	Part Name	Classic Part Number
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

SKL		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409

SKL		
Original Part Number	Part Name	Classic Part Number
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689

SKL		
Original Part Number	Part Name	Classic Part Number
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480

Sales Model D6T (Cont'd.)

SKL		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433

SKL		
Original Part Number	Part Name	Classic Part Number
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207

SKL		
Original Part Number	Part Name	Classic Part Number
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490

Sales Model D6T (Cont'd.)

SKL		
Original Part Number	Part Name	Classic Part Number
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686

SKL		
Original Part Number	Part Name	Classic Part Number
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659

SKL		
Original Part Number	Part Name	Classic Part Number
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

SLJ		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126

SLJ		
Original Part Number	Part Name	Classic Part Number
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306

SLJ		
Original Part Number	Part Name	Classic Part Number
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7S-4411	Cap As-Rain	373-1912
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354

Sales Model D6T (Cont'd.)

SLJ		
Original Part Number	Part Name	Classic Part Number
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425

SLJ		
Original Part Number	Part Name	Classic Part Number
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491

SLJ		
Original Part Number	Part Name	Classic Part Number
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

SMC		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174

SMC		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-6185	Pin	295-5694
3G-2580	Bearing-Sleeve	422-9526
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695

SMC		
Original Part Number	Part Name	Classic Part Number
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632

Sales Model D6T (Cont'd.)

SMC		
Original Part Number	Part Name	Classic Part Number
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414

SMC		
Original Part Number	Part Name	Classic Part Number
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425

SNK		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437

SMC		
Original Part Number	Part Name	Classic Part Number
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model D6T (Cont'd.)

SNK		
Original Part Number	Part Name	Classic Part Number
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3J-4284	Cap-Brg	314-8656
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712

SNK		
Original Part Number	Part Name	Classic Part Number
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361

SNK		
Original Part Number	Part Name	Classic Part Number
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719

Sales Model D6T (Cont'd.)

SNK		
Original Part Number	Part Name	Classic Part Number
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554

SNK		
Original Part Number	Part Name	Classic Part Number
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
164-4413	Mount	419-0876

SNK		
Original Part Number	Part Name	Classic Part Number
179-6152	Bearing	361-1704
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

STE		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3G-2580	Bearing-Sleeve	422-9526
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695

STE		
Original Part Number	Part Name	Classic Part Number
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442

STE		
Original Part Number	Part Name	Classic Part Number
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411

Sales Model D6T (Cont'd.)

STE		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018

STE		
Original Part Number	Part Name	Classic Part Number
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554

STE		
Original Part Number	Part Name	Classic Part Number
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
160-0305	Bearing-Aligning	396-9945
161-3411	Gasket	394-0896
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

TMY		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346

TMY		
Original Part Number	Part Name	Classic Part Number
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3G-2580	Bearing-Sleeve	422-9526
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407

TMY		
Original Part Number	Part Name	Classic Part Number
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444

Sales Model D6T (Cont'd.)

TMY		
Original Part Number	Part Name	Classic Part Number
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7P-8370	Bearing	295-6410

TMY		
Original Part Number	Part Name	Classic Part Number
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9P-7757	Gear-Sun	283-5218

TMY		
Original Part Number	Part Name	Classic Part Number
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

TSM		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543

TSM		
Original Part Number	Part Name	Classic Part Number
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695

TSM		
Original Part Number	Part Name	Classic Part Number
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633

Sales Model D6T (Cont'd.)

TSM		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
5D-2989	Bearing	380-7511
5J-4321	Trunnion	302-2700
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721

TSM		
Original Part Number	Part Name	Classic Part Number
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417

TSM		
Original Part Number	Part Name	Classic Part Number
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

WCG		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535

WCG		
Original Part Number	Part Name	Classic Part Number
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409

WCG		
Original Part Number	Part Name	Classic Part Number
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543

Sales Model D6T (Cont'd.)

WCG		
Original Part Number	Part Name	Classic Part Number
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022

WCG		
Original Part Number	Part Name	Classic Part Number
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296

WCG		
Original Part Number	Part Name	Classic Part Number
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
161-3411	Gasket	394-0896
164-4413	Mount	419-0876

Sales Model D6T (Cont'd.)

WCG		
Original Part Number	Part Name	Classic Part Number
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524

WCG		
Original Part Number	Part Name	Classic Part Number
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966

WCG		
Original Part Number	Part Name	Classic Part Number
328-4375	Disc-Friction	443-1922

WES		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3G-2580	Bearing-Sleeve	422-9526
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699

WES		
Original Part Number	Part Name	Classic Part Number
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361

WES		
Original Part Number	Part Name	Classic Part Number
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719

Sales Model D6T (Cont'd.)

WES		
Original Part Number	Part Name	Classic Part Number
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491

WES		
Original Part Number	Part Name	Classic Part Number
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932

WES		
Original Part Number	Part Name	Classic Part Number
112-8041	Carrier-Planet	295-5681
160-0305	Bearing-Aligning	396-9945
161-3411	Gasket	394-0896
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

WFH		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3K-2511	Dowel-Reaction	383-2126

WFH		
Original Part Number	Part Name	Classic Part Number
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306

WFH		
Original Part Number	Part Name	Classic Part Number
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714

Sales Model D6T (Cont'd.)

WFH		
Original Part Number	Part Name	Classic Part Number
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217

WFH		
Original Part Number	Part Name	Classic Part Number
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491

WFH		
Original Part Number	Part Name	Classic Part Number
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
161-3411	Gasket	394-0896
164-4413	Mount	419-0876
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

WLM		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020

WLM		
Original Part Number	Part Name	Classic Part Number
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3J-2682	Bracket	296-1345
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698

WLM		
Original Part Number	Part Name	Classic Part Number
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
3W-6551	Shaft	295-5702
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727

Sales Model D6T (Cont'd.)

WLM		
Original Part Number	Part Name	Classic Part Number
4T-5495	Ballstud	314-8626
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655

WLM		
Original Part Number	Part Name	Classic Part Number
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362

WLM		
Original Part Number	Part Name	Classic Part Number
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

WRN		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410

WRN		
Original Part Number	Part Name	Classic Part Number
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543

WRN		
Original Part Number	Part Name	Classic Part Number
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2K-4507	Bearing-Sleeve	325-6021

Sales Model D6T (Cont'd.)

WRN		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3G-2580	Bearing-Sleeve	422-9526
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436

WRN		
Original Part Number	Part Name	Classic Part Number
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658

WRN		
Original Part Number	Part Name	Classic Part Number
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
160-0305	Bearing-Aligning	396-9945
161-3411	Gasket	394-0896
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

ZEB		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1P-3934	Cup-Roller Brg	420-6535

ZEB		
Original Part Number	Part Name	Classic Part Number
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410

ZEB		
Original Part Number	Part Name	Classic Part Number
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326

Sales Model D6T (Cont'd.)

ZEB		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-6374	Bearing-Sleeve	295-6407
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4S-8472	Hood As-Preclnr	296-1355
4W-0255	Spider As-Fan	382-5052
4W-1203	Cup-Rlr Brg	418-9603

ZEB		
Original Part Number	**Part Name**	**Classic Part Number**
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
7C-3567	Mount As	314-8689
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7T-8136	Shaft-Planet	314-8714

ZEB		
Original Part Number	**Part Name**	**Classic Part Number**
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583

Sales Model D6T (Cont'd.)

ZEB		
Original Part Number	Part Name	Classic Part Number
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
161-3411	Gasket	394-0896

ZEB		
Original Part Number	Part Name	Classic Part Number
164-4413	Mount	419-0876
229-1490	Sleeve-Injector	393-3659
258-2303	Bearing-Sleeve	307-1524

ZEB		
Original Part Number	Part Name	Classic Part Number
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

ZJB		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0725	Retainer	314-8707
1U-4103	Trunnion	295-5680
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-4507	Bearing-Sleeve	325-6021
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3J-2682	Bracket	296-1345
3J-4284	Cap-Brg	314-8656
3J-6573	Screw-Adjusting	302-2714

ZJB		
Original Part Number	Part Name	Classic Part Number
3K-2511	Dowel-Reaction	383-2126
3T-0996	Bearing-Sleeve	295-5695
3T-1162	Sleeve-Wear	325-6209
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3W-0640	Piston	325-6160
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3583	Screw-Adjusting	297-7242
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-2514	Gear-Flywheel	421-7283
4T-0732	Bracket	314-8627
4T-1504	Trunnion	314-8727
4T-5495	Ballstud	314-8626
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022

ZJB		
Original Part Number	Part Name	Classic Part Number
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6I-8500	Plate-Clutch	377-7436
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-6751	Pin	325-6149
7C-3567	Mount As	314-8689
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-9555	Univ Joint As	314-8721
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-5131	Trunnion	296-1371
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7P-8370	Bearing	295-6410
7S-4411	Cap As-Rain	373-1912

Sales Model D6T (Cont'd.)

ZJB		
Original Part Number	Part Name	Classic Part Number
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8H-5352	Bearing-Ball	453-3658
8H-8898	Pin	385-3801
8J-2880	Cap-Bearing	295-6420
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217

ZJB		
Original Part Number	Part Name	Classic Part Number
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-8481	Pin As.	295-5675
9W-0099	Bearing-Sleeve	314-8639
9W-0876	Bearing-Sleeve	325-6031
9W-2579	Plate	314-8701
9W-4897	Bracket As	295-6414

ZJB		
Original Part Number	Part Name	Classic Part Number
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-2988	Breather As	361-1716
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
179-6152	Bearing	361-1704
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model D7

03T		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1J-0774	Bracket	369-9485
1M-7250	Bowl	360-2296
1S-1888	Bracket-Lamp	297-7147
1S-5331	Cylinder-Adj	226-0214
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-0025	Tube	325-6233
2H-3712	Bearing-Ball	392-4488
2S-4015	Plunger As-Valve	311-9438

03T		
Original Part Number	Part Name	Classic Part Number
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3H-0881	Ring-Piston	465-8998
3H-1996	Bearing-Ball	380-1498
3K-3124	Muffler-Trap	247-2673
4F-2393	Bearing-Ball	380-1499
4F-5003	Spring As-Arm	383-2127
4J-1999	Ballstud	314-8625
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5M-6709	Check As-Ball	380-7542
5S-1211	Cover-Valve	314-8665

03T		
Original Part Number	Part Name	Classic Part Number
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg	333-4954
6H-3957	Bearing-Ball	311-9358
6Y-7652	Cup-Rlr Brg	399-6067
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8F-3170	Bearing-Roller	417-4504
8F-8523	Bearing-Sleeve	383-3701
8H-1383	Rod-Tie	299-2051

Sales Model D7 (Cont'd.)

03T		
Original Part Number	Part Name	Classic Part Number
8H-4320	Bearing-Ball	419-2301
8H-7980	Piston	226-0249
8H-9789	Bearing-Ball	374-8342
8S-3517	Bearing-Spl Ball	417-4501

03T		
Original Part Number	Part Name	Classic Part Number
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

03T		
Original Part Number	Part Name	Classic Part Number
9S-5279	Bearing-Inner	453-3661
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311
160-6305	Cap-Bearing	295-5686

04T		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
1S-3743	Bearing-Ball	384-4786
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2F-0025	Tube	325-6233
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3H-0881	Ring-Piston	465-8998
3K-3124	Muffler-Trap	247-2673
3P-3623	Lock-Adj Nut	226-7989
4B-1455	Cap As-Filler	361-1719

04T		
Original Part Number	Part Name	Classic Part Number
4F-5003	Spring As-Arm	383-2127
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5F-2256	Cage-Bearing	226-7973
5H-7071	Director-Water	388-0555
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5S-1220	Lifter As-Valve	387-2926
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009
6H-3957	Bearing-Ball	311-9358
6L-7816	Seal-O-Ring	314-8542
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
7B-5088	Drum-Steer Cl Dr	223-4813

04T		
Original Part Number	Part Name	Classic Part Number
7F-9547	Pin As.-Drawbar	295-0414
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
8B-8439	Bearing-Ball	399-6069
8F-8523	Bearing-Sleeve	383-3701
8H-1383	Rod-Tie	299-2051
8M-8068	Bearing-Spl Ball	417-4500
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311

05E		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3937	Cup-Roller Brg	377-7394
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2H-3712	Bearing-Ball	392-4488

05E		
Original Part Number	Part Name	Classic Part Number
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3H-0881	Ring-Piston	465-8998
3H-1996	Bearing-Ball	380-1498
3K-3124	Muffler-Trap	247-2673
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-5004	Spring As-Arm	383-2128
4N-3875	Ring-Piston	465-8997
5F-8651	Bearing-Ball	420-3223

05E		
Original Part Number	Part Name	Classic Part Number
5H-7071	Director-Water	388-0555
6H-3957	Bearing-Ball	311-9358
7M-4926	Retainer-Piston	314-8538
8B-5972	Bearing-Ball	314-8503
8F-8523	Bearing-Sleeve	383-3701
8H-4320	Bearing-Ball	419-2301
8M-8068	Bearing-Spl Ball	417-4500
9B-0399	Link As-Cl Drive	431-5268
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950

Sales Model D7 (Cont'd.)

05E		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-9431	Precleaner As	361-1718

05E		
Original Part Number	**Part Name**	**Classic Part Number**
121-7746	Pre-Cleaner As	360-2311

06T		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
1S-3743	Bearing-Ball	384-4786
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2F-0025	Tube	325-6233
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3H-0881	Ring-Piston	465-8998
3K-3124	Muffler-Trap	247-2673
3P-3623	Lock-Adj Nut	226-7989
4B-1455	Cap As-Filler	361-1719

06T		
Original Part Number	**Part Name**	**Classic Part Number**
4F-5003	Spring As-Arm	383-2127
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5F-2256	Cage-Bearing	226-7973
5H-7071	Director-Water	388-0555
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5S-1220	Lifter As-Valve	387-2926
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009
6H-3957	Bearing-Ball	311-9358
6L-7816	Seal-O-Ring	314-8542
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
7B-5088	Drum-Steer Cl Dr	223-4813

06T		
Original Part Number	**Part Name**	**Classic Part Number**
7F-9547	Pin As.-Drawbar	295-0414
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
8B-8439	Bearing-Ball	399-6069
8F-8523	Bearing-Sleeve	383-3701
8H-1383	Rod-Tie	299-2051
8M-8068	Bearing-Spl Ball	417-4500
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311

07M		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1J-0774	Bracket	369-9485
1M-7250	Bowl	360-2296
1S-1888	Bracket-Lamp	297-7147
1S-5331	Cylinder-Adj	226-0214
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-0025	Tube	325-6233
2H-3712	Bearing-Ball	392-4488

07M		
Original Part Number	**Part Name**	**Classic Part Number**
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3H-0881	Ring-Piston	465-8998
3H-1996	Bearing-Ball	380-1498
3K-3124	Muffler-Trap	247-2673
4F-2393	Bearing-Ball	380-1499
4F-5003	Spring As-Arm	383-2127
4J-1999	Ballstud	314-8625
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5F-8651	Bearing-Ball	420-3223

07M		
Original Part Number	**Part Name**	**Classic Part Number**
5H-7071	Director-Water	388-0555
5M-6709	Check As-Ball	380-7542
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg	333-4954
6H-3957	Bearing-Ball	311-9358
6Y-7652	Cup-Rlr Brg	399-6067
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503

Sales Model D7 (Cont'd.)

07M		
Original Part Number	Part Name	Classic Part Number
8B-8439	Bearing-Ball	399-6069
8F-3170	Bearing-Roller	417-4504
8F-8523	Bearing-Sleeve	383-3701
8H-1383	Rod-Tie	299-2051
8H-4320	Bearing-Ball	419-2301
8H-7980	Piston	226-0249

07M		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8S-3517	Bearing-Spl Ball	417-4501
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

07M		
Original Part Number	Part Name	Classic Part Number
9S-5279	Bearing-Inner	453-3661
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311
160-6305	Cap-Bearing	295-5686

09G		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3937	Cup-Roller Brg	377-7394
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2H-3712	Bearing-Ball	392-4488
2S-4015	Plunger As-Valve	311-9438

09G		
Original Part Number	Part Name	Classic Part Number
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3H-0881	Ring-Piston	465-8998
3H-1996	Bearing-Ball	380-1498
3K-3124	Muffler-Trap	247-2673
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-5004	Spring As-Arm	383-2128
4N-3875	Ring-Piston	465-8997
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
6H-3957	Bearing-Ball	311-9358

09G		
Original Part Number	Part Name	Classic Part Number
7M-4926	Retainer-Piston	314-8538
8B-5972	Bearing-Ball	314-8503
8F-8523	Bearing-Sleeve	383-3701
8H-4320	Bearing-Ball	419-2301
8M-8068	Bearing-Spl Ball	417-4500
9B-0399	Link As-Cl Drive	431-5268
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
9Y-9431	Precleaner As	361-1718
121-7746	Pre-Cleaner As	360-2311

Sales Model D7A

01T		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
1S-3743	Bearing-Ball	384-4786
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2F-0025	Tube	325-6233
2S-4015	Plunger As-Valve	311-9438

01T		
Original Part Number	Part Name	Classic Part Number
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3H-0881	Ring-Piston	465-8998
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3P-3623	Lock-Adj Nut	226-7989
4B-1455	Cap As-Filler	361-1719
4F-2393	Bearing-Ball	380-1499
4F-5003	Spring As-Arm	383-2127
4M-9183	Bearing-Sleeve	386-4924

01T		
Original Part Number	Part Name	Classic Part Number
4N-3875	Ring-Piston	465-8997
5F-2256	Cage-Bearing	226-7973
5H-7071	Director-Water	388-0555
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5S-1220	Lifter As-Valve	387-2926
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009
6H-3957	Bearing-Ball	311-9358
6V-1013	Bearing	396-4140

Track-Type Tractors

Sales Model D7A (Cont'd.)

01T		
Original Part Number	**Part Name**	**Classic Part Number**
6V-1014	Race-Spl Rlr Brg	416-2173
7B-5088	Drum-Steer Cl Dr	223-4813
7F-9547	Pin As.-Drawbar	295-0414
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538

01T		
Original Part Number	**Part Name**	**Classic Part Number**
8B-8439	Bearing-Ball	399-6069
8F-3170	Bearing-Roller	417-4504
8F-8523	Bearing-Sleeve	383-3701
8H-1383	Rod-Tie	299-2051
8M-8068	Bearing-Spl Ball	417-4500
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866

01T		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5279	Bearing-Inner	453-3661
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311

Sales Model D7C, D7D

17A		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-7250	Bowl	360-2296
1P-0005	Pump Gp-Fuel Tfr	256-4756
1S-1888	Bracket-Lamp	297-7147
1S-5331	Cylinder-Adj	226-0214
1S-7056	Bearing-Ball	422-6483
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2M-7116	Strip-Tapping	384-3480
2P-0483	Chamber As	256-4760
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3B-8845	Bearing-Inner	417-4509
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3H-0881	Ring-Piston	465-8998
3H-1996	Bearing-Ball	380-1498

17A		
Original Part Number	**Part Name**	**Classic Part Number**
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3P-3623	Lock-Adj Nut	226-7989
4B-1455	Cap As-Filler	361-1719
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-2393	Bearing-Ball	380-1499
4F-5003	Spring As-Arm	383-2127
4F-5004	Spring As-Arm	383-2128
4H-9640	Bearing-Sleeve	386-4921
4M-9183	Bearing-Sleeve	386-4924
4M-9215	Gear-Pump Idler	311-9391
4N-3875	Ring-Piston	465-8997
5F-2256	Cage-Bearing	226-7973
5H-7071	Director-Water	388-0555
5M-2824	Coupling-Exhaust	431-5270
5M-6709	Check As-Ball	380-7542
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9553	Gasket Kit - Wp	393-3624
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738

17A		
Original Part Number	**Part Name**	**Classic Part Number**
6B-7178	Fork-Band Adj	299-2009
6F-2904	Bearing	295-5673
6H-2577	Spider Gp-Brg	333-4954
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6L-7816	Seal-O-Ring	314-8542
6N-5987	Shaft-Water Pump	390-0998
6T-1980	Collar-Idler End	226-0210
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
7B-5088	Drum-Steer Cl Dr	223-4813
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7H-4566	Cup-Roller Brg	399-6068
7H-6967	Bearing-Ball	422-6489
7K-5448	Cup-Bearing	415-1922
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7N-7639	Rotator-Valve	383-1582

Sales Model D7C, D7D (Cont'd.)

17A		
Original Part Number	**Part Name**	**Classic Part Number**
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8F-3170	Bearing-Roller	417-4504
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701

17A		
Original Part Number	**Part Name**	**Classic Part Number**
8H-1383	Rod-Tie	299-2051
8H-1994	Valve-Exhaust	443-1206
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-7980	Piston	226-0249
8H-9789	Bearing-Ball	374-8342
8M-8068	Bearing-Spl Ball	417-4500

17A		
Original Part Number	**Part Name**	**Classic Part Number**
9H-6236	Rod As	390-0999
9M-5350	Spring-Valve	380-7573
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
121-7746	Pre-Cleaner As	360-2311
160-6305	Cap-Bearing	295-5686

Sales Model D7E

47A		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1J-0774	Bracket	369-9485
1L-7205	Bearing-Ball	416-2167
1M-5270	Pipe-Extension	367-6065
1M-8776	Bearing-Roller	417-4516
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046
1P-0005	Pump Gp-Fuel Tfr	256-4756
1P-1367	Plunger-Valve	432-8913
1P-7590	Support As-Fr	213-4400
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188
1S-3926	Manifold-Exhaust	430-7622
1T-0043	Bearing-Ball	390-5294
1U-3953	Cartridge Gp	426-0024
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2J-5596	Pin-Pivot	297-7211
2K-5254	Bearing-Outer	377-7419

47A		
Original Part Number	**Part Name**	**Classic Part Number**
2L-5271	Bearing-Ball	371-4305
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4668	Retainer-Guard	297-4867
2M-7116	Strip-Tapping	384-3480
2M-8340	Rod End-Yoke	374-4678
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2P-2811	Race-Spl Rlr Brg	417-4528
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2S-3946	Gear-Final Drive	215-1678
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6401	Cup-Roller Brg	380-7497
2S-7062	Shaft-Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163

47A		
Original Part Number	**Part Name**	**Classic Part Number**
2S-7596	Retainer	215-1679
2S-7931	Bearing-Sleeve	387-2904
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3G-2720	Cartridge Gp-Rr	448-5051
3H-0881	Ring-Piston	465-8998
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2443	Bearing	383-2125
3J-2682	Bracket	296-1345
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961
3J-6502	Pin	319-3453
3J-6558	Brace As	416-5522
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3K-4290	Rod End	374-1823

Sales Model D7E (Cont'd.)

47A		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1885	Spring-Recoil	375-5449
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3P-3623	Lock-Adj Nut	226-7989
3P-6560	Stop-Rec Spring	226-0232
3P-6561	Stop-Rec Spring	226-0233
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-5017	Elbow-Exhaust	369-9498
3S-9669	Bearing	416-2168
3T-4482	Guide-Frt Idler	226-0248
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-5003	Spring As-Arm	383-2127
4H-9640	Bearing-Sleeve	386-4921
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-1999	Ballstud	314-8625
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4K-7463	Seal-Lip Type	472-8007
4M-9183	Bearing-Sleeve	386-4924
4M-9215	Gear-Pump Idler	311-9391
4N-3875	Ring-Piston	465-8997
4S-5367	Mount As	375-9986
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5J-2528	Plunger	391-1318
5J-3506	Retainer	399-8551

47A		
Original Part Number	**Part Name**	**Classic Part Number**
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-2971	Guard As-F Idler	226-0190
5M-5894	Cover-Bearing	448-2438
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5P-9553	Gasket Kit - Wp	393-3624
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5S-1684	Gasket Kt-V Gr	393-5224
5S-4863	Holder As-Cage	215-1732
5S-9080	Pulley-Alt Drive	264-5883
5T-8739	Spider Gp-Brg	373-5386
6B-6224	Ferrule	419-4738
6F-2904	Bearing	295-5673
6F-7523	Cap-Bearing	325-6039
6H-2577	Spider Gp-Brg	333-4954
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6J-5342	Retainer	325-6182
6J-6229	Pin	299-2030
6J-9258	Trunnion As	256-4846
6L-7816	Seal-O-Ring	314-8542
6N-5987	Shaft-Water Pump	390-0998
6P-4327	Pad	384-3472
6P-6653	Plate-Guide	226-0208
6T-0960	Pad As	367-6089
6T-1980	Collar-Idler End	226-0210
6V-2202	Bearing-Spl Ball	380-1574
6V-9228	Gasket Kt-Cyl Hd	438-0159
7F-9541	Pin As-Drawbar	296-1361
7G-6576	Cage As	216-7859

47A		
Original Part Number	**Part Name**	**Classic Part Number**
7H-4566	Cup-Roller Brg	399-6068
7H-6967	Bearing-Ball	422-6489
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-5131	Trunnion	296-1371
7J-7488	Bearing	256-4836
7K-5448	Cup-Bearing	415-1922
7M-1889	Guard As	213-9108
7M-1890	Guard As-Fd Wear	213-9109
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-7639	Rotator-Valve	383-1582
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7S-7973	Guard-Fd Wear	213-9110
7T-0119	Support As	299-2066
7T-0204	Bearing-Brace	247-4126
7T-2036	Cap As-Fuel	361-1721
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-1383	Rod-Tie	299-2051
8H-1994	Valve-Exhaust	443-1206
8H-2810	Case As-Filter	314-8512
8H-5026	Cover-Adj Pulley	445-7698

Sales Model D7E (Cont'd.)

47A		
Original Part Number	Part Name	Classic Part Number
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-7166	Housing-Screen	297-7192
8N-7923	Bearing-Main	419-7275
8N-7924	Bearing-Main	419-7276
8N-7933	Bearing-Conn Rod	419-7280
8N-7934	Bearing-Conn Rod	419-6308
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734

47A		
Original Part Number	Part Name	Classic Part Number
8P-1865	Bar As-Equalizer	231-3313
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8S-0905	Muffler As	302-2690
8S-1061	Pilot As-Spring	226-0227
8S-7818	Bracket	226-0211
8S-9686	Gasket Kit	393-5215
9G-0007	Hub	224-1311
9H-6236	Rod As	390-0999
9M-5350	Spring-Valve	380-7573
9P-0620	Cage-Pinion Brg	221-1052
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241

47A		
Original Part Number	Part Name	Classic Part Number
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5771	Bushing As	385-7219
9S-6875	Pinion-Final Dr	217-7705
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
112-3249	Muffler As	247-2661
160-6305	Cap-Bearing	295-5686

48A		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1J-0774	Bracket	369-9485
1L-7205	Bearing-Ball	416-2167
1M-3917	Shaft	386-4915
1M-5270	Pipe-Extension	367-6065
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046
1P-0005	Pump Gp-Fuel Tfr	256-4756
1P-0623	Bearing	420-3224
1P-1367	Plunger-Valve	432-8913
1P-4145	Valve Gp-Press	247-4436
1P-7590	Support As-Fr	213-4400
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188

48A		
Original Part Number	Part Name	Classic Part Number
1S-3926	Manifold-Exhaust	430-7622
1T-0043	Bearing-Ball	390-5294
1T-0256	Gear-Pump Drive	239-7930
1U-3953	Cartridge Gp	426-0024
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2J-5596	Pin-Pivot	297-7211
2K-5254	Bearing-Outer	377-7419
2L-5271	Bearing-Ball	371-4305
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4668	Retainer-Guard	297-4867
2M-7116	Strip-Tapping	384-3480
2M-8340	Rod End-Yoke	374-4678
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2P-2811	Race-Spl Rlr Brg	417-4528
2P-3424	Gear-First Red	215-1675

48A		
Original Part Number	Part Name	Classic Part Number
2P-3425	Pinion-Sec Red	217-7697
2S-3946	Gear-Final Drive	215-1678
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6401	Cup-Roller Brg	380-7497
2S-7062	Shaft-Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2S-7873	Pump Gp	226-0162
2S-7917	Gear-Pump Dr	247-4119
2S-7931	Bearing-Sleeve	387-2904
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033

Sales Model D7E (Cont'd.)

48A		
Original Part Number	Part Name	Classic Part Number
3G-2720	Cartridge Gp-Rr	448-5051
3H-0881	Ring-Piston	465-8998
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2443	Bearing	383-2125
3J-2682	Bracket	296-1345
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961
3J-6502	Pin	319-3453
3J-6558	Brace As	416-5522
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3K-4290	Rod End	374-1823
3P-1885	Spring-Recoil	375-5449
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3P-3623	Lock-Adj Nut	226-7989
3P-6560	Stop-Rec Spring	226-0232
3P-6561	Stop-Rec Spring	226-0233
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-5017	Elbow-Exhaust	369-9498
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-5003	Spring As-Arm	383-2127

48A		
Original Part Number	Part Name	Classic Part Number
4H-9640	Bearing-Sleeve	386-4921
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-1999	Ballstud	314-8625
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4M-0410	Gear-Oil Pump Dr	428-6660
4M-9183	Bearing-Sleeve	386-4924
4M-9215	Gear-Pump Idler	311-9391
4N-3875	Ring-Piston	465-8997
4S-5367	Mount As	375-9986
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5J-2528	Plunger	391-1318
5J-3506	Retainer	399-8551
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-2054	Bearing	380-7510
5M-2971	Guard As-F Idler	226-0190
5M-3499	Shaft-Planet	319-3475
5M-3941	Shaft-Planet	215-1691
5M-3942	Shaft-Planet	215-1692
5M-5018	Bearing-Roller	380-7509
5M-5894	Cover-Bearing	448-2438
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5P-9553	Gasket Kit - Wp	393-3624
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926

48A		
Original Part Number	Part Name	Classic Part Number
5S-1684	Gasket Kt-V Gr	393-5224
5S-4863	Holder As-Cage	215-1732
5S-9080	Pulley-Alt Drive	264-5883
5T-8739	Spider Gp-Brg	373-5386
6B-6224	Ferrule	419-4738
6F-2904	Bearing	295-5673
6F-7523	Cap-Bearing	325-6039
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6J-5342	Retainer	325-6182
6J-6229	Pin	299-2030
6J-9258	Trunnion As	256-4846
6L-7816	Seal-O-Ring	314-8542
6N-5987	Shaft-Water Pump	390-0998
6N-9211	Core As-O Clr	435-6049
6N-9653	Core As-Oil Clr	386-3056
6P-0236	Guide-Lever	422-6475
6P-4327	Pad	384-3472
6P-6653	Plate-Guide	226-0208
6T-0960	Pad As	367-6089
6T-1980	Collar-Idler End	226-0210
6V-2202	Bearing-Spl Ball	380-1574
6V-9228	Gasket Kt-Cyl Hd	438-0159
7F-9541	Pin As-Drawbar	296-1361
7G-2517	Gear-Planet	213-8747
7G-2521	Gear-Planet	213-8749
7G-6576	Cage As	216-7859
7H-4566	Cup-Roller Brg	399-6068
7H-6967	Bearing-Ball	422-6489
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-5131	Trunnion	296-1371
7J-7488	Bearing	256-4836
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-1889	Guard As	213-9108
7M-1890	Guard As-Fd Wear	213-9109

Sales Model D7E (Cont'd.)

48A		
Original Part Number	Part Name	Classic Part Number
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-7639	Rotator-Valve	383-1582
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7S-7973	Guard-Fd Wear	213-9110
7T-0119	Support As	299-2066
7T-0204	Bearing-Brace	247-4126
7T-2036	Cap As-Fuel	361-1721
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701

48A		
Original Part Number	Part Name	Classic Part Number
8H-1383	Rod-Tie	299-2051
8H-1994	Valve-Exhaust	443-1206
8H-2810	Case As-Filter	314-8512
8H-5026	Cover-Adj Pulley	445-7698
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-7166	Housing-Screen	297-7192
8N-7923	Bearing-Main	419-7275
8N-7924	Bearing-Main	419-7276
8N-7933	Bearing-Conn Rod	419-7280
8N-7934	Bearing-Conn Rod	419-6308
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734
8P-1865	Bar As-Equalizer	231-3313
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8S-0905	Muffler As	302-2690
8S-1061	Pilot As-Spring	226-0227
8S-7818	Bracket	226-0211

48A		
Original Part Number	Part Name	Classic Part Number
8S-9686	Gasket Kit	393-5215
9G-0007	Hub	224-1311
9H-6236	Rod As	390-0999
9M-5350	Spring-Valve	380-7573
9P-0620	Cage-Pinion Brg	221-1052
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5771	Bushing As	385-7219
9S-6875	Pinion-Final Dr	217-7705
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
112-3249	Muffler As	247-2661
128-3935	Bearing-Race	396-9897
156-8206	Kit-Dt Gasket	451-3112
160-6305	Cap-Bearing	295-5686
230-7116	Ster Cl Kit-Cla	229-8227

75E		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1M-3917	Shaft	386-4915
1M-5270	Pipe-Extension	367-6065
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046

75E		
Original Part Number	Part Name	Classic Part Number
1P-0005	Pump Gp-Fuel Tfr	256-4756
1P-0623	Bearing	420-3224
1P-1367	Plunger-Valve	432-8913
1P-4145	Valve Gp-Press	247-4436
1P-7590	Support As-Fr	213-4400
1S-0876	Bolt-Spring	226-0224
1S-2233	Bearing-Sleeve	379-0188
1S-3926	Manifold-Exhaust	430-7622
1T-0043	Bearing-Ball	390-5294

75E		
Original Part Number	Part Name	Classic Part Number
1T-0256	Gear-Pump Drive	239-7930
1U-3953	Cartridge Gp	426-0024
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2K-5254	Bearing-Outer	377-7419
2L-5271	Bearing-Ball	371-4305
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123

Sales Model D7E (Cont'd.)

75E		
Original Part Number	Part Name	Classic Part Number
2M-7116	Strip-Tapping	384-3480
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2P-2811	Race-Spl Rlr Brg	417-4528
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2S-3946	Gear-Final Drive	215-1678
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-6150	Cover-Pulley	428-8817
2S-6401	Cup-Roller Brg	380-7497
2S-7062	Shaft-Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2S-7873	Pump Gp	226-0162
2S-7917	Gear-Pump Dr	247-4119
2S-7931	Bearing-Sleeve	387-2904
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3F-4971	Pin	295-5693
3G-2720	Cartridge Gp-Rr	448-5051
3H-0881	Ring-Piston	465-8998
3H-8726	Mount As	385-7208
3J-2443	Bearing	383-2125
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961
3K-4290	Rod End	374-1823
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950

75E		
Original Part Number	Part Name	Classic Part Number
3S-5017	Elbow-Exhaust	369-9498
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
4F-2041	Cup-Roller Brg	418-9609
4F-5003	Spring As-Arm	383-2127
4H-9640	Bearing-Sleeve	386-4921
4J-1999	Ballstud	314-8625
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4M-9183	Bearing-Sleeve	386-4924
4M-9215	Gear-Pump Idler	311-9391
4N-3875	Ring-Piston	465-8997
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-7993	Pin	319-3454
5H-7071	Director-Water	388-0555
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-2054	Bearing	380-7510
5M-2971	Guard As-F Idler	226-0190
5M-3499	Shaft-Planet	319-3475
5M-3941	Shaft-Planet	215-1691
5M-3942	Shaft-Planet	215-1692
5M-5018	Bearing-Roller	380-7509
5M-5894	Cover-Bearing	448-2438
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5S-4863	Holder As-Cage	215-1732
5S-9080	Pulley-Alt Drive	264-5883
5T-8739	Spider Gp-Brg	373-5386
6B-6224	Ferrule	419-4738
6F-2904	Bearing	295-5673
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6N-5987	Shaft-Water Pump	390-0998

75E		
Original Part Number	Part Name	Classic Part Number
6N-9211	Core As-O Clr	435-6049
6N-9653	Core As-Oil Clr	386-3056
6P-4327	Pad	384-3472
6P-6653	Plate-Guide	226-0208
6T-0960	Pad As	367-6089
6T-1980	Collar-Idler End	226-0210
6V-2202	Bearing-Spl Ball	380-1574
7G-2517	Gear-Planet	213-8747
7G-2521	Gear-Planet	213-8749
7G-6576	Cage As	216-7859
7H-4566	Cup-Roller Brg	399-6068
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7N-4407	Gasket-Rod Comp	433-9853
7N-7386	Gasket-Cyl Head	392-4519
7N-7639	Rotator-Valve	383-1582
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-0119	Support As	299-2066
7T-0204	Bearing-Brace	247-4126
8F-8523	Bearing-Sleeve	383-3701
8H-1383	Rod-Tie	299-2051
8H-1994	Valve-Exhaust	443-1206
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8M-7166	Housing-Screen	297-7192
8N-7923	Bearing-Main	419-7275
8N-7933	Bearing-Conn Rod	419-7280

Sales Model D7E (Cont'd.)

75E		
Original Part Number	**Part Name**	**Classic Part Number**
8N-7934	Bearing-Conn Rod	419-6308
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734
8P-1865	Bar As-Equalizer	231-3313
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8S-0905	Muffler As	302-2690
8S-7818	Bracket	226-0211

75E		
Original Part Number	**Part Name**	**Classic Part Number**
8S-9686	Gasket Kit	393-5215
9G-0007	Hub	224-1311
9H-6236	Rod As	390-0999
9M-5350	Spring-Valve	380-7573
9P-0620	Cage-Pinion Brg	221-1052
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874

75E		
Original Part Number	**Part Name**	**Classic Part Number**
9S-4829	Race-Brg Inner	423-9668
9S-5771	Bushing As	385-7219
9S-6875	Pinion-Final Dr	217-7705
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
128-3935	Bearing-Race	396-9897
160-6305	Cap-Bearing	295-5686
230-7116	Ster Cl Kit-Cla	229-8227

79A		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8776	Bearing-Roller	417-4516
1S-2233	Bearing-Sleeve	379-0188
2P-2811	Race-Spl Rlr Brg	417-4528

79A		
Original Part Number	**Part Name**	**Classic Part Number**
2S-6401	Cup-Roller Brg	380-7497
3S-9669	Bearing	416-2168
5D-7449	Cup-Spl Tapered	416-2161

79A		
Original Part Number	**Part Name**	**Classic Part Number**
5F-1248	Cone-Roller Brg	399-4441
9S-4829	Race-Brg Inner	423-9668

95A		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1S-2233	Bearing-Sleeve	379-0188
2P-2811	Race-Spl Rlr Brg	417-4528

95A		
Original Part Number	**Part Name**	**Classic Part Number**
2S-6401	Cup-Roller Brg	380-7497
3S-9669	Bearing	416-2168
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441

95A		
Original Part Number	**Part Name**	**Classic Part Number**
5M-2054	Bearing	380-7510
9S-4829	Race-Brg Inner	423-9668
128-3935	Bearing-Race	396-9897
156-8206	Kit-Dt Gasket	451-3112

HKA		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4106	Pin As-Drawbar	325-6126
1T-0043	Bearing-Ball	390-5294
1U-0725	Retainer	314-8707
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1W-4738	Bearing-Sleeve	325-6020
3D-9133	Cup-Roller Brg	418-9601
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037

HKA		
Original Part Number	**Part Name**	**Classic Part Number**
3G-5999	Bearing-Sleeve	391-9813
3H-1996	Bearing-Ball	380-1498
3J-2682	Bracket	296-1345
3J-6484	Bearing-Sleeve	380-7383
3T-5294	Spacer	325-6216
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6374	Bearing-Sleeve	295-6407
4N-2514	Gear-Flywheel	421-7283

HKA		
Original Part Number	**Part Name**	**Classic Part Number**
4T-5495	Ballstud	314-8626
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-6659	Bearing	417-4511
5J-1192	Bearing-Sleeve	374-8355
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6V-3831	Seal-O-Ring	436-2657
6Y-6752	Pin	325-6150

Sales Model D7E (Cont'd.)

HKA		
Original Part Number	Part Name	Classic Part Number
6Y-7474	Pin-Pivot	325-6153
7C-3567	Mount As	314-8689
7J-1309	Bearing-Aligning	360-2275
7K-5448	Cup-Bearing	415-1922
7S-3002	Bearing-Spl Ball	386-4961
7S-4534	Bearing-Caged	417-9497
8D-0983	Mounting	384-3470
8E-5450	Seal-Ebar	325-6190

HKA		
Original Part Number	Part Name	Classic Part Number
8H-8898	Pin	385-3801
9J-0123	Trunnion	325-6227
9J-5284	Bearing-Sleeve	380-7379
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

HKA		
Original Part Number	Part Name	Classic Part Number
9W-1677	Bearing	297-7145
9W-4897	Bracket As	295-6414
9Y-2988	Breather As	361-1716
100-8010	Valve	423-5583
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
239-1497	Trunnion	394-0197

JDP		
Original Part Number	Part Name	Classic Part Number
1M-7912	Cone-Roller Brg	380-7503
1M-8923	Race-Brg Outer	440-3117
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0043	Bearing-Ball	390-5294
1U-0990	Pin	325-6138
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2D-5658	Bearing-Ball	301-4628
2S-7931	Bearing-Sleeve	387-2904
3D-9133	Cup-Roller Brg	418-9601
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3H-1996	Bearing-Ball	380-1498
3K-0526	Bearing-Ball	386-4949
3T-4008	Gear-Planet	295-5444
4J-5241	Retainer	434-1415
4M-3915	Bearing-Caged	377-7427

JDP		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4V-8674	Bearing-Sleeve	307-1529
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-6659	Bearing	417-4511
5F-2465	Cup-Roller Brg	447-8060
5J-1192	Bearing-Sleeve	374-8355
5P-3930	Bearing As-Rlr	419-6022
5P-6254	Bearing	420-2495
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
7B-7515	Bearing-Ball	399-6059
7C-3567	Mount As	314-8689
7J-1309	Bearing-Aligning	360-2275

JDP		
Original Part Number	Part Name	Classic Part Number
7J-5131	Trunnion	296-1371
7S-3002	Bearing-Spl Ball	386-4961
7S-4534	Bearing-Caged	417-9497
8D-0983	Mounting	384-3470
9D-7924	Mount As	360-2356
9J-5284	Bearing-Sleeve	380-7379
9J-7099	Bearing-Sleeve	391-9818
9M-4370	Bearing-Sleeve	453-6515
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9Y-2988	Breather As	361-1716
100-8010	Valve	423-5583
115-4072	Bearing	397-5069
130-3139	Bearing-Sleeve	391-9875
157-5075	Gear-Planet	394-9821
161-3411	Gasket	394-0896
248-2987	Guide	419-4709

KZA		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1T-0043	Bearing-Ball	390-5294
1U-0725	Retainer	314-8707
1U-0872	Pin	325-6136

KZA		
Original Part Number	Part Name	Classic Part Number
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1W-4738	Bearing-Sleeve	325-6020
3D-9133	Cup-Roller Brg	418-9601

KZA		
Original Part Number	Part Name	Classic Part Number
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3H-1996	Bearing-Ball	380-1498

Sales Model D7E (Cont'd.)

KZA		
Original Part Number	Part Name	Classic Part Number
3J-2682	Bracket	296-1345
3J-6484	Bearing-Sleeve	380-7383
3T-4008	Gear-Planet	295-5444
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6374	Bearing-Sleeve	295-6407
4M-3915	Bearing-Caged	377-7427
4N-2514	Gear-Flywheel	421-7283
4T-5495	Ballstud	314-8626
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-6659	Bearing	417-4511
5J-1192	Bearing-Sleeve	374-8355

KZA		
Original Part Number	Part Name	Classic Part Number
5P-3930	Bearing As-Rlr	419-6022
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-6752	Pin	325-6150
7C-3567	Mount As	314-8689
7J-1309	Bearing-Aligning	360-2275
7J-1336	Bearing-Sleeve	384-4776
7S-3002	Bearing-Spl Ball	386-4961
7S-4534	Bearing-Caged	417-9497
8D-0983	Mounting	384-3470
8E-5450	Seal-Ebar	325-6190

KZA		
Original Part Number	Part Name	Classic Part Number
8H-8898	Pin	385-3801
9J-0123	Trunnion	325-6227
9J-5284	Bearing-Sleeve	380-7379
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-1677	Bearing	297-7145
9W-4897	Bracket As	295-6414
9Y-2988	Breather As	361-1716
100-8010	Valve	423-5583
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
239-1497	Trunnion	394-0197

LTW		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1T-0043	Bearing-Ball	390-5294
1U-0725	Retainer	314-8707
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1W-4738	Bearing-Sleeve	325-6020
3D-9133	Cup-Roller Brg	418-9601
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3H-1996	Bearing-Ball	380-1498
3J-2682	Bracket	296-1345
3J-6484	Bearing-Sleeve	380-7383
3T-4008	Gear-Planet	295-5444
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6374	Bearing-Sleeve	295-6407
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427

LTW		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4T-5495	Ballstud	314-8626
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-6659	Bearing	417-4511
5J-1192	Bearing-Sleeve	374-8355
5P-3930	Bearing As-Rlr	419-6022
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
7C-3567	Mount As	314-8689
7J-1309	Bearing-Aligning	360-2275
7J-1336	Bearing-Sleeve	384-4776
7K-5448	Cup-Bearing	415-1922
7S-3002	Bearing-Spl Ball	386-4961

LTW		
Original Part Number	Part Name	Classic Part Number
7S-4534	Bearing-Caged	417-9497
8D-0983	Mounting	384-3470
8E-5450	Seal-Ebar	325-6190
8H-8898	Pin	385-3801
9J-0123	Trunnion	325-6227
9J-5284	Bearing-Sleeve	380-7379
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-1677	Bearing	297-7145
9W-4897	Bracket As	295-6414
9Y-2988	Breather As	361-1716
100-8010	Valve	423-5583
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
239-1497	Trunnion	394-0197

Sales Model D7E (Cont'd.)

MDB		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1M-7912	Cone-Roller Brg	380-7503
1M-8923	Race-Brg Outer	440-3117
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0043	Bearing-Ball	390-5294
1U-0725	Retainer	314-8707
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2S-7931	Bearing-Sleeve	387-2904
2W-7213	Bearing-Sleeve	419-4667
3D-9133	Cup-Roller Brg	418-9601
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3H-1996	Bearing-Ball	380-1498
3J-2682	Bracket	296-1345
3J-6484	Bearing-Sleeve	380-7383
3K-0526	Bearing-Ball	386-4949
3T-4008	Gear-Planet	295-5444
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415

MDB		
Original Part Number	Part Name	Classic Part Number
4J-6374	Bearing-Sleeve	295-6407
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4N-2514	Gear-Flywheel	421-7283
4T-0732	Bracket	314-8627
4T-5495	Ballstud	314-8626
4V-8674	Bearing-Sleeve	307-1529
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-6659	Bearing	417-4511
5F-2465	Cup-Roller Brg	447-8060
5J-1192	Bearing-Sleeve	374-8355
5P-3930	Bearing As-Rlr	419-6022
5P-6254	Bearing	420-2495
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
7B-7515	Bearing-Ball	399-6059
7C-3567	Mount As	314-8689
7J-1309	Bearing-Aligning	360-2275
7J-1336	Bearing-Sleeve	384-4776

MDB		
Original Part Number	Part Name	Classic Part Number
7S-3002	Bearing-Spl Ball	386-4961
7S-4534	Bearing-Caged	417-9497
8D-0983	Mounting	384-3470
8E-5450	Seal-Ebar	325-6190
8H-8898	Pin	385-3801
9D-7924	Mount As	360-2356
9J-0123	Trunnion	325-6227
9J-5284	Bearing-Sleeve	380-7379
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-1677	Bearing	297-7145
9W-4897	Bracket As	295-6414
9Y-2988	Breather As	361-1716
100-8010	Valve	423-5583
110-8368	Bearing-Cup	416-2172
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
130-3139	Bearing-Sleeve	391-9875
157-5075	Gear-Planet	394-9821
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
229-1490	Sleeve-Injector	393-3659
239-1497	Trunnion	394-0197
248-2987	Guide	419-4709

SCG		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1M-7912	Cone-Roller Brg	380-7503
1M-8923	Race-Brg Outer	440-3117
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401

SCG		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174

SCG		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2S-7931	Bearing-Sleeve	387-2904
2W-7213	Bearing-Sleeve	419-4667
3D-9133	Cup-Roller Brg	418-9601
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037

Sales Model D7E (Cont'd.)

SCG		
Original Part Number	Part Name	Classic Part Number
3G-5999	Bearing-Sleeve	391-9813
3H-1996	Bearing-Ball	380-1498
3J-6484	Bearing-Sleeve	380-7383
3K-0526	Bearing-Ball	386-4949
3T-4008	Gear-Planet	295-5444
4J-5241	Retainer	434-1415
4J-6374	Bearing-Sleeve	295-6407
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4N-2514	Gear-Flywheel	421-7283
4T-0732	Bracket	314-8627
4V-8674	Bearing-Sleeve	307-1529
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-6659	Bearing	417-4511
5F-2465	Cup-Roller Brg	447-8060
5J-1192	Bearing-Sleeve	374-8355

SCG		
Original Part Number	Part Name	Classic Part Number
5P-3930	Bearing As-Rlr	419-6022
5P-6254	Bearing	420-2495
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
7B-7515	Bearing-Ball	399-6059
7C-3567	Mount As	314-8689
7J-1336	Bearing-Sleeve	384-4776
7S-3002	Bearing-Spl Ball	386-4961
7S-4534	Bearing-Caged	417-9497
8D-0983	Mounting	384-3470
8E-5450	Seal-Ebar	325-6190
8H-8898	Pin	385-3801
9D-7924	Mount As	360-2356
9J-0123	Trunnion	325-6227
9J-5284	Bearing-Sleeve	380-7379
9J-7099	Bearing-Sleeve	391-9818

SCG		
Original Part Number	Part Name	Classic Part Number
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9Y-2988	Breather As	361-1716
100-8010	Valve	423-5583
110-8368	Bearing-Cup	416-2172
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
130-3139	Bearing-Sleeve	391-9875
157-5075	Gear-Planet	394-9821
161-3411	Gasket	394-0896
229-1490	Sleeve-Injector	393-3659
239-1497	Trunnion	394-0197
248-2987	Guide	419-4709

SSH		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1T-0043	Bearing-Ball	390-5294
1U-0725	Retainer	314-8707
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1W-4738	Bearing-Sleeve	325-6020
3D-9133	Cup-Roller Brg	418-9601
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3H-1996	Bearing-Ball	380-1498
3J-2682	Bracket	296-1345
3J-6484	Bearing-Sleeve	380-7383
3T-5294	Spacer	325-6216
4F-1252	Pin	295-5704

SSH		
Original Part Number	Part Name	Classic Part Number
4J-5241	Retainer	434-1415
4J-6374	Bearing-Sleeve	295-6407
4N-2514	Gear-Flywheel	421-7283
4T-5495	Ballstud	314-8626
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-6659	Bearing	417-4511
5J-1192	Bearing-Sleeve	374-8355
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6V-3831	Seal-O-Ring	436-2657
6Y-6752	Pin	325-6150
7C-3567	Mount As	314-8689
7J-1309	Bearing-Aligning	360-2275

SSH		
Original Part Number	Part Name	Classic Part Number
7J-1336	Bearing-Sleeve	384-4776
7K-5448	Cup-Bearing	415-1922
7S-3002	Bearing-Spl Ball	386-4961
7S-4534	Bearing-Caged	417-9497
8D-0983	Mounting	384-3470
8E-5450	Seal-Ebar	325-6190
8H-8898	Pin	385-3801
9J-0123	Trunnion	325-6227
9J-5284	Bearing-Sleeve	380-7379
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

Sales Model D7E (Cont'd.)

SSH		
Original Part Number	**Part Name**	**Classic Part Number**
9W-1677	Bearing	297-7145
9W-4897	Bracket As	295-6414
9Y-2988	Breather As	361-1716

SSH		
Original Part Number	**Part Name**	**Classic Part Number**
100-8010	Valve	423-5583
160-6306	Cap-Bearing	325-6038

SSH		
Original Part Number	**Part Name**	**Classic Part Number**
161-3411	Gasket	394-0896
239-1497	Trunnion	394-0197

TAN		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4106	Pin As-Drawbar	325-6126
1M-7912	Cone-Roller Brg	380-7503
1M-8923	Race-Brg Outer	440-3117
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0043	Bearing-Ball	390-5294
1U-0725	Retainer	314-8707
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2S-7931	Bearing-Sleeve	387-2904
2W-7213	Bearing-Sleeve	419-4667
3D-9133	Cup-Roller Brg	418-9601
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3H-1996	Bearing-Ball	380-1498
3J-2682	Bracket	296-1345
3J-6484	Bearing-Sleeve	380-7383
3K-0526	Bearing-Ball	386-4949
3T-4008	Gear-Planet	295-5444
3T-5294	Spacer	325-6216
4F-1252	Pin	295-5704

TAN		
Original Part Number	**Part Name**	**Classic Part Number**
4J-5241	Retainer	434-1415
4J-6374	Bearing-Sleeve	295-6407
4K-3128	Bearing-Sleeve	314-8633
4M-3915	Bearing-Caged	377-7427
4N-2514	Gear-Flywheel	421-7283
4T-5495	Ballstud	314-8626
4V-8674	Bearing-Sleeve	307-1529
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-6659	Bearing	417-4511
5F-2465	Cup-Roller Brg	447-8060
5J-1192	Bearing-Sleeve	374-8355
5P-3930	Bearing As-Rlr	419-6022
5P-6254	Bearing	420-2495
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
7B-7515	Bearing-Ball	399-6059
7C-3567	Mount As	314-8689
7J-1309	Bearing-Aligning	360-2275
7J-1336	Bearing-Sleeve	384-4776

TAN		
Original Part Number	**Part Name**	**Classic Part Number**
7S-3002	Bearing-Spl Ball	386-4961
7S-4534	Bearing-Caged	417-9497
8D-0983	Mounting	384-3470
8E-5450	Seal-Ebar	325-6190
8H-8898	Pin	385-3801
9D-7924	Mount As	360-2356
9J-0123	Trunnion	325-6227
9J-5284	Bearing-Sleeve	380-7379
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-1677	Bearing	297-7145
9W-4897	Bracket As	295-6414
9Y-2988	Breather As	361-1716
100-8010	Valve	423-5583
110-8368	Bearing-Cup	416-2172
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
130-3139	Bearing-Sleeve	391-9875
157-5075	Gear-Planet	394-9821
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
229-1490	Sleeve-Injector	393-3659
239-1497	Trunnion	394-0197
248-2987	Guide	419-4709

TJA		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4106	Pin As-Drawbar	325-6126

Sales Model D7E (Cont'd.)

TJA		
Original Part Number	Part Name	Classic Part Number
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1T-0043	Bearing-Ball	390-5294
1U-0725	Retainer	314-8707
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1W-4738	Bearing-Sleeve	325-6020
3D-9133	Cup-Roller Brg	418-9601
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3H-1996	Bearing-Ball	380-1498
3J-2682	Bracket	296-1345
3J-6484	Bearing-Sleeve	380-7383
3T-4008	Gear-Planet	295-5444
3T-5294	Spacer	325-6216
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6374	Bearing-Sleeve	295-6407
4M-3915	Bearing-Caged	377-7427

TJA		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4T-5495	Ballstud	314-8626
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-6659	Bearing	417-4511
5F-2465	Cup-Roller Brg	447-8060
5J-1192	Bearing-Sleeve	374-8355
5P-3930	Bearing As-Rlr	419-6022
6H-3566	Cone-Bearing	415-1918
6I-8860	Cup-Roller Brg	380-7495
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-6752	Pin	325-6150
7C-3567	Mount As	314-8689
7J-1309	Bearing-Aligning	360-2275
7J-1336	Bearing-Sleeve	384-4776
7S-3002	Bearing-Spl Ball	386-4961

TJA		
Original Part Number	Part Name	Classic Part Number
7S-4534	Bearing-Caged	417-9497
8D-0983	Mounting	384-3470
8E-5450	Seal-Ebar	325-6190
8H-8898	Pin	385-3801
9J-0123	Trunnion	325-6227
9J-5284	Bearing-Sleeve	380-7379
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-1677	Bearing	297-7145
9W-4897	Bracket As	295-6414
9Y-2988	Breather As	361-1716
100-8010	Valve	423-5583
110-8368	Bearing-Cup	416-2172
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
239-1497	Trunnion	394-0197
248-2987	Guide	419-4709

Sales Model D7F

61G		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1M-3917	Shaft	386-4915
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0623	Bearing	420-3224

61G		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-4303	Head As-Cylinder	242-3434
1P-7590	Support As-Fr	213-4400
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224
1S-2233	Bearing-Sleeve	379-0188
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442

61G		
Original Part Number	Part Name	Classic Part Number
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683

Sales Model D7F (Cont'd.)

61G		
Original Part Number	Part Name	Classic Part Number
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7082	Rebuild Kt-Pump	383-3681
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-7116	Strip-Tapping	384-3480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2784	Ejector As-Exh	367-6063
2P-2788	Adapter-Fan	390-0984

61G		
Original Part Number	Part Name	Classic Part Number
2P-2811	Race-Spl Rlr Brg	417-4528
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2P-3767	Tube-Disposal	377-5850
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6245	Shaft As-Pump	325-6197
2S-3946	Gear-Final Drive	215-1678
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6401	Cup-Roller Brg	380-7497
2S-7062	Shaft-Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3H-8726	Mount As	385-7208
3J-2443	Bearing	383-2125
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188

61G		
Original Part Number	Part Name	Classic Part Number
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
4D-2619	Bearing	417-4494
4F-5003	Spring As-Arm	383-2127
4J-1999	Ballstud	314-8625
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4M-0410	Gear-Oil Pump Dr	428-6660
4N-0432	Bearing-Ball	417-4499
4N-4864	Pump Gp-F Tfr	242-3442
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-7993	Pin	319-3454
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-2054	Bearing	380-7510

Sales Model D7F (Cont'd.)

61G		
Original Part Number	Part Name	Classic Part Number
5M-2971	Guard As-F Idler	226-0190
5M-3499	Shaft-Planet	319-3475
5M-3941	Shaft-Planet	215-1691
5M-3942	Shaft-Planet	215-1692
5M-5822	Gear-Pump Drive	247-4120
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-7864	Pump Gp-Scavenge	226-0169
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2904	Bearing	295-5673
6H-2577	Spider Gp-Brg	333-4954
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-2820	Pump Gp-Eng Oil	415-1903
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386

61G		
Original Part Number	Part Name	Classic Part Number
6P-4327	Pad	384-3472
6P-6653	Plate-Guide	226-0208
6T-0960	Pad As	367-6089
6T-1980	Collar-Idler End	226-0210
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7G-2474	Gear-Planet	300-2577
7G-2517	Gear-Planet	213-8747
7G-2521	Gear-Planet	213-8749
7G-6576	Cage As	216-7859
7H-4566	Cup-Roller Brg	399-6068
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-2949	Pulley	264-5887
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700

61G		
Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As-Radiator	295-6417
7T-0204	Bearing-Brace	247-4126
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290

Sales Model D7F (Cont'd.)

61G		
Original Part Number	**Part Name**	**Classic Part Number**
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0187	Nut-Adjusting	219-9676
8P-1865	Bar As-Equalizer	231-3313
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
9G-0007	Hub	224-1311
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517

61G		
Original Part Number	**Part Name**	**Classic Part Number**
9N-5251	Piston Gp-Bsc	250-6557
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9S-1267	Ejector As-Exh	397-5059
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6147	Body As	369-9499
9S-6875	Pinion-Final Dr	217-7705
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
128-3935	Bearing-Race	396-9897
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353

61G		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
250-6557	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005

91E		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8776	Bearing-Roller	417-4516
1S-2233	Bearing-Sleeve	379-0188
1U-2135	Cyl Gp-0121 0955	395-1304

91E		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513

91E		
Original Part Number	**Part Name**	**Classic Part Number**
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2J-5596	Pin-Pivot	297-7211
2M-4668	Retainer-Guard	297-4867

Sales Model D7F (Cont'd.)

91E		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
2P-2811	Race-Spl Rlr Brg	417-4528
2S-6097	Tang	375-9979
2S-6401	Cup-Roller Brg	380-7497
3F-6149	Pin	299-2033
3J-1943	Collar	468-5015
3J-2443	Bearing	383-2125
3J-2682	Bracket	296-1345
3J-6502	Pin	319-3453
3J-6558	Brace As	416-5522
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3L-1425	Bearing-Ball	311-9356
3S-9669	Bearing	416-2168
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4J-6167	Bearing-Sleeve	325-6009
4N-7693	Crankshaft As	269-8763

91E		
Original Part Number	Part Name	Classic Part Number
4S-8472	Hood As-Preclnr	296-1355
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5J-2528	Plunger	391-1318
5J-4321	Trunnion	302-2700
5P-8768	Kit-Gasket (Scl)	393-1024
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6J-9258	Trunnion As	256-4846
6N-7263	Gasket-Cyl Head	380-7386
7C-4297	Seal As-Cshaft	325-6192
7F-9541	Pin As-Drawbar	296-1361
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3338	Rod As	394-0906
7J-5131	Trunnion	296-1371
7J-7488	Bearing	256-4836
7N-2957	Cover-Rad Cap	361-1722
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417

91E		
Original Part Number	Part Name	Classic Part Number
8H-1383	Rod-Tie	299-2051
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
9S-4829	Race-Brg Inner	423-9668
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112

92E		
Original Part Number	Part Name	Classic Part Number
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1P-0623	Bearing	420-3224
1S-2233	Bearing-Sleeve	379-0188
1T-0043	Bearing-Ball	390-5294
1T-0441	Bearing-Ball	449-4738
1T-0902	Bearing-Sleeve	389-6326
1U-2135	Cyl Gp-0121 0955	395-1304
1W-3900	Gasket	472-8006
1W-7082	Rebuild Kt-Pump	383-3681

92E		
Original Part Number	Part Name	Classic Part Number
1W-9812	Gear-Crankshaft	380-1513
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2J-5596	Pin-Pivot	297-7211
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-2811	Race-Spl Rlr Brg	417-4528
2P-3767	Tube-Disposal	377-5850
2S-6097	Tang	375-9979
2S-6401	Cup-Roller Brg	380-7497
2W-7678	Gear-Water Pump	325-6088

92E		
Original Part Number	Part Name	Classic Part Number
3F-6149	Pin	299-2033
3J-1943	Collar	468-5015
3J-2443	Bearing	383-2125
3J-2682	Bracket	296-1345
3J-6502	Pin	319-3453
3J-6558	Brace As	416-5522
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265

Sales Model D7F (Cont'd.)

92E		
Original Part Number	**Part Name**	**Classic Part Number**
3J-6577	Pin-Brace	367-6077
3L-1425	Bearing-Ball	311-9356
3S-9669	Bearing	416-2168
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4J-6167	Bearing-Sleeve	325-6009
4N-7693	Crankshaft As	269-8763
4S-8472	Hood As-Preclnr	296-1355
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5J-2528	Plunger	391-1318
5J-4321	Trunnion	302-2700
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-8768	Kit-Gasket (Scl)	393-1024
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6J-9258	Trunnion As	256-4846

92E		
Original Part Number	**Part Name**	**Classic Part Number**
6N-7263	Gasket-Cyl Head	380-7386
7C-4297	Seal As-Cshaft	325-6192
7F-9541	Pin As-Drawbar	296-1361
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3338	Rod As	394-0906
7J-5131	Trunnion	296-1371
7J-7488	Bearing	256-4836
7N-2957	Cover-Rad Cap	361-1722
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
8H-1383	Rod-Tie	299-2051
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

92E		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
9M-1997	Bearing-Ball	384-5954
9S-4829	Race-Brg Inner	423-9668
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
128-3935	Bearing-Race	396-9897
131-3815	Seal Gp-Basic	325-6193
155-8698	Gasket Kit	394-0914
156-8206	Kit-Dt Gasket	451-3112
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112

93N		
Original Part Number	**Part Name**	**Classic Part Number**
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678

93N		
Original Part Number	**Part Name**	**Classic Part Number**
1P-0623	Bearing	420-3224
1P-1006	Strip-Guard	226-0245
1P-1367	Plunger-Valve	432-8913
1P-2187	Pump Gp-Gr 1 Bsc	299-2044
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1P-7590	Support As-Fr	213-4400
1P-8554	Coupling-Exhaust	325-6052
1P-8835	Shaft As	215-1672
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188

93N		
Original Part Number	**Part Name**	**Classic Part Number**
1S-3062	Director-Water	418-9572
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368

Sales Model D7F (Cont'd.)

93N		
Original Part Number	Part Name	Classic Part Number
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-2135	Cyl Gp-0121 0955	395-1304
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2H-9192	Bearing-Ball	394-8236
2J-5596	Pin-Pivot	297-7211
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-7116	Strip-Tapping	384-3480
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164

93N		
Original Part Number	Part Name	Classic Part Number
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2784	Ejector As-Exh	367-6063
2P-2788	Adapter-Fan	390-0984
2P-2811	Race-Spl Rlr Brg	417-4528
2P-2922	Gear-Transfer	219-9679
2P-2923	Gear-Transfer	219-9680
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2P-3598	Shaft-Output	215-1676
2P-3669	Pinion-Bevel	215-1677
2P-3767	Tube-Disposal	377-5850
2P-4370	Plate-Clutch	325-6166
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-5608	Pipe-Extension	367-6066
2P-6245	Shaft As-Pump	325-6197
2S-3946	Gear-Final Drive	215-1678
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6401	Cup-Roller Brg	380-7497
2S-6739	Pulley-Tightener	298-2794
2S-7062	Shaft-Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356

93N		
Original Part Number	Part Name	Classic Part Number
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2443	Bearing	383-2125
3J-2682	Bracket	296-1345
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961
3J-6502	Pin	319-3453
3J-6558	Brace As	416-5522
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3K-0526	Bearing-Ball	386-4949
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-0395	Cage-Carrier Brg	217-7723
3P-1885	Spring-Recoil	375-5449
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3P-3241	Plate-Pressure	325-6167
3P-4135	Support As	396-7266
3P-4142	Plate As	299-2039
3P-4143	Suspension As	393-3644
3P-4157	Yoke As-Idler	226-0221

Sales Model D7F (Cont'd.)

93N		
Original Part Number	Part Name	Classic Part Number
3P-4197	Guard As-Idler	226-0189
3P-6560	Stop-Rec Spring	226-0232
3P-6561	Stop-Rec Spring	226-0233
3P-6814	Pump Gp-Gr 1	226-0163
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-5003	Spring As-Arm	383-2127
4H-4021	Plate As-Loading	229-8219
4J-1616	Bracket	299-1982
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4K-7463	Seal-Lip Type	472-8007
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4864	Pump Gp-F Tfr	242-3442
4N-4878	Pump Gp-F Tfr	390-0995
4N-7692	Crankshaft As	269-8764

93N		
Original Part Number	Part Name	Classic Part Number
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-6707	Piston-Clutch	215-1686
4S-8472	Hood As-Preclnr	296-1355
4S-8708	Housing-Clutch	216-3557
4W-0452	Seal As -Cshaft	325-6191
4W-5363	Core Gp-O Clr	380-7531
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5G-3612	Cap Gp-Protn	295-6419
5H-5500	Collar-Fly Cl	302-2704
5J-2528	Plunger	391-1318
5J-3506	Retainer	399-8551
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5L-6326	Bearing-Ball	420-3222
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-2971	Guard As-F Idler	226-0190
5M-5822	Gear-Pump Drive	247-4120
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6709	Check As-Ball	380-7542
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953

93N		
Original Part Number	Part Name	Classic Part Number
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-8739	Spider Gp-Brg	373-5386
6B-7469	Spacer	417-4535
6F-7523	Cap-Bearing	325-6039
6H-2577	Spider Gp-Brg	333-4954
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-5342	Retainer	325-6182
6J-6229	Pin	299-2030
6J-9258	Trunnion As	256-4846
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0714	Pulley-Alt	264-5884
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-1218	Core As-Radiator	379-0181
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386

Sales Model D7F (Cont'd.)

93N		
Original Part Number	Part Name	Classic Part Number
6P-0169	Hub-Fly Clutch	297-7204
6P-0236	Guide-Lever	422-6475
6P-2322	Plate	389-6311
6P-4327	Pad	384-3472
6P-5172	Guard Gp-Rec -A	226-0196
6P-5173	Guard Gp-Rec -A	229-8617
6P-5343	Rod Gp-Tck Adj	226-0200
6P-6653	Plate-Guide	226-0208
6S-2828	Cup-Roller Brg	384-5932
6T-0960	Pad As	367-6089
6T-1980	Collar-Idler End	226-0210
6V-1033	Rod End-Spher	375-5444
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-5916	Disc-Friction	377-7442
6Y-7920	Disc-Friction	388-0587
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-2500	Gear-Planet	296-1350
7G-6576	Cage As	216-7859
7H-4566	Cup-Roller Brg	399-6068
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3338	Rod As	394-0906
7J-5131	Trunnion	296-1371
7J-7488	Bearing	256-4836
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922

93N		
Original Part Number	Part Name	Classic Part Number
7M-1296	Valve-Relief	390-0990
7M-1889	Guard As	213-9108
7M-1890	Guard As-Fd Wear	213-9109
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417
7S-7973	Guard-Fd Wear	213-9110
7T-0119	Support As	299-2066
7T-0204	Bearing-Brace	247-4126

93N		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8B-8439	Bearing-Ball	399-6069
8C-8741	Kit-Gasket-(Rs)	438-0172
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8F-6058	Bearing-Sleeve	416-5494
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

Sales Model D7F (Cont'd.)

93N		
Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734
8P-1865	Bar As-Equalizer	231-3313

93N		
Original Part Number	Part Name	Classic Part Number
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-0007	Hub	224-1311
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-5058	Pump Gp-Vn Bsc-B	422-8170
9K-8757	Rod End-Special	311-9361
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-8119	Retainer-Inlet	226-8022
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904

93N		
Original Part Number	Part Name	Classic Part Number
9P-7917	Valve Gp-Cont -C	385-3810
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1267	Ejector As-Exh	397-5059
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-6590	Pump Gp-Cl Oil	226-0176
9S-6875	Pinion-Final Dr	217-7705
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
131-3815	Seal Gp-Basic	325-6193
147-9670	Fan As-Rev	435-9912
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194

Sales Model D7F (Cont'd.)

93N		
Original Part Number	**Part Name**	**Classic Part Number**
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

93N		
Original Part Number	**Part Name**	**Classic Part Number**
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892

93N		
Original Part Number	**Part Name**	**Classic Part Number**
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

94N		
Original Part Number	**Part Name**	**Classic Part Number**
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1M-3917	Shaft	386-4915
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0623	Bearing	420-3224
1P-1006	Strip-Guard	226-0245
1P-1367	Plunger-Valve	432-8913
1P-2187	Pump Gp-Gr 1 Bsc	299-2044
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1P-7590	Support As-Fr	213-4400
1P-8554	Coupling-Exhaust	325-6052
1P-8835	Shaft As	215-1672
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147

94N		
Original Part Number	**Part Name**	**Classic Part Number**
1S-2233	Bearing-Sleeve	379-0188
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-2135	Cyl Gp-0121 0955	395-1304
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659

94N		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-5596	Pin-Pivot	297-7211
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-7116	Strip-Tapping	384-3480
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2407	Pulley	383-3684

Sales Model D7F (Cont'd.)

94N		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2784	Ejector As-Exh	367-6063
2P-2788	Adapter-Fan	390-0984
2P-2811	Race-Spl Rlr Brg	417-4528
2P-2922	Gear-Transfer	219-9679
2P-2923	Gear-Transfer	219-9680
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2P-3598	Shaft-Output	215-1676
2P-3669	Pinion-Bevel	215-1677
2P-3767	Tube-Disposal	377-5850
2P-4370	Plate-Clutch	325-6166
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-5608	Pipe-Extension	367-6066
2P-6245	Shaft As-Pump	325-6197
2S-3946	Gear-Final Drive	215-1678
2S-4015	Plunger As-Valve	311-9438
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6401	Cup-Roller Brg	380-7497
2S-6739	Pulley-Tightener	298-2794
2S-7062	Shaft-Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439

94N		
Original Part Number	Part Name	Classic Part Number
2W-7678	Gear-Water Pump	325-6088
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2443	Bearing	383-2125
3J-2682	Bracket	296-1345
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961
3J-6502	Pin	319-3453
3J-6558	Brace As	416-5522
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3K-0526	Bearing-Ball	386-4949
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-0395	Cage-Carrier Brg	217-7723
3P-1885	Spring-Recoil	375-5449
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3P-4135	Support As	396-7266
3P-4142	Plate As	299-2039
3P-4143	Suspension As	393-3644
3P-4157	Yoke As-Idler	226-0221
3P-4197	Guard As-Idler	226-0189
3P-6560	Stop-Rec Spring	226-0232
3P-6561	Stop-Rec Spring	226-0233
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188

94N		
Original Part Number	Part Name	Classic Part Number
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-5003	Spring As-Arm	383-2127
4J-1616	Bracket	299-1982
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4864	Pump Gp-F Tfr	242-3442
4N-4878	Pump Gp-F Tfr	390-0995
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-6707	Piston-Clutch	215-1686
4S-8472	Hood As-Preclnr	296-1355
4S-8708	Housing-Clutch	216-3557
4W-0452	Seal As -Cshaft	325-6191
4W-5363	Core Gp-O Clr	380-7531
4W-7188	Core As-Oclr	374-7501

Sales Model D7F (Cont'd.)

94N		
Original Part Number	Part Name	Classic Part Number
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5G-3612	Cap Gp-Protn	295-6419
5J-2528	Plunger	391-1318
5J-3506	Retainer	399-8551
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5L-6326	Bearing-Ball	420-3222
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-2054	Bearing	380-7510
5M-2971	Guard As-F Idler	226-0190
5M-3499	Shaft-Planet	319-3475
5M-3941	Shaft-Planet	215-1691
5M-3942	Shaft-Planet	215-1692
5M-5822	Gear-Pump Drive	247-4120
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6709	Check As-Ball	380-7542
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247

94N		
Original Part Number	Part Name	Classic Part Number
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-8739	Spider Gp-Brg	373-5386
6B-7469	Spacer	417-4535
6F-7523	Cap-Bearing	325-6039
6H-2577	Spider Gp-Brg	333-4954
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-5342	Retainer	325-6182
6J-6229	Pin	299-2030
6J-9258	Trunnion As	256-4846
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0714	Pulley-Alt	264-5884
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-1218	Core As-Radiator	379-0181
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0236	Guide-Lever	422-6475
6P-2322	Plate	389-6311
6P-4327	Pad	384-3472
6P-5172	Guard Gp-Rec -A	226-0196
6P-5173	Guard Gp-Rec -A	229-8617
6P-5343	Rod Gp-Tck Adj	226-0200
6P-6653	Plate-Guide	226-0208

94N		
Original Part Number	Part Name	Classic Part Number
6S-2828	Cup-Roller Brg	384-5932
6T-0960	Pad As	367-6089
6T-1980	Collar-Idler End	226-0210
6V-1033	Rod End-Spher	375-5444
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-5916	Disc-Friction	377-7442
6Y-7920	Disc-Friction	388-0587
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-2500	Gear-Planet	296-1350
7G-2517	Gear-Planet	213-8747
7G-2521	Gear-Planet	213-8749
7G-6576	Cage As	216-7859
7H-4566	Cup-Roller Brg	399-6068
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3338	Rod As	394-0906
7J-5131	Trunnion	296-1371
7J-7488	Bearing	256-4836
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-1889	Guard As	213-9108
7M-1890	Guard As-Fd Wear	213-9109
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670

Sales Model D7F (Cont'd.)

94N		
Original Part Number	Part Name	Classic Part Number
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417
7S-7973	Guard-Fd Wear	213-9110
7T-0119	Support As	299-2066
7T-0204	Bearing-Brace	247-4126
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069

94N		
Original Part Number	Part Name	Classic Part Number
8C-8741	Kit-Gasket-(Rs)	438-0172
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8F-6058	Bearing-Sleeve	416-5494
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555

94N		
Original Part Number	Part Name	Classic Part Number
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734
8P-1865	Bar As-Equalizer	231-3313
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042

Sales Model D7F (Cont'd.)

94N		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9B-1320	Valve-Check	377-5832
9G-0007	Hub	224-1311
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-5058	Pump Gp-Vn Bsc-B	422-8170
9K-8757	Rod End-Special	311-9361
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-7917	Valve Gp-Cont -C	385-3810
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241

94N		
Original Part Number	Part Name	Classic Part Number
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1267	Ejector As-Exh	397-5059
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-6875	Pinion-Final Dr	217-7705
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
128-3935	Bearing-Race	396-9897
131-3815	Seal Gp-Basic	325-6193

94N		
Original Part Number	Part Name	Classic Part Number
147-9670	Fan As-Rev	435-9912
155-8698	Gasket Kit	394-0914
156-8206	Kit-Dt Gasket	451-3112
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

Sales Model D7G

35N		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119

Sales Model D7G (Cont'd.)

35N		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-8382	Gear-Oil Pump Dr	226-6103
1L-7319	Cup-Roller Brg	380-7499
1M-8776	Bearing-Roller	417-4516
1M-9029	Guard	226-0219
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1P-1006	Strip-Guard	226-0245
1P-1367	Plunger-Valve	432-8913
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7590	Support As-Fr	213-4400
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188
1S-3062	Director-Water	418-9572
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9110	Bearing-Needle	420-2497
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914

35N		
Original Part Number	Part Name	Classic Part Number
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2K-5804	Rod End-Spher	416-2151
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4668	Retainer-Guard	297-4867
2M-7116	Strip-Tapping	384-3480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2784	Ejector As-Exh	367-6063
2P-2788	Adapter-Fan	390-0984
2P-2811	Race-Spl Rlr Brg	417-4528
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2P-3767	Tube-Disposal	377-5850
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6245	Shaft As-Pump	325-6197
2S-3946	Gear-Final Drive	215-1678

35N		
Original Part Number	Part Name	Classic Part Number
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6401	Cup-Roller Brg	380-7497
2S-7062	Shaft-Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3G-7655	Cartridge Gp	422-8119
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1885	Spring-Recoil	375-5449
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3P-3241	Plate-Pressure	325-6167
3P-4135	Support As	396-7266
3P-4142	Plate As	299-2039
3P-4143	Suspension As	393-3644
3P-4157	Yoke As-Idler	226-0221
3P-4197	Guard As-Idler	226-0189
3P-6560	Stop-Rec Spring	226-0232
3P-6561	Stop-Rec Spring	226-0233
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824

Sales Model D7G (Cont'd.)

35N		
Original Part Number	Part Name	Classic Part Number
4F-5003	Spring As-Arm	383-2127
4H-4021	Plate As-Loading	229-8219
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5G-3612	Cap Gp-Protn	295-6419
5H-5500	Collar-Fly Cl	302-2704
5L-6326	Bearing-Ball	420-3222
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502

35N		
Original Part Number	Part Name	Classic Part Number
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-7129	Housing	472-8013
6B-7469	Spacer	417-4535
6H-2577	Spider Gp-Brg	333-4954
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6N-0714	Pulley-Alt	264-5884
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-1218	Core As-Radiator	379-0181
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-0169	Hub-Fly Clutch	297-7204
6P-2322	Plate	389-6311
6P-4327	Pad	384-3472
6P-5172	Guard Gp-Rec -A	226-0196
6P-5173	Guard Gp-Rec -A	229-8617
6P-5343	Rod Gp-Tck Adj	226-0200
6P-6653	Plate-Guide	226-0208
6T-0960	Pad As	367-6089

35N		
Original Part Number	Part Name	Classic Part Number
6T-1980	Collar-Idler End	226-0210
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
7C-4297	Seal As-Cshaft	325-6192
7D-7889	Gear-Ring	275-5276
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7G-6576	Cage As	216-7859
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-4618	Ejector As-Exh	397-5060
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700

Sales Model D7G (Cont'd.)

35N		
Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As-Radiator	295-6417
7T-0119	Support As	299-2066
7T-0204	Bearing-Brace	247-4126
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-3744	Shaft-Drive	275-5283
8D-3877	Gear-Sun	275-5278
8D-8159	Retainer	419-8661
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8M-7166	Housing-Screen	297-7192
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623

35N		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734
8P-1865	Bar As-Equalizer	231-3313
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-7818	Bracket	226-0211

35N		
Original Part Number	Part Name	Classic Part Number
8W-2308	Shaft-Planet	275-5285
8W-8317	Sprocket	275-5287
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-0007	Hub	224-1311
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-5908	Gasket	433-8196
9M-3025	Cover As	299-2001
9M-5477	Bearing-Sleeve	374-6517
9M-8119	Retainer-Inlet	226-8022
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1267	Ejector As-Exh	397-5059
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-6590	Pump Gp-Cl Oil	226-0176
9S-6875	Pinion-Final Dr	217-7705
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
129-2381	Gear-Planet	275-5274
131-3815	Seal Gp-Basic	325-6193
147-9670	Fan As-Rev	435-9912
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125

Sales Model D7G (Cont'd.)

35N		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484

35N		
Original Part Number	**Part Name**	**Classic Part Number**
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489

35N		
Original Part Number	**Part Name**	**Classic Part Number**
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
236-7724	Retainer	299-2048
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

3GF		
Original Part Number	**Part Name**	**Classic Part Number**
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0623	Bearing	420-3224
1P-1367	Plunger-Valve	432-8913
1P-2187	Pump Gp-Gr 1 Bsc	299-2044
1P-4110	Disc-Friction	433-9858
1P-7590	Support As-Fr	213-4400
1P-8835	Shaft As	215-1672
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224
1S-2233	Bearing-Sleeve	379-0188

3GF		
Original Part Number	**Part Name**	**Classic Part Number**
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-2135	Cyl Gp-0121 0955	395-1304
1W-1219	Trunnion As	314-8724

3GF		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-5596	Pin-Pivot	297-7211
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4668	Retainer-Guard	297-4867
2M-7116	Strip-Tapping	384-3480

Sales Model D7G (Cont'd.)

3GF		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2784	Ejector As-Exh	367-6063
2P-2788	Adapter-Fan	390-0984
2P-2811	Race-Spl Rlr Brg	417-4528
2P-2922	Gear-Transfer	219-9679
2P-2923	Gear-Transfer	219-9680
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2P-3598	Shaft-Output	215-1676
2P-3669	Pinion-Bevel	215-1677
2P-3767	Tube-Disposal	377-5850
2P-4370	Plate-Clutch	325-6166
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6245	Shaft As-Pump	325-6197
2S-3946	Gear-Final Drive	215-1678
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6401	Cup-Roller Brg	380-7497
2S-6739	Pulley-Tightener	298-2794
2S-7062	Shaft-Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2S-7931	Bearing-Sleeve	387-2904

3GF		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3G-7660	Cartridge Gp	422-8103
3G-7663	Cartridge Gp	422-8120
3J-1943	Collar	468-5015
3J-2443	Bearing	383-2125
3J-2682	Bracket	296-1345
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961
3J-6502	Pin	319-3453
3J-6558	Brace As	416-5522
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0395	Cage-Carrier Brg	217-7723
3P-1885	Spring-Recoil	375-5449
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3P-4135	Support As	396-7266
3P-4142	Plate As	299-2039
3P-4143	Suspension As	393-3644

3GF		
Original Part Number	Part Name	Classic Part Number
3P-4157	Yoke As-Idler	226-0221
3P-4197	Guard As-Idler	226-0189
3P-6560	Stop-Rec Spring	226-0232
3P-6561	Stop-Rec Spring	226-0233
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-5003	Spring As-Arm	383-2127
4J-1616	Bracket	299-1982
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987

Sales Model D7G (Cont'd.)

3GF		
Original Part Number	Part Name	Classic Part Number
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-6707	Piston-Clutch	215-1686
4S-8708	Housing-Clutch	216-3557
4T-4073	Valve Gp-Shtl -B	439-1138
4T-9290	Cyl Gp-0152 0495	399-8579
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5J-2528	Plunger	391-1318
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-5822	Gear-Pump Drive	247-4120
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467

3GF		
Original Part Number	Part Name	Classic Part Number
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-7523	Cap-Bearing	325-6039
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-5342	Retainer	325-6182
6J-6229	Pin	299-2030
6J-9258	Trunnion As	256-4846
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0714	Pulley-Alt	264-5884
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0236	Guide-Lever	422-6475
6P-2322	Plate	389-6311
6P-4327	Pad	384-3472
6P-5172	Guard Gp-Rec -A	226-0196
6P-5173	Guard Gp-Rec -A	229-8617
6P-5343	Rod Gp-Tck Adj	226-0200
6P-6653	Plate-Guide	226-0208
6S-2828	Cup-Roller Brg	384-5932
6T-0960	Pad As	367-6089
6T-1980	Collar-Idler End	226-0210
6V-2202	Bearing-Spl Ball	380-1574

3GF		
Original Part Number	Part Name	Classic Part Number
6Y-5916	Disc-Friction	377-7442
6Y-7920	Disc-Friction	388-0587
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-2500	Gear-Planet	296-1350
7G-6576	Cage As	216-7859
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3338	Rod As	394-0906
7J-5131	Trunnion	296-1371
7J-7488	Bearing	256-4836
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417

Sales Model D7G (Cont'd.)

3GF		
Original Part Number	Part Name	Classic Part Number
7T-0119	Support As	299-2066
7T-0204	Bearing-Brace	247-4126
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-7466	Seat	385-3787
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623

3GF		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734
8P-1865	Bar As-Equalizer	231-3313
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0007	Hub	224-1311
9J-5058	Pump Gp-Vn Bsc-B	422-8170
9L-2685	Rod End	419-1866
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875

3GF		
Original Part Number	Part Name	Classic Part Number
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-3025	Cover As	299-2001
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-7917	Valve Gp-Cont -C	385-3810
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1267	Ejector As-Exh	397-5059
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6147	Body As	369-9499
9S-6875	Pinion-Final Dr	217-7705
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160

Sales Model D7G (Cont'd.)

3GF		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
147-9670	Fan As-Rev	435-9912
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

3GF		
Original Part Number	Part Name	Classic Part Number
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

3GF		
Original Part Number	Part Name	Classic Part Number
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

3ZD		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0623	Bearing	420-3224
1P-1367	Plunger-Valve	432-8913
1P-2187	Pump Gp-Gr 1 Bsc	299-2044
1P-4110	Disc-Friction	433-9858
1P-7590	Support As-Fr	213-4400
1P-8835	Shaft As	215-1672
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224
1S-2233	Bearing-Sleeve	379-0188
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017

3ZD		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-2135	Cyl Gp-0121 0955	395-1304
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

3ZD		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-5596	Pin-Pivot	297-7211
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4668	Retainer-Guard	297-4867
2M-7116	Strip-Tapping	384-3480
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164

Sales Model D7G (Cont'd.)

3ZD		
Original Part Number	Part Name	Classic Part Number
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2784	Ejector As-Exh	367-6063
2P-2788	Adapter-Fan	390-0984
2P-2811	Race-Spl Rlr Brg	417-4528
2P-2922	Gear-Transfer	219-9679
2P-2923	Gear-Transfer	219-9680
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2P-3598	Shaft-Output	215-1676
2P-3669	Pinion-Bevel	215-1677
2P-3767	Tube-Disposal	377-5850
2P-4370	Plate-Clutch	325-6166
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6245	Shaft As-Pump	325-6197
2S-3946	Gear-Final Drive	215-1678
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6401	Cup-Roller Brg	380-7497
2S-7062	Shaft-Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452

3ZD		
Original Part Number	Part Name	Classic Part Number
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3G-7660	Cartridge Gp	422-8103
3G-7663	Cartridge Gp	422-8120
3J-1943	Collar	468-5015
3J-2443	Bearing	383-2125
3J-2682	Bracket	296-1345
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961
3J-6502	Pin	319-3453
3J-6558	Brace As	416-5522
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3P-0395	Cage-Carrier Brg	217-7723
3P-1885	Spring-Recoil	375-5449
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3P-4135	Support As	396-7266
3P-4142	Plate As	299-2039
3P-4143	Suspension As	393-3644
3P-4157	Yoke As-Idler	226-0221
3P-4197	Guard As-Idler	226-0189
3P-6560	Stop-Rec Spring	226-0232
3P-6561	Stop-Rec Spring	226-0233
3S-3875	Screen-Suction	435-4849

3ZD		
Original Part Number	Part Name	Classic Part Number
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-5003	Spring As-Arm	383-2127
4J-1616	Bracket	299-1982
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-6707	Piston-Clutch	215-1686
4S-8708	Housing-Clutch	216-3557
4T-4073	Valve Gp-Shtl -B	439-1138

Sales Model D7G (Cont'd.)

3ZD		
Original Part Number	Part Name	Classic Part Number
4T-9290	Cyl Gp-0152 0495	399-8579
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5J-2528	Plunger	391-1318
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-5822	Gear-Pump Drive	247-4120
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

3ZD		
Original Part Number	Part Name	Classic Part Number
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-7523	Cap-Bearing	325-6039
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-5342	Retainer	325-6182
6J-6229	Pin	299-2030
6J-9258	Trunnion As	256-4846
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0714	Pulley-Alt	264-5884
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0236	Guide-Lever	422-6475
6P-2322	Plate	389-6311
6P-4327	Pad	384-3472
6P-5172	Guard Gp-Rec -A	226-0196
6P-5173	Guard Gp-Rec -A	229-8617
6P-5343	Rod Gp-Tck Adj	226-0200
6P-6653	Plate-Guide	226-0208
6S-2828	Cup-Roller Brg	384-5932
6T-0960	Pad As	367-6089
6T-1980	Collar-Idler End	226-0210
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
6Y-7920	Disc-Friction	388-0587
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414

3ZD		
Original Part Number	Part Name	Classic Part Number
7G-2037	Joint Gp-Univ	226-8017
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-2500	Gear-Planet	296-1350
7G-6576	Cage As	216-7859
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3338	Rod As	394-0906
7J-5131	Trunnion	296-1371
7J-7488	Bearing	256-4836
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417
7T-0204	Bearing-Brace	247-4126
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684

Sales Model D7G (Cont'd.)

3ZD		
Original Part Number	Part Name	Classic Part Number
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-7466	Seat	385-3787
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

3ZD		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1653	Nut-Sprocket Adj	449-4734
8P-1865	Bar As-Equalizer	231-3313
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0007	Hub	224-1311
9J-5058	Pump Gp-Vn Bsc-B	422-8170
9L-2685	Rod End	419-1866
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533

3ZD		
Original Part Number	Part Name	Classic Part Number
9M-3025	Cover As	299-2001
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-7917	Valve Gp-Cont -C	385-3810
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1267	Ejector As-Exh	397-5059
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6147	Body As	369-9499
9S-6875	Pinion-Final Dr	217-7705
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
131-3815	Seal Gp-Basic	325-6193

Sales Model D7G (Cont'd.)

3ZD		
Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194

3ZD		
Original Part Number	Part Name	Classic Part Number
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

3ZD		
Original Part Number	Part Name	Classic Part Number
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

44W		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1L-7319	Cup-Roller Brg	380-7499
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0623	Bearing	420-3224
1P-1367	Plunger-Valve	432-8913
1P-2187	Pump Gp-Gr 1 Bsc	299-2044
1P-4110	Disc-Friction	433-9858
1P-7590	Support As-Fr	213-4400
1P-8554	Coupling-Exhaust	325-6052
1P-8835	Shaft As	215-1672
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188

44W		
Original Part Number	Part Name	Classic Part Number
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

44W		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-7116	Strip-Tapping	384-3480
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164

Sales Model D7G (Cont'd.)

44W		
Original Part Number	Part Name	Classic Part Number
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2784	Ejector As-Exh	367-6063
2P-2788	Adapter-Fan	390-0984
2P-2811	Race-Spl Rlr Brg	417-4528
2P-2922	Gear-Transfer	219-9679
2P-2923	Gear-Transfer	219-9680
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2P-3598	Shaft-Output	215-1676
2P-3669	Pinion-Bevel	215-1677
2P-3767	Tube-Disposal	377-5850
2P-4370	Plate-Clutch	325-6166
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6245	Shaft As-Pump	325-6197
2S-3946	Gear-Final Drive	215-1678
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6401	Cup-Roller Brg	380-7497
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439

44W		
Original Part Number	Part Name	Classic Part Number
2W-7678	Gear-Water Pump	325-6088
3F-4971	Pin	295-5693
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3J-2443	Bearing	383-2125
3K-0526	Bearing-Ball	386-4949
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-0395	Cage-Carrier Brg	217-7723
3P-1885	Spring-Recoil	375-5449
3P-4157	Yoke As-Idler	226-0221
3P-6560	Stop-Rec Spring	226-0232
3P-6561	Stop-Rec Spring	226-0233
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-5003	Spring As-Arm	383-2127
4J-1616	Bracket	299-1982
4J-6167	Bearing-Sleeve	325-6009
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

44W		
Original Part Number	Part Name	Classic Part Number
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-6707	Piston-Clutch	215-1686
4S-8472	Hood As-Preclnr	296-1355
4S-8708	Housing-Clutch	216-3557
4T-4073	Valve Gp-Shtl -B	439-1138
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5G-3612	Cap Gp-Protn	295-6419
5J-2528	Plunger	391-1318
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5L-6326	Bearing-Ball	420-3222
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-5822	Gear-Pump Drive	247-4120
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121

Sales Model D7G (Cont'd.)

44W		
Original Part Number	Part Name	Classic Part Number
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-7523	Cap-Bearing	325-6039
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-5342	Retainer	325-6182
6J-6229	Pin	299-2030
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0714	Pulley-Alt	264-5884
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-1218	Core As-Radiator	379-0181
6N-7174	Shield-Oil	314-8544

44W		
Original Part Number	Part Name	Classic Part Number
6N-7263	Gasket-Cyl Head	380-7386
6P-0236	Guide-Lever	422-6475
6P-6653	Plate-Guide	226-0208
6S-2828	Cup-Roller Brg	384-5932
6T-0960	Pad As	367-6089
6T-1980	Collar-Idler End	226-0210
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-5916	Disc-Friction	377-7442
6Y-7920	Disc-Friction	388-0587
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-2500	Gear-Planet	296-1350
7G-6576	Cage As	216-7859
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181

44W		
Original Part Number	Part Name	Classic Part Number
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417
7S-7973	Guard-Fd Wear	213-9110
7T-0119	Support As	299-2066
7T-0204	Bearing-Brace	247-4126
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-7466	Seat	385-3787

Sales Model D7G (Cont'd.)

44W		
Original Part Number	Part Name	Classic Part Number
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860

44W		
Original Part Number	Part Name	Classic Part Number
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0007	Hub	224-1311
9J-5058	Pump Gp-Vn Bsc-B	422-8170
9K-8757	Rod End-Special	311-9361
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-3668	Base As.-Coolant	419-4718
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050

44W		
Original Part Number	Part Name	Classic Part Number
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-7917	Valve Gp-Cont -C	385-3810
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1267	Ejector As-Exh	397-5059
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6147	Body As	369-9499
9S-6875	Pinion-Final Dr	217-7705
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160

Sales Model D7G (Cont'd.)

44W		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
147-9670	Fan As-Rev	435-9912
148-7455	Valve - Exhaust	270-4361
155-8698	Gasket Kit	394-0914
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

44W		
Original Part Number	Part Name	Classic Part Number
170-0558	Kit-Rebuild-Pump	390-1001
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920

44W		
Original Part Number	Part Name	Classic Part Number
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

45W		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1M-8776	Bearing-Roller	417-4516
1N-3576	Block Gp-Cyl	279-4978
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188
1S-3062	Director-Water	418-9572
1W-3900	Gasket	472-8006
1W-5300	Rotocoil As	443-2659
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-5804	Rod End-Spher	416-2151
2P-0220	Gasket-Pump	398-2927
2P-2811	Race-Spl Rlr Brg	417-4528
2P-3767	Tube-Disposal	377-5850
2S-6097	Tang	375-9979
2S-6401	Cup-Roller Brg	380-7497
2W-2621	Valve-Inlet	247-6892
2W-7678	Gear-Water Pump	325-6088

45W		
Original Part Number	Part Name	Classic Part Number
3F-4971	Pin	295-5693
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3J-2443	Bearing	383-2125
3K-4290	Rod End	374-1823
3S-9669	Bearing	416-2168
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4J-1616	Bracket	299-1982
4J-6167	Bearing-Sleeve	325-6009
4S-8472	Hood As-Preclnr	296-1355
4T-4073	Valve Gp-Shtl -B	439-1138
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5J-2528	Plunger	391-1318
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024

45W		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9080	Pulley-Alt Drive	264-5883
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6J-5342	Retainer	325-6182
6J-6229	Pin	299-2030
6K-8088	Bearing-Roller	399-4428
6N-0714	Pulley-Alt	264-5884
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
7C-4297	Seal As-Cshaft	325-6192
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206

Sales Model D7G (Cont'd.)

45W		
Original Part Number	**Part Name**	**Classic Part Number**
7N-2957	Cover-Rad Cap	361-1722
7N-8018	Seal-Water	418-1964
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-7546	Gasket-Plate	433-8187
8H-7577	Plate-Locking	392-4486
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-7466	Seat	385-3787
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

45W		
Original Part Number	**Part Name**	**Classic Part Number**
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
9J-5058	Pump Gp-Vn Bsc-B	422-8170
9K-8757	Rod End-Special	311-9361
9M-3025	Cover As	299-2001
9S-4829	Race-Brg Inner	423-9668
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707

45W		
Original Part Number	**Part Name**	**Classic Part Number**
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
147-9670	Fan As-Rev	435-9912
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112

4LC		
Original Part Number	**Part Name**	**Classic Part Number**
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1M-8923	Race-Brg Outer	440-3117
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0623	Bearing	420-3224
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-8835	Shaft As	215-1672
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410

4LC		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-2135	Cyl Gp-0121 0955	395-1304
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

4LC		
Original Part Number	**Part Name**	**Classic Part Number**
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-5596	Pin-Pivot	297-7211
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-7116	Strip-Tapping	384-3480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2784	Ejector As-Exh	367-6063
2P-2788	Adapter-Fan	390-0984
2P-2922	Gear-Transfer	219-9679
2P-2923	Gear-Transfer	219-9680

Sales Model D7G (Cont'd.)

4LC		
Original Part Number	Part Name	Classic Part Number
2P-3598	Shaft-Output	215-1676
2P-3669	Pinion-Bevel	215-1677
2P-3767	Tube-Disposal	377-5850
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6245	Shaft As-Pump	325-6197
2S-5551	Coupling-Exhaust	398-2934
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-6149	Pin	299-2033
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3J-1943	Collar	468-5015
3J-2443	Bearing	383-2125
3J-2682	Bracket	296-1345
3J-6502	Pin	319-3453
3J-6558	Brace As	416-5522
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3L-1425	Bearing-Ball	311-9356
3P-0395	Cage-Carrier Brg	217-7723
3P-1885	Spring-Recoil	375-5449
3P-4135	Support As	396-7266
3P-4142	Plate As	299-2039
3P-4143	Suspension As	393-3644
3P-4157	Yoke As-Idler	226-0221
3P-4197	Guard As-Idler	226-0189

4LC		
Original Part Number	Part Name	Classic Part Number
3P-6560	Stop-Rec Spring	226-0232
3P-6561	Stop-Rec Spring	226-0233
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-5003	Spring As-Arm	383-2127
4J-6167	Bearing-Sleeve	325-6009
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0432	Bearing-Ball	417-4499
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-6707	Piston-Clutch	215-1686

4LC		
Original Part Number	Part Name	Classic Part Number
4S-8708	Housing-Clutch	216-3557
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
4Y-0709	Disc-Friction	377-7431
5J-2528	Plunger	391-1318
5L-6326	Bearing-Ball	420-3222
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-5822	Gear-Pump Drive	247-4120
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883

Sales Model D7G (Cont'd.)

4LC		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6F-7523	Cap-Bearing	325-6039
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6N-0714	Pulley-Alt	264-5884
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0236	Guide-Lever	422-6475
6P-2322	Plate	389-6311
6P-4327	Pad	384-3472
6P-5172	Guard Gp-Rec -A	226-0196
6P-5173	Guard Gp-Rec -A	229-8617
6P-5343	Rod Gp-Tck Adj	226-0200
6P-6653	Plate-Guide	226-0208
6T-0960	Pad As	367-6089
6T-1980	Collar-Idler End	226-0210
6V-2202	Bearing-Spl Ball	380-1574
6Y-5916	Disc-Friction	377-7442
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7G-2037	Joint Gp-Univ	226-8017
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3338	Rod As	394-0906
7J-5131	Trunnion	296-1371
7J-7488	Bearing	256-4836
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990

4LC		
Original Part Number	Part Name	Classic Part Number
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417
7T-0204	Bearing-Brace	247-4126
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420

4LC		
Original Part Number	Part Name	Classic Part Number
8J-7466	Seat	385-3787
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585

Sales Model D7G (Cont'd.)

4LC		
Original Part Number	Part Name	Classic Part Number
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1865	Bar As-Equalizer	231-3313
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
9J-5058	Pump Gp-Vn Bsc-B	422-8170
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904

4LC		
Original Part Number	Part Name	Classic Part Number
9P-7917	Valve Gp-Cont -C	385-3810
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1267	Ejector As-Exh	397-5059
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6147	Body As	369-9499
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125

4LC		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

Sales Model D7G (Cont'd.)

4YB		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0623	Bearing	420-3224
1P-1367	Plunger-Valve	432-8913
1P-2187	Pump Gp-Gr 1 Bsc	299-2044
1P-4110	Disc-Friction	433-9858
1P-7590	Support As-Fr	213-4400
1P-8835	Shaft As	215-1672
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224
1S-2233	Bearing-Sleeve	379-0188
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920

4YB		
Original Part Number	Part Name	Classic Part Number
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-2135	Cyl Gp-0121 0955	395-1304
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4668	Retainer-Guard	297-4867
2M-7116	Strip-Tapping	384-3480
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

4YB		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2784	Ejector As-Exh	367-6063
2P-2811	Race-Spl Rlr Brg	417-4528
2P-2922	Gear-Transfer	219-9679
2P-2923	Gear-Transfer	219-9680
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2P-3598	Shaft-Output	215-1676
2P-3669	Pinion-Bevel	215-1677
2P-4370	Plate-Clutch	325-6166
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6245	Shaft As-Pump	325-6197
2S-3946	Gear-Final Drive	215-1678
2S-5551	Coupling-Exhaust	398-2934
2S-6150	Cover-Pulley	428-8817
2S-6401	Cup-Roller Brg	380-7497
2S-6739	Pulley-Tightener	298-2794
2S-7062	Shaft-Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5540	Core As-Radiator	363-7452
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3J-2443	Bearing	383-2125
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961

Sales Model D7G (Cont'd.)

4YB		
Original Part Number	Part Name	Classic Part Number
3K-0526	Bearing-Ball	386-4949
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3N-3786	Rod-Thrt Cont	397-5051
3P-0395	Cage-Carrier Brg	217-7723
3P-1885	Spring-Recoil	375-5449
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3P-4135	Support As	396-7266
3P-4142	Plate As	299-2039
3P-4143	Suspension As	393-3644
3P-4157	Yoke As-Idler	226-0221
3P-4197	Guard As-Idler	226-0189
3P-6560	Stop-Rec Spring	226-0232
3P-6561	Stop-Rec Spring	226-0233
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-5003	Spring As-Arm	383-2127
4J-1616	Bracket	299-1982
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236

4YB		
Original Part Number	Part Name	Classic Part Number
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-6707	Piston-Clutch	215-1686
4S-8708	Housing-Clutch	216-3557
4T-4073	Valve Gp-Shtl -B	439-1138
4T-9290	Cyl Gp-0152 0495	399-8579
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-2541	Shaft-Gov Cont	399-8580
4W-5363	Core Gp-O Clr	380-7531
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5J-2528	Plunger	391-1318
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-5822	Gear-Pump Drive	247-4120
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433

4YB		
Original Part Number	Part Name	Classic Part Number
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-7523	Cap-Bearing	325-6039
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-5342	Retainer	325-6182
6J-6229	Pin	299-2030
6J-9258	Trunnion As	256-4846
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0714	Pulley-Alt	264-5884

Sales Model D7G (Cont'd.)

4YB		
Original Part Number	Part Name	Classic Part Number
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0236	Guide-Lever	422-6475
6P-2322	Plate	389-6311
6P-4327	Pad	384-3472
6P-5172	Guard Gp-Rec -A	226-0196
6P-5173	Guard Gp-Rec -A	229-8617
6P-5343	Rod Gp-Tck Adj	226-0200
6P-6653	Plate-Guide	226-0208
6S-2828	Cup-Roller Brg	384-5932
6T-0960	Pad As	367-6089
6T-1980	Collar-Idler End	226-0210
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-5916	Disc-Friction	377-7442
6Y-7920	Disc-Friction	388-0587
7C-4297	Seal As-Cshaft	325-6192
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-2500	Gear-Planet	296-1350
7G-6576	Cage As	216-7859
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3338	Rod As	394-0906
7J-5131	Trunnion	296-1371
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-2949	Pulley	264-5887

4YB		
Original Part Number	Part Name	Classic Part Number
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417
7T-0119	Support As	299-2066
7T-0204	Bearing-Brace	247-4126
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2731	Retainer	423-3541
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-7466	Seat	385-3787
8L-4282	Hub	444-0573
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776

4YB		
Original Part Number	Part Name	Classic Part Number
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734

Sales Model D7G (Cont'd.)

4YB		
Original Part Number	Part Name	Classic Part Number
8P-1865	Bar As-Equalizer	231-3313
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0007	Hub	224-1311
9J-5058	Pump Gp-Vn Bsc-B	422-8170
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-3025	Cover As	299-2001
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-7917	Valve Gp-Cont -C	385-3810
9S-1043	Guard As-Guiding	226-0240

4YB		
Original Part Number	Part Name	Classic Part Number
9S-1044	Guard As-Guiding	226-0241
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1267	Ejector As-Exh	397-5059
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6147	Body As	369-9499
9S-6875	Pinion-Final Dr	217-7705
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361

4YB		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7767	Pump Gp-Water -B	296-1365
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

64V		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1M-8776	Bearing-Roller	417-4516
1M-9029	Guard	226-0219

64V		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1006	Strip-Guard	226-0245
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188

64V		
Original Part Number	Part Name	Classic Part Number
1S-3062	Director-Water	418-9572
1U-2135	Cyl Gp-0121 0955	395-1304
1W-3900	Gasket	472-8006
1W-5300	Rotocoil As	443-2659

Sales Model D7G (Cont'd.)

64V		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2J-5596	Pin-Pivot	297-7211
2K-5804	Rod End-Spher	416-2151
2M-4668	Retainer-Guard	297-4867
2P-0220	Gasket-Pump	398-2927
2P-2811	Race-Spl Rlr Brg	417-4528
2P-3767	Tube-Disposal	377-5850
2S-6097	Tang	375-9979
2S-6401	Cup-Roller Brg	380-7497
2W-2621	Valve-Inlet	247-6892
2W-5540	Core As-Radiator	363-7452
2W-7678	Gear-Water Pump	325-6088
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3G-7660	Cartridge Gp	422-8103
3G-7663	Cartridge Gp	422-8120
3J-1943	Collar	468-5015
3J-2443	Bearing	383-2125
3J-2682	Bracket	296-1345
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961
3J-6502	Pin	319-3453
3J-6558	Brace As	416-5522
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-4142	Plate As	299-2039
3S-3917	Guard As-Sprkt	226-0188

64V		
Original Part Number	Part Name	Classic Part Number
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4J-1616	Bracket	299-1982
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4S-8472	Hood As-Preclnr	296-1355
4T-4073	Valve Gp-Shtl -B	439-1138
4T-9290	Cyl Gp-0152 0495	399-8579
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5J-2528	Plunger	391-1318
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9080	Pulley-Alt Drive	264-5883
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6J-5342	Retainer	325-6182
6J-6043	Bearing-Sleeve	374-1456
6J-6229	Pin	299-2030
6J-9258	Trunnion As	256-4846
6K-8088	Bearing-Roller	399-4428
6N-0714	Pulley-Alt	264-5884
6N-1218	Core As-Radiator	379-0181
6N-7174	Shield-Oil	314-8544

64V		
Original Part Number	Part Name	Classic Part Number
6N-7263	Gasket-Cyl Head	380-7386
6P-5172	Guard Gp-Rec -A	226-0196
6P-5173	Guard Gp-Rec -A	229-8617
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
7C-4297	Seal As-Cshaft	325-6192
7F-9541	Pin As-Drawbar	296-1361
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3338	Rod As	394-0906
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-7488	Bearing	256-4836
7J-9344	Bearing-Sleeve	360-2334
7J-9884	Bearing-Sleeve	325-6016
7K-0087	Bearing-Sleeve	374-6514
7K-2135	Bearing-Roller	417-4492
7K-9638	Bearing-Sleeve	365-8827
7M-1889	Guard As	213-9108
7M-1890	Guard As-Fd Wear	213-9109
7M-4046	Bearing-Sleeve	394-8206
7N-2957	Cover-Rad Cap	361-1722
7N-8018	Seal-Water	418-1964
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-0204	Bearing-Brace	247-4126
7W-7546	Gasket-Plate	433-8187
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-1383	Rod-Tie	299-2051
8H-7577	Plate-Locking	392-4486

Sales Model D7G (Cont'd.)

64V		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-7466	Seat	385-3787
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585
8P-1865	Bar As-Equalizer	231-3313
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-7818	Bracket	226-0211
9J-5058	Pump Gp-Vn Bsc-B	422-8170

64V		
Original Part Number	Part Name	Classic Part Number
9K-8757	Rod End-Special	311-9361
9M-3025	Cover As	299-2001
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-4829	Race-Brg Inner	423-9668
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042

64V		
Original Part Number	Part Name	Classic Part Number
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
147-9670	Fan As-Rev	435-9912
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112

65V		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1L-7319	Cup-Roller Brg	380-7499
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0623	Bearing	420-3224
1P-1006	Strip-Guard	226-0245
1P-1367	Plunger-Valve	432-8913
1P-2187	Pump Gp-Gr 1 Bsc	299-2044
1P-4110	Disc-Friction	433-9858
1P-7590	Support As-Fr	213-4400
1P-8835	Shaft As	215-1672
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147

65V		
Original Part Number	Part Name	Classic Part Number
1S-2233	Bearing-Sleeve	379-0188
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-2135	Cyl Gp-0121 0955	395-1304

65V		
Original Part Number	Part Name	Classic Part Number
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-5596	Pin-Pivot	297-7211
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123

Sales Model D7G (Cont'd.)

65V		
Original Part Number	Part Name	Classic Part Number
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-7116	Strip-Tapping	384-3480
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2784	Ejector As-Exh	367-6063
2P-2788	Adapter-Fan	390-0984
2P-2811	Race-Spl Rlr Brg	417-4528
2P-2922	Gear-Transfer	219-9679
2P-2923	Gear-Transfer	219-9680
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2P-3598	Shaft-Output	215-1676
2P-3669	Pinion-Bevel	215-1677
2P-3767	Tube-Disposal	377-5850
2P-4370	Plate-Clutch	325-6166
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6245	Shaft As-Pump	325-6197
2S-3946	Gear-Final Drive	215-1678
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6401	Cup-Roller Brg	380-7497
2S-6739	Pulley-Tightener	298-2794
2S-7062	Shaft-Sprocket	219-9673

65V		
Original Part Number	Part Name	Classic Part Number
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3G-7660	Cartridge Gp	422-8103
3G-7663	Cartridge Gp	422-8120
3J-1943	Collar	468-5015
3J-2443	Bearing	383-2125
3J-2682	Bracket	296-1345
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961
3J-6502	Pin	319-3453
3J-6558	Brace As	416-5522
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3K-0526	Bearing-Ball	386-4949
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-0395	Cage-Carrier Brg	217-7723

65V		
Original Part Number	Part Name	Classic Part Number
3P-1885	Spring-Recoil	375-5449
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3P-4135	Support As	396-7266
3P-4142	Plate As	299-2039
3P-4143	Suspension As	393-3644
3P-4157	Yoke As-Idler	226-0221
3P-4197	Guard As-Idler	226-0189
3P-6560	Stop-Rec Spring	226-0232
3P-6561	Stop-Rec Spring	226-0233
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-5003	Spring As-Arm	383-2127
4J-1616	Bracket	299-1982
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8204	Mount As	374-1449
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008

Sales Model D7G (Cont'd.)

65V		
Original Part Number	Part Name	Classic Part Number
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-6707	Piston-Clutch	215-1686
4S-8472	Hood As-Preclnr	296-1355
4S-8708	Housing-Clutch	216-3557
4T-4073	Valve Gp-Shtl -B	439-1138
4T-9290	Cyl Gp-0152 0495	399-8579
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5J-2528	Plunger	391-1318
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5L-6326	Bearing-Ball	420-3222
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-5822	Gear-Pump Drive	247-4120
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694

65V		
Original Part Number	Part Name	Classic Part Number
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-7523	Cap-Bearing	325-6039
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-5342	Retainer	325-6182
6J-6043	Bearing-Sleeve	374-1456
6J-6229	Pin	299-2030
6J-9258	Trunnion As	256-4846
6K-8088	Bearing-Roller	399-4428

65V		
Original Part Number	Part Name	Classic Part Number
6L-7751	Rod End-Spher	472-8015
6N-0714	Pulley-Alt	264-5884
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-1218	Core As-Radiator	379-0181
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0236	Guide-Lever	422-6475
6P-2322	Plate	389-6311
6P-4327	Pad	384-3472
6P-5172	Guard Gp-Rec -A	226-0196
6P-5173	Guard Gp-Rec -A	229-8617
6P-5343	Rod Gp-Tck Adj	226-0200
6P-6653	Plate-Guide	226-0208
6S-2828	Cup-Roller Brg	384-5932
6T-0960	Pad As	367-6089
6T-1980	Collar-Idler End	226-0210
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-5916	Disc-Friction	377-7442
6Y-7920	Disc-Friction	388-0587
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-2500	Gear-Planet	296-1350
7G-6576	Cage As	216-7859
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3338	Rod As	394-0906

Sales Model D7G (Cont'd.)

65V		
Original Part Number	Part Name	Classic Part Number
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-7488	Bearing	256-4836
7J-9344	Bearing-Sleeve	360-2334
7J-9884	Bearing-Sleeve	325-6016
7K-0087	Bearing-Sleeve	374-6514
7K-2135	Bearing-Roller	417-4492
7K-9638	Bearing-Sleeve	365-8827
7M-1296	Valve-Relief	390-0990
7M-1889	Guard As	213-9108
7M-1890	Guard As-Fd Wear	213-9109
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-6964	Gear-Ring	214-0532

65V		
Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As-Radiator	295-6417
7T-0119	Support As	299-2066
7T-0204	Bearing-Brace	247-4126
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8F-6058	Bearing-Sleeve	416-5494
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-7466	Seat	385-3787
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037

65V		
Original Part Number	Part Name	Classic Part Number
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734

Sales Model D7G (Cont'd.)

65V		
Original Part Number	Part Name	Classic Part Number
8P-1865	Bar As-Equalizer	231-3313
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0007	Hub	224-1311
9J-5058	Pump Gp-Vn Bsc-B	422-8170
9K-8757	Rod End-Special	311-9361
9L-5908	Gasket	433-8196
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-7917	Valve Gp-Cont -C	385-3810
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241

65V		
Original Part Number	Part Name	Classic Part Number
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1267	Ejector As-Exh	397-5059
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6147	Body As	369-9499
9S-6875	Pinion-Final Dr	217-7705
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
131-3815	Seal Gp-Basic	325-6193
147-9670	Fan As-Rev	435-9912
148-7455	Valve - Exhaust	270-4361
155-8698	Gasket Kit	394-0914
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353

65V		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

Sales Model D7G (Cont'd.)

6BJ		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0623	Bearing	420-3224
1P-1006	Strip-Guard	226-0245
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7590	Support As-Fr	213-4400
1P-8835	Shaft As	215-1672
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683

6BJ		
Original Part Number	Part Name	Classic Part Number
1T-2069	Carrier-Bearing	439-4543
1U-2135	Cyl Gp-0121 0955	395-1304
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-5596	Pin-Pivot	297-7211
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-7116	Strip-Tapping	384-3480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230

6BJ		
Original Part Number	Part Name	Classic Part Number
2P-2697	Tube As-Air Vent	382-6901
2P-2784	Ejector As-Exh	367-6063
2P-2788	Adapter-Fan	390-0984
2P-2811	Race-Spl Rlr Brg	417-4528
2P-2922	Gear-Transfer	219-9679
2P-2923	Gear-Transfer	219-9680
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2P-3598	Shaft-Output	215-1676
2P-3669	Pinion-Bevel	215-1677
2P-3767	Tube-Disposal	377-5850
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6245	Shaft As-Pump	325-6197
2S-3946	Gear-Final Drive	215-1678
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6401	Cup-Roller Brg	380-7497
2S-7062	Shaft-Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3G-7660	Cartridge Gp	422-8103
3G-7663	Cartridge Gp	422-8120
3J-1943	Collar	468-5015
3J-2443	Bearing	383-2125

Sales Model D7G (Cont'd.)

6BJ		
Original Part Number	Part Name	Classic Part Number
3J-2682	Bracket	296-1345
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961
3J-6502	Pin	319-3453
3J-6558	Brace As	416-5522
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3L-1425	Bearing-Ball	311-9356
3P-0395	Cage-Carrier Brg	217-7723
3P-1885	Spring-Recoil	375-5449
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3P-4135	Support As	396-7266
3P-4142	Plate As	299-2039
3P-4143	Suspension As	393-3644
3P-4157	Yoke As-Idler	226-0221
3P-4197	Guard As-Idler	226-0189
3P-6560	Stop-Rec Spring	226-0232
3P-6561	Stop-Rec Spring	226-0233
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-5003	Spring As-Arm	383-2127
4J-1616	Bracket	299-1982

6BJ		
Original Part Number	Part Name	Classic Part Number
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0432	Bearing-Ball	417-4499
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-6707	Piston-Clutch	215-1686
4S-8708	Housing-Clutch	216-3557
4T-4073	Valve Gp-Shtl -B	439-1138
4T-9290	Cyl Gp-0152 0495	399-8579
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161

6BJ		
Original Part Number	Part Name	Classic Part Number
5F-1248	Cone-Roller Brg	399-4441
5J-2528	Plunger	391-1318
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5L-6326	Bearing-Ball	420-3222
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-5822	Gear-Pump Drive	247-4120
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-7523	Cap-Bearing	325-6039
6H-3566	Cone-Bearing	415-1918

Sales Model D7G (Cont'd.)

6BJ		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-5342	Retainer	325-6182
6J-6229	Pin	299-2030
6J-9258	Trunnion As	256-4846
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0714	Pulley-Alt	264-5884
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-1218	Core As-Radiator	379-0181
6N-7174	Shield-Oil	314-8544
6P-0236	Guide-Lever	422-6475
6P-2322	Plate	389-6311
6P-4327	Pad	384-3472
6P-5172	Guard Gp-Rec -A	226-0196
6P-5173	Guard Gp-Rec -A	229-8617
6P-5343	Rod Gp-Tck Adj	226-0200
6P-6653	Plate-Guide	226-0208
6T-0960	Pad As	367-6089
6T-1980	Collar-Idler End	226-0210
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-5916	Disc-Friction	377-7442
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7G-2037	Joint Gp-Univ	226-8017
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-6576	Cage As	216-7859
7G-7681	Shaft As	307-1530

6BJ		
Original Part Number	Part Name	Classic Part Number
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3338	Rod As	394-0906
7J-5131	Trunnion	296-1371
7J-7488	Bearing	256-4836
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-1889	Guard As	213-9108
7M-1890	Guard As-Fd Wear	213-9109
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417
7T-0119	Support As	299-2066
7T-0204	Bearing-Brace	247-4126
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096

6BJ		
Original Part Number	Part Name	Classic Part Number
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-7466	Seat	385-3787
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

Sales Model D7G (Cont'd.)

6BJ		
Original Part Number	Part Name	Classic Part Number
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734
8P-1865	Bar As-Equalizer	231-3313
8P-3595	Mount	418-1950
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211

6BJ		
Original Part Number	Part Name	Classic Part Number
8T-1177	Bearing-Rlr	419-1862
9G-0007	Hub	224-1311
9J-5058	Pump Gp-Vn Bsc-B	422-8170
9L-5908	Gasket	433-8196
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-7917	Valve Gp-Cont -C	385-3810
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1267	Ejector As-Exh	397-5059
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6147	Body As	369-9499
9S-6875	Pinion-Final Dr	217-7705
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124

6BJ		
Original Part Number	Part Name	Classic Part Number
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
124-3237	Precleaner As	432-4220
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
190-3832	Core As-Oclr	438-3251

Sales Model D7G (Cont'd.)

6BJ		
Original Part Number	**Part Name**	**Classic Part Number**
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893

6BJ		
Original Part Number	**Part Name**	**Classic Part Number**
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989

6BJ		
Original Part Number	**Part Name**	**Classic Part Number**
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

72W		
Original Part Number	**Part Name**	**Classic Part Number**
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1L-7319	Cup-Roller Brg	380-7499
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0623	Bearing	420-3224
1P-1367	Plunger-Valve	432-8913
1P-2187	Pump Gp-Gr 1 Bsc	299-2044
1P-4110	Disc-Friction	433-9858
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7590	Support As-Fr	213-4400
1P-8554	Coupling-Exhaust	325-6052
1P-8835	Shaft As	215-1672
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497

72W		
Original Part Number	**Part Name**	**Classic Part Number**
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-3953	Cartridge Gp	426-0024
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

72W		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2L-5271	Bearing-Ball	371-4305
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-7116	Strip-Tapping	384-3480
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2784	Ejector As-Exh	367-6063

Sales Model D7G (Cont'd.)

72W		
Original Part Number	Part Name	Classic Part Number
2P-2788	Adapter-Fan	390-0984
2P-2811	Race-Spl Rlr Brg	417-4528
2P-2922	Gear-Transfer	219-9679
2P-2923	Gear-Transfer	219-9680
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2P-3598	Shaft-Output	215-1676
2P-3669	Pinion-Bevel	215-1677
2P-3767	Tube-Disposal	377-5850
2P-4370	Plate-Clutch	325-6166
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6245	Shaft As-Pump	325-6197
2S-3946	Gear-Final Drive	215-1678
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6401	Cup-Roller Brg	380-7497
2S-6739	Pulley-Tightener	298-2794
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3F-4971	Pin	295-5693
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3G-7661	Cartridge Gp	422-8113

72W		
Original Part Number	Part Name	Classic Part Number
3G-7663	Cartridge Gp	422-8120
3J-2443	Bearing	383-2125
3K-0526	Bearing-Ball	386-4949
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-0395	Cage-Carrier Brg	217-7723
3P-1885	Spring-Recoil	375-5449
3P-4157	Yoke As-Idler	226-0221
3P-6560	Stop-Rec Spring	226-0232
3P-6561	Stop-Rec Spring	226-0233
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-5003	Spring As-Arm	383-2127
4J-1616	Bracket	299-1982
4J-6167	Bearing-Sleeve	325-6009
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4864	Pump Gp-F Tfr	242-3442

72W		
Original Part Number	Part Name	Classic Part Number
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-6707	Piston-Clutch	215-1686
4S-8472	Hood As-Preclnr	296-1355
4S-8708	Housing-Clutch	216-3557
4T-4073	Valve Gp-Shtl -B	439-1138
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5G-3612	Cap Gp-Protn	295-6419
5J-2528	Plunger	391-1318
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5L-6326	Bearing-Ball	420-3222
5M-1988	Piston-Steer Cl	219-9691

Sales Model D7G (Cont'd.)

72W		
Original Part Number	**Part Name**	**Classic Part Number**
5M-1990	Pilot-Cl Piston	229-8233
5M-5822	Gear-Pump Drive	247-4120
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-7129	Housing	472-8013
6B-7469	Spacer	417-4535
6F-7523	Cap-Bearing	325-6039
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475

72W		
Original Part Number	**Part Name**	**Classic Part Number**
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-5342	Retainer	325-6182
6J-6229	Pin	299-2030
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0714	Pulley-Alt	264-5884
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-1218	Core As-Radiator	379-0181
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0236	Guide-Lever	422-6475
6P-6653	Plate-Guide	226-0208
6S-2828	Cup-Roller Brg	384-5932
6T-0960	Pad As	367-6089
6T-1980	Collar-Idler End	226-0210
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-5916	Disc-Friction	377-7442
6Y-7920	Disc-Friction	388-0587
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-7889	Gear-Ring	275-5276
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-2500	Gear-Planet	296-1350
7G-6576	Cage As	216-7859
7J-1333	Bearing-Sleeve	295-6408

72W		
Original Part Number	**Part Name**	**Classic Part Number**
7J-1334	Bearing-Sleeve	325-6015
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656

Sales Model D7G (Cont'd.)

72W		
Original Part Number	Part Name	Classic Part Number
7S-4097	Adapter-Exh Man	383-3700
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417
7S-7973	Guard-Fd Wear	213-9110
7T-0119	Support As	299-2066
7T-0204	Bearing-Brace	247-4126
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-3744	Shaft-Drive	275-5283
8D-3877	Gear-Sun	275-5278
8D-8159	Retainer	419-8661
8F-6058	Bearing-Sleeve	416-5494
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-7466	Seat	385-3787
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252

72W		
Original Part Number	Part Name	Classic Part Number
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083

72W		
Original Part Number	Part Name	Classic Part Number
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-2308	Shaft-Planet	275-5285
8W-8317	Sprocket	275-5287
9B-1320	Valve-Check	377-5832
9G-0007	Hub	224-1311
9H-5797	Plunger As-Pump	391-9891
9J-5050	Pump Gp-Vn Bsc-B	422-8168
9J-5058	Pump Gp-Vn Bsc-B	422-8170
9K-8757	Rod End-Special	311-9361
9L-5908	Gasket	433-8196
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050

Sales Model D7G (Cont'd.)

72W		
Original Part Number	Part Name	Classic Part Number
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-7917	Valve Gp-Cont -C	385-3810
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1267	Ejector As-Exh	397-5059
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6147	Body As	369-9499
9S-6875	Pinion-Final Dr	217-7705
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833

72W		
Original Part Number	Part Name	Classic Part Number
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
129-2381	Gear-Planet	275-5274
131-3815	Seal Gp-Basic	325-6193
147-9670	Fan As-Rev	435-9912
148-7455	Valve - Exhaust	270-4361
155-5619	Gasket	382-5054
155-8698	Gasket Kit	394-0914
159-3021	Gasket	377-5845
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

72W		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
172-7776	Pump Gp-Water -B	395-1314
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
232-6574	Kit-Gasket-Rs	437-2034
234-8016	Kit-Gasket-Sch	393-0919
235-0913	Tc Kit-Cla	235-0920
236-7724	Retainer	299-2048
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

7MB		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1J-0774	Bracket	369-9485

7MB		
Original Part Number	Part Name	Classic Part Number
1J-2087	Bushing	421-9041
1L-7319	Cup-Roller Brg	380-7499
1M-8776	Bearing-Roller	417-4516

7MB		
Original Part Number	Part Name	Classic Part Number
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046

Sales Model D7G (Cont'd.)

7MB		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0623	Bearing	420-3224
1P-1006	Strip-Guard	226-0245
1P-1367	Plunger-Valve	432-8913
1P-2187	Pump Gp-Gr 1 Bsc	299-2044
1P-4110	Disc-Friction	433-9858
1P-7590	Support As-Fr	213-4400
1P-8835	Shaft As	215-1672
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-2135	Cyl Gp-0121 0955	395-1304
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

7MB		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-1424	Rod As	469-4665
2J-5596	Pin-Pivot	297-7211
2J-8489	Bearing-Sleeve	295-5691
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-7116	Strip-Tapping	384-3480
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2784	Ejector As-Exh	367-6063
2P-2788	Adapter-Fan	390-0984

7MB		
Original Part Number	Part Name	Classic Part Number
2P-2811	Race-Spl Rlr Brg	417-4528
2P-2922	Gear-Transfer	219-9679
2P-2923	Gear-Transfer	219-9680
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2P-3598	Shaft-Output	215-1676
2P-3669	Pinion-Bevel	215-1677
2P-3767	Tube-Disposal	377-5850
2P-4370	Plate-Clutch	325-6166
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6245	Shaft As-Pump	325-6197
2S-3946	Gear-Final Drive	215-1678
2S-5551	Coupling-Exhaust	398-2934
2S-6401	Cup-Roller Brg	380-7497
2S-7062	Shaft-Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6612	Cap-Ball Joint	297-7155
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3J-1943	Collar	468-5015
3J-2443	Bearing	383-2125
3J-2682	Bracket	296-1345
3J-4284	Cap-Brg	314-8656

Sales Model D7G (Cont'd.)

7MB		
Original Part Number	Part Name	Classic Part Number
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961
3J-6502	Pin	319-3453
3J-6558	Brace As	416-5522
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3K-0526	Bearing-Ball	386-4949
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-0395	Cage-Carrier Brg	217-7723
3P-1885	Spring-Recoil	375-5449
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3P-4135	Support As	396-7266
3P-4142	Plate As	299-2039
3P-4143	Suspension As	393-3644
3P-4157	Yoke As-Idler	226-0221
3P-4197	Guard As-Idler	226-0189
3P-6560	Stop-Rec Spring	226-0232
3P-6561	Stop-Rec Spring	226-0233
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-5003	Spring As-Arm	383-2127

7MB		
Original Part Number	Part Name	Classic Part Number
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-6707	Piston-Clutch	215-1686
4S-8708	Housing-Clutch	216-3557
4T-9290	Cyl Gp-0152 0495	399-8579

7MB		
Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5J-2528	Plunger	391-1318
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5L-6326	Bearing-Ball	420-3222
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-5822	Gear-Pump Drive	247-4120
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

Sales Model D7G (Cont'd.)

7MB		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-7523	Cap-Bearing	325-6039
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-0774	Trunnion	256-4844
6J-5342	Retainer	325-6182
6J-6229	Pin	299-2030
6J-8183	Bracket	394-0195
6J-9258	Trunnion As	256-4846
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0714	Pulley-Alt	264-5884
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-1218	Core As-Radiator	379-0181
6N-7174	Shield-Oil	314-8544
6P-0236	Guide-Lever	422-6475
6P-2322	Plate	389-6311
6P-4327	Pad	384-3472
6P-5172	Guard Gp-Rec -A	226-0196
6P-5173	Guard Gp-Rec -A	229-8617
6P-5343	Rod Gp-Tck Adj	226-0200
6P-6653	Plate-Guide	226-0208
6S-2828	Cup-Roller Brg	384-5932
6T-0960	Pad As	367-6089
6T-1980	Collar-Idler End	226-0210
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-5916	Disc-Friction	377-7442
6Y-7920	Disc-Friction	388-0587
7C-3862	Camshaft	458-0151

7MB		
Original Part Number	Part Name	Classic Part Number
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-2500	Gear-Planet	296-1350
7G-6576	Cage As	216-7859
7G-7681	Shaft As	307-1530
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3338	Rod As	394-0906
7J-5131	Trunnion	296-1371
7J-7488	Bearing	256-4836
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-1889	Guard As	213-9108
7M-1890	Guard As-Fd Wear	213-9109
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995

7MB		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417
7T-0119	Support As	299-2066
7T-0204	Bearing-Brace	247-4126
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8F-6058	Bearing-Sleeve	416-5494
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-7466	Seat	385-3787
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583

Sales Model D7G (Cont'd.)

7MB		
Original Part Number	Part Name	Classic Part Number
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

7MB		
Original Part Number	Part Name	Classic Part Number
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734
8P-1865	Bar As-Equalizer	231-3313
8P-3595	Mount	418-1950
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-1177	Bearing-Rlr	419-1862
9G-0007	Hub	224-1311
9J-5058	Pump Gp-Vn Bsc-B	422-8170
9L-5908	Gasket	433-8196
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-7917	Valve Gp-Cont -C	385-3810

7MB		
Original Part Number	Part Name	Classic Part Number
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1267	Ejector As-Exh	397-5059
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6147	Body As	369-9499
9S-6875	Pinion-Final Dr	217-7705
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
124-3237	Precleaner As	432-4220
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125

Sales Model D7G (Cont'd.)

7MB		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

7MB		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893

7MB		
Original Part Number	Part Name	Classic Part Number
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

91V		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1H-8382	Gear-Oil Pump Dr	226-6103
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1L-7319	Cup-Roller Brg	380-7499
1M-8776	Bearing-Roller	417-4516
1M-9029	Guard	226-0219
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1006	Strip-Guard	226-0245
1P-1367	Plunger-Valve	432-8913
1P-2187	Pump Gp-Gr 1 Bsc	299-2044
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7590	Support As-Fr	213-4400
1P-8554	Coupling-Exhaust	325-6052

91V		
Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188
1S-3062	Director-Water	418-9572
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9110	Bearing-Needle	420-2497
1T-0043	Bearing-Ball	390-5294
1U-2135	Cyl Gp-0121 0955	395-1304
1U-3953	Cartridge Gp	426-0024
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

91V		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2J-5596	Pin-Pivot	297-7211
2K-5804	Rod End-Spher	416-2151
2L-5271	Bearing-Ball	371-4305
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532

Sales Model D7G (Cont'd.)

91V		
Original Part Number	Part Name	Classic Part Number
2M-4668	Retainer-Guard	297-4867
2M-7116	Strip-Tapping	384-3480
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2784	Ejector As-Exh	367-6063
2P-2788	Adapter-Fan	390-0984
2P-2811	Race-Spl Rlr Brg	417-4528
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2P-3767	Tube-Disposal	377-5850
2P-4370	Plate-Clutch	325-6166
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-5608	Pipe-Extension	367-6066
2P-6245	Shaft As-Pump	325-6197
2S-3946	Gear-Final Drive	215-1678
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6401	Cup-Roller Brg	380-7497
2S-6739	Pulley-Tightener	298-2794
2S-7062	Shaft-Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679

91V		
Original Part Number	Part Name	Classic Part Number
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3G-2797	Bearing-Sleeve	360-2329
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3G-7660	Cartridge Gp	422-8103
3G-7661	Cartridge Gp	422-8113
3G-7663	Cartridge Gp	422-8120
3J-1943	Collar	468-5015
3J-2443	Bearing	383-2125
3J-2682	Bracket	296-1345
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961
3J-6502	Pin	319-3453
3J-6558	Brace As	416-5522
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3K-0526	Bearing-Ball	386-4949
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1885	Spring-Recoil	375-5449

91V		
Original Part Number	Part Name	Classic Part Number
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3P-3241	Plate-Pressure	325-6167
3P-4135	Support As	396-7266
3P-4142	Plate As	299-2039
3P-4143	Suspension As	393-3644
3P-4157	Yoke As-Idler	226-0221
3P-4197	Guard As-Idler	226-0189
3P-6560	Stop-Rec Spring	226-0232
3P-6561	Stop-Rec Spring	226-0233
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-5003	Spring As-Arm	383-2127
4H-4021	Plate As-Loading	229-8219
4J-1616	Bracket	299-1982
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4M-3915	Bearing-Caged	377-7427
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363

Sales Model D7G (Cont'd.)

91V		
Original Part Number	Part Name	Classic Part Number
4N-3283	Line As-Fuel Inj	247-3364
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-4073	Valve Gp-Shtl -B	439-1138
4T-9290	Cyl Gp-0152 0495	399-8579
4V-3603	Pin As	319-3441
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5G-3612	Cap Gp-Protn	295-6419
5H-5500	Collar-Fly Cl	302-2704

91V		
Original Part Number	Part Name	Classic Part Number
5J-2528	Plunger	391-1318
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5L-6326	Bearing-Ball	420-3222
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-7129	Housing	472-8013
5T-8739	Spider Gp-Brg	373-5386
5V-1882	Pin As	361-1700
6B-7469	Spacer	417-4535
6F-7523	Cap-Bearing	325-6039
6H-2577	Spider Gp-Brg	333-4954
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-5342	Retainer	325-6182
6J-6229	Pin	299-2030
6J-9258	Trunnion As	256-4846
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0714	Pulley-Alt	264-5884
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991

91V		
Original Part Number	Part Name	Classic Part Number
6N-1218	Core As-Radiator	379-0181
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6N-8992	Adapter-Fan	394-9810
6P-0169	Hub-Fly Clutch	297-7204
6P-2322	Plate	389-6311
6P-4327	Pad	384-3472
6P-5172	Guard Gp-Rec -A	226-0196
6P-5173	Guard Gp-Rec -A	229-8617
6P-5343	Rod Gp-Tck Adj	226-0200
6P-6653	Plate-Guide	226-0208
6S-2828	Cup-Roller Brg	384-5932
6T-0960	Pad As	367-6089
6T-1980	Collar-Idler End	226-0210
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-7920	Disc-Friction	388-0587
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-7889	Gear-Ring	275-5276
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2500	Gear-Planet	296-1350
7G-6576	Cage As	216-7859
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3338	Rod As	394-0906
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-7488	Bearing	256-4836

Sales Model D7G (Cont'd.)

91V		
Original Part Number	Part Name	Classic Part Number
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-1889	Guard As	213-9108
7M-1890	Guard As-Fd Wear	213-9109
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-4618	Ejector As-Exh	397-5060
7N-5656	Sleeve	384-3848
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700

91V		
Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As-Radiator	295-6417
7S-7973	Guard-Fd Wear	213-9110
7T-0119	Support As	299-2066
7T-0204	Bearing-Brace	247-4126
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8B-8439	Bearing-Ball	399-6069
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-3744	Shaft-Drive	275-5283
8D-3877	Gear-Sun	275-5278
8D-8159	Retainer	419-8661
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8F-6058	Bearing-Sleeve	416-5494
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-7466	Seat	385-3787
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037

91V		
Original Part Number	Part Name	Classic Part Number
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0187	Nut-Adjusting	219-9676

Sales Model D7G (Cont'd.)

91V		
Original Part Number	Part Name	Classic Part Number
8P-1653	Nut-Sprocket Adj	449-4734
8P-1865	Bar As-Equalizer	231-3313
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-7818	Bracket	226-0211
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-2308	Shaft-Planet	275-5285
8W-8317	Sprocket	275-5287
9B-1320	Valve-Check	377-5832
9F-7101	Bushing-Collar	299-1988
9G-0007	Hub	224-1311
9H-5797	Plunger As-Pump	391-9891
9J-5050	Pump Gp-Vn Bsc-B	422-8168
9J-5058	Pump Gp-Vn Bsc-B	422-8170
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-5908	Gasket	433-8196
9M-1997	Bearing-Ball	384-5954
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-8119	Retainer-Inlet	226-8022
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558

91V		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1267	Ejector As-Exh	397-5059
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-6147	Body As	369-9499
9S-6590	Pump Gp-Cl Oil	226-0176
9S-6875	Pinion-Final Dr	217-7705
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
129-2381	Gear-Planet	275-5274
131-3815	Seal Gp-Basic	325-6193
147-9670	Fan As-Rev	435-9912
148-7455	Valve - Exhaust	270-4361
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353

91V		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
232-6574	Kit-Gasket-Rs	437-2034
234-8016	Kit-Gasket-Sch	393-0919
236-7724	Retainer	299-2048
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438

Sales Model D7G (Cont'd.)

91V		
Original Part Number	**Part Name**	**Classic Part Number**
275-0120	Pin As	419-7245
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989

91V		
Original Part Number	**Part Name**	**Classic Part Number**
310-1899	Pin As	393-0932
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

91V		
Original Part Number	**Part Name**	**Classic Part Number**
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

92V		
Original Part Number	**Part Name**	**Classic Part Number**
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-4102	Bearing-Ball	399-4426
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1L-7319	Cup-Roller Brg	380-7499
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0623	Bearing	420-3224
1P-1006	Strip-Guard	226-0245
1P-1367	Plunger-Valve	432-8913
1P-2187	Pump Gp-Gr 1 Bsc	299-2044
1P-4110	Disc-Friction	433-9858
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-7590	Support As-Fr	213-4400
1P-8554	Coupling-Exhaust	325-6052
1P-8835	Shaft As	215-1672
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188
1S-3062	Director-Water	418-9572
1S-9110	Bearing-Needle	420-2497
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294

92V		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-2135	Cyl Gp-0121 0955	395-1304
1U-3953	Cartridge Gp	426-0024
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

92V		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-5596	Pin-Pivot	297-7211
2L-5271	Bearing-Ball	371-4305
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-7116	Strip-Tapping	384-3480
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2784	Ejector As-Exh	367-6063
2P-2788	Adapter-Fan	390-0984
2P-2811	Race-Spl Rlr Brg	417-4528
2P-2922	Gear-Transfer	219-9679
2P-2923	Gear-Transfer	219-9680
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697

Sales Model D7G (Cont'd.)

92V		
Original Part Number	Part Name	Classic Part Number
2P-3598	Shaft-Output	215-1676
2P-3669	Pinion-Bevel	215-1677
2P-3767	Tube-Disposal	377-5850
2P-4370	Plate-Clutch	325-6166
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-5608	Pipe-Extension	367-6066
2P-6245	Shaft As-Pump	325-6197
2S-3946	Gear-Final Drive	215-1678
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6401	Cup-Roller Brg	380-7497
2S-6739	Pulley-Tightener	298-2794
2S-7062	Shaft-Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2S-7931	Bearing-Sleeve	387-2904
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3G-2797	Bearing-Sleeve	360-2329
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3G-7660	Cartridge Gp	422-8103
3G-7661	Cartridge Gp	422-8113
3G-7663	Cartridge Gp	422-8120

92V		
Original Part Number	Part Name	Classic Part Number
3J-1943	Collar	468-5015
3J-2443	Bearing	383-2125
3J-2682	Bracket	296-1345
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961
3J-6502	Pin	319-3453
3J-6558	Brace As	416-5522
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3K-0526	Bearing-Ball	386-4949
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-0395	Cage-Carrier Brg	217-7723
3P-1885	Spring-Recoil	375-5449
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3P-4135	Support As	396-7266
3P-4142	Plate As	299-2039
3P-4143	Suspension As	393-3644
3P-4157	Yoke As-Idler	226-0221
3P-4197	Guard As-Idler	226-0189
3P-6560	Stop-Rec Spring	226-0232
3P-6561	Stop-Rec Spring	226-0233
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494

92V		
Original Part Number	Part Name	Classic Part Number
4D-4065	Rod End-Spher	374-1824
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-5003	Spring As-Arm	383-2127
4J-1616	Bracket	299-1982
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

Sales Model D7G (Cont'd.)

92V		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-6707	Piston-Clutch	215-1686
4S-8472	Hood As-Preclnr	296-1355
4S-8708	Housing-Clutch	216-3557
4T-4073	Valve Gp-Shtl -B	439-1138
4T-9290	Cyl Gp-0152 0495	399-8579
4V-3603	Pin As	319-3441
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5G-3612	Cap Gp-Protn	295-6419
5J-2528	Plunger	391-1318
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5L-6326	Bearing-Ball	420-3222
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-5822	Gear-Pump Drive	247-4120
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525

92V		
Original Part Number	**Part Name**	**Classic Part Number**
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-3490	Cone-Rlr Bearing	380-7518
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-7129	Housing	472-8013
5T-8739	Spider Gp-Brg	373-5386
5V-1882	Pin As	361-1700
6B-7469	Spacer	417-4535
6F-7523	Cap-Bearing	325-6039
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-5342	Retainer	325-6182
6J-6229	Pin	299-2030
6J-9258	Trunnion As	256-4846
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0714	Pulley-Alt	264-5884
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991

92V		
Original Part Number	**Part Name**	**Classic Part Number**
6N-1218	Core As-Radiator	379-0181
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6N-8992	Adapter-Fan	394-9810
6P-0236	Guide-Lever	422-6475
6P-2322	Plate	389-6311
6P-4327	Pad	384-3472
6P-5172	Guard Gp-Rec -A	226-0196
6P-5173	Guard Gp-Rec -A	229-8617
6P-5343	Rod Gp-Tck Adj	226-0200
6P-6653	Plate-Guide	226-0208
6S-2828	Cup-Roller Brg	384-5932
6T-0960	Pad As	367-6089
6T-1980	Collar-Idler End	226-0210
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-5916	Disc-Friction	377-7442
6Y-7920	Disc-Friction	388-0587
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7D-7889	Gear-Ring	275-5276
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-2037	Joint Gp-Univ	226-8017
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-2500	Gear-Planet	296-1350
7G-6576	Cage As	216-7859
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015

Sales Model D7G (Cont'd.)

92V		
Original Part Number	Part Name	Classic Part Number
7J-3338	Rod As	394-0906
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-7488	Bearing	256-4836
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-1889	Guard As	213-9108
7M-1890	Guard As-Fd Wear	213-9109
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5656	Sleeve	384-3848
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995

92V		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417
7S-7973	Guard-Fd Wear	213-9110
7T-0119	Support As	299-2066
7T-0204	Bearing-Brace	247-4126
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-3591	Carrier-Planet	301-4769
8D-3743	Sprocket	391-9876
8D-3744	Shaft-Drive	275-5283
8D-3877	Gear-Sun	275-5278
8D-8159	Retainer	419-8661
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8F-6058	Bearing-Sleeve	416-5494
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-7466	Seat	385-3787
8M-0874	Plunger As-Valve	311-9439

92V		
Original Part Number	Part Name	Classic Part Number
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860

Sales Model D7G (Cont'd.)

92V		
Original Part Number	Part Name	Classic Part Number
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734
8P-1865	Bar As-Equalizer	231-3313
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8W-2308	Shaft-Planet	275-5285
8W-8317	Sprocket	275-5287
9B-1320	Valve-Check	377-5832
9G-0007	Hub	224-1311
9H-5797	Plunger As-Pump	391-9891
9J-5050	Pump Gp-Vn Bsc-B	422-8168
9J-5058	Pump Gp-Vn Bsc-B	422-8170
9K-8757	Rod End-Special	311-9361
9L-5908	Gasket	433-8196
9M-1500	Shaft-Planet	219-9685

92V		
Original Part Number	Part Name	Classic Part Number
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-7917	Valve Gp-Cont -C	385-3810
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1267	Ejector As-Exh	397-5059
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6147	Body As	369-9499
9S-6875	Pinion-Final Dr	217-7705
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707

92V		
Original Part Number	Part Name	Classic Part Number
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
129-2381	Gear-Planet	275-5274
131-3815	Seal Gp-Basic	325-6193
147-9670	Fan As-Rev	435-9912
148-7455	Valve - Exhaust	270-4361
155-5619	Gasket	382-5054
155-8698	Gasket Kit	394-0914
159-3021	Gasket	377-5845
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0558	Kit-Rebuild-Pump	390-1001
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365

Sales Model D7G (Cont'd.)

92V		
Original Part Number	Part Name	Classic Part Number
172-7776	Pump Gp-Water -B	395-1314
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
200-7929	Housing	416-5489
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
232-6574	Kit-Gasket-Rs	437-2034
234-8016	Kit-Gasket-Sch	393-0919
235-0913	Tc Kit-Cla	235-0920

92V		
Original Part Number	Part Name	Classic Part Number
236-7724	Retainer	299-2048
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
275-0120	Pin As	419-7245
296-1359	Line As-Cla	279-4988

92V		
Original Part Number	Part Name	Classic Part Number
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
310-1899	Pin As	393-0932
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

C7G		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9444	Retainer-Spring	299-2046
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0623	Bearing	420-3224
1P-1006	Strip-Guard	226-0245
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-7590	Support As-Fr	213-4400
1P-8835	Shaft As	215-1672
1P-9945	Bracket As-Fan	296-1344
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442

C7G		
Original Part Number	Part Name	Classic Part Number
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-2135	Cyl Gp-0121 0955	395-1304
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

C7G		
Original Part Number	Part Name	Classic Part Number
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-5596	Pin-Pivot	297-7211
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1163	Plate As-Spring	383-2123
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-7116	Strip-Tapping	384-3480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2784	Ejector As-Exh	367-6063

Sales Model D7G (Cont'd.)

C7G		
Original Part Number	Part Name	Classic Part Number
2P-2788	Adapter-Fan	390-0984
2P-2811	Race-Spl Rlr Brg	417-4528
2P-2922	Gear-Transfer	219-9679
2P-2923	Gear-Transfer	219-9680
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2P-3598	Shaft-Output	215-1676
2P-3669	Pinion-Bevel	215-1677
2P-3767	Tube-Disposal	377-5850
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-6245	Shaft As-Pump	325-6197
2S-3946	Gear-Final Drive	215-1678
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6401	Cup-Roller Brg	380-7497
2S-7062	Shaft-Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3G-7660	Cartridge Gp	422-8103
3G-7663	Cartridge Gp	422-8120
3J-1943	Collar	468-5015
3J-2443	Bearing	383-2125
3J-2682	Bracket	296-1345
3J-6167	Bearing-Sleeve	299-1960

C7G		
Original Part Number	Part Name	Classic Part Number
3J-6442	Bearing-Sleeve	299-1961
3J-6502	Pin	319-3453
3J-6558	Brace As	416-5522
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3L-1425	Bearing-Ball	311-9356
3P-0395	Cage-Carrier Brg	217-7723
3P-1885	Spring-Recoil	375-5449
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3P-4135	Support As	396-7266
3P-4142	Plate As	299-2039
3P-4143	Suspension As	393-3644
3P-4157	Yoke As-Idler	226-0221
3P-4197	Guard As-Idler	226-0189
3P-6560	Stop-Rec Spring	226-0232
3P-6561	Stop-Rec Spring	226-0233
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-9669	Bearing	416-2168
3T-1921	Drum-Cl Inner	229-8227
3T-4482	Guide-Frt Idler	226-0248
4D-2619	Bearing	417-4494
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-5003	Spring As-Arm	383-2127
4J-1616	Bracket	299-1982
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009

C7G		
Original Part Number	Part Name	Classic Part Number
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1641	Dowel-Reaction	386-4952
4N-0432	Bearing-Ball	417-4499
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-6707	Piston-Clutch	215-1686
4S-8708	Housing-Clutch	216-3557
4T-4073	Valve Gp-Shtl -B	439-1138
4T-9290	Cyl Gp-0152 0495	399-8579
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
4Y-0709	Disc-Friction	377-7431
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441

Sales Model D7G (Cont'd.)

C7G		
Original Part Number	Part Name	Classic Part Number
5J-2528	Plunger	391-1318
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5L-6326	Bearing-Ball	420-3222
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-5822	Gear-Pump Drive	247-4120
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7936	Bearing-Outer	386-4953
5M-9644	Bearing-Outer	384-5929
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-7523	Cap-Bearing	325-6039
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273

C7G		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8860	Cup-Roller Brg	380-7495
6J-5342	Retainer	325-6182
6J-6229	Pin	299-2030
6J-9258	Trunnion As	256-4846
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6N-0714	Pulley-Alt	264-5884
6N-0731	Muffler As-Exh	382-8018
6N-1036	Gear-Oil Pump	279-4991
6N-1218	Core As-Radiator	379-0181
6N-7174	Shield-Oil	314-8544
6P-0236	Guide-Lever	422-6475
6P-2322	Plate	389-6311
6P-4327	Pad	384-3472
6P-5172	Guard Gp-Rec -A	226-0196
6P-5173	Guard Gp-Rec -A	229-8617
6P-5343	Rod Gp-Tck Adj	226-0200
6P-6653	Plate-Guide	226-0208
6T-0960	Pad As	367-6089
6T-1980	Collar-Idler End	226-0210
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-5916	Disc-Friction	377-7442
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7G-2037	Joint Gp-Univ	226-8017
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-6576	Cage As	216-7859
7G-7681	Shaft As	307-1530
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015

C7G		
Original Part Number	Part Name	Classic Part Number
7J-3338	Rod As	394-0906
7J-5131	Trunnion	296-1371
7J-7488	Bearing	256-4836
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-1889	Guard As	213-9108
7M-1890	Guard As-Fd Wear	213-9109
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-6964	Gear-Ring	214-0532
7S-7809	Cap As-Radiator	295-6417
7T-0119	Support As	299-2066
7T-0204	Bearing-Brace	247-4126
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684

Sales Model D7G (Cont'd.)

C7G		
Original Part Number	Part Name	Classic Part Number
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-7466	Seat	385-3787
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200

C7G		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3539	Plunger As-Pump	377-5861
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0187	Nut-Adjusting	219-9676
8P-1653	Nut-Sprocket Adj	449-4734
8P-1865	Bar As-Equalizer	231-3313
8P-3595	Mount	418-1950
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8P-7790	Valve Gp-Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-1061	Pilot As-Spring	226-0227
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7818	Bracket	226-0211
8T-1177	Bearing-Rlr	419-1862
9G-0007	Hub	224-1311

C7G		
Original Part Number	Part Name	Classic Part Number
9J-5058	Pump Gp-Vn Bsc-B	422-8170
9L-5908	Gasket	433-8196
9M-1500	Shaft-Planet	219-9685
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2049	Gear-Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0620	Cage-Pinion Brg	221-1052
9P-2201	Valve Gp-Rlf -A	386-3816
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-7917	Valve Gp-Cont -C	385-3810
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1267	Ejector As-Exh	397-5059
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-6147	Body As	369-9499
9S-6875	Pinion-Final Dr	217-7705
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531

Sales Model D7G (Cont'd.)

C7G		
Original Part Number	Part Name	Classic Part Number
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-7799	Bearing-Ball	396-9947
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
124-3237	Precleaner As	432-4220
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351

C7G		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
190-3832	Core As-Oclr	438-3251

C7G		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
230-7116	Ster Cl Kit-Cla	229-8227
232-3233	Bearing-Main	376-9085
235-0913	Tc Kit-Cla	235-0920
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-7245	Shaft-Cla	215-1694
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

Sales Model D7H

2RG		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1L-7319	Cup-Roller Brg	380-7499
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685

2RG		
Original Part Number	Part Name	Classic Part Number
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race-Thrust Brg	453-3651
1T-0902	Bearing-Sleeve	389-6326
1T-1386	Yoke-Univ Joint	325-6239
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920

2RG		
Original Part Number	Part Name	Classic Part Number
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1U-4851	Cyl Gp-0102 1360	422-4560
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

Sales Model D7H (Cont'd.)

2RG		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197

2RG		
Original Part Number	Part Name	Classic Part Number
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3G-8746	Rod As	394-8217
3J-2682	Bracket	296-1345
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5929	Gear	288-8718
3T-7192	Guard As	325-6100
3T-7195	Guard As	325-6101
3T-7398	Guide As	419-4647
3T-7701	Cylinder As	325-6058
3T-7710	Guide	325-6102
3T-7711	Guide	325-6103

2RG		
Original Part Number	Part Name	Classic Part Number
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0640	Piston	325-6160
3Y-9984	Manifold-Exhaust	325-6123
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0202	Pin As	325-6130
4T-0998	Lever	314-8687
4T-5495	Ballstud	314-8626
4T-7534	Pin	433-9209
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191

Sales Model D7H (Cont'd.)

2RG		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

2RG		
Original Part Number	Part Name	Classic Part Number
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6J-5342	Retainer	325-6182
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6T-8249	Pin	399-8542
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655

2RG		
Original Part Number	Part Name	Classic Part Number
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-8295	Head	388-0566
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187

Sales Model D7H (Cont'd.)

2RG		
Original Part Number	Part Name	Classic Part Number
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8E-4526	Disc-Friction	417-9495
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8E-6758	Connector As	396-0639
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349

2RG		
Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089

2RG		
Original Part Number	Part Name	Classic Part Number
9N-4622	Pin	319-3468
9N-5769	Cover-Housing	325-6050
9P-0863	Pin	389-6321
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-0142	Cyl Gp-0184-0281	394-9830
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9W-2344	Coupling-Pump Dr	314-8666
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
110-8368	Bearing-Cup	416-2172
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
127-5537	Core As-Oclr	325-6045
130-3139	Bearing-Sleeve	391-9875
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831

Sales Model D7H (Cont'd.)

2RG		
Original Part Number	Part Name	Classic Part Number
139-6850	Gasket Kit	384-4809
141-4689	Bar Gp-Equalizer	443-3570
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

2RG		
Original Part Number	Part Name	Classic Part Number
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
191-9323	Kit-Bearing	464-9064
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

2RG		
Original Part Number	Part Name	Classic Part Number
258-2308	Bearing-Sleeve	325-6019
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	376-3636

2SB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1L-7319	Cup-Roller Brg	380-7499
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race-Thrust Brg	453-3651
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138

2SB		
Original Part Number	Part Name	Classic Part Number
1U-1204	Trunnion	325-6224
1U-4851	Cyl Gp-0102 1360	422-4560
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210

2SB		
Original Part Number	Part Name	Classic Part Number
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342

Sales Model D7H (Cont'd.)

2SB		
Original Part Number	Part Name	Classic Part Number
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3G-8746	Rod As	394-8217
3J-2682	Bracket	296-1345
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961
3L-9409	Cup-Roller Brg	399-4436
3T-1407	Disc-Friction	392-4516
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718

2SB		
Original Part Number	Part Name	Classic Part Number
3T-7192	Guard As	325-6100
3T-7195	Guard As	325-6101
3T-7398	Guide As	419-4647
3T-7701	Cylinder As	325-6058
3T-7710	Guide	325-6102
3T-7711	Guide	325-6103
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0640	Piston	325-6160
3Y-9984	Manifold-Exhaust	325-6123
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355

2SB		
Original Part Number	Part Name	Classic Part Number
4S-8538	Bearing-Spl Ball	417-4502
4T-0202	Pin As	325-6130
4T-0998	Lever	314-8687
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6J-5342	Retainer	325-6182
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544

Sales Model D7H (Cont'd.)

2SB		
Original Part Number	Part Name	Classic Part Number
6P-5404	Plate-Cl & Brake	325-6168
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6S-3457	Pin	325-6147
6T-0016	Pump Gp-Gr 4 Bsc	418-1957
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl & Brake	325-6170
6T-8249	Pin	399-8542
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-7946	Disc-Friction	384-4801
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361
7G-2500	Gear-Planet	296-1350
7G-2824	Piston	295-6439
7G-2828	Plate-Clutch	325-6171
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925

2SB		
Original Part Number	Part Name	Classic Part Number
7G-7681	Shaft As	307-1530
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-8295	Head	388-0566
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-6427	Pin	319-3462
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069

2SB		
Original Part Number	Part Name	Classic Part Number
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

Sales Model D7H (Cont'd.)

2SB		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-1177	Bearing-Rlr	419-1862
9D-3242	Cone-Roller Brg	453-3659
9J-0123	Trunnion	325-6227
9M-1853	Mount As.	376-3638
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-0863	Pin	389-6321
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042

2SB		
Original Part Number	Part Name	Classic Part Number
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9W-2344	Coupling-Pump Dr	314-8666
9W-4897	Bracket As	295-6414
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
130-3139	Bearing-Sleeve	391-9875
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
136-7813	Bearing-Race	460-8296
140-2246	Gasket Kit	383-3710
141-4689	Bar Gp-Equalizer	443-3570
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127

2SB		
Original Part Number	Part Name	Classic Part Number
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
232-3233	Bearing-Main	376-9085
250-1984	Trunnion	319-3476
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
325-6012	Brg-Cla	325-6019
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

3XG		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1L-7319	Cup-Roller Brg	380-7499
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535

3XG		
Original Part Number	Part Name	Classic Part Number
1P-3935	Cone-Roller Brg	377-7397
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442

3XG		
Original Part Number	Part Name	Classic Part Number
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180

Sales Model D7H (Cont'd.)

3XG		
Original Part Number	Part Name	Classic Part Number
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race-Thrust Brg	453-3651
1T-0902	Bearing-Sleeve	389-6326
1T-1386	Yoke-Univ Joint	325-6239
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-0025	Tube	325-6233

3XG		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3J-2682	Bracket	296-1345
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698

3XG		
Original Part Number	Part Name	Classic Part Number
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5929	Gear	288-8718
3T-7192	Guard As	325-6100
3T-7195	Guard As	325-6101
3T-7398	Guide As	419-4647
3T-7701	Cylinder As	325-6058
3T-7710	Guide	325-6102
3T-7711	Guide	325-6103
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0640	Piston	325-6160
3Y-9984	Manifold-Exhaust	325-6123
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988

Sales Model D7H (Cont'd.)

3XG		
Original Part Number	Part Name	Classic Part Number
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

3XG		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-1108	Bearing-Sleeve	325-6023
6F-2904	Bearing	295-5673
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6T-8249	Pin	399-8542
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-7471	Pin-Pivot	325-6152
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697

3XG		
Original Part Number	Part Name	Classic Part Number
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-8295	Head	388-0566
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417

Sales Model D7H (Cont'd.)

3XG		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7T-3365	Carrier-Planet	388-6563
7T-3566	Piston	394-9191
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8E-4526	Disc-Friction	417-9495
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

3XG		
Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448

3XG		
Original Part Number	Part Name	Classic Part Number
8T-1177	Bearing-Rlr	419-1862
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-4622	Pin	319-3468
9N-5769	Cover-Housing	325-6050
9P-0863	Pin	389-6321
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-3884	Piston As	393-3639
9T-4761	Head	325-6108
9T-4762	Head	325-6109
9W-2344	Coupling-Pump Dr	314-8666
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035

Sales Model D7H (Cont'd.)

3XG		
Original Part Number	Part Name	Classic Part Number
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
110-8368	Bearing-Cup	416-2172
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
127-5537	Core As-Oclr	325-6045
129-4259	Cyl Gp 0102 1437	393-3655
130-3139	Bearing-Sleeve	391-9875
130-8412	Piston-Clutch	394-0910
131-3815	Seal Gp-Basic	325-6193
139-6850	Gasket Kit	384-4809
141-4689	Bar Gp-Equalizer	443-3570
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

3XG		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
187-0605	Gasket Kit - Cl	382-5055
191-9323	Kit-Bearing	464-9064
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
250-1984	Trunnion	319-3476

3XG		
Original Part Number	Part Name	Classic Part Number
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	376-3636
464-9064	Kit-Dt Brg-Cla	434-3296

4AB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4106	Pin As-Drawbar	325-6126
1L-7319	Cup-Roller Brg	380-7499
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1S-3062	Director-Water	418-9572

4AB		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180

4AB		
Original Part Number	Part Name	Classic Part Number
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race-Thrust Brg	453-3651
1T-0902	Bearing-Sleeve	389-6326
1T-1386	Yoke-Univ Joint	325-6239
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543

Sales Model D7H (Cont'd.)

4AB		
Original Part Number	Part Name	Classic Part Number
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1U-4851	Cyl Gp-0102 1360	422-4560
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367

4AB		
Original Part Number	Part Name	Classic Part Number
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3G-8746	Rod As	394-8217
3J-2682	Bracket	296-1345
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524

4AB		
Original Part Number	Part Name	Classic Part Number
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-5929	Gear	288-8718
3T-7192	Guard As	325-6100
3T-7195	Guard As	325-6101
3T-7398	Guide As	419-4647
3T-7701	Cylinder As	325-6058
3T-7710	Guide	325-6102
3T-7711	Guide	325-6103
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0640	Piston	325-6160
3Y-9984	Manifold-Exhaust	325-6123
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984

Sales Model D7H (Cont'd.)

4AB		
Original Part Number	Part Name	Classic Part Number
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0202	Pin As	325-6130
4T-0998	Lever	314-8687
4T-5495	Ballstud	314-8626
4T-7534	Pin	433-9209
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360

4AB		
Original Part Number	Part Name	Classic Part Number
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6J-5342	Retainer	325-6182
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-5404	Plate-Cl & Brake	325-6168
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl & Brake	325-6170
6T-7882	Gear-Planet	296-1352
6T-8249	Pin	399-8542
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-4819	Carrier-Planet	296-1348
6Y-5812	Bearing-Sleeve	325-6019

4AB		
Original Part Number	Part Name	Classic Part Number
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-7946	Disc-Friction	384-4801
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-8295	Head	388-0566
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531

Sales Model D7H (Cont'd.)

4AB		
Original Part Number	Part Name	Classic Part Number
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-6427	Pin	319-3462
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8E-6758	Connector As	396-0639
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658

4AB		
Original Part Number	Part Name	Classic Part Number
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084

4AB		
Original Part Number	Part Name	Classic Part Number
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-1177	Bearing-Rlr	419-1862
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-9543	Gear-Pump (Oil)	295-6426
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-4622	Pin	319-3468
9N-5769	Cover-Housing	325-6050
9P-0863	Pin	389-6321
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994

Sales Model D7H (Cont'd.)

4AB		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-0142	Cyl Gp-0184-0281	394-9830
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9W-2344	Coupling-Pump Dr	314-8666
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
127-5537	Core As-Oclr	325-6045
130-3139	Bearing-Sleeve	391-9875
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
139-6850	Gasket Kit	384-4809
141-4689	Bar Gp-Equalizer	443-3570
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275

4AB		
Original Part Number	**Part Name**	**Classic Part Number**
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
191-9323	Kit-Bearing	464-9064
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
208-8796	Retainer	417-9489

4AB		
Original Part Number	**Part Name**	**Classic Part Number**
232-3233	Bearing-Main	376-9085
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	376-3636

4FG		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-4106	Pin As-Drawbar	325-6126
1L-7319	Cup-Roller Brg	380-7499
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913

4FG		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582

4FG		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409

Sales Model D7H (Cont'd.)

4FG		
Original Part Number	Part Name	Classic Part Number
1T-0521	Retainer-Bearing	325-6180
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race-Thrust Brg	453-3651
1T-0902	Bearing-Sleeve	389-6326
1T-1386	Yoke-Univ Joint	325-6239
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628

4FG		
Original Part Number	Part Name	Classic Part Number
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698

4FG		
Original Part Number	Part Name	Classic Part Number
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5929	Gear	288-8718
3T-7192	Guard As	325-6100
3T-7195	Guard As	325-6101
3T-7398	Guide As	419-4647
3T-7701	Cylinder As	325-6058
3T-7710	Guide	325-6102
3T-7711	Guide	325-6103
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0640	Piston	325-6160
3Y-9984	Manifold-Exhaust	325-6123
4D-4065	Rod End-Spher	374-1824
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987

Sales Model D7H (Cont'd.)

4FG		
Original Part Number	Part Name	Classic Part Number
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535

4FG		
Original Part Number	Part Name	Classic Part Number
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6T-8249	Pin	399-8542
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724

4FG		
Original Part Number	Part Name	Classic Part Number
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-8295	Head	388-0566
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714

Sales Model D7H (Cont'd.)

4FG		
Original Part Number	Part Name	Classic Part Number
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-4526	Disc-Friction	417-9495
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

4FG		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9G-0280	Piston	283-5213

4FG		
Original Part Number	Part Name	Classic Part Number
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-4622	Pin	319-3468
9N-5769	Cover-Housing	325-6050
9P-0863	Pin	389-6321
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-2344	Coupling-Pump Dr	314-8666
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
110-8368	Bearing-Cup	416-2172
111-8015	Gasket As-Head	279-4977

Sales Model D7H (Cont'd.)

4FG		
Original Part Number	Part Name	Classic Part Number
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
127-5537	Core As-Oclr	325-6045
129-4259	Cyl Gp 0102 1437	393-3655
130-3139	Bearing-Sleeve	391-9875
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
139-6850	Gasket Kit	384-4809
141-4689	Bar Gp-Equalizer	443-3570
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
163-3127	Sleeve	419-4668
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351

4FG		
Original Part Number	Part Name	Classic Part Number
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
187-0605	Gasket Kit - Cl	382-5055
191-9323	Kit-Bearing	464-9064
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
234-8015	Kit-Gasket-Sch	437-8674
250-1984	Trunnion	319-3476

4FG		
Original Part Number	Part Name	Classic Part Number
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	376-3636
464-9064	Kit-Dt Brg-Cla	418-1931

5BF		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4106	Pin As-Drawbar	325-6126
1L-7319	Cup-Roller Brg	380-7499
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582

5BF		
Original Part Number	Part Name	Classic Part Number
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race-Thrust Brg	453-3651

5BF		
Original Part Number	Part Name	Classic Part Number
1T-0902	Bearing-Sleeve	389-6326
1T-1386	Yoke-Univ Joint	325-6239
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942

Sales Model D7H (Cont'd.)

5BF		
Original Part Number	Part Name	Classic Part Number
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1U-4851	Cyl Gp-0102 1360	422-4560
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229

5BF		
Original Part Number	Part Name	Classic Part Number
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3G-8746	Rod As	394-8217
3J-2682	Bracket	296-1345
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052

5BF		
Original Part Number	Part Name	Classic Part Number
3T-5672	Gear As-Pump	295-5447
3T-5929	Gear	288-8718
3T-7192	Guard As	325-6100
3T-7195	Guard As	325-6101
3T-7398	Guide As	419-4647
3T-7701	Cylinder As	325-6058
3T-7710	Guide	325-6102
3T-7711	Guide	325-6103
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0640	Piston	325-6160
3Y-9984	Manifold-Exhaust	325-6123
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217

Sales Model D7H (Cont'd.)

5BF		
Original Part Number	Part Name	Classic Part Number
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0202	Pin As	325-6130
4T-0998	Lever	314-8687
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883

5BF		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6T-8249	Pin	399-8542
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7G-2500	Gear-Planet	296-1350

5BF		
Original Part Number	Part Name	Classic Part Number
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-8295	Head	388-0566
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721

Sales Model D7H (Cont'd.)

5BF		
Original Part Number	Part Name	Classic Part Number
7T-3566	Piston	394-9191
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-4526	Disc-Friction	417-9495
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210

5BF		
Original Part Number	Part Name	Classic Part Number
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862

5BF		
Original Part Number	Part Name	Classic Part Number
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9J-5875	Bearing-Sleeve	308-9830
9J-8165	Cyl Gp-050 288 Y	398-2941
9J-8166	Cylinder As	394-9834
9L-5908	Gasket	433-8196
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-4622	Pin	319-3468
9N-5769	Cover-Housing	325-6050
9P-0863	Pin	389-6321
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-0142	Cyl Gp-0184-0281	394-9830
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9W-2344	Coupling-Pump Dr	314-8666
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437

Sales Model D7H (Cont'd.)

5BF		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
110-8368	Bearing-Cup	416-2172
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
127-5537	Core As-Oclr	325-6045
130-3139	Bearing-Sleeve	391-9875
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
135-7989	Gasket Kit	393-3633
139-6850	Gasket Kit	384-4809
141-4689	Bar Gp-Equalizer	443-3570
141-4974	Gasket Kit	388-0658
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038

5BF		
Original Part Number	**Part Name**	**Classic Part Number**
163-3127	Sleeve	419-4668
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
191-9323	Kit-Bearing	464-9064
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133

5BF		
Original Part Number	**Part Name**	**Classic Part Number**
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
310-1899	Pin As	393-0932
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	376-3636

5WB		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1L-7319	Cup-Roller Brg	380-7499
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399

5WB		
Original Part Number	**Part Name**	**Classic Part Number**
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410

5WB		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0679	Roller-Freewheel	384-4797
1T-0699	Impeller-Conv	235-1808
1T-0807	Race-Thrust Brg	453-3651
1T-0902	Bearing-Sleeve	389-6326

Sales Model D7H (Cont'd.)

5WB		
Original Part Number	Part Name	Classic Part Number
1T-1386	Yoke-Univ Joint	325-6239
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-1204	Trunnion	325-6224
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236

5WB		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3J-2682	Bracket	296-1345
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-1445	Pump Gp-Gr 3	386-3051

5WB		
Original Part Number	Part Name	Classic Part Number
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-5929	Gear	288-8718
3T-7192	Guard As	325-6100
3T-7195	Guard As	325-6101
3T-7398	Guide As	419-4647
3T-7701	Cylinder As	325-6058
3T-7710	Guide	325-6102
3T-7711	Guide	325-6103
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0640	Piston	325-6160
3Y-9984	Manifold-Exhaust	325-6123
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009

Sales Model D7H (Cont'd.)

5WB		
Original Part Number	Part Name	Classic Part Number
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-PrecInr	296-1355
4T-0998	Lever	314-8687
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467

5WB		
Original Part Number	Part Name	Classic Part Number
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-5404	Plate-Cl & Brake	325-6168
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl & Brake	325-6170
6T-7882	Gear-Planet	296-1352
6T-8249	Pin	399-8542
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-2202	Bearing-Spl Ball	380-1574

5WB		
Original Part Number	Part Name	Classic Part Number
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-4819	Carrier-Planet	296-1348
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-7946	Disc-Friction	384-4801
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-8295	Head	388-0566
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451

Sales Model D7H (Cont'd.)

5WB		
Original Part Number	Part Name	Classic Part Number
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3365	Carrier-Planet	388-6563
7T-3566	Piston	394-9191
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-4473	Manifold-Ex	443-2095
7W-5698	Pulley-Cshaft	295-5679
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512

5WB		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084

5WB		
Original Part Number	Part Name	Classic Part Number
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-9543	Gear-Pump (Oil)	295-6426
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-4622	Pin	319-3468
9N-5769	Cover-Housing	325-6050
9P-0863	Pin	389-6321
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

Sales Model D7H (Cont'd.)

5WB		
Original Part Number	Part Name	Classic Part Number
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9W-2344	Coupling-Pump Dr	314-8666
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
127-5537	Core As-Oclr	325-6045
129-4259	Cyl Gp 0102 1437	393-3655
130-3139	Bearing-Sleeve	391-9875
130-8412	Piston-Clutch	394-0910
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
139-6850	Gasket Kit	384-4809

5WB		
Original Part Number	Part Name	Classic Part Number
141-4689	Bar Gp-Equalizer	443-3570
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
191-9323	Kit-Bearing	464-9064

5WB		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	376-3636
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	377-7397

77Z		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1H-4106	Pin As-Drawbar	325-6126
1L-7319	Cup-Roller Brg	380-7499
1N-3576	Block Gp-Cyl	279-4978

77Z		
Original Part Number	Part Name	Classic Part Number
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0679	Roller-Freewheel	384-4797

77Z		
Original Part Number	Part Name	Classic Part Number
1T-0807	Race-Thrust Brg	453-3651
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136

Sales Model D7H (Cont'd.)

77Z		
Original Part Number	Part Name	Classic Part Number
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1U-4851	Cyl Gp-0102 1360	422-4560
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357

77Z		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-8746	Rod As	394-8217
3J-2682	Bracket	296-1345
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961
3L-9409	Cup-Roller Brg	399-4436
3T-1407	Disc-Friction	392-4516
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3T-7192	Guard As	325-6100
3T-7195	Guard As	325-6101
3T-7398	Guide As	419-4647
3T-7701	Cylinder As	325-6058
3T-7710	Guide	325-6102
3T-7711	Guide	325-6103
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0640	Piston	325-6160

77Z		
Original Part Number	Part Name	Classic Part Number
3Y-9984	Manifold-Exhaust	325-6123
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0202	Pin As	325-6130
4T-0998	Lever	314-8687
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603

Sales Model D7H (Cont'd.)

77Z		
Original Part Number	**Part Name**	**Classic Part Number**
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6J-5342	Retainer	325-6182
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-5404	Plate-Cl & Brake	325-6168
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0016	Pump Gp-Gr 4 Bsc	418-1957
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440

77Z		
Original Part Number	**Part Name**	**Classic Part Number**
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl & Brake	325-6170
6T-8249	Pin	399-8542
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-7946	Disc-Friction	384-4801
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7G-2500	Gear-Planet	296-1350
7G-2824	Piston	295-6439
7G-2828	Plate-Clutch	325-6171
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7681	Shaft As	307-1530
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-8295	Head	388-0566
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492

77Z		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-6427	Pin	319-3462
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-4473	Manifold-Ex	443-2095
7W-5698	Pulley-Cshaft	295-5679
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636

Sales Model D7H (Cont'd.)

77Z		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501

77Z		
Original Part Number	Part Name	Classic Part Number
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-1177	Bearing-Rlr	419-1862
9D-3242	Cone-Roller Brg	453-3659
9J-0123	Trunnion	325-6227
9M-1853	Mount As.	376-3638
9M-8281	Gear As-Pump	325-6089
9N-5769	Cover-Housing	325-6050
9P-0863	Pin	389-6321
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9W-2344	Coupling-Pump Dr	314-8666
9W-4897	Bracket As	295-6414
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
130-3139	Bearing-Sleeve	391-9875
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
136-7813	Bearing-Race	460-8296
141-4689	Bar Gp-Equalizer	443-3570

77Z		
Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0564	Rebuild Kit-Pump	380-7576
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
232-3233	Bearing-Main	376-9085
250-1984	Trunnion	319-3476
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
325-6012	Brg-Cla	325-6019
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

Sales Model D7H (Cont'd.)

79Z		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4106	Pin As-Drawbar	325-6126
1L-7319	Cup-Roller Brg	380-7499
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race-Thrust Brg	453-3651
1T-0902	Bearing-Sleeve	389-6326
1T-1386	Yoke-Univ Joint	325-6239
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138

79Z		
Original Part Number	Part Name	Classic Part Number
1U-1204	Trunnion	325-6224
1U-4851	Cyl Gp-0102 1360	422-4560
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357

79Z		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3G-8746	Rod As	394-8217
3J-2682	Bracket	296-1345
3J-6167	Bearing-Sleeve	299-1960
3J-6442	Bearing-Sleeve	299-1961
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052

Sales Model D7H (Cont'd.)

79Z		
Original Part Number	Part Name	Classic Part Number
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-5929	Gear	288-8718
3T-7192	Guard As	325-6100
3T-7195	Guard As	325-6101
3T-7398	Guide As	419-4647
3T-7701	Cylinder As	325-6058
3T-7710	Guide	325-6102
3T-7711	Guide	325-6103
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0640	Piston	325-6160
3Y-9984	Manifold-Exhaust	325-6123
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986

79Z		
Original Part Number	Part Name	Classic Part Number
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0202	Pin As	325-6130
4T-0998	Lever	314-8687
4T-5495	Ballstud	314-8626
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

79Z		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-5404	Plate-Cl & Brake	325-6168
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl & Brake	325-6170
6T-7882	Gear-Planet	296-1352
6T-8249	Pin	399-8542
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-4819	Carrier-Planet	296-1348
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-7946	Disc-Friction	384-4801

Sales Model D7H (Cont'd.)

79Z		
Original Part Number	Part Name	Classic Part Number
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-8295	Head	388-0566
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964

79Z		
Original Part Number	Part Name	Classic Part Number
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-6427	Pin	319-3462
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-4473	Manifold-Ex	443-2095
7W-5698	Pulley-Cshaft	295-5679
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893

79Z		
Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501

Sales Model D7H (Cont'd.)

79Z		
Original Part Number	Part Name	Classic Part Number
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-1177	Bearing-Rlr	419-1862
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-9543	Gear-Pump (Oil)	295-6426
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-4622	Pin	319-3468
9N-5769	Cover-Housing	325-6050
9P-0863	Pin	389-6321
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-0142	Cyl Gp-0184-0281	394-9830
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9W-2344	Coupling-Pump Dr	314-8666

79Z		
Original Part Number	Part Name	Classic Part Number
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
104-3014	Gasket Kit	388-0656
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
110-8368	Bearing-Cup	416-2172
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
127-5537	Core As-Oclr	325-6045
130-3139	Bearing-Sleeve	391-9875
131-3815	Seal Gp-Basic	325-6193
134-3038	Gasket Kit	437-3228
134-3056	Guard-Duo-Cone	421-7831
135-7989	Gasket Kit	393-3633
139-6850	Gasket Kit	384-4809
140-2246	Gasket Kit	383-3710
141-4689	Bar Gp-Equalizer	443-3570
141-4974	Gasket Kit	388-0658
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
163-3127	Sleeve	419-4668
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127

79Z		
Original Part Number	Part Name	Classic Part Number
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0564	Rebuild Kit-Pump	380-7576
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
187-0605	Gasket Kit - Cl	382-5055
191-9323	Kit-Bearing	464-9064
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653
464-9064	Kit-Dt Brg-Cla	419-6022

Sales Model D7H (Cont'd.)

79Z		
Original Part Number	**Part Name**	**Classic Part Number**
464-9064	Kit-Dt Brg-Cla	376-3636
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	434-3296

79Z		
Original Part Number	**Part Name**	**Classic Part Number**
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	415-1917

79Z		
Original Part Number	**Part Name**	**Classic Part Number**
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	377-7433

80Z		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-4106	Pin As-Drawbar	325-6126
1L-7319	Cup-Roller Brg	380-7499
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race-Thrust Brg	453-3651
1T-0902	Bearing-Sleeve	389-6326
1T-1386	Yoke-Univ Joint	325-6239
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543

80Z		
Original Part Number	**Part Name**	**Classic Part Number**
1T-2077	Retainer-Bearing	380-7408
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2P-0220	Gasket-Pump	398-2927

80Z		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3K-2511	Dowel-Reaction	383-2126

Sales Model D7H (Cont'd.)

80Z		
Original Part Number	Part Name	Classic Part Number
3T-0997	Bearing-Sleeve	307-1524
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-5929	Gear	288-8718
3T-7192	Guard As	325-6100
3T-7195	Guard As	325-6101
3T-7398	Guide As	419-4647
3T-7701	Cylinder As	325-6058
3T-7710	Guide	325-6102
3T-7711	Guide	325-6103
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0640	Piston	325-6160
3Y-9984	Manifold-Exhaust	325-6123
4D-4065	Rod End-Spher	374-1824
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985

80Z		
Original Part Number	Part Name	Classic Part Number
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0998	Lever	314-8687
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

80Z		
Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-5404	Plate-Cl & Brake	325-6168
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl & Brake	325-6170
6T-7882	Gear-Planet	296-1352
6T-8249	Pin	399-8542
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-4819	Carrier-Planet	296-1348
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-7946	Disc-Friction	384-4801

Sales Model D7H (Cont'd.)

80Z		
Original Part Number	Part Name	Classic Part Number
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9595	Core As-Radiator	396-9926
7E-9980	Camshaft	377-5851
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-8295	Head	388-0566
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964

80Z		
Original Part Number	Part Name	Classic Part Number
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-6427	Pin	319-3462
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-4473	Manifold-Ex	443-2095
7W-5698	Pulley-Cshaft	295-5679
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893

80Z		
Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501

Sales Model D7H (Cont'd.)

80Z		
Original Part Number	Part Name	Classic Part Number
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-1177	Bearing-Rlr	419-1862
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-9543	Gear-Pump (Oil)	295-6426
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-4622	Pin	319-3468
9N-5769	Cover-Housing	325-6050
9P-0863	Pin	389-6321
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-2344	Coupling-Pump Dr	314-8666
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-8270	Gear-Ring	308-9859

80Z		
Original Part Number	Part Name	Classic Part Number
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
106-6540	Retainer	418-1941
108-7754	Housing As.	433-9856
110-8368	Bearing-Cup	416-2172
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
127-5537	Core As-Oclr	325-6045
129-4259	Cyl Gp 0102 1437	393-3655
130-3139	Bearing-Sleeve	391-9875
131-3815	Seal Gp-Basic	325-6193
134-3038	Gasket Kit	437-3228
134-3056	Guard-Duo-Cone	421-7831
135-7989	Gasket Kit	393-3633
139-6850	Gasket Kit	384-4809
140-2246	Gasket Kit	383-3710
141-4689	Bar Gp-Equalizer	443-3570
141-4974	Gasket Kit	388-0658
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
163-3127	Sleeve	419-4668
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0564	Rebuild Kit-Pump	380-7576

80Z		
Original Part Number	Part Name	Classic Part Number
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
187-0605	Gasket Kit - Cl	382-5055
191-9323	Kit-Bearing	464-9064
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
208-8796	Retainer	417-9489
232-3233	Bearing-Main	376-9085
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653
464-9064	Kit-Dt Brg-Cla	376-3636
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	415-1917

Sales Model D7H (Cont'd.)

80Z		
Original Part Number	Part Name	Classic Part Number
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	419-6022

80Z		
Original Part Number	Part Name	Classic Part Number
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	420-6535

80Z		
Original Part Number	Part Name	Classic Part Number
464-9064	Kit-Dt Brg-Cla	434-3296

82Z		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1L-7319	Cup-Roller Brg	380-7499
1M-9177	Plate-Cl Press	226-6112
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-8554	Coupling-Exhaust	325-6052
1S-3062	Director-Water	418-9572
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race-Thrust Brg	453-3651
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210

82Z		
Original Part Number	Part Name	Classic Part Number
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-8340	Rod End-Yoke	374-4678
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1503	Gear-First	213-8637
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

82Z		
Original Part Number	Part Name	Classic Part Number
2P-2719	Pipe-Oil Filler	363-7454
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2S-3803	Gear	226-6106
2S-3804	Gear-Sliding	226-6107
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
3B-8845	Bearing-Inner	417-4509
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3L-9409	Cup-Roller Brg	399-4436
3P-3241	Plate-Pressure	325-6167
3P-7640	Gear-Ctrshft	325-6093
3P-7641	Gear-Ctrshft	325-6094
3P-7643	Gear-Pinion Shft	302-2669
3T-1407	Disc-Friction	392-4516
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3T-7192	Guard As	325-6100
3T-7195	Guard As	325-6101
3T-7398	Guide As	419-4647
3T-7701	Cylinder As	325-6058
3T-7710	Guide	325-6102
3T-7711	Guide	325-6103

Sales Model D7H (Cont'd.)

82Z		
Original Part Number	Part Name	Classic Part Number
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0640	Piston	325-6160
3Y-9984	Manifold-Exhaust	325-6123
4D-4065	Rod End-Spher	374-1824
4H-4021	Plate As-Loading	229-8219
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4K-7463	Seal-Lip Type	472-8007
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4864	Pump Gp-F Tfr	242-3442
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191

82Z		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5F-2465	Cup-Roller Brg	447-8060
5H-5500	Collar-Fly Cl	302-2704
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5M-5073	Joint Gp-Univ	325-6113
5M-7340	Cage-Bearing	325-6034
5M-7341	Cover-Bearing	452-0443
5M-7342	Flange-Shaft	215-1696
5M-7344	Gear-Fifth	213-8741
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6J-5342	Retainer	325-6182
6K-8088	Bearing-Roller	399-4428
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0169	Hub-Fly Clutch	297-7204
6P-5404	Plate-Cl	325-6168
6P-7704	Carrier-Ring	314-8658

82Z		
Original Part Number	Part Name	Classic Part Number
6S-2828	Cup-Roller Brg	384-5932
6T-0016	Pump Gp-Gr 4 Bsc	418-1957
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl	325-6170
6T-8249	Pin	399-8542
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-7946	Disc-Friction	384-4801
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7G-2500	Gear-Planet	296-1350
7G-2824	Piston	295-6439
7G-2828	Plate-Clutch	325-6171
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7681	Shaft As	307-1530
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803

Sales Model D7H (Cont'd.)

82Z		
Original Part Number	Part Name	Classic Part Number
7J-6461	Crown	325-6054
7J-8295	Head	388-0566
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3566	Piston	394-9191
7T-6427	Pin	319-3462
7T-9931	Countershaft	215-1760
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-5965	Race & Roller As	417-4512
8B-8439	Bearing-Ball	399-6069
8E-5450	Seal-Ebar	325-6190
8E-5993	Gear As-Idler	215-1903
8E-6754	Connector As	325-6044

82Z		
Original Part Number	Part Name	Classic Part Number
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8F-6058	Bearing-Sleeve	416-5494
8H-1383	Rod-Tie	299-2051
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8M-0874	Plunger As-Valve	311-9439
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5385	Manifold-Exhaust	391-9835
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

82Z		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-1177	Bearing-Rlr	419-1862
9D-3242	Cone-Roller Brg	453-3659
9F-7101	Bushing-Collar	299-1988
9H-5797	Plunger As-Pump	391-9891
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9M-8281	Gear As-Pump	325-6089
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-0863	Pin	389-6321
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6590	Pump Gp-Cl Oil	226-0176

Sales Model D7H (Cont'd.)

82Z		
Original Part Number	Part Name	Classic Part Number
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-0550	Shaft-Xmsn Upper	226-6000
9W-0552	Shaft-Pinion	226-6001
9W-2344	Coupling-Pump Dr	314-8666
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
130-3139	Bearing-Sleeve	391-9875
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
140-2246	Gasket Kit	383-3710
141-4689	Bar Gp-Equalizer	443-3570
148-7455	Valve - Exhaust	270-4361

82Z		
Original Part Number	Part Name	Classic Part Number
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7767	Pump Gp-Water -B	296-1365
187-0605	Gasket Kit - Cl	382-5055

82Z		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
232-3233	Bearing-Main	376-9085
250-1984	Trunnion	319-3476
250-6558	Liner Kit-Cla	295-6438
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
325-6012	Brg-Cla	325-6019
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653

Sales Model D7R

2EN		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4106	Pin As-Drawbar	325-6126
1L-7319	Cup-Roller Brg	380-7499
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294

2EN		
Original Part Number	Part Name	Classic Part Number
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race-Thrust Brg	453-3651

2EN		
Original Part Number	Part Name	Classic Part Number
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137

Sales Model D7R (Cont'd.)

2EN		
Original Part Number	Part Name	Classic Part Number
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1U-4851	Cyl Gp-0102 1360	422-4560
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356

2EN		
Original Part Number	Part Name	Classic Part Number
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3G-8746	Rod As	394-8217
3J-2682	Bracket	296-1345
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0640	Piston	325-6160
3Y-9984	Manifold-Exhaust	325-6123
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763

2EN		
Original Part Number	Part Name	Classic Part Number
4N-8591	Coupling-Exhaust	325-6053
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0202	Pin As	325-6130
4T-5495	Ballstud	314-8626
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920

Sales Model D7R (Cont'd.)

2EN		
Original Part Number	Part Name	Classic Part Number
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9439	Bearing-Spl Ball	371-4306
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5V-1882	Pin As	361-1700
6B-7469	Spacer	417-4535
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689

2EN		
Original Part Number	Part Name	Classic Part Number
7C-4297	Seal As-Cshaft	325-6192
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-8295	Head	388-0566
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491

2EN		
Original Part Number	Part Name	Classic Part Number
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585

Sales Model D7R (Cont'd.)

2EN		
Original Part Number	Part Name	Classic Part Number
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-4622	Pin	319-3468
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124

2EN		
Original Part Number	Part Name	Classic Part Number
9S-8679	Chamber As	325-6042
9T-0142	Cyl Gp-0184-0281	394-9830
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9W-2344	Coupling-Pump Dr	314-8666
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
110-8368	Bearing-Cup	416-2172
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
118-8458	Spider As-Fan	395-1306
127-5537	Core As-Oclr	325-6045
130-3139	Bearing-Sleeve	391-9875
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3038	Gasket Kit	437-3228
134-3056	Guard-Duo-Cone	421-7831
135-7989	Gasket Kit	393-3633
139-6850	Gasket Kit	384-4809

2EN		
Original Part Number	Part Name	Classic Part Number
140-2246	Gasket Kit	383-3710
140-8435	Flange	451-9015
141-4974	Gasket Kit	388-0658
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
163-4063	Core As-Rdtr	391-9826
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
191-9323	Kit-Bearing	464-9064
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
232-3233	Bearing-Main	376-9085
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357

Sales Model D7R (Cont'd.)

2EN		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
310-1899	Pin As	393-0932
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

2EN		
Original Part Number	Part Name	Classic Part Number
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	377-7433

2EN		
Original Part Number	Part Name	Classic Part Number
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	376-3636
464-9064	Kit-Dt Brg-Cla	434-3296

2HR		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4106	Pin As-Drawbar	325-6126
1L-7319	Cup-Roller Brg	380-7499
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race-Thrust Brg	453-3651
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543

2HR		
Original Part Number	Part Name	Classic Part Number
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1U-4851	Cyl Gp-0102 1360	422-4560
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2J-1227	Retainer	440-0850
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342

2HR		
Original Part Number	Part Name	Classic Part Number
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3G-8746	Rod As	394-8217
3J-2682	Bracket	296-1345
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524

Sales Model D7R (Cont'd.)

2HR		
Original Part Number	Part Name	Classic Part Number
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0640	Piston	325-6160
3Y-9984	Manifold-Exhaust	325-6123
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355

2HR		
Original Part Number	Part Name	Classic Part Number
4S-8538	Bearing-Spl Ball	417-4502
4T-0202	Pin As	325-6130
4T-5495	Ballstud	314-8626
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9439	Bearing-Spl Ball	371-4306
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436

2HR		
Original Part Number	Part Name	Classic Part Number
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0145	Plate-Locking	419-8801
6Y-5692	Plate-Brake	380-7492
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-8295	Head	388-0566
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990

Sales Model D7R (Cont'd.)

2HR		
Original Part Number	Part Name	Classic Part Number
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-6427	Pin	319-3462
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8G-4510	Plate-Clutch	383-2113
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8N-0703	Bearing-Sleeve	472-8037

2HR		
Original Part Number	Part Name	Classic Part Number
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215

2HR		
Original Part Number	Part Name	Classic Part Number
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-4622	Pin	319-3468
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-0142	Cyl Gp-0184-0281	394-9830
9T-4761	Head	325-6108
9W-1677	Bearing	297-7145
9W-2344	Coupling-Pump Dr	314-8666
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
110-8368	Bearing-Cup	416-2172
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
127-5537	Core As-Oclr	325-6045
130-3139	Bearing-Sleeve	391-9875
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004

Sales Model D7R (Cont'd.)

2HR		
Original Part Number	Part Name	Classic Part Number
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3038	Gasket Kit	437-3228
134-3056	Guard-Duo-Cone	421-7831
135-7989	Gasket Kit	393-3633
139-6850	Gasket Kit	384-4809
140-2246	Gasket Kit	383-3710
140-8435	Flange	451-9015
141-4974	Gasket Kit	388-0658
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
163-4063	Core As-Rdtr	391-9826
164-6560	Body As-Piston	477-7125

2HR		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
191-9323	Kit-Bearing	464-9064
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
232-3233	Bearing-Main	376-9085
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524

2HR		
Original Part Number	Part Name	Classic Part Number
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	376-3636
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	384-5932

3DN		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4106	Pin As-Drawbar	325-6126
1L-7319	Cup-Roller Brg	380-7499
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442

3DN		
Original Part Number	Part Name	Classic Part Number
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0679	Roller-Freewheel	384-4797
1T-0699	Impeller-Conv	235-1808
1T-0807	Race-Thrust Brg	453-3651
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038

3DN		
Original Part Number	Part Name	Classic Part Number
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981

Sales Model D7R (Cont'd.)

3DN		
Original Part Number	Part Name	Classic Part Number
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481

3DN		
Original Part Number	Part Name	Classic Part Number
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0640	Piston	325-6160
3Y-9984	Manifold-Exhaust	325-6123
4F-1252	Pin	295-5704
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985

3DN		
Original Part Number	Part Name	Classic Part Number
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9439	Bearing-Spl Ball	371-4306
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535

Sales Model D7R (Cont'd.)

3DN		
Original Part Number	Part Name	Classic Part Number
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-6751	Pin	325-6149
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205

3DN		
Original Part Number	Part Name	Classic Part Number
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-8295	Head	388-0566
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044

3DN		
Original Part Number	Part Name	Classic Part Number
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209

Sales Model D7R (Cont'd.)

3DN		
Original Part Number	Part Name	Classic Part Number
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-4622	Pin	319-3468
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-2344	Coupling-Pump Dr	314-8666
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490

3DN		
Original Part Number	Part Name	Classic Part Number
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
110-8368	Bearing-Cup	416-2172
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
118-8458	Spider As-Fan	395-1306
127-5537	Core As-Oclr	325-6045
129-4259	Cyl Gp 0102 1437	393-3655
130-3139	Bearing-Sleeve	391-9875
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3038	Gasket Kit	437-3228
134-3056	Guard-Duo-Cone	421-7831
135-7989	Gasket Kit	393-3633
139-6850	Gasket Kit	384-4809
140-2246	Gasket Kit	383-3710
140-8435	Flange	451-9015
141-4689	Bar Gp-Equalizer	443-3570
141-4974	Gasket Kit	388-0658
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
163-4063	Core As-Rdtr	391-9826
164-6560	Body As-Piston	477-7125

3DN		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
191-9323	Kit-Bearing	464-9064
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
232-3233	Bearing-Main	376-9085
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
464-9064	Kit-Dt Brg-Cla	376-3636
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	377-7433

Sales Model D7R (Cont'd.)

3DN		
Original Part Number	Part Name	Classic Part Number
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	418-1931

3DN		
Original Part Number	Part Name	Classic Part Number
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	420-2491

3DN		
Original Part Number	Part Name	Classic Part Number
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	434-3296

3ZR		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1L-7319	Cup-Roller Brg	380-7499
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race-Thrust Brg	453-3651
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942

3ZR		
Original Part Number	Part Name	Classic Part Number
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-1227	Retainer	440-0850
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214

3ZR		
Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3J-2682	Bracket	296-1345
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0640	Piston	325-6160
3Y-9984	Manifold-Exhaust	325-6123
4F-1252	Pin	295-5704
4J-0121	Cap-Bearing	360-2344
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009

Sales Model D7R (Cont'd.)

3ZR		
Original Part Number	Part Name	Classic Part Number
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0202	Pin As	325-6130
4T-5495	Ballstud	314-8626
4T-7534	Pin	433-9209
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5F-2465	Cup-Roller Brg	447-8060

3ZR		
Original Part Number	Part Name	Classic Part Number
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5V-1882	Pin As	361-1700
6B-7469	Spacer	417-4535
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6J-5342	Retainer	325-6182
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0145	Plate-Locking	419-8801
6Y-5692	Plate-Brake	380-7492

3ZR		
Original Part Number	Part Name	Classic Part Number
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961

Sales Model D7R (Cont'd.)

3ZR		
Original Part Number	Part Name	Classic Part Number
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-6427	Pin	319-3462
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8E-6758	Connector As	396-0639
8G-4510	Plate-Clutch	383-2113
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

3ZR		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-3668	Base As.-Coolant	419-4718
9N-4622	Pin	319-3468
9N-5769	Cover-Housing	325-6050

3ZR		
Original Part Number	Part Name	Classic Part Number
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-0142	Cyl Gp-0184-0281	394-9830
9W-1677	Bearing	297-7145
9W-2344	Coupling-Pump Dr	314-8666
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
110-8368	Bearing-Cup	416-2172
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
127-5537	Core As-Oclr	325-6045
129-4259	Cyl Gp 0102 1437	393-3655
130-3139	Bearing-Sleeve	391-9875
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125

Sales Model D7R (Cont'd.)

3ZR		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835

3ZR		
Original Part Number	**Part Name**	**Classic Part Number**
187-0605	Gasket Kit - Cl	382-5055
191-9323	Kit-Bearing	464-9064
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
232-3233	Bearing-Main	376-9085
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
310-1899	Pin As	393-0932

3ZR		
Original Part Number	**Part Name**	**Classic Part Number**
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	376-3636
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	384-5932

4SR		
Original Part Number	**Part Name**	**Classic Part Number**
1L-7319	Cup-Roller Brg	380-7499
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0679	Roller-Freewheel	384-4797

4SR		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0699	Impeller-Conv	235-1808
1T-0807	Race-Thrust Brg	453-3651
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981

4SR		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2J-1227	Retainer	440-0850
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164

Sales Model D7R (Cont'd.)

4SR		
Original Part Number	Part Name	Classic Part Number
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0640	Piston	325-6160
3Y-9984	Manifold-Exhaust	325-6123
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495

4SR		
Original Part Number	Part Name	Classic Part Number
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0202	Pin As	325-6130
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024

4SR		
Original Part Number	Part Name	Classic Part Number
5P-8772	Gasket Kit	383-1575
5P-9439	Bearing-Spl Ball	371-4306
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0145	Plate-Locking	419-8801
6Y-5692	Plate-Brake	380-7492
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7G-2500	Gear-Planet	296-1350

Sales Model D7R (Cont'd.)

4SR		
Original Part Number	Part Name	Classic Part Number
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-6427	Pin	319-3462
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296

4SR		
Original Part Number	Part Name	Classic Part Number
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8G-4510	Plate-Clutch	383-2113
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084

4SR		
Original Part Number	Part Name	Classic Part Number
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-4622	Pin	319-3468
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-0142	Cyl Gp-0184-0281	394-9830
9W-2344	Coupling-Pump Dr	314-8666
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-7754	Housing As.	433-9856

Sales Model D7R (Cont'd.)

4SR		
Original Part Number	**Part Name**	**Classic Part Number**
109-4848	Pulley-Cshaft	416-5507
110-8368	Bearing-Cup	416-2172
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
127-5537	Core As-Oclr	325-6045
129-4259	Cyl Gp 0102 1437	393-3655
130-3139	Bearing-Sleeve	391-9875
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
141-4689	Bar Gp-Equalizer	443-3570
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351

4SR		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
191-9323	Kit-Bearing	464-9064
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
232-3233	Bearing-Main	376-9085
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524

4SR		
Original Part Number	**Part Name**	**Classic Part Number**
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	376-3636
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	420-6535

5KZ		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410

5KZ		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1W-1669	Piston	325-6158

5KZ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282

Sales Model D7R (Cont'd.)

5KZ		
Original Part Number	Part Name	Classic Part Number
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700

5KZ		
Original Part Number	Part Name	Classic Part Number
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0202	Pin As	325-6130
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018

5KZ		
Original Part Number	Part Name	Classic Part Number
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5812	Bearing-Sleeve	325-6019

Sales Model D7R (Cont'd.)

5KZ		
Original Part Number	Part Name	Classic Part Number
6Y-5814	Pin	389-6305
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351

5KZ		
Original Part Number	Part Name	Classic Part Number
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

5KZ		
Original Part Number	Part Name	Classic Part Number
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-0142	Cyl Gp-0184-0281	394-9830
9W-2344	Coupling-Pump Dr	314-8666
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490

Sales Model D7R (Cont'd.)

5KZ		
Original Part Number	Part Name	Classic Part Number
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
127-5537	Core As-Oclr	325-6045
130-3139	Bearing-Sleeve	391-9875
131-3815	Seal Gp-Basic	325-6193
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

5KZ		
Original Part Number	Part Name	Classic Part Number
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
191-9323	Kit-Bearing	464-9064
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
232-3233	Bearing-Main	376-9085
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

5KZ		
Original Part Number	Part Name	Classic Part Number
258-2308	Bearing-Sleeve	325-6019
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	376-3636

5MR		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1L-7319	Cup-Roller Brg	380-7499
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442

5MR		
Original Part Number	Part Name	Classic Part Number
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0679	Roller-Freewheel	384-4797
1T-0807	Race-Thrust Brg	453-3651
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543

5MR		
Original Part Number	Part Name	Classic Part Number
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020

Sales Model D7R (Cont'd.)

5MR		
Original Part Number	Part Name	Classic Part Number
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037

5MR		
Original Part Number	Part Name	Classic Part Number
3G-5999	Bearing-Sleeve	391-9813
3J-2682	Bracket	296-1345
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0640	Piston	325-6160
3Y-9984	Manifold-Exhaust	325-6123
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988

5MR		
Original Part Number	Part Name	Classic Part Number
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0202	Pin As	325-6130
4T-5495	Ballstud	314-8626
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9439	Bearing-Spl Ball	371-4306
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358

Sales Model D7R (Cont'd.)

5MR		
Original Part Number	Part Name	Classic Part Number
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068

5MR		
Original Part Number	Part Name	Classic Part Number
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-2810	Case As-Filter	314-8512

5MR		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198

Sales Model D7R (Cont'd.)

5MR		
Original Part Number	Part Name	Classic Part Number
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-4622	Pin	319-3468
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-0142	Cyl Gp-0184-0281	394-9830
9W-1677	Bearing	297-7145
9W-2344	Coupling-Pump Dr	314-8666
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490

5MR		
Original Part Number	Part Name	Classic Part Number
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
110-8368	Bearing-Cup	416-2172
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
127-5537	Core As-Oclr	325-6045
129-4259	Cyl Gp 0102 1437	393-3655
130-3139	Bearing-Sleeve	391-9875
131-3815	Seal Gp-Basic	325-6193
134-3038	Gasket Kit	437-3228
135-7989	Gasket Kit	393-3633
140-2246	Gasket Kit	383-3710
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
163-4063	Core As-Rdtr	391-9826
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484

5MR		
Original Part Number	Part Name	Classic Part Number
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
187-0605	Gasket Kit - Cl	382-5055
191-9323	Kit-Bearing	464-9064
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
232-3233	Bearing-Main	376-9085
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	376-3636

Sales Model D7R (Cont'd.)

6ER		
Original Part Number	Part Name	Classic Part Number
1L-7319	Cup-Roller Brg	380-7499
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0679	Roller-Freewheel	384-4797
1T-0699	Impeller-Conv	235-1808
1T-0807	Race-Thrust Brg	453-3651
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659

6ER		
Original Part Number	Part Name	Classic Part Number
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524

6ER		
Original Part Number	Part Name	Classic Part Number
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0640	Piston	325-6160
3Y-9984	Manifold-Exhaust	325-6123
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603

Sales Model D7R (Cont'd.)

6ER		
Original Part Number	Part Name	Classic Part Number
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544

6ER		
Original Part Number	Part Name	Classic Part Number
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816

6ER		
Original Part Number	Part Name	Classic Part Number
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291

Sales Model D7R (Cont'd.)

6ER		
Original Part Number	Part Name	Classic Part Number
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931

6ER		
Original Part Number	Part Name	Classic Part Number
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-4622	Pin	319-3468
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-2344	Coupling-Pump Dr	314-8666
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
110-8368	Bearing-Cup	416-2172
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
127-5537	Core As-Oclr	325-6045
129-4259	Cyl Gp 0102 1437	393-3655
130-3139	Bearing-Sleeve	391-9875
131-3815	Seal Gp-Basic	325-6193
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
141-4689	Bar Gp-Equalizer	443-3570

6ER		
Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
191-9323	Kit-Bearing	464-9064
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
232-3233	Bearing-Main	376-9085
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
325-6012	Brg-Cla	325-6019

Sales Model D7R (Cont'd.)

6ER		
Original Part Number	Part Name	Classic Part Number
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

6ER		
Original Part Number	Part Name	Classic Part Number
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	418-1931

6ER		
Original Part Number	Part Name	Classic Part Number
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	376-3636
464-9064	Kit-Dt Brg-Cla	419-6022

9HM		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4106	Pin As-Drawbar	325-6126
1L-7319	Cup-Roller Brg	380-7499
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0679	Roller-Freewheel	384-4797
1T-0699	Impeller-Conv	235-1808
1T-0807	Race-Thrust Brg	453-3651
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408

9HM		
Original Part Number	Part Name	Classic Part Number
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2J-8489	Bearing-Sleeve	295-5691
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

9HM		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-4370	Plate-Clutch	325-6166
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3J-2682	Bracket	296-1345
3J-6559	Cap-Bearing	296-1346
3J-6573	Screw-Adjusting	302-2714
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3W-0640	Piston	325-6160

Sales Model D7R (Cont'd.)

9HM		
Original Part Number	Part Name	Classic Part Number
3Y-9984	Manifold-Exhaust	325-6123
4F-1252	Pin	295-5704
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-0854	Core As-Oil Clr	419-0890
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534

9HM		
Original Part Number	Part Name	Classic Part Number
4Y-2817	Ejector As	295-6423
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9439	Bearing-Spl Ball	371-4306
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0145	Plate-Locking	419-8801

9HM		
Original Part Number	Part Name	Classic Part Number
6Y-5692	Plate-Brake	380-7492
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-6751	Pin	325-6149
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-8295	Head	388-0566
7J-9884	Bearing-Sleeve	325-6016
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995

Sales Model D7R (Cont'd.)

9HM		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-6427	Pin	319-3462
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5838	Ejector As-Ex	443-2660
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8B-8439	Bearing-Ball	399-6069
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8G-4510	Plate-Clutch	383-2113
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623

9HM		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-4622	Pin	319-3468
9N-5769	Cover-Housing	325-6050

9HM		
Original Part Number	Part Name	Classic Part Number
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9W-2344	Coupling-Pump Dr	314-8666
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
110-8368	Bearing-Cup	416-2172
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
127-5537	Core As-Oclr	325-6045
129-4259	Cyl Gp 0102 1437	393-3655
130-3139	Bearing-Sleeve	391-9875
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3038	Gasket Kit	437-3228
134-3056	Guard-Duo-Cone	421-7831

Sales Model D7R (Cont'd.)

9HM		
Original Part Number	Part Name	Classic Part Number
135-7989	Gasket Kit	393-3633
139-6850	Gasket Kit	384-4809
140-2246	Gasket Kit	383-3710
140-8435	Flange	451-9015
141-4689	Bar Gp-Equalizer	443-3570
141-4974	Gasket Kit	388-0658
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
163-4063	Core As-Rdtr	391-9826
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127

9HM		
Original Part Number	Part Name	Classic Part Number
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
191-9323	Kit-Bearing	464-9064
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
232-3233	Bearing-Main	376-9085
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019

9HM		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	376-3636

ABJ		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920

ABJ		
Original Part Number	Part Name	Classic Part Number
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-9229	Muffler As	302-4282
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628

ABJ		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699

Sales Model D7R (Cont'd.)

ABJ		
Original Part Number	Part Name	Classic Part Number
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4S-8472	Hood As-Preclnr	296-1355
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6N-6721	Coupling	377-5830
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442

ABJ		
Original Part Number	Part Name	Classic Part Number
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568
7W-5838	Ejector As-Ex	443-2660
7W-5844	Bearing-Conn Rod	419-4650
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026

ABJ		
Original Part Number	Part Name	Classic Part Number
8E-6756	Bearing-Sleeve	325-6027
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9W-2344	Coupling-Pump Dr	314-8666
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
101-3125	Gasket	420-8567

Sales Model D7R (Cont'd.)

ABJ		
Original Part Number	**Part Name**	**Classic Part Number**
104-1706	Valve-Regulating	432-8281
108-7754	Housing As.	433-9856
110-8368	Bearing-Cup	416-2172
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-8458	Spider As-Fan	395-1306

ABJ		
Original Part Number	**Part Name**	**Classic Part Number**
129-4259	Cyl Gp 0102 1437	393-3655
130-3139	Bearing-Sleeve	391-9875
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
141-4689	Bar Gp-Equalizer	443-3570
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
155-2819	Ejector As-Exh	325-6078
160-6305	Cap-Bearing	295-5686
165-7211	Strip	325-6219
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573

ABJ		
Original Part Number	**Part Name**	**Classic Part Number**
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
208-5026	Pin	325-6133
216-4781	Gasket Kit	437-8144
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

ACS		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4106	Pin As-Drawbar	325-6126
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408

ACS		
Original Part Number	**Part Name**	**Classic Part Number**
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-9229	Muffler As	302-4282
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-8509	Cone-Roller Brg	399-4434
2P-1370	Cup-Rlr Brg	384-5921
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3J-2682	Bracket	296-1345

ACS		
Original Part Number	**Part Name**	**Classic Part Number**
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4M-5858	Bearing-Spl Ball	417-4495
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041

Sales Model D7R (Cont'd.)

ACS		
Original Part Number	Part Name	Classic Part Number
4P-8280	Manifold-Exhaust	430-7236
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0202	Pin As	325-6130
4T-5495	Ballstud	314-8626
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6N-6721	Coupling	377-5830
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-5692	Plate-Brake	380-7492
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915

ACS		
Original Part Number	Part Name	Classic Part Number
7C-3567	Mount As	314-8689
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7T-6427	Pin	319-3462
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568
7W-5838	Ejector As-Ex	443-2660
7W-5844	Bearing-Conn Rod	419-4650
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8G-4510	Plate-Clutch	383-2113
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
9G-0280	Piston	283-5213

ACS		
Original Part Number	Part Name	Classic Part Number
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9W-1677	Bearing	297-7145
9W-2344	Coupling-Pump Dr	314-8666
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
104-1706	Valve-Regulating	432-8281
108-7754	Housing As.	433-9856
110-8368	Bearing-Cup	416-2172
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

Sales Model D7R (Cont'd.)

ACS		
Original Part Number	Part Name	Classic Part Number
118-8458	Spider As-Fan	395-1306
130-3139	Bearing-Sleeve	391-9875
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
155-2819	Ejector As-Exh	325-6078
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038

ACS		
Original Part Number	Part Name	Classic Part Number
165-7211	Strip	325-6219
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
208-5026	Pin	325-6133
216-4781	Gasket Kit	437-8144

ACS		
Original Part Number	Part Name	Classic Part Number
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

ADW		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689

ADW		
Original Part Number	Part Name	Classic Part Number
1W-4746	Retainer-Gear	295-5690
1W-9229	Muffler As	302-4282
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-8509	Cone-Roller Brg	399-4434
2P-1370	Cup-Rlr Brg	384-5921
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3J-2682	Bracket	296-1345
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407

ADW		
Original Part Number	Part Name	Classic Part Number
4K-1102	Bearing-Sleeve	325-6010
4M-5858	Bearing-Spl Ball	417-4495
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0202	Pin As	325-6130
4T-5495	Ballstud	314-8626
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306

Sales Model D7R (Cont'd.)

ADW		
Original Part Number	Part Name	Classic Part Number
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6N-6721	Coupling	377-5830
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-5692	Plate-Brake	380-7492
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7T-6427	Pin	319-3462
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568

ADW		
Original Part Number	Part Name	Classic Part Number
7W-5838	Ejector As-Ex	443-2660
7W-5844	Bearing-Conn Rod	419-4650
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8G-4510	Plate-Clutch	383-2113
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9W-1677	Bearing	297-7145
9W-2344	Coupling-Pump Dr	314-8666
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9W-9940	Mount As.	360-2355

ADW		
Original Part Number	Part Name	Classic Part Number
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
104-1706	Valve-Regulating	432-8281
108-7754	Housing As.	433-9856
110-8368	Bearing-Cup	416-2172
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-8458	Spider As-Fan	395-1306
130-3139	Bearing-Sleeve	391-9875
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
155-2819	Ejector As-Exh	325-6078
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
165-7211	Strip	325-6219
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
208-5026	Pin	325-6133
216-4781	Gasket Kit	437-8144

Sales Model D7R (Cont'd.)

ADW		
Original Part Number	Part Name	Classic Part Number
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

ADW		
Original Part Number	Part Name	Classic Part Number
258-2308	Bearing-Sleeve	325-6019
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966

ADW		
Original Part Number	Part Name	Classic Part Number
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

AEC		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-9229	Muffler As	302-4282
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628

AEC		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3J-2682	Bracket	296-1345
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041

AEC		
Original Part Number	Part Name	Classic Part Number
4P-8280	Manifold-Exhaust	430-7236
4S-8472	Hood As-Preclnr	296-1355
4T-0202	Pin As	325-6130
4T-5495	Ballstud	314-8626
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6N-6721	Coupling	377-5830
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990

Sales Model D7R (Cont'd.)

AEC		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5692	Plate-Brake	380-7492
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568
7W-5838	Ejector As-Ex	443-2660
7W-5844	Bearing-Conn Rod	419-4650
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026

AEC		
Original Part Number	Part Name	Classic Part Number
8E-6756	Bearing-Sleeve	325-6027
8G-4510	Plate-Clutch	383-2113
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9W-1677	Bearing	297-7145
9W-2344	Coupling-Pump Dr	314-8666
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-4834	Cone-Rlr Bearing	422-6490

AEC		
Original Part Number	Part Name	Classic Part Number
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
104-1706	Valve-Regulating	432-8281
108-7754	Housing As.	433-9856
110-8368	Bearing-Cup	416-2172
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-8458	Spider As-Fan	395-1306
130-3139	Bearing-Sleeve	391-9875
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
155-2819	Ejector As-Exh	325-6078
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
165-7211	Strip	325-6219
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
208-5026	Pin	325-6133
216-4781	Gasket Kit	437-8144
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524

Sales Model D7R (Cont'd.)

AEC		
Original Part Number	**Part Name**	**Classic Part Number**
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019

AEC		
Original Part Number	**Part Name**	**Classic Part Number**
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966

AEC		
Original Part Number	**Part Name**	**Classic Part Number**
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

AFG		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4106	Pin As-Drawbar	325-6126
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-9229	Muffler As	302-4282
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-8509	Cone-Roller Brg	399-4434
2P-1370	Cup-Rlr Brg	384-5921
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465

AFG		
Original Part Number	**Part Name**	**Classic Part Number**
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4M-5858	Bearing-Spl Ball	417-4495
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917

AFG		
Original Part Number	**Part Name**	**Classic Part Number**
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6N-6721	Coupling	377-5830
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-5692	Plate-Brake	380-7492
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104

Sales Model D7R (Cont'd.)

AFG		
Original Part Number	Part Name	Classic Part Number
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7T-6427	Pin	319-3462
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568
7W-5838	Ejector As-Ex	443-2660
7W-5844	Bearing-Conn Rod	419-4650
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8G-4510	Plate-Clutch	383-2113
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931

AFG		
Original Part Number	Part Name	Classic Part Number
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9W-2344	Coupling-Pump Dr	314-8666
9W-8270	Gear-Ring	308-9859
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
104-1706	Valve-Regulating	432-8281
108-7754	Housing As.	433-9856
110-8368	Bearing-Cup	416-2172
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259

AFG		
Original Part Number	Part Name	Classic Part Number
116-1102	Sleeve-Injector	451-9024
118-8458	Spider As-Fan	395-1306
129-4259	Cyl Gp 0102 1437	393-3655
130-3139	Bearing-Sleeve	391-9875
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
141-4689	Bar Gp-Equalizer	443-3570
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
155-2819	Ejector As-Exh	325-6078
160-6305	Cap-Bearing	295-5686
165-7211	Strip	325-6219
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
208-5026	Pin	325-6133
216-4781	Gasket Kit	437-8144
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

AGN		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535

AGN		
Original Part Number	Part Name	Classic Part Number
1P-3935	Cone-Roller Brg	377-7397
1T-0421	Flange As-Output	295-5442

AGN		
Original Part Number	Part Name	Classic Part Number
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410

Sales Model D7R (Cont'd.)

AGN		
Original Part Number	Part Name	Classic Part Number
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-9229	Muffler As	302-4282
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3J-2682	Bracket	296-1345
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699

AGN		
Original Part Number	Part Name	Classic Part Number
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4S-8472	Hood As-Preclnr	296-1355
4T-0202	Pin As	325-6130
4T-5495	Ballstud	314-8626
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387

AGN		
Original Part Number	Part Name	Classic Part Number
6J-5342	Retainer	325-6182
6N-6721	Coupling	377-5830
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568
7W-5838	Ejector As-Ex	443-2660

Sales Model D7R (Cont'd.)

AGN		
Original Part Number	Part Name	Classic Part Number
7W-5844	Bearing-Conn Rod	419-4650
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446

AGN		
Original Part Number	Part Name	Classic Part Number
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9W-1677	Bearing	297-7145
9W-2344	Coupling-Pump Dr	314-8666
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
108-7754	Housing As.	433-9856
110-8368	Bearing-Cup	416-2172
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259

AGN		
Original Part Number	Part Name	Classic Part Number
116-1102	Sleeve-Injector	451-9024
118-8458	Spider As-Fan	395-1306
130-3139	Bearing-Sleeve	391-9875
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
155-2819	Ejector As-Exh	325-6078
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
165-7211	Strip	325-6219
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
208-5026	Pin	325-6133
216-4781	Gasket Kit	437-8144
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

BNM		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

BNM		
Original Part Number	Part Name	Classic Part Number
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738

BNM		
Original Part Number	Part Name	Classic Part Number
1T-0447	Carrier-Ring	295-0409
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038

Sales Model D7R (Cont'd.)

BNM		
Original Part Number	Part Name	Classic Part Number
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-9229	Muffler As	302-4282
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-8509	Cone-Roller Brg	399-4434
2P-1370	Cup-Rlr Brg	384-5921
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4M-5858	Bearing-Spl Ball	417-4495
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4S-8472	Hood As-Preclnr	296-1355

BNM		
Original Part Number	Part Name	Classic Part Number
4S-8538	Bearing-Spl Ball	417-4502
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6N-6721	Coupling	377-5830
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-5692	Plate-Brake	380-7492
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450

BNM		
Original Part Number	Part Name	Classic Part Number
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7T-6427	Pin	319-3462
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568
7W-5838	Ejector As-Ex	443-2660
7W-5844	Bearing-Conn Rod	419-4650
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8G-4510	Plate-Clutch	383-2113
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-1853	Mount As.	376-3638

Sales Model D7R (Cont'd.)

BNM		
Original Part Number	Part Name	Classic Part Number
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9W-2344	Coupling-Pump Dr	314-8666
9W-8270	Gear-Ring	308-9859
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
104-1706	Valve-Regulating	432-8281
108-7754	Housing As.	433-9856
111-2645	Valve-Pump Byp	441-1561

BNM		
Original Part Number	Part Name	Classic Part Number
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-8458	Spider As-Fan	395-1306
129-4259	Cyl Gp 0102 1437	393-3655
130-3139	Bearing-Sleeve	391-9875
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
141-4689	Bar Gp-Equalizer	443-3570
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154

BNM		
Original Part Number	Part Name	Classic Part Number
155-2819	Ejector As-Exh	325-6078
165-7211	Strip	325-6219
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
208-5026	Pin	325-6133
216-4781	Gasket Kit	437-8144
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

BNX		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683

BNX		
Original Part Number	Part Name	Classic Part Number
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-9229	Muffler As	302-4282
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480

BNX		
Original Part Number	Part Name	Classic Part Number
2P-1370	Cup-Rlr Brg	384-5921
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700

Sales Model D7R (Cont'd.)

BNX		
Original Part Number	Part Name	Classic Part Number
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4S-8472	Hood As-Preclnr	296-1355
4T-0202	Pin As	325-6130
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6N-6721	Coupling	377-5830
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932

BNX		
Original Part Number	Part Name	Classic Part Number
6T-0064	Shaft-Planet	295-6442
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568
7W-5838	Ejector As-Ex	443-2660
7W-5844	Bearing-Conn Rod	419-4650
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044

BNX		
Original Part Number	Part Name	Classic Part Number
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9W-2344	Coupling-Pump Dr	314-8666
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-7215	Sleeve-Isolator	425-3646
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
101-3125	Gasket	420-8567

Sales Model D7R (Cont'd.)

BNX		
Original Part Number	Part Name	Classic Part Number
104-1706	Valve-Regulating	432-8281
108-7754	Housing As.	433-9856
110-8368	Bearing-Cup	416-2172
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

BNX		
Original Part Number	Part Name	Classic Part Number
118-8458	Spider As-Fan	395-1306
129-4259	Cyl Gp 0102 1437	393-3655
130-3139	Bearing-Sleeve	391-9875
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
141-4689	Bar Gp-Equalizer	443-3570
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
155-2819	Ejector As-Exh	325-6078
165-7211	Strip	325-6219
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600

BNX		
Original Part Number	Part Name	Classic Part Number
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
208-5026	Pin	325-6133
216-4781	Gasket Kit	437-8144
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

BPT		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942

BPT		
Original Part Number	Part Name	Classic Part Number
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-9229	Muffler As	302-4282
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3J-2682	Bracket	296-1345

BPT		
Original Part Number	Part Name	Classic Part Number
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4E-3196	Pin As	361-1697
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4N-2514	Gear-Flywheel	421-7283

Sales Model D7R (Cont'd.)

BPT		
Original Part Number	Part Name	Classic Part Number
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4S-8472	Hood As-Preclnr	296-1355
4T-0202	Pin As	325-6130
4T-5495	Ballstud	314-8626
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6N-6721	Coupling	377-5830
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5812	Bearing-Sleeve	325-6019

BPT		
Original Part Number	Part Name	Classic Part Number
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-9346	Bearing-Sleeve	374-8357
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568
7W-5838	Ejector As-Ex	443-2660
7W-5844	Bearing-Conn Rod	419-4650
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

BPT		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9W-1677	Bearing	297-7145
9W-2344	Coupling-Pump Dr	314-8666
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-7215	Sleeve-Isolator	425-3646
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
108-7754	Housing As.	433-9856
110-8368	Bearing-Cup	416-2172

Sales Model D7R (Cont'd.)

BPT		
Original Part Number	Part Name	Classic Part Number
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-8458	Spider As-Fan	395-1306
129-4259	Cyl Gp 0102 1437	393-3655

BPT		
Original Part Number	Part Name	Classic Part Number
130-3139	Bearing-Sleeve	391-9875
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
155-2819	Ejector As-Exh	325-6078
160-6306	Cap-Bearing	325-6038
165-7211	Strip	325-6219
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367

BPT		
Original Part Number	Part Name	Classic Part Number
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
208-5026	Pin	325-6133
216-4781	Gasket Kit	437-8144
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

BRM		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942

BRM		
Original Part Number	Part Name	Classic Part Number
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-9229	Muffler As	302-4282
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3J-2682	Bracket	296-1345
3K-2511	Dowel-Reaction	383-2126

BRM		
Original Part Number	Part Name	Classic Part Number
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4E-3196	Pin As	361-1697
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236

Sales Model D7R (Cont'd.)

BRM		
Original Part Number	Part Name	Classic Part Number
4S-8472	Hood As-Preclnr	296-1355
4T-0202	Pin As	325-6130
4T-5495	Ballstud	314-8626
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6J-5342	Retainer	325-6182
6N-6721	Coupling	377-5830
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153

BRM		
Original Part Number	Part Name	Classic Part Number
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-9346	Bearing-Sleeve	374-8357
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568
7W-5838	Ejector As-Ex	443-2660
7W-5844	Bearing-Conn Rod	419-4650
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8E-6758	Connector As	396-0639
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

BRM		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9N-3668	Base As.-Coolant	419-4718
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9W-1677	Bearing	297-7145
9W-2344	Coupling-Pump Dr	314-8666
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-7215	Sleeve-Isolator	425-3646
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281

Sales Model D7R (Cont'd.)

BRM		
Original Part Number	Part Name	Classic Part Number
108-7754	Housing As.	433-9856
110-8368	Bearing-Cup	416-2172
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-8458	Spider As-Fan	395-1306

BRM		
Original Part Number	Part Name	Classic Part Number
129-4259	Cyl Gp 0102 1437	393-3655
130-3139	Bearing-Sleeve	391-9875
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
155-2819	Ejector As-Exh	325-6078
160-6306	Cap-Bearing	325-6038
165-7211	Strip	325-6219
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573

BRM		
Original Part Number	Part Name	Classic Part Number
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
208-5026	Pin	325-6133
216-4781	Gasket Kit	437-8144
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

BRP		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136

BRP		
Original Part Number	Part Name	Classic Part Number
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-9229	Muffler As	302-4282
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-8509	Cone-Roller Brg	399-4434
2P-1370	Cup-Rlr Brg	384-5921
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3J-2682	Bracket	296-1345
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698

BRP		
Original Part Number	Part Name	Classic Part Number
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4M-5858	Bearing-Spl Ball	417-4495
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4T-0202	Pin As	325-6130
4T-5495	Ballstud	314-8626
4W-1203	Cup-Rlr Brg	418-9603

Sales Model D7R (Cont'd.)

BRP		
Original Part Number	Part Name	Classic Part Number
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6J-5342	Retainer	325-6182
6N-6721	Coupling	377-5830
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-5692	Plate-Brake	380-7492
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450

BRP		
Original Part Number	Part Name	Classic Part Number
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7T-6427	Pin	319-3462
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568
7W-5838	Ejector As-Ex	443-2660
7W-5844	Bearing-Conn Rod	419-4650
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8E-6758	Connector As	396-0639
8G-4510	Plate-Clutch	383-2113
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931

BRP		
Original Part Number	Part Name	Classic Part Number
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-7148	Cap As-Rain	378-3994
9W-1677	Bearing	297-7145
9W-2344	Coupling-Pump Dr	314-8666
9W-4897	Bracket As	295-6414
9W-8270	Gear-Ring	308-9859
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
104-1706	Valve-Regulating	432-8281
108-7754	Housing As.	433-9856
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-8458	Spider As-Fan	395-1306
129-4259	Cyl Gp 0102 1437	393-3655
130-3139	Bearing-Sleeve	391-9875
134-3056	Guard-Duo-Cone	421-7831
140-8435	Flange	451-9015
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
155-2819	Ejector As-Exh	325-6078

Sales Model D7R (Cont'd.)

BRP		
Original Part Number	Part Name	Classic Part Number
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
165-7211	Strip	325-6219
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573

BRP		
Original Part Number	Part Name	Classic Part Number
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
208-5026	Pin	325-6133
216-4781	Gasket Kit	437-8144
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524

BRP		
Original Part Number	Part Name	Classic Part Number
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

CBZ		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1T-0051	Wheel-Impeller	388-6582
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1W-1669	Piston	325-6158

CBZ		
Original Part Number	Part Name	Classic Part Number
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9229	Muffler As	302-4282
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197

CBZ		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4J-6374	Bearing-Sleeve	295-6407
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

Sales Model D7R (Cont'd.)

CBZ		
Original Part Number	Part Name	Classic Part Number
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6E-1108	Bearing-Sleeve	325-6023

CBZ		
Original Part Number	Part Name	Classic Part Number
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0145	Plate-Locking	419-8801
6Y-5692	Plate-Brake	380-7492
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7E-3557	Spider As-Fan	430-4471
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435

CBZ		
Original Part Number	Part Name	Classic Part Number
7N-1164	Mount As	295-5451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-6427	Pin	319-3462
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8G-4510	Plate-Clutch	383-2113
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

Sales Model D7R (Cont'd.)

CBZ		
Original Part Number	**Part Name**	**Classic Part Number**
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218

CBZ		
Original Part Number	**Part Name**	**Classic Part Number**
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-2344	Coupling-Pump Dr	314-8666
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
108-7754	Housing As.	433-9856
109-4848	Pulley-Cshaft	416-5507
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
127-5537	Core As-Oclr	325-6045
130-3139	Bearing-Sleeve	391-9875
131-3815	Seal Gp-Basic	325-6193
140-8435	Flange	451-9015
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As-Exh	325-6078
156-8208	Kit-Gasket-Trans	434-7275
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-7211	Strip	325-6219
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194

CBZ		
Original Part Number	**Part Name**	**Classic Part Number**
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
191-9323	Kit-Bearing	464-9064
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
208-5026	Pin	325-6133
232-3233	Bearing-Main	376-9085
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	376-3636

D7R		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849

Sales Model D7R (Cont'd.)

D7R		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921
2W-7213	Bearing-Sleeve	419-4667
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712

D7R		
Original Part Number	Part Name	Classic Part Number
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4D-4065	Rod End-Spher	374-1824
4J-5241	Retainer	434-1415
4J-6374	Bearing-Sleeve	295-6407
4N-2514	Gear-Flywheel	421-7283
4T-0202	Pin As	325-6130
4W-1203	Cup-Rlr Brg	418-9603
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6J-5342	Retainer	325-6182
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915

D7R		
Original Part Number	Part Name	Classic Part Number
7C-3567	Mount As	314-8689
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217

Sales Model D7R (Cont'd.)

D7R		
Original Part Number	Part Name	Classic Part Number
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859

D7R		
Original Part Number	Part Name	Classic Part Number
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
110-8368	Bearing-Cup	416-2172
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4072	Bearing	397-5069
118-8458	Spider As-Fan	395-1306
129-4259	Cyl Gp 0102 1437	393-3655
130-3139	Bearing-Sleeve	391-9875
134-3056	Guard-Duo-Cone	421-7831
141-4689	Bar Gp-Equalizer	443-3570

D7R		
Original Part Number	Part Name	Classic Part Number
161-3411	Gasket	394-0896
165-7211	Strip	325-6219
208-5026	Pin	325-6133
229-1490	Sleeve-Injector	393-3659
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

DJR		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690

DJR		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3J-2682	Bracket	296-1345
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216

DJR		
Original Part Number	Part Name	Classic Part Number
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4N-2514	Gear-Flywheel	421-7283
4T-0202	Pin As	325-6130
4T-5495	Ballstud	314-8626
4W-1203	Cup-Rlr Brg	418-9603
5F-2465	Cup-Roller Brg	447-8060
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306

Sales Model D7R (Cont'd.)

DJR		
Original Part Number	Part Name	Classic Part Number
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6J-5342	Retainer	325-6182
6J-9482	Pin As	380-7400
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491

DJR		
Original Part Number	Part Name	Classic Part Number
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218

DJR		
Original Part Number	Part Name	Classic Part Number
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-1677	Bearing	297-7145
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4072	Bearing	397-5069
118-8458	Spider As-Fan	395-1306
130-3139	Bearing-Sleeve	391-9875
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
165-7211	Strip	325-6219
208-5026	Pin	325-6133
229-1490	Sleeve-Injector	393-3659
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

DJT		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410

DJT		
Original Part Number	Part Name	Classic Part Number
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920

DJT		
Original Part Number	Part Name	Classic Part Number
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136

Sales Model D7R (Cont'd.)

DJT		
Original Part Number	Part Name	Classic Part Number
1U-0873	Pin	325-6137
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-9229	Muffler As	302-4282
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4J-6374	Bearing-Sleeve	295-6407
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917

DJT		
Original Part Number	Part Name	Classic Part Number
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6I-8500	Plate-Clutch	377-7436
6J-5342	Retainer	325-6182
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026

DJT		
Original Part Number	Part Name	Classic Part Number
8E-6756	Bearing-Sleeve	325-6027
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-7215	Sleeve-Isolator	425-3646
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
110-8368	Bearing-Cup	416-2172
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446

Sales Model D7R (Cont'd.)

DJT		
Original Part Number	**Part Name**	**Classic Part Number**
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
130-3139	Bearing-Sleeve	391-9875
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
155-2819	Ejector As-Exh	325-6078
165-7211	Strip	325-6219
176-4168	Bridge As-Valve	419-4727

DJT		
Original Part Number	**Part Name**	**Classic Part Number**
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
208-5026	Pin	325-6133
216-4781	Gasket Kit	437-8144
250-1984	Trunnion	319-3476

DJT		
Original Part Number	**Part Name**	**Classic Part Number**
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

DLN		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480

DLN		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1370	Cup-Rlr Brg	384-5921
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4D-4065	Rod End-Spher	374-1824
4J-5241	Retainer	434-1415
4J-6374	Bearing-Sleeve	295-6407
4N-2514	Gear-Flywheel	421-7283
4T-0202	Pin As	325-6130
4W-1203	Cup-Rlr Brg	418-9603
5F-2465	Cup-Roller Brg	447-8060
5J-8118	Bearing-Sleeve	451-9018

DLN		
Original Part Number	**Part Name**	**Classic Part Number**
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6J-5342	Retainer	325-6182
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7G-2830	Ring-Seal	295-6441

Sales Model D7R (Cont'd.)

DLN		
Original Part Number	Part Name	Classic Part Number
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8J-2880	Cap-Bearing	295-6420

DLN		
Original Part Number	Part Name	Classic Part Number
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490

DLN		
Original Part Number	Part Name	Classic Part Number
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4072	Bearing	397-5069
118-8458	Spider As-Fan	395-1306
129-4259	Cyl Gp 0102 1437	393-3655
130-3139	Bearing-Sleeve	391-9875
134-3056	Guard-Duo-Cone	421-7831
141-4689	Bar Gp-Equalizer	443-3570
161-3411	Gasket	394-0896
165-7211	Strip	325-6219
208-5026	Pin	325-6133
229-1490	Sleeve-Injector	393-3659
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

DSH		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326

DSH		
Original Part Number	Part Name	Classic Part Number
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138

DSH		
Original Part Number	Part Name	Classic Part Number
1U-1204	Trunnion	325-6224
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921

Sales Model D7R (Cont'd.)

DSH		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3J-2682	Bracket	296-1345
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4N-2514	Gear-Flywheel	421-7283
4T-0202	Pin As	325-6130
4T-5495	Ballstud	314-8626
4W-1203	Cup-Rlr Brg	418-9603
5F-2465	Cup-Roller Brg	447-8060
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023

DSH		
Original Part Number	Part Name	Classic Part Number
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6J-5342	Retainer	325-6182
6J-9482	Pin As	380-7400
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026

DSH		
Original Part Number	Part Name	Classic Part Number
8E-6756	Bearing-Sleeve	325-6027
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-1677	Bearing	297-7145
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4072	Bearing	397-5069
118-8458	Spider As-Fan	395-1306
130-3139	Bearing-Sleeve	391-9875

Sales Model D7R (Cont'd.)

DSH		
Original Part Number	**Part Name**	**Classic Part Number**
134-3056	Guard-Duo-Cone	421-7831
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
165-7211	Strip	325-6219
208-5026	Pin	325-6133

DSH		
Original Part Number	**Part Name**	**Classic Part Number**
229-1490	Sleeve-Injector	393-3659
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029

DSH		
Original Part Number	**Part Name**	**Classic Part Number**
258-2308	Bearing-Sleeve	325-6019
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

EEA		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-9229	Muffler As	302-4282
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693

EEA		
Original Part Number	**Part Name**	**Classic Part Number**
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4J-5241	Retainer	434-1415
4J-6374	Bearing-Sleeve	295-6407
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4S-8472	Hood As-Preclnr	296-1355
4T-0202	Pin As	325-6130
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018

EEA		
Original Part Number	**Part Name**	**Classic Part Number**
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6J-5342	Retainer	325-6182
6N-6721	Coupling	377-5830
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7G-2830	Ring-Seal	295-6441

Sales Model D7R (Cont'd.)

EEA		
Original Part Number	Part Name	Classic Part Number
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445

EEA		
Original Part Number	Part Name	Classic Part Number
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8626	Gear-Sun	283-5219
9S-7148	Cap As-Rain	378-3994
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-7215	Sleeve-Isolator	425-3646
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447

EEA		
Original Part Number	Part Name	Classic Part Number
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-8458	Spider As-Fan	395-1306
130-3139	Bearing-Sleeve	391-9875
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
155-2819	Ejector As-Exh	325-6078
165-7211	Strip	325-6219
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
208-5026	Pin	325-6133
216-4781	Gasket Kit	437-8144
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

KDY		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685

KDY		
Original Part Number	Part Name	Classic Part Number
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326

KDY		
Original Part Number	Part Name	Classic Part Number
1T-1993	Wheel-Turbine	235-0920
1T-2048	Carrier As-Stat	472-8038
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408

Sales Model D7R (Cont'd.)

KDY		
Original Part Number	Part Name	Classic Part Number
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-9229	Muffler As	302-4282
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-8509	Cone-Roller Brg	399-4434
2P-1370	Cup-Rlr Brg	384-5921
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3K-2511	Dowel-Reaction	383-2126
3T-0997	Bearing-Sleeve	307-1524
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4J-6374	Bearing-Sleeve	295-6407
4M-5858	Bearing-Spl Ball	417-4495
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4S-8472	Hood As-Preclnr	296-1355
4S-8538	Bearing-Spl Ball	417-4502
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-6126	Bearing	377-7433

KDY		
Original Part Number	Part Name	Classic Part Number
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5342	Retainer	325-6182
6N-6721	Coupling	377-5830
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-5692	Plate-Brake	380-7492
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7T-6427	Pin	319-3462
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207

KDY		
Original Part Number	Part Name	Classic Part Number
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8G-4510	Plate-Clutch	383-2113
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-7148	Cap As-Rain	378-3994
9W-2344	Coupling-Pump Dr	314-8666
9W-8270	Gear-Ring	308-9859
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
104-1706	Valve-Regulating	432-8281

Sales Model D7R (Cont'd.)

KDY		
Original Part Number	Part Name	Classic Part Number
108-7754	Housing As.	433-9856
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

KDY		
Original Part Number	Part Name	Classic Part Number
130-3139	Bearing-Sleeve	391-9875
140-8435	Flange	451-9015
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
155-2819	Ejector As-Exh	325-6078
165-7211	Strip	325-6219
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367

KDY		
Original Part Number	Part Name	Classic Part Number
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
208-5026	Pin	325-6133
216-4781	Gasket Kit	437-8144
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

KNA		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-9229	Muffler As	302-4282
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628

KNA		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4J-5241	Retainer	434-1415
4J-6374	Bearing-Sleeve	295-6407
4N-2514	Gear-Flywheel	421-7283

KNA		
Original Part Number	Part Name	Classic Part Number
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4S-8472	Hood As-Preclnr	296-1355
4T-0202	Pin As	325-6130
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023

Sales Model D7R (Cont'd.)

KNA		
Original Part Number	Part Name	Classic Part Number
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6J-5342	Retainer	325-6182
6N-6721	Coupling	377-5830
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5812	Bearing-Sleeve	325-6019
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650

KNA		
Original Part Number	Part Name	Classic Part Number
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5908	Gasket	433-8196
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8626	Gear-Sun	283-5219
9S-7148	Cap As-Rain	378-3994
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9Y-7215	Sleeve-Isolator	425-3646
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
110-8368	Bearing-Cup	416-2172
111-2645	Valve-Pump Byp	441-1561

KNA		
Original Part Number	Part Name	Classic Part Number
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-8458	Spider As-Fan	395-1306
130-3139	Bearing-Sleeve	391-9875
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
155-2819	Ejector As-Exh	325-6078
165-7211	Strip	325-6219
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
208-5026	Pin	325-6133
216-4781	Gasket Kit	437-8144
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

Sales Model D7R (Cont'd.)

LAZ		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921
2W-7213	Bearing-Sleeve	419-4667
2W-8494	Pulley-Alt	295-5692
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3J-2682	Bracket	296-1345
3K-2511	Dowel-Reaction	383-2126

LAZ		
Original Part Number	Part Name	Classic Part Number
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4N-2514	Gear-Flywheel	421-7283
4T-0202	Pin As	325-6130
4T-5495	Ballstud	314-8626
4W-1203	Cup-Rlr Brg	418-9603
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6J-5342	Retainer	325-6182
6J-9482	Pin As	380-7400
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442

LAZ		
Original Part Number	Part Name	Classic Part Number
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8J-2880	Cap-Bearing	295-6420
8J-5654	Bearing-Sleeve	325-6028

Sales Model D7R (Cont'd.)

LAZ		
Original Part Number	Part Name	Classic Part Number
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218

LAZ		
Original Part Number	Part Name	Classic Part Number
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-1677	Bearing	297-7145
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
110-8368	Bearing-Cup	416-2172
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4072	Bearing	397-5069
118-8458	Spider As-Fan	395-1306

LAZ		
Original Part Number	Part Name	Classic Part Number
130-3139	Bearing-Sleeve	391-9875
134-3056	Guard-Duo-Cone	421-7831
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
165-7211	Strip	325-6219
208-5026	Pin	325-6133
229-1490	Sleeve-Injector	393-3659
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

R7B		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138

R7B		
Original Part Number	Part Name	Classic Part Number
1U-1204	Trunnion	325-6224
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3J-2682	Bracket	296-1345
3K-2511	Dowel-Reaction	383-2126

R7B		
Original Part Number	Part Name	Classic Part Number
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4N-2514	Gear-Flywheel	421-7283
4T-0202	Pin As	325-6130
4T-5495	Ballstud	314-8626
4W-1203	Cup-Rlr Brg	418-9603
5F-2465	Cup-Roller Brg	447-8060

Sales Model D7R (Cont'd.)

R7B		
Original Part Number	Part Name	Classic Part Number
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6J-5342	Retainer	325-6182
6J-9482	Pin As	380-7400
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068

R7B		
Original Part Number	Part Name	Classic Part Number
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217

R7B		
Original Part Number	Part Name	Classic Part Number
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-1677	Bearing	297-7145
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4072	Bearing	397-5069
130-3139	Bearing-Sleeve	391-9875
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
165-7211	Strip	325-6219
208-5026	Pin	325-6133
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

R7C		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535

R7C		
Original Part Number	Part Name	Classic Part Number
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410

R7C		
Original Part Number	Part Name	Classic Part Number
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326

Sales Model D7R (Cont'd.)

R7C		
Original Part Number	Part Name	Classic Part Number
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3J-2682	Bracket	296-1345
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6374	Bearing-Sleeve	295-6407

R7C		
Original Part Number	Part Name	Classic Part Number
4K-1102	Bearing-Sleeve	325-6010
4N-2514	Gear-Flywheel	421-7283
4T-0202	Pin As	325-6130
4T-5495	Ballstud	314-8626
4W-1203	Cup-Rlr Brg	418-9603
5F-2465	Cup-Roller Brg	447-8060
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6J-5342	Retainer	325-6182
6J-9482	Pin As	380-7400
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068

R7C		
Original Part Number	Part Name	Classic Part Number
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923

Sales Model D7R (Cont'd.)

R7C		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3582	Cone-Roller Brg	396-4144
9W-1677	Bearing	297-7145
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583

R7C		
Original Part Number	**Part Name**	**Classic Part Number**
108-7754	Housing As.	433-9856
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4072	Bearing	397-5069
129-4259	Cyl Gp 0102 1437	393-3655
130-3139	Bearing-Sleeve	391-9875
141-4689	Bar Gp-Equalizer	443-3570
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896

R7C		
Original Part Number	**Part Name**	**Classic Part Number**
165-7211	Strip	325-6219
208-5026	Pin	325-6133
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

R7H		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4106	Pin As-Drawbar	325-6126
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921

R7H		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4D-4065	Rod End-Spher	374-1824
4J-5241	Retainer	434-1415
4J-6374	Bearing-Sleeve	295-6407
4N-2514	Gear-Flywheel	421-7283
4T-0202	Pin As	325-6130
4W-1203	Cup-Rlr Brg	418-9603
5F-2465	Cup-Roller Brg	447-8060
5J-8118	Bearing-Sleeve	451-9018

R7H		
Original Part Number	**Part Name**	**Classic Part Number**
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6J-5342	Retainer	325-6182
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8250	Retainer	319-3473
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5814	Pin	389-6305
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196

Sales Model D7R (Cont'd.)

R7H		
Original Part Number	Part Name	Classic Part Number
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636

R7H		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491

R7H		
Original Part Number	Part Name	Classic Part Number
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4072	Bearing	397-5069
129-4259	Cyl Gp 0102 1437	393-3655
130-3139	Bearing-Sleeve	391-9875
141-4689	Bar Gp-Equalizer	443-3570
161-3411	Gasket	394-0896
165-7211	Strip	325-6219
208-5026	Pin	325-6133
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

RHT		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0902	Bearing-Sleeve	389-6326
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543

RHT		
Original Part Number	Part Name	Classic Part Number
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
2A-4429	Lock-Retainer	379-0174

RHT		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2P-1370	Cup-Rlr Brg	384-5921
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3F-4971	Pin	295-5693
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813

Sales Model D7R (Cont'd.)

RHT		
Original Part Number	Part Name	Classic Part Number
3J-2682	Bracket	296-1345
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5929	Gear	288-8718
3W-0640	Piston	325-6160
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-5241	Retainer	434-1415
4J-6374	Bearing-Sleeve	295-6407
4K-1102	Bearing-Sleeve	325-6010
4N-2514	Gear-Flywheel	421-7283
4T-0202	Pin As	325-6130
4T-5495	Ballstud	314-8626
4W-1203	Cup-Rlr Brg	418-9603
5F-2465	Cup-Roller Brg	447-8060
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6J-5342	Retainer	325-6182
6J-9482	Pin As	380-7400
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8250	Retainer	319-3473

RHT		
Original Part Number	Part Name	Classic Part Number
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-5814	Pin	389-6305
6Y-6752	Pin	325-6150
6Y-7474	Pin-Pivot	325-6153
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7T-6427	Pin	319-3462
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-5838	Ejector As-Ex	443-2660
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8J-2880	Cap-Bearing	295-6420
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116

RHT		
Original Part Number	Part Name	Classic Part Number
8P-9507	Piston-Clutch	283-5212
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9W-1677	Bearing	297-7145
9W-4897	Bracket As	295-6414
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
108-7754	Housing As.	433-9856
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4072	Bearing	397-5069
118-8458	Spider As-Fan	395-1306
130-3139	Bearing-Sleeve	391-9875
160-6306	Cap-Bearing	325-6038
161-3411	Gasket	394-0896
165-7211	Strip	325-6219
208-5026	Pin	325-6133
229-1490	Sleeve-Injector	393-3659
250-1984	Trunnion	319-3476
258-2303	Bearing-Sleeve	307-1524

Track-Type Tractors

Sales Model D7R (Cont'd.)

RHT		
Original Part Number	**Part Name**	**Classic Part Number**
258-2305	Bearing-Sleeve	325-6029

RHT		
Original Part Number	**Part Name**	**Classic Part Number**
258-2308	Bearing-Sleeve	325-6019

RHT		
Original Part Number	**Part Name**	**Classic Part Number**
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model D8

01H		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-6577	Cone-Spl Tapered	374-1839
1J-0774	Bracket	369-9485
1L-7205	Bearing-Ball	416-2167
1M-7250	Bowl	360-2296
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3H-0881	Ring-Piston	465-8998

01H		
Original Part Number	**Part Name**	**Classic Part Number**
3H-1996	Bearing-Ball	380-1498
3K-3124	Muffler-Trap	247-2673
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-5003	Spring As-Arm	383-2127
4J-1999	Ballstud	314-8625
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5F-7993	Pin	319-3454
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6F-2904	Bearing	295-5673
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6T-8886	Disc-Ster Cl	380-7517
6Y-7652	Cup-Rlr Brg	399-6067
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7K-5448	Cup-Bearing	415-1922
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538

01H		
Original Part Number	**Part Name**	**Classic Part Number**
7N-4170	Pump Gp-Eng Oil	379-0169
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7T-0204	Bearing-Brace	247-4126
7W-2731	Retainer	423-3541
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8F-3170	Bearing-Roller	417-4504
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
8H-2434	Drum-Ster Cl Dr	216-7862
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8S-3517	Bearing-Spl Ball	417-4501
9F-3358	Link As-Cl Drive	394-0207
9F-7101	Bushing-Collar	299-1988
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311
160-6305	Cap-Bearing	295-5686

02U		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119

02U		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-6577	Cone-Spl Tapered	374-1839

02U		
Original Part Number	**Part Name**	**Classic Part Number**
1J-0774	Bracket	369-9485
1L-7205	Bearing-Ball	416-2167
1M-7250	Bowl	360-2296
1S-1888	Bracket-Lamp	297-7147

Sales Model D8 (Cont'd.)

02U		
Original Part Number	Part Name	Classic Part Number
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3H-0881	Ring-Piston	465-8998
3H-1996	Bearing-Ball	380-1498
3K-3124	Muffler-Trap	247-2673
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-5003	Spring As-Arm	383-2127
4J-1999	Ballstud	314-8625
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997

02U		
Original Part Number	Part Name	Classic Part Number
5F-7993	Pin	319-3454
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6F-2904	Bearing	295-5673
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6T-8886	Disc-Ster Cl	380-7517
6Y-7652	Cup-Rlr Brg	399-6067
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7K-5448	Cup-Bearing	415-1922
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
7N-4170	Pump Gp-Eng Oil	379-0169
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417

02U		
Original Part Number	Part Name	Classic Part Number
7T-0204	Bearing-Brace	247-4126
7W-2731	Retainer	423-3541
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8F-3170	Bearing-Roller	417-4504
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
8H-2434	Drum-Ster Cl Dr	216-7862
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8S-3517	Bearing-Spl Ball	417-4501
9F-3358	Link As-Cl Drive	394-0207
9F-7101	Bushing-Collar	299-1988
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311
160-6305	Cap-Bearing	295-5686

05E		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-6577	Cone-Spl Tapered	374-1839
1J-0774	Bracket	369-9485
1L-7205	Bearing-Ball	416-2167
1M-7250	Bowl	360-2296
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174

05E		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3H-0881	Ring-Piston	465-8998
3H-1996	Bearing-Ball	380-1498
3K-3124	Muffler-Trap	247-2673
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-5003	Spring As-Arm	383-2127
4J-1999	Ballstud	314-8625

05E		
Original Part Number	Part Name	Classic Part Number
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5F-7993	Pin	319-3454
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6F-2904	Bearing	295-5673
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6T-8886	Disc-Ster Cl	380-7517
6Y-7652	Cup-Rlr Brg	399-6067
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414

Sales Model D8 (Cont'd.)

05E		
Original Part Number	**Part Name**	**Classic Part Number**
7K-5448	Cup-Bearing	415-1922
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
7N-4170	Pump Gp-Eng Oil	379-0169
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7T-0204	Bearing-Brace	247-4126
7W-2731	Retainer	423-3541

05E		
Original Part Number	**Part Name**	**Classic Part Number**
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8F-3170	Bearing-Roller	417-4504
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
8H-2434	Drum-Ster Cl Dr	216-7862
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342

05E		
Original Part Number	**Part Name**	**Classic Part Number**
8S-3517	Bearing-Spl Ball	417-4501
9F-3358	Link As-Cl Drive	394-0207
9F-7101	Bushing-Collar	299-1988
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311
160-6305	Cap-Bearing	295-5686

08R		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-6577	Cone-Spl Tapered	374-1839
1J-0774	Bracket	369-9485
1L-7205	Bearing-Ball	416-2167
1M-7250	Bowl	360-2296
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3H-0881	Ring-Piston	465-8998

08R		
Original Part Number	**Part Name**	**Classic Part Number**
3H-1996	Bearing-Ball	380-1498
3K-3124	Muffler-Trap	247-2673
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-5003	Spring As-Arm	383-2127
4J-1999	Ballstud	314-8625
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5F-7993	Pin	319-3454
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6F-2904	Bearing	295-5673
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6T-8886	Disc-Ster Cl	380-7517
6Y-7652	Cup-Rlr Brg	399-6067
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7K-5448	Cup-Bearing	415-1922
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538

08R		
Original Part Number	**Part Name**	**Classic Part Number**
7N-4170	Pump Gp-Eng Oil	379-0169
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7T-0204	Bearing-Brace	247-4126
7W-2731	Retainer	423-3541
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8F-3170	Bearing-Roller	417-4504
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
8H-2434	Drum-Ster Cl Dr	216-7862
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8S-3517	Bearing-Spl Ball	417-4501
9F-3358	Link As-Cl Drive	394-0207
9F-7101	Bushing-Collar	299-1988
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311
160-6305	Cap-Bearing	295-5686

Sales Model D8 (Cont'd.)

13A		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1J-0774	Bracket	369-9485
1L-7205	Bearing-Ball	416-2167
1M-7250	Bowl	360-2296
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2L-5271	Bearing-Ball	371-4305
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3F-4971	Pin	295-5693
3H-0881	Ring-Piston	465-8998
3H-5867	Retainer-Spring	390-0992
3H-8726	Mount As	385-7208
4B-1455	Cap As-Filler	361-1719

13A		
Original Part Number	**Part Name**	**Classic Part Number**
4J-1999	Ballstud	314-8625
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5F-7993	Pin	319-3454
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5M-6709	Check As-Ball	380-7542
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6T-8886	Disc-Ster Cl	380-7517
7F-9541	Pin As-Drawbar	296-1361
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7N-4170	Pump Gp-Eng Oil	379-0169

13A		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7639	Rotator-Valve	383-1582
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
9F-7101	Bushing-Collar	299-1988
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
124-3237	Precleaner As	432-4220
160-6305	Cap-Bearing	295-5686

15A		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1L-7205	Bearing-Ball	416-2167
1M-7250	Bowl	360-2296
1M-9444	Retainer-Spring	299-2046
1S-3743	Bearing-Ball	384-4786
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2P-0483	Chamber As	256-4760
2S-3966	Ring-Seal	297-7237

15A		
Original Part Number	**Part Name**	**Classic Part Number**
2S-4015	Plunger As-Valve	311-9438
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3B-8845	Bearing-Inner	417-4509
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3H-0881	Ring-Piston	465-8998
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
4B-1455	Cap As-Filler	361-1719
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-5003	Spring As-Arm	383-2127
4H-9640	Bearing-Sleeve	386-4921
4M-9183	Bearing-Sleeve	386-4924

15A		
Original Part Number	**Part Name**	**Classic Part Number**
4N-3875	Ring-Piston	465-8997
5F-7993	Pin	319-3454
5H-7071	Director-Water	388-0555
5J-4321	Trunnion	302-2700
5M-6709	Check As-Ball	380-7542
5P-9553	Gasket Kit - Wp	393-3624
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6F-2904	Bearing	295-5673
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6L-7816	Seal-O-Ring	314-8542
6N-5987	Shaft-Water Pump	390-0998
6T-8886	Disc-Ster Cl	380-7517
7H-6967	Bearing-Ball	422-6489
7K-5448	Cup-Bearing	415-1922

Sales Model D8 (Cont'd.)

15A		
Original Part Number	**Part Name**	**Classic Part Number**
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7N-3352	Plate-Spacer	386-3062
7N-4170	Pump Gp-Eng Oil	379-0169
7N-4407	Gasket-Rod Comp	433-9853
7N-7639	Rotator-Valve	383-1582

15A		
Original Part Number	**Part Name**	**Classic Part Number**
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7T-0204	Bearing-Brace	247-4126
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206

15A		
Original Part Number	**Part Name**	**Classic Part Number**
8H-2434	Drum-Ster Cl Dr	216-7862
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-4810	Gasket-Cyl Head	437-2046
9H-6236	Rod As	390-0999
9M-5350	Spring-Valve	380-7573
9V-7710	Univ Joint As	394-8234
160-6305	Cap-Bearing	295-5686

Sales Model D8E, D8F

14A		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1H-4106	Pin As-Drawbar	325-6126
1J-0774	Bracket	369-9485
1J-6746	Pin	256-4817
1J-6747	Pin	367-6078
1J-6749	Screw-Adj	256-4824
1L-7205	Bearing-Ball	416-2167
1M-7250	Bowl	360-2296
1M-9444	Retainer-Spring	299-2046
1P-0005	Pump Gp-Fuel Tfr	256-4756
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2P-0483	Chamber As	256-4760
2S-3966	Ring-Seal	297-7237

14A		
Original Part Number	**Part Name**	**Classic Part Number**
2S-4015	Plunger As-Valve	311-9438
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3H-0881	Ring-Piston	465-8998
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-5003	Spring As-Arm	383-2127
4H-9640	Bearing-Sleeve	386-4921
4J-1999	Ballstud	314-8625
4M-9183	Bearing-Sleeve	386-4924
4M-9215	Gear-Pump Idler	311-9391
4N-3875	Ring-Piston	465-8997
5F-7993	Pin	319-3454
5H-7071	Director-Water	388-0555
5J-4321	Trunnion	302-2700
5M-6709	Check As-Ball	380-7542
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467

14A		
Original Part Number	**Part Name**	**Classic Part Number**
5P-9553	Gasket Kit - Wp	393-3624
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5S-9080	Pulley-Alt Drive	264-5883
6B-6224	Ferrule	419-4738
6F-2904	Bearing	295-5673
6F-2956	Cup-Spl Tapered	420-6538
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6L-7816	Seal-O-Ring	314-8542
6N-5987	Shaft-Water Pump	390-0998
6T-8886	Disc-Ster Cl	380-7517
6V-2202	Bearing-Spl Ball	380-1574
7H-6967	Bearing-Ball	422-6489
7K-5448	Cup-Bearing	415-1922
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7N-3352	Plate-Spacer	386-3062

Sales Model D8E, D8F (Cont'd.)

14A		
Original Part Number	**Part Name**	**Classic Part Number**
7N-4170	Pump Gp-Eng Oil	379-0169
7N-4407	Gasket-Rod Comp	433-9853
7N-7639	Rotator-Valve	383-1582
7N-9352	Gasket	433-8188
7S-5003	Cap As-Rain	379-0184
7S-7809	Cap As-Radiator	295-6417
7T-0204	Bearing-Brace	247-4126
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539

14A		
Original Part Number	**Part Name**	**Classic Part Number**
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
8H-2434	Drum-Ster Cl Dr	216-7862
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342

14A		
Original Part Number	**Part Name**	**Classic Part Number**
8N-4810	Gasket-Cyl Head	437-2046
9F-7101	Bushing-Collar	299-1988
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9M-5350	Spring-Valve	380-7573
9S-8217	Bolt-Spring	469-4672
9W-1677	Bearing	297-7145
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
308-1845	Seal-Wiper	472-8032

Sales Model D8G

15A		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-6577	Cone-Spl Tapered	374-1839
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1L-7205	Bearing-Ball	416-2167
1M-7250	Bowl	360-2296
1M-9444	Retainer-Spring	299-2046
1S-3743	Bearing-Ball	384-4786
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2P-0483	Chamber As	256-4760
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3B-8845	Bearing-Inner	417-4509
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694

15A		
Original Part Number	**Part Name**	**Classic Part Number**
3H-0881	Ring-Piston	465-8998
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
4B-1455	Cap As-Filler	361-1719
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-5003	Spring As-Arm	383-2127
4H-9640	Bearing-Sleeve	386-4921
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5F-7993	Pin	319-3454
5H-7071	Director-Water	388-0555
5J-4321	Trunnion	302-2700
5M-6709	Check As-Ball	380-7542
5P-9553	Gasket Kit - Wp	393-3624
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6F-2904	Bearing	295-5673
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6L-7816	Seal-O-Ring	314-8542
6N-5987	Shaft-Water Pump	390-0998

15A		
Original Part Number	**Part Name**	**Classic Part Number**
6T-8886	Disc-Ster Cl	380-7517
7H-6967	Bearing-Ball	422-6489
7K-5448	Cup-Bearing	415-1922
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7N-3352	Plate-Spacer	386-3062
7N-4170	Pump Gp-Eng Oil	379-0169
7N-4407	Gasket-Rod Comp	433-9853
7N-7639	Rotator-Valve	383-1582
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7T-0204	Bearing-Brace	247-4126
7W-2731	Retainer	423-3541
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206

Sales Model D8G (Cont'd.)

15A		
Original Part Number	**Part Name**	**Classic Part Number**
8H-2434	Drum-Ster Cl Dr	216-7862
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636

15A		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
8N-4810	Gasket-Cyl Head	437-2046
9H-6236	Rod As	390-0999

15A		
Original Part Number	**Part Name**	**Classic Part Number**
9M-5350	Spring-Valve	380-7573
9V-7710	Univ Joint As	394-8234
160-6305	Cap-Bearing	295-5686

Sales Model D8H

35A		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1J-6746	Pin	256-4817
1L-7205	Bearing-Ball	416-2167
1M-1994	Bearing As-Rlr	399-6066
1M-9444	Retainer-Spring	299-2046
1P-3318	Strip	385-7206
1S-1888	Bracket-Lamp	297-7147
1S-2269	Sleeve	226-2720
1S-7056	Bearing-Ball	422-6483
2A-4429	Lock-Retainer	379-0174
2D-6421	Bearing-Outer	417-4510
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2J-1227	Retainer	440-0850
2K-5254	Bearing-Outer	377-7419
2L-5271	Bearing-Ball	371-4305
2M-1149	Race-Brg Outer	418-9615
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2P-1604	Piston-Ster Cl	219-9694
2P-1605	Pilot-Cl Piston	219-9695
2S-3913	Cage-Gear Brg	217-7722
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438

35A		
Original Part Number	**Part Name**	**Classic Part Number**
2S-4357	Pinion-Fdr	217-7706
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3B-3967	Race-Roller Brg	386-4947
3B-8845	Bearing-Inner	417-4509
3F-6185	Pin	295-5694
3F-6523	Pin-Clevis	256-4818
3G-7660	Cartridge Gp	422-8103
3H-0881	Ring-Piston	465-8998
3H-7161	Pin	256-4819
3H-7164	Pin-Pivot	256-4820
3H-8726	Mount As	385-7208
3J-3493	Ballstud	256-4832
3J-5190	Cap-Brg	256-4837
3J-6484	Bearing-Sleeve	380-7383
3J-7798	Bracket	385-3791
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3S-6989	Nut-Spanner	219-9701
3S-7308	Cage-Pinion Brg	219-9702
3S-9669	Bearing	416-2168
3T-3150	Guide-Frt Idler	394-0191
4B-7255	Cone-Bearing	386-4951
4F-5003	Spring As-Arm	383-2127
4H-9640	Bearing-Sleeve	386-4921
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997

35A		
Original Part Number	**Part Name**	**Classic Part Number**
4S-9325	Race-Spl Rlr Brg	418-9590
4S-9326	Bearing	417-4506
4S-9782	Race & Roller As	385-3779
4S-9783	Race-Rlr Bearing	418-9589
4T-6869	Cartridge Gp	422-8104
5H-1719	Pump Gp-Fd Oil	226-0168
5H-7071	Director-Water	388-0555
5J-1192	Bearing-Sleeve	374-8355
5J-4321	Trunnion	302-2700
5K-8591	Bearing-Outer	380-7502
5M-6674	Guard-F Idler Lh	226-2736
5M-6709	Check As-Ball	380-7542
5M-7306	Cylinder	226-2737
5N-8501	Head As-Cyl	256-4762
5P-9553	Gasket Kit - Wp	393-3624
5S-0160	Strip-Guard	226-2738
5S-0161	Strip-Guard	226-2739
5S-0464	Gear-First Red	216-7852
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5T-8739	Spider Gp-Brg	373-5386
6B-6224	Ferrule	419-4738
6F-2956	Cup-Spl Tapered	420-6538
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6J-2326	Pin	319-3458
6J-9258	Trunnion As	256-4846

Sales Model D8H (Cont'd.)

35A		
Original Part Number	Part Name	Classic Part Number
6L-7816	Seal-O-Ring	314-8542
6N-5987	Shaft-Water Pump	390-0998
6P-0549	Guard-Fdr Wear	223-4812
6P-2776	Gear-Final Drive	217-7718
6P-3593	Support	229-8231
6P-3597	Retainer	222-1770
6P-4327	Pad	384-3472
6P-8829	Retainer	380-7407
6T-0952	Pad As	367-6087
6T-8886	Disc-Ster Cl	380-7517
6Y-7652	Cup-Rlr Brg	399-6067
7H-6967	Bearing-Ball	422-6489
7J-1335	Bearing-Sleeve	380-7567
7J-1336	Bearing-Sleeve	384-4776
7K-5448	Cup-Bearing	415-1922
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7N-3352	Plate-Spacer	386-3062

35A		
Original Part Number	Part Name	Classic Part Number
7N-4170	Pump Gp-Eng Oil	379-0169
7N-4407	Gasket-Rod Comp	433-9853
7N-7639	Rotator-Valve	383-1582
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-1994	Valve-Exhaust	443-1206
8H-2434	Drum-Ster Cl Dr	216-7862
8H-4320	Bearing-Ball	419-2301
8H-5026	Cover-Adj Pulley	445-7698

35A		
Original Part Number	Part Name	Classic Part Number
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8N-4810	Gasket-Cyl Head	437-2046
8N-6004	Head As-Cyl	247-3369
8P-8221	Plate-Guide	226-2748
8S-2123	Cage-Fdr Bearing	217-7726
8S-2126	Spacer-Hub Brg	222-1767
9F-8074	Bearing-Outer	452-3180
9H-6236	Rod As	390-0999
9J-5284	Bearing-Sleeve	380-7379
9M-5350	Spring-Valve	380-7573
9S-1026	Cage-Gear Brg	216-7873
9S-4829	Race-Brg Inner	423-9668
9S-8184	Pin-Drawbar	398-8345
9S-8217	Bolt-Spring	469-4672
9S-9696	Spider As-Fan	383-3707
9V-7710	Univ Joint As	394-8234
374-1849	Brg-Rlr-Cla	399-4442

36A		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1B-4102	Bearing-Ball	399-4426
1H-4106	Pin As-Drawbar	325-6126
1J-2087	Bushing	421-9041
1J-6744	Bearing	361-1705
1J-6746	Pin	256-4817
1J-6749	Screw-Adj	256-4824
1L-7205	Bearing-Ball	416-2167
1M-1994	Bearing As-Rlr	399-6066

36A		
Original Part Number	Part Name	Classic Part Number
1M-9444	Retainer-Spring	299-2046
1P-0005	Pump Gp-Fuel Tfr	256-4756
1P-1367	Plunger-Valve	432-8913
1P-2187	Pump Gp-Gr 1 Bsc	299-2044
1P-3318	Strip	385-7206
1P-6400	Plunger As-Pump	383-1568
1P-7295	Shaft-Acc Drive	431-5261
1S-1888	Bracket-Lamp	297-7147
1S-2269	Sleeve	226-2720
1S-7056	Bearing-Ball	422-6483
1S-8607	Baffle	380-7540
1T-0043	Bearing-Ball	390-5294

36A		
Original Part Number	Part Name	Classic Part Number
1U-3953	Cartridge Gp	426-0024
2A-4429	Lock-Retainer	379-0174
2D-6421	Bearing-Outer	417-4510
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2J-1227	Retainer	440-0850
2K-4507	Bearing-Sleeve	325-6021
2K-5254	Bearing-Outer	377-7419
2L-5271	Bearing-Ball	371-4305
2M-1149	Race-Brg Outer	418-9615
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296

Sales Model D8H (Cont'd.)

36A		
Original Part Number	Part Name	Classic Part Number
2P-1005	Bearing-Sleeve	296-1342
2P-1604	Piston-Ster Cl	219-9694
2P-1605	Pilot-Cl Piston	219-9695
2P-2656	Line As-Fuel Inj	430-9650
2P-4370	Plate-Clutch	325-6166
2P-4611	Pipe-Exhaust	365-8821
2S-3913	Cage-Gear Brg	217-7722
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-4357	Pinion-Fdr	217-7706
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-7931	Bearing-Sleeve	387-2904
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3B-3967	Race-Roller Brg	386-4947
3B-8845	Bearing-Inner	417-4509
3F-6185	Pin	295-5694
3F-6523	Pin-Clevis	256-4818
3G-7658	Cartridge Gp	426-0427
3G-7660	Cartridge Gp	422-8103
3H-0881	Ring-Piston	465-8998
3H-7161	Pin	256-4819
3H-7164	Pin-Pivot	256-4820
3H-8726	Mount As	385-7208
3J-3493	Ballstud	256-4832
3J-5190	Cap-Brg	256-4837
3J-6484	Bearing-Sleeve	380-7383
3J-7798	Bracket	385-3791
3K-0526	Bearing-Ball	386-4949
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3S-2252	Manifold-Exhaust	261-0887
3S-3875	Screen-Suction	435-4849
3S-6989	Nut-Spanner	219-9701
3S-7308	Cage-Pinion Brg	219-9702

36A		
Original Part Number	Part Name	Classic Part Number
3S-7517	Pulley-Belt Adj	264-5876
3S-9669	Bearing	416-2168
3T-3150	Guide-Frt Idler	394-0191
4B-7255	Cone-Bearing	386-4951
4F-2041	Cup-Roller Brg	418-9609
4F-5003	Spring As-Arm	383-2127
4H-9640	Bearing-Sleeve	386-4921
4M-3915	Bearing-Caged	377-7427
4M-9183	Bearing-Sleeve	386-4924
4M-9215	Gear-Pump Idler	311-9391
4N-3875	Ring-Piston	465-8997
4N-4577	Muffler As.	308-9877
4N-4880	Pump Gp-F Tfr	256-4758
4S-7793	Thrower-Cshft O	367-6085
4S-8472	Hood As-Preclnr	296-1355
4S-8855	Coupling-Exhaust	369-9488
4S-9325	Race-Spl Rlr Brg	418-9590
4S-9326	Bearing	417-4506
4S-9782	Race & Roller As	385-3779
4S-9783	Race-Rlr Bearing	418-9589
4T-6869	Cartridge Gp	422-8104
5F-7993	Pin	319-3454
5F-8651	Bearing-Ball	420-3223
5G-3612	Cap Gp-Protn	295-6419
5H-1719	Pump Gp-Fd Oil	226-0168
5H-7071	Director-Water	388-0555
5J-1192	Bearing-Sleeve	374-8355
5J-2528	Plunger	391-1318
5J-3506	Retainer	399-8551
5J-4321	Trunnion	302-2700
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5L-8856	Coupling-Exhaust	311-9379
5M-6674	Guard-F Idler Lh	226-2736
5M-6709	Check As-Ball	380-7542

36A		
Original Part Number	Part Name	Classic Part Number
5M-7306	Cylinder	226-2737
5N-8501	Head As-Cyl	256-4762
5N-8657	Manifold-Exhaust	261-0886
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9553	Gasket Kit - Wp	393-3624
5S-0160	Strip-Guard	226-2738
5S-0161	Strip-Guard	226-2739
5S-0464	Gear-First Red	216-7852
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-8739	Spider Gp-Brg	373-5386
6B-6224	Ferrule	419-4738
6F-2956	Cup-Spl Tapered	420-6538
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6J-2326	Pin	319-3458
6J-5179	Retainer	380-7406
6J-9258	Trunnion As	256-4846
6J-9480	Pin As	384-4774
6J-9482	Pin As	380-7400
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-5987	Shaft-Water Pump	390-0998
6N-6015	Pump Gp-Water	453-6502
6P-0549	Guard-Fdr Wear	223-4812
6P-2776	Gear-Final Drive	217-7718
6P-3593	Support	229-8231
6P-3597	Retainer	222-1770
6P-4327	Pad	384-3472
6P-8829	Retainer	380-7407
6S-2828	Cup-Roller Brg	384-5932
6T-0952	Pad As	367-6087
6T-1933	Collar-Idler End	226-2746

Sales Model D8H (Cont'd.)

36A		
Original Part Number	Part Name	Classic Part Number
6T-8886	Disc-Ster Cl	380-7517
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7920	Disc-Friction	388-0587
7E-5085	Bushing	377-5829
7G-2500	Gear-Planet	296-1350
7H-6967	Bearing-Ball	422-6489
7J-0086	Bearing As	256-4842
7J-1335	Bearing-Sleeve	380-7567
7J-1336	Bearing-Sleeve	384-4776
7J-9884	Bearing-Sleeve	325-6016
7K-5448	Cup-Bearing	415-1922
7L-7508	Bearing-Ball	420-6536
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7N-0113	Core As-Oclr	388-0564
7N-2957	Cover-Rad Cap	361-1722
7N-3352	Plate-Spacer	386-3062
7N-4170	Pump Gp-Eng Oil	379-0169
7N-4407	Gasket-Rod Comp	433-9853
7N-7091	Line As-Fuel Inj	396-9938
7N-7092	Line As-Fuel Inj	396-9937
7N-7386	Gasket-Cyl Head	392-4519
7N-7639	Rotator-Valve	383-1582
7N-9352	Gasket	433-8188
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7S-7809	Cap As-Radiator	295-6417

36A		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8B-8439	Bearing-Ball	399-6069
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-1994	Valve-Exhaust	443-1206
8H-2434	Drum-Ster Cl Dr	216-7862
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-5026	Cover-Adj Pulley	445-7698
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-7978	Bearing-Spher	388-0581
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8N-4810	Gasket-Cyl Head	437-2046
8N-6004	Head As-Cyl	247-3369
8N-7923	Bearing-Main	419-7275
8N-7924	Bearing-Main	419-7276
8N-7933	Bearing-Conn Rod	419-7280
8N-7934	Bearing-Conn Rod	419-6308
8P-5117	Rod Gp-Tck Adj	226-2747

46A		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586

36A		
Original Part Number	Part Name	Classic Part Number
8P-8221	Plate-Guide	226-2748
8S-2123	Cage-Fdr Bearing	217-7726
8S-2126	Spacer-Hub Brg	222-1767
8S-3653	Bonnet-Valve	374-4728
8S-6782	Adapter-Exhaust	383-1586
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9686	Gasket Kit	393-5215
9F-7101	Bushing-Collar	299-1988
9F-8074	Bearing-Outer	452-3180
9H-6236	Rod As	390-0999
9J-5050	Pump Gp-Vn Bsc-B	422-8168
9J-5284	Bearing-Sleeve	380-7379
9M-1328	Bearing-Aligning	325-6018
9M-1997	Bearing-Ball	384-5954
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5350	Spring-Valve	380-7573
9S-1026	Cage-Gear Brg	216-7873
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-4829	Race-Brg Inner	423-9668
9S-5771	Bushing As	385-7219
9S-7148	Cap As-Rain	378-3994
9S-7949	Cup-Roller Brg	420-6531
9S-8184	Pin-Drawbar	398-8345
9S-8217	Bolt-Spring	469-4672
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
162-3904	Pump As-F Prm	391-1102
226-8202	Seal-Wiper	472-8024
255-2899	Pipe As-Tail	301-5246
374-1849	Brg-Rlr-Cla	399-4442

Sales Model D8H (Cont'd.)

46A		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1B-4102	Bearing-Ball	399-4426
1H-4106	Pin As-Drawbar	325-6126
1J-2087	Bushing	421-9041
1J-6744	Bearing	361-1705
1J-6746	Pin	256-4817
1J-6747	Pin	367-6078
1J-6749	Screw-Adj	256-4824
1L-7205	Bearing-Ball	416-2167
1M-3917	Shaft	386-4915
1M-4095	Bearing-Inner	417-9486
1M-4167	Shaft-Planet	219-9700
1M-9444	Retainer-Spring	299-2046
1P-0005	Pump Gp-Fuel Tfr	256-4756
1P-1367	Plunger-Valve	432-8913
1P-2187	Pump Gp-Gr 1 Bsc	299-2044
1P-3318	Strip	385-7206
1P-4145	Valve Gp-Press	247-4436
1P-6400	Plunger As-Pump	383-1568
1P-7295	Shaft-Acc Drive	431-5261
1S-1888	Bracket-Lamp	297-7147
1S-2269	Sleeve	226-2720
1S-7056	Bearing-Ball	422-6483
1S-8607	Baffle	380-7540
1S-8754	Joint Gp-Univ	308-9873
1T-0043	Bearing-Ball	390-5294
1T-0221	Wheel-Turbine	390-5268
1T-0224	Carrier-Ring	239-7928
1T-0231	Retainer-Bearing	319-3471
1T-0237	Flange As-Output	239-7929
1T-0256	Gear-Pump Drive	239-7930
1T-0278	Bearing-Sleeve	394-0213

46A		
Original Part Number	Part Name	Classic Part Number
1T-0589	Cup-Roller Brg	386-4942
1T-0595	Carrier-Wheel	239-7939
1T-0610	Bearing-Ball	396-4136
1T-0611	Converter As-Tor	235-1804
1T-0633	Impeller-Conv	390-5266
1T-1389	Carrier-Bearing	247-4124
1T-1399	Impeller-Conv	391-9829
1T-1562	Wheel As-Guide	388-6580
1U-3953	Cartridge Gp	426-0024
2A-4429	Lock-Retainer	379-0174
2D-6421	Bearing-Outer	417-4510
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2J-1227	Retainer	440-0850
2K-4507	Bearing-Sleeve	325-6021
2K-5065	Cone-Roller Brg	416-2157
2K-5254	Bearing-Outer	377-7419
2L-5271	Bearing-Ball	371-4305
2M-1149	Race-Brg Outer	418-9615
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2P-1005	Bearing-Sleeve	296-1342
2P-1604	Piston-Ster Cl	219-9694
2P-1605	Pilot-Cl Piston	219-9695
2P-2656	Line As-Fuel Inj	430-9650
2P-4370	Plate-Clutch	325-6166
2P-4611	Pipe-Exhaust	365-8821
2S-3913	Cage-Gear Brg	217-7722
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-4357	Pinion-Fdr	217-7706
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-7873	Pump Gp	226-0162
2S-7917	Gear-Pump Dr	247-4119

46A		
Original Part Number	Part Name	Classic Part Number
2S-7931	Bearing-Sleeve	387-2904
2S-8884	Ring-Piston	465-8995
3B-1142	Retainer-Spring	391-1099
3B-3967	Race-Roller Brg	386-4947
3B-8845	Bearing-Inner	417-4509
3F-6185	Pin	295-5694
3F-6523	Pin-Clevis	256-4818
3G-7658	Cartridge Gp	426-0427
3G-7660	Cartridge Gp	422-8103
3H-0881	Ring-Piston	465-8998
3H-7161	Pin	256-4819
3H-7164	Pin-Pivot	256-4820
3H-8726	Mount As	385-7208
3J-3493	Ballstud	256-4832
3J-5190	Cap-Brg	256-4837
3J-6484	Bearing-Sleeve	380-7383
3J-7798	Bracket	385-3791
3K-0526	Bearing-Ball	386-4949
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3P-1686	Plate-Clutch	388-0586
3P-1687	Plate-Clutch	428-6658
3P-9394	Shaft-Planet	215-1680
3S-1262	Retainer	308-9915
3S-1404	Bearing-Outer	417-4508
3S-2252	Manifold-Exhaust	261-0887
3S-3875	Screen-Suction	435-4849
3S-6989	Nut-Spanner	219-9701
3S-7308	Cage-Pinion Brg	219-9702
3S-7517	Pulley-Belt Adj	264-5876
3S-9669	Bearing	416-2168
3S-9919	Shaft As	239-7959
3T-3150	Guide-Frt Idler	394-0191
4B-7255	Cone-Bearing	386-4951
4F-2041	Cup-Roller Brg	418-9609
4F-5003	Spring As-Arm	383-2127
4H-9640	Bearing-Sleeve	386-4921

Sales Model D8H (Cont'd.)

46A		
Original Part Number	Part Name	Classic Part Number
4M-0410	Gear-Oil Pump Dr	428-6660
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4M-9183	Bearing-Sleeve	386-4924
4M-9215	Gear-Pump Idler	311-9391
4N-3875	Ring-Piston	465-8997
4N-4577	Muffler As.	308-9877
4N-4880	Pump Gp-F Tfr	256-4758
4P-7731	Core Gp-O Clr	385-7228
4S-7793	Thrower-Cshft O	367-6085
4S-8472	Hood As-Preclnr	296-1355
4S-8855	Coupling-Exhaust	369-9488
4S-9325	Race-Spl Rlr Brg	418-9590
4S-9326	Bearing	417-4506
4S-9782	Race & Roller As	385-3779
4S-9783	Race-Rlr Bearing	418-9589
4T-6869	Cartridge Gp	422-8104
5F-7993	Pin	319-3454
5F-8651	Bearing-Ball	420-3223
5G-3612	Cap Gp-Protn	295-6419
5H-1719	Pump Gp-Fd Oil	226-0168
5H-7071	Director-Water	388-0555
5J-1192	Bearing-Sleeve	374-8355
5J-2528	Plunger	391-1318
5J-3506	Retainer	399-8551
5J-4321	Trunnion	302-2700
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5L-8856	Coupling-Exhaust	311-9379
5M-0549	Gear-Trans	215-1689
5M-2051	Bearing-Caged	380-7467
5M-3996	Gear-Ring	214-0527
5M-4427	Gear-Sun	214-0529
5M-6674	Guard-F Idler Lh	226-2736

46A		
Original Part Number	Part Name	Classic Part Number
5M-6709	Check As-Ball	380-7542
5M-7306	Cylinder	226-2737
5M-7955	Shaft As-Planet	364-5273
5N-8501	Head As-Cyl	256-4762
5N-8657	Manifold-Exhaust	261-0886
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9553	Gasket Kit - Wp	393-3624
5P-9814	Gasket Kt-Vg	393-3635
5S-0160	Strip-Guard	226-2738
5S-0161	Strip-Guard	226-2739
5S-0464	Gear-First Red	216-7852
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-8739	Spider Gp-Brg	373-5386
6B-6224	Ferrule	419-4738
6F-2956	Cup-Spl Tapered	420-6538
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6J-2326	Pin	319-3458
6J-5179	Retainer	380-7406
6J-9258	Trunnion As	256-4846
6J-9480	Pin As	384-4774
6J-9482	Pin As	380-7400
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-5987	Shaft-Water Pump	390-0998
6N-6015	Pump Gp-Water	453-6502
6P-0236	Guide-Lever	422-6475
6P-0549	Guard-Fdr Wear	223-4812
6P-2776	Gear-Final Drive	217-7718
6P-3593	Support	229-8231
6P-3597	Retainer	222-1770
6P-4327	Pad	384-3472

46A		
Original Part Number	Part Name	Classic Part Number
6P-8829	Retainer	380-7407
6S-2828	Cup-Roller Brg	384-5932
6T-0952	Pad As	367-6087
6T-1933	Collar-Idler End	226-2746
6T-4481	Shaft-Planet	221-7946
6T-8886	Disc-Ster Cl	380-7517
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7920	Disc-Friction	388-0587
7E-5085	Bushing	377-5829
7G-2492	Gear-Planet	239-7933
7G-2500	Gear-Planet	296-1350
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-0086	Bearing As	256-4842
7J-1335	Bearing-Sleeve	380-7567
7J-1336	Bearing-Sleeve	384-4776
7J-9884	Bearing-Sleeve	325-6016
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7N-0113	Core As-Oclr	388-0564
7N-2957	Cover-Rad Cap	361-1722
7N-3352	Plate-Spacer	386-3062
7N-4170	Pump Gp-Eng Oil	379-0169
7N-4407	Gasket-Rod Comp	433-9853
7N-7091	Line As-Fuel Inj	396-9938
7N-7092	Line As-Fuel Inj	396-9937
7N-7386	Gasket-Cyl Head	392-4519
7N-7639	Rotator-Valve	383-1582
7N-9352	Gasket	433-8188
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912

Sales Model D8H (Cont'd.)

46A		
Original Part Number	**Part Name**	**Classic Part Number**
7S-5003	Cap As-Rain	379-0184
7S-7400	Pump Gp	226-0173
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8B-8439	Bearing-Ball	399-6069
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8E-7455	Gear-Planet	221-7947
8E-7456	Gear-Planet	221-7948
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-1994	Valve-Exhaust	443-1206
8H-2434	Drum-Ster Cl Dr	216-7862
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-5026	Cover-Adj Pulley	445-7698
8H-7577	Plate-Locking	392-4486
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-7978	Bearing-Spher	388-0581

46A		
Original Part Number	**Part Name**	**Classic Part Number**
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8N-4810	Gasket-Cyl Head	437-2046
8N-6004	Head As-Cyl	247-3369
8N-7923	Bearing-Main	419-7275
8N-7924	Bearing-Main	419-7276
8N-7933	Bearing-Conn Rod	419-7280
8N-7934	Bearing-Conn Rod	419-6308
8P-5117	Rod Gp-Tck Adj	226-2747
8P-8221	Plate-Guide	226-2748
8S-2123	Cage-Fdr Bearing	217-7726
8S-2126	Spacer-Hub Brg	222-1767
8S-3653	Bonnet-Valve	374-4728
8S-6782	Adapter-Exhaust	383-1586
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9686	Gasket Kit	393-5215
9F-8074	Bearing-Outer	452-3180
9H-5233	Piston-Clutch	219-9708
9H-6236	Rod As	390-0999
9J-5050	Pump Gp-Vn Bsc-B	422-8168
9J-5284	Bearing-Sleeve	380-7379
9M-1328	Bearing-Aligning	325-6018

46A		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5350	Spring-Valve	380-7573
9P-3663	Carrier-Planet	213-6939
9P-6592	Gear-Planet	215-1915
9S-0440	Tube As	392-4499
9S-1026	Cage-Gear Brg	216-7873
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-4829	Race-Brg Inner	423-9668
9S-5771	Bushing As	385-7219
9S-7148	Cap As-Rain	378-3994
9S-7949	Cup-Roller Brg	420-6531
9S-8184	Pin-Drawbar	398-8345
9S-8217	Bolt-Spring	469-4672
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
155-8688	Gasket Kit	434-7273
162-3904	Pump As-F Prm	391-1102
226-8202	Seal-Wiper	472-8024
255-2899	Pipe As-Tail	301-5246
374-1849	Brg-Rlr-Cla	399-4442

68A		
Original Part Number	**Part Name**	**Classic Part Number**
1M-4095	Bearing-Inner	417-9486
1T-0278	Bearing-Sleeve	394-0213
1T-0589	Cup-Roller Brg	386-4942
1T-0610	Bearing-Ball	396-4136
2D-6421	Bearing-Outer	417-4510
2K-5065	Cone-Roller Brg	416-2157

68A		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5254	Bearing-Outer	377-7419
2M-1149	Race-Brg Outer	418-9615
2S-7931	Bearing-Sleeve	387-2904
3B-8845	Bearing-Inner	417-4509
3S-1404	Bearing-Outer	417-4508
3S-9669	Bearing	416-2168

68A		
Original Part Number	**Part Name**	**Classic Part Number**
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
5M-2051	Bearing-Caged	380-7467
7H-7628	Bearing	453-3655
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442

Sales Model D8H (Cont'd.)

68A		
Original Part Number	Part Name	Classic Part Number
9M-2042	Race-Roller Brg	417-9500

68A		
Original Part Number	Part Name	Classic Part Number
9S-4829	Race-Brg Inner	423-9668

68A		
Original Part Number	Part Name	Classic Part Number
374-1849	Brg-Rlr-Cla	399-4442

Sales Model D8K

66V		
Original Part Number	Part Name	Classic Part Number
1M-4095	Bearing-Inner	417-9486
1T-0278	Bearing-Sleeve	394-0213
1T-0589	Cup-Roller Brg	386-4942
1T-0610	Bearing-Ball	396-4136
2D-6421	Bearing-Outer	417-4510
2K-5065	Cone-Roller Brg	416-2157
2K-5254	Bearing-Outer	377-7419
2M-1149	Race-Brg Outer	418-9615

66V		
Original Part Number	Part Name	Classic Part Number
2S-7931	Bearing-Sleeve	387-2904
3B-8845	Bearing-Inner	417-4509
3S-1404	Bearing-Outer	417-4508
3S-9669	Bearing	416-2168
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
5M-2051	Bearing-Caged	380-7467
7H-7628	Bearing	453-3655

66V		
Original Part Number	Part Name	Classic Part Number
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
9M-2042	Race-Roller Brg	417-9500
9S-4829	Race-Brg Inner	423-9668
155-8688	Gasket Kit	434-7273
374-1849	Brg-Rlr-Cla	399-4442

76V		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1B-4102	Bearing-Ball	399-4426
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1J-6746	Pin	256-4817
1J-6749	Screw-Adj	256-4824
1M-1994	Bearing As-Rlr	399-6066
1M-4095	Bearing-Inner	417-9486
1M-9444	Retainer-Spring	299-2046
1P-1367	Plunger-Valve	432-8913
1P-2187	Pump Gp-Gr 1 Bsc	299-2044
1P-3318	Strip	385-7206
1P-6400	Plunger As-Pump	383-1568
1P-7295	Shaft-Acc Drive	431-5261

76V		
Original Part Number	Part Name	Classic Part Number
1S-1888	Bracket-Lamp	297-7147
1S-2269	Sleeve	226-2720
1S-8607	Baffle	380-7540
1T-0043	Bearing-Ball	390-5294
1U-3953	Cartridge Gp	426-0024
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-4738	Bearing-Sleeve	325-6020
1W-5910	Tappet As-Guide&	383-1569
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6421	Bearing-Outer	417-4510
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2K-5254	Bearing-Outer	377-7419
2K-5804	Rod End-Spher	416-2151

76V		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2M-1149	Race-Brg Outer	418-9615
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-0484	Chamber As	247-3296
2P-1005	Bearing-Sleeve	296-1342
2P-1126	Pulley-Cshft	264-5868
2P-1129	Pulley-Tightener	264-5869
2P-1131	Arm As-Tightener	430-8132
2P-1604	Piston-Ster Cl	219-9694
2P-1605	Pilot-Cl Piston	219-9695
2P-2656	Line As-Fuel Inj	430-9650
2P-4370	Plate-Clutch	325-6166
2P-9037	Drum-Ster Clutch	219-9696
2P-9038	Drum-Cl Driven	216-7821

Sales Model D8K (Cont'd.)

76V		
Original Part Number	Part Name	Classic Part Number
2S-3913	Cage-Gear Brg	217-7722
2S-3966	Ring-Seal	297-7237
2S-4357	Pinion-Fdr	217-7706
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-7931	Bearing-Sleeve	387-2904
2S-8884	Ring-Piston	465-8995
2W-7455	Gear As	396-9957
3B-1142	Retainer-Spring	391-1099
3B-8845	Bearing-Inner	417-4509
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3F-6523	Pin-Clevis	256-4818
3G-0910	Cap-Bearing	325-6037
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3G-7661	Cartridge Gp	422-8113
3G-7663	Cartridge Gp	422-8120
3H-0881	Ring-Piston	465-8998
3H-7161	Pin	256-4819
3H-7164	Pin-Pivot	256-4820
3J-3493	Ballstud	256-4832
3J-5190	Cap-Brg	256-4837
3J-6484	Bearing-Sleeve	380-7383
3J-7798	Bracket	385-3791
3K-0526	Bearing-Ball	386-4949
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3S-2252	Manifold-Exhaust	261-0887
3S-3875	Screen-Suction	435-4849
3S-6989	Nut-Spanner	219-9701
3S-7308	Cage-Pinion Brg	219-9702
3S-9669	Bearing	416-2168
3T-3150	Guide-Frt Idler	394-0191
4B-7255	Cone-Bearing	386-4951
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4F-5003	Spring As-Arm	383-2127

76V		
Original Part Number	Part Name	Classic Part Number
4H-9640	Bearing-Sleeve	386-4921
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4M-9183	Bearing-Sleeve	386-4924
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-3875	Ring-Piston	465-8997
4N-4577	Muffler As.	308-9877
4N-4668	Breather-Engine	396-7271
4N-4880	Pump Gp-F Tfr	256-4758
4N-5390	Pulley-Alt Drive	264-5879
4N-5572	Gasket	433-8192
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-7793	Thrower-Cshft O	367-6085
4S-8472	Hood As-Preclnr	296-1355
4S-9782	Race & Roller As	385-3779
4S-9783	Race-Rlr Bearing	418-9589
4T-4073	Valve Gp-Shtl -B	439-1138
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

76V		
Original Part Number	Part Name	Classic Part Number
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5F-7993	Pin	319-3454
5G-3612	Cap Gp-Protn	295-6419
5H-1719	Pump Gp-Fd Oil	226-0168
5H-7071	Director-Water	388-0555
5J-1192	Bearing-Sleeve	374-8355
5J-2528	Plunger	391-1318
5J-4321	Trunnion	302-2700
5L-6326	Bearing-Ball	420-3222
5M-6674	Guard-F Idler Lh	226-2736
5M-7306	Cylinder	226-2737
5N-8501	Head As-Cyl	256-4762
5N-8657	Manifold-Exhaust	261-0886
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9552	Gasket Kt	393-3623
5P-9553	Gasket Kit - Wp	393-3624
5S-0160	Strip-Guard	226-2738
5S-0161	Strip-Guard	226-2739
5S-0464	Gear-First Red	216-7852
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-8739	Spider Gp-Brg	373-5386
6B-6224	Ferrule	419-4738
6F-2956	Cup-Spl Tapered	420-6538
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358

Sales Model D8K (Cont'd.)

76V		
Original Part Number	Part Name	Classic Part Number
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6J-2326	Pin	319-3458
6J-9480	Pin As	384-4774
6J-9482	Pin As	380-7400
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-1931	Plunger	379-0171
6N-5435	Ejector As-Exh	443-2663
6N-5437	Muffler As.	247-2674
6N-5967	Elbow	394-9825
6N-5978	Coupling-Exhaust	369-9487
6N-5987	Shaft-Water Pump	390-0998
6N-6015	Pump Gp-Water	453-6502
6N-7154	Rotocoil As	380-7556
6N-9653	Core As-Oil Clr	386-3056
6P-0549	Guard-Fdr Wear	223-4812
6P-2776	Gear-Final Drive	217-7718
6P-3593	Support	229-8231
6P-3597	Retainer	222-1770
6P-8829	Retainer	380-7407
6S-2828	Cup-Roller Brg	384-5932
6T-0952	Pad As	367-6087
6T-1933	Collar-Idler End	226-2746
6T-8886	Disc-Ster Cl	380-7517
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-3709	Gasket Kit	393-5223
6V-3710	Gasket Kit	447-8646
6V-3831	Seal-O-Ring	436-2657
6Y-0145	Plate-Locking	419-8801
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7920	Disc-Friction	388-0587

76V		
Original Part Number	Part Name	Classic Part Number
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7J-0086	Bearing As	256-4842
7J-1335	Bearing-Sleeve	380-7567
7J-1336	Bearing-Sleeve	384-4776
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7N-0113	Core As-Oclr	388-0564
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2957	Cover-Rad Cap	361-1722
7N-3349	Shaft As-Drive	394-0889
7N-3350	Gear As-Pump Dr	319-3437
7N-3352	Plate-Spacer	386-3062
7N-4170	Pump Gp-Eng Oil	379-0169

76V		
Original Part Number	Part Name	Classic Part Number
7N-4407	Gasket-Rod Comp	433-9853
7N-4618	Ejector As-Exh	397-5060
7N-7091	Line As-Fuel Inj	396-9938
7N-7092	Line As-Fuel Inj	396-9937
7N-7628	Gasket	419-1811
7N-7639	Rotator-Valve	383-1582
7N-7878	Cover-Plate	434-2401
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8B-8439	Bearing-Ball	399-6069
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-1994	Valve-Exhaust	443-1206
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-7466	Seat	385-3787
8J-7978	Bearing-Spher	388-0581
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-4810	Gasket-Cyl Head	437-2046
8N-6004	Head As-Cyl	247-3369
8N-7923	Bearing-Main	419-7275

Sales Model D8K (Cont'd.)

76V		
Original Part Number	Part Name	Classic Part Number
8N-7924	Bearing-Main	419-7276
8N-7933	Bearing-Conn Rod	419-7280
8N-7934	Bearing-Conn Rod	419-6308
8N-8258	Bearing-Sleeve	452-1077
8P-5117	Rod Gp-Tck Adj	226-2747
8P-8221	Plate-Guide	226-2748
8S-2123	Cage-Fdr Bearing	217-7726
8S-2126	Spacer-Hub Brg	222-1767
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9F-7101	Bushing-Collar	299-1988
9H-6236	Rod As	390-0999
9J-0123	Trunnion	325-6227
9J-5050	Pump Gp-Vn Bsc-B	422-8168
9J-5058	Pump Gp-Vn Bsc-B	422-8170
9J-5284	Bearing-Sleeve	380-7379
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5350	Spring-Valve	380-7573
9N-1545	Race-Thrust	394-9205
9S-1026	Cage-Gear Brg	216-7873
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-4829	Race-Brg Inner	423-9668

76V		
Original Part Number	Part Name	Classic Part Number
9S-5771	Bushing As	385-7219
9S-7148	Cap As-Rain	378-3994
9S-7949	Cup-Roller Brg	420-6531
9S-8184	Pin-Drawbar	398-8345
9S-8217	Bolt-Spring	469-4672
9T-5096	Flexplate	455-3271
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547

76V		
Original Part Number	Part Name	Classic Part Number
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-3904	Pump As-F Prm	391-1102
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-3294	Gage As-O Level	398-2930
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
221-9356	Flywheel As	435-2575
226-8202	Seal-Wiper	472-8024
230-7117	Ster Cl Kit-Cla	219-9696
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
374-1849	Brg-Rlr-Cla	399-4442
430-7619	Adapter-Cla	438-1812

Sales Model D8K (Cont'd.)

77V		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-0744	Screw-Rocker Adj	379-0167
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-3934	Cup-Roller Brg	392-4487
1B-4102	Bearing-Ball	399-4426
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1J-6746	Pin	256-4817
1J-6749	Screw-Adj	256-4824
1M-3917	Shaft	386-4915
1M-4095	Bearing-Inner	417-9486
1M-4167	Shaft-Planet	219-9700
1M-9444	Retainer-Spring	299-2046
1P-1367	Plunger-Valve	432-8913
1P-2187	Pump Gp-Gr 1 Bsc	299-2044
1P-3318	Strip	385-7206
1P-4145	Valve Gp-Press	247-4436
1P-6400	Plunger As-Pump	383-1568
1P-7295	Shaft-Acc Drive	431-5261
1S-1888	Bracket-Lamp	297-7147
1S-2269	Sleeve	226-2720
1S-8607	Baffle	380-7540
1S-8754	Joint Gp-Univ	308-9873
1T-0043	Bearing-Ball	390-5294
1T-0221	Wheel-Turbine	390-5268
1T-0224	Carrier-Ring	239-7928
1T-0231	Retainer-Bearing	319-3471
1T-0237	Flange As-Output	239-7929
1T-0256	Gear-Pump Drive	239-7930
1T-0278	Bearing-Sleeve	394-0213
1T-0589	Cup-Roller Brg	386-4942
1T-0595	Carrier-Wheel	239-7939
1T-0610	Bearing-Ball	396-4136
1T-0611	Converter As-Tor	235-1804

77V		
Original Part Number	Part Name	Classic Part Number
1T-0633	Impeller-Conv	390-5266
1T-1389	Carrier-Bearing	247-4124
1T-1399	Impeller-Conv	391-9829
1T-1562	Wheel As-Guide	388-6580
1U-3953	Cartridge Gp	426-0024
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6421	Bearing-Outer	417-4510
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2K-5065	Cone-Roller Brg	416-2157
2K-5254	Bearing-Outer	377-7419
2L-5271	Bearing-Ball	371-4305
2M-1149	Race-Brg Outer	418-9615
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0484	Chamber As	247-3296
2P-1005	Bearing-Sleeve	296-1342
2P-1126	Pulley-Cshft	264-5868
2P-1129	Pulley-Tightener	264-5869
2P-1131	Arm As-Tightener	430-8132
2P-1604	Piston-Ster Cl	219-9694
2P-1605	Pilot-Cl Piston	219-9695
2P-2656	Line As-Fuel Inj	430-9650
2P-4370	Plate-Clutch	325-6166
2P-9037	Drum-Ster Clutch	219-9696
2P-9038	Drum-Cl Driven	216-7821
2S-3913	Cage-Gear Brg	217-7722
2S-3966	Ring-Seal	297-7237
2S-4357	Pinion-Fdr	217-7706
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-7917	Gear-Pump Dr	247-4119
2S-7931	Bearing-Sleeve	387-2904
2S-8884	Ring-Piston	465-8995

77V		
Original Part Number	Part Name	Classic Part Number
3B-1142	Retainer-Spring	391-1099
3B-8845	Bearing-Inner	417-4509
3F-6185	Pin	295-5694
3F-6523	Pin-Clevis	256-4818
3G-0910	Cap-Bearing	325-6037
3G-7655	Cartridge Gp	422-8119
3G-7658	Cartridge Gp	426-0427
3G-7661	Cartridge Gp	422-8113
3G-7663	Cartridge Gp	422-8120
3H-0881	Ring-Piston	465-8998
3H-7161	Pin	256-4819
3H-7164	Pin-Pivot	256-4820
3J-3493	Ballstud	256-4832
3J-5190	Cap-Brg	256-4837
3J-6484	Bearing-Sleeve	380-7383
3J-7798	Bracket	385-3791
3K-0526	Bearing-Ball	386-4949
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3P-1687	Plate-Clutch	428-6658
3P-9394	Shaft-Planet	215-1680
3S-1262	Retainer	308-9915
3S-1404	Bearing-Outer	417-4508
3S-2252	Manifold-Exhaust	261-0887
3S-3875	Screen-Suction	435-4849
3S-6989	Nut-Spanner	219-9701
3S-7308	Cage-Pinion Brg	219-9702
3S-9669	Bearing	416-2168
3S-9919	Shaft As	239-7959
3T-3150	Guide-Frt Idler	394-0191
4B-7255	Cone-Bearing	386-4951
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4F-5003	Spring As-Arm	383-2127
4H-9640	Bearing-Sleeve	386-4921
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495

Sales Model D8K (Cont'd.)

77V		
Original Part Number	Part Name	Classic Part Number
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
4N-4577	Muffler As.	308-9877
4N-4880	Pump Gp-F Tfr	256-4758
4N-5390	Pulley-Alt Drive	264-5879
4N-5572	Gasket	433-8192
4S-5367	Mount As	375-9986
4S-7793	Thrower-Cshft O	367-6085
4S-8472	Hood As-Preclnr	296-1355
4S-9782	Race & Roller As	385-3779
4S-9783	Race-Rlr Bearing	418-9589
4T-4073	Valve Gp-Shtl -B	439-1138
5F-7993	Pin	319-3454
5G-3612	Cap Gp-Protn	295-6419
5H-1719	Pump Gp-Fd Oil	226-0168
5H-7071	Director-Water	388-0555
5J-1192	Bearing-Sleeve	374-8355
5J-2528	Plunger	391-1318
5J-4321	Trunnion	302-2700
5L-6326	Bearing-Ball	420-3222
5L-9738	Coupling-Exhaust	311-9380
5M-0549	Gear-Trans	215-1689
5M-2051	Bearing-Caged	380-7467
5M-3996	Gear-Ring	214-0527
5M-4427	Gear-Sun	214-0529
5M-6674	Guard-F Idler Lh	226-2736
5M-7306	Cylinder	226-2737
5M-7955	Shaft As-Planet	364-5273
5N-8501	Head As-Cyl	256-4762
5N-8657	Manifold-Exhaust	261-0886
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9552	Gasket Kt	393-3623
5P-9553	Gasket Kit - Wp	393-3624

77V		
Original Part Number	Part Name	Classic Part Number
5S-0160	Strip-Guard	226-2738
5S-0161	Strip-Guard	226-2739
5S-0464	Gear-First Red	216-7852
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-8739	Spider Gp-Brg	373-5386
6B-6224	Ferrule	419-4738
6F-2956	Cup-Spl Tapered	420-6538
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6J-2326	Pin	319-3458
6J-9480	Pin As	384-4774
6J-9482	Pin As	380-7400
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8968	Coupling-Exhaust	311-9381
6N-0957	Core As-Radiator	398-2938
6N-5435	Ejector As-Exh	443-2663
6N-5437	Muffler As.	247-2674
6N-5967	Elbow	394-9825
6N-5978	Coupling-Exhaust	369-9487
6N-5987	Shaft-Water Pump	390-0998
6N-6015	Pump Gp-Water	453-6502
6N-9653	Core As-Oil Clr	386-3056
6P-0236	Guide-Lever	422-6475
6P-0549	Guard-Fdr Wear	223-4812
6P-2776	Gear-Final Drive	217-7718
6P-3593	Support	229-8231
6P-3597	Retainer	222-1770
6P-8829	Retainer	380-7407
6S-2828	Cup-Roller Brg	384-5932
6T-0952	Pad As	367-6087
6T-1933	Collar-Idler End	226-2746
6T-4481	Shaft-Planet	221-7946
6T-8886	Disc-Ster Cl	380-7517

77V		
Original Part Number	Part Name	Classic Part Number
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-3709	Gasket Kit	393-5223
6V-3710	Gasket Kit	447-8646
6Y-0145	Plate-Locking	419-8801
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7920	Disc-Friction	388-0587
7C-0307	Gasket	399-8571
7E-5085	Bushing	377-5829
7G-2492	Gear-Planet	239-7933
7G-2500	Gear-Planet	296-1350
7H-7628	Bearing	453-3655
7J-0086	Bearing As	256-4842
7J-1335	Bearing-Sleeve	380-7567
7J-1336	Bearing-Sleeve	384-4776
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7N-2957	Cover-Rad Cap	361-1722
7N-3349	Shaft As-Drive	394-0889
7N-3350	Gear As-Pump Dr	319-3437
7N-3352	Plate-Spacer	386-3062
7N-4170	Pump Gp-Eng Oil	379-0169
7N-4407	Gasket-Rod Comp	433-9853
7N-4618	Ejector As-Exh	397-5060
7N-7091	Line As-Fuel Inj	396-9938
7N-7092	Line As-Fuel Inj	396-9937
7N-7628	Gasket	419-1811
7N-7639	Rotator-Valve	383-1582
7N-7878	Cover-Plate	434-2401
7N-9352	Gasket	433-8188

Sales Model D8K (Cont'd.)

77V		
Original Part Number	Part Name	Classic Part Number
7S-7400	Pump Gp	226-0173
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0205	Core As-Oclr	379-0183
7W-1927	Ring-Retainer	387-2935
8B-8439	Bearing-Ball	399-6069
8E-7455	Gear-Planet	221-7947
8E-7456	Gear-Planet	221-7948
8F-6058	Bearing-Sleeve	416-5494
8F-8523	Bearing-Sleeve	383-3701
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-1994	Valve-Exhaust	443-1206
8H-2810	Case As-Filter	314-8512
8H-7577	Plate-Locking	392-4486
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8J-7466	Seat	385-3787
8J-7978	Bearing-Spher	388-0581
8M-0874	Plunger As-Valve	311-9439
8M-7166	Housing-Screen	297-7192
8N-4810	Gasket-Cyl Head	437-2046
8N-6004	Head As-Cyl	247-3369
8N-7923	Bearing-Main	419-7275
8N-7924	Bearing-Main	419-7276

77V		
Original Part Number	Part Name	Classic Part Number
8N-7933	Bearing-Conn Rod	419-7280
8N-7934	Bearing-Conn Rod	419-6308
8P-5117	Rod Gp-Tck Adj	226-2747
8P-8221	Plate-Guide	226-2748
8S-2123	Cage-Fdr Bearing	217-7726
8S-2126	Spacer-Hub Brg	222-1767
8S-3487	Gear As-Ring	221-7949
8S-3653	Bonnet-Valve	374-4728
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9H-5233	Piston-Clutch	219-9708
9H-6236	Rod As	390-0999
9J-0123	Trunnion	325-6227
9J-5050	Pump Gp-Vn Bsc-B	422-8168
9J-5058	Pump Gp-Vn Bsc-B	422-8170
9J-5284	Bearing-Sleeve	380-7379
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9M-1997	Bearing-Ball	384-5954
9M-2042	Race-Roller Brg	417-9500
9M-3025	Cover As	299-2001
9M-4789	Shaft-Gov Cont	297-7256
9M-5350	Spring-Valve	380-7573

77V		
Original Part Number	Part Name	Classic Part Number
9P-3663	Carrier-Planet	213-6939
9P-6592	Gear-Planet	215-1915
9P-7917	Valve Gp-Cont -C	385-3810
9S-0440	Tube As	392-4499
9S-1026	Cage-Gear Brg	216-7873
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-4829	Race-Brg Inner	423-9668
9S-5771	Bushing As	385-7219
9S-7148	Cap As-Rain	378-3994
9S-7949	Cup-Roller Brg	420-6531
9S-8184	Pin-Drawbar	398-8345
9S-8217	Bolt-Spring	469-4672
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
131-3815	Seal Gp-Basic	325-6193
155-8688	Gasket Kit	434-7273
162-3904	Pump As-F Prm	391-1102
170-0566	Kit-Rebuild-Pump	377-5835
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
226-8202	Seal-Wiper	472-8024
230-7117	Ster Cl Kit-Cla	219-9696
374-1849	Brg-Rlr-Cla	399-4442

Sales Model D8L

4FB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-5675	Bearing	377-7396
1H-4106	Pin As-Drawbar	325-6126

4FB		
Original Part Number	Part Name	Classic Part Number
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1W-5009	Crankshaft As	398-2969

4FB		
Original Part Number	Part Name	Classic Part Number
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

Sales Model D8L (Cont'd.)

4FB		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2N-5842	Screw-Bridge Adj	418-1934
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-3391	Body As-F Inj V	383-3687
2W-4087	Gear As-Idler	418-9582
2W-6965	Coupling	416-5490
2W-6967	Elbow As	420-6385
2W-7610	Gear-Hyd Pump Dr	418-1940
2W-7614	Gear-Crankshaft	425-7752
2W-7980	Camshaft As	378-3972
3E-4880	Coupling As	417-9465
3E-6772	Seal-Water	382-8017
3P-2685	Piston-Clutch	308-9908
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3245	Shaft-Planet	308-9924
3P-3738	Housing As	385-7196
3P-7489	Plate-Clutch	377-7423
3P-8845	Bearing-Inner	416-5491
3S-3875	Screen-Suction	435-4849
3S-9669	Bearing	416-2168
3T-0300	Pump Gp-Gr 2Bsc	421-1557
3T-2139	Housing As-Cl	394-2583
3T-5355	Flange	386-3052
4D-4065	Rod End-Spher	374-1824
4M-5858	Bearing-Spl Ball	417-4495
4N-0342	Plate-Cam Thrust	375-9974

4FB		
Original Part Number	Part Name	Classic Part Number
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4W-2357	Mount As	386-4927
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-8485	Muffler As	430-4472
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-1370	Bearing As-Rlr	416-2164
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502

4FB		
Original Part Number	Part Name	Classic Part Number
5P-8876	Cup-Rlr Bearing	416-2170
5P-9301	Bearing-Spl Ball	417-4496
5P-9505	Cone-Roller Brg	420-6540
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1032	Line As-Fuel Inj	390-0931
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922
6I-1038	Line As-Fuel Inj	390-0923
6I-4613	Plate-Spacer	380-7405
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6N-0977	Bearing-Sleeve	417-4524
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564

Sales Model D8L (Cont'd.)

4FB		
Original Part Number	Part Name	Classic Part Number
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-0593	Bearing-Roller	386-4959
6P-5404	Plate-C & Brake	325-6168
6P-6739	Shaft-Planet	308-9929
6P-7564	Carrier-Ring	384-3850
6P-8340	Sleeve	422-7895
6P-8829	Retainer	380-7407
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-3726	Carrier As	390-5269
6T-7407	Shaft-Pivot	432-8910
6T-8801	Guide As	396-0640
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-5919	Gasket Kit	437-3193
6Y-0145	Plate-Locking	419-8801
6Y-0210	Bearing-Sleeve	453-6506
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5287	Elbow As-Ex	430-4470
7E-5996	Rod As-Conn	379-8864
7G-2262	Pump Gp-Gr 2 Bsc	421-1552
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7G-5749	Piston-Clutch	416-2132
7G-5972	Plate-Thrust	393-1055
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7681	Shaft As	307-1530
7G-9708	Plate-Thrust	393-1054

4FB		
Original Part Number	Part Name	Classic Part Number
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1275	Pulley-Fan	380-7535
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2957	Cover-Rad Cap	361-1722
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-5003	Cap As-Rain	379-0184
7S-7809	Cap As-Radiator	295-6417
7T-1776	Slide	396-0659
7T-2036	Cap As-Fuel	361-1721
7T-4053	Shaft As-Output	398-2940
7T-5510	Pad As-Resilient	367-6090
7T-8336	Hub	418-9580
7T-8337	Shaft	416-2138
7W-0182	Plunger & Bbl As	391-9893
7W-0205	Core As-Oclr	379-0183
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5524	Ejector As-Exh	397-5056
8D-1817	Cup-Roller Brg	434-3296
8E-4164	Bar As-Equalizer	469-4661
8E-5001	Shaft As.	434-2400
8E-5450	Seal-Ebar	325-6190
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8M-0874	Plunger As-Valve	311-9439

4FB		
Original Part Number	Part Name	Classic Part Number
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3304	Pulley-Tightener	419-4708
8N-7257	Mount As	396-0660
8P-4047	Shaft-Planet	373-5390
8P-7788	Retainer-Cl Pstn	417-9476
8S-3517	Bearing-Spl Ball	417-4501
9G-1499	Gear-Pump (Oil)	295-6424
9G-1696	Pad As	391-9820
9G-1697	Pad As	391-9821
9G-1919	Gear-Planet	371-4307
9G-6774	Gear-Transfer	398-8343
9G-7038	Pin	396-0665
9M-1990	Dowel-Reaction	386-4963
9M-4370	Bearing-Sleeve	453-6515
9N-1161	Line As-Fuel Inj	383-3705
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9P-5531	Gear-Sun	417-9499
9P-6912	Pin	394-0189
9P-8663	Spacer	422-9521
9S-5279	Bearing-Inner	453-3661
9W-2344	Coupling-Pump Dr	314-8666

Sales Model D8L (Cont'd.)

4FB		
Original Part Number	Part Name	Classic Part Number
9W-2977	Hub As	423-6985
9W-5768	Gear-Ring	380-7474
9W-7040	Piston-Clutch	377-7462
9W-7919	Bearing-Sleeve	425-3647
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062

4FB		
Original Part Number	Part Name	Classic Part Number
104-3133	Carrier-Planet	435-2897
106-7798	Bearing-Ball	417-9494
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-2665	Shaft-Planet	391-9871
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5984	Ring-Backup	419-4654
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477

4FB		
Original Part Number	Part Name	Classic Part Number
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
166-6930	Cone-Spl Tapered	399-4443
184-4395	Guide	393-1042
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
232-2672	Kit-Gasket-Fs	393-0922
233-9748	Disc-Friction	417-9502
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

53Y		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-5675	Bearing	377-7396
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401

53Y		
Original Part Number	Part Name	Classic Part Number
1S-9110	Bearing-Needle	420-2497
1S-9209	Shaft-Tightener	374-6499
1T-0043	Bearing-Ball	390-5294
1T-0278	Bearing-Sleeve	394-0213
1T-0610	Bearing-Ball	396-4136
1U-0725	Retainer	314-8707
1U-2666	Cartridge Gp	422-8115
1U-2669	Cartridge Gp	422-8118
1W-5009	Crankshaft As	398-2969

53Y		
Original Part Number	Part Name	Classic Part Number
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850

Sales Model D8L (Cont'd.)

53Y		
Original Part Number	Part Name	Classic Part Number
2K-0227	Bearing-Sleeve	384-4780
2K-5103	Cone-Roller Brg	380-7505
2K-5254	Bearing-Outer	377-7419
2K-5804	Rod End-Spher	416-2151
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2N-5842	Screw-Bridge Adj	418-1934
2P-1005	Bearing-Sleeve	296-1342
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-4370	Plate-Clutch	325-6166
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-3391	Body As-F Inj V	383-3687
2W-4087	Gear As-Idler	418-9582
2W-6965	Coupling	416-5490
2W-6967	Elbow As	420-6385
2W-7610	Gear-Hyd Pump Dr	418-1940
2W-7614	Gear-Crankshaft	425-7752
2W-7980	Camshaft As	378-3972
2W-8038	Gear-Camshaft	425-7751
2W-9978	Core As-Oclr	279-4983
3E-4880	Coupling As	417-9465
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-5707	Cyl Gp-0210 0188	399-8556
3G-5999	Bearing-Sleeve	391-9813
3G-9303	Pin	367-6079
3J-5190	Cap-Brg	256-4837
3J-6167	Bearing-Sleeve	299-1960
3J-7798	Bracket	385-3791
3K-0526	Bearing-Ball	386-4949

53Y		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
3P-2685	Piston-Clutch	308-9908
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3245	Shaft-Planet	308-9924
3P-3738	Housing As	385-7196
3P-7489	Plate-Clutch	377-7423
3P-8845	Bearing-Inner	416-5491
3S-3875	Screen-Suction	435-4849
3S-9669	Bearing	416-2168
3T-0300	Pump Gp-Gr 2Bsc	421-1557
3T-2139	Housing As-Cl	394-2583
3T-5355	Flange	386-3052
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4M-6107	Bearing-Roller	380-7507
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1186	Bearing-Sleeve	417-4519
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216

53Y		
Original Part Number	Part Name	Classic Part Number
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-5367	Mount As	375-9986
4T-0202	Pin As	325-6130
4T-0406	Rod As	394-8215
4T-4073	Valve Gp-Shtl -B	439-1138
4T-7534	Pin	433-9209
4W-2357	Mount As	386-4927
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-8485	Muffler As	430-4472
5F-7404	Nut-Bearing Lock	308-9878
5J-1192	Bearing-Sleeve	374-8355
5J-2528	Plunger	391-1318
5J-5643	Connector	325-6043
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-1370	Bearing As-Rlr	416-2164
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8876	Cup-Rlr Bearing	416-2170
5P-9301	Bearing-Spl Ball	417-4496
5P-9505	Cone-Roller Brg	420-6540
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535

Sales Model D8L (Cont'd.)

53Y		
Original Part Number	Part Name	Classic Part Number
6E-1108	Bearing-Sleeve	325-6023
6E-2190	Rod As	394-8213
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1032	Line As-Fuel Inj	390-0931
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922
6I-1038	Line As-Fuel Inj	390-0923
6I-4613	Plate-Spacer	380-7405
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-5179	Retainer	380-7406
6L-7751	Rod End-Spher	472-8015
6N-0977	Bearing-Sleeve	417-4524
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371

53Y		
Original Part Number	Part Name	Classic Part Number
6N-9133	Gasket-Plate	398-2959
6P-0593	Bearing-Roller	386-4959
6P-3904	Retainer-Bearing	396-0644
6P-5404	Plate-C & Brake	325-6168
6P-6739	Shaft-Planet	308-9929
6P-7564	Carrier-Ring	384-3850
6P-8340	Sleeve	422-7895
6P-8829	Retainer	380-7407
6S-2828	Cup-Roller Brg	384-5932
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-3726	Carrier As	390-5269
6T-7407	Shaft-Pivot	432-8910
6T-8801	Guide As	396-0640
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-5905	Gasket Kit	437-3195
6V-5918	Gasket Kit	437-3194
6V-5919	Gasket Kit	437-3193
6V-5920	Gasket Kit - F	388-0653
6Y-0145	Plate-Locking	419-8801
6Y-0210	Bearing-Sleeve	453-6506
6Y-2878	Retainer	424-0740
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-7920	Disc-Friction	388-0587
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-3938	Pulley-Alt	433-2030
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5287	Elbow As-Ex	430-4470
7E-5996	Rod As-Conn	379-8864
7G-2262	Pump Gp-Gr 2 Bsc	421-1552
7G-2476	Gear-Planet	223-4816
7G-2500	Gear-Planet	296-1350

53Y		
Original Part Number	Part Name	Classic Part Number
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7G-5749	Piston-Clutch	416-2132
7G-5972	Plate-Thrust	393-1055
7G-6059	Carrier-Ring	393-0911
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7681	Shaft As	307-1530
7G-9708	Plate-Thrust	393-1054
7H-7628	Bearing	453-3655
7J-1335	Bearing-Sleeve	380-7567
7J-1336	Bearing-Sleeve	384-4776
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1275	Pulley-Fan	380-7535
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2957	Cover-Rad Cap	361-1722
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-5003	Cap As-Rain	379-0184
7S-7809	Cap As-Radiator	295-6417
7T-1776	Slide	396-0659
7T-2036	Cap As-Fuel	361-1721
7T-2879	Trunnion As	396-7262
7T-3676	Hub-Reaction	388-6578
7T-4053	Shaft As-Output	398-2940
7T-5216	Sleeve-Wear	422-9522
7T-5510	Pad As-Resilient	367-6090
7T-8336	Hub	418-9580

Sales Model D8L (Cont'd.)

53Y		
Original Part Number	Part Name	Classic Part Number
7T-8337	Shaft	416-2138
7W-0182	Plunger & Bbl As	391-9893
7W-0205	Core As-Oclr	379-0183
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5524	Ejector As-Exh	397-5056
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8E-3525	Hub-Sprocket	393-1043
8E-4164	Bar As-Equalizer	469-4661
8E-5001	Shaft As.	434-2400
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8E-6758	Connector As	396-0639
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-7466	Seat	385-3787
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-0935	Gear-Pump Drive	399-8569
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725

53Y		
Original Part Number	Part Name	Classic Part Number
8N-1622	Shield As-Manf	374-4726
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3304	Pulley-Tightener	419-4708
8N-4550	Shaft-Pulley	445-9247
8N-7257	Mount As	396-0660
8N-8983	Hub-Fan Pulley	421-7227
8P-4047	Shaft-Planet	373-5390
8P-5229	Carrier-Stator	395-1309
8P-6083	Yoke-U Joint	446-3073
8P-7788	Retainer-Cl Pstn	417-9476
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0209	Race-Spl Rlr Brg	384-5951
8T-2500	Kit-Gasket	393-1028
8T-6487	Kit-Gasket-Sch	436-8384
9G-1499	Gear-Pump (Oil)	295-6424
9G-1696	Pad As	391-9820
9G-1697	Pad As	391-9821
9G-1919	Gear-Planet	371-4307
9G-3056	Pump Gp-Gr 4A	421-1563
9G-6774	Gear-Transfer	398-8343
9G-7038	Pin	396-0665
9J-0123	Trunnion	325-6227
9J-2290	Pin As	423-3538
9J-2365	Retainer	325-6186
9J-5284	Bearing-Sleeve	380-7379
9M-1990	Dowel-Reaction	386-4963
9M-1997	Bearing-Ball	384-5954
9M-4370	Bearing-Sleeve	453-6515

53Y		
Original Part Number	Part Name	Classic Part Number
9N-1161	Line As-Fuel Inj	383-3705
9N-3668	Base As.-Coolant	419-4718
9P-5531	Gear-Sun	417-9499
9P-6912	Pin	394-0189
9P-8663	Spacer	422-9521
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5279	Bearing-Inner	453-3661
9S-7949	Cup-Roller Brg	420-6531
9S-8184	Pin-Drawbar	398-8345
9T-2860	Cyl Gp-0133-1535	395-1310
9W-2344	Coupling-Pump Dr	314-8666
9W-2977	Hub As	423-6985
9W-5768	Gear-Ring	380-7474
9W-6099	Piston-Clutch	391-9828
9W-7040	Piston-Clutch	377-7462
9W-7458	Piston-Clutch	391-9862
9W-7919	Bearing-Sleeve	425-3647
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069

Sales Model D8L (Cont'd.)

53Y		
Original Part Number	Part Name	Classic Part Number
102-8608	Manifold-Exhaust	376-9062
104-3133	Carrier-Planet	435-2897
106-7098	Flange Assm	390-5271
106-7099	Carrier-Planet	388-6585
106-7798	Bearing-Ball	417-9494
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-2665	Shaft-Planet	391-9871
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
114-0915	Shield As.	394-0887
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-0023	Kit-Bearing-Tc	464-9061
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397

53Y		
Original Part Number	Part Name	Classic Part Number
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
126-5057	Shield As-Man Lh	369-9493
126-5984	Ring-Backup	419-4654
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
133-9016	Pulley	421-7191
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
145-8503	Shaft As-Idler	426-0035
147-1007	Kit-Dt Gasket	388-6587
152-3952	Impeller-Pump	374-4696
155-6057	Kit-Gasket-Trans	388-6588
155-6637	Gear-Oil Drive	425-9189

53Y		
Original Part Number	Part Name	Classic Part Number
160-6305	Cap-Bearing	295-5686
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
166-6930	Cone-Spl Tapered	399-4443
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
184-4395	Guide	393-1042
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
221-9356	Flywheel As	435-2575
226-8202	Seal-Wiper	472-8024
232-2672	Kit-Gasket-Fs	393-0922
233-8683	Kit-Gasket-Mch	393-1039
233-9748	Disc-Friction	417-9502
253-1752	Plate-Thrust	379-0170
277-7089	Shaft As	380-7578
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109
352-0209	Pump Gp-Water -B	375-4336

7JC		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-5675	Bearing	377-7396
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1N-3300	Shield As	374-4702

7JC		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9110	Bearing-Needle	420-2497
1S-9209	Shaft-Tightener	374-6499

7JC		
Original Part Number	Part Name	Classic Part Number
1T-0278	Bearing-Sleeve	394-0213
1T-0610	Bearing-Ball	396-4136
1U-0725	Retainer	314-8707
1U-2666	Cartridge Gp	422-8115
1U-2669	Cartridge Gp	422-8118
1W-3900	Gasket	472-8006
1W-5009	Crankshaft As	398-2969

Sales Model D8L (Cont'd.)

7JC		
Original Part Number	Part Name	Classic Part Number
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2K-5103	Cone-Roller Brg	380-7505
2K-5254	Bearing-Outer	377-7419
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-4087	Gear As-Idler	418-9582
2W-6965	Coupling	416-5490
2W-6967	Elbow As	420-6385
2W-7610	Gear-Hyd Pump Dr	418-1940
2W-7614	Gear-Crankshaft	425-7752
2W-7980	Camshaft As	378-3972
2W-9978	Core As-Oclr	279-4983
3E-4880	Coupling As	417-9465
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-5707	Cyl Gp-0210 0188	399-8556
3G-5999	Bearing-Sleeve	391-9813
3J-5190	Cap-Brg	256-4837
3J-6167	Bearing-Sleeve	299-1960

7JC		
Original Part Number	Part Name	Classic Part Number
3J-7798	Bracket	385-3791
3P-2685	Piston-Clutch	308-9908
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3245	Shaft-Planet	308-9924
3P-3738	Housing As	385-7196
3P-7489	Plate-Clutch	377-7423
3P-8845	Bearing-Inner	416-5491
3S-3875	Screen-Suction	435-4849
3S-9669	Bearing	416-2168
3T-0300	Pump Gp-Gr 2Bsc	421-1557
3T-2139	Housing As-Cl	394-2583
3T-5355	Flange	386-3052
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4M-5858	Bearing-Spl Ball	417-4495
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1106	Shaft As-Rocker	377-5837
4N-1119	Gear-Tfr Pump	373-1884
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4T-0202	Pin As	325-6130
4T-0406	Rod As	394-8215
4T-4073	Valve Gp-Shtl -B	439-1138
4T-7534	Pin	433-9209

7JC		
Original Part Number	Part Name	Classic Part Number
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-8485	Muffler As	430-4472
5J-1192	Bearing-Sleeve	374-8355
5J-2528	Plunger	391-1318
5J-5643	Connector	325-6043
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-1370	Bearing As-Rlr	416-2164
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8876	Cup-Rlr Bearing	416-2170
5P-9301	Bearing-Spl Ball	417-4496
5P-9505	Cone-Roller Brg	420-6540
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
6E-2190	Rod As	394-8213
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717

Sales Model D8L (Cont'd.)

7JC		
Original Part Number	Part Name	Classic Part Number
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-4613	Plate-Spacer	380-7405
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-5179	Retainer	380-7406
6N-0977	Bearing-Sleeve	417-4524
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-0593	Bearing-Roller	386-4959
6P-3904	Retainer-Bearing	396-0644
6P-5404	Plate-C & Brake	325-6168
6P-6739	Shaft-Planet	308-9929
6P-7564	Carrier-Ring	384-3850
6P-8340	Sleeve	422-7895
6P-8829	Retainer	380-7407
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-8801	Guide As	396-0640
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-2543	Gasket Kit	437-3206
6V-3831	Seal-O-Ring	436-2657
6V-5918	Gasket Kit	437-3194
6Y-0145	Plate-Locking	419-8801
6Y-0210	Bearing-Sleeve	453-6506
6Y-2878	Retainer	424-0740
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571

7JC		
Original Part Number	Part Name	Classic Part Number
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5287	Elbow As-Ex	430-4470
7E-5996	Rod As-Conn	379-8864
7G-2262	Pump Gp-Gr 2 Bsc	421-1552
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7G-5972	Plate-Thrust	393-1055
7G-6059	Carrier-Ring	393-0911
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7681	Shaft As	307-1530
7G-9708	Plate-Thrust	393-1054
7H-7628	Bearing	453-3655
7J-1335	Bearing-Sleeve	380-7567
7J-1336	Bearing-Sleeve	384-4776
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-7219	Bearing-Thrust	384-4816
7N-1275	Pulley-Fan	380-7535
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2957	Cover-Rad Cap	361-1722
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-5003	Cap As-Rain	379-0184
7S-7809	Cap As-Radiator	295-6417
7T-1776	Slide	396-0659
7T-2036	Cap As-Fuel	361-1721
7T-2879	Trunnion As	396-7262
7T-4053	Shaft As-Output	398-2940
7T-5510	Pad As-Resilient	367-6090

7JC		
Original Part Number	Part Name	Classic Part Number
7W-0182	Plunger & Bbl As	391-9893
7W-0205	Core As-Oclr	379-0183
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5524	Ejector As-Exh	397-5056
8D-1817	Cup-Roller Brg	434-3296
8E-4164	Bar As-Equalizer	469-4661
8E-5001	Shaft As.	434-2400
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8E-6758	Connector As	396-0639
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8J-7466	Seat	385-3787
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562

Sales Model D8L (Cont'd.)

7JC		
Original Part Number	Part Name	Classic Part Number
8N-2368	Shield As	449-9547
8N-3304	Pulley-Tightener	419-4708
8N-7257	Mount As	396-0660
8P-4047	Shaft-Planet	373-5390
8P-5229	Carrier-Stator	395-1309
8P-6083	Yoke-U Joint	446-3073
8S-3517	Bearing-Spl Ball	417-4501
9G-1499	Gear-Pump (Oil)	295-6424
9G-1696	Pad As	391-9820
9G-1697	Pad As	391-9821
9G-1919	Gear-Planet	371-4307
9G-7038	Pin	396-0665
9J-0123	Trunnion	325-6227
9J-2290	Pin As	423-3538
9J-5284	Bearing-Sleeve	380-7379
9M-1990	Dowel-Reaction	386-4963
9M-4370	Bearing-Sleeve	453-6515
9N-3668	Base As.-Coolant	419-4718
9P-6912	Pin	394-0189
9P-8663	Spacer	422-9521
9T-2860	Cyl Gp-0133-1535	395-1310
9W-2344	Coupling-Pump Dr	314-8666
9W-2977	Hub As	423-6985
9W-5768	Gear-Ring	380-7474
9W-6099	Piston-Clutch	391-9828
9W-7458	Piston-Clutch	391-9862
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729

7JC		
Original Part Number	Part Name	Classic Part Number
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
104-3133	Carrier-Planet	435-2897
106-7098	Flange Assm	390-5271
106-7099	Carrier-Planet	388-6585
106-7798	Bearing-Ball	417-9494
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-2665	Shaft-Planet	391-9871
112-7309	Shaft-Planet	380-7521
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-9712	Shaft-Dr Idler	425-7754

7JC		
Original Part Number	Part Name	Classic Part Number
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
145-2867	Kit-Gasket (Wp)	449-9830
145-8503	Shaft As-Idler	426-0035
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
166-6930	Cone-Spl Tapered	399-4443
184-4395	Guide	393-1042
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
226-8202	Seal-Wiper	472-8024
232-2672	Kit-Gasket-Fs	393-0922
233-9748	Disc-Friction	417-9502
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

7YB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443

7YB		
Original Part Number	Part Name	Classic Part Number
1B-5675	Bearing	377-7396
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705

7YB		
Original Part Number	Part Name	Classic Part Number
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401

Sales Model D8L (Cont'd.)

7YB		
Original Part Number	**Part Name**	**Classic Part Number**
1S-9110	Bearing-Needle	420-2497
1S-9209	Shaft-Tightener	374-6499
1T-0278	Bearing-Sleeve	394-0213
1T-0610	Bearing-Ball	396-4136
1U-0725	Retainer	314-8707
1U-2666	Cartridge Gp	422-8115
1U-2669	Cartridge Gp	422-8118
1W-5009	Crankshaft As	398-2969
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9490	Pulley-Alt	394-0885
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2J-1227	Retainer	440-0850
2K-5103	Cone-Roller Brg	380-7505
2K-5254	Bearing-Outer	377-7419
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2N-5842	Screw-Bridge Adj	418-1934
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2W-3391	Body As-F Inj V	383-3687
2W-4087	Gear As-Idler	418-9582
2W-6965	Coupling	416-5490
2W-6967	Elbow As	420-6385
2W-7610	Gear-Hyd Pump Dr	418-1940

7YB		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7614	Gear-Crankshaft	425-7752
2W-7980	Camshaft As	378-3972
2W-8038	Gear-Camshaft	425-7751
2W-9978	Core As-Oclr	279-4983
3E-4880	Coupling As	417-9465
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-5707	Cyl Gp-0210 0188	399-8556
3G-5999	Bearing-Sleeve	391-9813
3J-5190	Cap-Brg	256-4837
3J-6167	Bearing-Sleeve	299-1960
3J-7798	Bracket	385-3791
3P-2685	Piston-Clutch	308-9908
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3245	Shaft-Planet	308-9924
3P-3738	Housing As	385-7196
3P-7489	Plate-Clutch	377-7423
3P-8845	Bearing-Inner	416-5491
3S-3875	Screen-Suction	435-4849
3S-9669	Bearing	416-2168
3T-0300	Pump Gp-Gr 2Bsc	421-1557
3T-2139	Housing As-Cl	394-2583
3T-5355	Flange	386-3052
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4M-5858	Bearing-Spl Ball	417-4495
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473

7YB		
Original Part Number	**Part Name**	**Classic Part Number**
4N-1119	Gear-Tfr Pump	373-1884
4N-1186	Bearing-Sleeve	417-4519
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4T-0202	Pin As	325-6130
4T-0406	Rod As	394-8215
4T-4073	Valve Gp-Shtl -B	439-1138
4T-7534	Pin	433-9209
4W-2357	Mount As	386-4927
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-8485	Muffler As	430-4472
5F-7404	Nut-Bearing Lock	308-9878
5J-1192	Bearing-Sleeve	374-8355
5J-2528	Plunger	391-1318
5J-5643	Connector	325-6043
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-1370	Bearing As-Rlr	416-2164
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502

Sales Model D8L (Cont'd.)

7YB		
Original Part Number	Part Name	Classic Part Number
5P-8876	Cup-Rlr Bearing	416-2170
5P-9301	Bearing-Spl Ball	417-4496
5P-9505	Cone-Roller Brg	420-6540
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
6E-1108	Bearing-Sleeve	325-6023
6E-2190	Rod As	394-8213
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1032	Line As-Fuel Inj	390-0931
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922
6I-1038	Line As-Fuel Inj	390-0923
6I-4613	Plate-Spacer	380-7405
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-5179	Retainer	380-7406
6N-0977	Bearing-Sleeve	417-4524
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656

7YB		
Original Part Number	Part Name	Classic Part Number
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-0593	Bearing-Roller	386-4959
6P-3904	Retainer-Bearing	396-0644
6P-5404	Plate-C & Brake	325-6168
6P-6739	Shaft-Planet	308-9929
6P-7564	Carrier-Ring	384-3850
6P-8340	Sleeve	422-7895
6P-8829	Retainer	380-7407
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-3726	Carrier As	390-5269
6T-7407	Shaft-Pivot	432-8910
6T-8801	Guide As	396-0640
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-5905	Gasket Kit	437-3195
6V-5918	Gasket Kit	437-3194
6V-5919	Gasket Kit	437-3193
6V-5920	Gasket Kit - F	388-0653
6Y-0145	Plate-Locking	419-8801
6Y-0210	Bearing-Sleeve	453-6506
6Y-2878	Retainer	424-0740
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-3938	Pulley-Alt	433-2030
7E-3205	Manifold-Inlet	376-9060
7E-5085	Bushing	377-5829
7E-5287	Elbow As-Ex	430-4470

7YB		
Original Part Number	Part Name	Classic Part Number
7E-5996	Rod As-Conn	379-8864
7G-2262	Pump Gp-Gr 2 Bsc	421-1552
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7G-5749	Piston-Clutch	416-2132
7G-5972	Plate-Thrust	393-1055
7G-6059	Carrier-Ring	393-0911
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7681	Shaft As	307-1530
7G-9708	Plate-Thrust	393-1054
7H-7628	Bearing	453-3655
7J-1335	Bearing-Sleeve	380-7567
7J-1336	Bearing-Sleeve	384-4776
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1275	Pulley-Fan	380-7535
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2957	Cover-Rad Cap	361-1722
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-5003	Cap As-Rain	379-0184
7S-7809	Cap As-Radiator	295-6417
7T-1776	Slide	396-0659
7T-2036	Cap As-Fuel	361-1721
7T-2879	Trunnion As	396-7262
7T-4053	Shaft As-Output	398-2940
7T-5510	Pad As-Resilient	367-6090
7T-8336	Hub	418-9580
7T-8337	Shaft	416-2138
7W-0182	Plunger & Bbl As	391-9893

Sales Model D8L (Cont'd.)

7YB		
Original Part Number	Part Name	Classic Part Number
7W-0205	Core As-Oclr	379-0183
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5524	Ejector As-Exh	397-5056
8D-1817	Cup-Roller Brg	434-3296
8E-4164	Bar As-Equalizer	469-4661
8E-5001	Shaft As.	434-2400
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8E-6758	Connector As	396-0639
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8J-7466	Seat	385-3787
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0788	Cover	440-0849
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547

7YB		
Original Part Number	Part Name	Classic Part Number
8N-3304	Pulley-Tightener	419-4708
8N-7257	Mount As	396-0660
8P-4047	Shaft-Planet	373-5390
8P-5229	Carrier-Stator	395-1309
8P-6083	Yoke-U Joint	446-3073
8P-7788	Retainer-Cl Pstn	417-9476
8S-3517	Bearing-Spl Ball	417-4501
9G-1499	Gear-Pump (Oil)	295-6424
9G-1696	Pad As	391-9820
9G-1697	Pad As	391-9821
9G-1919	Gear-Planet	371-4307
9G-3056	Pump Gp-Gr 4A	421-1563
9G-6774	Gear-Transfer	398-8343
9G-7038	Pin	396-0665
9J-0123	Trunnion	325-6227
9J-5284	Bearing-Sleeve	380-7379
9M-1990	Dowel-Reaction	386-4963
9M-4370	Bearing-Sleeve	453-6515
9N-1161	Line As-Fuel Inj	383-3705
9N-3668	Base As.-Coolant	419-4718
9P-5531	Gear-Sun	417-9499
9P-6912	Pin	394-0189
9P-8663	Spacer	422-9521
9S-5279	Bearing-Inner	453-3661
9T-2860	Cyl Gp-0133-1535	395-1310
9W-2344	Coupling-Pump Dr	314-8666
9W-2977	Hub As	423-6985
9W-5768	Gear-Ring	380-7474
9W-6099	Piston-Clutch	391-9828
9W-7040	Piston-Clutch	377-7462
9W-7458	Piston-Clutch	391-9862
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482

7YB		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-8608	Manifold-Exhaust	376-9062
104-3133	Carrier-Planet	435-2897
106-7098	Flange Assm	390-5271
106-7099	Carrier-Planet	388-6585
106-7798	Bearing-Ball	417-9494
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-2665	Shaft-Planet	391-9871
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
114-0915	Shield As.	394-0887
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-0023	Kit-Bearing-Tc	464-9061
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042

Sales Model D8L (Cont'd.)

7YB		
Original Part Number	Part Name	Classic Part Number
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-5056	Shield As-Man Lh	369-9492
126-5057	Shield As-Man Lh	369-9493
126-5984	Ring-Backup	419-4654
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
133-3565	Tube As-Exhaust	374-4695

7YB		
Original Part Number	Part Name	Classic Part Number
133-3566	Tube As-Exhaust	378-4003
133-9016	Pulley	421-7191
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
145-8503	Shaft As-Idler	426-0035
147-1007	Kit-Dt Gasket	388-6587
152-3952	Impeller-Pump	374-4696
155-6057	Kit-Gasket-Trans	388-6588
155-6637	Gear-Oil Drive	425-9189
160-6305	Cap-Bearing	295-5686
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992

7YB		
Original Part Number	Part Name	Classic Part Number
166-6930	Cone-Spl Tapered	399-4443
180-6645	Shaft As.	396-1566
184-4395	Guide	393-1042
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
221-9356	Flywheel As	435-2575
226-8202	Seal-Wiper	472-8024
232-2672	Kit-Gasket-Fs	393-0922
233-9748	Disc-Friction	417-9502
253-1752	Plate-Thrust	379-0170
277-7089	Shaft As	380-7578
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109
352-0209	Pump Gp-Water -B	375-4336

Sales Model D8N

1XJ		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1L-7319	Cup-Roller Brg	380-7499
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-9209	Shaft-Tightener	374-6499
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442

1XJ		
Original Part Number	Part Name	Classic Part Number
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0679	Roller-Freewheel	384-4797
1T-0699	Impeller-Conv	235-1808
1T-0807	Race-Thrust Brg	453-3651
1T-0902	Bearing-Sleeve	389-6326
1T-1386	Yoke-Univ Joint	325-6239

1XJ		
Original Part Number	Part Name	Classic Part Number
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0990	Pin	325-6138
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-4738	Bearing-Sleeve	325-6020

Sales Model D8N (Cont'd.)

1XJ		
Original Part Number	Part Name	Classic Part Number
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9229	Muffler As	302-4282
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-1005	Bearing-Sleeve	296-1342
2P-1370	Cup-Rlr Brg	384-5921
2P-4370	Plate-Clutch	325-6166
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7455	Gear As	396-9957
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3E-6772	Seal-Water	382-8017
3E-7473	Gasket Kit	393-3616
3G-5999	Bearing-Sleeve	391-9813
3J-3493	Ballstud	256-4832
3J-5190	Cap-Brg	256-4837
3J-7798	Bracket	385-3791
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698

1XJ		
Original Part Number	Part Name	Classic Part Number
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-6167	Bearing-Sleeve	325-6009
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-0202	Pin As	325-6130
4T-0998	Lever	314-8687
4T-7534	Pin	433-9209

1XJ		
Original Part Number	Part Name	Classic Part Number
4W-0255	Spider As-Fan	382-5052
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518

Sales Model D8N (Cont'd.)

1XJ		
Original Part Number	Part Name	Classic Part Number
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6L-7751	Rod End-Spher	472-8015
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6P-5404	Plate-Cl	325-6168
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl	325-6170
6T-7882	Gear-Planet	296-1352
6T-8249	Pin	399-8542
6T-8250	Retainer	319-3473
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3545	Pin	391-9815
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-7946	Disc-Friction	384-4801
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7C-6628	Pulley-Alt	396-9894
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522

1XJ		
Original Part Number	Part Name	Classic Part Number
7E-6004	Bearing-Sleeve	417-4520
7E-9595	Core As-Radiator	396-9926
7E-9907	Spacer-Fp Timing	394-0222
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-3002	Bearing-Spl Ball	386-4961
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3365	Carrier-Planet	388-6563
7T-3566	Piston	394-9191
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491

1XJ		
Original Part Number	Part Name	Classic Part Number
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8B-8439	Bearing-Ball	399-6069
8C-4455	Gasket Kit	436-8392
8C-4456	Gasket Kit - Sch	393-1029
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8N-8983	Hub-Fan Pulley	421-7227
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9G-0280	Piston	283-5213

Sales Model D8N (Cont'd.)

1XJ		
Original Part Number	Part Name	Classic Part Number
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5839	Coupling-Exhaust	374-7480
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-0142	Cyl Gp-0184-0281	394-9830
9W-1683	Pin	391-9819
9W-2344	Coupling-Pump Dr	314-8666
9W-3271	Body As-Oil Pump	430-4553
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
005-4834	Cone-Rlr Bearing	422-6490

1XJ		
Original Part Number	Part Name	Classic Part Number
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-8010	Valve	423-5583
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
104-6374	Piston	393-1052
107-8106	Manifold-Exh	374-7487
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
118-8458	Spider As-Fan	395-1306
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
130-3139	Bearing-Sleeve	391-9875
130-8412	Piston-Clutch	394-0910
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919

1XJ		
Original Part Number	Part Name	Classic Part Number
131-8674	Gear As-Drive	394-0911
133-8890	Race	399-4423
134-3056	Guard-Duo-Cone	421-7831
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
139-6849	Gasket Kit	388-6586
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-2819	Ejector As-Exh	325-6078
155-5619	Gasket	382-5054
157-5075	Gear-Planet	394-9821
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
164-4413	Mount	419-0876
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
174-5385	Gasket Kit - Ocl	393-1037
177-9024	Adapter-Damper	299-1956
184-4395	Guide	393-1042
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
191-9323	Kit-Bearing	464-9064
200-3199	Muffler As-Eject	396-1565
200-3200	Muffler As-Eject	418-9586
202-3572	Shaft As-Drive	426-0037
208-5026	Pin	325-6133

Sales Model D8N (Cont'd.)

1XJ		
Original Part Number	**Part Name**	**Classic Part Number**
211-0592	Bearing - Main	419-6368
213-3294	Gage As-O Level	398-2930
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3679	Kit-Gasket (Rs)	437-2039
234-1874	Kit-Gasket-Fs	437-8668
239-1497	Trunnion	394-0197
248-2987	Guide	419-4709
250-1984	Trunnion	319-3476
253-1752	Plate-Thrust	379-0170
258-0768	Bearing Sleeve	394-0201
258-2305	Bearing-Sleeve	325-6029

1XJ		
Original Part Number	**Part Name**	**Classic Part Number**
258-2308	Bearing-Sleeve	325-6019
278-1365	Arm As-Ui Rkr	433-7507
288-2551	Kit-Dt Gasket	396-9958
321-5746	Bearing-Main	419-6367
325-6012	Brg-Cla	325-6019
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266

1XJ		
Original Part Number	**Part Name**	**Classic Part Number**
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	376-3636
464-9064	Kit-Dt Brg-Cla	415-1917

5TJ		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1L-7319	Cup-Roller Brg	380-7499
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-9209	Shaft-Tightener	374-6499
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0679	Roller-Freewheel	384-4797
1T-0699	Impeller-Conv	235-1808

5TJ		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0807	Race-Thrust Brg	453-3651
1T-0902	Bearing-Sleeve	389-6326
1T-1386	Yoke-Univ Joint	325-6239
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0990	Pin	325-6138
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164

5TJ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7239	Shaft As-Idler	379-0163
1W-9229	Muffler As	302-4282
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-1005	Bearing-Sleeve	296-1342
2P-1370	Cup-Rlr Brg	384-5921
2P-4370	Plate-Clutch	325-6166
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7455	Gear As	396-9957

Sales Model D8N (Cont'd.)

5TJ		
Original Part Number	Part Name	Classic Part Number
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3E-7473	Gasket Kit	393-3616
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3J-3493	Ballstud	256-4832
3J-5190	Cap-Brg	256-4837
3J-7798	Bracket	385-3791
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5929	Gear	288-8718
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216

5TJ		
Original Part Number	Part Name	Classic Part Number
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-0202	Pin As	325-6130
4T-0998	Lever	314-8687
4T-7534	Pin	433-9209
4T-8054	Seal As	472-8010
4W-0255	Spider As-Fan	382-5052
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360

5TJ		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6J-9482	Pin As	380-7400
6L-7751	Rod End-Spher	472-8015
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8249	Pin	399-8542
6T-8250	Retainer	319-3473
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-2065	Mount As-650 Cup	377-5844
6Y-3545	Pin	391-9815
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7C-6628	Pulley-Alt	396-9894

Sales Model D8N (Cont'd.)

5TJ		
Original Part Number	Part Name	Classic Part Number
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9595	Core As-Radiator	396-9926
7E-9907	Spacer-Fp Timing	394-0222
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5784	Gear-Planet	288-8725
7G-7014	Flange-Stub	396-9925
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531

5TJ		
Original Part Number	Part Name	Classic Part Number
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3365	Carrier-Planet	388-6563
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9542	Gear-Ring	384-4822
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8N-8983	Hub-Fan Pulley	421-7227
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445

5TJ		
Original Part Number	Part Name	Classic Part Number
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5839	Coupling-Exhaust	374-7480
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-0142	Cyl Gp-0184-0281	394-9830
9W-1683	Pin	391-9819
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
005-0469	Cup-Rlr Bearing	418-9610

Sales Model D8N (Cont'd.)

5TJ		
Original Part Number	Part Name	Classic Part Number
005-0471	Cone-Spl Tapered	415-1924
005-4834	Cone-Rlr Bearing	422-6490
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-8010	Valve	423-5583
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
104-6374	Piston	393-1052
107-8106	Manifold-Exh	374-7487
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
118-8458	Spider As-Fan	395-1306
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-3139	Bearing-Sleeve	391-9875
130-8412	Piston-Clutch	394-0910

5TJ		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
133-8890	Race	399-4423
134-3056	Guard-Duo-Cone	421-7831
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
139-6849	Gasket Kit	388-6586
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-2819	Ejector As-Exh	325-6078
155-5619	Gasket	382-5054
157-5075	Gear-Planet	394-9821
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
164-4413	Mount	419-0876
164-6560	Body As-Piston	477-7125
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
174-5385	Gasket Kit - Ocl	393-1037
177-9024	Adapter-Damper	299-1956
184-4395	Guide	393-1042
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
191-9323	Kit-Bearing	464-9064
200-3199	Muffler As-Eject	396-1565

5TJ		
Original Part Number	Part Name	Classic Part Number
200-3200	Muffler As-Eject	418-9586
202-3572	Shaft As-Drive	426-0037
208-5026	Pin	325-6133
211-0592	Bearing - Main	419-6368
213-3294	Gage As-O Level	398-2930
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
226-8202	Seal-Wiper	472-8024
232-3679	Kit-Gasket (Rs)	437-2039
232-4649	Kit-Gasket-Rs	437-8669
234-1874	Kit-Gasket-Fs	437-8668
239-1497	Trunnion	394-0197
248-2987	Guide	419-4709
253-1752	Plate-Thrust	379-0170
258-0768	Bearing Sleeve	394-0201
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
278-1365	Arm As-Ui Rkr	433-7507
288-2551	Kit-Dt Gasket	396-9958
321-5746	Bearing-Main	419-6367
325-6012	Brg-Cla	325-6019
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	377-7433

Sales Model D8N (Cont'd.)

5TJ		
Original Part Number	Part Name	Classic Part Number
464-9064	Kit-Dt Brg-Cla	376-3636

5TJ		
Original Part Number	Part Name	Classic Part Number
464-9064	Kit-Dt Brg-Cla	384-5932

7TK		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1L-7319	Cup-Roller Brg	380-7499
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-9209	Shaft-Tightener	374-6499
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-0807	Race-Thrust Brg	453-3651
1T-0902	Bearing-Sleeve	389-6326
1T-1386	Yoke-Univ Joint	325-6239
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0990	Pin	325-6138

7TK		
Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-4738	Bearing-Sleeve	325-6020
1W-4746	Retainer-Gear	295-5690
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9229	Muffler As	302-4282
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-1005	Bearing-Sleeve	296-1342
2P-4370	Plate-Clutch	325-6166
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7455	Gear As	396-9957
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813

7TK		
Original Part Number	Part Name	Classic Part Number
3J-3493	Ballstud	256-4832
3J-5190	Cap-Brg	256-4837
3J-7798	Bracket	385-3791
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216

Sales Model D8N (Cont'd.)

7TK		
Original Part Number	Part Name	Classic Part Number
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-0202	Pin As	325-6130
4T-0998	Lever	314-8687
4T-7534	Pin	433-9209
4W-0255	Spider As-Fan	382-5052
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360

7TK		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6J-9482	Pin As	380-7400
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8249	Pin	399-8542
6T-8250	Retainer	319-3473
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-2065	Mount As-650 Cup	377-5844
6Y-3545	Pin	391-9815
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7C-6628	Pulley-Alt	396-9894
7C-6697	Shaft - Idler	425-9370

7TK		
Original Part Number	Part Name	Classic Part Number
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9595	Core As-Radiator	396-9926
7E-9907	Spacer-Fp Timing	394-0222
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7014	Flange-Stub	396-9925
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7K-2135	Bearing-Roller	417-4492
7K-8877	Cone-Bearing	374-1847
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3365	Carrier-Planet	388-6563

Sales Model D8N (Cont'd.)

7TK		
Original Part Number	Part Name	Classic Part Number
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9542	Gear-Ring	384-4822
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8E-6758	Connector As	396-0639
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8N-1726	Rod As-Conn	379-8866
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8N-8983	Hub-Fan Pulley	421-7227
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448

7TK		
Original Part Number	Part Name	Classic Part Number
8T-1177	Bearing-Rlr	419-1862
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5839	Coupling-Exhaust	374-7480
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-0142	Cyl Gp-0184-0281	394-9830
9W-1683	Pin	391-9819
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
005-4834	Cone-Rlr Bearing	422-6490
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000

7TK		
Original Part Number	Part Name	Classic Part Number
100-8010	Valve	423-5583
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
104-6374	Piston	393-1052
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-3139	Bearing-Sleeve	391-9875
130-8412	Piston-Clutch	394-0910
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
139-6849	Gasket Kit	388-6586
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
155-2819	Ejector As-Exh	325-6078

Sales Model D8N (Cont'd.)

7TK		
Original Part Number	**Part Name**	**Classic Part Number**
155-5619	Gasket	382-5054
157-5075	Gear-Planet	394-9821
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
164-4413	Mount	419-0876
164-6560	Body As-Piston	477-7125
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
184-4395	Guide	393-1042
185-2831	Line As	380-1516
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012

7TK		
Original Part Number	**Part Name**	**Classic Part Number**
191-7946	Line As-Fuel Inj	378-4013
191-9323	Kit-Bearing	464-9064
200-3199	Muffler As-Eject	396-1565
202-3572	Shaft As-Drive	426-0037
208-5026	Pin	325-6133
211-0592	Bearing - Main	419-6368
213-3294	Gage As-O Level	398-2930
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
226-8202	Seal-Wiper	472-8024
232-3679	Kit-Gasket (Rs)	437-2039
234-1874	Kit-Gasket-Fs	437-8668
239-1497	Trunnion	394-0197
248-2987	Guide	419-4709
253-1752	Plate-Thrust	379-0170
258-0768	Bearing Sleeve	394-0201
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019

7TK		
Original Part Number	**Part Name**	**Classic Part Number**
288-2551	Kit-Dt Gasket	396-9958
321-5746	Bearing-Main	419-6367
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	376-3636
464-9064	Kit-Dt Brg-Cla	384-5932

9TC		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1L-7319	Cup-Roller Brg	380-7499
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-9209	Shaft-Tightener	374-6499
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442

9TC		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0679	Roller-Freewheel	384-4797
1T-0699	Impeller-Conv	235-1808
1T-0807	Race-Thrust Brg	453-3651
1T-0902	Bearing-Sleeve	389-6326
1T-1386	Yoke-Univ Joint	325-6239
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408

9TC		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1993	Wheel-Turbine	235-0920
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0990	Pin	325-6138
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5910	Tappet As-Guide&	383-1569

Sales Model D8N (Cont'd.)

9TC		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9229	Muffler As	302-4282
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-1005	Bearing-Sleeve	296-1342
2P-1370	Cup-Rlr Brg	384-5921
2P-4370	Plate-Clutch	325-6166
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-5540	Core As-Radiator	363-7452
2W-6280	Bracket As-Fan	431-5271
2W-7455	Gear As	396-9957
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3E-6772	Seal-Water	382-8017
3E-7473	Gasket Kit	393-3616
3G-5264	Cylinder As.	393-1018
3G-5497	Cyl Gp-0210 0535	394-9822
3G-5999	Bearing-Sleeve	391-9813
3J-3493	Ballstud	256-4832
3J-5190	Cap-Brg	256-4837
3J-7798	Bracket	385-3791
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698

9TC		
Original Part Number	Part Name	Classic Part Number
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5929	Gear	288-8718
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4J-6167	Bearing-Sleeve	325-6009
4J-6374	Bearing-Sleeve	295-6407
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-0202	Pin As	325-6130

9TC		
Original Part Number	Part Name	Classic Part Number
4T-0998	Lever	314-8687
4T-7534	Pin	433-9209
4V-6421	Pin As	319-3442
4V-7099	Pin As	361-1698
4W-0255	Spider As-Fan	382-5052
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8876	Cup-Rlr Bearing	416-2170
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883

Sales Model D8N (Cont'd.)

9TC		
Original Part Number	Part Name	Classic Part Number
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-5179	Retainer	380-7406
6J-9482	Pin As	380-7400
6L-7751	Rod End-Spher	472-8015
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6P-5404	Plate-Cl & Brake	325-6168
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl & Brake	325-6170
6T-7882	Gear-Planet	296-1352
6T-8249	Pin	399-8542
6T-8250	Retainer	319-3473
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-3545	Pin	391-9815
6Y-5812	Bearing-Sleeve	325-6019

9TC		
Original Part Number	Part Name	Classic Part Number
6Y-5814	Pin	389-6305
6Y-7946	Disc-Friction	384-4801
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7C-6628	Pulley-Alt	396-9894
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9595	Core As-Radiator	396-9926
7E-9907	Spacer-Fp Timing	394-0222
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-4083	Piston	396-9907
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133

9TC		
Original Part Number	Part Name	Classic Part Number
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-3365	Carrier-Planet	388-6563
7T-3566	Piston	394-9191
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8B-8439	Bearing-Ball	399-6069
8C-4455	Gasket Kit	436-8392
8C-4456	Gasket Kit - Sch	393-1029
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8N-0788	Cover	440-0849

Sales Model D8N (Cont'd.)

9TC		
Original Part Number	Part Name	Classic Part Number
8N-1726	Rod As-Conn	379-8866
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8N-8983	Hub-Fan Pulley	421-7227
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-3517	Bearing-Spl Ball	417-4501
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9J-6549	Bearing-Sleeve	453-6514
9J-6556	Rod As	394-8212
9J-7099	Bearing-Sleeve	391-9818
9L-5839	Coupling-Exhaust	374-7480
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-4622	Pin	319-3468
9P-7757	Gear-Sun	283-5218

9TC		
Original Part Number	Part Name	Classic Part Number
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-0142	Cyl Gp-0184-0281	394-9830
9W-1683	Pin	391-9819
9W-2344	Coupling-Pump Dr	314-8666
9W-3271	Body As-Oil Pump	430-4553
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
005-4834	Cone-Rlr Bearing	422-6490
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-8010	Valve	423-5583
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
104-6374	Piston	393-1052
107-8106	Manifold-Exh	374-7487
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276

9TC		
Original Part Number	Part Name	Classic Part Number
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
118-8458	Spider As-Fan	395-1306
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
130-3139	Bearing-Sleeve	391-9875
130-8412	Piston-Clutch	394-0910
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
133-8890	Race	399-4423
134-3056	Guard-Duo-Cone	421-7831
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
139-6849	Gasket Kit	388-6586
139-6850	Gasket Kit	384-4809
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-2819	Ejector As-Exh	325-6078
155-5619	Gasket	382-5054
157-5075	Gear-Planet	394-9821
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048

Sales Model D8N (Cont'd.)

9TC		
Original Part Number	**Part Name**	**Classic Part Number**
164-4413	Mount	419-0876
164-6560	Body As-Piston	477-7125
166-6930	Cone-Spl Tapered	399-4443
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
174-5385	Gasket Kit - Ocl	393-1037
177-9024	Adapter-Damper	299-1956
184-4395	Guide	393-1042
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
191-9323	Kit-Bearing	464-9064
192-6445	Cyl Gp-235 535 Y	393-3651

9TC		
Original Part Number	**Part Name**	**Classic Part Number**
192-6446	Cyl Gp-235 535 Y	393-3657
192-6447	Head	425-9365
192-6448	Rod As	428-7630
200-3199	Muffler As-Eject	396-1565
200-3200	Muffler As-Eject	418-9586
202-3572	Shaft As-Drive	426-0037
208-5026	Pin	325-6133
211-0592	Bearing - Main	419-6368
213-3294	Gage As-O Level	398-2930
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
226-8202	Seal-Wiper	472-8024
232-3679	Kit-Gasket (Rs)	437-2039
234-1874	Kit-Gasket-Fs	437-8668
239-1497	Trunnion	394-0197
248-2987	Guide	419-4709
250-1984	Trunnion	319-3476
253-1752	Plate-Thrust	379-0170
258-0768	Bearing Sleeve	394-0201
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019

9TC		
Original Part Number	**Part Name**	**Classic Part Number**
278-1365	Arm As-Ui Rkr	433-7507
288-2551	Kit-Dt Gasket	396-9958
321-5746	Bearing-Main	419-6367
325-6012	Brg-Cla	325-6019
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	376-3636
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	418-1931

Sales Model D8R

6YZ		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7057	Gasket	420-6384
1S-9209	Shaft-Tightener	374-6499

6YZ		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0679	Roller-Freewheel	384-4797
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-0725	Retainer	314-8707
1U-0990	Pin	325-6138
1W-4738	Bearing-Sleeve	325-6020
1W-7238	Shaft As-Pump Dr	379-0164

6YZ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541

Sales Model D8R (Cont'd.)

6YZ		
Original Part Number	Part Name	Classic Part Number
2W-7455	Gear As	396-9957
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3H-1996	Bearing-Ball	380-1498
3J-5190	Cap-Brg	256-4837
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4S-5367	Mount As	375-9986
4T-7534	Pin	433-9209
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-6150	Adapter-Support	432-4219

6YZ		
Original Part Number	Part Name	Classic Part Number
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6J-9482	Pin As	380-7400
6N-1931	Plunger	379-0171
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-2065	Mount As-650 Cup	377-5844
6Y-3545	Pin	391-9815
6Y-5812	Bearing-Sleeve	325-6019
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-3557	Spider As-Fan	430-4471
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488

6YZ		
Original Part Number	Part Name	Classic Part Number
7G-2830	Ring-Seal	295-6441
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7K-8877	Cone-Bearing	374-1847
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4411	Cap As-Rain	373-1912
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-5164	Gasket	420-8568
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8N-2104	Bell As-Suction	380-1521
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-6511	Bearing-Sleeve	380-7372

Sales Model D8R (Cont'd.)

6YZ		
Original Part Number	Part Name	Classic Part Number
8T-0072	Cone-Rlr Brg	377-7448
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5839	Coupling-Exhaust	374-7480
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-8626	Gear-Sun	283-5219
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7215	Sleeve-Isolator	425-3646
9Y-7735	Bearing-Rod	419-4665
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
102-8608	Manifold-Exhaust	376-9062
104-1706	Valve-Regulating	432-8281
104-6374	Piston	393-1052
108-7930	Bearing As	377-7463
110-8368	Bearing-Cup	416-2172
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446

6YZ		
Original Part Number	Part Name	Classic Part Number
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
118-8458	Spider As-Fan	395-1306
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-3139	Bearing-Sleeve	391-9875
130-8412	Piston-Clutch	394-0910
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
147-3781	Kit-Gasket(Wp)	422-2484
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
157-5075	Gear-Planet	394-9821
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
163-4063	Core As-Rdtr	391-9826
164-4413	Mount	419-0876
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573

6YZ		
Original Part Number	Part Name	Classic Part Number
176-6998	Impeller-Wtr Pmp	425-9367
177-9024	Adapter-Damper	299-1956
184-4395	Guide	393-1042
186-2001	Rotocoil As	397-5055
187-3307	Gasket As-Cyl	438-2022
191-9323	Kit-Bearing	464-9064
197-9251	Pin As.-Piston	454-6110
200-3199	Muffler As-Eject	396-1565
200-3200	Muffler As-Eject	418-9586
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-4781	Gasket Kit	437-8144
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
239-1497	Trunnion	394-0197
248-2987	Guide	419-4709
253-1752	Plate-Thrust	379-0170
258-0768	Bearing Sleeve	394-0201
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
325-6012	Brg-Cla	325-6019
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
343-4836	Mount As	424-6369
352-2077	Pump Gp-Water -B	434-6108
430-7619	Adapter-Cla	438-1812
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	419-6022

Sales Model D8R (Cont'd.)

6YZ		
Original Part Number	Part Name	Classic Part Number
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	377-7433

6YZ		
Original Part Number	Part Name	Classic Part Number
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	376-3636

6YZ		
Original Part Number	Part Name	Classic Part Number
464-9064	Kit-Dt Brg-Cla	418-1931

7XM		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1L-7319	Cup-Roller Brg	380-7499
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1S-9209	Shaft-Tightener	374-6499
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0679	Roller-Freewheel	384-4797
1T-0699	Impeller-Conv	235-1808
1T-0807	Race-Thrust Brg	453-3651
1T-0902	Bearing-Sleeve	389-6326
1T-1386	Yoke-Univ Joint	325-6239
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543

7XM		
Original Part Number	Part Name	Classic Part Number
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0990	Pin	325-6138
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-4738	Bearing-Sleeve	325-6020
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-1005	Bearing-Sleeve	296-1342
2P-4370	Plate-Clutch	325-6166
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-7455	Gear As	396-9957
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813

7XM		
Original Part Number	Part Name	Classic Part Number
3J-3493	Ballstud	256-4832
3J-5190	Cap-Brg	256-4837
3J-7798	Bracket	385-3791
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216

Sales Model D8R (Cont'd.)

7XM		
Original Part Number	Part Name	Classic Part Number
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-0202	Pin As	325-6130
4T-0998	Lever	314-8687
4T-7534	Pin	433-9209
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-8485	Muffler As	430-4472
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-1453	Crankshaft As	368-5916

7XM		
Original Part Number	Part Name	Classic Part Number
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6J-5179	Retainer	380-7406
6J-9482	Pin As	380-7400
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-2065	Mount As-650 Cup	377-5844
6Y-3545	Pin	391-9815
6Y-5812	Bearing-Sleeve	325-6019
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6628	Pulley-Alt	396-9894
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-3557	Spider As-Fan	430-4471
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7G-2500	Gear-Planet	296-1350

7XM		
Original Part Number	Part Name	Classic Part Number
7G-2830	Ring-Seal	295-6441
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-3002	Bearing-Spl Ball	386-4961
7S-4411	Cap As-Rain	373-1912
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658

Sales Model D8R (Cont'd.)

7XM		
Original Part Number	Part Name	Classic Part Number
8H-8175	Bearing-Sleeve	376-3636
8J-2880	Cap-Bearing	295-6420
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5839	Coupling-Exhaust	374-7480
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-4622	Pin	319-3468
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-0142	Cyl Gp-0184-0281	394-9830
9W-1683	Pin	391-9819
9W-3605	Carrier-Ring	314-8662
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491

7XM		
Original Part Number	Part Name	Classic Part Number
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
005-4834	Cone-Rlr Bearing	422-6490
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-8010	Valve	423-5583
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
104-6374	Piston	393-1052
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
110-8368	Bearing-Cup	416-2172
112-5585	Shaft-Planet	308-9932
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
118-8458	Spider As-Fan	395-1306
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566

7XM		
Original Part Number	Part Name	Classic Part Number
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-3139	Bearing-Sleeve	391-9875
130-8412	Piston-Clutch	394-0910
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
133-3359	Manifold-Exhaust	419-4730
133-8890	Race	399-4423
134-3056	Guard-Duo-Cone	421-7831
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052
139-6849	Gasket Kit	388-6586
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
157-5075	Gear-Planet	394-9821
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
163-4063	Core As-Rdtr	391-9826
164-4413	Mount	419-0876
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
184-4395	Guide	393-1042
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
190-9861	Kit-Gskt-Acl	386-3812
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701

Sales Model D8R (Cont'd.)

7XM		
Original Part Number	Part Name	Classic Part Number
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
191-9323	Kit-Bearing	464-9064
200-3199	Muffler As-Eject	396-1565
200-3200	Muffler As-Eject	418-9586
202-3572	Shaft As-Drive	426-0037
208-5026	Pin	325-6133
211-0592	Bearing - Main	419-6368
213-3294	Gage As-O Level	398-2930
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
226-2018	Kit-Gasket-Acl	393-0921
226-8202	Seal-Wiper	472-8024

7XM		
Original Part Number	Part Name	Classic Part Number
234-1874	Kit-Gasket-Fs	437-8668
234-1983	Kit-Gasket-Fs	393-0924
239-1497	Trunnion	394-0197
246-3130	Shaft-Water Pump	392-4508
248-2987	Guide	419-4709
253-1752	Plate-Thrust	379-0170
258-0768	Bearing Sleeve	394-0201
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
278-1365	Arm As-Ui Rkr	433-7507
288-2551	Kit-Dt Gasket	396-9958
321-5746	Bearing-Main	419-6367
325-6012	Brg-Cla	325-6019
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

7XM		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	376-3636
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	377-7397

9EM		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1L-7319	Cup-Roller Brg	380-7499
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7115	Mount As	418-1936
1S-9209	Shaft-Tightener	374-6499
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409

9EM		
Original Part Number	Part Name	Classic Part Number
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-0807	Race-Thrust Brg	453-3651
1T-0902	Bearing-Sleeve	389-6326
1T-1386	Yoke-Univ Joint	325-6239
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0990	Pin	325-6138
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846

9EM		
Original Part Number	Part Name	Classic Part Number
1W-4738	Bearing-Sleeve	325-6020
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-1005	Bearing-Sleeve	296-1342
2P-4370	Plate-Clutch	325-6166

Sales Model D8R (Cont'd.)

9EM		
Original Part Number	Part Name	Classic Part Number
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-7455	Gear As	396-9957
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3J-3493	Ballstud	256-4832
3J-5190	Cap-Brg	256-4837
3J-7798	Bracket	385-3791
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
4D-4065	Rod End-Spher	374-1824
4F-1252	Pin	295-5704
4M-3915	Bearing-Caged	377-7427
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4539	Sleeve	314-8720
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885

9EM		
Original Part Number	Part Name	Classic Part Number
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-0202	Pin As	325-6130
4T-0998	Lever	314-8687
4T-7534	Pin	433-9209
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6E-1108	Bearing-Sleeve	325-6023

9EM		
Original Part Number	Part Name	Classic Part Number
6F-7523	Cap-Bearing	325-6039
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6J-5179	Retainer	380-7406
6J-9482	Pin As	380-7400
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-2065	Mount As-650 Cup	377-5844
6Y-3545	Pin	391-9815
6Y-5812	Bearing-Sleeve	325-6019
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6628	Pulley-Alt	396-9894
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-3557	Spider As-Fan	430-4471
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222

Sales Model D8R (Cont'd.)

9EM		
Original Part Number	Part Name	Classic Part Number
7G-2500	Gear-Planet	296-1350
7G-2830	Ring-Seal	295-6441
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-3002	Bearing-Spl Ball	386-4961
7S-4411	Cap As-Rain	373-1912
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8B-8439	Bearing-Ball	399-6069
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8J-2880	Cap-Bearing	295-6420

9EM		
Original Part Number	Part Name	Classic Part Number
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5839	Coupling-Exhaust	374-7480
9M-4370	Bearing-Sleeve	453-6515
9M-8281	Gear As-Pump	325-6089
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-4622	Pin	319-3468
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-0142	Cyl Gp-0184-0281	394-9830
9W-1683	Pin	391-9819
9W-3605	Carrier-Ring	314-8662
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437

9EM		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
005-4834	Cone-Rlr Bearing	422-6490
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-8010	Valve	423-5583
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
104-6374	Piston	393-1052
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
110-8368	Bearing-Cup	416-2172
112-5585	Shaft-Planet	308-9932
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
118-8458	Spider As-Fan	395-1306
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589

Sales Model D8R (Cont'd.)

9EM		
Original Part Number	Part Name	Classic Part Number
130-3139	Bearing-Sleeve	391-9875
130-8412	Piston-Clutch	394-0910
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
133-8890	Race	399-4423
134-3056	Guard-Duo-Cone	421-7831
135-4928	Shaft-Water Pump	386-3813
139-6849	Gasket Kit	388-6586
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
157-5075	Gear-Planet	394-9821
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
163-4063	Core As-Rdtr	391-9826
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
184-4395	Guide	393-1042
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011

9EM		
Original Part Number	Part Name	Classic Part Number
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
191-9323	Kit-Bearing	464-9064
200-3199	Muffler As-Eject	396-1565
200-3200	Muffler As-Eject	418-9586
202-3572	Shaft As-Drive	426-0037
208-5026	Pin	325-6133
211-0592	Bearing - Main	419-6368
213-3294	Gage As-O Level	398-2930
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
226-2018	Kit-Gasket-Acl	393-0921
226-8202	Seal-Wiper	472-8024
239-1497	Trunnion	394-0197
248-2987	Guide	419-4709
253-1752	Plate-Thrust	379-0170
258-0768	Bearing Sleeve	394-0201

9EM		
Original Part Number	Part Name	Classic Part Number
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
288-2551	Kit-Dt Gasket	396-9958
321-5746	Bearing-Main	419-6367
325-6012	Brg-Cla	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	376-3636
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	377-7433

AKA		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7057	Gasket	420-6384
1S-9209	Shaft-Tightener	374-6499
1T-0679	Roller-Freewheel	384-4797
1T-1278	Bearing-Thrust	370-8370

AKA		
Original Part Number	Part Name	Classic Part Number
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-0725	Retainer	314-8707
1U-0990	Pin	325-6138
1W-4738	Bearing-Sleeve	325-6020
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-1227	Retainer	440-0850

AKA		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-7455	Gear As	396-9957
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3F-6185	Pin	295-5694
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3H-1996	Bearing-Ball	380-1498

Sales Model D8R (Cont'd.)

AKA		
Original Part Number	Part Name	Classic Part Number
3J-5190	Cap-Brg	256-4837
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-4534	Pulley-Crkshft	374-4709
4N-4539	Sleeve	314-8720
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4S-5367	Mount As	375-9986
4T-7534	Pin	433-9209
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700

AKA		
Original Part Number	Part Name	Classic Part Number
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6J-9482	Pin As	380-7400
6N-1931	Plunger	379-0171
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-2065	Mount As-650 Cup	377-5844
6Y-3545	Pin	391-9815
6Y-5812	Bearing-Sleeve	325-6019
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-3557	Spider As-Fan	430-4471
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441

AKA		
Original Part Number	Part Name	Classic Part Number
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-5131	Trunnion	296-1371
7K-8877	Cone-Bearing	374-1847
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4411	Cap As-Rain	373-1912
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7W-2164	Core As-Oclr	299-1996
7W-3145	Plate	422-7894
7W-5164	Gasket	420-8568
7W-5733	Gasket	421-7333
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8N-2104	Bell As-Suction	380-1521
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448

Sales Model D8R (Cont'd.)

AKA		
Original Part Number	Part Name	Classic Part Number
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5839	Coupling-Exhaust	374-7480
9M-4370	Bearing-Sleeve	453-6515
9N-4622	Pin	319-3468
9P-8626	Gear-Sun	283-5219
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7215	Sleeve-Isolator	425-3646
9Y-7735	Bearing-Rod	419-4665
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
102-8608	Manifold-Exhaust	376-9062
104-1706	Valve-Regulating	432-8281
104-6374	Piston	393-1052
108-7930	Bearing As	377-7463
110-8368	Bearing-Cup	416-2172
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259

AKA		
Original Part Number	Part Name	Classic Part Number
116-1102	Sleeve-Injector	451-9024
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
118-8458	Spider As-Fan	395-1306
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-3139	Bearing-Sleeve	391-9875
130-8412	Piston-Clutch	394-0910
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
134-3056	Guard-Duo-Cone	421-7831
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
147-3781	Kit-Gasket(Wp)	422-2484
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
157-5075	Gear-Planet	394-9821
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
163-4063	Core As-Rdtr	391-9826
164-4413	Mount	419-0876
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367

AKA		
Original Part Number	Part Name	Classic Part Number
177-9024	Adapter-Damper	299-1956
184-4395	Guide	393-1042
186-2001	Rotocoil As	397-5055
187-3307	Gasket As-Cyl	438-2022
191-9323	Kit-Bearing	464-9064
197-9251	Pin As.-Piston	454-6110
200-3199	Muffler As-Eject	396-1565
200-3200	Muffler As-Eject	418-9586
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-4781	Gasket Kit	437-8144
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
239-1497	Trunnion	394-0197
248-2987	Guide	419-4709
253-1752	Plate-Thrust	379-0170
258-0768	Bearing Sleeve	394-0201
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
325-6012	Brg-Cla	325-6019
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
343-4836	Mount As	424-6369
352-2077	Pump Gp-Water -B	434-6108
430-7619	Adapter-Cla	438-1812
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	434-3296
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	377-7433

Sales Model D8R (Cont'd.)

AKA		
Original Part Number	Part Name	Classic Part Number
464-9064	Kit-Dt Brg-Cla	377-7397

AKA		
Original Part Number	Part Name	Classic Part Number
464-9064	Kit-Dt Brg-Cla	376-3636

AKA		
Original Part Number	Part Name	Classic Part Number
464-9064	Kit-Dt Brg-Cla	415-1917

MEJ		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-9209	Shaft-Tightener	374-6499
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0447	Carrier-Ring	295-0409
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1386	Yoke-Univ Joint	325-6239
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0990	Pin	325-6138
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-4738	Bearing-Sleeve	325-6020
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163

MEJ		
Original Part Number	Part Name	Classic Part Number
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-7455	Gear As	396-9957
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3J-5190	Cap-Brg	256-4837
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
4D-4065	Rod End-Spher	374-1824
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056

MEJ		
Original Part Number	Part Name	Classic Part Number
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4T-7534	Pin	433-9209
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920

Sales Model D8R (Cont'd.)

MEJ		
Original Part Number	Part Name	Classic Part Number
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6J-5179	Retainer	380-7406
6J-9482	Pin As	380-7400
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7G-2830	Ring-Seal	295-6441
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7K-8877	Cone-Bearing	374-1847

MEJ		
Original Part Number	Part Name	Classic Part Number
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4411	Cap As-Rain	373-1912
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5839	Coupling-Exhaust	374-7480

MEJ		
Original Part Number	Part Name	Classic Part Number
9M-4370	Bearing-Sleeve	453-6515
9N-1545	Race-Thrust	394-9205
9N-4622	Pin	319-3468
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9W-3605	Carrier-Ring	314-8662
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
005-4834	Cone-Rlr Bearing	422-6490
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-8010	Valve	423-5583
101-1816	Bridge As-Intake	374-4689
101-1818	Bridge As-Exh	374-4691
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
104-6374	Piston	393-1052
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
112-5585	Shaft-Planet	308-9932
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703

Sales Model D8R (Cont'd.)

MEJ		
Original Part Number	**Part Name**	**Classic Part Number**
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-3139	Bearing-Sleeve	391-9875
130-8412	Piston-Clutch	394-0910
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
157-5075	Gear-Planet	394-9821
160-9874	Kit-Gasket-Scl	386-3048
163-4063	Core As-Rdtr	391-9826

MEJ		
Original Part Number	**Part Name**	**Classic Part Number**
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
200-3199	Muffler As-Eject	396-1565
200-3200	Muffler As-Eject	418-9586

MEJ		
Original Part Number	**Part Name**	**Classic Part Number**
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
239-1497	Trunnion	394-0197
248-2987	Guide	419-4709
253-1752	Plate-Thrust	379-0170
258-0768	Bearing Sleeve	394-0201
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

RJM		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-9209	Shaft-Tightener	374-6499
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0447	Carrier-Ring	295-0409
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1386	Yoke-Univ Joint	325-6239
1T-1880	Carrier-Ring	295-0408

RJM		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1993	Wheel-Turbine	235-0920
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0990	Pin	325-6138
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-4738	Bearing-Sleeve	325-6020
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174

RJM		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-7455	Gear As	396-9957
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3J-5190	Cap-Brg	256-4837
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698

Sales Model D8R (Cont'd.)

RJM		
Original Part Number	Part Name	Classic Part Number
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
4D-4065	Rod End-Spher	374-1824
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4T-7534	Pin	433-9209
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700

RJM		
Original Part Number	Part Name	Classic Part Number
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6J-5179	Retainer	380-7406
6J-9482	Pin As	380-7400
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522

RJM		
Original Part Number	Part Name	Classic Part Number
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7G-2830	Ring-Seal	295-6441
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7K-8877	Cone-Bearing	374-1847
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4411	Cap As-Rain	373-1912
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-6511	Bearing-Sleeve	380-7372

Sales Model D8R (Cont'd.)

RJM		
Original Part Number	Part Name	Classic Part Number
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5839	Coupling-Exhaust	374-7480
9M-4370	Bearing-Sleeve	453-6515
9N-1545	Race-Thrust	394-9205
9N-4622	Pin	319-3468
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9W-3605	Carrier-Ring	314-8662
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
005-4834	Cone-Rlr Bearing	422-6490
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-8010	Valve	423-5583
101-1816	Bridge As-Intake	374-4689
101-1818	Bridge As-Exh	374-4691
102-8608	Manifold-Exhaust	376-9062

RJM		
Original Part Number	Part Name	Classic Part Number
104-5283	Manifold-Exhaust	394-9831
104-6374	Piston	393-1052
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
112-5585	Shaft-Planet	308-9932
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-3139	Bearing-Sleeve	391-9875
130-8412	Piston-Clutch	394-0910
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
157-5075	Gear-Planet	394-9821
160-9874	Kit-Gasket-Scl	386-3048
163-4063	Core As-Rdtr	391-9826
166-9142	Gasket	420-8546

RJM		
Original Part Number	Part Name	Classic Part Number
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
200-3199	Muffler As-Eject	396-1565
200-3200	Muffler As-Eject	418-9586
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
217-0578	Bearing-Rod	419-4665
239-1497	Trunnion	394-0197
248-2987	Guide	419-4709
253-1752	Plate-Thrust	379-0170
258-0768	Bearing Sleeve	394-0201
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

T5X		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705

T5X		
Original Part Number	Part Name	Classic Part Number
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913

T5X		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

Sales Model D8R (Cont'd.)

T5X		
Original Part Number	Part Name	Classic Part Number
1S-9209	Shaft-Tightener	374-6499
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0447	Carrier-Ring	295-0409
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1386	Yoke-Univ Joint	325-6239
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0725	Retainer	314-8707
1U-0990	Pin	325-6138
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-4738	Bearing-Sleeve	325-6020
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2W-7455	Gear As	396-9957

T5X		
Original Part Number	Part Name	Classic Part Number
3B-4124	Cup-Spl Tapered	422-6481
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3J-5190	Cap-Brg	256-4837
3K-2511	Dowel-Reaction	383-2126
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
4D-4065	Rod End-Spher	374-1824
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4T-0998	Lever	314-8687
4T-7534	Pin	433-9209
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

T5X		
Original Part Number	Part Name	Classic Part Number
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5S-4557	Bearing	311-9360
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6J-5179	Retainer	380-7406
6J-9482	Pin As	380-7400
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990

Sales Model D8R (Cont'd.)

T5X		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
6Y-0145	Plate-Locking	419-8801
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-2065	Mount As-650 Cup	377-5844
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-9907	Spacer-Fp Timing	394-0222
7G-2830	Ring-Seal	295-6441
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7K-8877	Cone-Bearing	374-1847
7M-1296	Valve-Relief	390-0990
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4411	Cap As-Rain	373-1912
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493

T5X		
Original Part Number	Part Name	Classic Part Number
7W-5733	Gasket	421-7333
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8N-0788	Cover	440-0849
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-1177	Bearing-Rlr	419-1862
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9L-5839	Coupling-Exhaust	374-7480
9M-4370	Bearing-Sleeve	453-6515
9N-1545	Race-Thrust	394-9205
9N-4622	Pin	319-3468
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9W-3605	Carrier-Ring	314-8662
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437

T5X		
Original Part Number	Part Name	Classic Part Number
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
005-4834	Cone-Rlr Bearing	422-6490
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-8010	Valve	423-5583
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8608	Manifold-Exhaust	376-9062
104-5283	Manifold-Exhaust	394-9831
104-6374	Piston	393-1052
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
110-8368	Bearing-Cup	416-2172
112-5585	Shaft-Planet	308-9932
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
116-7885	Pan-Oil (Front)	379-0173
117-0456	Crankshaft As	394-2587
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-3139	Bearing-Sleeve	391-9875
130-8412	Piston-Clutch	394-0910

Sales Model D8R (Cont'd.)

T5X		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
131-8674	Gear As-Drive	394-0911
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
155-5619	Gasket	382-5054
157-5075	Gear-Planet	394-9821
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
163-4063	Core As-Rdtr	391-9826
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516

T5X		
Original Part Number	Part Name	Classic Part Number
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
200-3199	Muffler As-Eject	396-1565
200-3200	Muffler As-Eject	418-9586
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-3294	Gage As-O Level	398-2930

T5X		
Original Part Number	Part Name	Classic Part Number
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
239-1497	Trunnion	394-0197
248-2987	Guide	419-4709
253-1752	Plate-Thrust	379-0170
258-0768	Bearing Sleeve	394-0201
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
430-7619	Adapter-Cla	438-1812

Sales Model D8T

FCT		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0679	Roller-Freewheel	384-4797
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-0725	Retainer	314-8707
1U-0990	Pin	325-6138
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163

FCT		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3H-1996	Bearing-Ball	380-1498
3J-5190	Cap-Brg	256-4837
3K-2511	Dowel-Reaction	383-2126
3S-3875	Screen-Suction	435-4849
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698

FCT		
Original Part Number	Part Name	Classic Part Number
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4T-7534	Pin	433-9209
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700

Sales Model D8T (Cont'd.)

FCT		
Original Part Number	Part Name	Classic Part Number
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6J-5179	Retainer	380-7406
6J-9482	Pin As	380-7400
6N-1931	Plunger	379-0171
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-2065	Mount As-650 Cup	377-5844
6Y-3545	Pin	391-9815
6Y-4819	Carrier-Planet	296-1348
7C-0307	Gasket	399-8571
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491

FCT		
Original Part Number	Part Name	Classic Part Number
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
104-6374	Piston	393-1052
108-7930	Bearing As	377-7463
110-8368	Bearing-Cup	416-2172
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681

FMC		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126

FCT		
Original Part Number	Part Name	Classic Part Number
116-7885	Pan-Oil (Front)	379-0173
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-3139	Bearing-Sleeve	391-9875
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
157-5075	Gear-Planet	394-9821
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
184-4395	Guide	393-1042
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
239-1497	Trunnion	394-0197
246-3130	Shaft-Water Pump	392-4508
248-2987	Guide	419-4709
253-1752	Plate-Thrust	379-0170
258-0768	Bearing Sleeve	394-0201
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model D8T (Cont'd.)

FMC		
Original Part Number	Part Name	Classic Part Number
1J-6744	Bearing	361-1705
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0679	Roller-Freewheel	384-4797
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-0725	Retainer	314-8707
1U-0990	Pin	325-6138
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3H-1996	Bearing-Ball	380-1498
3J-5190	Cap-Brg	256-4837
3K-2511	Dowel-Reaction	383-2126
3S-3875	Screen-Suction	435-4849
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4T-7534	Pin	433-9209
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320

FMC		
Original Part Number	Part Name	Classic Part Number
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6J-9482	Pin As	380-7400
6N-1931	Plunger	379-0171
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-2065	Mount As-650 Cup	377-5844
6Y-4819	Carrier-Planet	296-1348
7C-0307	Gasket	399-8571
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7N-2156	Bearing-Sleeve	380-7373

FMC		
Original Part Number	Part Name	Classic Part Number
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
104-6374	Piston	393-1052
108-7930	Bearing As	377-7463
110-8368	Bearing-Cup	416-2172
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
116-7885	Pan-Oil (Front)	379-0173
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589

Sales Model D8T (Cont'd.)

FMC		
Original Part Number	**Part Name**	**Classic Part Number**
130-3139	Bearing-Sleeve	391-9875
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107

FMC		
Original Part Number	**Part Name**	**Classic Part Number**
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
157-5075	Gear-Planet	394-9821
160-9874	Kit-Gasket-Scl	386-3048
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914

FMC		
Original Part Number	**Part Name**	**Classic Part Number**
239-1497	Trunnion	394-0197
246-3130	Shaft-Water Pump	392-4508
248-2987	Guide	419-4709
253-1752	Plate-Thrust	379-0170
258-0768	Bearing Sleeve	394-0201
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019

J8B		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0679	Roller-Freewheel	384-4797
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-0725	Retainer	314-8707
1U-0990	Pin	325-6138
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813

J8B		
Original Part Number	**Part Name**	**Classic Part Number**
3H-1996	Bearing-Ball	380-1498
3J-5190	Cap-Brg	256-4837
3K-2511	Dowel-Reaction	383-2126
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4T-7534	Pin	433-9209
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320

J8B		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-2726	Bearing-Sleeve	419-4757
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6J-9482	Pin As	380-7400
6N-1931	Plunger	379-0171

Sales Model D8T (Cont'd.)

J8B		
Original Part Number	Part Name	Classic Part Number
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-2065	Mount As-650 Cup	377-5844
6Y-3545	Pin	391-9815
6Y-4819	Carrier-Planet	296-1348
6Y-5812	Bearing-Sleeve	325-6019
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7M-7219	Bearing-Thrust	384-4816
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4411	Cap As-Rain	373-1912
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-3145	Plate	422-7894
7W-5733	Gasket	421-7333
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576

J8B		
Original Part Number	Part Name	Classic Part Number
8E-6758	Connector As	396-0639
8H-5352	Bearing-Ball	453-3658
8J-2880	Cap-Bearing	295-6420
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
102-8608	Manifold-Exhaust	376-9062
104-6374	Piston	393-1052
108-7930	Bearing As	377-7463
110-8368	Bearing-Cup	416-2172
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681

J8B		
Original Part Number	Part Name	Classic Part Number
116-7885	Pan-Oil (Front)	379-0173
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-3139	Bearing-Sleeve	391-9875
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
157-5075	Gear-Planet	394-9821
160-9874	Kit-Gasket-Scl	386-3048
164-4413	Mount	419-0876
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
184-4395	Guide	393-1042
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
239-1497	Trunnion	394-0197
246-3130	Shaft-Water Pump	392-4508
248-2987	Guide	419-4709
253-1752	Plate-Thrust	379-0170
258-0768	Bearing Sleeve	394-0201
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
325-6012	Brg-Cla	325-6019

Sales Model D8T (Cont'd.)

J8B		
Original Part Number	**Part Name**	**Classic Part Number**
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966

J8B		
Original Part Number	**Part Name**	**Classic Part Number**
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665

J8B		
Original Part Number	**Part Name**	**Classic Part Number**
328-5573	Bearing-Conn Rod	419-6387

JET		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0679	Roller-Freewheel	384-4797
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-0725	Retainer	314-8707
1U-0990	Pin	325-6138
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3H-1996	Bearing-Ball	380-1498
3J-5190	Cap-Brg	256-4837
3K-2511	Dowel-Reaction	383-2126
3S-3875	Screen-Suction	435-4849
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700

JET		
Original Part Number	**Part Name**	**Classic Part Number**
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4T-7534	Pin	433-9209
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6J-9482	Pin As	380-7400
6N-1931	Plunger	379-0171
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442

JET		
Original Part Number	**Part Name**	**Classic Part Number**
6T-7882	Gear-Planet	296-1352
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-2065	Mount As-650 Cup	377-5844
6Y-4819	Carrier-Planet	296-1348
7C-0307	Gasket	399-8571
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7N-2156	Bearing-Sleeve	380-7373
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227

Sales Model D8T (Cont'd.)

JET		
Original Part Number	Part Name	Classic Part Number
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
104-6374	Piston	393-1052
108-7930	Bearing As	377-7463
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
116-7885	Pan-Oil (Front)	379-0173
127-6356	Cover As.-Pump	420-8566

JET		
Original Part Number	Part Name	Classic Part Number
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-3139	Bearing-Sleeve	391-9875
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
157-5075	Gear-Planet	394-9821
160-9874	Kit-Gasket-Scl	386-3048

JET		
Original Part Number	Part Name	Classic Part Number
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
239-1497	Trunnion	394-0197
246-3130	Shaft-Water Pump	392-4508
248-2987	Guide	419-4709
253-1752	Plate-Thrust	379-0170
258-0768	Bearing Sleeve	394-0201
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019

KPZ		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0679	Roller-Freewheel	384-4797
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-0725	Retainer	314-8707
1U-0990	Pin	325-6138
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346

KPZ		
Original Part Number	Part Name	Classic Part Number
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813
3H-1996	Bearing-Ball	380-1498
3J-5190	Cap-Brg	256-4837
3K-2511	Dowel-Reaction	383-2126
3S-3875	Screen-Suction	435-4849
3T-0996	Bearing-Sleeve	295-5695
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700

KPZ		
Original Part Number	Part Name	Classic Part Number
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4T-7534	Pin	433-9209
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060

Sales Model D8T (Cont'd.)

KPZ		
Original Part Number	Part Name	Classic Part Number
5J-4321	Trunnion	302-2700
5J-8118	Bearing-Sleeve	451-9018
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-2726	Bearing-Sleeve	419-4757
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-5179	Retainer	380-7406
6J-9482	Pin As	380-7400
6N-1931	Plunger	379-0171
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6V-3831	Seal-O-Ring	436-2657
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-2065	Mount As-650 Cup	377-5844
6Y-3545	Pin	391-9815
6Y-4819	Carrier-Planet	296-1348
6Y-5812	Bearing-Sleeve	325-6019
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257

KPZ		
Original Part Number	Part Name	Classic Part Number
7E-5996	Rod As-Conn	379-8864
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7M-7219	Bearing-Thrust	384-4816
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4411	Cap As-Rain	373-1912
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-3145	Plate	422-7894
7W-5733	Gasket	421-7333
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8H-5352	Bearing-Ball	453-3658
8J-2880	Cap-Bearing	295-6420
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227

KPZ		
Original Part Number	Part Name	Classic Part Number
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
102-8608	Manifold-Exhaust	376-9062
104-6374	Piston	393-1052
108-7930	Bearing As	377-7463
110-8368	Bearing-Cup	416-2172
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
116-7885	Pan-Oil (Front)	379-0173
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-3139	Bearing-Sleeve	391-9875
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599

Sales Model D8T (Cont'd.)

KPZ		
Original Part Number	Part Name	Classic Part Number
157-5075	Gear-Planet	394-9821
160-9874	Kit-Gasket-Scl	386-3048
164-4413	Mount	419-0876
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
184-4395	Guide	393-1042
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914

KPZ		
Original Part Number	Part Name	Classic Part Number
217-0578	Bearing-Rod	419-4665
239-1497	Trunnion	394-0197
246-3130	Shaft-Water Pump	392-4508
248-2987	Guide	419-4709
253-1752	Plate-Thrust	379-0170
258-0768	Bearing Sleeve	394-0201
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019

KPZ		
Original Part Number	Part Name	Classic Part Number
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
325-6012	Brg-Cla	325-6019
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387

MLN		
Original Part Number	Part Name	Classic Part Number
1H-4106	Pin As-Drawbar	325-6126
1J-6744	Bearing	361-1705
1M-7912	Cone-Roller Brg	380-7503
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0679	Roller-Freewheel	384-4797
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-0725	Retainer	314-8707
1U-0990	Pin	325-6138
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2J-1227	Retainer	440-0850
2K-5069	Cup-Roller Brg	374-8346
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3E-4880	Coupling As	417-9465
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-5999	Bearing-Sleeve	391-9813

MLN		
Original Part Number	Part Name	Classic Part Number
3H-1996	Bearing-Ball	380-1498
3J-5190	Cap-Brg	256-4837
3K-2511	Dowel-Reaction	383-2126
3S-3875	Screen-Suction	435-4849
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4T-7534	Pin	433-9209
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5J-4321	Trunnion	302-2700
5J-8118	Bearing-Sleeve	451-9018

MLN		
Original Part Number	Part Name	Classic Part Number
5M-0578	Bearing	419-7775
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
6E-1108	Bearing-Sleeve	325-6023
6F-7523	Cap-Bearing	325-6039
6I-8500	Plate-Clutch	377-7436
6J-5179	Retainer	380-7406
6J-9482	Pin As	380-7400
6N-1931	Plunger	379-0171
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0064	Shaft-Planet	295-6442
6T-7882	Gear-Planet	296-1352
6T-8801	Guide As	396-0640
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-2065	Mount As-650 Cup	377-5844
6Y-3545	Pin	391-9815
6Y-4819	Carrier-Planet	296-1348
7C-0307	Gasket	399-8571

Sales Model D8T (Cont'd.)

MLN		
Original Part Number	Part Name	Classic Part Number
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7H-4566	Cup-Roller Brg	399-6068
7H-7628	Bearing	453-3655
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7T-8136	Shaft-Planet	314-8714
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
8D-0983	Mounting	384-3470
8D-1817	Cup-Roller Brg	434-3296
8E-5450	Seal-Ebar	325-6190
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
9D-7924	Mount As	360-2356
9G-0284	Housing-Clutch	283-5214
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931

MLN		
Original Part Number	Part Name	Classic Part Number
9J-0123	Trunnion	325-6227
9M-4370	Bearing-Sleeve	453-6515
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9W-7481	Gear-Planet	295-6431
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
104-6374	Piston	393-1052
108-7930	Bearing As	377-7463
110-8368	Bearing-Cup	416-2172
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
116-7885	Pan-Oil (Front)	379-0173
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
130-3139	Bearing-Sleeve	391-9875
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

MLN		
Original Part Number	Part Name	Classic Part Number
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
157-5075	Gear-Planet	394-9821
160-9874	Kit-Gasket-Scl	386-3048
167-8126	Damper As	382-8019
184-4395	Guide	393-1042
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
239-1497	Trunnion	394-0197
246-3130	Shaft-Water Pump	392-4508
248-2987	Guide	419-4709
253-1752	Plate-Thrust	379-0170
258-0768	Bearing Sleeve	394-0201
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model DEUCE

7RR		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114
1S-3743	Bearing-Ball	384-4786

7RR		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
2A-4429	Lock-Retainer	379-0174
2S-7931	Bearing-Sleeve	387-2904

7RR		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3K-2511	Dowel-Reaction	383-2126
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899

Sales Model DEUCE (Cont'd.)

7RR		
Original Part Number	Part Name	Classic Part Number
3P-3208	Flange-Joint	301-4647
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5200	Carrier-Planet	295-5701
4F-2393	Bearing-Ball	380-1499
4K-0299	Bearing-Sleeve	308-9816
4M-3915	Bearing-Caged	377-7427
4P-7051	Pulley-Alt	376-9064
4S-8472	Hood As-Preclnr	296-1355
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4W-0456	Muffler As-Eject	360-7879
4W-1203	Cup-Rlr Brg	418-9603
5D-2989	Bearing	380-7511
5M-0578	Bearing	419-7775
5M-6212	Tube	390-0996
5M-7925	Bearing-Roller	419-7774
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
5T-1362	Univ Joint As-5C	325-6011
6D-0217	Bearing-Sleeve	325-6022
6I-1099	Manifold-Exh	424-6366
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-7500	Retainer	383-2104
6L-7751	Rod End-Spher	472-8015
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6S-3463	Bearing-Sleeve	374-6513
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6T-0064	Shaft-Planet	295-6442

7RR		
Original Part Number	Part Name	Classic Part Number
6T-2293	Piston-Load	426-0040
6Y-1690	Carrier-Ring	384-3849
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-9267	Yoke	330-9297
7E-6794	Arm As-Injector	433-0449
7G-2830	Ring-Seal	295-6441
7G-7431	Piston-Selector	432-8911
7G-7724	Piston-Clutch	283-5206
7J-1309	Bearing-Aligning	360-2275
7J-2604	Bearing-Sleeve	380-7369
7J-8893	Cone-Roller Brg	374-1846
7J-9884	Bearing-Sleeve	325-6016
7K-0078	Bearing-Sleeve	308-9825
7T-2036	Cap As-Fuel	361-1721
7T-4754	Impeller-Conv	385-7231
7T-8136	Shaft-Planet	314-8714
7W-3773	Pulley-Cshaft	383-1583
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8D-1817	Cup-Roller Brg	434-3296
8D-2459	Gear-Planet	390-5293
8E-6221	Pin	325-6155
8H-5352	Bearing-Ball	453-3658
8P-0953	Turbine-Conv	297-7269
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016

7RR		
Original Part Number	Part Name	Classic Part Number
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8W-4523	Bearing-Sleeve	385-3798
9G-0280	Piston	283-5213
9J-3206	Bearing-Spher	360-2275
9M-1328	Bearing-Aligning	325-6018
9P-8517	Case-Xmsn	394-0909
9S-5279	Bearing-Inner	453-3661
9W-7481	Gear-Planet	295-6431
9W-9931	Mount As.	360-2354
100-4529	Piston As	424-6368
100-6174	Cyl Gp-0089 0421	425-9368
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
106-7799	Bearing-Ball	396-9947
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
112-5495	Joint Gp-Univ	297-4858
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5984	Ring-Backup	419-4654
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
136-7813	Bearing-Race	460-8296
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
221-9755	Gear-Planet	390-5293
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912

Sales Model DEUCE (Cont'd.)

7RR		
Original Part Number	Part Name	Classic Part Number
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

7RR		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

7RR		
Original Part Number	Part Name	Classic Part Number
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441

Sales Model DV87

9AM		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-3958	Bearing-Needle	434-6114
1P-7115	Mount As	418-1936
1P-7522	Yoke As	382-6893
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1005	Bearing-Sleeve	296-1342
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075

9AM		
Original Part Number	Part Name	Classic Part Number
2P-1374	Cone-Rlr Brg	374-1844
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-6245	Shaft As-Pump	325-6197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5539	Core As-Rad	374-7492
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
3B-4124	Cup-Spl Tapered	422-6481
3F-6523	Pin-Clevis	256-4818
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436
3S-3875	Screen-Suction	435-4849
4M-6107	Bearing-Roller	380-7507
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763

9AM		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4S-9326	Bearing	417-4506
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5B-9169	Plug-Drain	419-4736
5M-0578	Bearing	419-7775
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9531	Cone-Rlr Bearing	386-4956

Sales Model DV87 (Cont'd.)

9AM		
Original Part Number	Part Name	Classic Part Number
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8642	Race-Brg Outer	396-9898
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6Y-2027	Disc-Friction	377-7441
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7G-7431	Piston-Selector	432-8911
7H-4566	Cup-Roller Brg	399-6068
7J-3216	Bearing	368-0104
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438

9AM		
Original Part Number	Part Name	Classic Part Number
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7V-0638	Spacer	425-3651
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8E-5450	Seal-Ebar	325-6190
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585

9AM		
Original Part Number	Part Name	Classic Part Number
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1656	Plate-Clutch	367-6071
8R-1693	Pin As	415-1906
8R-6631	Hub	443-2057
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9L-5908	Gasket	433-8196
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6306	Cap-Bearing	325-6038
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

Sales Model DV87 (Cont'd.)

9AM		
Original Part Number	Part Name	Classic Part Number
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574

9AM		
Original Part Number	Part Name	Classic Part Number
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
173-0888	Univ Jt As	394-0898
176-3900	Accumulator	416-5513
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

9AM		
Original Part Number	Part Name	Classic Part Number
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

Sales Model MT735

AKN		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1T-0043	Bearing-Ball	390-5294
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2J-2152	Cup-Roller Brg	374-1852
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017

AKN		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
4E-2250	Housing	399-6043
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5F-2465	Cup-Roller Brg	447-8060
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-7936	Bearing-Outer	386-4953
5P-3930	Bearing As-Rlr	419-6022
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6K-9070	Washer-Thrust	330-9294
6N-1931	Plunger	379-0171
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921

AKN		
Original Part Number	Part Name	Classic Part Number
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-9555	Univ Joint As	314-8721
7J-5131	Trunnion	296-1371
7M-5334	Cone-Roller Brg	420-2505
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7W-3145	Plate	422-7894
8H-9789	Bearing-Ball	374-8342
8S-6511	Bearing-Sleeve	380-7372
8T-0209	Race-Spl Rlr Brg	384-5951
9F-3212	Bearing-Ball	384-5953
9Y-6054	Rod As-Conn	379-8868

Sales Model MT735 (Cont'd.)

AKN		
Original Part Number	Part Name	Classic Part Number
9Y-7735	Bearing-Rod	419-4665
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
101-3125	Gasket	420-8567
101-9640	Gear-Air Compr	398-2966
107-7708	Bearing-Main	419-6381
108-7930	Bearing As	377-7463
115-4072	Bearing	397-5069
126-8557	Pulley	433-2027
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-4995	Gasket-Cyl Head	434-2445
135-4928	Shaft-Water Pump	386-3813

AKN		
Original Part Number	Part Name	Classic Part Number
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
145-8503	Shaft As-Idler	426-0035
152-3952	Impeller-Pump	374-4696
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-8030	Gasket	394-0894
160-9874	Kit-Gasket-Scl	386-3048
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
190-0649	Tightener-Belt	434-1407
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
212-4893	Bearing-Thrust	419-6372

AKN		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
243-6718	Kit-Brg(Main)	469-1690
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
271-5658	Crankshaft As.	368-5912
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
430-7619	Adapter-Cla	438-1812

Sales Model MT745

ALA		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2J-2152	Cup-Roller Brg	374-1852
2M-5685	Bearing-Needle	380-7469

ALA		
Original Part Number	Part Name	Classic Part Number
2N-2139	Cone-Roller Brg	415-1911
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3P-1210	Cone-Roller Brg	399-4433
4E-2250	Housing	399-6043
4M-6107	Bearing-Roller	380-7507
5F-2465	Cup-Roller Brg	447-8060

ALA		
Original Part Number	Part Name	Classic Part Number
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-7936	Bearing-Outer	386-4953
5P-3930	Bearing As-Rlr	419-6022
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
6K-9070	Washer-Thrust	330-9294
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
7G-9555	Univ Joint As	314-8721
7J-5131	Trunnion	296-1371
7M-5334	Cone-Roller Brg	420-2505

Sales Model MT745 (Cont'd.)

ALA		
Original Part Number	**Part Name**	**Classic Part Number**
8T-0209	Race-Spl Rlr Brg	384-5951
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926

ALA		
Original Part Number	**Part Name**	**Classic Part Number**
030-0061	Bearing-Cone	418-9605
115-4072	Bearing	397-5069
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697

ALA		
Original Part Number	**Part Name**	**Classic Part Number**
176-3900	Accumulator	416-5513
190-0649	Tightener-Belt	434-1407
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659

Sales Model MT755

ALM		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2J-2152	Cup-Roller Brg	374-1852
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667

ALM		
Original Part Number	**Part Name**	**Classic Part Number**
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3P-1210	Cone-Roller Brg	399-4433
4E-2250	Housing	399-6043
4M-6107	Bearing-Roller	380-7507
4N-2514	Gear-Flywheel	421-7283
5F-2465	Cup-Roller Brg	447-8060
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-7936	Bearing-Outer	386-4953
5P-3930	Bearing As-Rlr	419-6022
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
6K-9070	Washer-Thrust	330-9294
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921

ALM		
Original Part Number	**Part Name**	**Classic Part Number**
6V-2202	Bearing-Spl Ball	380-1574
7G-9555	Univ Joint As	314-8721
7J-5131	Trunnion	296-1371
7M-5334	Cone-Roller Brg	420-2505
8T-0209	Race-Spl Rlr Brg	384-5951
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
115-4072	Bearing	397-5069
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
176-3900	Accumulator	416-5513
190-0649	Tightener-Belt	434-1407
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659

Sales Model MT765

AMS		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955

AMS		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2J-2152	Cup-Roller Brg	374-1852
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911

AMS		
Original Part Number	**Part Name**	**Classic Part Number**
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601

Sales Model MT765 (Cont'd.)

AMS		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
4E-2250	Housing	399-6043
4M-6107	Bearing-Roller	380-7507
5F-2465	Cup-Roller Brg	447-8060
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-7936	Bearing-Outer	386-4953
5P-3930	Bearing As-Rlr	419-6022
5P-6254	Bearing	420-2495

AMS		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
6K-9070	Washer-Thrust	330-9294
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
7G-9555	Univ Joint As	314-8721
7M-5334	Cone-Roller Brg	420-2505
8T-0209	Race-Spl Rlr Brg	384-5951
002-1212	Cup-Roller Brg	399-4446

AMS		
Original Part Number	Part Name	Classic Part Number
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
115-4072	Bearing	397-5069
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
176-3900	Accumulator	416-5513
190-0649	Tightener-Belt	434-1407
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659

Sales Model MT845

BBP		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2J-2152	Cup-Roller Brg	374-1852
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3P-1210	Cone-Roller Brg	399-4433
4E-2250	Housing	399-6043
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775

BBP		
Original Part Number	Part Name	Classic Part Number
5M-2051	Bearing-Caged	380-7467
5P-6254	Bearing	420-2495
6F-2956	Cup-Spl Tapered	420-6538
6K-9070	Washer-Thrust	330-9294
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-0347	Cone-Spl Tapered	420-6537
6V-3831	Seal-O-Ring	436-2657
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7J-1309	Bearing-Aligning	360-2275
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568
8D-2256	Cone-Roller Brg	374-1848
8H-9789	Bearing-Ball	374-8342
9K-1171	Cup-Rlr Bearing	430-3339
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646

BBP		
Original Part Number	Part Name	Classic Part Number
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
132-6597	Cone-Spl	422-6477
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
176-3900	Accumulator	416-5513
176-4168	Bridge As-Valve	419-4727

Sales Model MT845 (Cont'd.)

BBP		
Original Part Number	**Part Name**	**Classic Part Number**
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367

BBP		
Original Part Number	**Part Name**	**Classic Part Number**
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
289-2935	Seal As-Buffer	472-8028

BBP		
Original Part Number	**Part Name**	**Classic Part Number**
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2077	Pump Gp-Water -B	434-6108

Sales Model MT855

BCC		
Original Part Number	**Part Name**	**Classic Part Number**
1B-6577	Cone-Spl Tapered	374-1839
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3P-1210	Cone-Roller Brg	399-4433
4E-2250	Housing	399-6043
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333

BCC		
Original Part Number	**Part Name**	**Classic Part Number**
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5P-6254	Bearing	420-2495
6F-2956	Cup-Spl Tapered	420-6538
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6K-9070	Washer-Thrust	330-9294
6N-1931	Plunger	379-0171
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-0347	Cone-Spl Tapered	420-6537
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7J-1309	Bearing-Aligning	360-2275
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7W-3145	Plate	422-7894
8D-2256	Cone-Roller Brg	374-1848
8H-9789	Bearing-Ball	374-8342

BCC		
Original Part Number	**Part Name**	**Classic Part Number**
8S-6511	Bearing-Sleeve	380-7372
9K-1171	Cup-Rlr Bearing	430-3339
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054

Sales Model MT855 (Cont'd.)

BCC		
Original Part Number	Part Name	Classic Part Number
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368

BCC		
Original Part Number	Part Name	Classic Part Number
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

BCC		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
430-7619	Adapter-Cla	438-1812

Sales Model MT865

BDS		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3P-1210	Cone-Roller Brg	399-4433
4E-2250	Housing	399-6043
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

BDS		
Original Part Number	Part Name	Classic Part Number
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5P-6254	Bearing	420-2495
6F-2956	Cup-Spl Tapered	420-6538
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6K-9070	Washer-Thrust	330-9294
6N-1931	Plunger	379-0171
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-0347	Cone-Spl Tapered	420-6537
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-8926	Head Kt-Cyl	377-5847

BDS		
Original Part Number	Part Name	Classic Part Number
7F-2742	Bearing-Ball	422-6488
7J-1309	Bearing-Aligning	360-2275
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7W-3145	Plate	422-7894
8D-2256	Cone-Roller Brg	374-1848
8H-9789	Bearing-Ball	374-8342
8R-1693	Pin As	415-1906
8S-6511	Bearing-Sleeve	380-7372
9K-1171	Cup-Rlr Bearing	430-3339
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566

Sales Model MT865 (Cont'd.)

BDS		
Original Part Number	Part Name	Classic Part Number
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117

BDS		
Original Part Number	Part Name	Classic Part Number
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
246-3130	Shaft-Water Pump	392-4508

BDS		
Original Part Number	Part Name	Classic Part Number
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

Sales Model MTC735

812		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601

812		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4M-6107	Bearing-Roller	380-7507
5F-2465	Cup-Roller Brg	447-8060
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-7936	Bearing-Outer	386-4953
5P-3930	Bearing As-Rlr	419-6022
5P-6254	Bearing	420-2495
6K-9070	Washer-Thrust	330-9294
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-1033	Rod End-Spher	375-5444
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449

812		
Original Part Number	Part Name	Classic Part Number
7G-9555	Univ Joint As	314-8721
7M-5334	Cone-Roller Brg	420-2505
8T-0209	Race-Spl Rlr Brg	384-5951
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
176-3900	Accumulator	416-5513
190-0649	Tightener-Belt	434-1407

Sales Model MTC735 (Cont'd.)

812		
Original Part Number	Part Name	Classic Part Number
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024

812		
Original Part Number	Part Name	Classic Part Number
229-1490	Sleeve-Injector	393-3659
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

812		
Original Part Number	Part Name	Classic Part Number
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912

Sales Model MTC745

813		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667

813		
Original Part Number	Part Name	Classic Part Number
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3P-1210	Cone-Roller Brg	399-4433
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4M-6107	Bearing-Roller	380-7507
5F-2465	Cup-Roller Brg	447-8060
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-7936	Bearing-Outer	386-4953
5P-3930	Bearing As-Rlr	419-6022
5P-6254	Bearing	420-2495
6K-9070	Washer-Thrust	330-9294
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921

813		
Original Part Number	Part Name	Classic Part Number
6V-1033	Rod End-Spher	375-5444
7G-9555	Univ Joint As	314-8721
7M-5334	Cone-Roller Brg	420-2505
8T-0209	Race-Spl Rlr Brg	384-5951
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
115-4072	Bearing	397-5069
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
176-3900	Accumulator	416-5513
190-0649	Tightener-Belt	434-1407
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659

Sales Model MTC755

814		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

814		
Original Part Number	Part Name	Classic Part Number
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3D-9132	Cone-Roller Brg	453-3652

814		
Original Part Number	Part Name	Classic Part Number
3D-9133	Cup-Roller Brg	418-9601
3P-1210	Cone-Roller Brg	399-4433
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4M-6107	Bearing-Roller	380-7507
4N-1320	Gasket-Adapter	398-2928
5F-2465	Cup-Roller Brg	447-8060

Sales Model MTC755 (Cont'd.)

814		
Original Part Number	**Part Name**	**Classic Part Number**
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-7936	Bearing-Outer	386-4953
5P-3930	Bearing As-Rlr	419-6022
5P-6254	Bearing	420-2495
6K-9070	Washer-Thrust	330-9294
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921

814		
Original Part Number	**Part Name**	**Classic Part Number**
6V-1033	Rod End-Spher	375-5444
7G-9555	Univ Joint As	314-8721
7M-5334	Cone-Roller Brg	420-2505
8T-0209	Race-Spl Rlr Brg	384-5951
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926

814		
Original Part Number	**Part Name**	**Classic Part Number**
030-0061	Bearing-Cone	418-9605
115-4072	Bearing	397-5069
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
176-3900	Accumulator	416-5513
190-0649	Tightener-Belt	434-1407
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659

Sales Model MTC765

815		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2M-5685	Bearing-Needle	380-7469
2N-2139	Cone-Roller Brg	415-1911
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667

815		
Original Part Number	**Part Name**	**Classic Part Number**
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3P-1210	Cone-Roller Brg	399-4433
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4M-6107	Bearing-Roller	380-7507
5F-2465	Cup-Roller Brg	447-8060
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-7936	Bearing-Outer	386-4953
5P-3930	Bearing As-Rlr	419-6022
5P-6254	Bearing	420-2495
6K-9070	Washer-Thrust	330-9294
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921

815		
Original Part Number	**Part Name**	**Classic Part Number**
6V-1033	Rod End-Spher	375-5444
7G-9555	Univ Joint As	314-8721
7M-5334	Cone-Roller Brg	420-2505
8T-0209	Race-Spl Rlr Brg	384-5951
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
115-4072	Bearing	397-5069
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
176-3900	Accumulator	416-5513
190-0649	Tightener-Belt	434-1407
226-8202	Seal-Wiper	472-8024
229-1490	Sleeve-Injector	393-3659

Sales Model MTC835

816		
Original Part Number	**Part Name**	**Classic Part Number**
1B-6577	Cone-Spl Tapered	374-1839
1J-2860	Cup-Spl Tapered	374-8347

816		
Original Part Number	**Part Name**	**Classic Part Number**
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114

816		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

Sales Model MTC835 (Cont'd.)

816		
Original Part Number	**Part Name**	**Classic Part Number**
2J-2152	Cup-Roller Brg	374-1852
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3P-1210	Cone-Roller Brg	399-4433
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5P-6254	Bearing	420-2495
6F-2956	Cup-Spl Tapered	420-6538
6K-9070	Washer-Thrust	330-9294
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-0347	Cone-Spl Tapered	420-6537
6V-3831	Seal-O-Ring	436-2657
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697

816		
Original Part Number	**Part Name**	**Classic Part Number**
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7J-1309	Bearing-Aligning	360-2275
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568
8D-2256	Cone-Roller Brg	374-1848
8H-9789	Bearing-Ball	374-8342
9K-1171	Cup-Rlr Bearing	430-3339
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446

816		
Original Part Number	**Part Name**	**Classic Part Number**
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
132-6597	Cone-Spl	422-6477
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
176-3900	Accumulator	416-5513
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2077	Pump Gp-Water -B	434-6108

Sales Model MTC845

817		
Original Part Number	**Part Name**	**Classic Part Number**
1B-6577	Cone-Spl Tapered	374-1839
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174

817		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2J-2152	Cup-Roller Brg	374-1852
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3P-1210	Cone-Roller Brg	399-4433
4D-2619	Bearing	417-4494

817		
Original Part Number	**Part Name**	**Classic Part Number**
4E-2250	Housing	399-6043
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467

Sales Model MTC845 (Cont'd.)

817		
Original Part Number	**Part Name**	**Classic Part Number**
5P-6254	Bearing	420-2495
6F-2956	Cup-Spl Tapered	420-6538
6K-9070	Washer-Thrust	330-9294
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-0347	Cone-Spl Tapered	420-6537
6V-3831	Seal-O-Ring	436-2657
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7J-1309	Bearing-Aligning	360-2275
7N-7435	Kit-Major Repair	374-4724
7W-5164	Gasket	420-8568
8D-2256	Cone-Roller Brg	374-1848
8H-9789	Bearing-Ball	374-8342
9K-1171	Cup-Rlr Bearing	430-3339

817		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
132-6597	Cone-Spl	422-6477
144-0502	Ring Kit-Piston	395-1312

817		
Original Part Number	**Part Name**	**Classic Part Number**
144-0503	Piston & Ring Kt	380-1554
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
176-3900	Accumulator	416-5513
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
216-4781	Gasket Kit	437-8144
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2077	Pump Gp-Water -B	434-6108

Sales Model MTC855

818		
Original Part Number	**Part Name**	**Classic Part Number**
1B-6577	Cone-Spl Tapered	374-1839
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2J-2152	Cup-Roller Brg	374-1852

818		
Original Part Number	**Part Name**	**Classic Part Number**
2L-5271	Bearing-Ball	371-4305
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3P-1210	Cone-Roller Brg	399-4433
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

818		
Original Part Number	**Part Name**	**Classic Part Number**
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5P-6254	Bearing	420-2495
6F-2956	Cup-Spl Tapered	420-6538
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6K-9070	Washer-Thrust	330-9294
6N-1931	Plunger	379-0171

Sales Model MTC855 (Cont'd.)

818		
Original Part Number	Part Name	Classic Part Number
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-0347	Cone-Spl Tapered	420-6537
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7J-1309	Bearing-Aligning	360-2275
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724
7W-3145	Plate	422-7894
8D-2256	Cone-Roller Brg	374-1848
8H-9789	Bearing-Ball	374-8342
8S-6511	Bearing-Sleeve	380-7372
9K-1171	Cup-Rlr Bearing	430-3339
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868

818		
Original Part Number	Part Name	Classic Part Number
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048

818		
Original Part Number	Part Name	Classic Part Number
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

Sales Model MTC865

819		
Original Part Number	Part Name	Classic Part Number
1B-6577	Cone-Spl Tapered	374-1839
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1W-7238	Shaft As-Pump Dr	379-0164

819		
Original Part Number	Part Name	Classic Part Number
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305
3D-9132	Cone-Roller Brg	453-3652

819		
Original Part Number	Part Name	Classic Part Number
3D-9133	Cup-Roller Brg	418-9601
3E-6772	Seal-Water	382-8017
3P-1210	Cone-Roller Brg	399-4433
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4N-2514	Gear-Flywheel	421-7283
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812

Sales Model MTC865 (Cont'd.)

819		
Original Part Number	**Part Name**	**Classic Part Number**
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5P-6254	Bearing	420-2495
6F-2956	Cup-Spl Tapered	420-6538
6I-2726	Bearing-Sleeve	419-4757
6I-3907	Adapter-Pilot	398-8348
6K-9070	Washer-Thrust	330-9294
6N-1931	Plunger	379-0171
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-0347	Cone-Spl Tapered	420-6537
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5816	Shaft-Fan	399-8552
7E-8830	Bracket As-Fan	383-3697
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7J-1309	Bearing-Aligning	360-2275
7N-2156	Bearing-Sleeve	380-7373
7N-7435	Kit-Major Repair	374-4724

819		
Original Part Number	**Part Name**	**Classic Part Number**
7W-3145	Plate	422-7894
8D-2256	Cone-Roller Brg	374-1848
8H-9789	Bearing-Ball	374-8342
8S-6511	Bearing-Sleeve	380-7372
9K-1171	Cup-Rlr Bearing	430-3339
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
101-9640	Gear-Air Compr	398-2966
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
108-7930	Bearing As	377-7463
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035

819		
Original Part Number	**Part Name**	**Classic Part Number**
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
166-6352	Tube As.	432-4223
167-8126	Damper As	382-8019
170-4860	Bonnet-Oil Clr	430-5359
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
256-9653	Flywheel As.	425-3444
278-1365	Arm As-Ui Rkr	433-7507
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

Sales Model R2

04J		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8736	Cup-Roller Brg	423-7759

Sales Model R2 (Cont'd.)

04J		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
2F-5721	Bearing-Ball	311-9354

04J		
Original Part Number	Part Name	Classic Part Number
3B-6217	Muffler As	247-2671
3L-1425	Bearing-Ball	311-9356

04J		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8H-9789	Bearing-Ball	374-8342

05E		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1B-3922	Cup-Roller Brg	416-2158
2H-3712	Bearing-Ball	392-4488

05E		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
8H-9789	Bearing-Ball	374-8342

05E		
Original Part Number	Part Name	Classic Part Number
9L-2685	Rod End	419-1866
108-5603	Screw-Adj Arm	379-0166

06J		
Original Part Number	Part Name	Classic Part Number
1M-8736	Cup-Roller Brg	423-7759
1T-0043	Bearing-Ball	390-5294
2F-5721	Bearing-Ball	311-9354

06J		
Original Part Number	Part Name	Classic Part Number
3B-6217	Muffler As	247-2671
3L-1425	Bearing-Ball	311-9356

06J		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8H-9789	Bearing-Ball	374-8342

Sales Model R4

06G		
Original Part Number	Part Name	Classic Part Number
1B-3924	Cone-Roller Brg	422-6482
1B-4102	Bearing-Ball	399-4426
1M-8736	Cup-Roller Brg	423-7759
1T-0210	Bearing-Ball	417-4498
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2H-6936	Disc-Steer Cl Dr	380-7471
2L-5271	Bearing-Ball	371-4305
2M-1086	Plate As-Press	226-8023
3B-3967	Race-Roller Brg	386-4947

06G		
Original Part Number	Part Name	Classic Part Number
3B-6217	Muffler As	247-2671
3H-1996	Bearing-Ball	380-1498
3L-1425	Bearing-Ball	311-9356
4B-7270	Cone-Bearing	399-4439
5F-8651	Bearing-Ball	420-3223
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6W-0240	Bearing-Brace	297-7143

06G		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
8B-5972	Bearing-Ball	314-8503
8H-1174	Drum-Ster Cl Dr	226-6101
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9L-2685	Rod End	419-1866
108-5603	Screw-Adj Arm	379-0166
231-1937	Kit-Strg Cl-Cla	226-6101

Sales Model R5

03R		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-4043	Cone-Roller Brg	377-7395
1B-4102	Bearing-Ball	399-4426
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2H-3712	Bearing-Ball	392-4488

03R		
Original Part Number	**Part Name**	**Classic Part Number**
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-8845	Bearing-Inner	417-4509
3H-0881	Ring-Piston	465-8998
3H-1996	Bearing-Ball	380-1498
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4N-3875	Ring-Piston	465-8997
5H-7071	Director-Water	388-0555
6H-3957	Bearing-Ball	311-9358

03R		
Original Part Number	**Part Name**	**Classic Part Number**
7M-1154	Bearing-Spl	417-4515
7M-4926	Retainer-Piston	314-8538
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-8523	Bearing-Sleeve	383-3701
8M-8068	Bearing-Spl Ball	417-4500
9B-0399	Link As-Cl Drive	431-5268
9L-2685	Rod End	419-1866
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

04H		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-4043	Cone-Roller Brg	377-7395
1B-4102	Bearing-Ball	399-4426
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2H-3712	Bearing-Ball	392-4488

04H		
Original Part Number	**Part Name**	**Classic Part Number**
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-8845	Bearing-Inner	417-4509
3H-0881	Ring-Piston	465-8998
3H-1996	Bearing-Ball	380-1498
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4N-3875	Ring-Piston	465-8997
5H-7071	Director-Water	388-0555
6H-3957	Bearing-Ball	311-9358

04H		
Original Part Number	**Part Name**	**Classic Part Number**
7M-1154	Bearing-Spl	417-4515
7M-4926	Retainer-Piston	314-8538
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-8523	Bearing-Sleeve	383-3701
8M-8068	Bearing-Spl Ball	417-4500
9B-0399	Link As-Cl Drive	431-5268
9L-2685	Rod End	419-1866
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

05E		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-4043	Cone-Roller Brg	377-7395

05E		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4102	Bearing-Ball	399-4426
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2H-3712	Bearing-Ball	392-4488
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099

05E		
Original Part Number	**Part Name**	**Classic Part Number**
3B-8845	Bearing-Inner	417-4509
3H-0881	Ring-Piston	465-8998
3H-1996	Bearing-Ball	380-1498
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4N-3875	Ring-Piston	465-8997

Sales Model R5 (Cont'd.)

05E		
Original Part Number	Part Name	Classic Part Number
5H-7071	Director-Water	388-0555
6H-3957	Bearing-Ball	311-9358
7M-1154	Bearing-Spl	417-4515
7M-4926	Retainer-Piston	314-8538

05E		
Original Part Number	Part Name	Classic Part Number
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-8523	Bearing-Sleeve	383-3701
8M-8068	Bearing-Spl Ball	417-4500

05E		
Original Part Number	Part Name	Classic Part Number
9B-0399	Link As-Cl Drive	431-5268
9L-2685	Rod End	419-1866
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166

Sales Model RD4

02T		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1B-4102	Bearing-Ball	399-4426
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2H-6936	Disc-Steer Cl Dr	380-7471
2L-5271	Bearing-Ball	371-4305
2M-1086	Plate As-Press	226-8023
2S-4015	Plunger As-Valve	311-9438
3B-3967	Race-Roller Brg	386-4947

02T		
Original Part Number	Part Name	Classic Part Number
3B-6217	Muffler As	247-2671
3H-1996	Bearing-Ball	380-1498
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6W-0240	Bearing-Brace	297-7143
7H-6967	Bearing-Ball	422-6489

02T		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8H-1174	Drum-Ster Cl Dr	226-6101
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9W-1677	Bearing	297-7145
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
160-6306	Cap-Bearing	325-6038
231-1937	Kit-Strg Cl-Cla	226-6101

04G		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1B-4102	Bearing-Ball	399-4426
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488

04G		
Original Part Number	Part Name	Classic Part Number
2H-6936	Disc-Steer Cl Dr	380-7471
2L-5271	Bearing-Ball	371-4305
2M-1086	Plate As-Press	226-8023
2S-4015	Plunger As-Valve	311-9438
3B-3967	Race-Roller Brg	386-4947
3B-6217	Muffler As	247-2671
3H-1996	Bearing-Ball	380-1498
3L-1425	Bearing-Ball	311-9356

04G		
Original Part Number	Part Name	Classic Part Number
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358

Sales Model RD4 (Cont'd.)

04G		
Original Part Number	**Part Name**	**Classic Part Number**
6I-8860	Cup-Roller Brg	380-7495
6W-0240	Bearing-Brace	297-7143
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8H-1174	Drum-Ster Cl Dr	226-6101

04G		
Original Part Number	**Part Name**	**Classic Part Number**
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9W-1677	Bearing	297-7145
108-5603	Screw-Adj Arm	379-0166

04G		
Original Part Number	**Part Name**	**Classic Part Number**
121-7746	Pre-Cleaner As	360-2311
160-6306	Cap-Bearing	325-6038
231-1937	Kit-Strg Cl-Cla	226-6101

05T		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1B-4102	Bearing-Ball	399-4426
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2H-6936	Disc-Steer Cl Dr	380-7471
2L-5271	Bearing-Ball	371-4305
2M-1086	Plate As-Press	226-8023
2S-4015	Plunger As-Valve	311-9438
3B-3967	Race-Roller Brg	386-4947

05T		
Original Part Number	**Part Name**	**Classic Part Number**
3B-6217	Muffler As	247-2671
3H-1996	Bearing-Ball	380-1498
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6W-0240	Bearing-Brace	297-7143
7H-6967	Bearing-Ball	422-6489

05T		
Original Part Number	**Part Name**	**Classic Part Number**
7L-7508	Bearing-Ball	420-6536
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8H-1174	Drum-Ster Cl Dr	226-6101
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9W-1677	Bearing	297-7145
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
160-6306	Cap-Bearing	325-6038
231-1937	Kit-Strg Cl-Cla	226-6101

07J		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1B-4102	Bearing-Ball	399-4426
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-8824	Drum	216-7817
2D-5658	Bearing-Ball	301-4628
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2H-6936	Disc-Steer Cl Dr	380-7471

07J		
Original Part Number	**Part Name**	**Classic Part Number**
2L-5271	Bearing-Ball	371-4305
2M-1086	Plate As-Press	226-8023
2S-4015	Plunger As-Valve	311-9438
3B-3967	Race-Roller Brg	386-4947
3B-6217	Muffler As	247-2671
3H-1996	Bearing-Ball	380-1498
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4B-7270	Cone-Bearing	399-4439
5F-8651	Bearing-Ball	420-3223

07J		
Original Part Number	**Part Name**	**Classic Part Number**
5H-7071	Director-Water	388-0555
5K-2754	Spring-Recoil	418-1956
5K-8591	Bearing-Outer	380-7502
6B-3223	Cup-Bearing	399-6065
6B-6224	Ferrule	419-4738
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6I-8860	Cup-Roller Brg	380-7495
6W-0240	Bearing-Brace	297-7143
7H-6967	Bearing-Ball	422-6489
7L-7508	Bearing-Ball	420-6536

Sales Model RD4 (Cont'd.)

07J		
Original Part Number	Part Name	Classic Part Number
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8H-1174	Drum-Ster Cl Dr	226-6101
8H-4320	Bearing-Ball	419-2301

07J		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9W-1677	Bearing	297-7145

07J		
Original Part Number	Part Name	Classic Part Number
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
160-6306	Cap-Bearing	325-6038
231-1937	Kit-Strg Cl-Cla	226-6101

Sales Model RD6

02H		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-4043	Cone-Roller Brg	377-7395
1B-4102	Bearing-Ball	399-4426
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2H-3712	Bearing-Ball	392-4488
2S-4015	Plunger As-Valve	311-9438

02H		
Original Part Number	Part Name	Classic Part Number
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3B-8845	Bearing-Inner	417-4509
3H-0881	Ring-Piston	465-8998
3H-1996	Bearing-Ball	380-1498
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4N-3875	Ring-Piston	465-8997
5H-7071	Director-Water	388-0555
6H-3957	Bearing-Ball	311-9358

02H		
Original Part Number	Part Name	Classic Part Number
7M-1154	Bearing-Spl	417-4515
7M-4926	Retainer-Piston	314-8538
7N-9352	Gasket	433-8188
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-8523	Bearing-Sleeve	383-3701
8H-4320	Bearing-Ball	419-2301
8M-8068	Bearing-Spl Ball	417-4500
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
9Y-9431	Precleaner As	361-1718

05E		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-4043	Cone-Roller Brg	377-7395
1B-4102	Bearing-Ball	399-4426
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2H-3712	Bearing-Ball	392-4488
2S-4015	Plunger As-Valve	311-9438

05E		
Original Part Number	Part Name	Classic Part Number
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3B-8845	Bearing-Inner	417-4509
3H-0881	Ring-Piston	465-8998
3H-1996	Bearing-Ball	380-1498
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4N-3875	Ring-Piston	465-8997
5H-7071	Director-Water	388-0555
6H-3957	Bearing-Ball	311-9358

05E		
Original Part Number	Part Name	Classic Part Number
7M-1154	Bearing-Spl	417-4515
7M-4926	Retainer-Piston	314-8538
7N-9352	Gasket	433-8188
7W-2731	Retainer	423-3541
8B-5972	Bearing-Ball	314-8503
8F-8523	Bearing-Sleeve	383-3701
8H-4320	Bearing-Ball	419-2301
8M-8068	Bearing-Spl Ball	417-4500
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
9Y-9431	Precleaner As	361-1718

Sales Model RD8

01H		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-6577	Cone-Spl Tapered	374-1839
1J-0774	Bracket	369-9485
1L-7205	Bearing-Ball	416-2167
1M-7250	Bowl	360-2296
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3H-0881	Ring-Piston	465-8998

01H		
Original Part Number	**Part Name**	**Classic Part Number**
3H-1996	Bearing-Ball	380-1498
3K-3124	Muffler-Trap	247-2673
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-5003	Spring As-Arm	383-2127
4J-1999	Ballstud	314-8625
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5F-7993	Pin	319-3454
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6F-2904	Bearing	295-5673
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6T-8886	Disc-Ster Cl	380-7517
6Y-7652	Cup-Rlr Brg	399-6067
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7K-5448	Cup-Bearing	415-1922
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538

01H		
Original Part Number	**Part Name**	**Classic Part Number**
7N-4170	Pump Gp-Eng Oil	379-0169
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7T-0204	Bearing-Brace	247-4126
7W-2731	Retainer	423-3541
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8F-3170	Bearing-Roller	417-4504
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
8H-2434	Drum-Ster Cl Dr	216-7862
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8S-3517	Bearing-Spl Ball	417-4501
9F-3358	Link As-Cl Drive	394-0207
9F-7101	Bushing-Collar	299-1988
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311
160-6305	Cap-Bearing	295-5686

02U		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-6577	Cone-Spl Tapered	374-1839
1J-0774	Bracket	369-9485
1L-7205	Bearing-Ball	416-2167
1M-7250	Bowl	360-2296

02U		
Original Part Number	**Part Name**	**Classic Part Number**
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099

02U		
Original Part Number	**Part Name**	**Classic Part Number**
3B-6218	Muffler As	247-2672
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3H-0881	Ring-Piston	465-8998
3H-1996	Bearing-Ball	380-1498
3K-3124	Muffler-Trap	247-2673
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-5003	Spring As-Arm	383-2127
4J-1999	Ballstud	314-8625
4M-9183	Bearing-Sleeve	386-4924

Sales Model RD8 (Cont'd.)

02U		
Original Part Number	Part Name	Classic Part Number
4N-3875	Ring-Piston	465-8997
5F-7993	Pin	319-3454
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6F-2904	Bearing	295-5673
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6T-8886	Disc-Ster Cl	380-7517
6Y-7652	Cup-Rlr Brg	399-6067
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414

02U		
Original Part Number	Part Name	Classic Part Number
7K-5448	Cup-Bearing	415-1922
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
7N-4170	Pump Gp-Eng Oil	379-0169
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7T-0204	Bearing-Brace	247-4126
7W-2731	Retainer	423-3541
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8F-3170	Bearing-Roller	417-4504
8F-8523	Bearing-Sleeve	383-3701

02U		
Original Part Number	Part Name	Classic Part Number
8H-1994	Valve-Exhaust	443-1206
8H-2434	Drum-Ster Cl Dr	216-7862
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8S-3517	Bearing-Spl Ball	417-4501
9F-3358	Link As-Cl Drive	394-0207
9F-7101	Bushing-Collar	299-1988
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311
160-6305	Cap-Bearing	295-5686

05E		
Original Part Number	Part Name	Classic Part Number
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-6577	Cone-Spl Tapered	374-1839
1J-0774	Bracket	369-9485
1L-7205	Bearing-Ball	416-2167
1M-7250	Bowl	360-2296
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672

05E		
Original Part Number	Part Name	Classic Part Number
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3H-0881	Ring-Piston	465-8998
3H-1996	Bearing-Ball	380-1498
3K-3124	Muffler-Trap	247-2673
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-5003	Spring As-Arm	383-2127
4J-1999	Ballstud	314-8625
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5F-7993	Pin	319-3454
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6F-2904	Bearing	295-5673
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6T-8886	Disc-Ster Cl	380-7517
6Y-7652	Cup-Rlr Brg	399-6067
7F-9541	Pin As-Drawbar	296-1361

05E		
Original Part Number	Part Name	Classic Part Number
7F-9547	Pin As.-Drawbar	295-0414
7K-5448	Cup-Bearing	415-1922
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538
7N-4170	Pump Gp-Eng Oil	379-0169
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7T-0204	Bearing-Brace	247-4126
7W-2731	Retainer	423-3541
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8F-3170	Bearing-Roller	417-4504
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
8H-2434	Drum-Ster Cl Dr	216-7862
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8S-3517	Bearing-Spl Ball	417-4501

Sales Model RD8 (Cont'd.)

05E		
Original Part Number	**Part Name**	**Classic Part Number**
9F-3358	Link As-Cl Drive	394-0207
9F-7101	Bushing-Collar	299-1988

05E		
Original Part Number	**Part Name**	**Classic Part Number**
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950

05E		
Original Part Number	**Part Name**	**Classic Part Number**
121-7746	Pre-Cleaner As	360-2311
160-6305	Cap-Bearing	295-5686

08R		
Original Part Number	**Part Name**	**Classic Part Number**
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-6577	Cone-Spl Tapered	374-1839
1J-0774	Bracket	369-9485
1L-7205	Bearing-Ball	416-2167
1M-7250	Bowl	360-2296
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2H-3712	Bearing-Ball	392-4488
2L-5271	Bearing-Ball	371-4305
2S-4015	Plunger As-Valve	311-9438
3B-1142	Retainer-Spring	391-1099
3B-6218	Muffler As	247-2672
3B-8845	Bearing-Inner	417-4509
3F-4971	Pin	295-5693
3H-0881	Ring-Piston	465-8998

08R		
Original Part Number	**Part Name**	**Classic Part Number**
3H-1996	Bearing-Ball	380-1498
3K-3124	Muffler-Trap	247-2673
4B-1455	Cap As-Filler	361-1719
4F-2041	Cup-Roller Brg	418-9609
4F-5003	Spring As-Arm	383-2127
4J-1999	Ballstud	314-8625
4M-9183	Bearing-Sleeve	386-4924
4N-3875	Ring-Piston	465-8997
5F-7993	Pin	319-3454
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
6B-6224	Ferrule	419-4738
6F-2904	Bearing	295-5673
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6T-8886	Disc-Ster Cl	380-7517
6Y-7652	Cup-Rlr Brg	399-6067
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7K-5448	Cup-Bearing	415-1922
7L-7508	Bearing-Ball	420-6536
7M-4926	Retainer-Piston	314-8538

08R		
Original Part Number	**Part Name**	**Classic Part Number**
7N-4170	Pump Gp-Eng Oil	379-0169
7N-9352	Gasket	433-8188
7S-7809	Cap As-Radiator	295-6417
7T-0204	Bearing-Brace	247-4126
7W-2731	Retainer	423-3541
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8F-3170	Bearing-Roller	417-4504
8F-8523	Bearing-Sleeve	383-3701
8H-1994	Valve-Exhaust	443-1206
8H-2434	Drum-Ster Cl Dr	216-7862
8H-4320	Bearing-Ball	419-2301
8H-9789	Bearing-Ball	374-8342
8S-3517	Bearing-Spl Ball	417-4501
9F-3358	Link As-Cl Drive	394-0207
9F-7101	Bushing-Collar	299-1988
9H-6236	Rod As	390-0999
9L-2685	Rod End	419-1866
9S-7534	Pipe-Exh Ext	398-2950
121-7746	Pre-Cleaner As	360-2311
160-6305	Cap-Bearing	295-5686

Sales Model SEM816

S8D		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9931	Mount As.	360-2354

Sales Model SEM822

S8G		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9931	Mount As.	360-2354

Sales Model 814B

16Z		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-2936	Muffler As	298-2782
1N-2946	Extension-Exh	367-6064
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-1997	Rod As	419-4652
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5910	Tappet As-Guide&	383-1569
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163

16Z		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9171	Bonnet-Valve	374-4707
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5709	Shaft-Axle	299-2056
2V-5714	Gear-Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356

16Z		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7455	Gear As	396-9957
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-7933	Core As-O Clr	374-4708
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3E-6772	Seal-Water	382-8017
3G-9891	Pump Gp-Gr A	399-8541
3J-2443	Bearing	383-2125
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
3V-0593	Rim As	418-9568
4E-3456	Lever As	367-6081
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4J-6167	Bearing-Sleeve	325-6009
4J-7650	Retainer As	440-0851
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500

Sales Model 814B (Cont'd.)

16Z		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4N-7693	Crankshaft As	269-8763
4P-2383	Adapter-Inlet	438-1812
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-6869	Cartridge Gp	422-8104
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5213	Spindle	299-2060

16Z		
Original Part Number	**Part Name**	**Classic Part Number**
4V-5388	Shaft-Bev Pinion	297-7244
4V-5392	Spider	377-7430
4V-5393	Gear-Bevel	297-7189
4V-5394	Gear-Diff	297-7177
4V-5400	Housing-Brg Spt	385-7202
4V-7082	Joint Gp-Slip	367-6068
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5053	Muffler As	360-7881
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-6869	Spacer-Fuel Pump	417-4534
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5F-7993	Pin	319-3454
5G-3612	Cap Gp-Protn	295-6419
5K-3493	Cover	391-9814
5K-3495	Collar	383-2129
5K-8591	Bearing-Outer	380-7502
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5L-6326	Bearing-Ball	420-3222
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507

16Z		
Original Part Number	**Part Name**	**Classic Part Number**
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-0775	Head	425-9373
6E-5028	Rod As	425-9372
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1453	Crankshaft As	368-5916
6I-2408	Muffler As.	378-3978
6I-2409	Pipe	383-3693
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436

Sales Model 814B (Cont'd.)

16Z		
Original Part Number	Part Name	Classic Part Number
6I-8510	Housing As - Clu	373-5387
6J-3999	Connector	428-7631
6J-6604	Pin	419-6071
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1931	Plunger	379-0171
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7653	Gage As-O Level	428-7206
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1690	Carrier-Ring	384-3849
6Y-3151	Stator-Converter	388-6562
6Y-4819	Carrier-Planet	296-1348
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5851	Muffler As	298-2790
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222

16Z		
Original Part Number	Part Name	Classic Part Number
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7T-3370	Yoke As	302-2702
7T-4753	Stator-Converter	384-5945
7T-8816	Bearing-Spl Ball	420-2491

16Z		
Original Part Number	Part Name	Classic Part Number
7T-9370	Gear-Sun	283-5207
7W-0140	Gear-Drive	399-8546
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-5733	Gasket	421-7333
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8555	Gasket Kit	434-7278
8F-3170	Bearing-Roller	417-4504
8F-6058	Bearing-Sleeve	416-5494
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-7978	Bearing-Spher	388-0581
8N-0703	Bearing-Sleeve	472-8037
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1726	Rod As-Conn	379-8866
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842

Sales Model 814B (Cont'd.)

16Z		
Original Part Number	**Part Name**	**Classic Part Number**
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8258	Bearing-Sleeve	452-1077
8P-0953	Turbine-Conv	297-7269
8P-0961	Impeller-Conv	433-9204
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416

16Z		
Original Part Number	**Part Name**	**Classic Part Number**
8T-0072	Cone-Rlr Brg	377-7448
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-6390	Drum-Brake	377-7449
8V-7659	Pin As	361-1702
8V-7885	Housing-Support	297-7193
9C-4007	Bearing-Sleeve	374-1459
9C-4080	Yoke-Brake	302-2703
9C-5852	Hub As	297-7208
9C-6015	Pinion-Diff Bev	297-7225
9C-8218	Shaft-Bev Pinion	302-2697
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-5836	Coupling-Exhaust	385-7212
9L-5839	Coupling-Exhaust	374-7480
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-5477	Bearing-Sleeve	374-6517
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219

16Z		
Original Part Number	**Part Name**	**Classic Part Number**
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5160	Plunger Kt-Adj	385-7218
9V-5174	Joint Gp-Univ	375-2628
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-7860	Valve-Inlet	270-4360
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8608	Manifold-Exhaust	376-9062
103-5961	Wheel	398-2963

Sales Model 814B (Cont'd.)

16Z		
Original Part Number	Part Name	Classic Part Number
104-5283	Manifold-Exhaust	394-9831
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
119-5727	Bearing-Spl Ball	417-9491
126-2522	Cone-Spl Tapered	377-7397
127-5537	Core As-Oclr	325-6045
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
136-7813	Bearing-Race	460-8296
139-9175	Gasket Kit	377-7464
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
155-5619	Gasket	382-5054
158-1438	Kit-Dt Gasket	434-7276
159-3021	Gasket	377-5845
160-1400	Yoke (1710)	319-3479
160-6305	Cap-Bearing	295-5686

16Z		
Original Part Number	Part Name	Classic Part Number
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
166-9142	Gasket	420-8546
167-8123	Damper As	299-2006
167-8126	Damper As	382-8019
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0560	Rebuild Kit-Pump	363-7458
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700

16Z		
Original Part Number	Part Name	Classic Part Number
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
211-0592	Bearing - Main	419-6368
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
216-7957	U-Joint	367-6069
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
234-8002	Kit-Gasket-Sch	386-3817
250-6558	Liner Kit-Cla	295-6438
253-1752	Plate-Thrust	379-0170
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
343-4836	Mount As	424-6369
391-8229	Kit-Gasket-Fs	398-2955

Wheel Dozers

Sales Model 814B (Cont'd.)

16Z		
Original Part Number	**Part Name**	**Classic Part Number**
391-8256	Kit-Gasket (Sch)	447-8653

16Z		
Original Part Number	**Part Name**	**Classic Part Number**
430-7619	Adapter-Cla	438-1812

16Z		
Original Part Number	**Part Name**	**Classic Part Number**
443-1200	Brg-Rlr-Cla	377-7397

Sales Model 814F

9DM		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2F-5721	Bearing-Ball	311-9354
2K-5065	Cone-Roller Brg	416-2157
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2M-1149	Race-Brg Outer	418-9615
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

9DM		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3H-8726	Mount As	385-7208
3J-2443	Bearing	383-2125
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-4384	Housing As-Cl	435-2573
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-8535	Retainer-Seal	300-2589
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370

9DM		
Original Part Number	**Part Name**	**Classic Part Number**
4J-6167	Bearing-Sleeve	325-6009
4J-7650	Retainer As	440-0851
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7270	Support-Trunnion	373-5384
4K-7467	Bearing As-Rlr	380-1500
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0897	Core As-Radiator	376-9058
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-6869	Cartridge Gp	422-8104
4T-8054	Seal As	472-8010

Sales Model 814F (Cont'd.)

9DM		
Original Part Number	Part Name	Classic Part Number
4V-0015	Plate-Lock	282-6563
4V-5099	Cover	418-1929
4V-5392	Spider	377-7430
4V-7082	Joint Gp-Slip	367-6068
4W-0452	Seal As -Cshaft	325-6191
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5F-7993	Pin	319-3454
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6C-3617	Support-Trunnion	374-4712
6E-0775	Head	425-9373
6E-5028	Rod As	425-9372
6H-3957	Bearing-Ball	311-9358
6I-1240	Governor As	380-7538

9DM		
Original Part Number	Part Name	Classic Part Number
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-2408	Muffler As.	378-3978
6I-2409	Pipe	383-3693
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-3999	Connector	428-7631
6J-6604	Pin	419-6071
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-3151	Stator-Converter	388-6562
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3557	Spider As-Fan	430-4471
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-1334	Bearing-Sleeve	325-6015
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7M-4046	Bearing-Sleeve	394-8206
7M-5334	Cone-Roller Brg	420-2505
7M-7219	Bearing-Thrust	384-4816

9DM		
Original Part Number	Part Name	Classic Part Number
7N-0110	Core As-Oil Clr	319-3435
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5699	Pulley-Cshaft	378-3988
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-7569	Case-Xmsn	394-0899
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-7978	Bearing-Spher	388-0581
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207

Sales Model 814F (Cont'd.)

9DM		
Original Part Number	**Part Name**	**Classic Part Number**
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8R-0931	Housing-Pinion	302-4300
8R-0942	Plate-Reaction	380-1484
8R-1015	Support-Trunnion	374-4712
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-3252	Shaft-Planet	297-7259
8R-6213	Mount As	389-6301
8R-8335	Gear-Bevel	368-0105
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416

9DM		
Original Part Number	**Part Name**	**Classic Part Number**
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-7659	Pin As	361-1702
9C-4080	Yoke-Brake	302-2703
9C-6029	Bearing-Planet	375-9982
9C-8669	Shaft-Bev Pinion	368-0107
9C-9191	Trunnion	302-2701
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7412	Gear As-Pump	297-7183
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-2787	Gear-Planet	367-6093
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5174	Joint Gp-Univ	375-2628
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
9Y-3318	Core As-Radiator	374-7491
100-3596	Piston	380-1511
100-3597	Plate-Reaction	380-1501

9DM		
Original Part Number	**Part Name**	**Classic Part Number**
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
110-1488	Gear-Ring	394-0882
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
119-5727	Bearing-Spl Ball	417-9491
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
134-3036	Gasket Kit	393-3629
134-3038	Gasket Kit	437-3228
135-7989	Gasket Kit	393-3633
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
148-9288	Case As-Diff	380-1496
151-4836	Diff Gp -A	416-2120
158-1439	Kit-Dt Gasket	434-7290
160-1400	Yoke (1710)	319-3479
160-6305	Cap-Bearing	295-5686
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574

Sales Model 814F (Cont'd.)

9DM		
Original Part Number	**Part Name**	**Classic Part Number**
172-7765	Pump Gp-Water -B	394-9835
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
216-7957	U-Joint	367-6069
226-8202	Seal-Wiper	472-8024

9DM		
Original Part Number	**Part Name**	**Classic Part Number**
228-0419	Seal As	443-3571
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989

9DM		
Original Part Number	**Part Name**	**Classic Part Number**
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-1032	Disc-Friction	440-3116
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

BGF		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2K-5065	Cone-Roller Brg	416-2157
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2M-1149	Race-Brg Outer	418-9615
2P-8986	Cup-Rlr Bearing	415-1912
3H-8726	Mount As	385-7208
3J-2443	Bearing	383-2125
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-8535	Retainer-Seal	300-2589
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4J-6167	Bearing-Sleeve	325-6009
4J-7650	Retainer As	440-0851
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7270	Support-Trunnion	373-5384

BGF		
Original Part Number	**Part Name**	**Classic Part Number**
4K-7467	Bearing As-Rlr	380-1500
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4T-6869	Cartridge Gp	422-8104
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4V-5099	Cover	418-1929
4V-5392	Spider	377-7430
4V-7082	Joint Gp-Slip	367-6068
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5F-7993	Pin	319-3454
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6E-0775	Head	425-9373
6E-5028	Rod As	425-9372

BGF		
Original Part Number	**Part Name**	**Classic Part Number**
6I-8510	Housing As - Clu	373-5387
6J-3999	Connector	428-7631
6J-6604	Pin	419-6071
6N-5978	Coupling-Exhaust	369-9487
6P-7704	Carrier-Ring	314-8658
6V-3831	Seal-O-Ring	436-2657
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-3151	Stator-Converter	388-6562
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5816	Shaft-Fan	399-8552
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-1334	Bearing-Sleeve	325-6015
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7M-5334	Cone-Roller Brg	420-2505
7M-7219	Bearing-Thrust	384-4816
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207

Sales Model 814F (Cont'd.)

BGF		
Original Part Number	**Part Name**	**Classic Part Number**
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8F-3170	Bearing-Roller	417-4504
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8J-7978	Bearing-Spher	388-0581
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-0931	Housing-Pinion	302-4300
8R-0942	Plate-Reaction	380-1484
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-3252	Shaft-Planet	297-7259
8R-8335	Gear-Bevel	368-0105
8V-7659	Pin As	361-1702
9C-4080	Yoke-Brake	302-2703
9C-6029	Bearing-Planet	375-9982
9C-8669	Shaft-Bev Pinion	368-0107
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719

BGF		
Original Part Number	**Part Name**	**Classic Part Number**
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9U-2787	Gear-Planet	367-6093
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5174	Joint Gp-Univ	375-2628
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-8437	Gear-Sun	450-7550
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
100-3596	Piston	380-1511
100-3597	Plate-Reaction	380-1501
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
110-1488	Gear-Ring	394-0882
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
112-8042	Carrier-Planet	390-0916
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259

BGF		
Original Part Number	**Part Name**	**Classic Part Number**
116-1102	Sleeve-Injector	451-9024
119-5727	Bearing-Spl Ball	417-9491
132-6597	Cone-Spl	422-6477
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-9288	Case As-Diff	380-1496
151-4836	Diff Gp -A	416-2120
160-1400	Yoke (1710)	319-3479
160-6305	Cap-Bearing	295-5686
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
213-1370	Bearing-Sleeve	380-7370
216-4781	Gasket Kit	437-8144
216-7957	U-Joint	367-6069
226-8202	Seal-Wiper	472-8024
228-0419	Seal As	443-3571
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
334-1032	Disc-Friction	440-3116
352-2077	Pump Gp-Water -B	434-6108

BXG		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2K-5065	Cone-Roller Brg	416-2157

BXG		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3H-8726	Mount As	385-7208

BXG		
Original Part Number	**Part Name**	**Classic Part Number**
3J-2443	Bearing	383-2125
3J-6043	Trunnion	319-3477
3J-9097	Retainer	397-5045
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-8535	Retainer-Seal	300-2589
4J-0121	Cap-Bearing	360-2344

Sales Model 814F (Cont'd.)

BXG		
Original Part Number	Part Name	Classic Part Number
4J-2414	Trunnion	296-1370
4J-6167	Bearing-Sleeve	325-6009
4J-7650	Retainer As	440-0851
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7270	Support-Trunnion	373-5384
4K-7467	Bearing As-Rlr	380-1500
4T-6869	Cartridge Gp	422-8104
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4V-5099	Cover	418-1929
4V-5392	Spider	377-7430
4W-1203	Cup-Rlr Brg	418-9603
5C-6739	Bearing-Sleeve	445-7704
5D-2989	Bearing	380-7511
5F-7993	Pin	319-3454
5J-2245	Bearing	422-6916
5J-2246	Bearing	418-1927
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-8194	Ring-Retaining	308-9920
5P-9439	Bearing-Spl Ball	371-4306
5T-5682	Driver	418-9579
6E-0775	Head	425-9373
6E-5028	Rod As	425-9372
6F-2904	Bearing	295-5673
6I-8510	Housing As - Clu	373-5387
6J-3999	Connector	428-7631
6J-6604	Pin	419-6071
6P-7704	Carrier-Ring	314-8658
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-3151	Stator-Converter	388-6562

BXG		
Original Part Number	Part Name	Classic Part Number
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-1334	Bearing-Sleeve	325-6015
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-0078	Bearing-Sleeve	308-9825
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
8F-3170	Bearing-Roller	417-4504
8H-5352	Bearing-Ball	453-3658
8J-2880	Cap-Bearing	295-6420
8J-7978	Bearing-Spher	388-0581
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-0931	Housing-Pinion	302-4300
8R-0942	Plate-Reaction	380-1484
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-3252	Shaft-Planet	297-7259
8R-8335	Gear-Bevel	368-0105
8V-7659	Pin As	361-1702
9C-4080	Yoke-Brake	302-2703
9C-6029	Bearing-Planet	375-9982
9C-8669	Shaft-Bev Pinion	368-0107
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9P-7757	Gear-Sun	283-5218

BXG		
Original Part Number	Part Name	Classic Part Number
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9U-2787	Gear-Planet	367-6093
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-8437	Gear-Sun	450-7550
9W-9940	Mount As.	360-2355
100-3596	Piston	380-1511
100-3597	Plate-Reaction	380-1501
110-1488	Gear-Ring	394-0882
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
112-8042	Carrier-Planet	390-0916
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
119-5727	Bearing-Spl Ball	417-9491
148-9288	Case As-Diff	380-1496
151-4836	Diff Gp -A	416-2120
160-1400	Yoke (1710)	319-3479
160-6305	Cap-Bearing	295-5686
161-3411	Gasket	394-0896
163-1387	Gear-Flywheel	374-4697
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
228-0419	Seal As	443-3571
229-1490	Sleeve-Injector	393-3659
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
334-1032	Disc-Friction	440-3116

Wheel Dozers

Sales Model 814K

DMB		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5411	Race-Brg Outer	417-9481
5P-8194	Ring-Retaining	308-9920
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658

DMB		
Original Part Number	**Part Name**	**Classic Part Number**
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-3151	Stator-Converter	388-6562
6Y-4819	Carrier-Planet	296-1348
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579

DMB		
Original Part Number	**Part Name**	**Classic Part Number**
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9W-8437	Gear-Sun	450-7550
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
119-5727	Bearing-Spl Ball	417-9491

WCM		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5411	Race-Brg Outer	417-9481
5P-8194	Ring-Retaining	308-9920
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658

WCM		
Original Part Number	**Part Name**	**Classic Part Number**
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-3151	Stator-Converter	388-6562
6Y-4819	Carrier-Planet	296-1348
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579

WCM		
Original Part Number	**Part Name**	**Classic Part Number**
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9W-8437	Gear-Sun	450-7550
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
119-5727	Bearing-Spl Ball	417-9491

Sales Model 824

29G		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368

Sales Model 824 (Cont'd.)

29G		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1J-6744	Bearing	361-1705
1J-6746	Pin	256-4817
1J-6747	Pin	367-6078
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-0057	Plate-Clutch	377-7404
1S-1888	Bracket-Lamp	297-7147
1S-8754	Joint Gp-Univ	308-9873
1T-0043	Bearing-Ball	390-5294
1U-2668	Cartridge Gp	422-8117
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2D-9130	Washer-Thrust	308-9943
2F-5721	Bearing-Ball	311-9354
2J-5649	Pin-Cylinder	256-4782
2K-4502	Bearing-Sleeve	299-1986
2M-5685	Bearing-Needle	380-7469
2M-8340	Rod End-Yoke	374-4678
2S-3966	Ring-Seal	297-7237
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
3D-5315	Pinion-Dif Bevel	308-9856
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3H-8726	Mount As	385-7208
3J-5190	Cap-Brg	256-4837
3J-6043	Trunnion	319-3477
3J-6442	Bearing-Sleeve	299-1961
3J-6559	Cap-Bearing	296-1346
3J-9097	Retainer	397-5045
3K-9604	Cage-Bearing	396-0654
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824

29G		
Original Part Number	Part Name	Classic Part Number
4E-0403	Gear-Planet	260-0781
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4J-4497	Cylinder Gp-Rh	399-8585
4J-4498	Cylinder Gp-Lh	425-9374
4J-7650	Retainer As	440-0851
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4V-4483	Plate-Lock	396-9933
5D-7449	Cup-Spl Tapered	416-2161
5D-9675	Spider	394-9203
5F-2465	Cup-Roller Brg	447-8060
5F-7993	Pin	319-3454
5J-2245	Bearing	422-6916
5J-2246	Bearing	418-1927
5J-4321	Trunnion	302-2700
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5M-7925	Bearing-Roller	419-7774
5P-7487	Bearing-Aligning	434-3300
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6F-2904	Bearing	295-5673
6F-2956	Cup-Spl Tapered	420-6538
6F-7523	Cap-Bearing	325-6039
6J-3999	Connector	428-7631
6J-6604	Pin	419-6071
6K-8088	Bearing-Roller	399-4428
6M-1592	Bearing-Sleeve	374-1462

29G		
Original Part Number	Part Name	Classic Part Number
6N-9211	Core As-O Clr	435-6049
6N-9752	Core As-Oil Clr	468-5016
6V-2202	Bearing-Spl Ball	380-1574
7F-9541	Pin As-Drawbar	296-1361
7G-2496	Gear-Planet	446-3071
7J-7488	Bearing	256-4836
7J-9708	Bearing-Sleeve	299-1964
7K-6432	Retainer-Bearing	398-2933
7M-7219	Bearing-Thrust	384-4816
7N-2957	Cover-Rad Cap	361-1722
7S-3206	Seal-O-Ring	436-2656
7S-5003	Cap As-Rain	379-0184
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-7978	Bearing-Spher	388-0581
8M-0874	Plunger As-Valve	311-9439
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3517	Bearing-Spl Ball	417-4501
9M-8395	Bearing-Sleeve	391-1103
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
101-1504	Shaft	373-5379
124-3237	Precleaner As	432-4220
128-3935	Bearing-Race	396-9897
160-6305	Cap-Bearing	295-5686
308-1845	Seal-Wiper	472-8032

Wheel Dozers

Sales Model 824B

36H		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1J-6744	Bearing	361-1705
1J-6746	Pin	256-4817
1J-6747	Pin	367-6078
1P-1367	Plunger-Valve	432-8913
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-0057	Plate-Clutch	377-7404
1S-1888	Bracket-Lamp	297-7147
1S-8754	Joint Gp-Univ	308-9873
1T-0043	Bearing-Ball	390-5294
1T-0766	Bearing-Sleeve	383-2107
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1U-2668	Cartridge Gp	422-8117
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9130	Washer-Thrust	308-9943
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2J-5649	Pin-Cylinder	256-4782
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2M-8340	Rod End-Yoke	374-4678
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
3D-5315	Pinion-Dif Bevel	308-9856

36H		
Original Part Number	**Part Name**	**Classic Part Number**
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3J-5190	Cap-Brg	256-4837
3J-6043	Trunnion	319-3477
3J-6442	Bearing-Sleeve	299-1961
3J-6559	Cap-Bearing	296-1346
3J-9097	Retainer	397-5045
3K-9604	Cage-Bearing	396-0654
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3S-4646	Bearing-Roller	419-2302
3V-4046	Plate-Pressure	380-7470
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4E-0403	Gear-Planet	260-0781
4J-0121	Cap-Bearing	360-2344
4J-1612	Pin	308-9896
4J-2414	Trunnion	296-1370
4J-4497	Cylinder Gp-Rh	399-8585
4J-4498	Cylinder Gp-Lh	425-9374
4J-7650	Retainer As	440-0851
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4P-7731	Core Gp-O Clr	385-7228
4S-5367	Mount As	375-9986
4S-8855	Coupling-Exhaust	369-9488
4V-4483	Plate-Lock	396-9933
5D-7449	Cup-Spl Tapered	416-2161
5D-9675	Spider	394-9203
5F-2465	Cup-Roller Brg	447-8060
5F-7993	Pin	319-3454
5G-3612	Cap Gp-Protn	295-6419
5J-2245	Bearing	422-6916
5J-2246	Bearing	418-1927

36H		
Original Part Number	**Part Name**	**Classic Part Number**
5J-4321	Trunnion	302-2700
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5M-7925	Bearing-Roller	419-7774
5P-7487	Bearing-Aligning	434-3300
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-0927	Sleeve-Wear	425-3453
5S-0928	Carrier-Ring	443-2969
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6F-2904	Bearing	295-5673
6F-2956	Cup-Spl Tapered	420-6538
6F-7523	Cap-Bearing	325-6039
6H-3957	Bearing-Ball	311-9358
6J-3999	Connector	428-7631
6J-6604	Pin	419-6071
6K-4442	Rod End-Special	373-5388
6K-8088	Bearing-Roller	399-4428
6M-1592	Bearing-Sleeve	374-1462
6N-9211	Core As-O Clr	435-6049
6N-9752	Core As-Oil Clr	468-5016
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7F-9541	Pin As-Drawbar	296-1361
7G-2496	Gear-Planet	446-3071
7H-6967	Bearing-Ball	422-6489
7J-7488	Bearing	256-4836
7J-9708	Bearing-Sleeve	299-1964
7K-6432	Retainer-Bearing	398-2933

Sales Model 824B (Cont'd.)

36H		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-2957	Cover-Rad Cap	361-1722
7S-3206	Seal-O-Ring	436-2656
7S-4000	Piston	416-2143
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8F-5104	Screen As-Se Pan	314-8539

36H		
Original Part Number	Part Name	Classic Part Number
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8J-7978	Bearing-Spher	388-0581
8M-0874	Plunger As-Valve	311-9439
8N-4550	Shaft-Pulley	445-9247
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3517	Bearing-Spl Ball	417-4501
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750

36H		
Original Part Number	Part Name	Classic Part Number
9M-8395	Bearing-Sleeve	391-1103
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
101-1504	Shaft	373-5379
128-3935	Bearing-Race	396-9897
148-0885	Stator-Converter	379-0161
160-6305	Cap-Bearing	295-5686
162-3904	Pump As-F Prm	391-1102
236-8675	Disc-Friction	428-7202
308-1845	Seal-Wiper	472-8032

Sales Model 824C

85X		
Original Part Number	Part Name	Classic Part Number
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107

85X		
Original Part Number	Part Name	Classic Part Number
1T-1078	Bearing-Thrust	384-4802
1T-1333	Carrier As	445-9250
1T-1534	Carrier-Ring	386-4916
1T-1607	Spider As	434-9637
1U-2667	Cartridge Gp	422-8116
1U-2669	Cartridge Gp	422-8118
1V-6342	Gear As	308-9847
1V-8280	Plate	382-6889
1V-8604	Gear-Ring	308-9853
1V-8606	Gear-Sun	308-9860
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
1W-0156	Core As-Oclr	416-5525
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164

85X		
Original Part Number	Part Name	Classic Part Number
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9130	Washer-Thrust	308-9943
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-6489	Race-Brg Outer	374-8350
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-5680	Turbine-Conv	308-9942

Sales Model 824C (Cont'd.)

85X		
Original Part Number	Part Name	Classic Part Number
2S-5100	Valve-Ball	386-3049
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2V-4374	Joint Gp-Slip	308-9872
2V-7170	Yoke	308-9948
2V-7990	Tube As	373-5382
2W-3391	Body As-F Inj V	383-3687
2W-7455	Gear As	396-9957
3D-5315	Pinion-Dif Bevel	308-9856
3E-6772	Seal-Water	382-8017
3E-7466	Gasket Kit	393-3615
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3G-2665	Cover	308-9842
3G-2835	Cartridge Gp-Rr	422-8106
3G-2858	Pump Gp-Gr A	424-7054
3G-4602	Pump Gp-Vn-Bsc-B	439-1131
3G-7662	Cartridge Gp	422-8105
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3J-6043	Trunnion	319-3477
3J-6559	Cap-Bearing	296-1346
3J-9097	Retainer	397-5045
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3P-2414	Housing-Clutch	391-9831
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3246	Shaft-Planet	308-9925
3P-3429	Cage-Bearing	452-0430
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-3739	Carrier As	431-4032

85X		
Original Part Number	Part Name	Classic Part Number
3P-7489	Plate-Clutch	377-7423
3P-8186	Housing-Screen	390-5261
3P-9366	Piston-Clutch	391-9861
3R-8530	Boss	425-3454
3S-1262	Retainer	308-9915
3T-2139	Housing As-Cl	394-2583
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350
3V-6697	Housing	424-4944
3V-7065	Plate	380-1487
4C-1335	Washer-Thrust	399-4425
4E-3456	Lever As	367-6081
4F-2041	Cup-Roller Brg	418-9609
4J-4497	Cylinder Gp-Rh	399-8585
4J-4498	Cylinder Gp-Lh	425-9374
4J-7650	Retainer As	440-0851
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-2954	Sleeve-Camshaft	299-2059
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885

85X		
Original Part Number	Part Name	Classic Part Number
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-0589	Slider	434-1411
4T-9311	Housing	396-0652
4V-0189	Pin	374-6504
4V-2057	Bearing-Spher	419-6019
4V-2518	Shaft	297-7243
4V-3044	Plate-Lock	308-9911
4V-3680	Bellcrank	308-9802
4V-8611	Yoke As	418-9567
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-4588	Sleeve	394-0218
4W-5363	Core Gp-O Clr	380-7531
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-0470	Valve Gp-Qrel	314-8549
5F-7404	Nut-Bearing Lock	308-9878
5F-7993	Pin	319-3454
5G-3612	Cap Gp-Protn	295-6419
5J-2245	Bearing	422-6916
5J-2246	Bearing	418-1927
5J-4321	Trunnion	302-2700
5K-0609	Cover	308-9843
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-3967	Yoke As	308-9946

Sales Model 824C (Cont'd.)

85X		
Original Part Number	Part Name	Classic Part Number
5K-3968	Cage-Bearing	308-9804
5K-4079	Cage-Bearing	308-9805
5K-4268	Retainer-Bearing	308-9916
5K-4273	Bearing-Sleeve	374-1461
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5P-8053	Kit-Gasket (Sch)	415-1901
5P-9301	Bearing-Spl Ball	417-4496
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-6125	Diaphragm	384-5931
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2387	Cartridge Gp	422-8132
6E-2396	Cartridge Gp	422-8122
6F-2904	Bearing	295-5673
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-3907	Adapter-Pilot	398-8348
6I-4024	Gasket-Plate	377-5839
6J-3999	Connector	428-7631
6J-6604	Pin	419-6071
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-2687	Spider As.-Fan	385-7199
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487

85X		
Original Part Number	Part Name	Classic Part Number
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6N-9743	Support-Muffler	308-9940
6P-0593	Bearing-Roller	386-4959
6P-2090	Base-Xmsn O Fil	397-5049
6P-2923	Yoke As	382-6891
6P-6739	Shaft-Planet	308-9929
6V-1033	Rod End-Spher	375-5444
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-9221	Gasket Kit	391-1092
6W-4281	Yoke-Flange	308-9949
6W-4789	Shaft Gp-Drive-D	452-0444
6W-7290	Shaft-Planet	308-9930
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857

85X		
Original Part Number	Part Name	Classic Part Number
7G-5746	Housing-Clutch	392-4520
7J-8893	Cone-Roller Brg	374-1846
7J-9694	Bearing-Sleeve	385-3794
7K-1510	Washer-Thrust	330-9295
7K-1512	Cover	469-8101
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742
7N-1220	Plunger As-Pump	419-4743
7N-1393	Muffler As	374-7477
7N-1572	Cover-Water Pump	377-5854
7N-1760	Ejector As	373-1914
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8371	Line As-Fuel Inj	373-1901
7N-9674	Muffler As	360-7892
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0140	Gear-Drive	399-8546
7W-0182	Plunger & Bbl As	391-9893
7W-0205	Core As-Oclr	379-0183
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-0901	Cup-Spl Tap Roll	399-4444

Sales Model 824C (Cont'd.)

85X		
Original Part Number	**Part Name**	**Classic Part Number**
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077
8N-9622	Bracket As-Fan	433-2024
8P-0514	Yoke As	308-9947
8R-3921	Collet	308-9839
8R-3943	Collet	308-9840
8R-4184	Bearing-Sleeve	374-6515
8R-4821	Carrier-Planet	308-9837
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
8V-3550	Rim As	417-9477
8V-6382	Hub As	308-9868
8V-6384	Spacer As	308-9935
9B-1320	Valve-Check	377-5832
9C-0624	Pin As.	361-1709
9C-2249	Yoke As	382-6890
9C-3530	Joint Gp-Univ	449-9832
9C-8074	Gear-Planet	308-9858
9C-8075	Gear-Sun	308-9864
9C-8278	Case As-Diff	423-6984
9J-5284	Bearing-Sleeve	380-7379
9K-5639	Pin	425-6451
9K-8757	Rod End-Special	311-9361

85X		
Original Part Number	**Part Name**	**Classic Part Number**
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9S-5279	Bearing-Inner	453-3661
9S-8597	Spring	399-8561
9T-5360	Plate-Pressure	424-4941
9U-0971	Gear-Sun	368-0124
9U-0974	Bushing-Sleeve	374-1460
9U-0975	Hub As	390-5259
9V-6165	Plate-Outer	377-7460
9V-6526	Ring-Retaining	422-2485
9V-7710	Univ Joint As	394-8234
9V-7860	Support As-Front	308-9938
9W-2977	Hub As	423-6985
9W-4175	Shaft-Xmsn Input	394-8241
9W-4702	Stator-Converter	308-9939
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-7019	Disc-Friction	377-7461
9Y-1917	Pulley-Fan	395-1311
9Y-2988	Breather As	361-1716
9Y-3318	Core As-Radiator	374-7491
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-2930	Gasket Kit - F	393-1026
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567

85X		
Original Part Number	**Part Name**	**Classic Part Number**
101-9640	Gear-Air Compr	398-2966
102-4563	Gear-Transfer	399-4430
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
106-7798	Bearing-Ball	417-9494
108-2102	Bonnet-Valve	455-3274
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
109-6928	Gasket Kit	436-8413
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
112-7309	Shaft-Planet	380-7521
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
120-3861	Bracket As	415-1897
121-7583	Gear-Planet	364-5257
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-8890	Race	399-4423

Sales Model 824C (Cont'd.)

85X		
Original Part Number	Part Name	Classic Part Number
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
139-9170	Gasket Kit	447-0825
141-9792	Gasket Kit - Ocl	393-3632
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
146-4229	Gasket Kit - Sch	437-4599
147-1900	Gasket Kit	447-0826
149-5985	Stator-Converter	419-1865
150-1916	Manifold-Exh	395-1322
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-5679	Kit-Dt Gasket	390-5277
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-6305	Cap-Bearing	295-5686
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726

85X		
Original Part Number	Part Name	Classic Part Number
164-4891	Plate As.	391-1093
166-6352	Tube As.	432-4223
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-8541	Core As-Rdtr	379-0180
174-5385	Gasket Kit - Ocl	393-1037
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
190-3832	Core As-Oclr	438-3251
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
197-5510	Support As	419-0880
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217

85X		
Original Part Number	Part Name	Classic Part Number
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
232-6574	Kit-Gasket-Rs	437-2034
232-6599	Kit-Gasket (Mch)	437-2033
233-7083	Kit-Gasket-Fs	387-2919
233-9748	Disc-Friction	417-9502
234-1874	Kit-Gasket-Fs	437-8668
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
243-0728	Kit-Dt Gasket	394-9206
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
374-1849	Brg-Rlr-Cla	399-4442
430-7619	Adapter-Cla	438-1812

Sales Model 824G

4SN		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9594	Bearing-Cup	377-7401
1T-0655	Bearing-Thrust	377-7409

4SN		
Original Part Number	Part Name	Classic Part Number
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1V-8852	Cap	308-9834

4SN		
Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059

Sales Model 824G (Cont'd.)

4SN		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-6489	Race-Brg Outer	374-8350
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-2665	Cover	308-9842
3G-5999	Bearing-Sleeve	391-9813
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3246	Shaft-Planet	308-9925
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3R-8530	Boss	425-3454
3T-2139	Housing As-Cl	394-2583
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502

4SN		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-0589	Slider	434-1411
4V-2057	Bearing-Spher	419-6019
4V-8629	Bearing-Sleeve	379-0194
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5F-2465	Cup-Roller Brg	447-8060
5F-8651	Bearing-Ball	420-3223
5J-1192	Bearing-Sleeve	374-8355
5J-1193	Bearing-Sleeve	382-8046
5J-2528	Plunger	391-1318
5J-5365	Pin	380-7553
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774

4SN		
Original Part Number	**Part Name**	**Classic Part Number**
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5P-9301	Bearing-Spl Ball	417-4496
5P-9514	Bearing-Ball	417-9467
5P-9538	Bearing-Roller	421-8183
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6F-7523	Cap-Bearing	325-6039
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6J-3999	Connector	428-7631
6J-6604	Pin	419-6071
6K-5528	Cup-Roller Brg	447-8059
6N-1931	Plunger	379-0171
6N-7154	Rotocoil As	380-7556
6P-0593	Bearing-Roller	386-4959
6P-6739	Shaft-Planet	308-9929
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520

Sales Model 824G (Cont'd.)

4SN		
Original Part Number	Part Name	Classic Part Number
7E-9595	Core As-Radiator	396-9926
7E-9907	Spacer-Fp Timing	394-0222
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7J-1335	Bearing-Sleeve	380-7567
7J-1336	Bearing-Sleeve	384-4776
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7M-5334	Cone-Roller Brg	420-2505
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7W-0205	Core As-Oclr	379-0183
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8C-3111	Rod End-Spher	392-4523
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456

4SN		
Original Part Number	Part Name	Classic Part Number
9J-0123	Trunnion	325-6227
9J-5284	Bearing-Sleeve	380-7379
9J-5942	Bearing-Sleeve	380-7380
9J-6001	Cap As	444-0570
9K-5639	Pin	425-6451
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9S-5279	Bearing-Inner	453-3661
9V-0247	Plate	417-4527
9W-2977	Hub As	423-6985
9W-4175	Shaft-Xmsn Input	394-8241
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
002-1212	Cup-Roller Brg	399-4446
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-8010	Valve	423-5583
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-4563	Gear-Transfer	399-4430
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494

4SN		
Original Part Number	Part Name	Classic Part Number
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929
107-5006	Joint Gp-Univ	416-2137
107-5007	Joint Gp-Slip	416-2145
107-5610	Yoke	398-8334
107-9172	Piston	375-2622
108-2102	Bonnet-Valve	455-3274
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-0551	Hub As	416-2146
110-5096	Head As-Cyl	394-0915
112-7309	Shaft-Planet	380-7521
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-2958	Pin-Lower	393-0939
115-3184	Cap-Lower	395-1324
117-0456	Crankshaft As	394-2587
117-6675	Step As	419-0881
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
123-8509	Pump Gp-Vn Bsc	422-8152
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3046	Carrier-Planet	393-1015
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
134-0039	Housing-Piston	432-4217
135-4928	Shaft-Water Pump	386-3813
138-4338	Kit-Gasket-T	393-1032
139-9170	Gasket Kit	447-0825
141-4617	Kit-Gasket(Acl)	393-0917
142-7526	Gasket Kit	393-0918
144-0482	Gasket	420-8547
145-8503	Shaft As-Idler	426-0035
147-1900	Gasket Kit	447-0826

Sales Model 824G (Cont'd.)

4SN		
Original Part Number	**Part Name**	**Classic Part Number**
149-2914	Pinion-Dif Bevel	396-9950
150-4637	Pan-Oil	377-5843
150-8459	Kit-Gasket(F)	438-1798
150-8685	Gasket Kit	392-4503
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
159-8169	Gear-Planet	391-9870
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-9918	Retainer-Bearing	395-1321
164-4891	Plate As.	391-1093
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
177-9024	Adapter-Damper	299-1956

4SN		
Original Part Number	**Part Name**	**Classic Part Number**
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
197-5510	Support As	419-0880
202-3572	Shaft As-Drive	426-0037
208-7534	Case As-Diff	388-6590
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266

4SN		
Original Part Number	**Part Name**	**Classic Part Number**
220-3779	Kit-Gasket(F)	437-1998
232-3679	Kit-Gasket (Rs)	437-2039
233-9464	Kit-Gasket (Sch)	393-0925
233-9748	Disc-Friction	417-9502
234-1874	Kit-Gasket-Fs	437-8668
237-9849	Cage-Bearing	443-1201
243-0726	Kit-Dt Gasket	394-9210
253-1752	Plate-Thrust	379-0170
315-6671	Kit-Gasket(Op)	438-0139
319-5239	Wheel	396-9956
321-5746	Bearing-Main	419-6367
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

AWW		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9594	Bearing-Cup	377-7401
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1V-8852	Cap	308-9834
1W-7238	Shaft As-Pump Dr	379-0164

AWW		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2F-8509	Cone-Roller Brg	399-4434
2H-6489	Race-Brg Outer	374-8350
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-2665	Cover	308-9842
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861

AWW		
Original Part Number	**Part Name**	**Classic Part Number**
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3246	Shaft-Planet	308-9925
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3R-8530	Boss	425-3454
3T-2139	Housing As-Cl	394-2583
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4T-0589	Slider	434-1411

Sales Model 824G (Cont'd.)

AWW		
Original Part Number	Part Name	Classic Part Number
4V-2057	Bearing-Spher	419-6019
4V-8629	Bearing-Sleeve	379-0194
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5F-2465	Cup-Roller Brg	447-8060
5J-1192	Bearing-Sleeve	374-8355
5J-1193	Bearing-Sleeve	382-8046
5J-2528	Plunger	391-1318
5J-5365	Pin	380-7553
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-7807	Bearing-Ball	314-8502
5P-9301	Bearing-Spl Ball	417-4496
5T-5682	Driver	418-9579
6F-7523	Cap-Bearing	325-6039
6I-2726	Bearing-Sleeve	419-4757
6J-3999	Connector	428-7631
6J-6604	Pin	419-6071
6K-5528	Cup-Roller Brg	447-8059
6N-1931	Plunger	379-0171
6P-0593	Bearing-Roller	386-4959
6P-6739	Shaft-Planet	308-9929
6V-1781	Bearing-Spl Ball	380-1508
6V-3831	Seal-O-Ring	436-2657
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607

AWW		
Original Part Number	Part Name	Classic Part Number
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7J-1335	Bearing-Sleeve	380-7567
7J-1336	Bearing-Sleeve	384-4776
7J-1337	Bearing	380-7367
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7M-5334	Cone-Roller Brg	420-2505
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7W-3145	Plate	422-7894
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9J-0123	Trunnion	325-6227
9J-5284	Bearing-Sleeve	380-7379
9J-5942	Bearing-Sleeve	380-7380
9J-6001	Cap As	444-0570
9K-5639	Pin	425-6451
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9N-3167	Plate-Block Bot	430-4468
9S-5279	Bearing-Inner	453-3661
9V-0247	Plate	417-4527
9W-2977	Hub As	423-6985
9W-4175	Shaft-Xmsn Input	394-8241
9W-6434	Hub-Impeller	443-2018

AWW		
Original Part Number	Part Name	Classic Part Number
9W-6435	Flange-Drive	308-9846
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
102-4563	Gear-Transfer	399-4430
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929
107-5006	Joint Gp-Univ	416-2137
107-5007	Joint Gp-Slip	416-2145
107-5610	Yoke	398-8334
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
110-0551	Hub As	416-2146
112-7309	Shaft-Planet	380-7521
115-2958	Pin-Lower	393-0939
115-3184	Cap-Lower	395-1324
117-6675	Step As	419-0881
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3046	Carrier-Planet	393-1015
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052

Wheel Dozers

Sales Model 824G (Cont'd.)

AWW		
Original Part Number	**Part Name**	**Classic Part Number**
146-2601	Cover	399-6054
149-2914	Pinion-Dif Bevel	396-9950
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-8169	Gear-Planet	391-9870
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-9918	Retainer-Bearing	395-1321
164-4413	Mount	419-0876
164-4891	Plate As.	391-1093
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
170-8541	Core As-Rdtr	379-0180

AWW		
Original Part Number	**Part Name**	**Classic Part Number**
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
197-5510	Support As	419-0880
208-7534	Case As-Diff	388-6590
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735

AWW		
Original Part Number	**Part Name**	**Classic Part Number**
232-3679	Kit-Gasket (Rs)	437-2039
233-9748	Disc-Friction	417-9502
237-9849	Cage-Bearing	443-1201
243-0726	Kit-Dt Gasket	394-9210
243-0729	Kit-Dt Gasket	434-7287
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
319-5239	Wheel	396-9956
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-6387
328-5573	Bearing-Conn Rod	419-4665
430-7619	Adapter-Cla	438-1812

Sales Model 824H

ASX		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9594	Bearing-Cup	377-7401
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1V-8852	Cap	308-9834

ASX		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2F-8509	Cone-Roller Brg	399-4434
2H-6489	Race-Brg Outer	374-8350
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-2665	Cover	308-9842
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861

ASX		
Original Part Number	**Part Name**	**Classic Part Number**
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3246	Shaft-Planet	308-9925
3P-3735	Housing As	391-9830
3P-7489	Plate-Clutch	377-7423
3T-2139	Housing As-Cl	394-2583
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407
4N-0685	Bearing-Sleeve	379-0191
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4T-0589	Slider	434-1411
4V-8629	Bearing-Sleeve	379-0194

Sales Model 824H (Cont'd.)

ASX		
Original Part Number	Part Name	Classic Part Number
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5F-2465	Cup-Roller Brg	447-8060
5J-1192	Bearing-Sleeve	374-8355
5J-1193	Bearing-Sleeve	382-8046
5J-2528	Plunger	391-1318
5J-5365	Pin	380-7553
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5T-5682	Driver	418-9579
6F-7523	Cap-Bearing	325-6039
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6J-3999	Connector	428-7631
6J-6604	Pin	419-6071
6K-5528	Cup-Roller Brg	447-8059
6N-1931	Plunger	379-0171
6P-0593	Bearing-Roller	386-4959
6P-6739	Shaft-Planet	308-9929
6V-3831	Seal-O-Ring	436-2657
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7F-9541	Pin As-Drawbar	296-1361
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7J-1335	Bearing-Sleeve	380-7567
7J-1336	Bearing-Sleeve	384-4776

ASX		
Original Part Number	Part Name	Classic Part Number
7J-1337	Bearing	380-7367
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7M-5334	Cone-Roller Brg	420-2505
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7W-5733	Gasket	421-7333
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9J-0123	Trunnion	325-6227
9J-5284	Bearing-Sleeve	380-7379
9J-5942	Bearing-Sleeve	380-7380
9J-6001	Cap As	444-0570
9K-5639	Pin	425-6451
9S-5279	Bearing-Inner	453-3661
9V-0247	Plate	417-4527
9W-2977	Hub As	423-6985
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9Y-2988	Breather As	361-1716
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
102-4563	Gear-Transfer	399-4430
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929

ASX		
Original Part Number	Part Name	Classic Part Number
107-5006	Joint Gp-Univ	416-2137
107-5007	Joint Gp-Slip	416-2145
107-5610	Yoke	398-8334
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
110-0551	Hub As	416-2146
112-7309	Shaft-Planet	380-7521
115-2958	Pin-Lower	393-0939
115-3184	Cap-Lower	395-1324
117-6675	Step As	419-0881
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3046	Carrier-Planet	393-1015
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
149-2914	Pinion-Dif Bevel	396-9950
150-1916	Manifold-Exh	395-1322
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-8169	Gear-Planet	391-9870
160-9874	Kit-Gasket-Scl	386-3048
161-9918	Retainer-Bearing	395-1321
164-4891	Plate As.	391-1093
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
208-7534	Case As-Diff	388-6590
211-0592	Bearing - Main	419-6368

Wheel Dozers

Sales Model 824H (Cont'd.)

ASX		
Original Part Number	**Part Name**	**Classic Part Number**
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735

ASX		
Original Part Number	**Part Name**	**Classic Part Number**
233-9748	Disc-Friction	417-9502
237-9849	Cage-Bearing	443-1201
246-3130	Shaft-Water Pump	392-4508

ASX		
Original Part Number	**Part Name**	**Classic Part Number**
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
319-5239	Wheel	396-9956
328-4240	Arm As-V Rocker	433-0443

Sales Model 824K

234		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1V-8852	Cap	308-9834
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2H-6489	Race-Brg Outer	374-8350
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3P-1210	Cone-Roller Brg	399-4433
3P-2415	Carrier-Planet	396-0653
3P-2983	Gear-Sun	417-9468

234		
Original Part Number	**Part Name**	**Classic Part Number**
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3246	Shaft-Planet	308-9925
3P-3735	Housing As	391-9830
4B-7255	Cone-Bearing	386-4951
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4T-0589	Slider	434-1411
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5F-2465	Cup-Roller Brg	447-8060
5J-1192	Bearing-Sleeve	374-8355
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5T-5682	Driver	418-9579
6F-7523	Cap-Bearing	325-6039
6J-3999	Connector	428-7631
6J-6604	Pin	419-6071
6K-5528	Cup-Roller Brg	447-8059
6N-1931	Plunger	379-0171
6P-6739	Shaft-Planet	308-9929
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028

234		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7J-5131	Trunnion	296-1371
7M-5334	Cone-Roller Brg	420-2505
7N-2156	Bearing-Sleeve	380-7373
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8J-2880	Cap-Bearing	295-6420
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9D-7924	Mount As	360-2356
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9J-5284	Bearing-Sleeve	380-7379
9K-5639	Pin	425-6451
9S-5279	Bearing-Inner	453-3661
9W-2977	Hub As	423-6985
9W-9930	Mount As	295-6437
9W-9931	Mount As.	360-2354
100-8010	Valve	423-5583
105-2485	Gear-Tfr Output	398-2932

Sales Model 824K (Cont'd.)

234		
Original Part Number	**Part Name**	**Classic Part Number**
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929
107-5006	Joint Gp-Univ	416-2137
107-5610	Yoke	398-8334
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
110-0551	Hub As	416-2146
112-7309	Shaft-Planet	380-7521
124-0502	Cup-Spl Tapered	416-2161

234		
Original Part Number	**Part Name**	**Classic Part Number**
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3046	Carrier-Planet	393-1015
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
149-2914	Pinion-Dif Bevel	396-9950
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-8169	Gear-Planet	391-9870
160-9874	Kit-Gasket-Scl	386-3048

234		
Original Part Number	**Part Name**	**Classic Part Number**
161-9918	Retainer-Bearing	395-1321
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
208-7534	Case As-Diff	388-6590
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
233-9748	Disc-Friction	417-9502
237-9849	Cage-Bearing	443-1201
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
319-5239	Wheel	396-9956

RWB		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1V-8852	Cap	308-9834
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174

RWB		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4576	Cup-Roller Brg	386-4944
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2H-6489	Race-Brg Outer	374-8350
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3P-1210	Cone-Roller Brg	399-4433
3P-2415	Carrier-Planet	396-0653
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3246	Shaft-Planet	308-9925
3P-3735	Housing As	391-9830
4B-7255	Cone-Bearing	386-4951
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407

RWB		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4T-0589	Slider	434-1411
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5F-2465	Cup-Roller Brg	447-8060
5J-1192	Bearing-Sleeve	374-8355
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5T-5682	Driver	418-9579
6F-7523	Cap-Bearing	325-6039
6J-3999	Connector	428-7631
6J-6604	Pin	419-6071
6K-5528	Cup-Roller Brg	447-8059
6N-1931	Plunger	379-0171

Sales Model 824K (Cont'd.)

RWB		
Original Part Number	Part Name	Classic Part Number
6P-6739	Shaft-Planet	308-9929
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-7652	Cup-Rlr Brg	399-6067
7C-0307	Gasket	399-8571
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7J-5131	Trunnion	296-1371
7M-5334	Cone-Roller Brg	420-2505
7N-2156	Bearing-Sleeve	380-7373
7N-7878	Cover-Plate	434-2401
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8J-2880	Cap-Bearing	295-6420
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9D-7924	Mount As	360-2356
9G-6744	Bearing-Sleeve	418-1931
9J-0123	Trunnion	325-6227
9J-5284	Bearing-Sleeve	380-7379
9K-5639	Pin	425-6451
9S-5279	Bearing-Inner	453-3661

RWB		
Original Part Number	Part Name	Classic Part Number
9W-2977	Hub As	423-6985
9W-9930	Mount As	295-6437
9W-9931	Mount As.	360-2354
100-8010	Valve	423-5583
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929
107-5006	Joint Gp-Univ	416-2137
107-5610	Yoke	398-8334
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
110-0551	Hub As	416-2146
112-7309	Shaft-Planet	380-7521
124-0502	Cup-Spl Tapered	416-2161
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3046	Carrier-Planet	393-1015
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919

RWB		
Original Part Number	Part Name	Classic Part Number
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
149-2914	Pinion-Dif Bevel	396-9950
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-8169	Gear-Planet	391-9870
160-9874	Kit-Gasket-Scl	386-3048
161-9918	Retainer-Bearing	395-1321
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
208-7534	Case As-Diff	388-6590
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
233-9748	Disc-Friction	417-9502
237-9849	Cage-Bearing	443-1201
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
319-5239	Wheel	396-9956
328-4240	Arm As-V Rocker	433-0443

Sales Model 830M

41E		
Original Part Number	Part Name	Classic Part Number
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443

41E		
Original Part Number	Part Name	Classic Part Number
1J-6746	Pin	256-4817
1J-6749	Screw-Adj	256-4824
1P-1367	Plunger-Valve	432-8913
1S-0057	Plate-Clutch	377-7404

41E		
Original Part Number	Part Name	Classic Part Number
1S-1888	Bracket-Lamp	297-7147
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410

Sales Model 830M (Cont'd.)

41E		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2D-9130	Washer-Thrust	308-9943
2F-5721	Bearing-Ball	311-9354
2J-5649	Pin-Cylinder	256-4782
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2M-8340	Rod End-Yoke	374-4678
2P-3839	Crankshaft As	398-2968
2R-0524	Cone-Bearing	422-6484
2S-3966	Ring-Seal	297-7237
2S-7931	Bearing-Sleeve	387-2904
3D-5315	Pinion-Dif Bevel	308-9856
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-2749	Cartridge Gp-Rr	422-8125
3G-7660	Cartridge Gp	422-8103
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3S-9466	Bearing-Sleeve	314-8509
4D-2619	Bearing	417-4494
4E-0403	Gear-Planet	260-0781
4F-2041	Cup-Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391

41E		
Original Part Number	**Part Name**	**Classic Part Number**
4V-4483	Plate-Lock	396-9933
5D-0470	Valve Gp-Qrel	314-8549
5D-7449	Cup-Spl Tapered	416-2161
5D-9675	Spider	394-9203
5F-2465	Cup-Roller Brg	447-8060
5J-2528	Plunger	391-1318
5L-2660	Bearing-Sleeve	311-9363
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-9738	Coupling-Exhaust	311-9380
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5M-7925	Bearing-Roller	419-7774
5P-8789	Gasket Kt	393-3620
5S-0927	Sleeve-Wear	425-3453
5S-0928	Carrier-Ring	443-2969
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6N-9211	Core As-O Clr	435-6049
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7G-2496	Gear-Planet	446-3071
7H-6967	Bearing-Ball	422-6489
7J-9708	Bearing-Sleeve	299-1964
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417

45E		
Original Part Number	**Part Name**	**Classic Part Number**
1A-3987	Disc-Ster Cl Dr	230-7119

41E		
Original Part Number	**Part Name**	**Classic Part Number**
7W-0205	Core As-Oclr	379-0183
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-3666	Repair Kt-Major	377-5842
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3517	Bearing-Spl Ball	417-4501
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
9M-8395	Bearing-Sleeve	391-1103
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
005-8639	Bearing-Aligning	415-1925
101-1504	Shaft	373-5379
110-1337	Ring Kit-Pstn	377-5834
128-3935	Bearing-Race	396-9897
148-0885	Stator-Converter	379-0161
160-6305	Cap-Bearing	295-5686
162-3904	Pump As-F Prm	391-1102

Sales Model 830M (Cont'd.)

45E		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1J-6746	Pin	256-4817
1J-6749	Screw-Adj	256-4824
1P-1367	Plunger-Valve	432-8913
1S-0057	Plate-Clutch	377-7404
1S-1888	Bracket-Lamp	297-7147
1T-0766	Bearing-Sleeve	383-2107
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2D-9130	Washer-Thrust	308-9943
2F-5721	Bearing-Ball	311-9354
2J-5649	Pin-Cylinder	256-4782
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2M-8340	Rod End-Yoke	374-4678
2P-3839	Crankshaft As	398-2968
2R-0524	Cone-Bearing	422-6484
2S-3966	Ring-Seal	297-7237
2S-7931	Bearing-Sleeve	387-2904
3D-5315	Pinion-Dif Bevel	308-9856
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3G-2749	Cartridge Gp-Rr	422-8125
3G-7660	Cartridge Gp	422-8103
3H-8726	Mount As	385-7208
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356

45E		
Original Part Number	**Part Name**	**Classic Part Number**
3S-9466	Bearing-Sleeve	314-8509
4D-2619	Bearing	417-4494
4E-0403	Gear-Planet	260-0781
4F-2041	Cup-Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4V-4483	Plate-Lock	396-9933
5D-0470	Valve Gp-Qrel	314-8549
5D-7449	Cup-Spl Tapered	416-2161
5D-9675	Spider	394-9203
5F-2465	Cup-Roller Brg	447-8060
5J-2528	Plunger	391-1318
5L-2660	Bearing-Sleeve	311-9363
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-9738	Coupling-Exhaust	311-9380
5M-2054	Bearing	380-7510
5M-3560	Bearing-Sleeve	392-4521
5M-7925	Bearing-Roller	419-7774
5P-8789	Gasket Kt	393-3620
5S-0927	Sleeve-Wear	425-3453
5S-0928	Carrier-Ring	443-2969
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6F-2956	Cup-Spl Tapered	420-6538
6N-9211	Core As-O Clr	435-6049
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7G-2496	Gear-Planet	446-3071
7H-6967	Bearing-Ball	422-6489
7J-9708	Bearing-Sleeve	299-1964

45E		
Original Part Number	**Part Name**	**Classic Part Number**
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7W-0205	Core As-Oclr	379-0183
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-3666	Repair Kt-Major	377-5842
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3517	Bearing-Spl Ball	417-4501
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
9M-8395	Bearing-Sleeve	391-1103
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9V-7710	Univ Joint As	394-8234
005-8639	Bearing-Aligning	415-1925
101-1504	Shaft	373-5379
110-1337	Ring Kit-Pstn	377-5834
128-3935	Bearing-Race	396-9897
148-0885	Stator-Converter	379-0161
160-6305	Cap-Bearing	295-5686
162-3904	Pump As-F Prm	391-1102

Sales Model 834

43E		
Original Part Number	Part Name	Classic Part Number
0R-5013	Plate-Clutch	388-0586
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1J-6747	Pin	367-6078
1P-1367	Plunger-Valve	432-8913
1S-0057	Plate-Clutch	377-7404
1S-1888	Bracket-Lamp	297-7147
1S-9110	Bearing-Needle	420-2497
1T-0766	Bearing-Sleeve	383-2107
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1U-2668	Cartridge Gp	422-8117
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-5721	Bearing-Ball	311-9354
2J-5649	Pin-Cylinder	256-4782
2K-4502	Bearing-Sleeve	299-1986
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2M-8340	Rod End-Yoke	374-4678
2P-3839	Crankshaft As	398-2968
2S-3966	Ring-Seal	297-7237
2S-6097	Tang	375-9979
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3H-8726	Mount As	385-7208
3J-5190	Cap-Brg	256-4837

43E		
Original Part Number	Part Name	Classic Part Number
3J-6043	Trunnion	319-3477
3J-6442	Bearing-Sleeve	299-1961
3J-6559	Cap-Bearing	296-1346
3J-9097	Retainer	397-5045
3K-9604	Cage-Bearing	396-0654
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3P-1686	Plate-Clutch	388-0586
3S-4646	Bearing-Roller	419-2302
3S-9466	Bearing-Sleeve	314-8509
3V-4046	Plate-Pressure	380-7470
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4F-2041	Cup-Roller Brg	418-9609
4J-0121	Cap-Bearing	360-2344
4J-2414	Trunnion	296-1370
4J-4497	Cylinder Gp-Rh	399-8585
4J-4498	Cylinder Gp-Lh	425-9374
4J-7650	Retainer As	440-0851
4K-7463	Seal-Lip Type	472-8007
4M-1641	Dowel-Reaction	386-4952
4M-9215	Gear-Pump Idler	311-9391
4V-4483	Plate-Lock	396-9933
5G-3612	Cap Gp-Protn	295-6419
5J-2245	Bearing	422-6916
5J-2246	Bearing	418-1927
5J-4321	Trunnion	302-2700
5L-2660	Bearing-Sleeve	311-9363
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-9738	Coupling-Exhaust	311-9380
5M-3560	Bearing-Sleeve	392-4521
5P-7487	Bearing-Aligning	434-3300
5P-7807	Bearing-Ball	314-8502
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-0927	Sleeve-Wear	425-3453

43E		
Original Part Number	Part Name	Classic Part Number
5S-0928	Carrier-Ring	443-2969
5S-1211	Cover-Valve	314-8665
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6D-0738	Pinion-Dif Bevel	394-9840
6F-2956	Cup-Spl Tapered	420-6538
6F-7523	Cap-Bearing	325-6039
6J-3999	Connector	428-7631
6J-6604	Pin	419-6071
6K-4442	Rod End-Special	373-5388
6K-8088	Bearing-Roller	399-4428
6M-1592	Bearing-Sleeve	374-1462
6N-9211	Core As-O Clr	435-6049
6N-9752	Core As-Oil Clr	468-5016
6V-2202	Bearing-Spl Ball	380-1574
7D-7607	Gear-Dif Bevel	388-0595
7E-5085	Bushing	377-5829
7F-9541	Pin As-Drawbar	296-1361
7G-2830	Ring-Seal	295-6441
7H-6967	Bearing-Ball	422-6489
7J-7488	Bearing	256-4836
7J-9708	Bearing-Sleeve	299-1964
7K-6432	Retainer-Bearing	398-2933
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7N-2957	Cover-Rad Cap	361-1722
7S-3206	Seal-O-Ring	436-2656
7S-4000	Piston	416-2143
7S-4411	Cap As-Rain	373-1912
7S-5003	Cap As-Rain	379-0184
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0205	Core As-Oclr	379-0183

Wheel Dozers

Sales Model 834 (Cont'd.)

43E		
Original Part Number	**Part Name**	**Classic Part Number**
7W-1927	Ring-Retainer	387-2935
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-8175	Bearing-Sleeve	376-3636
8J-7978	Bearing-Spher	388-0581

43E		
Original Part Number	**Part Name**	**Classic Part Number**
8M-0874	Plunger As-Valve	311-9439
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
9M-8395	Bearing-Sleeve	391-1103
9S-1195	Pump As-Oil	390-1000
9S-5746	Ferrule-Seal	392-4493
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271

43E		
Original Part Number	**Part Name**	**Classic Part Number**
9V-7710	Univ Joint As	394-8234
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
128-3935	Bearing-Race	396-9897
148-0885	Stator-Converter	379-0161
162-3904	Pump As-F Prm	391-1102
208-8795	Retainer	430-5355
236-8675	Disc-Friction	428-7202
308-1845	Seal-Wiper	472-8032

Sales Model 834B

7BR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3941	Cone-Roller Brg	422-6486
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1J-6747	Pin	367-6078
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7522	Yoke As	382-6893
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9594	Bearing-Cup	377-7401
1S-0057	Plate-Clutch	377-7404
1S-1888	Bracket-Lamp	297-7147
1S-9209	Shaft-Tightener	374-6499
1T-0766	Bearing-Sleeve	383-2107
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1V-6342	Gear As	308-9847
1W-5009	Crankshaft As	398-2969
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164

7BR		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9490	Pulley-Alt	394-0885
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-6489	Race-Brg Outer	374-8350
2K-5065	Cone-Roller Brg	416-2157
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-4470	Turbine-Conv	390-0910
2P-5861	Housing As-Rot	430-8128
2P-8986	Cup-Rlr Bearing	415-1912
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817

7BR		
Original Part Number	**Part Name**	**Classic Part Number**
2V-4148	Shaft-Planet	388-6579
2V-4700	Pin	308-9894
2V-6129	Cover	390-5295
2V-6371	Cover As	398-8338
2W-4087	Gear As-Idler	418-9582
2W-7610	Gear-Hyd Pump Dr	418-1940
2W-7980	Camshaft As	378-3972
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
3F-4971	Pin	295-5693
3G-6856	Pump Gp-Gr A	421-1556
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3J-6043	Trunnion	319-3477
3J-6559	Cap-Bearing	296-1346
3J-9097	Retainer	397-5045
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924

Sales Model 834B (Cont'd.)

7BR		
Original Part Number	Part Name	Classic Part Number
3P-3246	Shaft-Planet	308-9925
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-7489	Plate-Clutch	377-7423
3R-5327	Pipe-Extension	383-1571
3R-8530	Boss	425-3454
3S-1262	Retainer	308-9915
3T-2139	Housing As-Cl	394-2583
3T-5419	Impeller-Conv	416-2144
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350
3V-4046	Plate-Pressure	380-7470
4D-4065	Rod End-Spher	374-1824
4E-0079	Cage-Bearing	434-4387
4E-0752	Joint Gp-Univ	435-0197
4E-3604	Joint Gp-Univ	421-5542
4E-3751	Yoke As	451-0750
4F-2041	Cup-Roller Brg	418-9609
4J-4497	Cylinder Gp-Rh	399-8585
4J-4498	Cylinder Gp-Lh	425-9374
4J-7650	Retainer As	440-0851
4K-7463	Seal-Lip Type	472-8007
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1186	Bearing-Sleeve	417-4519
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710

7BR		
Original Part Number	Part Name	Classic Part Number
4N-5858	Cap-Cshft Brg	448-9157
4N-6302	Belt Set-Vee	314-8495
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-5884	Core As-Oclr	435-0196
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4T-0589	Slider	434-1411
4T-9311	Housing	396-0652
4V-4483	Plate-Lock	396-9933
4W-0452	Seal As -Cshaft	325-6191
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-7404	Nut-Bearing Lock	308-9878
5J-2245	Bearing	422-6916
5J-2246	Bearing	418-1927
5K-3968	Cage-Bearing	308-9804
5K-4079	Cage-Bearing	308-9805
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-1370	Bearing As-Rlr	416-2164
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541

7BR		
Original Part Number	Part Name	Classic Part Number
5P-2526	Cup-Rlr Bearing	380-7498
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9769	Cone-Rlr Bearing	422-6486
5S-0927	Sleeve-Wear	425-3453
5S-0928	Carrier-Ring	443-2969
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6F-7523	Cap-Bearing	325-6039
6H-2577	Spider Gp-Brg&	333-4954
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-4613	Plate-Spacer	380-7405
6I-9508	Piston-Clutch	390-5274
6J-3999	Connector	428-7631
6J-6604	Pin	419-6071
6K-8088	Bearing-Roller	399-4428
6M-1592	Bearing-Sleeve	374-1462
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536

Sales Model 834B (Cont'd.)

7BR		
Original Part Number	**Part Name**	**Classic Part Number**
6N-5300	Pulley-Cshaft	378-3979
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-0593	Bearing-Roller	386-4959
6P-6739	Shaft-Planet	308-9929
6P-8340	Sleeve	422-7895
6T-3726	Carrier As	390-5269
6T-6779	Housing As-Clu	398-2962
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4573	Carrier As	421-7243
6Y-5793	Ring-Seal	451-9028
6Y-9885	Bearing-Rlr As	396-9906
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7E-3909	Tube-Exhaust	398-8339
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7G-5749	Piston-Clutch	416-2132
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7S-4000	Piston	416-2143
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721

7BR		
Original Part Number	**Part Name**	**Classic Part Number**
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
8D-7719	Spider & Brg As	384-5946
8E-3726	Stator-Converter	394-0907
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-0067	Spacer	396-1569
8M-0874	Plunger As-Valve	311-9439
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0784	Manifold-Mount	393-1044
8N-0935	Gear-Pump Drive	399-8569
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-4550	Shaft-Pulley	445-9247
8P-4047	Shaft-Planet	373-5390
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8V-1540	Univ Jt As	388-6574
9G-1919	Gear-Planet	371-4307
9J-5875	Bearing-Sleeve	308-9830
9J-8165	Cyl Gp-050 288 Y	398-2941
9J-8166	Cylinder As	394-9834
9K-0723	Pin	396-7283
9K-0724	Collar	392-4524
9K-0725	Cap	444-0575

7BR		
Original Part Number	**Part Name**	**Classic Part Number**
9K-0726	Cap	393-3680
9K-0802	Spacer	419-0892
9K-0804	Pin	367-6092
9K-0805	Cap	415-1910
9K-0806	Cap	430-4469
9K-5639	Pin	425-6451
9L-2685	Rod End	419-1866
9M-1990	Dowel-Reaction	386-4963
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9P-5531	Gear-Sun	417-9499
9S-7949	Cup-Roller Brg	420-6531
9T-6906	Gear-Idler	419-4662
9V-3052	Plate	434-1401
9W-1566	Impeller-Conv	390-5270
9W-1572	Shaft-Xmsn Input	419-1864
9W-2977	Hub As	423-6985
9W-5768	Gear-Ring	380-7474
9W-7040	Piston-Clutch	377-7462
9Y-2988	Breather As	361-1716
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-4563	Gear-Transfer	399-4430
102-8608	Manifold-Exhaust	376-9062
105-8651	Core As-Oclr	434-9521
106-7798	Bearing-Ball	417-9494
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488

Sales Model 834B (Cont'd.)

7BR		
Original Part Number	Part Name	Classic Part Number
107-8112	Manifold-Exh	376-9063
107-9172	Piston	375-2622
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
120-3861	Bracket As	415-1897
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
123-6597	Gasket Kit	436-8421
124-0501	Cone-Spl Tapered	399-4441
124-0502	Cup-Spl Tapered	416-2161
124-0503	Cone-Spl Tapered	418-9604
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566

7BR		
Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-0985	Bearing-Sleeve	399-6056
134-0039	Housing-Piston	432-4217
135-2707	Kit-Gasket (Bsc)	392-4506
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
138-6744	Rebuild Kit-Pump	363-7457
139-9170	Gasket Kit	447-0825
140-9902	Gasket Kit	393-0916
142-1662	Kit-Gasket(F)	392-4511
142-1699	Gasket Kit	392-4507
144-1150	Gasket Kit	391-9879
145-8503	Shaft As-Idler	426-0035
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
162-0191	Gear-Planet	418-9593
162-0195	Carrier-Planet	435-4784

7BR		
Original Part Number	Part Name	Classic Part Number
162-0268	Hub As	426-3475
162-0270	Carrier-Planet	394-9819
163-3103	Manifold-Exh	430-8992
164-4891	Plate As.	391-1093
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
193-0646	Spacer	419-2310
196-6845	Yoke As	451-9034
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
217-0586	Bearing-Rod	419-7266
220-4556	Kit - Gasket	391-9878
232-6167	Kit-Gasket(Fs)	437-2035
233-9748	Disc-Friction	417-9502
234-1929	Kit-Gasket-Rs	393-1022
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
241-1399	Kit-Dt Gasket	394-9211
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

92Z		
Original Part Number	Part Name	Classic Part Number
1B-3941	Cone-Roller Brg	422-6486
1J-0774	Bracket	369-9485
1J-2087	Bushing	421-9041
1J-6747	Pin	367-6078
1M-8736	Cup-Roller Brg	423-7759
1N-3300	Shield As	374-4702
1P-1367	Plunger-Valve	432-8913
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-3958	Bearing-Needle	434-6114
1P-7522	Yoke As	382-6893
1P-7834	Cup-Bearing	380-7500

92Z		
Original Part Number	Part Name	Classic Part Number
1P-7835	Cone-Bearing	377-7399
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-0057	Plate-Clutch	377-7404
1S-1888	Bracket-Lamp	297-7147
1S-9209	Shaft-Tightener	374-6499
1T-0766	Bearing-Sleeve	383-2107
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1V-6342	Gear As	308-9847
1W-5009	Crankshaft As	398-2969

92Z		
Original Part Number	Part Name	Classic Part Number
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9490	Pulley-Alt	394-0885
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354

Sales Model 834B (Cont'd.)

92Z		
Original Part Number	**Part Name**	**Classic Part Number**
2G-1034	Valve-Safety	380-7555
2H-6489	Race-Brg Outer	374-8350
2K-5065	Cone-Roller Brg	416-2157
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1757	Hub-Fan Pulley	296-1357
2P-4470	Turbine-Conv	390-0910
2P-5861	Housing As-Rot	430-8128
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2V-4148	Shaft-Planet	388-6579
2V-4405	Housing-Brg Spt	396-0648
2V-4700	Pin	308-9894
2V-4734	Gear-Diff Ring	417-9474
2V-6129	Cover	390-5295
2V-6371	Cover As	398-8338
2V-7170	Yoke	308-9948
2W-4087	Gear As-Idler	418-9582
2W-7610	Gear-Hyd Pump Dr	418-1940
2W-7774	Ejector As-Exh	393-0914
2W-7980	Camshaft As	378-3972
2W-8038	Gear-Camshaft	425-7751
2W-8437	Muffler As	385-7198
3E-6772	Seal-Water	382-8017
3F-4971	Pin	295-5693
3G-6856	Pump Gp-Gr A	421-1556
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3J-6043	Trunnion	319-3477
3J-6559	Cap-Bearing	296-1346
3J-9097	Retainer	397-5045
3K-9604	Cage-Bearing	396-0654
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3N-6411	Cup-Rlr Bearing	423-7759
3P-2414	Housing-Clutch	391-9831
3P-2415	Carrier-Planet	396-0653

92Z		
Original Part Number	**Part Name**	**Classic Part Number**
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3246	Shaft-Planet	308-9925
3P-3429	Cage-Bearing	452-0430
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-8186	Housing-Screen	390-5261
3P-9366	Piston-Clutch	391-9861
3R-5327	Pipe-Extension	383-1571
3R-8530	Boss	425-3454
3S-1262	Retainer	308-9915
3T-2139	Housing As-Cl	394-2583
3T-5419	Impeller-Conv	416-2144
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350
3V-4046	Plate-Pressure	380-7470
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-4065	Rod End-Spher	374-1824
4E-0079	Cage-Bearing	434-4387
4E-0752	Joint Gp-Univ	435-0197
4E-2138	Gear-Sun	399-4401
4E-3604	Joint Gp-Univ	421-5542
4E-3751	Yoke As	451-0750
4F-2041	Cup-Roller Brg	418-9609
4J-4497	Cylinder Gp-Rh	399-8585
4J-4498	Cylinder Gp-Lh	425-9374
4J-7650	Retainer As	440-0851
4K-7463	Seal-Lip Type	472-8007
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722

92Z		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1186	Bearing-Sleeve	417-4519
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6302	Belt Set-Vee	314-8495
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4P-5884	Core As-Oclr	435-0196
4P-7688	Valve As-Check	420-6216
4S-5367	Mount As	375-9986
4T-0589	Slider	434-1411
4T-9311	Housing	396-0652
4V-4483	Plate-Lock	396-9933
4V-7725	Piston	394-2581
4W-4588	Sleeve	394-0218
4W-5477	Pump Gp-F Tfr	380-1512
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975

Sales Model 834B (Cont'd.)

92Z		
Original Part Number	Part Name	Classic Part Number
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-7404	Nut-Bearing Lock	308-9878
5J-2245	Bearing	422-6916
5J-2246	Bearing	418-1927
5K-3968	Cage-Bearing	308-9804
5K-4079	Cage-Bearing	308-9805
5M-0578	Bearing	419-7775
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5N-1932	Shaft-Clutch	425-0216
5P-0403	Bearing-Roller	420-6542
5P-1370	Bearing As-Rlr	416-2164
5P-2526	Cup-Rlr Bearing	380-7498
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9769	Cone-Rlr Bearing	422-6486
5P-9972	Gasket Kit	393-5207
5S-0927	Sleeve-Wear	425-3453
5S-0928	Carrier-Ring	443-2969
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6F-7523	Cap-Bearing	325-6039
6H-2577	Spider Gp-Brg&	333-4954
6H-3957	Bearing-Ball	311-9358
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714

92Z		
Original Part Number	Part Name	Classic Part Number
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-4613	Plate-Spacer	380-7405
6I-9508	Piston-Clutch	390-5274
6J-3999	Connector	428-7631
6J-6604	Pin	419-6071
6K-8088	Bearing-Roller	399-4428
6M-1592	Bearing-Sleeve	374-1462
6N-0425	Coupling-Exhaust	394-9836
6N-0977	Bearing-Sleeve	417-4524
6N-1931	Plunger	379-0171
6N-3025	Tube As	419-4656
6N-3641	Pulley-Tightener	380-7536
6N-5300	Pulley-Cshaft	378-3979
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-9133	Gasket-Plate	398-2959
6P-0593	Bearing-Roller	386-4959
6P-2923	Yoke As	382-6891
6P-6739	Shaft-Planet	308-9929
6P-8340	Sleeve	422-7895
6T-1996	Plate-Clutch	368-0117
6T-3726	Carrier As	390-5269
6T-6779	Housing As-Clu	398-2962
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574

92Z		
Original Part Number	Part Name	Classic Part Number
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4573	Carrier As	421-7243
6Y-5793	Ring-Seal	451-9028
6Y-7652	Cup-Rlr Brg	399-6067
6Y-9885	Bearing-Rlr As	396-9906
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7E-3205	Manifold-Inlet	376-9060
7E-3909	Tube-Exhaust	398-8339
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7G-5749	Piston-Clutch	416-2132
7K-5448	Cup-Bearing	415-1922
7K-6432	Retainer-Bearing	398-2933
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7N-1275	Pulley-Fan	380-7535
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-8629	Coupling-Elbow	419-4664
7S-4000	Piston	416-2143
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0182	Plunger & Bbl As	391-9893
7W-0561	Pump Gp-F Inj -B	432-8278
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475

Sales Model 834B (Cont'd.)

92Z		
Original Part Number	**Part Name**	**Classic Part Number**
7W-5435	Adapter-Nozzle	374-7493
7W-6459	Core As-Oclr	395-1313
8D-7719	Spider & Brg As	384-5946
8E-3726	Stator-Converter	394-0907
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-0067	Spacer	396-1569
8M-0874	Plunger As-Valve	311-9439
8N-0111	Mount As	374-1452
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0784	Manifold-Mount	393-1044
8N-0788	Cover	440-0849
8N-0935	Gear-Pump Drive	399-8569
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726
8N-1628	Shaft As-F Pump	383-3703
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2368	Shield As	449-9547
8N-3666	Repair Kt-Major	377-5842
8N-4550	Shaft-Pulley	445-9247
8P-0514	Yoke As	308-9947
8P-4047	Shaft-Planet	373-5390
8R-9750	Gear-Planet	391-9869
8S-6511	Bearing-Sleeve	380-7372
8T-2500	Kit-Gasket	393-1028
8V-1540	Univ Jt As	388-6574

92Z		
Original Part Number	**Part Name**	**Classic Part Number**
8V-1612	Shaft	425-6456
9C-4202	Ring	424-0127
9G-1919	Gear-Planet	371-4307
9J-5875	Bearing-Sleeve	308-9830
9J-8165	Cyl Gp-050 288 Y	398-2941
9J-8166	Cylinder As	394-9834
9K-0723	Pin	396-7283
9K-0724	Collar	392-4524
9K-0725	Cap	444-0575
9K-0726	Cap	393-3680
9K-0802	Spacer	419-0892
9K-0804	Pin	367-6092
9K-0805	Cap	415-1910
9K-0806	Cap	430-4469
9K-5639	Pin	425-6451
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9L-5961	Adapter-Compr Dr	416-5508
9M-1990	Dowel-Reaction	386-4963
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9P-5531	Gear-Sun	417-9499
9S-7949	Cup-Roller Brg	420-6531
9T-6906	Gear-Idler	419-4662
9U-0465	Shaft-Pinion	394-0904
9U-0466	Gear-Bevel	418-9587
9V-1290	Wheel	396-9946
9V-3052	Plate	434-1401
9W-1566	Impeller-Conv	390-5270
9W-1572	Shaft-Xmsn Input	419-1864
9W-2977	Hub As	423-6985
9W-5768	Gear-Ring	380-7474
9W-7040	Piston-Clutch	377-7462
9W-9930	Mount As	295-6437
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482

92Z		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-2988	Breather As	361-1716
9Y-3317	Core As-Radiator	378-3996
9Y-3969	Line As-Fuel Inj	378-3998
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
102-4563	Gear-Transfer	399-4430
102-8608	Manifold-Exhaust	376-9062
105-8651	Core As-Oclr	434-9521
106-7798	Bearing-Ball	417-9494
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
120-3861	Bracket As	415-1897
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-0501	Cone-Spl Tapered	399-4441
124-0502	Cup-Spl Tapered	416-2161

Sales Model 834B (Cont'd.)

92Z		
Original Part Number	**Part Name**	**Classic Part Number**
124-0503	Cone-Spl Tapered	418-9604
124-7609	Gear-Pump Idler	428-8504
127-6356	Cover As.-Pump	420-8566
129-3068	Rebuild Kit-Pump	363-7455
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-0985	Bearing-Sleeve	399-6056
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1970	Impeller-Pump	380-1553

92Z		
Original Part Number	**Part Name**	**Classic Part Number**
137-6500	Rotocoil As.	397-5053
139-9170	Gasket Kit	447-0825
144-1150	Gasket Kit	391-9879
145-8503	Shaft As-Idler	426-0035
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
162-0191	Gear-Planet	418-9593
162-0268	Hub As	426-3475
162-0270	Carrier-Planet	394-9819
163-3103	Manifold-Exh	430-8992
164-4891	Plate As.	391-1093
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
180-6645	Shaft As.	396-1566
193-0646	Spacer	419-2310
196-6845	Yoke As	451-9034

92Z		
Original Part Number	**Part Name**	**Classic Part Number**
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
217-0586	Bearing-Rod	419-7266
220-4556	Kit - Gasket	391-9878
232-1841	Kit-Gasket (Fs)	387-2922
233-8669	Kit-Gasket-Mch	393-1038
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
241-1399	Kit-Dt Gasket	394-9211
253-1752	Plate-Thrust	379-0170
283-5666	Gasket-Cyl Head	388-6565
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0209	Pump Gp-Water -B	375-4336

Sales Model 834G

6GZ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1S-0057	Plate-Clutch	377-7404
1T-0807	Race-Thrust Brg	453-3651
1T-1401	Ring-Seal	384-4799
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2H-6489	Race-Brg Outer	374-8350
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305
2P-4470	Turbine-Conv	390-0910

6GZ		
Original Part Number	**Part Name**	**Classic Part Number**
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3246	Shaft-Planet	308-9925
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-7489	Plate-Clutch	377-7423

6GZ		
Original Part Number	**Part Name**	**Classic Part Number**
3S-1262	Retainer	308-9915
3T-2139	Housing As-Cl	394-2583
3T-6175	Gear-Transfer	398-8351
3V-4046	Plate-Pressure	380-7470
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-0079	Cage-Bearing	434-4387
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4T-0589	Slider	434-1411
4T-7534	Pin	433-9209

Sales Model 834G (Cont'd.)

6GZ		
Original Part Number	**Part Name**	**Classic Part Number**
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-6298	Cup-Spl Tapered	399-6063
5J-2528	Plunger	391-1318
5K-3968	Cage-Bearing	308-9804
5K-4079	Cage-Bearing	308-9805
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-7807	Bearing-Ball	314-8502
5P-9769	Cone-Rlr Bearing	422-6486
6F-7523	Cap-Bearing	325-6039
6I-2726	Bearing-Sleeve	419-4757
6J-3999	Connector	428-7631
6J-5179	Retainer	380-7406
6J-6604	Pin	419-6071
6M-1592	Bearing-Sleeve	374-1462
6N-1931	Plunger	379-0171
6P-0593	Bearing-Roller	386-4959
6P-6739	Shaft-Planet	308-9929
6V-3831	Seal-O-Ring	436-2657
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-9885	Bearing-Rlr As	396-9906
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857

6GZ		
Original Part Number	**Part Name**	**Classic Part Number**
7G-5746	Housing-Clutch	392-4520
7J-1309	Bearing-Aligning	360-2275
7K-8877	Cone-Bearing	374-1847
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7S-4000	Piston	416-2143
7W-3145	Plate	422-7894
8C-3111	Rod End-Spher	392-4523
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8K-0067	Spacer	396-1569
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9J-0123	Trunnion	325-6227
9M-4370	Bearing-Sleeve	453-6515
9N-3167	Plate-Block Bot	430-4468
9P-5531	Gear-Sun	417-9499
9S-7949	Cup-Roller Brg	420-6531
9T-5360	Plate-Pressure	424-4941
9W-1572	Shaft-Xmsn Input	419-1864
9W-2977	Hub As	423-6985
9W-7040	Piston-Clutch	377-7462
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725

6GZ		
Original Part Number	**Part Name**	**Classic Part Number**
106-7798	Bearing-Ball	417-9494
107-9172	Piston	375-2622
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
124-0501	Cone-Spl Tapered	399-4441
124-0502	Cup-Spl Tapered	416-2161
124-0503	Cone-Spl Tapered	418-9604
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
134-0039	Housing-Piston	432-4217
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
164-4891	Plate As.	391-1093
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368

Sales Model 834G (Cont'd.)

6GZ		
Original Part Number	Part Name	Classic Part Number
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202

6GZ		
Original Part Number	Part Name	Classic Part Number
237-9849	Cage-Bearing	443-1201
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665

6GZ		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-6387
336-4979	Kit-Gasket(Dt)	451-1511
430-7619	Adapter-Cla	438-1812

BPC		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1S-0057	Plate-Clutch	377-7404
1T-0807	Race-Thrust Brg	453-3651
1T-1401	Ring-Seal	384-4799
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2H-6489	Race-Brg Outer	374-8350
2J-2152	Cup-Roller Brg	374-1852
2P-4470	Turbine-Conv	390-0910
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3246	Shaft-Planet	308-9925
3P-3505	Shaft-Brake	384-3477

BPC		
Original Part Number	Part Name	Classic Part Number
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-7489	Plate-Clutch	377-7423
3S-1262	Retainer	308-9915
3T-2139	Housing As-Cl	394-2583
3T-6175	Gear-Transfer	398-8351
3V-4046	Plate-Pressure	380-7470
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-0079	Cage-Bearing	434-4387
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4T-0589	Slider	434-1411
4T-7534	Pin	433-9209
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-6298	Cup-Spl Tapered	399-6063
5J-2528	Plunger	391-1318
5K-3968	Cage-Bearing	308-9804
5K-4079	Cage-Bearing	308-9805
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541

BPC		
Original Part Number	Part Name	Classic Part Number
5P-9769	Cone-Rlr Bearing	422-6486
5T-5682	Driver	418-9579
6F-7523	Cap-Bearing	325-6039
6I-2726	Bearing-Sleeve	419-4757
6J-3999	Connector	428-7631
6J-5179	Retainer	380-7406
6J-6604	Pin	419-6071
6M-1592	Bearing-Sleeve	374-1462
6N-1931	Plunger	379-0171
6P-0593	Bearing-Roller	386-4959
6P-6739	Shaft-Planet	308-9929
6V-3831	Seal-O-Ring	436-2657
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4457	Bearing-Aligning	420-2504
6Y-5793	Ring-Seal	451-9028
6Y-9885	Bearing-Rlr As	396-9906
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7I-7181	Piston	393-5217
7J-1309	Bearing-Aligning	360-2275

Sales Model 834G (Cont'd.)

BPC		
Original Part Number	Part Name	Classic Part Number
7K-0078	Bearing-Sleeve	308-9825
7K-8877	Cone-Bearing	374-1847
7N-2156	Bearing-Sleeve	380-7373
7S-4000	Piston	416-2143
7W-3145	Plate	422-7894
7Y-0680	Piston	360-2262
8C-3111	Rod End-Spher	392-4523
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8K-0067	Spacer	396-1569
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9J-0123	Trunnion	325-6227
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9N-3167	Plate-Block Bot	430-4468
9P-5531	Gear-Sun	417-9499
9S-7949	Cup-Roller Brg	420-6531
9T-5360	Plate-Pressure	424-4941
9W-1572	Shaft-Xmsn Input	419-1864
9W-2977	Hub As	423-6985
9W-7040	Piston-Clutch	377-7462
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

BPC		
Original Part Number	Part Name	Classic Part Number
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8112	Cylinder	360-2276
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
106-7798	Bearing-Ball	417-9494
107-9172	Piston	375-2622
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
124-0501	Cone-Spl Tapered	399-4441
124-0502	Cup-Spl Tapered	416-2161
124-0503	Cone-Spl Tapered	418-9604
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
134-0039	Housing-Piston	432-4217
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052

BPC		
Original Part Number	Part Name	Classic Part Number
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
164-4891	Plate As.	391-1093
176-3900	Accumulator	416-5513
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
336-4979	Kit-Gasket(Dt)	451-1511
357-7540	Valve-Fill	360-2292

Sales Model 834H

BTX		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500

BTX		
Original Part Number	Part Name	Classic Part Number
1P-7835	Cone-Bearing	377-7399
1T-0807	Race-Thrust Brg	453-3651
1T-1401	Ring-Seal	384-4799

BTX		
Original Part Number	Part Name	Classic Part Number
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174

Sales Model 834H (Cont'd.)

BTX		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2H-6489	Race-Brg Outer	374-8350
2J-2152	Cup-Roller Brg	374-1852
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2P-4470	Turbine-Conv	390-0910
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3246	Shaft-Planet	308-9925
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-7489	Plate-Clutch	377-7423
3S-1262	Retainer	308-9915
3T-6175	Gear-Transfer	398-8351
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4T-0589	Slider	434-1411
4T-7534	Pin	433-9209
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-6298	Cup-Spl Tapered	399-6063
5J-2528	Plunger	391-1318
5K-3968	Cage-Bearing	308-9804

BTX		
Original Part Number	Part Name	Classic Part Number
5K-4079	Cage-Bearing	308-9805
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-9769	Cone-Rlr Bearing	422-6486
5T-5682	Driver	418-9579
6F-7523	Cap-Bearing	325-6039
6J-3999	Connector	428-7631
6J-5179	Retainer	380-7406
6J-6604	Pin	419-6071
6M-1592	Bearing-Sleeve	374-1462
6N-1931	Plunger	379-0171
6P-6739	Shaft-Planet	308-9929
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4457	Bearing-Aligning	420-2504
6Y-5793	Ring-Seal	451-9028
6Y-9885	Bearing-Rlr As	396-9906
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7I-7181	Piston	393-5217
7J-1309	Bearing-Aligning	360-2275
7K-0078	Bearing-Sleeve	308-9825
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7Y-0680	Piston	360-2262
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639

BTX		
Original Part Number	Part Name	Classic Part Number
8K-0067	Spacer	396-1569
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9D-7924	Mount As	360-2356
9J-0123	Trunnion	325-6227
9M-1853	Mount As.	376-3638
9M-4370	Bearing-Sleeve	453-6515
9N-3167	Plate-Block Bot	430-4468
9P-5531	Gear-Sun	417-9499
9S-7949	Cup-Roller Brg	420-6531
9W-1572	Shaft-Xmsn Input	419-1864
9W-2977	Hub As	423-6985
9W-7040	Piston-Clutch	377-7462
9W-9930	Mount As	295-6437
101-3125	Gasket	420-8567
102-8112	Cylinder	360-2276
106-7798	Bearing-Ball	417-9494
107-9172	Piston	375-2622
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
124-0501	Cone-Spl Tapered	399-4441
124-0502	Cup-Spl Tapered	416-2161
124-0503	Cone-Spl Tapered	418-9604
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
134-0039	Housing-Piston	432-4217
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052

Wheel Dozers

Sales Model 834H (Cont'd.)

BTX		
Original Part Number	**Part Name**	**Classic Part Number**
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
164-4891	Plate As.	391-1093
176-3900	Accumulator	416-5513
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656

BTX		
Original Part Number	**Part Name**	**Classic Part Number**
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201

BTX		
Original Part Number	**Part Name**	**Classic Part Number**
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
357-7540	Valve-Fill	360-2292

Sales Model 834K

LWY		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-1401	Ring-Seal	384-4799
1U-0873	Pin	325-6137
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-6489	Race-Brg Outer	374-8350
2J-2152	Cup-Roller Brg	374-1852
2P-4470	Turbine-Conv	390-0910
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3K-9608	Guard-Dirt	374-1447
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3P-3059	Gear-Sun	308-9861

LWY		
Original Part Number	**Part Name**	**Classic Part Number**
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3246	Shaft-Planet	308-9925
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3R-8530	Boss	425-3454
3S-1262	Retainer	308-9915
3T-6175	Gear-Transfer	398-8351
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4T-0589	Slider	434-1411
4T-7534	Pin	433-9209
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-6298	Cup-Spl Tapered	399-6063
5K-3968	Cage-Bearing	308-9804
5K-4079	Cage-Bearing	308-9805
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542

LWY		
Original Part Number	**Part Name**	**Classic Part Number**
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-9769	Cone-Rlr Bearing	422-6486
6J-3999	Connector	428-7631
6J-5179	Retainer	380-7406
6J-6604	Pin	419-6071
6N-1931	Plunger	379-0171
6P-6739	Shaft-Planet	308-9929
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4457	Bearing-Aligning	420-2504
6Y-5793	Ring-Seal	451-9028
6Y-9885	Bearing-Rlr As	396-9906
7C-0145	Core As-Oclr	374-4720
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7I-7181	Piston	393-5217
7J-1309	Bearing-Aligning	360-2275
7J-5131	Trunnion	296-1371
7K-0078	Bearing-Sleeve	308-9825
7N-2156	Bearing-Sleeve	380-7373
7N-7878	Cover-Plate	434-2401
8E-6752	Bearing-Sleeve	388-6576

Sales Model 834K (Cont'd.)

LWY		
Original Part Number	Part Name	Classic Part Number
8E-6758	Connector As	396-0639
8J-2880	Cap-Bearing	295-6420
8K-0067	Spacer	396-1569
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9D-7924	Mount As	360-2356
9J-0123	Trunnion	325-6227
9P-5531	Gear-Sun	417-9499
9S-7949	Cup-Roller Brg	420-6531
9W-1572	Shaft-Xmsn Input	419-1864
9W-2977	Hub As	423-6985
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
9W-9931	Mount As.	360-2354
100-8010	Valve	423-5583

LWY		
Original Part Number	Part Name	Classic Part Number
101-3125	Gasket	420-8567
106-7798	Bearing-Ball	417-9494
107-9172	Piston	375-2622
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
124-0501	Cone-Spl Tapered	399-4441
124-0502	Cup-Spl Tapered	416-2161
127-6356	Cover As.-Pump	420-8566
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

LWY		
Original Part Number	Part Name	Classic Part Number
134-0039	Housing-Piston	432-4217
138-9381	Plate-Spacer	424-7052
150-1916	Manifold-Exh	395-1322
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443

TWY		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1T-0679	Roller-Freewheel	384-4797
1T-0766	Bearing-Sleeve	383-2107
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-1401	Ring-Seal	384-4799
1U-0873	Pin	325-6137
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-6489	Race-Brg Outer	374-8350
2J-2152	Cup-Roller Brg	374-1852
2P-4470	Turbine-Conv	390-0910
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3K-9608	Guard-Dirt	374-1447

TWY		
Original Part Number	Part Name	Classic Part Number
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3P-1210	Cone-Roller Brg	399-4433
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3246	Shaft-Planet	308-9925
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3R-8530	Boss	425-3454
3S-1262	Retainer	308-9915
3T-6175	Gear-Transfer	398-8351
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4F-2041	Cup-Roller Brg	418-9609
4J-6374	Bearing-Sleeve	295-6407
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4T-0589	Slider	434-1411
4T-7534	Pin	433-9209
4W-5698	Bearing-Main	419-6323

TWY		
Original Part Number	Part Name	Classic Part Number
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-6298	Cup-Spl Tapered	399-6063
5K-3968	Cage-Bearing	308-9804
5K-4079	Cage-Bearing	308-9805
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-9769	Cone-Rlr Bearing	422-6486
6J-3999	Connector	428-7631
6J-5179	Retainer	380-7406
6J-6604	Pin	419-6071
6N-1931	Plunger	379-0171
6P-6739	Shaft-Planet	308-9929
6Y-3484	Bearing-Spl Ball	416-2166

Sales Model 834K (Cont'd.)

TWY		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-4457	Bearing-Aligning	420-2504
6Y-5793	Ring-Seal	451-9028
6Y-9885	Bearing-Rlr As	396-9906
7C-0145	Core As-Oclr	374-4720
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7I-7181	Piston	393-5217
7J-1309	Bearing-Aligning	360-2275
7J-5131	Trunnion	296-1371
7K-0078	Bearing-Sleeve	308-9825
7N-2156	Bearing-Sleeve	380-7373
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8J-2880	Cap-Bearing	295-6420
8K-0067	Spacer	396-1569
8N-2104	Bell As-Suction	380-1521

TWY		
Original Part Number	**Part Name**	**Classic Part Number**
8S-6511	Bearing-Sleeve	380-7372
9D-7924	Mount As	360-2356
9J-0123	Trunnion	325-6227
9P-5531	Gear-Sun	417-9499
9S-7949	Cup-Roller Brg	420-6531
9W-1572	Shaft-Xmsn Input	419-1864
9W-2977	Hub As	423-6985
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
9W-9931	Mount As.	360-2354
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
106-7798	Bearing-Ball	417-9494
107-9172	Piston	375-2622
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
124-0501	Cone-Spl Tapered	399-4441

TWY		
Original Part Number	**Part Name**	**Classic Part Number**
124-0502	Cup-Spl Tapered	416-2161
127-6356	Cover As.-Pump	420-8566
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
134-0039	Housing-Piston	432-4217
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
253-1752	Plate-Thrust	379-0170

Sales Model 844

2KZ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1N-3113	Support-Elbow	433-8185
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-4695	Cup-Rlr Bearing	374-1842
1P-4696	Cone-Rlr Bearing	374-1843
1S-9110	Bearing-Needle	420-2497

2KZ		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0576	Bearing-Sleeve	379-0186
1T-0766	Bearing-Sleeve	383-2107
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-1401	Ring-Seal	384-4799
1U-3953	Cartridge Gp	426-0024
1W-3900	Gasket	472-8006
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934

2KZ		
Original Part Number	**Part Name**	**Classic Part Number**
2P-0220	Gasket-Pump	398-2927
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-4470	Turbine-Conv	390-0910
2S-6097	Tang	375-9979
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-2752	Cartridge Gp-Rr	422-8127
3G-5285	Bearing-Sleeve	360-2312
3G-7663	Cartridge Gp	422-8120

Sales Model 844 (Cont'd.)

2KZ		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
3W-7770	Tube As	385-7227
4D-7534	Bearing As-Rlr	441-5602
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1157	Coupling-Exhaust	379-0177
4N-1186	Bearing-Sleeve	417-4519
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4Q-1346	Link As-Bearing&	425-3649
4T-0406	Rod As	394-8215
4T-4073	Valve Gp-Shtl -B	439-1138
4T-7534	Pin	433-9209
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2883	Bearing-Sleeve	379-0193
4W-0419	Core As-Oclr	379-0182
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333

2KZ		
Original Part Number	Part Name	Classic Part Number
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-7404	Nut-Bearing Lock	308-9878
5J-1192	Bearing-Sleeve	374-8355
5J-1193	Bearing-Sleeve	382-8046
5J-2528	Plunger	391-1318
5L-5772	Race & Roller As	394-9200
5M-7925	Bearing-Roller	419-7774
5P-7807	Bearing-Ball	314-8502
5P-8043	Bearing-Cone	423-6989
5S-1211	Cover-Valve	314-8665
6E-6153	Plate-Port	346-5678
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-5179	Retainer	380-7406
6N-0977	Bearing-Sleeve	417-4524
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6P-8340	Sleeve	422-7895
6V-3831	Seal-O-Ring	436-2657
6W-7352	Retainer	424-0741
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5996	Rod As-Conn	379-8864
7J-1335	Bearing-Sleeve	380-7567
7J-1336	Bearing-Sleeve	384-4776
7K-8877	Cone-Bearing	374-1847
7N-2156	Bearing-Sleeve	380-7373

2KZ		
Original Part Number	Part Name	Classic Part Number
7N-2957	Cover-Rad Cap	361-1722
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-7809	Cap As-Radiator	295-6417
7T-2879	Trunnion As	396-7262
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8J-7466	Seat	385-3787
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8N-7257	Mount As	396-0660
8S-6511	Bearing-Sleeve	380-7372
9C-3095	Spider Gp-Brg&	394-8219
9D-7924	Mount As	360-2356
9J-0123	Trunnion	325-6227
9J-2365	Retainer	325-6186
9J-5284	Bearing-Sleeve	380-7379
9M-2744	Cone-Spl Tapered	380-1480
9N-3668	Base As.-Coolant	419-4718
9P-8663	Spacer	422-9521
9V-9833	Gear-Bevel	394-8243
9V-9840	Spider	417-9498
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
107-8106	Manifold-Exh	374-7487
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463

Sales Model 844 (Cont'd.)

2KZ		
Original Part Number	**Part Name**	**Classic Part Number**
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-4237	Pulley-Idler	374-4693
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
120-3861	Bracket As	415-1897
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-8181	Cone-Spl Tapered	434-3295
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
135-2707	Kit-Gasket (Bsc)	392-4506

2KZ		
Original Part Number	**Part Name**	**Classic Part Number**
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
140-2749	Gasket Kit	393-1033
141-0338	Kit-Gasket(Acl)	437-3215
141-0340	Kit-Gasket(F)	436-8402
141-0345	Gasket Kit	437-3227
141-0348	Gasket Kit	437-4579
141-4109	Core As-Oclr	416-5518
142-3035	Kit-Gasket (Wlg)	393-0926
155-6637	Gear-Oil Drive	425-9189
157-0956	Pump Gp-Vn Bsc-B	422-8154
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048

2KZ		
Original Part Number	**Part Name**	**Classic Part Number**
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
164-4413	Mount	419-0876
180-6645	Shaft As.	396-1566
210-2154	Kit-Gasket-Trans	394-8232
210-2155	Kit-Gasket-Trans	434-7285
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
221-6947	Kit - Gasket	394-9209
232-6148	Kit-Gasket(Rs)	437-2036
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

BBN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1N-3113	Support-Elbow	433-8185
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-4695	Cup-Rlr Bearing	374-1842
1P-4696	Cone-Rlr Bearing	374-1843
1S-9110	Bearing-Needle	420-2497
1T-0576	Bearing-Sleeve	379-0186
1T-0766	Bearing-Sleeve	383-2107
1T-0787	Plate-Freewheel	430-8131

BBN		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0807	Race-Thrust Brg	453-3651
1T-1401	Ring-Seal	384-4799
1U-3953	Cartridge Gp	426-0024
2A-4429	Lock-Retainer	379-0174
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-4470	Turbine-Conv	390-0910
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-8038	Gear-Camshaft	425-7751
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-2752	Cartridge Gp-Rr	422-8127
3G-7663	Cartridge Gp	422-8120
3H-8726	Mount As	385-7208

BBN		
Original Part Number	**Part Name**	**Classic Part Number**
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4D-7534	Bearing As-Rlr	441-5602
4N-0342	Plate-Cam Thrust	375-9974
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1157	Coupling-Exhaust	379-0177
4N-1186	Bearing-Sleeve	417-4519
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710

Sales Model 844 (Cont'd.)

BBN		
Original Part Number	Part Name	Classic Part Number
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-8472	Housing-Aftclr	419-0887
4T-0406	Rod As	394-8215
4T-4073	Valve Gp-Shtl -B	439-1138
4T-7534	Pin	433-9209
4W-0419	Core As-Oclr	379-0182
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-7404	Nut-Bearing Lock	308-9878
5J-1192	Bearing-Sleeve	374-8355
5J-1193	Bearing-Sleeve	382-8046
5J-2528	Plunger	391-1318
5L-5772	Race & Roller As	394-9200
5M-7925	Bearing-Roller	419-7774
5P-7807	Bearing-Ball	314-8502
5P-8043	Bearing-Cone	423-6989
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-5179	Retainer	380-7406
6N-0977	Bearing-Sleeve	417-4524
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6P-8340	Sleeve	422-7895
6V-3831	Seal-O-Ring	436-2657

BBN		
Original Part Number	Part Name	Classic Part Number
6W-7352	Retainer	424-0741
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7E-5996	Rod As-Conn	379-8864
7J-1335	Bearing-Sleeve	380-7567
7J-1336	Bearing-Sleeve	384-4776
7K-8877	Cone-Bearing	374-1847
7N-2156	Bearing-Sleeve	380-7373
7T-2879	Trunnion As	396-7262
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8J-7466	Seat	385-3787
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9C-3095	Spider Gp-Brg&	394-8219
9D-7924	Mount As	360-2356
9J-0123	Trunnion	325-6227
9J-2365	Retainer	325-6186
9J-5284	Bearing-Sleeve	380-7379
9M-2744	Cone-Spl Tapered	380-1480
9P-8663	Spacer	422-9521
9V-9833	Gear-Bevel	394-8243
9V-9840	Spider	417-9498
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
100-6920	Adapter-Nozzle	380-1552
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
107-8106	Manifold-Exh	374-7487

BBN		
Original Part Number	Part Name	Classic Part Number
108-5603	Screw-Adj Arm	379-0166
108-7930	Bearing As	377-7463
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-4237	Pulley-Idler	374-4693
115-6469	Spacer	425-3645
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
126-8181	Cone-Spl Tapered	434-3295
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
141-4109	Core As-Oclr	416-5518
142-3035	Kit-Gasket (Wlg)	393-0926
155-6637	Gear-Oil Drive	425-9189
157-0956	Pump Gp-Vn Bsc-B	422-8154
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
164-4413	Mount	419-0876
180-6645	Shaft As.	396-1566
210-2154	Kit-Gasket-Trans	394-8232
211-0592	Bearing - Main	419-6368
217-0586	Bearing-Rod	419-7266
221-6947	Kit - Gasket	394-9209
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202

Sales Model 844 (Cont'd.)

BBN		
Original Part Number	**Part Name**	**Classic Part Number**
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367

BBN		
Original Part Number	**Part Name**	**Classic Part Number**
328-5574	Bearing-Rod	419-7266
352-0200	Pump Gp-Water -B	434-6109

Sales Model 844H

BTW		
Original Part Number	**Part Name**	**Classic Part Number**
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-4695	Cup-Rlr Bearing	374-1842
1P-4696	Cone-Rlr Bearing	374-1843
1S-9110	Bearing-Needle	420-2497
1T-0576	Bearing-Sleeve	379-0186
1T-0766	Bearing-Sleeve	383-2107
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-1401	Ring-Seal	384-4799
1U-3953	Cartridge Gp	426-0024
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-4470	Turbine-Conv	390-0910
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
3E-6772	Seal-Water	382-8017

BTW		
Original Part Number	**Part Name**	**Classic Part Number**
3G-0910	Cap-Bearing	325-6037
3G-2752	Cartridge Gp-Rr	422-8127
3G-7663	Cartridge Gp	422-8120
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3P-1210	Cone-Roller Brg	399-4433
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4D-7534	Bearing As-Rlr	441-5602
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-6658	Bearing-Sleeve	373-1885
4T-0406	Rod As	394-8215
4T-4073	Valve Gp-Shtl -B	439-1138
4T-7534	Pin	433-9209
4W-0419	Core As-Oclr	379-0182
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-7404	Nut-Bearing Lock	308-9878

BTW		
Original Part Number	**Part Name**	**Classic Part Number**
5J-1192	Bearing-Sleeve	374-8355
5J-1193	Bearing-Sleeve	382-8046
5J-2528	Plunger	391-1318
5L-5772	Race & Roller As	394-9200
5M-7925	Bearing-Roller	419-7774
5P-8043	Bearing-Cone	423-6989
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-5179	Retainer	380-7406
6N-0977	Bearing-Sleeve	417-4524
6P-8340	Sleeve	422-7895
6V-3831	Seal-O-Ring	436-2657
6W-7352	Retainer	424-0741
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7J-1335	Bearing-Sleeve	380-7567
7J-1336	Bearing-Sleeve	384-4776
7K-8877	Cone-Bearing	374-1847
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-2879	Trunnion As	396-7262
7V-0638	Spacer	425-3651
7W-3145	Plate	422-7894
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8J-7466	Seat	385-3787

Sales Model 844H (Cont'd.)

BTW		
Original Part Number	**Part Name**	**Classic Part Number**
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9D-7924	Mount As	360-2356
9J-0123	Trunnion	325-6227
9J-2365	Retainer	325-6186
9J-5284	Bearing-Sleeve	380-7379
9M-2744	Cone-Spl Tapered	380-1480
9V-9840	Spider	417-9498
9W-9930	Mount As	295-6437
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-7930	Bearing As	377-7463
115-6469	Spacer	425-3645

BTW		
Original Part Number	**Part Name**	**Classic Part Number**
117-9712	Shaft-Dr Idler	425-7754
126-8181	Cone-Spl Tapered	434-3295
127-6356	Cover As.-Pump	420-8566
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
141-4109	Core As-Oclr	416-5518
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
157-0956	Pump Gp-Vn Bsc-B	422-8154

BTW		
Original Part Number	**Part Name**	**Classic Part Number**
160-9874	Kit-Gasket-Scl	386-3048
163-3103	Manifold-Exh	430-8992
164-4413	Mount	419-0876
173-0888	Univ Jt As	394-0898
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
221-6947	Kit - Gasket	394-9209
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
238-0293	Adapter-Jacket	424-0742
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
352-0200	Pump Gp-Water -B	434-6109

Sales Model 844K

KLS		
Original Part Number	**Part Name**	**Classic Part Number**
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-4695	Cup-Rlr Bearing	374-1842
1P-4696	Cone-Rlr Bearing	374-1843
1S-9110	Bearing-Needle	420-2497
1T-0766	Bearing-Sleeve	383-2107
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651

KLS		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1401	Ring-Seal	384-4799
1U-3953	Cartridge Gp	426-0024
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-7663	Cartridge Gp	422-8120
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4D-7534	Bearing As-Rlr	441-5602
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1849	Pipe-Air	421-7143

KLS		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2514	Gear-Flywheel	421-7283
4N-6658	Bearing-Sleeve	373-1885
4T-0406	Rod As	394-8215
4T-4073	Valve Gp-Shtl -B	439-1138
4T-7534	Pin	433-9209
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-7404	Nut-Bearing Lock	308-9878
5J-1192	Bearing-Sleeve	374-8355
5J-2528	Plunger	391-1318
5L-5772	Race & Roller As	394-9200

Sales Model 844K (Cont'd.)

KLS		
Original Part Number	**Part Name**	**Classic Part Number**
5M-7925	Bearing-Roller	419-7774
5P-8043	Bearing-Cone	423-6989
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-5179	Retainer	380-7406
6W-7352	Retainer	424-0741
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7J-1335	Bearing-Sleeve	380-7567
7J-1336	Bearing-Sleeve	384-4776
7K-8877	Cone-Bearing	374-1847
7N-2156	Bearing-Sleeve	380-7373
7T-2879	Trunnion As	396-7262
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639

KLS		
Original Part Number	**Part Name**	**Classic Part Number**
8J-7466	Seat	385-3787
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
9J-0123	Trunnion	325-6227
9J-2365	Retainer	325-6186
9J-5284	Bearing-Sleeve	380-7379
9M-2744	Cone-Spl Tapered	380-1480
9V-9840	Spider	417-9498
9W-9930	Mount As	295-6437
101-3374	Gear-Camshaft Dr	376-9069
108-7930	Bearing As	377-7463
117-9712	Shaft-Dr Idler	425-7754
126-8181	Cone-Spl Tapered	434-3295
127-6356	Cover As.-Pump	420-8566

KLS		
Original Part Number	**Part Name**	**Classic Part Number**
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
157-0956	Pump Gp-Vn Bsc-B	422-8154
160-9874	Kit-Gasket-Scl	386-3048
173-0888	Univ Jt As	394-0898
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
238-0293	Adapter-Jacket	424-0742
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367

MBE		
Original Part Number	**Part Name**	**Classic Part Number**
1B-6577	Cone-Spl Tapered	374-1839
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-4695	Cup-Rlr Bearing	374-1842
1P-4696	Cone-Rlr Bearing	374-1843
1S-9110	Bearing-Needle	420-2497
1T-0766	Bearing-Sleeve	383-2107
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-1401	Ring-Seal	384-4799

MBE		
Original Part Number	**Part Name**	**Classic Part Number**
1U-3953	Cartridge Gp	426-0024
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2J-2152	Cup-Roller Brg	374-1852
2L-5271	Bearing-Ball	371-4305
3E-6772	Seal-Water	382-8017
3G-0910	Cap-Bearing	325-6037
3G-7663	Cartridge Gp	422-8120
3H-8726	Mount As	385-7208
3J-2903	Cover	422-6922
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
4D-7534	Bearing As-Rlr	441-5602
4N-0342	Plate-Cam Thrust	375-9974
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1849	Pipe-Air	421-7143
4N-2514	Gear-Flywheel	421-7283
4N-6658	Bearing-Sleeve	373-1885

MBE		
Original Part Number	**Part Name**	**Classic Part Number**
4T-0406	Rod As	394-8215
4T-4073	Valve Gp-Shtl -B	439-1138
4T-7534	Pin	433-9209
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-7449	Cup-Spl Tapered	416-2161
5F-1248	Cone-Roller Brg	399-4441
5F-7404	Nut-Bearing Lock	308-9878
5J-1192	Bearing-Sleeve	374-8355
5J-2528	Plunger	391-1318
5L-5772	Race & Roller As	394-9200
5M-7925	Bearing-Roller	419-7774
5P-8043	Bearing-Cone	423-6989
6I-8849	Cone-Rlr Bearing	415-1919

Sales Model 844K (Cont'd.)

MBE		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
6J-5179	Retainer	380-7406
6W-7352	Retainer	424-0741
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7J-1335	Bearing-Sleeve	380-7567
7J-1336	Bearing-Sleeve	384-4776
7K-8877	Cone-Bearing	374-1847
7N-2156	Bearing-Sleeve	380-7373
7T-2879	Trunnion As	396-7262
8E-6752	Bearing-Sleeve	388-6576
8E-6758	Connector As	396-0639
8J-7466	Seat	385-3787
8N-2104	Bell As-Suction	380-1521

MBE		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
9J-0123	Trunnion	325-6227
9J-2365	Retainer	325-6186
9J-5284	Bearing-Sleeve	380-7379
9M-2744	Cone-Spl Tapered	380-1480
9V-9840	Spider	417-9498
9W-9930	Mount As	295-6437
101-3374	Gear-Camshaft Dr	376-9069
108-7930	Bearing As	377-7463
117-9712	Shaft-Dr Idler	425-7754
126-8181	Cone-Spl Tapered	434-3295
127-6356	Cover As.-Pump	420-8566

MBE		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
157-0956	Pump Gp-Vn Bsc-B	422-8154
160-9874	Kit-Gasket-Scl	386-3048
173-0888	Univ Jt As	394-0898
186-2001	Rotocoil As	397-5055
211-0592	Bearing - Main	419-6368
216-5582	Bearing-Sleeve	390-0914
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
238-0293	Adapter-Jacket	424-0742
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367

Cat Classic Parts for Wheel Loaders

Cat Wheel loaders are designed to deliver exceptional performance, ease of serviceability, and to have long, productive lives. The residual value of a machine depreciates As. it gets older, so maintenance costs often need to be re-evaluated. Caterpillar offers Cat Classic parts for several models of Wheel loaders (920, 930, 950/B/E, 966A/B/C/D/E, 980/B/C) to help you manage those maintenance costs.

Cat Classic parts provide owners of older Cat products with low cost Repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts coverage for Wheel loaders includes:

- Axle Final Drive
- Circle/Center Shift Linkage Pin
- Differential Torque Converter
- Engine
- Final Drive
- Transmission
- ...and many more.

Sales Model 901B

W7A		
Original Part Number	**Part Name**	**Classic Part Number**
1P-7115	Mount As	418-1936

W7B		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1P-7115	Mount As	418-1936

Sales Model 901C

W4T		
Original Part Number	**Part Name**	**Classic Part Number**
1P-7115	Mount As	418-1936

W4T		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
9L-2685	Rod End	419-1866

YKY		
Original Part Number	**Part Name**	**Classic Part Number**
1P-7115	Mount As	418-1936
9L-2685	Rod End	419-1866

Wheel Loaders

Sales Model 902

7ES		
Original Part Number	**Part Name**	**Classic Part Number**
3T-4308	Bearing-Sleeve	296-1341
6V-0832	Cone-Rlr Bearing	453-3654

7ES		
Original Part Number	**Part Name**	**Classic Part Number**
8H-5352	Bearing-Ball	453-3658
9D-7924	Mount As	360-2356
9W-9931	Mount As.	360-2354

7ES		
Original Part Number	**Part Name**	**Classic Part Number**
054-2213	Spider & Brg As	347-0464
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024

Sales Model 902B

W8A		
Original Part Number	**Part Name**	**Classic Part Number**
1P-7115	Mount As	418-1936

W8A		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1P-7115	Mount As	418-1936

Sales Model 902C

W5T		
Original Part Number	**Part Name**	**Classic Part Number**
1P-7115	Mount As	418-1936

W5T		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
9L-2685	Rod End	419-1866

YKT		
Original Part Number	**Part Name**	**Classic Part Number**
1P-7115	Mount As	418-1936
9L-2685	Rod End	419-1866

Sales Model 903B

W8B		
Original Part Number	**Part Name**	**Classic Part Number**
1P-7115	Mount As	418-1936

W8B		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1P-7115	Mount As	418-1936

Sales Model 903C

G93		
Original Part Number	**Part Name**	**Classic Part Number**
1P-7115	Mount As	418-1936

Sales Model 903C (Cont'd.)

G93		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356

G93		
Original Part Number	Part Name	Classic Part Number
9L-2685	Rod End	419-1866

MW4		
Original Part Number	Part Name	Classic Part Number
1P-7115	Mount As	418-1936

MW4		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
9L-2685	Rod End	419-1866

W6T		
Original Part Number	Part Name	Classic Part Number
1P-7115	Mount As	418-1936

W6T		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
9L-2685	Rod End	419-1866

YKL		
Original Part Number	Part Name	Classic Part Number
1P-7115	Mount As	418-1936
9L-2685	Rod End	419-1866

Sales Model 904B

B4L		
Original Part Number	Part Name	Classic Part Number
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

B4L		
Original Part Number	Part Name	Classic Part Number
8J-2880	Cap-Bearing	295-6420
9T-5729	Cyl Gp-0038 0158	422-2486

B4L		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024

Sales Model 904H

H4T		
Original Part Number	Part Name	Classic Part Number
1P-7115	Mount As	418-1936
6K-8088	Bearing-Roller	399-4428
6Y-7652	Cup-Rlr Brg	399-6067

H4T		
Original Part Number	Part Name	Classic Part Number
7L-7508	Bearing-Ball	420-6536
8J-2880	Cap-Bearing	295-6420
9T-5729	Cyl Gp-0038 0158	422-2486

H4T		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024

Wheel Loaders

Sales Model 905X

EMC		
Original Part Number	**Part Name**	**Classic Part Number**
3G-0910	Cap-Bearing	325-6037
6E-1108	Bearing-Sleeve	325-6023

Sales Model 906

6ZS		
Original Part Number	**Part Name**	**Classic Part Number**
3T-4308	Bearing-Sleeve	296-1341
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019
5J-7010	Seal As	472-8011

6ZS		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0832	Cone-Rlr Bearing	453-3654
8H-5352	Bearing-Ball	453-3658
9D-7924	Mount As	360-2356
9W-9931	Mount As.	360-2354

6ZS		
Original Part Number	**Part Name**	**Classic Part Number**
054-2213	Spider & Brg As	347-0464
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

MER		
Original Part Number	**Part Name**	**Classic Part Number**
3T-4308	Bearing-Sleeve	296-1341
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019
5J-7010	Seal As	472-8011

MER		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0832	Cone-Rlr Bearing	453-3654
8H-5352	Bearing-Ball	453-3658
9D-7924	Mount As	360-2356
9W-9931	Mount As.	360-2354

MER		
Original Part Number	**Part Name**	**Classic Part Number**
054-2213	Spider & Brg As	347-0464
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

Sales Model 906H

JRF		
Original Part Number	**Part Name**	**Classic Part Number**
2D-5658	Bearing-Ball	301-4628
4T-8054	Seal As	472-8010
8B-5972	Bearing-Ball	314-8503
8H-5352	Bearing-Ball	453-3658
9D-7924	Mount As	360-2356

JRF		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9931	Mount As.	360-2354
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028

JRF		
Original Part Number	**Part Name**	**Classic Part Number**
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

SDH		
Original Part Number	**Part Name**	**Classic Part Number**
1S-7056	Bearing-Ball	422-6483
2D-5658	Bearing-Ball	301-4628
4T-8054	Seal As	472-8010
6Y-7652	Cup-Rlr Brg	399-6067

SDH		
Original Part Number	**Part Name**	**Classic Part Number**
7L-7508	Bearing-Ball	420-6536
8B-5972	Bearing-Ball	314-8503
8H-5352	Bearing-Ball	453-3658
9D-7924	Mount As	360-2356

SDH		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9931	Mount As.	360-2354
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028

Sales Model 906H (Cont'd.)

SDH		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030

SDH		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032

SDH		
Original Part Number	Part Name	Classic Part Number
392-6301	Kit-Spider & Brg	390-0915

TPE		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
2D-5658	Bearing-Ball	301-4628
4T-8054	Seal As	472-8010
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

TPE		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8H-5352	Bearing-Ball	453-3658
9D-7924	Mount As	360-2356
9W-9931	Mount As.	360-2354
178-8608	Cone	422-6479

TPE		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

Sales Model 906K

L66		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
4T-8054	Seal As	472-8010
8B-5972	Bearing-Ball	314-8503
8H-5352	Bearing-Ball	453-3658
9D-7924	Mount As	360-2356

L66		
Original Part Number	Part Name	Classic Part Number
9W-9931	Mount As.	360-2354
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028

L66		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

Sales Model 906M

H66		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
4T-8054	Seal As	472-8010
8B-5972	Bearing-Ball	314-8503
8H-5352	Bearing-Ball	453-3658
9D-7924	Mount As	360-2356

H66		
Original Part Number	Part Name	Classic Part Number
9W-9931	Mount As.	360-2354
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028

H66		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

Z66		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
4T-8054	Seal As	472-8010
8B-5972	Bearing-Ball	314-8503
8H-5352	Bearing-Ball	453-3658

Z66		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
9W-9931	Mount As.	360-2354
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024

Z66		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

Wheel Loaders

Sales Model 907H

JRS		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
4T-8054	Seal As	472-8010
8B-5972	Bearing-Ball	314-8503
8H-5352	Bearing-Ball	453-3658
9D-7924	Mount As	360-2356

JRS		
Original Part Number	Part Name	Classic Part Number
9W-9931	Mount As.	360-2354
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028

JRS		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

MJF		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
2D-5658	Bearing-Ball	301-4628
4T-8054	Seal As	472-8010
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

MJF		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8H-5352	Bearing-Ball	453-3658
9D-7924	Mount As	360-2356
9W-9931	Mount As.	360-2354
178-8608	Cone	422-6479

MJF		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

SJM		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
2D-5658	Bearing-Ball	301-4628
4T-8054	Seal As	472-8010
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

SJM		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8H-5352	Bearing-Ball	453-3658
9D-7924	Mount As	360-2356
9W-9931	Mount As.	360-2354
178-8608	Cone	422-6479

SJM		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

Sales Model 907K

L77		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
4T-8054	Seal As	472-8010
8B-5972	Bearing-Ball	314-8503
8H-5352	Bearing-Ball	453-3658
9D-7924	Mount As	360-2356

L77		
Original Part Number	Part Name	Classic Part Number
9W-9931	Mount As.	360-2354
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028

L77		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

Sales Model 907M

H77		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
4T-8054	Seal As	472-8010
8B-5972	Bearing-Ball	314-8503
8H-5352	Bearing-Ball	453-3658
9D-7924	Mount As	360-2356

H77		
Original Part Number	Part Name	Classic Part Number
9W-9931	Mount As.	360-2354
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028

H77		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

Z77		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
4T-8054	Seal As	472-8010
8B-5972	Bearing-Ball	314-8503
8H-5352	Bearing-Ball	453-3658
9D-7924	Mount As	360-2356

Z77		
Original Part Number	Part Name	Classic Part Number
9W-9931	Mount As.	360-2354
176-3900	Accumulator	416-5513
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028

Z77		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
392-6301	Kit-Spider & Brg	390-0915

Sales Model 908

8BS		
Original Part Number	Part Name	Classic Part Number
3T-4308	Bearing-Sleeve	296-1341
4V-2057	Bearing-Spher	419-6019
5J-7010	Seal As	472-8011
5M-5856	Pipe-Extension	373-1913
6V-0832	Cone-Rlr Bearing	453-3654

8BS		
Original Part Number	Part Name	Classic Part Number
7Y-6608	Bearing	314-8649
8H-5352	Bearing-Ball	453-3658
9D-7924	Mount As	360-2356
9W-9931	Mount As.	360-2354
054-2213	Spider & Brg As	347-0464

8BS		
Original Part Number	Part Name	Classic Part Number
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

TAR		
Original Part Number	Part Name	Classic Part Number
3T-4308	Bearing-Sleeve	296-1341
4V-2057	Bearing-Spher	419-6019
5J-7010	Seal As	472-8011
6V-0832	Cone-Rlr Bearing	453-3654

TAR		
Original Part Number	Part Name	Classic Part Number
8H-5352	Bearing-Ball	453-3658
9D-7924	Mount As	360-2356
9W-9931	Mount As.	360-2354
054-2213	Spider & Brg As	347-0464

TAR		
Original Part Number	Part Name	Classic Part Number
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

Wheel Loaders

Sales Model 908H

JRD		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
8B-5972	Bearing-Ball	314-8503
8H-5352	Bearing-Ball	453-3658

JRD		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
9W-9931	Mount As.	360-2354
176-3900	Accumulator	416-5513

JRD		
Original Part Number	Part Name	Classic Part Number
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
392-6301	Kit-Spider & Brg	390-0915

LMD		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
2D-5658	Bearing-Ball	301-4628
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

LMD		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8H-5352	Bearing-Ball	453-3658
9D-7924	Mount As	360-2356
9W-9931	Mount As.	360-2354

LMD		
Original Part Number	Part Name	Classic Part Number
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
392-6301	Kit-Spider & Brg	390-0915

MXF		
Original Part Number	Part Name	Classic Part Number
1S-7056	Bearing-Ball	422-6483
2D-5658	Bearing-Ball	301-4628
6Y-7652	Cup-Rlr Brg	399-6067
7L-7508	Bearing-Ball	420-6536

MXF		
Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing-Ball	314-8503
8H-5352	Bearing-Ball	453-3658
9D-7924	Mount As	360-2356
9W-9931	Mount As.	360-2354

MXF		
Original Part Number	Part Name	Classic Part Number
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
392-6301	Kit-Spider & Brg	390-0915

Sales Model 908K

L88		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
8B-5972	Bearing-Ball	314-8503
8H-5352	Bearing-Ball	453-3658

L88		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
9W-9931	Mount As.	360-2354
176-3900	Accumulator	416-5513

L88		
Original Part Number	Part Name	Classic Part Number
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
392-6301	Kit-Spider & Brg	390-0915

Sales Model 908M

H88		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
8B-5972	Bearing-Ball	314-8503
8H-5352	Bearing-Ball	453-3658

H88		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
9W-9931	Mount As.	360-2354
176-3900	Accumulator	416-5513

H88		
Original Part Number	Part Name	Classic Part Number
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
392-6301	Kit-Spider & Brg	390-0915

Sales Model 908M (Cont'd.)

Z88		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
8B-5972	Bearing-Ball	314-8503
8H-5352	Bearing-Ball	453-3658

Z88		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
9W-9931	Mount As.	360-2354
176-3900	Accumulator	416-5513

Z88		
Original Part Number	Part Name	Classic Part Number
178-8608	Cone	422-6479
226-8202	Seal-Wiper	472-8024
392-6301	Kit-Spider & Brg	390-0915

Sales Model 910

40Y		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1S-1888	Bracket-Lamp	297-7147
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-2566	Ring-Lock	416-2123
2D-5658	Bearing-Ball	301-4628
2K-8753	Pinion-Bevel	253-1432
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-1599	Gear	378-3970
2S-0479	Bearing-Cone	380-7506
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971

40Y		
Original Part Number	Part Name	Classic Part Number
2W-8271	Arm As-Rocker	432-8912
3G-4704	Bearing-Sleeve	379-0185
3H-8726	Mount As	385-7208
4N-0432	Bearing-Ball	417-4499
4N-4161	Mount As	374-1448
4N-4539	Sleeve	314-8720
4P-7688	Valve As-Check	420-6216
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5J-7010	Seal As	472-8011
5M-2054	Bearing	380-7510
5M-7936	Bearing-Outer	386-4953
5P-7807	Bearing-Ball	314-8502
5P-9439	Bearing-Spl Ball	371-4306
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg	373-5386
5V-1168	Spider & Brg As	377-7435
6B-7469	Spacer	417-4535
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6K-8275	Cone-Roller Brg	399-6070
6S-3051	Cup-Rlr Brg	415-1928
6S-3158	Yoke	380-1478
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513

40Y		
Original Part Number	Part Name	Classic Part Number
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-3975	Trunnion	396-9940
6S-3976	Bearing	388-0589
6S-4074	Bearing	330-9249
6S-6009	Yoke-Univ Joint	446-3070
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-6896	Rebuild Kit	390-1006
6Y-7935	Disc-Friction	383-2121
7C-7955	Gasket-Cover	382-6899
7E-5085	Bushing	377-5829
7J-3351	Head	380-1515
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-3913	Rim As	398-2952
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2397	Gasket Kit	393-5193
8H-2810	Case As-Filter	314-8512

Sales Model 910 (Cont'd.)

40Y		
Original Part Number	**Part Name**	**Classic Part Number**
8J-5392	Ballstud	364-5264
8N-0701	Bearing-Sleeve	419-4745
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3539	Plunger As-Pump	377-5861
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8W-9587	Flange As	373-5394

40Y		
Original Part Number	**Part Name**	**Classic Part Number**
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-4789	Shaft-Gov Cont	297-7256
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-2653	Pump Gp-Gr 1 Bsc	386-3057
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

40Y		
Original Part Number	**Part Name**	**Classic Part Number**
9S-5211	Plate-Clutch	380-1493
9S-6917	Gear-Cplg Ring	446-3075
9S-7949	Cup-Roller Brg	420-6531
9Y-9431	Precleaner As	361-1718
100-8010	Valve	423-5583
119-6772	Valve-Exhaust	384-8699
154-5679	Kit-Dt Gasket	390-5277
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

41Y		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173

41Y		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
1W-9832	Muffler As	416-5493
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2F-5721	Bearing-Ball	311-9354
2K-8753	Pinion-Bevel	253-1432
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-1599	Gear	378-3970
2P-1757	Hub-Fan Pulley	296-1357
2S-0479	Bearing-Cone	380-7506
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3G-4704	Bearing-Sleeve	379-0185
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449

41Y		
Original Part Number	**Part Name**	**Classic Part Number**
4N-8344	Spider As-Fan	416-5520
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4V-9577	Shaft-Planet	231-0001
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
5G-3612	Cap Gp-Protn	295-6419
5J-7010	Seal As	472-8011
5M-2054	Bearing	380-7510
5P-7807	Bearing-Ball	314-8502
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5T-8739	Spider Gp-Brg	373-5386
5V-1168	Spider & Brg As	377-7435
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517

Sales Model 910 (Cont'd.)

41Y		
Original Part Number	Part Name	Classic Part Number
6I-1364	Spider As	391-9824
6K-4442	Rod End-Special	373-5388
6K-8088	Bearing-Roller	399-4428
6K-8275	Cone-Roller Brg	399-6070
6N-3256	Mount As	314-8688
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-3975	Trunnion	396-9940
6S-3976	Bearing	388-0589
6S-4074	Bearing	330-9249
6S-6009	Yoke-Univ Joint	446-3070
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7C-7955	Gasket-Cover	382-6899
7E-5085	Bushing	377-5829
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925

41Y		
Original Part Number	Part Name	Classic Part Number
7J-3351	Head	380-1515
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-3913	Rim As	398-2952
7K-5448	Cup-Bearing	415-1922
7K-7237	Gear-Planet	231-0009
7K-7431	Hub As	470-3783
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7X-2397	Gasket Kit	393-5193
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-5392	Ballstud	364-5264
8K-6321	Gear-Sun	253-1441
8N-0701	Bearing-Sleeve	419-4745
8N-1214	Mount As	325-6125
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

41Y		
Original Part Number	Part Name	Classic Part Number
8N-3539	Plunger As-Pump	377-5861
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8V-3134	Pinion-Bevel	260-0788
8W-9587	Flange As	373-5394
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9M-4789	Shaft-Gov Cont	297-7256
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9W-6390	Sleeve	385-3795
9Y-5168	Manifold-Exhaust	374-7483
9Y-9431	Precleaner As	361-1718
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
130-6856	Pre-Cleaner As	361-1717
140-2382	Gasket Kit	390-5285
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

80U		
Original Part Number	Part Name	Classic Part Number
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077

80U		
Original Part Number	Part Name	Classic Part Number
1P-4693	Cup-Rlr Bearing	377-7398
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079

80U		
Original Part Number	Part Name	Classic Part Number
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-5920	Bearing-Camshaft	421-1558

Sales Model 910 (Cont'd.)

80U		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-2566	Ring-Lock	416-2123
2D-5658	Bearing-Ball	301-4628
2K-8753	Pinion-Bevel	253-1432
2S-0479	Bearing-Cone	380-7506
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
4F-5003	Spring As-Arm	383-2127
4N-8809	Chamber As	247-3297
4T-8054	Seal As	472-8010
5G-3612	Cap Gp-Protn	295-6419
5M-2054	Bearing	380-7510
5M-7936	Bearing-Outer	386-4953
5S-5917	Screw-Rocker Adj	380-7537
6K-8275	Cone-Roller Brg	399-6070

80U		
Original Part Number	**Part Name**	**Classic Part Number**
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6V-6896	Rebuild Kit	390-1006
7J-3351	Head	380-1515
7J-6461	Crown	325-6054
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7T-2036	Cap As-Fuel	361-1721
7W-2059	Gasket-Cyl Hd	380-1548
7X-2396	Gasket Kit	393-5194
7X-2397	Gasket Kit	393-5193
8N-0701	Bearing-Sleeve	419-4745

80U		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8W-9587	Flange As	373-5394
9N-5246	Bearing-Camshaft	384-4772
9N-6500	Rod-Valve Push	383-3706
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9Y-9431	Precleaner As	361-1718
154-5679	Kit-Dt Gasket	390-5277
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Slaes Model 910E

1SF		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1P-4693	Cup-Rlr Bearing	377-7398
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-1064	Gear-Flywheel	374-4703
2D-2566	Ring-Lock	416-2123
2D-9191	Cone-Roller Brg	374-1837
2K-8753	Pinion-Bevel	253-1432
2N-1599	Gear	378-3970
2S-0479	Bearing-Cone	380-7506
2W-7213	Bearing-Sleeve	419-4667

1SF		
Original Part Number	**Part Name**	**Classic Part Number**
3E-7461	Gasket Kit-Sch	437-4575
3G-4704	Bearing-Sleeve	379-0185
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3T-2094	Bearing-Sleeve	388-0638
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4V-8629	Bearing-Sleeve	379-0194
4V-8643	Bearing-Sleeve	374-8354
4W-1203	Cup-Rlr Brg	418-9603

1SF		
Original Part Number	**Part Name**	**Classic Part Number**
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5M-9644	Bearing-Outer	384-5929
5T-1362	Univ Joint As-5C	325-6011
5T-8739	Spider Gp-Brg	373-5386
5V-1168	Spider & Brg As	377-7435
6F-2956	Cup-Spl Tapered	420-6538
6I-4689	Gasket-Cyl Head	377-5840
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503

Slaes Model 910E (Cont'd.)

1SF		
Original Part Number	Part Name	Classic Part Number
6K-8088	Bearing-Roller	399-4428
6K-8275	Cone-Roller Brg	399-6070
6S-3158	Yoke	380-1478
6S-3457	Pin	325-6147
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3975	Trunnion	396-9940
6S-3976	Bearing	388-0589
6S-4074	Bearing	330-9249
6V-4582	Bearing-Ball	380-1504
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-0087	Bearing-Sleeve	374-6514
7K-8877	Cone-Bearing	374-1847
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705

1SF		
Original Part Number	Part Name	Classic Part Number
8C-3111	Rod End-Spher	392-4523
8E-6221	Pin	325-6155
8H-2810	Case As-Filter	314-8512
8J-5392	Ballstud	364-5264
8S-0248	Breather As	325-6033
8W-9587	Flange As	373-5394
8Y-0809	Spider Gp-Brg	417-4526
8Y-7186	Link As	399-8584
9C-5687	Separator	377-7456
9C-8772	Piston	376-9052
9M-1853	Mount As.	376-3638
9P-8663	Spacer	422-9521
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
9V-4975	Bearing-Sleeve	384-4784
9X-2192	Gasket Kit-Sch	393-5189
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195

1SF		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
133-6597	Pipe-Extension	420-6220
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
154-5683	Kit-Dt Gasket	420-6528
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

1YK		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1P-4693	Cup-Rlr Bearing	377-7398
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476

1YK		
Original Part Number	Part Name	Classic Part Number
1T-1401	Ring-Seal	384-4799
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-9191	Cone-Roller Brg	374-1837
2K-0227	Bearing-Sleeve	384-4780
2K-8753	Pinion-Bevel	253-1432

1YK		
Original Part Number	Part Name	Classic Part Number
2N-1599	Gear	378-3970
2S-0479	Bearing-Cone	380-7506
2W-7213	Bearing-Sleeve	419-4667
3G-4704	Bearing-Sleeve	379-0185
3G-8917	Pin	325-6141
3H-8726	Mount As	385-7208
3T-2094	Bearing-Sleeve	388-0638

Slaes Model 910E (Cont'd.)

1YK		
Original Part Number	**Part Name**	**Classic Part Number**
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-8629	Bearing-Sleeve	379-0194
4V-8643	Bearing-Sleeve	374-8354
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5T-1362	Univ Joint As-5C	325-6011
5T-8739	Spider Gp-Brg	373-5386
5V-1168	Spider & Brg As	377-7435
6F-2956	Cup-Spl Tapered	420-6538
6I-4689	Gasket-Cyl Head	377-5840
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8088	Bearing-Roller	399-4428
6K-8275	Cone-Roller Brg	399-6070
6K-8314	Pin	252-6863
6S-3158	Yoke	380-1478
6S-3457	Pin	325-6147
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3975	Trunnion	396-9940
6S-3976	Bearing	388-0589
6S-4074	Bearing	330-9249

1YK		
Original Part Number	**Part Name**	**Classic Part Number**
6V-4582	Bearing-Ball	380-1504
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7J-1309	Bearing-Aligning	360-2275
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9884	Bearing-Sleeve	325-6016
7K-0084	Bearing-Sleeve	453-6508
7K-0087	Bearing-Sleeve	374-6514
7K-8877	Cone-Bearing	374-1847
7K-9642	Bearing-Sleeve	360-2340
7T-2036	Cap As-Fuel	361-1721
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8J-5392	Ballstud	364-5264
8S-0248	Breather As	325-6033
8W-9587	Flange As	373-5394
8Y-0809	Spider Gp-Brg	417-4526
8Y-7186	Link As	399-8584
9C-5687	Separator	377-7456
9C-8772	Piston	376-9052
9J-3206	Bearing-Spher	360-2275
9M-1853	Mount As.	376-3638
9P-8663	Spacer	422-9521
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486

1YK		
Original Part Number	**Part Name**	**Classic Part Number**
9V-0247	Plate	417-4527
9V-4975	Bearing-Sleeve	384-4784
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
121-7746	Pre-Cleaner As	360-2311
133-6597	Pipe-Extension	420-6220
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model 910F

1SF		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1P-4693	Cup-Rlr Bearing	377-7398
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-1064	Gear-Flywheel	374-4703
2D-2566	Ring-Lock	416-2123
2D-9191	Cone-Roller Brg	374-1837
2K-8753	Pinion-Bevel	253-1432
2N-1599	Gear	378-3970
2S-0479	Bearing-Cone	380-7506
2W-7213	Bearing-Sleeve	419-4667
3E-7461	Gasket Kit-Sch	437-4575
3G-4704	Bearing-Sleeve	379-0185
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3T-2094	Bearing-Sleeve	388-0638
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4V-8629	Bearing-Sleeve	379-0194
4V-8643	Bearing-Sleeve	374-8354
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5M-9644	Bearing-Outer	384-5929
5T-1362	Univ Joint As-5C	325-6011
5T-8739	Spider Gp-Brg	373-5386

1SF		
Original Part Number	**Part Name**	**Classic Part Number**
5V-1168	Spider & Brg As	377-7435
6F-2956	Cup-Spl Tapered	420-6538
6I-4689	Gasket-Cyl Head	377-5840
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8088	Bearing-Roller	399-4428
6K-8275	Cone-Roller Brg	399-6070
6S-3158	Yoke	380-1478
6S-3457	Pin	325-6147
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3975	Trunnion	396-9940
6S-3976	Bearing	388-0589
6S-4074	Bearing	330-9249
6V-4582	Bearing-Ball	380-1504
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-0087	Bearing-Sleeve	374-6514
7K-8877	Cone-Bearing	374-1847
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8E-6221	Pin	325-6155
8H-2810	Case As-Filter	314-8512

1SF		
Original Part Number	**Part Name**	**Classic Part Number**
8J-5392	Ballstud	364-5264
8S-0248	Breather As	325-6033
8W-9587	Flange As	373-5394
8Y-0809	Spider Gp-Brg	417-4526
8Y-7186	Link As	399-8584
9C-5687	Separator	377-7456
9C-8772	Piston	376-9052
9M-1853	Mount As.	376-3638
9P-8663	Spacer	422-9521
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
9V-4975	Bearing-Sleeve	384-4784
9X-2192	Gasket Kit-Sch	393-5189
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
121-7746	Pre-Cleaner As	360-2311
133-6597	Pipe-Extension	420-6220
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
154-5683	Kit-Dt Gasket	420-6528
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123

Sales Model 910F (Cont'd.)

1SF		
Original Part Number	**Part Name**	**Classic Part Number**
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

1SF		
Original Part Number	**Part Name**	**Classic Part Number**
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

1SF		
Original Part Number	**Part Name**	**Classic Part Number**
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

1YK		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1P-4693	Cup-Rlr Bearing	377-7398
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-9191	Cone-Roller Brg	374-1837
2K-0227	Bearing-Sleeve	384-4780
2K-8753	Pinion-Bevel	253-1432
2N-1599	Gear	378-3970
2S-0479	Bearing-Cone	380-7506
2W-7213	Bearing-Sleeve	419-4667
3G-4704	Bearing-Sleeve	379-0185
3G-8917	Pin	325-6141
3H-8726	Mount As	385-7208
3T-2094	Bearing-Sleeve	388-0638
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513

1YK		
Original Part Number	**Part Name**	**Classic Part Number**
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-8629	Bearing-Sleeve	379-0194
4V-8643	Bearing-Sleeve	374-8354
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5T-1362	Univ Joint As-5C	325-6011
5T-8739	Spider Gp-Brg	373-5386
5V-1168	Spider & Brg As	377-7435
6F-2956	Cup-Spl Tapered	420-6538
6I-4689	Gasket-Cyl Head	377-5840
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8088	Bearing-Roller	399-4428
6K-8275	Cone-Roller Brg	399-6070
6K-8314	Pin	252-6863
6S-3158	Yoke	380-1478
6S-3457	Pin	325-6147
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3975	Trunnion	396-9940
6S-3976	Bearing	388-0589
6S-4074	Bearing	330-9249
6V-4582	Bearing-Ball	380-1504

1YK		
Original Part Number	**Part Name**	**Classic Part Number**
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7J-1309	Bearing-Aligning	360-2275
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9884	Bearing-Sleeve	325-6016
7K-0084	Bearing-Sleeve	453-6508
7K-0087	Bearing-Sleeve	374-6514
7K-8877	Cone-Bearing	374-1847
7K-9642	Bearing-Sleeve	360-2340
7T-2036	Cap As-Fuel	361-1721
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8J-5392	Ballstud	364-5264
8S-0248	Breather As	325-6033
8W-9587	Flange As	373-5394
8Y-0809	Spider Gp-Brg	417-4526
8Y-7186	Link As	399-8584
9C-5687	Separator	377-7456
9C-8772	Piston	376-9052

Sales Model 910F (Cont'd.)

1YK		
Original Part Number	Part Name	Classic Part Number
9J-3206	Bearing-Spher	360-2275
9M-1853	Mount As.	376-3638
9P-8663	Spacer	422-9521
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
9V-0247	Plate	417-4527
9V-4975	Bearing-Sleeve	384-4784
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

1YK		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
121-7746	Pre-Cleaner As	360-2311
133-6597	Pipe-Extension	420-6220
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696

1YK		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

2SS		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-5338	Cup-Roller Brg	374-8345
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
2D-2566	Ring-Lock	416-2123
2D-9191	Cone-Roller Brg	374-1837
2K-8753	Pinion-Bevel	253-1432
3G-4704	Bearing-Sleeve	379-0185
3G-8917	Pin	325-6141
3T-2094	Bearing-Sleeve	388-0638
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-6107	Bearing-Roller	380-7507
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-8629	Bearing-Sleeve	379-0194
4V-8643	Bearing-Sleeve	374-8354
5J-7010	Seal As	472-8011

2SS		
Original Part Number	Part Name	Classic Part Number
5L-6326	Bearing-Ball	420-3222
5M-5856	Pipe-Extension	373-1913
5V-1168	Spider & Brg As	377-7435
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6K-8088	Bearing-Roller	399-4428
6K-8314	Pin	252-6863
6S-3975	Trunnion	396-9940
6S-3976	Bearing	388-0589
6V-4582	Bearing-Ball	380-1504
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7J-9884	Bearing-Sleeve	325-6016
7K-0084	Bearing-Sleeve	453-6508
7K-9639	Bearing-Sleeve	314-8643
7K-9642	Bearing-Sleeve	360-2340
8D-0983	Mounting	384-3470
8J-5392	Ballstud	364-5264
8W-9587	Flange As	373-5394

2SS		
Original Part Number	Part Name	Classic Part Number
8Y-7186	Link As	399-8584
9C-5687	Separator	377-7456
9C-8772	Piston	376-9052
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
9V-0247	Plate	417-4527
9V-4975	Bearing-Sleeve	384-4784
9W-0876	Bearing-Sleeve	325-6031
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
114-1071	Piston	388-6583
115-4237	Pulley-Idler	374-4693
133-6597	Pipe-Extension	420-6220
151-5349	Head	383-1592
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

AKR		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup-Roller Brg	374-8345
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-9191	Cone-Roller Brg	374-1837
3G-4704	Bearing-Sleeve	379-0185
3W-7770	Tube As	385-7227
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-8629	Bearing-Sleeve	379-0194
4V-8643	Bearing-Sleeve	374-8354
5J-7010	Seal As	472-8011
5L-6326	Bearing-Ball	420-3222
6E-0775	Head	425-9373

AKR		
Original Part Number	**Part Name**	**Classic Part Number**
6K-8088	Bearing-Roller	399-4428
6P-0593	Bearing-Roller	386-4959
6S-3975	Trunnion	396-9940
6S-3976	Bearing	388-0589
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-9639	Bearing-Sleeve	314-8643
8B-5972	Bearing-Ball	314-8503
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8J-5392	Ballstud	364-5264
8V-1612	Shaft	425-6456
8W-9587	Flange As	373-5394
8Y-7186	Link As	399-8584
9D-7924	Mount As	360-2356

AKR		
Original Part Number	**Part Name**	**Classic Part Number**
9J-9812	Bearing	434-7258
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
9V-0247	Plate	417-4527
9V-4975	Bearing-Sleeve	384-4784
9W-0876	Bearing-Sleeve	325-6031
9W-9940	Mount As.	360-2355
115-4237	Pulley-Idler	374-4693
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348

B9X		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-9191	Cone-Roller Brg	374-1837
3G-4704	Bearing-Sleeve	379-0185
3W-7770	Tube As	385-7227
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-8629	Bearing-Sleeve	379-0194
4V-8643	Bearing-Sleeve	374-8354
5J-7010	Seal As	472-8011
5L-6326	Bearing-Ball	420-3222
6E-0775	Head	425-9373

B9X		
Original Part Number	**Part Name**	**Classic Part Number**
6K-8088	Bearing-Roller	399-4428
6K-8314	Pin	252-6863
6S-3975	Trunnion	396-9940
6S-3976	Bearing	388-0589
7J-1309	Bearing-Aligning	360-2275
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-0084	Bearing-Sleeve	453-6508
7K-9639	Bearing-Sleeve	314-8643
7K-9642	Bearing-Sleeve	360-2340
8B-5972	Bearing-Ball	314-8503
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8J-5392	Ballstud	364-5264
8W-9587	Flange As	373-5394
8Y-7186	Link As	399-8584

B9X		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
9J-9812	Bearing	434-7258
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
9V-0247	Plate	417-4527
9V-4975	Bearing-Sleeve	384-4784
9W-0876	Bearing-Sleeve	325-6031
9W-9940	Mount As.	360-2355
115-4237	Pulley-Idler	374-4693
121-7746	Pre-Cleaner As	360-2311
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348

Sales Model 910H

SAT		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
2D-2566	Ring-Lock	416-2123
2D-9191	Cone-Roller Brg	374-1837
3G-4704	Bearing-Sleeve	379-0185
3W-7770	Tube As	385-7227
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-8629	Bearing-Sleeve	379-0194
4V-8643	Bearing-Sleeve	374-8354
5J-7010	Seal As	472-8011

SAT		
Original Part Number	Part Name	Classic Part Number
6E-0775	Head	425-9373
6K-8088	Bearing-Roller	399-4428
6K-8314	Pin	252-6863
6S-3975	Trunnion	396-9940
6S-3976	Bearing	388-0589
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-0084	Bearing-Sleeve	453-6508
7K-9639	Bearing-Sleeve	314-8643
8B-5972	Bearing-Ball	314-8503
8G-4022	Bearing	422-6920
8J-5392	Ballstud	364-5264
8W-9587	Flange As	373-5394

SAT		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
9V-0247	Plate	417-4527
9V-4975	Bearing-Sleeve	384-4784
9W-0876	Bearing-Sleeve	325-6031
9W-9940	Mount As.	360-2355
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
347-6081	Gauge As	360-2348

Sales Model 910K

AY4		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3G-4704	Bearing-Sleeve	379-0185
3P-1210	Cone-Roller Brg	399-4433

AY4		
Original Part Number	Part Name	Classic Part Number
6I-9103	Bearing-Outer	421-8182
9D-7924	Mount As	360-2356
9W-9931	Mount As.	360-2354
176-3900	Accumulator	416-5513

AY4		
Original Part Number	Part Name	Classic Part Number
178-8608	Cone	422-6479
392-6301	Kit-Spider & Brg	390-0915

L22		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356

L22		
Original Part Number	Part Name	Classic Part Number
9W-9931	Mount As.	360-2354
176-3900	Accumulator	416-5513

Sales Model 910M

H22		
Original Part Number	Part Name	Classic Part Number
6I-9103	Bearing-Outer	421-8182
9D-7924	Mount As	360-2356

H22		
Original Part Number	Part Name	Classic Part Number
9W-9931	Mount As.	360-2354
176-3900	Accumulator	416-5513

Wheel Loaders

Sales Model 914G

SNP		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
3G-4704	Bearing-Sleeve	379-0185
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-8629	Bearing-Sleeve	379-0194
4V-8643	Bearing-Sleeve	374-8354
5J-7010	Seal As	472-8011
5M-5856	Pipe-Extension	373-1913
6B-7469	Spacer	417-4535
6E-0775	Head	425-9373
6K-8088	Bearing-Roller	399-4428

SNP		
Original Part Number	Part Name	Classic Part Number
6L-7751	Rod End-Spher	472-8015
7C-4349	Mount As	383-2117
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-9639	Bearing-Sleeve	314-8643
7M-7219	Bearing-Thrust	384-4816
8B-5972	Bearing-Ball	314-8503
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8J-5392	Ballstud	364-5264
8Y-7186	Link As	399-8584
9D-7924	Mount As	360-2356
9J-9812	Bearing	434-7258
9M-1328	Bearing-Aligning	325-6018
9S-7949	Cup-Roller Brg	420-6531

SNP		
Original Part Number	Part Name	Classic Part Number
9T-5729	Cyl Gp-0038 0158	422-2486
9V-4975	Bearing-Sleeve	384-4784
9W-0876	Bearing-Sleeve	325-6031
9W-9940	Mount As.	360-2355
116-8539	Spider & Brg Kit	399-4399
121-7746	Pre-Cleaner As	360-2311
176-3900	Accumulator	416-5513
223-3095	Gauge As	360-2295
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 914K

CD2		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
3G-4704	Bearing-Sleeve	379-0185
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010

CD2		
Original Part Number	Part Name	Classic Part Number
6I-9103	Bearing-Outer	421-8182
7K-0084	Bearing-Sleeve	453-6508
9D-7924	Mount As	360-2356
9W-9931	Mount As.	360-2354
176-3900	Accumulator	416-5513

CD2		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
9D-7924	Mount As	360-2356
9W-9931	Mount As.	360-2354
176-3900	Accumulator	416-5513

Sales Model 914M

H24		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433

H24		
Original Part Number	Part Name	Classic Part Number
6I-9103	Bearing-Outer	421-8182
9D-7924	Mount As	360-2356

H24		
Original Part Number	Part Name	Classic Part Number
9W-9931	Mount As.	360-2354
176-3900	Accumulator	416-5513

Sales Model 916

2XB		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1219	Trunnion As	314-8724
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173

2XB		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8271	Arm As-Rocker	432-8912
2W-9978	Core As-Oclr	279-4983
3B-4124	Cup-Spl Tapered	422-6481
3K-3124	Muffler-Trap	247-2673

2XB		
Original Part Number	**Part Name**	**Classic Part Number**
3T-2094	Bearing-Sleeve	388-0638
4B-7255	Cone-Bearing	386-4951
4E-3456	Lever As	367-6081
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4T-3196	Cartridge Gp	422-8112
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4V-8629	Bearing-Sleeve	379-0194
4V-8643	Bearing-Sleeve	374-8354
4V-8661	Pin As	375-9968
4V-9577	Shaft-Planet	231-0001
4V-9901	Pin As	374-6508
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603

Sales Model 916 (Cont'd.)

2XB		
Original Part Number	Part Name	Classic Part Number
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-2931	Pump Gp-Vn Bsc-B	422-8161
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2706	Cap-Lower	451-6443
6K-2707	Plate-Lock	319-3470
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-6721	Coupling	377-5830
6N-7174	Shield-Oil	314-8544

2XB		
Original Part Number	Part Name	Classic Part Number
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-7955	Gasket-Cover	382-6899
7E-9980	Camshaft	377-5851
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7K-2135	Bearing-Roller	417-4492
7K-7237	Gear-Planet	231-0009
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0691	Elbow-Water Rglt	378-3983
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995

2XB		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7681	Pipe-Exh Ext	385-7213
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6321	Gear-Sun	253-1441
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3753	Rod As-Conn	379-8867

Sales Model 916 (Cont'd.)

2XB		
Original Part Number	Part Name	Classic Part Number
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6308	Bearing-Conn Rod	419-7267
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8W-9587	Flange As	373-5394
9D-7924	Mount As	360-2356
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9M-5477	Bearing-Sleeve	374-6517
9N-5246	Bearing-Camshaft	384-4772

2XB		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-2356	Manifold-Exhaust	261-0905
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9T-5096	Flexplate	455-3271
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-5168	Manifold-Exhaust	374-7483
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
140-2382	Gasket Kit	390-5285
140-2383	Gasket Kit	396-9927
148-7455	Valve - Exhaust	270-4361

2XB		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

3SC		
Original Part Number	Part Name	Classic Part Number
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443

3SC		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077

3SC		
Original Part Number	Part Name	Classic Part Number
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476

Sales Model 916 (Cont'd.)

3SC		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1401	Ring-Seal	384-4799
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2K-9295	Bearing-Cone	422-6480
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3B-4124	Cup-Spl Tapered	422-6481
3K-3124	Muffler-Trap	247-2673
3T-2094	Bearing-Sleeve	388-0638
4B-7255	Cone-Bearing	386-4951
4E-3456	Lever As	367-6081
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502

3SC		
Original Part Number	**Part Name**	**Classic Part Number**
4T-0998	Lever	314-8687
4T-3196	Cartridge Gp	422-8112
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4V-8629	Bearing-Sleeve	379-0194
4V-8643	Bearing-Sleeve	374-8354
4V-8661	Pin As	375-9968
4V-9577	Shaft-Planet	231-0001
4V-9901	Pin As	374-6508
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-2931	Pump Gp-Vn Bsc-B	422-8161
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6K-2706	Cap-Lower	451-6443
6K-2707	Plate-Lock	319-3470
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959

3SC		
Original Part Number	**Part Name**	**Classic Part Number**
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7C-7955	Gasket-Cover	382-6899
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7K-2135	Bearing-Roller	417-4492
7K-7237	Gear-Planet	231-0009
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7P-1577	Pin As	375-9969
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6321	Gear-Sun	253-1441
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867

Sales Model 916 (Cont'd.)

3SC		
Original Part Number	**Part Name**	**Classic Part Number**
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772

3SC		
Original Part Number	**Part Name**	**Classic Part Number**
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

3SC		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7949	Cup-Roller Brg	420-6531
9T-5096	Flexplate	455-3271
9W-6390	Sleeve	385-3795
9Y-5168	Manifold-Exhaust	374-7483
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
226-8202	Seal-Wiper	472-8024

5KC		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913

5KC		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2K-9295	Bearing-Cone	422-6480
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3B-4124	Cup-Spl Tapered	422-6481
3G-4704	Bearing-Sleeve	379-0185
3G-8932	Pin	325-6143
3K-3124	Muffler-Trap	247-2673
3T-2094	Bearing-Sleeve	388-0638
4B-7255	Cone-Bearing	386-4951
4E-3456	Lever As	367-6081
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-4757	Muffler As	360-7877

5KC		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-3196	Cartridge Gp	422-8112
4T-8054	Seal As	472-8010
4V-2518	Shaft	297-7243
4V-2873	Bearing-Sleeve	379-0192
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4V-8629	Bearing-Sleeve	379-0194
4V-8643	Bearing-Sleeve	374-8354
4V-8661	Pin As	375-9968
4V-9577	Shaft-Planet	231-0001
4V-9901	Pin As	374-6508
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467

Sales Model 916 (Cont'd.)

5KC		
Original Part Number	**Part Name**	**Classic Part Number**
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-2931	Pump Gp-Vn Bsc-B	422-8161
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6K-2706	Cap-Lower	451-6443
6K-2707	Plate-Lock	319-3470
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7934	Disc-Friction	384-5937

5KC		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7935	Disc-Friction	383-2121
7C-7955	Gasket-Cover	382-6899
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7K-2135	Bearing-Roller	417-4492
7K-7237	Gear-Planet	231-0009
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7P-1577	Pin As	375-9969
7S-7681	Pipe-Exh Ext	385-7213
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6321	Gear-Sun	253-1441
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267

5KC		
Original Part Number	**Part Name**	**Classic Part Number**
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8W-9587	Flange As	373-5394
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9W-6390	Sleeve	385-3795
9Y-5168	Manifold-Exhaust	374-7483
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
140-2382	Gasket Kit	390-5285
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

8GC		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296

8GC		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-7125	Governor As	383-3672

8GC		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078

Sales Model 916 (Cont'd.)

8GC		
Original Part Number	**Part Name**	**Classic Part Number**
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2K-9295	Bearing-Cone	422-6480
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3B-4124	Cup-Spl Tapered	422-6481
3T-2094	Bearing-Sleeve	388-0638
4B-7255	Cone-Bearing	386-4951
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4T-3196	Cartridge Gp	422-8112
4V-2518	Shaft	297-7243
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050

8GC		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8643	Bearing-Sleeve	374-8354
4V-9577	Shaft-Planet	231-0001
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
6E-2931	Pump Gp-Vn Bsc-B	422-8161
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6K-5746	Bearing-Roller	417-4503
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6N-6721	Coupling	377-5830
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7C-7955	Gasket-Cover	382-6899
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7K-7237	Gear-Planet	231-0009
7M-7219	Bearing-Thrust	384-4816

8GC		
Original Part Number	**Part Name**	**Classic Part Number**
7N-0691	Elbow-Water Rglt	378-3983
7N-7166	Race-Brg Thrust	417-4531
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6321	Gear-Sun	253-1441
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-3134	Pinion-Bevel	260-0788
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-5096	Flexplate	455-3271
9Y-5168	Manifold-Exhaust	374-7483
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311

Sales Model 916 (Cont'd.)

9WB		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3165	Plunger-Rlf V	373-1883
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3821	Bearing-Conn Rod	376-9076
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1N-3822	Bearing-Conn Rod	376-9077
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-7125	Governor As	383-3672
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1401	Ring-Seal	384-4799
1V-6342	Gear As	308-9847
1V-6342	Gear As	308-9847

9WB		
Original Part Number	**Part Name**	**Classic Part Number**
1W-0311	Bearing-Main	376-9078
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-0568	Pump Gp-F Tfr	377-5859
1W-1219	Trunnion As	314-8724
1W-1661	Bearing-Main	376-9080
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-1662	Bearing-Main	382-6900
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5920	Bearing-Camshaft	421-1558
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2B-0941	Spacer	418-1955

9WB		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9191	Cone-Roller Brg	374-1837
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2F-5721	Bearing-Ball	311-9354
2K-9295	Bearing-Cone	422-6480
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2V-7990	Tube As	373-5382
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-1223	Pump Gp-Water	385-7197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-5536	Core As-Radiator	380-7554
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8271	Arm As-Rocker	432-8912
2W-8271	Arm As-Rocker	432-8912
2W-9978	Core As-Oclr	279-4983
3B-4124	Cup-Spl Tapered	422-6481
3B-4124	Cup-Spl Tapered	422-6481
3K-3124	Muffler-Trap	247-2673
3K-3124	Muffler-Trap	247-2673

Sales Model 916 (Cont'd.)

9WB		
Original Part Number	**Part Name**	**Classic Part Number**
3T-2094	Bearing-Sleeve	388-0638
3T-2094	Bearing-Sleeve	388-0638
4B-7255	Cone-Bearing	386-4951
4B-7255	Cone-Bearing	386-4951
4E-3456	Lever As	367-6081
4E-3456	Lever As	367-6081
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8204	Mount As	374-1449
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-4757	Muffler As	360-7877
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9942	Seal-End Tank	385-7217
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4T-0998	Lever	314-8687

9WB		
Original Part Number	**Part Name**	**Classic Part Number**
4T-3196	Cartridge Gp	422-8112
4T-3196	Cartridge Gp	422-8112
4V-2518	Shaft	297-7243
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4V-6527	Disc	376-9050
4V-8629	Bearing-Sleeve	379-0194
4V-8629	Bearing-Sleeve	379-0194
4V-8643	Bearing-Sleeve	374-8354
4V-8643	Bearing-Sleeve	374-8354
4V-8661	Pin As	375-9968
4V-8661	Pin As	375-9968
4V-9577	Shaft-Planet	231-0001
4V-9577	Shaft-Planet	231-0001
4V-9901	Pin As	374-6508
4V-9901	Pin As	374-6508
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
4W-9492	Repair Kt-Major	375-2261
5L-2031	Cup-Roller Brg	384-5927
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024

9WB		
Original Part Number	**Part Name**	**Classic Part Number**
5P-9514	Bearing-Ball	417-9467
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6B-7469	Spacer	417-4535
6E-2931	Pump Gp-Vn Bsc-B	422-8161
6E-2931	Pump Gp-Vn Bsc-B	422-8161
6F-2956	Cup-Spl Tapered	420-6538
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2706	Cap-Lower	451-6443
6K-2706	Cap-Lower	451-6443
6K-2707	Plate-Lock	319-3470
6K-2707	Plate-Lock	319-3470
6K-5744	Cage-Bearing	330-9266
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-5746	Bearing-Roller	417-4503
6K-9070	Washer-Thrust	330-9294
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264

Sales Model 916 (Cont'd.)

9WB		
Original Part Number	**Part Name**	**Classic Part Number**
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6K-9151	Bearing-Sleeve	330-9265
6L-7751	Rod End-Spher	472-8015
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-6721	Coupling	377-5830
6N-6721	Coupling	377-5830
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6P-3735	Shaft-Planet	368-0103
6V-0347	Cone-Spl Tapered	420-6537
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6V-6896	Rebuild Kit	390-1006
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7934	Disc-Friction	384-5937
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7935	Disc-Friction	383-2121
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-7955	Gasket-Cover	382-6899

9WB		
Original Part Number	**Part Name**	**Classic Part Number**
7C-7955	Gasket-Cover	382-6899
7E-9980	Camshaft	377-5851
7G-2480	Gear-Planet	226-6091
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7G-7611	Gear-Ring	398-2925
7K-2135	Bearing-Roller	417-4492
7K-2135	Bearing-Roller	417-4492
7K-7237	Gear-Planet	231-0009
7K-7237	Gear-Planet	231-0009
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0691	Elbow-Water Rglt	378-3983
7N-0691	Elbow-Water Rglt	378-3983
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5206	Mount As	374-1451
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656

9WB		
Original Part Number	**Part Name**	**Classic Part Number**
7S-7070	Head As-Cylinder	325-6107
7S-7681	Pipe-Exh Ext	385-7213
7S-7681	Pipe-Exh Ext	385-7213
7T-2036	Cap As-Fuel	361-1721
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7W-2059	Gasket-Cyl Hd	380-1548
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8E-4024	Carrier-Planet	398-8333
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8H-9789	Bearing-Ball	374-8342
8K-6321	Gear-Sun	253-1441
8K-6321	Gear-Sun	253-1441
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2051	Compressor Gp -B	386-2063
8N-2051	Compressor Gp -B	386-2063

Sales Model 916 (Cont'd.)

9WB		
Original Part Number	**Part Name**	**Classic Part Number**
8N-2516	Bonnet-Valve	377-5858
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2518	Bearing-Sleeve	417-4518
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3753	Rod As-Conn	379-8867
8N-3753	Rod As-Conn	379-8867
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6308	Bearing-Conn Rod	419-7267
8N-6308	Bearing-Conn Rod	419-7267
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8V-1612	Shaft	425-6456
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-1624	Lever	299-2019

9WB		
Original Part Number	**Part Name**	**Classic Part Number**
8V-3134	Pinion-Bevel	260-0788
8V-3134	Pinion-Bevel	260-0788
9D-7924	Mount As	360-2356
9D-7924	Mount As	360-2356
9L-2685	Rod End	419-1866
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9M-1853	Mount As.	376-3638
9M-5477	Bearing-Sleeve	374-6517
9N-5246	Bearing-Camshaft	384-4772
9N-5246	Bearing-Camshaft	384-4772
9N-5769	Cover-Housing	325-6050
9N-5786	Lifter-Valve	457-6607
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9P-7101	Plate-Clutch	368-0122
9S-2356	Manifold-Exhaust	261-0905
9S-3581	Cup-Roller Brg	415-1923
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9T-5096	Flexplate	455-3271
9T-5096	Flexplate	455-3271
9W-6390	Sleeve	385-3795
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165

9WB		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-5168	Manifold-Exhaust	374-7483
9Y-5168	Manifold-Exhaust	374-7483
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
119-6772	Valve-Exhaust	384-8699
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
140-2382	Gasket Kit	390-5285
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259

Wheel Loaders

Sales Model 916 (Cont'd.)

9WB		
Original Part Number	**Part Name**	**Classic Part Number**
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893

9WB		
Original Part Number	**Part Name**	**Classic Part Number**
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438

9WB		
Original Part Number	**Part Name**	**Classic Part Number**
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 916X

DZ8		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
176-3900	Accumulator	416-5513

Sales Model 918F

2CK		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-3980	Cone-Roller Brg	399-4443
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1M-7250	Bowl	360-2296
1P-3934	Cup-Roller Brg	420-6535
1P-3934	Cup-Roller Brg	420-6535
1S-7057	Gasket	420-6384
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1401	Ring-Seal	384-4799
1T-1804	Stator As-Conv	388-0572
1T-1805	Turbine-Conv	380-1490
1W-1064	Gear-Flywheel	374-4703
1W-1064	Gear-Flywheel	374-4703
2D-2654	Ring-Lock	380-1488
2K-9295	Bearing-Cone	422-6480
2N-1599	Gear	378-3970

2CK		
Original Part Number	**Part Name**	**Classic Part Number**
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3H-8726	Mount As	385-7208
3H-8726	Mount As	385-7208
3T-2094	Bearing-Sleeve	388-0638
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4E-4524	Pin As	380-7392
4M-6107	Bearing-Roller	380-7507
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-8577	Rod As-Injector	455-5513

2CK		
Original Part Number	**Part Name**	**Classic Part Number**
4T-0998	Lever	314-8687
4T-0998	Lever	314-8687
4V-2057	Bearing-Spher	419-6019
4V-2057	Bearing-Spher	419-6019
4V-8643	Bearing-Sleeve	374-8354
4V-8643	Bearing-Sleeve	374-8354
4V-8661	Pin As	375-9968
4V-8661	Pin As	375-9968
4V-9901	Pin As	374-6508
4V-9901	Pin As	374-6508
4W-1203	Cup-Rlr Brg	418-9603
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
5L-2031	Cup-Roller Brg	384-5927
5M-6212	Tube	390-0996
5M-6212	Tube	390-0996
6E-6474	Cartridge Gp	422-8135
6E-6474	Cartridge Gp	422-8135
6E-6476	Pump Gp-Vn Bsc-A	422-8163

Sales Model 918F (Cont'd.)

2CK		
Original Part Number	Part Name	Classic Part Number
6E-6476	Pump Gp-Vn Bsc-A	422-8163
6F-2956	Cup-Spl Tapered	420-6538
6I-4689	Gasket-Cyl Head	377-5840
6I-4689	Gasket-Cyl Head	377-5840
6K-2707	Plate-Lock	319-3470
6K-2707	Plate-Lock	319-3470
6K-5746	Bearing-Roller	417-4503
6K-5746	Bearing-Roller	417-4503
6K-9070	Washer-Thrust	330-9294
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6K-9151	Bearing-Sleeve	330-9265
6P-0593	Bearing-Roller	386-4959
6P-0593	Bearing-Roller	386-4959
6V-0347	Cone-Spl Tapered	420-6537
6V-4582	Bearing-Ball	380-1504
6V-4582	Bearing-Ball	380-1504
6W-9172	Bearing	389-6330
6W-9172	Bearing	389-6330
6W-9173	Bearing	374-1457
6W-9173	Bearing	374-1457
6Y-5913	Disc-Friction	391-9836
6Y-9960	Mount As.	376-3639
6Y-9960	Mount As.	376-3639
7C-3729	Pulley	376-9066
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-3760	Tube As-O Drain	375-5443
7C-6450	Pipe Gp-Ext	377-5862
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

2CK		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8636	Cone-Bearing	418-9606
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-7302	Bracket	416-5497
7I-4187	Yoke-1550	380-1510
7M-7219	Bearing-Thrust	384-4816
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7P-1577	Pin As	375-9969
7T-2036	Cap As-Fuel	361-1721
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8C-3111	Rod End-Spher	392-4523
8F-6058	Bearing-Sleeve	416-5494
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-2810	Case As-Filter	314-8512
8R-2193	Piston	376-9051
8R-2196	Plate-Reaction	375-2626
8R-2199	Gear-Planet	421-7986
8R-2533	Piston	377-7446
8R-2533	Piston	377-7446
8R-2535	Plate-Reaction	377-7447
8R-2535	Plate-Reaction	377-7447
8S-0248	Breather As	325-6033

2CK		
Original Part Number	Part Name	Classic Part Number
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8S-9151	Cup-Spl Tapered	374-8348
8V-1612	Shaft	425-6456
8V-1612	Shaft	425-6456
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6435	Spider & Brg Kit	377-7451
8W-9566	Flange As	376-9073
9C-3848	Bearing	417-4493
9C-3848	Bearing	417-4493
9C-3857	Pin	374-6503
9C-3857	Pin	374-6503
9C-6318	Bearing-Sleeve	374-6516
9S-7949	Cup-Roller Brg	420-6531
9S-7949	Cup-Roller Brg	420-6531
9V-0247	Plate	417-4527
9V-0247	Plate	417-4527
9V-4975	Bearing-Sleeve	384-4784
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
005-0471	Cone-Spl Tapered	415-1924
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-6267	Plate As-Idler	375-9983
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

Sales Model 918F (Cont'd.)

2CK		
Original Part Number	Part Name	Classic Part Number
101-1530	Bearing-Main	419-6382
105-2125	Joint Gp-Slip	398-2937
105-2125	Joint Gp-Slip	398-2937
107-7708	Bearing-Main	419-6381
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
119-2950	Gasket	433-8195
121-7746	Pre-Cleaner As	360-2311
121-7746	Pre-Cleaner As	360-2311
128-7228	Pump Gp-Vn Bsc-A	422-8153
136-0819	Valve-Exhaust	384-8697
136-0819	Valve-Exhaust	384-8697

2CK		
Original Part Number	Part Name	Classic Part Number
145-0162	Bearing-Main	419-6380
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
152-3952	Impeller-Pump	374-4696
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
226-8202	Seal-Wiper	472-8024
228-0416	Seal As	430-5356

2CK		
Original Part Number	Part Name	Classic Part Number
229-5153	Bearing-Thrust	419-6370
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703
441-9566	Gear-Flywheel	374-4703

3TJ		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-3980	Cone-Roller Brg	399-4443
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1M-7250	Bowl	360-2296
1P-3934	Cup-Roller Brg	420-6535
1P-3934	Cup-Roller Brg	420-6535
1S-7057	Gasket	420-6384
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1401	Ring-Seal	384-4799
1T-1804	Stator As-Conv	388-0572

3TJ		
Original Part Number	Part Name	Classic Part Number
1T-1805	Turbine-Conv	380-1490
1W-1064	Gear-Flywheel	374-4703
1W-1064	Gear-Flywheel	374-4703
2D-2566	Ring-Lock	416-2123
2D-2566	Ring-Lock	416-2123
2K-9295	Bearing-Cone	422-6480
2N-1599	Gear	378-3970
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3H-8726	Mount As	385-7208
3H-8726	Mount As	385-7208
3T-2094	Bearing-Sleeve	388-0638
3T-2094	Bearing-Sleeve	388-0638

3TJ		
Original Part Number	Part Name	Classic Part Number
4E-4524	Pin As	380-7392
4E-4524	Pin As	380-7392
4M-6107	Bearing-Roller	380-7507
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-0998	Lever	314-8687
4T-0998	Lever	314-8687
4V-2057	Bearing-Spher	419-6019

Sales Model 918F (Cont'd.)

3TJ		
Original Part Number	Part Name	Classic Part Number
4V-2057	Bearing-Spher	419-6019
4V-8643	Bearing-Sleeve	374-8354
4V-8643	Bearing-Sleeve	374-8354
4V-8661	Pin As	375-9968
4V-8661	Pin As	375-9968
4V-9901	Pin As	374-6508
4V-9901	Pin As	374-6508
4W-1203	Cup-Rlr Brg	418-9603
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
5J-7010	Seal As	472-8011
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
5L-2031	Cup-Roller Brg	384-5927
5M-6212	Tube	390-0996
5M-6212	Tube	390-0996
5P-9531	Cone-Rlr Bearing	386-4956
6E-6474	Cartridge Gp	422-8135
6E-6474	Cartridge Gp	422-8135
6E-6476	Pump Gp-Vn Bsc-A	422-8163
6E-6476	Pump Gp-Vn Bsc-A	422-8163
6F-2956	Cup-Spl Tapered	420-6538
6I-4689	Gasket-Cyl Head	377-5840
6I-4689	Gasket-Cyl Head	377-5840
6K-2707	Plate-Lock	319-3470
6K-2707	Plate-Lock	319-3470
6K-5746	Bearing-Roller	417-4503
6K-5746	Bearing-Roller	417-4503
6K-9070	Washer-Thrust	330-9294
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6K-9151	Bearing-Sleeve	330-9265

3TJ		
Original Part Number	Part Name	Classic Part Number
6P-0593	Bearing-Roller	386-4959
6P-0593	Bearing-Roller	386-4959
6V-0347	Cone-Spl Tapered	420-6537
6V-4582	Bearing-Ball	380-1504
6V-4582	Bearing-Ball	380-1504
6W-9172	Bearing	389-6330
6W-9172	Bearing	389-6330
6W-9173	Bearing	374-1457
6W-9173	Bearing	374-1457
6Y-5913	Disc-Friction	391-9836
6Y-9960	Mount As.	376-3639
6Y-9960	Mount As.	376-3639
7C-3729	Pulley	376-9066
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-3760	Tube As-O Drain	375-5443
7C-6450	Pipe Gp-Ext	377-5862
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8636	Cone-Bearing	418-9606
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-7302	Bracket	416-5497
7I-4187	Yoke-1550	380-1510
7J-5131	Trunnion	296-1371
7M-7219	Bearing-Thrust	384-4816
7M-7219	Bearing-Thrust	384-4816

3TJ		
Original Part Number	Part Name	Classic Part Number
7P-1577	Pin As	375-9969
7P-1577	Pin As	375-9969
7T-2036	Cap As-Fuel	361-1721
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8C-3111	Rod End-Spher	392-4523
8F-6058	Bearing-Sleeve	416-5494
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-2810	Case As-Filter	314-8512
8R-2193	Piston	376-9051
8R-2196	Plate-Reaction	375-2626
8R-2199	Gear-Planet	421-7986
8R-2533	Piston	377-7446
8R-2533	Piston	377-7446
8R-2535	Plate-Reaction	377-7447
8R-2535	Plate-Reaction	377-7447
8S-0248	Breather As	325-6033
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8S-9151	Cup-Spl Tapered	374-8348
8V-1612	Shaft	425-6456
8V-1612	Shaft	425-6456
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6435	Spider & Brg Kit	377-7451
8W-9587	Flange As	373-5394
8W-9587	Flange As	373-5394
9C-3848	Bearing	417-4493
9C-3848	Bearing	417-4493
9C-3857	Pin	374-6503
9C-3857	Pin	374-6503
9C-6318	Bearing-Sleeve	374-6516

Sales Model 918F (Cont'd.)

3TJ		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7949	Cup-Roller Brg	420-6531
9S-7949	Cup-Roller Brg	420-6531
9V-0247	Plate	417-4527
9V-0247	Plate	417-4527
9V-4975	Bearing-Sleeve	384-4784
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
005-0471	Cone-Spl Tapered	415-1924
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-6267	Plate As-Idler	375-9983
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-1530	Bearing-Main	419-6382
105-2125	Joint Gp-Slip	398-2937
105-2125	Joint Gp-Slip	398-2937
107-7708	Bearing-Main	419-6381
107-7708	Bearing-Main	419-6381

3TJ		
Original Part Number	**Part Name**	**Classic Part Number**
107-7750	Pulley	382-6896
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
119-2950	Gasket	433-8195
121-7746	Pre-Cleaner As	360-2311
121-7746	Pre-Cleaner As	360-2311
128-7228	Pump Gp-Vn Bsc-A	422-8153
136-0819	Valve-Exhaust	384-8697
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
152-3952	Impeller-Pump	374-4696
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372
212-4893	Bearing-Thrust	419-6372

3TJ		
Original Part Number	**Part Name**	**Classic Part Number**
213-3193	Rod As-Conn	379-8870
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
226-8202	Seal-Wiper	472-8024
228-0416	Seal As	430-5356
229-5153	Bearing-Thrust	419-6370
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703
441-9566	Gear-Flywheel	374-4703

5DL		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1P-3934	Cup-Roller Brg	420-6535
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799

5DL		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3G-4704	Bearing-Sleeve	379-0185
3H-8726	Mount As	385-7208

5DL		
Original Part Number	**Part Name**	**Classic Part Number**
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596

Sales Model 918F (Cont'd.)

5DL		
Original Part Number	Part Name	Classic Part Number
4P-8577	Rod As-Injector	455-5513
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019
4V-8643	Bearing-Sleeve	374-8354
4V-8661	Pin As	375-9968
4V-9901	Pin As	374-6508
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
6E-6474	Cartridge Gp	422-8135
6E-6476	Pump Gp-Vn Bsc-A	422-8163
6I-4689	Gasket-Cyl Head	377-5840
6K-2707	Plate-Lock	319-3470
6K-5746	Bearing-Roller	417-4503
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6P-0593	Bearing-Roller	386-4959
6V-4582	Bearing-Ball	380-1504
6W-9172	Bearing	389-6330
6W-9173	Bearing	374-1457
6Y-9960	Mount As.	376-3639
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

5DL		
Original Part Number	Part Name	Classic Part Number
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8R-2533	Piston	377-7446
8R-2535	Plate-Reaction	377-7447
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8V-1612	Shaft	425-6456
8V-6435	Spider & Brg Kit	377-7451
9C-3848	Bearing	417-4493
9C-3857	Pin	374-6503
9S-7949	Cup-Roller Brg	420-6531
9V-0247	Plate	417-4527
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

5DL		
Original Part Number	Part Name	Classic Part Number
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-2125	Joint Gp-Slip	398-2937
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
121-7746	Pre-Cleaner As	360-2311
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model 918M

H26		
Original Part Number	Part Name	Classic Part Number
6I-9103	Bearing-Outer	421-8182

Wheel Loaders

Sales Model 918M (Cont'd.)

H26		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356

H26		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9931	Mount As.	360-2354

H26		
Original Part Number	**Part Name**	**Classic Part Number**
176-3900	Accumulator	416-5513

Sales Model 920

41J		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
1T-0555	Carrier-Gde Whl	384-3853
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1701	Carrier-Stator	384-3853
1T-1987	Housing-Rotating	297-4864
1T-1988	Shaft-Output	428-6656
1T-1991	Stator As-Conv	380-1482
1V-4838	Link As-Spring	308-9874
1W-0777	Muffler As	247-2662
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-6473	Compressor Gp -B	448-9150
1W-9812	Gear-Crankshaft	380-1513

41J		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4404	Housing As-Cl	226-8027
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-0479	Bearing-Cone	380-7506
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7678	Gear-Water Pump	325-6088
3G-7658	Cartridge Gp	426-0427
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823

41J		
Original Part Number	**Part Name**	**Classic Part Number**
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
3P-8393	Plate-Clutch	388-0592
3S-2616	Pump Gp-Trans	226-0165
3S-7987	Shaft-Planet	226-6074
3T-2095	Bearing-Sleeve	384-3459
3V-7427	Housing As	297-7197
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-5891	Plate-Clutch	388-0575

Sales Model 920 (Cont'd.)

41J		
Original Part Number	Part Name	Classic Part Number
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4V-9577	Shaft-Planet	231-0001
4W-0452	Seal As -Cshaft	325-6191
5K-2294	Bearing	396-9912
5L-6326	Bearing-Ball	420-3222
5M-7882	Joint Gp-Univ	297-7210
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2034	Shaft	297-7249
6K-2694	Bearing-Sleeve	453-6504
6K-2697	Bearing-Sleeve	330-9263
6K-2703	Pin-Lower	252-6853
6K-2704	Pin-Upper	252-6873
6K-2706	Cap-Lower	451-6443
6K-2707	Plate-Lock	319-3470
6K-3674	Shaft-Bev Pinion	253-1427
6K-5619	Shaft	253-1429
6K-5625	Gear-Bevel	253-1438
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281

41J		
Original Part Number	Part Name	Classic Part Number
6K-5746	Bearing-Roller	417-4503
6K-6175	Pin	241-2606
6K-6185	Pin-Cylinder	252-6859
6K-6349	Pin	252-6860
6K-7356	Yoke As	330-9296
6K-8275	Cone-Roller Brg	399-6070
6K-8314	Pin	252-6863
6K-8316	Pin	252-6865
6K-8542	Pin	252-6867
6K-8544	Pin	252-6874
6K-8546	Pin	252-6868
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-2237	Gasket Kit	437-3212
6V-2246	Gasket Kit	391-1091
6Y-5348	Disc-Friction	384-4827
6Y-5915	Disc-Friction	384-5936
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9918	Repair Kit-Major	388-0655
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7H-4566	Cup-Roller Brg	399-6068
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7J-9842	Bearing-Sleeve	299-1968
7J-9843	Rod As	469-4667
7K-3913	Rim As	398-2952
7K-5213	Pin	252-6869
7K-6497	Pin	252-6870
7K-7237	Gear-Planet	231-0009
7K-7431	Hub As	470-3783

41J		
Original Part Number	Part Name	Classic Part Number
7K-9346	Pin	252-6871
7K-9347	Pin	252-6875
7K-9348	Pin	252-6872
7K-9589	Bearing-Sleeve	453-6509
7K-9591	Bearing-Sleeve	365-8826
7K-9592	Bearing-Sleeve	360-2336
7K-9593	Bearing-Sleeve	360-2337
7K-9717	Link As-Rear	434-2447
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-7765	Governor As	377-5841
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7043	Mount As	389-6332
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-5687	Hub-Cshft	314-8684

Sales Model 920 (Cont'd.)

41J		
Original Part Number	**Part Name**	**Classic Part Number**
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-6321	Gear-Sun	253-1441
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

62K		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849

41J		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8V-3134	Pinion-Bevel	260-0788
9B-1320	Valve-Check	377-5832
9J-5053	Pump Gp-Vn Bsc-B	422-8169
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125

41J		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

Sales Model 920 (Cont'd.)

62K		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-5480	Cover As.-End	299-1998
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
1T-0555	Carrier-Gde Whl	384-3853
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1701	Carrier-Stator	384-3853
1T-1987	Housing-Rotating	297-4864
1T-1988	Shaft-Output	428-6656
1T-1991	Stator As-Conv	380-1482
1V-4838	Link As-Spring	308-9874
1W-0777	Muffler As	247-2662
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1766	Muffler As.	298-2783
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659

62K		
Original Part Number	Part Name	Classic Part Number
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7082	Rebuild Kt-Pump	383-3681
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-4502	Bearing-Sleeve	299-1986
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4404	Housing As-Cl	226-8027
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2S-0479	Bearing-Cone	380-7506
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357

62K		
Original Part Number	Part Name	Classic Part Number
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-7658	Cartridge Gp	426-0427
3H-8726	Mount As	385-7208
3J-9325	Piston	390-0993
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
3P-8393	Plate-Clutch	388-0592
3S-2616	Pump Gp-Trans	226-0165
3S-7987	Shaft-Planet	226-6074
3T-2095	Bearing-Sleeve	384-3459
3V-7427	Housing As	297-7197
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4864	Pump Gp-F Tfr	242-3442

Sales Model 920 (Cont'd.)

62K		
Original Part Number	Part Name	Classic Part Number
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-5891	Plate-Clutch	388-0575
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4V-9577	Shaft-Planet	231-0001
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5K-2294	Bearing	396-9912
5L-6326	Bearing-Ball	420-3222
5M-7882	Joint Gp-Univ	297-7210
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024

62K		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5S-9080	Pulley-Alt Drive	264-5883
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2034	Shaft	297-7249
6K-2694	Bearing-Sleeve	453-6504
6K-2697	Bearing-Sleeve	330-9263
6K-2703	Pin-Lower	252-6853
6K-2704	Pin-Upper	252-6873
6K-2706	Cap-Lower	451-6443
6K-2707	Plate-Lock	319-3470
6K-3674	Shaft-Bev Pinion	253-1427
6K-4148	Bearing-Sleeve	393-3670
6K-4442	Rod End-Special	373-5388
6K-5619	Shaft	253-1429
6K-5625	Gear-Bevel	253-1438
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-6175	Pin	241-2606
6K-6185	Pin-Cylinder	252-6859
6K-6349	Pin	252-6860
6K-7288	Pin	252-6862
6K-7356	Yoke As	330-9296
6K-8275	Cone-Roller Brg	399-6070

62K		
Original Part Number	Part Name	Classic Part Number
6K-8314	Pin	252-6863
6K-8316	Pin	252-6865
6K-8542	Pin	252-6867
6K-8544	Pin	252-6874
6K-8546	Pin	252-6868
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-0600	Gasket Kit	437-4583
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6V-2237	Gasket Kit	437-3212
6V-2246	Gasket Kit	391-1091
6Y-5348	Disc-Friction	384-4827
6Y-5915	Disc-Friction	384-5936
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7H-4566	Cup-Roller Brg	399-6068
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7J-9842	Bearing-Sleeve	299-1968
7J-9843	Rod As	469-4667
7K-3913	Rim As	398-2952
7K-5213	Pin	252-6869
7K-6497	Pin	252-6870

Sales Model 920 (Cont'd.)

62K		
Original Part Number	Part Name	Classic Part Number
7K-7237	Gear-Planet	231-0009
7K-7431	Hub As	470-3783
7K-9346	Pin	252-6871
7K-9347	Pin	252-6875
7K-9348	Pin	252-6872
7K-9589	Bearing-Sleeve	453-6509
7K-9591	Bearing-Sleeve	365-8826
7K-9592	Bearing-Sleeve	360-2336
7K-9593	Bearing-Sleeve	360-2337
7K-9717	Link As-Rear	434-2447
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192

62K		
Original Part Number	Part Name	Classic Part Number
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7043	Mount As	389-6332
7S-7070	Head As-Cylinder	325-6107
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-6321	Gear-Sun	253-1441
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563

62K		
Original Part Number	Part Name	Classic Part Number
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
8V-3134	Pinion-Bevel	260-0788
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
9B-1320	Valve-Check	377-5832

Sales Model 920 (Cont'd.)

62K		
Original Part Number	Part Name	Classic Part Number
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-5053	Pump Gp-Vn Bsc-B	422-8169
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193

62K		
Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0556	Kit-Rebuild-Pump	383-3712
170-0560	Rebuild Kit-Pump	363-7458
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698

62K		
Original Part Number	Part Name	Classic Part Number
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

75J		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344

75J		
Original Part Number	Part Name	Classic Part Number
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
1T-0555	Carrier-Gde Whl	384-3853
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1701	Carrier-Stator	384-3853
1T-1987	Housing-Rotating	297-4864
1T-1988	Shaft-Output	428-6656

75J		
Original Part Number	Part Name	Classic Part Number
1T-1991	Stator As-Conv	380-1482
1V-4838	Link As-Spring	308-9874
1W-0777	Muffler As	247-2662
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836

Sales Model 920 (Cont'd.)

75J		
Original Part Number	Part Name	Classic Part Number
2D-2566	Ring-Lock	416-2123
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4404	Housing As-Cl	226-8027
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-0479	Bearing-Cone	380-7506
2S-6097	Tang	375-9979
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7678	Gear-Water Pump	325-6088
3G-7658	Cartridge Gp	426-0427
3H-8726	Mount As	385-7208
3J-9325	Piston	390-0993
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
3P-8393	Plate-Clutch	388-0592
3S-2616	Pump Gp-Trans	226-0165
3S-7987	Shaft-Planet	226-6074
3T-2095	Bearing-Sleeve	384-3459

75J		
Original Part Number	Part Name	Classic Part Number
3V-7427	Housing As	297-7197
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-5891	Plate-Clutch	388-0575
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4T-8054	Seal As	472-8010
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4V-9577	Shaft-Planet	231-0001
4W-0452	Seal As -Cshaft	325-6191
5G-3612	Cap Gp-Protn	295-6419
5K-2294	Bearing	396-9912
5L-6326	Bearing-Ball	420-3222
5M-7882	Joint Gp-Univ	297-7210
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5S-9080	Pulley-Alt Drive	264-5883

75J		
Original Part Number	Part Name	Classic Part Number
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2034	Shaft	297-7249
6K-2694	Bearing-Sleeve	453-6504
6K-2697	Bearing-Sleeve	330-9263
6K-2703	Pin-Lower	252-6853
6K-2704	Pin-Upper	252-6873
6K-2706	Cap-Lower	451-6443
6K-2707	Plate-Lock	319-3470
6K-3674	Shaft-Bev Pinion	253-1427
6K-4442	Rod End-Special	373-5388
6K-5619	Shaft	253-1429
6K-5625	Gear-Bevel	253-1438
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-6175	Pin	241-2606
6K-6185	Pin-Cylinder	252-6859
6K-6349	Pin	252-6860
6K-7288	Pin	252-6862
6K-7356	Yoke As	330-9296
6K-8275	Cone-Roller Brg	399-6070
6K-8314	Pin	252-6863
6K-8316	Pin	252-6865
6K-8542	Pin	252-6867
6K-8544	Pin	252-6874
6K-8546	Pin	252-6868
6K-8895	Cap	374-6500
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544

Sales Model 920 (Cont'd.)

75J		
Original Part Number	**Part Name**	**Classic Part Number**
6P-7704	Carrier-Ring	314-8658
6S-3474	Pin As	375-9981
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6V-2246	Gasket Kit	391-1091
6Y-5348	Disc-Friction	384-4827
6Y-5915	Disc-Friction	384-5936
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-5085	Bushing	377-5829
7E-9918	Repair Kit-Major	388-0655
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7H-4566	Cup-Roller Brg	399-6068
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7J-9842	Bearing-Sleeve	299-1968
7J-9843	Rod As	469-4667
7K-3913	Rim As	398-2952
7K-5213	Pin	252-6869
7K-6497	Pin	252-6870
7K-7237	Gear-Planet	231-0009
7K-7431	Hub As	470-3783
7K-9346	Pin	252-6871
7K-9347	Pin	252-6875
7K-9348	Pin	252-6872
7K-9589	Bearing-Sleeve	453-6509
7K-9591	Bearing-Sleeve	365-8826
7K-9592	Bearing-Sleeve	360-2336
7K-9593	Bearing-Sleeve	360-2337
7K-9717	Link As-Rear	434-2447
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451

75J		
Original Part Number	**Part Name**	**Classic Part Number**
7N-2834	Kit-Repair	374-4723
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-7765	Governor As	377-5841
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7043	Mount As	389-6332
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-6058	Bearing-Sleeve	416-5494
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-6321	Gear-Sun	253-1441
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1849	Bearing-Conn Rod	379-0196

75J		
Original Part Number	**Part Name**	**Classic Part Number**
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8V-3134	Pinion-Bevel	260-0788
8W-9587	Flange As	373-5394
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-5053	Pump Gp-Vn Bsc-B	422-8169
9M-4789	Shaft-Gov Cont	297-7256

Sales Model 920 (Cont'd.)

75J		
Original Part Number	Part Name	Classic Part Number
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126

75J		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
169-1750	Seal Gp-Basic	472-8022
170-0556	Kit-Rebuild-Pump	383-3712
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646

75J		
Original Part Number	Part Name	Classic Part Number
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

89R		
Original Part Number	Part Name	Classic Part Number
3K-4290	Rod End	374-1823
6K-4442	Rod End-Special	373-5388

Sales Model 922A

59A		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1K-8041	Bearing-Sleeve	330-9257
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894

59A		
Original Part Number	Part Name	Classic Part Number
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2H-3517	Bearing-Inner	417-4505
2K-0535	Nut	299-2026
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2K-5065	Cone-Roller Brg	416-2157

59A		
Original Part Number	Part Name	Classic Part Number
2K-8753	Pinion-Bevel	253-1432
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
2V-1074	Shaft-Planet	364-5262
2V-5608	Shaft-Pin (Bevel)	446-3056
3G-2720	Cartridge Gp-Rr	448-5051

Sales Model 922A (Cont'd.)

59A		
Original Part Number	**Part Name**	**Classic Part Number**
3G-2749	Cartridge Gp-Rr	422-8125
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3K-7110	Gear-Planet	253-1435
3P-1210	Cone-Roller Brg	399-4433
3S-2616	Pump Gp-Trans	226-0165
3T-2095	Bearing-Sleeve	384-3459
4D-2619	Bearing	417-4494
4M-0410	Gear-Oil Pump Dr	428-6660
4M-5858	Bearing-Spl Ball	417-4495
4T-6869	Cartridge Gp	422-8104
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-2031	Cup-Roller Brg	384-5927
5M-2054	Bearing	380-7510
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5V-7574	Ring-Retaining	392-4483
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6K-4148	Bearing-Sleeve	393-3670
6K-4442	Rod End-Special	373-5388
6K-6175	Pin	241-2606
6K-7288	Pin	252-6862
6K-7356	Yoke As	330-9296
6K-8314	Pin	252-6863
6K-8316	Pin	252-6865
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7K-9346	Pin	252-6871
7K-9348	Pin	252-6872
7K-9589	Bearing-Sleeve	453-6509
7K-9591	Bearing-Sleeve	365-8826

59A		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9592	Bearing-Sleeve	360-2336
7K-9717	Link As-Rear	434-2447
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8S-9686	Gasket Kit	393-5215
8W-9587	Flange As	373-5394
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9K-5780	Rim As	388-6597
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1K-8041	Bearing-Sleeve	330-9257
1N-4337	Bearing-Conn Rod	419-6328
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0210	Bearing-Ball	417-4498
2D-2566	Ring-Lock	416-2123

59A		
Original Part Number	**Part Name**	**Classic Part Number**
2H-3517	Bearing-Inner	417-4505
2K-0535	Nut	299-2026
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2K-5065	Cone-Roller Brg	416-2157
2K-8753	Pinion-Bevel	253-1432
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2V-1074	Shaft-Planet	364-5262
2V-5608	Shaft-Pin (Bevel)	446-3056
3G-2720	Cartridge Gp-Rr	448-5051
3G-2749	Cartridge Gp-Rr	422-8125
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3K-7110	Gear-Planet	253-1435
3P-1210	Cone-Roller Brg	399-4433
3S-2616	Pump Gp-Trans	226-0165
3T-2095	Bearing-Sleeve	384-3459
4D-2619	Bearing	417-4494
4M-5858	Bearing-Spl Ball	417-4495
4T-6869	Cartridge Gp	422-8104
5L-2031	Cup-Roller Brg	384-5927
5M-2054	Bearing	380-7510
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5S-1211	Cover-Valve	314-8665
5V-7574	Ring-Retaining	392-4483
6K-4148	Bearing-Sleeve	393-3670
6K-4442	Rod End-Special	373-5388
6K-6175	Pin	241-2606
6K-7288	Pin	252-6862
6K-7356	Yoke As	330-9296
6K-8314	Pin	252-6863
6K-8316	Pin	252-6865

Sales Model 922A (Cont'd.)

59A		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
7K-9346	Pin	252-6871
7K-9348	Pin	252-6872
7K-9589	Bearing-Sleeve	453-6509
7K-9591	Bearing-Sleeve	365-8826
7K-9592	Bearing-Sleeve	360-2336
7K-9717	Link As-Rear	434-2447

59A		
Original Part Number	Part Name	Classic Part Number
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
8H-5352	Bearing-Ball	453-3658
8S-4996	Muffler	390-0909
8S-9686	Gasket Kit	393-5215
8W-9587	Flange As	373-5394

59A		
Original Part Number	Part Name	Classic Part Number
9K-5780	Rim As	388-6597
9L-2685	Rod End	419-1866
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-9431	Precleaner As	361-1718
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

Sales Model 922B

59A		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1K-8041	Bearing-Sleeve	330-9257
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0210	Bearing-Ball	417-4498
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2H-3517	Bearing-Inner	417-4505
2K-0535	Nut	299-2026
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2K-5065	Cone-Roller Brg	416-2157
2K-8753	Pinion-Bevel	253-1432
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532

59A		
Original Part Number	Part Name	Classic Part Number
2S-4015	Plunger As-Valve	311-9438
2V-1074	Shaft-Planet	364-5262
2V-5608	Shaft-Pin (Bevel)	446-3056
3G-2720	Cartridge Gp-Rr	448-5051
3G-2749	Cartridge Gp-Rr	422-8125
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3K-7110	Gear-Planet	253-1435
3P-1210	Cone-Roller Brg	399-4433
3S-2616	Pump Gp-Trans	226-0165
3T-2095	Bearing-Sleeve	384-3459
4D-2619	Bearing	417-4494
4M-0410	Gear-Oil Pump Dr	428-6660
4M-5858	Bearing-Spl Ball	417-4495
4T-6869	Cartridge Gp	422-8104
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5L-2031	Cup-Roller Brg	384-5927
5M-2054	Bearing	380-7510
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498

59A		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5V-7574	Ring-Retaining	392-4483
6B-6224	Ferrule	419-4738
6H-3957	Bearing-Ball	311-9358
6K-4148	Bearing-Sleeve	393-3670
6K-4442	Rod End-Special	373-5388
6K-6175	Pin	241-2606
6K-7288	Pin	252-6862
6K-7356	Yoke As	330-9296
6K-8314	Pin	252-6863
6K-8316	Pin	252-6865
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7K-9346	Pin	252-6871
7K-9348	Pin	252-6872
7K-9589	Bearing-Sleeve	453-6509
7K-9591	Bearing-Sleeve	365-8826
7K-9592	Bearing-Sleeve	360-2336
7K-9717	Link As-Rear	434-2447
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348

Sales Model 922B (Cont'd.)

59A		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494

59A		
Original Part Number	**Part Name**	**Classic Part Number**
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8S-9686	Gasket Kit	393-5215
8W-9587	Flange As	373-5394
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9K-5780	Rim As	388-6597

59A		
Original Part Number	**Part Name**	**Classic Part Number**
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

63A		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1K-8041	Bearing-Sleeve	330-9257
1N-4337	Bearing-Conn Rod	419-6328
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0210	Bearing-Ball	417-4498
2D-2566	Ring-Lock	416-2123
2H-3517	Bearing-Inner	417-4505
2K-0535	Nut	299-2026
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2K-5065	Cone-Roller Brg	416-2157
2K-8753	Pinion-Bevel	253-1432
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2V-1074	Shaft-Planet	364-5262
2V-5608	Shaft-Pin (Bevel)	446-3056
3G-2720	Cartridge Gp-Rr	448-5051
3G-2749	Cartridge Gp-Rr	422-8125

63A		
Original Part Number	**Part Name**	**Classic Part Number**
3H-8726	Mount As	385-7208
3K-4290	Rod End	374-1823
3K-7110	Gear-Planet	253-1435
3P-1210	Cone-Roller Brg	399-4433
3S-2616	Pump Gp-Trans	226-0165
3T-2095	Bearing-Sleeve	384-3459
4D-2619	Bearing	417-4494
4M-5858	Bearing-Spl Ball	417-4495
4T-6869	Cartridge Gp	422-8104
5L-2031	Cup-Roller Brg	384-5927
5M-2054	Bearing	380-7510
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5S-1211	Cover-Valve	314-8665
5V-7574	Ring-Retaining	392-4483
6K-4148	Bearing-Sleeve	393-3670
6K-4442	Rod End-Special	373-5388
6K-6175	Pin	241-2606
6K-7288	Pin	252-6862
6K-7356	Yoke As	330-9296
6K-8314	Pin	252-6863
6K-8316	Pin	252-6865
6V-2202	Bearing-Spl Ball	380-1574

63A		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9346	Pin	252-6871
7K-9348	Pin	252-6872
7K-9589	Bearing-Sleeve	453-6509
7K-9591	Bearing-Sleeve	365-8826
7K-9592	Bearing-Sleeve	360-2336
7K-9717	Link As-Rear	434-2447
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
8H-5352	Bearing-Ball	453-3658
8S-4996	Muffler	390-0909
8S-9686	Gasket Kit	393-5215
8W-9587	Flange As	373-5394
9K-5780	Rim As	388-6597
9L-2685	Rod End	419-1866
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-9431	Precleaner As	361-1718
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

Sales Model 922B (Cont'd.)

74J		
Original Part Number	Part Name	Classic Part Number
1W-7082	Rebuild Kt-Pump	383-3681
2F-5721	Bearing-Ball	311-9354

74J		
Original Part Number	Part Name	Classic Part Number
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656

74J		
Original Part Number	Part Name	Classic Part Number
8M-3368	Valve-Check	388-6599
9K-5780	Rim As	388-6597

88J		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0210	Bearing-Ball	417-4498
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-2566	Ring-Lock	416-2123
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-0535	Nut	299-2026
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2K-5065	Cone-Roller Brg	416-2157
2K-8753	Pinion-Bevel	253-1432
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533

88J		
Original Part Number	Part Name	Classic Part Number
2M-4209	Spacer-Timing	417-4532
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2V-1074	Shaft-Planet	364-5262
2V-5608	Shaft-Pin (Bevel)	446-3056
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
3G-2720	Cartridge Gp-Rr	448-5051
3G-2749	Cartridge Gp-Rr	422-8125
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3K-7110	Gear-Planet	253-1435
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433
3S-2616	Pump Gp-Trans	226-0165
3T-2095	Bearing-Sleeve	384-3459
4D-2619	Bearing	417-4494
4M-5858	Bearing-Spl Ball	417-4495
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4T-6869	Cartridge Gp	422-8104

88J		
Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As -Cshaft	325-6191
5G-3612	Cap Gp-Protn	295-6419
5L-2031	Cup-Roller Brg	384-5927
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5V-7574	Ring-Retaining	392-4483
6I-1345	Shaft As-O Pump	374-7475
6K-4148	Bearing-Sleeve	393-3670
6K-4442	Rod End-Special	373-5388
6K-6175	Pin	241-2606
6K-7288	Pin	252-6862
6K-7356	Yoke As	330-9296
6K-8314	Pin	252-6863
6K-8316	Pin	252-6865
6N-1036	Gear-Oil Pump	279-4991
6N-2820	Pump Gp-Eng Oil	415-1903
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7C-3862	Camshaft	458-0151

Sales Model 922B (Cont'd.)

88J		
Original Part Number	**Part Name**	**Classic Part Number**
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7K-9346	Pin	252-6871
7K-9348	Pin	252-6872
7K-9589	Bearing-Sleeve	453-6509
7K-9591	Bearing-Sleeve	365-8826
7K-9592	Bearing-Sleeve	360-2336
7K-9717	Link As-Rear	434-2447
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7043	Mount As	389-6332
7S-7070	Head As-Cylinder	325-6107
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381

88J		
Original Part Number	**Part Name**	**Classic Part Number**
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
8W-9587	Flange As	373-5394
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891

88J		
Original Part Number	**Part Name**	**Classic Part Number**
9K-5780	Rim As	388-6597
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9S-2356	Manifold-Exhaust	261-0905
9S-7788	Ring-Piston	461-5124
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
170-7502	Shaft-Dr Idler	374-7484
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345

Sales Model 922B (Cont'd.)

88J		
Original Part Number	Part Name	Classic Part Number
1K-8041	Bearing-Sleeve	330-9257
1M-0090	Gasket-Manifold	445-7701
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1S-9670	Univ Jt As	443-2017
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0210	Bearing-Ball	417-4498
1W-7074	Kit-Rebuild-Pump	419-4712
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-2566	Ring-Lock	416-2123
2H-3517	Bearing-Inner	417-4505
2K-0535	Nut	299-2026
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2K-5065	Cone-Roller Brg	416-2157
2K-8753	Pinion-Bevel	253-1432
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
2V-1074	Shaft-Planet	364-5262
2V-5608	Shaft-Pin (Bevel)	446-3056
3G-2720	Cartridge Gp-Rr	448-5051
3G-2749	Cartridge Gp-Rr	422-8125
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3K-7110	Gear-Planet	253-1435
3P-1210	Cone-Roller Brg	399-4433

88J		
Original Part Number	Part Name	Classic Part Number
3S-2616	Pump Gp-Trans	226-0165
3T-2095	Bearing-Sleeve	384-3459
4D-2619	Bearing	417-4494
4M-5858	Bearing-Spl Ball	417-4495
4T-6869	Cartridge Gp	422-8104
5H-7071	Director-Water	388-0555
5L-2031	Cup-Roller Brg	384-5927
5M-2054	Bearing	380-7510
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5V-7574	Ring-Retaining	392-4483
6B-6224	Ferrule	419-4738
6K-4148	Bearing-Sleeve	393-3670
6K-4442	Rod End-Special	373-5388
6K-6175	Pin	241-2606
6K-7288	Pin	252-6862
6K-7356	Yoke As	330-9296
6K-8314	Pin	252-6863
6K-8316	Pin	252-6865
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7K-9346	Pin	252-6871
7K-9348	Pin	252-6872
7K-9589	Bearing-Sleeve	453-6509
7K-9591	Bearing-Sleeve	365-8826
7K-9592	Bearing-Sleeve	360-2336
7K-9717	Link As-Rear	434-2447
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774

88J		
Original Part Number	Part Name	Classic Part Number
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7043	Mount As	389-6332
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8M-3368	Valve-Check	388-6599
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-9686	Gasket Kit	393-5215
8W-9587	Flange As	373-5394
9H-2256	Pump Gp-F Prm	311-9443
9K-5780	Rim As	388-6597
9M-5477	Bearing-Sleeve	374-6517
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-9431	Precleaner As	361-1718
108-5603	Screw-Adj Arm	379-0166
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
308-1845	Seal-Wiper	472-8032
1W-7074	Kit-Rebuild-Pump	419-4712
2L-5271	Bearing-Ball	371-4305
8M-3368	Valve-Check	388-6599
9K-5780	Rim As	388-6597

4YN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1P-3934	Cup-Roller Brg	420-6535
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1804	Stator As-Conv	388-0572
1T-1805	Turbine-Conv	380-1490
1W-1064	Gear-Flywheel	374-4703
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3H-8726	Mount As	385-7208
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4V-2057	Bearing-Spher	419-6019
4V-8643	Bearing-Sleeve	374-8354
4V-8661	Pin As	375-9968
4V-9901	Pin As	374-6508
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
6I-4689	Gasket-Cyl Head	377-5840
6K-2707	Plate-Lock	319-3470
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6P-0593	Bearing-Roller	386-4959
6V-4582	Bearing-Ball	380-1504
6W-9172	Bearing	389-6330
6W-9173	Bearing	374-1457

4YN		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-9960	Mount As.	376-3639
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-2036	Cap As-Fuel	361-1721
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8R-2533	Piston	377-7446
8R-2535	Plate-Reaction	377-7447
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8V-1612	Shaft	425-6456
8V-6435	Spider & Brg Kit	377-7451
9C-3848	Bearing	417-4493
9C-3857	Pin	374-6503
9S-7949	Cup-Roller Brg	420-6531
9V-3363	Pin As	396-0663
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610

4YN		
Original Part Number	**Part Name**	**Classic Part Number**
005-0471	Cone-Spl Tapered	415-1924
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-2125	Joint Gp-Slip	398-2937
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
116-8539	Spider & Brg Kit	399-4399
119-2950	Gasket	433-8195
121-7746	Pre-Cleaner As	360-2311
128-7228	Pump Gp-Vn Bsc-A	422-8153
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
154-5685	Kit-Dt Gasket	396-0649
165-9864	Gasket Kit-Sch	388-0659
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model 924F (Cont'd.)

5NN		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-3934	Cup-Roller Brg	420-6535
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1804	Stator As-Conv	388-0572
1T-1805	Turbine-Conv	380-1490
1W-1064	Gear-Flywheel	374-4703
2D-2566	Ring-Lock	416-2123
2G-6375	Shaft-Drive	275-5282
2G-6377	Sprocket	275-5286
2G-9097	Cap	418-1926
2G-9098	Cap	300-2573
2M-5685	Bearing-Needle	380-7469
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3E-7461	Gasket Kit-Sch	437-4575
3H-8726	Mount As	385-7208
3T-2094	Bearing-Sleeve	388-0638
4E-3997	Housing-Pinion	374-6498
4E-4524	Pin As	380-7392
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4V-2057	Bearing-Spher	419-6019
4V-8643	Bearing-Sleeve	374-8354
4V-8661	Pin As	375-9968
4V-9901	Pin As	374-6508
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-0735	Chain Gp	390-5262

5NN		
Original Part Number	Part Name	Classic Part Number
5V-1274	Spider	385-6110
6F-2956	Cup-Spl Tapered	420-6538
6G-7213	Carrier-Planet	396-9936
6I-4689	Gasket-Cyl Head	377-5840
6K-2707	Plate-Lock	319-3470
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6P-0593	Bearing-Roller	386-4959
6V-4582	Bearing-Ball	380-1504
6W-9172	Bearing	389-6330
6W-9173	Bearing	374-1457
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-9960	Mount As.	376-3639
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7J-5131	Trunnion	296-1371
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-2036	Cap As-Fuel	361-1721
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8D-8633	Shaft-Drive	275-5281
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8H-2810	Case As-Filter	314-8512

5NN		
Original Part Number	Part Name	Classic Part Number
8R-2533	Piston	377-7446
8R-2535	Plate-Reaction	377-7447
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8V-1612	Shaft	425-6456
8V-6435	Spider & Brg Kit	377-7451
8W-2307	Shaft-Planet	275-5284
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-9587	Flange As	373-5394
8X-4741	Insert	375-4335
9C-3848	Bearing	417-4493
9C-3857	Pin	374-6503
9D-2756	Insert	333-4949
9S-7949	Cup-Roller Brg	420-6531
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-2125	Joint Gp-Slip	398-2937
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
116-8539	Spider & Brg Kit	399-4399
119-2950	Gasket	433-8195
121-7746	Pre-Cleaner As	360-2311

Sales Model 924F (Cont'd.)

5NN		
Original Part Number	**Part Name**	**Classic Part Number**
128-7228	Pump Gp-Vn Bsc-A	422-8153
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
136-0819	Valve-Exhaust	384-8697
138-1840	Retainer-Seal	374-6511
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-3400	Spindle	282-6549

5NN		
Original Part Number	**Part Name**	**Classic Part Number**
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
154-5685	Kit-Dt Gasket	396-0649
165-9864	Gasket Kit-Sch	388-0659
176-3900	Accumulator	416-5513
178-3086	Ballstud	374-1453
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370

5NN		
Original Part Number	**Part Name**	**Classic Part Number**
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

6MN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1P-3934	Cup-Roller Brg	420-6535
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1804	Stator As-Conv	388-0572
1T-1805	Turbine-Conv	380-1490
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3E-7461	Gasket Kit-Sch	437-4575
3H-8726	Mount As	385-7208
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4V-2057	Bearing-Spher	419-6019
4V-8643	Bearing-Sleeve	374-8354
4V-8661	Pin As	375-9968

6MN		
Original Part Number	**Part Name**	**Classic Part Number**
4V-9901	Pin As	374-6508
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
6I-4689	Gasket-Cyl Head	377-5840
6K-2707	Plate-Lock	319-3470
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6P-0593	Bearing-Roller	386-4959
6V-4582	Bearing-Ball	380-1504
6W-9172	Bearing	389-6330
6W-9173	Bearing	374-1457
6Y-9960	Mount As.	376-3639
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607

6MN		
Original Part Number	**Part Name**	**Classic Part Number**
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-2036	Cap As-Fuel	361-1721
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8R-2533	Piston	377-7446
8R-2535	Plate-Reaction	377-7447
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8V-1612	Shaft	425-6456
8V-6435	Spider & Brg Kit	377-7451
8W-9566	Flange As	376-9073
9C-3848	Bearing	417-4493
9C-3857	Pin	374-6503
9S-7949	Cup-Roller Brg	420-6531
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671

Sales Model 924F (Cont'd.)

6MN		
Original Part Number	**Part Name**	**Classic Part Number**
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-2125	Joint Gp-Slip	398-2937
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
116-8539	Spider & Brg Kit	399-4399

6MN		
Original Part Number	**Part Name**	**Classic Part Number**
119-2950	Gasket	433-8195
121-7746	Pre-Cleaner As	360-2311
128-7228	Pump Gp-Vn Bsc-A	422-8153
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
154-5685	Kit-Dt Gasket	396-0649
165-9864	Gasket Kit-Sch	388-0659
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372

6MN		
Original Part Number	**Part Name**	**Classic Part Number**
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

7PN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1P-3934	Cup-Roller Brg	420-6535
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1804	Stator As-Conv	388-0572
1T-1805	Turbine-Conv	380-1490
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2K-9295	Bearing-Cone	422-6480
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-4704	Bearing-Sleeve	379-0185
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3H-8726	Mount As	385-7208
3T-2094	Bearing-Sleeve	388-0638
3W-4363	Pin As	375-2634

7PN		
Original Part Number	**Part Name**	**Classic Part Number**
4E-4524	Pin As	380-7392
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019
4V-2873	Bearing-Sleeve	379-0192
4V-8643	Bearing-Sleeve	374-8354
4V-8661	Pin As	375-9968
4V-9901	Pin As	374-6508
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
6F-2956	Cup-Spl Tapered	420-6538
6I-4689	Gasket-Cyl Head	377-5840
6K-2707	Plate-Lock	319-3470

7PN		
Original Part Number	**Part Name**	**Classic Part Number**
6K-5746	Bearing-Roller	417-4503
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6P-0593	Bearing-Roller	386-4959
6V-0347	Cone-Spl Tapered	420-6537
6V-4582	Bearing-Ball	380-1504
6W-9172	Bearing	389-6330
6W-9173	Bearing	374-1457
6Y-5913	Disc-Friction	391-9836
6Y-9960	Mount As.	376-3639
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449

Sales Model 924F (Cont'd.)

7PN		
Original Part Number	**Part Name**	**Classic Part Number**
7E-7302	Bracket	416-5497
7I-4187	Yoke-1550	380-1510
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7P-1577	Pin As	375-9969
7T-2036	Cap As-Fuel	361-1721
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8D-0983	Mounting	384-3470
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8H-2810	Case As-Filter	314-8512
8R-2193	Piston	376-9051
8R-2196	Plate-Reaction	375-2626
8R-2199	Gear-Planet	421-7986
8R-2533	Piston	377-7446
8R-2535	Plate-Reaction	377-7447
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8V-1612	Shaft	425-6456
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
9C-3848	Bearing	417-4493
9C-3857	Pin	374-6503
9C-6318	Bearing-Sleeve	374-6516

7PN		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7949	Cup-Roller Brg	420-6531
9V-0247	Plate	417-4527
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-2125	Joint Gp-Slip	398-2937
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
121-7746	Pre-Cleaner As	360-2311
128-7228	Pump Gp-Vn Bsc-A	422-8153
135-7393	Head	382-6895
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380

7PN		
Original Part Number	**Part Name**	**Classic Part Number**
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
154-5685	Kit-Dt Gasket	396-0649
165-9864	Gasket Kit-Sch	388-0659
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
228-0416	Seal As	430-5356
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model 924G

3DZ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
3P-1210	Cone-Roller Brg	399-4433

3DZ		
Original Part Number	**Part Name**	**Classic Part Number**
3T-2094	Bearing-Sleeve	388-0638
4T-0231	Retainer	376-3641
4V-8520	Bearing-Sleeve	307-1527
4V-8643	Bearing-Sleeve	374-8354
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011

3DZ		
Original Part Number	**Part Name**	**Classic Part Number**
5L-2031	Cup-Roller Brg	384-5927
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6K-9070	Washer-Thrust	330-9294

Sales Model 924G (Cont'd.)

3DZ		
Original Part Number	**Part Name**	**Classic Part Number**
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6V-0347	Cone-Spl Tapered	420-6537
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-7302	Bracket	416-5497
7M-7219	Bearing-Thrust	384-4816
7P-3466	Bearing-Sleeve	422-9523
8C-3111	Rod End-Spher	392-4523

3DZ		
Original Part Number	**Part Name**	**Classic Part Number**
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8S-9151	Cup-Spl Tapered	374-8348
9D-7924	Mount As	360-2356
9S-7949	Cup-Roller Brg	420-6531
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947

3DZ		
Original Part Number	**Part Name**	**Classic Part Number**
114-1071	Piston	388-6583
116-8539	Spider & Brg Kit	399-4399
121-7746	Pre-Cleaner As	360-2311
132-2463	Joint Gp-Slip	432-6605
159-3263	Muffler As	430-7623
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028

3PZ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
3G-2797	Bearing-Sleeve	360-2329
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4T-8054	Seal As	472-8010
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428

3PZ		
Original Part Number	**Part Name**	**Classic Part Number**
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6V-0347	Cone-Spl Tapered	420-6537
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-7302	Bracket	416-5497
7J-6250	Bearing-Sleeve	385-3803
7J-9344	Bearing-Sleeve	360-2334
7J-9884	Bearing-Sleeve	325-6016
7K-9528	Bearing-Sleeve	308-9828
7M-7219	Bearing-Thrust	384-4816
7P-3466	Bearing-Sleeve	422-9523
8C-3111	Rod End-Spher	392-4523
8S-9151	Cup-Spl Tapered	374-8348

3PZ		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
9S-7949	Cup-Roller Brg	420-6531
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
116-8539	Spider & Brg Kit	399-4399
121-7746	Pre-Cleaner As	360-2311
132-2463	Joint Gp-Slip	432-6605
159-3263	Muffler As	430-7623
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

6YW		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437

Sales Model 924G (Cont'd.)

6YW		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0421	Flange As-Output	295-5442
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0699	Impeller-Conv	235-1808
1T-0902	Bearing-Sleeve	389-6326
1T-1790	Carrier As	296-1347
1T-1880	Carrier-Ring	295-0408
1T-1993	Wheel-Turbine	235-0920
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

6YW		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6987	Valve As-Check	420-6221
1W-7940	Spider As-Fan	295-5443
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-9192	Bearing-Ball	394-8236
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2W-0994	Body As-Preclnr	367-6084
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley-Alt	295-5692
3E-4880	Coupling As	417-9465
3G-2797	Bearing-Sleeve	360-2329
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126

6YW		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-2094	Bearing-Sleeve	388-0638
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-5355	Flange	386-3052
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4D-4065	Rod End-Spher	374-1824
4M-5858	Bearing-Spl Ball	417-4495
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217

Sales Model 924G (Cont'd.)

6YW		
Original Part Number	Part Name	Classic Part Number
4P-9943	Seal-End Tank	385-7216
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-8643	Bearing-Sleeve	374-8354
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-2817	Ejector As	295-6423
4Y-4951	Muffler As	419-0889
5D-2989	Bearing	380-7511
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

6YW		
Original Part Number	Part Name	Classic Part Number
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6N-8992	Adapter-Fan	394-9810
6P-7704	Carrier-Ring	314-8658
6S-2828	Cup-Roller Brg	384-5932
6T-0248	Ring-Seal	295-6440
6T-3080	Plate-Cl B& Brake	325-6170
6T-7882	Gear-Planet	296-1352
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6Y-0145	Plate-Locking	419-8801
6Y-3896	Pin As	325-6132
6Y-4819	Carrier-Planet	296-1348
6Y-7946	Disc-Friction	384-4801
6Y-8037	Guide As	435-9915
7C-3567	Mount As	314-8689
7C-4297	Seal As-Cshaft	325-6192
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-5816	Shaft-Fan	399-8552
7E-7302	Bracket	416-5497
7E-8830	Bracket As-Fan	383-3697
7E-9980	Camshaft	377-5851
7F-9541	Pin As-Drawbar	296-1361

6YW		
Original Part Number	Part Name	Classic Part Number
7F-9547	Pin As.-Drawbar	295-0414
7G-2830	Ring-Seal	295-6441
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7H-7628	Bearing	453-3655
7J-1333	Bearing-Sleeve	295-6408
7J-6250	Bearing-Sleeve	385-3803
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
7J-9884	Bearing-Sleeve	325-6016
7K-9528	Bearing-Sleeve	308-9828
7K-9639	Bearing-Sleeve	314-8643
7M-1296	Valve-Relief	390-0990
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-1164	Mount As	295-5451
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-8370	Bearing	295-6410
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417

Sales Model 924G (Cont'd.)

6YW		
Original Part Number	Part Name	Classic Part Number
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5838	Ejector As-Ex	443-2660
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-3111	Rod End-Spher	392-4523
8D-1817	Cup-Roller Brg	434-3296
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-8311	Bearin - Sleeve	295-6412
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-8628	Flange-Joint	217-9776
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349

6YW		
Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3517	Bearing-Spl Ball	417-4501
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8T-1177	Bearing-Rlr	419-1862
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1499	Gear-Pump (Oil)	295-6424
9G-6744	Bearing-Sleeve	418-1931
9G-8638	Gear-Planet	295-6425
9G-9180	Hub-Sprocket	295-6436
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9J-5875	Bearing-Sleeve	308-9830

6YW		
Original Part Number	Part Name	Classic Part Number
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9T-5360	Plate-Pressure	424-4941
9U-8481	Pin As.	295-5675
9W-2344	Coupling-Pump Dr	314-8666
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-8270	Gear-Ring	308-9859
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
102-8636	Gear-Drive	472-8035
106-7799	Bearing-Ball	396-9947
108-7754	Housing As.	433-9856
111-8015	Gasket As-Head	279-4977
112-5088	Muffler As.	396-9943
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
114-1071	Piston	388-6583
116-8539	Spider & Brg Kit	399-4399
121-7746	Pre-Cleaner As	360-2311
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
132-2463	Joint Gp-Slip	432-6605

Sales Model 924G (Cont'd.)

6YW		
Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
159-3263	Muffler As	430-7623
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7767	Pump Gp-Water -B	296-1365
176-3900	Accumulator	416-5513
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
233-9204	Kit-Seal-H.Cyl-1	472-8025
258-2303	Bearing-Sleeve	307-1524
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989

6YW		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
3G-2797	Bearing-Sleeve	360-2329
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4J-0121	Cap-Bearing	360-2344
4T-8054	Seal As	472-8010
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6N-9133	Gasket-Plate	398-2959
6V-0347	Cone-Spl Tapered	420-6537
6V-3831	Seal-O-Ring	436-2657
7C-0307	Gasket	399-8571
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-7302	Bracket	416-5497
7J-6250	Bearing-Sleeve	385-3803
7J-9344	Bearing-Sleeve	360-2334

6YW		
Original Part Number	Part Name	Classic Part Number
7J-9346	Bearing-Sleeve	374-8357
7J-9884	Bearing-Sleeve	325-6016
7K-9528	Bearing-Sleeve	308-9828
7K-9639	Bearing-Sleeve	314-8643
7M-7219	Bearing-Thrust	384-4816
7N-7628	Gasket	419-1811
7P-3466	Bearing-Sleeve	422-9523
8C-3111	Rod End-Spher	392-4523
8S-9151	Cup-Spl Tapered	374-8348
9D-7924	Mount As	360-2356
9M-1328	Bearing-Aligning	325-6018
9S-7949	Cup-Roller Brg	420-6531
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
108-7930	Bearing As	377-7463
114-1071	Piston	388-6583
116-8539	Spider & Brg Kit	399-4399
121-7746	Pre-Cleaner As	360-2311
132-2463	Joint Gp-Slip	432-6605
135-4928	Shaft-Water Pump	386-3813
159-3263	Muffler As	430-7623
160-9874	Kit-Gasket-Scl	386-3048
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
283-5666	Gasket-Cyl Head	388-6565
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 924G (Cont'd.)

AAB		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
3G-2797	Bearing-Sleeve	360-2329
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4P-7051	Pulley-Alt	376-9064
4V-8520	Bearing-Sleeve	307-1527
4V-8643	Bearing-Sleeve	374-8354
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
6F-2956	Cup-Spl Tapered	420-6538

AAB		
Original Part Number	**Part Name**	**Classic Part Number**
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6V-0347	Cone-Spl Tapered	420-6537
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-7302	Bracket	416-5497
7M-7219	Bearing-Thrust	384-4816
7P-3466	Bearing-Sleeve	422-9523
8C-3111	Rod End-Spher	392-4523
8S-9151	Cup-Spl Tapered	374-8348

AAB		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
9S-7949	Cup-Roller Brg	420-6531
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
116-8539	Spider & Brg Kit	399-4399
121-7746	Pre-Cleaner As	360-2311
132-2463	Joint Gp-Slip	432-6605
159-3263	Muffler As	430-7623
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

AAN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
3G-2797	Bearing-Sleeve	360-2329
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4P-7051	Pulley-Alt	376-9064
4T-8054	Seal As	472-8010
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919

AAN		
Original Part Number	**Part Name**	**Classic Part Number**
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6V-0347	Cone-Spl Tapered	420-6537
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-7302	Bracket	416-5497
7J-9344	Bearing-Sleeve	360-2334
7K-9639	Bearing-Sleeve	314-8643
7M-7219	Bearing-Thrust	384-4816
7P-3466	Bearing-Sleeve	422-9523
8C-3111	Rod End-Spher	392-4523

AAN		
Original Part Number	**Part Name**	**Classic Part Number**
8S-9151	Cup-Spl Tapered	374-8348
9D-7924	Mount As	360-2356
9M-1328	Bearing-Aligning	325-6018
9S-7949	Cup-Roller Brg	420-6531
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
116-8539	Spider & Brg Kit	399-4399
121-7746	Pre-Cleaner As	360-2311
132-2463	Joint Gp-Slip	432-6605
159-3263	Muffler As	430-7623
176-3900	Accumulator	416-5513
226-8202	Seal-Wiper	472-8024

Sales Model 924G (Cont'd.)

AAN		
Original Part Number	**Part Name**	**Classic Part Number**
233-9204	Kit-Seal-H.Cyl-1	472-8025

AAN		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

AAN		
Original Part Number	**Part Name**	**Classic Part Number**
308-1845	Seal-Wiper	472-8032

DDA		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
2A-4429	Lock-Retainer	379-0174
2K-4502	Bearing-Sleeve	299-1986
2W-7213	Bearing-Sleeve	419-4667
3G-2797	Bearing-Sleeve	360-2329
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4T-8054	Seal As	472-8010
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

DDA		
Original Part Number	**Part Name**	**Classic Part Number**
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
7J-9884	Bearing-Sleeve	325-6016
7K-0078	Bearing-Sleeve	308-9825
7K-9528	Bearing-Sleeve	308-9828
7K-9639	Bearing-Sleeve	314-8643
7M-7219	Bearing-Thrust	384-4816
7P-3466	Bearing-Sleeve	422-9523
7W-5095	Gear-Flywheel	425-9190
8S-9151	Cup-Spl Tapered	374-8348
9D-7924	Mount As	360-2356
9J-5875	Bearing-Sleeve	308-9830
9M-1328	Bearing-Aligning	325-6018
9S-7949	Cup-Roller Brg	420-6531
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610

DDA		
Original Part Number	**Part Name**	**Classic Part Number**
005-0471	Cone-Spl Tapered	415-1924
101-1530	Bearing-Main	419-6382
106-7799	Bearing-Ball	396-9947
107-7708	Bearing-Main	419-6381
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
121-7746	Pre-Cleaner As	360-2311
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
176-3900	Accumulator	416-5513
199-5067	Muffler As	360-7894
212-4893	Bearing-Thrust	419-6372
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

DFZ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437

Sales Model 924G (Cont'd.)

DFZ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
2K-4502	Bearing-Sleeve	299-1986
3G-2797	Bearing-Sleeve	360-2329
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4T-8054	Seal As	472-8010
4V-8520	Bearing-Sleeve	307-1527
4V-8643	Bearing-Sleeve	374-8354
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576

DFZ		
Original Part Number	**Part Name**	**Classic Part Number**
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7J-6250	Bearing-Sleeve	385-3803
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
7J-9884	Bearing-Sleeve	325-6016
7K-0078	Bearing-Sleeve	308-9825
7K-9528	Bearing-Sleeve	308-9828
7K-9639	Bearing-Sleeve	314-8643
7M-7219	Bearing-Thrust	384-4816
7P-3466	Bearing-Sleeve	422-9523
8S-9151	Cup-Spl Tapered	374-8348
9D-7924	Mount As	360-2356
9J-5875	Bearing-Sleeve	308-9830

DFZ		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1328	Bearing-Aligning	325-6018
9S-7949	Cup-Roller Brg	420-6531
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
176-3900	Accumulator	416-5513
199-5067	Muffler As	360-7894
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

EEB		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
3G-2797	Bearing-Sleeve	360-2329
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927

EEB		
Original Part Number	**Part Name**	**Classic Part Number**
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7P-3466	Bearing-Sleeve	422-9523
8S-9151	Cup-Spl Tapered	374-8348

EEB		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
9S-7949	Cup-Roller Brg	420-6531
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
176-3900	Accumulator	416-5513
199-5067	Muffler As	360-7894
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

Sales Model 924G (Cont'd.)

RBB		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
2K-4442	Bearing-Sleeve	308-9812
3G-2797	Bearing-Sleeve	360-2329
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4K-0299	Bearing-Sleeve	308-9816
4T-8054	Seal As	472-8010
4V-8520	Bearing-Sleeve	307-1527
4V-8643	Bearing-Sleeve	374-8354
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927

RBB		
Original Part Number	**Part Name**	**Classic Part Number**
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7J-9344	Bearing-Sleeve	360-2334
7M-7219	Bearing-Thrust	384-4816
7P-3466	Bearing-Sleeve	422-9523
8D-7086	Bearing	330-9251
8S-9151	Cup-Spl Tapered	374-8348
9D-7924	Mount As	360-2356
9M-1328	Bearing-Aligning	325-6018

RBB		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7949	Cup-Roller Brg	420-6531
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
199-5067	Muffler As	360-7894
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

RTA		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
3G-2797	Bearing-Sleeve	360-2329
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4V-8520	Bearing-Sleeve	307-1527
4V-8643	Bearing-Sleeve	374-8354
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927

RTA		
Original Part Number	**Part Name**	**Classic Part Number**
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7M-7219	Bearing-Thrust	384-4816
7P-3466	Bearing-Sleeve	422-9523
8S-9151	Cup-Spl Tapered	374-8348
9D-7924	Mount As	360-2356

RTA		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7949	Cup-Roller Brg	420-6531
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
176-3900	Accumulator	416-5513
199-5067	Muffler As	360-7894
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

Sales Model 924G (Cont'd.)

WGX		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-8643	Bearing-Sleeve	374-8354
5J-7010	Seal As	472-8011

WGX		
Original Part Number	**Part Name**	**Classic Part Number**
5L-2031	Cup-Roller Brg	384-5927
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6K-8314	Pin	252-6863
6V-0347	Cone-Spl Tapered	420-6537
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7K-0084	Bearing-Sleeve	453-6508
7M-7219	Bearing-Thrust	384-4816
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155

WGX		
Original Part Number	**Part Name**	**Classic Part Number**
8S-9151	Cup-Spl Tapered	374-8348
9D-7924	Mount As	360-2356
9S-7949	Cup-Roller Brg	420-6531
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
176-3900	Accumulator	416-5513
199-5067	Muffler As	360-7894
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028

WMB		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
3G-2797	Bearing-Sleeve	360-2329
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4T-8054	Seal As	472-8010
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919

WMB		
Original Part Number	**Part Name**	**Classic Part Number**
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7J-6250	Bearing-Sleeve	385-3803
7J-9344	Bearing-Sleeve	360-2334
7J-9884	Bearing-Sleeve	325-6016
7K-9528	Bearing-Sleeve	308-9828
7M-7219	Bearing-Thrust	384-4816
7P-3466	Bearing-Sleeve	422-9523
8S-9151	Cup-Spl Tapered	374-8348

WMB		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
9S-7949	Cup-Roller Brg	420-6531
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
176-3900	Accumulator	416-5513
199-5067	Muffler As	360-7894
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 924H

HXC		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
2K-4502	Bearing-Sleeve	299-1986
3G-2797	Bearing-Sleeve	360-2329
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4J-0121	Cap-Bearing	360-2344
4T-8054	Seal As	472-8010
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
6F-2956	Cup-Spl Tapered	420-6538

HXC		
Original Part Number	Part Name	Classic Part Number
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7J-5131	Trunnion	296-1371
7J-9346	Bearing-Sleeve	374-8357
7M-7219	Bearing-Thrust	384-4816
7P-3466	Bearing-Sleeve	422-9523
8S-9151	Cup-Spl Tapered	374-8348
9D-7924	Mount As	360-2356
9M-1328	Bearing-Aligning	325-6018

HXC		
Original Part Number	Part Name	Classic Part Number
9S-7949	Cup-Roller Brg	420-6531
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

JRL		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
3G-2797	Bearing-Sleeve	360-2329
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4V-8643	Bearing-Sleeve	374-8354
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
6F-2956	Cup-Spl Tapered	420-6538

JRL		
Original Part Number	Part Name	Classic Part Number
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
8S-9151	Cup-Spl Tapered	374-8348
9D-7924	Mount As	360-2356
9S-7949	Cup-Roller Brg	420-6531
9W-9930	Mount As	295-6437

JRL		
Original Part Number	Part Name	Classic Part Number
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

JTM		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443

JTM		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
3G-2797	Bearing-Sleeve	360-2329

Sales Model 924H (Cont'd.)

JTM		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576

JTM		
Original Part Number	**Part Name**	**Classic Part Number**
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7M-7219	Bearing-Thrust	384-4816
7P-3466	Bearing-Sleeve	422-9523
8S-9151	Cup-Spl Tapered	374-8348
9D-7924	Mount As	360-2356
9S-7949	Cup-Roller Brg	420-6531
9W-9930	Mount As	295-6437

JTM		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

JZZ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
2K-4502	Bearing-Sleeve	299-1986
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4J-0121	Cap-Bearing	360-2344
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-8643	Bearing-Sleeve	374-8354
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927

JZZ		
Original Part Number	**Part Name**	**Classic Part Number**
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7J-5131	Trunnion	296-1371
7J-9346	Bearing-Sleeve	374-8357
7M-7219	Bearing-Thrust	384-4816
8S-9151	Cup-Spl Tapered	374-8348
9D-7924	Mount As	360-2356
9M-1328	Bearing-Aligning	325-6018

JZZ		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7949	Cup-Roller Brg	420-6531
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

KLN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296

KLN		
Original Part Number	**Part Name**	**Classic Part Number**
2K-4442	Bearing-Sleeve	308-9812
3G-2797	Bearing-Sleeve	360-2329

KLN		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638

Sales Model 924H (Cont'd.)

KLN		
Original Part Number	**Part Name**	**Classic Part Number**
4K-0299	Bearing-Sleeve	308-9816
4T-8054	Seal As	472-8010
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537

KLN		
Original Part Number	**Part Name**	**Classic Part Number**
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7J-9344	Bearing-Sleeve	360-2334
7K-9639	Bearing-Sleeve	314-8643
7P-3466	Bearing-Sleeve	422-9523
8S-9151	Cup-Spl Tapered	374-8348
9D-7924	Mount As	360-2356
9M-1328	Bearing-Aligning	325-6018
9S-7949	Cup-Roller Brg	420-6531
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355

KLN		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

LKW		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
3G-2797	Bearing-Sleeve	360-2329
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
6F-2956	Cup-Spl Tapered	420-6538

LKW		
Original Part Number	**Part Name**	**Classic Part Number**
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7P-3466	Bearing-Sleeve	422-9523
9D-7924	Mount As	360-2356
9S-7949	Cup-Roller Brg	420-6531
9W-9930	Mount As	295-6437

LKW		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

PED		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
3G-2797	Bearing-Sleeve	360-2329
3G-8932	Pin	325-6143

PED		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-2873	Bearing-Sleeve	379-0192

PED		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8643	Bearing-Sleeve	374-8354
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919

Sales Model 924H (Cont'd.)

PED		
Original Part Number	**Part Name**	**Classic Part Number**
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7M-7219	Bearing-Thrust	384-4816
8S-9151	Cup-Spl Tapered	374-8348

PED		
Original Part Number	**Part Name**	**Classic Part Number**
9D-7924	Mount As	360-2356
9S-7949	Cup-Roller Brg	420-6531
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

PED		
Original Part Number	**Part Name**	**Classic Part Number**
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

RCB		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
3G-2797	Bearing-Sleeve	360-2329
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4V-8643	Bearing-Sleeve	374-8354
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
6F-2956	Cup-Spl Tapered	420-6538

RCB		
Original Part Number	**Part Name**	**Classic Part Number**
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
8S-9151	Cup-Spl Tapered	374-8348
9D-7924	Mount As	360-2356
9S-7949	Cup-Roller Brg	420-6531
9W-9930	Mount As	295-6437

RCB		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

RRS		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
2K-4442	Bearing-Sleeve	308-9812
3G-2797	Bearing-Sleeve	360-2329
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4K-0299	Bearing-Sleeve	308-9816

RRS		
Original Part Number	**Part Name**	**Classic Part Number**
4T-8054	Seal As	472-8010
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428

RRS		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0347	Cone-Spl Tapered	420-6537
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7K-9639	Bearing-Sleeve	314-8643
7P-3466	Bearing-Sleeve	422-9523
8S-9151	Cup-Spl Tapered	374-8348
9D-7924	Mount As	360-2356
9M-1328	Bearing-Aligning	325-6018

Sales Model 924H (Cont'd.)

RRS		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7949	Cup-Roller Brg	420-6531
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610

RRS		
Original Part Number	**Part Name**	**Classic Part Number**
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
226-8202	Seal-Wiper	472-8024

RRS		
Original Part Number	**Part Name**	**Classic Part Number**
233-9204	Kit-Seal-H.Cyl-1	472-8025
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

WEM		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495

WEM		
Original Part Number	**Part Name**	**Classic Part Number**
6J-6604	Pin	419-6071
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7J-6461	Crown	325-6054
9D-7924	Mount As	360-2356
9J-9812	Bearing	434-7258
9S-7949	Cup-Roller Brg	420-6531
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610

WEM		
Original Part Number	**Part Name**	**Classic Part Number**
005-0471	Cone-Spl Tapered	415-1924
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
150-0351	Spacer	396-7291
160-6306	Cap-Bearing	325-6038
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

WLB		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
3G-2797	Bearing-Sleeve	360-2329
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4V-8643	Bearing-Sleeve	374-8354
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
6F-2956	Cup-Spl Tapered	420-6538

WLB		
Original Part Number	**Part Name**	**Classic Part Number**
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
8S-9151	Cup-Spl Tapered	374-8348
9D-7924	Mount As	360-2356
9S-7949	Cup-Roller Brg	420-6531
9W-9930	Mount As	295-6437

WLB		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

ENC		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
2K-4502	Bearing-Sleeve	299-1986
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-8643	Bearing-Sleeve	374-8354

ENC		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8675	Bearing-Sleeve	394-0187
6E-4892	Cyl Gp-089 478 Y	394-9828
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6V-0347	Cone-Spl Tapered	420-6537
6Y-7929	Disc-Friction	456-0555
7K-9528	Bearing-Sleeve	308-9828

ENC		
Original Part Number	**Part Name**	**Classic Part Number**
7P-3466	Bearing-Sleeve	422-9523
9M-1328	Bearing-Aligning	325-6018
9W-9931	Mount As.	360-2354
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
121-7746	Pre-Cleaner As	360-2311
135-7393	Head	382-6895
274-4553	Disc-Clutch	416-2153
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

HJF		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
2K-4502	Bearing-Sleeve	299-1986
3P-1210	Cone-Roller Brg	399-4433
4V-5099	Cover	418-1929
5T-5682	Driver	418-9579
6F-2956	Cup-Spl Tapered	420-6538

HJF		
Original Part Number	**Part Name**	**Classic Part Number**
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6V-0347	Cone-Spl Tapered	420-6537
6Y-7929	Disc-Friction	456-0555
7J-9346	Bearing-Sleeve	374-8357
7P-3466	Bearing-Sleeve	422-9523

HJF		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1328	Bearing-Aligning	325-6018
9W-9931	Mount As.	360-2354
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
121-7746	Pre-Cleaner As	360-2311
274-4553	Disc-Clutch	416-2153
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

KW4		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
3G-2797	Bearing-Sleeve	360-2329
3P-1210	Cone-Roller Brg	399-4433
4V-5099	Cover	418-1929
4V-8643	Bearing-Sleeve	374-8354

KW4		
Original Part Number	**Part Name**	**Classic Part Number**
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6V-0347	Cone-Spl Tapered	420-6537
6Y-7929	Disc-Friction	456-0555
7P-3466	Bearing-Sleeve	422-9523

KW4		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1328	Bearing-Aligning	325-6018
9W-9931	Mount As.	360-2354
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
121-7746	Pre-Cleaner As	360-2311
135-7393	Head	382-6895
274-4553	Disc-Clutch	416-2153
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028

Sales Model 924K (Cont'd.)

KW4		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030

KW4		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032

PWR		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
2K-4502	Bearing-Sleeve	299-1986
3G-4704	Bearing-Sleeve	379-0185
3P-1210	Cone-Roller Brg	399-4433
4V-5099	Cover	418-1929
5T-5682	Driver	418-9579
6F-2956	Cup-Spl Tapered	420-6538

PWR		
Original Part Number	Part Name	Classic Part Number
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6V-0347	Cone-Spl Tapered	420-6537
6Y-7929	Disc-Friction	456-0555
7J-9344	Bearing-Sleeve	360-2334
7K-9528	Bearing-Sleeve	308-9828
7P-3466	Bearing-Sleeve	422-9523

PWR		
Original Part Number	Part Name	Classic Part Number
8J-5778	Bearing-Sleeve	374-8359
9M-1328	Bearing-Aligning	325-6018
9W-9931	Mount As.	360-2354
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
121-7746	Pre-Cleaner As	360-2311
274-4553	Disc-Clutch	416-2153
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

SNZ		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
3P-1210	Cone-Roller Brg	399-4433
4V-5099	Cover	418-1929
5T-5682	Driver	418-9579
6F-2956	Cup-Spl Tapered	420-6538

SNZ		
Original Part Number	Part Name	Classic Part Number
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6V-0347	Cone-Spl Tapered	420-6537
6Y-7929	Disc-Friction	456-0555
7P-3466	Bearing-Sleeve	422-9523

SNZ		
Original Part Number	Part Name	Classic Part Number
9M-1328	Bearing-Aligning	325-6018
9W-9931	Mount As.	360-2354
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
121-7746	Pre-Cleaner As	360-2311
274-4553	Disc-Clutch	416-2153

Sales Model 926

SNP		
Original Part Number	Part Name	Classic Part Number
0R-8169	Compressor Gp	386-2063
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257

SNP		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077

SNP		
Original Part Number	Part Name	Classic Part Number
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476

Sales Model 926 (Cont'd.)

SNP		
Original Part Number	Part Name	Classic Part Number
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3G-2797	Bearing-Sleeve	360-2329
3T-2094	Bearing-Sleeve	388-0638
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-4852	Piston	433-0452

SNP		
Original Part Number	Part Name	Classic Part Number
4V-6527	Disc	376-9050
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5V-7574	Ring-Retaining	392-4483
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6H-3957	Bearing-Ball	311-9358
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6N-6721	Coupling	377-5830
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7C-7955	Gasket-Cover	382-6899
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7I-4187	Yoke-1550	380-1510
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-7166	Race-Brg Thrust	417-4531

SNP		
Original Part Number	Part Name	Classic Part Number
7S-8576	Bearing As	435-4848
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8V-1612	Shaft	425-6456
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
9G-5525	Shaft-Planet	419-8662
9G-8931	Yoke As	446-3074
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-5096	Flexplate	455-3271
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-5168	Manifold-Exhaust	374-7483

Sales Model 926 (Cont'd.)

SNP		
Original Part Number	Part Name	Classic Part Number
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834

SNP		
Original Part Number	Part Name	Classic Part Number
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311

SNP		
Original Part Number	Part Name	Classic Part Number
213-1364	Bearing-Sleeve	330-9255

4NB		
Original Part Number	Part Name	Classic Part Number
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513

4NB		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-8753	Pinion-Bevel	253-1432
2K-9295	Bearing-Cone	422-6480
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329
3K-3124	Muffler-Trap	247-2673
3T-2094	Bearing-Sleeve	388-0638
4E-3456	Lever As	367-6081
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-3603	Pin As	319-3441
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452

4NB		
Original Part Number	Part Name	Classic Part Number
4V-6527	Disc	376-9050
4V-9577	Shaft-Planet	231-0001
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
4Y-1034	Pin As	396-0641
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5V-7574	Ring-Retaining	392-4483
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-2694	Bearing-Sleeve	453-6504
6K-2704	Pin-Upper	252-6873
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070

Sales Model 926 (Cont'd.)

4NB		
Original Part Number	**Part Name**	**Classic Part Number**
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7C-7955	Gasket-Cover	382-6899
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7I-4187	Yoke-1550	380-1510
7J-8893	Cone-Roller Brg	374-1846
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7K-7237	Gear-Planet	231-0009
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848

4NB		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7166	Race-Brg Thrust	417-4531
7S-7681	Pipe-Exh Ext	385-7213
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6321	Gear-Sun	253-1441
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8T-2470	Gasket Kit	393-5219
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972

4NB		
Original Part Number	**Part Name**	**Classic Part Number**
8W-9566	Flange As	376-9073
9G-5525	Shaft-Planet	419-8662
9G-8931	Yoke As	446-3074
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-5096	Flexplate	455-3271
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795
9Y-5168	Manifold-Exhaust	374-7483
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
140-2383	Gasket Kit	396-9927
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024

4TC		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296

4TC		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147

4TC		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847

Sales Model 926 (Cont'd.)

4TC		
Original Part Number	Part Name	Classic Part Number
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3G-2797	Bearing-Sleeve	360-2329
3T-2094	Bearing-Sleeve	388-0638
4E-3456	Lever As	367-6081
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-3603	Pin As	319-3441
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050

4TC		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
4Y-1034	Pin As	396-0641
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5V-7574	Ring-Retaining	392-4483
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6H-3957	Bearing-Ball	311-9358
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-6832	Bearing-Rlr As	421-8181

4TC		
Original Part Number	Part Name	Classic Part Number
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7C-7955	Gasket-Cover	382-6899
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7I-4187	Yoke-1550	380-1510
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
9G-5525	Shaft-Planet	419-8662
9G-8931	Yoke As	446-3074
9L-2685	Rod End	419-1866

Sales Model 926 (Cont'd.)

4TC		
Original Part Number	**Part Name**	**Classic Part Number**
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108

4TC		
Original Part Number	**Part Name**	**Classic Part Number**
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-5096	Flexplate	455-3271
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795

4TC		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-5168	Manifold-Exhaust	374-7483
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024

7TC		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558

7TC		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3G-2797	Bearing-Sleeve	360-2329
3K-3124	Muffler-Trap	247-2673
3T-2094	Bearing-Sleeve	388-0638
4E-3456	Lever As	367-6081
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502

7TC		
Original Part Number	**Part Name**	**Classic Part Number**
4T-0998	Lever	314-8687
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-3603	Pin As	319-3441
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
4Y-1034	Pin As	396-0641
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5V-7574	Ring-Retaining	392-4483
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6H-3957	Bearing-Ball	311-9358
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855

Sales Model 926 (Cont'd.)

7TC		
Original Part Number	Part Name	Classic Part Number
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7C-7955	Gasket-Cover	382-6899
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7I-4187	Yoke-1550	380-1510
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983

7TC		
Original Part Number	Part Name	Classic Part Number
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7S-7681	Pipe-Exh Ext	385-7213
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788

7TC		
Original Part Number	Part Name	Classic Part Number
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
9G-5525	Shaft-Planet	419-8662
9G-8931	Yoke As	446-3074
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-5096	Flexplate	455-3271
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795
9Y-5168	Manifold-Exhaust	374-7483
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024

8NB		
Original Part Number	Part Name	Classic Part Number
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076

8NB		
Original Part Number	Part Name	Classic Part Number
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799

8NB		
Original Part Number	Part Name	Classic Part Number
1T-1428	Retainer-Brg	300-2587
1T-1446	Impeller-Conv	377-7413
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079

Sales Model 926 (Cont'd.)

8NB		
Original Part Number	**Part Name**	**Classic Part Number**
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-6167	Bearing-Sleeve	299-1960
3K-3124	Muffler-Trap	247-2673
3T-2094	Bearing-Sleeve	388-0638
4E-3456	Lever As	367-6081
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502

8NB		
Original Part Number	**Part Name**	**Classic Part Number**
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-3603	Pin As	319-3441
4V-3623	Pin As	375-9967
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
4Y-1034	Pin As	396-0641
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5V-7574	Ring-Retaining	392-4483
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6H-3957	Bearing-Ball	311-9358
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281

8NB		
Original Part Number	**Part Name**	**Classic Part Number**
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7C-7955	Gasket-Cover	382-6899
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7I-4187	Yoke-1550	380-1510
7J-1309	Bearing-Aligning	360-2275
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-9528	Bearing-Sleeve	308-9828
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7S-7681	Pipe-Exh Ext	385-7213
7S-8576	Bearing As	435-4848
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509

Sales Model 926 (Cont'd.)

8NB		
Original Part Number	Part Name	Classic Part Number
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8V-1612	Shaft	425-6456

8NB		
Original Part Number	Part Name	Classic Part Number
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
9G-5525	Shaft-Planet	419-8662
9G-8931	Yoke As	446-3074
9J-3206	Bearing-Spher	360-2275
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

8NB		
Original Part Number	Part Name	Classic Part Number
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795
9Y-5168	Manifold-Exhaust	374-7483
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
140-2383	Gasket Kit	396-9927
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

94Z		
Original Part Number	Part Name	Classic Part Number
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476

94Z		
Original Part Number	Part Name	Classic Part Number
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913

94Z		
Original Part Number	Part Name	Classic Part Number
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3G-2797	Bearing-Sleeve	360-2329
3K-3124	Muffler-Trap	247-2673
3T-2094	Bearing-Sleeve	388-0638
4E-3456	Lever As	367-6081
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499

Sales Model 926 (Cont'd.)

94Z		
Original Part Number	**Part Name**	**Classic Part Number**
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-3603	Pin As	319-3441
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
4Y-1034	Pin As	396-0641
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5V-7574	Ring-Retaining	392-4483
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6H-3957	Bearing-Ball	311-9358
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266

94Z		
Original Part Number	**Part Name**	**Classic Part Number**
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7C-7955	Gasket-Cover	382-6899
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7I-4187	Yoke-1550	380-1510
7J-9344	Bearing-Sleeve	360-2334
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7S-7681	Pipe-Exh Ext	385-7213
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582

94Z		
Original Part Number	**Part Name**	**Classic Part Number**
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8T-2470	Gasket Kit	393-5219
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
9G-5525	Shaft-Planet	419-8662
9G-8931	Yoke As	446-3074
9J-5875	Bearing-Sleeve	308-9830
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-5096	Flexplate	455-3271
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795
9Y-5168	Manifold-Exhaust	374-7483
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699

Sales Model 926 (Cont'd.)

94Z		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
140-2383	Gasket Kit	396-9927
213-1364	Bearing-Sleeve	330-9255

94Z		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028

94Z		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 926E

1CB		
Original Part Number	Part Name	Classic Part Number
0R-8169	Compressor Gp	386-2063
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

1CB		
Original Part Number	Part Name	Classic Part Number
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3G-2797	Bearing-Sleeve	360-2329
3T-2094	Bearing-Sleeve	388-0638
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261

1CB		
Original Part Number	Part Name	Classic Part Number
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5V-7574	Ring-Retaining	392-4483
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6H-3957	Bearing-Ball	311-9358
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6N-6721	Coupling	377-5830
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7C-7955	Gasket-Cover	382-6899
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7I-4187	Yoke-1550	380-1510

Sales Model 926E (Cont'd.)

1CB		
Original Part Number	**Part Name**	**Classic Part Number**
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-7166	Race-Brg Thrust	417-4531
7S-8576	Bearing As	435-4848
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-2051	Compressor Gp -B	386-2063

1CB		
Original Part Number	**Part Name**	**Classic Part Number**
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8V-1612	Shaft	425-6456
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
9G-5525	Shaft-Planet	419-8662
9G-8931	Yoke As	446-3074
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607

1CB		
Original Part Number	**Part Name**	**Classic Part Number**
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-5096	Flexplate	455-3271
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-5168	Manifold-Exhaust	374-7483
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
213-1364	Bearing-Sleeve	330-9255

4NB		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1N-3822	Bearing-Conn Rod	376-9077

4NB		
Original Part Number	**Part Name**	**Classic Part Number**
1P-4693	Cup-Rlr Bearing	377-7398
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1T-1446	Impeller-Conv	377-7413
1U-2665	Cartridge Gp	422-8108
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117
1U-2668	Cartridge Gp	422-8117

4NB		
Original Part Number	**Part Name**	**Classic Part Number**
1V-6342	Gear As	308-9847
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

Sales Model 926E (Cont'd.)

4NB		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-2654	Ring-Lock	380-1488
2F-5721	Bearing-Ball	311-9354
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0535	Nut	299-2026
2K-8753	Pinion-Bevel	253-1432
2K-9295	Bearing-Cone	422-6480
2S-0479	Bearing-Cone	380-7506
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
2W-8271	Arm As-Rocker	432-8912
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329
3G-2797	Bearing-Sleeve	360-2329
3K-3124	Muffler-Trap	247-2673
3K-3124	Muffler-Trap	247-2673
3T-2094	Bearing-Sleeve	388-0638
3T-2094	Bearing-Sleeve	388-0638

4NB		
Original Part Number	Part Name	Classic Part Number
4E-3456	Lever As	367-6081
4E-3456	Lever As	367-6081
4M-3915	Bearing-Caged	377-7427
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-0660	Muffler As	298-2787
4P-4757	Muffler As	360-7877
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4T-0998	Lever	314-8687
4V-0094	Shaft-Planet	380-1486
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2588	Pin As	435-6050
4V-3603	Pin As	319-3441
4V-3603	Pin As	319-3441
4V-3680	Bellcrank	308-9802
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4V-6527	Disc	376-9050
4V-9577	Shaft-Planet	231-0001
4W-1203	Cup-Rlr Brg	418-9603
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2042	Spacer	325-6217

4NB		
Original Part Number	Part Name	Classic Part Number
4W-2357	Mount As	386-4927
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
4W-9492	Repair Kt-Major	375-2261
4Y-1034	Pin As	396-0641
4Y-1034	Pin As	396-0641
5L-2031	Cup-Roller Brg	384-5927
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5S-9080	Pulley-Alt Drive	264-5883
5V-7574	Ring-Retaining	392-4483
5V-7574	Ring-Retaining	392-4483
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6H-3957	Bearing-Ball	311-9358
6I-8849	Cone-Rlr Bearing	415-1919
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6I-8860	Cup-Roller Brg	380-7495
6K-2694	Bearing-Sleeve	453-6504
6K-2704	Pin-Upper	252-6873

Sales Model 926E (Cont'd.)

4NB		
Original Part Number	Part Name	Classic Part Number
6K-4189	Spacer	367-6075
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6K-8275	Cone-Roller Brg	399-6070
6L-7751	Rod End-Spher	472-8015
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6P-3735	Shaft-Planet	368-0103
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6V-2202	Bearing-Spl Ball	380-1574

4NB		
Original Part Number	Part Name	Classic Part Number
6V-6896	Rebuild Kit	390-1006
6V-6896	Rebuild Kit	390-1006
6Y-6832	Bearing-Rlr As	421-8181
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
6Y-7965	Disc-Friction	392-4518
7C-7955	Gasket-Cover	382-6899
7C-7955	Gasket-Cover	382-6899
7G-7610	Gear-Ring	375-2625
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7G-7611	Gear-Ring	398-2925
7I-4187	Yoke-1550	380-1510
7I-4187	Yoke-1550	380-1510
7J-8893	Cone-Roller Brg	374-1846
7K-2135	Bearing-Roller	417-4492
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7K-7237	Gear-Planet	231-0009
7K-8877	Cone-Bearing	374-1847
7M-7219	Bearing-Thrust	384-4816
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7N-7166	Race-Brg Thrust	417-4531
7S-7681	Pipe-Exh Ext	385-7213
7S-7681	Pipe-Exh Ext	385-7213
7S-8576	Bearing As	435-4848
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583

4NB		
Original Part Number	Part Name	Classic Part Number
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7W-2059	Gasket-Cyl Hd	380-1548
8E-4589	Carrier As	416-2122
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8H-9789	Bearing-Ball	374-8342
8K-6321	Gear-Sun	253-1441
8N-2051	Compressor Gp -B	386-2063
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8S-9151	Cup-Spl Tapered	374-8348
8T-2470	Gasket Kit	393-5219
8V-1612	Shaft	425-6456
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-1624	Lever	299-2019

Sales Model 926E (Cont'd.)

4NB		
Original Part Number	Part Name	Classic Part Number
8V-3134	Pinion-Bevel	260-0788
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
8V-6825	Joint Gp-Slip	453-0972
8W-9566	Flange As	376-9073
8W-9566	Flange As	376-9073
9G-5525	Shaft-Planet	419-8662
9G-5525	Shaft-Planet	419-8662
9G-8931	Yoke As	446-3074
9G-8931	Yoke As	446-3074
9L-2685	Rod End	419-1866
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9M-1853	Mount As.	376-3638
9N-5246	Bearing-Camshaft	384-4772
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607

4NB		
Original Part Number	Part Name	Classic Part Number
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-5096	Flexplate	455-3271
9T-5096	Flexplate	455-3271
9W-6044	Shaft-Planet	384-5957
9W-6044	Shaft-Planet	384-5957

4NB		
Original Part Number	Part Name	Classic Part Number
9W-6046	Carrier As	388-0645
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795
9W-6390	Sleeve	385-3795
9Y-5168	Manifold-Exhaust	374-7483
9Y-5168	Manifold-Exhaust	374-7483
100-8010	Valve	423-5583
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
121-7746	Pre-Cleaner As	360-2311
140-2383	Gasket Kit	396-9927
213-1364	Bearing-Sleeve	330-9255
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024
226-8202	Seal-Wiper	472-8024

4TC		
Original Part Number	Part Name	Classic Part Number
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294

4TC		
Original Part Number	Part Name	Classic Part Number
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

4TC		
Original Part Number	Part Name	Classic Part Number
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3G-2797	Bearing-Sleeve	360-2329
3T-2094	Bearing-Sleeve	388-0638

Sales Model 926E (Cont'd.)

4TC		
Original Part Number	**Part Name**	**Classic Part Number**
4E-3456	Lever As	367-6081
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-3603	Pin As	319-3441
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
4Y-1034	Pin As	396-0641
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5V-7574	Ring-Retaining	392-4483
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6H-3957	Bearing-Ball	311-9358
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266

4TC		
Original Part Number	**Part Name**	**Classic Part Number**
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7C-7955	Gasket-Cover	382-6899
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7I-4187	Yoke-1550	380-1510
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342

4TC		
Original Part Number	**Part Name**	**Classic Part Number**
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
9G-5525	Shaft-Planet	419-8662
9G-8931	Yoke As	446-3074
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-5096	Flexplate	455-3271
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795
9Y-5168	Manifold-Exhaust	374-7483
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024

Sales Model 926E (Cont'd.)

7TC		
Original Part Number	Part Name	Classic Part Number
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382

7TC		
Original Part Number	Part Name	Classic Part Number
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3G-2797	Bearing-Sleeve	360-2329
3K-3124	Muffler-Trap	247-2673
3T-2094	Bearing-Sleeve	388-0638
4E-3456	Lever As	367-6081
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-3603	Pin As	319-3441
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
4Y-1034	Pin As	396-0641
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5V-7574	Ring-Retaining	392-4483
6C-0570	Pump Gp-Mtrg Bsc	374-5380

7TC		
Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing-Ball	311-9358
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7C-7955	Gasket-Cover	382-6899
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7I-4187	Yoke-1550	380-1510
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7S-7681	Pipe-Exh Ext	385-7213
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721

Sales Model 926E (Cont'd.)

7TC		
Original Part Number	**Part Name**	**Classic Part Number**
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033

7TC		
Original Part Number	**Part Name**	**Classic Part Number**
8S-9151	Cup-Spl Tapered	374-8348
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
9G-5525	Shaft-Planet	419-8662
9G-8931	Yoke As	446-3074
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108

7TC		
Original Part Number	**Part Name**	**Classic Part Number**
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-5096	Flexplate	455-3271
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795
9Y-5168	Manifold-Exhaust	374-7483
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024

8NB		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1428	Retainer-Brg	300-2587

8NB		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1446	Impeller-Conv	377-7413
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

8NB		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-6167	Bearing-Sleeve	299-1960
3K-3124	Muffler-Trap	247-2673
3T-2094	Bearing-Sleeve	388-0638
4E-3456	Lever As	367-6081
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499

Sales Model 926E (Cont'd.)

8NB		
Original Part Number	Part Name	Classic Part Number
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-3603	Pin As	319-3441
4V-3623	Pin As	375-9967
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
4Y-1034	Pin As	396-0641
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5V-7574	Ring-Retaining	392-4483
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6H-3957	Bearing-Ball	311-9358
6I-8849	Cone-Rlr Bearing	415-1919

8NB		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7C-7955	Gasket-Cover	382-6899
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7I-4187	Yoke-1550	380-1510
7J-1309	Bearing-Aligning	360-2275
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7J-9884	Bearing-Sleeve	325-6016
7K-2135	Bearing-Roller	417-4492
7K-9528	Bearing-Sleeve	308-9828
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848

8NB		
Original Part Number	Part Name	Classic Part Number
7N-7166	Race-Brg Thrust	417-4531
7S-7681	Pipe-Exh Ext	385-7213
7S-8576	Bearing As	435-4848
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
9G-5525	Shaft-Planet	419-8662
9G-8931	Yoke As	446-3074
9J-3206	Bearing-Spher	360-2275
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671

Sales Model 926E (Cont'd.)

8NB		
Original Part Number	**Part Name**	**Classic Part Number**
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9W-6044	Shaft-Planet	384-5957

8NB		
Original Part Number	**Part Name**	**Classic Part Number**
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795
9Y-5168	Manifold-Exhaust	374-7483
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
140-2383	Gasket Kit	396-9927

8NB		
Original Part Number	**Part Name**	**Classic Part Number**
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

94Z		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981

94Z		
Original Part Number	**Part Name**	**Classic Part Number**
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3G-2797	Bearing-Sleeve	360-2329
3K-3124	Muffler-Trap	247-2673
3T-2094	Bearing-Sleeve	388-0638
4E-3456	Lever As	367-6081
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217

94Z		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-3603	Pin As	319-3441
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
4Y-1034	Pin As	396-0641
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5V-7574	Ring-Retaining	392-4483
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6H-3957	Bearing-Ball	311-9358
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495

Sales Model 926E (Cont'd.)

94Z		
Original Part Number	**Part Name**	**Classic Part Number**
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7C-7955	Gasket-Cover	382-6899
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7I-4187	Yoke-1550	380-1510
7J-9344	Bearing-Sleeve	360-2334
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983

94Z		
Original Part Number	**Part Name**	**Classic Part Number**
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7S-7681	Pipe-Exh Ext	385-7213
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8T-2470	Gasket Kit	393-5219
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
9G-5525	Shaft-Planet	419-8662
9G-8931	Yoke As	446-3074

94Z		
Original Part Number	**Part Name**	**Classic Part Number**
9J-5875	Bearing-Sleeve	308-9830
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-5096	Flexplate	455-3271
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795
9Y-5168	Manifold-Exhaust	374-7483
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
140-2383	Gasket Kit	396-9927
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 926M

LTE		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437

Sales Model 926M (Cont'd.)

LTE		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
2K-4502	Bearing-Sleeve	299-1986
3P-1210	Cone-Roller Brg	399-4433
4V-5099	Cover	418-1929
6F-2956	Cup-Spl Tapered	420-6538

LTE		
Original Part Number	**Part Name**	**Classic Part Number**
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6V-0347	Cone-Spl Tapered	420-6537
6Y-7929	Disc-Friction	456-0555
7P-3466	Bearing-Sleeve	422-9523

LTE		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1328	Bearing-Aligning	325-6018
9W-9931	Mount As.	360-2354
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
121-7746	Pre-Cleaner As	360-2311
274-4553	Disc-Clutch	416-2153

2XL		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1494	Impeller-Conv	388-6564
1T-1804	Stator As-Conv	388-0572
1T-1805	Turbine-Conv	380-1490
1T-2041	Carrier As	396-9893
2B-0941	Spacer	418-1955
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4K-7463	Seal-Lip Type	472-8007
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019

2XL		
Original Part Number	**Part Name**	**Classic Part Number**
4V-2588	Pin As	435-6050
4V-3603	Pin As	319-3441
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4Y-1034	Pin As	396-0641
5J-7010	Seal As	472-8011
5M-6212	Tube	390-0996
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
6F-2956	Cup-Spl Tapered	420-6538
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6P-0593	Bearing-Roller	386-4959
6V-0347	Cone-Spl Tapered	420-6537
6V-4582	Bearing-Ball	380-1504
6Y-5913	Disc-Friction	391-9836
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7C-3729	Pulley	376-9066

2XL		
Original Part Number	**Part Name**	**Classic Part Number**
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7I-4187	Yoke-1550	380-1510
7J-8210	Cone-Roller Brg	423-6987
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8C-3111	Rod End-Spher	392-4523
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8R-2193	Piston	376-9051
8R-2196	Plate-Reaction	375-2626
8R-2199	Gear-Planet	421-7986
8S-0248	Breather As	325-6033

Sales Model 926M (Cont'd.)

2XL		
Original Part Number	Part Name	Classic Part Number
8V-1612	Shaft	425-6456
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
9C-6318	Bearing-Sleeve	374-6516
9R-6161	Pin	374-6505
9U-3665	Joint Gp-Univ -A	398-8342
9U-3670	Yoke As	432-4221
9V-0247	Plate	417-4527
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-6267	Plate As-Idler	375-9983
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382

2XL		
Original Part Number	Part Name	Classic Part Number
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
125-1037	Pin As	375-9985
126-5875	Flywheel As.	374-4694
128-7228	Pump Gp-Vn Bsc-A	422-8153
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697

2XL		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
228-0416	Seal As	430-5356
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
265-5287	Ring-Seal	472-8028
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
282-6648	Kit-Dt Gasket	396-9955
286-2494	Kit-Gasket-Sch	387-2920
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

Sales Model 928F

2XL		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1494	Impeller-Conv	388-6564
1T-1804	Stator As-Conv	388-0572
1T-1805	Turbine-Conv	380-1490
1T-2041	Carrier As	396-9893
2B-0941	Spacer	418-1955
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481

2XL		
Original Part Number	Part Name	Classic Part Number
3G-2797	Bearing-Sleeve	360-2329
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4K-7463	Seal-Lip Type	472-8007
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019
4V-2588	Pin As	435-6050

2XL		
Original Part Number	Part Name	Classic Part Number
4V-3603	Pin As	319-3441
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4Y-1034	Pin As	396-0641
5J-7010	Seal As	472-8011
5M-6212	Tube	390-0996
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
6F-2956	Cup-Spl Tapered	420-6538
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495

Sales Model 928F (Cont'd.)

2XL		
Original Part Number	**Part Name**	**Classic Part Number**
6K-4189	Spacer	367-6075
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6P-0593	Bearing-Roller	386-4959
6V-0347	Cone-Spl Tapered	420-6537
6V-4582	Bearing-Ball	380-1504
6Y-5913	Disc-Friction	391-9836
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7I-4187	Yoke-1550	380-1510
7J-8210	Cone-Roller Brg	423-6987
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987

2XL		
Original Part Number	**Part Name**	**Classic Part Number**
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8C-3111	Rod End-Spher	392-4523
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8R-2193	Piston	376-9051
8R-2196	Plate-Reaction	375-2626
8R-2199	Gear-Planet	421-7986
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
9C-6318	Bearing-Sleeve	374-6516
9R-6161	Pin	374-6505
9U-3665	Joint Gp-Univ -A	398-8342
9U-3670	Yoke As	432-4221
9V-0247	Plate	417-4527
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-6267	Plate As-Idler	375-9983
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020

2XL		
Original Part Number	**Part Name**	**Classic Part Number**
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
125-1037	Pin As	375-9985
126-5875	Flywheel As.	374-4694
128-7228	Pump Gp-Vn Bsc-A	422-8153
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
228-0416	Seal As	430-5356
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
265-5287	Ring-Seal	472-8028
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
282-6648	Kit-Dt Gasket	396-9955
286-2494	Kit-Gasket-Sch	387-2920
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

7YM		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1S-7057	Gasket	420-6384

7YM		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1494	Impeller-Conv	388-6564

7YM		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1804	Stator As-Conv	388-0572
1T-1805	Turbine-Conv	380-1490
1T-2041	Carrier As	396-9893

Sales Model 928F (Cont'd.)

7YM		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
3G-8917	Pin	325-6141
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4K-7463	Seal-Lip Type	472-8007
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4V-2057	Bearing-Spher	419-6019
4V-2588	Pin As	435-6050
4V-3603	Pin As	319-3441
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4Y-1034	Pin As	396-0641
5J-7010	Seal As	472-8011
5M-6212	Tube	390-0996
5P-7807	Bearing-Ball	314-8502
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
6F-2956	Cup-Spl Tapered	420-6538
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4191	Cap-Upper	300-2576

7YM		
Original Part Number	Part Name	Classic Part Number
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6P-0593	Bearing-Roller	386-4959
6V-0347	Cone-Spl Tapered	420-6537
6V-4582	Bearing-Ball	380-1504
6Y-5913	Disc-Friction	391-9836
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7I-4187	Yoke-1550	380-1510
7J-8210	Cone-Roller Brg	423-6987
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8R-2193	Piston	376-9051
8R-2196	Plate-Reaction	375-2626
8R-2199	Gear-Planet	421-7986
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456

7YM		
Original Part Number	Part Name	Classic Part Number
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
9C-6318	Bearing-Sleeve	374-6516
9U-3665	Joint Gp-Univ -A	398-8342
9U-3670	Yoke As	432-4221
9V-0247	Plate	417-4527
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-6267	Plate As-Idler	375-9983
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
126-5875	Flywheel As.	374-4694
128-7228	Pump Gp-Vn Bsc-A	422-8153
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
228-0416	Seal As	430-5356

Sales Model 928F (Cont'd.)

7YM		
Original Part Number	**Part Name**	**Classic Part Number**
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025

7YM		
Original Part Number	**Part Name**	**Classic Part Number**
265-5287	Ring-Seal	472-8028
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

7YM		
Original Part Number	**Part Name**	**Classic Part Number**
282-6648	Kit-Dt Gasket	396-9955
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

8AK		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1494	Impeller-Conv	388-6564
1T-1804	Stator As-Conv	388-0572
1T-1805	Turbine-Conv	380-1490
1T-2041	Carrier As	396-9893
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4K-7463	Seal-Lip Type	472-8007
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019
4V-2588	Pin As	435-6050
4V-3603	Pin As	319-3441
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

8AK		
Original Part Number	**Part Name**	**Classic Part Number**
4W-2357	Mount As	386-4927
4Y-1034	Pin As	396-0641
5J-7010	Seal As	472-8011
5M-6212	Tube	390-0996
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
6F-2956	Cup-Spl Tapered	420-6538
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6P-0593	Bearing-Roller	386-4959
6V-0347	Cone-Spl Tapered	420-6537
6V-4582	Bearing-Ball	380-1504
6Y-5913	Disc-Friction	391-9836
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025

8AK		
Original Part Number	**Part Name**	**Classic Part Number**
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7I-4187	Yoke-1550	380-1510
7J-8210	Cone-Roller Brg	423-6987
7M-7219	Bearing-Thrust	384-4816
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8C-3111	Rod End-Spher	392-4523
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8R-2193	Piston	376-9051
8R-2196	Plate-Reaction	375-2626
8R-2199	Gear-Planet	421-7986
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8W-9566	Flange As	376-9073
9C-6318	Bearing-Sleeve	374-6516
9R-6161	Pin	374-6505
9U-3665	Joint Gp-Univ -A	398-8342
9U-3670	Yoke As	432-4221
9V-0247	Plate	417-4527
9V-4975	Bearing-Sleeve	384-4784
9W-9931	Mount As.	360-2354

Sales Model 928F (Cont'd.)

8AK		
Original Part Number	Part Name	Classic Part Number
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-6267	Plate As-Idler	375-9983
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219

8AK		
Original Part Number	Part Name	Classic Part Number
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
125-1037	Pin As	375-9985
126-5875	Flywheel As.	374-4694
128-7228	Pump Gp-Vn Bsc-A	422-8153
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372

8AK		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
228-0416	Seal As	430-5356
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
265-5287	Ring-Seal	472-8028
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
282-6648	Kit-Dt Gasket	396-9955
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

Sales Model 928G

6XR		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1494	Impeller-Conv	388-6564
1T-1804	Stator As-Conv	388-0572
1T-1805	Turbine-Conv	380-1490
1V-9148	Bearing-Sleeve	308-9811
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2K-9295	Bearing-Cone	422-6480
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329

6XR		
Original Part Number	Part Name	Classic Part Number
3G-5285	Bearing-Sleeve	360-2312
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019
4V-2883	Bearing-Sleeve	379-0193
4V-8629	Bearing-Sleeve	379-0194
4W-1203	Cup-Rlr Brg	418-9603
5J-7010	Seal As	472-8011
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
6F-2956	Cup-Spl Tapered	420-6538

6XR		
Original Part Number	Part Name	Classic Part Number
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
6V-4582	Bearing-Ball	380-1504
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497

Sales Model 928G (Cont'd.)

6XR		
Original Part Number	**Part Name**	**Classic Part Number**
7J-6250	Bearing-Sleeve	385-3803
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
7J-9884	Bearing-Sleeve	325-6016
7K-9528	Bearing-Sleeve	308-9828
7M-7219	Bearing-Thrust	384-4816
7S-4411	Cap As-Rain	373-1912
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8R-2193	Piston	376-9051
8R-2196	Plate-Reaction	375-2626
8S-0248	Breather As	325-6033
9D-7924	Mount As	360-2356
9J-5875	Bearing-Sleeve	308-9830
9R-6161	Pin	374-6505
9U-3670	Yoke As	432-4221
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671

6XR		
Original Part Number	**Part Name**	**Classic Part Number**
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
087-5978	Flange	374-3496
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
106-7799	Bearing-Ball	396-9947
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
116-8533	Yoke As	451-9031
116-8537	Shaft Gp-Drive-D	418-9570
116-8539	Spider & Brg Kit	399-4399
119-2940	Gasket	378-4002
125-1037	Pin As	375-9985
126-5875	Flywheel As.	374-4694
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388

6XR		
Original Part Number	**Part Name**	**Classic Part Number**
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
176-3900	Accumulator	416-5513
177-4132	Kit-Dt Gasket	394-8227
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
228-0416	Seal As	430-5356
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703
460-5395	Kit-Gasket (Sch)	436-8395

7SR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1494	Impeller-Conv	388-6564
1T-1804	Stator As-Conv	388-0572
1T-1805	Turbine-Conv	380-1490
1V-9148	Bearing-Sleeve	308-9811

7SR		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2K-9295	Bearing-Cone	422-6480
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185

7SR		
Original Part Number	**Part Name**	**Classic Part Number**
3G-5285	Bearing-Sleeve	360-2312
3P-1210	Cone-Roller Brg	399-4433
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-0231	Retainer	376-3641

Sales Model 928G (Cont'd.)

7SR		
Original Part Number	**Part Name**	**Classic Part Number**
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019
4V-2883	Bearing-Sleeve	379-0193
4V-8520	Bearing-Sleeve	307-1527
4V-8629	Bearing-Sleeve	379-0194
4V-8643	Bearing-Sleeve	374-8354
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
6F-2956	Cup-Spl Tapered	420-6538
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
6V-4582	Bearing-Ball	380-1504
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7J-9344	Bearing-Sleeve	360-2334
7M-7219	Bearing-Thrust	384-4816
7P-3466	Bearing-Sleeve	422-9523

7SR		
Original Part Number	**Part Name**	**Classic Part Number**
7S-4411	Cap As-Rain	373-1912
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8R-2193	Piston	376-9051
8R-2196	Plate-Reaction	375-2626
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
9D-7924	Mount As	360-2356
9R-6161	Pin	374-6505
9S-7949	Cup-Roller Brg	420-6531
9U-3670	Yoke As	432-4221
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-7215	Sleeve-Isolator	425-3646
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
087-5978	Flange	374-3496
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
106-7799	Bearing-Ball	396-9947
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
116-8533	Yoke As	451-9031
116-8537	Shaft Gp-Drive-D	418-9570
116-8539	Spider & Brg Kit	399-4399

7SR		
Original Part Number	**Part Name**	**Classic Part Number**
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
125-1037	Pin As	375-9985
126-5875	Flywheel As.	374-4694
132-2463	Joint Gp-Slip	432-6605
134-8950	Plate	399-8587
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
159-3263	Muffler As	430-7623
163-1387	Gear-Flywheel	374-4697
176-3900	Accumulator	416-5513
177-4132	Kit-Dt Gasket	394-8227
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
228-0416	Seal As	430-5356
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703
460-5395	Kit-Gasket (Sch)	436-8395

Sales Model 928G (Cont'd.)

DJD		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1V-9148	Bearing-Sleeve	308-9811
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329
3G-5285	Bearing-Sleeve	360-2312
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4V-2057	Bearing-Spher	419-6019
4V-2883	Bearing-Sleeve	379-0193
4V-8629	Bearing-Sleeve	379-0194
5J-7010	Seal As	472-8011

DJD		
Original Part Number	**Part Name**	**Classic Part Number**
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
7M-7219	Bearing-Thrust	384-4816
8J-5778	Bearing-Sleeve	374-8359
9D-7924	Mount As	360-2356
9J-5875	Bearing-Sleeve	308-9830

DJD		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1328	Bearing-Aligning	325-6018
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
151-5349	Head	383-1592
176-3900	Accumulator	416-5513
199-5067	Muffler As	360-7894
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

WLG		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1V-9148	Bearing-Sleeve	308-9811
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4T-0231	Retainer	376-3641
4V-2057	Bearing-Spher	419-6019

WLG		
Original Part Number	**Part Name**	**Classic Part Number**
4V-2883	Bearing-Sleeve	379-0193
4V-8629	Bearing-Sleeve	379-0194
4V-8643	Bearing-Sleeve	374-8354
5J-7010	Seal As	472-8011
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7M-7219	Bearing-Thrust	384-4816

WLG		
Original Part Number	**Part Name**	**Classic Part Number**
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
9D-7924	Mount As	360-2356
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
151-5349	Head	383-1592
176-3900	Accumulator	416-5513
199-5067	Muffler As	360-7894
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028

Sales Model 928H

BYD		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1V-9148	Bearing-Sleeve	308-9811
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329
3G-5285	Bearing-Sleeve	360-2312
3T-2094	Bearing-Sleeve	388-0638

BYD		
Original Part Number	Part Name	Classic Part Number
4E-4524	Pin As	380-7392
4V-2057	Bearing-Spher	419-6019
4V-2883	Bearing-Sleeve	379-0193
4V-8629	Bearing-Sleeve	379-0194
5J-7010	Seal As	472-8011
5V-1274	Spider	385-6110
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537

BYD		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
9D-7924	Mount As	360-2356
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
151-5349	Head	383-1592
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

CXK		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1V-8242	Bearing-Sleeve	308-9809
1V-9148	Bearing-Sleeve	308-9811
2K-4502	Bearing-Sleeve	299-1986
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329
3G-5285	Bearing-Sleeve	360-2312
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4J-0121	Cap-Bearing	360-2344

CXK		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019
4V-2883	Bearing-Sleeve	379-0193
4V-8629	Bearing-Sleeve	379-0194
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011
5V-1274	Spider	385-6110
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7J-5131	Trunnion	296-1371
7J-9346	Bearing-Sleeve	374-8357
7K-9639	Bearing-Sleeve	314-8643

CXK		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
9D-7924	Mount As	360-2356
9M-1328	Bearing-Aligning	325-6018
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
151-5349	Head	383-1592
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Wheel Loaders

Sales Model 928H (Cont'd.)

RSB		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4V-2057	Bearing-Spher	419-6019
4V-8629	Bearing-Sleeve	379-0194
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011

RSB		
Original Part Number	**Part Name**	**Classic Part Number**
5V-1274	Spider	385-6110
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7J-9682	Bearing-Sleeve	360-2335
9D-7924	Mount As	360-2356
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355

RSB		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
122-6381	Pin As	419-6073
122-6387	Pin As	425-6448
151-5349	Head	383-1592
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

Sales Model 930

41K		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-5480	Cover As.-End	299-1998
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0020	Wheel-Turbine	297-4862

41K		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
1T-0555	Carrier-Gde Whl	384-3853
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1701	Carrier-Stator	384-3853
1T-1987	Housing-Rotating	297-4864
1T-1988	Shaft-Output	428-6656
1T-1991	Stator As-Conv	380-1482
1V-4838	Link As-Spring	308-9874
1W-0777	Muffler As	247-2662
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716

41K		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-7082	Rebuild Kt-Pump	383-3681
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-0535	Nut	299-2026
2K-4502	Bearing-Sleeve	299-1986
2K-4513	Bearing-Sleeve	308-9814

Sales Model 930 (Cont'd.)

41K		
Original Part Number	Part Name	Classic Part Number
2K-5065	Cone-Roller Brg	416-2157
2K-8753	Pinion-Bevel	253-1432
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4404	Housing As-Cl	226-8027
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-6097	Tang	375-9979
2V-1074	Shaft-Planet	364-5262
2V-5608	Shaft-Pin (Bevel)	446-3056
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-7658	Cartridge Gp	426-0427
3H-8726	Mount As	385-7208
3J-9325	Piston	390-0993
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3K-7110	Gear-Planet	253-1435
3L-1425	Bearing-Ball	311-9356

41K		
Original Part Number	Part Name	Classic Part Number
3P-3208	Flange-Joint	301-4647
3P-8393	Plate-Clutch	388-0592
3S-2616	Pump Gp-Trans	226-0165
3S-7987	Shaft-Planet	226-6074
3T-2095	Bearing-Sleeve	384-3459
3V-7427	Housing As	297-7197
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4D-4065	Rod End-Spher	374-1824
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

41K		
Original Part Number	Part Name	Classic Part Number
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-5891	Plate-Clutch	388-0575
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4T-6869	Cartridge Gp	422-8104
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5K-2294	Bearing	396-9912
5K-7995	Bearing-Sleeve	308-9820
5L-2031	Cup-Roller Brg	384-5927
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-7882	Joint Gp-Univ	297-7210
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

Sales Model 930 (Cont'd.)

41K		
Original Part Number	**Part Name**	**Classic Part Number**
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5S-9080	Pulley-Alt Drive	264-5883
5V-7574	Ring-Retaining	392-4483
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-2034	Shaft	297-7249
6K-4180	Pin-Upper	252-6854
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-4442	Rod End-Special	373-5388
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-6046	Pin	241-2602
6K-6047	Pin	241-2603
6K-6053	Pin	241-2604
6K-6054	Pin	241-2605
6K-6175	Pin	241-2606
6K-6185	Pin-Cylinder	252-6859
6K-6349	Pin	252-6860
6K-6350	Bearing-Sleeve	451-6444
6K-7356	Yoke As	330-9296
6K-8275	Cone-Roller Brg	399-6070
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903

41K		
Original Part Number	**Part Name**	**Classic Part Number**
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-0600	Gasket Kit	437-4583
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6V-2237	Gasket Kit	437-3212
6V-2246	Gasket Kit	391-1091
6Y-5348	Disc-Friction	384-4827
6Y-5915	Disc-Friction	384-5936
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7H-4566	Cup-Roller Brg	399-6068
7J-9682	Bearing-Sleeve	360-2335
7J-9842	Bearing-Sleeve	299-1968
7J-9843	Rod As	469-4667
7K-3527	Shaft As-Joint	448-9153
7K-7176	Pin	241-2570
7K-9343	Pin	241-2571
7K-9344	Pin	241-2607
7K-9345	Pin	241-2608
7K-9589	Bearing-Sleeve	453-6509
7K-9601	Bearing-Sleeve	360-2338
7K-9602	Bearing-Sleeve	360-2339
7K-9604	Bearing-Sleeve	308-9829
7K-9794	Link As-Rear	431-5262
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994

41K		
Original Part Number	**Part Name**	**Classic Part Number**
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7043	Mount As	389-6332
7S-7070	Head As-Cylinder	325-6107
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8576	Bearing As	435-4848
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068

Sales Model 930 (Cont'd.)

41K		
Original Part Number	Part Name	Classic Part Number
8A-2305	Repair Kt-Major	386-3042
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-5999	Gear-Sun	253-1440
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349

41K		
Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8R-6830	Joint Gp-Slip	388-0567
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
8W-9566	Flange As	376-9073
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9K-5780	Rim As	388-6597
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042

41K		
Original Part Number	Part Name	Classic Part Number
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-8711	Elbow-Exhaust	383-3709
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0556	Kit-Rebuild-Pump	383-3712
170-0560	Rebuild Kit-Pump	363-7458
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314

Sales Model 930 (Cont'd.)

41K		
Original Part Number	**Part Name**	**Classic Part Number**
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892

41K		
Original Part Number	**Part Name**	**Classic Part Number**
247-2670	Muffler-Classic	247-2675
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351

41K		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

71H		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
1T-0555	Carrier-Gde Whl	384-3853
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1701	Carrier-Stator	384-3853
1T-1987	Housing-Rotating	297-4864
1T-1988	Shaft-Output	428-6656
1T-1991	Stator As-Conv	380-1482
1V-4838	Link As-Spring	308-9874

71H		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-0535	Nut	299-2026
2K-4513	Bearing-Sleeve	308-9814
2K-5065	Cone-Roller Brg	416-2157
2K-8753	Pinion-Bevel	253-1432
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927

71H		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4404	Housing As-Cl	226-8027
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2V-1074	Shaft-Planet	364-5262
2V-5608	Shaft-Pin (Bevel)	446-3056
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3G-7658	Cartridge Gp	426-0427
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673

Sales Model 930 (Cont'd.)

71H		
Original Part Number	Part Name	Classic Part Number
3K-4290	Rod End	374-1823
3K-7110	Gear-Planet	253-1435
3L-1425	Bearing-Ball	311-9356
3P-0114	Elbow-Exhaust	314-8516
3P-3208	Flange-Joint	301-4647
3P-8393	Plate-Clutch	388-0592
3S-2616	Pump Gp-Trans	226-0165
3S-7987	Shaft-Planet	226-6074
3T-2095	Bearing-Sleeve	384-3459
3V-7427	Housing As	297-7197
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8591	Coupling-Exhaust	325-6053
4N-9213	Elbow-Exhaust	330-9270
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988

71H		
Original Part Number	Part Name	Classic Part Number
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-5891	Plate-Clutch	388-0575
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4T-6869	Cartridge Gp	422-8104
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5G-3612	Cap Gp-Protn	295-6419
5K-2294	Bearing	396-9912
5L-2031	Cup-Roller Brg	384-5927
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-7882	Joint Gp-Univ	297-7210
5P-2526	Cup-Rlr Bearing	380-7498
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5V-7574	Ring-Retaining	392-4483
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358

71H		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-2034	Shaft	297-7249
6K-4180	Pin-Upper	252-6854
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-4442	Rod End-Special	373-5388
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-6046	Pin	241-2602
6K-6047	Pin	241-2603
6K-6053	Pin	241-2604
6K-6054	Pin	241-2605
6K-6175	Pin	241-2606
6K-6185	Pin-Cylinder	252-6859
6K-6349	Pin	252-6860
6K-7356	Yoke As	330-9296
6K-8275	Cone-Roller Brg	399-6070
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-2246	Gasket Kit	391-1091
6Y-5348	Disc-Friction	384-4827
6Y-5915	Disc-Friction	384-5936
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-8926	Head Kt-Cyl	377-5847

Sales Model 930 (Cont'd.)

71H		
Original Part Number	Part Name	Classic Part Number
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7H-4566	Cup-Roller Brg	399-6068
7J-9682	Bearing-Sleeve	360-2335
7J-9842	Bearing-Sleeve	299-1968
7J-9843	Rod As	469-4667
7K-3527	Shaft As-Joint	448-9153
7K-7176	Pin	241-2570
7K-9343	Pin	241-2571
7K-9344	Pin	241-2607
7K-9345	Pin	241-2608
7K-9589	Bearing-Sleeve	453-6509
7K-9601	Bearing-Sleeve	360-2338
7K-9602	Bearing-Sleeve	360-2339
7K-9604	Bearing-Sleeve	308-9829
7K-9794	Link As-Rear	431-5262
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496

71H		
Original Part Number	Part Name	Classic Part Number
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7043	Mount As	389-6332
7S-7070	Head As-Cylinder	325-6107
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-5999	Gear-Sun	253-1440
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555

71H		
Original Part Number	Part Name	Classic Part Number
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8R-6830	Joint Gp-Slip	388-0567
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1606	Kit-Gskt-Sch	386-3046
8W-9566	Flange As	376-9073
9B-1320	Valve-Check	377-5832
9K-5780	Rim As	388-6597
9M-5477	Bearing-Sleeve	374-6517

Sales Model 930 (Cont'd.)

71H		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361

71H		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314

71H		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

73U		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-5480	Cover As.-End	299-1998

73U		
Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
1T-0555	Carrier-Gde Whl	384-3853
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1701	Carrier-Stator	384-3853
1T-1987	Housing-Rotating	297-4864

73U		
Original Part Number	Part Name	Classic Part Number
1T-1988	Shaft-Output	428-6656
1T-1991	Stator As-Conv	380-1482
1V-4838	Link As-Spring	308-9874
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-0535	Nut	299-2026

Sales Model 930 (Cont'd.)

73U		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5065	Cone-Roller Brg	416-2157
2K-8753	Pinion-Bevel	253-1432
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4404	Housing As-Cl	226-8027
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-6097	Tang	375-9979
2V-1074	Shaft-Planet	364-5262
2V-5608	Shaft-Pin (Bevel)	446-3056
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7678	Gear-Water Pump	325-6088
3G-7658	Cartridge Gp	426-0427
3H-8726	Mount As	385-7208
3J-6502	Pin	319-3453
3J-9325	Piston	390-0993
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3K-7110	Gear-Planet	253-1435
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
3P-8393	Plate-Clutch	388-0592

73U		
Original Part Number	**Part Name**	**Classic Part Number**
3S-2616	Pump Gp-Trans	226-0165
3S-7987	Shaft-Planet	226-6074
3T-2095	Bearing-Sleeve	384-3459
3V-7427	Housing As	297-7197
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-5891	Plate-Clutch	388-0575
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4T-6869	Cartridge Gp	422-8104
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4W-0452	Seal As -Cshaft	325-6191
5G-3612	Cap Gp-Protn	295-6419
5K-2294	Bearing	396-9912
5L-2031	Cup-Roller Brg	384-5927
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-7882	Joint Gp-Univ	297-7210
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

73U		
Original Part Number	**Part Name**	**Classic Part Number**
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5S-9080	Pulley-Alt Drive	264-5883
5V-7574	Ring-Retaining	392-4483
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-2034	Shaft	297-7249
6K-4180	Pin-Upper	252-6854
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-4442	Rod End-Special	373-5388
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-6046	Pin	241-2602
6K-6047	Pin	241-2603
6K-6053	Pin	241-2604
6K-6054	Pin	241-2605
6K-6175	Pin	241-2606
6K-6185	Pin-Cylinder	252-6859
6K-6349	Pin	252-6860
6K-7356	Yoke As	330-9296
6K-8275	Cone-Roller Brg	399-6070
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574

Sales Model 930 (Cont'd.)

73U		
Original Part Number	Part Name	Classic Part Number
6V-2209	Gasket Kit	419-4732
6V-2246	Gasket Kit	391-1091
6Y-5348	Disc-Friction	384-4827
6Y-5915	Disc-Friction	384-5936
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-5085	Bushing	377-5829
7E-9918	Repair Kit-Major	388-0655
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7H-4566	Cup-Roller Brg	399-6068
7J-9682	Bearing-Sleeve	360-2335
7J-9842	Bearing-Sleeve	299-1968
7J-9843	Rod As	469-4667
7K-3527	Shaft As-Joint	448-9153
7K-7176	Pin	241-2570
7K-9343	Pin	241-2571
7K-9344	Pin	241-2607
7K-9345	Pin	241-2608
7K-9589	Bearing-Sleeve	453-6509
7K-9601	Bearing-Sleeve	360-2338
7K-9602	Bearing-Sleeve	360-2339
7K-9604	Bearing-Sleeve	308-9829
7K-9644	Bearing-Sleeve	360-2341
7K-9794	Link As-Rear	431-5262
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519

73U		
Original Part Number	Part Name	Classic Part Number
7N-7765	Governor As	377-5841
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7043	Mount As	389-6332
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7S-8576	Bearing As	435-4848
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-6058	Bearing-Sleeve	416-5494
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8K-5999	Gear-Sun	253-1440
8M-0874	Plunger As-Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555

73U		
Original Part Number	Part Name	Classic Part Number
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8R-6830	Joint Gp-Slip	388-0567
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9K-5780	Rim As	388-6597
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891

Sales Model 930 (Cont'd.)

73U		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7788	Ring-Piston	461-5124
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
169-1750	Seal Gp-Basic	472-8022

73U		
Original Part Number	**Part Name**	**Classic Part Number**
170-0556	Kit-Rebuild-Pump	383-3712
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259

73U		
Original Part Number	**Part Name**	**Classic Part Number**
196-0029	Gear As-Idler	374-4674
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

79J		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-5480	Cover As.-End	299-1998
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
1T-0576	Bearing-Sleeve	379-0186
1W-0777	Muffler As	247-2662
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006

79J		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-6473	Compressor Gp -B	448-9150
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-5065	Cone-Roller Brg	416-2157
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

79J		
Original Part Number	**Part Name**	**Classic Part Number**
2P-2719	Pipe-Oil Filler	363-7454
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7678	Gear-Water Pump	325-6088
3G-7658	Cartridge Gp	426-0427
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3L-1425	Bearing-Ball	311-9356
3T-2095	Bearing-Sleeve	384-3459
4M-5858	Bearing-Spl Ball	417-4495

Sales Model 930 (Cont'd.)

79J		
Original Part Number	Part Name	Classic Part Number
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4T-6869	Cartridge Gp	422-8104
4W-0452	Seal As -Cshaft	325-6191
5L-2031	Cup-Roller Brg	384-5927
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5P-2526	Cup-Rlr Bearing	380-7498
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358

79J		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8275	Cone-Roller Brg	399-6070
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
6V-2237	Gasket Kit	437-3212
6V-2246	Gasket Kit	391-1091
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9918	Repair Kit-Major	388-0655
7G-2830	Ring-Seal	295-6441
7H-4566	Cup-Roller Brg	399-6068
7J-9682	Bearing-Sleeve	360-2335
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-7765	Governor As	377-5841
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994

79J		
Original Part Number	Part Name	Classic Part Number
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7043	Mount As	389-6332
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7S-8576	Bearing As	435-4848
7W-0508	Gear-Fp Drive	296-1351
7W-5687	Hub-Cshft	314-8684
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860

Sales Model 930 (Cont'd.)

79J		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9B-1320	Valve-Check	377-5832
9K-5780	Rim As	388-6597
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891

79J		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687

79J		
Original Part Number	**Part Name**	**Classic Part Number**
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

8CB		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-5480	Cover As.-End	299-1998

8CB		
Original Part Number	**Part Name**	**Classic Part Number**
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0210	Bearing-Ball	417-4498
1T-0555	Carrier-Gde Whl	384-3853
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1701	Carrier-Stator	384-3853
1T-1987	Housing-Rotating	297-4864
1T-1988	Shaft-Output	428-6656

8CB		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1991	Stator As-Conv	380-1482
1V-4838	Link As-Spring	308-9874
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-0535	Nut	299-2026
2K-5065	Cone-Roller Brg	416-2157
2K-8753	Pinion-Bevel	253-1432
2L-5271	Bearing-Ball	371-4305

Sales Model 930 (Cont'd.)

8CB		
Original Part Number	Part Name	Classic Part Number
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4404	Housing As-Cl	226-8027
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2V-1074	Shaft-Planet	364-5262
2V-5608	Shaft-Pin (Bevel)	446-3056
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7678	Gear-Water Pump	325-6088
3G-7658	Cartridge Gp	426-0427
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3K-7110	Gear-Planet	253-1435
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
3P-8393	Plate-Clutch	388-0592
3S-2616	Pump Gp-Trans	226-0165
3S-7987	Shaft-Planet	226-6074
3T-2095	Bearing-Sleeve	384-3459
3V-7427	Housing As	297-7197
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4M-1641	Dowel-Reaction	386-4952
4M-5858	Bearing-Spl Ball	417-4495

8CB		
Original Part Number	Part Name	Classic Part Number
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-5891	Plate-Clutch	388-0575
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4T-6869	Cartridge Gp	422-8104
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4W-0452	Seal As -Cshaft	325-6191
5K-2294	Bearing	396-9912
5L-2031	Cup-Roller Brg	384-5927
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5M-7882	Joint Gp-Univ	297-7210
5P-2526	Cup-Rlr Bearing	380-7498
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5V-7574	Ring-Retaining	392-4483
6B-3223	Cup-Bearing	399-6065
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495

8CB		
Original Part Number	Part Name	Classic Part Number
6K-2034	Shaft	297-7249
6K-4180	Pin-Upper	252-6854
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-6046	Pin	241-2602
6K-6047	Pin	241-2603
6K-6053	Pin	241-2604
6K-6054	Pin	241-2605
6K-6175	Pin	241-2606
6K-6185	Pin-Cylinder	252-6859
6K-6349	Pin	252-6860
6K-7356	Yoke As	330-9296
6K-8275	Cone-Roller Brg	399-6070
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6Y-5348	Disc-Friction	384-4827
6Y-5915	Disc-Friction	384-5936
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-5085	Bushing	377-5829
7E-9918	Repair Kit-Major	388-0655
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2830	Ring-Seal	295-6441
7H-4566	Cup-Roller Brg	399-6068
7J-9682	Bearing-Sleeve	360-2335
7J-9842	Bearing-Sleeve	299-1968
7J-9843	Rod As	469-4667
7K-3527	Shaft As-Joint	448-9153
7K-7176	Pin	241-2570
7K-9343	Pin	241-2571

Sales Model 930 (Cont'd.)

8CB		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9344	Pin	241-2607
7K-9345	Pin	241-2608
7K-9589	Bearing-Sleeve	453-6509
7K-9601	Bearing-Sleeve	360-2338
7K-9602	Bearing-Sleeve	360-2339
7K-9604	Bearing-Sleeve	308-9829
7K-9794	Link As-Rear	431-5262
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7765	Governor As	377-5841
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7043	Mount As	389-6332
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-6058	Bearing-Sleeve	416-5494
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342

8CB		
Original Part Number	**Part Name**	**Classic Part Number**
8K-5999	Gear-Sun	253-1440
8M-0874	Plunger As-Valve	311-9439
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8R-6830	Joint Gp-Slip	388-0567
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198

8CB		
Original Part Number	**Part Name**	**Classic Part Number**
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
9H-5797	Plunger As-Pump	391-9891
9K-5780	Rim As	388-6597
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-2356	Manifold-Exhaust	261-0905
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7766	Pump Gp-Water -B	374-4698
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024

Sales Model 930 (Cont'd.)

8CB		
Original Part Number	Part Name	Classic Part Number
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
270-4353	Kit-Liner-Cla	295-6438

8CB		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

8CB		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

Sales Model 930G

TFW		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1V-8242	Bearing-Sleeve	308-9809
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3T-2094	Bearing-Sleeve	388-0638
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011

TFW		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7M-7219	Bearing-Thrust	384-4816
9D-7924	Mount As	360-2356
9M-1328	Bearing-Aligning	325-6018

TFW		
Original Part Number	Part Name	Classic Part Number
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
176-3900	Accumulator	416-5513
199-5067	Muffler As	360-7894
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658

TWR		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1V-8242	Bearing-Sleeve	308-9809
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3T-2094	Bearing-Sleeve	388-0638
4T-8054	Seal As	472-8010
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529

TWR		
Original Part Number	Part Name	Classic Part Number
5J-7010	Seal As	472-8011
5V-1274	Spider	385-6110
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7J-6250	Bearing-Sleeve	385-3803
7J-9344	Bearing-Sleeve	360-2334

TWR		
Original Part Number	Part Name	Classic Part Number
7J-9346	Bearing-Sleeve	374-8357
7J-9884	Bearing-Sleeve	325-6016
7K-9528	Bearing-Sleeve	308-9828
7M-7219	Bearing-Thrust	384-4816
8J-5778	Bearing-Sleeve	374-8359
9D-7924	Mount As	360-2356
9M-1328	Bearing-Aligning	325-6018
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610

Wheel Loaders

Sales Model 930G (Cont'd.)

TWR		
Original Part Number	Part Name	Classic Part Number
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311

TWR		
Original Part Number	Part Name	Classic Part Number
176-3900	Accumulator	416-5513
199-5067	Muffler As	360-7894
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025

TWR		
Original Part Number	Part Name	Classic Part Number
235-9832	Head	419-4658
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 930H

DHC		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
1V-8242	Bearing-Sleeve	308-9809
2A-4429	Lock-Retainer	379-0174
2K-4502	Bearing-Sleeve	299-1986
2K-9295	Bearing-Cone	422-6480
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-4704	Bearing-Sleeve	379-0185
3T-2094	Bearing-Sleeve	388-0638
4J-0121	Cap-Bearing	360-2344
4T-8054	Seal As	472-8010
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5B-9169	Plug-Drain	419-4736
5J-7010	Seal As	472-8011
5V-1274	Spider	385-6110
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919

DHC		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6L-2279	Plug-Ptf	419-4739
6V-0347	Cone-Spl Tapered	420-6537
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
7J-9884	Bearing-Sleeve	325-6016
7K-0078	Bearing-Sleeve	308-9825
7K-9528	Bearing-Sleeve	308-9828
7M-7219	Bearing-Thrust	384-4816
7W-3145	Plate	422-7894
8H-4320	Bearing-Ball	419-2301
8J-5778	Bearing-Sleeve	374-8359
9D-7924	Mount As	360-2356
9J-5875	Bearing-Sleeve	308-9830
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638

DHC		
Original Part Number	Part Name	Classic Part Number
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
101-1530	Bearing-Main	419-6382
106-7799	Bearing-Ball	396-9947
107-7708	Bearing-Main	419-6381
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
121-7746	Pre-Cleaner As	360-2311
133-4995	Gasket-Cyl Head	434-2445
135-2151	Tensioner	419-4735
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
217-8938	Tightening-Belt	419-4735
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
235-9832	Head	419-4658
255-6863	Gasket	450-5024
271-5658	Crankshaft As.	368-5912
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 930H (Cont'd.)

FTD		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1V-8242	Bearing-Sleeve	308-9809
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3G-4704	Bearing-Sleeve	379-0185
3T-2094	Bearing-Sleeve	388-0638

FTD		
Original Part Number	Part Name	Classic Part Number
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011
5V-1274	Spider	385-6110
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
7M-7219	Bearing-Thrust	384-4816

FTD		
Original Part Number	Part Name	Classic Part Number
9D-7924	Mount As	360-2356
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
121-7746	Pre-Cleaner As	360-2311
226-8202	Seal-Wiper	472-8024
235-9832	Head	419-4658

Sales Model 930K

DYB		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
2K-4502	Bearing-Sleeve	299-1986
2K-9295	Bearing-Cone	422-6480
3G-2797	Bearing-Sleeve	360-2329
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010

DYB		
Original Part Number	Part Name	Classic Part Number
4V-5099	Cover	418-1929
4V-8643	Bearing-Sleeve	374-8354
4V-8675	Bearing-Sleeve	394-0187
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6V-0347	Cone-Spl Tapered	420-6537
6Y-7929	Disc-Friction	456-0555
7K-9528	Bearing-Sleeve	308-9828

DYB		
Original Part Number	Part Name	Classic Part Number
7P-3466	Bearing-Sleeve	422-9523
9M-1328	Bearing-Aligning	325-6018
9W-9931	Mount As.	360-2354
121-7746	Pre-Cleaner As	360-2311
135-7393	Head	382-6895
274-4553	Disc-Clutch	416-2153
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

EYE		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296

EYE		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
2K-4502	Bearing-Sleeve	299-1986

EYE		
Original Part Number	Part Name	Classic Part Number
2K-9295	Bearing-Cone	422-6480
3P-1210	Cone-Roller Brg	399-4433
4V-2872	Bearing-Sleeve	380-7558

Sales Model 930K (Cont'd.)

EYE		
Original Part Number	**Part Name**	**Classic Part Number**
4V-5099	Cover	418-1929
5T-5682	Driver	418-9579
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576

EYE		
Original Part Number	**Part Name**	**Classic Part Number**
6V-0347	Cone-Spl Tapered	420-6537
6Y-7929	Disc-Friction	456-0555
7J-9346	Bearing-Sleeve	374-8357
7P-3466	Bearing-Sleeve	422-9523
9M-1328	Bearing-Aligning	325-6018

EYE		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9931	Mount As.	360-2354
121-7746	Pre-Cleaner As	360-2311
274-4553	Disc-Clutch	416-2153
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

FRK		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
2K-9295	Bearing-Cone	422-6480
3P-1210	Cone-Roller Brg	399-4433

FRK		
Original Part Number	**Part Name**	**Classic Part Number**
4V-5099	Cover	418-1929
5T-5682	Driver	418-9579
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6V-0347	Cone-Spl Tapered	420-6537

FRK		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7929	Disc-Friction	456-0555
7P-3466	Bearing-Sleeve	422-9523
9M-1328	Bearing-Aligning	325-6018
9W-9931	Mount As.	360-2354
121-7746	Pre-Cleaner As	360-2311
274-4553	Disc-Clutch	416-2153

P3K		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
2K-9295	Bearing-Cone	422-6480
3G-2797	Bearing-Sleeve	360-2329
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010

P3K		
Original Part Number	**Part Name**	**Classic Part Number**
4V-5099	Cover	418-1929
4V-8643	Bearing-Sleeve	374-8354
4V-8675	Bearing-Sleeve	394-0187
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6V-0347	Cone-Spl Tapered	420-6537

P3K		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7929	Disc-Friction	456-0555
7P-3466	Bearing-Sleeve	422-9523
9M-1328	Bearing-Aligning	325-6018
9W-9931	Mount As.	360-2354
121-7746	Pre-Cleaner As	360-2311
135-7393	Head	382-6895
274-4553	Disc-Clutch	416-2153
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

RHN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443

RHN		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1P-3934	Cup-Roller Brg	420-6535

RHN		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3935	Cone-Roller Brg	377-7397
2K-4502	Bearing-Sleeve	299-1986

Sales Model 930K (Cont'd.)

RHN		
Original Part Number	Part Name	Classic Part Number
2K-9295	Bearing-Cone	422-6480
3G-4704	Bearing-Sleeve	379-0185
3P-1210	Cone-Roller Brg	399-4433
4V-2872	Bearing-Sleeve	380-7558
4V-5099	Cover	418-1929
5T-5682	Driver	418-9579
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6V-0347	Cone-Spl Tapered	420-6537
6Y-7929	Disc-Friction	456-0555
7J-9344	Bearing-Sleeve	360-2334
7K-9528	Bearing-Sleeve	308-9828
7P-3466	Bearing-Sleeve	422-9523
8J-5778	Bearing-Sleeve	374-8359

RHN		
Original Part Number	Part Name	Classic Part Number
9J-5875	Bearing-Sleeve	308-9830
9M-1328	Bearing-Aligning	325-6018
9W-9931	Mount As.	360-2354
121-7746	Pre-Cleaner As	360-2311
274-4553	Disc-Clutch	416-2153
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
2K-9295	Bearing-Cone	422-6480
3P-1210	Cone-Roller Brg	399-4433
4V-2872	Bearing-Sleeve	380-7558
4V-5099	Cover	418-1929
4V-8629	Bearing-Sleeve	379-0194

RHN		
Original Part Number	Part Name	Classic Part Number
4V-8674	Bearing-Sleeve	307-1529
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6V-0347	Cone-Spl Tapered	420-6537
6Y-7929	Disc-Friction	456-0555
7J-9682	Bearing-Sleeve	360-2335
7P-3466	Bearing-Sleeve	422-9523
9M-1328	Bearing-Aligning	325-6018
9W-9931	Mount As.	360-2354
121-7746	Pre-Cleaner As	360-2311
122-6381	Pin As	419-6073
122-6387	Pin As	425-6448
274-4553	Disc-Clutch	416-2153

Sales Model 930M

KTG		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
2K-4502	Bearing-Sleeve	299-1986
2K-9295	Bearing-Cone	422-6480
3P-1210	Cone-Roller Brg	399-4433

KTG		
Original Part Number	Part Name	Classic Part Number
4V-2872	Bearing-Sleeve	380-7558
4V-5099	Cover	418-1929
5T-5682	Driver	418-9579
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6V-0347	Cone-Spl Tapered	420-6537

KTG		
Original Part Number	Part Name	Classic Part Number
6Y-7929	Disc-Friction	456-0555
7P-3466	Bearing-Sleeve	422-9523
9M-1328	Bearing-Aligning	325-6018
9W-9931	Mount As.	360-2354
121-7746	Pre-Cleaner As	360-2311
274-4553	Disc-Clutch	416-2153

17B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1428	Retainer-Brg	300-2587
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1U-2665	Cartridge Gp	422-8108
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

17B		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-5065	Cone-Roller Brg	416-2157
2K-8753	Pinion-Bevel	253-1432
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4611	Pipe-Exhaust	365-8821
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-0479	Bearing-Cone	380-7506
2S-6097	Tang	375-9979
2V-1074	Shaft-Planet	364-5262
2V-5608	Shaft-Pin (Bevel)	446-3056
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3H-8726	Mount As	385-7208

17B		
Original Part Number	**Part Name**	**Classic Part Number**
3K-3124	Muffler-Trap	247-2673
3K-7110	Gear-Planet	253-1435
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3V-7427	Housing As	297-7197
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778

Sales Model 930R (Cont'd.)

17B		
Original Part Number	**Part Name**	**Classic Part Number**
4S-8538	Bearing-Spl Ball	417-4502
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5G-3612	Cap Gp-Protn	295-6419
5K-2294	Bearing	396-9912
5L-2031	Cup-Roller Brg	384-5927
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5P-2526	Cup-Rlr Bearing	380-7498
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5V-7574	Ring-Retaining	392-4483
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-2034	Shaft	297-7249
6K-4180	Pin-Upper	252-6854
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566

17B		
Original Part Number	**Part Name**	**Classic Part Number**
6K-4442	Rod End-Special	373-5388
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-6046	Pin	241-2602
6K-6047	Pin	241-2603
6K-6053	Pin	241-2604
6K-6054	Pin	241-2605
6K-6175	Pin	241-2606
6K-6185	Pin-Cylinder	252-6859
6K-6349	Pin	252-6860
6K-7356	Yoke As	330-9296
6K-8275	Cone-Roller Brg	399-6070
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-2202	Bearing-Spl Ball	380-1574
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-9682	Bearing-Sleeve	360-2335
7J-9842	Bearing-Sleeve	299-1968

17B		
Original Part Number	**Part Name**	**Classic Part Number**
7J-9843	Rod As	469-4667
7K-3527	Shaft As-Joint	448-9153
7K-7176	Pin	241-2570
7K-9343	Pin	241-2571
7K-9344	Pin	241-2607
7K-9345	Pin	241-2608
7K-9589	Bearing-Sleeve	453-6509
7K-9601	Bearing-Sleeve	360-2338
7K-9602	Bearing-Sleeve	360-2339
7K-9604	Bearing-Sleeve	308-9829
7K-9794	Link As-Rear	431-5262
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7043	Mount As	389-6332
7S-7070	Head As-Cylinder	325-6107

Sales Model 930R (Cont'd.)

17B		
Original Part Number	**Part Name**	**Classic Part Number**
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-5999	Gear-Sun	253-1440
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623

17B		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8R-6830	Joint Gp-Slip	388-0567
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8T-1606	Kit-Gskt-Sch	386-3046
8T-9486	Gasket Kt	393-5197
8W-9566	Flange As	376-9073
9B-1320	Valve-Check	377-5832
9G-5525	Shaft-Planet	419-8662
9K-5780	Rim As	388-6597
9L-2685	Rod End	419-1866
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505

17B		
Original Part Number	**Part Name**	**Classic Part Number**
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2356	Manifold-Exhaust	261-0905
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9T-5096	Flexplate	455-3271
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
140-2383	Gasket Kit	396-9927
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

Sales Model 930R (Cont'd.)

17B		
Original Part Number	**Part Name**	**Classic Part Number**
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
174-0739	Gasket Kit - F	437-2012

17B		
Original Part Number	**Part Name**	**Classic Part Number**
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
250-6555	Kit-Liner-Cla	250-6563
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	295-6438

17B		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

57Z		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1428	Retainer-Brg	300-2587
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1U-2665	Cartridge Gp	422-8108

57Z		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-5065	Cone-Roller Brg	416-2157
2K-8753	Pinion-Bevel	253-1432
2L-5271	Bearing-Ball	371-4305

57Z		
Original Part Number	**Part Name**	**Classic Part Number**
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4611	Pipe-Exhaust	365-8821
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-0479	Bearing-Cone	380-7506
2V-1074	Shaft-Planet	364-5262
2V-5608	Shaft-Pin (Bevel)	446-3056
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088

Sales Model 930R (Cont'd.)

57Z		
Original Part Number	**Part Name**	**Classic Part Number**
2W-9978	Core As-Oclr	279-4983
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3K-7110	Gear-Planet	253-1435
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3V-7427	Housing As	297-7197
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8538	Bearing-Spl Ball	417-4502
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050

57Z		
Original Part Number	**Part Name**	**Classic Part Number**
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5K-2294	Bearing	396-9912
5L-2031	Cup-Roller Brg	384-5927
5M-2054	Bearing	380-7510
5M-7882	Joint Gp-Univ	297-7210
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5V-7574	Ring-Retaining	392-4483
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-2034	Shaft	297-7249
6K-4180	Pin-Upper	252-6854
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-4442	Rod End-Special	373-5388
6K-5744	Cage-Bearing	330-9266

57Z		
Original Part Number	**Part Name**	**Classic Part Number**
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-6046	Pin	241-2602
6K-6047	Pin	241-2603
6K-6053	Pin	241-2604
6K-6054	Pin	241-2605
6K-6175	Pin	241-2606
6K-6185	Pin-Cylinder	252-6859
6K-6349	Pin	252-6860
6K-7356	Yoke As	330-9296
6K-8275	Cone-Roller Brg	399-6070
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-4582	Bearing-Ball	380-1504
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-9682	Bearing-Sleeve	360-2335
7J-9842	Bearing-Sleeve	299-1968
7J-9843	Rod As	469-4667
7K-3527	Shaft As-Joint	448-9153
7K-7176	Pin	241-2570
7K-9343	Pin	241-2571
7K-9344	Pin	241-2607

Sales Model 930R (Cont'd.)

57Z		
Original Part Number	Part Name	Classic Part Number
7K-9345	Pin	241-2608
7K-9589	Bearing-Sleeve	453-6509
7K-9601	Bearing-Sleeve	360-2338
7K-9602	Bearing-Sleeve	360-2339
7K-9604	Bearing-Sleeve	308-9829
7K-9794	Link As-Rear	431-5262
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7043	Mount As	389-6332
7S-7070	Head As-Cylinder	325-6107
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613

57Z		
Original Part Number	Part Name	Classic Part Number
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-5999	Gear-Sun	253-1440
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860

57Z		
Original Part Number	Part Name	Classic Part Number
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8R-6830	Joint Gp-Slip	388-0567
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8T-1606	Kit-Gskt-Sch	386-3046
8W-9566	Flange As	376-9073
9G-5525	Shaft-Planet	419-8662
9K-5780	Rim As	388-6597
9L-2685	Rod End	419-1866
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-2356	Manifold-Exhaust	261-0905
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-5096	Flexplate	455-3271
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-1798	Seal-Water	379-0165

Sales Model 930R (Cont'd.)

57Z		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
140-2383	Gasket Kit	396-9927
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

57Z		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

57Z		
Original Part Number	**Part Name**	**Classic Part Number**
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 930T

17B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-3062	Director-Water	418-9572

17B		
Original Part Number	**Part Name**	**Classic Part Number**
1S-9670	Univ Jt As	443-2017
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1428	Retainer-Brg	300-2587
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1U-2665	Cartridge Gp	422-8108
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715

17B		
Original Part Number	**Part Name**	**Classic Part Number**
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488

Sales Model 930T (Cont'd.)

17B		
Original Part Number	**Part Name**	**Classic Part Number**
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-5065	Cone-Roller Brg	416-2157
2K-8753	Pinion-Bevel	253-1432
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4611	Pipe-Exhaust	365-8821
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-0479	Bearing-Cone	380-7506
2S-6097	Tang	375-9979
2V-1074	Shaft-Planet	364-5262
2V-5608	Shaft-Pin (Bevel)	446-3056
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3K-7110	Gear-Planet	253-1435
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3V-7427	Housing As	297-7197

17B		
Original Part Number	**Part Name**	**Classic Part Number**
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8538	Bearing-Spl Ball	417-4502
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534

17B		
Original Part Number	**Part Name**	**Classic Part Number**
4W-9655	Support	419-0882
5G-3612	Cap Gp-Protn	295-6419
5K-2294	Bearing	396-9912
5L-2031	Cup-Roller Brg	384-5927
5L-6326	Bearing-Ball	420-3222
5M-2054	Bearing	380-7510
5P-2526	Cup-Rlr Bearing	380-7498
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5V-7574	Ring-Retaining	392-4483
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-2034	Shaft	297-7249
6K-4180	Pin-Upper	252-6854
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-4442	Rod End-Special	373-5388
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-6046	Pin	241-2602
6K-6047	Pin	241-2603

Sales Model 930T (Cont'd.)

17B		
Original Part Number	**Part Name**	**Classic Part Number**
6K-6053	Pin	241-2604
6K-6054	Pin	241-2605
6K-6175	Pin	241-2606
6K-6185	Pin-Cylinder	252-6859
6K-6349	Pin	252-6860
6K-7356	Yoke As	330-9296
6K-8275	Cone-Roller Brg	399-6070
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-2202	Bearing-Spl Ball	380-1574
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-9682	Bearing-Sleeve	360-2335
7J-9842	Bearing-Sleeve	299-1968
7J-9843	Rod As	469-4667
7K-3527	Shaft As-Joint	448-9153
7K-7176	Pin	241-2570
7K-9343	Pin	241-2571
7K-9344	Pin	241-2607
7K-9345	Pin	241-2608
7K-9589	Bearing-Sleeve	453-6509

17B		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9601	Bearing-Sleeve	360-2338
7K-9602	Bearing-Sleeve	360-2339
7K-9604	Bearing-Sleeve	308-9829
7K-9794	Link As-Rear	431-5262
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7043	Mount As	389-6332
7S-7070	Head As-Cylinder	325-6107
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583

17B		
Original Part Number	**Part Name**	**Classic Part Number**
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-5999	Gear-Sun	253-1440
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290

Sales Model 930T (Cont'd.)

17B		
Original Part Number	**Part Name**	**Classic Part Number**
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8R-6830	Joint Gp-Slip	388-0567
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8T-1606	Kit-Gskt-Sch	386-3046
8T-9486	Gasket Kt	393-5197
8W-9566	Flange As	376-9073
9B-1320	Valve-Check	377-5832
9G-5525	Shaft-Planet	419-8662
9K-5780	Rim As	388-6597
9L-2685	Rod End	419-1866
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122

17B		
Original Part Number	**Part Name**	**Classic Part Number**
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2356	Manifold-Exhaust	261-0905
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9T-5096	Flexplate	455-3271
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
140-2383	Gasket Kit	396-9927
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127

17B		
Original Part Number	**Part Name**	**Classic Part Number**
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
174-0739	Gasket Kit - F	437-2012
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
250-6555	Kit-Liner-Cla	250-6563
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

57Z		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437

Sales Model 930T (Cont'd.)

57Z		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-9670	Univ Jt As	443-2017
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1428	Retainer-Brg	300-2587
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1U-2665	Cartridge Gp	422-8108
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

57Z		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-5065	Cone-Roller Brg	416-2157
2K-8753	Pinion-Bevel	253-1432
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-4611	Pipe-Exhaust	365-8821
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-0479	Bearing-Cone	380-7506
2V-1074	Shaft-Planet	364-5262
2V-5608	Shaft-Pin (Bevel)	446-3056
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3H-8726	Mount As	385-7208
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823

57Z		
Original Part Number	**Part Name**	**Classic Part Number**
3K-7110	Gear-Planet	253-1435
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3V-7427	Housing As	297-7197
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8538	Bearing-Spl Ball	417-4502
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534

Sales Model 930T (Cont'd.)

57Z		
Original Part Number	Part Name	Classic Part Number
4W-9655	Support	419-0882
5K-2294	Bearing	396-9912
5L-2031	Cup-Roller Brg	384-5927
5M-2054	Bearing	380-7510
5M-7882	Joint Gp-Univ	297-7210
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5V-7574	Ring-Retaining	392-4483
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-2034	Shaft	297-7249
6K-4180	Pin-Upper	252-6854
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-4442	Rod End-Special	373-5388
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-6046	Pin	241-2602

57Z		
Original Part Number	Part Name	Classic Part Number
6K-6047	Pin	241-2603
6K-6053	Pin	241-2604
6K-6054	Pin	241-2605
6K-6175	Pin	241-2606
6K-6185	Pin-Cylinder	252-6859
6K-6349	Pin	252-6860
6K-7356	Yoke As	330-9296
6K-8275	Cone-Roller Brg	399-6070
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-7174	Shield-Oil	314-8544
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-4582	Bearing-Ball	380-1504
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-9682	Bearing-Sleeve	360-2335
7J-9842	Bearing-Sleeve	299-1968
7J-9843	Rod As	469-4667
7K-3527	Shaft As-Joint	448-9153
7K-7176	Pin	241-2570
7K-9343	Pin	241-2571
7K-9344	Pin	241-2607
7K-9345	Pin	241-2608
7K-9589	Bearing-Sleeve	453-6509
7K-9601	Bearing-Sleeve	360-2338

57Z		
Original Part Number	Part Name	Classic Part Number
7K-9602	Bearing-Sleeve	360-2339
7K-9604	Bearing-Sleeve	308-9829
7K-9794	Link As-Rear	431-5262
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7043	Mount As	389-6332
7S-7070	Head As-Cylinder	325-6107
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187

Sales Model 930T (Cont'd.)

57Z		
Original Part Number	**Part Name**	**Classic Part Number**
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-5999	Gear-Sun	253-1440
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

57Z		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8R-6830	Joint Gp-Slip	388-0567
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8T-1606	Kit-Gskt-Sch	386-3046
8W-9566	Flange As	376-9073
9G-5525	Shaft-Planet	419-8662
9K-5780	Rim As	388-6597
9L-2685	Rod End	419-1866
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-2356	Manifold-Exhaust	261-0905
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-5096	Flexplate	455-3271
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360

57Z		
Original Part Number	**Part Name**	**Classic Part Number**
111-8015	Gasket As-Head	279-4977
112-3249	Muffler As	247-2661
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
140-2383	Gasket Kit	396-9927
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	295-6438

Sales Model 930T (Cont'd.)

57Z		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028

57Z		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032

57Z		
Original Part Number	Part Name	Classic Part Number
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 936

1HJ		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1647	Impeller-Conv	377-7415
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2L-5271	Bearing-Ball	371-4305
2P-8912	Elbow-Exhaust	398-2957
2P-8986	Cup-Rlr Bearing	415-1912
2V-7990	Tube As	373-5382
2W-5536	Core As-Radiator	380-7554
3G-2752	Cartridge Gp-Rr	422-8127

1HJ		
Original Part Number	Part Name	Classic Part Number
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4M-3915	Bearing-Caged	377-7427
4T-0998	Lever	314-8687
4V-0092	Hub As	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-3680	Bellcrank	308-9802
4V-3842	Support-Trunnion	396-9935
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-6527	Disc	376-9050
4V-7543	Retainer	281-1699
4V-7545	Gear-Ring	394-9823
4W-7188	Core As-Oclr	374-7501
5L-2031	Cup-Roller Brg	384-5927
5P-2526	Cup-Rlr Bearing	380-7498

1HJ		
Original Part Number	Part Name	Classic Part Number
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
5V-7574	Ring-Retaining	392-4483
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6L-7751	Rod End-Spher	472-8015
6N-1553	Coupling-Exhaust	295-6422
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-2202	Bearing-Spl Ball	380-1574
6W-2899	Shaft-Pinion	446-3057
6Y-3484	Bearing-Spl Ball	416-2166

Sales Model 936 (Cont'd.)

1HJ		
Original Part Number	**Part Name**	**Classic Part Number**
7B-7515	Bearing-Ball	399-6059
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7I-4187	Yoke-1550	380-1510
7K-0686	Trunnion-Rear	297-7266
7K-2135	Bearing-Roller	417-4492
7N-1164	Mount As	295-5451
7N-5206	Mount As	374-1451
7S-4534	Bearing-Caged	417-9497

1HJ		
Original Part Number	**Part Name**	**Classic Part Number**
7T-2036	Cap As-Fuel	361-1721
7V-5645	Rod-Indicator	397-5061
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8P-3563	Cage-Bearing	451-0747
8T-0072	Cone-Rlr Brg	377-7448
8V-1537	Gear-Sun	446-3061
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-8117	Housing As-Cl	302-2686
9L-2685	Rod End	419-1866
9N-4460	Housing As-Cl	297-7203
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

1HJ		
Original Part Number	**Part Name**	**Classic Part Number**
9T-2200	Cartridgr Gp	422-8114
9V-8693	Actuator Gp-Bk	375-2629
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
138-2317	Wheel	396-9948
155-6648	Cone Spl Rol Brg	418-9599
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
275-0120	Pin As	419-7245

2ZB		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-5480	Cover As.-End	299-1998
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587

2ZB		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1647	Impeller-Conv	377-7415
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173

2ZB		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357

Sales Model 936 (Cont'd.)

2ZB		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2752	Cartridge Gp-Rr	422-8127
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4K-7463	Seal-Lip Type	472-8007
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8344	Spider As-Fan	416-5520
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008

2ZB		
Original Part Number	Part Name	Classic Part Number
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-0998	Lever	314-8687
4V-0092	Hub As	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3842	Support-Trunnion	396-9935
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-6527	Disc	376-9050
4V-7543	Retainer	281-1699
4V-7545	Gear-Ring	394-9823
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
5L-2031	Cup-Roller Brg	384-5927
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022

2ZB		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
5V-7574	Ring-Retaining	392-4483
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2932	Pump Gp-Vn Bsc-B	422-8155
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-2202	Bearing-Spl Ball	380-1574
6W-2899	Shaft-Pinion	446-3057
6Y-3484	Bearing-Spl Ball	416-2166

Sales Model 936 (Cont'd.)

2ZB		
Original Part Number	Part Name	Classic Part Number
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7I-4187	Yoke-1550	380-1510
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613

2ZB		
Original Part Number	Part Name	Classic Part Number
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

2ZB		
Original Part Number	Part Name	Classic Part Number
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-1537	Gear-Sun	446-3061
8V-1612	Shaft	425-6456
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-8117	Housing As-Cl	302-2686
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9V-8693	Actuator Gp-Bk	375-2629
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
138-2317	Wheel	396-9948
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599

Sales Model 936 (Cont'd.)

2ZB		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

2ZB		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370

2ZB		
Original Part Number	Part Name	Classic Part Number
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

33Z		
Original Part Number	Part Name	Classic Part Number
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-5338	Cup-Roller Brg	374-8345
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-4693	Cup-Rlr Bearing	377-7398
1P-5480	Cover As.-End	299-1998

33Z		
Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-0576	Bearing-Sleeve	379-0186
1T-1401	Ring-Seal	384-4799
1T-1428	Retainer-Brg	300-2587
1T-1446	Impeller-Conv	377-7413
1T-1647	Impeller-Conv	377-7415
1T-1691	Impeller-Conv	297-4863
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079

33Z		
Original Part Number	Part Name	Classic Part Number
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1766	Muffler As.	298-2783
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-5920	Bearing-Camshaft	421-1558
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913

Sales Model 936 (Cont'd.)

33Z		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4611	Pipe-Exhaust	365-8821
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2P-8986	Cup-Rlr Bearing	415-1912
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203

33Z		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8271	Arm As-Rocker	432-8912
3G-2752	Cartridge Gp-Rr	422-8127
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3G-9891	Pump Gp-Gr A	399-8541
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4E-3456	Lever As	367-6081
4E-7608	Bearing-Sleeve	388-0639
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8204	Mount As	374-1449
4N-8344	Spider As-Fan	416-5520
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988

33Z		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4Q-1346	Link As-Bearing&	425-3649
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0092	Hub As	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-3680	Bellcrank	308-9802
4V-3842	Support-Trunnion	396-9935
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-6527	Disc	376-9050
4V-7543	Retainer	281-1699
4V-7545	Gear-Ring	394-9823
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534

Sales Model 936 (Cont'd.)

33Z		
Original Part Number	Part Name	Classic Part Number
4W-7188	Core As-Oclr	374-7501
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
4W-9655	Support	419-0882
4Y-1034	Pin As	396-0641
5L-2031	Cup-Roller Brg	384-5927
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
5V-7574	Ring-Retaining	392-4483
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2932	Pump Gp-Vn Bsc-B	422-8155
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855

33Z		
Original Part Number	Part Name	Classic Part Number
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-6721	Coupling	377-5830
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-2202	Bearing-Spl Ball	380-1574
6V-5413	Gasket Kit	390-5291
6V-5414	Gasket Kit	434-7289
6V-5976	Kit-Gasket (Rs)	393-5200
6V-6896	Rebuild Kit	390-1006
6V-7459	Gasket Kit	391-1095
6W-2899	Shaft-Pinion	446-3057
6Y-3484	Bearing-Spl Ball	416-2166
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-7955	Gasket-Cover	382-6899

33Z		
Original Part Number	Part Name	Classic Part Number
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7H-4566	Cup-Roller Brg	399-6068
7I-4187	Yoke-1550	380-1510
7J-9682	Bearing-Sleeve	360-2335
7K-0084	Bearing-Sleeve	453-6508
7K-0686	Trunnion-Rear	297-7266
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0691	Elbow-Water Rglt	378-3983
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996

Sales Model 936 (Cont'd.)

33Z		
Original Part Number	**Part Name**	**Classic Part Number**
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-7681	Pipe-Exh Ext	385-7213
7S-8443	Muffler	247-2675
7S-8576	Bearing As	435-4848
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-0638	Spacer	425-3651
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8E-4589	Carrier As	416-2122
8E-4954	Housing As-Cl	391-9823
8E-5284	Bearing	388-0582
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

33Z		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3753	Rod As-Conn	379-8867
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6308	Bearing-Conn Rod	419-7267
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3563	Cage-Bearing	451-0747
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
8T-1606	Kit-Gskt-Sch	386-3046
8T-9486	Gasket Kt	393-5197
8V-1537	Gear-Sun	446-3061
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972

33Z		
Original Part Number	**Part Name**	**Classic Part Number**
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-5525	Shaft-Planet	419-8662
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9G-8931	Yoke As	446-3074
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9N-4460	Housing As-Cl	297-7203
9N-5246	Bearing-Camshaft	384-4772
9N-5769	Cover-Housing	325-6050
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9V-3363	Pin As	396-0663
9V-3405	Bearing-Sleeve	425-6453
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784
9V-8693	Actuator Gp-Bk	375-2629
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165

Sales Model 936 (Cont'd.)

33Z		
Original Part Number	Part Name	Classic Part Number
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-5168	Manifold-Exhaust	374-7483
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
138-2317	Wheel	396-9948
139-9177	Gasket Kit	377-7465
148-7455	Valve - Exhaust	270-4361
148-9810	Gasket Kit	393-3631
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125

33Z		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0560	Rebuild Kit-Pump	363-7458
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
174-0739	Gasket Kit - F	437-2012
196-0028	Gear As-Idler	364-5259

33Z		
Original Part Number	Part Name	Classic Part Number
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
234-8013	Kit-Gasket-Sch	437-8650
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
252-5650	Rim As	397-5067
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
275-0120	Pin As	419-7245
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-6872	Kit-Dt Gasket	394-8228
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

45Z		
Original Part Number	Part Name	Classic Part Number
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-4038	Cup-Roller Brg	423-6988
1H-5338	Cup-Roller Brg	374-8345
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3821	Bearing-Conn Rod	376-9076

45Z		
Original Part Number	Part Name	Classic Part Number
1N-3822	Bearing-Conn Rod	376-9077
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-4693	Cup-Rlr Bearing	377-7398
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344

45Z		
Original Part Number	Part Name	Classic Part Number
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-0576	Bearing-Sleeve	379-0186
1T-1401	Ring-Seal	384-4799
1T-1428	Retainer-Brg	300-2587
1T-1446	Impeller-Conv	377-7413
1T-1647	Impeller-Conv	377-7415
1T-1691	Impeller-Conv	297-4863

Sales Model 936 (Cont'd.)

45Z		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1766	Muffler As.	298-2783
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-5920	Bearing-Camshaft	421-1558
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0535	Nut	299-2026

45Z		
Original Part Number	**Part Name**	**Classic Part Number**
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-8753	Pinion-Bevel	253-1432
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4611	Pipe-Exhaust	365-8821
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2P-8986	Cup-Rlr Bearing	415-1912
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8271	Arm As-Rocker	432-8912
3B-4124	Cup-Spl Tapered	422-6481
3G-2752	Cartridge Gp-Rr	422-8127

45Z		
Original Part Number	**Part Name**	**Classic Part Number**
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3G-9891	Pump Gp-Gr A	399-8541
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4D-0487	Valve As-Check	375-4334
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383
4E-2168	Piston	375-2623
4E-3456	Lever As	367-6081
4E-3997	Housing-Pinion	374-6498
4E-7608	Bearing-Sleeve	388-0639
4E-9658	Joint Gp-Slip	452-9553
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8204	Mount As	374-1449
4N-8344	Spider As-Fan	416-5520
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985

Sales Model 936 (Cont'd.)

45Z		
Original Part Number	Part Name	Classic Part Number
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4Q-1346	Link As-Bearing&	425-3649
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0092	Hub As	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-3680	Bellcrank	308-9802
4V-3842	Support-Trunnion	396-9935
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-6527	Disc	376-9050
4V-7543	Retainer	281-1699
4V-7545	Gear-Ring	394-9823
4V-9577	Shaft-Planet	231-0001
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

45Z		
Original Part Number	Part Name	Classic Part Number
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
4W-9655	Support	419-0882
4Y-1034	Pin As	396-0641
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
5V-7574	Ring-Retaining	392-4483
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2932	Pump Gp-Vn Bsc-B	422-8155
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919

45Z		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-6721	Coupling	377-5830
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6V-2466	Kit-Gasket-Fs	437-3211
6V-5413	Gasket Kit	390-5291
6V-5414	Gasket Kit	434-7289
6V-5976	Kit-Gasket (Rs)	393-5200
6V-6896	Rebuild Kit	390-1006
6W-2899	Shaft-Pinion	446-3057
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097

Sales Model 936 (Cont'd.)

45Z		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3484	Bearing-Spl Ball	416-2166
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-7955	Gasket-Cover	382-6899
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7H-4566	Cup-Roller Brg	399-6068
7I-4187	Yoke-1550	380-1510
7J-8893	Cone-Roller Brg	374-1846
7J-9682	Bearing-Sleeve	360-2335
7K-0084	Bearing-Sleeve	453-6508
7K-0686	Trunnion-Rear	297-7266
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7K-7237	Gear-Planet	231-0009
7K-8877	Cone-Bearing	374-1847
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816

45Z		
Original Part Number	**Part Name**	**Classic Part Number**
7N-0165	Core As-O Clr	295-5670
7N-0691	Elbow-Water Rglt	378-3983
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-7681	Pipe-Exh Ext	385-7213
7S-8443	Muffler	247-2675
7S-8576	Bearing As	435-4848
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-0638	Spacer	425-3651
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8E-4589	Carrier As	416-2122
8E-4954	Housing As-Cl	391-9823
8E-5284	Bearing	388-0582
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512

45Z		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
8K-6321	Gear-Sun	253-1441
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3753	Rod As-Conn	379-8867
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6308	Bearing-Conn Rod	419-7267
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083

Sales Model 936 (Cont'd.)

45Z		
Original Part Number	Part Name	Classic Part Number
8N-8229	Bearing-Main	376-9084
8P-3563	Cage-Bearing	451-0747
8R-1891	Gear-Ring	450-7547
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
8T-1606	Kit-Gskt-Sch	386-3046
8T-9486	Gasket Kt	393-5197
8V-1537	Gear-Sun	446-3061
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
8V-7659	Pin As	361-1702
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-5525	Shaft-Planet	419-8662
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9G-8931	Yoke As	446-3074
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-4460	Housing As-Cl	297-7203
9N-5246	Bearing-Camshaft	384-4772
9N-5769	Cover-Housing	325-6050
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122

45Z		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9V-3363	Pin As	396-0663
9V-3405	Bearing-Sleeve	425-6453
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784
9V-8693	Actuator Gp-Bk	375-2629
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-5168	Manifold-Exhaust	374-7483
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
138-1840	Retainer-Seal	374-6511
138-2317	Wheel	396-9948

45Z		
Original Part Number	Part Name	Classic Part Number
139-9177	Gasket Kit	377-7465
148-7455	Valve - Exhaust	270-4361
148-9810	Gasket Kit	393-3631
155-6648	Cone Spl Rol Brg	418-9599
159-1845	Yoke As (1480)	380-1494
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
174-0739	Gasket Kit - F	437-2012
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
234-8013	Kit-Gasket-Sch	437-8650
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
252-5650	Rim As	397-5067
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357

Sales Model 936 (Cont'd.)

45Z		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
275-0120	Pin As	419-7245
296-1359	Line As-Cla	279-4988

45Z		
Original Part Number	**Part Name**	**Classic Part Number**
296-1360	Line As-Cla	279-4989
297-6872	Kit-Dt Gasket	394-8228
328-5572	Bearing-Rod	419-6349
334-1033	Disc-Friction	394-8242

45Z		
Original Part Number	**Part Name**	**Classic Part Number**
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

4SB		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1647	Impeller-Conv	377-7415
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1766	Muffler As.	298-2783
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716

4SB		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-2566	Ring-Lock	416-2123
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

4SB		
Original Part Number	**Part Name**	**Classic Part Number**
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2P-8986	Cup-Rlr Bearing	415-1912
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2752	Cartridge Gp-Rr	422-8127
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3G-9891	Pump Gp-Gr A	399-8541
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4E-3456	Lever As	367-6081
4E-7608	Bearing-Sleeve	388-0639
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007

Sales Model 936 (Cont'd.)

4SB		
Original Part Number	Part Name	Classic Part Number
4M-0410	Gear-Oil Pump Dr	428-6660
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8344	Spider As-Fan	416-5520
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0092	Hub As	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192

4SB		
Original Part Number	Part Name	Classic Part Number
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-3680	Bellcrank	308-9802
4V-3842	Support-Trunnion	396-9935
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-6527	Disc	376-9050
4V-7543	Retainer	281-1699
4V-7545	Gear-Ring	394-9823
4W-0452	Seal As -Cshaft	325-6191
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
4Y-1034	Pin As	396-0641
5J-1192	Bearing-Sleeve	374-8355
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
5L-6326	Bearing-Ball	420-3222
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110

4SB		
Original Part Number	Part Name	Classic Part Number
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
5V-7574	Ring-Retaining	392-4483
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2932	Pump Gp-Vn Bsc-B	422-8155
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-2202	Bearing-Spl Ball	380-1574
6W-2899	Shaft-Pinion	446-3057
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9918	Repair Kit-Major	388-0655

Sales Model 936 (Cont'd.)

4SB		
Original Part Number	**Part Name**	**Classic Part Number**
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7I-4187	Yoke-1550	380-1510
7J-1309	Bearing-Aligning	360-2275
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7K-0686	Trunnion-Rear	297-7266
7K-2135	Bearing-Roller	417-4492
7K-9528	Bearing-Sleeve	308-9828
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066

4SB		
Original Part Number	**Part Name**	**Classic Part Number**
7T-2036	Cap As-Fuel	361-1721
7V-0638	Spacer	425-3651
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585

4SB		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-1537	Gear-Sun	446-3061
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
8W-9587	Flange As	373-5394
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9J-3206	Bearing-Spher	360-2275
9L-2685	Rod End	419-1866
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9V-0247	Plate	417-4527

Sales Model 936 (Cont'd.)

4SB		
Original Part Number	Part Name	Classic Part Number
9V-8693	Actuator Gp-Bk	375-2629
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
138-2317	Wheel	396-9948
139-9177	Gasket Kit	377-7465
148-7455	Valve - Exhaust	270-4361
148-9810	Gasket Kit	393-3631
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125

4SB		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
174-0739	Gasket Kit - F	437-2012
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828

4SB		
Original Part Number	Part Name	Classic Part Number
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-6872	Kit-Dt Gasket	394-8228
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

5GC		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344

5GC		
Original Part Number	Part Name	Classic Part Number
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1647	Impeller-Conv	377-7415
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

5GC		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173

Sales Model 936 (Cont'd.)

5GC		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2P-8986	Cup-Rlr Bearing	415-1912
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088

5GC		
Original Part Number	Part Name	Classic Part Number
3G-2752	Cartridge Gp-Rr	422-8127
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4E-3456	Lever As	367-6081
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8344	Spider As-Fan	416-5520
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010

5GC		
Original Part Number	Part Name	Classic Part Number
4V-0092	Hub As	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-3680	Bellcrank	308-9802
4V-3842	Support-Trunnion	396-9935
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-6527	Disc	376-9050
4V-7543	Retainer	281-1699
4V-7545	Gear-Ring	394-9823
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
4Y-1034	Pin As	396-0641
5L-2031	Cup-Roller Brg	384-5927
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5V-1274	Spider	385-6110

Sales Model 936 (Cont'd.)

5GC		
Original Part Number	Part Name	Classic Part Number
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
5V-7574	Ring-Retaining	392-4483
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2932	Pump Gp-Vn Bsc-B	422-8155
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-2202	Bearing-Spl Ball	380-1574
6W-2899	Shaft-Pinion	446-3057
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9918	Repair Kit-Major	388-0655

5GC		
Original Part Number	Part Name	Classic Part Number
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7I-4187	Yoke-1550	380-1510
7K-0686	Trunnion-Rear	297-7266
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187

5GC		
Original Part Number	Part Name	Classic Part Number
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083

Sales Model 936 (Cont'd.)

5GC		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8229	Bearing-Main	376-9084
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-1537	Gear-Sun	446-3061
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9L-2685	Rod End	419-1866
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9V-0247	Plate	417-4527
9V-8693	Actuator Gp-Bk	375-2629
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
9Y-1798	Seal-Water	379-0165

5GC		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
138-2317	Wheel	396-9948
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

5GC		
Original Part Number	**Part Name**	**Classic Part Number**
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
247-2670	Muffler-Classic	247-2675
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
275-0120	Pin As	419-7245
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 936E

1HJ		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294

1HJ		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1647	Impeller-Conv	377-7415
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482

1HJ		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157

Sales Model 936E (Cont'd.)

1HJ		
Original Part Number	Part Name	Classic Part Number
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2L-5271	Bearing-Ball	371-4305
2P-8912	Elbow-Exhaust	398-2957
2P-8986	Cup-Rlr Bearing	415-1912
2V-7990	Tube As	373-5382
2W-5536	Core As-Radiator	380-7554
3G-2752	Cartridge Gp-Rr	422-8127
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4M-3915	Bearing-Caged	377-7427
4T-0998	Lever	314-8687
4V-0092	Hub As	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-3680	Bellcrank	308-9802
4V-3842	Support-Trunnion	396-9935
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-6527	Disc	376-9050
4V-7543	Retainer	281-1699
4V-7545	Gear-Ring	394-9823
4W-7188	Core As-Oclr	374-7501
5L-2031	Cup-Roller Brg	384-5927
5P-2526	Cup-Rlr Bearing	380-7498

1HJ		
Original Part Number	Part Name	Classic Part Number
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
5V-7574	Ring-Retaining	392-4483
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6L-7751	Rod End-Spher	472-8015
6N-1553	Coupling-Exhaust	295-6422
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-2202	Bearing-Spl Ball	380-1574
6W-2899	Shaft-Pinion	446-3057
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692

1HJ		
Original Part Number	Part Name	Classic Part Number
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7I-4187	Yoke-1550	380-1510
7K-0686	Trunnion-Rear	297-7266
7K-2135	Bearing-Roller	417-4492
7N-1164	Mount As	295-5451
7N-5206	Mount As	374-1451
7S-4534	Bearing-Caged	417-9497
7T-2036	Cap As-Fuel	361-1721
7V-5645	Rod-Indicator	397-5061
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8P-3563	Cage-Bearing	451-0747
8T-0072	Cone-Rlr Brg	377-7448
8V-1537	Gear-Sun	446-3061
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-8117	Housing As-Cl	302-2686
9L-2685	Rod End	419-1866
9N-4460	Housing As-Cl	297-7203
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-2200	Cartridgr Gp	422-8114
9V-8693	Actuator Gp-Bk	375-2629
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
005-4834	Cone-Rlr Bearing	422-6490
100-8010	Valve	423-5583
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
138-2317	Wheel	396-9948
155-6648	Cone Spl Rol Brg	418-9599
213-1364	Bearing-Sleeve	330-9255

Sales Model 936E (Cont'd.)

1HJ		
Original Part Number	**Part Name**	**Classic Part Number**
213-1370	Bearing-Sleeve	380-7370

1HJ		
Original Part Number	**Part Name**	**Classic Part Number**
275-0120	Pin As	419-7245

2ZB		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-5480	Cover As.-End	299-1998
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1647	Impeller-Conv	377-7415
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

2ZB		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055

2ZB		
Original Part Number	**Part Name**	**Classic Part Number**
2W-5536	Core As-Radiator	380-7554
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2752	Cartridge Gp-Rr	422-8127
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4K-7463	Seal-Lip Type	472-8007
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8344	Spider As-Fan	416-5520
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988

Sales Model 936E (Cont'd.)

2ZB		
Original Part Number	Part Name	Classic Part Number
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-0998	Lever	314-8687
4V-0092	Hub As	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3842	Support-Trunnion	396-9935
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-6527	Disc	376-9050
4V-7543	Retainer	281-1699
4V-7545	Gear-Ring	394-9823
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
5L-2031	Cup-Roller Brg	384-5927
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437

2ZB		
Original Part Number	Part Name	Classic Part Number
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
5V-7574	Ring-Retaining	392-4483
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2932	Pump Gp-Vn Bsc-B	422-8155
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-2202	Bearing-Spl Ball	380-1574
6W-2899	Shaft-Pinion	446-3057
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691

2ZB		
Original Part Number	Part Name	Classic Part Number
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7I-4187	Yoke-1550	380-1510
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037

Sales Model 936E (Cont'd.)

2ZB		
Original Part Number	**Part Name**	**Classic Part Number**
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198

2ZB		
Original Part Number	**Part Name**	**Classic Part Number**
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-1537	Gear-Sun	446-3061
8V-1612	Shaft	425-6456
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-8117	Housing As-Cl	302-2686
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9V-8693	Actuator Gp-Bk	375-2629
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
138-2317	Wheel	396-9948
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599

2ZB		
Original Part Number	**Part Name**	**Classic Part Number**
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

33Z		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063

33Z		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437

Sales Model 936E (Cont'd.)

33Z		
Original Part Number	Part Name	Classic Part Number
1B-3980	Cone-Roller Brg	399-4443
1H-5338	Cup-Roller Brg	374-8345
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-4693	Cup-Rlr Bearing	377-7398
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-0576	Bearing-Sleeve	379-0186
1T-1401	Ring-Seal	384-4799
1T-1428	Retainer-Brg	300-2587
1T-1446	Impeller-Conv	377-7413
1T-1647	Impeller-Conv	377-7415
1T-1691	Impeller-Conv	297-4863
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1U-2665	Cartridge Gp	422-8108

33Z		
Original Part Number	Part Name	Classic Part Number
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1766	Muffler As.	298-2783
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-5920	Bearing-Camshaft	421-1558
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142

33Z		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4611	Pipe-Exhaust	365-8821
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2P-8986	Cup-Rlr Bearing	415-1912
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8271	Arm As-Rocker	432-8912
3G-2752	Cartridge Gp-Rr	422-8127
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3G-9891	Pump Gp-Gr A	399-8541
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638

Sales Model 936E (Cont'd.)

33Z		
Original Part Number	**Part Name**	**Classic Part Number**
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4E-3456	Lever As	367-6081
4E-7608	Bearing-Sleeve	388-0639
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8204	Mount As	374-1449
4N-8344	Spider As-Fan	416-5520
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4Q-1346	Link As-Bearing&	425-3649

33Z		
Original Part Number	**Part Name**	**Classic Part Number**
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0092	Hub As	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-3680	Bellcrank	308-9802
4V-3842	Support-Trunnion	396-9935
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-6527	Disc	376-9050
4V-7543	Retainer	281-1699
4V-7545	Gear-Ring	394-9823
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
4W-9655	Support	419-0882
4Y-1034	Pin As	396-0641
5L-2031	Cup-Roller Brg	384-5927
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024

33Z		
Original Part Number	**Part Name**	**Classic Part Number**
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
5V-7574	Ring-Retaining	392-4483
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2932	Pump Gp-Vn Bsc-B	422-8155
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-6721	Coupling	377-5830
6N-7174	Shield-Oil	314-8544

Sales Model 936E (Cont'd.)

33Z		
Original Part Number	Part Name	Classic Part Number
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-2202	Bearing-Spl Ball	380-1574
6V-5413	Gasket Kit	390-5291
6V-5414	Gasket Kit	434-7289
6V-5976	Kit-Gasket (Rs)	393-5200
6V-6896	Rebuild Kit	390-1006
6V-7459	Gasket Kit	391-1095
6W-2899	Shaft-Pinion	446-3057
6Y-3484	Bearing-Spl Ball	416-2166
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-7955	Gasket-Cover	382-6899
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581

33Z		
Original Part Number	Part Name	Classic Part Number
7G-5614	Shaft-Planet	281-1697
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7H-4566	Cup-Roller Brg	399-6068
7I-4187	Yoke-1550	380-1510
7J-9682	Bearing-Sleeve	360-2335
7K-0084	Bearing-Sleeve	453-6508
7K-0686	Trunnion-Rear	297-7266
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0691	Elbow-Water Rglt	378-3983
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-7681	Pipe-Exh Ext	385-7213
7S-8443	Muffler	247-2675
7S-8576	Bearing As	435-4848
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-0638	Spacer	425-3651
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351

33Z		
Original Part Number	Part Name	Classic Part Number
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8E-4589	Carrier As	416-2122
8E-4954	Housing As-Cl	391-9823
8E-5284	Bearing	388-0582
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3753	Rod As-Conn	379-8867
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6308	Bearing-Conn Rod	419-7267
8N-6796	Head Gp-Cyl -A	269-5290

Sales Model 936E (Cont'd.)

33Z		
Original Part Number	**Part Name**	**Classic Part Number**
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3563	Cage-Bearing	451-0747
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
8T-1606	Kit-Gskt-Sch	386-3046
8T-9486	Gasket Kt	393-5197
8V-1537	Gear-Sun	446-3061
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-5525	Shaft-Planet	419-8662
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9G-8931	Yoke As	446-3074
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9N-4460	Housing As-Cl	297-7203
9N-5246	Bearing-Camshaft	384-4772

33Z		
Original Part Number	**Part Name**	**Classic Part Number**
9N-5769	Cover-Housing	325-6050
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9V-3363	Pin As	396-0663
9V-3405	Bearing-Sleeve	425-6453
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784
9V-8693	Actuator Gp-Bk	375-2629
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-5168	Manifold-Exhaust	374-7483
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
119-6772	Valve-Exhaust	384-8699

33Z		
Original Part Number	**Part Name**	**Classic Part Number**
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
138-2317	Wheel	396-9948
139-9177	Gasket Kit	377-7465
148-7455	Valve - Exhaust	270-4361
148-9810	Gasket Kit	393-3631
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0560	Rebuild Kit-Pump	363-7458
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
174-0739	Gasket Kit - F	437-2012
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
234-8013	Kit-Gasket-Sch	437-8650
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893

Sales Model 936E (Cont'd.)

33Z		
Original Part Number	Part Name	Classic Part Number
247-2670	Muffler-Classic	247-2675
252-5650	Rim As	397-5067
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438

33Z		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4351
275-0120	Pin As	419-7245
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-6872	Kit-Dt Gasket	394-8228

33Z		
Original Part Number	Part Name	Classic Part Number
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

45Z		
Original Part Number	Part Name	Classic Part Number
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-4038	Cup-Roller Brg	423-6988
1H-5338	Cup-Roller Brg	374-8345
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-4693	Cup-Rlr Bearing	377-7398
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040

45Z		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-0576	Bearing-Sleeve	379-0186
1T-1401	Ring-Seal	384-4799
1T-1428	Retainer-Brg	300-2587
1T-1446	Impeller-Conv	377-7413
1T-1647	Impeller-Conv	377-7415
1T-1691	Impeller-Conv	297-4863
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1766	Muffler As.	298-2783
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

45Z		
Original Part Number	Part Name	Classic Part Number
1W-5920	Bearing-Camshaft	421-1558
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-8753	Pinion-Bevel	253-1432
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454

Sales Model 936E (Cont'd.)

45Z		
Original Part Number	**Part Name**	**Classic Part Number**
2P-4611	Pipe-Exhaust	365-8821
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2P-8986	Cup-Rlr Bearing	415-1912
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8271	Arm As-Rocker	432-8912
3B-4124	Cup-Spl Tapered	422-6481
3G-2752	Cartridge Gp-Rr	422-8127
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3G-9891	Pump Gp-Gr A	399-8541
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4D-0487	Valve As-Check	375-4334
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383
4E-2168	Piston	375-2623
4E-3456	Lever As	367-6081
4E-3997	Housing-Pinion	374-6498
4E-7608	Bearing-Sleeve	388-0639

45Z		
Original Part Number	**Part Name**	**Classic Part Number**
4E-9658	Joint Gp-Slip	452-9553
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8204	Mount As	374-1449
4N-8344	Spider As-Fan	416-5520
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4Q-1346	Link As-Bearing&	425-3649
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010

45Z		
Original Part Number	**Part Name**	**Classic Part Number**
4V-0092	Hub As	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-3680	Bellcrank	308-9802
4V-3842	Support-Trunnion	396-9935
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-6527	Disc	376-9050
4V-7543	Retainer	281-1699
4V-7545	Gear-Ring	394-9823
4V-9577	Shaft-Planet	231-0001
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
4W-9655	Support	419-0882
4Y-1034	Pin As	396-0641
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024

Sales Model 936E (Cont'd.)

45Z		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
5V-7574	Ring-Retaining	392-4483
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2932	Pump Gp-Vn Bsc-B	422-8155
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422

45Z		
Original Part Number	Part Name	Classic Part Number
6N-6721	Coupling	377-5830
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6V-2466	Kit-Gasket-Fs	437-3211
6V-5413	Gasket Kit	390-5291
6V-5414	Gasket Kit	434-7289
6V-5976	Kit-Gasket (Rs)	393-5200
6V-6896	Rebuild Kit	390-1006
6W-2899	Shaft-Pinion	446-3057
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3484	Bearing-Spl Ball	416-2166
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-7955	Gasket-Cover	382-6899
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851

45Z		
Original Part Number	Part Name	Classic Part Number
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7H-4566	Cup-Roller Brg	399-6068
7I-4187	Yoke-1550	380-1510
7J-8893	Cone-Roller Brg	374-1846
7J-9682	Bearing-Sleeve	360-2335
7K-0084	Bearing-Sleeve	453-6508
7K-0686	Trunnion-Rear	297-7266
7K-2135	Bearing-Roller	417-4492
7K-5448	Cup-Bearing	415-1922
7K-7237	Gear-Planet	231-0009
7K-8877	Cone-Bearing	374-1847
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0691	Elbow-Water Rglt	378-3983
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994

Sales Model 936E (Cont'd.)

45Z		
Original Part Number	**Part Name**	**Classic Part Number**
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-7681	Pipe-Exh Ext	385-7213
7S-8443	Muffler	247-2675
7S-8576	Bearing As	435-4848
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-0638	Spacer	425-3651
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8E-4589	Carrier As	416-2122
8E-4954	Housing As-Cl	391-9823
8E-5284	Bearing	388-0582
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6321	Gear-Sun	253-1441
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

45Z		
Original Part Number	**Part Name**	**Classic Part Number**
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3753	Rod As-Conn	379-8867
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6308	Bearing-Conn Rod	419-7267
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3563	Cage-Bearing	451-0747
8R-1891	Gear-Ring	450-7547
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
8T-1606	Kit-Gskt-Sch	386-3046
8T-9486	Gasket Kt	393-5197
8V-1537	Gear-Sun	446-3061
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019

45Z		
Original Part Number	**Part Name**	**Classic Part Number**
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
8V-7659	Pin As	361-1702
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-5525	Shaft-Planet	419-8662
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9G-8931	Yoke As	446-3074
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-4460	Housing As-Cl	297-7203
9N-5246	Bearing-Camshaft	384-4772
9N-5769	Cover-Housing	325-6050
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9V-3363	Pin As	396-0663
9V-3405	Bearing-Sleeve	425-6453
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784

Sales Model 936E (Cont'd.)

45Z		
Original Part Number	Part Name	Classic Part Number
9V-8693	Actuator Gp-Bk	375-2629
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-5168	Manifold-Exhaust	374-7483
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
138-1840	Retainer-Seal	374-6511

45Z		
Original Part Number	Part Name	Classic Part Number
138-2317	Wheel	396-9948
139-9177	Gasket Kit	377-7465
148-7455	Valve - Exhaust	270-4361
148-9810	Gasket Kit	393-3631
155-6648	Cone Spl Rol Brg	418-9599
159-1845	Yoke As (1480)	380-1494
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365

45Z		
Original Part Number	Part Name	Classic Part Number
172-7771	Pump Gp-Water -B	419-4646
174-0739	Gasket Kit - F	437-2012
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
234-8013	Kit-Gasket-Sch	437-8650
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
252-5650	Rim As	397-5067
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
275-0120	Pin As	419-7245
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-6872	Kit-Dt Gasket	394-8228
328-5572	Bearing-Rod	419-6349
334-1033	Disc-Friction	394-8242
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

4SB		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770

4SB		
Original Part Number	Part Name	Classic Part Number
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587

4SB		
Original Part Number	Part Name	Classic Part Number
1T-1647	Impeller-Conv	377-7415
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1766	Muffler As.	298-2783
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716

Sales Model 936E (Cont'd.)

4SB		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-2566	Ring-Lock	416-2123
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2P-8986	Cup-Rlr Bearing	415-1912
2V-7990	Tube As	373-5382

4SB		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2752	Cartridge Gp-Rr	422-8127
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3G-9891	Pump Gp-Gr A	399-8541
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4E-3456	Lever As	367-6081
4E-7608	Bearing-Sleeve	388-0639
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4M-0410	Gear-Oil Pump Dr	428-6660
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8344	Spider As-Fan	416-5520
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008

4SB		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-0231	Retainer	376-3641
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0092	Hub As	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-3680	Bellcrank	308-9802
4V-3842	Support-Trunnion	396-9935
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-6527	Disc	376-9050
4V-7543	Retainer	281-1699
4V-7545	Gear-Ring	394-9823

Sales Model 936E (Cont'd.)

4SB		
Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As -Cshaft	325-6191
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
4Y-1034	Pin As	396-0641
5J-1192	Bearing-Sleeve	374-8355
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
5L-6326	Bearing-Ball	420-3222
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
5V-7574	Ring-Retaining	392-4483
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2932	Pump Gp-Vn Bsc-B	422-8155
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919

4SB		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-2202	Bearing-Spl Ball	380-1574
6W-2899	Shaft-Pinion	446-3057
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7I-4187	Yoke-1550	380-1510

4SB		
Original Part Number	Part Name	Classic Part Number
7J-1309	Bearing-Aligning	360-2275
7J-6461	Crown	325-6054
7J-9884	Bearing-Sleeve	325-6016
7K-0686	Trunnion-Rear	297-7266
7K-2135	Bearing-Roller	417-4492
7K-9528	Bearing-Sleeve	308-9828
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7V-0638	Spacer	425-3651
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8F-3170	Bearing-Roller	417-4504

Sales Model 936E (Cont'd.)

4SB		
Original Part Number	**Part Name**	**Classic Part Number**
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033

4SB		
Original Part Number	**Part Name**	**Classic Part Number**
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-1537	Gear-Sun	446-3061
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
8W-9587	Flange As	373-5394
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9J-3206	Bearing-Spher	360-2275
9L-2685	Rod End	419-1866
9M-1328	Bearing-Aligning	325-6018
9M-1853	Mount As.	376-3638
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9V-0247	Plate	417-4527
9V-8693	Actuator Gp-Bk	375-2629
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485

4SB		
Original Part Number	**Part Name**	**Classic Part Number**
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
138-2317	Wheel	396-9948
139-9177	Gasket Kit	377-7465
148-7455	Valve - Exhaust	270-4361
148-9810	Gasket Kit	393-3631
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
174-0739	Gasket Kit - F	437-2012
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
270-4353	Kit-Liner-Cla	295-6438

Sales Model 936E (Cont'd.)

4SB		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028

4SB		
Original Part Number	**Part Name**	**Classic Part Number**
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-6872	Kit-Dt Gasket	394-8228
308-1845	Seal-Wiper	472-8032

4SB		
Original Part Number	**Part Name**	**Classic Part Number**
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

5GC		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1647	Impeller-Conv	377-7415
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716

5GC		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454

5GC		
Original Part Number	**Part Name**	**Classic Part Number**
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2P-8986	Cup-Rlr Bearing	415-1912
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2752	Cartridge Gp-Rr	422-8127
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4E-3456	Lever As	367-6081
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763

Sales Model 936E (Cont'd.)

5GC		
Original Part Number	**Part Name**	**Classic Part Number**
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8344	Spider As-Fan	416-5520
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0092	Hub As	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-3680	Bellcrank	308-9802
4V-3842	Support-Trunnion	396-9935

5GC		
Original Part Number	**Part Name**	**Classic Part Number**
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-6527	Disc	376-9050
4V-7543	Retainer	281-1699
4V-7545	Gear-Ring	394-9823
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
4Y-1034	Pin As	396-0641
5L-2031	Cup-Roller Brg	384-5927
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5V-1274	Spider	385-6110
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
5V-7574	Ring-Retaining	392-4483
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2932	Pump Gp-Vn Bsc-B	422-8155
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161

5GC		
Original Part Number	**Part Name**	**Classic Part Number**
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-2202	Bearing-Spl Ball	380-1574
6W-2899	Shaft-Pinion	446-3057
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7I-4187	Yoke-1550	380-1510
7K-0686	Trunnion-Rear	297-7266
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206

Sales Model 936E (Cont'd.)

5GC		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858

5GC		
Original Part Number	Part Name	Classic Part Number
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-1537	Gear-Sun	446-3061
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-5842	Gear-Transfer	394-0913

5GC		
Original Part Number	Part Name	Classic Part Number
9G-8117	Housing As-Cl	302-2686
9L-2685	Rod End	419-1866
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9V-0247	Plate	417-4527
9V-8693	Actuator Gp-Bk	375-2629
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
138-2317	Wheel	396-9948
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

Sales Model 936E (Cont'd.)

5GC		
Original Part Number	**Part Name**	**Classic Part Number**
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259

5GC		
Original Part Number	**Part Name**	**Classic Part Number**
196-0029	Gear As-Idler	374-4674
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
270-4353	Kit-Liner-Cla	270-4356

5GC		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
275-0120	Pin As	419-7245
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 936F

4TK		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-4038	Cup-Roller Brg	423-6988
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1647	Impeller-Conv	377-7415
1T-1691	Impeller-Conv	297-4863

4TK		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1766	Muffler As.	298-2783
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2K-9295	Bearing-Cone	422-6480

4TK		
Original Part Number	**Part Name**	**Classic Part Number**
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4611	Pipe-Exhaust	365-8821
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203

Sales Model 936F (Cont'd.)

4TK		
Original Part Number	Part Name	Classic Part Number
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3B-4124	Cup-Spl Tapered	422-6481
3G-2752	Cartridge Gp-Rr	422-8127
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3G-9891	Pump Gp-Gr A	399-8541
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4D-0487	Valve As-Check	375-4334
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383
4E-2168	Piston	375-2623
4E-3456	Lever As	367-6081
4E-3997	Housing-Pinion	374-6498
4E-9658	Joint Gp-Slip	452-9553
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8344	Spider As-Fan	416-5520
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988

4TK		
Original Part Number	Part Name	Classic Part Number
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4Q-1346	Link As-Bearing&	425-3649
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-3680	Bellcrank	308-9802
4V-3842	Support-Trunnion	396-9935
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-9901	Pin As	374-6508
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
4Y-1034	Pin As	396-0641
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-9644	Bearing-Outer	384-5929
5P-3930	Bearing As-Rlr	419-6022

4TK		
Original Part Number	Part Name	Classic Part Number
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5V-1274	Spider	385-6110
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
5V-7574	Ring-Retaining	392-4483
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2932	Pump Gp-Vn Bsc-B	422-8155
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-6043	Bearing-Sleeve	374-1456
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133

Sales Model 936F (Cont'd.)

4TK		
Original Part Number	Part Name	Classic Part Number
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-5413	Gasket Kit	390-5291
6V-5414	Gasket Kit	434-7289
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496

4TK		
Original Part Number	Part Name	Classic Part Number
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7V-0638	Spacer	425-3651
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8E-4954	Housing As-Cl	391-9823
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623

4TK		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3563	Cage-Bearing	451-0747
8R-1891	Gear-Ring	450-7547
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-6435	Spider & Brg Kit	377-7451
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9L-2685	Rod End	419-1866
9M-1853	Mount As.	376-3638
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923

Sales Model 936F (Cont'd.)

4TK		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9V-8693	Actuator Gp-Bk	375-2629
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193

4TK		
Original Part Number	Part Name	Classic Part Number
138-1840	Retainer-Seal	374-6511
139-9177	Gasket Kit	377-7465
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
159-1845	Yoke As (1480)	380-1494
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365

4TK		
Original Part Number	Part Name	Classic Part Number
172-7771	Pump Gp-Water -B	419-4646
174-0739	Gasket Kit - F	437-2012
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828
207-2016	Gasket Kit	434-7284
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
275-0120	Pin As	419-7245
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-6872	Kit-Dt Gasket	394-8228
328-5572	Bearing-Rod	419-6349
334-1033	Disc-Friction	394-8242
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

7GL		
Original Part Number	Part Name	Classic Part Number
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
5L-2030	Cone-Roller Brg	418-9614

7GL		
Original Part Number	Part Name	Classic Part Number
5L-2031	Cup-Roller Brg	384-5927
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050

7GL		
Original Part Number	Part Name	Classic Part Number
6Y-2540	Cup-Roller Brg	434-8985
9C-6318	Bearing-Sleeve	374-6516
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605

8AJ		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-4038	Cup-Roller Brg	423-6988

8AJ		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298

8AJ		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087

Sales Model 936F (Cont'd.)

8AJ		
Original Part Number	**Part Name**	**Classic Part Number**
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0406	Wheel-Impeller	384-3854
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1647	Impeller-Conv	377-7415
1T-1691	Impeller-Conv	297-4863
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

8AJ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3B-4124	Cup-Spl Tapered	422-6481
3E-8905	Gasket Kit	393-3617
3G-2752	Cartridge Gp-Rr	422-8127
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3G-9891	Pump Gp-Gr A	399-8541

8AJ		
Original Part Number	**Part Name**	**Classic Part Number**
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383
4E-2168	Piston	375-2623
4E-3456	Lever As	367-6081
4E-3997	Housing-Pinion	374-6498
4E-7608	Bearing-Sleeve	388-0639
4E-9658	Joint Gp-Slip	452-9553
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8344	Spider As-Fan	416-5520
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777

Sales Model 936F (Cont'd.)

8AJ		
Original Part Number	Part Name	Classic Part Number
4P-9964	Line As-Fuel Inj	298-2778
4Q-1346	Link As-Bearing&	425-3649
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-3680	Bellcrank	308-9802
4V-3842	Support-Trunnion	396-9935
4V-5099	Cover	418-1929
4V-7105	Pin As	361-1699
4V-9901	Pin As	374-6508
4W-0452	Seal As -Cshaft	325-6191
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
4Y-1034	Pin As	396-0641
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-9644	Bearing-Outer	384-5929
5P-3930	Bearing As-Rlr	419-6022
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5V-1274	Spider	385-6110

8AJ		
Original Part Number	Part Name	Classic Part Number
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
5V-7574	Ring-Retaining	392-4483
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2932	Pump Gp-Vn Bsc-B	422-8155
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6J-6043	Bearing-Sleeve	374-1456
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-5413	Gasket Kit	390-5291
6V-5414	Gasket Kit	434-7289
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050

8AJ		
Original Part Number	Part Name	Classic Part Number
6Y-2540	Cup-Roller Brg	434-8985
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7J-5131	Trunnion	296-1371
7J-9344	Bearing-Sleeve	360-2334
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656

Sales Model 936F (Cont'd.)

8AJ		
Original Part Number	**Part Name**	**Classic Part Number**
7S-4534	Bearing-Caged	417-9497
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7V-0638	Spacer	425-3651
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-5778	Bearing-Sleeve	374-8359
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349

8AJ		
Original Part Number	**Part Name**	**Classic Part Number**
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3563	Cage-Bearing	451-0747
8R-1891	Gear-Ring	450-7547
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-1606	Kit-Gskt-Sch	386-3046
8T-9486	Gasket Kt	393-5197
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-6435	Spider & Brg Kit	377-7451
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9L-2685	Rod End	419-1866
9M-1853	Mount As.	376-3638
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042

8AJ		
Original Part Number	**Part Name**	**Classic Part Number**
9T-2200	Cartridgr Gp	422-8114
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9V-8693	Actuator Gp-Bk	375-2629
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
138-1840	Retainer-Seal	374-6511
139-9177	Gasket Kit	377-7465
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
159-1845	Yoke As (1480)	380-1494
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

Sales Model 936F (Cont'd.)

8AJ		
Original Part Number	Part Name	Classic Part Number
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
174-0739	Gasket Kit - F	437-2012
196-0028	Gear As-Idler	364-5259

8AJ		
Original Part Number	Part Name	Classic Part Number
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
247-2670	Muffler-Classic	247-2675
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357

8AJ		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4356
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-6872	Kit-Dt Gasket	394-8228
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-1033	Disc-Friction	394-8242
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

9MK		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-4038	Cup-Roller Brg	423-6988
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0406	Wheel-Impeller	384-3854
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1647	Impeller-Conv	377-7415

9MK		
Original Part Number	Part Name	Classic Part Number
1T-1691	Impeller-Conv	297-4863
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1766	Muffler As.	298-2783
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2K-9295	Bearing-Cone	422-6480

9MK		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2P-8986	Cup-Rlr Bearing	415-1912
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088

Sales Model 936F (Cont'd.)

9MK		
Original Part Number	**Part Name**	**Classic Part Number**
3B-4124	Cup-Spl Tapered	422-6481
3G-2752	Cartridge Gp-Rr	422-8127
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3G-9891	Pump Gp-Gr A	399-8541
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383
4E-2168	Piston	375-2623
4E-3456	Lever As	367-6081
4E-3997	Housing-Pinion	374-6498
4E-7608	Bearing-Sleeve	388-0639
4K-7420	Retainer	297-7234
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8344	Spider As-Fan	416-5520
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216

9MK		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-3680	Bellcrank	308-9802
4V-3842	Support-Trunnion	396-9935
4V-5099	Cover	418-1929
4W-0452	Seal As -Cshaft	325-6191
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
4Y-1034	Pin As	396-0641
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-9644	Bearing-Outer	384-5929
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

9MK		
Original Part Number	**Part Name**	**Classic Part Number**
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5V-1274	Spider	385-6110
5V-7574	Ring-Retaining	392-4483
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2932	Pump Gp-Vn Bsc-B	422-8155
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-2202	Bearing-Spl Ball	380-1574
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3484	Bearing-Spl Ball	416-2166

Sales Model 936F (Cont'd.)

9MK		
Original Part Number	Part Name	Classic Part Number
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7V-0638	Spacer	425-3651

9MK		
Original Part Number	Part Name	Classic Part Number
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

9MK		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3563	Cage-Bearing	451-0747
8R-1891	Gear-Ring	450-7547
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9L-2685	Rod End	419-1866
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-8693	Actuator Gp-Bk	375-2629
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913

Sales Model 936F (Cont'd.)

9MK		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
138-1840	Retainer-Seal	374-6511
139-9177	Gasket Kit	377-7465
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
159-1845	Yoke As (1480)	380-1494

9MK		
Original Part Number	**Part Name**	**Classic Part Number**
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259

9MK		
Original Part Number	**Part Name**	**Classic Part Number**
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
275-0120	Pin As	419-7245
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-6872	Kit-Dt Gasket	394-8228
328-5572	Bearing-Rod	419-6349
334-1033	Disc-Friction	394-8242
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

9SK		
Original Part Number	**Part Name**	**Classic Part Number**
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
5L-2030	Cone-Roller Brg	418-9614

9SK		
Original Part Number	**Part Name**	**Classic Part Number**
5L-2031	Cup-Roller Brg	384-5927
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050

9SK		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-2540	Cup-Roller Brg	434-8985
9C-6318	Bearing-Sleeve	374-6516
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605

Sales Model 938F

1KM		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-7250	Bowl	360-2296
1P-2694	Cone-Rlr Brg	374-1841

1KM		
Original Part Number	**Part Name**	**Classic Part Number**
1P-2695	Cup-Rlr Brg	374-8344
1P-7115	Mount As	418-1936
1S-7057	Gasket	420-6384

1KM		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490

Sales Model 938F (Cont'd.)

1KM		
Original Part Number	Part Name	Classic Part Number
1T-2041	Carrier As	396-9893
2B-0941	Spacer	418-1955
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3T-2094	Bearing-Sleeve	388-0638
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383
4E-2168	Piston	375-2623
4E-2250	Housing	399-6043
4E-3997	Housing-Pinion	374-6498
4K-7463	Seal-Lip Type	472-8007
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4Q-1346	Link As-Bearing&	425-3649
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927

1KM		
Original Part Number	Part Name	Classic Part Number
4Y-1034	Pin As	396-0641
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5V-1274	Spider	385-6110
5V-7574	Ring-Retaining	392-4483
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6P-0593	Bearing-Roller	386-4959
6V-4582	Bearing-Ball	380-1504
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
7C-1371	Coupling-Exhaust	369-9490
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7H-4566	Cup-Roller Brg	399-6068
7J-5131	Trunnion	296-1371
7J-8210	Cone-Roller Brg	423-6987
7J-9344	Bearing-Sleeve	360-2334
7M-7219	Bearing-Thrust	384-4816
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190

1KM		
Original Part Number	Part Name	Classic Part Number
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8J-5778	Bearing-Sleeve	374-8359
8R-1891	Gear-Ring	450-7547
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9J-5875	Bearing-Sleeve	308-9830
9R-4067	Joint Gp-Univ	373-5399
9V-0247	Plate	417-4527
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-3650	Support-Trunnion	394-2580
100-3651	Support-Trunnion	445-7699
100-5927	Joint Gp-Univ -A	390-5260
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
103-1713	Yoke-Bk-Flange	382-6892
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-6167	Pin As	375-9972

Sales Model 938F (Cont'd.)

1KM		
Original Part Number	**Part Name**	**Classic Part Number**
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
138-1840	Retainer-Seal	374-6511
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388

1KM		
Original Part Number	**Part Name**	**Classic Part Number**
152-3952	Impeller-Pump	374-4696
159-1845	Yoke As (1480)	380-1494
163-1387	Gear-Flywheel	374-4697
179-1970	Yoke As.	376-9053
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

1KM		
Original Part Number	**Part Name**	**Classic Part Number**
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578
282-6648	Kit-Dt Gasket	396-9955
286-2494	Kit-Gasket-Sch	387-2920
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
334-1033	Disc-Friction	394-8242
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
460-5395	Kit-Gasket (Sch)	436-8395

2RM		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1M-7250	Bowl	360-2296
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
1T-2041	Carrier As	396-9893
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3T-2094	Bearing-Sleeve	388-0638
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383
4E-2168	Piston	375-2623

2RM		
Original Part Number	**Part Name**	**Classic Part Number**
4E-2250	Housing	399-6043
4E-3997	Housing-Pinion	374-6498
4K-7463	Seal-Lip Type	472-8007
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4Q-1346	Link As-Bearing&	425-3649
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529

2RM		
Original Part Number	**Part Name**	**Classic Part Number**
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4Y-1034	Pin As	396-0641
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-7574	Ring-Retaining	392-4483
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6P-0593	Bearing-Roller	386-4959
6V-2202	Bearing-Spl Ball	380-1574
6V-4582	Bearing-Ball	380-1504
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097

Sales Model 938F (Cont'd.)

2RM		
Original Part Number	Part Name	Classic Part Number
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
7C-1371	Coupling-Exhaust	369-9490
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7H-4566	Cup-Roller Brg	399-6068
7J-8210	Cone-Roller Brg	423-6987
7J-9344	Bearing-Sleeve	360-2334
7M-7219	Bearing-Thrust	384-4816
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8J-5778	Bearing-Sleeve	374-8359
8R-1891	Gear-Ring	450-7547
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9C-6317	Shaft-Planet	373-5397

2RM		
Original Part Number	Part Name	Classic Part Number
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9J-5875	Bearing-Sleeve	308-9830
9R-4067	Joint Gp-Univ	373-5399
9V-0247	Plate	417-4527
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-3650	Support-Trunnion	394-2580
100-3651	Support-Trunnion	445-7699
100-5927	Joint Gp-Univ -A	390-5260
100-6267	Plate As-Idler	375-9983
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
103-1713	Yoke-Bk-Flange	382-6892
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-6167	Pin As	375-9972
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
124-3237	Precleaner As	432-4220

2RM		
Original Part Number	Part Name	Classic Part Number
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
138-1840	Retainer-Seal	374-6511
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
159-1845	Yoke As (1480)	380-1494
163-1387	Gear-Flywheel	374-4697
179-1970	Yoke As.	376-9053
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578
282-6648	Kit-Dt Gasket	396-9955
286-2494	Kit-Gasket-Sch	387-2920
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
334-1033	Disc-Friction	394-8242
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
460-5395	Kit-Gasket (Sch)	436-8395

7SN		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988

Sales Model 938F (Cont'd.)

7SN		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
1T-2041	Carrier As	396-9893
2B-0941	Spacer	418-1955
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3T-2094	Bearing-Sleeve	388-0638
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383
4E-2168	Piston	375-2623
4E-2250	Housing	399-6043
4E-3997	Housing-Pinion	374-6498
4K-7463	Seal-Lip Type	472-8007
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193

7SN		
Original Part Number	**Part Name**	**Classic Part Number**
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-5099	Cover	418-1929
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4V-9901	Pin As	374-6508
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4Y-1034	Pin As	396-0641
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5V-1274	Spider	385-6110
5V-7574	Ring-Retaining	392-4483
6E-4892	Cyl Gp-089 478 Y	394-9828
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6P-0593	Bearing-Roller	386-4959
6V-4582	Bearing-Ball	380-1504
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
7C-1371	Coupling-Exhaust	369-9490
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449

7SN		
Original Part Number	**Part Name**	**Classic Part Number**
7E-7302	Bracket	416-5497
7H-4566	Cup-Roller Brg	399-6068
7J-8210	Cone-Roller Brg	423-6987
7M-7219	Bearing-Thrust	384-4816
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8R-1891	Gear-Ring	450-7547
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9R-4067	Joint Gp-Univ	373-5399
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-3650	Support-Trunnion	394-2580
100-3651	Support-Trunnion	445-7699
100-5927	Joint Gp-Univ -A	390-5260
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
103-1713	Yoke-Bk-Flange	382-6892

Sales Model 938F (Cont'd.)

7SN		
Original Part Number	Part Name	Classic Part Number
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-6167	Pin As	375-9972
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
138-1840	Retainer-Seal	374-6511

7SN		
Original Part Number	Part Name	Classic Part Number
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
159-1845	Yoke As (1480)	380-1494
163-1387	Gear-Flywheel	374-4697
179-1970	Yoke As.	376-9053
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123

7SN		
Original Part Number	Part Name	Classic Part Number
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578
282-6648	Kit-Dt Gasket	396-9955
286-2494	Kit-Gasket-Sch	387-2920
334-1033	Disc-Friction	394-8242
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
460-5395	Kit-Gasket (Sch)	436-8395

8SM		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1M-7250	Bowl	360-2296
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
1T-2041	Carrier As	396-9893
2B-0941	Spacer	418-1955
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3G-8932	Pin	325-6143
3T-2094	Bearing-Sleeve	388-0638
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383

8SM		
Original Part Number	Part Name	Classic Part Number
4E-2168	Piston	375-2623
4E-2250	Housing	399-6043
4E-3997	Housing-Pinion	374-6498
4K-7463	Seal-Lip Type	472-8007
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4Q-1346	Link As-Bearing&	425-3649
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967

8SM		
Original Part Number	Part Name	Classic Part Number
4V-3625	Pin As	418-1944
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4Y-1034	Pin As	396-0641
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5V-1274	Spider	385-6110
5V-7574	Ring-Retaining	392-4483
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6P-0593	Bearing-Roller	386-4959
6S-3457	Pin	325-6147
6V-4582	Bearing-Ball	380-1504
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097

Sales Model 938F (Cont'd.)

8SM		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
7C-1371	Coupling-Exhaust	369-9490
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7H-4566	Cup-Roller Brg	399-6068
7J-6461	Crown	325-6054
7J-8210	Cone-Roller Brg	423-6987
7K-9528	Bearing-Sleeve	308-9828
7M-7219	Bearing-Thrust	384-4816
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8H-2810	Case As-Filter	314-8512
8R-1891	Gear-Ring	450-7547
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-6435	Spider & Brg Kit	377-7451

8YN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988

8SM		
Original Part Number	**Part Name**	**Classic Part Number**
8V-7659	Pin As	361-1702
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9M-1328	Bearing-Aligning	325-6018
9R-4067	Joint Gp-Univ	373-5399
9V-0247	Plate	417-4527
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-3650	Support-Trunnion	394-2580
100-3651	Support-Trunnion	445-7699
100-5927	Joint Gp-Univ -A	390-5260
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
103-1713	Yoke-Bk-Flange	382-6892
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-6167	Pin As	375-9972
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002

8SM		
Original Part Number	**Part Name**	**Classic Part Number**
121-7746	Pre-Cleaner As	360-2311
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
138-1840	Retainer-Seal	374-6511
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
159-1845	Yoke As (1480)	380-1494
163-1387	Gear-Flywheel	374-4697
179-1970	Yoke As.	376-9053
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578
282-6648	Kit-Dt Gasket	396-9955
286-2494	Kit-Gasket-Sch	387-2920
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
334-1033	Disc-Friction	394-8242
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
460-5395	Kit-Gasket (Sch)	436-8395

Sales Model 938F (Cont'd.)

8YN		
Original Part Number	Part Name	Classic Part Number
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
1T-2041	Carrier As	396-9893
2B-0941	Spacer	418-1955
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-5285	Bearing-Sleeve	360-2312
3T-2094	Bearing-Sleeve	388-0638
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383
4E-2168	Piston	375-2623
4E-3997	Housing-Pinion	374-6498
4K-7463	Seal-Lip Type	472-8007
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-5099	Cover	418-1929
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5V-1274	Spider	385-6110
5V-7574	Ring-Retaining	392-4483
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495

8YN		
Original Part Number	Part Name	Classic Part Number
6V-4582	Bearing-Ball	380-1504
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7H-4566	Cup-Roller Brg	399-6068
7J-8210	Cone-Roller Brg	423-6987
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8H-2810	Case As-Filter	314-8512
8R-1891	Gear-Ring	450-7547
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-6435	Spider & Brg Kit	377-7451
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9R-4067	Joint Gp-Univ	373-5399
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3414	Pump Gp-Vn Bsc-A	422-8149

8YN		
Original Part Number	Part Name	Classic Part Number
100-3650	Support-Trunnion	394-2580
100-3651	Support-Trunnion	445-7699
100-5927	Joint Gp-Univ -A	390-5260
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
103-1713	Yoke-Bk-Flange	382-6892
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
138-1840	Retainer-Seal	374-6511
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
159-1845	Yoke As (1480)	380-1494
163-1387	Gear-Flywheel	374-4697
179-1970	Yoke As.	376-9053
212-4893	Bearing-Thrust	419-6372
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
334-1033	Disc-Friction	394-8242
352-2151	Pump Gp-Water -B	434-6107

Sales Model 938F (Cont'd.)

8YN		
Original Part Number	**Part Name**	**Classic Part Number**
352-2160	Pump Gp-Water -B	433-0789

8YN		
Original Part Number	**Part Name**	**Classic Part Number**
460-5395	Kit-Gasket (Sch)	436-8395

Sales Model 938G

4YS		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
1T-2041	Carrier As	396-9893
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3T-2094	Bearing-Sleeve	388-0638
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383
4E-2168	Piston	375-2623
4E-2250	Housing	399-6043
4E-3997	Housing-Pinion	374-6498
4J-0121	Cap-Bearing	360-2344
4K-7463	Seal-Lip Type	472-8007
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217

4YS		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9943	Seal-End Tank	385-7216
4Q-1346	Link As-Bearing&	425-3649
4T-8054	Seal As	472-8010
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-1034	Pin As	396-0641
5J-7010	Seal As	472-8011
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-7574	Ring-Retaining	392-4483
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-4582	Bearing-Ball	380-1504

4YS		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
7C-1371	Coupling-Exhaust	369-9490
7C-3729	Pulley	376-9066
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7H-4566	Cup-Roller Brg	399-6068
7J-8210	Cone-Roller Brg	423-6987
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
7K-0078	Bearing-Sleeve	308-9825
7K-9639	Bearing-Sleeve	314-8643
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8J-5778	Bearing-Sleeve	374-8359

Sales Model 938G (Cont'd.)

4YS		
Original Part Number	Part Name	Classic Part Number
8R-1891	Gear-Ring	450-7547
8S-0248	Breather As	325-6033
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9D-7924	Mount As	360-2356
9J-5875	Bearing-Sleeve	308-9830
9M-1328	Bearing-Aligning	325-6018
9R-4067	Joint Gp-Univ	373-5399
9V-0247	Plate	417-4527
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-3650	Support-Trunnion	394-2580
100-3651	Support-Trunnion	445-7699
100-5927	Joint Gp-Univ -A	390-5260
100-6267	Plate As-Idler	375-9983

4YS		
Original Part Number	Part Name	Classic Part Number
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
103-1713	Yoke-Bk-Flange	382-6892
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
110-6167	Pin As	375-9972
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
125-2873	Core As-Ac Cond	436-2254
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
137-6995	Muffler As	360-7868
138-1840	Retainer-Seal	374-6511
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
159-1845	Yoke As (1480)	380-1494
166-6757	Yoke	446-3078
176-3900	Accumulator	416-5513
179-1970	Yoke As.	376-9053
184-9843	Head	347-0461

4YS		
Original Part Number	Part Name	Classic Part Number
212-4893	Bearing-Thrust	419-6372
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
239-4290	Kit-Gasket-Sch	435-2574
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578
282-6648	Kit-Dt Gasket	396-9955
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
334-1033	Disc-Friction	394-8242
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

6WS		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
1T-2041	Carrier As	396-9893
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

6WS		
Original Part Number	Part Name	Classic Part Number
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312

6WS		
Original Part Number	Part Name	Classic Part Number
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383
4E-2168	Piston	375-2623
4E-2250	Housing	399-6043
4E-3997	Housing-Pinion	374-6498
4K-7463	Seal-Lip Type	472-8007
4P-3683	Pump Gp-Water -B	374-7498

Sales Model 938G (Cont'd.)

6WS		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4Q-1346	Link As-Bearing&	425-3649
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-1034	Pin As	396-0641
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-7574	Ring-Retaining	392-4483
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-4582	Bearing-Ball	380-1504
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985

6WS		
Original Part Number	**Part Name**	**Classic Part Number**
7C-1371	Coupling-Exhaust	369-9490
7C-3729	Pulley	376-9066
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7H-4566	Cup-Roller Brg	399-6068
7J-8210	Cone-Roller Brg	423-6987
7J-9344	Bearing-Sleeve	360-2334
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8J-5778	Bearing-Sleeve	374-8359
8R-1891	Gear-Ring	450-7547
8S-0248	Breather As	325-6033
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9D-7924	Mount As	360-2356
9J-5875	Bearing-Sleeve	308-9830
9R-4067	Joint Gp-Univ	373-5399
9V-0247	Plate	417-4527
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605

6WS		
Original Part Number	**Part Name**	**Classic Part Number**
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-3650	Support-Trunnion	394-2580
100-3651	Support-Trunnion	445-7699
100-5927	Joint Gp-Univ -A	390-5260
100-6267	Plate As-Idler	375-9983
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
103-0887	Pulley-Idler	449-9546
103-1713	Yoke-Bk-Flange	382-6892
105-1738	Manifold-Exhaust	374-4692
105-7535	Bearing-Dbl Row	417-9496
107-7708	Bearing-Main	419-6381
110-6167	Pin As	375-9972
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
125-2873	Core As-Ac Cond	436-2254
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
137-6995	Muffler As	360-7868
138-1840	Retainer-Seal	374-6511
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
159-1845	Yoke As (1480)	380-1494
166-6757	Yoke	446-3078
176-3900	Accumulator	416-5513
179-1970	Yoke As.	376-9053
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370

Sales Model 938G (Cont'd.)

6WS		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
239-4290	Kit-Gasket-Sch	435-2574
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912

6WS		
Original Part Number	Part Name	Classic Part Number
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578
282-6648	Kit-Dt Gasket	396-9955
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526

6WS		
Original Part Number	Part Name	Classic Part Number
334-1033	Disc-Friction	394-8242
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

8RS		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
1T-2041	Carrier As	396-9893
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3T-2094	Bearing-Sleeve	388-0638
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383
4E-2168	Piston	375-2623
4E-2250	Housing	399-6043
4E-3997	Housing-Pinion	374-6498
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-7463	Seal-Lip Type	472-8007
4P-3683	Pump Gp-Water -B	374-7498

8RS		
Original Part Number	Part Name	Classic Part Number
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4Q-1346	Link As-Bearing&	425-3649
4T-0231	Retainer	376-3641
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-5099	Cover	418-1929
4V-8643	Bearing-Sleeve	374-8354
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-1034	Pin As	396-0641
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5V-1274	Spider	385-6110
5V-7574	Ring-Retaining	392-4483
6I-1099	Manifold-Exh	424-6366

8RS		
Original Part Number	Part Name	Classic Part Number
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6K-8314	Pin	252-6863
6V-4582	Bearing-Ball	380-1504
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
7C-1371	Coupling-Exhaust	369-9490
7C-3729	Pulley	376-9066
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-6461	Crown	325-6054
7J-8210	Cone-Roller Brg	423-6987
7K-0084	Bearing-Sleeve	453-6508

Sales Model 938G (Cont'd.)

8RS		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9528	Bearing-Sleeve	308-9828
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8R-1891	Gear-Ring	450-7547
8S-0248	Breather As	325-6033
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9D-7924	Mount As	360-2356
9M-1328	Bearing-Aligning	325-6018
9R-4067	Joint Gp-Univ	373-5399
9V-0247	Plate	417-4527
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3414	Pump Gp-Vn Bsc-A	422-8149

8RS		
Original Part Number	**Part Name**	**Classic Part Number**
100-3650	Support-Trunnion	394-2580
100-3651	Support-Trunnion	445-7699
100-5927	Joint Gp-Univ -A	390-5260
100-6267	Plate As-Idler	375-9983
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
103-1713	Yoke-Bk-Flange	382-6892
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
110-6167	Pin As	375-9972
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
125-2873	Core As-Ac Cond	436-2254
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
137-6995	Muffler As	360-7868
138-1840	Retainer-Seal	374-6511
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

8RS		
Original Part Number	**Part Name**	**Classic Part Number**
152-3952	Impeller-Pump	374-4696
159-1845	Yoke As (1480)	380-1494
166-6757	Yoke	446-3078
176-3900	Accumulator	416-5513
179-1970	Yoke As.	376-9053
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
239-4290	Kit-Gasket-Sch	435-2574
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578
282-6648	Kit-Dt Gasket	396-9955
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
334-1033	Disc-Friction	394-8242
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

9HS		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
1T-2041	Carrier As	396-9893
2A-4429	Lock-Retainer	379-0174

9HS		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481

9HS		
Original Part Number	**Part Name**	**Classic Part Number**
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3T-2094	Bearing-Sleeve	388-0638
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383

Sales Model 938G (Cont'd.)

9HS		
Original Part Number	Part Name	Classic Part Number
4E-2168	Piston	375-2623
4E-2250	Housing	399-6043
4E-3997	Housing-Pinion	374-6498
4K-7463	Seal-Lip Type	472-8007
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4Q-1346	Link As-Bearing&	425-3649
4T-8054	Seal As	472-8010
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-5099	Cover	418-1929
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4V-9901	Pin As	374-6508
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4Y-1034	Pin As	396-0641
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5V-1274	Spider	385-6110
5V-7574	Ring-Retaining	392-4483
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428

9HS		
Original Part Number	Part Name	Classic Part Number
6V-4582	Bearing-Ball	380-1504
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
7C-1371	Coupling-Exhaust	369-9490
7C-3729	Pulley	376-9066
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7H-4566	Cup-Roller Brg	399-6068
7J-8210	Cone-Roller Brg	423-6987
7J-9344	Bearing-Sleeve	360-2334
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8J-5778	Bearing-Sleeve	374-8359
8R-1891	Gear-Ring	450-7547
8S-0248	Breather As	325-6033
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9D-7924	Mount As	360-2356

9HS		
Original Part Number	Part Name	Classic Part Number
9M-1328	Bearing-Aligning	325-6018
9R-4067	Joint Gp-Univ	373-5399
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-3650	Support-Trunnion	394-2580
100-3651	Support-Trunnion	445-7699
100-5927	Joint Gp-Univ -A	390-5260
100-6267	Plate As-Idler	375-9983
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
103-0887	Pulley-Idler	449-9546
103-1713	Yoke-Bk-Flange	382-6892
105-1738	Manifold-Exhaust	374-4692
105-7535	Bearing-Dbl Row	417-9496
107-7708	Bearing-Main	419-6381
110-6167	Pin As	375-9972
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
125-2873	Core As-Ac Cond	436-2254
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
137-6995	Muffler As	360-7868
138-1840	Retainer-Seal	374-6511

Sales Model 938G (Cont'd.)

9HS		
Original Part Number	**Part Name**	**Classic Part Number**
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
159-1845	Yoke As (1480)	380-1494
166-6757	Yoke	446-3078
176-3900	Accumulator	416-5513
179-1970	Yoke As.	376-9053
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-1364	Bearing-Sleeve	330-9255

9HS		
Original Part Number	**Part Name**	**Classic Part Number**
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
239-4290	Kit-Gasket-Sch	435-2574
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578

9HS		
Original Part Number	**Part Name**	**Classic Part Number**
282-6648	Kit-Dt Gasket	396-9955
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
334-1033	Disc-Friction	394-8242
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

B9Y		
Original Part Number	**Part Name**	**Classic Part Number**
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
2A-4429	Lock-Retainer	379-0174
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3G-8932	Pin	325-6143
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383
4E-2168	Piston	375-2623
4E-2250	Housing	399-6043
4E-3997	Housing-Pinion	374-6498
4Q-1346	Link As-Bearing&	425-3649
4T-0231	Retainer	376-3641
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2883	Bearing-Sleeve	379-0193

B9Y		
Original Part Number	**Part Name**	**Classic Part Number**
4V-3619	Pin As	380-7393
4V-3625	Pin As	418-1944
4V-5099	Cover	418-1929
4V-8643	Bearing-Sleeve	374-8354
4V-8674	Bearing-Sleeve	307-1529
4Y-1034	Pin As	396-0641
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5V-1274	Spider	385-6110
5V-7574	Ring-Retaining	392-4483
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-6234	Bearing-Sleeve	325-6014
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673

B9Y		
Original Part Number	**Part Name**	**Classic Part Number**
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7H-4566	Cup-Roller Brg	399-6068
7J-1309	Bearing-Aligning	360-2275
7J-6461	Crown	325-6054
7J-8210	Cone-Roller Brg	423-6987
7K-9528	Bearing-Sleeve	308-9828
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8R-1891	Gear-Ring	450-7547
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9D-7924	Mount As	360-2356
9M-1328	Bearing-Aligning	325-6018
9V-0247	Plate	417-4527

Sales Model 938G (Cont'd.)

B9Y		
Original Part Number	Part Name	Classic Part Number
9W-9940	Mount As.	360-2355
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-3650	Support-Trunnion	394-2580
100-3651	Support-Trunnion	445-7699
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
124-3237	Precleaner As	432-4220

B9Y		
Original Part Number	Part Name	Classic Part Number
125-2873	Core As-Ac Cond	436-2254
133-4995	Gasket-Cyl Head	434-2445
138-1840	Retainer-Seal	374-6511
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
164-4413	Mount	419-0876
166-6757	Yoke	446-3078
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370

B9Y		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
334-1033	Disc-Friction	394-8242

CRD		
Original Part Number	Part Name	Classic Part Number
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
2A-4429	Lock-Retainer	379-0174
2K-4502	Bearing-Sleeve	299-1986
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383
4E-2168	Piston	375-2623
4E-2250	Housing	399-6043
4E-3997	Housing-Pinion	374-6498
4Q-1346	Link As-Bearing&	425-3649

CRD		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3625	Pin As	418-1944
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
4Y-1034	Pin As	396-0641
5J-7010	Seal As	472-8011
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-7574	Ring-Retaining	392-4483
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576

CRD		
Original Part Number	Part Name	Classic Part Number
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7H-4566	Cup-Roller Brg	399-6068
7J-8210	Cone-Roller Brg	423-6987
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357

Sales Model 938G (Cont'd.)

CRD		
Original Part Number	**Part Name**	**Classic Part Number**
7K-0078	Bearing-Sleeve	308-9825
7K-9639	Bearing-Sleeve	314-8643
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8J-5778	Bearing-Sleeve	374-8359
8R-1891	Gear-Ring	450-7547
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9D-7924	Mount As	360-2356
9J-5875	Bearing-Sleeve	308-9830
9M-1328	Bearing-Aligning	325-6018
9V-0247	Plate	417-4527
9W-9940	Mount As.	360-2355
005-4834	Cone-Rlr Bearing	422-6490

CRD		
Original Part Number	**Part Name**	**Classic Part Number**
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-3650	Support-Trunnion	394-2580
100-3651	Support-Trunnion	445-7699
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
124-3237	Precleaner As	432-4220
125-2873	Core As-Ac Cond	436-2254
133-4995	Gasket-Cyl Head	434-2445
138-1840	Retainer-Seal	374-6511
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
164-4413	Mount	419-0876
166-6757	Yoke	446-3078

CRD		
Original Part Number	**Part Name**	**Classic Part Number**
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
236-4413	Pump Gp-Water -B	434-6110
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
334-1033	Disc-Friction	394-8242

PHN		
Original Part Number	**Part Name**	**Classic Part Number**
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
2A-4429	Lock-Retainer	379-0174
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
4E-2165	Gear-Sun	376-9070

PHN		
Original Part Number	**Part Name**	**Classic Part Number**
4E-2166	Carrier-Planet	373-5383
4E-2168	Piston	375-2623
4E-2250	Housing	399-6043
4E-3997	Housing-Pinion	374-6498
4Q-1346	Link As-Bearing&	425-3649
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3625	Pin As	418-1944
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529

PHN		
Original Part Number	**Part Name**	**Classic Part Number**
4Y-1034	Pin As	396-0641
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-7574	Ring-Retaining	392-4483
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050

Sales Model 938G (Cont'd.)

PHN		
Original Part Number	Part Name	Classic Part Number
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7H-4566	Cup-Roller Brg	399-6068
7J-8210	Cone-Roller Brg	423-6987
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8R-1891	Gear-Ring	450-7547
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457

PHN		
Original Part Number	Part Name	Classic Part Number
9C-6335	Gear-Planet	319-3439
9D-7924	Mount As	360-2356
9V-0247	Plate	417-4527
9W-9940	Mount As.	360-2355
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-3650	Support-Trunnion	394-2580
100-3651	Support-Trunnion	445-7699
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
124-3237	Precleaner As	432-4220
125-2873	Core As-Ac Cond	436-2254
133-4995	Gasket-Cyl Head	434-2445
138-1840	Retainer-Seal	374-6511
145-0162	Bearing-Main	419-6380

PHN		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
164-4413	Mount	419-0876
166-6757	Yoke	446-3078
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
275-0120	Pin As	419-7245
310-8658	Pin As	425-1526
334-1033	Disc-Friction	394-8242

RTB		
Original Part Number	Part Name	Classic Part Number
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
2A-4429	Lock-Retainer	379-0174
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312

RTB		
Original Part Number	Part Name	Classic Part Number
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383
4E-2168	Piston	375-2623
4E-2250	Housing	399-6043
4E-3997	Housing-Pinion	374-6498
4Q-1346	Link As-Bearing&	425-3649
4T-8054	Seal As	472-8010
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2883	Bearing-Sleeve	379-0193

RTB		
Original Part Number	Part Name	Classic Part Number
4V-3619	Pin As	380-7393
4V-3625	Pin As	418-1944
4V-5099	Cover	418-1929
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4V-9901	Pin As	374-6508
4Y-1034	Pin As	396-0641
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5V-1274	Spider	385-6110
5V-7574	Ring-Retaining	392-4483
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495

Wheel Loaders

Sales Model 938G (Cont'd.)

RTB		
Original Part Number	**Part Name**	**Classic Part Number**
6K-4191	Cap-Upper	300-2576
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7H-4566	Cup-Roller Brg	399-6068
7J-8210	Cone-Roller Brg	423-6987
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8R-1891	Gear-Ring	450-7547
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702

RTB		
Original Part Number	**Part Name**	**Classic Part Number**
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9D-7924	Mount As	360-2356
9M-1328	Bearing-Aligning	325-6018
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9W-9940	Mount As.	360-2355
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-3650	Support-Trunnion	394-2580
100-3651	Support-Trunnion	445-7699
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
110-6167	Pin As	375-9972
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
124-3237	Precleaner As	432-4220
125-2873	Core As-Ac Cond	436-2254

RTB		
Original Part Number	**Part Name**	**Classic Part Number**
133-4995	Gasket-Cyl Head	434-2445
138-1840	Retainer-Seal	374-6511
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
164-4413	Mount	419-0876
166-6757	Yoke	446-3078
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
275-0120	Pin As	419-7245
310-8658	Pin As	425-1526
334-1033	Disc-Friction	394-8242

Sales Model 938H

JKM		
Original Part Number	**Part Name**	**Classic Part Number**
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
2D-5658	Bearing-Ball	301-4628
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312

JKM		
Original Part Number	**Part Name**	**Classic Part Number**
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4Q-1346	Link As-Bearing&	425-3649
4T-8054	Seal As	472-8010
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192

JKM		
Original Part Number	**Part Name**	**Classic Part Number**
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3625	Pin As	418-1944
4V-8674	Bearing-Sleeve	307-1529
4Y-1034	Pin As	396-0641
5J-7010	Seal As	472-8011
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927

Sales Model 938H (Cont'd.)

JKM		
Original Part Number	**Part Name**	**Classic Part Number**
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6Y-3151	Stator-Converter	388-6562
7H-4566	Cup-Roller Brg	399-6068
7J-8210	Cone-Roller Brg	423-6987

JKM		
Original Part Number	**Part Name**	**Classic Part Number**
8C-3111	Rod End-Spher	392-4523
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9D-7924	Mount As	360-2356
9M-1328	Bearing-Aligning	325-6018
9W-9940	Mount As.	360-2355
005-4834	Cone-Rlr Bearing	422-6490

JKM		
Original Part Number	**Part Name**	**Classic Part Number**
114-1071	Piston	388-6583
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
265-5287	Ring-Seal	472-8028
275-0120	Pin As	419-7245
310-8658	Pin As	425-1526

LKM		
Original Part Number	**Part Name**	**Classic Part Number**
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
2D-5658	Bearing-Ball	301-4628
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4Q-1346	Link As-Bearing&	425-3649
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2883	Bearing-Sleeve	379-0193

LKM		
Original Part Number	**Part Name**	**Classic Part Number**
4V-3619	Pin As	380-7393
4V-3625	Pin As	418-1944
4V-8674	Bearing-Sleeve	307-1529
4Y-1034	Pin As	396-0641
5J-7010	Seal As	472-8011
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-5682	Driver	418-9579
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6Y-3151	Stator-Converter	388-6562
7H-4566	Cup-Roller Brg	399-6068
7J-8210	Cone-Roller Brg	423-6987
8C-3111	Rod End-Spher	392-4523

LKM		
Original Part Number	**Part Name**	**Classic Part Number**
8J-5778	Bearing-Sleeve	374-8359
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9D-7924	Mount As	360-2356
9M-1328	Bearing-Aligning	325-6018
9W-9940	Mount As.	360-2355
005-4834	Cone-Rlr Bearing	422-6490
114-1071	Piston	388-6583
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
265-5287	Ring-Seal	472-8028
275-0120	Pin As	419-7245
310-8658	Pin As	425-1526

MCC		
Original Part Number	**Part Name**	**Classic Part Number**
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
2D-5658	Bearing-Ball	301-4628
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3G-4704	Bearing-Sleeve	379-0185

MCC		
Original Part Number	**Part Name**	**Classic Part Number**
3G-5285	Bearing-Sleeve	360-2312
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4Q-1346	Link As-Bearing&	425-3649
4T-0231	Retainer	376-3641

MCC		
Original Part Number	**Part Name**	**Classic Part Number**
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393

Sales Model 938H (Cont'd.)

MCC		
Original Part Number	**Part Name**	**Classic Part Number**
4V-3625	Pin As	418-1944
4V-8643	Bearing-Sleeve	374-8354
4V-8674	Bearing-Sleeve	307-1529
4Y-1034	Pin As	396-0641
5J-7010	Seal As	472-8011
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495

MCC		
Original Part Number	**Part Name**	**Classic Part Number**
6K-4191	Cap-Upper	300-2576
6Y-3151	Stator-Converter	388-6562
7H-4566	Cup-Roller Brg	399-6068
7J-8210	Cone-Roller Brg	423-6987
8C-3111	Rod End-Spher	392-4523
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9D-7924	Mount As	360-2356
9M-1328	Bearing-Aligning	325-6018

MCC		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9940	Mount As.	360-2355
005-4834	Cone-Rlr Bearing	422-6490
114-1071	Piston	388-6583
124-3237	Precleaner As	432-4220
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
265-5287	Ring-Seal	472-8028
275-0120	Pin As	419-7245
310-8658	Pin As	425-1526

MJC		
Original Part Number	**Part Name**	**Classic Part Number**
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
2D-5658	Bearing-Ball	301-4628
2K-4502	Bearing-Sleeve	299-1986
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4J-0121	Cap-Bearing	360-2344
4Q-1346	Link As-Bearing&	425-3649
4T-8054	Seal As	472-8010
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393

MJC		
Original Part Number	**Part Name**	**Classic Part Number**
4V-3625	Pin As	418-1944
4V-8674	Bearing-Sleeve	307-1529
4Y-1034	Pin As	396-0641
5J-7010	Seal As	472-8011
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5T-5682	Driver	418-9579
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6Y-3151	Stator-Converter	388-6562
7H-4566	Cup-Roller Brg	399-6068
7J-5131	Trunnion	296-1371
7J-8210	Cone-Roller Brg	423-6987
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
7K-0078	Bearing-Sleeve	308-9825
7K-9639	Bearing-Sleeve	314-8643

MJC		
Original Part Number	**Part Name**	**Classic Part Number**
8C-3111	Rod End-Spher	392-4523
8J-5778	Bearing-Sleeve	374-8359
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9D-7924	Mount As	360-2356
9J-5875	Bearing-Sleeve	308-9830
9M-1328	Bearing-Aligning	325-6018
9W-9940	Mount As.	360-2355
005-4834	Cone-Rlr Bearing	422-6490
114-1071	Piston	388-6583
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
265-5287	Ring-Seal	472-8028
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526

Sales Model 938K

HFW		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
2K-4502	Bearing-Sleeve	299-1986
3P-1210	Cone-Roller Brg	399-4433

HFW		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
4V-8675	Bearing-Sleeve	394-0187
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6Y-7929	Disc-Friction	456-0555

HFW		
Original Part Number	Part Name	Classic Part Number
7H-4566	Cup-Roller Brg	399-6068
9M-1328	Bearing-Aligning	325-6018
9W-9931	Mount As.	360-2354
005-4834	Cone-Rlr Bearing	422-6490
121-7746	Pre-Cleaner As	360-2311
274-4553	Disc-Clutch	416-2153

REP		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
3P-1210	Cone-Roller Brg	399-4433
5T-5682	Driver	418-9579
6I-8849	Cone-Rlr Bearing	415-1919

REP		
Original Part Number	Part Name	Classic Part Number
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6Y-7929	Disc-Friction	456-0555
7H-4566	Cup-Roller Brg	399-6068
7K-0078	Bearing-Sleeve	308-9825
9J-5875	Bearing-Sleeve	308-9830

REP		
Original Part Number	Part Name	Classic Part Number
9M-1328	Bearing-Aligning	325-6018
9W-9931	Mount As.	360-2354
005-4834	Cone-Rlr Bearing	422-6490
121-7746	Pre-Cleaner As	360-2311
274-4553	Disc-Clutch	416-2153

SWL		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
2K-4502	Bearing-Sleeve	299-1986
3P-1210	Cone-Roller Brg	399-4433
5T-5682	Driver	418-9579
6H-3957	Bearing-Ball	311-9358
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495

SWL		
Original Part Number	Part Name	Classic Part Number
6K-4191	Cap-Upper	300-2576
6Y-7929	Disc-Friction	456-0555
7H-4566	Cup-Roller Brg	399-6068
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
7K-0078	Bearing-Sleeve	308-9825
7K-9528	Bearing-Sleeve	308-9828
7K-9639	Bearing-Sleeve	314-8643

SWL		
Original Part Number	Part Name	Classic Part Number
9J-5875	Bearing-Sleeve	308-9830
9M-1328	Bearing-Aligning	325-6018
9W-9931	Mount As.	360-2354
005-4834	Cone-Rlr Bearing	422-6490
121-7746	Pre-Cleaner As	360-2311
274-4553	Disc-Clutch	416-2153
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

W8K		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296

W8K		
Original Part Number	Part Name	Classic Part Number
3P-1210	Cone-Roller Brg	399-4433
4T-8054	Seal As	472-8010

W8K		
Original Part Number	Part Name	Classic Part Number
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576

Wheel Loaders

Sales Model 938K (Cont'd.)

W8K		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-7929	Disc-Friction	456-0555
7H-4566	Cup-Roller Brg	399-6068
9M-1328	Bearing-Aligning	325-6018

W8K		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9931	Mount As.	360-2354
005-4834	Cone-Rlr Bearing	422-6490

W8K		
Original Part Number	**Part Name**	**Classic Part Number**
121-7746	Pre-Cleaner As	360-2311
274-4553	Disc-Clutch	416-2153

XXT		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
2K-4502	Bearing-Sleeve	299-1986
3P-1210	Cone-Roller Brg	399-4433
5T-5682	Driver	418-9579

XXT		
Original Part Number	**Part Name**	**Classic Part Number**
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6Y-7929	Disc-Friction	456-0555
7H-4566	Cup-Roller Brg	399-6068
7K-9528	Bearing-Sleeve	308-9828

XXT		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1328	Bearing-Aligning	325-6018
9W-9931	Mount As.	360-2354
005-4834	Cone-Rlr Bearing	422-6490
121-7746	Pre-Cleaner As	360-2311
274-4553	Disc-Clutch	416-2153

Sales Model 938M

J3R		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
2K-4502	Bearing-Sleeve	299-1986
3P-1210	Cone-Roller Brg	399-4433
5T-5682	Driver	418-9579

J3R		
Original Part Number	**Part Name**	**Classic Part Number**
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6Y-7929	Disc-Friction	456-0555
7H-4566	Cup-Roller Brg	399-6068
7K-9528	Bearing-Sleeve	308-9828

J3R		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1328	Bearing-Aligning	325-6018
9W-9931	Mount As.	360-2354
005-4834	Cone-Rlr Bearing	422-6490
121-7746	Pre-Cleaner As	360-2311
274-4553	Disc-Clutch	416-2153

Sales Model 944

87J		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-4493	Cone-Spl Tapered	386-4939
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347

87J		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769

87J		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1722	Gear-Balance	298-2770
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0210	Bearing-Ball	417-4498

Sales Model 944 (Cont'd.)

87J		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0555	Carrier-Gde Whl	384-3853
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1701	Carrier-Stator	384-3853
1T-1987	Housing-Rotating	297-4864
1T-1988	Shaft-Output	428-6656
1T-1991	Stator As-Conv	380-1482
1U-3953	Cartridge Gp	426-0024
1V-1080	Housing-Brg Spt	260-0775
1V-5724	Diff Gp -A	260-0776
1V-9208	Link As-Rear	299-2020
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2K-4513	Bearing-Sleeve	308-9814
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532

87J		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2V-6220	Shaft-Planet	221-9073
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
3B-3967	Race-Roller Brg	386-4947
3G-2720	Cartridge Gp-Rr	448-5051
3G-2749	Cartridge Gp-Rr	422-8125
3H-8726	Mount As	385-7208
3K-0526	Bearing-Ball	386-4949
3K-0963	Pin-Lock	308-9895
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3K-7020	Gear-Planet	221-9074
3L-1425	Bearing-Ball	311-9356
3S-2616	Pump Gp-Trans	226-0165
3T-2095	Bearing-Sleeve	384-3459
4D-2619	Bearing	417-4494
4K-9598	Retainer	297-7235
4M-3915	Bearing-Caged	377-7427
4N-7692	Crankshaft As	269-8764
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4V-0381	Bearing-Sleeve	299-1963
4V-5454	Link	299-2025
4W-0452	Seal As -Cshaft	325-6191
5K-1068	Retainer-Seal	260-0786
5K-7995	Bearing-Sleeve	308-9820

87J		
Original Part Number	**Part Name**	**Classic Part Number**
5K-8591	Bearing-Outer	380-7502
5L-6326	Bearing-Ball	420-3222
5P-2526	Cup-Rlr Bearing	380-7498
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5V-1274	Spider	385-6110
5V-5661	Bearing-Sleeve	299-1965
6H-2577	Spider Gp-Brg	333-4954
6I-1345	Shaft As-O Pump	374-7475
6K-2899	Bearing-Sleeve	453-6505
6K-4442	Rod End-Special	373-5388
6K-5513	Pin	241-2558
6K-7161	Pin	241-2559
6K-7162	Pin	241-2560
6K-7164	Pin	241-2561
6K-7165	Pin	241-2562
6K-7287	Pin	241-2564
6N-1036	Gear-Oil Pump	279-4991
6N-2820	Pump Gp-Eng Oil	415-1903
6N-7174	Shield-Oil	314-8544
6V-2202	Bearing-Spl Ball	380-1574
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7G-3454	Gear-Planet	300-2578
7J-9682	Bearing-Sleeve	360-2335
7K-0084	Bearing-Sleeve	453-6508
7K-0085	Bearing-Sleeve	393-3646

Sales Model 944 (Cont'd.)

87J		
Original Part Number	**Part Name**	**Classic Part Number**
7K-0087	Bearing-Sleeve	374-6514
7K-0686	Trunnion-Rear	297-7266
7K-9343	Pin	241-2571
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-4603	Body-Fuel Valve	311-9348
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-7386	Gasket-Cyl Head	392-4519
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7043	Mount As	389-6332
7S-7070	Head As-Cylinder	325-6107
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494
8H-9789	Bearing-Ball	374-8342
8K-5283	Plate	299-2043
8K-5757	Bearing-Sleeve	367-6076
8K-5758	Pin	241-2566
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196

87J		
Original Part Number	**Part Name**	**Classic Part Number**
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1918	Gear-Planet	283-5210
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8V-7175	Pin	241-2567
8V-7176	Pin	241-2568
8W-9566	Flange As	376-9073
9H-2256	Pump Gp-F Prm	311-9443

87J		
Original Part Number	**Part Name**	**Classic Part Number**
9H-5797	Plunger As-Pump	391-9891
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9S-2356	Manifold-Exhaust	261-0905
9S-7788	Ring-Piston	461-5124
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
170-7502	Shaft-Dr Idler	374-7484
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

Sales Model 944A

43A		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1H-4493	Cone-Spl Tapered	386-4939
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1M-0090	Gasket-Manifold	445-7701
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0210	Bearing-Ball	417-4498
1T-0555	Carrier-Gde Whl	384-3853
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1701	Carrier-Stator	384-3853
1T-1987	Housing-Rotating	297-4864
1T-1988	Shaft-Output	428-6656
1T-1991	Stator As-Conv	380-1482
1U-3953	Cartridge Gp	426-0024
1V-1080	Housing-Brg Spt	260-0775
1V-5724	Diff Gp -A	260-0776
1V-9208	Link As-Rear	299-2020
1W-7074	Kit-Rebuild-Pump	419-4712
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040

43A		
Original Part Number	Part Name	Classic Part Number
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2K-4513	Bearing-Sleeve	308-9814
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934
2V-6220	Shaft-Planet	221-9073
3B-3967	Race-Roller Brg	386-4947
3B-8845	Bearing-Inner	417-4509
3G-2720	Cartridge Gp-Rr	448-5051
3G-2749	Cartridge Gp-Rr	422-8125
3H-8726	Mount As	385-7208
3K-0526	Bearing-Ball	386-4949
3K-0963	Pin-Lock	308-9895
3K-2511	Dowel-Reaction	383-2126
3K-4290	Rod End	374-1823
3K-7020	Gear-Planet	221-9074
3S-2616	Pump Gp-Trans	226-0165
3S-5017	Elbow-Exhaust	369-9498
3T-2095	Bearing-Sleeve	384-3459
4D-2619	Bearing	417-4494
4K-9598	Retainer	297-7235
4M-3915	Bearing-Caged	377-7427
4V-0381	Bearing-Sleeve	299-1963
4V-5454	Link	299-2025
5F-8651	Bearing-Ball	420-3223

43A		
Original Part Number	Part Name	Classic Part Number
5H-7071	Director-Water	388-0555
5K-1068	Retainer-Seal	260-0786
5K-7995	Bearing-Sleeve	308-9820
5K-8591	Bearing-Outer	380-7502
5M-2824	Coupling-Exhaust	431-5270
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-5661	Bearing-Sleeve	299-1965
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg	333-4954
6K-2899	Bearing-Sleeve	453-6505
6K-4442	Rod End-Special	373-5388
6K-5513	Pin	241-2558
6K-7161	Pin	241-2559
6K-7162	Pin	241-2560
6K-7164	Pin	241-2561
6K-7165	Pin	241-2562
6K-7287	Pin	241-2564
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7G-3454	Gear-Planet	300-2578
7J-9682	Bearing-Sleeve	360-2335
7K-0084	Bearing-Sleeve	453-6508
7K-0085	Bearing-Sleeve	393-3646
7K-0087	Bearing-Sleeve	374-6514
7K-0686	Trunnion-Rear	297-7266
7K-9343	Pin	241-2571

Sales Model 944A (Cont'd.)

43A		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4046	Bearing-Sleeve	394-8206
7M-4358	Manifold-Exhaust	261-0907
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7043	Mount As	389-6332
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-5283	Plate	299-2043
8K-5757	Bearing-Sleeve	367-6076
8K-5758	Pin	241-2566

43A		
Original Part Number	**Part Name**	**Classic Part Number**
8M-3368	Valve-Check	388-6599
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1918	Gear-Planet	283-5210
8S-9686	Gasket Kit	393-5215
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8V-7175	Pin	241-2567
8V-7176	Pin	241-2568

43A		
Original Part Number	**Part Name**	**Classic Part Number**
8W-9566	Flange As	376-9073
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-5477	Bearing-Sleeve	374-6517
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
308-1845	Seal-Wiper	472-8032

58A		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-4493	Cone-Spl Tapered	386-4939
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1M-7250	Bowl	360-2296
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0210	Bearing-Ball	417-4498
1T-0555	Carrier-Gde Whl	384-3853
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1701	Carrier-Stator	384-3853
1T-1987	Housing-Rotating	297-4864
1T-1988	Shaft-Output	428-6656
1T-1991	Stator As-Conv	380-1482
1U-3953	Cartridge Gp	426-0024

58A		
Original Part Number	**Part Name**	**Classic Part Number**
1V-1080	Housing-Brg Spt	260-0775
1V-5724	Diff Gp -A	260-0776
1V-9208	Link As-Rear	299-2020
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2H-3517	Bearing-Inner	417-4505
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2K-4513	Bearing-Sleeve	308-9814
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989

58A		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2V-6220	Shaft-Planet	221-9073
3B-3967	Race-Roller Brg	386-4947
3B-8845	Bearing-Inner	417-4509
3G-2720	Cartridge Gp-Rr	448-5051
3G-2749	Cartridge Gp-Rr	422-8125
3H-8726	Mount As	385-7208
3K-0526	Bearing-Ball	386-4949
3K-0963	Pin-Lock	308-9895
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3K-7020	Gear-Planet	221-9074
3S-2616	Pump Gp-Trans	226-0165
3T-2095	Bearing-Sleeve	384-3459

Sales Model 944A (Cont'd.)

58A		
Original Part Number	Part Name	Classic Part Number
4K-9598	Retainer	297-7235
4M-3915	Bearing-Caged	377-7427
4V-0381	Bearing-Sleeve	299-1963
4V-5454	Link	299-2025
5K-1068	Retainer-Seal	260-0786
5K-7995	Bearing-Sleeve	308-9820
5K-8591	Bearing-Outer	380-7502
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5S-1211	Cover-Valve	314-8665
5V-1274	Spider	385-6110
5V-5661	Bearing-Sleeve	299-1965
6H-2577	Spider Gp-Brg	333-4954
6K-2899	Bearing-Sleeve	453-6505
6K-5513	Pin	241-2558
6K-7161	Pin	241-2559

58A		
Original Part Number	Part Name	Classic Part Number
6K-7162	Pin	241-2560
6K-7164	Pin	241-2561
6K-7165	Pin	241-2562
6K-7287	Pin	241-2564
6V-2202	Bearing-Spl Ball	380-1574
7G-3454	Gear-Planet	300-2578
7J-9682	Bearing-Sleeve	360-2335
7K-0084	Bearing-Sleeve	453-6508
7K-0085	Bearing-Sleeve	393-3646
7K-0087	Bearing-Sleeve	374-6514
7K-0686	Trunnion-Rear	297-7266
7K-9343	Pin	241-2571
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7043	Mount As	389-6332
7S-7809	Cap As-Radiator	295-6417

58A		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
8K-5283	Plate	299-2043
8K-5757	Bearing-Sleeve	367-6076
8K-5758	Pin	241-2566
8P-1918	Gear-Planet	283-5210
8S-9686	Gasket Kit	393-5215
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8V-7175	Pin	241-2567
8V-7176	Pin	241-2568
8W-9566	Flange As	376-9073
9L-2685	Rod End	419-1866
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271
121-7746	Pre-Cleaner As	360-2311
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
308-1845	Seal-Wiper	472-8032

Sales Model 950

15J		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1M-0090	Gasket-Manifold	445-7701
1M-7250	Bowl	360-2296
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-7125	Governor As	383-3672
1T-0020	Wheel-Turbine	297-4862
1T-0210	Bearing-Ball	417-4498
1T-0555	Carrier-Gde Whl	384-3853
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587

15J		
Original Part Number	Part Name	Classic Part Number
1T-1701	Carrier-Stator	384-3853
1T-1987	Housing-Rotating	297-4864
1T-1988	Shaft-Output	428-6656
1T-1991	Stator As-Conv	380-1482
1U-3953	Cartridge Gp	426-0024
1V-1080	Housing-Brg Spt	260-0775
1V-5724	Diff Gp -A	260-0776
1V-9208	Link As-Rear	299-2020
1W-7074	Kit-Rebuild-Pump	419-4712
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

15J		
Original Part Number	Part Name	Classic Part Number
2H-3517	Bearing-Inner	417-4505
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2K-4513	Bearing-Sleeve	308-9814
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305

Sales Model 950 (Cont'd.)

15J		
Original Part Number	**Part Name**	**Classic Part Number**
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
2V-4331	Collar	387-2910
2V-6220	Shaft-Planet	221-9073
3B-3967	Race-Roller Brg	386-4947
3G-2752	Cartridge Gp-Rr	422-8127
3H-8726	Mount As	385-7208
3K-0526	Bearing-Ball	386-4949
3K-0963	Pin-Lock	308-9895
3K-2511	Dowel-Reaction	383-2126
3K-4290	Rod End	374-1823
3K-7020	Gear-Planet	221-9074
3S-2616	Pump Gp-Trans	226-0165
3S-5017	Elbow-Exhaust	369-9498
3T-2095	Bearing-Sleeve	384-3459
4D-2619	Bearing	417-4494
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4K-7556	Yoke	385-6118
4K-9598	Retainer	297-7235
4M-3915	Bearing-Caged	377-7427
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4V-0381	Bearing-Sleeve	299-1963
4V-5454	Link	299-2025
5H-7071	Director-Water	388-0555
5K-0609	Cover	308-9843
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035

15J		
Original Part Number	**Part Name**	**Classic Part Number**
5K-0991	Cap-Lower	319-3433
5K-1068	Retainer-Seal	260-0786
5K-2432	Pin-Cylinder	384-3473
5K-3171	Plate-Coupling	417-9475
5K-5933	Cover As	247-4125
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5V-1274	Spider	385-6110
5V-5661	Bearing-Sleeve	299-1965
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg	333-4954
6K-2899	Bearing-Sleeve	453-6505
6K-4442	Rod End-Special	373-5388
6K-4597	Yoke As	446-3069
6K-4599	Yoke As	385-6111
6K-4600	Yoke	226-5993
6K-5513	Pin	241-2558
6K-7161	Pin	241-2559
6K-7162	Pin	241-2560
6K-7164	Pin	241-2561
6K-7165	Pin	241-2562
6K-7166	Pin-Arm Pivot	241-2563
6K-7167	Pin	241-2569
6K-7287	Pin	241-2564
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7G-3454	Gear-Planet	300-2578
7J-9344	Bearing-Sleeve	360-2334
7J-9694	Bearing-Sleeve	385-3794
7K-0084	Bearing-Sleeve	453-6508
7K-0085	Bearing-Sleeve	393-3646

15J		
Original Part Number	**Part Name**	**Classic Part Number**
7K-0087	Bearing-Sleeve	374-6514
7K-0686	Trunnion-Rear	297-7266
7K-7176	Pin	241-2570
7K-9343	Pin	241-2571
7M-4046	Bearing-Sleeve	394-8206
7M-4358	Manifold-Exhaust	261-0907
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8D-0983	Mounting	384-3470
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-5283	Plate	299-2043
8K-5757	Bearing-Sleeve	367-6076
8K-5758	Pin	241-2566
8M-3368	Valve-Check	388-6599
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1918	Gear-Planet	283-5210
8S-9686	Gasket Kit	393-5215
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8V-7175	Pin	241-2567
8V-7176	Pin	241-2568
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-5070	Pump Gp-Vn Bsc-B	422-8140
9J-8006	Piston	449-4736

Sales Model 950 (Cont'd.)

15J		
Original Part Number	**Part Name**	**Classic Part Number**
9M-5477	Bearing-Sleeve	374-6517
108-5603	Screw-Adj Arm	379-0166

15J		
Original Part Number	**Part Name**	**Classic Part Number**
121-7746	Pre-Cleaner As	360-2311
143-7356	Bearing As	380-1483
213-1365	Bearing-Sleeve	330-9256

15J		
Original Part Number	**Part Name**	**Classic Part Number**
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085

31K		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1T-0210	Bearing-Ball	417-4498
1T-0576	Bearing-Sleeve	379-0186
2A-4576	Cup-Roller Brg	386-4944
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-5065	Cone-Roller Brg	416-2157

31K		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505
3K-0526	Bearing-Ball	386-4949
3T-2095	Bearing-Sleeve	384-3459
4M-3915	Bearing-Caged	377-7427
4S-8538	Bearing-Spl Ball	417-4502

31K		
Original Part Number	**Part Name**	**Classic Part Number**
5M-2051	Bearing-Caged	380-7467
5P-2526	Cup-Rlr Bearing	380-7498
6Y-3484	Bearing-Spl Ball	416-2166
7F-2742	Bearing-Ball	422-6488
7S-3002	Bearing-Spl Ball	386-4961
8W-9566	Flange As	376-9073
139-9176	Gasket Kit	390-5283
216-5361	Kit - Gasket	383-2109

43J		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1T-0210	Bearing-Ball	417-4498
1T-0576	Bearing-Sleeve	379-0186
1W-3900	Gasket	472-8006
2A-4576	Cup-Roller Brg	386-4944
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142

43J		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505
2P-0220	Gasket-Pump	398-2927
3K-0526	Bearing-Ball	386-4949
3T-2095	Bearing-Sleeve	384-3459
4M-3915	Bearing-Caged	377-7427
4S-8538	Bearing-Spl Ball	417-4502
4W-0452	Seal As -Cshaft	325-6191
5M-2051	Bearing-Caged	380-7467
5P-2526	Cup-Rlr Bearing	380-7498

43J		
Original Part Number	**Part Name**	**Classic Part Number**
5P-8768	Kit-Gasket (Scl)	393-1024
6V-0600	Gasket Kit	437-4583
6V-2466	Kit-Gasket-Fs	437-3211
6Y-3484	Bearing-Spl Ball	416-2166
7F-2742	Bearing-Ball	422-6488
7N-7386	Gasket-Cyl Head	392-4519
7S-3002	Bearing-Spl Ball	386-4961
131-3815	Seal Gp-Basic	325-6193
139-9176	Gasket Kit	390-5283
216-5361	Kit - Gasket	383-2109

73J		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup-Roller Brg	374-8345

Sales Model 950 (Cont'd.)

73J		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-4304	Head Gp-Cyl -A	269-8761
1P-5480	Cover As.-End	299-1998
1S-3062	Director-Water	418-9572
1T-0210	Bearing-Ball	417-4498
1T-0576	Bearing-Sleeve	379-0186
1V-5724	Diff Gp -A	260-0776
1V-9208	Link As-Rear	299-2020
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-6473	Compressor Gp -B	448-9150
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-2719	Pipe-Oil Filler	363-7454
2P-2744	Muffler As.	247-2664
2P-6245	Shaft As-Pump	325-6197
2P-8912	Elbow-Exhaust	398-2957
2S-6097	Tang	375-9979

73J		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
3K-0526	Bearing-Ball	386-4949
3K-0963	Pin-Lock	308-9895
3T-2095	Bearing-Sleeve	384-3459
4M-3915	Bearing-Caged	377-7427
4N-7692	Crankshaft As	269-8764
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-8538	Bearing-Spl Ball	417-4502
4V-0381	Bearing-Sleeve	299-1963
4V-5454	Link	299-2025
4W-0452	Seal As -Cshaft	325-6191
5G-3612	Cap Gp-Protn	295-6419
5M-2051	Bearing-Caged	380-7467
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-5661	Bearing-Sleeve	299-1965
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6K-5513	Pin	241-2558
6K-7161	Pin	241-2559
6K-7162	Pin	241-2560
6K-7164	Pin	241-2561

73J		
Original Part Number	**Part Name**	**Classic Part Number**
6K-7165	Pin	241-2562
6K-7166	Pin-Arm Pivot	241-2563
6K-7287	Pin	241-2564
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6V-0600	Gasket Kit	437-4583
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6V-2466	Kit-Gasket-Fs	437-3211
6Y-3484	Bearing-Spl Ball	416-2166
7C-3862	Camshaft	458-0151
7F-2742	Bearing-Ball	422-6488
7K-0084	Bearing-Sleeve	453-6508
7K-0085	Bearing-Sleeve	393-3646
7K-0087	Bearing-Sleeve	374-6514
7K-7176	Pin	241-2570
7K-9343	Pin	241-2571
7M-4046	Bearing-Sleeve	394-8206
7N-2834	Kit-Repair	374-4723
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-7765	Governor As	377-5841
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042

Sales Model 950 (Cont'd.)

73J		
Original Part Number	Part Name	Classic Part Number
8K-5283	Plate	299-2043
8K-5757	Bearing-Sleeve	367-6076
8K-5758	Pin	241-2566
8M-3368	Valve-Check	388-6599
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

73J		
Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8V-3134	Pinion-Bevel	260-0788
8V-7175	Pin	241-2567
8V-7176	Pin	241-2568
8W-9566	Flange As	376-9073
9S-1768	Pipe-Ext Exhaust	380-7544
9S-7788	Ring-Piston	461-5124
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-8711	Elbow-Exhaust	383-3709
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
139-9176	Gasket Kit	390-5283
148-7455	Valve - Exhaust	270-4361

73J		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
170-0556	Kit-Rebuild-Pump	383-3712
170-7502	Shaft-Dr Idler	374-7484
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
216-5361	Kit - Gasket	383-2109
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
328-5572	Bearing-Rod	419-6349
337-0872	Crankshaft As	242-3440

81J		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769

81J		
Original Part Number	Part Name	Classic Part Number
1P-1722	Gear-Balance	298-2770
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-9670	Univ Jt As	443-2017
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0210	Bearing-Ball	417-4498

81J		
Original Part Number	Part Name	Classic Part Number
1T-0555	Carrier-Gde Whl	384-3853
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1701	Carrier-Stator	384-3853
1T-1987	Housing-Rotating	297-4864
1T-1988	Shaft-Output	428-6656
1T-1991	Stator As-Conv	380-1482
1U-3953	Cartridge Gp	426-0024
1V-0188	Disc	386-4943
1V-1080	Housing-Brg Spt	260-0775

Sales Model 950 (Cont'd.)

81J		
Original Part Number	**Part Name**	**Classic Part Number**
1V-3995	Pin	319-3449
1V-5724	Diff Gp -A	260-0776
1V-9208	Link As-Rear	299-2020
1W-1219	Trunnion As	314-8724
1W-1766	Muffler As.	298-2783
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-6473	Compressor Gp -B	448-9150
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2H-3517	Bearing-Inner	417-4505
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2K-4513	Bearing-Sleeve	308-9814
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505
2K-6413	Pin	360-2270
2K-8753	Pinion-Bevel	253-1432
2K-9295	Bearing-Cone	422-6480

81J		
Original Part Number	**Part Name**	**Classic Part Number**
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2744	Muffler As.	247-2664
2P-5081	Muffler As	360-7872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
2V-1074	Shaft-Planet	364-5262
2V-4331	Collar	387-2910
2V-5608	Shaft-Pin (Bevel)	446-3056
2V-6220	Shaft-Planet	221-9073
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2752	Cartridge Gp-Rr	422-8127
3H-8726	Mount As	385-7208
3K-0526	Bearing-Ball	386-4949
3K-0963	Pin-Lock	308-9895
3K-4290	Rod End	374-1823
3K-7020	Gear-Planet	221-9074
3K-7110	Gear-Planet	253-1435
3L-1425	Bearing-Ball	311-9356
3P-1210	Cone-Roller Brg	399-4433

81J		
Original Part Number	**Part Name**	**Classic Part Number**
3P-5672	Yoke	223-6313
3P-5955	Disc-Friction	428-7205
3S-2616	Pump Gp-Trans	226-0165
3S-5017	Elbow-Exhaust	369-9498
3T-2095	Bearing-Sleeve	384-3459
3V-5762	Support As	389-6310
3V-7427	Housing As	297-7197
4D-2619	Bearing	417-4494
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4K-6212	Shaft-Bev Pinion	223-4806
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4K-7556	Yoke	385-6118
4K-9598	Retainer	297-7235
4M-3915	Bearing-Caged	377-7427
4M-5858	Bearing-Spl Ball	417-4495
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-3927	Compressor As	435-6051
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709

Sales Model 950 (Cont'd.)

81J		
Original Part Number	Part Name	Classic Part Number
4N-7978	Shaft As-Balance	314-8710
4N-8344	Spider As-Fan	416-5520
4P-3546	Valve As-Relief	325-6236
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4S-5891	Plate-Clutch	388-0575
4S-5943	Piston-Clutch	221-9112
4S-8530	Shaft-Planet	221-9111
4S-8534	Shaft As-Planet	221-9116
4S-8538	Bearing-Spl Ball	417-4502
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4V-0381	Bearing-Sleeve	299-1963
4V-4852	Piston	433-0452
4V-5454	Link	299-2025
4W-0452	Seal As -Cshaft	325-6191
5D-0470	Valve Gp-Qrel	314-8549
5G-3612	Cap Gp-Protn	295-6419
5K-0609	Cover	308-9843
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5K-1068	Retainer-Seal	260-0786
5K-2294	Bearing	396-9912
5K-2432	Pin-Cylinder	384-3473
5K-3171	Plate-Coupling	417-9475
5K-5933	Cover As	247-4125
5K-7995	Bearing-Sleeve	308-9820
5L-2031	Cup-Roller Brg	384-5927
5L-6326	Bearing-Ball	420-3222
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913

81J		
Original Part Number	Part Name	Classic Part Number
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4326	Housing-Screen	435-4790
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-6978	Shaft-Planet	221-9103
5S-7010	Shaft-Planet	221-9104
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-5661	Bearing-Sleeve	299-1965
6B-7469	Spacer	417-4535
6H-2577	Spider Gp-Brg	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2034	Shaft	297-7249
6K-2899	Bearing-Sleeve	453-6505
6K-4442	Rod End-Special	373-5388
6K-4597	Yoke As	446-3069
6K-4599	Yoke As	385-6111
6K-4600	Yoke	226-5993
6K-5513	Pin	241-2558
6K-7161	Pin	241-2559
6K-7162	Pin	241-2560
6K-7164	Pin	241-2561
6K-7165	Pin	241-2562
6K-7166	Pin-Arm Pivot	241-2563
6K-7167	Pin	241-2569

81J		
Original Part Number	Part Name	Classic Part Number
6K-7287	Pin	241-2564
6K-7356	Yoke As	330-9296
6K-8088	Bearing-Roller	399-4428
6K-8895	Cap	374-6500
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6V-0600	Gasket Kit	437-4583
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6V-2246	Gasket Kit	391-1091
6V-2466	Kit-Gasket-Fs	437-3211
6Y-2027	Disc-Friction	377-7441
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5348	Disc-Friction	384-4827
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2487	Gear-Planet	221-9092
7J-9344	Bearing-Sleeve	360-2334
7J-9682	Bearing-Sleeve	360-2335
7J-9694	Bearing-Sleeve	385-3794
7K-0084	Bearing-Sleeve	453-6508
7K-0085	Bearing-Sleeve	393-3646
7K-0087	Bearing-Sleeve	374-6514
7K-0686	Trunnion-Rear	297-7266
7K-7176	Pin	241-2570
7K-9343	Pin	241-2571
7K-9640	Bearing-Sleeve	389-6328

Sales Model 950 (Cont'd.)

81J		
Original Part Number	**Part Name**	**Classic Part Number**
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-8117	Muffler As	247-2668
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4629	Pump Gp-Trans	226-0158
7S-7043	Mount As	389-6332
7S-7070	Head As-Cylinder	325-6107
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351

81J		
Original Part Number	**Part Name**	**Classic Part Number**
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8D-0983	Mounting	384-3470
8F-3170	Bearing-Roller	417-4504
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8K-5283	Plate	299-2043
8K-5757	Bearing-Sleeve	367-6076
8K-5758	Pin	241-2566
8K-6283	Gear-Sun	221-9077
8M-3368	Valve-Check	388-6599
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

81J		
Original Part Number	**Part Name**	**Classic Part Number**
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1656	Plate-Clutch	367-6071
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
8S-9698	Gasket Kit	393-5221
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8V-7175	Pin	241-2567
8V-7176	Pin	241-2568
8W-9566	Flange As	376-9073
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-5070	Pump Gp-Vn Bsc-B	422-8140
9J-8006	Piston	449-4736
9K-3413	Gear-Bevel	223-4807

Sales Model 950 (Cont'd.)

81J		
Original Part Number	Part Name	Classic Part Number
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9V-8693	Actuator Gp-Bk	375-2629
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-8711	Elbow-Exhaust	383-3709
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
139-9176	Gasket Kit	390-5283
143-7356	Bearing As	380-1483
148-7455	Valve - Exhaust	270-4361

81J		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0556	Kit-Rebuild-Pump	383-3712
170-0560	Rebuild Kit-Pump	363-7458
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365

81J		
Original Part Number	Part Name	Classic Part Number
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
216-5361	Kit - Gasket	383-2109
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

90A		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1M-0090	Gasket-Manifold	445-7701
1M-7250	Bowl	360-2296
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1T-0020	Wheel-Turbine	297-4862
1T-0210	Bearing-Ball	417-4498

90A		
Original Part Number	Part Name	Classic Part Number
1T-0555	Carrier-Gde Whl	384-3853
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1701	Carrier-Stator	384-3853
1T-1987	Housing-Rotating	297-4864
1T-1988	Shaft-Output	428-6656
1T-1991	Stator As-Conv	380-1482
1U-3953	Cartridge Gp	426-0024
1V-1080	Housing-Brg Spt	260-0775
1V-5724	Diff Gp -A	260-0776
1V-9208	Link As-Rear	299-2020

90A		
Original Part Number	Part Name	Classic Part Number
1W-7074	Kit-Rebuild-Pump	419-4712
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2H-3517	Bearing-Inner	417-4505
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021

Sales Model 950 (Cont'd.)

90A		
Original Part Number	**Part Name**	**Classic Part Number**
2K-4513	Bearing-Sleeve	308-9814
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
2S-6097	Tang	375-9979
2V-4331	Collar	387-2910
2V-6220	Shaft-Planet	221-9073
3B-3967	Race-Roller Brg	386-4947
3G-2752	Cartridge Gp-Rr	422-8127
3H-8726	Mount As	385-7208
3K-0526	Bearing-Ball	386-4949
3K-0963	Pin-Lock	308-9895
3K-2511	Dowel-Reaction	383-2126
3K-4290	Rod End	374-1823
3K-7020	Gear-Planet	221-9074
3S-2616	Pump Gp-Trans	226-0165
3S-5017	Elbow-Exhaust	369-9498
3T-2095	Bearing-Sleeve	384-3459
4D-2619	Bearing	417-4494
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7420	Retainer	297-7234

90A		
Original Part Number	**Part Name**	**Classic Part Number**
4K-7463	Seal-Lip Type	472-8007
4K-7556	Yoke	385-6118
4K-9598	Retainer	297-7235
4M-3915	Bearing-Caged	377-7427
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4V-0381	Bearing-Sleeve	299-1963
4V-5454	Link	299-2025
5H-7071	Director-Water	388-0555
5K-0609	Cover	308-9843
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5K-1068	Retainer-Seal	260-0786
5K-2432	Pin-Cylinder	384-3473
5K-3171	Plate-Coupling	417-9475
5K-5933	Cover As	247-4125
5K-7995	Bearing-Sleeve	308-9820
5K-8591	Bearing-Outer	380-7502
5M-5856	Pipe-Extension	373-1913
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5V-1274	Spider	385-6110
5V-5661	Bearing-Sleeve	299-1965
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg	333-4954
6K-2899	Bearing-Sleeve	453-6505
6K-4442	Rod End-Special	373-5388
6K-4597	Yoke As	446-3069
6K-4599	Yoke As	385-6111
6K-4600	Yoke	226-5993

90A		
Original Part Number	**Part Name**	**Classic Part Number**
6K-5513	Pin	241-2558
6K-7161	Pin	241-2559
6K-7162	Pin	241-2560
6K-7164	Pin	241-2561
6K-7165	Pin	241-2562
6K-7166	Pin-Arm Pivot	241-2563
6K-7167	Pin	241-2569
6K-7287	Pin	241-2564
6K-8088	Bearing-Roller	399-4428
6L-8968	Coupling-Exhaust	311-9381
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7G-3454	Gear-Planet	300-2578
7J-9344	Bearing-Sleeve	360-2334
7J-9682	Bearing-Sleeve	360-2335
7J-9694	Bearing-Sleeve	385-3794
7K-0084	Bearing-Sleeve	453-6508
7K-0085	Bearing-Sleeve	393-3646
7K-0087	Bearing-Sleeve	374-6514
7K-0686	Trunnion-Rear	297-7266
7K-7176	Pin	241-2570
7K-9343	Pin	241-2571
7M-4046	Bearing-Sleeve	394-8206
7M-4358	Manifold-Exhaust	261-0907
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8D-0983	Mounting	384-3470
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342

Sales Model 950 (Cont'd.)

90A		
Original Part Number	Part Name	Classic Part Number
8K-5283	Plate	299-2043
8K-5757	Bearing-Sleeve	367-6076
8K-5758	Pin	241-2566
8M-3368	Valve-Check	388-6599
8N-8220	Bearing-Conn Rod	377-5860
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1918	Gear-Planet	283-5210
8S-9686	Gasket Kit	393-5215

90A		
Original Part Number	Part Name	Classic Part Number
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8V-7175	Pin	241-2567
8V-7176	Pin	241-2568
8W-9566	Flange As	376-9073
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-5070	Pump Gp-Vn Bsc-B	422-8140
9J-8006	Piston	449-4736
9M-5477	Bearing-Sleeve	374-6517

90A		
Original Part Number	Part Name	Classic Part Number
9S-9696	Spider As-Fan	383-3707
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
143-7356	Bearing As	380-1483
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
308-1845	Seal-Wiper	472-8032

99A		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1W-7074	Kit-Rebuild-Pump	419-4712
2L-5271	Bearing-Ball	371-4305

99A		
Original Part Number	Part Name	Classic Part Number
5M-5856	Pipe-Extension	373-1913
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066

99A		
Original Part Number	Part Name	Classic Part Number
8M-3368	Valve-Check	388-6599
9S-1768	Pipe-Ext Exhaust	380-7544
121-7746	Pre-Cleaner As	360-2311

M5K		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
2D-5658	Bearing-Ball	301-4628
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3P-1210	Cone-Roller Brg	399-4433

M5K		
Original Part Number	Part Name	Classic Part Number
4E-3196	Pin As	361-1697
4E-3197	Pin As	374-6507
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
6H-3957	Bearing-Ball	311-9358
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985

M5K		
Original Part Number	Part Name	Classic Part Number
6Y-9930	Mount As	360-2353
7J-8210	Cone-Roller Brg	423-6987
9W-9931	Mount As.	360-2354
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
114-1071	Piston	388-6583
213-1365	Bearing-Sleeve	330-9256
265-5287	Ring-Seal	472-8028
310-1899	Pin As	393-0932

Sales Model 950B

20E		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158

Sales Model 950B (Cont'd.)

20E		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1331	Stator-Converter	229-8237
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150

20E		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088

20E		
Original Part Number	**Part Name**	**Classic Part Number**
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4D-2619	Bearing	417-4494
4E-3456	Lever As	367-6081
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4F-2041	Cup-Roller Brg	418-9609
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116

Sales Model 950B (Cont'd.)

20E		
Original Part Number	Part Name	Classic Part Number
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7105	Pin As	361-1699
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4V-8674	Bearing-Sleeve	307-1529
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5M-0578	Bearing	419-7775
5P-3930	Bearing As-Rlr	419-6022
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

20E		
Original Part Number	Part Name	Classic Part Number
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945
5V-1530	Link As	374-1463
5V-1882	Pin As	361-1700
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2396	Cartridge Gp	422-8122
6E-4892	Cyl Gp-089 478 Y	394-9828
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8895	Cap	374-6500
6K-8897	Bracket As	299-1977
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6W-5119	Housing-Support	450-8051
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851

20E		
Original Part Number	Part Name	Classic Part Number
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7T-2036	Cap As-Fuel	361-1721
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698

Sales Model 950B (Cont'd.)

20E		
Original Part Number	**Part Name**	**Classic Part Number**
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-4445	Pipe-Exhaust Ext	386-3061
8N-5305	Spacer	363-7464
8N-5387	Elbow-Exh Ext	373-1908
8N-5388	Muffler As	360-7895
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084

20E		
Original Part Number	**Part Name**	**Classic Part Number**
8N-9402	Coupling	325-6048
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8V-7659	Pin As	361-1702
9C-4096	Yoke-Bk Flange	369-9496
9C-6281	Tube As	398-2953
9C-8205	Gear-Bevel	319-8175
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9M-5477	Bearing-Sleeve	374-6517
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5173	Joint Gp-Univ	451-9019
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688

20E		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
124-2726	Head	377-5855
131-3815	Seal Gp-Basic	325-6193
143-7356	Bearing As	380-1483
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1365	Bearing-Sleeve	330-9256

Sales Model 950B (Cont'd.)

20E		
Original Part Number	**Part Name**	**Classic Part Number**
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893

20E		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989

20E		
Original Part Number	**Part Name**	**Classic Part Number**
310-1899	Pin As	393-0932
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0406	Wheel-Impeller	384-3854
1T-0576	Bearing-Sleeve	379-0186
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1051	Impeller-Conv	388-6598

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1053	Turbine As-Conv	377-7412
1T-1331	Stator-Converter	229-8237
1T-1428	Retainer-Brg	300-2587
1T-1691	Impeller-Conv	297-4863
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5714	Gear-Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356

Sales Model 950B (Cont'd.)

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5539	Core As-Rad	374-7492
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666
3G-9891	Pump Gp-Gr A	399-8541
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3197	Pin As	374-6507
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4F-2041	Cup-Roller Brg	418-9609
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-4679	Pulley-Fan	394-9837
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-0893	Core As-Radiator	376-9057

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7105	Pin As	361-1699
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4V-8674	Bearing-Sleeve	307-1529
4W-0452	Seal As -Cshaft	325-6191

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5G-3612	Cap Gp-Protn	295-6419
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5L-6326	Bearing-Ball	420-3222
5M-0578	Bearing	419-7775
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945
5V-1530	Link As	374-1463
5V-1882	Pin As	361-1700
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2396	Cartridge Gp	422-8122
6E-4892	Cyl Gp-089 478 Y	394-9828
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

Sales Model 950B (Cont'd.)

22Z		
Original Part Number	Part Name	Classic Part Number
6K-8895	Cap	374-6500
6K-8897	Bracket As	299-1977
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5392	Manifold-Exhaust	394-0905
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-3651	Pump Gp-Gr 1 Bsc	345-1978
6T-5383	Gear-Ring	375-2624
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-5413	Gasket Kit	390-5291
6V-5414	Gasket Kit	434-7289
6V-5976	Kit-Gasket (Rs)	393-5200
6V-7459	Gasket Kit	391-1095
6W-5119	Housing-Support	450-8051
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201

22Z		
Original Part Number	Part Name	Classic Part Number
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-5131	Trunnion	296-1371
7J-9344	Bearing-Sleeve	360-2334
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-8443	Muffler	247-2675
7T-1285	Gear-Planet	297-7190
7T-2036	Cap As-Fuel	361-1721
7T-3343	Plate-Clutch	297-7231
7V-0638	Spacer	425-3651
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041

22Z		
Original Part Number	Part Name	Classic Part Number
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-4445	Pipe-Exhaust Ext	386-3061
8N-5305	Spacer	363-7464
8N-5387	Elbow-Exh Ext	373-1908
8N-5388	Muffler As	360-7895
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232

Sales Model 950B (Cont'd.)

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8P-3563	Cage-Bearing	451-0747
8R-4568	Piston	385-6108
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-1606	Kit-Gskt-Sch	386-3046
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6390	Drum-Brake	377-7449
8V-7659	Pin As	361-1702
9C-4096	Yoke-Bk Flange	369-9496
9C-5852	Hub As	297-7208
9C-6281	Tube As	398-2953
9C-8205	Gear-Bevel	319-8175
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-5842	Gear-Transfer	394-0913
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-6371	Rod-Eye	363-7459
9M-5477	Bearing-Sleeve	374-6517
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5160	Plunger Kt-Adj	385-7218
9V-5173	Joint Gp-Univ	451-9019
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
103-5961	Wheel	398-2963
106-8711	Elbow-Exhaust	383-3709
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
123-3472	Pump Gp-Gr 1 Bsc	345-1978
124-2726	Head	377-5855
131-3815	Seal Gp-Basic	325-6193
139-9177	Gasket Kit	377-7465
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0560	Rebuild Kit-Pump	363-7458
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365

Sales Model 950B (Cont'd.)

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
172-7771	Pump Gp-Water -B	419-4646
176-9273	Piston	297-4860
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
232-3233	Bearing-Main	376-9085
234-8009	Kit-Gasket-Sch	382-5056
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
252-5650	Rim As	397-5067
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
345-1976	Pump-Gr-Cla	345-1978
391-8229	Kit-Gasket-Fs	398-2955

31R		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1331	Stator-Converter	229-8237
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847

31R		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0535	Nut	299-2026

31R		
Original Part Number	**Part Name**	**Classic Part Number**
2K-0714	Plate-Thrust	299-2040
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5539	Core As-Rad	374-7492
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678

Sales Model 950B (Cont'd.)

31R		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666
3G-9891	Pump Gp-Gr A	399-8541
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4D-2619	Bearing	417-4494
4E-3196	Pin As	361-1697
4E-3197	Pin As	374-6507
4E-3456	Lever As	367-6081
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4F-2041	Cup-Roller Brg	418-9609
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985

31R		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7105	Pin As	361-1699
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4V-8674	Bearing-Sleeve	307-1529
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5G-3612	Cap Gp-Protn	295-6419
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5L-6326	Bearing-Ball	420-3222
5M-0578	Bearing	419-7775
5P-3930	Bearing As-Rlr	419-6022

31R		
Original Part Number	**Part Name**	**Classic Part Number**
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945
5V-1530	Link As	374-1463
5V-1882	Pin As	361-1700
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2396	Cartridge Gp	422-8122
6E-4892	Cyl Gp-089 478 Y	394-9828
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8895	Cap	374-6500
6K-8897	Bracket As	299-1977
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624

Sales Model 950B (Cont'd.)

31R		
Original Part Number	Part Name	Classic Part Number
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-5413	Gasket Kit	390-5291
6V-5414	Gasket Kit	434-7289
6W-5119	Housing-Support	450-8051
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985

31R		
Original Part Number	Part Name	Classic Part Number
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7T-2036	Cap As-Fuel	361-1721
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-4445	Pipe-Exhaust Ext	386-3061
8N-5305	Spacer	363-7464
8N-5387	Elbow-Exh Ext	373-1908
8N-5388	Muffler As	360-7895

31R		
Original Part Number	Part Name	Classic Part Number
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-7659	Pin As	361-1702
9C-4096	Yoke-Bk Flange	369-9496
9C-6281	Tube As	398-2953
9C-8205	Gear-Bevel	319-8175
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-6371	Rod-Eye	363-7459
9M-5477	Bearing-Sleeve	374-6517
9N-4460	Housing As-Cl	297-7203

Sales Model 950B (Cont'd.)

31R		
Original Part Number	**Part Name**	**Classic Part Number**
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5173	Joint Gp-Univ	451-9019
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160

31R		
Original Part Number	**Part Name**	**Classic Part Number**
121-7746	Pre-Cleaner As	360-2311
124-2726	Head	377-5855
131-3815	Seal Gp-Basic	325-6193
139-9177	Gasket Kit	377-7465
143-7356	Bearing As	380-1483
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-0560	Rebuild Kit-Pump	363-7458
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

31R		
Original Part Number	**Part Name**	**Classic Part Number**
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
176-9273	Piston	297-4860
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
234-8009	Kit-Gasket-Sch	382-5056
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
252-5650	Rim As	397-5067
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
310-1899	Pin As	393-0932
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

63R		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-2936	Muffler As	298-2782
1N-2946	Extension-Exh	367-6064
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087

63R		
Original Part Number	**Part Name**	**Classic Part Number**
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-5480	Cover As.-End	299-1998
1P-7125	Governor As	383-3672

63R		
Original Part Number	**Part Name**	**Classic Part Number**
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1331	Stator-Converter	229-8237
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158

Sales Model 950B (Cont'd.)

63R		
Original Part Number	Part Name	Classic Part Number
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230

63R		
Original Part Number	Part Name	Classic Part Number
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5539	Core As-Rad	374-7492
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-7933	Core As-O Clr	374-4708
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666
3G-9891	Pump Gp-Gr A	399-8541
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4D-2619	Bearing	417-4494
4E-3196	Pin As	361-1697
4E-3197	Pin As	374-6507
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000

63R		
Original Part Number	Part Name	Classic Part Number
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4F-2041	Cup-Roller Brg	418-9609
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778

Sales Model 950B (Cont'd.)

63R		
Original Part Number	**Part Name**	**Classic Part Number**
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7105	Pin As	361-1699
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4V-8674	Bearing-Sleeve	307-1529
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5053	Muffler As	360-7881
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5G-3612	Cap Gp-Protn	295-6419
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5L-6326	Bearing-Ball	420-3222
5M-0578	Bearing	419-7775
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

63R		
Original Part Number	**Part Name**	**Classic Part Number**
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945
5V-1530	Link As	374-1463
5V-1882	Pin As	361-1700
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2396	Cartridge Gp	422-8122
6E-4892	Cyl Gp-089 478 Y	394-9828
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8895	Cap	374-6500
6K-8897	Bracket As	299-1977
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5392	Manifold-Exhaust	394-0905
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-5413	Gasket Kit	390-5291
6V-5414	Gasket Kit	434-7289
6V-5976	Kit-Gasket (Rs)	393-5200
6V-7459	Gasket Kit	391-1095

63R		
Original Part Number	**Part Name**	**Classic Part Number**
6W-5119	Housing-Support	450-8051
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-5851	Muffler As	298-2790
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496

Sales Model 950B (Cont'd.)

63R		
Original Part Number	Part Name	Classic Part Number
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-8443	Muffler	247-2675
7T-2036	Cap As-Fuel	361-1721
7V-0638	Spacer	425-3651
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

63R		
Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-4445	Pipe-Exhaust Ext	386-3061
8N-5305	Spacer	363-7464
8N-5387	Elbow-Exh Ext	373-1908
8N-5388	Muffler As	360-7895
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-1606	Kit-Gskt-Sch	386-3046
8V-1612	Shaft	425-6456

63R		
Original Part Number	Part Name	Classic Part Number
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-7659	Pin As	361-1702
9C-4096	Yoke-Bk Flange	369-9496
9C-6281	Tube As	398-2953
9C-8205	Gear-Bevel	319-8175
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-6371	Rod-Eye	363-7459
9M-5477	Bearing-Sleeve	374-6517
9N-4460	Housing As-Cl	297-7203
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5173	Joint Gp-Univ	451-9019
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163

Sales Model 950B (Cont'd.)

63R		
Original Part Number	**Part Name**	**Classic Part Number**
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
106-8711	Elbow-Exhaust	383-3709
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
124-2726	Head	377-5855
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
139-9177	Gasket Kit	377-7465
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599

63R		
Original Part Number	**Part Name**	**Classic Part Number**
159-1847	Yoke As (1610)	373-5381
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365

63R		
Original Part Number	**Part Name**	**Classic Part Number**
172-7771	Pump Gp-Water -B	419-4646
176-9273	Piston	297-4860
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828
207-2016	Gasket Kit	434-7284
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
234-8009	Kit-Gasket-Sch	382-5056
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6558	Liner Kit-Cla	295-6438
252-5650	Rim As	397-5067
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
310-1899	Pin As	393-0932
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

65R		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902

65R		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-5480	Cover As.-End	299-1998
1P-7590	Support As-Fr	213-4400
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188

65R		
Original Part Number	**Part Name**	**Classic Part Number**
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1331	Stator-Converter	229-8237
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

Sales Model 950B (Cont'd.)

65R		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984

65R		
Original Part Number	Part Name	Classic Part Number
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5539	Core As-Rad	374-7492
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3G-9891	Pump Gp-Gr A	399-8541
3H-8726	Mount As	385-7208
3J-2443	Bearing	383-2125
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3197	Pin As	374-6507
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4F-2041	Cup-Roller Brg	418-9609

65R		
Original Part Number	Part Name	Classic Part Number
4J-6167	Bearing-Sleeve	325-6009
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-0231	Retainer	376-3641
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652

Sales Model 950B (Cont'd.)

65R		
Original Part Number	**Part Name**	**Classic Part Number**
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7105	Pin As	361-1699
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4V-8674	Bearing-Sleeve	307-1529
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5G-3612	Cap Gp-Protn	295-6419
5J-1192	Bearing-Sleeve	374-8355
5J-2528	Plunger	391-1318
5J-4321	Trunnion	302-2700
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5L-6326	Bearing-Ball	420-3222
5M-0578	Bearing	419-7775
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437

65R		
Original Part Number	**Part Name**	**Classic Part Number**
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945
5V-1530	Link As	374-1463
5V-1882	Pin As	361-1700
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2396	Cartridge Gp	422-8122
6E-4892	Cyl Gp-089 478 Y	394-9828
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6J-9258	Trunnion As	256-4846
6K-8895	Cap	374-6500
6K-8897	Bracket As	299-1977
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1218	Core As-Radiator	379-0181
6N-5392	Manifold-Exhaust	394-0905
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-5414	Gasket Kit	434-7289
6W-5119	Housing-Support	450-8051

65R		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7J-9884	Bearing-Sleeve	325-6016
7K-0686	Trunnion-Rear	297-7266
7K-9528	Bearing-Sleeve	308-9828
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-3536	Gear-Fuel	279-4993
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531

Sales Model 950B (Cont'd.)

65R		
Original Part Number	Part Name	Classic Part Number
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0119	Support As	299-2066
7T-2036	Cap As-Fuel	361-1721
7V-0638	Spacer	425-3651
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8F-3170	Bearing-Roller	417-4504
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8K-6282	Gear-Sun	281-1698
8M-0874	Plunger As-Valve	311-9439
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381

65R		
Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-4445	Pipe-Exhaust Ext	386-3061
8N-5305	Spacer	363-7464
8N-5387	Elbow-Exh Ext	373-1908
8N-5388	Muffler As	360-7895
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831

65R		
Original Part Number	Part Name	Classic Part Number
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-7659	Pin As	361-1702
9C-4096	Yoke-Bk Flange	369-9496
9C-6281	Tube As	398-2953
9C-8205	Gear-Bevel	319-8175
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9H-5797	Plunger As-Pump	391-9891
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-4460	Housing As-Cl	297-7203
9N-5251	Piston Gp-Bsc	250-6557
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-5729	Cyl Gp-0038 0158	422-2486
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905

Sales Model 950B (Cont'd.)

65R		
Original Part Number	Part Name	Classic Part Number
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5173	Joint Gp-Univ	451-9019
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-8711	Elbow-Exhaust	383-3709
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
124-2726	Head	377-5855
131-3815	Seal Gp-Basic	325-6193
139-9177	Gasket Kit	377-7465
143-7356	Bearing As	380-1483
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361

65R		
Original Part Number	Part Name	Classic Part Number
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
176-9273	Piston	297-4860

65R		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
234-8009	Kit-Gasket-Sch	382-5056
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438
252-5650	Rim As	397-5067
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

6CC		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770

6CC		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1331	Stator-Converter	229-8237
1V-3995	Pin	319-3449

6CC		
Original Part Number	Part Name	Classic Part Number
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

Sales Model 950B (Cont'd.)

6CC		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5539	Core As-Rad	374-7492
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678

6CC		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4D-2619	Bearing	417-4494
4E-3456	Lever As	367-6081
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4F-2041	Cup-Roller Brg	418-9609
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988

6CC		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7105	Pin As	361-1699
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4V-8674	Bearing-Sleeve	307-1529
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5M-0578	Bearing	419-7775
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467

Sales Model 950B (Cont'd.)

6CC		
Original Part Number	**Part Name**	**Classic Part Number**
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945
5V-1530	Link As	374-1463
5V-1882	Pin As	361-1700
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2396	Cartridge Gp	422-8122
6E-4892	Cyl Gp-089 478 Y	394-9828
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8895	Cap	374-6500
6K-8897	Bracket As	299-1977
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6W-5119	Housing-Support	450-8051

6CC		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7T-2036	Cap As-Fuel	361-1721
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351

6CC		
Original Part Number	**Part Name**	**Classic Part Number**
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-4445	Pipe-Exhaust Ext	386-3061
8N-5305	Spacer	363-7464
8N-5387	Elbow-Exh Ext	373-1908
8N-5388	Muffler As	360-7895
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377

Sales Model 950B (Cont'd.)

6CC		
Original Part Number	Part Name	Classic Part Number
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-7659	Pin As	361-1702
9C-4096	Yoke-Bk Flange	369-9496
9C-6281	Tube As	398-2953
9C-8205	Gear-Bevel	319-8175
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9M-5477	Bearing-Sleeve	374-6517
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923

6CC		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-9657	Bearing-Spl Ball	371-4308
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5173	Joint Gp-Univ	451-9019
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
124-2726	Head	377-5855
131-3815	Seal Gp-Basic	325-6193
143-7356	Bearing As	380-1483
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351

6CC		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
310-1899	Pin As	393-0932
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

7AB		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1H-5338	Cup-Roller Brg	374-8345

7AB		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840

7AB		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978

Sales Model 950B (Cont'd.)

7AB		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-5480	Cover As.-End	299-1998
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1331	Stator-Converter	229-8237
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354

7AB		
Original Part Number	**Part Name**	**Classic Part Number**
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5539	Core As-Rad	374-7492
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-4704	Bearing-Sleeve	379-0185
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4F-2041	Cup-Roller Brg	418-9609
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116

7AB		
Original Part Number	**Part Name**	**Classic Part Number**
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-1893	Cartridge Gp	422-8110
4T-9311	Housing	396-0652
4V-2518	Shaft	297-7243
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534

Sales Model 950B (Cont'd.)

7AB		
Original Part Number	Part Name	Classic Part Number
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5M-0578	Bearing	419-7775
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2396	Cartridge Gp	422-8122
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-2202	Bearing-Spl Ball	380-1574
6W-5119	Housing-Support	450-8051
6Y-3484	Bearing-Spl Ball	416-2166

7AB		
Original Part Number	Part Name	Classic Part Number
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068

7AB		
Original Part Number	Part Name	Classic Part Number
8A-2305	Repair Kt-Major	386-3042
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5388	Muffler As	360-7895
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

Wheel Loaders

Sales Model 950B (Cont'd.)

7AB		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
9C-4096	Yoke-Bk Flange	369-9496
9C-8205	Gear-Bevel	319-8175
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9M-5477	Bearing-Sleeve	374-6517
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-9657	Bearing-Spl Ball	371-4308

7AB		
Original Part Number	**Part Name**	**Classic Part Number**
9V-5173	Joint Gp-Univ	451-9019
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

7AB		
Original Part Number	**Part Name**	**Classic Part Number**
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 950E

20E		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298

20E		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913

20E		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344

Sales Model 950E (Cont'd.)

20E		
Original Part Number	Part Name	Classic Part Number
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1331	Stator-Converter	229-8237
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

20E		
Original Part Number	Part Name	Classic Part Number
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4D-2619	Bearing	417-4494
4E-3456	Lever As	367-6081
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4F-2041	Cup-Roller Brg	418-9609
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116

20E		
Original Part Number	Part Name	Classic Part Number
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7105	Pin As	361-1699
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720

Sales Model 950E (Cont'd.)

20E		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8674	Bearing-Sleeve	307-1529
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5M-0578	Bearing	419-7775
5P-3930	Bearing As-Rlr	419-6022
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945
5V-1530	Link As	374-1463
5V-1882	Pin As	361-1700
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2396	Cartridge Gp	422-8122
6E-4892	Cyl Gp-089 478 Y	394-9828
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8895	Cap	374-6500

20E		
Original Part Number	**Part Name**	**Classic Part Number**
6K-8897	Bracket As	299-1977
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6W-5119	Housing-Support	450-8051
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848

20E		
Original Part Number	**Part Name**	**Classic Part Number**
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7T-2036	Cap As-Fuel	361-1721
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623

Sales Model 950E (Cont'd.)

20E		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-4445	Pipe-Exhaust Ext	386-3061
8N-5305	Spacer	363-7464
8N-5387	Elbow-Exh Ext	373-1908
8N-5388	Muffler As	360-7895
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
8V-7659	Pin As	361-1702
9C-4096	Yoke-Bk Flange	369-9496
9C-6281	Tube As	398-2953
9C-8205	Gear-Bevel	319-8175
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-8117	Housing As-Cl	302-2686

20E		
Original Part Number	Part Name	Classic Part Number
9G-9764	Yoke As	319-3478
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9M-5477	Bearing-Sleeve	374-6517
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5173	Joint Gp-Univ	451-9019
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
124-2726	Head	377-5855
131-3815	Seal Gp-Basic	325-6193
143-7356	Bearing As	380-1483
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599

20E		
Original Part Number	Part Name	Classic Part Number
159-1847	Yoke As (1610)	373-5381
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
310-1899	Pin As	393-0932
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 950E (Cont'd.)

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0406	Wheel-Impeller	384-3854
1T-0576	Bearing-Sleeve	379-0186
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1051	Impeller-Conv	388-6598
1T-1053	Turbine As-Conv	377-7412
1T-1331	Stator-Converter	229-8237
1T-1428	Retainer-Brg	300-2587
1T-1691	Impeller-Conv	297-4863
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5714	Gear-Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5539	Core As-Rad	374-7492
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666
3G-9891	Pump Gp-Gr A	399-8541
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3197	Pin As	374-6507
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588

Sales Model 950E (Cont'd.)

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
4E-9658	Joint Gp-Slip	452-9553
4F-2041	Cup-Roller Brg	418-9609
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-4679	Pulley-Fan	394-9837
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7105	Pin As	361-1699
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4V-8674	Bearing-Sleeve	307-1529
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5G-3612	Cap Gp-Protn	295-6419
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5L-6326	Bearing-Ball	420-3222
5M-0578	Bearing	419-7775
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945
5V-1530	Link As	374-1463
5V-1882	Pin As	361-1700
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2396	Cartridge Gp	422-8122
6E-4892	Cyl Gp-089 478 Y	394-9828
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8895	Cap	374-6500
6K-8897	Bracket As	299-1977
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5392	Manifold-Exhaust	394-0905
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-3651	Pump Gp-Gr 1 Bsc	345-1978
6T-5383	Gear-Ring	375-2624
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-5413	Gasket Kit	390-5291
6V-5414	Gasket Kit	434-7289
6V-5976	Kit-Gasket (Rs)	393-5200
6V-7459	Gasket Kit	391-1095
6W-5119	Housing-Support	450-8051

Sales Model 950E (Cont'd.)

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-5131	Trunnion	296-1371
7J-9344	Bearing-Sleeve	360-2334
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7765	Governor As	377-5841

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-8443	Muffler	247-2675
7T-1285	Gear-Planet	297-7190
7T-2036	Cap As-Fuel	361-1721
7T-3343	Plate-Clutch	297-7231
7V-0638	Spacer	425-3651
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-4445	Pipe-Exhaust Ext	386-3061
8N-5305	Spacer	363-7464
8N-5387	Elbow-Exh Ext	373-1908
8N-5388	Muffler As	360-7895
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8P-3563	Cage-Bearing	451-0747
8R-4568	Piston	385-6108
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-1606	Kit-Gskt-Sch	386-3046
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788

Sales Model 950E (Cont'd.)

22Z		
Original Part Number	Part Name	Classic Part Number
8V-6390	Drum-Brake	377-7449
8V-7659	Pin As	361-1702
9C-4096	Yoke-Bk Flange	369-9496
9C-5852	Hub As	297-7208
9C-6281	Tube As	398-2953
9C-8205	Gear-Bevel	319-8175
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-5842	Gear-Transfer	394-0913
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-6371	Rod-Eye	363-7459
9M-5477	Bearing-Sleeve	374-6517
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5160	Plunger Kt-Adj	385-7218
9V-5173	Joint Gp-Univ	451-9019
9V-6523	Cap	297-7162

22Z		
Original Part Number	Part Name	Classic Part Number
9V-6524	Cap	297-7163
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
103-5961	Wheel	398-2963
106-8711	Elbow-Exhaust	383-3709
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
123-3472	Pump Gp-Gr 1 Bsc	345-1978
124-2726	Head	377-5855
131-3815	Seal Gp-Basic	325-6193
139-9177	Gasket Kit	377-7465
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

22Z		
Original Part Number	Part Name	Classic Part Number
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0560	Rebuild Kit-Pump	363-7458
170-0566	Kit-Rebuild-Pump	377-5835
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
176-9273	Piston	297-4860
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
234-8009	Kit-Gasket-Sch	382-5056
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
252-5650	Rim As	397-5067
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

Sales Model 950E (Cont'd.)

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
337-0872	Crankshaft As	242-3440

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
345-1976	Pump-Gr-Cla	345-1978

22Z		
Original Part Number	**Part Name**	**Classic Part Number**
391-8229	Kit-Gasket-Fs	398-2955

31R		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1331	Stator-Converter	229-8237
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340

31R		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912

31R		
Original Part Number	**Part Name**	**Classic Part Number**
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5539	Core As-Rad	374-7492
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666
3G-9891	Pump Gp-Gr A	399-8541
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4D-2619	Bearing	417-4494
4E-3196	Pin As	361-1697
4E-3197	Pin As	374-6507
4E-3456	Lever As	367-6081
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4F-2041	Cup-Roller Brg	418-9609
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007

Sales Model 950E (Cont'd.)

31R		
Original Part Number	Part Name	Classic Part Number
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7105	Pin As	361-1699
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720

31R		
Original Part Number	Part Name	Classic Part Number
4V-8674	Bearing-Sleeve	307-1529
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5G-3612	Cap Gp-Protn	295-6419
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5L-6326	Bearing-Ball	420-3222
5M-0578	Bearing	419-7775
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945
5V-1530	Link As	374-1463
5V-1882	Pin As	361-1700
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2396	Cartridge Gp	422-8122
6E-4892	Cyl Gp-089 478 Y	394-9828
6H-3957	Bearing-Ball	311-9358

31R		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8895	Cap	374-6500
6K-8897	Bracket As	299-1977
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-5413	Gasket Kit	390-5291
6V-5414	Gasket Kit	434-7289
6W-5119	Housing-Support	450-8051
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697

Sales Model 950E (Cont'd.)

31R		
Original Part Number	**Part Name**	**Classic Part Number**
7G-6062	Gear-Ring	302-2678
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7T-2036	Cap As-Fuel	361-1721
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196

31R		
Original Part Number	**Part Name**	**Classic Part Number**
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-4445	Pipe-Exhaust Ext	386-3061
8N-5305	Spacer	363-7464
8N-5387	Elbow-Exh Ext	373-1908
8N-5388	Muffler As	360-7895
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788

31R		
Original Part Number	**Part Name**	**Classic Part Number**
8V-7659	Pin As	361-1702
9C-4096	Yoke-Bk Flange	369-9496
9C-6281	Tube As	398-2953
9C-8205	Gear-Bevel	319-8175
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-6371	Rod-Eye	363-7459
9M-5477	Bearing-Sleeve	374-6517
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5173	Joint Gp-Univ	451-9019
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485

Sales Model 950E (Cont'd.)

31R		
Original Part Number	**Part Name**	**Classic Part Number**
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
124-2726	Head	377-5855
131-3815	Seal Gp-Basic	325-6193
139-9177	Gasket Kit	377-7465
143-7356	Bearing As	380-1483
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127

31R		
Original Part Number	**Part Name**	**Classic Part Number**
169-1750	Seal Gp-Basic	472-8022
170-0560	Rebuild Kit-Pump	363-7458
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
176-9273	Piston	297-4860
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828

31R		
Original Part Number	**Part Name**	**Classic Part Number**
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
234-8009	Kit-Gasket-Sch	382-5056
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
252-5650	Rim As	397-5067
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
310-1899	Pin As	393-0932
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

63R		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-2936	Muffler As	298-2782
1N-2946	Extension-Exh	367-6064
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

63R		
Original Part Number	**Part Name**	**Classic Part Number**
1P-5480	Cover As.-End	299-1998
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1331	Stator-Converter	229-8237
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006

63R		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354

Sales Model 950E (Cont'd.)

63R		
Original Part Number	**Part Name**	**Classic Part Number**
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5539	Core As-Rad	374-7492
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-7933	Core As-O Clr	374-4708
2W-8493	Pulley-Fan	430-5361

63R		
Original Part Number	**Part Name**	**Classic Part Number**
2W-8494	Pulley-Alt	295-5692
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666
3G-9891	Pump Gp-Gr A	399-8541
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4D-2619	Bearing	417-4494
4E-3196	Pin As	361-1697
4E-3197	Pin As	374-6507
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4F-2041	Cup-Roller Brg	418-9609
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985

63R		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7105	Pin As	361-1699
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4V-8674	Bearing-Sleeve	307-1529
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5053	Muffler As	360-7881
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5G-3612	Cap Gp-Protn	295-6419

Sales Model 950E (Cont'd.)

63R		
Original Part Number	Part Name	Classic Part Number
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5L-6326	Bearing-Ball	420-3222
5M-0578	Bearing	419-7775
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945
5V-1530	Link As	374-1463
5V-1882	Pin As	361-1700
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2396	Cartridge Gp	422-8122
6E-4892	Cyl Gp-089 478 Y	394-9828
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8895	Cap	374-6500
6K-8897	Bracket As	299-1977
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5392	Manifold-Exhaust	394-0905

63R		
Original Part Number	Part Name	Classic Part Number
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-5413	Gasket Kit	390-5291
6V-5414	Gasket Kit	434-7289
6V-5976	Kit-Gasket (Rs)	393-5200
6V-7459	Gasket Kit	391-1095
6W-5119	Housing-Support	450-8051
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-5851	Muffler As	298-2790
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7K-0686	Trunnion-Rear	297-7266

63R		
Original Part Number	Part Name	Classic Part Number
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-8443	Muffler	247-2675
7T-2036	Cap As-Fuel	361-1721
7V-0638	Spacer	425-3651
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-3170	Bearing-Roller	417-4504

Sales Model 950E (Cont'd.)

63R		
Original Part Number	**Part Name**	**Classic Part Number**
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-4445	Pipe-Exhaust Ext	386-3061
8N-5305	Spacer	363-7464
8N-5387	Elbow-Exh Ext	373-1908
8N-5388	Muffler As	360-7895
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

63R		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-1606	Kit-Gskt-Sch	386-3046
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-7659	Pin As	361-1702
9C-4096	Yoke-Bk Flange	369-9496
9C-6281	Tube As	398-2953
9C-8205	Gear-Bevel	319-8175
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-6371	Rod-Eye	363-7459
9M-5477	Bearing-Sleeve	374-6517
9N-4460	Housing As-Cl	297-7203
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891

63R		
Original Part Number	**Part Name**	**Classic Part Number**
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5173	Joint Gp-Univ	451-9019
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
106-8711	Elbow-Exhaust	383-3709
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
124-2726	Head	377-5855
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
139-9177	Gasket Kit	377-7465
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361

Sales Model 950E (Cont'd.)

63R		
Original Part Number	**Part Name**	**Classic Part Number**
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

63R		
Original Part Number	**Part Name**	**Classic Part Number**
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
176-9273	Piston	297-4860
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828
207-2016	Gasket Kit	434-7284
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370

63R		
Original Part Number	**Part Name**	**Classic Part Number**
232-3233	Bearing-Main	376-9085
234-8009	Kit-Gasket-Sch	382-5056
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6558	Liner Kit-Cla	295-6438
252-5650	Rim As	397-5067
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
310-1899	Pin As	393-0932
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

65R		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-5480	Cover As.-End	299-1998
1P-7590	Support As-Fr	213-4400

65R		
Original Part Number	**Part Name**	**Classic Part Number**
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-2233	Bearing-Sleeve	379-0188
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1331	Stator-Converter	229-8237
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716

65R		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

Sales Model 950E (Cont'd.)

65R		
Original Part Number	**Part Name**	**Classic Part Number**
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5539	Core As-Rad	374-7492
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666
3G-8917	Pin	325-6141

65R		
Original Part Number	**Part Name**	**Classic Part Number**
3G-8932	Pin	325-6143
3G-9891	Pump Gp-Gr A	399-8541
3H-8726	Mount As	385-7208
3J-2443	Bearing	383-2125
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3197	Pin As	374-6507
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4F-2041	Cup-Roller Brg	418-9609
4J-6167	Bearing-Sleeve	325-6009
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-4864	Pump Gp-F Tfr	242-3442
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984

65R		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-0231	Retainer	376-3641
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7105	Pin As	361-1699
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4V-8674	Bearing-Sleeve	307-1529
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5G-3612	Cap Gp-Protn	295-6419
5J-1192	Bearing-Sleeve	374-8355
5J-2528	Plunger	391-1318
5J-4321	Trunnion	302-2700

Sales Model 950E (Cont'd.)

65R		
Original Part Number	Part Name	Classic Part Number
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5L-6326	Bearing-Ball	420-3222
5M-0578	Bearing	419-7775
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945
5V-1530	Link As	374-1463
5V-1882	Pin As	361-1700
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2396	Cartridge Gp	422-8122
6E-4892	Cyl Gp-089 478 Y	394-9828
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6J-9258	Trunnion As	256-4846
6K-8895	Cap	374-6500
6K-8897	Bracket As	299-1977
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991

65R		
Original Part Number	Part Name	Classic Part Number
6N-1218	Core As-Radiator	379-0181
6N-5392	Manifold-Exhaust	394-0905
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-5414	Gasket Kit	434-7289
6W-5119	Housing-Support	450-8051
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015

65R		
Original Part Number	Part Name	Classic Part Number
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7J-9884	Bearing-Sleeve	325-6016
7K-0686	Trunnion-Rear	297-7266
7K-9528	Bearing-Sleeve	308-9828
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-3536	Gear-Fuel	279-4993
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0119	Support As	299-2066
7T-2036	Cap As-Fuel	361-1721
7V-0638	Spacer	425-3651
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187

Sales Model 950E (Cont'd.)

65R		
Original Part Number	**Part Name**	**Classic Part Number**
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8F-3170	Bearing-Roller	417-4504
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8J-2880	Cap-Bearing	295-6420
8K-6282	Gear-Sun	281-1698
8M-0874	Plunger As-Valve	311-9439
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-4445	Pipe-Exhaust Ext	386-3061
8N-5305	Spacer	363-7464
8N-5387	Elbow-Exh Ext	373-1908
8N-5388	Muffler As	360-7895
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232

65R		
Original Part Number	**Part Name**	**Classic Part Number**
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-7659	Pin As	361-1702
9C-4096	Yoke-Bk Flange	369-9496
9C-6281	Tube As	398-2953
9C-8205	Gear-Bevel	319-8175
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9H-5797	Plunger As-Pump	391-9891
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9M-4789	Shaft-Gov Cont	297-7256

65R		
Original Part Number	**Part Name**	**Classic Part Number**
9M-5477	Bearing-Sleeve	374-6517
9N-4460	Housing As-Cl	297-7203
9N-5251	Piston Gp-Bsc	250-6557
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-5729	Cyl Gp-0038 0158	422-2486
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5173	Joint Gp-Univ	451-9019
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
106-8711	Elbow-Exhaust	383-3709
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
124-2726	Head	377-5855
131-3815	Seal Gp-Basic	325-6193
139-9177	Gasket Kit	377-7465
143-7356	Bearing As	380-1483
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361

Sales Model 950E (Cont'd.)

65R		
Original Part Number	**Part Name**	**Classic Part Number**
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687

65R		
Original Part Number	**Part Name**	**Classic Part Number**
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
176-9273	Piston	297-4860
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
234-8009	Kit-Gasket-Sch	382-5056
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6892

65R		
Original Part Number	**Part Name**	**Classic Part Number**
241-3381	Valve Kit-Cla	247-6893
250-6557	Liner Kit-Cla	295-6438
252-5650	Rim As	397-5067
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

6CC		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786

6CC		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1331	Stator-Converter	229-8237
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150

6CC		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

Sales Model 950E (Cont'd.)

6CC		
Original Part Number	**Part Name**	**Classic Part Number**
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5539	Core As-Rad	374-7492
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666
3H-8726	Mount As	385-7208
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4D-2619	Bearing	417-4494
4E-3456	Lever As	367-6081
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4F-2041	Cup-Roller Brg	418-9609
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007

6CC		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7105	Pin As	361-1699
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720

6CC		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8674	Bearing-Sleeve	307-1529
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5M-0578	Bearing	419-7775
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945
5V-1530	Link As	374-1463
5V-1882	Pin As	361-1700
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2396	Cartridge Gp	422-8122
6E-4892	Cyl Gp-089 478 Y	394-9828
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475

Sales Model 950E (Cont'd.)

6CC		
Original Part Number	Part Name	Classic Part Number
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-8895	Cap	374-6500
6K-8897	Bracket As	299-1977
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6W-5119	Housing-Support	450-8051
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816

6CC		
Original Part Number	Part Name	Classic Part Number
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7T-2036	Cap As-Fuel	361-1721
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

6CC		
Original Part Number	Part Name	Classic Part Number
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-4445	Pipe-Exhaust Ext	386-3061
8N-5305	Spacer	363-7464
8N-5387	Elbow-Exh Ext	373-1908
8N-5388	Muffler As	360-7895
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-7659	Pin As	361-1702
9C-4096	Yoke-Bk Flange	369-9496
9C-6281	Tube As	398-2953
9C-8205	Gear-Bevel	319-8175

Sales Model 950E (Cont'd.)

6CC		
Original Part Number	**Part Name**	**Classic Part Number**
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9M-5477	Bearing-Sleeve	374-6517
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-9657	Bearing-Spl Ball	371-4308
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5173	Joint Gp-Univ	451-9019
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687

6CC		
Original Part Number	**Part Name**	**Classic Part Number**
9W-4950	Gear-Sun	281-1688
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
124-2726	Head	377-5855
131-3815	Seal Gp-Basic	325-6193
143-7356	Bearing As	380-1483
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

6CC		
Original Part Number	**Part Name**	**Classic Part Number**
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
310-1899	Pin As	393-0932
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

7AB		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3922	Cup-Roller Brg	416-2158
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087

7AB		
Original Part Number	**Part Name**	**Classic Part Number**
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

7AB		
Original Part Number	**Part Name**	**Classic Part Number**
1P-5480	Cover As.-End	299-1998
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1331	Stator-Converter	229-8237
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

Sales Model 950E (Cont'd.)

7AB		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382

7AB		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5539	Core As-Rad	374-7492
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-4704	Bearing-Sleeve	379-0185
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4F-2041	Cup-Roller Brg	418-9609
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988

7AB		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9384	Line As-Fuel Inj	279-4989
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-1893	Cartridge Gp	422-8110
4T-9311	Housing	396-0652
4V-2518	Shaft	297-7243
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5M-0578	Bearing	419-7775
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110

Sales Model 950E (Cont'd.)

7AB		
Original Part Number	**Part Name**	**Classic Part Number**
5V-4573	Disc	388-0591
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2396	Cartridge Gp	422-8122
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-2202	Bearing-Spl Ball	380-1574
6W-5119	Housing-Support	450-8051
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697

7AB		
Original Part Number	**Part Name**	**Classic Part Number**
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

7AB		
Original Part Number	**Part Name**	**Classic Part Number**
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5388	Muffler As	360-7895
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
9C-4096	Yoke-Bk Flange	369-9496
9C-8205	Gear-Bevel	319-8175
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686

Sales Model 950E (Cont'd.)

7AB		
Original Part Number	Part Name	Classic Part Number
9G-9764	Yoke As	319-3478
9M-5477	Bearing-Sleeve	374-6517
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-9657	Bearing-Spl Ball	371-4308
9V-5173	Joint Gp-Univ	451-9019
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160

7AB		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

7AB		
Original Part Number	Part Name	Classic Part Number
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model 950F

2LM		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1053	Turbine As-Conv	377-7412
1T-1331	Stator-Converter	229-8237

2LM		
Original Part Number	Part Name	Classic Part Number
1T-1940	Housing As	396-0646
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-5539	Core As-Rad	374-7492
2W-7213	Bearing-Sleeve	419-4667

2LM		
Original Part Number	Part Name	Classic Part Number
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666
3G-9891	Pump Gp-Gr A	399-8541
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4D-0487	Valve As-Check	375-4334
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3197	Pin As	374-6507
4E-5213	Cover As	299-2000

Sales Model 950F (Cont'd.)

2LM		
Original Part Number	**Part Name**	**Classic Part Number**
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4K-7270	Support-Trunnion	373-5384
4K-7463	Seal-Lip Type	472-8007
4P-0893	Core As-Radiator	376-9057
4P-5433	Compressor As	419-4728
4P-5435	Compressor As	396-9942
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
5G-3612	Cap Gp-Protn	295-6419
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945
5V-1530	Link As	374-1463
5V-1882	Pin As	361-1700
6C-0570	Pump Gp-Mtrg Bsc	374-5380

2LM		
Original Part Number	**Part Name**	**Classic Part Number**
6E-2396	Cartridge Gp	422-8122
6E-4892	Cyl Gp-089 478 Y	394-9828
6I-1099	Manifold-Exh	424-6366
6I-3662	Muffler As	360-7882
6L-7751	Rod End-Spher	472-8015
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-3651	Pump Gp-Gr 1 Bsc	345-1978
6V-2202	Bearing-Spl Ball	380-1574
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-2944	Muffler As	360-7888
7E-3455	Tube As	374-4721
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691

2LM		
Original Part Number	**Part Name**	**Classic Part Number**
7G-4281	Housing As-Spt	297-7201
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7M-7219	Bearing-Thrust	384-4816
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-2036	Cap As-Fuel	361-1721
7T-3343	Plate-Clutch	297-7231
7V-5645	Rod-Indicator	397-5061
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8E-4954	Housing As-Cl	391-9823
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8P-3563	Cage-Bearing	451-0747
8R-4568	Piston	385-6108
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-7659	Pin As	361-1702
9C-4096	Yoke-Bk Flange	369-9496
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-5842	Gear-Transfer	394-0913
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9N-4460	Housing As-Cl	297-7203

Sales Model 950F (Cont'd.)

2LM		
Original Part Number	**Part Name**	**Classic Part Number**
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381

2LM		
Original Part Number	**Part Name**	**Classic Part Number**
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
123-3472	Pump Gp-Gr 1 Bsc	345-1978
124-2726	Head	377-5855
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
127-5537	Core As-Oclr	325-6045
136-0819	Valve-Exhaust	384-8697
139-9177	Gasket Kit	377-7465
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381

2LM		
Original Part Number	**Part Name**	**Classic Part Number**
163-1387	Gear-Flywheel	374-4697
176-9273	Piston	297-4860
207-2015	Gasket Kit	447-0828
207-2016	Gasket Kit	434-7284
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
216-5359	Kit-Dt Gasket	451-1504
216-7957	U-Joint	367-6069
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
237-2859	Bearing-Rlr	368-0125
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
300-9500	Kit-Gasket-Sch	387-2914
310-1899	Pin As	393-0932
345-1976	Pump-Gr-Cla	345-1978
352-2153	Pump As-Water	433-0444
460-5395	Kit-Gasket (Sch)	436-8395

2XK		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
2D-9454	Cup-Roller Brg	415-1914

2XK		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
6Y-2539	Cone-Roller Brg	464-4050

2XK		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-2540	Cup-Roller Brg	434-8985
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605

4DJ		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-0737	Race-Spl Thrust	384-4798

4DJ		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0767	Bearing-Sleeve	383-2108
1T-1053	Turbine As-Conv	377-7412
1T-1331	Stator-Converter	229-8237
1T-1940	Housing As	396-0646
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847

4DJ		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-5065	Cone-Roller Brg	416-2157

Sales Model 950F (Cont'd.)

4DJ		
Original Part Number	**Part Name**	**Classic Part Number**
2K-8753	Pinion-Bevel	253-1432
2L-5271	Bearing-Ball	371-4305
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2V-5608	Shaft-Pin (Bevel)	446-3056
2V-7990	Tube As	373-5382
2W-5539	Core As-Rad	374-7492
2W-7213	Bearing-Sleeve	419-4667
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3G-9891	Pump Gp-Gr A	399-8541
3H-1996	Bearing-Ball	380-1498
3K-2511	Dowel-Reaction	383-2126
3T-2094	Bearing-Sleeve	388-0638
3T-4384	Housing As-Cl	435-2573
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3197	Pin As	374-6507
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4K-7270	Support-Trunnion	373-5384
4K-7463	Seal-Lip Type	472-8007
4P-0893	Core As-Radiator	376-9057
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-5435	Compressor As	396-9942
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217

4DJ		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9943	Seal-End Tank	385-7216
4T-0231	Retainer	376-3641
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5L-2031	Cup-Roller Brg	384-5927
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945

4DJ		
Original Part Number	**Part Name**	**Classic Part Number**
5V-1530	Link As	374-1463
5V-1882	Pin As	361-1700
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2396	Cartridge Gp	422-8122
6E-4892	Cyl Gp-089 478 Y	394-9828
6I-1099	Manifold-Exh	424-6366
6I-3662	Muffler As	360-7882
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7704	Carrier-Ring	314-8658
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6S-3457	Pin	325-6147
6T-3651	Pump Gp-Gr 1 Bsc	345-1978
6T-5383	Gear-Ring	375-2624
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7C-1371	Coupling-Exhaust	369-9490
7C-3729	Pulley	376-9066

Sales Model 950F (Cont'd.)

4DJ		
Original Part Number	Part Name	Classic Part Number
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-2944	Muffler As	360-7888
7E-3455	Tube As	374-4721
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7G-2830	Ring-Seal	295-6441
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-5618	Manifold As	283-5204
7G-6062	Gear-Ring	302-2678
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-1309	Bearing-Aligning	360-2275
7J-9884	Bearing-Sleeve	325-6016
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7S-4411	Cap As-Rain	373-1912
7S-4534	Bearing-Caged	417-9497
7T-2036	Cap As-Fuel	361-1721
7T-3370	Yoke As	302-2702

4DJ		
Original Part Number	Part Name	Classic Part Number
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-5645	Rod-Indicator	397-5061
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8E-4954	Housing As-Cl	391-9823
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8E-7569	Case-Xmsn	394-0899
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-3563	Cage-Bearing	451-0747
8P-9507	Piston-Clutch	283-5212
8R-4568	Piston	385-6108
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-7659	Pin As	361-1702
9C-4096	Yoke-Bk Flange	369-9496
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216

4DJ		
Original Part Number	Part Name	Classic Part Number
9G-0290	Hub-Clutch	283-5217
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-5842	Gear-Transfer	394-0913
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9J-3206	Bearing-Spher	360-2275
9L-2685	Rod End	419-1866
9M-1328	Bearing-Aligning	325-6018
9M-6692	Strip	386-4934
9N-4460	Housing As-Cl	297-7203
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-5729	Cyl Gp-0038 0158	422-2486
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5173	Joint Gp-Univ	451-9019
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163

Sales Model 950F (Cont'd.)

4DJ		
Original Part Number	Part Name	Classic Part Number
9W-0517	Carrier-Planet	281-1686
9W-3605	Carrier-Ring	314-8662
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
111-1757	Gasket Kit - Sch	436-8395
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
113-6200	Gasket	438-2020
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219

4DJ		
Original Part Number	Part Name	Classic Part Number
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
119-5727	Bearing-Spl Ball	417-9491
121-7746	Pre-Cleaner As	360-2311
123-3472	Pump Gp-Gr 1 Bsc	345-1978
124-2726	Head	377-5855
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
127-5537	Core As-Oclr	325-6045
136-0819	Valve-Exhaust	384-8697
139-9177	Gasket Kit	377-7465
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
163-1387	Gear-Flywheel	374-4697
176-9273	Piston	297-4860
206-6405	Bearing-Spl Ball	420-2503
207-2015	Gasket Kit	447-0828
207-2016	Gasket Kit	434-7284
212-4893	Bearing-Thrust	419-6372

4DJ		
Original Part Number	Part Name	Classic Part Number
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
216-5359	Kit-Dt Gasket	451-1504
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
237-2859	Bearing-Rlr	368-0125
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
300-9500	Kit-Gasket-Sch	387-2914
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
345-1976	Pump-Gr-Cla	345-1978
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789
460-5395	Kit-Gasket (Sch)	436-8395

5PJ		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1053	Turbine As-Conv	377-7412
1T-1331	Stator-Converter	229-8237
1T-1940	Housing As	396-0646

5PJ		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2L-5271	Bearing-Ball	371-4305
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487

5PJ		
Original Part Number	Part Name	Classic Part Number
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4K-7270	Support-Trunnion	373-5384
4K-7463	Seal-Lip Type	472-8007
4P-0893	Core As-Radiator	376-9057
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216

Sales Model 950F (Cont'd.)

5PJ		
Original Part Number	Part Name	Classic Part Number
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1530	Link As	374-1463
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2396	Cartridge Gp	422-8122
6I-1099	Manifold-Exh	424-6366
6I-3662	Muffler As	360-7882
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-3651	Pump Gp-Gr 1 Bsc	345-1978
6V-2202	Bearing-Spl Ball	380-1574
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466

5PJ		
Original Part Number	Part Name	Classic Part Number
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7M-7219	Bearing-Thrust	384-4816
7S-4534	Bearing-Caged	417-9497
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8E-4954	Housing As-Cl	391-9823
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8P-3563	Cage-Bearing	451-0747
8R-4568	Piston	385-6108
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
9C-4096	Yoke-Bk Flange	369-9496
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-5842	Gear-Transfer	394-0913
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9N-4460	Housing As-Cl	297-7203
9U-9657	Bearing-Spl Ball	371-4308
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688

5PJ		
Original Part Number	Part Name	Classic Part Number
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
123-3472	Pump Gp-Gr 1 Bsc	345-1978
126-5875	Flywheel As.	374-4694
127-5537	Core As-Oclr	325-6045
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
163-1387	Gear-Flywheel	374-4697
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
237-2859	Bearing-Rlr	368-0125
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
345-1976	Pump-Gr-Cla	345-1978

Sales Model 950F (Cont'd.)

5SK		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1P-7115	Mount As	418-1936
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1051	Impeller-Conv	388-6598
1T-1053	Turbine As-Conv	377-7412
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1331	Stator-Converter	229-8237
1T-1428	Retainer-Brg	300-2587
1T-1647	Impeller-Conv	377-7415
1T-1691	Impeller-Conv	297-4863
1T-1940	Housing As	396-0646
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904

5SK		
Original Part Number	**Part Name**	**Classic Part Number**
2V-0707	Bearing-Sleeve	360-2328
2V-7990	Tube As	373-5382
2W-5539	Core As-Rad	374-7492
2W-7213	Bearing-Sleeve	419-4667
3E-3339	Gasket Kit	393-3614
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666
3G-9891	Pump Gp-Gr A	399-8541
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3197	Pin As	374-6507
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4J-0121	Cap-Bearing	360-2344
4K-7270	Support-Trunnion	373-5384
4K-7463	Seal-Lip Type	472-8007
4P-0893	Core As-Radiator	376-9057
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-5435	Compressor As	396-9942
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243

5SK		
Original Part Number	**Part Name**	**Classic Part Number**
4V-2883	Bearing-Sleeve	379-0193
4V-3680	Bellcrank	308-9802
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
5D-0470	Valve Gp-Qrel	314-8549
5G-3612	Cap Gp-Protn	295-6419
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5T-1362	Univ Joint As-5C	325-6011
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945
5V-1530	Link As	374-1463
5V-1882	Pin As	361-1700
5V-6327	Yoke-Flange Bk	391-1086
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2396	Cartridge Gp	422-8122
6E-4892	Cyl Gp-089 478 Y	394-9828
6I-1099	Manifold-Exh	424-6366
6I-3662	Muffler As	360-7882
6J-6043	Bearing-Sleeve	374-1456

Sales Model 950F (Cont'd.)

5SK		
Original Part Number	Part Name	Classic Part Number
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-1705	Shaft-Pump Drive	283-5201
6T-3651	Pump Gp-Gr 1 Bsc	345-1978
6T-5383	Gear-Ring	375-2624
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6V-5413	Gasket Kit	390-5291
6V-5414	Gasket Kit	434-7289
6Y-1690	Carrier-Ring	384-3849
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-2944	Muffler As	360-7888

5SK		
Original Part Number	Part Name	Classic Part Number
7E-3455	Tube As	374-4721
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-5131	Trunnion	296-1371
7J-8893	Cone-Roller Brg	374-1846
7K-9639	Bearing-Sleeve	314-8643
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-2036	Cap As-Fuel	361-1721
7T-3343	Plate-Clutch	297-7231
7T-4754	Impeller-Conv	385-7231
7V-5645	Rod-Indicator	397-5061
7V-6715	Pin As	361-1701
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8E-4954	Housing As-Cl	391-9823
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8P-0953	Turbine-Conv	297-7269
8P-3563	Cage-Bearing	451-0747

5SK		
Original Part Number	Part Name	Classic Part Number
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8R-4568	Piston	385-6108
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-7659	Pin As	361-1702
9C-4096	Yoke-Bk Flange	369-9496
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-5842	Gear-Transfer	394-0913
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9J-5875	Bearing-Sleeve	308-9830
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3289	Pin As	382-6904
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5173	Joint Gp-Univ	451-9019
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163

Sales Model 950F (Cont'd.)

5SK		
Original Part Number	**Part Name**	**Classic Part Number**
9V-8693	Actuator Gp-Bk	375-2629
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
101-1530	Bearing-Main	419-6382
101-7689	Yoke As	422-7245
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
119-5727	Bearing-Spl Ball	417-9491

5SK		
Original Part Number	**Part Name**	**Classic Part Number**
121-7746	Pre-Cleaner As	360-2311
123-3472	Pump Gp-Gr 1 Bsc	345-1978
124-2726	Head	377-5855
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
127-5537	Core As-Oclr	325-6045
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
136-7813	Bearing-Race	460-8296
139-9177	Gasket Kit	377-7465
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-6749	Shaft As-Input	433-9211
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
163-1387	Gear-Flywheel	374-4697
176-9273	Piston	297-4860
206-6405	Bearing-Spl Ball	420-2503
207-2015	Gasket Kit	447-0828
207-2016	Gasket Kit	434-7284
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370

5SK		
Original Part Number	**Part Name**	**Classic Part Number**
213-3193	Rod As-Conn	379-8870
216-5359	Kit-Dt Gasket	451-1504
216-7957	U-Joint	367-6069
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
237-2859	Bearing-Rlr	368-0125
264-6898	Kit-Gasket-Sch	382-5069
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
300-9500	Kit-Gasket-Sch	387-2914
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932
318-9013	Kit-Gasket (Sch)	437-8128
321-5714	Piston-Clutch	281-1693
345-1976	Pump-Gr-Cla	345-1978
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789
460-5395	Kit-Gasket (Sch)	436-8395

5SL		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
2D-9454	Cup-Roller Brg	415-1914

5SL		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
6Y-2539	Cone-Roller Brg	464-4050

6LJ		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347

5SL		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-2540	Cup-Roller Brg	434-8985
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605

Sales Model 950F (Cont'd.)

6LJ		
Original Part Number	Part Name	Classic Part Number
1J-4757	Cone-Bearing	374-1840
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

6LJ		
Original Part Number	Part Name	Classic Part Number
2P-1373	Cup-Rlr Brg	382-5075
6Y-2539	Cone-Roller Brg	464-4050

6LJ		
Original Part Number	Part Name	Classic Part Number
6Y-2540	Cup-Roller Brg	434-8985
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605

6LL		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1053	Turbine As-Conv	377-7412
1T-1331	Stator-Converter	229-8237
1T-1940	Housing As	396-0646
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2L-5271	Bearing-Ball	371-4305
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4K-7270	Support-Trunnion	373-5384
4K-7463	Seal-Lip Type	472-8007
4P-0893	Core As-Radiator	376-9057
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217

6LL		
Original Part Number	Part Name	Classic Part Number
4P-9943	Seal-End Tank	385-7216
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1530	Link As	374-1463
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2396	Cartridge Gp	422-8122
6I-1099	Manifold-Exh	424-6366
6I-3662	Muffler As	360-7882
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-3651	Pump Gp-Gr 1 Bsc	345-1978
6V-2202	Bearing-Spl Ball	380-1574
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

6LL		
Original Part Number	Part Name	Classic Part Number
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7M-7219	Bearing-Thrust	384-4816
7S-4534	Bearing-Caged	417-9497
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8E-4954	Housing As-Cl	391-9823
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8P-3563	Cage-Bearing	451-0747
8R-4568	Piston	385-6108
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
9C-4096	Yoke-Bk Flange	369-9496
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620

Sales Model 950F (Cont'd.)

6LL		
Original Part Number	**Part Name**	**Classic Part Number**
9G-1491	Carrier-Planet	281-1685
9G-5842	Gear-Transfer	394-0913
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9N-4460	Housing As-Cl	297-7203
9U-9657	Bearing-Spl Ball	371-4308
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382

6LL		
Original Part Number	**Part Name**	**Classic Part Number**
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
123-3472	Pump Gp-Gr 1 Bsc	345-1978
126-5875	Flywheel As.	374-4694
127-5537	Core As-Oclr	325-6045
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696

6LL		
Original Part Number	**Part Name**	**Classic Part Number**
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
163-1387	Gear-Flywheel	374-4697
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
237-2859	Bearing-Rlr	368-0125
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
345-1976	Pump-Gr-Cla	345-1978

6YG		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-5480	Cover As.-End	299-1998
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294

6YG		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1053	Turbine As-Conv	377-7412
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1331	Stator-Converter	229-8237
1T-1940	Housing As	396-0646
1U-2667	Cartridge Gp	422-8116
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716

6YG		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

Sales Model 950F (Cont'd.)

6YG		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5539	Core As-Rad	374-7492
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692

6YG		
Original Part Number	Part Name	Classic Part Number
3E-3339	Gasket Kit	393-3614
3G-2665	Cover	308-9842
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666
3G-9891	Pump Gp-Gr A	399-8541
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3197	Pin As	374-6507
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4E-8535	Retainer-Seal	300-2589
4E-9658	Joint Gp-Slip	452-9553
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7270	Support-Trunnion	373-5384
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-0893	Core As-Radiator	376-9057

6YG		
Original Part Number	Part Name	Classic Part Number
4P-0897	Core As-Radiator	376-9058
4P-3546	Valve As-Relief	325-6236
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-5435	Compressor As	396-9942
4P-6548	Muffler As	360-7878
4P-6589	Pipe As	382-6898
4P-7051	Pulley-Alt	376-9064
4P-7688	Valve As-Check	420-6216
4P-7790	Shaft As-Arm	457-4596
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8577	Rod As-Injector	455-5513
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8472	Hood As-Preclnr	296-1355
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652

Sales Model 950F (Cont'd.)

6YG		
Original Part Number	**Part Name**	**Classic Part Number**
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-2883	Bearing-Sleeve	379-0193
4V-3680	Bellcrank	308-9802
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5392	Spider	377-7430
4V-7082	Joint Gp-Slip	367-6068
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920

6YG		
Original Part Number	**Part Name**	**Classic Part Number**
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945
5V-1530	Link As	374-1463
5V-1882	Pin As	361-1700
5V-6327	Yoke-Flange Bk	391-1086
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3617	Support-Trunnion	374-4712
6E-0775	Head	425-9373
6E-2387	Cartridge Gp	422-8132
6E-2396	Cartridge Gp	422-8122
6E-4892	Cyl Gp-089 478 Y	394-9828
6E-5028	Rod As	425-9372
6H-3957	Bearing-Ball	311-9358
6I-1099	Manifold-Exh	424-6366
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-3662	Muffler As	360-7882
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-6043	Bearing-Sleeve	374-1456
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015

6YG		
Original Part Number	**Part Name**	**Classic Part Number**
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7704	Carrier-Ring	314-8658
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-1705	Shaft-Pump Drive	283-5201
6T-3651	Pump Gp-Gr 1 Bsc	345-1978
6T-5383	Gear-Ring	375-2624
6V-0538	Bearing-Spl Ball	398-2935
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6V-5414	Gasket Kit	434-7289
6V-5976	Kit-Gasket (Rs)	393-5200
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-1690	Carrier-Ring	384-3849
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7C-1371	Coupling-Exhaust	369-9490
7C-2880	Bell As-Suction	380-1520
7C-3760	Tube As-O Drain	375-5443

Sales Model 950F (Cont'd.)

6YG		
Original Part Number	Part Name	Classic Part Number
7C-3862	Camshaft	458-0151
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-2944	Muffler As	360-7888
7E-3455	Tube As	374-4721
7E-3509	Pipe As-Ex Ext	373-1907
7E-3557	Spider As-Fan	430-4471
7E-5085	Bushing	377-5829
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7G-2830	Ring-Seal	295-6441
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-5618	Manifold As	283-5204
7G-6062	Gear-Ring	302-2678
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-9639	Bearing-Sleeve	314-8643

6YG		
Original Part Number	Part Name	Classic Part Number
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-2036	Cap As-Fuel	361-1721
7T-3343	Plate-Clutch	297-7231
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-5645	Rod-Indicator	397-5061
7V-6715	Pin As	361-1701
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-5699	Pulley-Cshaft	378-3988
7W-7546	Gasket-Plate	433-8187
7W-8064	Valve-Inlet	384-8705
7W-9020	Bell As-Pump Suc	378-3989
7W-9027	Base-Oil Cooler	399-8545

6YG		
Original Part Number	Part Name	Classic Part Number
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8E-4954	Housing As-Cl	391-9823
8E-7569	Case-Xmsn	394-0899
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5387	Elbow-Exh Ext	373-1908
8N-5388	Muffler As	360-7895
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290

Sales Model 950F (Cont'd.)

6YG		
Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-3563	Cage-Bearing	451-0747
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-0931	Housing-Pinion	302-4300
8R-0942	Plate-Reaction	380-1484
8R-1015	Support-Trunnion	374-4712
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-3252	Shaft-Planet	297-7259
8R-4568	Piston	385-6108
8R-6213	Mount As	389-6301
8R-8335	Gear-Bevel	368-0105
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372

6YG		
Original Part Number	Part Name	Classic Part Number
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-7659	Pin As	361-1702
9C-4080	Yoke-Brake	302-2703
9C-4096	Yoke-Bk Flange	369-9496
9C-6029	Bearing-Planet	375-9982
9C-8418	Plate-Reaction	385-6129
9C-8669	Shaft-Bev Pinion	368-0107
9C-9191	Trunnion	302-2701
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-2413	Shaft-Output	297-7255
9G-5842	Gear-Transfer	394-0913
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9J-5875	Bearing-Sleeve	308-9830
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9N-4460	Housing As-Cl	297-7203

6YG		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-2787	Gear-Planet	367-6093
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3289	Pin As	382-6904
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5173	Joint Gp-Univ	451-9019
9V-5174	Joint Gp-Univ	375-2628
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6526	Ring-Retaining	422-2485
9V-8693	Actuator Gp-Bk	375-2629
9W-0517	Carrier-Planet	281-1686
9W-3605	Carrier-Ring	314-8662
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688

Sales Model 950F (Cont'd.)

6YG		
Original Part Number	Part Name	Classic Part Number
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-3318	Core As-Radiator	374-7491
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2941	Gasket Kit	393-1020
100-3596	Piston	380-1511
100-3597	Plate-Reaction	380-1501
100-6267	Plate As-Idler	375-9983
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382
101-8740	Muffler As	360-7878
102-8636	Gear-Drive	472-8035
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
108-5680	Gage-Oil Level	378-4001
110-1337	Ring Kit-Pstn	377-5834
110-1488	Gear-Ring	394-0882
111-1757	Gasket Kit - Sch	436-8395
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
113-6200	Gasket	438-2020
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
119-5727	Bearing-Spl Ball	417-9491

6YG		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
123-3472	Pump Gp-Gr 1 Bsc	345-1978
124-2726	Head	377-5855
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
136-0819	Valve-Exhaust	384-8697
136-7813	Bearing-Race	460-8296
139-9177	Gasket Kit	377-7465
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-6749	Shaft As-Input	433-9211
148-7455	Valve - Exhaust	270-4361
148-9288	Case As-Diff	380-1496
151-4836	Diff Gp -A	416-2120
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
160-1400	Yoke (1710)	319-3479
163-1387	Gear-Flywheel	374-4697
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484

6YG		
Original Part Number	Part Name	Classic Part Number
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
176-9273	Piston	297-4860
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
207-2015	Gasket Kit	447-0828
207-2016	Gasket Kit	434-7284
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
216-5359	Kit-Dt Gasket	451-1504
216-7957	U-Joint	367-6069
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
228-0419	Seal As	443-3571
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
264-6898	Kit-Gasket-Sch	382-5069
266-5907	Kit-Gasket-Cl	438-0155
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351

Sales Model 950F (Cont'd.)

6YG		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4356
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932

6YG		
Original Part Number	**Part Name**	**Classic Part Number**
310-8658	Pin As	425-1526
318-9013	Kit-Gasket (Sch)	437-8128
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-1032	Disc-Friction	440-3116
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
345-1976	Pump-Gr-Cla	345-1978

6YG		
Original Part Number	**Part Name**	**Classic Part Number**
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789
360-7863	Muffler-Cla	360-7878
391-8229	Kit-Gasket-Fs	398-2955
460-5395	Kit-Gasket (Sch)	436-8395

7ZF		
Original Part Number	**Part Name**	**Classic Part Number**
1A-2846	Cap As-Filler	311-9368
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1P-7115	Mount As	418-1936
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1051	Impeller-Conv	388-6598
1T-1053	Turbine As-Conv	377-7412
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1331	Stator-Converter	229-8237
1T-1428	Retainer-Brg	300-2587
1T-1647	Impeller-Conv	377-7415
1T-1691	Impeller-Conv	297-4863
1T-1940	Housing As	396-0646
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482

7ZF		
Original Part Number	**Part Name**	**Classic Part Number**
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2S-7931	Bearing-Sleeve	387-2904
2V-0707	Bearing-Sleeve	360-2328
2V-7990	Tube As	373-5382
2W-5539	Core As-Rad	374-7492
2W-7213	Bearing-Sleeve	419-4667
3E-3339	Gasket Kit	393-3614
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666
3G-9891	Pump Gp-Gr A	399-8541
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494

7ZF		
Original Part Number	**Part Name**	**Classic Part Number**
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3197	Pin As	374-6507
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4J-0121	Cap-Bearing	360-2344
4K-7270	Support-Trunnion	373-5384
4K-7463	Seal-Lip Type	472-8007
4P-0893	Core As-Radiator	376-9057
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-5435	Compressor As	396-9942
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-2883	Bearing-Sleeve	379-0193
4V-3680	Bellcrank	308-9802
4V-5099	Cover	418-1929

Sales Model 950F (Cont'd.)

7ZF		
Original Part Number	Part Name	Classic Part Number
4V-5100	Support-Trunnion	299-2068
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
5D-0470	Valve Gp-Qrel	314-8549
5G-3612	Cap Gp-Protn	295-6419
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5167	Race-Brg Outer	417-4529
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5T-1362	Univ Joint As-5C	325-6011
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945
5V-1530	Link As	374-1463
5V-1882	Pin As	361-1700
5V-6327	Yoke-Flange Bk	391-1086
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2396	Cartridge Gp	422-8122
6E-4892	Cyl Gp-089 478 Y	394-9828
6I-1099	Manifold-Exh	424-6366
6I-3662	Muffler As	360-7882
6J-6043	Bearing-Sleeve	374-1456
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6P-0593	Bearing-Roller	386-4959

7ZF		
Original Part Number	Part Name	Classic Part Number
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-1705	Shaft-Pump Drive	283-5201
6T-3651	Pump Gp-Gr 1 Bsc	345-1978
6T-5383	Gear-Ring	375-2624
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6V-5413	Gasket Kit	390-5291
6V-5414	Gasket Kit	434-7289
6Y-1690	Carrier-Ring	384-3849
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-2944	Muffler As	360-7888
7E-3455	Tube As	374-4721
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449

7ZF		
Original Part Number	Part Name	Classic Part Number
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-5131	Trunnion	296-1371
7J-8893	Cone-Roller Brg	374-1846
7K-9639	Bearing-Sleeve	314-8643
7M-7219	Bearing-Thrust	384-4816
7N-1164	Mount As	295-5451
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-2036	Cap As-Fuel	361-1721
7T-3343	Plate-Clutch	297-7231
7T-4754	Impeller-Conv	385-7231
7V-5645	Rod-Indicator	397-5061
7V-6715	Pin As	361-1701
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8E-4954	Housing As-Cl	391-9823
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8P-0953	Turbine-Conv	297-7269
8P-3563	Cage-Bearing	451-0747
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205

Sales Model 950F (Cont'd.)

7ZF		
Original Part Number	**Part Name**	**Classic Part Number**
8R-4568	Piston	385-6108
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-7659	Pin As	361-1702
9C-4096	Yoke-Bk Flange	369-9496
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-5842	Gear-Transfer	394-0913
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9J-5875	Bearing-Sleeve	308-9830
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3289	Pin As	382-6904
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5173	Joint Gp-Univ	451-9019
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-8693	Actuator Gp-Bk	375-2629
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687

7ZF		
Original Part Number	**Part Name**	**Classic Part Number**
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
101-1530	Bearing-Main	419-6382
101-7689	Yoke As	422-7245
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
119-5727	Bearing-Spl Ball	417-9491
121-7746	Pre-Cleaner As	360-2311
123-3472	Pump Gp-Gr 1 Bsc	345-1978
124-2726	Head	377-5855
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
127-5537	Core As-Oclr	325-6045
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
136-7813	Bearing-Race	460-8296
139-9177	Gasket Kit	377-7465
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-6749	Shaft As-Input	433-9211

7ZF		
Original Part Number	**Part Name**	**Classic Part Number**
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
163-1387	Gear-Flywheel	374-4697
176-9273	Piston	297-4860
206-6405	Bearing-Spl Ball	420-2503
207-2015	Gasket Kit	447-0828
207-2016	Gasket Kit	434-7284
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
216-5359	Kit-Dt Gasket	451-1504
216-7957	U-Joint	367-6069
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
237-2859	Bearing-Rlr	368-0125
264-6898	Kit-Gasket-Sch	382-5069
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
300-9500	Kit-Gasket-Sch	387-2914
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932
318-9013	Kit-Gasket (Sch)	437-8128
321-5714	Piston-Clutch	281-1693
345-1976	Pump-Gr-Cla	345-1978
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789
460-5395	Kit-Gasket (Sch)	436-8395

Sales Model 950F (Cont'd.)

8TK		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-5480	Cover As.-End	299-1998
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1053	Turbine As-Conv	377-7412
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1331	Stator-Converter	229-8237
1T-1940	Housing As	396-0646
1U-2667	Cartridge Gp	422-8116
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006

8TK		
Original Part Number	Part Name	Classic Part Number
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2788	Adapter-Fan	390-0984

8TK		
Original Part Number	Part Name	Classic Part Number
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5539	Core As-Rad	374-7492
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3E-3339	Gasket Kit	393-3614
3G-2665	Cover	308-9842
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666
3G-9891	Pump Gp-Gr A	399-8541
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494

Sales Model 950F (Cont'd.)

8TK		
Original Part Number	Part Name	Classic Part Number
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3197	Pin As	374-6507
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4E-8535	Retainer-Seal	300-2589
4E-9658	Joint Gp-Slip	452-9553
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7270	Support-Trunnion	373-5384
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4P-0893	Core As-Radiator	376-9057
4P-0897	Core As-Radiator	376-9058
4P-3546	Valve As-Relief	325-6236
4P-3683	Pump Gp-Water -B	374-7498
4P-5433	Compressor As	419-4728
4P-5435	Compressor As	396-9942
4P-6548	Muffler As	360-7878
4P-6589	Pipe As	382-6898
4P-7051	Pulley-Alt	376-9064
4P-7688	Valve As-Check	420-6216
4P-7790	Shaft As-Arm	457-4596
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8577	Rod As-Injector	455-5513
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984

8TK		
Original Part Number	Part Name	Classic Part Number
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8472	Hood As-Preclnr	296-1355
4T-1893	Cartridge Gp	422-8110
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-2883	Bearing-Sleeve	379-0193
4V-3680	Bellcrank	308-9802
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5392	Spider	377-7430
4V-7082	Joint Gp-Slip	367-6068
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882

8TK		
Original Part Number	Part Name	Classic Part Number
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945
5V-1530	Link As	374-1463
5V-1882	Pin As	361-1700
5V-6327	Yoke-Flange Bk	391-1086

Sales Model 950F (Cont'd.)

8TK		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3617	Support-Trunnion	374-4712
6E-0775	Head	425-9373
6E-2387	Cartridge Gp	422-8132
6E-2396	Cartridge Gp	422-8122
6E-4892	Cyl Gp-089 478 Y	394-9828
6E-5028	Rod As	425-9372
6H-3957	Bearing-Ball	311-9358
6I-1099	Manifold-Exh	424-6366
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-3662	Muffler As	360-7882
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6J-6043	Bearing-Sleeve	374-1456
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7704	Carrier-Ring	314-8658
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-1705	Shaft-Pump Drive	283-5201
6T-3651	Pump Gp-Gr 1 Bsc	345-1978
6T-5383	Gear-Ring	375-2624
6V-0538	Bearing-Spl Ball	398-2935
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574

8TK		
Original Part Number	Part Name	Classic Part Number
6V-4350	Race-Spl Rlr Brg	384-5933
6V-5414	Gasket Kit	434-7289
6V-5976	Kit-Gasket (Rs)	393-5200
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-1690	Carrier-Ring	384-3849
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7C-1371	Coupling-Exhaust	369-9490
7C-2880	Bell As-Suction	380-1520
7C-3760	Tube As-O Drain	375-5443
7C-3862	Camshaft	458-0151
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-2944	Muffler As	360-7888
7E-3455	Tube As	374-4721
7E-3509	Pipe As-Ex Ext	373-1907
7E-3557	Spider As-Fan	430-4471
7E-5085	Bushing	377-5829
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847

8TK		
Original Part Number	Part Name	Classic Part Number
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7G-2830	Ring-Seal	295-6441
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-5618	Manifold As	283-5204
7G-6062	Gear-Ring	302-2678
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-9639	Bearing-Sleeve	314-8643
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996

Sales Model 950F (Cont'd.)

8TK		
Original Part Number	**Part Name**	**Classic Part Number**
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-2036	Cap As-Fuel	361-1721
7T-3343	Plate-Clutch	297-7231
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-5645	Rod-Indicator	397-5061
7V-6715	Pin As	361-1701
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-5699	Pulley-Cshaft	378-3988
7W-7546	Gasket-Plate	433-8187
7W-8064	Valve-Inlet	384-8705
7W-9020	Bell As-Pump Suc	378-3989
7W-9027	Base-Oil Cooler	399-8545
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8E-4954	Housing As-Cl	391-9823
8E-7569	Case-Xmsn	394-0899
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1214	Mount As	325-6125

8TK		
Original Part Number	**Part Name**	**Classic Part Number**
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5387	Elbow-Exh Ext	373-1908
8N-5388	Muffler As	360-7895
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9402	Coupling	325-6048
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579

8TK		
Original Part Number	**Part Name**	**Classic Part Number**
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-3563	Cage-Bearing	451-0747
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-0931	Housing-Pinion	302-4300
8R-0942	Plate-Reaction	380-1484
8R-1015	Support-Trunnion	374-4712
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-3252	Shaft-Planet	297-7259
8R-4568	Piston	385-6108
8R-6213	Mount As	389-6301
8R-8335	Gear-Bevel	368-0105
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-7659	Pin As	361-1702
9C-4080	Yoke-Brake	302-2703
9C-4096	Yoke-Bk Flange	369-9496
9C-6029	Bearing-Planet	375-9982
9C-8418	Plate-Reaction	385-6129
9C-8669	Shaft-Bev Pinion	368-0107
9C-9191	Trunnion	302-2701
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1231	Plate	297-7232

Sales Model 950F (Cont'd.)

8TK		
Original Part Number	Part Name	Classic Part Number
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-2413	Shaft-Output	297-7255
9G-5842	Gear-Transfer	394-0913
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9J-5875	Bearing-Sleeve	308-9830
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124

8TK		
Original Part Number	Part Name	Classic Part Number
9S-8679	Chamber As	325-6042
9U-2787	Gear-Planet	367-6093
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3289	Pin As	382-6904
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5173	Joint Gp-Univ	451-9019
9V-5174	Joint Gp-Univ	375-2628
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6526	Ring-Retaining	422-2485
9V-8693	Actuator Gp-Bk	375-2629
9W-0517	Carrier-Planet	281-1686
9W-3605	Carrier-Ring	314-8662
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-3318	Core As-Radiator	374-7491
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2941	Gasket Kit	393-1020
100-3596	Piston	380-1511
100-3597	Plate-Reaction	380-1501
100-6267	Plate As-Idler	375-9983
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382

8TK		
Original Part Number	Part Name	Classic Part Number
101-8740	Muffler As	360-7878
102-8636	Gear-Drive	472-8035
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
108-5680	Gage-Oil Level	378-4001
110-1337	Ring Kit-Pstn	377-5834
110-1488	Gear-Ring	394-0882
111-1757	Gasket Kit - Sch	436-8395
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
113-6200	Gasket	438-2020
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
119-5727	Bearing-Spl Ball	417-9491
121-7746	Pre-Cleaner As	360-2311
123-3472	Pump Gp-Gr 1 Bsc	345-1978
124-2726	Head	377-5855
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
136-0819	Valve-Exhaust	384-8697
136-7813	Bearing-Race	460-8296
139-9177	Gasket Kit	377-7465
143-7356	Bearing As	380-1483
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-6749	Shaft As-Input	433-9211

Sales Model 950F (Cont'd.)

8TK		
Original Part Number	**Part Name**	**Classic Part Number**
148-7455	Valve - Exhaust	270-4361
148-9288	Case As-Diff	380-1496
151-4836	Diff Gp -A	416-2120
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
160-1400	Yoke (1710)	319-3479
163-1387	Gear-Flywheel	374-4697
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574

8TK		
Original Part Number	**Part Name**	**Classic Part Number**
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
176-9273	Piston	297-4860
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
207-2015	Gasket Kit	447-0828
207-2016	Gasket Kit	434-7284
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
216-5359	Kit-Dt Gasket	451-1504
216-7957	U-Joint	367-6069
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
228-0419	Seal As	443-3571
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
264-6898	Kit-Gasket-Sch	382-5069

8TK		
Original Part Number	**Part Name**	**Classic Part Number**
266-5907	Kit-Gasket-Cl	438-0155
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932
310-8658	Pin As	425-1526
318-9013	Kit-Gasket (Sch)	437-8128
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-1032	Disc-Friction	440-3116
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
345-1976	Pump-Gr-Cla	345-1978
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789
360-7863	Muffler-Cla	360-7878
391-8229	Kit-Gasket-Fs	398-2955
460-5395	Kit-Gasket (Sch)	436-8395

Sales Model 950G

2JS		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384

2JS		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

2JS		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667

Sales Model 950G (Cont'd.)

2JS		
Original Part Number	Part Name	Classic Part Number
3E-6772	Seal-Water	382-8017
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4N-0685	Bearing-Sleeve	379-0191
4N-6658	Bearing-Sleeve	373-1885
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9538	Bearing-Roller	421-8183
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6I-1099	Manifold-Exh	424-6366
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6N-1931	Plunger	379-0171
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133

2JS		
Original Part Number	Part Name	Classic Part Number
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-3831	Seal-O-Ring	436-2657
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-5996	Rod As-Conn	379-8864
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5733	Gasket	421-7333
8C-3111	Rod End-Spher	392-4523
8J-5778	Bearing-Sleeve	374-8359

2JS		
Original Part Number	Part Name	Classic Part Number
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
103-0887	Pulley-Idler	449-9546
105-1738	Manifold-Exhaust	374-4692
105-7535	Bearing-Dbl Row	417-9496
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-6675	Step As	419-0881
119-2940	Gasket	378-4002
124-2726	Head	377-5855
124-3237	Precleaner As	432-4220

Sales Model 950G (Cont'd.)

2JS		
Original Part Number	**Part Name**	**Classic Part Number**
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
128-1009	Muffler As	435-6047
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
131-7123	Bearing-Sleeve	422-6919
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

2JS		
Original Part Number	**Part Name**	**Classic Part Number**
152-3952	Impeller-Pump	374-4696
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
160-9874	Kit-Gasket-Scl	386-3048
166-9142	Gasket	420-8546
176-3900	Accumulator	416-5513
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371

2JS		
Original Part Number	**Part Name**	**Classic Part Number**
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
310-1899	Pin As	393-0932
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

3JW		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513

3JW		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5K-0983	Seal-Lip Type	472-8012
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9538	Bearing-Roller	421-8183
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6I-1099	Manifold-Exh	424-6366
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695

3JW		
Original Part Number	**Part Name**	**Classic Part Number**
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497

Sales Model 950G (Cont'd.)

3JW		
Original Part Number	Part Name	Classic Part Number
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-5131	Trunnion	296-1371
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8J-5778	Bearing-Sleeve	374-8359
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-4568	Piston	385-6108
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183

3JW		
Original Part Number	Part Name	Classic Part Number
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-6675	Step As	419-0881
119-2940	Gasket	378-4002
124-2726	Head	377-5855
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254

3JW		
Original Part Number	Part Name	Classic Part Number
128-1009	Muffler As	435-6047
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
162-4012	Gasket Kit - F	437-8126
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
239-4290	Kit-Gasket-Sch	435-2574
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

4BS		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384

4BS		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914

4BS		
Original Part Number	Part Name	Classic Part Number
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912

Sales Model 950G (Cont'd.)

4BS		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4J-0121	Cap-Bearing	360-2344
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9538	Bearing-Roller	421-8183
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6I-1099	Manifold-Exh	424-6366
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050

4BS		
Original Part Number	Part Name	Classic Part Number
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-5131	Trunnion	296-1371
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8J-5778	Bearing-Sleeve	374-8359
8R-1088	Bearing-Sleeve	419-0885

4BS		
Original Part Number	Part Name	Classic Part Number
8R-1465	Rim As	417-9501
8R-4568	Piston	385-6108
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-6675	Step As	419-0881
119-2940	Gasket	378-4002
124-2726	Head	377-5855
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566

Sales Model 950G (Cont'd.)

4BS		
Original Part Number	Part Name	Classic Part Number
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
127-3467	Manifold-Exhaust	394-9827
128-1009	Muffler As	435-6047
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

4BS		
Original Part Number	Part Name	Classic Part Number
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
164-4413	Mount	419-0876
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

4BS		
Original Part Number	Part Name	Classic Part Number
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

5FW		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596

5FW		
Original Part Number	Part Name	Classic Part Number
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9538	Bearing-Roller	421-8183
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6I-1099	Manifold-Exh	424-6366
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691

5FW		
Original Part Number	Part Name	Classic Part Number
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692

Sales Model 950G (Cont'd.)

5FW		
Original Part Number	Part Name	Classic Part Number
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8J-5778	Bearing-Sleeve	374-8359
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
103-0887	Pulley-Idler	449-9546

5FW		
Original Part Number	Part Name	Classic Part Number
105-1738	Manifold-Exhaust	374-4692
105-7535	Bearing-Dbl Row	417-9496
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-6675	Step As	419-0881
119-2940	Gasket	378-4002
124-2726	Head	377-5855
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
128-1009	Muffler As	435-6047
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
176-3900	Accumulator	416-5513
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
310-1899	Pin As	393-0932
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444

5FW		
Original Part Number	Part Name	Classic Part Number
352-2160	Pump Gp-Water -B	433-0789
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-8629	Bearing-Sleeve	379-0194
4V-8643	Bearing-Sleeve	374-8354
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187

Sales Model 950G (Cont'd.)

5FW		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9538	Bearing-Roller	421-8183
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6I-1099	Manifold-Exh	424-6366
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580

5FW		
Original Part Number	Part Name	Classic Part Number
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-1309	Bearing-Aligning	360-2275
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-7659	Pin As	361-1702
8Y-7186	Link As	399-8584
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9T-5729	Cyl Gp-0038 0158	422-2486
9V-0247	Plate	417-4527
9V-4975	Bearing-Sleeve	384-4784
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926

5FW		
Original Part Number	Part Name	Classic Part Number
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-6675	Step As	419-0881
119-2940	Gasket	378-4002
124-2726	Head	377-5855
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
128-1009	Muffler As	435-6047
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

Sales Model 950G (Cont'd.)

5FW		
Original Part Number	**Part Name**	**Classic Part Number**
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

5FW		
Original Part Number	**Part Name**	**Classic Part Number**
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932
352-2151	Pump Gp-Water -B	434-6107

5FW		
Original Part Number	**Part Name**	**Classic Part Number**
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

6NS		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5K-0983	Seal-Lip Type	472-8012

6NS		
Original Part Number	**Part Name**	**Classic Part Number**
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9538	Bearing-Roller	421-8183
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6I-1099	Manifold-Exh	424-6366
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449

6NS		
Original Part Number	**Part Name**	**Classic Part Number**
7E-7302	Bracket	416-5497
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-9930	Mount As	295-6437

Sales Model 950G (Cont'd.)

6NS		
Original Part Number	Part Name	Classic Part Number
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-6675	Step As	419-0881
119-2940	Gasket	378-4002

6NS		
Original Part Number	Part Name	Classic Part Number
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
128-1009	Muffler As	435-6047
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599

6NS		
Original Part Number	Part Name	Classic Part Number
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
310-1899	Pin As	393-0932
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

8JW		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2G-8631	Bearing-Sleeve	391-9811
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3F-6185	Pin	295-5694
3G-4704	Bearing-Sleeve	379-0185
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638

8JW		
Original Part Number	Part Name	Classic Part Number
3T-9960	Disc-Friction	417-9487
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9538	Bearing-Roller	421-8183

8JW		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6E-0775	Head	425-9373
6E-5028	Rod As	425-9372
6I-1099	Manifold-Exh	424-6366
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059

Sales Model 950G (Cont'd.)

8JW		
Original Part Number	**Part Name**	**Classic Part Number**
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9682	Bearing-Sleeve	360-2335
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8J-5778	Bearing-Sleeve	374-8359
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8S-0248	Breather As	325-6033

8JW		
Original Part Number	**Part Name**	**Classic Part Number**
8V-1612	Shaft	425-6456
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9J-9598	Pin	296-1362
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-6675	Step As	419-0881
119-2940	Gasket	378-4002

8JW		
Original Part Number	**Part Name**	**Classic Part Number**
124-2726	Head	377-5855
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
128-1009	Muffler As	435-6047
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

AXR		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840

AXR		
Original Part Number	**Part Name**	**Classic Part Number**
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174

AXR		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

Sales Model 950G (Cont'd.)

AXR		
Original Part Number	Part Name	Classic Part Number
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4J-0121	Cap-Bearing	360-2344
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

AXR		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-5131	Trunnion	296-1371
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686

AXR		
Original Part Number	Part Name	Classic Part Number
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
117-6675	Step As	419-0881
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
164-4413	Mount	419-0876
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932

Sales Model 950G (Cont'd.)

AXX		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4J-0121	Cap-Bearing	360-2344
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691

AXX		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-5131	Trunnion	296-1371
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8J-5778	Bearing-Sleeve	374-8359
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182

AXX		
Original Part Number	**Part Name**	**Classic Part Number**
9G-7412	Gear As-Pump	297-7183
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
117-6675	Step As	419-0881
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
164-4413	Mount	419-0876
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

Sales Model 950G (Cont'd.)

AXX		
Original Part Number	Part Name	Classic Part Number
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710

AXX		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

AXX		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932

AYB		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689

AYB		
Original Part Number	Part Name	Classic Part Number
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818

AYB		
Original Part Number	Part Name	Classic Part Number
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
117-6675	Step As	419-0881
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
164-4413	Mount	419-0876
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370

Sales Model 950G (Cont'd.)

AYB		
Original Part Number	**Part Name**	**Classic Part Number**
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

AYB		
Original Part Number	**Part Name**	**Classic Part Number**
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710

AYB		
Original Part Number	**Part Name**	**Classic Part Number**
310-1899	Pin As	393-0932

AYD		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695

AYD		
Original Part Number	**Part Name**	**Classic Part Number**
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685

AYD		
Original Part Number	**Part Name**	**Classic Part Number**
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
117-6675	Step As	419-0881
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
164-4413	Mount	419-0876
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370

Sales Model 950G (Cont'd.)

AYD		
Original Part Number	Part Name	Classic Part Number
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370

AYD		
Original Part Number	Part Name	Classic Part Number
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

AYD		
Original Part Number	Part Name	Classic Part Number
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
310-1899	Pin As	393-0932

AYL		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133

AYL		
Original Part Number	Part Name	Classic Part Number
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182

AYL		
Original Part Number	Part Name	Classic Part Number
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
117-6675	Step As	419-0881
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
164-4413	Mount	419-0876
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370

Sales Model 950G (Cont'd.)

AYL		
Original Part Number	**Part Name**	**Classic Part Number**
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370

AYL		
Original Part Number	**Part Name**	**Classic Part Number**
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110

AYL		
Original Part Number	**Part Name**	**Classic Part Number**
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
310-1899	Pin As	393-0932

AYS		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8643	Bearing-Sleeve	374-8354
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022

AYS		
Original Part Number	**Part Name**	**Classic Part Number**
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-1309	Bearing-Aligning	360-2275
7S-4534	Bearing-Caged	417-9497

AYS		
Original Part Number	**Part Name**	**Classic Part Number**
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9T-5729	Cyl Gp-0038 0158	422-2486
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
117-6675	Step As	419-0881
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
130-4778	Housing As	419-4659

Sales Model 950G (Cont'd.)

AYS		
Original Part Number	Part Name	Classic Part Number
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
164-4413	Mount	419-0876

AYS		
Original Part Number	Part Name	Classic Part Number
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

AYS		
Original Part Number	Part Name	Classic Part Number
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932

BAA		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3G-4704	Bearing-Sleeve	379-0185
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187

BAA		
Original Part Number	Part Name	Classic Part Number
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6E-0775	Head	425-9373
6E-5028	Rod As	425-9372
6K-8088	Bearing-Roller	399-4428
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074

BAA		
Original Part Number	Part Name	Classic Part Number
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9344	Bearing-Sleeve	360-2334
7J-9682	Bearing-Sleeve	360-2335
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9D-7924	Mount As	360-2356
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018

Wheel Loaders

Sales Model 950G (Cont'd.)

BAA		
Original Part Number	**Part Name**	**Classic Part Number**
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
117-6675	Step As	419-0881
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208

BAA		
Original Part Number	**Part Name**	**Classic Part Number**
125-2873	Core As-Ac Cond	436-2254
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
164-4413	Mount	419-0876
176-3900	Accumulator	416-5513
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256

BAA		
Original Part Number	**Part Name**	**Classic Part Number**
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932

Sales Model 950H

J5J		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487

J5J		
Original Part Number	**Part Name**	**Classic Part Number**
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8643	Bearing-Sleeve	374-8354
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695

J5J		
Original Part Number	**Part Name**	**Classic Part Number**
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-3831	Seal-O-Ring	436-2657
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-6234	Bearing-Sleeve	325-6014
7B-7515	Bearing-Ball	399-6059
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-6794	Arm As-Injector	433-0449

Sales Model 950H (Cont'd.)

J5J		
Original Part Number	Part Name	Classic Part Number
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-1309	Bearing-Aligning	360-2275
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685

J5J		
Original Part Number	Part Name	Classic Part Number
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9T-5729	Cyl Gp-0038 0158	422-2486
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380

J5J		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932

JAD		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010

JAD		
Original Part Number	Part Name	Classic Part Number
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-3831	Seal-O-Ring	436-2657

JAD		
Original Part Number	Part Name	Classic Part Number
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678

Sales Model 950H (Cont'd.)

JAD		
Original Part Number	**Part Name**	**Classic Part Number**
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818

JAD		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

JAD		
Original Part Number	**Part Name**	**Classic Part Number**
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
310-1899	Pin As	393-0932

JLX		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3G-4704	Bearing-Sleeve	379-0185
3P-1210	Cone-Roller Brg	399-4433
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4B-9373	Cone-Roller Brg	399-4440

JLX		
Original Part Number	**Part Name**	**Classic Part Number**
4B-9374	Bearing-Cup	380-7494
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6E-0775	Head	425-9373
6E-5028	Rod As	425-9372
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696

JLX		
Original Part Number	**Part Name**	**Classic Part Number**
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-3831	Seal-O-Ring	436-2657
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697

Sales Model 950H (Cont'd.)

JLX		
Original Part Number	Part Name	Classic Part Number
7G-6062	Gear-Ring	302-2678
7J-9344	Bearing-Sleeve	360-2334
7J-9682	Bearing-Sleeve	360-2335
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7V-6715	Pin As	361-1701
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183

JLX		
Original Part Number	Part Name	Classic Part Number
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599

JLX		
Original Part Number	Part Name	Classic Part Number
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932

K5K		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-4502	Bearing-Sleeve	299-1986
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588

K5K		
Original Part Number	Part Name	Classic Part Number
4J-0121	Cap-Bearing	360-2344
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5D-7449	Cup-Spl Tapered	416-2161
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133

K5K		
Original Part Number	Part Name	Classic Part Number
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-3831	Seal-O-Ring	436-2657
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581

Sales Model 950H (Cont'd.)

K5K		
Original Part Number	**Part Name**	**Classic Part Number**
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-5131	Trunnion	296-1371
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
7K-0078	Bearing-Sleeve	308-9825
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8J-5778	Bearing-Sleeve	374-8359
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701

K5K		
Original Part Number	**Part Name**	**Classic Part Number**
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445

K5K		
Original Part Number	**Part Name**	**Classic Part Number**
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932

M1G		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3G-4704	Bearing-Sleeve	379-0185
3P-1210	Cone-Roller Brg	399-4433

M1G		
Original Part Number	**Part Name**	**Classic Part Number**
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-7449	Cup-Spl Tapered	416-2161
5K-0983	Seal-Lip Type	472-8012

M1G		
Original Part Number	**Part Name**	**Classic Part Number**
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6E-0775	Head	425-9373
6E-5028	Rod As	425-9372
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-3831	Seal-O-Ring	436-2657
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985

Sales Model 950H (Cont'd.)

M1G		
Original Part Number	Part Name	Classic Part Number
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9344	Bearing-Sleeve	360-2334
7J-9682	Bearing-Sleeve	360-2335
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190

M1G		
Original Part Number	Part Name	Classic Part Number
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381

M1G		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932

MXL		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3P-1210	Cone-Roller Brg	399-4433
3R-8530	Boss	425-3454

MXL		
Original Part Number	Part Name	Classic Part Number
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703

MXL		
Original Part Number	Part Name	Classic Part Number
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-3831	Seal-O-Ring	436-2657
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-5403	Tube As	374-4673

Sales Model 950H (Cont'd.)

MXL		
Original Part Number	**Part Name**	**Classic Part Number**
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108

MXL		
Original Part Number	**Part Name**	**Classic Part Number**
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381

MXL		
Original Part Number	**Part Name**	**Classic Part Number**
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
310-1899	Pin As	393-0932

N1A		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929

N1A		
Original Part Number	**Part Name**	**Classic Part Number**
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-3831	Seal-O-Ring	436-2657
6Y-2539	Cone-Roller Brg	464-4050

N1A		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231

Sales Model 950H (Cont'd.)

N1A		
Original Part Number	Part Name	Classic Part Number
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018

N1A		
Original Part Number	Part Name	Classic Part Number
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
154-8030	Gasket	394-0894

N1A		
Original Part Number	Part Name	Classic Part Number
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
310-1899	Pin As	393-0932

Sales Model 950K

DPT		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1V-8241	Bearing-Sleeve	308-9808
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5T-5682	Driver	418-9579

DPT		
Original Part Number	Part Name	Classic Part Number
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-1084	Impeller-Conv	380-1477
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190

DPT		
Original Part Number	Part Name	Classic Part Number
7T-3343	Plate-Clutch	297-7231
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860

Sales Model 950K (Cont'd.)

DPT		
Original Part Number	**Part Name**	**Classic Part Number**
213-1365	Bearing-Sleeve	330-9256

DPT		
Original Part Number	**Part Name**	**Classic Part Number**
213-1370	Bearing-Sleeve	380-7370

FER		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1V-8241	Bearing-Sleeve	308-9808
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945

FER		
Original Part Number	**Part Name**	**Classic Part Number**
5V-1882	Pin As	361-1700
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-1084	Impeller-Conv	380-1477
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9344	Bearing-Sleeve	360-2334
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7V-0638	Spacer	425-3651
8J-5778	Bearing-Sleeve	374-8359

FER		
Original Part Number	**Part Name**	**Classic Part Number**
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-4568	Piston	385-6108
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
310-1899	Pin As	393-0932

J5M		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1V-8241	Bearing-Sleeve	308-9808

J5M		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912

J5M		
Original Part Number	**Part Name**	**Classic Part Number**
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010

Sales Model 950K (Cont'd.)

J5M		
Original Part Number	Part Name	Classic Part Number
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-1084	Impeller-Conv	380-1477
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059

J5M		
Original Part Number	Part Name	Classic Part Number
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9344	Bearing-Sleeve	360-2334
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7V-0638	Spacer	425-3651
8G-4022	Bearing	422-6920
8J-5778	Bearing-Sleeve	374-8359
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
9C-8418	Plate-Reaction	385-6129

J5M		
Original Part Number	Part Name	Classic Part Number
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
310-1899	Pin As	393-0932

R4A		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1V-8241	Bearing-Sleeve	308-9808
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-4502	Bearing-Sleeve	299-1986
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638

R4A		
Original Part Number	Part Name	Classic Part Number
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4J-0121	Cap-Bearing	360-2344
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133

R4A		
Original Part Number	Part Name	Classic Part Number
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-1084	Impeller-Conv	380-1477
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-5131	Trunnion	296-1371
7J-9344	Bearing-Sleeve	360-2334

Wheel Loaders

Sales Model 950K (Cont'd.)

R4A		
Original Part Number	**Part Name**	**Classic Part Number**
7J-9346	Bearing-Sleeve	374-8357
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7V-0638	Spacer	425-3651
8G-4022	Bearing	422-6920
8J-5778	Bearing-Sleeve	374-8359
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
9C-8418	Plate-Reaction	385-6129

R4A		
Original Part Number	**Part Name**	**Classic Part Number**
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437

R4A		
Original Part Number	**Part Name**	**Classic Part Number**
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932

Sales Model 950L

LXX		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-9295	Bearing-Cone	422-6480
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3B-4124	Cup-Spl Tapered	422-6481
3P-1210	Cone-Roller Brg	399-4433
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494

LXX		
Original Part Number	**Part Name**	**Classic Part Number**
4E-8534	Retainer-Seal	300-2588
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5T-5682	Driver	418-9579
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7J-8210	Cone-Roller Brg	423-6987

LXX		
Original Part Number	**Part Name**	**Classic Part Number**
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
114-1071	Piston	388-6583
213-1365	Bearing-Sleeve	330-9256
265-5287	Ring-Seal	472-8028
310-1899	Pin As	393-0932
334-1032	Disc-Friction	440-3116

TNS		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-9295	Bearing-Cone	422-6480

TNS		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3B-4124	Cup-Spl Tapered	422-6481

TNS		
Original Part Number	**Part Name**	**Classic Part Number**
3P-1210	Cone-Roller Brg	399-4433
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494

Sales Model 950L (Cont'd.)

TNS		
Original Part Number	**Part Name**	**Classic Part Number**
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5T-5682	Driver	418-9579
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
6Y-1031	Cone-Rlr Bearing	434-5098

TNS		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-1032	Cup-Rlr Bearing	434-5097
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7J-8210	Cone-Roller Brg	423-6987
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018

TNS		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
114-1071	Piston	388-6583
213-1365	Bearing-Sleeve	330-9256
265-5287	Ring-Seal	472-8028
310-1899	Pin As	393-0932
334-1032	Disc-Friction	440-3116

Sales Model 950M

EMB		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
1V-8241	Bearing-Sleeve	308-9808
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-4502	Bearing-Sleeve	299-1986
2K-9295	Bearing-Cone	422-6480
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3B-4124	Cup-Spl Tapered	422-6481
3P-1210	Cone-Roller Brg	399-4433
4B-9373	Cone-Roller Brg	399-4440

EMB		
Original Part Number	**Part Name**	**Classic Part Number**
4B-9374	Bearing-Cup	380-7494
4E-8534	Retainer-Seal	300-2588
5K-0983	Seal-Lip Type	472-8012
5T-5682	Driver	418-9579
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7J-8210	Cone-Roller Brg	423-6987
7J-9344	Bearing-Sleeve	360-2334
7K-0078	Bearing-Sleeve	308-9825
7K-9639	Bearing-Sleeve	314-8643

EMB		
Original Part Number	**Part Name**	**Classic Part Number**
8G-4022	Bearing	422-6920
8J-5778	Bearing-Sleeve	374-8359
9J-5875	Bearing-Sleeve	308-9830
9M-1328	Bearing-Aligning	325-6018
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
114-1071	Piston	388-6583
213-1365	Bearing-Sleeve	330-9256
265-5287	Ring-Seal	472-8028
334-1032	Disc-Friction	440-3116

ENE		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
1V-8241	Bearing-Sleeve	308-9808
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-9295	Bearing-Cone	422-6480

ENE		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3B-4124	Cup-Spl Tapered	422-6481
3P-1210	Cone-Roller Brg	399-4433

ENE		
Original Part Number	**Part Name**	**Classic Part Number**
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-8534	Retainer-Seal	300-2588
5K-0983	Seal-Lip Type	472-8012
5T-5682	Driver	418-9579
6Y-1031	Cone-Rlr Bearing	434-5098

Sales Model 950M (Cont'd.)

ENE		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-1032	Cup-Rlr Bearing	434-5097
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7J-8210	Cone-Roller Brg	423-6987

ENE		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1328	Bearing-Aligning	325-6018
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583

ENE		
Original Part Number	**Part Name**	**Classic Part Number**
114-1071	Piston	388-6583
213-1365	Bearing-Sleeve	330-9256
265-5287	Ring-Seal	472-8028
334-1032	Disc-Friction	440-3116

FTR		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
1V-8241	Bearing-Sleeve	308-9808
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-9295	Bearing-Cone	422-6480
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3B-4124	Cup-Spl Tapered	422-6481
3P-1210	Cone-Roller Brg	399-4433
4B-9373	Cone-Roller Brg	399-4440

FTR		
Original Part Number	**Part Name**	**Classic Part Number**
4B-9374	Bearing-Cup	380-7494
4E-8534	Retainer-Seal	300-2588
5K-0983	Seal-Lip Type	472-8012
5T-5682	Driver	418-9579
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7J-8210	Cone-Roller Brg	423-6987
7J-9344	Bearing-Sleeve	360-2334
7K-9639	Bearing-Sleeve	314-8643

FTR		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1328	Bearing-Aligning	325-6018
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
114-1071	Piston	388-6583
213-1365	Bearing-Sleeve	330-9256
265-5287	Ring-Seal	472-8028
334-1032	Disc-Friction	440-3116

J1S		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
1V-8241	Bearing-Sleeve	308-9808
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-9295	Bearing-Cone	422-6480
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3B-4124	Cup-Spl Tapered	422-6481
3P-1210	Cone-Roller Brg	399-4433

J1S		
Original Part Number	**Part Name**	**Classic Part Number**
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-8534	Retainer-Seal	300-2588
5K-0983	Seal-Lip Type	472-8012
5T-5682	Driver	418-9579
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074

J1S		
Original Part Number	**Part Name**	**Classic Part Number**
7J-8210	Cone-Roller Brg	423-6987
9M-1328	Bearing-Aligning	325-6018
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
114-1071	Piston	388-6583
213-1365	Bearing-Sleeve	330-9256
265-5287	Ring-Seal	472-8028
334-1032	Disc-Friction	440-3116

Sales Model 950M (Cont'd.)

LCR		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1V-8241	Bearing-Sleeve	308-9808
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-9295	Bearing-Cone	422-6480
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3B-4124	Cup-Spl Tapered	422-6481
3P-1210	Cone-Roller Brg	399-4433

LCR		
Original Part Number	Part Name	Classic Part Number
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-8534	Retainer-Seal	300-2588
5K-0983	Seal-Lip Type	472-8012
5T-5682	Driver	418-9579
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074

LCR		
Original Part Number	Part Name	Classic Part Number
7J-8210	Cone-Roller Brg	423-6987
9M-1328	Bearing-Aligning	325-6018
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
114-1071	Piston	388-6583
213-1365	Bearing-Sleeve	330-9256
265-5287	Ring-Seal	472-8028
334-1032	Disc-Friction	440-3116

XCJ		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1V-8241	Bearing-Sleeve	308-9808
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3P-1210	Cone-Roller Brg	399-4433

XCJ		
Original Part Number	Part Name	Classic Part Number
4E-8534	Retainer-Seal	300-2588
5K-0983	Seal-Lip Type	472-8012
5T-5682	Driver	418-9579
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7J-8210	Cone-Roller Brg	423-6987
9M-1328	Bearing-Aligning	325-6018
9W-9930	Mount As	295-6437

XCJ		
Original Part Number	Part Name	Classic Part Number
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
114-1071	Piston	388-6583
213-1365	Bearing-Sleeve	330-9256
265-5287	Ring-Seal	472-8028
334-1032	Disc-Friction	440-3116

Sales Model 960F

1YM		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-7250	Bowl	360-2296
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108

1YM		
Original Part Number	Part Name	Classic Part Number
1T-1053	Turbine As-Conv	377-7412
1T-1331	Stator-Converter	229-8237
1T-1940	Housing As	396-0646
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354

1YM		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-5539	Core As-Rad	374-7492
2W-7213	Bearing-Sleeve	419-4667
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666

Sales Model 960F (Cont'd.)

1YM		
Original Part Number	**Part Name**	**Classic Part Number**
3G-9891	Pump Gp-Gr A	399-8541
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4D-0487	Valve As-Check	375-4334
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3197	Pin As	374-6507
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4K-7270	Support-Trunnion	373-5384
4P-0893	Core As-Radiator	376-9057
4P-5435	Compressor As	396-9942
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110

1YM		
Original Part Number	**Part Name**	**Classic Part Number**
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-4892	Cyl Gp-089 478 Y	394-9828
6F-7523	Cap-Bearing	325-6039
6I-1099	Manifold-Exh	424-6366
6I-3662	Muffler As	360-7882
6L-7751	Rod End-Spher	472-8015
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-3651	Pump Gp-Gr 1 Bsc	345-1978
6V-2202	Bearing-Spl Ball	380-1574
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3455	Tube As	374-4721
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497

1YM		
Original Part Number	**Part Name**	**Classic Part Number**
7E-8926	Head Kt-Cyl	377-5847
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7M-7219	Bearing-Thrust	384-4816
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7V-5645	Rod-Indicator	397-5061
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8E-4954	Housing As-Cl	391-9823
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8P-3563	Cage-Bearing	451-0747
8R-4568	Piston	385-6108
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-7659	Pin As	361-1702
9C-4096	Yoke-Bk Flange	369-9496
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9N-4460	Housing As-Cl	297-7203
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679

Sales Model 960F (Cont'd.)

1YM		
Original Part Number	Part Name	Classic Part Number
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-0517	Carrier-Planet	281-1686
9W-4950	Gear-Sun	281-1688
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160

1YM		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
123-3472	Pump Gp-Gr 1 Bsc	345-1978
124-2726	Head	377-5855
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
127-5537	Core As-Oclr	325-6045
136-0819	Valve-Exhaust	384-8697
139-9177	Gasket Kit	377-7465
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
163-1387	Gear-Flywheel	374-4697

1YM		
Original Part Number	Part Name	Classic Part Number
176-9273	Piston	297-4860
207-2015	Gasket Kit	447-0828
207-2016	Gasket Kit	434-7284
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
216-5359	Kit-Dt Gasket	451-1504
216-7957	U-Joint	367-6069
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
237-2859	Bearing-Rlr	368-0125
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
310-1899	Pin As	393-0932
345-1976	Pump-Gr-Cla	345-1978
352-2153	Pump As-Water	433-0444
460-5395	Kit-Gasket (Sch)	436-8395

4CL		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1053	Turbine As-Conv	377-7412
1T-1331	Stator-Converter	229-8237
1T-1940	Housing As	396-0646
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354

4CL		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-5539	Core As-Rad	374-7492
2W-7213	Bearing-Sleeve	419-4667
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666
3G-9891	Pump Gp-Gr A	399-8541
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4D-0487	Valve As-Check	375-4334
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697

4CL		
Original Part Number	Part Name	Classic Part Number
4E-3197	Pin As	374-6507
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4K-7270	Support-Trunnion	373-5384
4P-0893	Core As-Radiator	376-9057
4P-5433	Compressor As	419-4728
4P-5435	Compressor As	396-9942
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563

Sales Model 960F (Cont'd.)

4CL		
Original Part Number	**Part Name**	**Classic Part Number**
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-4892	Cyl Gp-089 478 Y	394-9828
6I-1099	Manifold-Exh	424-6366
6I-3662	Muffler As	360-7882
6L-7751	Rod End-Spher	472-8015
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-3651	Pump Gp-Gr 1 Bsc	345-1978
6V-2202	Bearing-Spl Ball	380-1574
6V-5414	Gasket Kit	434-7289
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3484	Bearing-Spl Ball	416-2166

4CL		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3455	Tube As	374-4721
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7M-7219	Bearing-Thrust	384-4816
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7V-5645	Rod-Indicator	397-5061
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8E-4954	Housing As-Cl	391-9823
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512

4CL		
Original Part Number	**Part Name**	**Classic Part Number**
8P-3563	Cage-Bearing	451-0747
8R-4568	Piston	385-6108
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-7659	Pin As	361-1702
9C-4096	Yoke-Bk Flange	369-9496
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9N-4460	Housing As-Cl	297-7203
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-0517	Carrier-Planet	281-1686
9W-4950	Gear-Sun	281-1688
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2953	Gasket Kit-Sch	393-1025
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020

Sales Model 960F (Cont'd.)

4CL		
Original Part Number	Part Name	Classic Part Number
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
123-3472	Pump Gp-Gr 1 Bsc	345-1978
124-2726	Head	377-5855
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
127-5537	Core As-Oclr	325-6045
136-0819	Valve-Exhaust	384-8697
139-9177	Gasket Kit	377-7465
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336

4CL		
Original Part Number	Part Name	Classic Part Number
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
163-1387	Gear-Flywheel	374-4697
176-9273	Piston	297-4860
207-2015	Gasket Kit	447-0828
207-2016	Gasket Kit	434-7284
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
216-5359	Kit-Dt Gasket	451-1504

4CL		
Original Part Number	Part Name	Classic Part Number
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
237-2859	Bearing-Rlr	368-0125
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
310-1899	Pin As	393-0932
318-9013	Kit-Gasket (Sch)	437-8128
345-1976	Pump-Gr-Cla	345-1978
352-2153	Pump As-Water	433-0444
460-5395	Kit-Gasket (Sch)	436-8395

6XL		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1053	Turbine As-Conv	377-7412
1T-1331	Stator-Converter	229-8237
1T-1940	Housing As	396-0646
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-5539	Core As-Rad	374-7492
2W-7213	Bearing-Sleeve	419-4667

6XL		
Original Part Number	Part Name	Classic Part Number
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666
3G-9891	Pump Gp-Gr A	399-8541
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3197	Pin As	374-6507
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4K-7270	Support-Trunnion	373-5384
4P-0893	Core As-Radiator	376-9057
4P-5435	Compressor As	396-9942
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216

6XL		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443

Sales Model 960F (Cont'd.)

6XL		
Original Part Number	**Part Name**	**Classic Part Number**
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-4892	Cyl Gp-089 478 Y	394-9828
6I-1099	Manifold-Exh	424-6366
6I-3662	Muffler As	360-7882
6L-7751	Rod End-Spher	472-8015
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-3651	Pump Gp-Gr 1 Bsc	345-1978
6V-2202	Bearing-Spl Ball	380-1574
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3455	Tube As	374-4721
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691

6XL		
Original Part Number	**Part Name**	**Classic Part Number**
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7M-7219	Bearing-Thrust	384-4816
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7V-5645	Rod-Indicator	397-5061
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-8064	Valve-Inlet	384-8705
8E-4954	Housing As-Cl	391-9823
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8P-3563	Cage-Bearing	451-0747
8R-4568	Piston	385-6108
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-7659	Pin As	361-1702
9C-4096	Yoke-Bk Flange	369-9496
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478
9N-4460	Housing As-Cl	297-7203
9T-5729	Cyl Gp-0038 0158	422-2486
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166

6XL		
Original Part Number	**Part Name**	**Classic Part Number**
9V-3853	Pin	319-3469
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-0517	Carrier-Planet	281-1686
9W-4950	Gear-Sun	281-1688
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
123-3472	Pump Gp-Gr 1 Bsc	345-1978
124-2726	Head	377-5855
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
127-5537	Core As-Oclr	325-6045
136-0819	Valve-Exhaust	384-8697
139-9177	Gasket Kit	377-7465
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
163-1387	Gear-Flywheel	374-4697
176-9273	Piston	297-4860
207-2015	Gasket Kit	447-0828
207-2016	Gasket Kit	434-7284

Sales Model 960F (Cont'd.)

6XL		
Original Part Number	**Part Name**	**Classic Part Number**
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870

6XL		
Original Part Number	**Part Name**	**Classic Part Number**
216-5359	Kit-Dt Gasket	451-1504
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
237-2859	Bearing-Rlr	368-0125

6XL		
Original Part Number	**Part Name**	**Classic Part Number**
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
310-1899	Pin As	393-0932
345-1976	Pump-Gr-Cla	345-1978
352-2153	Pump As-Water	433-0444

9ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-0737	Race-Spl Thrust	384-4798
1T-0767	Bearing-Sleeve	383-2108
1T-1053	Turbine As-Conv	377-7412
1T-1331	Stator-Converter	229-8237
1T-1428	Retainer-Brg	300-2587
1T-1647	Impeller-Conv	377-7415
1T-1691	Impeller-Conv	297-4863
1T-1940	Housing As	396-0646
1T-1981	Stator As-Conv	377-7416
1T-1991	Stator As-Conv	380-1482
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

9ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5539	Core As-Rad	374-7492
2W-7213	Bearing-Sleeve	419-4667

9ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-4704	Bearing-Sleeve	379-0185
3G-8792	Cylinder As	469-4666
3G-9891	Pump Gp-Gr A	399-8541
3L-1425	Bearing-Ball	311-9356
3N-5869	Support-Elbow	375-9973
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
3V-2337	Pin As	319-3440
4D-0487	Valve As-Check	375-4334
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3197	Pin As	374-6507
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4E-9658	Joint Gp-Slip	452-9553
4K-7270	Support-Trunnion	373-5384
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-5433	Compressor As	419-4728
4P-5435	Compressor As	396-9942
4P-7051	Pulley-Alt	376-9064
4P-7688	Valve As-Check	420-6216
4P-7790	Shaft As-Arm	457-4596
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

Sales Model 960F (Cont'd.)

9ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7830	Gear-Oil Drive	472-8009
4P-8577	Rod As-Injector	455-5513
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2883	Bearing-Sleeve	379-0193
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-8674	Bearing-Sleeve	307-1529
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0989	Cap-Upper	297-7158
5K-0991	Cap-Lower	319-3433
5K-3493	Cover	391-9814
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247

9ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
5V-6327	Yoke-Flange Bk	391-1086
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-4892	Cyl Gp-089 478 Y	394-9828
6H-3957	Bearing-Ball	311-9358
6I-1099	Manifold-Exh	424-6366
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-3662	Muffler As	360-7882
6J-6043	Bearing-Sleeve	374-1456
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-3651	Pump Gp-Gr 1 Bsc	345-1978
6T-5383	Gear-Ring	375-2624
6V-2202	Bearing-Spl Ball	380-1574

9ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
6V-5414	Gasket Kit	434-7289
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-0307	Gasket	399-8571
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3455	Tube As	374-4721
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-8926	Head Kt-Cyl	377-5847
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7K-9639	Bearing-Sleeve	314-8643
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686

Sales Model 960F (Cont'd.)

9ZJ		
Original Part Number	Part Name	Classic Part Number
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-8064	Valve-Inlet	384-8705
7W-9020	Bell As-Pump Suc	378-3989
7W-9027	Base-Oil Cooler	399-8545
8E-4954	Housing As-Cl	391-9823
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207

9ZJ		
Original Part Number	Part Name	Classic Part Number
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3563	Cage-Bearing	451-0747
8R-4568	Piston	385-6108
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-7659	Pin As	361-1702
9C-4096	Yoke-Bk Flange	369-9496
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9G-8117	Housing As-Cl	302-2686
9G-9764	Yoke As	319-3478

9ZJ		
Original Part Number	Part Name	Classic Part Number
9L-5908	Gasket	433-8196
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3289	Pin As	382-6904
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-0517	Carrier-Planet	281-1686
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
111-8015	Gasket As-Head	279-4977
113-6200	Gasket	438-2020
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
123-3472	Pump Gp-Gr 1 Bsc	345-1978
124-2726	Head	377-5855

Sales Model 960F (Cont'd.)

9ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
127-5537	Core As-Oclr	325-6045
130-1455	Gasket Kit	437-4604
131-3815	Seal Gp-Basic	325-6193
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
139-9177	Gasket Kit	377-7465
143-7356	Bearing As	380-1483
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
148-7455	Valve - Exhaust	270-4361
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
159-1847	Yoke As (1610)	373-5381
163-1387	Gear-Flywheel	374-4697
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

9ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7765	Pump Gp-Water -B	394-9835
174-6829	Gasket Kit	394-8237
176-9273	Piston	297-4860
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828
207-2016	Gasket Kit	434-7284
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
216-5359	Kit-Dt Gasket	451-1504

9ZJ		
Original Part Number	**Part Name**	**Classic Part Number**
216-7957	U-Joint	367-6069
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3233	Bearing-Main	376-9085
237-2859	Bearing-Rlr	368-0125
264-6898	Kit-Gasket-Sch	382-5069
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
310-1899	Pin As	393-0932
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
345-1976	Pump-Gr-Cla	345-1978
352-2153	Pump As-Water	433-0444
460-5395	Kit-Gasket (Sch)	436-8395

Sales Model 962G

3BS		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	C one-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

3BS		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-2250	Housing	399-6043

3BS		
Original Part Number	**Part Name**	**Classic Part Number**
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4K-7270	Support-Trunnion	373-5384
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217

Sales Model 962G (Cont'd.)

3BS		
Original Part Number	Part Name	Classic Part Number
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9538	Bearing-Roller	421-8183
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6I-1099	Manifold-Exh	424-6366
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939

3BS		
Original Part Number	Part Name	Classic Part Number
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8J-5778	Bearing-Sleeve	374-8359
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-9930	Mount As	295-6437

3BS		
Original Part Number	Part Name	Classic Part Number
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
103-0887	Pulley-Idler	449-9546
105-1738	Manifold-Exhaust	374-4692
105-7535	Bearing-Dbl Row	417-9496
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-6675	Step As	419-0881
119-2940	Gasket	378-4002
124-2726	Head	377-5855
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
128-1009	Muffler As	435-6047
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
176-3900	Accumulator	416-5513
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870

Sales Model 962G (Cont'd.)

3BS		
Original Part Number	**Part Name**	**Classic Part Number**
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912

3BS		
Original Part Number	**Part Name**	**Classic Part Number**
277-7089	Shaft As	380-7578
310-1899	Pin As	393-0932
352-2151	Pump Gp-Water -B	434-6107

3BS		
Original Part Number	**Part Name**	**Classic Part Number**
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

4PW		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4K-7270	Support-Trunnion	373-5384
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-7099	Pin As	361-1698

4PW		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9538	Bearing-Roller	421-8183
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6I-1099	Manifold-Exh	424-6366
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

4PW		
Original Part Number	**Part Name**	**Classic Part Number**
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8J-5778	Bearing-Sleeve	374-8359
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-4568	Piston	385-6108
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033

Sales Model 962G (Cont'd.)

4PW		
Original Part Number	Part Name	Classic Part Number
8V-1612	Shaft	425-6456
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983

4PW		
Original Part Number	Part Name	Classic Part Number
100-6298	Camshaft As	398-2958
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-6675	Step As	419-0881
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
128-1009	Muffler As	435-6047
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

4PW		
Original Part Number	Part Name	Classic Part Number
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
162-4012	Gasket Kit - F	437-8126
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
239-4290	Kit-Gasket-Sch	435-2574
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

5RS		
Original Part Number	Part Name	Classic Part Number
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356

5RS		
Original Part Number	Part Name	Classic Part Number
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4K-7270	Support-Trunnion	373-5384
4P-3683	Pump Gp-Water -B	374-7498
4P-6548	Muffler As	360-7878
4P-6589	Pipe As	382-6898
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513

5RS		
Original Part Number	Part Name	Classic Part Number
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9538	Bearing-Roller	421-8183

Sales Model 962G (Cont'd.)

5RS		
Original Part Number	**Part Name**	**Classic Part Number**
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6I-1099	Manifold-Exh	424-6366
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497

5RS		
Original Part Number	**Part Name**	**Classic Part Number**
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
101-8740	Muffler As	360-7878
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020

5RS		
Original Part Number	**Part Name**	**Classic Part Number**
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-6675	Step As	419-0881
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
128-1009	Muffler As	435-6047
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
310-1899	Pin As	393-0932
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789
360-7863	Muffler-Cla	360-7878

Sales Model 962G (Cont'd.)

6EW		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3G-4704	Bearing-Sleeve	379-0185
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4K-7270	Support-Trunnion	373-5384
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-2883	Bearing-Sleeve	379-0193
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

6EW		
Original Part Number	Part Name	Classic Part Number
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9538	Bearing-Roller	421-8183
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6E-0775	Head	425-9373
6E-5028	Rod As	425-9372
6I-1099	Manifold-Exh	424-6366
6J-6043	Bearing-Sleeve	374-1456
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7G-0437	Plate-Clutch	417-9466

6EW		
Original Part Number	Part Name	Classic Part Number
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9682	Bearing-Sleeve	360-2335
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8J-5778	Bearing-Sleeve	374-8359
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605

Sales Model 962G (Cont'd.)

6EW		
Original Part Number	**Part Name**	**Classic Part Number**
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-6675	Step As	419-0881
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208

6EW		
Original Part Number	**Part Name**	**Classic Part Number**
125-2873	Core As-Ac Cond	436-2254
128-1009	Muffler As	435-6047
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370

6EW		
Original Part Number	**Part Name**	**Classic Part Number**
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

6HW		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638

6HW		
Original Part Number	**Part Name**	**Classic Part Number**
3T-9960	Disc-Friction	417-9487
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4K-7270	Support-Trunnion	373-5384
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5K-0983	Seal-Lip Type	472-8012

6HW		
Original Part Number	**Part Name**	**Classic Part Number**
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9538	Bearing-Roller	421-8183
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6I-1099	Manifold-Exh	424-6366
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639

Sales Model 962G (Cont'd.)

6HW		
Original Part Number	Part Name	Classic Part Number
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-7659	Pin As	361-1702

6HW		
Original Part Number	Part Name	Classic Part Number
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-6675	Step As	419-0881
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208

6HW		
Original Part Number	Part Name	Classic Part Number
125-2873	Core As-Ac Cond	436-2254
128-1009	Muffler As	435-6047
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
162-4012	Gasket Kit - F	437-8126
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
239-4290	Kit-Gasket-Sch	435-2574
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
310-1899	Pin As	393-0932
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

7BW		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840

7BW		
Original Part Number	Part Name	Classic Part Number
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294

7BW		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914

Sales Model 962G (Cont'd.)

7BW		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4K-7270	Support-Trunnion	373-5384
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9538	Bearing-Roller	421-8183
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6I-1099	Manifold-Exh	424-6366
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695

7BW		
Original Part Number	**Part Name**	**Classic Part Number**
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8J-5778	Bearing-Sleeve	374-8359
8R-1088	Bearing-Sleeve	419-0885

7BW		
Original Part Number	**Part Name**	**Classic Part Number**
8R-4568	Piston	385-6108
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
103-0887	Pulley-Idler	449-9546
105-1738	Manifold-Exhaust	374-4692
105-7535	Bearing-Dbl Row	417-9496
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-6675	Step As	419-0881
119-2940	Gasket	378-4002
124-2726	Head	377-5855
124-3237	Precleaner As	432-4220

Sales Model 962G (Cont'd.)

7BW		
Original Part Number	Part Name	Classic Part Number
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
128-1009	Muffler As	435-6047
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

7BW		
Original Part Number	Part Name	Classic Part Number
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
162-4012	Gasket Kit - F	437-8126
176-3900	Accumulator	416-5513
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123

7BW		
Original Part Number	Part Name	Classic Part Number
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
239-4290	Kit-Gasket-Sch	435-2574
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
310-1899	Pin As	393-0932
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

AXS		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529

AXS		
Original Part Number	Part Name	Classic Part Number
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074

AXS		
Original Part Number	Part Name	Classic Part Number
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183

Sales Model 962G (Cont'd.)

AXS		
Original Part Number	**Part Name**	**Classic Part Number**
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
117-6675	Step As	419-0881

AXS		
Original Part Number	**Part Name**	**Classic Part Number**
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
164-4413	Mount	419-0876
176-9273	Piston	297-4860

AXS		
Original Part Number	**Part Name**	**Classic Part Number**
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932

AXY		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652

AXY		
Original Part Number	**Part Name**	**Classic Part Number**
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985

AXY		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357

Sales Model 962G (Cont'd.)

AXY		
Original Part Number	Part Name	Classic Part Number
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203

AXY		
Original Part Number	Part Name	Classic Part Number
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
117-6675	Step As	419-0881
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696

AXY		
Original Part Number	Part Name	Classic Part Number
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
164-4413	Mount	419-0876
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932

AYE		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638

AYE		
Original Part Number	Part Name	Classic Part Number
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690

AYE		
Original Part Number	Part Name	Classic Part Number
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939

Sales Model 962G (Cont'd.)

AYE		
Original Part Number	**Part Name**	**Classic Part Number**
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183

AYE		
Original Part Number	**Part Name**	**Classic Part Number**
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
117-6675	Step As	419-0881
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562

AYE		
Original Part Number	**Part Name**	**Classic Part Number**
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
164-4413	Mount	419-0876
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
310-1899	Pin As	393-0932

AYG		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638

AYG		
Original Part Number	**Part Name**	**Classic Part Number**
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-0593	Bearing-Roller	386-4959

AYG		
Original Part Number	**Part Name**	**Classic Part Number**
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

Sales Model 962G (Cont'd.)

AYG		
Original Part Number	Part Name	Classic Part Number
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182

AYG		
Original Part Number	Part Name	Classic Part Number
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
117-6675	Step As	419-0881
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562

AYG		
Original Part Number	Part Name	Classic Part Number
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
164-4413	Mount	419-0876
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
310-1899	Pin As	393-0932

BAB		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638

BAB		
Original Part Number	Part Name	Classic Part Number
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-0593	Bearing-Roller	386-4959

BAB		
Original Part Number	Part Name	Classic Part Number
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

Sales Model 962G (Cont'd.)

BAB		
Original Part Number	**Part Name**	**Classic Part Number**
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182

BAB		
Original Part Number	**Part Name**	**Classic Part Number**
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
117-6675	Step As	419-0881
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562

BAB		
Original Part Number	**Part Name**	**Classic Part Number**
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
164-4413	Mount	419-0876
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
310-1899	Pin As	393-0932

BAC		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185

BAC		
Original Part Number	**Part Name**	**Classic Part Number**
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579

BAC		
Original Part Number	**Part Name**	**Classic Part Number**
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059

Sales Model 962G (Cont'd.)

BAC		
Original Part Number	Part Name	Classic Part Number
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-1309	Bearing-Aligning	360-2275
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108

BAC		
Original Part Number	Part Name	Classic Part Number
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9T-5729	Cyl Gp-0038 0158	422-2486
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
117-6675	Step As	419-0881
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208

BAC		
Original Part Number	Part Name	Classic Part Number
125-2873	Core As-Ac Cond	436-2254
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
164-4413	Mount	419-0876
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
310-1899	Pin As	393-0932

BAD		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912

BAD		
Original Part Number	Part Name	Classic Part Number
2W-7213	Bearing-Sleeve	419-4667
3G-4704	Bearing-Sleeve	379-0185
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652

BAD		
Original Part Number	Part Name	Classic Part Number
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703

Sales Model 962G (Cont'd.)

BAD		
Original Part Number	**Part Name**	**Classic Part Number**
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6E-0775	Head	425-9373
6E-5028	Rod As	425-9372
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678

BAD		
Original Part Number	**Part Name**	**Classic Part Number**
7J-9682	Bearing-Sleeve	360-2335
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
117-6675	Step As	419-0881
124-3237	Precleaner As	432-4220

BAD		
Original Part Number	**Part Name**	**Classic Part Number**
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
164-4413	Mount	419-0876
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932

BDP		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

BDP		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328

BDP		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697

Sales Model 962G (Cont'd.)

BDP		
Original Part Number	Part Name	Classic Part Number
4E-8534	Retainer-Seal	300-2588
4K-7270	Support-Trunnion	373-5384
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-2883	Bearing-Sleeve	379-0193
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9538	Bearing-Roller	421-8183
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1511	Pin As	418-1945
6I-1099	Manifold-Exh	424-6366
6J-6043	Bearing-Sleeve	374-1456
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059

BDP		
Original Part Number	Part Name	Classic Part Number
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203

BDP		
Original Part Number	Part Name	Classic Part Number
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
103-0887	Pulley-Idler	449-9546
105-1738	Manifold-Exhaust	374-4692
105-7535	Bearing-Dbl Row	417-9496
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-6675	Step As	419-0881
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
128-1009	Muffler As	435-6047
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
176-3900	Accumulator	416-5513
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372

Wheel Loaders

Sales Model 962G (Cont'd.)

BDP		
Original Part Number	**Part Name**	**Classic Part Number**
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371

BDP		
Original Part Number	**Part Name**	**Classic Part Number**
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578

BDP		
Original Part Number	**Part Name**	**Classic Part Number**
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

Sales Model 962H

J6J		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3G-4704	Bearing-Sleeve	379-0185
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110

J6J		
Original Part Number	**Part Name**	**Classic Part Number**
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-3831	Seal-O-Ring	436-2657
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-1309	Bearing-Aligning	360-2275

J6J		
Original Part Number	**Part Name**	**Classic Part Number**
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9T-5729	Cyl Gp-0038 0158	422-2486
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
124-3237	Precleaner As	432-4220

Sales Model 962H (Cont'd.)

J6J		
Original Part Number	Part Name	Classic Part Number
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599

J6J		
Original Part Number	Part Name	Classic Part Number
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870

J6J		
Original Part Number	Part Name	Classic Part Number
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
310-1899	Pin As	393-0932

K6K		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4J-0121	Cap-Bearing	360-2344
4T-8054	Seal As	472-8010
4V-2883	Bearing-Sleeve	379-0193
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5D-7449	Cup-Spl Tapered	416-2161
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022

K6K		
Original Part Number	Part Name	Classic Part Number
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6J-6043	Bearing-Sleeve	374-1456
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-3831	Seal-O-Ring	436-2657
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678

K6K		
Original Part Number	Part Name	Classic Part Number
7J-5131	Trunnion	296-1371
7J-9346	Bearing-Sleeve	374-8357
7K-0078	Bearing-Sleeve	308-9825
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8J-5778	Bearing-Sleeve	374-8359
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9V-3289	Pin As	382-6904
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926

Sales Model 962H (Cont'd.)

K6K		
Original Part Number	**Part Name**	**Classic Part Number**
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
154-8030	Gasket	394-0894

K6K		
Original Part Number	**Part Name**	**Classic Part Number**
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371

K6K		
Original Part Number	**Part Name**	**Classic Part Number**
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932

M3G		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3G-4704	Bearing-Sleeve	379-0185
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-7449	Cup-Spl Tapered	416-2161

M3G		
Original Part Number	**Part Name**	**Classic Part Number**
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6E-0775	Head	425-9373
6E-5028	Rod As	425-9372
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-3831	Seal-O-Ring	436-2657
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-6794	Arm As-Injector	433-0449

M3G		
Original Part Number	**Part Name**	**Classic Part Number**
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9682	Bearing-Sleeve	360-2335
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605

Sales Model 962H (Cont'd.)

M3G		
Original Part Number	Part Name	Classic Part Number
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
154-8030	Gasket	394-0894

M3G		
Original Part Number	Part Name	Classic Part Number
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870

M3G		
Original Part Number	Part Name	Classic Part Number
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932

MAL		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700

MAL		
Original Part Number	Part Name	Classic Part Number
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-3831	Seal-O-Ring	436-2657
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190

MAL		
Original Part Number	Part Name	Classic Part Number
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860

Sales Model 962H (Cont'd.)

MAL		
Original Part Number	**Part Name**	**Classic Part Number**
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370

MAL		
Original Part Number	**Part Name**	**Classic Part Number**
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370

MAL		
Original Part Number	**Part Name**	**Classic Part Number**
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
310-1899	Pin As	393-0932

N4A		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696

N4A		
Original Part Number	**Part Name**	**Classic Part Number**
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-3831	Seal-O-Ring	436-2657
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685

N4A		
Original Part Number	**Part Name**	**Classic Part Number**
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
310-1899	Pin As	393-0932

Sales Model 962H (Cont'd.)

PCW		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3P-1210	Cone-Roller Brg	399-4433
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695

PCW		
Original Part Number	Part Name	Classic Part Number
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-3831	Seal-O-Ring	436-2657
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182

PCW		
Original Part Number	Part Name	Classic Part Number
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
310-1899	Pin As	393-0932

SSA		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840

SSA		
Original Part Number	Part Name	Classic Part Number
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174

SSA		
Original Part Number	Part Name	Classic Part Number
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

Sales Model 962H (Cont'd.)

SSA		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3G-4704	Bearing-Sleeve	379-0185
3P-1210	Cone-Roller Brg	399-4433
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6E-0775	Head	425-9373
6E-5028	Rod As	425-9372
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689

SSA		
Original Part Number	**Part Name**	**Classic Part Number**
6P-8005	Gear-Planet	281-1691
6V-3831	Seal-O-Ring	436-2657
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9682	Bearing-Sleeve	360-2335
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182

SSA		
Original Part Number	**Part Name**	**Classic Part Number**
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932

Sales Model 962K

FLL		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347

Sales Model 962K (Cont'd.)

FLL		
Original Part Number	Part Name	Classic Part Number
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1V-8241	Bearing-Sleeve	308-9808
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5T-5682	Driver	418-9579
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-2233	Gear-Planet	281-1690

FLL		
Original Part Number	Part Name	Classic Part Number
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-1084	Impeller-Conv	380-1477
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9344	Bearing-Sleeve	360-2334
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7V-0638	Spacer	425-3651
8J-5778	Bearing-Sleeve	374-8359
8R-1088	Bearing-Sleeve	419-0885

FLL		
Original Part Number	Part Name	Classic Part Number
8R-4568	Piston	385-6108
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
310-1899	Pin As	393-0932

T6A		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1V-8241	Bearing-Sleeve	308-9808
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075

T6A		
Original Part Number	Part Name	Classic Part Number
2P-8986	Cup-Rlr Bearing	415-1912
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012

T6A		
Original Part Number	Part Name	Classic Part Number
5P-3930	Bearing As-Rlr	419-6022
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-1084	Impeller-Conv	380-1477

Sales Model 962K (Cont'd.)

T6A		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9344	Bearing-Sleeve	360-2334
7K-9639	Bearing-Sleeve	314-8643

T6A		
Original Part Number	**Part Name**	**Classic Part Number**
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7V-0638	Spacer	425-3651
8G-4022	Bearing	422-6920
8J-5778	Bearing-Sleeve	374-8359
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818

T6A		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
310-1899	Pin As	393-0932

X4T		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1V-8241	Bearing-Sleeve	308-9808
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-4502	Bearing-Sleeve	299-1986
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4J-0121	Cap-Bearing	360-2344
4T-8054	Seal As	472-8010

X4T		
Original Part Number	**Part Name**	**Classic Part Number**
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-1084	Impeller-Conv	380-1477
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562

X4T		
Original Part Number	**Part Name**	**Classic Part Number**
7B-7515	Bearing-Ball	399-6059
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-5131	Trunnion	296-1371
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7V-0638	Spacer	425-3651
8G-4022	Bearing	422-6920
8J-5778	Bearing-Sleeve	374-8359
8R-1088	Bearing-Sleeve	419-0885

Sales Model 962K (Cont'd.)

X4T		
Original Part Number	Part Name	Classic Part Number
8R-4568	Piston	385-6108
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818

X4T		
Original Part Number	Part Name	Classic Part Number
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
155-6648	Cone Spl Rol Brg	418-9599

X4T		
Original Part Number	Part Name	Classic Part Number
176-9273	Piston	297-4860
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932

Sales Model 962L

MTN		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-9295	Bearing-Cone	422-6480
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3B-4124	Cup-Spl Tapered	422-6481
3P-1210	Cone-Roller Brg	399-4433
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-8534	Retainer-Seal	300-2588
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5T-5682	Driver	418-9579
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074

MTN		
Original Part Number	Part Name	Classic Part Number
7J-8210	Cone-Roller Brg	423-6987
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
114-1071	Piston	388-6583
213-1365	Bearing-Sleeve	330-9256
265-5287	Ring-Seal	472-8028
310-1899	Pin As	393-0932
334-1032	Disc-Friction	440-3116
1T-0043	Bearing-Ball	390-5294
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-9295	Bearing-Cone	422-6480
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3B-4124	Cup-Spl Tapered	422-6481
3P-1210	Cone-Roller Brg	399-4433

MTN		
Original Part Number	Part Name	Classic Part Number
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-8534	Retainer-Seal	300-2588
4V-7099	Pin As	361-1698
4V-8520	Bearing-Sleeve	307-1527
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5T-5682	Driver	418-9579
5V-1508	Pin As.	361-1703
5V-1511	Pin As	418-1945
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7J-8210	Cone-Roller Brg	423-6987
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605

Wheel Loaders

Sales Model 962L (Cont'd.)

MTN		
Original Part Number	Part Name	Classic Part Number
114-1071	Piston	388-6583
213-1365	Bearing-Sleeve	330-9256

MTN		
Original Part Number	Part Name	Classic Part Number
265-5287	Ring-Seal	472-8028
310-1899	Pin As	393-0932

MTN		
Original Part Number	Part Name	Classic Part Number
334-1032	Disc-Friction	440-3116

Sales Model 962M

EJB		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1V-8241	Bearing-Sleeve	308-9808
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-4502	Bearing-Sleeve	299-1986
2K-9295	Bearing-Cone	422-6480
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3B-4124	Cup-Spl Tapered	422-6481
3P-1210	Cone-Roller Brg	399-4433
4B-9373	Cone-Roller Brg	399-4440

EJB		
Original Part Number	Part Name	Classic Part Number
4B-9374	Bearing-Cup	380-7494
4E-8534	Retainer-Seal	300-2588
5K-0983	Seal-Lip Type	472-8012
5T-5682	Driver	418-9579
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7J-8210	Cone-Roller Brg	423-6987
7J-9344	Bearing-Sleeve	360-2334
7K-0078	Bearing-Sleeve	308-9825
7K-9639	Bearing-Sleeve	314-8643

EJB		
Original Part Number	Part Name	Classic Part Number
8G-4022	Bearing	422-6920
8J-5778	Bearing-Sleeve	374-8359
9J-5875	Bearing-Sleeve	308-9830
9M-1328	Bearing-Aligning	325-6018
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
114-1071	Piston	388-6583
213-1365	Bearing-Sleeve	330-9256
265-5287	Ring-Seal	472-8028
334-1032	Disc-Friction	440-3116

F2T		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1V-8241	Bearing-Sleeve	308-9808
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-9295	Bearing-Cone	422-6480
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3B-4124	Cup-Spl Tapered	422-6481
3P-1210	Cone-Roller Brg	399-4433

F2T		
Original Part Number	Part Name	Classic Part Number
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-8534	Retainer-Seal	300-2588
5K-0983	Seal-Lip Type	472-8012
5T-5682	Driver	418-9579
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7J-8210	Cone-Roller Brg	423-6987

F2T		
Original Part Number	Part Name	Classic Part Number
7J-9344	Bearing-Sleeve	360-2334
7K-9639	Bearing-Sleeve	314-8643
9M-1328	Bearing-Aligning	325-6018
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
114-1071	Piston	388-6583
213-1365	Bearing-Sleeve	330-9256
265-5287	Ring-Seal	472-8028
334-1032	Disc-Friction	440-3116

Sales Model 962M (Cont'd.)

J2S		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
1V-8241	Bearing-Sleeve	308-9808
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-9295	Bearing-Cone	422-6480
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3B-4124	Cup-Spl Tapered	422-6481
3P-1210	Cone-Roller Brg	399-4433

J2S		
Original Part Number	**Part Name**	**Classic Part Number**
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-8534	Retainer-Seal	300-2588
5K-0983	Seal-Lip Type	472-8012
5T-5682	Driver	418-9579
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074

J2S		
Original Part Number	**Part Name**	**Classic Part Number**
7J-8210	Cone-Roller Brg	423-6987
9M-1328	Bearing-Aligning	325-6018
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
114-1071	Piston	388-6583
213-1365	Bearing-Sleeve	330-9256
265-5287	Ring-Seal	472-8028
334-1032	Disc-Friction	440-3116

JYD		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
1V-8241	Bearing-Sleeve	308-9808
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3P-1210	Cone-Roller Brg	399-4433

JYD		
Original Part Number	**Part Name**	**Classic Part Number**
4E-8534	Retainer-Seal	300-2588
5K-0983	Seal-Lip Type	472-8012
5T-5682	Driver	418-9579
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7J-8210	Cone-Roller Brg	423-6987
9M-1328	Bearing-Aligning	325-6018
9W-9930	Mount As	295-6437

JYD		
Original Part Number	**Part Name**	**Classic Part Number**
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
114-1071	Piston	388-6583
213-1365	Bearing-Sleeve	330-9256
265-5287	Ring-Seal	472-8028
334-1032	Disc-Friction	440-3116

LSE		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
1V-8241	Bearing-Sleeve	308-9808
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-9295	Bearing-Cone	422-6480
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3B-4124	Cup-Spl Tapered	422-6481
3P-1210	Cone-Roller Brg	399-4433

LSE		
Original Part Number	**Part Name**	**Classic Part Number**
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-8534	Retainer-Seal	300-2588
5K-0983	Seal-Lip Type	472-8012
5T-5682	Driver	418-9579
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074

LSE		
Original Part Number	**Part Name**	**Classic Part Number**
7J-8210	Cone-Roller Brg	423-6987
9M-1328	Bearing-Aligning	325-6018
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
114-1071	Piston	388-6583
213-1365	Bearing-Sleeve	330-9256
265-5287	Ring-Seal	472-8028
334-1032	Disc-Friction	440-3116

Wheel Loaders

Sales Model 962M (Cont'd.)

RCL		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0043	Bearing-Ball	390-5294
1V-8241	Bearing-Sleeve	308-9808
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-9295	Bearing-Cone	422-6480
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3B-4124	Cup-Spl Tapered	422-6481
3P-1210	Cone-Roller Brg	399-4433

RCL		
Original Part Number	**Part Name**	**Classic Part Number**
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-8534	Retainer-Seal	300-2588
5K-0983	Seal-Lip Type	472-8012
5T-5682	Driver	418-9579
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074

RCL		
Original Part Number	**Part Name**	**Classic Part Number**
7J-8210	Cone-Roller Brg	423-6987
9M-1328	Bearing-Aligning	325-6018
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
114-1071	Piston	388-6583
213-1365	Bearing-Sleeve	330-9256
265-5287	Ring-Seal	472-8028
334-1032	Disc-Friction	440-3116

Sales Model 964K

N8K		
Original Part Number	**Part Name**	**Classic Part Number**
1M-6573	Cup-Roller Brg	399-4438
1P-3935	Cone-Roller Brg	377-7397
2P-8986	Cup-Rlr Bearing	415-1912
3P-8186	Housing-Screen	390-5261
3R-8530	Boss	425-3454
4E-3196	Pin As	361-1697
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526

N8K		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-6659	Bearing	417-4511
5M-6126	Bearing	377-7433
5M-7936	Bearing-Outer	386-4953
5P-5411	Race-Brg Outer	417-9481

N8K		
Original Part Number	**Part Name**	**Classic Part Number**
6B-3223	Cup-Bearing	399-6065
6K-5528	Cup-Roller Brg	447-8059
6K-8275	Cone-Roller Brg	399-6070
7V-6715	Pin As	361-1701
9M-1328	Bearing-Aligning	325-6018
100-8010	Valve	423-5583
161-3411	Gasket	394-0896
213-1365	Bearing-Sleeve	330-9256

Sales Model 966A

33A		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-4493	Cone-Spl Tapered	386-4939
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347

33A		
Original Part Number	**Part Name**	**Classic Part Number**
1M-0090	Gasket-Manifold	445-7701
1M-5270	Pipe-Extension	367-6065
1M-7250	Bowl	360-2296
1P-1367	Plunger-Valve	432-8913

33A		
Original Part Number	**Part Name**	**Classic Part Number**
1S-1888	Bracket-Lamp	297-7147
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040

Sales Model 966A (Cont'd.)

33A		
Original Part Number	Part Name	Classic Part Number
1T-0210	Bearing-Ball	417-4498
1T-0406	Wheel-Impeller	384-3854
1T-0555	Carrier-Gde Whl	384-3853
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1701	Carrier-Stator	384-3853
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1T-1988	Shaft-Output	428-6656
1T-1991	Stator As-Conv	380-1482
1V-1080	Housing-Brg Spt	260-0775
1V-5724	Diff Gp -A	260-0776
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2H-3517	Bearing-Inner	417-4505
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-4442	Bearing-Sleeve	308-9812
2K-4507	Bearing-Sleeve	325-6021
2K-4513	Bearing-Sleeve	308-9814
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934

33A		
Original Part Number	Part Name	Classic Part Number
2S-6150	Cover-Pulley	428-8817
3B-3967	Race-Roller Brg	386-4947
3B-8845	Bearing-Inner	417-4509
3G-7658	Cartridge Gp	426-0427
3G-7661	Cartridge Gp	422-8113
3H-8726	Mount As	385-7208
3K-0526	Bearing-Ball	386-4949
3K-0963	Pin-Lock	308-9895
3K-2511	Dowel-Reaction	383-2126
3K-4290	Rod End	374-1823
3K-7020	Gear-Planet	221-9074
3L-1425	Bearing-Ball	311-9356
3S-2616	Pump Gp-Trans	226-0165
3S-5017	Elbow-Exhaust	369-9498
3T-2095	Bearing-Sleeve	384-3459
3V-2281	Link As	299-2023
4K-9598	Retainer	297-7235
4M-3915	Bearing-Caged	377-7427
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5K-1068	Retainer-Seal	260-0786
5K-5927	Boss	299-1973
5K-7995	Bearing-Sleeve	308-9820
5K-8265	Pin	241-2590
5K-8591	Bearing-Outer	380-7502
5L-7632	Support-Elbow	433-9854
5M-2824	Coupling-Exhaust	431-5270
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5V-1274	Spider	385-6110
5V-5279	Bearing-Sleeve	299-1966
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg	333-4954
6K-7284	Pin	241-2591

33A		
Original Part Number	Part Name	Classic Part Number
6K-8307	Pin	241-2593
6K-8308	Pin	241-2594
6K-8309	Pin	241-2595
6K-8311	Pin	241-2599
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7G-3454	Gear-Planet	300-2578
7J-9344	Bearing-Sleeve	360-2334
7J-9682	Bearing-Sleeve	360-2335
7K-0686	Trunnion-Rear	297-7266
7K-9513	Pin	241-2596
7K-9514	Pin	241-2597
7K-9515	Pin	241-2589
7K-9638	Bearing-Sleeve	365-8827
7K-9639	Bearing-Sleeve	314-8643
7K-9640	Bearing-Sleeve	389-6328
7K-9642	Bearing-Sleeve	360-2340
7K-9643	Bearing-Sleeve	445-7707
7K-9644	Bearing-Sleeve	360-2341
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7N-0113	Core As-Oclr	388-0564
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-5283	Plate	299-2043
8K-5334	Pin	241-2598
8N-8220	Bearing-Conn Rod	377-5860

Wheel Loaders

Sales Model 966A (Cont'd.)

33A		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1918	Gear-Planet	283-5210
8S-9686	Gasket Kit	393-5215

33A		
Original Part Number	**Part Name**	**Classic Part Number**
8V-3134	Pinion-Bevel	260-0788
8W-9566	Flange As	376-9073
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9K-9156	Retainer As	297-7236
9K-9158	Bearing-Sleeve	299-1970
9M-5477	Bearing-Sleeve	374-6517
9S-9696	Spider As-Fan	383-3707
9T-5096	Flexplate	455-3271

33A		
Original Part Number	**Part Name**	**Classic Part Number**
108-5603	Screw-Adj Arm	379-0166
121-7746	Pre-Cleaner As	360-2311
169-4200	Gasket	472-8023
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
308-1845	Seal-Wiper	472-8032

Sales Model 966B

57H		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-5103	Cone-Roller Brg	380-7505
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1M-0090	Gasket-Manifold	445-7701
1M-5270	Pipe-Extension	367-6065
1M-8736	Cup-Roller Brg	423-7759
1P-1367	Plunger-Valve	432-8913
1S-1888	Bracket-Lamp	297-7147
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0210	Bearing-Ball	417-4498
1T-0555	Carrier-Gde Whl	384-3853
1T-0576	Bearing-Sleeve	379-0186

57H		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1428	Retainer-Brg	300-2587
1T-1701	Carrier-Stator	384-3853
1T-1987	Housing-Rotating	297-4864
1T-1988	Shaft-Output	428-6656
1T-1991	Stator As-Conv	380-1482
1V-1080	Housing-Brg Spt	260-0775
1V-5724	Diff Gp -A	260-0776
1V-6913	Tube As	435-4793
1W-7073	Rebuild Kt-Pump	383-3677
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-2654	Ring-Lock	380-1488
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-4442	Bearing-Sleeve	308-9812
2K-4507	Bearing-Sleeve	325-6021
2K-4513	Bearing-Sleeve	308-9814

57H		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505
2K-6413	Pin	360-2270
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6739	Pulley-Tightener	298-2794
2V-6221	Shaft-Planet	221-9108
3G-2834	Cartridge Gp-Rr	426-0025
3G-7657	Cartridge Gp	422-8101
3H-8726	Mount As	385-7208
3J-9325	Piston	390-0993

Sales Model 966B (Cont'd.)

57H		
Original Part Number	Part Name	Classic Part Number
3K-0526	Bearing-Ball	386-4949
3K-0963	Pin-Lock	308-9895
3K-2511	Dowel-Reaction	383-2126
3K-4290	Rod End	374-1823
3K-7020	Gear-Planet	221-9074
3L-1425	Bearing-Ball	311-9356
3S-5017	Elbow-Exhaust	369-9498
3V-2281	Link As	299-2023
4D-2619	Bearing	417-4494
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4K-6212	Shaft-Bev Pinion	223-4806
4K-6558	Pin-Lower	302-2710
4K-6736	Drum-Brake	223-6320
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4K-7556	Yoke	385-6118
4K-8225	Pin-Cylinder	297-7215
4K-8561	Pin	299-2036
4K-8734	Bearing-Sleeve	299-1962
4K-9598	Retainer	297-7235
4M-3915	Bearing-Caged	377-7427
4V-0015	Plate-Lock	282-6563
5F-8651	Bearing-Ball	420-3223
5H-7071	Director-Water	388-0555
5K-0609	Cover	308-9843
5K-5927	Boss	299-1973
5K-5933	Cover As	247-4125
5K-7995	Bearing-Sleeve	308-9820
5K-8265	Pin	241-2590
5K-8591	Bearing-Outer	380-7502
5L-7632	Support-Elbow	433-9854

57H		
Original Part Number	Part Name	Classic Part Number
5M-5856	Pipe-Extension	373-1913
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-8543	Bearing-Sleeve	376-3635
5V-1274	Spider	385-6110
5V-5279	Bearing-Sleeve	299-1966
6B-6224	Ferrule	419-4738
6H-2577	Spider Gp-Brg	333-4954
6K-4442	Rod End-Special	373-5388
6K-4599	Yoke As	385-6111
6K-4600	Yoke	226-5993
6K-7284	Pin	241-2591
6K-8307	Pin	241-2593
6K-8308	Pin	241-2594
6K-8309	Pin	241-2595
6K-8311	Pin	241-2599
6V-2202	Bearing-Spl Ball	380-1574
7E-5085	Bushing	377-5829
7G-3454	Gear-Planet	300-2578
7J-9344	Bearing-Sleeve	360-2334
7J-9365	Bearing-Sleeve	453-6507
7J-9366	Bearing-Sleeve	299-1985
7J-9367	Rod As	469-4660
7J-9682	Bearing-Sleeve	360-2335
7J-9731	Bearing-Sleeve	308-9822
7K-0449	Yoke As	297-7271
7K-0450	Yoke As	297-7272
7K-0686	Trunnion-Rear	297-7266
7K-7200	Pin	241-2600
7K-9513	Pin	241-2596
7K-9514	Pin	241-2597
7K-9515	Pin	241-2589
7K-9638	Bearing-Sleeve	365-8827

57H		
Original Part Number	Part Name	Classic Part Number
7K-9639	Bearing-Sleeve	314-8643
7K-9640	Bearing-Sleeve	389-6328
7K-9642	Bearing-Sleeve	360-2340
7K-9643	Bearing-Sleeve	445-7707
7K-9644	Bearing-Sleeve	360-2341
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901
7M-4603	Body-Fuel Valve	311-9348
7M-7358	Valve-Inlet	298-2774
7N-0113	Core As-Oclr	388-0564
7N-2957	Cover-Rad Cap	361-1722
7N-5511	Gear As-Idler	233-2180
7N-7386	Gasket-Cyl Head	392-4519
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8F-3170	Bearing-Roller	417-4504
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-5283	Plate	299-2043
8K-5334	Pin	241-2598
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1918	Gear-Planet	283-5210
8S-9686	Gasket Kit	393-5215
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788

Sales Model 966B (Cont'd.)

57H		
Original Part Number	**Part Name**	**Classic Part Number**
8W-9566	Flange As	376-9073
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-2433	Cylinder As	480-8276
9J-5049	Pump Gp-Vn Bsc-B	422-8156
9K-1193	Gear-Sun	221-9099
9K-3413	Gear-Bevel	223-4807

57H		
Original Part Number	**Part Name**	**Classic Part Number**
9K-9156	Retainer As	297-7236
9K-9158	Bearing-Sleeve	299-1970
9M-5477	Bearing-Sleeve	374-6517
9M-8281	Gear As-Pump	325-6089
9S-9696	Spider As-Fan	383-3707
108-5603	Screw-Adj Arm	379-0166
124-3237	Precleaner As	432-4220

57H		
Original Part Number	**Part Name**	**Classic Part Number**
169-4200	Gasket	472-8023
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 966C

18B		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-8554	Coupling-Exhaust	325-6052
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0406	Wheel-Impeller	384-3854
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1691	Impeller-Conv	297-4863
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1V-1080	Housing-Brg Spt	260-0775
1V-3995	Pin	319-3449
1V-5724	Diff Gp -A	260-0776
1V-6913	Tube As	435-4793

18B		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989

18B		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5103	Cone-Roller Brg	380-7505
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2S-6097	Tang	375-9979
2V-6221	Shaft-Planet	221-9108
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055

Sales Model 966C (Cont'd.)

18B		
Original Part Number	Part Name	Classic Part Number
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3G-7667	Cartridge Gp	422-8107
3H-8726	Mount As	385-7208
3J-9325	Piston	390-0993
3K-0963	Pin-Lock	308-9895
3K-7020	Gear-Planet	221-9074
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3V-2281	Link As	299-2023
3V-7427	Housing As	297-7197
4K-6212	Shaft-Bev Pinion	223-4806
4K-6558	Pin-Lower	302-2710
4K-6736	Drum-Brake	223-6320
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4K-8225	Pin-Cylinder	297-7215
4K-8561	Pin	299-2036
4K-8734	Bearing-Sleeve	299-1962
4K-9598	Retainer	297-7235
4M-3915	Bearing-Caged	377-7427
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7693	Crankshaft As	269-8763

18B		
Original Part Number	Part Name	Classic Part Number
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-0509	Pump Gp-Vn Bsc-B	422-8159
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-6869	Spacer-Fuel Pump	417-4534
5D-0470	Valve Gp-Qrel	314-8549
5G-3612	Cap Gp-Protn	295-6419
5K-0609	Cover	308-9843
5K-2294	Bearing	396-9912
5K-5927	Boss	299-1973
5K-5933	Cover As	247-4125
5K-8265	Pin	241-2590
5M-0578	Bearing	419-7775
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

18B		
Original Part Number	Part Name	Classic Part Number
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-5279	Bearing-Sleeve	299-1966
6B-7469	Spacer	417-4535
6E-4258	Cartridge	422-8133
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2034	Shaft	297-7249
6K-4442	Rod End-Special	373-5388
6K-8307	Pin	241-2593
6K-8308	Pin	241-2594
6K-8309	Pin	241-2595
6K-8311	Pin	241-2599
6K-8895	Cap	374-6500
6K-8897	Bracket As	299-1977
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-2090	Base-Xmsn O Fil	397-5049
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-3651	Pump Gp-Gr 1 Bsc	345-1978
6T-5383	Gear-Ring	375-2624
6V-2202	Bearing-Spl Ball	380-1574
6V-5413	Gasket Kit	390-5291
6V-5414	Gasket Kit	434-7289

Sales Model 966C (Cont'd.)

18B		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9344	Bearing-Sleeve	360-2334
7J-9365	Bearing-Sleeve	453-6507
7J-9366	Bearing-Sleeve	299-1985
7J-9367	Rod As	469-4660
7K-0449	Yoke As	297-7271
7K-0450	Yoke As	297-7272
7K-0686	Trunnion-Rear	297-7266
7K-7200	Pin	241-2600
7K-8890	Tube As	391-1098
7K-9513	Pin	241-2596
7K-9514	Pin	241-2597
7K-9515	Pin	241-2589
7K-9638	Bearing-Sleeve	365-8827
7K-9639	Bearing-Sleeve	314-8643
7K-9640	Bearing-Sleeve	389-6328
7K-9642	Bearing-Sleeve	360-2340
7K-9643	Bearing-Sleeve	445-7707
7K-9644	Bearing-Sleeve	360-2341
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816

18B		
Original Part Number	**Part Name**	**Classic Part Number**
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7T-1285	Gear-Planet	297-7190
7T-2036	Cap As-Fuel	361-1721
7T-3343	Plate-Clutch	297-7231
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-3170	Bearing-Roller	417-4504
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342

18B		
Original Part Number	**Part Name**	**Classic Part Number**
8K-5283	Plate	299-2043
8K-5334	Pin	241-2598
8K-6282	Gear-Sun	281-1698
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083

Sales Model 966C (Cont'd.)

18B		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-3134	Pinion-Bevel	260-0788
9B-1320	Valve-Check	377-5832
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9G-8117	Housing As-Cl	302-2686
9J-2433	Cylinder As	480-8276
9K-1193	Gear-Sun	221-9099
9K-1773	Gear-Ring	221-9100
9K-3413	Gear-Bevel	223-4807
9K-9156	Retainer As	297-7236
9K-9158	Bearing-Sleeve	299-1970
9L-2685	Rod End	419-1866
9M-5477	Bearing-Sleeve	374-6517
9N-4460	Housing As-Cl	297-7203
9N-5251	Piston Gp-Bsc	250-6557
9N-5769	Cover-Housing	325-6050
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891

18B		
Original Part Number	**Part Name**	**Classic Part Number**
9S-6147	Body As	369-9499
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-9657	Bearing-Spl Ball	371-4308
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
123-3472	Pump Gp-Gr 1 Bsc	345-1978
131-3815	Seal Gp-Basic	325-6193
139-9177	Gasket Kit	377-7465
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361
155-1379	Gasket Kit - Sch	386-3815
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484

18B		
Original Part Number	**Part Name**	**Classic Part Number**
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
176-9273	Piston	297-4860
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
250-6556	Kit-Liner-Cla	250-6564
250-6557	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-6872	Kit-Dt Gasket	394-8228
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
345-1976	Pump-Gr-Cla	345-1978
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 966C (Cont'd.)

25U		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1M-8736	Cup-Roller Brg	423-7759
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4231	Pump Gp-Gear	226-0156
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0020	Wheel-Turbine	297-4862
1T-0210	Bearing-Ball	417-4498
1T-0406	Wheel-Impeller	384-3854
1T-0555	Carrier-Gde Whl	384-3853
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1701	Carrier-Stator	384-3853
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1T-1988	Shaft-Output	428-6656
1V-1080	Housing-Brg Spt	260-0775
1V-3995	Pin	319-3449
1V-5724	Diff Gp -A	260-0776
1V-6913	Tube As	435-4793
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513

25U		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-4507	Bearing-Sleeve	325-6021
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2V-6221	Shaft-Planet	221-9108
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088

25U		
Original Part Number	**Part Name**	**Classic Part Number**
2W-9978	Core As-Oclr	279-4983
3G-2834	Cartridge Gp-Rr	426-0025
3G-7657	Cartridge Gp	422-8101
3J-9325	Piston	390-0993
3K-0526	Bearing-Ball	386-4949
3K-0963	Pin-Lock	308-9895
3K-4290	Rod End	374-1823
3K-7020	Gear-Planet	221-9074
3L-1425	Bearing-Ball	311-9356
3P-5955	Disc-Friction	428-7205
3T-2095	Bearing-Sleeve	384-3459
3V-5762	Support As	389-6310
3V-7427	Housing As	297-7197
4K-6212	Shaft-Bev Pinion	223-4806
4K-6558	Pin-Lower	302-2710
4K-6736	Drum-Brake	223-6320
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4K-7556	Yoke	385-6118
4K-8225	Pin-Cylinder	297-7215
4K-8561	Pin	299-2036
4K-8734	Bearing-Sleeve	299-1962
4K-9598	Retainer	297-7235
4M-3915	Bearing-Caged	377-7427
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053

Sales Model 966C (Cont'd.)

25U		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-5891	Plate-Clutch	388-0575
4S-5943	Piston-Clutch	221-9112
4S-8530	Shaft-Planet	221-9111
4S-8534	Shaft As-Planet	221-9116
4S-8538	Bearing-Spl Ball	417-4502
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-6869	Spacer-Fuel Pump	417-4534
5D-0470	Valve Gp-Qrel	314-8549
5K-0609	Cover	308-9843
5K-2294	Bearing	396-9912
5K-5933	Cover As	247-4125
5K-8265	Pin	241-2590
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5P-2526	Cup-Rlr Bearing	380-7498
5P-8768	Kit-Gasket (Scl)	393-1024
5S-4326	Housing-Screen	435-4790
5S-5879	Bracket-Shaft	330-9247

25U		
Original Part Number	Part Name	Classic Part Number
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-6978	Shaft-Planet	221-9103
5S-7010	Shaft-Planet	221-9104
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5V-1274	Spider	385-6110
5V-5279	Bearing-Sleeve	299-1966
6B-7469	Spacer	417-4535
6H-2577	Spider Gp-Brg	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2034	Shaft	297-7249
6K-4442	Rod End-Special	373-5388
6K-4599	Yoke As	385-6111
6K-6046	Pin	241-2602
6K-6047	Pin	241-2603
6K-6053	Pin	241-2604
6K-6054	Pin	241-2605
6K-6175	Pin	241-2606
6K-8307	Pin	241-2593
6K-8308	Pin	241-2594
6K-8309	Pin	241-2595
6K-8311	Pin	241-2599
6K-8895	Cap	374-6500
6K-8897	Bracket As	299-1977
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6Y-2027	Disc-Friction	377-7441
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5348	Disc-Friction	384-4827
7C-3862	Camshaft	458-0151
7E-5085	Bushing	377-5829

25U		
Original Part Number	Part Name	Classic Part Number
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2487	Gear-Planet	221-9092
7J-9344	Bearing-Sleeve	360-2334
7J-9365	Bearing-Sleeve	453-6507
7J-9366	Bearing-Sleeve	299-1985
7J-9367	Rod As	469-4660
7K-0449	Yoke As	297-7271
7K-0450	Yoke As	297-7272
7K-0686	Trunnion-Rear	297-7266
7K-7176	Pin	241-2570
7K-7200	Pin	241-2600
7K-8890	Tube As	391-1098
7K-9343	Pin	241-2571
7K-9344	Pin	241-2607
7K-9345	Pin	241-2608
7K-9513	Pin	241-2596
7K-9514	Pin	241-2597
7K-9515	Pin	241-2589
7K-9589	Bearing-Sleeve	453-6509
7K-9601	Bearing-Sleeve	360-2338
7K-9602	Bearing-Sleeve	360-2339
7K-9604	Bearing-Sleeve	308-9829
7K-9638	Bearing-Sleeve	365-8827
7K-9639	Bearing-Sleeve	314-8643
7K-9640	Bearing-Sleeve	389-6328
7K-9642	Bearing-Sleeve	360-2340
7K-9643	Bearing-Sleeve	445-7707
7K-9644	Bearing-Sleeve	360-2341
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451

Sales Model 966C (Cont'd.)

25U		
Original Part Number	**Part Name**	**Classic Part Number**
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5511	Gear As-Idler	233-2180
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-3170	Bearing-Roller	417-4504
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-5283	Plate	299-2043
8K-5334	Pin	241-2598
8K-6282	Gear-Sun	281-1698
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037

25U		
Original Part Number	**Part Name**	**Classic Part Number**
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083

25U		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1656	Plate-Clutch	367-6071
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6380	Tube As	452-0446
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-2466	Gasket Kit	393-5199
8V-3134	Pinion-Bevel	260-0788
9B-1320	Valve-Check	377-5832
9J-2433	Cylinder As	480-8276
9J-5049	Pump Gp-Vn Bsc-B	422-8156
9K-1193	Gear-Sun	221-9099
9K-1773	Gear-Ring	221-9100
9K-3413	Gear-Bevel	223-4807
9K-9156	Retainer As	297-7236
9K-9158	Bearing-Sleeve	299-1970
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
139-9176	Gasket Kit	390-5283
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554

Sales Model 966C (Cont'd.)

25U		
Original Part Number	**Part Name**	**Classic Part Number**
144-0744	Compressor Gp -B	435-6046
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

25U		
Original Part Number	**Part Name**	**Classic Part Number**
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
216-5361	Kit - Gasket	383-2109
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085

25U		
Original Part Number	**Part Name**	**Classic Part Number**
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955

30K		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1T-0210	Bearing-Ball	417-4498
1T-0576	Bearing-Sleeve	379-0186
1W-3900	Gasket	472-8006
2A-4576	Cup-Roller Brg	386-4944
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989

30K		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5103	Cone-Roller Brg	380-7505
2P-0220	Gasket-Pump	398-2927
3K-0526	Bearing-Ball	386-4949
3T-2095	Bearing-Sleeve	384-3459
4S-8538	Bearing-Spl Ball	417-4502
4W-0452	Seal As -Cshaft	325-6191
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5P-2526	Cup-Rlr Bearing	380-7498
5P-8768	Kit-Gasket (Scl)	393-1024
6N-7263	Gasket-Cyl Head	380-7386

30K		
Original Part Number	**Part Name**	**Classic Part Number**
6V-1339	Gasket Kit	388-0651
6Y-3484	Bearing-Spl Ball	416-2166
7F-2742	Bearing-Ball	422-6488
7S-3002	Bearing-Spl Ball	386-4961
8T-0072	Cone-Rlr Brg	377-7448
8T-2466	Gasket Kit	393-5199
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
139-9176	Gasket Kit	390-5283
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
174-6836	Gasket Kit - Tof	434-7280
216-5361	Kit - Gasket	383-2109

Sales Model 966C (Cont'd.)

42J		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1T-0210	Bearing-Ball	417-4498
1T-0576	Bearing-Sleeve	379-0186
1W-3900	Gasket	472-8006
2A-4576	Cup-Roller Brg	386-4944
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505

42J		
Original Part Number	**Part Name**	**Classic Part Number**
2P-0220	Gasket-Pump	398-2927
3K-0526	Bearing-Ball	386-4949
3L-1425	Bearing-Ball	311-9356
3T-2095	Bearing-Sleeve	384-3459
4K-7463	Seal-Lip Type	472-8007
4S-8538	Bearing-Spl Ball	417-4502
4W-0452	Seal As -Cshaft	325-6191
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5P-2526	Cup-Rlr Bearing	380-7498
5P-8768	Kit-Gasket (Scl)	393-1024
6N-7263	Gasket-Cyl Head	380-7386
6V-1339	Gasket Kit	388-0651

42J		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-3484	Bearing-Spl Ball	416-2166
7C-4297	Seal As-Cshaft	325-6192
7F-2742	Bearing-Ball	422-6488
7S-3002	Bearing-Spl Ball	386-4961
7S-3206	Seal-O-Ring	436-2656
8C-8741	Kit-Gasket-(Rs)	438-0172
8H-9789	Bearing-Ball	374-8342
8T-0072	Cone-Rlr Brg	377-7448
8T-2466	Gasket Kit	393-5199
111-8015	Gasket As-Head	279-4977
131-3815	Seal Gp-Basic	325-6193
139-9176	Gasket Kit	390-5283
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
174-6836	Gasket Kit - Tof	434-7280
216-5361	Kit - Gasket	383-2109

76J		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1M-7250	Bowl	360-2296
1M-8736	Cup-Roller Brg	423-7759
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4231	Pump Gp-Gear	226-0156
1P-4303	Head As-Cylinder	242-3434
1P-8554	Coupling-Exhaust	325-6052
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1T-0020	Wheel-Turbine	297-4862
1T-0210	Bearing-Ball	417-4498
1T-0406	Wheel-Impeller	384-3854
1T-0555	Carrier-Gde Whl	384-3853

76J		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1701	Carrier-Stator	384-3853
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1T-1988	Shaft-Output	428-6656
1T-1991	Stator As-Conv	380-1482
1V-1080	Housing-Brg Spt	260-0775
1V-3995	Pin	319-3449
1V-5724	Diff Gp -A	260-0776
1V-6913	Tube As	435-4793
1W-1219	Trunnion As	314-8724
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-6473	Compressor Gp -B	448-9150
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513

76J		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-4442	Bearing-Sleeve	308-9812
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2K-4513	Bearing-Sleeve	308-9814
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505

Sales Model 966C (Cont'd.)

76J		
Original Part Number	**Part Name**	**Classic Part Number**
2K-6413	Pin	360-2270
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-5608	Pipe-Extension	367-6066
2P-5609	Muffler As.	247-2665
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2V-6221	Shaft-Planet	221-9108
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3G-2834	Cartridge Gp-Rr	426-0025
3G-7657	Cartridge Gp	422-8101
3H-8726	Mount As	385-7208
3J-9325	Piston	390-0993
3K-0526	Bearing-Ball	386-4949

76J		
Original Part Number	**Part Name**	**Classic Part Number**
3K-0963	Pin-Lock	308-9895
3K-4290	Rod End	374-1823
3K-7020	Gear-Planet	221-9074
3L-1425	Bearing-Ball	311-9356
3P-5672	Yoke	223-6313
3P-5955	Disc-Friction	428-7205
3S-5017	Elbow-Exhaust	369-9498
3T-2095	Bearing-Sleeve	384-3459
3V-2281	Link As	299-2023
3V-5762	Support As	389-6310
3V-7427	Housing As	297-7197
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4K-6212	Shaft-Bev Pinion	223-4806
4K-6558	Pin-Lower	302-2710
4K-6736	Drum-Brake	223-6320
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4K-7556	Yoke	385-6118
4K-8225	Pin-Cylinder	297-7215
4K-8561	Pin	299-2036
4K-8734	Bearing-Sleeve	299-1962
4K-9598	Retainer	297-7235
4M-3915	Bearing-Caged	377-7427
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362

76J		
Original Part Number	**Part Name**	**Classic Part Number**
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3927	Compressor As	435-6051
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4S-5891	Plate-Clutch	388-0575
4S-5943	Piston-Clutch	221-9112
4S-8530	Shaft-Planet	221-9111
4S-8534	Shaft As-Planet	221-9116
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5G-3612	Cap Gp-Protn	295-6419
5K-0609	Cover	308-9843
5K-2294	Bearing	396-9912
5K-5927	Boss	299-1973
5K-5933	Cover As	247-4125
5K-7995	Bearing-Sleeve	308-9820
5K-8265	Pin	241-2590
5L-6326	Bearing-Ball	420-3222
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5M-5856	Pipe-Extension	373-1913
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024

Sales Model 966C (Cont'd.)

76J		
Original Part Number	**Part Name**	**Classic Part Number**
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4326	Housing-Screen	435-4790
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-6978	Shaft-Planet	221-9103
5S-7010	Shaft-Planet	221-9104
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-5279	Bearing-Sleeve	299-1966
6B-7469	Spacer	417-4535
6E-0775	Head	425-9373
6H-2577	Spider Gp-Brg	333-4954
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2034	Shaft	297-7249
6K-4442	Rod End-Special	373-5388
6K-4599	Yoke As	385-6111
6K-4600	Yoke	226-5993
6K-7284	Pin	241-2591
6K-8088	Bearing-Roller	399-4428
6K-8307	Pin	241-2593
6K-8308	Pin	241-2594
6K-8309	Pin	241-2595
6K-8311	Pin	241-2599
6K-8895	Cap	374-6500
6K-8897	Bracket As	299-1977
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886

76J		
Original Part Number	**Part Name**	**Classic Part Number**
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-1339	Gasket Kit	388-0651
6V-2202	Bearing-Spl Ball	380-1574
6Y-2027	Disc-Friction	377-7441
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5348	Disc-Friction	384-4827
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2487	Gear-Planet	221-9092
7J-9344	Bearing-Sleeve	360-2334
7J-9365	Bearing-Sleeve	453-6507
7J-9366	Bearing-Sleeve	299-1985
7J-9367	Rod As	469-4660
7J-9682	Bearing-Sleeve	360-2335
7J-9731	Bearing-Sleeve	308-9822
7K-0449	Yoke As	297-7271
7K-0450	Yoke As	297-7272
7K-0686	Trunnion-Rear	297-7266
7K-7200	Pin	241-2600
7K-8890	Tube As	391-1098
7K-9513	Pin	241-2596
7K-9514	Pin	241-2597
7K-9515	Pin	241-2589
7K-9638	Bearing-Sleeve	365-8827
7K-9639	Bearing-Sleeve	314-8643
7K-9640	Bearing-Sleeve	389-6328
7K-9642	Bearing-Sleeve	360-2340
7K-9643	Bearing-Sleeve	445-7707

76J		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9644	Bearing-Sleeve	360-2341
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5511	Gear As-Idler	233-2180
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7386	Gasket-Cyl Head	392-4519
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066

Sales Model 966C (Cont'd.)

76J		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-3170	Bearing-Roller	417-4504
8F-6058	Bearing-Sleeve	416-5494
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-5283	Plate	299-2043
8K-5334	Pin	241-2598
8K-6282	Gear-Sun	281-1698
8M-3368	Valve-Check	388-6599
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

76J		
Original Part Number	Part Name	Classic Part Number
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-1656	Plate-Clutch	367-6071
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3554	Yoke	448-9154
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6380	Tube As	452-0446
8S-6511	Bearing-Sleeve	380-7372
8S-9686	Gasket Kit	393-5215
8T-0072	Cone-Rlr Brg	377-7448
8T-2466	Gasket Kit	393-5199
8V-3134	Pinion-Bevel	260-0788
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9J-2433	Cylinder As	480-8276
9J-5049	Pump Gp-Vn Bsc-B	422-8156

76J		
Original Part Number	Part Name	Classic Part Number
9K-1193	Gear-Sun	221-9099
9K-1773	Gear-Ring	221-9100
9K-3413	Gear-Bevel	223-4807
9K-9156	Retainer As	297-7236
9K-9158	Bearing-Sleeve	299-1970
9M-1328	Bearing-Aligning	325-6018
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9M-8281	Gear As-Pump	325-6089
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9T-8944	Cyl Gp-102 356 Y	393-3665
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
139-9176	Gasket Kit	390-5283
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361

Sales Model 966C (Cont'd.)

76J		
Original Part Number	**Part Name**	**Classic Part Number**
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687

76J		
Original Part Number	**Part Name**	**Classic Part Number**
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
174-6836	Gasket Kit - Tof	434-7280
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
216-5361	Kit - Gasket	383-2109
226-8202	Seal-Wiper	472-8024

76J		
Original Part Number	**Part Name**	**Classic Part Number**
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005

78G		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1N-3576	Block Gp-Cyl	279-4978
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1T-0210	Bearing-Ball	417-4498
1T-0576	Bearing-Sleeve	379-0186
1V-5724	Diff Gp -A	260-0776
1W-3900	Gasket	472-8006
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354

78G		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505
2P-0220	Gasket-Pump	398-2927
2P-2719	Pipe-Oil Filler	363-7454
2S-6097	Tang	375-9979
2W-2621	Valve-Inlet	247-6892
3K-0526	Bearing-Ball	386-4949
3K-0963	Pin-Lock	308-9895
3T-2095	Bearing-Sleeve	384-3459
3V-2281	Link As	299-2023
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4S-8538	Bearing-Spl Ball	417-4502
4W-0452	Seal As -Cshaft	325-6191

78G		
Original Part Number	**Part Name**	**Classic Part Number**
5K-5927	Boss	299-1973
5K-8265	Pin	241-2590
5M-0578	Bearing	419-7775
5M-2051	Bearing-Caged	380-7467
5P-2526	Cup-Rlr Bearing	380-7498
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-5279	Bearing-Sleeve	299-1966
6H-3957	Bearing-Ball	311-9358
6K-4442	Rod End-Special	373-5388
6K-8307	Pin	241-2593
6K-8308	Pin	241-2594
6K-8309	Pin	241-2595

Sales Model 966C (Cont'd.)

78G		
Original Part Number	**Part Name**	**Classic Part Number**
6K-8311	Pin	241-2599
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
7F-2742	Bearing-Ball	422-6488
7J-9344	Bearing-Sleeve	360-2334
7J-9365	Bearing-Sleeve	453-6507
7J-9366	Bearing-Sleeve	299-1985
7J-9367	Rod As	469-4660
7K-7200	Pin	241-2600
7K-8890	Tube As	391-1098
7K-9513	Pin	241-2596
7K-9514	Pin	241-2597
7K-9515	Pin	241-2589
7K-9638	Bearing-Sleeve	365-8827
7K-9639	Bearing-Sleeve	314-8643
7K-9640	Bearing-Sleeve	389-6328
7K-9642	Bearing-Sleeve	360-2340

78G		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9643	Bearing-Sleeve	445-7707
7K-9644	Bearing-Sleeve	360-2341
7M-4046	Bearing-Sleeve	394-8206
7N-2957	Cover-Rad Cap	361-1722
7N-8018	Seal-Water	418-1964
7S-3002	Bearing-Spl Ball	386-4961
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
8K-5283	Plate	299-2043
8K-5334	Pin	241-2598
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-4110	Bearing-Sleeve	394-8207
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081

78G		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8227	Bearing-Main	376-9082
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
8T-0072	Cone-Rlr Brg	377-7448
8T-2466	Gasket Kit	393-5199
8V-3134	Pinion-Bevel	260-0788
9J-2433	Cylinder As	480-8276
9K-9156	Retainer As	297-7236
9K-9158	Bearing-Sleeve	299-1970
9S-8679	Chamber As	325-6042
9Y-1798	Seal-Water	379-0165
111-8015	Gasket As-Head	279-4977
124-3237	Precleaner As	432-4220
131-3815	Seal Gp-Basic	325-6193
139-9176	Gasket Kit	390-5283
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
172-5188	Shaft-Water Pump	325-6202
172-6712	Impeller-Pump	325-6112
216-5361	Kit - Gasket	383-2109
255-2899	Pipe As-Tail	301-5246

9KC		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0406	Wheel-Impeller	384-3854

9KC		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1691	Impeller-Conv	297-4863
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1V-1080	Housing-Brg Spt	260-0775
1V-3995	Pin	319-3449
1V-5724	Diff Gp -A	260-0776
1V-6913	Tube As	435-4793
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

9KC		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914

Sales Model 966C (Cont'd.)

9KC		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9455	Cone-Roller Brg	415-1915
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2S-6097	Tang	375-9979
2V-6221	Shaft-Planet	221-9108
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3G-7667	Cartridge Gp	422-8107

9KC		
Original Part Number	**Part Name**	**Classic Part Number**
3H-8726	Mount As	385-7208
3J-9325	Piston	390-0993
3K-0963	Pin-Lock	308-9895
3K-7020	Gear-Planet	221-9074
3L-1425	Bearing-Ball	311-9356
3N-1968	Mount-Shock	397-5046
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3V-2281	Link As	299-2023
3V-7427	Housing As	297-7197
4K-6212	Shaft-Bev Pinion	223-4806
4K-6558	Pin-Lower	302-2710
4K-6736	Drum-Brake	223-6320
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4K-8225	Pin-Cylinder	297-7215
4K-8561	Pin	299-2036
4K-8734	Bearing-Sleeve	299-1962
4K-9598	Retainer	297-7235
4M-3915	Bearing-Caged	377-7427
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008

9KC		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-0509	Pump Gp-Vn Bsc-B	422-8159
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-6869	Spacer-Fuel Pump	417-4534
5D-0470	Valve Gp-Qrel	314-8549
5G-3612	Cap Gp-Protn	295-6419
5K-0609	Cover	308-9843
5K-2294	Bearing	396-9912
5K-5927	Boss	299-1973
5K-5933	Cover As	247-4125
5K-8265	Pin	241-2590
5M-0578	Bearing	419-7775
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5V-1274	Spider	385-6110
5V-5279	Bearing-Sleeve	299-1966

Sales Model 966C (Cont'd.)

9KC		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6E-4258	Cartridge	422-8133
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2034	Shaft	297-7249
6K-4442	Rod End-Special	373-5388
6K-8307	Pin	241-2593
6K-8308	Pin	241-2594
6K-8309	Pin	241-2595
6K-8311	Pin	241-2599
6K-8895	Cap	374-6500
6K-8897	Bracket As	299-1977
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-2090	Base-Xmsn O Fil	397-5049
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-3651	Pump Gp-Gr 1 Bsc	345-1978
6V-2202	Bearing-Spl Ball	380-1574
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4990	Case-Xmsn	388-6561

9KC		
Original Part Number	Part Name	Classic Part Number
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9344	Bearing-Sleeve	360-2334
7J-9365	Bearing-Sleeve	453-6507
7J-9366	Bearing-Sleeve	299-1985
7J-9367	Rod As	469-4660
7K-0449	Yoke As	297-7271
7K-0450	Yoke As	297-7272
7K-0686	Trunnion-Rear	297-7266
7K-7200	Pin	241-2600
7K-8890	Tube As	391-1098
7K-9513	Pin	241-2596
7K-9514	Pin	241-2597
7K-9515	Pin	241-2589
7K-9638	Bearing-Sleeve	365-8827
7K-9639	Bearing-Sleeve	314-8643
7K-9640	Bearing-Sleeve	389-6328
7K-9642	Bearing-Sleeve	360-2340
7K-9643	Bearing-Sleeve	445-7707
7K-9644	Bearing-Sleeve	360-2341
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781

9KC		
Original Part Number	Part Name	Classic Part Number
7N-2957	Cover-Rad Cap	361-1722
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7T-1285	Gear-Planet	297-7190
7T-2036	Cap As-Fuel	361-1721
7T-3343	Plate-Clutch	297-7231
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-3170	Bearing-Roller	417-4504
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-5283	Plate	299-2043
8K-5334	Pin	241-2598
8K-6282	Gear-Sun	281-1698
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858

Sales Model 966C (Cont'd.)

9KC		
Original Part Number	**Part Name**	**Classic Part Number**
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448

9KC		
Original Part Number	**Part Name**	**Classic Part Number**
8V-3134	Pinion-Bevel	260-0788
9B-1320	Valve-Check	377-5832
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9G-8117	Housing As-Cl	302-2686
9J-2433	Cylinder As	480-8276
9K-1193	Gear-Sun	221-9099
9K-1773	Gear-Ring	221-9100
9K-3413	Gear-Bevel	223-4807
9K-9156	Retainer As	297-7236
9K-9158	Bearing-Sleeve	299-1970
9L-2685	Rod End	419-1866
9M-5477	Bearing-Sleeve	374-6517
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-9657	Bearing-Spl Ball	371-4308
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9Y-1798	Seal-Water	379-0165
100-7860	Valve-Inlet	270-4360
109-7687	Bearing-Ball	420-3220
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
123-3472	Pump Gp-Gr 1 Bsc	345-1978
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554

9KC		
Original Part Number	**Part Name**	**Classic Part Number**
144-0744	Compressor Gp -B	435-6046
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
176-9273	Piston	297-4860
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
250-6556	Kit-Liner-Cla	250-6564
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357

Sales Model 966C (Cont'd.)

9KC		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988

9KC		
Original Part Number	Part Name	Classic Part Number
296-1360	Line As-Cla	279-4989
297-6872	Kit-Dt Gasket	394-8228
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349

9KC		
Original Part Number	Part Name	Classic Part Number
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
345-1976	Pump-Gr-Cla	345-1978

Sales Model 966D

11D		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-2936	Muffler As	298-2782
1N-2946	Extension-Exh	367-6064
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

11D		
Original Part Number	Part Name	Classic Part Number
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912

11D		
Original Part Number	Part Name	Classic Part Number
2V-5656	Ring-Snap	374-1454
2V-5709	Shaft-Axle	299-2056
2V-5714	Gear-Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3G-5264	Cylinder As.	393-1018
3G-5492	Rod As	377-5836
3G-5497	Cyl Gp-0210 0535	394-9822
3G-5502	Cylinder As	390-0988
3G-7660	Cartridge Gp	422-8103
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573

Sales Model 966D (Cont'd.)

11D		
Original Part Number	**Part Name**	**Classic Part Number**
4D-2619	Bearing	417-4494
4E-3456	Lever As	367-6081
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0422	Cartridge Gp	422-8129
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-5388	Shaft-Bev Pinion	297-7244

11D		
Original Part Number	**Part Name**	**Classic Part Number**
4V-5392	Spider	377-7430
4V-5393	Gear-Bevel	297-7189
4V-5394	Gear-Diff	297-7177
4V-5400	Housing-Brg Spt	385-7202
4V-6421	Pin As	319-3442
4V-7082	Joint Gp-Slip	367-6068
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-8518	Link As-Brg&	374-1450
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5053	Muffler As	360-7881
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481

11D		
Original Part Number	**Part Name**	**Classic Part Number**
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2387	Cartridge Gp	422-8132
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-8895	Cap	374-6500
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6W-9677	Tube As-Rh	388-6569
6W-9678	Tube As-Lh	388-6570
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074

Sales Model 966D (Cont'd.)

11D		
Original Part Number	Part Name	Classic Part Number
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7V-6716	Pin As	396-7273
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-9740	Gear-Output Tfr	432-8905

11D		
Original Part Number	Part Name	Classic Part Number
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081

11D		
Original Part Number	Part Name	Classic Part Number
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-6390	Drum-Brake	377-7449
8V-7659	Pin As	361-1702
8V-7885	Housing-Support	297-7193
9C-1484	Pin As	319-3446
9C-4007	Bearing-Sleeve	374-1459
9C-4080	Yoke-Brake	302-2703
9C-5852	Hub As	297-7208
9C-6015	Pinion-Diff Bev	297-7225
9C-8218	Shaft-Bev Pinion	302-2697
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9K-8757	Rod End-Special	311-9361

Sales Model 966D (Cont'd.)

11D		
Original Part Number	**Part Name**	**Classic Part Number**
9L-2685	Rod End	419-1866
9L-5836	Coupling-Exhaust	385-7212
9L-6371	Rod-Eye	363-7459
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5160	Plunger Kt-Adj	385-7218
9V-5174	Joint Gp-Univ	375-2628
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163

11D		
Original Part Number	**Part Name**	**Classic Part Number**
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
103-5961	Wheel	398-2963
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
124-2726	Head	377-5855
126-2522	Cone-Spl Tapered	377-7397
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
160-1400	Yoke (1710)	319-3479
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

11D		
Original Part Number	**Part Name**	**Classic Part Number**
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
216-7957	U-Joint	367-6069
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
443-1200	Brg-Rlr-Cla	377-7397

Sales Model 966D (Cont'd.)

2FD		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157

2FD		
Original Part Number	Part Name	Classic Part Number
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5709	Shaft-Axle	299-2056
2V-5714	Gear-Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2665	Cover	308-9842
3G-5264	Cylinder As.	393-1018
3G-5492	Rod As	377-5836
3G-5497	Cyl Gp-0210 0535	394-9822
3G-5502	Cylinder As	390-0988
3G-7660	Cartridge Gp	422-8103

2FD		
Original Part Number	Part Name	Classic Part Number
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
4D-2619	Bearing	417-4494
4E-3456	Lever As	367-6081
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0422	Cartridge Gp	422-8129
4T-8054	Seal As	472-8010

Sales Model 966D (Cont'd.)

2FD		
Original Part Number	**Part Name**	**Classic Part Number**
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-5388	Shaft-Bev Pinion	297-7244
4V-5392	Spider	377-7430
4V-5393	Gear-Bevel	297-7189
4V-5394	Gear-Diff	297-7177
4V-5400	Housing-Brg Spt	385-7202
4V-6421	Pin As	319-3442
4V-7082	Joint Gp-Slip	367-6068
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-8518	Link As-Brg&	374-1450
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5053	Muffler As	360-7881
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-2989	Bearing	380-7511
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022

2FD		
Original Part Number	**Part Name**	**Classic Part Number**
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6E-0775	Head	425-9373
6E-2387	Cartridge Gp	422-8132
6E-5028	Rod As	425-9372
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-8895	Cap	374-6500
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574

2FD		
Original Part Number	**Part Name**	**Classic Part Number**
6V-4350	Race-Spl Rlr Brg	384-5933
6W-9677	Tube As-Rh	388-6569
6W-9678	Tube As-Lh	388-6570
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7V-6716	Pin As	396-7273
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935

Sales Model 966D (Cont'd.)

2FD		
Original Part Number	Part Name	Classic Part Number
7W-5698	Pulley-Cshaft	295-5679
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

2FD		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-6390	Drum-Brake	377-7449
8V-7659	Pin As	361-1702
8V-7885	Housing-Support	297-7193
9C-1484	Pin As	319-3446
9C-4007	Bearing-Sleeve	374-1459
9C-5852	Hub As	297-7208
9C-6015	Pinion-Diff Bev	297-7225
9C-8218	Shaft-Bev Pinion	302-2697
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183

2FD		
Original Part Number	Part Name	Classic Part Number
9J-7099	Bearing-Sleeve	391-9818
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-5836	Coupling-Exhaust	385-7212
9L-6371	Rod-Eye	363-7459
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5160	Plunger Kt-Adj	385-7218
9V-5174	Joint Gp-Univ	375-2628
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859

Sales Model 966D (Cont'd.)

2FD		
Original Part Number	Part Name	Classic Part Number
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
103-5961	Wheel	398-2963
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
124-2726	Head	377-5855
126-2522	Cone-Spl Tapered	377-7397
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126

2FD		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
196-0028	Gear As-Idler	364-5259

2FD		
Original Part Number	Part Name	Classic Part Number
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
216-7957	U-Joint	367-6069
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
443-1200	Brg-Rlr-Cla	377-7397

35S		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-2936	Muffler As	298-2782
1N-2946	Extension-Exh	367-6064
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572

35S		
Original Part Number	Part Name	Classic Part Number
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981

35S		
Original Part Number	Part Name	Classic Part Number
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

Sales Model 966D (Cont'd.)

35S		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2K-0714	Plate-Thrust	299-2040
2K-4442	Bearing-Sleeve	308-9812
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5709	Shaft-Axle	299-2056
2V-5714	Gear-Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088

35S		
Original Part Number	Part Name	Classic Part Number
2W-7933	Core As-O Clr	374-4708
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3G-5264	Cylinder As.	393-1018
3G-5492	Rod As	377-5836
3G-5497	Cyl Gp-0210 0535	394-9822
3G-5502	Cylinder As	390-0988
3G-7660	Cartridge Gp	422-8103
3G-9891	Pump Gp-Gr A	399-8541
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
3V-0593	Rim As	418-9568
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

35S		
Original Part Number	Part Name	Classic Part Number
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0422	Cartridge Gp	422-8129
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-5388	Shaft-Bev Pinion	297-7244
4V-5392	Spider	377-7430
4V-5393	Gear-Bevel	297-7189
4V-5394	Gear-Diff	297-7177
4V-5400	Housing-Brg Spt	385-7202
4V-6421	Pin As	319-3442
4V-7082	Joint Gp-Slip	367-6068
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-8518	Link As-Brg&	374-1450
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528

Sales Model 966D (Cont'd.)

35S		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5053	Muffler As	360-7881
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4Y-4340	Pin As	319-3442
4Y-5711	Pin As	425-6442
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5J-1192	Bearing-Sleeve	374-8355
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5L-6326	Bearing-Ball	420-3222
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

35S		
Original Part Number	**Part Name**	**Classic Part Number**
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-0775	Head	425-9373
6E-2387	Cartridge Gp	422-8132
6E-5028	Rod As	425-9372
6E-6416	Cylinder As	425-9371
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6W-9677	Tube As-Rh	388-6569
6W-9678	Tube As-Lh	388-6570
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
7C-5851	Muffler As	298-2790
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851

35S		
Original Part Number	**Part Name**	**Classic Part Number**
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7J-6461	Crown	325-6054
7J-9344	Bearing-Sleeve	360-2334
7J-9682	Bearing-Sleeve	360-2335
7K-0084	Bearing-Sleeve	453-6508
7K-0686	Trunnion-Rear	297-7266
7K-6497	Pin	252-6870
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7V-6716	Pin As	396-7273
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-7546	Gasket-Plate	433-8187

Sales Model 966D (Cont'd.)

35S		
Original Part Number	Part Name	Classic Part Number
7W-9020	Bell As-Pump Suc	378-3989
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

35S		
Original Part Number	Part Name	Classic Part Number
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-3943	Collet	308-9840
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-6390	Drum-Brake	377-7449
8V-7659	Pin As	361-1702
8V-7885	Housing-Support	297-7193
9C-0624	Pin As.	361-1709
9C-1484	Pin As	319-3446
9C-4007	Bearing-Sleeve	374-1459
9C-4080	Yoke-Brake	302-2703
9C-5852	Hub As	297-7208
9C-6015	Pinion-Diff Bev	297-7225
9C-8218	Shaft-Bev Pinion	302-2697
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182

35S		
Original Part Number	Part Name	Classic Part Number
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-5836	Coupling-Exhaust	385-7212
9L-6371	Rod-Eye	363-7459
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-4975	Bearing-Sleeve	384-4784
9V-5160	Plunger Kt-Adj	385-7218
9V-5174	Joint Gp-Univ	375-2628
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6526	Ring-Retaining	422-2485

Sales Model 966D (Cont'd.)

35S		
Original Part Number	**Part Name**	**Classic Part Number**
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
103-5961	Wheel	398-2963
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
114-0468	Pin-G.E.T.	443-1203
119-5727	Bearing-Spl Ball	417-9491
124-2726	Head	377-5855
126-2522	Cone-Spl Tapered	377-7397
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
139-9175	Gasket Kit	377-7464
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
158-1438	Kit-Dt Gasket	434-7276

35S		
Original Part Number	**Part Name**	**Classic Part Number**
160-1400	Yoke (1710)	319-3479
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
186-4439	Gear-Planet	380-1485

35S		
Original Part Number	**Part Name**	**Classic Part Number**
186-4440	Shaft-Planet	364-5261
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
216-7957	U-Joint	367-6069
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
234-8002	Kit-Gasket-Sch	386-3817
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
443-1200	Brg-Rlr-Cla	377-7397

6ZC		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

6ZC		
Original Part Number	**Part Name**	**Classic Part Number**
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116

6ZC		
Original Part Number	**Part Name**	**Classic Part Number**
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659

Sales Model 966D (Cont'd.)

6ZC		
Original Part Number	Part Name	Classic Part Number
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5709	Shaft-Axle	299-2056
2V-5714	Gear-Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357

6ZC		
Original Part Number	Part Name	Classic Part Number
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3G-5264	Cylinder As.	393-1018
3G-5492	Rod As	377-5836
3G-5497	Cyl Gp-0210 0535	394-9822
3G-5502	Cylinder As	390-0988
3G-7660	Cartridge Gp	422-8103
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
4D-2619	Bearing	417-4494
4E-3196	Pin As	361-1697
4E-3456	Lever As	367-6081
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216

6ZC		
Original Part Number	Part Name	Classic Part Number
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0422	Cartridge Gp	422-8129
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-5388	Shaft-Bev Pinion	297-7244
4V-5392	Spider	377-7430
4V-5393	Gear-Bevel	297-7189
4V-5394	Gear-Diff	297-7177
4V-5400	Housing-Brg Spt	385-7202
4V-6421	Pin As	319-3442
4V-7082	Joint Gp-Slip	367-6068
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-8518	Link As-Brg&	374-1450
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187

Sales Model 966D (Cont'd.)

6ZC		
Original Part Number	**Part Name**	**Classic Part Number**
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5053	Muffler As	360-7881
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4Y-4340	Pin As	319-3442
4Y-5711	Pin As	425-6442
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535

6ZC		
Original Part Number	**Part Name**	**Classic Part Number**
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-0775	Head	425-9373
6E-2387	Cartridge Gp	422-8132
6E-5028	Rod As	425-9372
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-8895	Cap	374-6500
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6W-9677	Tube As-Rh	388-6569
6W-9678	Tube As-Lh	388-6570
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816

6ZC		
Original Part Number	**Part Name**	**Classic Part Number**
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7V-6716	Pin As	396-7273
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196

Sales Model 966D (Cont'd.)

6ZC		
Original Part Number	Part Name	Classic Part Number
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033

6ZC		
Original Part Number	Part Name	Classic Part Number
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-6390	Drum-Brake	377-7449
8V-7659	Pin As	361-1702
8V-7885	Housing-Support	297-7193
9C-1484	Pin As	319-3446
9C-4007	Bearing-Sleeve	374-1459
9C-4080	Yoke-Brake	302-2703
9C-5852	Hub As	297-7208
9C-6015	Pinion-Diff Bev	297-7225
9C-8218	Shaft-Bev Pinion	302-2697
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-5836	Coupling-Exhaust	385-7212
9L-6371	Rod-Eye	363-7459
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353

6ZC		
Original Part Number	Part Name	Classic Part Number
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5160	Plunger Kt-Adj	385-7218
9V-5174	Joint Gp-Univ	375-2628
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
103-5961	Wheel	398-2963
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
124-2726	Head	377-5855
126-2522	Cone-Spl Tapered	377-7397

Sales Model 966D (Cont'd.)

6ZC		
Original Part Number	**Part Name**	**Classic Part Number**
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
160-1400	Yoke (1710)	319-3479
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

6ZC		
Original Part Number	**Part Name**	**Classic Part Number**
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370

6ZC		
Original Part Number	**Part Name**	**Classic Part Number**
216-7957	U-Joint	367-6069
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
443-1200	Brg-Rlr-Cla	377-7397

7BB		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7125	Governor As	383-3672
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116

7BB		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914

7BB		
Original Part Number	**Part Name**	**Classic Part Number**
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357

Sales Model 966D (Cont'd.)

7BB		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5709	Shaft-Axle	299-2056
2V-5714	Gear-Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-7933	Core As-O Clr	374-4708
3G-2665	Cover	308-9842
3G-5492	Rod As	377-5836
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116

7BB		
Original Part Number	Part Name	Classic Part Number
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0422	Cartridge Gp	422-8129
4T-9311	Housing	396-0652
4V-2518	Shaft	297-7243
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-5388	Shaft-Bev Pinion	297-7244
4V-5392	Spider	377-7430
4V-5393	Gear-Bevel	297-7189
4V-5394	Gear-Diff	297-7177
4V-5400	Housing-Brg Spt	385-7202
4V-7082	Joint Gp-Slip	367-6068
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502

7BB		
Original Part Number	Part Name	Classic Part Number
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2387	Cartridge Gp	422-8132
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544

Sales Model 966D (Cont'd.)

7BB		
Original Part Number	**Part Name**	**Classic Part Number**
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
7C-5851	Muffler As	298-2790
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-9682	Bearing-Sleeve	360-2335
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207

7BB		
Original Part Number	**Part Name**	**Classic Part Number**
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377

7BB		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-6390	Drum-Brake	377-7449
8V-7885	Housing-Support	297-7193
9C-4007	Bearing-Sleeve	374-1459
9C-4080	Yoke-Brake	302-2703
9C-5852	Hub As	297-7208
9C-6015	Pinion-Diff Bev	297-7225
9C-8218	Shaft-Bev Pinion	302-2697
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183

Sales Model 966D (Cont'd.)

7BB		
Original Part Number	Part Name	Classic Part Number
9J-7099	Bearing-Sleeve	391-9818
9L-5836	Coupling-Exhaust	385-7212
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-5160	Plunger Kt-Adj	385-7218
9V-5174	Joint Gp-Univ	375-2628
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165

7BB		
Original Part Number	Part Name	Classic Part Number
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
103-5961	Wheel	398-2963
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
126-2522	Cone-Spl Tapered	377-7397
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
160-1400	Yoke (1710)	319-3479
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

7BB		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
216-7957	U-Joint	367-6069
232-3233	Bearing-Main	376-9085
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
443-1200	Brg-Rlr-Cla	377-7397

99Y		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1B-3934	Cup-Roller Brg	392-4487

99Y		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347

99Y		
Original Part Number	Part Name	Classic Part Number
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167

Sales Model 966D (Cont'd.)

99Y		
Original Part Number	**Part Name**	**Classic Part Number**
1N-2936	Muffler As	298-2782
1N-2946	Extension-Exh	367-6064
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5910	Tappet As-Guide&	383-1569
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513

99Y		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4611	Pipe-Exhaust	365-8821
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5709	Shaft-Axle	299-2056
2V-5714	Gear-Ring	288-8716

99Y		
Original Part Number	**Part Name**	**Classic Part Number**
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7455	Gear As	396-9957
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-7933	Core As-O Clr	374-4708
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3E-6772	Seal-Water	382-8017
3G-2665	Cover	308-9842
3G-5264	Cylinder As.	393-1018
3G-5492	Rod As	377-5836
3G-5497	Cyl Gp-0210 0535	394-9822
3G-5502	Cylinder As	390-0988
3G-7660	Cartridge Gp	422-8103
3G-9891	Pump Gp-Gr A	399-8541
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
3T-2094	Bearing-Sleeve	388-0638
3T-2095	Bearing-Sleeve	384-3459
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
3V-0593	Rim As	418-9568
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494

Sales Model 966D (Cont'd.)

99Y		
Original Part Number	Part Name	Classic Part Number
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4E-8535	Retainer-Seal	300-2589
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1767	Valve-Bypass	419-4716
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-2954	Sleeve-Camshaft	299-2059
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4N-7693	Crankshaft As	269-8763
4P-2383	Adapter-Inlet	438-1812

99Y		
Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355
4T-0422	Cartridge Gp	422-8129
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2057	Bearing-Spher	419-6019
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-5388	Shaft-Bev Pinion	297-7244
4V-5392	Spider	377-7430
4V-5393	Gear-Bevel	297-7189
4V-5394	Gear-Diff	297-7177
4V-5400	Housing-Brg Spt	385-7202
4V-6421	Pin As	319-3442
4V-7082	Joint Gp-Slip	367-6068
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699

99Y		
Original Part Number	Part Name	Classic Part Number
4V-7543	Retainer	281-1699
4V-8518	Link As-Brg&	374-1450
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5053	Muffler As	360-7881
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-7382	Core As-Oclr	380-1514
4Y-4340	Pin As	319-3442
4Y-5711	Pin As	425-6442
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5K-3493	Cover	391-9814
5K-3495	Collar	383-2129
5K-8591	Bearing-Outer	380-7502
5L-2030	Cone-Roller Brg	418-9614

Sales Model 966D (Cont'd.)

99Y		
Original Part Number	**Part Name**	**Classic Part Number**
5L-2031	Cup-Roller Brg	384-5927
5L-6326	Bearing-Ball	420-3222
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3617	Support-Trunnion	374-4712
6E-0775	Head	425-9373
6E-2387	Cartridge Gp	422-8132
6E-5028	Rod As	425-9372
6E-6416	Cylinder As	425-9371
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475

99Y		
Original Part Number	**Part Name**	**Classic Part Number**
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1453	Crankshaft As	368-5916
6I-2408	Muffler As.	378-3978
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-9743	Support-Muffler	308-9940
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-4350	Race-Spl Rlr Brg	384-5933
6W-9677	Tube As-Rh	388-6569
6W-9678	Tube As-Lh	388-6570
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5403	Tube As	374-4673
7C-5851	Muffler As	298-2790
7C-6697	Shaft - Idler	425-9370
7C-6976	Bearing-Conn Rod	419-6317

99Y		
Original Part Number	**Part Name**	**Classic Part Number**
7C-6977	Bearing-Conn Rod	419-6316
7C-9198	Block	419-2303
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-5645	Tube As-Outlet	378-3984

Sales Model 966D (Cont'd.)

99Y		
Original Part Number	Part Name	Classic Part Number
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8371	Line As-Fuel Inj	373-1901
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700
7S-4629	Pump Gp-Trans	226-0158
7T-2036	Cap As-Fuel	361-1721
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7V-6716	Pin As	396-7273
7W-0140	Gear-Drive	399-8546
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5095	Gear-Flywheel	425-9190
7W-5435	Adapter-Nozzle	374-7493
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-5733	Gasket	421-7333
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8555	Gasket Kit	434-7278
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8F-6058	Bearing-Sleeve	416-5494

99Y		
Original Part Number	Part Name	Classic Part Number
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1726	Rod As-Conn	379-8866
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

99Y		
Original Part Number	Part Name	Classic Part Number
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8258	Bearing-Sleeve	452-1077
8N-9733	Line As-F Inj	319-8174
8P-0953	Turbine-Conv	297-7269
8P-0961	Impeller-Conv	433-9204
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-0931	Housing-Pinion	302-4300
8R-0942	Plate-Reaction	380-1484
8R-1015	Support-Trunnion	374-4712
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-3252	Shaft-Planet	297-7259
8R-8335	Gear-Bevel	368-0105
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3653	Bonnet-Valve	374-4728
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6390	Drum-Brake	377-7449
8V-7659	Pin As	361-1702
8V-7885	Housing-Support	297-7193
9B-1320	Valve-Check	377-5832
9C-1484	Pin As	319-3446
9C-4007	Bearing-Sleeve	374-1459

Sales Model 966D (Cont'd.)

99Y		
Original Part Number	**Part Name**	**Classic Part Number**
9C-4080	Yoke-Brake	302-2703
9C-5852	Hub As	297-7208
9C-6015	Pinion-Diff Bev	297-7225
9C-6029	Bearing-Planet	375-9982
9C-8218	Shaft-Bev Pinion	302-2697
9C-8669	Shaft-Bev Pinion	368-0107
9C-9191	Trunnion	302-2701
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-5836	Coupling-Exhaust	385-7212
9L-5839	Coupling-Exhaust	374-7480
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-5477	Bearing-Sleeve	374-6517
9N-1545	Race-Thrust	394-9205
9N-5403	Body As-Piston	250-6558
9N-5529	Body-F Inj Valve	378-3993
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446

99Y		
Original Part Number	**Part Name**	**Classic Part Number**
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9U-2787	Gear-Planet	367-6093
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5160	Plunger Kt-Adj	385-7218
9V-5174	Joint Gp-Univ	375-2628
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
9Y-1917	Pulley-Fan	395-1311
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-3596	Piston	380-1511
100-3597	Plate-Reaction	380-1501

99Y		
Original Part Number	**Part Name**	**Classic Part Number**
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
102-8636	Gear-Drive	472-8035
103-5961	Wheel	398-2963
107-7708	Bearing-Main	419-6381
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166
108-5680	Gage-Oil Level	378-4001
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-1488	Gear-Ring	394-0882
110-5096	Head As-Cyl	394-0915
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
114-0468	Pin-G.E.T.	443-1203
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-4072	Bearing	397-5069
117-0456	Crankshaft As	394-2587
119-5727	Bearing-Spl Ball	417-9491
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-2726	Head	377-5855
126-2522	Cone-Spl Tapered	377-7397
127-5537	Core As-Oclr	325-6045
127-6356	Cover As.-Pump	420-8566

Sales Model 966D (Cont'd.)

99Y		
Original Part Number	Part Name	Classic Part Number
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-4995	Gasket-Cyl Head	434-2445
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
136-7813	Bearing-Race	460-8296
139-9175	Gasket Kit	377-7464
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
145-8503	Shaft As-Idler	426-0035
148-7455	Valve - Exhaust	270-4361
148-9288	Case As-Diff	380-1496
150-4637	Pan-Oil	377-5843
151-4836	Diff Gp -A	416-2120
154-8030	Gasket	394-0894
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
158-1438	Kit-Dt Gasket	434-7276
159-3021	Gasket	377-5845
160-1400	Yoke (1710)	319-3479
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
166-9142	Gasket	420-8546
167-8123	Damper As	299-2006

99Y		
Original Part Number	Part Name	Classic Part Number
167-8126	Damper As	382-8019
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0560	Rebuild Kit-Pump	363-7458
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
187-0605	Gasket Kit - Cl	382-5055
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
197-5510	Support As	419-0880

99Y		
Original Part Number	Part Name	Classic Part Number
202-3572	Shaft As-Drive	426-0037
206-6405	Bearing-Spl Ball	420-2503
211-0592	Bearing - Main	419-6368
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
216-7957	U-Joint	367-6069
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
228-0419	Seal As	443-3571
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3233	Bearing-Main	376-9085
234-8002	Kit-Gasket-Sch	386-3817
250-6558	Liner Kit-Cla	295-6438
253-1752	Plate-Thrust	379-0170
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
334-1032	Disc-Friction	440-3116
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005

Sales Model 966D (Cont'd.)

99Y		
Original Part Number	**Part Name**	**Classic Part Number**
391-8229	Kit-Gasket-Fs	398-2955

99Y		
Original Part Number	**Part Name**	**Classic Part Number**
430-7619	Adapter-Cla	438-1812

99Y		
Original Part Number	**Part Name**	**Classic Part Number**
443-1200	Brg-Rlr-Cla	377-7397

Sales Model 966E

11D		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-2936	Muffler As	298-2782
1N-2946	Extension-Exh	367-6064
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

11D		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5709	Shaft-Axle	299-2056
2V-5714	Gear-Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164

11D		
Original Part Number	**Part Name**	**Classic Part Number**
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3G-5264	Cylinder As.	393-1018
3G-5492	Rod As	377-5836
3G-5497	Cyl Gp-0210 0535	394-9822
3G-5502	Cylinder As	390-0988
3G-7660	Cartridge Gp	422-8103
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
4D-2619	Bearing	417-4494
4E-3456	Lever As	367-6081
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575

Sales Model 966E (Cont'd.)

11D		
Original Part Number	Part Name	Classic Part Number
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0422	Cartridge Gp	422-8129
4T-8054	Seal As	472-8010
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-5388	Shaft-Bev Pinion	297-7244
4V-5392	Spider	377-7430
4V-5393	Gear-Bevel	297-7189
4V-5394	Gear-Diff	297-7177
4V-5400	Housing-Brg Spt	385-7202
4V-6421	Pin As	319-3442
4V-7082	Joint Gp-Slip	367-6068

11D		
Original Part Number	Part Name	Classic Part Number
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-8518	Link As-Brg&	374-1450
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5053	Muffler As	360-7881
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247

11D		
Original Part Number	Part Name	Classic Part Number
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2387	Cartridge Gp	422-8132
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-8895	Cap	374-6500
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6W-9677	Tube As-Rh	388-6569
6W-9678	Tube As-Lh	388-6570
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204

Sales Model 966E (Cont'd.)

11D		
Original Part Number	**Part Name**	**Classic Part Number**
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7V-6716	Pin As	396-7273
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

11D		
Original Part Number	**Part Name**	**Classic Part Number**
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210

11D		
Original Part Number	**Part Name**	**Classic Part Number**
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-6390	Drum-Brake	377-7449
8V-7659	Pin As	361-1702
8V-7885	Housing-Support	297-7193
9C-1484	Pin As	319-3446
9C-4007	Bearing-Sleeve	374-1459
9C-4080	Yoke-Brake	302-2703
9C-5852	Hub As	297-7208
9C-6015	Pinion-Diff Bev	297-7225
9C-8218	Shaft-Bev Pinion	302-2697
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-5836	Coupling-Exhaust	385-7212
9L-6371	Rod-Eye	363-7459
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558

Sales Model 966E (Cont'd.)

11D		
Original Part Number	Part Name	Classic Part Number
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5160	Plunger Kt-Adj	385-7218
9V-5174	Joint Gp-Univ	375-2628
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550

11D		
Original Part Number	Part Name	Classic Part Number
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
103-5961	Wheel	398-2963
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
124-2726	Head	377-5855
126-2522	Cone-Spl Tapered	377-7397
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
160-1400	Yoke (1710)	319-3479
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687

11D		
Original Part Number	Part Name	Classic Part Number
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
216-7957	U-Joint	367-6069
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
443-1200	Brg-Rlr-Cla	377-7397

2FD		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487

Sales Model 966E (Cont'd.)

2FD		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142

2FD		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5709	Shaft-Axle	299-2056
2V-5714	Gear-Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2665	Cover	308-9842
3G-5264	Cylinder As.	393-1018
3G-5492	Rod As	377-5836
3G-5497	Cyl Gp-0210 0535	394-9822
3G-5502	Cylinder As	390-0988
3G-7660	Cartridge Gp	422-8103
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126

2FD		
Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
4D-2619	Bearing	417-4494
4E-3456	Lever As	367-6081
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0422	Cartridge Gp	422-8129
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243

Sales Model 966E (Cont'd.)

2FD		
Original Part Number	Part Name	Classic Part Number
4V-3680	Bellcrank	308-9802
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-5388	Shaft-Bev Pinion	297-7244
4V-5392	Spider	377-7430
4V-5393	Gear-Bevel	297-7189
4V-5394	Gear-Diff	297-7177
4V-5400	Housing-Brg Spt	385-7202
4V-6421	Pin As	319-3442
4V-7082	Joint Gp-Slip	367-6068
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-8518	Link As-Brg&	374-1450
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5053	Muffler As	360-7881
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-2989	Bearing	380-7511
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917

2FD		
Original Part Number	Part Name	Classic Part Number
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6E-0775	Head	425-9373
6E-2387	Cartridge Gp	422-8132
6E-5028	Rod As	425-9372
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-8895	Cap	374-6500
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933

2FD		
Original Part Number	Part Name	Classic Part Number
6W-9677	Tube As-Rh	388-6569
6W-9678	Tube As-Lh	388-6570
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7V-6716	Pin As	396-7273
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-7546	Gasket-Plate	433-8187

Sales Model 966E (Cont'd.)

2FD		
Original Part Number	**Part Name**	**Classic Part Number**
7W-9020	Bell As-Pump Suc	378-3989
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

2FD		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-6390	Drum-Brake	377-7449
8V-7659	Pin As	361-1702
8V-7885	Housing-Support	297-7193
9C-1484	Pin As	319-3446
9C-4007	Bearing-Sleeve	374-1459
9C-5852	Hub As	297-7208
9C-6015	Pinion-Diff Bev	297-7225
9C-8218	Shaft-Bev Pinion	302-2697
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9K-8757	Rod End-Special	311-9361

2FD		
Original Part Number	**Part Name**	**Classic Part Number**
9L-2685	Rod End	419-1866
9L-5836	Coupling-Exhaust	385-7212
9L-6371	Rod-Eye	363-7459
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5160	Plunger Kt-Adj	385-7218
9V-5174	Joint Gp-Univ	375-2628
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926

Sales Model 966E (Cont'd.)

2FD		
Original Part Number	Part Name	Classic Part Number
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
103-5961	Wheel	398-2963
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
124-2726	Head	377-5855
126-2522	Cone-Spl Tapered	377-7397
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126

2FD		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

2FD		
Original Part Number	Part Name	Classic Part Number
206-6405	Bearing-Spl Ball	420-2503
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
216-7957	U-Joint	367-6069
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
443-1200	Brg-Rlr-Cla	377-7397

35S		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-2936	Muffler As	298-2782
1N-2946	Extension-Exh	367-6064
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108

35S		
Original Part Number	Part Name	Classic Part Number
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

35S		
Original Part Number	Part Name	Classic Part Number
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0714	Plate-Thrust	299-2040
2K-4442	Bearing-Sleeve	308-9812
2K-5065	Cone-Roller Brg	416-2157

Sales Model 966E (Cont'd.)

35S		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5709	Shaft-Axle	299-2056
2V-5714	Gear-Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-7933	Core As-O Clr	374-4708
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3G-5264	Cylinder As.	393-1018

35S		
Original Part Number	**Part Name**	**Classic Part Number**
3G-5492	Rod As	377-5836
3G-5497	Cyl Gp-0210 0535	394-9822
3G-5502	Cylinder As	390-0988
3G-7660	Cartridge Gp	422-8103
3G-9891	Pump Gp-Gr A	399-8541
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
3V-0593	Rim As	418-9568
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984

35S		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0422	Cartridge Gp	422-8129
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-5388	Shaft-Bev Pinion	297-7244
4V-5392	Spider	377-7430
4V-5393	Gear-Bevel	297-7189
4V-5394	Gear-Diff	297-7177
4V-5400	Housing-Brg Spt	385-7202
4V-6421	Pin As	319-3442
4V-7082	Joint Gp-Slip	367-6068
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-8518	Link As-Brg&	374-1450
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191

Sales Model 966E (Cont'd.)

35S		
Original Part Number	Part Name	Classic Part Number
4W-2446	Damper As	279-4990
4W-5053	Muffler As	360-7881
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4Y-4340	Pin As	319-3442
4Y-5711	Pin As	425-6442
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5J-1192	Bearing-Sleeve	374-8355
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5L-6326	Bearing-Ball	420-3222
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-5917	Pinion-Diff	297-7224

35S		
Original Part Number	Part Name	Classic Part Number
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-0775	Head	425-9373
6E-2387	Cartridge Gp	422-8132
6E-5028	Rod As	425-9372
6E-6416	Cylinder As	425-9371
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6W-9677	Tube As-Rh	388-6569
6W-9678	Tube As-Lh	388-6570
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
7C-5851	Muffler As	298-2790
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7J-6461	Crown	325-6054

35S		
Original Part Number	Part Name	Classic Part Number
7J-9344	Bearing-Sleeve	360-2334
7J-9682	Bearing-Sleeve	360-2335
7K-0084	Bearing-Sleeve	453-6508
7K-0686	Trunnion-Rear	297-7266
7K-6497	Pin	252-6870
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7V-6716	Pin As	396-7273
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8F-9365	Pin	319-3463

Sales Model 966E (Cont'd.)

35S		
Original Part Number	**Part Name**	**Classic Part Number**
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209

35S		
Original Part Number	**Part Name**	**Classic Part Number**
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-3943	Collet	308-9840
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-6390	Drum-Brake	377-7449
8V-7659	Pin As	361-1702
8V-7885	Housing-Support	297-7193
9C-0624	Pin As.	361-1709
9C-1484	Pin As	319-3446
9C-4007	Bearing-Sleeve	374-1459
9C-4080	Yoke-Brake	302-2703
9C-5852	Hub As	297-7208
9C-6015	Pinion-Diff Bev	297-7225
9C-8218	Shaft-Bev Pinion	302-2697
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-5836	Coupling-Exhaust	385-7212

35S		
Original Part Number	**Part Name**	**Classic Part Number**
9L-6371	Rod-Eye	363-7459
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-4975	Bearing-Sleeve	384-4784
9V-5160	Plunger Kt-Adj	385-7218
9V-5174	Joint Gp-Univ	375-2628
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605

Sales Model 966E (Cont'd.)

35S		
Original Part Number	Part Name	Classic Part Number
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
103-5961	Wheel	398-2963
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
114-0468	Pin-G.E.T.	443-1203
119-5727	Bearing-Spl Ball	417-9491
124-2726	Head	377-5855
126-2522	Cone-Spl Tapered	377-7397
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
139-9175	Gasket Kit	377-7464
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
158-1438	Kit-Dt Gasket	434-7276
160-1400	Yoke (1710)	319-3479
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126

35S		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
187-0605	Gasket Kit - Cl	382-5055

35S		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
216-7957	U-Joint	367-6069
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
234-8002	Kit-Gasket-Sch	386-3817
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955
443-1200	Brg-Rlr-Cla	377-7397

6ZC		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344

6ZC		
Original Part Number	Part Name	Classic Part Number
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

6ZC		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

Sales Model 966E (Cont'd.)

6ZC		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5709	Shaft-Axle	299-2056
2V-5714	Gear-Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203

6ZC		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3G-5264	Cylinder As.	393-1018
3G-5492	Rod As	377-5836
3G-5497	Cyl Gp-0210 0535	394-9822
3G-5502	Cylinder As	390-0988
3G-7660	Cartridge Gp	422-8103
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
4D-2619	Bearing	417-4494
4E-3196	Pin As	361-1697
4E-3456	Lever As	367-6081
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985

6ZC		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0422	Cartridge Gp	422-8129
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-5388	Shaft-Bev Pinion	297-7244
4V-5392	Spider	377-7430
4V-5393	Gear-Bevel	297-7189
4V-5394	Gear-Diff	297-7177
4V-5400	Housing-Brg Spt	385-7202
4V-6421	Pin As	319-3442
4V-7082	Joint Gp-Slip	367-6068
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-8518	Link As-Brg&	374-1450
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5053	Muffler As	360-7881
4W-6869	Spacer-Fuel Pump	417-4534

Sales Model 966E (Cont'd.)

6ZC		
Original Part Number	Part Name	Classic Part Number
4W-7188	Core As-Oclr	374-7501
4Y-4340	Pin As	319-3442
4Y-5711	Pin As	425-6442
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-0775	Head	425-9373
6E-2387	Cartridge Gp	422-8132
6E-5028	Rod As	425-9372
6H-3957	Bearing-Ball	311-9358

6ZC		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-8895	Cap	374-6500
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6W-9677	Tube As-Rh	388-6569
6W-9678	Tube As-Lh	388-6570
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531

6ZC		
Original Part Number	Part Name	Classic Part Number
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7V-6716	Pin As	396-7273
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623

Sales Model 966E (Cont'd.)

6ZC		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-6390	Drum-Brake	377-7449
8V-7659	Pin As	361-1702
8V-7885	Housing-Support	297-7193

6ZC		
Original Part Number	**Part Name**	**Classic Part Number**
9C-1484	Pin As	319-3446
9C-4007	Bearing-Sleeve	374-1459
9C-4080	Yoke-Brake	302-2703
9C-5852	Hub As	297-7208
9C-6015	Pinion-Diff Bev	297-7225
9C-8218	Shaft-Bev Pinion	302-2697
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-5836	Coupling-Exhaust	385-7212
9L-6371	Rod-Eye	363-7459
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221

6ZC		
Original Part Number	**Part Name**	**Classic Part Number**
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5160	Plunger Kt-Adj	385-7218
9V-5174	Joint Gp-Univ	375-2628
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
103-5961	Wheel	398-2963
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
124-2726	Head	377-5855
126-2522	Cone-Spl Tapered	377-7397
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
160-1400	Yoke (1710)	319-3479

Sales Model 966E (Cont'd.)

6ZC		
Original Part Number	**Part Name**	**Classic Part Number**
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

6ZC		
Original Part Number	**Part Name**	**Classic Part Number**
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
216-7957	U-Joint	367-6069
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
250-6558	Liner Kit-Cla	295-6438

6ZC		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
443-1200	Brg-Rlr-Cla	377-7397

7BB		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7125	Governor As	383-3672
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

7BB		
Original Part Number	**Part Name**	**Classic Part Number**
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142

7BB		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5069	Cup-Roller Brg	374-8346
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5709	Shaft-Axle	299-2056
2V-5714	Gear-Ring	288-8716

Sales Model 966E (Cont'd.)

7BB		
Original Part Number	**Part Name**	**Classic Part Number**
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-7933	Core As-O Clr	374-4708
3G-2665	Cover	308-9842
3G-5492	Rod As	377-5836
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984

7BB		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4S-8472	Hood As-Preclnr	296-1355
4T-0422	Cartridge Gp	422-8129
4T-9311	Housing	396-0652
4V-2518	Shaft	297-7243
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-5388	Shaft-Bev Pinion	297-7244
4V-5392	Spider	377-7430
4V-5393	Gear-Bevel	297-7189
4V-5394	Gear-Diff	297-7177
4V-5400	Housing-Brg Spt	385-7202
4V-7082	Joint Gp-Slip	367-6068
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529

7BB		
Original Part Number	**Part Name**	**Classic Part Number**
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2387	Cartridge Gp	422-8132
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
7C-5851	Muffler As	298-2790

Sales Model 966E (Cont'd.)

7BB		
Original Part Number	Part Name	Classic Part Number
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-9682	Bearing-Sleeve	360-2335
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5698	Pulley-Cshaft	295-5679
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504

7BB		
Original Part Number	Part Name	Classic Part Number
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269

7BB		
Original Part Number	Part Name	Classic Part Number
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-6390	Drum-Brake	377-7449
8V-7885	Housing-Support	297-7193
9C-4007	Bearing-Sleeve	374-1459
9C-4080	Yoke-Brake	302-2703
9C-5852	Hub As	297-7208
9C-6015	Pinion-Diff Bev	297-7225
9C-8218	Shaft-Bev Pinion	302-2697
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9L-5836	Coupling-Exhaust	385-7212
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767

Sales Model 966E (Cont'd.)

7BB		
Original Part Number	**Part Name**	**Classic Part Number**
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-5160	Plunger Kt-Adj	385-7218
9V-5174	Joint Gp-Univ	375-2628
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
103-5961	Wheel	398-2963
110-1337	Ring Kit-Pstn	377-5834

7BB		
Original Part Number	**Part Name**	**Classic Part Number**
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
126-2522	Cone-Spl Tapered	377-7397
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
160-1400	Yoke (1710)	319-3479
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

7BB		
Original Part Number	**Part Name**	**Classic Part Number**
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
216-7957	U-Joint	367-6069
232-3233	Bearing-Main	376-9085
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
443-1200	Brg-Rlr-Cla	377-7397

94X		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-2936	Muffler As	298-2782
1N-2946	Extension-Exh	367-6064

94X		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

94X		
Original Part Number	**Part Name**	**Classic Part Number**
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370

Sales Model 966E (Cont'd.)

94X		
Original Part Number	Part Name	Classic Part Number
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357

94X		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5709	Shaft-Axle	299-2056
2V-5714	Gear-Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-7933	Core As-O Clr	374-4708
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3G-5264	Cylinder As.	393-1018
3G-5492	Rod As	377-5836
3G-5497	Cyl Gp-0210 0535	394-9822
3G-5502	Cylinder As	390-0988
3G-7660	Cartridge Gp	422-8103
3G-9891	Pump Gp-Gr A	399-8541
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638

94X		
Original Part Number	Part Name	Classic Part Number
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
3V-0593	Rim As	418-9568
4D-2619	Bearing	417-4494
4E-3196	Pin As	361-1697
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987

Sales Model 966E (Cont'd.)

94X		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0422	Cartridge Gp	422-8129
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-5388	Shaft-Bev Pinion	297-7244
4V-5392	Spider	377-7430
4V-5393	Gear-Bevel	297-7189
4V-5394	Gear-Diff	297-7177
4V-5400	Housing-Brg Spt	385-7202
4V-6421	Pin As	319-3442
4V-7082	Joint Gp-Slip	367-6068
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-7543	Retainer	281-1699
4V-8518	Link As-Brg&	374-1450
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-2446	Damper As	279-4990
4W-5053	Muffler As	360-7881
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4Y-4340	Pin As	319-3442
4Y-5711	Pin As	425-6442

94X		
Original Part Number	**Part Name**	**Classic Part Number**
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5K-3493	Cover	391-9814
5K-3495	Collar	383-2129
5K-8591	Bearing-Outer	380-7502
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5L-6326	Bearing-Ball	420-3222
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8789	Gasket Kt	393-3620
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-0775	Head	425-9373
6E-2387	Cartridge Gp	422-8132

94X		
Original Part Number	**Part Name**	**Classic Part Number**
6E-5028	Rod As	425-9372
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6W-9677	Tube As-Rh	388-6569
6W-9678	Tube As-Lh	388-6570
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
7C-5851	Muffler As	298-2790
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206

Sales Model 966E (Cont'd.)

94X		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7V-6716	Pin As	396-7273
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8555	Gasket Kit	434-7278
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504

94X		
Original Part Number	Part Name	Classic Part Number
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084

94X		
Original Part Number	Part Name	Classic Part Number
8N-9733	Line As-F Inj	319-8174
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-6390	Drum-Brake	377-7449
8V-7659	Pin As	361-1702
8V-7885	Housing-Support	297-7193
9B-1320	Valve-Check	377-5832
9C-1484	Pin As	319-3446
9C-4007	Bearing-Sleeve	374-1459
9C-4080	Yoke-Brake	302-2703
9C-5852	Hub As	297-7208
9C-6015	Pinion-Diff Bev	297-7225
9C-8218	Shaft-Bev Pinion	302-2697
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818

Sales Model 966E (Cont'd.)

94X		
Original Part Number	**Part Name**	**Classic Part Number**
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-5836	Coupling-Exhaust	385-7212
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-5477	Bearing-Sleeve	374-6517
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5160	Plunger Kt-Adj	385-7218
9V-5174	Joint Gp-Univ	375-2628
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163

94X		
Original Part Number	**Part Name**	**Classic Part Number**
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
102-8636	Gear-Drive	472-8035
103-5961	Wheel	398-2963
104-3014	Gasket Kit	388-0656
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
119-5727	Bearing-Spl Ball	417-9491
124-2726	Head	377-5855
126-2522	Cone-Spl Tapered	377-7397
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
139-9175	Gasket Kit	377-7464
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
158-1438	Kit-Dt Gasket	434-7276
160-1400	Yoke (1710)	319-3479
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194

94X		
Original Part Number	**Part Name**	**Classic Part Number**
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7776	Pump Gp-Water -B	395-1314
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
216-7957	U-Joint	367-6069
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
234-8002	Kit-Gasket-Sch	386-3817
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
328-4374	Disc-Friction	384-5966

Sales Model 966E (Cont'd.)

94X		
Original Part Number	Part Name	Classic Part Number
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349

94X		
Original Part Number	Part Name	Classic Part Number
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005

94X		
Original Part Number	Part Name	Classic Part Number
391-8229	Kit-Gasket-Fs	398-2955
443-1200	Brg-Rlr-Cla	377-7397

99Y		
Original Part Number	Part Name	Classic Part Number
1B-3922	Cup-Roller Brg	416-2158
1B-3934	Cup-Roller Brg	392-4487
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1L-7205	Bearing-Ball	416-2167
1N-2936	Muffler As	298-2782
1N-2946	Extension-Exh	367-6064
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659

99Y		
Original Part Number	Part Name	Classic Part Number
1W-5910	Tappet As-Guide&	383-1569
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-5685	Bearing-Needle	380-7469

99Y		
Original Part Number	Part Name	Classic Part Number
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4611	Pipe-Exhaust	365-8821
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5709	Shaft-Axle	299-2056
2V-5714	Gear-Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203

Sales Model 966E (Cont'd.)

99Y		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7455	Gear As	396-9957
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-7933	Core As-O Clr	374-4708
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3E-6772	Seal-Water	382-8017
3G-2665	Cover	308-9842
3G-5264	Cylinder As.	393-1018
3G-5492	Rod As	377-5836
3G-5497	Cyl Gp-0210 0535	394-9822
3G-5502	Cylinder As	390-0988
3G-7660	Cartridge Gp	422-8103
3G-9891	Pump Gp-Gr A	399-8541
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
3T-2094	Bearing-Sleeve	388-0638
3T-2095	Bearing-Sleeve	384-3459
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
3V-0593	Rim As	418-9568
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4E-8535	Retainer-Seal	300-2589
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384

99Y		
Original Part Number	**Part Name**	**Classic Part Number**
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1767	Valve-Bypass	419-4716
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-2954	Sleeve-Camshaft	299-2059
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4N-7693	Crankshaft As	269-8763
4P-2383	Adapter-Inlet	438-1812
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986

99Y		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-8472	Hood As-Preclnr	296-1355
4T-0422	Cartridge Gp	422-8129
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2057	Bearing-Spher	419-6019
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-5388	Shaft-Bev Pinion	297-7244
4V-5392	Spider	377-7430
4V-5393	Gear-Bevel	297-7189
4V-5394	Gear-Diff	297-7177
4V-5400	Housing-Brg Spt	385-7202
4V-6421	Pin As	319-3442
4V-7082	Joint Gp-Slip	367-6068
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-7543	Retainer	281-1699
4V-8518	Link As-Brg&	374-1450
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0255	Spider As-Fan	382-5052
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

Sales Model 966E (Cont'd.)

99Y		
Original Part Number	Part Name	Classic Part Number
4W-2446	Damper As	279-4990
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5053	Muffler As	360-7881
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-7382	Core As-Oclr	380-1514
4Y-4340	Pin As	319-3442
4Y-5711	Pin As	425-6442
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5K-3493	Cover	391-9814
5K-3495	Collar	383-2129
5K-8591	Bearing-Outer	380-7502
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5L-6326	Bearing-Ball	420-3222
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502

99Y		
Original Part Number	Part Name	Classic Part Number
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3617	Support-Trunnion	374-4712
6E-0775	Head	425-9373
6E-2387	Cartridge Gp	422-8132
6E-5028	Rod As	425-9372
6E-6416	Cylinder As	425-9371
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1453	Crankshaft As	368-5916
6I-2408	Muffler As.	378-3978
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1572	Mount As	308-9876

99Y		
Original Part Number	Part Name	Classic Part Number
6N-1931	Plunger	379-0171
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-9743	Support-Muffler	308-9940
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-4350	Race-Spl Rlr Brg	384-5933
6W-9677	Tube As-Rh	388-6569
6W-9678	Tube As-Lh	388-6570
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5403	Tube As	374-4673
7C-5851	Muffler As	298-2790
7C-6697	Shaft - Idler	425-9370
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-9198	Block	419-2303
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-6794	Arm As-Injector	433-0449

Sales Model 966E (Cont'd.)

99Y		
Original Part Number	**Part Name**	**Classic Part Number**
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-1572	Cover-Water Pump	377-5854
7N-2156	Bearing-Sleeve	380-7373
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8371	Line As-Fuel Inj	373-1901
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4097	Adapter-Exh Man	383-3700

99Y		
Original Part Number	**Part Name**	**Classic Part Number**
7S-4629	Pump Gp-Trans	226-0158
7T-2036	Cap As-Fuel	361-1721
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7V-6716	Pin As	396-7273
7W-0140	Gear-Drive	399-8546
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5095	Gear-Flywheel	425-9190
7W-5435	Adapter-Nozzle	374-7493
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-5733	Gasket	421-7333
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8555	Gasket Kit	434-7278
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8F-6058	Bearing-Sleeve	416-5494
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1726	Rod As-Conn	379-8866
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521

99Y		
Original Part Number	**Part Name**	**Classic Part Number**
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8258	Bearing-Sleeve	452-1077
8N-9733	Line As-F Inj	319-8174
8P-0953	Turbine-Conv	297-7269
8P-0961	Impeller-Conv	433-9204
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116

Sales Model 966E (Cont'd.)

99Y		
Original Part Number	Part Name	Classic Part Number
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-0931	Housing-Pinion	302-4300
8R-0942	Plate-Reaction	380-1484
8R-1015	Support-Trunnion	374-4712
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-3252	Shaft-Planet	297-7259
8R-8335	Gear-Bevel	368-0105
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3653	Bonnet-Valve	374-4728
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6390	Drum-Brake	377-7449
8V-7659	Pin As	361-1702
8V-7885	Housing-Support	297-7193
9B-1320	Valve-Check	377-5832
9C-1484	Pin As	319-3446
9C-4007	Bearing-Sleeve	374-1459
9C-4080	Yoke-Brake	302-2703
9C-5852	Hub As	297-7208
9C-6015	Pinion-Diff Bev	297-7225
9C-6029	Bearing-Planet	375-9982
9C-8218	Shaft-Bev Pinion	302-2697
9C-8669	Shaft-Bev Pinion	368-0107
9C-9191	Trunnion	302-2701
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931

99Y		
Original Part Number	Part Name	Classic Part Number
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-5836	Coupling-Exhaust	385-7212
9L-5839	Coupling-Exhaust	374-7480
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-5477	Bearing-Sleeve	374-6517
9N-1545	Race-Thrust	394-9205
9N-5403	Body As-Piston	250-6558
9N-5529	Body-F Inj Valve	378-3993
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9U-2787	Gear-Planet	367-6093
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807

99Y		
Original Part Number	Part Name	Classic Part Number
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5160	Plunger Kt-Adj	385-7218
9V-5174	Joint Gp-Univ	375-2628
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9W-9027	Plate	419-2306
9Y-1798	Seal-Water	379-0165
9Y-1917	Pulley-Fan	395-1311
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-2848	Ring-Guide	399-6057
100-3596	Piston	380-1511
100-3597	Plate-Reaction	380-1501
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
102-8636	Gear-Drive	472-8035
103-5961	Wheel	398-2963
107-7708	Bearing-Main	419-6381
108-2102	Bonnet-Valve	455-3274
108-5603	Screw-Adj Arm	379-0166

Sales Model 966E (Cont'd.)

99Y		
Original Part Number	**Part Name**	**Classic Part Number**
108-5680	Gage-Oil Level	378-4001
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-1488	Gear-Ring	394-0882
110-5096	Head As-Cyl	394-0915
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
114-0468	Pin-G.E.T.	443-1203
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-4072	Bearing	397-5069
117-0456	Crankshaft As	394-2587
119-5727	Bearing-Spl Ball	417-9491
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-2726	Head	377-5855
126-2522	Cone-Spl Tapered	377-7397
127-5537	Core As-Oclr	325-6045
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-4995	Gasket-Cyl Head	434-2445
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
136-7813	Bearing-Race	460-8296
139-9175	Gasket Kit	377-7464
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554

99Y		
Original Part Number	**Part Name**	**Classic Part Number**
144-0744	Compressor Gp -B	435-6046
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
145-8503	Shaft As-Idler	426-0035
148-7455	Valve - Exhaust	270-4361
148-9288	Case As-Diff	380-1496
150-4637	Pan-Oil	377-5843
151-4836	Diff Gp -A	416-2120
154-8030	Gasket	394-0894
155-5619	Gasket	382-5054
155-6648	Cone Spl Rol Brg	418-9599
158-1438	Kit-Dt Gasket	434-7276
159-3021	Gasket	377-5845
160-1400	Yoke (1710)	319-3479
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
166-9142	Gasket	420-8546
167-8123	Damper As	299-2006
167-8126	Damper As	382-8019
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0560	Rebuild Kit-Pump	363-7458
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574

99Y		
Original Part Number	**Part Name**	**Classic Part Number**
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
187-0605	Gasket Kit - Cl	382-5055
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
197-5510	Support As	419-0880
202-3572	Shaft As-Drive	426-0037
206-6405	Bearing-Spl Ball	420-2503
211-0592	Bearing - Main	419-6368
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
216-7957	U-Joint	367-6069
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
228-0419	Seal As	443-3571
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

Sales Model 966E (Cont'd.)

99Y		
Original Part Number	Part Name	Classic Part Number
232-3233	Bearing-Main	376-9085
234-8002	Kit-Gasket-Sch	386-3817
250-6558	Liner Kit-Cla	295-6438
253-1752	Plate-Thrust	379-0170
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028

99Y		
Original Part Number	Part Name	Classic Part Number
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387

99Y		
Original Part Number	Part Name	Classic Part Number
328-5574	Bearing-Rod	419-7266
334-1032	Disc-Friction	440-3116
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
391-8229	Kit-Gasket-Fs	398-2955
430-7619	Adapter-Cla	438-1812
443-1200	Brg-Rlr-Cla	377-7397

Sales Model 966F

1SL		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7125	Governor As	383-3672
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1V-8604	Gear-Ring	308-9853
1W-1669	Piston	325-6158

1SL		
Original Part Number	Part Name	Classic Part Number
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6511	Cup-Roller Brg	377-7417
2D-9130	Washer-Thrust	308-9943
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

1SL		
Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5103	Cone-Roller Brg	380-7505
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230

Sales Model 966F (Cont'd.)

1SL		
Original Part Number	**Part Name**	**Classic Part Number**
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4611	Pipe-Exhaust	365-8821
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5709	Shaft-Axle	299-2056
2V-5714	Gear-Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3G-5264	Cylinder As.	393-1018
3G-5492	Rod As	377-5836
3G-5497	Cyl Gp-0210 0535	394-9822
3G-5502	Cylinder As	390-0988
3G-7660	Cartridge Gp	422-8103
3G-9891	Pump Gp-Gr A	399-8541
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
3T-2094	Bearing-Sleeve	388-0638
3T-2095	Bearing-Sleeve	384-3459

1SL		
Original Part Number	**Part Name**	**Classic Part Number**
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
3V-0593	Rim As	418-9568
3V-3855	Housing-Brg Spt	375-9980
3V-6697	Housing	424-4944
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4C-1335	Washer-Thrust	399-4425
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4E-8535	Retainer-Seal	300-2589
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0897	Core As-Radiator	376-9058
4P-3546	Valve As-Relief	325-6236
4P-6548	Muffler As	360-7878
4P-6589	Pipe As	382-6898
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985

1SL		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0422	Cartridge Gp	422-8129
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3680	Bellcrank	308-9802
4V-5099	Cover	418-1929
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-6421	Pin As	319-3442
4V-7082	Joint Gp-Slip	367-6068
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-8518	Link As-Brg&	374-1450
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534

Sales Model 966F (Cont'd.)

1SL		
Original Part Number	Part Name	Classic Part Number
4W-7188	Core As-Oclr	374-7501
4Y-4340	Pin As	319-3442
4Y-5711	Pin As	425-6442
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5G-3612	Cap Gp-Protn	295-6419
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-5917	Pinion-Diff	297-7224
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3617	Support-Trunnion	374-4712
6E-0775	Head	425-9373
6E-2387	Cartridge Gp	422-8132

1SL		
Original Part Number	Part Name	Classic Part Number
6E-5028	Rod As	425-9372
6E-6416	Cylinder As	425-9371
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-2408	Muffler As.	378-3978
6I-2409	Pipe	383-3693
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6V-5976	Kit-Gasket (Rs)	393-5200
6W-7290	Shaft-Planet	308-9930
6W-9677	Tube As-Rh	388-6569
6W-9678	Tube As-Lh	388-6570
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939

1SL		
Original Part Number	Part Name	Classic Part Number
7D-8349	Cone-Rlr Brg	419-6074
7D-8437	Cone-Roller Brg	380-1502
7E-3557	Spider As-Fan	430-4471
7E-5085	Bushing	377-5829
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-0686	Trunnion-Rear	297-7266
7K-9639	Bearing-Sleeve	314-8643
7M-4046	Bearing-Sleeve	394-8206
7M-5334	Cone-Roller Brg	420-2505
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4629	Pump Gp-Trans	226-0158
7T-2036	Cap As-Fuel	361-1721

Sales Model 966F (Cont'd.)

1SL		
Original Part Number	**Part Name**	**Classic Part Number**
7T-3365	Carrier-Planet	388-6563
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-5645	Rod-Indicator	397-5061
7V-6715	Pin As	361-1701
7V-6716	Pin As	396-7273
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5095	Gear-Flywheel	425-9190
7W-5699	Pulley-Cshaft	378-3988
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8555	Gasket Kit	434-7278
8E-7569	Case-Xmsn	394-0899
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8F-9365	Pin	319-3463
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

1SL		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0514	Yoke As	308-9947
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-0931	Housing-Pinion	302-4300
8R-0942	Plate-Reaction	380-1484
8R-1015	Support-Trunnion	374-4712
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-3252	Shaft-Planet	297-7259

1SL		
Original Part Number	**Part Name**	**Classic Part Number**
8R-3921	Collet	308-9839
8R-3943	Collet	308-9840
8R-4184	Bearing-Sleeve	374-6515
8R-4821	Carrier-Planet	308-9837
8R-6213	Mount As	389-6301
8R-7425	Retainer	308-9917
8R-8335	Gear-Bevel	368-0105
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3550	Rim As	417-9477
8V-6382	Hub As	308-9868
8V-6384	Spacer As	308-9935
8V-6390	Drum-Brake	377-7449
8V-7659	Pin As	361-1702
8V-7885	Housing-Support	297-7193
9C-1484	Pin As	319-3446
9C-2249	Yoke As	382-6890
9C-4007	Bearing-Sleeve	374-1459
9C-4080	Yoke-Brake	302-2703
9C-5852	Hub As	297-7208
9C-6029	Bearing-Planet	375-9982
9C-8074	Gear-Planet	308-9858
9C-8075	Gear-Sun	308-9864
9C-8218	Shaft-Bev Pinion	302-2697
9C-8669	Shaft-Bev Pinion	368-0107
9C-9191	Trunnion	302-2701
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214

Sales Model 966F (Cont'd.)

1SL		
Original Part Number	Part Name	Classic Part Number
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-0971	Gear-Sun	368-0124
9U-0974	Bushing-Sleeve	374-1460
9U-0975	Hub As	390-5259
9U-2787	Gear-Planet	367-6093
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-0247	Plate	417-4527

1SL		
Original Part Number	Part Name	Classic Part Number
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5160	Plunger Kt-Adj	385-7218
9V-5174	Joint Gp-Univ	375-2628
9V-6165	Plate-Outer	377-7460
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6526	Ring-Retaining	422-2485
9V-7710	Univ Joint As	394-8234
9W-3605	Carrier-Ring	314-8662
9W-7019	Disc-Friction	377-7461
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
9Y-3318	Core As-Radiator	374-7491
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3596	Piston	380-1511
100-3597	Plate-Reaction	380-1501
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382
101-8740	Muffler As	360-7878
102-8636	Gear-Drive	472-8035
103-5961	Wheel	398-2963
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
107-7708	Bearing-Main	419-6381
107-9172	Piston	375-2622
108-5680	Gage-Oil Level	378-4001
110-0551	Hub As	416-2146
110-1337	Ring Kit-Pstn	377-5834
110-1488	Gear-Ring	394-0882
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932

1SL		
Original Part Number	Part Name	Classic Part Number
112-8041	Carrier-Planet	295-5681
112-8042	Carrier-Planet	390-0916
115-4072	Bearing	397-5069
119-5727	Bearing-Spl Ball	417-9491
121-7583	Gear-Planet	364-5257
124-2726	Head	377-5855
126-2522	Cone-Spl Tapered	377-7397
127-5537	Core As-Oclr	325-6045
129-3046	Carrier-Planet	393-1015
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
133-4995	Gasket-Cyl Head	434-2445
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-0039	Housing-Piston	432-4217
134-3036	Gasket Kit	393-3629
134-3038	Gasket Kit	437-3228
134-3068	Kit-Gasket(F)	393-3636
135-7989	Gasket Kit	393-3633
136-7813	Bearing-Race	460-8296
139-9175	Gasket Kit	377-7464
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
148-7455	Valve - Exhaust	270-4361
148-9288	Case As-Diff	380-1496
149-2914	Pinion-Dif Bevel	396-9950
151-4836	Diff Gp -A	416-2120
154-8030	Gasket	394-0894

Sales Model 966F (Cont'd.)

1SL		
Original Part Number	**Part Name**	**Classic Part Number**
155-1379	Gasket Kit - Sch	386-3815
158-1438	Kit-Dt Gasket	434-7276
158-1439	Kit-Dt Gasket	434-7290
159-8169	Gear-Planet	391-9870
160-1400	Yoke (1710)	319-3479
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112

1SL		
Original Part Number	**Part Name**	**Classic Part Number**
172-7760	Pump Gp-Water -B	380-7574
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
176-3900	Accumulator	416-5513
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
208-7534	Case As-Diff	388-6590
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
216-7957	U-Joint	367-6069
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
228-0419	Seal As	443-3571

1SL		
Original Part Number	**Part Name**	**Classic Part Number**
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3233	Bearing-Main	376-9085
234-7988	Kit-Gasket-Sch	387-2925
234-8016	Kit-Gasket-Sch	393-0919
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
319-5239	Wheel	396-9956
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-1032	Disc-Friction	440-3116
334-8389	Crankshaft As	242-3439
360-7863	Muffler-Cla	360-7878
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
443-1200	Brg-Rlr-Cla	377-7397

3FK		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
2D-9453	Cone-Roller Brg	380-7508
2K-5103	Cone-Roller Brg	380-7505
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
9C-6029	Bearing-Planet	375-9982
228-0419	Seal As	443-3571
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347

3FK		
Original Part Number	**Part Name**	**Classic Part Number**
1N-2936	Muffler As	298-2782
1N-2946	Extension-Exh	367-6064
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924

3FK		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358

Sales Model 966F (Cont'd.)

3FK		
Original Part Number	Part Name	Classic Part Number
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9453	Cone-Roller Brg	380-7508
2F-5721	Bearing-Ball	311-9354
2K-5065	Cone-Roller Brg	416-2157
2K-5103	Cone-Roller Brg	380-7505
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6757	Trunnion As	295-5678

3FK		
Original Part Number	Part Name	Classic Part Number
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-7933	Core As-O Clr	374-4708
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3G-5264	Cylinder As.	393-1018
3G-5492	Rod As	377-5836
3G-5497	Cyl Gp-0210 0535	394-9822
3G-5502	Cylinder As	390-0988
3G-7660	Cartridge Gp	422-8103
3G-9891	Pump Gp-Gr A	399-8541
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3N-5869	Support-Elbow	375-9973
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8535	Retainer-Seal	300-2589
4F-2393	Bearing-Ball	380-1499
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7270	Support-Trunnion	373-5384
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4N-0432	Bearing-Ball	417-4499

3FK		
Original Part Number	Part Name	Classic Part Number
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0897	Core As-Radiator	376-9058
4P-3546	Valve As-Relief	325-6236
4P-6548	Muffler As	360-7878
4P-6589	Pipe As	382-6898
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0422	Cartridge Gp	422-8129
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-5099	Cover	418-1929
4V-5392	Spider	377-7430
4V-6421	Pin As	319-3442
4V-7082	Joint Gp-Slip	367-6068
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-8518	Link As-Brg&	374-1450
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528

Sales Model 966F (Cont'd.)

3FK		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-5053	Muffler As	360-7881
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4Y-4340	Pin As	319-3442
4Y-5711	Pin As	425-6442
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

3FK		
Original Part Number	**Part Name**	**Classic Part Number**
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3617	Support-Trunnion	374-4712
6E-0775	Head	425-9373
6E-2387	Cartridge Gp	422-8132
6E-5028	Rod As	425-9372
6E-6416	Cylinder As	425-9371
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-2408	Muffler As.	378-3978
6I-2409	Pipe	383-3693
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6V-5976	Kit-Gasket (Rs)	393-5200
6W-9172	Bearing	389-6330
6W-9677	Tube As-Rh	388-6569
6W-9678	Tube As-Lh	388-6570
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113

3FK		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7C-5851	Muffler As	298-2790
7C-6628	Pulley-Alt	396-9894
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3557	Spider As-Fan	430-4471
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7J-6461	Crown	325-6054
7J-9344	Bearing-Sleeve	360-2334
7J-9682	Bearing-Sleeve	360-2335
7K-9639	Bearing-Sleeve	314-8643
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-5206	Mount As	374-1451
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996

Sales Model 966F (Cont'd.)

3FK		
Original Part Number	Part Name	Classic Part Number
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7T-3370	Yoke As	302-2702
7T-4753	Stator-Converter	384-5945
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-5645	Rod-Indicator	397-5061
7V-6715	Pin As	361-1701
7V-6716	Pin As	396-7273
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8555	Gasket Kit	434-7278
8E-7569	Case-Xmsn	394-0899
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

3FK		
Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-0961	Impeller-Conv	433-9204
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-0931	Housing-Pinion	302-4300
8R-0942	Plate-Reaction	380-1484
8R-1015	Support-Trunnion	374-4712

3FK		
Original Part Number	Part Name	Classic Part Number
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-3252	Shaft-Planet	297-7259
8R-6213	Mount As	389-6301
8R-8335	Gear-Bevel	368-0105
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-7659	Pin As	361-1702
9C-1484	Pin As	319-3446
9C-4080	Yoke-Brake	302-2703
9C-6029	Bearing-Planet	375-9982
9C-8669	Shaft-Bev Pinion	368-0107
9C-9191	Trunnion	302-2701
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-5477	Bearing-Sleeve	374-6517

Sales Model 966F (Cont'd.)

3FK		
Original Part Number	**Part Name**	**Classic Part Number**
9M-6692	Strip	386-4934
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-2787	Gear-Planet	367-6093
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-4975	Bearing-Sleeve	384-4784
9V-5174	Joint Gp-Univ	375-2628
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355

3FK		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-1798	Seal-Water	379-0165
9Y-3318	Core As-Radiator	374-7491
100-3596	Piston	380-1511
100-3597	Plate-Reaction	380-1501
100-7860	Valve-Inlet	270-4360
101-8740	Muffler As	360-7878
102-8636	Gear-Drive	472-8035
108-5680	Gage-Oil Level	378-4001
110-1337	Ring Kit-Pstn	377-5834
110-1488	Gear-Ring	394-0882
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
114-0468	Pin-G.E.T.	443-1203
119-5727	Bearing-Spl Ball	417-9491
124-2726	Head	377-5855
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
136-7813	Bearing-Race	460-8296
139-9175	Gasket Kit	377-7464
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
148-9288	Case As-Diff	380-1496
151-4836	Diff Gp -A	416-2120
155-1379	Gasket Kit - Sch	386-3815
158-1438	Kit-Dt Gasket	434-7276
158-1439	Kit-Dt Gasket	434-7290

3FK		
Original Part Number	**Part Name**	**Classic Part Number**
160-1400	Yoke (1710)	319-3479
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
216-7957	U-Joint	367-6069
226-8202	Seal-Wiper	472-8024
228-0419	Seal As	443-3571
232-3233	Bearing-Main	376-9085
234-8016	Kit-Gasket-Sch	393-0919

Sales Model 966F (Cont'd.)

3FK		
Original Part Number	Part Name	Classic Part Number
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

3FK		
Original Part Number	Part Name	Classic Part Number
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349

3FK		
Original Part Number	Part Name	Classic Part Number
334-1032	Disc-Friction	440-3116
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
360-7863	Muffler-Cla	360-7878
391-8229	Kit-Gasket-Fs	398-2955

4YG		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7125	Governor As	383-3672
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1V-8604	Gear-Ring	308-9853
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659

4YG		
Original Part Number	Part Name	Classic Part Number
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6511	Cup-Roller Brg	377-7417
2D-9130	Washer-Thrust	308-9943
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5103	Cone-Roller Brg	380-7505
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1738	Plate As-Oil Pan	325-6164

4YG		
Original Part Number	Part Name	Classic Part Number
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4611	Pipe-Exhaust	365-8821
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5709	Shaft-Axle	299-2056
2V-5714	Gear-Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8493	Pulley-Fan	430-5361

Sales Model 966F (Cont'd.)

4YG		
Original Part Number	Part Name	Classic Part Number
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3G-5264	Cylinder As.	393-1018
3G-5492	Rod As	377-5836
3G-5497	Cyl Gp-0210 0535	394-9822
3G-5502	Cylinder As	390-0988
3G-7660	Cartridge Gp	422-8103
3G-9891	Pump Gp-Gr A	399-8541
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
3T-2094	Bearing-Sleeve	388-0638
3T-2095	Bearing-Sleeve	384-3459
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
3V-0593	Rim As	418-9568
3V-3855	Housing-Brg Spt	375-9980
3V-6697	Housing	424-4944
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4C-1335	Washer-Thrust	399-4425
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4E-8535	Retainer-Seal	300-2589
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116

4YG		
Original Part Number	Part Name	Classic Part Number
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0897	Core As-Radiator	376-9058
4P-3546	Valve As-Relief	325-6236
4P-6548	Muffler As	360-7878
4P-6589	Pipe As	382-6898
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0422	Cartridge Gp	422-8129
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3680	Bellcrank	308-9802
4V-5099	Cover	418-1929
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-6421	Pin As	319-3442
4V-7082	Joint Gp-Slip	367-6068

4YG		
Original Part Number	Part Name	Classic Part Number
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-8518	Link As-Brg&	374-1450
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4Y-4340	Pin As	319-3442
4Y-5711	Pin As	425-6442
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5G-3612	Cap Gp-Protn	295-6419
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467

Sales Model 966F (Cont'd.)

4YG		
Original Part Number	Part Name	Classic Part Number
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-5917	Pinion-Diff	297-7224
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3617	Support-Trunnion	374-4712
6E-0775	Head	425-9373
6E-2387	Cartridge Gp	422-8132
6E-5028	Rod As	425-9372
6E-6416	Cylinder As	425-9371
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-2408	Muffler As.	378-3978
6I-2409	Pipe	383-3693
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-1033	Rod End-Spher	375-5444

4YG		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6V-5976	Kit-Gasket (Rs)	393-5200
6W-7290	Shaft-Planet	308-9930
6W-9677	Tube As-Rh	388-6569
6W-9678	Tube As-Lh	388-6570
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8437	Cone-Roller Brg	380-1502
7E-3557	Spider As-Fan	430-4471
7E-5085	Bushing	377-5829
7E-6794	Arm As-Injector	433-0449
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-0686	Trunnion-Rear	297-7266
7K-9639	Bearing-Sleeve	314-8643
7M-4046	Bearing-Sleeve	394-8206
7M-5334	Cone-Roller Brg	420-2505
7M-7219	Bearing-Thrust	384-4816

4YG		
Original Part Number	Part Name	Classic Part Number
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4629	Pump Gp-Trans	226-0158
7T-2036	Cap As-Fuel	361-1721
7T-3365	Carrier-Planet	388-6563
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-5645	Rod-Indicator	397-5061
7V-6715	Pin As	361-1701
7V-6716	Pin As	396-7273
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5095	Gear-Flywheel	425-9190
7W-5699	Pulley-Cshaft	378-3988
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8555	Gasket Kit	434-7278
8E-7569	Case-Xmsn	394-0899
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8F-9365	Pin	319-3463
8H-0901	Cup-Spl Tap Roll	399-4444

Sales Model 966F (Cont'd.)

4YG		
Original Part Number	Part Name	Classic Part Number
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0514	Yoke As	308-9947

4YG		
Original Part Number	Part Name	Classic Part Number
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-0931	Housing-Pinion	302-4300
8R-0942	Plate-Reaction	380-1484
8R-1015	Support-Trunnion	374-4712
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-3252	Shaft-Planet	297-7259
8R-3921	Collet	308-9839
8R-3943	Collet	308-9840
8R-4184	Bearing-Sleeve	374-6515
8R-4821	Carrier-Planet	308-9837
8R-6213	Mount As	389-6301
8R-7425	Retainer	308-9917
8R-8335	Gear-Bevel	368-0105
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3550	Rim As	417-9477
8V-6382	Hub As	308-9868
8V-6384	Spacer As	308-9935
8V-6390	Drum-Brake	377-7449
8V-7659	Pin As	361-1702

4YG		
Original Part Number	Part Name	Classic Part Number
8V-7885	Housing-Support	297-7193
9C-1484	Pin As	319-3446
9C-2249	Yoke As	382-6890
9C-4007	Bearing-Sleeve	374-1459
9C-4080	Yoke-Brake	302-2703
9C-5852	Hub As	297-7208
9C-6029	Bearing-Planet	375-9982
9C-8074	Gear-Planet	308-9858
9C-8075	Gear-Sun	308-9864
9C-8218	Shaft-Bev Pinion	302-2697
9C-8669	Shaft-Bev Pinion	368-0107
9C-9191	Trunnion	302-2701
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220

Sales Model 966F (Cont'd.)

4YG		
Original Part Number	Part Name	Classic Part Number
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-0971	Gear-Sun	368-0124
9U-0974	Bushing-Sleeve	374-1460
9U-0975	Hub As	390-5259
9U-2787	Gear-Planet	367-6093
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5160	Plunger Kt-Adj	385-7218
9V-5174	Joint Gp-Univ	375-2628
9V-6165	Plate-Outer	377-7460
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6526	Ring-Retaining	422-2485
9V-7710	Univ Joint As	394-8234
9W-3605	Carrier-Ring	314-8662
9W-7019	Disc-Friction	377-7461
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
9Y-3318	Core As-Radiator	374-7491
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3596	Piston	380-1511

4YG		
Original Part Number	Part Name	Classic Part Number
100-3597	Plate-Reaction	380-1501
100-7860	Valve-Inlet	270-4360
101-1530	Bearing-Main	419-6382
101-8740	Muffler As	360-7878
102-8636	Gear-Drive	472-8035
103-5961	Wheel	398-2963
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
107-7708	Bearing-Main	419-6381
107-9172	Piston	375-2622
108-5680	Gage-Oil Level	378-4001
110-0551	Hub As	416-2146
110-1337	Ring Kit-Pstn	377-5834
110-1488	Gear-Ring	394-0882
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
112-8042	Carrier-Planet	390-0916
115-4072	Bearing	397-5069
119-5727	Bearing-Spl Ball	417-9491
121-7583	Gear-Planet	364-5257
124-2726	Head	377-5855
126-2522	Cone-Spl Tapered	377-7397
127-5537	Core As-Oclr	325-6045
129-3046	Carrier-Planet	393-1015
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
133-4995	Gasket-Cyl Head	434-2445
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-0039	Housing-Piston	432-4217

4YG		
Original Part Number	Part Name	Classic Part Number
134-3036	Gasket Kit	393-3629
134-3038	Gasket Kit	437-3228
134-3068	Kit-Gasket(F)	393-3636
135-7989	Gasket Kit	393-3633
136-7813	Bearing-Race	460-8296
139-9175	Gasket Kit	377-7464
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
148-7455	Valve - Exhaust	270-4361
148-9288	Case As-Diff	380-1496
149-2914	Pinion-Dif Bevel	396-9950
151-4836	Diff Gp -A	416-2120
154-8030	Gasket	394-0894
155-1379	Gasket Kit - Sch	386-3815
158-1438	Kit-Dt Gasket	434-7276
158-1439	Kit-Dt Gasket	434-7290
159-8169	Gear-Planet	391-9870
160-1400	Yoke (1710)	319-3479
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687

Sales Model 966F (Cont'd.)

4YG		
Original Part Number	**Part Name**	**Classic Part Number**
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
176-3900	Accumulator	416-5513
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503

4YG		
Original Part Number	**Part Name**	**Classic Part Number**
208-7534	Case As-Diff	388-6590
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
216-7957	U-Joint	367-6069
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
228-0419	Seal As	443-3571
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3233	Bearing-Main	376-9085
234-7988	Kit-Gasket-Sch	387-2925
234-8016	Kit-Gasket-Sch	393-0919
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356

4YG		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
319-5239	Wheel	396-9956
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-1032	Disc-Friction	440-3116
334-8389	Crankshaft As	242-3439
360-7863	Muffler-Cla	360-7878
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
443-1200	Brg-Rlr-Cla	377-7397

6FJ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006

6FJ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2F-5721	Bearing-Ball	311-9354
2K-5065	Cone-Roller Brg	416-2157
2K-5103	Cone-Roller Brg	380-7505

6FJ		
Original Part Number	**Part Name**	**Classic Part Number**
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055

Sales Model 966F (Cont'd.)

6FJ		
Original Part Number	Part Name	Classic Part Number
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3G-5492	Rod As	377-5836
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-8535	Retainer-Seal	300-2589
4F-2393	Bearing-Ball	380-1499
4K-7270	Support-Trunnion	373-5384
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-0897	Core As-Radiator	376-9058
4P-3546	Valve As-Relief	325-6236
4P-6548	Muffler As	360-7878
4P-6589	Pipe As	382-6898
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

6FJ		
Original Part Number	Part Name	Classic Part Number
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-9311	Housing	396-0652
4V-2518	Shaft	297-7243
4V-5099	Cover	418-1929
4V-5392	Spider	377-7430
4V-7082	Joint Gp-Slip	367-6068
4V-8518	Link As-Brg&	374-1450
4V-8520	Bearing-Sleeve	307-1527
4W-0452	Seal As -Cshaft	325-6191
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437

6FJ		
Original Part Number	Part Name	Classic Part Number
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3617	Support-Trunnion	374-4712
6E-2387	Cartridge Gp	422-8132
6E-5028	Rod As	425-9372
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6V-5976	Kit-Gasket (Rs)	393-5200
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3557	Spider As-Fan	430-4471
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-9682	Bearing-Sleeve	360-2335

Sales Model 966F (Cont'd.)

6FJ		
Original Part Number	**Part Name**	**Classic Part Number**
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5699	Pulley-Cshaft	378-3988
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-7569	Case-Xmsn	394-0899
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210

6FJ		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-0931	Housing-Pinion	302-4300
8R-0942	Plate-Reaction	380-1484
8R-1015	Support-Trunnion	374-4712
8R-1088	Bearing-Sleeve	419-0885
8R-3252	Shaft-Planet	297-7259

6FJ		
Original Part Number	**Part Name**	**Classic Part Number**
8R-8335	Gear-Bevel	368-0105
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8V-1612	Shaft	425-6456
9C-4080	Yoke-Brake	302-2703
9C-6029	Bearing-Planet	375-9982
9C-8669	Shaft-Bev Pinion	368-0107
9C-9191	Trunnion	302-2701
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221

Sales Model 966F (Cont'd.)

6FJ		
Original Part Number	Part Name	Classic Part Number
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-2787	Gear-Planet	367-6093
9V-5174	Joint Gp-Univ	375-2628
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
100-3596	Piston	380-1511
100-3597	Plate-Reaction	380-1501
100-7860	Valve-Inlet	270-4360
101-8740	Muffler As	360-7878
102-8636	Gear-Drive	472-8035
108-5680	Gage-Oil Level	378-4001
110-1337	Ring Kit-Pstn	377-5834
110-1488	Gear-Ring	394-0882
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
119-5727	Bearing-Spl Ball	417-9491
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
144-0502	Ring Kit-Piston	395-1312

6FJ		
Original Part Number	Part Name	Classic Part Number
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
148-9288	Case As-Diff	380-1496
151-4836	Diff Gp -A	416-2120
160-1400	Yoke (1710)	319-3479
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574

6FJ		
Original Part Number	Part Name	Classic Part Number
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
216-7957	U-Joint	367-6069
228-0419	Seal As	443-3571
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-1032	Disc-Friction	440-3116
334-8389	Crankshaft As	242-3439
360-7863	Muffler-Cla	360-7878
391-8229	Kit-Gasket-Fs	398-2955

6ML		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572

6ML		
Original Part Number	Part Name	Classic Part Number
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

6ML		
Original Part Number	Part Name	Classic Part Number
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036

Sales Model 966F (Cont'd.)

6ML		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2F-5721	Bearing-Ball	311-9354
2K-5065	Cone-Roller Brg	416-2157
2K-5103	Cone-Roller Brg	380-7505
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3G-5492	Rod As	377-5836
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208

6ML		
Original Part Number	**Part Name**	**Classic Part Number**
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-8535	Retainer-Seal	300-2589
4F-2393	Bearing-Ball	380-1499
4K-7270	Support-Trunnion	373-5384
4K-7463	Seal-Lip Type	472-8007
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-0897	Core As-Radiator	376-9058
4P-3546	Valve As-Relief	325-6236
4P-6548	Muffler As	360-7878
4P-6589	Pipe As	382-6898
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-9311	Housing	396-0652
4V-2518	Shaft	297-7243
4V-5099	Cover	418-1929
4V-5392	Spider	377-7430

6ML		
Original Part Number	**Part Name**	**Classic Part Number**
4V-7082	Joint Gp-Slip	367-6068
4V-8518	Link As-Brg&	374-1450
4V-8520	Bearing-Sleeve	307-1527
4W-0452	Seal As -Cshaft	325-6191
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3617	Support-Trunnion	374-4712
6E-2387	Cartridge Gp	422-8132
6E-5028	Rod As	425-9372
6H-3957	Bearing-Ball	311-9358

Sales Model 966F (Cont'd.)

6ML		
Original Part Number	Part Name	Classic Part Number
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6V-5976	Kit-Gasket (Rs)	393-5200
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3557	Spider As-Fan	430-4471
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-9682	Bearing-Sleeve	360-2335
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496

6ML		
Original Part Number	Part Name	Classic Part Number
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5699	Pulley-Cshaft	378-3988
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-7569	Case-Xmsn	394-0899
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464

6ML		
Original Part Number	Part Name	Classic Part Number
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-0931	Housing-Pinion	302-4300
8R-0942	Plate-Reaction	380-1484
8R-1015	Support-Trunnion	374-4712
8R-1088	Bearing-Sleeve	419-0885
8R-3252	Shaft-Planet	297-7259
8R-8335	Gear-Bevel	368-0105
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416

Sales Model 966F (Cont'd.)

6ML		
Original Part Number	**Part Name**	**Classic Part Number**
8V-1612	Shaft	425-6456
9C-4080	Yoke-Brake	302-2703
9C-6029	Bearing-Planet	375-9982
9C-8669	Shaft-Bev Pinion	368-0107
9C-9191	Trunnion	302-2701
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-2787	Gear-Planet	367-6093
9V-5174	Joint Gp-Univ	375-2628

6ML		
Original Part Number	**Part Name**	**Classic Part Number**
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
100-3596	Piston	380-1511
100-3597	Plate-Reaction	380-1501
100-7860	Valve-Inlet	270-4360
101-8740	Muffler As	360-7878
102-8636	Gear-Drive	472-8035
108-5680	Gage-Oil Level	378-4001
110-1337	Ring Kit-Pstn	377-5834
110-1488	Gear-Ring	394-0882
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
119-5727	Bearing-Spl Ball	417-9491
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
136-7813	Bearing-Race	460-8296
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
148-9288	Case As-Diff	380-1496
151-4836	Diff Gp -A	416-2120
160-1400	Yoke (1710)	319-3479
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

6ML		
Original Part Number	**Part Name**	**Classic Part Number**
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
216-7957	U-Joint	367-6069
228-0419	Seal As	443-3571
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-1032	Disc-Friction	440-3116
334-8389	Crankshaft As	242-3439
360-7863	Muffler-Cla	360-7878
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 966F (Cont'd.)

7HL		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
2D-9453	Cone-Roller Brg	380-7508
2K-5103	Cone-Roller Brg	380-7505
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
9C-6029	Bearing-Planet	375-9982
228-0419	Seal As	443-3571
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-2936	Muffler As	298-2782
1N-2946	Extension-Exh	367-6064
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

7HL		
Original Part Number	Part Name	Classic Part Number
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5103	Cone-Roller Brg	380-7505
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5709	Shaft-Axle	299-2056
2V-5714	Gear-Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164

7HL		
Original Part Number	Part Name	Classic Part Number
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3G-2797	Bearing-Sleeve	360-2329
3G-5264	Cylinder As.	393-1018
3G-5492	Rod As	377-5836
3G-5497	Cyl Gp-0210 0535	394-9822
3G-5502	Cylinder As	390-0988
3G-7660	Cartridge Gp	422-8103
3G-9891	Pump Gp-Gr A	399-8541
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4E-8535	Retainer-Seal	300-2589
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-6558	Pin-Lower	302-2710

Sales Model 966F (Cont'd.)

7HL		
Original Part Number	**Part Name**	**Classic Part Number**
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0897	Core As-Radiator	376-9058
4P-3546	Valve As-Relief	325-6236
4P-6548	Muffler As	360-7878
4P-6589	Pipe As	382-6898
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0231	Retainer	376-3641
4T-0422	Cartridge Gp	422-8129
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-5099	Cover	418-1929
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430

7HL		
Original Part Number	**Part Name**	**Classic Part Number**
4V-5394	Gear-Diff	297-7177
4V-6421	Pin As	319-3442
4V-7082	Joint Gp-Slip	367-6068
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-8518	Link As-Brg&	374-1450
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-4340	Pin As	319-3442
4Y-5711	Pin As	425-6442
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247

7HL		
Original Part Number	**Part Name**	**Classic Part Number**
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-1530	Link As	374-1463
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3617	Support-Trunnion	374-4712
6E-0775	Head	425-9373
6E-2387	Cartridge Gp	422-8132
6E-5028	Rod As	425-9372
6E-6416	Cylinder As	425-9371
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-2408	Muffler As.	378-3978
6I-2409	Pipe	383-3693
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6V-5976	Kit-Gasket (Rs)	393-5200

Sales Model 966F (Cont'd.)

7HL		
Original Part Number	Part Name	Classic Part Number
6W-9677	Tube As-Rh	388-6569
6W-9678	Tube As-Lh	388-6570
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3557	Spider As-Fan	430-4471
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7J-6461	Crown	325-6054
7J-9346	Bearing-Sleeve	374-8357
7J-9682	Bearing-Sleeve	360-2335
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491

7HL		
Original Part Number	Part Name	Classic Part Number
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7V-6716	Pin As	396-7273
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5699	Pulley-Cshaft	378-3988
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-7569	Case-Xmsn	394-0899
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349

7HL		
Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-0931	Housing-Pinion	302-4300
8R-0942	Plate-Reaction	380-1484
8R-1015	Support-Trunnion	374-4712
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-3252	Shaft-Planet	297-7259
8R-6213	Mount As	389-6301
8R-8335	Gear-Bevel	368-0105
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416

Sales Model 966F (Cont'd.)

7HL		
Original Part Number	**Part Name**	**Classic Part Number**
8T-0072	Cone-Rlr Brg	377-7448
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-6390	Drum-Brake	377-7449
8V-7659	Pin As	361-1702
8V-7885	Housing-Support	297-7193
9C-1484	Pin As	319-3446
9C-4007	Bearing-Sleeve	374-1459
9C-4080	Yoke-Brake	302-2703
9C-5852	Hub As	297-7208
9C-6029	Bearing-Planet	375-9982
9C-8218	Shaft-Bev Pinion	302-2697
9C-8669	Shaft-Bev Pinion	368-0107
9C-9191	Trunnion	302-2701
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9L-2685	Rod End	419-1866
9L-6371	Rod-Eye	363-7459
9M-6692	Strip	386-4934
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309

7HL		
Original Part Number	**Part Name**	**Classic Part Number**
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-2787	Gear-Planet	367-6093
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5160	Plunger Kt-Adj	385-7218
9V-5174	Joint Gp-Univ	375-2628
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
9Y-3318	Core As-Radiator	374-7491
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3596	Piston	380-1511
100-3597	Plate-Reaction	380-1501
100-7860	Valve-Inlet	270-4360
101-8740	Muffler As	360-7878
102-8636	Gear-Drive	472-8035
103-5961	Wheel	398-2963
108-5680	Gage-Oil Level	378-4001
110-1337	Ring Kit-Pstn	377-5834
110-1488	Gear-Ring	394-0882

7HL		
Original Part Number	**Part Name**	**Classic Part Number**
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
119-5727	Bearing-Spl Ball	417-9491
124-2726	Head	377-5855
126-2522	Cone-Spl Tapered	377-7397
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-3068	Kit-Gasket(F)	393-3636
136-7813	Bearing-Race	460-8296
139-9175	Gasket Kit	377-7464
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
148-9288	Case As-Diff	380-1496
151-4836	Diff Gp -A	416-2120
155-1379	Gasket Kit - Sch	386-3815
158-1438	Kit-Dt Gasket	434-7276
158-1439	Kit-Dt Gasket	434-7290
160-1400	Yoke (1710)	319-3479
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687

Sales Model 966F (Cont'd.)

7HL		
Original Part Number	Part Name	Classic Part Number
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1365	Bearing-Sleeve	330-9256

7HL		
Original Part Number	Part Name	Classic Part Number
213-1370	Bearing-Sleeve	380-7370
216-7957	U-Joint	367-6069
226-8202	Seal-Wiper	472-8024
228-0419	Seal As	443-3571
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349

7HL		
Original Part Number	Part Name	Classic Part Number
334-1032	Disc-Friction	440-3116
334-8389	Crankshaft As	242-3439
360-7863	Muffler-Cla	360-7878
391-8229	Kit-Gasket-Fs	398-2955
443-1200	Brg-Rlr-Cla	377-7397
1J-2860	Cup-Spl Tapered	374-8347
2D-9453	Cone-Roller Brg	380-7508
2K-5103	Cone-Roller Brg	380-7505
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
9C-6029	Bearing-Planet	375-9982
228-0419	Seal As	443-3571

8BG		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-2936	Muffler As	298-2782
1N-2946	Extension-Exh	367-6064
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116

8BG		
Original Part Number	Part Name	Classic Part Number
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9453	Cone-Roller Brg	380-7508

8BG		
Original Part Number	Part Name	Classic Part Number
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5103	Cone-Roller Brg	380-7505
2M-5685	Bearing-Needle	380-7469
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214

Sales Model 966F (Cont'd.)

8BG		
Original Part Number	**Part Name**	**Classic Part Number**
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5709	Shaft-Axle	299-2056
2V-5714	Gear-Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-7092	Plate-Retainer	374-6510
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3G-2797	Bearing-Sleeve	360-2329
3G-5264	Cylinder As.	393-1018
3G-5492	Rod As	377-5836
3G-5497	Cyl Gp-0210 0535	394-9822
3G-5502	Cylinder As	390-0988
3G-7660	Cartridge Gp	422-8103
3G-9891	Pump Gp-Gr A	399-8541
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573

8BG		
Original Part Number	**Part Name**	**Classic Part Number**
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8534	Retainer-Seal	300-2588
4E-8535	Retainer-Seal	300-2589
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0897	Core As-Radiator	376-9058
4P-3546	Valve As-Relief	325-6236
4P-6548	Muffler As	360-7878
4P-6589	Pipe As	382-6898
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217

8BG		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0231	Retainer	376-3641
4T-0422	Cartridge Gp	422-8129
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-5099	Cover	418-1929
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-5394	Gear-Diff	297-7177
4V-6421	Pin As	319-3442
4V-7082	Joint Gp-Slip	367-6068
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-8518	Link As-Brg&	374-1450
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4Y-4340	Pin As	319-3442
4Y-5711	Pin As	425-6442
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917

Sales Model 966F (Cont'd.)

8BG		
Original Part Number	Part Name	Classic Part Number
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-1530	Link As	374-1463
5V-5917	Pinion-Diff	297-7224
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3617	Support-Trunnion	374-4712
6E-0775	Head	425-9373
6E-2387	Cartridge Gp	422-8132
6E-5028	Rod As	425-9372
6E-6416	Cylinder As	425-9371
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-2408	Muffler As.	378-3978
6I-2409	Pipe	383-3693
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487

8BG		
Original Part Number	Part Name	Classic Part Number
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6V-5976	Kit-Gasket (Rs)	393-5200
6W-9677	Tube As-Rh	388-6569
6W-9678	Tube As-Lh	388-6570
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3557	Spider As-Fan	430-4471
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7J-6461	Crown	325-6054
7J-9346	Bearing-Sleeve	374-8357
7J-9682	Bearing-Sleeve	360-2335
7K-0686	Trunnion-Rear	297-7266
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531

8BG		
Original Part Number	Part Name	Classic Part Number
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7V-6716	Pin As	396-7273
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5699	Pulley-Cshaft	378-3988
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-7569	Case-Xmsn	394-0899
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210

Sales Model 966F (Cont'd.)

8BG		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-0931	Housing-Pinion	302-4300
8R-0942	Plate-Reaction	380-1484
8R-1015	Support-Trunnion	374-4712
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501

8BG		
Original Part Number	**Part Name**	**Classic Part Number**
8R-3252	Shaft-Planet	297-7259
8R-6213	Mount As	389-6301
8R-8335	Gear-Bevel	368-0105
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8T-0072	Cone-Rlr Brg	377-7448
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-6390	Drum-Brake	377-7449
8V-7659	Pin As	361-1702
8V-7885	Housing-Support	297-7193
9C-1484	Pin As	319-3446
9C-4007	Bearing-Sleeve	374-1459
9C-4080	Yoke-Brake	302-2703
9C-5852	Hub As	297-7208
9C-6029	Bearing-Planet	375-9982
9C-8218	Shaft-Bev Pinion	302-2697
9C-8669	Shaft-Bev Pinion	368-0107
9C-9191	Trunnion	302-2701
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9L-2685	Rod End	419-1866
9L-6371	Rod-Eye	363-7459
9M-6692	Strip	386-4934

8BG		
Original Part Number	**Part Name**	**Classic Part Number**
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-2787	Gear-Planet	367-6093
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5160	Plunger Kt-Adj	385-7218
9V-5174	Joint Gp-Univ	375-2628
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
9Y-3318	Core As-Radiator	374-7491

Sales Model 966F (Cont'd.)

8BG		
Original Part Number	**Part Name**	**Classic Part Number**
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3596	Piston	380-1511
100-3597	Plate-Reaction	380-1501
100-7860	Valve-Inlet	270-4360
101-8740	Muffler As	360-7878
102-8636	Gear-Drive	472-8035
103-5961	Wheel	398-2963
108-5680	Gage-Oil Level	378-4001
110-1337	Ring Kit-Pstn	377-5834
110-1488	Gear-Ring	394-0882
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
119-5727	Bearing-Spl Ball	417-9491
124-2726	Head	377-5855
126-2522	Cone-Spl Tapered	377-7397
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-3068	Kit-Gasket(F)	393-3636
136-7813	Bearing-Race	460-8296
139-9175	Gasket Kit	377-7464
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
148-9288	Case As-Diff	380-1496
151-4836	Diff Gp -A	416-2120
155-1379	Gasket Kit - Sch	386-3815

8BG		
Original Part Number	**Part Name**	**Classic Part Number**
158-1438	Kit-Dt Gasket	434-7276
158-1439	Kit-Dt Gasket	434-7290
160-1400	Yoke (1710)	319-3479
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646

8BG		
Original Part Number	**Part Name**	**Classic Part Number**
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
216-7957	U-Joint	367-6069
226-8202	Seal-Wiper	472-8024
228-0419	Seal As	443-3571
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-1032	Disc-Friction	440-3116
334-8389	Crankshaft As	242-3439
360-7863	Muffler-Cla	360-7878
391-8229	Kit-Gasket-Fs	398-2955
443-1200	Brg-Rlr-Cla	377-7397

9YJ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1N-2936	Muffler As	298-2782
1N-2946	Extension-Exh	367-6064
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087

9YJ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108

9YJ		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847

Sales Model 966F (Cont'd.)

9YJ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9453	Cone-Roller Brg	380-7508
2F-5721	Bearing-Ball	311-9354
2K-5065	Cone-Roller Brg	416-2157
2K-5103	Cone-Roller Brg	380-7505
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-7990	Tube As	373-5382

9YJ		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5540	Core As-Radiator	363-7452
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-7933	Core As-O Clr	374-4708
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3G-5264	Cylinder As.	393-1018
3G-5492	Rod As	377-5836
3G-5497	Cyl Gp-0210 0535	394-9822
3G-5502	Cylinder As	390-0988
3G-7660	Cartridge Gp	422-8103
3G-9891	Pump Gp-Gr A	399-8541
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3N-5869	Support-Elbow	375-9973
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-0487	Valve As-Check	375-4334
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4E-8535	Retainer-Seal	300-2589
4F-2393	Bearing-Ball	380-1499

9YJ		
Original Part Number	**Part Name**	**Classic Part Number**
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7270	Support-Trunnion	373-5384
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0897	Core As-Radiator	376-9058
4P-3546	Valve As-Relief	325-6236
4P-6548	Muffler As	360-7878
4P-6589	Pipe As	382-6898
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-0422	Cartridge Gp	422-8129
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-5099	Cover	418-1929
4V-5392	Spider	377-7430
4V-6421	Pin As	319-3442
4V-7082	Joint Gp-Slip	367-6068

Sales Model 966F (Cont'd.)

9YJ		
Original Part Number	Part Name	Classic Part Number
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-8518	Link As-Brg&	374-1450
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-5053	Muffler As	360-7881
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4Y-4340	Pin As	319-3442
4Y-5711	Pin As	425-6442
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5G-3612	Cap Gp-Protn	295-6419
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024

9YJ		
Original Part Number	Part Name	Classic Part Number
5P-9514	Bearing-Ball	417-9467
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3617	Support-Trunnion	374-4712
6E-0775	Head	425-9373
6E-2387	Cartridge Gp	422-8132
6E-5028	Rod As	425-9372
6E-6416	Cylinder As	425-9371
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-2408	Muffler As.	378-3978
6I-2409	Pipe	383-3693
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574

9YJ		
Original Part Number	Part Name	Classic Part Number
6V-4350	Race-Spl Rlr Brg	384-5933
6V-5976	Kit-Gasket (Rs)	393-5200
6W-9172	Bearing	389-6330
6W-9677	Tube As-Rh	388-6569
6W-9678	Tube As-Lh	388-6570
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7C-5851	Muffler As	298-2790
7C-6628	Pulley-Alt	396-9894
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3557	Spider As-Fan	430-4471
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7J-6461	Crown	325-6054
7J-9344	Bearing-Sleeve	360-2334
7J-9682	Bearing-Sleeve	360-2335
7K-9639	Bearing-Sleeve	314-8643
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-5206	Mount As	374-1451
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724

Sales Model 966F (Cont'd.)

9YJ		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7628	Gasket	419-1811
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-2036	Cap As-Fuel	361-1721
7T-3370	Yoke As	302-2702
7T-4753	Stator-Converter	384-5945
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-5645	Rod-Indicator	397-5061
7V-6715	Pin As	361-1701
7V-6716	Pin As	396-7273
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8555	Gasket Kit	434-7278
8E-7569	Case-Xmsn	394-0899
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

9YJ		
Original Part Number	**Part Name**	**Classic Part Number**
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8196	Adapter-Exh Manf	377-5852
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-0961	Impeller-Conv	433-9204
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663

9YJ		
Original Part Number	**Part Name**	**Classic Part Number**
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-0931	Housing-Pinion	302-4300
8R-0942	Plate-Reaction	380-1484
8R-1015	Support-Trunnion	374-4712
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-3252	Shaft-Planet	297-7259
8R-6213	Mount As	389-6301
8R-8335	Gear-Bevel	368-0105
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-7659	Pin As	361-1702
9C-1484	Pin As	319-3446
9C-4080	Yoke-Brake	302-2703
9C-6029	Bearing-Planet	375-9982
9C-8669	Shaft-Bev Pinion	368-0107
9C-9191	Trunnion	302-2701
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183

Sales Model 966F (Cont'd.)

9YJ		
Original Part Number	Part Name	Classic Part Number
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-7148	Cap As-Rain	378-3994
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-2787	Gear-Planet	367-6093
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-4975	Bearing-Sleeve	384-4784
9V-5174	Joint Gp-Univ	375-2628

9YJ		
Original Part Number	Part Name	Classic Part Number
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
9Y-3318	Core As-Radiator	374-7491
100-3596	Piston	380-1511
100-3597	Plate-Reaction	380-1501
100-7860	Valve-Inlet	270-4360
101-8740	Muffler As	360-7878
102-8636	Gear-Drive	472-8035
108-5680	Gage-Oil Level	378-4001
110-1337	Ring Kit-Pstn	377-5834
110-1488	Gear-Ring	394-0882
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
114-0468	Pin-G.E.T.	443-1203
119-5727	Bearing-Spl Ball	417-9491
124-2726	Head	377-5855
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
136-7813	Bearing-Race	460-8296
139-9175	Gasket Kit	377-7464
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554

9YJ		
Original Part Number	Part Name	Classic Part Number
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
148-9288	Case As-Diff	380-1496
151-4836	Diff Gp -A	416-2120
155-1379	Gasket Kit - Sch	386-3815
158-1438	Kit-Dt Gasket	434-7276
158-1439	Kit-Dt Gasket	434-7290
160-1400	Yoke (1710)	319-3479
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259

Sales Model 966F (Cont'd.)

9YJ		
Original Part Number	Part Name	Classic Part Number
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
216-7957	U-Joint	367-6069
226-8202	Seal-Wiper	472-8024
228-0419	Seal As	443-3571
232-3233	Bearing-Main	376-9085
234-8016	Kit-Gasket-Sch	393-0919

9YJ		
Original Part Number	Part Name	Classic Part Number
250-6558	Liner Kit-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032

9YJ		
Original Part Number	Part Name	Classic Part Number
310-8658	Pin As	425-1526
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-1032	Disc-Friction	440-3116
334-8389	Crankshaft As	242-3439
341-2430	Damper As-Cshft	299-2005
360-7863	Muffler-Cla	360-7878
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 966G

3PW		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453
1S-0057	Plate-Clutch	377-7404
1S-3062	Director-Water	418-9572
1V-8852	Cap	308-9834
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157

3PW		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3P-3505	Shaft-Brake	384-3477
3S-1262	Retainer	308-9915
3T-2094	Bearing-Sleeve	388-0638
3V-4046	Plate-Pressure	380-7470
4E-0079	Cage-Bearing	434-4387

3PW		
Original Part Number	Part Name	Classic Part Number
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652

Sales Model 966G (Cont'd.)

3PW		
Original Part Number	**Part Name**	**Classic Part Number**
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

3PW		
Original Part Number	**Part Name**	**Classic Part Number**
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6V-5976	Kit-Gasket (Rs)	393-5200
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7C-4297	Seal As-Cshaft	325-6192
7C-6628	Pulley-Alt	396-9894
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-3509	Pipe As-Ex Ext	373-1907
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7K-9639	Bearing-Sleeve	314-8643
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4000	Piston	416-2143

3PW		
Original Part Number	**Part Name**	**Classic Part Number**
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-3111	Rod End-Spher	392-4523
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081

Sales Model 966G (Cont'd.)

3PW		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220

3PW		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491
127-5537	Core As-Oclr	325-6045
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
144-9072	Cylinder As	394-8209
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

3SW		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487

3PW		
Original Part Number	**Part Name**	**Classic Part Number**
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
236-8675	Disc-Friction	428-7202
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 966G (Cont'd.)

3SW		
Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1V-8852	Cap	308-9834
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357

3SW		
Original Part Number	Part Name	Classic Part Number
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3T-2094	Bearing-Sleeve	388-0638
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528

3SW		
Original Part Number	Part Name	Classic Part Number
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-1882	Pin As	361-1700
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487

Sales Model 966G (Cont'd.)

3SW		
Original Part Number	**Part Name**	**Classic Part Number**
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6V-5976	Kit-Gasket (Rs)	393-5200
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7C-6628	Pulley-Alt	396-9894
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-3509	Pipe As-Ex Ext	373-1907
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7J-5131	Trunnion	296-1371
7J-9344	Bearing-Sleeve	360-2334
7J-9731	Bearing-Sleeve	308-9822
7K-0078	Bearing-Sleeve	308-9825
7K-9639	Bearing-Sleeve	314-8643
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491

3SW		
Original Part Number	**Part Name**	**Classic Part Number**
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-3111	Rod End-Spher	392-4523
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-5778	Bearing-Sleeve	374-8359
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081

3SW		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7412	Gear As-Pump	297-7183
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042

Sales Model 966G (Cont'd.)

3SW		
Original Part Number	Part Name	Classic Part Number
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491
127-5537	Core As-Oclr	325-6045
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
134-3038	Gasket Kit	437-3228
144-9072	Cylinder As	394-8209
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125

3SW		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259

3SW		
Original Part Number	Part Name	Classic Part Number
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

3ZS		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1B-5675	Bearing	377-7396
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-9209	Shaft-Tightener	374-6499
1V-8852	Cap	308-9834
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659

3ZS		
Original Part Number	Part Name	Classic Part Number
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934

3ZS		
Original Part Number	Part Name	Classic Part Number
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2S-6150	Cover-Pulley	428-8817
2W-1707	Ring-Piston Top	270-4356

Sales Model 966G (Cont'd.)

3ZS		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7610	Gear-Hyd Pump Dr	418-1940
2W-7614	Gear-Crankshaft	425-7752
2W-8038	Gear-Camshaft	425-7751
2W-9978	Core As-Oclr	279-4983
3E-4903	Mount As	396-7274
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3S-3875	Screen-Suction	435-4849
3T-2094	Bearing-Sleeve	388-0638
3T-5355	Flange	386-3052
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4N-0342	Plate-Cam Thrust	375-9974
4N-0432	Bearing-Ball	417-4499
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1157	Coupling-Exhaust	379-0177
4N-2514	Gear-Flywheel	421-7283
4N-3714	Chamber As	363-7450
4N-4668	Breather-Engine	396-7271
4N-4942	Rod-Eye	421-8919
4N-5614	Arm As-Rocker	374-4710
4N-5858	Cap-Cshft Brg	448-9157
4N-6658	Bearing-Sleeve	373-1885
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236

3ZS		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-5367	Mount As	375-9986
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5733	Adapter As-Valve	378-3975

3ZS		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-1370	Bearing As-Rlr	416-2164
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-1882	Pin As	361-1700
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8510	Housing As - Clu	373-5387
6I-9103	Bearing-Outer	421-8182
6K-5528	Cup-Roller Brg	447-8059
6N-0977	Bearing-Sleeve	417-4524
6N-1036	Gear-Oil Pump	279-4991

Sales Model 966G (Cont'd.)

3ZS		
Original Part Number	Part Name	Classic Part Number
6N-1186	Pulley-Belt	448-2424
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-4350	Race-Spl Rlr Brg	384-5933
6V-5976	Kit-Gasket (Rs)	393-5200
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-7652	Cup-Rlr Brg	399-6067
6Y-9960	Mount As.	376-3639
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1068	Impeller-Pump	378-3981
7C-6628	Pulley-Alt	396-9894
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-3509	Pipe As-Ex Ext	373-1907
7E-5996	Rod As-Conn	379-8864
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7J-5131	Trunnion	296-1371
7J-9344	Bearing-Sleeve	360-2334
7J-9731	Bearing-Sleeve	308-9822
7K-0078	Bearing-Sleeve	308-9825
7K-9639	Bearing-Sleeve	314-8643
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435

3ZS		
Original Part Number	Part Name	Classic Part Number
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-3111	Rod End-Spher	392-4523
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-5778	Bearing-Sleeve	374-8359
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196

3ZS		
Original Part Number	Part Name	Classic Part Number
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7257	Mount As	396-0660
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613

Sales Model 966G (Cont'd.)

3ZS		
Original Part Number	**Part Name**	**Classic Part Number**
8V-1612	Shaft	425-6456
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7412	Gear As-Pump	297-7183
9G-9543	Gear-Pump (Oil)	295-6426
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9M-4370	Bearing-Sleeve	453-6515
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-8663	Spacer	422-9521
9P-9031	Gear-Sun	283-5220
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
9Y-2988	Breather As	361-1716
9Y-9497	Bearing-Conn Rod	441-1563
002-1212	Cup-Roller Brg	399-4446
100-6920	Adapter-Nozzle	380-1552
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-2749	Adaptr-Water Pmp	375-9984
101-3374	Gear-Camshaft Dr	376-9069
108-5603	Screw-Adj Arm	379-0166

3ZS		
Original Part Number	**Part Name**	**Classic Part Number**
108-7930	Bearing As	377-7463
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-6469	Spacer	425-3645
117-6675	Step As	419-0881
117-9712	Shaft-Dr Idler	425-7754
118-6335	Pin	436-3042
119-5727	Bearing-Spl Ball	417-9491
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
124-7609	Gear-Pump Idler	428-8504
127-5537	Core As-Oclr	325-6045
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-6500	Rotocoil As.	397-5053
144-9072	Cylinder As	394-8209
145-8503	Shaft As-Idler	426-0035
148-7455	Valve - Exhaust	270-4361
155-6637	Gear-Oil Drive	425-9189
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
162-0152	Bearing-Sleeve	422-9519
163-3103	Manifold-Exh	430-8992
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

3ZS		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
170-8541	Core As-Rdtr	379-0180
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835
180-6645	Shaft As.	396-1566
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
202-3572	Shaft As-Drive	426-0037
206-6405	Bearing-Spl Ball	420-2503
211-0592	Bearing - Main	419-6368
213-1370	Bearing-Sleeve	380-7370
217-0586	Bearing-Rod	419-7266
232-3233	Bearing-Main	376-9085
252-7038	Kit-Dt Bearing	464-9065
253-1752	Plate-Thrust	379-0170
262-4335	Kit - Dt Gasket	434-7288
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model 966G (Cont'd.)

3ZS		
Original Part Number	**Part Name**	**Classic Part Number**
328-5572	Bearing-Rod	419-6349
328-5574	Bearing-Rod	419-7266

3ZS		
Original Part Number	**Part Name**	**Classic Part Number**
334-8389	Crankshaft As	242-3439
352-0200	Pump Gp-Water -B	434-6109

3ZS		
Original Part Number	**Part Name**	**Classic Part Number**
391-8229	Kit-Gasket-Fs	398-2955

8XW		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
1V-8852	Cap	308-9834
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-0714	Plate-Thrust	299-2040

8XW		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5065	Cone-Roller Brg	416-2157
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3G-2797	Bearing-Sleeve	360-2329
3J-2903	Cover	422-6922
3T-2094	Bearing-Sleeve	388-0638
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4N-0432	Bearing-Ball	417-4499

8XW		
Original Part Number	**Part Name**	**Classic Part Number**
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-3683	Pump Gp-Water -B	374-7498
4P-7688	Valve As-Check	420-6216
4P-7790	Shaft As-Arm	457-4596
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8577	Rod As-Injector	455-5513
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-5213	Spindle	299-2060
4V-5392	Spider	377-7430
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527

Sales Model 966G (Cont'd.)

8XW		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-1882	Pin As	361-1700
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1099	Manifold-Exh	424-6366
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8510	Housing As - Clu	373-5387

8XW		
Original Part Number	**Part Name**	**Classic Part Number**
6K-5528	Cup-Roller Brg	447-8059
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6V-5976	Kit-Gasket (Rs)	393-5200
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7C-5403	Tube As	374-4673
7C-6628	Pulley-Alt	396-9894
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7J-9346	Bearing-Sleeve	374-8357
7K-0686	Trunnion-Rear	297-7266
7K-9639	Bearing-Sleeve	314-8643
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686

8XW		
Original Part Number	**Part Name**	**Classic Part Number**
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-3111	Rod End-Spher	392-4523
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349

Sales Model 966G (Cont'd.)

8XW		
Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-0072	Cone-Rlr Brg	377-7448
8V-1612	Shaft	425-6456
8V-6390	Drum-Brake	377-7449
8V-7885	Housing-Support	297-7193
9C-5852	Hub As	297-7208
9C-8218	Shaft-Bev Pinion	302-2697
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931

8XW		
Original Part Number	Part Name	Classic Part Number
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-0247	Plate	417-4527
9V-5160	Plunger Kt-Adj	385-7218
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-6675	Step As	419-0881
119-2940	Gasket	378-4002
119-5727	Bearing-Spl Ball	417-9491
127-5537	Core As-Oclr	325-6045

8XW		
Original Part Number	Part Name	Classic Part Number
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
144-9072	Cylinder As	394-8209
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
147-1206	Gear Planet	418-9597
148-7455	Valve - Exhaust	270-4361
152-3952	Impeller-Pump	374-4696
160-1400	Yoke (1710)	319-3479
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
212-4893	Bearing-Thrust	419-6372

Wheel Loaders

Sales Model 966G (Cont'd.)

8XW		
Original Part Number	**Part Name**	**Classic Part Number**
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3233	Bearing-Main	376-9085
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288

8XW		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032

8XW		
Original Part Number	**Part Name**	**Classic Part Number**
310-1899	Pin As	393-0932
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
391-8229	Kit-Gasket-Fs	398-2955

9RS		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453
1S-0057	Plate-Clutch	377-7404
1S-3062	Director-Water	418-9572
1V-8852	Cap	308-9834
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

9RS		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3P-3505	Shaft-Brake	384-3477
3S-1262	Retainer	308-9915
3T-2094	Bearing-Sleeve	388-0638
3V-4046	Plate-Pressure	380-7470
4E-0079	Cage-Bearing	434-4387
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919

9RS		
Original Part Number	**Part Name**	**Classic Part Number**
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528

Sales Model 966G (Cont'd.)

9RS		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544

9RS		
Original Part Number	**Part Name**	**Classic Part Number**
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6V-5976	Kit-Gasket (Rs)	393-5200
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7C-4297	Seal As-Cshaft	325-6192
7C-6628	Pulley-Alt	396-9894
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-3509	Pipe As-Ex Ext	373-1907
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4000	Piston	416-2143
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989

9RS		
Original Part Number	**Part Name**	**Classic Part Number**
8C-3111	Rod End-Spher	392-4523
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211

Sales Model 966G (Cont'd.)

9RS		
Original Part Number	**Part Name**	**Classic Part Number**
8R-1465	Rim As	417-9501
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446

9RS		
Original Part Number	**Part Name**	**Classic Part Number**
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491
127-5537	Core As-Oclr	325-6045
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
144-9072	Cylinder As	394-8209
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127

9RS		
Original Part Number	**Part Name**	**Classic Part Number**
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
236-8675	Disc-Friction	428-7202
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

AAH		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913

AAH		
Original Part Number	**Part Name**	**Classic Part Number**
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572

AAH		
Original Part Number	**Part Name**	**Classic Part Number**
1V-8852	Cap	308-9834
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

Sales Model 966G (Cont'd.)

AAH		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3T-2094	Bearing-Sleeve	388-0638
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697

AAH		
Original Part Number	Part Name	Classic Part Number
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498

AAH		
Original Part Number	Part Name	Classic Part Number
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6V-5976	Kit-Gasket (Rs)	393-5200
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639

Sales Model 966G (Cont'd.)

AAH		
Original Part Number	**Part Name**	**Classic Part Number**
7C-6628	Pulley-Alt	396-9894
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-3509	Pipe As-Ex Ext	373-1907
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7K-9639	Bearing-Sleeve	314-8643
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-3111	Rod End-Spher	392-4523
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

AAH		
Original Part Number	**Part Name**	**Classic Part Number**
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612

AAH		
Original Part Number	**Part Name**	**Classic Part Number**
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491
127-5537	Core As-Oclr	325-6045
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
144-9072	Cylinder As	394-8209
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125

Sales Model 966G (Cont'd.)

AAH		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687

AAH		
Original Part Number	**Part Name**	**Classic Part Number**
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288

AAH		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

ANT		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
3J-2903	Cover	422-6922
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
4E-3196	Pin As	361-1697
4J-0121	Cap-Bearing	360-2344
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393

ANT		
Original Part Number	**Part Name**	**Classic Part Number**
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059

ANT		
Original Part Number	**Part Name**	**Classic Part Number**
6N-5978	Coupling-Exhaust	369-9487
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-3831	Seal-O-Ring	436-2657
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7J-5131	Trunnion	296-1371
7J-9344	Bearing-Sleeve	360-2334
7K-9639	Bearing-Sleeve	314-8643
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701

Sales Model 966G (Cont'd.)

ANT		
Original Part Number	**Part Name**	**Classic Part Number**
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8R-7336	Bearing	301-3394
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9P-3731	Carrier-Planet	301-4767

ANT		
Original Part Number	**Part Name**	**Classic Part Number**
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659

ANT		
Original Part Number	**Part Name**	**Classic Part Number**
130-4779	Housing As	441-1562
132-6597	Cone-Spl	422-6477
144-9072	Cylinder As	394-8209
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
164-4413	Mount	419-0876
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
216-4781	Gasket Kit	437-8144
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
315-6671	Kit-Gasket(Op)	438-0139
319-0848	Kit-Gasket(T)	438-0138
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

ANZ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157

ANZ		
Original Part Number	**Part Name**	**Classic Part Number**
2P-8986	Cup-Rlr Bearing	415-1912
3J-2903	Cover	422-6922
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
4E-3196	Pin As	361-1697
4J-0121	Cap-Bearing	360-2344
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041

ANZ		
Original Part Number	**Part Name**	**Classic Part Number**
4P-8280	Manifold-Exhaust	430-7236
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526

Sales Model 966G (Cont'd.)

ANZ		
Original Part Number	Part Name	Classic Part Number
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-5978	Coupling-Exhaust	369-9487
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-3831	Seal-O-Ring	436-2657
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7J-9344	Bearing-Sleeve	360-2334
7K-9639	Bearing-Sleeve	314-8643
7T-8816	Bearing-Spl Ball	420-2491

ANZ		
Original Part Number	Part Name	Classic Part Number
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8R-7336	Bearing	301-3394
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561

ANZ		
Original Part Number	Part Name	Classic Part Number
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
132-6597	Cone-Spl	422-6477
144-9072	Cylinder As	394-8209
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
164-4413	Mount	419-0876
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
216-4781	Gasket Kit	437-8144
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
315-6671	Kit-Gasket(Op)	438-0139
319-0848	Kit-Gasket(T)	438-0138
328-4374	Disc-Friction	384-5966

Sales Model 966G (Cont'd.)

ANZ		
Original Part Number	**Part Name**	**Classic Part Number**
328-4375	Disc-Friction	443-1922

ANZ		
Original Part Number	**Part Name**	**Classic Part Number**
352-2077	Pump Gp-Water -B	434-6108

AWY		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
3J-2903	Cover	422-6922
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
4E-3196	Pin As	361-1697
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022

AWY		
Original Part Number	**Part Name**	**Classic Part Number**
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-5978	Coupling-Exhaust	369-9487
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-3831	Seal-O-Ring	436-2657
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342

AWY		
Original Part Number	**Part Name**	**Classic Part Number**
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-7099	Bearing-Sleeve	391-9818
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
114-0468	Pin-G.E.T.	443-1203
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448

Sales Model 966G (Cont'd.)

AWY		
Original Part Number	**Part Name**	**Classic Part Number**
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
132-6597	Cone-Spl	422-6477
144-9072	Cylinder As	394-8209

AWY		
Original Part Number	**Part Name**	**Classic Part Number**
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
164-4413	Mount	419-0876
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
206-6405	Bearing-Spl Ball	420-2503

AWY		
Original Part Number	**Part Name**	**Classic Part Number**
213-1370	Bearing-Sleeve	380-7370
216-4781	Gasket Kit	437-8144
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
315-6671	Kit-Gasket(Op)	438-0139
319-0848	Kit-Gasket(T)	438-0138
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

AWZ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
3J-2903	Cover	422-6922
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
4E-3196	Pin As	361-1697
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527

AWZ		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-5978	Coupling-Exhaust	369-9487
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-3831	Seal-O-Ring	436-2657
6V-4350	Race-Spl Rlr Brg	384-5933

AWZ		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7K-9639	Bearing-Sleeve	314-8643
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209

Sales Model 966G (Cont'd.)

AWZ		
Original Part Number	**Part Name**	**Classic Part Number**
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-7215	Sleeve-Isolator	425-3646

AWZ		
Original Part Number	**Part Name**	**Classic Part Number**
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
132-6597	Cone-Spl	422-6477
144-9072	Cylinder As	394-8209
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154

AWZ		
Original Part Number	**Part Name**	**Classic Part Number**
164-4413	Mount	419-0876
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
216-4781	Gasket Kit	437-8144
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
315-6671	Kit-Gasket(Op)	438-0139
319-0848	Kit-Gasket(T)	438-0138
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

AXJ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
3J-2903	Cover	422-6922
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638

AXJ		
Original Part Number	**Part Name**	**Classic Part Number**
4E-3196	Pin As	361-1697
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529

AXJ		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8675	Bearing-Sleeve	394-0187
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387

Sales Model 966G (Cont'd.)

AXJ		
Original Part Number	Part Name	Classic Part Number
6K-5528	Cup-Roller Brg	447-8059
6N-5978	Coupling-Exhaust	369-9487
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-3831	Seal-O-Ring	436-2657
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211

AXJ		
Original Part Number	Part Name	Classic Part Number
8R-1465	Rim As	417-9501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-7099	Bearing-Sleeve	391-9818
9L-5908	Gasket	433-8196
9M-1328	Bearing-Aligning	325-6018
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
114-0468	Pin-G.E.T.	443-1203
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259

AXJ		
Original Part Number	Part Name	Classic Part Number
116-1102	Sleeve-Injector	451-9024
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
132-6597	Cone-Spl	422-6477
144-9072	Cylinder As	394-8209
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
164-4413	Mount	419-0876
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
216-4781	Gasket Kit	437-8144
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
315-6671	Kit-Gasket(Op)	438-0139
319-0848	Kit-Gasket(T)	438-0138
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

AXL		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384

AXL		
Original Part Number	Part Name	Classic Part Number
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434

AXL		
Original Part Number	Part Name	Classic Part Number
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157

Sales Model 966G (Cont'd.)

AXL		
Original Part Number	**Part Name**	**Classic Part Number**
2P-8986	Cup-Rlr Bearing	415-1912
3G-2797	Bearing-Sleeve	360-2329
3J-2903	Cover	422-6922
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3V-2337	Pin As	319-3440
4E-3196	Pin As	361-1697
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
5V-1511	Pin As	418-1945
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-5978	Coupling-Exhaust	369-9487

AXL		
Original Part Number	**Part Name**	**Classic Part Number**
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-3831	Seal-O-Ring	436-2657
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7J-9346	Bearing-Sleeve	374-8357
7K-9639	Bearing-Sleeve	314-8643
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931

AXL		
Original Part Number	**Part Name**	**Classic Part Number**
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
132-6597	Cone-Spl	422-6477
144-9072	Cylinder As	394-8209
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
164-4413	Mount	419-0876
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573

Sales Model 966G (Cont'd.)

AXL		
Original Part Number	Part Name	Classic Part Number
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
206-6405	Bearing-Spl Ball	420-2503

AXL		
Original Part Number	Part Name	Classic Part Number
213-1370	Bearing-Sleeve	380-7370
216-4781	Gasket Kit	437-8144
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

AXL		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032
315-6671	Kit-Gasket(Op)	438-0139
319-0848	Kit-Gasket(T)	438-0138
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

HDH		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1V-8852	Cap	308-9834
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

HDH		
Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3T-2094	Bearing-Sleeve	388-0638
4E-3196	Pin As	361-1697
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988

HDH		
Original Part Number	Part Name	Classic Part Number
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502

Sales Model 966G (Cont'd.)

HDH		
Original Part Number	**Part Name**	**Classic Part Number**
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7C-6628	Pulley-Alt	396-9894
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-3509	Pipe As-Ex Ext	373-1907
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441

HDH		
Original Part Number	**Part Name**	**Classic Part Number**
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-3111	Rod End-Spher	392-4523
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624

HDH		
Original Part Number	**Part Name**	**Classic Part Number**
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818

Sales Model 966G (Cont'd.)

HDH		
Original Part Number	Part Name	Classic Part Number
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491
127-5537	Core As-Oclr	325-6045

HDH		
Original Part Number	Part Name	Classic Part Number
129-4299	Gear-Planet	446-3077
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
144-9072	Cylinder As	394-8209
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574

HDH		
Original Part Number	Part Name	Classic Part Number
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

Sales Model 966H

A6D		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912

A6D		
Original Part Number	Part Name	Classic Part Number
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4J-0121	Cap-Bearing	360-2344
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529

A6D		
Original Part Number	Part Name	Classic Part Number
4V-8675	Bearing-Sleeve	394-0187
5K-8591	Bearing-Outer	380-7502
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5411	Race-Brg Outer	417-9481
5T-5682	Driver	418-9579
6K-5528	Cup-Roller Brg	447-8059
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690

Sales Model 966H (Cont'd.)

A6D		
Original Part Number	**Part Name**	**Classic Part Number**
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-9344	Bearing-Sleeve	360-2334

A6D		
Original Part Number	**Part Name**	**Classic Part Number**
7J-9731	Bearing-Sleeve	308-9822
7J-9884	Bearing-Sleeve	325-6016
7K-0078	Bearing-Sleeve	308-9825
7K-9528	Bearing-Sleeve	308-9828
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7T-8816	Bearing-Spl Ball	420-2491
7V-6715	Pin As	361-1701
8H-9789	Bearing-Ball	374-8342
8J-5778	Bearing-Sleeve	374-8359
8R-1465	Rim As	417-9501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701

A6D		
Original Part Number	**Part Name**	**Classic Part Number**
9G-1491	Carrier-Planet	281-1685
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
132-6597	Cone-Spl	422-6477
176-9273	Piston	297-4860
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

A6G		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527

A6G		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5K-8591	Bearing-Outer	380-7502
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5411	Race-Brg Outer	417-9481
5T-5682	Driver	418-9579
6K-5528	Cup-Roller Brg	447-8059
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689

A6G		
Original Part Number	**Part Name**	**Classic Part Number**
6P-8005	Gear-Planet	281-1691
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7T-8816	Bearing-Spl Ball	420-2491

Sales Model 966H (Cont'd.)

A6G		
Original Part Number	**Part Name**	**Classic Part Number**
7V-6715	Pin As	361-1701
8H-9789	Bearing-Ball	374-8342
8R-1465	Rim As	417-9501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9G-1491	Carrier-Planet	281-1685
9J-7099	Bearing-Sleeve	391-9818

A6G		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
119-5727	Bearing-Spl Ball	417-9491

A6G		
Original Part Number	**Part Name**	**Classic Part Number**
129-4299	Gear-Planet	446-3077
132-6597	Cone-Spl	422-6477
176-9273	Piston	297-4860
213-1370	Bearing-Sleeve	380-7370
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

A6J		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
3G-2797	Bearing-Sleeve	360-2329
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5K-8591	Bearing-Outer	380-7502
5P-2526	Cup-Rlr Bearing	380-7498

A6J		
Original Part Number	**Part Name**	**Classic Part Number**
5P-3930	Bearing As-Rlr	419-6022
5P-5411	Race-Brg Outer	417-9481
5T-5682	Driver	418-9579
6K-5528	Cup-Roller Brg	447-8059
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9346	Bearing-Sleeve	374-8357
7K-9639	Bearing-Sleeve	314-8643

A6J		
Original Part Number	**Part Name**	**Classic Part Number**
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7T-8816	Bearing-Spl Ball	420-2491
7V-6715	Pin As	361-1701
8H-9789	Bearing-Ball	374-8342
8R-1465	Rim As	417-9501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9G-1491	Carrier-Planet	281-1685
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
132-6597	Cone-Spl	422-6477
176-9273	Piston	297-4860
213-1370	Bearing-Sleeve	380-7370
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 966H (Cont'd.)

BJ6		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5K-8591	Bearing-Outer	380-7502
5P-2526	Cup-Rlr Bearing	380-7498

BJ6		
Original Part Number	**Part Name**	**Classic Part Number**
5P-3930	Bearing As-Rlr	419-6022
5P-5411	Race-Brg Outer	417-9481
5T-5682	Driver	418-9579
6K-5528	Cup-Roller Brg	447-8059
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190

BJ6		
Original Part Number	**Part Name**	**Classic Part Number**
7T-3343	Plate-Clutch	297-7231
7T-8816	Bearing-Spl Ball	420-2491
7V-6715	Pin As	361-1701
8H-9789	Bearing-Ball	374-8342
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9G-1491	Carrier-Planet	281-1685
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
132-6597	Cone-Spl	422-6477
176-9273	Piston	297-4860
213-1370	Bearing-Sleeve	380-7370
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

BS6		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698

BS6		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5K-8591	Bearing-Outer	380-7502
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5411	Race-Brg Outer	417-9481
5T-5682	Driver	418-9579

BS6		
Original Part Number	**Part Name**	**Classic Part Number**
6K-5528	Cup-Roller Brg	447-8059
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466

Sales Model 966H (Cont'd.)

BS6		
Original Part Number	**Part Name**	**Classic Part Number**
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7T-8816	Bearing-Spl Ball	420-2491
7V-6715	Pin As	361-1701
8H-9789	Bearing-Ball	374-8342

BS6		
Original Part Number	**Part Name**	**Classic Part Number**
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9G-1491	Carrier-Planet	281-1685
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583

BS6		
Original Part Number	**Part Name**	**Classic Part Number**
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
132-6597	Cone-Spl	422-6477
176-9273	Piston	297-4860
213-1370	Bearing-Sleeve	380-7370
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

FMW		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5K-8591	Bearing-Outer	380-7502
5P-2526	Cup-Rlr Bearing	380-7498

FMW		
Original Part Number	**Part Name**	**Classic Part Number**
5P-3930	Bearing As-Rlr	419-6022
5P-5411	Race-Brg Outer	417-9481
5T-5682	Driver	418-9579
6K-5528	Cup-Roller Brg	447-8059
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7T-8816	Bearing-Spl Ball	420-2491

FMW		
Original Part Number	**Part Name**	**Classic Part Number**
7V-6715	Pin As	361-1701
8H-9789	Bearing-Ball	374-8342
8R-1465	Rim As	417-9501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9G-1491	Carrier-Planet	281-1685
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
132-6597	Cone-Spl	422-6477
176-9273	Piston	297-4860
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 966H (Cont'd.)

RYF		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5K-8591	Bearing-Outer	380-7502
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022

RYF		
Original Part Number	**Part Name**	**Classic Part Number**
5P-5411	Race-Brg Outer	417-9481
5T-5682	Driver	418-9579
6K-5528	Cup-Roller Brg	447-8059
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231

RYF		
Original Part Number	**Part Name**	**Classic Part Number**
7T-8816	Bearing-Spl Ball	420-2491
7V-6715	Pin As	361-1701
8H-9789	Bearing-Ball	374-8342
8R-1465	Rim As	417-9501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9G-1491	Carrier-Planet	281-1685
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
132-6597	Cone-Spl	422-6477
176-9273	Piston	297-4860
213-1370	Bearing-Sleeve	380-7370
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

TAL		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929

TAL		
Original Part Number	**Part Name**	**Classic Part Number**
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5K-8591	Bearing-Outer	380-7502
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022

TAL		
Original Part Number	**Part Name**	**Classic Part Number**
5P-5411	Race-Brg Outer	417-9481
5T-5682	Driver	418-9579
6K-5528	Cup-Roller Brg	447-8059
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1089	Turbine-Conv	385-6112

Sales Model 966H (Cont'd.)

TAL		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-1090	Stator-Converter	385-6113
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231

TAL		
Original Part Number	**Part Name**	**Classic Part Number**
7T-8816	Bearing-Spl Ball	420-2491
7V-6715	Pin As	361-1701
8H-9789	Bearing-Ball	374-8342
8R-1465	Rim As	417-9501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9G-1491	Carrier-Planet	281-1685
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203

TAL		
Original Part Number	**Part Name**	**Classic Part Number**
9W-0517	Carrier-Planet	281-1686
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
132-6597	Cone-Spl	422-6477
176-9273	Piston	297-4860
213-1370	Bearing-Sleeve	380-7370
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model 966K

NEC		
Original Part Number	**Part Name**	**Classic Part Number**
161-3411	Gasket	394-0896

NGX		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1M-8776	Bearing-Roller	417-4516
1V-8852	Cap	308-9834
2B-0941	Spacer	418-1955
2F-8509	Cone-Roller Brg	399-4434
2P-8986	Cup-Rlr Bearing	415-1912
3B-3967	Race-Roller Brg	386-4947
4E-3196	Pin As	361-1697
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527

NGX		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-6659	Bearing	417-4511
5M-6126	Bearing	377-7433
5P-6254	Bearing	420-2495
5T-5682	Driver	418-9579
6K-5528	Cup-Roller Brg	447-8059
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7J-9344	Bearing-Sleeve	360-2334
7K-9639	Bearing-Sleeve	314-8643

PBG		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487

NGX		
Original Part Number	**Part Name**	**Classic Part Number**
7V-6715	Pin As	361-1701
8B-8439	Bearing-Ball	399-6069
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
129-4299	Gear-Planet	446-3077
132-6597	Cone-Spl	422-6477
161-3411	Gasket	394-0896
213-1370	Bearing-Sleeve	380-7370

Sales Model 966K (Cont'd.)

PBG		
Original Part Number	**Part Name**	**Classic Part Number**
1M-8776	Bearing-Roller	417-4516
1V-8852	Cap	308-9834
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
3B-3967	Race-Roller Brg	386-4947
3R-8530	Boss	425-3454
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-6659	Bearing	417-4511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498

PBG		
Original Part Number	**Part Name**	**Classic Part Number**
5P-3930	Bearing As-Rlr	419-6022
5P-5411	Race-Brg Outer	417-9481
5P-6254	Bearing	420-2495
5T-5682	Driver	418-9579
6K-5528	Cup-Roller Brg	447-8059
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-3151	Stator-Converter	388-6562
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9344	Bearing-Sleeve	360-2334

PBG		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7V-0638	Spacer	425-3651
7V-6715	Pin As	361-1701
8B-8439	Bearing-Ball	399-6069
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9G-1491	Carrier-Planet	281-1685
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
132-6597	Cone-Spl	422-6477
161-3411	Gasket	394-0896
176-9273	Piston	297-4860
213-1370	Bearing-Sleeve	380-7370

TFS		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1M-8776	Bearing-Roller	417-4516
1V-8852	Cap	308-9834
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
3B-3967	Race-Roller Brg	386-4947
3R-8530	Boss	425-3454
3T-9960	Disc-Friction	417-9487

TFS		
Original Part Number	**Part Name**	**Classic Part Number**
4E-3196	Pin As	361-1697
4J-0121	Cap-Bearing	360-2344
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187

TFS		
Original Part Number	**Part Name**	**Classic Part Number**
5D-6659	Bearing	417-4511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5411	Race-Brg Outer	417-9481
5P-6254	Bearing	420-2495
5T-5682	Driver	418-9579
6K-5528	Cup-Roller Brg	447-8059
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695

Sales Model 966K (Cont'd.)

TFS		
Original Part Number	Part Name	Classic Part Number
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-3151	Stator-Converter	388-6562
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678

TFS		
Original Part Number	Part Name	Classic Part Number
7J-9344	Bearing-Sleeve	360-2334
7J-9731	Bearing-Sleeve	308-9822
7K-0078	Bearing-Sleeve	308-9825
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7V-0638	Spacer	425-3651
7V-6715	Pin As	361-1701
8B-8439	Bearing-Ball	399-6069
8G-4022	Bearing	422-6920
8J-5778	Bearing-Sleeve	374-8359
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613

TFS		
Original Part Number	Part Name	Classic Part Number
9C-9191	Trunnion	302-2701
9G-1491	Carrier-Planet	281-1685
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9W-0517	Carrier-Planet	281-1686
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
132-6597	Cone-Spl	422-6477
161-3411	Gasket	394-0896
176-9273	Piston	297-4860
213-1370	Bearing-Sleeve	380-7370

Sales Model 966L

FRS		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1M-6573	Cup-Roller Brg	399-4438
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0210	Bearing-Ball	417-4498
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2K-5065	Cone-Roller Brg	416-2157
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667

FRS		
Original Part Number	Part Name	Classic Part Number
2W-8494	Pulley-Alt	295-5692
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-3196	Pin As	361-1697
4N-2514	Gear-Flywheel	421-7283
4N-4577	Muffler As.	308-9877
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

FRS		
Original Part Number	Part Name	Classic Part Number
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5411	Race-Brg Outer	417-9481
5T-5682	Driver	418-9579
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678

Sales Model 966L (Cont'd.)

FRS		
Original Part Number	**Part Name**	**Classic Part Number**
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7V-6715	Pin As	361-1701
9G-1491	Carrier-Planet	281-1685
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018

FRS		
Original Part Number	**Part Name**	**Classic Part Number**
9M-2744	Cone-Spl Tapered	380-1480
9N-4460	Housing As-Cl	297-7203
9S-7148	Cap As-Rain	378-3994
9W-0517	Carrier-Planet	281-1686
100-8010	Valve	423-5583
115-4072	Bearing	397-5069

FRS		
Original Part Number	**Part Name**	**Classic Part Number**
115-4237	Pulley-Idler	374-4693
161-3411	Gasket	394-0896
176-9273	Piston	297-4860
213-1365	Bearing-Sleeve	330-9256

Sales Model 966M

B8P		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1M-6573	Cup-Roller Brg	399-4438
1M-8776	Bearing-Roller	417-4516
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
2W-8494	Pulley-Alt	295-5692
3B-3967	Race-Roller Brg	386-4947
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
4B-9373	Cone-Roller Brg	399-4440

B8P		
Original Part Number	**Part Name**	**Classic Part Number**
4B-9374	Bearing-Cup	380-7494
4E-3196	Pin As	361-1697
4N-2514	Gear-Flywheel	421-7283
4N-4577	Muffler As.	308-9877
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5D-6659	Bearing	417-4511
5M-6126	Bearing	377-7433
5P-6254	Bearing	420-2495
5T-5682	Driver	418-9579
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7J-9344	Bearing-Sleeve	360-2334

B8P		
Original Part Number	**Part Name**	**Classic Part Number**
7K-0078	Bearing-Sleeve	308-9825
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7V-6715	Pin As	361-1701
8B-8439	Bearing-Ball	399-6069
8J-5778	Bearing-Sleeve	374-8359
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9M-2744	Cone-Spl Tapered	380-1480
9S-7148	Cap As-Rain	378-3994
100-8010	Valve	423-5583
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
161-3411	Gasket	394-0896
213-1365	Bearing-Sleeve	330-9256

DYC		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1M-6573	Cup-Roller Brg	399-4438

DYC		
Original Part Number	**Part Name**	**Classic Part Number**
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

DYC		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0210	Bearing-Ball	417-4498
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802

Sales Model 966M (Cont'd.)

DYC		
Original Part Number	Part Name	Classic Part Number
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2K-5065	Cone-Roller Brg	416-2157
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
2W-8494	Pulley-Alt	295-5692
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-3196	Pin As	361-1697
4N-2514	Gear-Flywheel	421-7283
4N-4577	Muffler As.	308-9877
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528

DYC		
Original Part Number	Part Name	Classic Part Number
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5411	Race-Brg Outer	417-9481
5T-5682	Driver	418-9579
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-3831	Seal-O-Ring	436-2657
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697

DYC		
Original Part Number	Part Name	Classic Part Number
7G-6062	Gear-Ring	302-2678
7J-9344	Bearing-Sleeve	360-2334
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7V-0638	Spacer	425-3651
7V-6715	Pin As	361-1701
9G-1491	Carrier-Planet	281-1685
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9M-2744	Cone-Spl Tapered	380-1480
9N-4460	Housing As-Cl	297-7203
9S-7148	Cap As-Rain	378-3994
9W-0517	Carrier-Planet	281-1686
100-8010	Valve	423-5583
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
161-3411	Gasket	394-0896
176-9273	Piston	297-4860
213-1365	Bearing-Sleeve	330-9256

EJA		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1M-6573	Cup-Roller Brg	399-4438
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0210	Bearing-Ball	417-4498
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2K-5065	Cone-Roller Brg	416-2157
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844

EJA		
Original Part Number	Part Name	Classic Part Number
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
2W-8494	Pulley-Alt	295-5692
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4N-2514	Gear-Flywheel	421-7283
4N-4577	Muffler As.	308-9877
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528

EJA		
Original Part Number	Part Name	Classic Part Number
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5411	Race-Brg Outer	417-9481
5T-5682	Driver	418-9579
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689

Sales Model 966M (Cont'd.)

EJA		
Original Part Number	**Part Name**	**Classic Part Number**
6P-8005	Gear-Planet	281-1691
6V-3831	Seal-O-Ring	436-2657
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678

EJA		
Original Part Number	**Part Name**	**Classic Part Number**
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7V-0638	Spacer	425-3651
7V-6715	Pin As	361-1701
9G-1491	Carrier-Planet	281-1685
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9M-2744	Cone-Spl Tapered	380-1480

EJA		
Original Part Number	**Part Name**	**Classic Part Number**
9N-4460	Housing As-Cl	297-7203
9S-7148	Cap As-Rain	378-3994
9W-0517	Carrier-Planet	281-1686
100-8010	Valve	423-5583
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
161-3411	Gasket	394-0896
176-9273	Piston	297-4860
213-1365	Bearing-Sleeve	330-9256

KJP		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1M-6573	Cup-Roller Brg	399-4438
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0210	Bearing-Ball	417-4498
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1V-8241	Bearing-Sleeve	308-9808
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2K-5065	Cone-Roller Brg	416-2157
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
2W-8494	Pulley-Alt	295-5692
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-3196	Pin As	361-1697
4N-2514	Gear-Flywheel	421-7283
4N-4577	Muffler As.	308-9877
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526

KJP		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5411	Race-Brg Outer	417-9481
5T-5682	Driver	418-9579
5V-1882	Pin As	361-1700
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-3831	Seal-O-Ring	436-2657
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678

KJP		
Original Part Number	**Part Name**	**Classic Part Number**
7J-9344	Bearing-Sleeve	360-2334
7J-9731	Bearing-Sleeve	308-9822
7K-0078	Bearing-Sleeve	308-9825
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7V-0638	Spacer	425-3651
7V-6715	Pin As	361-1701
8J-5778	Bearing-Sleeve	374-8359
9G-1491	Carrier-Planet	281-1685
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9M-2744	Cone-Spl Tapered	380-1480
9N-4460	Housing As-Cl	297-7203
9S-7148	Cap As-Rain	378-3994
9W-0517	Carrier-Planet	281-1686
100-8010	Valve	423-5583
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
161-3411	Gasket	394-0896
176-9273	Piston	297-4860

Sales Model 966M (Cont'd.)

KJP		
Original Part Number	**Part Name**	**Classic Part Number**
213-1365	Bearing-Sleeve	330-9256

KJP		
Original Part Number	**Part Name**	**Classic Part Number**
310-1899	Pin As	393-0932

L8R		
Original Part Number	**Part Name**	**Classic Part Number**
7J-9344	Bearing-Sleeve	360-2334
7K-9639	Bearing-Sleeve	314-8643

P6C		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1M-6573	Cup-Roller Brg	399-4438
1M-8776	Bearing-Roller	417-4516
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
2W-8494	Pulley-Alt	295-5692
3B-3967	Race-Roller Brg	386-4947
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899

P6C		
Original Part Number	**Part Name**	**Classic Part Number**
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-3196	Pin As	361-1697
4N-2514	Gear-Flywheel	421-7283
4N-4577	Muffler As.	308-9877
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5D-6659	Bearing	417-4511
5M-6126	Bearing	377-7433
5P-6254	Bearing	420-2495
5T-5682	Driver	418-9579

P6C		
Original Part Number	**Part Name**	**Classic Part Number**
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7J-9344	Bearing-Sleeve	360-2334
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7V-6715	Pin As	361-1701
8B-8439	Bearing-Ball	399-6069
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9M-2744	Cone-Spl Tapered	380-1480
9S-7148	Cap As-Rain	378-3994
100-8010	Valve	423-5583
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
161-3411	Gasket	394-0896
213-1365	Bearing-Sleeve	330-9256

R8D		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1M-6573	Cup-Roller Brg	399-4438
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

R8D		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0210	Bearing-Ball	417-4498
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174

R8D		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2K-5065	Cone-Roller Brg	416-2157
2P-1373	Cup-Rlr Brg	382-5075

Wheel Loaders

Sales Model 966M (Cont'd.)

R8D		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1374	Cone-Rlr Brg	374-1844
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
2W-8494	Pulley-Alt	295-5692
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-3196	Pin As	361-1697
4N-2514	Gear-Flywheel	421-7283
4N-4577	Muffler As.	308-9877
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187

R8D		
Original Part Number	**Part Name**	**Classic Part Number**
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5411	Race-Brg Outer	417-9481
5T-5682	Driver	418-9579
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697

R8D		
Original Part Number	**Part Name**	**Classic Part Number**
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7V-0638	Spacer	425-3651
7V-6715	Pin As	361-1701
9G-1491	Carrier-Planet	281-1685
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9M-2744	Cone-Spl Tapered	380-1480
9N-4460	Housing As-Cl	297-7203
9S-7148	Cap As-Rain	378-3994
9W-0517	Carrier-Planet	281-1686
100-8010	Valve	423-5583
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
161-3411	Gasket	394-0896
176-9273	Piston	297-4860
213-1365	Bearing-Sleeve	330-9256

Sales Model 966R

58Z		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1J-2860	Cup-Spl Tapered	374-8347
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-0406	Wheel-Impeller	384-3854
1T-0576	Bearing-Sleeve	379-0186

58Z		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1401	Ring-Seal	384-4799
1T-1428	Retainer-Brg	300-2587
1T-1691	Impeller-Conv	297-4863
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1V-1080	Housing-Brg Spt	260-0775
1V-3995	Pin	319-3449
1V-5724	Diff Gp -A	260-0776
1V-6913	Tube As	435-4793
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006

58Z		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2H-3712	Bearing-Ball	392-4488
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040

Sales Model 966R (Cont'd.)

58Z		
Original Part Number	Part Name	Classic Part Number
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2V-6221	Shaft-Planet	221-9108
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-9978	Core As-Oclr	279-4983
3G-2834	Cartridge Gp-Rr	426-0025
3G-7657	Cartridge Gp	422-8101
3G-7667	Cartridge Gp	422-8107
3H-8726	Mount As	385-7208
3J-9325	Piston	390-0993

58Z		
Original Part Number	Part Name	Classic Part Number
3K-0963	Pin-Lock	308-9895
3K-4290	Rod End	374-1823
3K-7020	Gear-Planet	221-9074
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3V-2281	Link As	299-2023
3V-5762	Support As	389-6310
3V-7427	Housing As	297-7197
4K-6212	Shaft-Bev Pinion	223-4806
4K-6558	Pin-Lower	302-2710
4K-6736	Drum-Brake	223-6320
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4K-8225	Pin-Cylinder	297-7215
4K-8561	Pin	299-2036
4K-8734	Bearing-Sleeve	299-1962
4K-9598	Retainer	297-7235
4M-3915	Bearing-Caged	377-7427
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8591	Coupling-Exhaust	325-6053
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008

58Z		
Original Part Number	Part Name	Classic Part Number
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4T-0509	Pump Gp-Vn Bsc-B	422-8159
4V-0015	Plate-Lock	282-6563
4W-0452	Seal As -Cshaft	325-6191
4W-2061	Pan As-Oil Sump	416-5519
4W-6869	Spacer-Fuel Pump	417-4534
4W-9655	Support	419-0882
5D-0470	Valve Gp-Qrel	314-8549
5K-0609	Cover	308-9843
5K-2294	Bearing	396-9912
5K-5927	Boss	299-1973
5K-5933	Cover As	247-4125
5K-8265	Pin	241-2590
5M-0578	Bearing	419-7775
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9439	Bearing-Spl Ball	371-4306
5S-1211	Cover-Valve	314-8665
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

Sales Model 966R (Cont'd.)

58Z		
Original Part Number	Part Name	Classic Part Number
5S-8543	Bearing-Sleeve	376-3635
5V-1274	Spider	385-6110
5V-5279	Bearing-Sleeve	299-1966
6B-7469	Spacer	417-4535
6E-4258	Cartridge	422-8133
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2034	Shaft	297-7249
6K-4442	Rod End-Special	373-5388
6K-8307	Pin	241-2593
6K-8308	Pin	241-2594
6K-8309	Pin	241-2595
6K-8311	Pin	241-2599
6K-8895	Cap	374-6500
6K-8897	Bracket As	299-1977
6N-1036	Gear-Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386
6P-2090	Base-Xmsn O Fil	397-5049
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-3651	Pump Gp-Gr 1 Bsc	345-1978
6T-5383	Gear-Ring	375-2624
6V-4582	Bearing-Ball	380-1504
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-3862	Camshaft	458-0151
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851

58Z		
Original Part Number	Part Name	Classic Part Number
7F-2742	Bearing-Ball	422-6488
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9344	Bearing-Sleeve	360-2334
7J-9365	Bearing-Sleeve	453-6507
7J-9366	Bearing-Sleeve	299-1985
7J-9367	Rod As	469-4660
7K-0449	Yoke As	297-7271
7K-0450	Yoke As	297-7272
7K-0686	Trunnion-Rear	297-7266
7K-7200	Pin	241-2600
7K-8890	Tube As	391-1098
7K-9513	Pin	241-2596
7K-9514	Pin	241-2597
7K-9515	Pin	241-2589
7K-9638	Bearing-Sleeve	365-8827
7K-9639	Bearing-Sleeve	314-8643
7K-9640	Bearing-Sleeve	389-6328
7K-9642	Bearing-Sleeve	360-2340
7K-9643	Bearing-Sleeve	445-7707
7K-9644	Bearing-Sleeve	360-2341
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172

58Z		
Original Part Number	Part Name	Classic Part Number
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-3486	Manifold-Exhaust	261-0899
7N-3536	Gear-Fuel	279-4993
7N-5511	Gear As-Idler	233-2180
7N-5645	Tube As-Outlet	378-3984
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8876	Head Gp-Cyl -A	269-5290
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-7809	Cap As-Radiator	295-6417
7T-1285	Gear-Planet	297-7190
7T-2036	Cap As-Fuel	361-1721
7T-3343	Plate-Clutch	297-7231
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8F-3170	Bearing-Roller	417-4504
8F-9365	Pin	319-3463
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-5283	Plate	299-2043
8K-5334	Pin	241-2598
8K-6282	Gear-Sun	281-1698

Sales Model 966R (Cont'd.)

58Z		
Original Part Number	Part Name	Classic Part Number
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385

58Z		
Original Part Number	Part Name	Classic Part Number
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0905	Muffler As	302-2690
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-2466	Gasket Kit	393-5199
8V-3134	Pinion-Bevel	260-0788
9B-1320	Valve-Check	377-5832
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9G-8117	Housing As-Cl	302-2686
9J-2433	Cylinder As	480-8276
9J-5049	Pump Gp-Vn Bsc-B	422-8156
9K-1193	Gear-Sun	221-9099
9K-1773	Gear-Ring	221-9100
9K-3413	Gear-Bevel	223-4807
9K-9156	Retainer As	297-7236
9K-9158	Bearing-Sleeve	299-1970
9L-2685	Rod End	419-1866
9M-5477	Bearing-Sleeve	374-6517
9N-4460	Housing As-Cl	297-7203
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-2355	Manifold-Exhaust	261-0891
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

58Z		
Original Part Number	Part Name	Classic Part Number
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-9657	Bearing-Spl Ball	371-4308
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
100-7860	Valve-Inlet	270-4360
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
123-3472	Pump Gp-Gr 1 Bsc	345-1978
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202

Sales Model 966R (Cont'd.)

58Z		
Original Part Number	**Part Name**	**Classic Part Number**
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
176-9273	Piston	297-4860
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828
213-1365	Bearing-Sleeve	330-9256

58Z		
Original Part Number	**Part Name**	**Classic Part Number**
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
250-6556	Kit-Liner-Cla	250-6564
250-6558	Liner Kit-Cla	295-6438
255-2899	Pipe As-Tail	301-5246
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438

58Z		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-6872	Kit-Dt Gasket	394-8228
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
345-1976	Pump-Gr-Cla	345-1978
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 970F

7PL		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1U-2667	Cartridge Gp	422-8116
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513

7PL		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2F-5721	Bearing-Ball	311-9354
2K-5065	Cone-Roller Brg	416-2157
2K-5103	Cone-Roller Brg	380-7505
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912

7PL		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3G-5492	Rod As	377-5836
3G-5502	Cylinder As	390-0988
3G-9891	Pump Gp-Gr A	399-8541
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-4384	Housing As-Cl	435-2573
4B-9373	Cone-Roller Brg	399-4440

Sales Model 970F (Cont'd.)

7PL		
Original Part Number	Part Name	Classic Part Number
4B-9374	Bearing-Cup	380-7494
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-5213	Cover As	299-2000
4E-8535	Retainer-Seal	300-2589
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7270	Support-Trunnion	373-5384
4K-7467	Bearing As-Rlr	380-1500
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0897	Core As-Radiator	376-9058
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-5099	Cover	418-1929
4V-5392	Spider	377-7430
4V-6421	Pin As	319-3442
4V-7082	Joint Gp-Slip	367-6068
4V-7099	Pin As	361-1698

7PL		
Original Part Number	Part Name	Classic Part Number
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4Y-4340	Pin As	319-3442
4Y-5711	Pin As	425-6442
5D-2989	Bearing	380-7511
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535

7PL		
Original Part Number	Part Name	Classic Part Number
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3617	Support-Trunnion	374-4712
6E-0775	Head	425-9373
6E-5028	Rod As	425-9372
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-2408	Muffler As.	378-3978
6I-2409	Pipe	383-3693
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6W-9677	Tube As-Rh	388-6569
6W-9678	Tube As-Lh	388-6570
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3557	Spider As-Fan	430-4471
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-6461	Crown	325-6054

Sales Model 970F (Cont'd.)

7PL		
Original Part Number	**Part Name**	**Classic Part Number**
7J-9682	Bearing-Sleeve	360-2335
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7V-6716	Pin As	396-7273
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5699	Pulley-Cshaft	378-3988
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-7569	Case-Xmsn	394-0899
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

7PL		
Original Part Number	**Part Name**	**Classic Part Number**
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8R-0931	Housing-Pinion	302-4300
8R-0942	Plate-Reaction	380-1484
8R-1015	Support-Trunnion	374-4712
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501

7PL		
Original Part Number	**Part Name**	**Classic Part Number**
8R-3252	Shaft-Planet	297-7259
8R-6213	Mount As	389-6301
8R-8335	Gear-Bevel	368-0105
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-7659	Pin As	361-1702
9C-1484	Pin As	319-3446
9C-4080	Yoke-Brake	302-2703
9C-6029	Bearing-Planet	375-9982
9C-8669	Shaft-Bev Pinion	368-0107
9C-9191	Trunnion	302-2701
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309

Sales Model 970F (Cont'd.)

7PL		
Original Part Number	**Part Name**	**Classic Part Number**
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-2787	Gear-Planet	367-6093
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5174	Joint Gp-Univ	375-2628
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
9Y-3318	Core As-Radiator	374-7491
100-3596	Piston	380-1511
100-3597	Plate-Reaction	380-1501
100-7860	Valve-Inlet	270-4360
108-5680	Gage-Oil Level	378-4001
110-1337	Ring Kit-Pstn	377-5834
110-1488	Gear-Ring	394-0882
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
119-5727	Bearing-Spl Ball	417-9491
124-2726	Head	377-5855
127-5537	Core As-Oclr	325-6045
130-1521	Gasket Kit - Sch	393-1030

7PL		
Original Part Number	**Part Name**	**Classic Part Number**
131-3815	Seal Gp-Basic	325-6193
134-3036	Gasket Kit	393-3629
134-3068	Kit-Gasket(F)	393-3636
135-7989	Gasket Kit	393-3633
139-9175	Gasket Kit	377-7464
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
148-9288	Case As-Diff	380-1496
151-4836	Diff Gp -A	416-2120
158-1439	Kit-Dt Gasket	434-7290
160-1400	Yoke (1710)	319-3479
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

7PL		
Original Part Number	**Part Name**	**Classic Part Number**
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
216-7957	U-Joint	367-6069
226-8202	Seal-Wiper	472-8024
228-0419	Seal As	443-3571
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-1032	Disc-Friction	440-3116
334-8389	Crankshaft As	242-3439

7SK		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347

7SK		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344

7SK		
Original Part Number	**Part Name**	**Classic Part Number**
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108

Sales Model 970F (Cont'd.)

7SK		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508
2F-5721	Bearing-Ball	311-9354
2K-5065	Cone-Roller Brg	416-2157
2K-5103	Cone-Roller Brg	380-7505
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912

7SK		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3G-5492	Rod As	377-5836
3G-9891	Pump Gp-Gr A	399-8541
3H-1996	Bearing-Ball	380-1498
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-0487	Valve As-Check	375-4334
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-5213	Cover As	299-2000
4E-8535	Retainer-Seal	300-2589
4F-2393	Bearing-Ball	380-1499
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7270	Support-Trunnion	373-5384
4K-7467	Bearing As-Rlr	380-1500
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0897	Core As-Radiator	376-9058
4P-3546	Valve As-Relief	325-6236

7SK		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-5099	Cover	418-1929
4V-5392	Spider	377-7430
4V-6421	Pin As	319-3442
4V-7082	Joint Gp-Slip	367-6068
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4Y-4340	Pin As	319-3442
4Y-5711	Pin As	425-6442

Sales Model 970F (Cont'd.)

7SK		
Original Part Number	Part Name	Classic Part Number
5D-2989	Bearing	380-7511
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3617	Support-Trunnion	374-4712
6E-0775	Head	425-9373
6E-2387	Cartridge Gp	422-8132
6E-5028	Rod As	425-9372
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-2408	Muffler As.	378-3978

7SK		
Original Part Number	Part Name	Classic Part Number
6I-2409	Pipe	383-3693
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6T-1705	Shaft-Pump Drive	283-5201
6V-0538	Bearing-Spl Ball	398-2935
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3557	Spider As-Fan	430-4471
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531

7SK		
Original Part Number	Part Name	Classic Part Number
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-3365	Carrier-Planet	388-6563
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7V-5645	Rod-Indicator	397-5061
7V-6715	Pin As	361-1701
7V-6716	Pin As	396-7273
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5699	Pulley-Cshaft	378-3988
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-7569	Case-Xmsn	394-0899
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

Sales Model 970F (Cont'd.)

7SK		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-0931	Housing-Pinion	302-4300
8R-0942	Plate-Reaction	380-1484
8R-1015	Support-Trunnion	374-4712
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-3252	Shaft-Planet	297-7259
8R-3921	Collet	308-9839
8R-3943	Collet	308-9840
8R-6213	Mount As	389-6301

7SK		
Original Part Number	**Part Name**	**Classic Part Number**
8R-8335	Gear-Bevel	368-0105
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3550	Rim As	417-9477
8V-7659	Pin As	361-1702
9C-1484	Pin As	319-3446
9C-4080	Yoke-Brake	302-2703
9C-6029	Bearing-Planet	375-9982
9C-8669	Shaft-Bev Pinion	368-0107
9C-9191	Trunnion	302-2701
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309

7SK		
Original Part Number	**Part Name**	**Classic Part Number**
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-2787	Gear-Planet	367-6093
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5174	Joint Gp-Univ	375-2628
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
9Y-3318	Core As-Radiator	374-7491
100-3596	Piston	380-1511
100-3597	Plate-Reaction	380-1501
100-7860	Valve-Inlet	270-4360
108-5680	Gage-Oil Level	378-4001
110-1337	Ring Kit-Pstn	377-5834
110-1488	Gear-Ring	394-0882
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
112-8042	Carrier-Planet	390-0916
119-5727	Bearing-Spl Ball	417-9491
124-2726	Head	377-5855
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
134-3036	Gasket Kit	393-3629
134-3038	Gasket Kit	437-3228
134-3068	Kit-Gasket(F)	393-3636
136-7813	Bearing-Race	460-8296

Sales Model 970F (Cont'd.)

7SK		
Original Part Number	**Part Name**	**Classic Part Number**
139-9175	Gasket Kit	377-7464
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Ktt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
148-9288	Case As-Diff	380-1496
151-4836	Diff Gp -A	416-2120
155-1379	Gasket Kit - Sch	386-3815
158-1439	Kit-Dt Gasket	434-7290
160-1400	Yoke (1710)	319-3479
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

7SK		
Original Part Number	**Part Name**	**Classic Part Number**
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

7SK		
Original Part Number	**Part Name**	**Classic Part Number**
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
216-7957	U-Joint	367-6069
226-8202	Seal-Wiper	472-8024
228-0419	Seal As	443-3571
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-1032	Disc-Friction	440-3116
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

9JK		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1T-0767	Bearing-Sleeve	383-2108
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980

9JK		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9453	Cone-Roller Brg	380-7508

9JK		
Original Part Number	**Part Name**	**Classic Part Number**
2F-5721	Bearing-Ball	311-9354
2K-5065	Cone-Roller Brg	416-2157
2K-5103	Cone-Roller Brg	380-7505
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

Sales Model 970F (Cont'd.)

9JK		
Original Part Number	**Part Name**	**Classic Part Number**
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3G-5264	Cylinder As.	393-1018
3G-5492	Rod As	377-5836
3G-5497	Cyl Gp-0210 0535	394-9822
3G-9891	Pump Gp-Gr A	399-8541
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3N-5869	Support-Elbow	375-9973
3T-2094	Bearing-Sleeve	388-0638
3T-2145	Carrier As	325-6041
3T-4384	Housing As-Cl	435-2573
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-0487	Valve As-Check	375-4334
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-5213	Cover As	299-2000
4E-8535	Retainer-Seal	300-2589
4K-6558	Pin-Lower	302-2710
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7270	Support-Trunnion	373-5384
4K-7467	Bearing As-Rlr	380-1500

9JK		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0897	Core As-Radiator	376-9058
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8472	Hood As-Preclnr	296-1355
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-5099	Cover	418-1929
4V-5392	Spider	377-7430
4V-6421	Pin As	319-3442
4V-7082	Joint Gp-Slip	367-6068
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-8518	Link As-Brg&	374-1450
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187

9JK		
Original Part Number	**Part Name**	**Classic Part Number**
4W-0452	Seal As -Cshaft	325-6191
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4Y-4340	Pin As	319-3442
4Y-5711	Pin As	425-6442
5D-2989	Bearing	380-7511
5K-3493	Cover	391-9814
5K-8591	Bearing-Outer	380-7502
5L-7632	Support-Elbow	433-9854
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-3617	Support-Trunnion	374-4712
6E-0775	Head	425-9373
6E-5028	Rod As	425-9372

Sales Model 970F (Cont'd.)

9JK		
Original Part Number	Part Name	Classic Part Number
6E-6416	Cylinder As	425-9371
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-2408	Muffler As.	378-3978
6I-2409	Pipe	383-3693
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7C-6628	Pulley-Alt	396-9894
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3557	Spider As-Fan	430-4471
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7M-4046	Bearing-Sleeve	394-8206

9JK		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5206	Mount As	374-1451
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-3370	Yoke As	302-2702
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-5645	Rod-Indicator	397-5061
7V-6715	Pin As	361-1701
7V-6716	Pin As	396-7273
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-5699	Pulley-Cshaft	378-3988
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-7569	Case-Xmsn	394-0899
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8L-8867	Pulley	434-1409
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893

9JK		
Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212

Sales Model 970F (Cont'd.)

9JK		
Original Part Number	**Part Name**	**Classic Part Number**
8R-0931	Housing-Pinion	302-4300
8R-0942	Plate-Reaction	380-1484
8R-1015	Support-Trunnion	374-4712
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-3252	Shaft-Planet	297-7259
8R-6213	Mount As	389-6301
8R-8335	Gear-Bevel	368-0105
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-7659	Pin As	361-1702
9C-1484	Pin As	319-3446
9C-4080	Yoke-Brake	302-2703
9C-6029	Bearing-Planet	375-9982
9C-8669	Shaft-Bev Pinion	368-0107
9C-9191	Trunnion	302-2701
9D-7924	Mount As	360-2356
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-2413	Shaft-Output	297-7255
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587

9JK		
Original Part Number	**Part Name**	**Classic Part Number**
9L-5521	Manifold-Exhaust	396-9895
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9U-2787	Gear-Planet	367-6093
9V-0247	Plate	417-4527
9V-2410	Housing-Bearing	302-2679
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-5174	Joint Gp-Univ	375-2628
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6526	Ring-Retaining	422-2485
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355
9Y-1798	Seal-Water	379-0165
9Y-3318	Core As-Radiator	374-7491
100-3596	Piston	380-1511
100-3597	Plate-Reaction	380-1501
100-7860	Valve-Inlet	270-4360
108-5680	Gage-Oil Level	378-4001
110-1337	Ring Kit-Pstn	377-5834
110-1488	Gear-Ring	394-0882

9JK		
Original Part Number	**Part Name**	**Classic Part Number**
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
119-5727	Bearing-Spl Ball	417-9491
124-2726	Head	377-5855
127-5537	Core As-Oclr	325-6045
131-3815	Seal Gp-Basic	325-6193
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
134-3036	Gasket Kit	393-3629
134-3068	Kit-Gasket(F)	393-3636
135-7989	Gasket Kit	393-3633
136-7813	Bearing-Race	460-8296
139-9175	Gasket Kit	377-7464
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
148-7455	Valve - Exhaust	270-4361
148-9288	Case As-Diff	380-1496
151-4836	Diff Gp -A	416-2120
155-1379	Gasket Kit - Sch	386-3815
158-1439	Kit-Dt Gasket	434-7290
160-1400	Yoke (1710)	319-3479
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006

Sales Model 970F (Cont'd.)

9JK		
Original Part Number	Part Name	Classic Part Number
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0564	Rebuild Kit-Pump	380-7576
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7763	Pump Gp-Water -B	374-7499

9JK		
Original Part Number	Part Name	Classic Part Number
172-7765	Pump Gp-Water -B	394-9835
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
187-0605	Gasket Kit - Cl	382-5055
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
216-7957	U-Joint	367-6069
226-8202	Seal-Wiper	472-8024
228-0419	Seal As	443-3571
232-3233	Bearing-Main	376-9085

9JK		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-1032	Disc-Friction	440-3116
334-8389	Crankshaft As	242-3439
391-8229	Kit-Gasket-Fs	398-2955

Sales Model 972G

1EW		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453
1S-0057	Plate-Clutch	377-7404
1S-3062	Director-Water	418-9572
1V-8852	Cap	308-9834
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

1EW		
Original Part Number	Part Name	Classic Part Number
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

1EW		
Original Part Number	Part Name	Classic Part Number
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3P-3505	Shaft-Brake	384-3477
3S-1262	Retainer	308-9915
3T-2094	Bearing-Sleeve	388-0638
3V-4046	Plate-Pressure	380-7470
4E-0079	Cage-Bearing	434-4387
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4N-0432	Bearing-Ball	417-4499

Sales Model 972G (Cont'd.)

1EW		
Original Part Number	**Part Name**	**Classic Part Number**
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022

1EW		
Original Part Number	**Part Name**	**Classic Part Number**
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7C-6628	Pulley-Alt	396-9894
7D-8636	Cone-Bearing	418-9606

1EW		
Original Part Number	**Part Name**	**Classic Part Number**
7D-8637	Cup-Bearing	418-9607
7E-3509	Pipe As-Ex Ext	373-1907
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4000	Piston	416-2143
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-3111	Rod End-Spher	392-4523
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196

Sales Model 972G (Cont'd.)

1EW		
Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9C-9191	Trunnion	302-2701

1EW		
Original Part Number	Part Name	Classic Part Number
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491
127-5537	Core As-Oclr	325-6045
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007

1EW		
Original Part Number	Part Name	Classic Part Number
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
144-9072	Cylinder As	394-8209
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
236-8675	Disc-Friction	428-7202
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988

Sales Model 972G (Cont'd.)

1EW		
Original Part Number	**Part Name**	**Classic Part Number**
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032

1EW		
Original Part Number	**Part Name**	**Classic Part Number**
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

1EW		
Original Part Number	**Part Name**	**Classic Part Number**
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

4WW		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1V-8852	Cap	308-9834
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

4WW		
Original Part Number	**Part Name**	**Classic Part Number**
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3T-2094	Bearing-Sleeve	388-0638
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4J-0121	Cap-Bearing	360-2344
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987

4WW		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

Sales Model 972G (Cont'd.)

4WW		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7C-6628	Pulley-Alt	396-9894
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-3509	Pipe As-Ex Ext	373-1907
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7J-9344	Bearing-Sleeve	360-2334
7J-9731	Bearing-Sleeve	308-9822
7K-0078	Bearing-Sleeve	308-9825
7K-9639	Bearing-Sleeve	314-8643
7M-4046	Bearing-Sleeve	394-8206

4WW		
Original Part Number	Part Name	Classic Part Number
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-3111	Rod End-Spher	392-4523
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-5778	Bearing-Sleeve	374-8359
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207

4WW		
Original Part Number	Part Name	Classic Part Number
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7412	Gear As-Pump	297-7183
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818

Sales Model 972G (Cont'd.)

4WW		
Original Part Number	**Part Name**	**Classic Part Number**
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491
127-5537	Core As-Oclr	325-6045
128-3132	Gasket Kit	437-4566

4WW		
Original Part Number	**Part Name**	**Classic Part Number**
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574

4WW		
Original Part Number	**Part Name**	**Classic Part Number**
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-1742	Kit-Gasket-Sch	438-0156
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

6AW		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453
1S-0057	Plate-Clutch	377-7404
1S-3062	Director-Water	418-9572
1V-8852	Cap	308-9834
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659

6AW		
Original Part Number	**Part Name**	**Classic Part Number**
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157

6AW		
Original Part Number	**Part Name**	**Classic Part Number**
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912

Sales Model 972G (Cont'd.)

6AW		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3P-3505	Shaft-Brake	384-3477
3S-1262	Retainer	308-9915
3T-2094	Bearing-Sleeve	388-0638
3V-4046	Plate-Pressure	380-7470
4E-0079	Cage-Bearing	434-4387
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526

6AW		
Original Part Number	Part Name	Classic Part Number
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-1036	Gear-Oil Pump	279-4991

6AW		
Original Part Number	Part Name	Classic Part Number
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7C-6628	Pulley-Alt	396-9894
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-3509	Pipe As-Ex Ext	373-1907
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4000	Piston	416-2143
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989

Sales Model 972G (Cont'd.)

6AW		
Original Part Number	**Part Name**	**Classic Part Number**
8C-3111	Rod End-Spher	392-4523
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211

6AW		
Original Part Number	**Part Name**	**Classic Part Number**
8R-1465	Rim As	417-9501
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
117-6675	Step As	419-0881

6AW		
Original Part Number	**Part Name**	**Classic Part Number**
119-5727	Bearing-Spl Ball	417-9491
127-5537	Core As-Oclr	325-6045
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
144-9072	Cylinder As	394-8209
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835

Sales Model 972G (Cont'd.)

6AW		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
236-8675	Disc-Friction	428-7202

6AW		
Original Part Number	Part Name	Classic Part Number
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

6AW		
Original Part Number	Part Name	Classic Part Number
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

7LS		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1V-8852	Cap	308-9834
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229

7LS		
Original Part Number	Part Name	Classic Part Number
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3T-2094	Bearing-Sleeve	388-0638
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4J-0121	Cap-Bearing	360-2344
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

7LS		
Original Part Number	Part Name	Classic Part Number
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433

Sales Model 972G (Cont'd.)

7LS		
Original Part Number	**Part Name**	**Classic Part Number**
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348

7LS		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-9960	Mount As.	376-3639
7C-6628	Pulley-Alt	396-9894
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-3509	Pipe As-Ex Ext	373-1907
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7J-9344	Bearing-Sleeve	360-2334
7J-9731	Bearing-Sleeve	308-9822
7K-0078	Bearing-Sleeve	308-9825
7K-9639	Bearing-Sleeve	314-8643
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-3111	Rod End-Spher	392-4523
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658

7LS		
Original Part Number	**Part Name**	**Classic Part Number**
8H-9789	Bearing-Ball	374-8342
8J-5778	Bearing-Sleeve	374-8359
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438

Sales Model 972G (Cont'd.)

7LS		
Original Part Number	**Part Name**	**Classic Part Number**
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7412	Gear As-Pump	297-7183
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-0247	Plate	417-4527

7LS		
Original Part Number	**Part Name**	**Classic Part Number**
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491
127-5537	Core As-Oclr	325-6045
128-3132	Gasket Kit	437-4566
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023

7LS		
Original Part Number	**Part Name**	**Classic Part Number**
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-1742	Kit-Gasket-Sch	438-0156
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

8TS		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1V-8852	Cap	308-9834
1W-1669	Piston	325-6158

8TS		
Original Part Number	**Part Name**	**Classic Part Number**
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036

8TS		
Original Part Number	**Part Name**	**Classic Part Number**
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434

Sales Model 972G (Cont'd.)

8TS		
Original Part Number	**Part Name**	**Classic Part Number**
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3T-2094	Bearing-Sleeve	388-0638
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988

8TS		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

8TS		
Original Part Number	**Part Name**	**Classic Part Number**
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7C-6628	Pulley-Alt	396-9894
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-3509	Pipe As-Ex Ext	373-1907
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496

Sales Model 972G (Cont'd.)

8TS		
Original Part Number	Part Name	Classic Part Number
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7V-6715	Pin As	361-1701
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-3111	Rod End-Spher	392-4523
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377

8TS		
Original Part Number	Part Name	Classic Part Number
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220

8TS		
Original Part Number	Part Name	Classic Part Number
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
119-5727	Bearing-Spl Ball	417-9491
127-5537	Core As-Oclr	325-6045
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674

Sales Model 972G (Cont'd.)

8TS		
Original Part Number	**Part Name**	**Classic Part Number**
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288

8TS		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988

8TS		
Original Part Number	**Part Name**	**Classic Part Number**
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

9GW		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1V-8852	Cap	308-9834
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

9GW		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3T-2094	Bearing-Sleeve	388-0638
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985

9GW		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481

Sales Model 972G (Cont'd.)

9GW		
Original Part Number	**Part Name**	**Classic Part Number**
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7C-6628	Pulley-Alt	396-9894
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-3509	Pipe As-Ex Ext	373-1907
7E-9980	Camshaft	377-5851

9GW		
Original Part Number	**Part Name**	**Classic Part Number**
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7K-9639	Bearing-Sleeve	314-8643
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-3111	Rod End-Spher	392-4523
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711

9GW		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931

Sales Model 972G (Cont'd.)

9GW		
Original Part Number	**Part Name**	**Classic Part Number**
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491

9GW		
Original Part Number	**Part Name**	**Classic Part Number**
127-5537	Core As-Oclr	325-6045
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574

9GW		
Original Part Number	**Part Name**	**Classic Part Number**
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

AAW		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1V-8852	Cap	308-9834
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659

AAW		
Original Part Number	**Part Name**	**Classic Part Number**
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157

AAW		
Original Part Number	**Part Name**	**Classic Part Number**
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912

Sales Model 972G (Cont'd.)

AAW		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3T-2094	Bearing-Sleeve	388-0638
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528

AAW		
Original Part Number	Part Name	Classic Part Number
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544

AAW		
Original Part Number	Part Name	Classic Part Number
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7C-6628	Pulley-Alt	396-9894
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-3509	Pipe As-Ex Ext	373-1907
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7K-9639	Bearing-Sleeve	314-8643
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-3111	Rod End-Spher	392-4523

Sales Model 972G (Cont'd.)

AAW		
Original Part Number	Part Name	Classic Part Number
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501

AAW		
Original Part Number	Part Name	Classic Part Number
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491

AAW		
Original Part Number	Part Name	Classic Part Number
127-5537	Core As-Oclr	325-6045
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

Sales Model 972G (Cont'd.)

AAW		
Original Part Number	Part Name	Classic Part Number
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032

AAW		
Original Part Number	Part Name	Classic Part Number
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

AAW		
Original Part Number	Part Name	Classic Part Number
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

AAW		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9989	Pipe-Head Outlet	363-7453
1S-3062	Director-Water	418-9572
1V-8852	Cap	308-9834
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901

AAW		
Original Part Number	Part Name	Classic Part Number
2P-6245	Shaft As-Pump	325-6197
2P-8986	Cup-Rlr Bearing	415-1912
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3J-2903	Cover	422-6922
3T-2094	Bearing-Sleeve	388-0638
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4N-0432	Bearing-Ball	417-4499
4N-4942	Rod-Eye	421-8919
4N-7693	Crankshaft As	269-8763
4P-0893	Core As-Radiator	376-9057
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217

AAW		
Original Part Number	Part Name	Classic Part Number
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

Sales Model 972G (Cont'd.)

AAW		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-1036	Gear-Oil Pump	279-4991
6N-5978	Coupling-Exhaust	369-9487
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-2202	Bearing-Spl Ball	380-1574
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7C-6628	Pulley-Alt	396-9894
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-3509	Pipe As-Ex Ext	373-1907
7E-9980	Camshaft	377-5851
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7K-9639	Bearing-Sleeve	314-8643
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531

AAW		
Original Part Number	Part Name	Classic Part Number
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-3111	Rod End-Spher	392-4523
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377

AAW		
Original Part Number	Part Name	Classic Part Number
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9L-5908	Gasket	433-8196
9L-6371	Rod-Eye	363-7459
9M-1328	Bearing-Aligning	325-6018
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719

Sales Model 972G (Cont'd.)

AAW		
Original Part Number	Part Name	Classic Part Number
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
002-1212	Cup-Roller Brg	399-4446
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491
127-5537	Core As-Oclr	325-6045
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
131-3815	Seal Gp-Basic	325-6193
132-6597	Cone-Spl	422-6477
148-7455	Valve - Exhaust	270-4361

AAW		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835

AAW		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

ANY		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
3J-2903	Cover	422-6922
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
4E-3196	Pin As	361-1697
4J-0121	Cap-Bearing	360-2344

ANY		
Original Part Number	Part Name	Classic Part Number
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187

ANY		
Original Part Number	Part Name	Classic Part Number
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-5978	Coupling-Exhaust	369-9487

Sales Model 972G (Cont'd.)

ANY		
Original Part Number	**Part Name**	**Classic Part Number**
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-3831	Seal-O-Ring	436-2657
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7J-9344	Bearing-Sleeve	360-2334
7J-9731	Bearing-Sleeve	308-9822
7K-9639	Bearing-Sleeve	314-8643
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663

ANY		
Original Part Number	**Part Name**	**Classic Part Number**
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8R-7336	Bearing	301-3394
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447

ANY		
Original Part Number	**Part Name**	**Classic Part Number**
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
132-6597	Cone-Spl	422-6477
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
164-4413	Mount	419-0876
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
216-4781	Gasket Kit	437-8144
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

AWP		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384

AWP		
Original Part Number	**Part Name**	**Classic Part Number**
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434

AWP		
Original Part Number	**Part Name**	**Classic Part Number**
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157

Sales Model 972G (Cont'd.)

AWP		
Original Part Number	Part Name	Classic Part Number
2P-8986	Cup-Rlr Bearing	415-1912
3J-2903	Cover	422-6922
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
4E-3196	Pin As	361-1697
4J-0121	Cap-Bearing	360-2344
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-5978	Coupling-Exhaust	369-9487
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-3831	Seal-O-Ring	436-2657

AWP		
Original Part Number	Part Name	Classic Part Number
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7J-9344	Bearing-Sleeve	360-2334
7J-9731	Bearing-Sleeve	308-9822
7K-9639	Bearing-Sleeve	314-8643
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8R-7336	Bearing	301-3394
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931

AWP		
Original Part Number	Part Name	Classic Part Number
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
132-6597	Cone-Spl	422-6477
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
164-4413	Mount	419-0876
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600

Sales Model 972G (Cont'd.)

AWP		
Original Part Number	**Part Name**	**Classic Part Number**
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
206-6405	Bearing-Spl Ball	420-2503

AWP		
Original Part Number	**Part Name**	**Classic Part Number**
213-1370	Bearing-Sleeve	380-7370
216-4781	Gasket Kit	437-8144
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

AWP		
Original Part Number	**Part Name**	**Classic Part Number**
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

AXC		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
3J-2903	Cover	422-6922
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
4E-3196	Pin As	361-1697
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187

AXC		
Original Part Number	**Part Name**	**Classic Part Number**
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-5978	Coupling-Exhaust	369-9487
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-3831	Seal-O-Ring	436-2657
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206

AXC		
Original Part Number	**Part Name**	**Classic Part Number**
7J-4083	Piston	396-9907
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398

Sales Model 972G (Cont'd.)

AXC		
Original Part Number	Part Name	Classic Part Number
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
114-0468	Pin-G.E.T.	443-1203
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447

AXC		
Original Part Number	Part Name	Classic Part Number
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
132-6597	Cone-Spl	422-6477
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
164-4413	Mount	419-0876
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600

AXC		
Original Part Number	Part Name	Classic Part Number
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
216-4781	Gasket Kit	437-8144
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

AXE		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
3J-2903	Cover	422-6922
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
4E-3196	Pin As	361-1697
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652

AXE		
Original Part Number	Part Name	Classic Part Number
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502

AXE		
Original Part Number	Part Name	Classic Part Number
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-5978	Coupling-Exhaust	369-9487
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-3831	Seal-O-Ring	436-2657
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205

Sales Model 972G (Cont'd.)

AXE		
Original Part Number	**Part Name**	**Classic Part Number**
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7K-9639	Bearing-Sleeve	314-8643
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931

AXE		
Original Part Number	**Part Name**	**Classic Part Number**
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491

AXE		
Original Part Number	**Part Name**	**Classic Part Number**
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
132-6597	Cone-Spl	422-6477
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
164-4413	Mount	419-0876
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
216-4781	Gasket Kit	437-8144
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

AXN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912

AXN		
Original Part Number	**Part Name**	**Classic Part Number**
3J-2903	Cover	422-6922
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
4E-3196	Pin As	361-1697
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652

AXN		
Original Part Number	**Part Name**	**Classic Part Number**
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-2989	Bearing	380-7511

Sales Model 972G (Cont'd.)

AXN		
Original Part Number	Part Name	Classic Part Number
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-5978	Coupling-Exhaust	369-9487
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-3831	Seal-O-Ring	436-2657
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8E-9740	Gear-Output Tfr	432-8905

AXN		
Original Part Number	Part Name	Classic Part Number
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9P-3731	Carrier-Planet	301-4767
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448

AXN		
Original Part Number	Part Name	Classic Part Number
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
132-6597	Cone-Spl	422-6477
144-9072	Cylinder As	394-8209
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048
164-4413	Mount	419-0876
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
216-4781	Gasket Kit	437-8144
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

AXP		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487

Sales Model 972G (Cont'd.)

AXP		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
3J-2903	Cover	422-6922
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
4E-3196	Pin As	361-1697
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387

AXP		
Original Part Number	Part Name	Classic Part Number
6K-5528	Cup-Roller Brg	447-8059
6N-5978	Coupling-Exhaust	369-9487
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-3831	Seal-O-Ring	436-2657
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-4083	Piston	396-9907
7K-9639	Bearing-Sleeve	314-8643
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217

AXP		
Original Part Number	Part Name	Classic Part Number
9G-6744	Bearing-Sleeve	418-1931
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
132-6597	Cone-Spl	422-6477
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
164-4413	Mount	419-0876
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367

Sales Model 972G (Cont'd.)

AXP		
Original Part Number	Part Name	Classic Part Number
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370

AXP		
Original Part Number	Part Name	Classic Part Number
216-4781	Gasket Kit	437-8144
252-7038	Kit-Dt Bearing	464-9065
262-4335	Kit - Dt Gasket	434-7288
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

AXP		
Original Part Number	Part Name	Classic Part Number
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

TLA		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2H-3712	Bearing-Ball	392-4488
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
3J-2903	Cover	422-6922
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579

TLA		
Original Part Number	Part Name	Classic Part Number
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-5978	Coupling-Exhaust	369-9487
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-3831	Seal-O-Ring	436-2657
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579

TLA		
Original Part Number	Part Name	Classic Part Number
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9V-0247	Plate	417-4527
9W-8437	Gear-Sun	450-7550
9Y-7215	Sleeve-Isolator	425-3646
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446

Sales Model 972G (Cont'd.)

TLA		
Original Part Number	**Part Name**	**Classic Part Number**
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
117-6675	Step As	419-0881
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
132-6597	Cone-Spl	422-6477
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
160-9874	Kit-Gasket-Scl	386-3048

TLA		
Original Part Number	**Part Name**	**Classic Part Number**
164-4413	Mount	419-0876
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
190-0649	Tightener-Belt	434-1407
197-9251	Pin As.-Piston	454-6110

TLA		
Original Part Number	**Part Name**	**Classic Part Number**
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
216-4781	Gasket Kit	437-8144
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

Sales Model 972H

A7D		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4J-0121	Cap-Bearing	360-2344
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502

A7D		
Original Part Number	**Part Name**	**Classic Part Number**
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7704	Carrier-Ring	314-8658
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639

A7D		
Original Part Number	**Part Name**	**Classic Part Number**
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7G-2830	Ring-Seal	295-6441
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-9344	Bearing-Sleeve	360-2334
7J-9731	Bearing-Sleeve	308-9822
7J-9884	Bearing-Sleeve	325-6016
7K-0078	Bearing-Sleeve	308-9825
7K-9528	Bearing-Sleeve	308-9828
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231

Sales Model 972H (Cont'd.)

A7D		
Original Part Number	Part Name	Classic Part Number
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8J-5778	Bearing-Sleeve	374-8359
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501

A7D		
Original Part Number	Part Name	Classic Part Number
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1491	Carrier-Planet	281-1685
9G-6744	Bearing-Sleeve	418-1931
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219

A7D		
Original Part Number	Part Name	Classic Part Number
9P-9031	Gear-Sun	283-5220
9W-0517	Carrier-Planet	281-1686
9W-8437	Gear-Sun	450-7550
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
132-6597	Cone-Spl	422-6477
176-9273	Piston	297-4860
213-1370	Bearing-Sleeve	380-7370
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

A7G		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
4E-3196	Pin As	361-1697
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-2989	Bearing	380-7511

A7G		
Original Part Number	Part Name	Classic Part Number
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606

A7G		
Original Part Number	Part Name	Classic Part Number
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701

Sales Model 972H (Cont'd.)

A7G		
Original Part Number	**Part Name**	**Classic Part Number**
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719

A7G		
Original Part Number	**Part Name**	**Classic Part Number**
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9W-8437	Gear-Sun	450-7550
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
114-0468	Pin-G.E.T.	443-1203
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077

A7G		
Original Part Number	**Part Name**	**Classic Part Number**
132-6597	Cone-Spl	422-6477
213-1370	Bearing-Sleeve	380-7370
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

A7J		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
3G-2797	Bearing-Sleeve	360-2329
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022

A7J		
Original Part Number	**Part Name**	**Classic Part Number**
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7704	Carrier-Ring	314-8658
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7G-2830	Ring-Seal	295-6441
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697

A7J		
Original Part Number	**Part Name**	**Classic Part Number**
7G-6062	Gear-Ring	302-2678
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1491	Carrier-Planet	281-1685
9G-6744	Bearing-Sleeve	418-1931

Sales Model 972H (Cont'd.)

A7J		
Original Part Number	Part Name	Classic Part Number
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220

A7J		
Original Part Number	Part Name	Classic Part Number
9W-0517	Carrier-Planet	281-1686
9W-8437	Gear-Sun	450-7550
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
132-6597	Cone-Spl	422-6477

A7J		
Original Part Number	Part Name	Classic Part Number
176-9273	Piston	297-4860
213-1370	Bearing-Sleeve	380-7370
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

GTA		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917

GTA		
Original Part Number	Part Name	Classic Part Number
5P-5411	Race-Brg Outer	417-9481
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7704	Carrier-Ring	314-8658
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7G-2830	Ring-Seal	295-6441
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206

GTA		
Original Part Number	Part Name	Classic Part Number
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1465	Rim As	417-9501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1491	Carrier-Planet	281-1685
9G-6744	Bearing-Sleeve	418-1931
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203

Sales Model 972H (Cont'd.)

GTA		
Original Part Number	**Part Name**	**Classic Part Number**
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9W-0517	Carrier-Planet	281-1686
9W-8437	Gear-Sun	450-7550
002-1212	Cup-Roller Brg	399-4446

GTA		
Original Part Number	**Part Name**	**Classic Part Number**
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
114-0468	Pin-G.E.T.	443-1203
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
132-6597	Cone-Spl	422-6477

GTA		
Original Part Number	**Part Name**	**Classic Part Number**
176-9273	Piston	297-4860
213-1370	Bearing-Sleeve	380-7370
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

LCC		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
4E-3196	Pin As	361-1697
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-8194	Ring-Retaining	308-9920

LCC		
Original Part Number	**Part Name**	**Classic Part Number**
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6P-0593	Bearing-Roller	386-4959
6P-7704	Carrier-Ring	314-8658
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211

LCC		
Original Part Number	**Part Name**	**Classic Part Number**
8R-1465	Rim As	417-9501
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9W-8437	Gear-Sun	450-7550
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
132-6597	Cone-Spl	422-6477
213-1370	Bearing-Sleeve	380-7370
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model 972H (Cont'd.)

NPE		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
4E-3196	Pin As	361-1697
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481

NPE		
Original Part Number	Part Name	Classic Part Number
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6P-7704	Carrier-Ring	314-8658
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-0638	Spacer	425-3651
7V-6715	Pin As	361-1701
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445

NPE		
Original Part Number	Part Name	Classic Part Number
8P-2042	Shaft-Planet	283-5211
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9W-8437	Gear-Sun	450-7550
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
132-6597	Cone-Spl	422-6477
213-1370	Bearing-Sleeve	380-7370
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

WLA		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157

WLA		
Original Part Number	Part Name	Classic Part Number
2P-8986	Cup-Rlr Bearing	415-1912
4E-3196	Pin As	361-1697
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527

WLA		
Original Part Number	Part Name	Classic Part Number
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433

Sales Model 972H (Cont'd.)

WLA		
Original Part Number	**Part Name**	**Classic Part Number**
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6P-7704	Carrier-Ring	314-8658
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206

WLA		
Original Part Number	**Part Name**	**Classic Part Number**
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7V-6715	Pin As	361-1701
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-7099	Bearing-Sleeve	391-9818

WLA		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9W-8437	Gear-Sun	450-7550
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
112-8042	Carrier-Planet	390-0916
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
132-6597	Cone-Spl	422-6477
213-1370	Bearing-Sleeve	380-7370
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

WXZ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1P-1367	Plunger-Valve	432-8913
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
4E-3196	Pin As	361-1697
4T-8054	Seal As	472-8010
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527

WXZ		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579

WXZ		
Original Part Number	**Part Name**	**Classic Part Number**
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6P-7704	Carrier-Ring	314-8658
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-4819	Carrier-Planet	296-1348
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7T-8816	Bearing-Spl Ball	420-2491

Sales Model 972H (Cont'd.)

WXZ		
Original Part Number	Part Name	Classic Part Number
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613

WXZ		
Original Part Number	Part Name	Classic Part Number
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9W-8437	Gear-Sun	450-7550
002-1212	Cup-Roller Brg	399-4446

WXZ		
Original Part Number	Part Name	Classic Part Number
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
132-6597	Cone-Spl	422-6477
213-1370	Bearing-Sleeve	380-7370
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model 972K

PEM		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1V-8241	Bearing-Sleeve	308-9808
1V-8852	Cap	308-9834
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638

PEM		
Original Part Number	Part Name	Classic Part Number
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481

PEM		
Original Part Number	Part Name	Classic Part Number
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6P-2233	Gear-Planet	281-1690
6P-7704	Carrier-Ring	314-8658
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-4819	Carrier-Planet	296-1348
7B-7515	Bearing-Ball	399-6059
7D-8636	Cone-Bearing	418-9606

Sales Model 972K (Cont'd.)

PEM		
Original Part Number	**Part Name**	**Classic Part Number**
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7G-2830	Ring-Seal	295-6441
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-9344	Bearing-Sleeve	360-2334
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7V-0638	Spacer	425-3651
7V-6715	Pin As	361-1701
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088

PEM		
Original Part Number	**Part Name**	**Classic Part Number**
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018

PEM		
Original Part Number	**Part Name**	**Classic Part Number**
9N-4460	Housing As-Cl	297-7203
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9W-0517	Carrier-Planet	281-1686
9W-8437	Gear-Sun	450-7550
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
114-0468	Pin-G.E.T.	443-1203
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
132-6597	Cone-Spl	422-6477
155-6648	Cone Spl Rol Brg	418-9599
161-3411	Gasket	394-0896
176-9273	Piston	297-4860
213-1370	Bearing-Sleeve	380-7370
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Z4W		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1V-8241	Bearing-Sleeve	308-9808
1V-8852	Cap	308-9834
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-8509	Cone-Roller Brg	399-4434
2K-5065	Cone-Roller Brg	416-2157

Z4W		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4V-5099	Cover	418-1929
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528

Z4W		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579

Sales Model 972K (Cont'd.)

Z4W		
Original Part Number	Part Name	Classic Part Number
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6P-2233	Gear-Planet	281-1690
6P-7704	Carrier-Ring	314-8658
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-1084	Impeller-Conv	380-1477
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-4819	Carrier-Planet	296-1348
7B-7515	Bearing-Ball	399-6059
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-0437	Plate-Clutch	417-9466
7G-2830	Ring-Seal	295-6441
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-9344	Bearing-Sleeve	360-2334
7J-9731	Bearing-Sleeve	308-9822
7K-0078	Bearing-Sleeve	308-9825

Z4W		
Original Part Number	Part Name	Classic Part Number
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7V-0638	Spacer	425-3651
7V-6715	Pin As	361-1701
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8G-4022	Bearing	422-6920
8H-5352	Bearing-Ball	453-3658
8J-5778	Bearing-Sleeve	374-8359
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-4568	Piston	385-6108
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-6744	Bearing-Sleeve	418-1931

Z4W		
Original Part Number	Part Name	Classic Part Number
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9W-0517	Carrier-Planet	281-1686
9W-8437	Gear-Sun	450-7550
002-1212	Cup-Roller Brg	399-4446
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
119-5727	Bearing-Spl Ball	417-9491
129-4299	Gear-Planet	446-3077
132-6597	Cone-Spl	422-6477
155-6648	Cone Spl Rol Brg	418-9599
161-3411	Gasket	394-0896
176-9273	Piston	297-4860
213-1370	Bearing-Sleeve	380-7370
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model 972L

RFB		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1M-6573	Cup-Roller Brg	399-4438

RFB		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397

RFB		
Original Part Number	Part Name	Classic Part Number
1T-0210	Bearing-Ball	417-4498
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802

Wheel Loaders

Sales Model 972L (Cont'd.)

RFB		
Original Part Number	Part Name	Classic Part Number
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2K-5065	Cone-Roller Brg	416-2157
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
2W-8494	Pulley-Alt	295-5692
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-3196	Pin As	361-1697
4N-2514	Gear-Flywheel	421-7283
4N-4577	Muffler As.	308-9877
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

RFB		
Original Part Number	Part Name	Classic Part Number
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-4819	Carrier-Planet	296-1348
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6715	Pin As	361-1701
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579

RFB		
Original Part Number	Part Name	Classic Part Number
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9M-2744	Cone-Spl Tapered	380-1480
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-7148	Cap As-Rain	378-3994
9W-8437	Gear-Sun	450-7550
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
161-3411	Gasket	394-0896
213-1365	Bearing-Sleeve	330-9256
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model 972M

A8P		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1M-6573	Cup-Roller Brg	399-4438
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0210	Bearing-Ball	417-4498
1T-0762	Race-Thrust	384-4803

A8P		
Original Part Number	Part Name	Classic Part Number
1T-1078	Bearing-Thrust	384-4802
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2K-5065	Cone-Roller Brg	416-2157

A8P		
Original Part Number	Part Name	Classic Part Number
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
2W-8494	Pulley-Alt	295-5692

Sales Model 972M (Cont'd.)

A8P		
Original Part Number	Part Name	Classic Part Number
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-3196	Pin As	361-1697
4N-2514	Gear-Flywheel	421-7283
4N-4577	Muffler As.	308-9877
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658

A8P		
Original Part Number	Part Name	Classic Part Number
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-3151	Stator-Converter	388-6562
6Y-4819	Carrier-Planet	296-1348
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-9344	Bearing-Sleeve	360-2334
7J-9731	Bearing-Sleeve	308-9822
7K-0078	Bearing-Sleeve	308-9825
7K-9639	Bearing-Sleeve	314-8643
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7V-0638	Spacer	425-3651
7V-6715	Pin As	361-1701
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8J-5778	Bearing-Sleeve	374-8359
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663

A8P		
Original Part Number	Part Name	Classic Part Number
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9M-2744	Cone-Spl Tapered	380-1480
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-7148	Cap As-Rain	378-3994
9W-8437	Gear-Sun	450-7550
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
112-8042	Carrier-Planet	390-0916
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
119-5727	Bearing-Spl Ball	417-9491
161-3411	Gasket	394-0896
213-1365	Bearing-Sleeve	330-9256
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

EDW		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1M-6573	Cup-Roller Brg	399-4438
1M-8776	Bearing-Roller	417-4516
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174

EDW		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
2W-8494	Pulley-Alt	295-5692

EDW		
Original Part Number	Part Name	Classic Part Number
3B-3967	Race-Roller Brg	386-4947
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-3196	Pin As	361-1697

Sales Model 972M (Cont'd.)

EDW		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2514	Gear-Flywheel	421-7283
4N-4577	Muffler As.	308-9877
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-1203	Cup-Rlr Brg	418-9603

EDW		
Original Part Number	**Part Name**	**Classic Part Number**
4W-2042	Spacer	325-6217
5D-6659	Bearing	417-4511
5M-6126	Bearing	377-7433
5P-6254	Bearing	420-2495
5T-5682	Driver	418-9579
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7J-9344	Bearing-Sleeve	360-2334
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7V-6715	Pin As	361-1701

EDW		
Original Part Number	**Part Name**	**Classic Part Number**
8B-8439	Bearing-Ball	399-6069
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9M-2744	Cone-Spl Tapered	380-1480
9S-7148	Cap As-Rain	378-3994
100-8010	Valve	423-5583
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
161-3411	Gasket	394-0896
213-1365	Bearing-Sleeve	330-9256

JPR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1M-6573	Cup-Roller Brg	399-4438
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0210	Bearing-Ball	417-4498
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2K-5065	Cone-Roller Brg	416-2157
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
2W-8494	Pulley-Alt	295-5692
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-3196	Pin As	361-1697
4N-2514	Gear-Flywheel	421-7283
4N-4577	Muffler As.	308-9877
4V-7099	Pin As	361-1698

JPR		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6V-4350	Race-Spl Rlr Brg	384-5933

JPR		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-3151	Stator-Converter	388-6562
6Y-4819	Carrier-Planet	296-1348
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-9344	Bearing-Sleeve	360-2334
7K-9639	Bearing-Sleeve	314-8643
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7V-0638	Spacer	425-3651
7V-6715	Pin As	361-1701
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211

Sales Model 972M (Cont'd.)

JPR		
Original Part Number	Part Name	Classic Part Number
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9M-2744	Cone-Spl Tapered	380-1480
9P-7757	Gear-Sun	283-5218

JPR		
Original Part Number	Part Name	Classic Part Number
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-7148	Cap As-Rain	378-3994
9W-8437	Gear-Sun	450-7550
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
112-8042	Carrier-Planet	390-0916

JPR		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
119-5727	Bearing-Spl Ball	417-9491
161-3411	Gasket	394-0896
213-1365	Bearing-Sleeve	330-9256
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

L8E		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1M-6573	Cup-Roller Brg	399-4438
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0210	Bearing-Ball	417-4498
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2K-5065	Cone-Roller Brg	416-2157
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
2W-8494	Pulley-Alt	295-5692
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-3196	Pin As	361-1697
4N-2514	Gear-Flywheel	421-7283
4N-4577	Muffler As.	308-9877
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527

L8E		
Original Part Number	Part Name	Classic Part Number
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-3151	Stator-Converter	388-6562
6Y-4819	Carrier-Planet	296-1348
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206

L8E		
Original Part Number	Part Name	Classic Part Number
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7V-0638	Spacer	425-3651
7V-6715	Pin As	361-1701
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9M-2744	Cone-Spl Tapered	380-1480
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-7148	Cap As-Rain	378-3994

Sales Model 972M (Cont'd.)

L8E		
Original Part Number	**Part Name**	**Classic Part Number**
9W-8437	Gear-Sun	450-7550
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
112-8042	Carrier-Planet	390-0916

L8E		
Original Part Number	**Part Name**	**Classic Part Number**
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
119-5727	Bearing-Spl Ball	417-9491
161-3411	Gasket	394-0896

L8E		
Original Part Number	**Part Name**	**Classic Part Number**
213-1365	Bearing-Sleeve	330-9256
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

LSJ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1M-6573	Cup-Roller Brg	399-4438
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1T-0210	Bearing-Ball	417-4498
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2K-5065	Cone-Roller Brg	416-2157
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
2W-8494	Pulley-Alt	295-5692
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4N-2514	Gear-Flywheel	421-7283
4N-4577	Muffler As.	308-9877
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187

LSJ		
Original Part Number	**Part Name**	**Classic Part Number**
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5D-2989	Bearing	380-7511
5K-8591	Bearing-Outer	380-7502
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-3151	Stator-Converter	388-6562
6Y-4819	Carrier-Planet	296-1348
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7V-0638	Spacer	425-3651
7V-6715	Pin As	361-1701
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088

LSJ		
Original Part Number	**Part Name**	**Classic Part Number**
8H-5352	Bearing-Ball	453-3658
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9M-2744	Cone-Spl Tapered	380-1480
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-7148	Cap As-Rain	378-3994
9W-8437	Gear-Sun	450-7550
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8041	Carrier-Planet	295-5681
112-8042	Carrier-Planet	390-0916
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
119-5727	Bearing-Spl Ball	417-9491
161-3411	Gasket	394-0896
213-1365	Bearing-Sleeve	330-9256
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model 972M (Cont'd.)

M5S		
Original Part Number	Part Name	Classic Part Number
1B-3934	Cup-Roller Brg	392-4487
1M-6573	Cup-Roller Brg	399-4438
1M-8776	Bearing-Roller	417-4516
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
2W-8494	Pulley-Alt	295-5692
3B-3967	Race-Roller Brg	386-4947
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
4B-9373	Cone-Roller Brg	399-4440

M5S		
Original Part Number	Part Name	Classic Part Number
4B-9374	Bearing-Cup	380-7494
4E-3196	Pin As	361-1697
4N-2514	Gear-Flywheel	421-7283
4N-4577	Muffler As.	308-9877
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5D-6659	Bearing	417-4511
5M-6126	Bearing	377-7433
5P-6254	Bearing	420-2495
5T-5682	Driver	418-9579
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7J-9344	Bearing-Sleeve	360-2334

M5S		
Original Part Number	Part Name	Classic Part Number
7K-0078	Bearing-Sleeve	308-9825
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7V-6715	Pin As	361-1701
8B-8439	Bearing-Ball	399-6069
8J-5778	Bearing-Sleeve	374-8359
9J-5875	Bearing-Sleeve	308-9830
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9M-2744	Cone-Spl Tapered	380-1480
9S-7148	Cap As-Rain	378-3994
100-8010	Valve	423-5583
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
161-3411	Gasket	394-0896
213-1365	Bearing-Sleeve	330-9256

M8W		
Original Part Number	Part Name	Classic Part Number
7J-9344	Bearing-Sleeve	360-2334
7K-9639	Bearing-Sleeve	314-8643

Sales Model 980

42H		
Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As-Filler	311-9368
1A-9252	Rod End-Yoke	377-5849
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1P-1367	Plunger-Valve	432-8913

42H		
Original Part Number	Part Name	Classic Part Number
1P-4110	Disc-Friction	433-9858
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
1S-8754	Joint Gp-Univ	308-9873
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464

42H		
Original Part Number	Part Name	Classic Part Number
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1V-4838	Link As-Spring	308-9874
2A-4429	Lock-Retainer	379-0174
2D-9130	Washer-Thrust	308-9943
2F-5721	Bearing-Ball	311-9354

Sales Model 980 (Cont'd.)

42H		
Original Part Number	**Part Name**	**Classic Part Number**
2J-5649	Pin-Cylinder	256-4782
2K-4442	Bearing-Sleeve	308-9812
2K-4507	Bearing-Sleeve	325-6021
2K-4513	Bearing-Sleeve	308-9814
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2S-6097	Tang	375-9979
2V-4374	Joint Gp-Slip	308-9872
3B-4124	Cup-Spl Tapered	422-6481
3D-5315	Pinion-Dif Bevel	308-9856
3F-4971	Pin	295-5693
3G-7657	Cartridge Gp	422-8101
3G-7662	Cartridge Gp	422-8105
3H-8726	Mount As	385-7208
3K-0963	Pin-Lock	308-9895
3K-2511	Dowel-Reaction	383-2126
3K-4290	Rod End	374-1823
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
3S-8055	Bearing-Inner	433-7506
3S-9466	Bearing-Sleeve	314-8509
4J-1612	Pin	308-9896
4K-0299	Bearing-Sleeve	308-9816
4K-0300	Bearing-Sleeve	308-9817
4K-1102	Bearing-Sleeve	325-6010
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4S-5891	Plate-Clutch	388-0575
4W-5363	Core Gp-O Clr	380-7531
5D-0470	Valve Gp-Qrel	314-8549
5F-2830	Bearing-Needle	384-5925

42H		
Original Part Number	**Part Name**	**Classic Part Number**
5F-7404	Nut-Bearing Lock	308-9878
5F-8651	Bearing-Ball	420-3223
5G-3612	Cap Gp-Protn	295-6419
5K-2294	Bearing	396-9912
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3493	Cover	391-9814
5K-3495	Collar	383-2129
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-3929	Bearing As-Rlr	416-2163
5K-3967	Yoke As	308-9946
5K-3968	Cage-Bearing	308-9804
5K-4079	Cage-Bearing	308-9805
5K-4268	Retainer-Bearing	308-9916
5K-4273	Bearing-Sleeve	374-1461
5K-4787	Bearing-Sleeve	308-9819
5K-7995	Bearing-Sleeve	308-9820
5M-2051	Bearing-Caged	380-7467
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
6H-3957	Bearing-Ball	311-9358
6K-2034	Shaft	297-7249
6K-4442	Rod End-Special	373-5388
6K-6001	Pin	308-9902
6P-6739	Shaft-Planet	308-9929
6V-2202	Bearing-Spl Ball	380-1574
6W-7290	Shaft-Planet	308-9930
6Y-5348	Disc-Friction	384-4827
7E-5085	Bushing	377-5829
7F-2742	Bearing-Ball	422-6488
7H-6967	Bearing-Ball	422-6489
7J-9344	Bearing-Sleeve	360-2334

42H		
Original Part Number	**Part Name**	**Classic Part Number**
7J-9707	Bearing-Sleeve	308-9821
7J-9708	Bearing-Sleeve	299-1964
7J-9731	Bearing-Sleeve	308-9822
7J-9814	Bearing-Sleeve	308-9824
7K-0078	Bearing-Sleeve	308-9825
7K-1510	Washer-Thrust	330-9295
7K-1512	Cover	469-8101
7K-9528	Bearing-Sleeve	308-9828
7K-9604	Bearing-Sleeve	308-9829
7K-9981	Pin As	308-9887
7K-9988	Pin	308-9904
7K-9989	Pin	308-9905
7K-9990	Pin	308-9906
7M-7219	Bearing-Thrust	384-4816
7N-2957	Cover-Rad Cap	361-1722
7N-7386	Gasket-Cyl Head	392-4519
7N-9146	Gear-Fly Starter	279-4995
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7W-1927	Ring-Retainer	387-2935
8F-6058	Bearing-Sleeve	416-5494
8F-9365	Pin	319-3463
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-4445	Pipe-Exhaust Ext	386-3061
8P-4520	Piston-Clutch	394-0908
8S-9151	Cup-Spl Tapered	374-8348
8S-9686	Gasket Kit	393-5215
9M-8395	Bearing-Sleeve	391-1103

Sales Model 980 (Cont'd.)

42H		
Original Part Number	Part Name	Classic Part Number
9S-9696	Spider As-Fan	383-3707
9T-2200	Cartridgr Gp	422-8114
9V-7710	Univ Joint As	394-8234
9V-7860	Support As-Front	308-9938

42H		
Original Part Number	Part Name	Classic Part Number
121-7746	Pre-Cleaner As	360-2311
149-5985	Stator-Converter	419-1865
161-9082	Gasket Kit	434-7277

42H		
Original Part Number	Part Name	Classic Part Number
190-3832	Core As-Oclr	438-3251
308-1845	Seal-Wiper	472-8032
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442

Sales Model 980B

89P		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1P-1367	Plunger-Valve	432-8913
1P-4110	Disc-Friction	433-9858
1P-4303	Head As-Cylinder	242-3434
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-8754	Joint Gp-Univ	308-9873
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0767	Bearing-Sleeve	383-2108
1T-1078	Bearing-Thrust	384-4802
1V-4838	Link As-Spring	308-9874
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-7082	Rebuild Kt-Pump	383-3681
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174

89P		
Original Part Number	Part Name	Classic Part Number
2D-9130	Washer-Thrust	308-9943
2F-5721	Bearing-Ball	311-9354
2J-5649	Pin-Cylinder	256-4782
2K-4442	Bearing-Sleeve	308-9812
2K-4507	Bearing-Sleeve	325-6021
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2S-4015	Plunger As-Valve	311-9438
2S-5551	Coupling-Exhaust	398-2934
2S-6097	Tang	375-9979
2V-3687	Gear-Diff Bevel	308-9849
2V-4374	Joint Gp-Slip	308-9872

89P		
Original Part Number	Part Name	Classic Part Number
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3B-4124	Cup-Spl Tapered	422-6481
3D-5315	Pinion-Dif Bevel	308-9856
3F-4971	Pin	295-5693
3G-7662	Cartridge Gp	422-8105
3H-8726	Mount As	385-7208
3K-0963	Pin-Lock	308-9895
3K-2511	Dowel-Reaction	383-2126
3K-4290	Rod End	374-1823
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3S-1262	Retainer	308-9915
3S-3875	Screen-Suction	435-4849
3S-5017	Elbow-Exhaust	369-9498
3S-8055	Bearing-Inner	433-7506
3V-7427	Housing As	297-7197
4J-1612	Pin	308-9896
4K-0299	Bearing-Sleeve	308-9816
4K-0300	Bearing-Sleeve	308-9817
4K-1102	Bearing-Sleeve	325-6010

Sales Model 980B (Cont'd.)

89P		
Original Part Number	**Part Name**	**Classic Part Number**
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-4577	Muffler As.	308-9877
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-8814	Line As-F Inj	247-3366
4P-3546	Valve As-Relief	325-6236
4P-8915	Gasket-Cyl Head	377-5838
4S-5891	Plate-Clutch	388-0575
4S-8472	Hood As-Preclnr	296-1355
4V-3044	Plate-Lock	308-9911
4W-0452	Seal As -Cshaft	325-6191
5D-0470	Valve Gp-Qrel	314-8549
5F-2830	Bearing-Needle	384-5925
5F-7404	Nut-Bearing Lock	308-9878
5G-3612	Cap Gp-Protn	295-6419
5K-2294	Bearing	396-9912
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3493	Cover	391-9814
5K-3495	Collar	383-2129
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-3929	Bearing As-Rlr	416-2163
5K-3967	Yoke As	308-9946
5K-3968	Cage-Bearing	308-9804
5K-4079	Cage-Bearing	308-9805
5K-4268	Retainer-Bearing	308-9916

89P		
Original Part Number	**Part Name**	**Classic Part Number**
5K-4273	Bearing-Sleeve	374-1461
5K-4787	Bearing-Sleeve	308-9819
5K-7995	Bearing-Sleeve	308-9820
5L-6326	Bearing-Ball	420-3222
5M-2051	Bearing-Caged	380-7467
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2034	Shaft	297-7249
6K-4442	Rod End-Special	373-5388
6K-6001	Pin	308-9902
6N-1036	Gear-Oil Pump	279-4991
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-5482	Plate-Friction	376-3637
6N-7174	Shield-Oil	314-8544
6N-7263	Gasket-Cyl Head	380-7386

89P		
Original Part Number	**Part Name**	**Classic Part Number**
6P-6739	Shaft-Planet	308-9929
6V-2202	Bearing-Spl Ball	380-1574
6V-2580	Gasket Kt-V G	393-3637
6W-7290	Shaft-Planet	308-9930
6Y-5348	Disc-Friction	384-4827
6Y-5916	Disc-Friction	377-7442
7C-3862	Camshaft	458-0151
7C-4297	Seal As-Cshaft	325-6192
7E-5085	Bushing	377-5829
7E-8926	Head Kt-Cyl	377-5847
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7J-9344	Bearing-Sleeve	360-2334
7J-9707	Bearing-Sleeve	308-9821
7J-9708	Bearing-Sleeve	299-1964
7J-9731	Bearing-Sleeve	308-9822
7J-9814	Bearing-Sleeve	308-9824
7K-0078	Bearing-Sleeve	308-9825
7K-1510	Washer-Thrust	330-9295
7K-1512	Cover	469-8101
7K-9528	Bearing-Sleeve	308-9828
7K-9604	Bearing-Sleeve	308-9829
7K-9981	Pin As	308-9887
7K-9988	Pin	308-9904
7K-9989	Pin	308-9905
7K-9990	Pin	308-9906
7M-2167	Ring-Gov Cont	308-9919
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780

Sales Model 980B (Cont'd.)

89P		
Original Part Number	Part Name	Classic Part Number
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3536	Gear-Fuel	279-4993
7N-5511	Gear As-Idler	233-2180
7N-5910	Impeller-Pump	314-8686
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-1234	Bushing As-Spt	394-0192
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7809	Cap As-Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8C-8741	Kit-Gasket-(Rs)	438-0172
8F-6058	Bearing-Sleeve	416-5494
8F-9365	Pin	319-3463
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-3368	Valve-Check	388-6599
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435

89P		
Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9733	Line As-F Inj	319-8174
8P-4520	Piston-Clutch	394-0908
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-2389	Body-Fuel Valve	377-5831
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8S-7716	Manifold-Exhaust	295-0415

89P		
Original Part Number	Part Name	Classic Part Number
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-9151	Cup-Spl Tapered	374-8348
9B-1320	Valve-Check	377-5832
9H-2256	Pump Gp-F Prm	311-9443
9H-5797	Plunger As-Pump	391-9891
9M-4789	Shaft-Gov Cont	297-7256
9M-5477	Bearing-Sleeve	374-6517
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5769	Cover-Housing	325-6050
9S-6129	Pulley-Alt Drive	264-5891
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9S-9696	Spider As-Fan	383-3707
9V-7710	Univ Joint As	394-8234
9V-7860	Support As-Front	308-9938
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
161-9082	Gasket Kit	434-7277
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0556	Kit-Rebuild-Pump	383-3712
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

Sales Model 980B (Cont'd.)

89P		
Original Part Number	**Part Name**	**Classic Part Number**
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646

89P		
Original Part Number	**Part Name**	**Classic Part Number**
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
250-6557	Liner Kit-Cla	295-6438

89P		
Original Part Number	**Part Name**	**Classic Part Number**
250-6558	Liner Kit-Cla	295-6438
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442

Sales Model 980C

13B		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916
1U-3522	Rod As	390-5281
1V-6342	Gear As	308-9847
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809

13B		
Original Part Number	**Part Name**	**Classic Part Number**
1V-8280	Plate	382-6889
1V-8439	Pin As	308-9881
1V-8604	Gear-Ring	308-9853
1V-8606	Gear-Sun	308-9860
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8953	Pin	308-9892
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

13B		
Original Part Number	**Part Name**	**Classic Part Number**
2D-5658	Bearing-Ball	301-4628
2D-9130	Washer-Thrust	308-9943
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2H-6489	Race-Brg Outer	374-8350
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-5680	Turbine-Conv	308-9942
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2V-3687	Gear-Diff Bevel	308-9849
2V-4374	Joint Gp-Slip	308-9872
2V-4700	Pin	308-9894
2V-7170	Yoke	308-9948
2V-7990	Tube As	373-5382
2W-7455	Gear As	396-9957

Sales Model 980C (Cont'd.)

13B		
Original Part Number	**Part Name**	**Classic Part Number**
3D-5315	Pinion-Dif Bevel	308-9856
3E-6772	Seal-Water	382-8017
3E-7466	Gasket Kit	393-3615
3G-0222	Bearing-Sleeve	374-6512
3G-1305	Cyl Gp-159 586 Y	430-5966
3G-2665	Cover	308-9842
3G-2858	Pump Gp-Gr A	424-7054
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3P-2414	Housing-Clutch	391-9831
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3246	Shaft-Planet	308-9925
3P-3429	Cage-Bearing	452-0430
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-8186	Housing-Screen	390-5261
3P-9366	Piston-Clutch	391-9861
3S-1262	Retainer	308-9915
3S-9669	Bearing	416-2168
3T-2139	Housing As-Cl	394-2583
3T-4384	Housing As-Cl	435-2573
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350
3V-3855	Housing-Brg Spt	375-9980
3V-6515	Link As	394-0186
3V-6648	Pin As	308-9884
3V-6697	Housing	424-4944

13B		
Original Part Number	**Part Name**	**Classic Part Number**
3V-7065	Plate	380-1487
4C-1335	Washer-Thrust	399-4425
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4F-2041	Cup-Roller Brg	418-9609
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1767	Valve-Bypass	419-4716
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-2954	Sleeve-Camshaft	299-2059
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-9311	Housing	396-0652
4V-2057	Bearing-Spher	419-6019
4V-2518	Shaft	297-7243

13B		
Original Part Number	**Part Name**	**Classic Part Number**
4V-3044	Plate-Lock	308-9911
4V-3680	Bellcrank	308-9802
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-8611	Yoke As	418-9567
4V-8674	Bearing-Sleeve	307-1529
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-7382	Core As-Oclr	380-1514
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5F-7404	Nut-Bearing Lock	308-9878
5J-1192	Bearing-Sleeve	374-8355
5K-0609	Cover	308-9843
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-3967	Yoke As	308-9946
5K-3968	Cage-Bearing	308-9804
5K-4079	Cage-Bearing	308-9805
5K-4268	Retainer-Bearing	308-9916
5K-4273	Bearing-Sleeve	374-1461
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917

Sales Model 980C (Cont'd.)

13B		
Original Part Number	**Part Name**	**Classic Part Number**
5P-5410	Bearing-Spl Ball	396-4134
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9301	Bearing-Spl Ball	417-4496
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-6125	Diaphragm	384-5931
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-2687	Spider As.-Fan	385-7199
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6N-9743	Support-Muffler	308-9940
6P-0593	Bearing-Roller	386-4959
6P-2090	Base-Xmsn O Fil	397-5049
6P-2923	Yoke As	382-6891
6P-6739	Shaft-Planet	308-9929
6P-7357	Gear As-Pump	388-0561
6P-7358	Pump Gp-Gr 1 Bsc	308-9913

13B		
Original Part Number	**Part Name**	**Classic Part Number**
6P-7564	Carrier-Ring	384-3850
6P-7704	Carrier-Ring	314-8658
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-4281	Yoke-Flange	308-9949
6W-4284	Cage-Bearing	308-9832
6W-4733	Retainer-Bearing	391-1089
6W-4789	Shaft Gp-Drive-D	452-0444
6W-7290	Shaft-Planet	308-9930
6Y-1603	Housing-Clutch	438-1818
6Y-1604	Carrier As	468-9790
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206

13B		
Original Part Number	**Part Name**	**Classic Part Number**
7H-7628	Bearing	453-3655
7J-8893	Cone-Roller Brg	374-1846
7K-1510	Washer-Thrust	330-9295
7K-1512	Cover	469-8101
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7N-1393	Muffler As	374-7477
7N-1572	Cover-Water Pump	377-5854
7N-1760	Ejector As	373-1914
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-8371	Line As-Fuel Inj	373-1901
7N-9674	Muffler As	360-7892
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6790	Shaft-Bev Pinion	308-9922
7W-0140	Gear-Drive	399-8546
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439

Sales Model 980C (Cont'd.)

13B		
Original Part Number	Part Name	Classic Part Number
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077
8N-9622	Bracket As-Fan	433-2024
8P-0514	Yoke As	308-9947
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-4047	Shaft-Planet	373-5390
8P-9507	Piston-Clutch	283-5212
8R-3921	Collet	308-9839
8R-3943	Collet	308-9840
8R-3946	Collet	308-9841
8R-4184	Bearing-Sleeve	374-6515
8R-4821	Carrier-Planet	308-9837
8R-7425	Retainer	308-9917
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
8V-3550	Rim As	417-9477
8V-6382	Hub As	308-9868
8V-6384	Spacer As	308-9935
9B-1320	Valve-Check	377-5832
9C-0624	Pin As.	361-1709
9C-0625	Pin As	308-9888
9C-2249	Yoke As	382-6890
9C-3530	Joint Gp-Univ	449-9832
9C-8074	Gear-Planet	308-9858
9C-8075	Gear-Sun	308-9864
9C-8278	Case As-Diff	423-6984

13B		
Original Part Number	Part Name	Classic Part Number
9C-8986	Collet As	374-6502
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1919	Gear-Planet	371-4307
9G-6744	Bearing-Sleeve	418-1931
9J-5875	Bearing-Sleeve	308-9830
9J-8006	Piston	449-4736
9K-5639	Pin	425-6451
9K-8428	Pin As	241-2533
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-5529	Body-F Inj Valve	378-3993
9P-5531	Gear-Sun	417-9499
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-5279	Bearing-Inner	453-3661
9S-8597	Spring	399-8561
9T-5360	Plate-Pressure	424-4941
9U-0971	Gear-Sun	368-0124
9U-0974	Bushing-Sleeve	374-1460
9U-0975	Hub As	390-5259
9V-0247	Plate	417-4527
9V-6165	Plate-Outer	377-7460
9V-7710	Univ Joint As	394-8234
9V-7860	Support As-Front	308-9938
9W-2977	Hub As	423-6985
9W-4175	Shaft-Xmsn Input	394-8241
9W-4702	Stator-Converter	308-9939

13B		
Original Part Number	Part Name	Classic Part Number
9W-5768	Gear-Ring	380-7474
9W-6433	Impeller-Conv	308-9871
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-7019	Disc-Friction	377-7461
9W-7040	Piston-Clutch	377-7462
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9Y-1917	Pulley-Fan	395-1311
9Y-2988	Breather As	361-1716
9Y-3318	Core As-Radiator	374-7491
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-4563	Gear-Transfer	399-4430
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
106-7798	Bearing-Ball	417-9494
108-2102	Bonnet-Valve	455-3274
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8041	Carrier-Planet	295-5681

Sales Model 980C (Cont'd.)

13B		
Original Part Number	**Part Name**	**Classic Part Number**
114-0468	Pin-G.E.T.	443-1203
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
120-3861	Bracket As	415-1897
121-7583	Gear-Planet	364-5257
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
139-9172	Gasket Kit	384-5964
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
145-8503	Shaft As-Idler	426-0035

13B		
Original Part Number	**Part Name**	**Classic Part Number**
147-1900	Gasket Kit	447-0826
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
164-4891	Plate As.	391-1093
165-5634	Shaft As.-Output	421-7067
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701

13B		
Original Part Number	**Part Name**	**Classic Part Number**
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
197-5510	Support As	419-0880
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
241-1397	Kit-Dt Gasket	434-7286
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
374-1849	Brg-Rlr-Cla	399-4442
430-7619	Adapter-Cla	438-1812

2EB		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-7125	Governor As	383-3672
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802

2EB		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1534	Carrier-Ring	386-4916
1U-3522	Rod As	390-5281
1V-6342	Gear As	308-9847
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8280	Plate	382-6889
1V-8439	Pin As	308-9881
1V-8604	Gear-Ring	308-9853
1V-8606	Gear-Sun	308-9860
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882

2EB		
Original Part Number	**Part Name**	**Classic Part Number**
1V-8949	Pin As	308-9883
1V-8953	Pin	308-9892
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059

Sales Model 980C (Cont'd.)

2EB		
Original Part Number	Part Name	Classic Part Number
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9130	Washer-Thrust	308-9943
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-6489	Race-Brg Outer	374-8350
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-5680	Turbine-Conv	308-9942
2S-6150	Cover-Pulley	428-8817
2V-3687	Gear-Diff Bevel	308-9849
2V-4374	Joint Gp-Slip	308-9872
2V-4700	Pin	308-9894
2V-7170	Yoke	308-9948
2V-7990	Tube As	373-5382
2W-3391	Body As-F Inj V	383-3687
2W-7455	Gear As	396-9957
3D-5315	Pinion-Dif Bevel	308-9856
3E-6772	Seal-Water	382-8017
3G-1305	Cyl Gp-159 586 Y	430-5966
3G-2665	Cover	308-9842
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3P-2685	Piston-Clutch	308-9908
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3245	Shaft-Planet	308-9924
3P-3429	Cage-Bearing	452-0430
3P-3505	Shaft-Brake	384-3477
3P-7489	Plate-Clutch	377-7423
3P-8186	Housing-Screen	390-5261

2EB		
Original Part Number	Part Name	Classic Part Number
3S-1262	Retainer	308-9915
3S-9669	Bearing	416-2168
3T-2139	Housing As-Cl	394-2583
3T-4384	Housing As-Cl	435-2573
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350
3V-3855	Housing-Brg Spt	375-9980
3V-6515	Link As	394-0186
3V-6648	Pin As	308-9884
3V-6697	Housing	424-4944
3V-7065	Plate	380-1487
4C-1335	Washer-Thrust	399-4425
4D-2619	Bearing	417-4494
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4F-2041	Cup-Roller Brg	418-9609
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-2954	Sleeve-Camshaft	299-2059
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216

2EB		
Original Part Number	Part Name	Classic Part Number
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-9311	Housing	396-0652
4V-2518	Shaft	297-7243
4V-3044	Plate-Lock	308-9911
4V-3680	Bellcrank	308-9802
4V-7099	Pin As	361-1698
4V-8611	Yoke As	418-9567
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-7382	Core As-Oclr	380-1514
5D-2989	Bearing	380-7511
5F-7404	Nut-Bearing Lock	308-9878
5K-0609	Cover	308-9843
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-3967	Yoke As	308-9946
5K-3968	Cage-Bearing	308-9804
5K-4079	Cage-Bearing	308-9805
5K-4268	Retainer-Bearing	308-9916
5K-4273	Bearing-Sleeve	374-1461
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917

Sales Model 980C (Cont'd.)

2EB		
Original Part Number	**Part Name**	**Classic Part Number**
5P-5410	Bearing-Spl Ball	396-4134
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9301	Bearing-Spl Ball	417-4496
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-2687	Spider As.-Fan	385-7199
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6N-9743	Support-Muffler	308-9940
6P-2923	Yoke As	382-6891
6P-6739	Shaft-Planet	308-9929
6P-7357	Gear As-Pump	388-0561
6P-7358	Pump Gp-Gr 1 Bsc	308-9913
6P-7564	Carrier-Ring	384-3850
6P-7704	Carrier-Ring	314-8658

2EB		
Original Part Number	**Part Name**	**Classic Part Number**
6V-1033	Rod End-Spher	375-5444
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-7290	Shaft-Planet	308-9930
6Y-1603	Housing-Clutch	438-1818
6Y-1604	Carrier As	468-9790
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-8893	Cone-Roller Brg	374-1846
7K-1510	Washer-Thrust	330-9295
7K-1512	Cover	469-8101
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7N-1183	Plunger As-Fuel	419-4742

2EB		
Original Part Number	**Part Name**	**Classic Part Number**
7N-1220	Plunger As-Pump	419-4743
7N-1393	Muffler As	374-7477
7N-1572	Cover-Water Pump	377-5854
7N-1760	Ejector As	373-1914
7N-2156	Bearing-Sleeve	380-7373
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-8371	Line As-Fuel Inj	373-1901
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7V-6790	Shaft-Bev Pinion	308-9922
7W-0140	Gear-Drive	399-8546
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464

Sales Model 980C (Cont'd.)

2EB		
Original Part Number	Part Name	Classic Part Number
8N-5579	Retainer	425-3451
8N-8258	Bearing-Sleeve	452-1077
8N-9622	Bracket As-Fan	433-2024
8P-0514	Yoke As	308-9947
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-4047	Shaft-Planet	373-5390
8P-9507	Piston-Clutch	283-5212
8R-3921	Collet	308-9839
8R-3943	Collet	308-9840
8R-3946	Collet	308-9841
8R-4184	Bearing-Sleeve	374-6515
8R-4821	Carrier-Planet	308-9837
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-3550	Rim As	417-9477
8V-6382	Hub As	308-9868
8V-6384	Spacer As	308-9935
9B-1320	Valve-Check	377-5832
9C-0624	Pin As.	361-1709
9C-8074	Gear-Planet	308-9858
9C-8075	Gear-Sun	308-9864
9C-8278	Case As-Diff	423-6984
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1919	Gear-Planet	371-4307
9G-6744	Bearing-Sleeve	418-1931
9J-5875	Bearing-Sleeve	308-9830
9K-5639	Pin	425-6451
9K-8757	Rod End-Special	311-9361

2EB		
Original Part Number	Part Name	Classic Part Number
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9P-5531	Gear-Sun	417-9499
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-5279	Bearing-Inner	453-3661
9S-8597	Spring	399-8561
9T-5360	Plate-Pressure	424-4941
9U-0971	Gear-Sun	368-0124
9U-0974	Bushing-Sleeve	374-1460
9U-0975	Hub As	390-5259
9V-0247	Plate	417-4527
9V-6165	Plate-Outer	377-7460
9V-7710	Univ Joint As	394-8234
9V-7860	Support As-Front	308-9938
9W-2977	Hub As	423-6985
9W-4702	Stator-Converter	308-9939
9W-5768	Gear-Ring	380-7474
9W-6433	Impeller-Conv	308-9871
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-7019	Disc-Friction	377-7461
9W-7040	Piston-Clutch	377-7462
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9Y-1917	Pulley-Fan	395-1311
9Y-2988	Breather As	361-1716
9Y-3318	Core As-Radiator	374-7491
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552

2EB		
Original Part Number	Part Name	Classic Part Number
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-4563	Gear-Transfer	399-4430
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
106-7798	Bearing-Ball	417-9494
108-2102	Bonnet-Valve	455-3274
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8041	Carrier-Planet	295-5681
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
120-3861	Bracket As	415-1897
121-7583	Gear-Planet	364-5257
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
144-0482	Gasket	420-8547

Sales Model 980C (Cont'd.)

2EB		
Original Part Number	**Part Name**	**Classic Part Number**
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
147-1900	Gasket Kit	447-0826
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
165-5634	Shaft As.-Output	421-7067
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956

2EB		
Original Part Number	**Part Name**	**Classic Part Number**
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
217-0578	Bearing-Rod	419-4665

2EB		
Original Part Number	**Part Name**	**Classic Part Number**
217-0586	Bearing-Rod	419-7266
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
241-1397	Kit-Dt Gasket	434-7286
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
343-4836	Mount As	424-6369
374-1849	Brg-Rlr-Cla	399-4442
430-7619	Adapter-Cla	438-1812

2XD		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916
1U-3522	Rod As	390-5281
1V-6342	Gear As	308-9847
1V-8240	Bearing-Sleeve	308-9807

2XD		
Original Part Number	**Part Name**	**Classic Part Number**
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8280	Plate	382-6889
1V-8439	Pin As	308-9881
1V-8604	Gear-Ring	308-9853
1V-8606	Gear-Sun	308-9860
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8953	Pin	308-9892
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569

2XD		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9130	Washer-Thrust	308-9943
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-6489	Race-Brg Outer	374-8350
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357

Sales Model 980C (Cont'd.)

2XD		
Original Part Number	Part Name	Classic Part Number
2P-5680	Turbine-Conv	308-9942
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2V-3687	Gear-Diff Bevel	308-9849
2V-4374	Joint Gp-Slip	308-9872
2V-4700	Pin	308-9894
2V-7170	Yoke	308-9948
2V-7990	Tube As	373-5382
2W-7455	Gear As	396-9957
3D-5315	Pinion-Dif Bevel	308-9856
3E-6772	Seal-Water	382-8017
3E-7466	Gasket Kit	393-3615
3G-1305	Cyl Gp-159 586 Y	430-5966
3G-2665	Cover	308-9842
3G-2858	Pump Gp-Gr A	424-7054
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3P-2414	Housing-Clutch	391-9831
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3246	Shaft-Planet	308-9925
3P-3429	Cage-Bearing	452-0430
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-8186	Housing-Screen	390-5261
3P-9366	Piston-Clutch	391-9861
3S-1262	Retainer	308-9915
3S-9669	Bearing	416-2168
3T-2139	Housing As-Cl	394-2583

2XD		
Original Part Number	Part Name	Classic Part Number
3T-4384	Housing As-Cl	435-2573
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350
3V-3855	Housing-Brg Spt	375-9980
3V-6515	Link As	394-0186
3V-6648	Pin As	308-9884
3V-6697	Housing	424-4944
3V-7065	Plate	380-1487
4C-1335	Washer-Thrust	399-4425
4D-2619	Bearing	417-4494
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4F-2041	Cup-Roller Brg	418-9609
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1767	Valve-Bypass	419-4716
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-2954	Sleeve-Camshaft	299-2059
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-0897	Core As-Radiator	376-9058
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216

2XD		
Original Part Number	Part Name	Classic Part Number
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-9311	Housing	396-0652
4V-2518	Shaft	297-7243
4V-3044	Plate-Lock	308-9911
4V-3680	Bellcrank	308-9802
4V-7099	Pin As	361-1698
4V-8611	Yoke As	418-9567
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5363	Core Gp-O Clr	380-7531
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-7382	Core As-Oclr	380-1514
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5F-7404	Nut-Bearing Lock	308-9878
5K-0609	Cover	308-9843
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-3967	Yoke As	308-9946
5K-3968	Cage-Bearing	308-9804
5K-4079	Cage-Bearing	308-9805
5K-4268	Retainer-Bearing	308-9916
5K-4273	Bearing-Sleeve	374-1461
5M-2054	Bearing	380-7510

Sales Model 980C (Cont'd.)

2XD		
Original Part Number	**Part Name**	**Classic Part Number**
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9301	Bearing-Spl Ball	417-4496
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-2687	Spider As.-Fan	385-7199
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6N-9743	Support-Muffler	308-9940
6P-0593	Bearing-Roller	386-4959

2XD		
Original Part Number	**Part Name**	**Classic Part Number**
6P-2090	Base-Xmsn O Fil	397-5049
6P-2923	Yoke As	382-6891
6P-6739	Shaft-Planet	308-9929
6P-7357	Gear As-Pump	388-0561
6P-7358	Pump Gp-Gr 1 Bsc	308-9913
6P-7564	Carrier-Ring	384-3850
6P-7704	Carrier-Ring	314-8658
6V-1033	Rod End-Spher	375-5444
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-9221	Gasket Kit	391-1092
6W-4281	Yoke-Flange	308-9949
6W-4284	Cage-Bearing	308-9832
6W-4733	Retainer-Bearing	391-1089
6W-4789	Shaft Gp-Drive-D	452-0444
6W-7290	Shaft-Planet	308-9930
6Y-1603	Housing-Clutch	438-1818
6Y-1604	Carrier As	468-9790
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847

2XD		
Original Part Number	**Part Name**	**Classic Part Number**
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-8893	Cone-Roller Brg	374-1846
7K-1510	Washer-Thrust	330-9295
7K-1512	Cover	469-8101
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7N-1393	Muffler As	374-7477
7N-1572	Cover-Water Pump	377-5854
7N-1760	Ejector As	373-1914
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-8371	Line As-Fuel Inj	373-1901
7N-9674	Muffler As	360-7892
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7V-6790	Shaft-Bev Pinion	308-9922
7W-0140	Gear-Drive	399-8546
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494

Sales Model 980C (Cont'd.)

2XD		
Original Part Number	Part Name	Classic Part Number
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077
8N-9622	Bracket As-Fan	433-2024
8P-0514	Yoke As	308-9947
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-4047	Shaft-Planet	373-5390
8P-9507	Piston-Clutch	283-5212
8R-3921	Collet	308-9839
8R-3943	Collet	308-9840
8R-3946	Collet	308-9841
8R-4184	Bearing-Sleeve	374-6515
8R-4821	Carrier-Planet	308-9837
8R-7425	Retainer	308-9917
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
8V-3550	Rim As	417-9477

2XD		
Original Part Number	Part Name	Classic Part Number
8V-6382	Hub As	308-9868
8V-6384	Spacer As	308-9935
9B-1320	Valve-Check	377-5832
9C-0624	Pin As.	361-1709
9C-0625	Pin As	308-9888
9C-2249	Yoke As	382-6890
9C-3530	Joint Gp-Univ	449-9832
9C-8074	Gear-Planet	308-9858
9C-8075	Gear-Sun	308-9864
9C-8278	Case As-Diff	423-6984
9C-8986	Collet As	374-6502
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1919	Gear-Planet	371-4307
9G-6744	Bearing-Sleeve	418-1931
9J-5875	Bearing-Sleeve	308-9830
9K-5639	Pin	425-6451
9K-8428	Pin As	241-2533
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-5529	Body-F Inj Valve	378-3993
9P-5531	Gear-Sun	417-9499
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-5279	Bearing-Inner	453-3661
9S-8597	Spring	399-8561
9T-5360	Plate-Pressure	424-4941
9U-0971	Gear-Sun	368-0124
9U-0974	Bushing-Sleeve	374-1460

2XD		
Original Part Number	Part Name	Classic Part Number
9U-0975	Hub As	390-5259
9V-0247	Plate	417-4527
9V-6165	Plate-Outer	377-7460
9V-7710	Univ Joint As	394-8234
9V-7860	Support As-Front	308-9938
9W-2977	Hub As	423-6985
9W-4175	Shaft-Xmsn Input	394-8241
9W-4702	Stator-Converter	308-9939
9W-5768	Gear-Ring	380-7474
9W-6433	Impeller-Conv	308-9871
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-7019	Disc-Friction	377-7461
9W-7040	Piston-Clutch	377-7462
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9Y-1917	Pulley-Fan	395-1311
9Y-2988	Breather As	361-1716
9Y-3318	Core As-Radiator	374-7491
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-4563	Gear-Transfer	399-4430
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
106-7798	Bearing-Ball	417-9494
108-2102	Bonnet-Valve	455-3274
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276

Sales Model 980C (Cont'd.)

2XD		
Original Part Number	**Part Name**	**Classic Part Number**
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8041	Carrier-Planet	295-5681
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
120-3861	Bracket As	415-1897
121-7583	Gear-Planet	364-5257
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813

2XD		
Original Part Number	**Part Name**	**Classic Part Number**
139-9172	Gasket Kit	384-5964
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
145-8503	Shaft As-Idler	426-0035
147-1900	Gasket Kit	447-0826
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
164-4891	Plate As.	391-1093
165-5634	Shaft As.-Output	421-7067
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-3832	Core As-Oclr	438-3251
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701

2XD		
Original Part Number	**Part Name**	**Classic Part Number**
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
197-5510	Support As	419-0880
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-6574	Kit-Gasket-Rs	437-2034
232-6599	Kit-Gasket (Mch)	437-2033
233-9748	Disc-Friction	417-9502
234-1874	Kit-Gasket-Fs	437-8668
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
241-1397	Kit-Dt Gasket	434-7286
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
374-1849	Brg-Rlr-Cla	399-4442
430-7619	Adapter-Cla	438-1812

63X		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-8736	Cup-Roller Brg	423-7759
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114

63X		
Original Part Number	**Part Name**	**Classic Part Number**
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803

63X		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916
1U-3522	Rod As	390-5281
1V-6342	Gear As	308-9847
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8280	Plate	382-6889
1V-8439	Pin As	308-9881

Sales Model 980C (Cont'd.)

63X		
Original Part Number	Part Name	Classic Part Number
1V-8604	Gear-Ring	308-9853
1V-8606	Gear-Sun	308-9860
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8953	Pin	308-9892
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5036	Bracket As-Fan	425-1210
1W-5300	Rotocoil As	443-2659
1W-5910	Tappet As-Guide&	383-1569
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9171	Bonnet-Valve	374-4707
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9130	Washer-Thrust	308-9943
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-6489	Race-Brg Outer	374-8350
2K-5103	Cone-Roller Brg	380-7505

63X		
Original Part Number	Part Name	Classic Part Number
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-5680	Turbine-Conv	308-9942
2P-6245	Shaft As-Pump	325-6197
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2V-3687	Gear-Diff Bevel	308-9849
2V-4374	Joint Gp-Slip	308-9872
2V-4700	Pin	308-9894
2V-7170	Yoke	308-9948
2V-7198	Pilot As-Rec Spg	302-2709
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-3391	Body As-F Inj V	383-3687
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7455	Gear As	396-9957
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8494	Pulley-Alt	295-5692
3D-5315	Pinion-Dif Bevel	308-9856

63X		
Original Part Number	Part Name	Classic Part Number
3E-6772	Seal-Water	382-8017
3E-7466	Gasket Kit	393-3615
3G-1305	Cyl Gp-159 586 Y	430-5966
3G-2665	Cover	308-9842
3G-2858	Pump Gp-Gr A	424-7054
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3K-4290	Rod End	374-1823
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3P-2414	Housing-Clutch	391-9831
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3246	Shaft-Planet	308-9925
3P-3429	Cage-Bearing	452-0430
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-8186	Housing-Screen	390-5261
3P-9366	Piston-Clutch	391-9861
3S-1262	Retainer	308-9915
3S-9669	Bearing	416-2168
3T-2139	Housing As-Cl	394-2583
3T-4384	Housing As-Cl	435-2573
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350
3V-3855	Housing-Brg Spt	375-9980
3V-6515	Link As	394-0186
3V-6648	Pin As	308-9884
3V-6697	Housing	424-4944
3V-7065	Plate	380-1487
4C-1335	Washer-Thrust	399-4425

Sales Model 980C (Cont'd.)

63X		
Original Part Number	**Part Name**	**Classic Part Number**
4D-2619	Bearing	417-4494
4E-2250	Housing	399-6043
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4F-2041	Cup-Roller Brg	418-9609
4K-4780	Strip As-Wear	299-2063
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1320	Gasket-Adapter	398-2928
4N-1767	Valve-Bypass	419-4716
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-2954	Sleeve-Camshaft	299-2059
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4N-7693	Crankshaft As	269-8763
4P-0897	Core As-Radiator	376-9058
4P-2383	Adapter-Inlet	438-1812
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533

63X		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-9311	Housing	396-0652
4V-2057	Bearing-Spher	419-6019
4V-2518	Shaft	297-7243
4V-3044	Plate-Lock	308-9911
4V-3680	Bellcrank	308-9802
4V-7099	Pin As	361-1698
4V-8611	Yoke As	418-9567
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-4588	Sleeve	394-0218
4W-5363	Core Gp-O Clr	380-7531
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219

63X		
Original Part Number	**Part Name**	**Classic Part Number**
4W-6869	Spacer-Fuel Pump	417-4534
4W-7382	Core As-Oclr	380-1514
4W-9822	Core Gp-O Clr	374-4711
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5F-7404	Nut-Bearing Lock	308-9878
5K-0609	Cover	308-9843
5K-2754	Spring-Recoil	418-1956
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-3967	Yoke As	308-9946
5K-3968	Cage-Bearing	308-9804
5K-4079	Cage-Bearing	308-9805
5K-4268	Retainer-Bearing	308-9916
5K-4273	Bearing-Sleeve	374-1461
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8053	Kit-Gasket (Sch)	415-1901
5P-8194	Ring-Retaining	308-9920
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9301	Bearing-Spl Ball	417-4496
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537

Sales Model 980C (Cont'd.)

63X		
Original Part Number	Part Name	Classic Part Number
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
5V-6125	Diaphragm	384-5931
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6L-8968	Coupling-Exhaust	311-9381
6N-1036	Gear-Oil Pump	279-4991
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-2687	Spider As.-Fan	385-7199
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7653	Gage As-O Level	428-7206
6N-9743	Support-Muffler	308-9940
6P-0593	Bearing-Roller	386-4959
6P-2090	Base-Xmsn O Fil	397-5049
6P-2923	Yoke As	382-6891
6P-6739	Shaft-Planet	308-9929

63X		
Original Part Number	Part Name	Classic Part Number
6P-7357	Gear As-Pump	388-0561
6P-7358	Pump Gp-Gr 1 Bsc	308-9913
6P-7564	Carrier-Ring	384-3850
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-1033	Rod End-Spher	375-5444
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-4350	Race-Spl Rlr Brg	384-5933
6V-9221	Gasket Kit	391-1092
6W-0240	Bearing-Brace	297-7143
6W-4281	Yoke-Flange	308-9949
6W-4284	Cage-Bearing	308-9832
6W-4733	Retainer-Bearing	391-1089
6W-4789	Shaft Gp-Drive-D	452-0444
6W-7290	Shaft-Planet	308-9930
6Y-1603	Housing-Clutch	438-1818
6Y-1604	Carrier As	468-9790
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4819	Carrier-Planet	296-1348
6Y-5793	Ring-Seal	451-9028
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-4297	Seal As-Cshaft	325-6192
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523

63X		
Original Part Number	Part Name	Classic Part Number
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7J-8893	Cone-Roller Brg	374-1846
7K-1510	Washer-Thrust	330-9295
7K-1512	Cover	469-8101
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-1183	Plunger As-Fuel	419-4742
7N-1220	Plunger As-Pump	419-4743
7N-1393	Muffler As	374-7477
7N-1572	Cover-Water Pump	377-5854
7N-1760	Ejector As	373-1914
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8371	Line As-Fuel Inj	373-1901

Sales Model 980C (Cont'd.)

63X		
Original Part Number	**Part Name**	**Classic Part Number**
7N-9146	Gear-Fly Starter	279-4995
7N-9674	Muffler As	360-7892
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-2036	Cap As-Fuel	361-1721
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7V-6790	Shaft-Bev Pinion	308-9922
7W-0140	Gear-Drive	399-8546
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5699	Pulley-Cshaft	378-3988
7W-5733	Gasket	421-7333
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-7546	Gasket-Plate	433-8187
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
8F-6058	Bearing-Sleeve	416-5494
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8M-6676	Cylinder-Adj	226-4960

63X		
Original Part Number	**Part Name**	**Classic Part Number**
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As-Conn	269-5291
8N-1726	Rod As-Conn	379-8866
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3666	Repair Kt-Major	377-5842
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-5779	Coupling-Exhaust	325-6047
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7486	Condenser As	436-2263
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8258	Bearing-Sleeve	452-1077

63X		
Original Part Number	**Part Name**	**Classic Part Number**
8N-9622	Bracket As-Fan	433-2024
8P-0514	Yoke As	308-9947
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-4047	Shaft-Planet	373-5390
8P-9507	Piston-Clutch	283-5212
8R-3921	Collet	308-9839
8R-3943	Collet	308-9840
8R-3946	Collet	308-9841
8R-4184	Bearing-Sleeve	374-6515
8R-4821	Carrier-Planet	308-9837
8R-7425	Retainer	308-9917
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3653	Bonnet-Valve	374-4728
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3550	Rim As	417-9477
8V-6382	Hub As	308-9868
8V-6384	Spacer As	308-9935
9B-1320	Valve-Check	377-5832
9C-0624	Pin As.	361-1709
9C-0625	Pin As	308-9888
9C-2249	Yoke As	382-6890
9C-3530	Joint Gp-Univ	449-9832
9C-8074	Gear-Planet	308-9858
9C-8075	Gear-Sun	308-9864
9C-8278	Case As-Diff	423-6984
9C-8986	Collet As	374-6502
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217

Sales Model 980C (Cont'd.)

63X		
Original Part Number	Part Name	Classic Part Number
9G-1919	Gear-Planet	371-4307
9G-6744	Bearing-Sleeve	418-1931
9H-7670	Piston	226-4961
9J-5875	Bearing-Sleeve	308-9830
9K-5639	Pin	425-6451
9K-8428	Pin As	241-2533
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9L-5908	Gasket	433-8196
9M-1990	Dowel-Reaction	386-4963
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-5529	Body-F Inj Valve	378-3993
9N-5769	Cover-Housing	325-6050
9P-3731	Carrier-Planet	301-4767
9P-5531	Gear-Sun	417-9499
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-5279	Bearing-Inner	453-3661
9S-7788	Ring-Piston	461-5124
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9T-5360	Plate-Pressure	424-4941
9U-0971	Gear-Sun	368-0124
9U-0974	Bushing-Sleeve	374-1460
9U-0975	Hub As	390-5259
9V-0247	Plate	417-4527
9V-6165	Plate-Outer	377-7460
9V-7710	Univ Joint As	394-8234
9V-7860	Support As-Front	308-9938
9W-2977	Hub As	423-6985
9W-3605	Carrier-Ring	314-8662

63X		
Original Part Number	Part Name	Classic Part Number
9W-4175	Shaft-Xmsn Input	394-8241
9W-4702	Stator-Converter	308-9939
9W-5768	Gear-Ring	380-7474
9W-6433	Impeller-Conv	308-9871
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-7019	Disc-Friction	377-7461
9W-7040	Piston-Clutch	377-7462
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9Y-1798	Seal-Water	379-0165
9Y-1917	Pulley-Fan	395-1311
9Y-2988	Breather As	361-1716
9Y-3318	Core As-Radiator	374-7491
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-7860	Valve-Inlet	270-4360
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-4563	Gear-Transfer	399-4430
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
106-7798	Bearing-Ball	417-9494
108-2102	Bonnet-Valve	455-3274
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463

63X		
Original Part Number	Part Name	Classic Part Number
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
111-8015	Gasket As-Head	279-4977
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8041	Carrier-Planet	295-5681
114-0468	Pin-G.E.T.	443-1203
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
120-3861	Bracket As	415-1897
121-7583	Gear-Planet	364-5257
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
139-9172	Gasket Kit	384-5964
141-9792	Gasket Kit - Ocl	393-3632
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
144-0744	Compressor Gp -B	435-6046
145-8503	Shaft As-Idler	426-0035
147-1900	Gasket Kit	447-0826
148-7455	Valve - Exhaust	270-4361
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502

Sales Model 980C (Cont'd.)

63X		
Original Part Number	**Part Name**	**Classic Part Number**
161-7128	Spring As.	419-4726
164-4891	Plate As.	391-1093
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-5634	Shaft As.-Output	421-7067
166-9142	Gasket	420-8546
167-8123	Damper As	299-2006
167-8126	Damper As	382-8019
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698

63X		
Original Part Number	**Part Name**	**Classic Part Number**
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
190-3832	Core As-Oclr	438-3251
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
197-5510	Support As	419-0880
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3233	Bearing-Main	376-9085

63X		
Original Part Number	**Part Name**	**Classic Part Number**
232-6574	Kit-Gasket-Rs	437-2034
232-6599	Kit-Gasket (Mch)	437-2033
233-7083	Kit-Gasket-Fs	387-2919
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
241-1397	Kit-Dt Gasket	434-7286
253-1752	Plate-Thrust	379-0170
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
334-8389	Crankshaft As	242-3439
343-4836	Mount As	424-6369
374-1849	Brg-Rlr-Cla	399-4442
430-7619	Adapter-Cla	438-1812

Sales Model 980F

3HK		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7115	Mount As	418-1936

3HK		
Original Part Number	**Part Name**	**Classic Part Number**
1P-7125	Governor As	383-3672
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802

3HK		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1534	Carrier-Ring	386-4916
1U-3522	Rod As	390-5281
1V-6342	Gear As	308-9847
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8280	Plate	382-6889
1V-8439	Pin As	308-9881

Sales Model 980F (Cont'd.)

3HK		
Original Part Number	Part Name	Classic Part Number
1V-8604	Gear-Ring	308-9853
1V-8606	Gear-Sun	308-9860
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8953	Pin	308-9892
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9130	Washer-Thrust	308-9943
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-6489	Race-Brg Outer	374-8350
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2N-5842	Screw-Bridge Adj	418-1934
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-5680	Turbine-Conv	308-9942
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817

3HK		
Original Part Number	Part Name	Classic Part Number
2V-3687	Gear-Diff Bevel	308-9849
2V-4374	Joint Gp-Slip	308-9872
2V-4700	Pin	308-9894
2V-7170	Yoke	308-9948
2V-7990	Tube As	373-5382
2W-7455	Gear As	396-9957
3D-5315	Pinion-Dif Bevel	308-9856
3E-6772	Seal-Water	382-8017
3G-1305	Cyl Gp-159 586 Y	430-5966
3G-2665	Cover	308-9842
3G-2858	Pump Gp-Gr A	424-7054
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3P-2414	Housing-Clutch	391-9831
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3246	Shaft-Planet	308-9925
3P-3429	Cage-Bearing	452-0430
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-8186	Housing-Screen	390-5261
3P-9366	Piston-Clutch	391-9861
3S-1262	Retainer	308-9915
3S-9669	Bearing	416-2168
3T-2139	Housing As-Cl	394-2583
3T-4384	Housing As-Cl	435-2573
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350

3HK		
Original Part Number	Part Name	Classic Part Number
3V-3855	Housing-Brg Spt	375-9980
3V-6515	Link As	394-0186
3V-6648	Pin As	308-9884
3V-6697	Housing	424-4944
3V-7065	Plate	380-1487
4C-1335	Washer-Thrust	399-4425
4E-2250	Housing	399-6043
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4F-2041	Cup-Roller Brg	418-9609
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1767	Valve-Bypass	419-4716
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-2954	Sleeve-Camshaft	299-2059
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-0897	Core As-Radiator	376-9058
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216

Sales Model 980F (Cont'd.)

3HK		
Original Part Number	Part Name	Classic Part Number
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-9311	Housing	396-0652
4V-2057	Bearing-Spher	419-6019
4V-2518	Shaft	297-7243
4V-3044	Plate-Lock	308-9911
4V-3680	Bellcrank	308-9802
4V-7099	Pin As	361-1698
4V-8611	Yoke As	418-9567
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-7382	Core As-Oclr	380-1514
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5F-7404	Nut-Bearing Lock	308-9878
5K-0609	Cover	308-9843
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-4268	Retainer-Bearing	308-9916
5K-4273	Bearing-Sleeve	374-1461
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022

3HK		
Original Part Number	Part Name	Classic Part Number
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9301	Bearing-Spl Ball	417-4496
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6H-3957	Bearing-Ball	311-9358
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-2687	Spider As.-Fan	385-7199
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-7653	Gage As-O Level	428-7206
6N-9743	Support-Muffler	308-9940
6P-0593	Bearing-Roller	386-4959
6P-2090	Base-Xmsn O Fil	397-5049
6P-2923	Yoke As	382-6891
6P-6739	Shaft-Planet	308-9929
6P-7357	Gear As-Pump	388-0561

3HK		
Original Part Number	Part Name	Classic Part Number
6P-7358	Pump Gp-Gr 1 Bsc	308-9913
6P-7564	Carrier-Ring	384-3850
6P-7704	Carrier-Ring	314-8658
6V-1033	Rod End-Spher	375-5444
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-4281	Yoke-Flange	308-9949
6W-4284	Cage-Bearing	308-9832
6W-4733	Retainer-Bearing	391-1089
6W-4789	Shaft Gp-Drive-D	452-0444
6W-7290	Shaft-Planet	308-9930
6Y-1603	Housing-Clutch	438-1818
6Y-1604	Carrier As	468-9790
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5085	Bushing	377-5829
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441

Sales Model 980F (Cont'd.)

3HK		
Original Part Number	Part Name	Classic Part Number
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-8893	Cone-Roller Brg	374-1846
7K-1510	Washer-Thrust	330-9295
7K-1512	Cover	469-8101
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7N-1393	Muffler As	374-7477
7N-1572	Cover-Water Pump	377-5854
7N-1760	Ejector As	373-1914
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-8371	Line As-Fuel Inj	373-1901
7N-9674	Muffler As	360-7892
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7V-6790	Shaft-Bev Pinion	308-9922
7W-0140	Gear-Drive	399-8546
7W-1927	Ring-Retainer	387-2935
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636

3HK		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8M-0874	Plunger As-Valve	311-9439
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077
8N-9622	Bracket As-Fan	433-2024
8P-0514	Yoke As	308-9947
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-4047	Shaft-Planet	373-5390
8P-9507	Piston-Clutch	283-5212
8R-3921	Collet	308-9839
8R-3943	Collet	308-9840
8R-3946	Collet	308-9841
8R-4184	Bearing-Sleeve	374-6515
8R-4821	Carrier-Planet	308-9837
8R-7425	Retainer	308-9917
8S-3653	Bonnet-Valve	374-4728
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
8V-3550	Rim As	417-9477
8V-6382	Hub As	308-9868
8V-6384	Spacer As	308-9935
9B-1320	Valve-Check	377-5832
9C-0624	Pin As.	361-1709
9C-0625	Pin As	308-9888
9C-2249	Yoke As	382-6890
9C-3530	Joint Gp-Univ	449-9832

3HK		
Original Part Number	Part Name	Classic Part Number
9C-8074	Gear-Planet	308-9858
9C-8075	Gear-Sun	308-9864
9C-8278	Case As-Diff	423-6984
9C-8986	Collet As	374-6502
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1919	Gear-Planet	371-4307
9G-6744	Bearing-Sleeve	418-1931
9J-5875	Bearing-Sleeve	308-9830
9K-5639	Pin	425-6451
9K-8428	Pin As	241-2533
9K-8757	Rod End-Special	311-9361
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9M-6692	Strip	386-4934
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9N-5529	Body-F Inj Valve	378-3993
9P-5531	Gear-Sun	417-9499
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-5279	Bearing-Inner	453-3661
9S-8597	Spring	399-8561
9T-5360	Plate-Pressure	424-4941
9U-0971	Gear-Sun	368-0124
9U-0974	Bushing-Sleeve	374-1460
9U-0975	Hub As	390-5259
9V-0247	Plate	417-4527
9V-6165	Plate-Outer	377-7460
9V-7710	Univ Joint As	394-8234
9V-7860	Support As-Front	308-9938

Sales Model 980F (Cont'd.)

3HK		
Original Part Number	**Part Name**	**Classic Part Number**
9W-2977	Hub As	423-6985
9W-4175	Shaft-Xmsn Input	394-8241
9W-4702	Stator-Converter	308-9939
9W-5768	Gear-Ring	380-7474
9W-6433	Impeller-Conv	308-9871
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-7019	Disc-Friction	377-7461
9W-7040	Piston-Clutch	377-7462
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9W-9027	Plate	419-2306
9Y-1917	Pulley-Fan	395-1311
9Y-2988	Breather As	361-1716
9Y-3318	Core As-Radiator	374-7491
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-4563	Gear-Transfer	399-4430
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
106-7798	Bearing-Ball	417-9494
108-2102	Bonnet-Valve	455-3274
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744

3HK		
Original Part Number	**Part Name**	**Classic Part Number**
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8041	Carrier-Planet	295-5681
112-8042	Carrier-Planet	390-0916
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
120-3861	Bracket As	415-1897
121-7583	Gear-Planet	364-5257
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
139-9172	Gasket Kit	384-5964
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
145-8503	Shaft As-Idler	426-0035
147-1900	Gasket Kit	447-0826
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
164-4891	Plate As.	391-1093

3HK		
Original Part Number	**Part Name**	**Classic Part Number**
165-5634	Shaft As.-Output	421-7067
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
197-5510	Support As	419-0880
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3679	Kit-Gasket (Rs)	437-2039
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
241-1397	Kit-Dt Gasket	434-7286
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
374-1849	Brg-Rlr-Cla	399-4442
430-7619	Adapter-Cla	438-1812

Sales Model 980F (Cont'd.)

4RN		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916
1U-3522	Rod As	390-5281
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8280	Plate	382-6889
1V-8439	Pin As	308-9881
1V-8604	Gear-Ring	308-9853
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8953	Pin	308-9892
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164

4RN		
Original Part Number	Part Name	Classic Part Number
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9130	Washer-Thrust	308-9943
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-6489	Race-Brg Outer	374-8350
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-5680	Turbine-Conv	308-9942
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2V-4374	Joint Gp-Slip	308-9872
2V-4700	Pin	308-9894
2V-7170	Yoke	308-9948
2W-7455	Gear As	396-9957
3D-5315	Pinion-Dif Bevel	308-9856
3E-6772	Seal-Water	382-8017
3G-1305	Cyl Gp-159 586 Y	430-5966
3G-2665	Cover	308-9842
3G-2858	Pump Gp-Gr A	424-7054
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3P-2414	Housing-Clutch	391-9831
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468

4RN		
Original Part Number	Part Name	Classic Part Number
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3246	Shaft-Planet	308-9925
3P-3429	Cage-Bearing	452-0430
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-8186	Housing-Screen	390-5261
3P-9366	Piston-Clutch	391-9861
3S-1262	Retainer	308-9915
3S-9669	Bearing	416-2168
3T-2139	Housing As-Cl	394-2583
3T-4384	Housing As-Cl	435-2573
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350
3V-3855	Housing-Brg Spt	375-9980
3V-6515	Link As	394-0186
3V-6648	Pin As	308-9884
3V-6697	Housing	424-4944
3V-7065	Plate	380-1487
4C-1335	Washer-Thrust	399-4425
4E-2250	Housing	399-6043
4E-5213	Cover As	299-2000
4F-2041	Cup-Roller Brg	418-9609
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056

Sales Model 980F (Cont'd.)

4RN		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2954	Sleeve-Camshaft	299-2059
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-0897	Core As-Radiator	376-9058
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-9311	Housing	396-0652
4V-2057	Bearing-Spher	419-6019
4V-3044	Plate-Lock	308-9911
4V-7099	Pin As	361-1698
4V-8611	Yoke As	418-9567
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-7382	Core As-Oclr	380-1514
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511

4RN		
Original Part Number	**Part Name**	**Classic Part Number**
5K-0609	Cover	308-9843
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-4268	Retainer-Bearing	308-9916
5K-4273	Bearing-Sleeve	374-1461
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9301	Bearing-Spl Ball	417-4496
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-2687	Spider As.-Fan	385-7199

4RN		
Original Part Number	**Part Name**	**Classic Part Number**
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-9743	Support-Muffler	308-9940
6P-0593	Bearing-Roller	386-4959
6P-2090	Base-Xmsn O Fil	397-5049
6P-2923	Yoke As	382-6891
6P-6739	Shaft-Planet	308-9929
6P-7357	Gear As-Pump	388-0561
6P-7358	Pump Gp-Gr 1 Bsc	308-9913
6P-7564	Carrier-Ring	384-3850
6P-7704	Carrier-Ring	314-8658
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-4281	Yoke-Flange	308-9949
6W-4284	Cage-Bearing	308-9832
6W-4733	Retainer-Bearing	391-1089
6W-4789	Shaft Gp-Drive-D	452-0444
6W-7290	Shaft-Planet	308-9930
6Y-1603	Housing-Clutch	438-1818
6Y-1604	Carrier As	468-9790
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522

Sales Model 980F (Cont'd.)

4RN		
Original Part Number	Part Name	Classic Part Number
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-8893	Cone-Roller Brg	374-1846
7K-1510	Washer-Thrust	330-9295
7K-1512	Cover	469-8101
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7N-1393	Muffler As	374-7477
7N-1572	Cover-Water Pump	377-5854
7N-1760	Ejector As	373-1914
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-9674	Muffler As	360-7892
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442

4RN		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077
8N-9622	Bracket As-Fan	433-2024
8P-0514	Yoke As	308-9947
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-4047	Shaft-Planet	373-5390
8P-9507	Piston-Clutch	283-5212
8R-3921	Collet	308-9839
8R-3943	Collet	308-9840
8R-3946	Collet	308-9841
8R-4184	Bearing-Sleeve	374-6515
8R-4821	Carrier-Planet	308-9837
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
8V-3550	Rim As	417-9477
8V-6382	Hub As	308-9868
8V-6384	Spacer As	308-9935
9B-1320	Valve-Check	377-5832
9C-0624	Pin As.	361-1709
9C-0625	Pin As	308-9888
9C-2249	Yoke As	382-6890
9C-3530	Joint Gp-Univ	449-9832
9C-8074	Gear-Planet	308-9858
9C-8075	Gear-Sun	308-9864

4RN		
Original Part Number	Part Name	Classic Part Number
9C-8986	Collet As	374-6502
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1919	Gear-Planet	371-4307
9G-6744	Bearing-Sleeve	418-1931
9J-5875	Bearing-Sleeve	308-9830
9K-5639	Pin	425-6451
9K-8428	Pin As	241-2533
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9M-6692	Strip	386-4934
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9P-5531	Gear-Sun	417-9499
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-5279	Bearing-Inner	453-3661
9S-8597	Spring	399-8561
9T-5360	Plate-Pressure	424-4941
9U-0971	Gear-Sun	368-0124
9U-0974	Bushing-Sleeve	374-1460
9U-0975	Hub As	390-5259
9V-0247	Plate	417-4527
9V-6165	Plate-Outer	377-7460
9V-7710	Univ Joint As	394-8234
9V-7860	Support As-Front	308-9938
9W-2977	Hub As	423-6985
9W-4175	Shaft-Xmsn Input	394-8241
9W-4702	Stator-Converter	308-9939
9W-5768	Gear-Ring	380-7474
9W-6433	Impeller-Conv	308-9871

Sales Model 980F (Cont'd.)

4RN		
Original Part Number	**Part Name**	**Classic Part Number**
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-7019	Disc-Friction	377-7461
9W-7040	Piston-Clutch	377-7462
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9W-9027	Plate	419-2306
9Y-1917	Pulley-Fan	395-1311
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-4563	Gear-Transfer	399-4430
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
106-7798	Bearing-Ball	417-9494
108-2102	Bonnet-Valve	455-3274
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
112-5585	Shaft-Planet	308-9932

4RN		
Original Part Number	**Part Name**	**Classic Part Number**
112-7309	Shaft-Planet	380-7521
112-8041	Carrier-Planet	295-5681
112-8042	Carrier-Planet	390-0916
114-0468	Pin-G.E.T.	443-1203
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
120-3861	Bracket As	415-1897
121-7583	Gear-Planet	364-5257
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
139-9172	Gasket Kit	384-5964
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
145-8503	Shaft As-Idler	426-0035
147-1900	Gasket Kit	447-0826
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
164-4891	Plate As.	391-1093
165-5634	Shaft As.-Output	421-7067

4RN		
Original Part Number	**Part Name**	**Classic Part Number**
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-6574	Kit-Gasket-Rs	437-2034
233-9748	Disc-Friction	417-9502
234-1874	Kit-Gasket-Fs	437-8668
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
243-0723	Kit-Dt Gasket	391-9886
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
374-1849	Brg-Rlr-Cla	399-4442
430-7619	Adapter-Cla	438-1812

5XJ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395

5XJ		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840

5XJ		
Original Part Number	**Part Name**	**Classic Part Number**
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114

Sales Model 980F (Cont'd.)

5XJ		
Original Part Number	Part Name	Classic Part Number
1P-7115	Mount As	418-1936
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916
1U-3522	Rod As	390-5281
1V-6342	Gear As	308-9847
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8280	Plate	382-6889
1V-8439	Pin As	308-9881
1V-8604	Gear-Ring	308-9853
1V-8606	Gear-Sun	308-9860
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8953	Pin	308-9892
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

5XJ		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2D-9130	Washer-Thrust	308-9943
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-6489	Race-Brg Outer	374-8350
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-5680	Turbine-Conv	308-9942
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2V-3687	Gear-Diff Bevel	308-9849
2V-4374	Joint Gp-Slip	308-9872
2V-4700	Pin	308-9894
2V-7170	Yoke	308-9948
2V-7990	Tube As	373-5382
2W-7455	Gear As	396-9957
3D-5315	Pinion-Dif Bevel	308-9856
3E-6772	Seal-Water	382-8017
3G-0222	Bearing-Sleeve	374-6512
3G-1305	Cyl Gp-159 586 Y	430-5966
3G-2665	Cover	308-9842
3G-2858	Pump Gp-Gr A	424-7054
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3P-2414	Housing-Clutch	391-9831
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861

5XJ		
Original Part Number	Part Name	Classic Part Number
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3246	Shaft-Planet	308-9925
3P-3429	Cage-Bearing	452-0430
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-8186	Housing-Screen	390-5261
3P-9366	Piston-Clutch	391-9861
3S-1262	Retainer	308-9915
3S-9669	Bearing	416-2168
3T-2139	Housing As-Cl	394-2583
3T-4384	Housing As-Cl	435-2573
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350
3V-3855	Housing-Brg Spt	375-9980
3V-6515	Link As	394-0186
3V-6648	Pin As	308-9884
3V-6697	Housing	424-4944
3V-7065	Plate	380-1487
4C-1335	Washer-Thrust	399-4425
4E-2250	Housing	399-6043
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4F-2041	Cup-Roller Brg	418-9609
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056

Sales Model 980F (Cont'd.)

5XJ		
Original Part Number	**Part Name**	**Classic Part Number**
4N-2954	Sleeve-Camshaft	299-2059
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-0893	Core As-Radiator	376-9057
4P-0897	Core As-Radiator	376-9058
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-9311	Housing	396-0652
4V-2057	Bearing-Spher	419-6019
4V-2518	Shaft	297-7243
4V-3044	Plate-Lock	308-9911
4V-3680	Bellcrank	308-9802
4V-7099	Pin As	361-1698
4V-8611	Yoke As	418-9567
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219

5XJ		
Original Part Number	**Part Name**	**Classic Part Number**
4W-7382	Core As-Oclr	380-1514
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5F-7404	Nut-Bearing Lock	308-9878
5K-0609	Cover	308-9843
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-4268	Retainer-Bearing	308-9916
5K-4273	Bearing-Sleeve	374-1461
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9301	Bearing-Spl Ball	417-4496
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387

5XJ		
Original Part Number	**Part Name**	**Classic Part Number**
6L-7751	Rod End-Spher	472-8015
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-2687	Spider As.-Fan	385-7199
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-9743	Support-Muffler	308-9940
6P-0593	Bearing-Roller	386-4959
6P-2090	Base-Xmsn O Fil	397-5049
6P-2923	Yoke As	382-6891
6P-6739	Shaft-Planet	308-9929
6P-7357	Gear As-Pump	388-0561
6P-7358	Pump Gp-Gr 1 Bsc	308-9913
6P-7564	Carrier-Ring	384-3850
6P-7704	Carrier-Ring	314-8658
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-4281	Yoke-Flange	308-9949
6W-4284	Cage-Bearing	308-9832
6W-4733	Retainer-Bearing	391-1089
6W-4789	Shaft Gp-Drive-D	452-0444
6W-7290	Shaft-Planet	308-9930
6Y-1603	Housing-Clutch	438-1818
6Y-1604	Carrier As	468-9790
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256

Sales Model 980F (Cont'd.)

5XJ		
Original Part Number	Part Name	Classic Part Number
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-3216	Bearing	368-0104
7J-8893	Cone-Roller Brg	374-1846
7K-1510	Washer-Thrust	330-9295
7K-1512	Cover	469-8101
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7N-1393	Muffler As	374-7477
7N-1572	Cover-Water Pump	377-5854
7N-1760	Ejector As	373-1914
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7435	Kit-Major Repair	374-4724
7N-9674	Muffler As	360-7892
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7V-6790	Shaft-Bev Pinion	308-9922
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475

5XJ		
Original Part Number	Part Name	Classic Part Number
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077
8N-9622	Bracket As-Fan	433-2024
8P-0514	Yoke As	308-9947
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-4047	Shaft-Planet	373-5390
8P-9507	Piston-Clutch	283-5212
8R-3921	Collet	308-9839
8R-3943	Collet	308-9840
8R-3946	Collet	308-9841
8R-4184	Bearing-Sleeve	374-6515
8R-4821	Carrier-Planet	308-9837
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
8V-3550	Rim As	417-9477
8V-6382	Hub As	308-9868

5XJ		
Original Part Number	Part Name	Classic Part Number
8V-6384	Spacer As	308-9935
9B-1320	Valve-Check	377-5832
9C-0624	Pin As.	361-1709
9C-0625	Pin As	308-9888
9C-2249	Yoke As	382-6890
9C-3530	Joint Gp-Univ	449-9832
9C-8074	Gear-Planet	308-9858
9C-8075	Gear-Sun	308-9864
9C-8278	Case As-Diff	423-6984
9C-8986	Collet As	374-6502
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1919	Gear-Planet	371-4307
9G-6744	Bearing-Sleeve	418-1931
9J-5875	Bearing-Sleeve	308-9830
9J-8006	Piston	449-4736
9K-5639	Pin	425-6451
9K-8428	Pin As	241-2533
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9M-6692	Strip	386-4934
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9P-5531	Gear-Sun	417-9499
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-5279	Bearing-Inner	453-3661
9S-8597	Spring	399-8561
9T-5360	Plate-Pressure	424-4941
9U-0971	Gear-Sun	368-0124
9U-0974	Bushing-Sleeve	374-1460
9U-0975	Hub As	390-5259
9V-0247	Plate	417-4527

Sales Model 980F (Cont'd.)

5XJ		
Original Part Number	**Part Name**	**Classic Part Number**
9V-6165	Plate-Outer	377-7460
9V-7710	Univ Joint As	394-8234
9V-7860	Support As-Front	308-9938
9W-2977	Hub As	423-6985
9W-4175	Shaft-Xmsn Input	394-8241
9W-4702	Stator-Converter	308-9939
9W-5768	Gear-Ring	380-7474
9W-6433	Impeller-Conv	308-9871
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-7019	Disc-Friction	377-7461
9W-7040	Piston-Clutch	377-7462
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9W-9027	Plate	419-2306
9Y-1917	Pulley-Fan	395-1311
9Y-2988	Breather As	361-1716
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-4563	Gear-Transfer	399-4430
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
106-7798	Bearing-Ball	417-9494
108-2102	Bonnet-Valve	455-3274
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215

5XJ		
Original Part Number	**Part Name**	**Classic Part Number**
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8041	Carrier-Planet	295-5681
112-8042	Carrier-Planet	390-0916
114-0468	Pin-G.E.T.	443-1203
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
120-3861	Bracket As	415-1897
121-7583	Gear-Planet	364-5257
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
139-9172	Gasket Kit	384-5964
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
147-1900	Gasket Kit	447-0826
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
164-4891	Plate As.	391-1093

5XJ		
Original Part Number	**Part Name**	**Classic Part Number**
165-5634	Shaft As.-Output	421-7067
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
233-9748	Disc-Friction	417-9502
234-1874	Kit-Gasket-Fs	437-8668
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
241-1397	Kit-Dt Gasket	434-7286
243-0723	Kit-Dt Gasket	391-9886
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
374-1849	Brg-Rlr-Cla	399-4442
430-7619	Adapter-Cla	438-1812

Sales Model 980F (Cont'd.)

8CJ		
Original Part Number	Part Name	Classic Part Number
1B-3937	Cup-Roller Brg	377-7394
1B-4043	Cone-Roller Brg	377-7395
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-1078	Bearing-Thrust	384-4802
1T-1333	Carrier As	445-9250
1T-1534	Carrier-Ring	386-4916
1T-1607	Spider As	434-9637
1U-3522	Rod As	390-5281
1V-6342	Gear As	308-9847
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8280	Plate	382-6889
1V-8439	Pin As	308-9881
1V-8604	Gear-Ring	308-9853
1V-8606	Gear-Sun	308-9860
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8953	Pin	308-9892
1V-8954	Pin As	361-1696

8CJ		
Original Part Number	Part Name	Classic Part Number
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9130	Washer-Thrust	308-9943
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2H-6489	Race-Brg Outer	374-8350
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-5680	Turbine-Conv	308-9942
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2V-3687	Gear-Diff Bevel	308-9849
2V-4374	Joint Gp-Slip	308-9872
2V-4700	Pin	308-9894
2V-6129	Cover	390-5295
2V-7170	Yoke	308-9948
2V-7990	Tube As	373-5382
2W-7455	Gear As	396-9957
3D-5315	Pinion-Dif Bevel	308-9856
3E-6772	Seal-Water	382-8017
3E-7466	Gasket Kit	393-3615
3G-1305	Cyl Gp-159 586 Y	430-5966

8CJ		
Original Part Number	Part Name	Classic Part Number
3G-2665	Cover	308-9842
3G-2858	Pump Gp-Gr A	424-7054
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3P-2414	Housing-Clutch	391-9831
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3246	Shaft-Planet	308-9925
3P-3429	Cage-Bearing	452-0430
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-8186	Housing-Screen	390-5261
3P-9366	Piston-Clutch	391-9861
3S-1262	Retainer	308-9915
3S-9669	Bearing	416-2168
3T-2139	Housing As-Cl	394-2583
3T-4384	Housing As-Cl	435-2573
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350
3V-3855	Housing-Brg Spt	375-9980
3V-6515	Link As	394-0186
3V-6648	Pin As	308-9884
3V-6697	Housing	424-4944
3V-7065	Plate	380-1487
4C-1335	Washer-Thrust	399-4425
4E-0403	Gear-Planet	260-0781
4E-2250	Housing	399-6043
4E-3456	Lever As	367-6081
4E-5213	Cover As	299-2000
4F-2041	Cup-Roller Brg	418-9609

Sales Model 980F (Cont'd.)

8CJ		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-2954	Sleeve-Camshaft	299-2059
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-0893	Core As-Radiator	376-9057
4P-0897	Core As-Radiator	376-9058
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-9311	Housing	396-0652
4V-0189	Pin	374-6504
4V-2057	Bearing-Spher	419-6019
4V-2518	Shaft	297-7243
4V-3044	Plate-Lock	308-9911
4V-3680	Bellcrank	308-9802

8CJ		
Original Part Number	**Part Name**	**Classic Part Number**
4V-7099	Pin As	361-1698
4V-8611	Yoke As	418-9567
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-7382	Core As-Oclr	380-1514
4W-9822	Core Gp-O Clr	374-4711
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5D-7449	Cup-Spl Tapered	416-2161
5F-7404	Nut-Bearing Lock	308-9878
5K-0609	Cover	308-9843
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-4268	Retainer-Bearing	308-9916
5K-4273	Bearing-Sleeve	374-1461
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502

8CJ		
Original Part Number	**Part Name**	**Classic Part Number**
5P-8194	Ring-Retaining	308-9920
5P-9301	Bearing-Spl Ball	417-4496
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6M-1592	Bearing-Sleeve	374-1462
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-2687	Spider As.-Fan	385-7199
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-9743	Support-Muffler	308-9940
6P-0593	Bearing-Roller	386-4959
6P-2090	Base-Xmsn O Fil	397-5049
6P-2923	Yoke As	382-6891
6P-6739	Shaft-Planet	308-9929
6P-7357	Gear As-Pump	388-0561
6P-7358	Pump Gp-Gr 1 Bsc	308-9913
6P-7564	Carrier-Ring	384-3850
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-1781	Bearing-Spl Ball	380-1508

Sales Model 980F (Cont'd.)

8CJ		
Original Part Number	Part Name	Classic Part Number
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6V-4350	Race-Spl Rlr Brg	384-5933
6W-4281	Yoke-Flange	308-9949
6W-4284	Cage-Bearing	308-9832
6W-4733	Retainer-Bearing	391-1089
6W-4789	Shaft Gp-Drive-D	452-0444
6W-7290	Shaft-Planet	308-9930
6W-7352	Retainer	424-0741
6Y-1603	Housing-Clutch	438-1818
6Y-1604	Carrier As	468-9790
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4819	Carrier-Planet	296-1348
6Y-5793	Ring-Seal	451-9028
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206

8CJ		
Original Part Number	Part Name	Classic Part Number
7H-7628	Bearing	453-3655
7J-8893	Cone-Roller Brg	374-1846
7K-1510	Washer-Thrust	330-9295
7K-1512	Cover	469-8101
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7N-1393	Muffler As	374-7477
7N-1572	Cover-Water Pump	377-5854
7N-1760	Ejector As	373-1914
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7166	Race-Brg Thrust	417-4531
7N-7435	Kit-Major Repair	374-4724
7N-9674	Muffler As	360-7892
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7V-6790	Shaft-Bev Pinion	308-9922
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-5352	Bearing-Ball	453-3658
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521

8CJ		
Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077
8N-9622	Bracket As-Fan	433-2024
8P-0514	Yoke As	308-9947
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-4047	Shaft-Planet	373-5390
8P-9507	Piston-Clutch	283-5212
8R-3921	Collet	308-9839
8R-3943	Collet	308-9840
8R-3946	Collet	308-9841
8R-4184	Bearing-Sleeve	374-6515
8R-4821	Carrier-Planet	308-9837
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
8V-3550	Rim As	417-9477
8V-6382	Hub As	308-9868
8V-6384	Spacer As	308-9935
9B-1320	Valve-Check	377-5832
9C-0624	Pin As.	361-1709
9C-0625	Pin As	308-9888
9C-2249	Yoke As	382-6890
9C-3530	Joint Gp-Univ	449-9832
9C-8074	Gear-Planet	308-9858
9C-8075	Gear-Sun	308-9864
9C-8278	Case As-Diff	423-6984
9C-8986	Collet As	374-6502
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216

Sales Model 980F (Cont'd.)

8CJ		
Original Part Number	**Part Name**	**Classic Part Number**
9G-0290	Hub-Clutch	283-5217
9G-1919	Gear-Planet	371-4307
9G-6744	Bearing-Sleeve	418-1931
9J-5875	Bearing-Sleeve	308-9830
9K-5639	Pin	425-6451
9K-8428	Pin As	241-2533
9L-2685	Rod End	419-1866
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9P-3731	Carrier-Planet	301-4767
9P-5531	Gear-Sun	417-9499
9P-7757	Gear-Sun	283-5218
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-5279	Bearing-Inner	453-3661
9S-8597	Spring	399-8561
9T-5360	Plate-Pressure	424-4941
9U-0971	Gear-Sun	368-0124
9U-0974	Bushing-Sleeve	374-1460
9U-0975	Hub As	390-5259
9V-0247	Plate	417-4527
9V-3052	Plate	434-1401
9V-6165	Plate-Outer	377-7460
9V-7710	Univ Joint As	394-8234
9V-7860	Support As-Front	308-9938
9W-2977	Hub As	423-6985
9W-3605	Carrier-Ring	314-8662
9W-4175	Shaft-Xmsn Input	394-8241
9W-4702	Stator-Converter	308-9939
9W-5768	Gear-Ring	380-7474
9W-6433	Impeller-Conv	308-9871
9W-6434	Hub-Impeller	443-2018

8CJ		
Original Part Number	**Part Name**	**Classic Part Number**
9W-6435	Flange-Drive	308-9846
9W-7019	Disc-Friction	377-7461
9W-7040	Piston-Clutch	377-7462
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9W-9027	Plate	419-2306
9Y-1917	Pulley-Fan	395-1311
9Y-2988	Breather As	361-1716
9Y-3318	Core As-Radiator	374-7491
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-4563	Gear-Transfer	399-4430
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
106-7798	Bearing-Ball	417-9494
108-2102	Bonnet-Valve	455-3274
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8041	Carrier-Planet	295-5681
112-8042	Carrier-Planet	390-0916
114-0468	Pin-G.E.T.	443-1203
115-2367	Valve-Exhaust	384-8700

8CJ		
Original Part Number	**Part Name**	**Classic Part Number**
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
120-3861	Bracket As	415-1897
121-7583	Gear-Planet	364-5257
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3068	Rebuild Kit-Pump	363-7455
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
138-6744	Rebuild Kit-Pump	363-7457
139-9172	Gasket Kit	384-5964
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston Kt	380-1554
145-8503	Shaft As-Idler	426-0035
147-1900	Gasket Kit	447-0826
149-5985	Stator-Converter	419-1865
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
164-4891	Plate As.	391-1093
165-5634	Shaft As.-Output	421-7067
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011

Sales Model 980F (Cont'd.)

8CJ		
Original Part Number	**Part Name**	**Classic Part Number**
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
197-5510	Support As	419-0880
202-3572	Shaft As-Drive	426-0037

8CJ		
Original Part Number	**Part Name**	**Classic Part Number**
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-3679	Kit-Gasket (Rs)	437-2039
232-6574	Kit-Gasket-Rs	437-2034
233-9748	Disc-Friction	417-9502
234-1874	Kit-Gasket-Fs	437-8668
234-1983	Kit-Gasket-Fs	393-0924
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201

8CJ		
Original Part Number	**Part Name**	**Classic Part Number**
241-1397	Kit-Dt Gasket	434-7286
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
374-1849	Brg-Rlr-Cla	399-4442
430-7619	Adapter-Cla	438-1812

8JN		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7115	Mount As	418-1936
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-1078	Bearing-Thrust	384-4802
1T-1333	Carrier As	445-9250
1T-1534	Carrier-Ring	386-4916
1T-1607	Spider As	434-9637
1U-3522	Rod As	390-5281
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8280	Plate	382-6889

8JN		
Original Part Number	**Part Name**	**Classic Part Number**
1V-8439	Pin As	308-9881
1V-8604	Gear-Ring	308-9853
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8953	Pin	308-9892
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-9130	Washer-Thrust	308-9943
2D-9457	Cone-Spl Tapered	377-7418

8JN		
Original Part Number	**Part Name**	**Classic Part Number**
2F-5721	Bearing-Ball	311-9354
2H-6489	Race-Brg Outer	374-8350
2K-5103	Cone-Roller Brg	380-7505
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1757	Hub-Fan Pulley	296-1357
2P-5680	Turbine-Conv	308-9942
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2V-4374	Joint Gp-Slip	308-9872
2V-4700	Pin	308-9894
2V-6129	Cover	390-5295
2V-7170	Yoke	308-9948
2W-7455	Gear As	396-9957
3D-5315	Pinion-Dif Bevel	308-9856
3E-6772	Seal-Water	382-8017
3G-1305	Cyl Gp-159 586 Y	430-5966
3G-2665	Cover	308-9842
3G-2858	Pump Gp-Gr A	424-7054
3H-8726	Mount As	385-7208
3K-2511	Dowel-Reaction	383-2126
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356

Sales Model 980F (Cont'd.)

8JN		
Original Part Number	**Part Name**	**Classic Part Number**
3P-2414	Housing-Clutch	391-9831
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3246	Shaft-Planet	308-9925
3P-3429	Cage-Bearing	452-0430
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-8186	Housing-Screen	390-5261
3P-9366	Piston-Clutch	391-9861
3S-1262	Retainer	308-9915
3S-9669	Bearing	416-2168
3T-2139	Housing As-Cl	394-2583
3T-4384	Housing As-Cl	435-2573
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350
3V-3855	Housing-Brg Spt	375-9980
3V-6515	Link As	394-0186
3V-6648	Pin As	308-9884
3V-6697	Housing	424-4944
3V-7065	Plate	380-1487
4C-1335	Washer-Thrust	399-4425
4E-0403	Gear-Planet	260-0781
4E-2250	Housing	399-6043
4E-5213	Cover As	299-2000
4F-2041	Cup-Roller Brg	418-9609
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191

8JN		
Original Part Number	**Part Name**	**Classic Part Number**
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-2954	Sleeve-Camshaft	299-2059
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6658	Bearing-Sleeve	373-1885
4P-0893	Core As-Radiator	376-9057
4P-0897	Core As-Radiator	376-9058
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-9311	Housing	396-0652
4V-0189	Pin	374-6504
4V-2057	Bearing-Spher	419-6019
4V-3044	Plate-Lock	308-9911
4V-7099	Pin As	361-1698
4V-8611	Yoke As	418-9567
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318

8JN		
Original Part Number	**Part Name**	**Classic Part Number**
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-7382	Core As-Oclr	380-1514
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5D-7449	Cup-Spl Tapered	416-2161
5K-0609	Cover	308-9843
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-4268	Retainer-Bearing	308-9916
5K-4273	Bearing-Sleeve	374-1461
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5410	Bearing-Spl Ball	396-4134
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9301	Bearing-Spl Ball	417-4496
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6B-3223	Cup-Bearing	399-6065
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757

Sales Model 980F (Cont'd.)

8JN		
Original Part Number	Part Name	Classic Part Number
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6L-7751	Rod End-Spher	472-8015
6M-1592	Bearing-Sleeve	374-1462
6N-1572	Mount As	308-9876
6N-1931	Plunger	379-0171
6N-2687	Spider As.-Fan	385-7199
6N-5482	Plate-Friction	376-3637
6N-5978	Coupling-Exhaust	369-9487
6N-7154	Rotocoil As	380-7556
6N-9743	Support-Muffler	308-9940
6P-0593	Bearing-Roller	386-4959
6P-2090	Base-Xmsn O Fil	397-5049
6P-2923	Yoke As	382-6891
6P-6739	Shaft-Planet	308-9929
6P-7357	Gear As-Pump	388-0561
6P-7358	Pump Gp-Gr 1 Bsc	308-9913
6P-7564	Carrier-Ring	384-3850
6P-7704	Carrier-Ring	314-8658
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-4281	Yoke-Flange	308-9949
6W-4284	Cage-Bearing	308-9832
6W-4733	Retainer-Bearing	391-1089
6W-4789	Shaft Gp-Drive-D	452-0444
6W-7290	Shaft-Planet	308-9930
6W-7352	Retainer	424-0741
6Y-1603	Housing-Clutch	438-1818
6Y-1604	Carrier As	468-9790
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028

8JN		
Original Part Number	Part Name	Classic Part Number
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7H-7628	Bearing	453-3655
7J-8893	Cone-Roller Brg	374-1846
7K-1510	Washer-Thrust	330-9295
7K-1512	Cover	469-8101
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7N-1393	Muffler As	374-7477
7N-1572	Cover-Water Pump	377-5854
7N-1760	Ejector As	373-1914
7N-2156	Bearing-Sleeve	380-7373
7N-2957	Cover-Rad Cap	361-1722
7N-7435	Kit-Major Repair	374-4724
7N-9674	Muffler As	360-7892
7S-4411	Cap As-Rain	373-1912
7S-7809	Cap As-Radiator	295-6417
7T-8816	Bearing-Spl Ball	420-2491

8JN		
Original Part Number	Part Name	Classic Part Number
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-0140	Gear-Drive	399-8546
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-2810	Case As-Filter	314-8512
8H-8175	Bearing-Sleeve	376-3636
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-7486	Condenser As	436-2263
8N-8258	Bearing-Sleeve	452-1077
8N-9622	Bracket As-Fan	433-2024
8P-0514	Yoke As	308-9947
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-4047	Shaft-Planet	373-5390
8P-9507	Piston-Clutch	283-5212
8R-3921	Collet	308-9839
8R-3943	Collet	308-9840
8R-3946	Collet	308-9841
8R-4184	Bearing-Sleeve	374-6515
8R-4821	Carrier-Planet	308-9837
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372

Sales Model 980F (Cont'd.)

8JN		
Original Part Number	**Part Name**	**Classic Part Number**
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
8V-3550	Rim As	417-9477
8V-6382	Hub As	308-9868
8V-6384	Spacer As	308-9935
9B-1320	Valve-Check	377-5832
9C-0624	Pin As.	361-1709
9C-0625	Pin As	308-9888
9C-2249	Yoke As	382-6890
9C-3530	Joint Gp-Univ	449-9832
9C-8074	Gear-Planet	308-9858
9C-8075	Gear-Sun	308-9864
9C-8986	Collet As	374-6502
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1919	Gear-Planet	371-4307
9G-6744	Bearing-Sleeve	418-1931
9J-5875	Bearing-Sleeve	308-9830
9K-5639	Pin	425-6451
9K-8428	Pin As	241-2533
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9P-5531	Gear-Sun	417-9499
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-5279	Bearing-Inner	453-3661
9S-8597	Spring	399-8561
9T-5360	Plate-Pressure	424-4941
9U-0971	Gear-Sun	368-0124
9U-0974	Bushing-Sleeve	374-1460
9U-0975	Hub As	390-5259

8JN		
Original Part Number	**Part Name**	**Classic Part Number**
9V-0247	Plate	417-4527
9V-3052	Plate	434-1401
9V-6165	Plate-Outer	377-7460
9V-7710	Univ Joint As	394-8234
9V-7860	Support As-Front	308-9938
9W-2977	Hub As	423-6985
9W-4175	Shaft-Xmsn Input	394-8241
9W-4702	Stator-Converter	308-9939
9W-5768	Gear-Ring	380-7474
9W-6433	Impeller-Conv	308-9871
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-7019	Disc-Friction	377-7461
9W-7040	Piston-Clutch	377-7462
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9W-9027	Plate	419-2306
9Y-1917	Pulley-Fan	395-1311
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
101-1504	Shaft	373-5379
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
102-4563	Gear-Transfer	399-4430
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
106-7798	Bearing-Ball	417-9494
108-2102	Bonnet-Valve	455-3274
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215

8JN		
Original Part Number	**Part Name**	**Classic Part Number**
108-7930	Bearing As	377-7463
110-5096	Head As-Cyl	394-0915
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8041	Carrier-Planet	295-5681
112-8042	Carrier-Planet	390-0916
114-0468	Pin-G.E.T.	443-1203
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
117-0456	Crankshaft As	394-2587
120-3861	Bracket As	415-1897
121-7583	Gear-Planet	364-5257
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-6597	Cone-Spl	422-6477
133-8890	Race	399-4423
135-4928	Shaft-Water Pump	386-3813
139-9172	Gasket Kit	384-5964
141-9792	Gasket Kit - Ocl	393-3632
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
147-1900	Gasket Kit	447-0826
149-5985	Stator-Converter	419-1865
150-4637	Pan-Oil	377-5843
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
164-4891	Plate As.	391-1093
165-5634	Shaft As.-Output	421-7067

Sales Model 980F (Cont'd.)

8JN		
Original Part Number	Part Name	Classic Part Number
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012

8JN		
Original Part Number	Part Name	Classic Part Number
191-7946	Line As-Fuel Inj	378-4013
197-5510	Support As	419-0880
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
232-6574	Kit-Gasket-Rs	437-2034
233-9748	Disc-Friction	417-9502
234-1874	Kit-Gasket-Fs	437-8668
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201

8JN		
Original Part Number	Part Name	Classic Part Number
243-0723	Kit-Dt Gasket	391-9886
253-1752	Plate-Thrust	379-0170
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
374-1849	Brg-Rlr-Cla	399-4442
430-7619	Adapter-Cla	438-1812

Sales Model 980G

2KR		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9594	Bearing-Cup	377-7401
1S-0057	Plate-Clutch	377-7404
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809

2KR		
Original Part Number	Part Name	Classic Part Number
1V-8439	Pin As	308-9881
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628

2KR		
Original Part Number	Part Name	Classic Part Number
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-6489	Race-Brg Outer	374-8350
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-5680	Turbine-Conv	308-9942
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3G-2665	Cover	308-9842
3G-7663	Cartridge Gp	422-8120
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-2414	Housing-Clutch	391-9831
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908

Sales Model 980G (Cont'd.)

2KR		
Original Part Number	**Part Name**	**Classic Part Number**
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3246	Shaft-Planet	308-9925
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-9366	Piston-Clutch	391-9861
3R-8530	Boss	425-3454
3S-1262	Retainer	308-9915
3V-4046	Plate-Pressure	380-7470
3V-6515	Link As	394-0186
3V-6648	Pin As	308-9884
4E-0079	Cage-Bearing	434-4387
4E-2250	Housing	399-6043
4F-2041	Cup-Roller Brg	418-9609
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-2954	Sleeve-Camshaft	299-2059
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086

2KR		
Original Part Number	**Part Name**	**Classic Part Number**
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-9311	Housing	396-0652
4V-2057	Bearing-Spher	419-6019
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-7099	Pin As	361-1698
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-7382	Core As-Oclr	380-1514
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5F-8651	Bearing-Ball	420-3223
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917

2KR		
Original Part Number	**Part Name**	**Classic Part Number**
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9301	Bearing-Spl Ball	417-4496
5P-9514	Bearing-Ball	417-9467
5P-9538	Bearing-Roller	421-8183
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6K-5528	Cup-Roller Brg	447-8059
6L-7751	Rod End-Spher	472-8015
6N-1931	Plunger	379-0171
6N-5482	Plate-Friction	376-3637
6N-7154	Rotocoil As	380-7556
6N-9743	Support-Muffler	308-9940
6P-0593	Bearing-Roller	386-4959
6P-6739	Shaft-Planet	308-9929
6P-7704	Carrier-Ring	314-8658
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6W-7352	Retainer	424-0741
6Y-1603	Housing-Clutch	438-1818
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257

Sales Model 980G (Cont'd.)

2KR		
Original Part Number	Part Name	Classic Part Number
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9595	Core As-Radiator	396-9926
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7K-9639	Bearing-Sleeve	314-8643
7M-5334	Cone-Roller Brg	420-2505
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4000	Piston	416-2143
7T-3365	Carrier-Planet	388-6563
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-0140	Gear-Drive	399-8546
7W-0205	Core As-Oclr	379-0183
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894

2KR		
Original Part Number	Part Name	Classic Part Number
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8C-3111	Rod End-Spher	392-4523
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-3666	Repair Kt-Major	377-5842
8N-8258	Bearing-Sleeve	452-1077
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8R-3946	Collet	308-9841
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9B-1320	Valve-Check	377-5832
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-5639	Pin	425-6451
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719

2KR		
Original Part Number	Part Name	Classic Part Number
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-5279	Bearing-Inner	453-3661
9S-8597	Spring	399-8561
9V-0247	Plate	417-4527
9W-2977	Hub As	423-6985
9W-4175	Shaft-Xmsn Input	394-8241
9W-4702	Stator-Converter	308-9939
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
002-1212	Cup-Roller Brg	399-4446
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-8010	Valve	423-5583
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154

Sales Model 980G (Cont'd.)

2KR		
Original Part Number	**Part Name**	**Classic Part Number**
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929
107-5006	Joint Gp-Univ	416-2137
107-5007	Joint Gp-Slip	416-2145
107-5610	Yoke	398-8334
107-9172	Piston	375-2622
108-2102	Bonnet-Valve	455-3274
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-0551	Hub As	416-2146
110-1337	Ring Kit-Pstn	377-5834
110-5096	Head As-Cyl	394-0915
111-8181	Cyl Gp-197 864 Y	390-0986
112-5003	Cyl Gp-159 582 Y	393-3654
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8042	Carrier-Planet	390-0916
114-0468	Pin-G.E.T.	443-1203
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-2958	Pin-Lower	393-0939
115-3184	Cap-Lower	395-1324
115-7048	Pin	393-3684
117-0456	Crankshaft As	394-2587
117-6675	Step As	419-0881
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3046	Carrier-Planet	393-1015
129-9907	Impeller-Pump	383-1589
130-2621	Pin As	390-5273
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730

2KR		
Original Part Number	**Part Name**	**Classic Part Number**
133-8890	Race	399-4423
134-0039	Housing-Piston	432-4217
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
135-5553	Bearing	394-0203
138-4338	Kit-Gasket-T	393-1032
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052
139-9173	Gasket Kit	434-7261
141-4617	Kit-Gasket(Acl)	393-0917
141-9792	Gasket Kit - Ocl	393-3632
142-7526	Gasket Kit	393-0918
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
147-1900	Gasket Kit	447-0826
149-2914	Pinion-Dif Bevel	396-9950
150-1916	Manifold-Exh	395-1322
150-4637	Pan-Oil	377-5843
150-8459	Kit-Gasket(F)	438-1798
150-8685	Gasket Kit	392-4503
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5091	Cartridge Gp	422-8124
155-5619	Gasket	382-5054
157-6257	Collar	393-0912
159-3021	Gasket	377-5845
159-8169	Gear-Planet	391-9870
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-9918	Retainer-Bearing	395-1321
164-4891	Plate As.	391-1093
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
176-3900	Accumulator	416-5513

2KR		
Original Part Number	**Part Name**	**Classic Part Number**
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
189-3041	Rod As	394-9811
191-4610	Pump Gp-Vane	422-8160
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
197-5510	Support As	419-0880
202-3572	Shaft As-Drive	426-0037
208-7534	Case As-Diff	388-6590
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
220-3779	Kit-Gasket(F)	437-1998
226-2018	Kit-Gasket-Acl	393-0921
232-3679	Kit-Gasket (Rs)	437-2039
233-9464	Kit-Gasket (Sch)	393-0925
233-9748	Disc-Friction	417-9502
234-1874	Kit-Gasket-Fs	437-8668
234-1983	Kit-Gasket-Fs	393-0924
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
243-0725	Kit-Dt Gasket	396-9953
243-0727	Kit-Dt Gasket	451-1506
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

Sales Model 980G (Cont'd.)

2KR		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032
319-5239	Wheel	396-9956
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443

2KR		
Original Part Number	Part Name	Classic Part Number
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-6387

2KR		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-4665
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

2SR		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8439	Pin As	308-9881
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
1W-1669	Piston	325-6158
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846

2SR		
Original Part Number	Part Name	Classic Part Number
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-6489	Race-Brg Outer	374-8350
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-5680	Turbine-Conv	308-9942
2S-6150	Cover-Pulley	428-8817
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3G-0222	Bearing-Sleeve	374-6512
3G-2665	Cover	308-9842
3G-2797	Bearing-Sleeve	360-2329
3G-7663	Cartridge Gp	422-8120
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-2414	Housing-Clutch	391-9831

2SR		
Original Part Number	Part Name	Classic Part Number
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3246	Shaft-Planet	308-9925
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-9366	Piston-Clutch	391-9861
3R-8530	Boss	425-3454
3V-6515	Link As	394-0186
3V-6648	Pin As	308-9884
4E-2250	Housing	399-6043
4F-2041	Cup-Roller Brg	418-9609
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-2954	Sleeve-Camshaft	299-2059

Sales Model 980G (Cont'd.)

2SR		
Original Part Number	Part Name	Classic Part Number
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4T-9311	Housing	396-0652
4V-2057	Bearing-Spher	419-6019
4V-7099	Pin As	361-1698
4V-8674	Bearing-Sleeve	307-1529
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-7382	Core As-Oclr	380-1514
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5F-8651	Bearing-Ball	420-3223
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774

2SR		
Original Part Number	Part Name	Classic Part Number
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9301	Bearing-Spl Ball	417-4496
5P-9514	Bearing-Ball	417-9467
5P-9538	Bearing-Roller	421-8183
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6K-5528	Cup-Roller Brg	447-8059
6N-1931	Plunger	379-0171
6N-5482	Plate-Friction	376-3637
6N-7154	Rotocoil As	380-7556
6N-9743	Support-Muffler	308-9940
6P-0593	Bearing-Roller	386-4959
6P-6739	Shaft-Planet	308-9929
6P-7704	Carrier-Ring	314-8658
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-1603	Housing-Clutch	438-1818
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256

2SR		
Original Part Number	Part Name	Classic Part Number
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9595	Core As-Radiator	396-9926
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-3216	Bearing	368-0104
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7M-5334	Cone-Roller Brg	420-2505
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-3365	Carrier-Planet	388-6563
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-0140	Gear-Drive	399-8546
7W-0205	Core As-Oclr	379-0183
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493

Sales Model 980G (Cont'd.)

2SR		
Original Part Number	Part Name	Classic Part Number
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8R-3946	Collet	308-9841
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9B-1320	Valve-Check	377-5832
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-8006	Piston	449-4736
9K-5639	Pin	425-6451
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-5279	Bearing-Inner	453-3661

2SR		
Original Part Number	Part Name	Classic Part Number
9S-8597	Spring	399-8561
9V-0247	Plate	417-4527
9W-2977	Hub As	423-6985
9W-4175	Shaft-Xmsn Input	394-8241
9W-4702	Stator-Converter	308-9939
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
002-1212	Cup-Roller Brg	399-4446
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-8010	Valve	423-5583
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929

2SR		
Original Part Number	Part Name	Classic Part Number
107-5006	Joint Gp-Univ	416-2137
107-5007	Joint Gp-Slip	416-2145
107-5610	Yoke	398-8334
107-9172	Piston	375-2622
108-2102	Bonnet-Valve	455-3274
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-0551	Hub As	416-2146
110-5096	Head As-Cyl	394-0915
111-8181	Cyl Gp-197 864 Y	390-0986
112-5003	Cyl Gp-159 582 Y	393-3654
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8042	Carrier-Planet	390-0916
114-0468	Pin-G.E.T.	443-1203
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-2958	Pin-Lower	393-0939
115-3184	Cap-Lower	395-1324
115-7048	Pin	393-3684
117-0456	Crankshaft As	394-2587
117-6675	Step As	419-0881
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3046	Carrier-Planet	393-1015
129-9907	Impeller-Pump	383-1589
130-2621	Pin As	390-5273
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
133-8890	Race	399-4423
134-0039	Housing-Piston	432-4217
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813

Sales Model 980G (Cont'd.)

2SR		
Original Part Number	**Part Name**	**Classic Part Number**
135-5553	Bearing	394-0203
138-4338	Kit-Gasket-T	393-1032
138-9381	Plate-Spacer	424-7052
139-9173	Gasket Kit	434-7261
141-4617	Kit-Gasket(Acl)	393-0917
142-7526	Gasket Kit	393-0918
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
147-1900	Gasket Kit	447-0826
149-2914	Pinion-Dif Bevel	396-9950
150-1916	Manifold-Exh	395-1322
150-4637	Pan-Oil	377-5843
150-8459	Kit-Gasket(F)	438-1798
150-8685	Gasket Kit	392-4503
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5091	Cartridge Gp	422-8124
155-5619	Gasket	382-5054
157-6257	Collar	393-0912
159-3021	Gasket	377-5845
159-8169	Gear-Planet	391-9870
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-9918	Retainer-Bearing	395-1321

2SR		
Original Part Number	**Part Name**	**Classic Part Number**
164-4891	Plate As.	391-1093
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
189-3041	Rod As	394-9811
191-4610	Pump Gp-Vane	422-8160
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
197-5510	Support As	419-0880
202-3572	Shaft As-Drive	426-0037
208-7534	Case As-Diff	388-6590
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914

2SR		
Original Part Number	**Part Name**	**Classic Part Number**
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
217-8938	Tightening-Belt	419-4735
223-3095	Gauge As	360-2295
226-2018	Kit-Gasket-Acl	393-0921
232-3679	Kit-Gasket (Rs)	437-2039
233-9464	Kit-Gasket (Sch)	393-0925
233-9748	Disc-Friction	417-9502
234-1874	Kit-Gasket-Fs	437-8668
237-9849	Cage-Bearing	443-1201
243-0725	Kit-Dt Gasket	396-9953
243-0727	Kit-Dt Gasket	451-1506
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
319-5239	Wheel	396-9956
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

9CM		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9594	Bearing-Cup	377-7401
1S-0057	Plate-Clutch	377-7404
1S-9209	Shaft-Tightener	374-6499

9CM		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808

9CM		
Original Part Number	**Part Name**	**Classic Part Number**
1V-8242	Bearing-Sleeve	308-9809
1V-8439	Pin As	308-9881
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
1W-1669	Piston	325-6158

Sales Model 980G (Cont'd.)

9CM		
Original Part Number	Part Name	Classic Part Number
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5910	Tappet As-Guide&	383-1569
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2F-5721	Bearing-Ball	311-9354
2F-8509	Cone-Roller Brg	399-4434
2H-6489	Race-Brg Outer	374-8350
2L-5271	Bearing-Ball	371-4305
2N-5842	Screw-Bridge Adj	418-1934
2P-5680	Turbine-Conv	308-9942
2S-6150	Cover-Pulley	428-8817
2V-4700	Pin	308-9894
2W-7455	Gear As	396-9957
3E-6772	Seal-Water	382-8017
3G-2665	Cover	308-9842
3G-7663	Cartridge Gp	422-8120
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-2414	Housing-Clutch	391-9831
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203

9CM		
Original Part Number	Part Name	Classic Part Number
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3246	Shaft-Planet	308-9925
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-9366	Piston-Clutch	391-9861
3R-8530	Boss	425-3454
3S-1262	Retainer	308-9915
3T-2139	Housing As-Cl	394-2583
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350
3V-4046	Plate-Pressure	380-7470
3V-6515	Link As	394-0186
3V-6648	Pin As	308-9884
4E-0079	Cage-Bearing	434-4387
4E-2250	Housing	399-6043
4F-2041	Cup-Roller Brg	418-9609
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-2954	Sleeve-Camshaft	299-2059
4N-3714	Chamber As	363-7450
4N-4534	Pulley-Crkshft	374-4709
4N-4668	Breather-Engine	396-7271
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-6658	Bearing-Sleeve	373-1885

9CM		
Original Part Number	Part Name	Classic Part Number
4P-2383	Adapter-Inlet	438-1812
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4S-5367	Mount As	375-9986
4S-8472	Hood As-Preclnr	296-1355
4T-9311	Housing	396-0652
4V-2057	Bearing-Spher	419-6019
4V-7099	Pin As	361-1698
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-7382	Core As-Oclr	380-1514
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5F-8651	Bearing-Ball	420-3223
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9301	Bearing-Spl Ball	417-4496
5P-9514	Bearing-Ball	417-9467

Sales Model 980G (Cont'd.)

9CM		
Original Part Number	**Part Name**	**Classic Part Number**
5P-9538	Bearing-Roller	421-8183
5S-9080	Pulley-Alt Drive	264-5883
5T-5682	Driver	418-9579
6E-2396	Cartridge Gp	422-8122
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6K-5528	Cup-Roller Brg	447-8059
6L-7751	Rod End-Spher	472-8015
6N-1931	Plunger	379-0171
6N-5482	Plate-Friction	376-3637
6N-7154	Rotocoil As	380-7556
6N-9743	Support-Muffler	308-9940
6P-0593	Bearing-Roller	386-4959
6P-6739	Shaft-Planet	308-9929
6P-7704	Carrier-Ring	314-8658
6V-1781	Bearing-Spl Ball	380-1508
6V-2202	Bearing-Spl Ball	380-1574
6V-3831	Seal-O-Ring	436-2657
6Y-1603	Housing-Clutch	438-1818
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-6697	Shaft - Idler	425-9370
7C-9198	Block	419-2303
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522

9CM		
Original Part Number	**Part Name**	**Classic Part Number**
7E-6004	Bearing-Sleeve	417-4520
7E-8926	Head Kt-Cyl	377-5847
7E-9595	Core As-Radiator	396-9926
7E-9907	Spacer-Fp Timing	394-0222
7F-2742	Bearing-Ball	422-6488
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7M-5334	Cone-Roller Brg	420-2505
7M-7219	Bearing-Thrust	384-4816
7N-1572	Cover-Water Pump	377-5854
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4000	Piston	416-2143
7T-3365	Carrier-Planet	388-6563
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-0140	Gear-Drive	399-8546
7W-0205	Core As-Oclr	379-0183
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-3145	Plate	422-7894
7W-5435	Adapter-Nozzle	374-7493
7W-5733	Gasket	421-7333
8F-6058	Bearing-Sleeve	416-5494

9CM		
Original Part Number	**Part Name**	**Classic Part Number**
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-2641	Sleeve	325-6210
8N-8258	Bearing-Sleeve	452-1077
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8R-3946	Collet	308-9841
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1612	Shaft	425-6456
9B-1320	Valve-Check	377-5832
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-5639	Pin	425-6451
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9N-1545	Race-Thrust	394-9205
9N-3668	Base As.-Coolant	419-4718
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-5279	Bearing-Inner	453-3661
9S-8597	Spring	399-8561
9V-0247	Plate	417-4527
9W-2977	Hub As	423-6985
9W-4175	Shaft-Xmsn Input	394-8241

Sales Model 980G (Cont'd.)

9CM		
Original Part Number	Part Name	Classic Part Number
9W-4702	Stator-Converter	308-9939
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
9Y-9497	Bearing-Conn Rod	441-1563
002-1212	Cup-Roller Brg	399-4446
100-2848	Ring-Guide	399-6057
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-8010	Valve	423-5583
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-4563	Gear-Transfer	399-4430
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929
107-5006	Joint Gp-Univ	416-2137
107-5007	Joint Gp-Slip	416-2145
107-5610	Yoke	398-8334
107-9172	Piston	375-2622

9CM		
Original Part Number	Part Name	Classic Part Number
108-2102	Bonnet-Valve	455-3274
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-6633	Pump Gp-Fuel Inj	420-6215
108-7930	Bearing As	377-7463
110-0551	Hub As	416-2146
110-5096	Head As-Cyl	394-0915
111-8181	Cyl Gp-197 864 Y	390-0986
112-5003	Cyl Gp-159 582 Y	393-3654
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8042	Carrier-Planet	390-0916
114-0468	Pin-G.E.T.	443-1203
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-2958	Pin-Lower	393-0939
115-3184	Cap-Lower	395-1324
115-7048	Pin	393-3684
117-0456	Crankshaft As	394-2587
117-6675	Step As	419-0881
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3046	Carrier-Planet	393-1015
129-9907	Impeller-Pump	383-1589
130-2621	Pin As	390-5273
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
133-8890	Race	399-4423
134-0039	Housing-Piston	432-4217
135-4928	Shaft-Water Pump	386-3813
135-5553	Bearing	394-0203
138-4338	Kit-Gasket-T	393-1032
138-6744	Rebuild Kit-Pump	363-7457
139-9173	Gasket Kit	434-7261
141-4617	Kit-Gasket(Acl)	393-0917

9CM		
Original Part Number	Part Name	Classic Part Number
141-9792	Gasket Kit - Ocl	393-3632
142-7526	Gasket Kit	393-0918
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
145-8503	Shaft As-Idler	426-0035
147-1900	Gasket Kit	447-0826
149-2914	Pinion-Dif Bevel	396-9950
150-4637	Pan-Oil	377-5843
150-8459	Kit-Gasket(F)	438-1798
150-8685	Gasket Kit	392-4503
155-5091	Cartridge Gp	422-8124
155-5619	Gasket	382-5054
157-6257	Collar	393-0912
159-3021	Gasket	377-5845
159-8169	Gear-Planet	391-9870
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-9918	Retainer-Bearing	395-1321
164-4891	Plate As.	391-1093
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
176-3900	Accumulator	416-5513
177-9024	Adapter-Damper	299-1956
185-2831	Line As	380-1516
189-3041	Rod As	394-9811
191-4610	Pump Gp-Vane	422-8160
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013

Sales Model 980G (Cont'd.)

9CM		
Original Part Number	**Part Name**	**Classic Part Number**
197-5510	Support As	419-0880
202-3572	Shaft As-Drive	426-0037
208-7534	Case As-Diff	388-6590
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
220-3779	Kit-Gasket(F)	437-1998
226-2018	Kit-Gasket-Acl	393-0921
232-3679	Kit-Gasket (Rs)	437-2039

9CM		
Original Part Number	**Part Name**	**Classic Part Number**
233-9464	Kit-Gasket (Sch)	393-0925
233-9748	Disc-Friction	417-9502
234-1874	Kit-Gasket-Fs	437-8668
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
243-0725	Kit-Dt Gasket	396-9953
243-0727	Kit-Dt Gasket	451-1506
253-1752	Plate-Thrust	379-0170
319-5239	Wheel	396-9956

9CM		
Original Part Number	**Part Name**	**Classic Part Number**
321-5746	Bearing-Main	419-6367
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
430-7619	Adapter-Cla	438-1812

AWH		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9594	Bearing-Cup	377-7401
1S-0057	Plate-Clutch	377-7404
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8439	Pin As	308-9881
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811

AWH		
Original Part Number	**Part Name**	**Classic Part Number**
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2F-8509	Cone-Roller Brg	399-4434
2H-6489	Race-Brg Outer	374-8350
2L-5271	Bearing-Ball	371-4305
2P-5680	Turbine-Conv	308-9942
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-2414	Housing-Clutch	391-9831
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924

AWH		
Original Part Number	**Part Name**	**Classic Part Number**
3P-3246	Shaft-Planet	308-9925
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-9366	Piston-Clutch	391-9861
3R-8530	Boss	425-3454
3S-1262	Retainer	308-9915
3V-4046	Plate-Pressure	380-7470
3V-6515	Link As	394-0186
3V-6648	Pin As	308-9884
4E-0079	Cage-Bearing	434-4387
4E-2250	Housing	399-6043
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4T-9311	Housing	396-0652
4V-2057	Bearing-Spher	419-6019
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-7099	Pin As	361-1698
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307

Sales Model 980G (Cont'd.)

AWH		
Original Part Number	Part Name	Classic Part Number
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7487	Bearing-Aligning	434-3300
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9301	Bearing-Spl Ball	417-4496
5T-5682	Driver	418-9579
6E-5449	Bearing-Sleeve	464-4048
6I-2726	Bearing-Sleeve	419-4757
6I-8500	Plate-Clutch	377-7436
6K-5528	Cup-Roller Brg	447-8059
6N-1931	Plunger	379-0171
6P-0593	Bearing-Roller	386-4959
6P-6739	Shaft-Planet	308-9929
6P-7704	Carrier-Ring	314-8658
6V-1781	Bearing-Spl Ball	380-1508
6V-3831	Seal-O-Ring	436-2657
6Y-1603	Housing-Clutch	438-1818
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257

AWH		
Original Part Number	Part Name	Classic Part Number
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-1309	Bearing-Aligning	360-2275
7J-5131	Trunnion	296-1371
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7K-9639	Bearing-Sleeve	314-8643
7M-5334	Cone-Roller Brg	420-2505
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4000	Piston	416-2143
7T-3365	Carrier-Planet	388-6563
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-3145	Plate	422-7894
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8R-3946	Collet	308-9841
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217

AWH		
Original Part Number	Part Name	Classic Part Number
9G-6744	Bearing-Sleeve	418-1931
9K-5639	Pin	425-6451
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9N-3167	Plate-Block Bot	430-4468
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-5279	Bearing-Inner	453-3661
9V-0247	Plate	417-4527
9W-2977	Hub As	423-6985
9W-4175	Shaft-Xmsn Input	394-8241
9W-4702	Stator-Converter	308-9939
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154

Sales Model 980G (Cont'd.)

AWH		
Original Part Number	**Part Name**	**Classic Part Number**
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929
107-5006	Joint Gp-Univ	416-2137
107-5007	Joint Gp-Slip	416-2145
107-5610	Yoke	398-8334
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
110-0551	Hub As	416-2146
111-8181	Cyl Gp-197 864 Y	390-0986
112-5003	Cyl Gp-159 582 Y	393-3654
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8042	Carrier-Planet	390-0916
114-0468	Pin-G.E.T.	443-1203
115-2958	Pin-Lower	393-0939
115-3184	Cap-Lower	395-1324
115-7048	Pin	393-3684
117-6675	Step As	419-0881
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3046	Carrier-Planet	393-1015
129-9907	Impeller-Pump	383-1589
130-2621	Pin As	390-5273
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-2151	Tensioner	419-4735

AWH		
Original Part Number	**Part Name**	**Classic Part Number**
135-4928	Shaft-Water Pump	386-3813
135-5553	Bearing	394-0203
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
147-1900	Gasket Kit	447-0826
149-2914	Pinion-Dif Bevel	396-9950
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5091	Cartridge Gp	422-8124
155-5619	Gasket	382-5054
157-6257	Collar	393-0912
159-8169	Gear-Planet	391-9870
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-9918	Retainer-Bearing	395-1321
164-4891	Plate As.	391-1093
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
189-3041	Rod As	394-9811
191-4610	Pump Gp-Vane	422-8160

AWH		
Original Part Number	**Part Name**	**Classic Part Number**
197-5510	Support As	419-0880
202-3572	Shaft As-Drive	426-0037
208-7534	Case As-Diff	388-6590
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
232-3679	Kit-Gasket (Rs)	437-2039
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
243-0725	Kit-Dt Gasket	396-9953
243-0727	Kit-Dt Gasket	451-1506
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
319-5239	Wheel	396-9956
321-5746	Bearing-Main	419-6367
325-2721	Kit-Gasket(T)	393-3662
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

AXG		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9594	Bearing-Cup	377-7401

AXG		
Original Part Number	**Part Name**	**Classic Part Number**
1S-0057	Plate-Clutch	377-7404
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916

AXG		
Original Part Number	**Part Name**	**Classic Part Number**
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8439	Pin As	308-9881
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883

Sales Model 980G (Cont'd.)

AXG		
Original Part Number	Part Name	Classic Part Number
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2F-8509	Cone-Roller Brg	399-4434
2H-6489	Race-Brg Outer	374-8350
2L-5271	Bearing-Ball	371-4305
2P-5680	Turbine-Conv	308-9942
3E-6772	Seal-Water	382-8017
3G-7663	Cartridge Gp	422-8120
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-2414	Housing-Clutch	391-9831
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3246	Shaft-Planet	308-9925
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-9366	Piston-Clutch	391-9861
3R-8530	Boss	425-3454
3S-1262	Retainer	308-9915

AXG		
Original Part Number	Part Name	Classic Part Number
3V-4046	Plate-Pressure	380-7470
3V-6515	Link As	394-0186
3V-6648	Pin As	308-9884
4E-0079	Cage-Bearing	434-4387
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4T-9311	Housing	396-0652
4V-2057	Bearing-Spher	419-6019
4V-7099	Pin As	361-1698
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5F-8651	Bearing-Ball	420-3223
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9301	Bearing-Spl Ball	417-4496
5T-5682	Driver	418-9579
6I-2726	Bearing-Sleeve	419-4757
6I-8500	Plate-Clutch	377-7436
6K-5528	Cup-Roller Brg	447-8059
6N-1931	Plunger	379-0171
6P-0593	Bearing-Roller	386-4959
6P-6739	Shaft-Planet	308-9929
6P-7704	Carrier-Ring	314-8658

AXG		
Original Part Number	Part Name	Classic Part Number
6V-1781	Bearing-Spl Ball	380-1508
6V-3831	Seal-O-Ring	436-2657
6Y-1603	Housing-Clutch	438-1818
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7M-5334	Cone-Roller Brg	420-2505
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7S-4000	Piston	416-2143
7T-3365	Carrier-Planet	388-6563
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-3145	Plate	422-7894
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212

Sales Model 980G (Cont'd.)

AXG		
Original Part Number	**Part Name**	**Classic Part Number**
8R-3946	Collet	308-9841
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-5639	Pin	425-6451
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9N-3167	Plate-Block Bot	430-4468
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-5279	Bearing-Inner	453-3661
9V-0247	Plate	417-4527
9W-2977	Hub As	423-6985
9W-4175	Shaft-Xmsn Input	394-8241
9W-4702	Stator-Converter	308-9939
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058

AXG		
Original Part Number	**Part Name**	**Classic Part Number**
104-8584	Housing-Rgltr	419-4725
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929
107-5006	Joint Gp-Univ	416-2137
107-5007	Joint Gp-Slip	416-2145
107-5610	Yoke	398-8334
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
110-0551	Hub As	416-2146
111-8181	Cyl Gp-197 864 Y	390-0986
112-5003	Cyl Gp-159 582 Y	393-3654
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8042	Carrier-Planet	390-0916
114-0468	Pin-G.E.T.	443-1203
115-2958	Pin-Lower	393-0939
115-3184	Cap-Lower	395-1324
115-7048	Pin	393-3684
117-6675	Step As	419-0881
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3046	Carrier-Planet	393-1015
129-9907	Impeller-Pump	383-1589
130-2621	Pin As	390-5273
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813

AXG		
Original Part Number	**Part Name**	**Classic Part Number**
135-5553	Bearing	394-0203
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
147-1900	Gasket Kit	447-0826
149-2914	Pinion-Dif Bevel	396-9950
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5091	Cartridge Gp	422-8124
155-5619	Gasket	382-5054
157-6257	Collar	393-0912
159-8169	Gear-Planet	391-9870
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-9918	Retainer-Bearing	395-1321
164-4891	Plate As.	391-1093
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
189-3041	Rod As	394-9811
191-4610	Pump Gp-Vane	422-8160
197-5510	Support As	419-0880
202-3572	Shaft As-Drive	426-0037
208-7534	Case As-Diff	388-6590
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
232-3679	Kit-Gasket (Rs)	437-2039
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
243-0725	Kit-Dt Gasket	396-9953
243-0727	Kit-Dt Gasket	451-1506
253-1752	Plate-Thrust	379-0170

Sales Model 980G (Cont'd.)

AXG		
Original Part Number	Part Name	Classic Part Number
278-1365	Arm As-Ui Rkr	433-7507
319-5239	Wheel	396-9956
321-5746	Bearing-Main	419-6367
325-2721	Kit-Gasket(T)	393-3662
328-4240	Arm As-V Rocker	433-0443

AXG		
Original Part Number	Part Name	Classic Part Number
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-6387

AXG		
Original Part Number	Part Name	Classic Part Number
328-5573	Bearing-Conn Rod	419-4665
430-7619	Adapter-Cla	438-1812

AYT		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9594	Bearing-Cup	377-7401
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8439	Pin As	308-9881
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174

AYT		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2F-8509	Cone-Roller Brg	399-4434
2H-6489	Race-Brg Outer	374-8350
2L-5271	Bearing-Ball	371-4305
2P-5680	Turbine-Conv	308-9942
3E-6772	Seal-Water	382-8017
3G-0222	Bearing-Sleeve	374-6512
3G-5285	Bearing-Sleeve	360-2312
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-2414	Housing-Clutch	391-9831
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3246	Shaft-Planet	308-9925
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-9366	Piston-Clutch	391-9861

AYT		
Original Part Number	Part Name	Classic Part Number
3R-8530	Boss	425-3454
3V-6515	Link As	394-0186
4F-2041	Cup-Roller Brg	418-9609
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812
4T-9311	Housing	396-0652
4V-7099	Pin As	361-1698
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9301	Bearing-Spl Ball	417-4496
5T-5682	Driver	418-9579
6I-2726	Bearing-Sleeve	419-4757

Sales Model 980G (Cont'd.)

AYT		
Original Part Number	Part Name	Classic Part Number
6I-8500	Plate-Clutch	377-7436
6K-5528	Cup-Roller Brg	447-8059
6N-1931	Plunger	379-0171
6P-0593	Bearing-Roller	386-4959
6P-6739	Shaft-Planet	308-9929
6P-7704	Carrier-Ring	314-8658
6V-1781	Bearing-Spl Ball	380-1508
6V-3831	Seal-O-Ring	436-2657
6Y-1603	Housing-Clutch	438-1818
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-3216	Bearing	368-0104
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7M-5334	Cone-Roller Brg	420-2505
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-3365	Carrier-Planet	388-6563
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-3145	Plate	422-7894
8N-0788	Cover	440-0849
8N-2104	Bell As-Suction	380-1521
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209

AYT		
Original Part Number	Part Name	Classic Part Number
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8R-3946	Collet	308-9841
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-5639	Pin	425-6451
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9N-3167	Plate-Block Bot	430-4468
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9S-5279	Bearing-Inner	453-3661
9V-0247	Plate	417-4527
9W-2977	Hub As	423-6985
9W-4175	Shaft-Xmsn Input	394-8241
9W-4702	Stator-Converter	308-9939
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567

AYT		
Original Part Number	Part Name	Classic Part Number
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929
107-5006	Joint Gp-Univ	416-2137
107-5007	Joint Gp-Slip	416-2145
107-5610	Yoke	398-8334
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
110-0551	Hub As	416-2146
111-8181	Cyl Gp-197 864 Y	390-0986
112-5003	Cyl Gp-159 582 Y	393-3654
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8042	Carrier-Planet	390-0916
115-2958	Pin-Lower	393-0939
115-3184	Cap-Lower	395-1324
115-7048	Pin	393-3684
117-6675	Step As	419-0881
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3046	Carrier-Planet	393-1015
129-9907	Impeller-Pump	383-1589
130-2621	Pin As	390-5273
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919

Sales Model 980G (Cont'd.)

AYT		
Original Part Number	Part Name	Classic Part Number
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
135-5553	Bearing	394-0203
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
147-1900	Gasket Kit	447-0826
149-2914	Pinion-Dif Bevel	396-9950
150-4637	Pan-Oil	377-5843
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5091	Cartridge Gp	422-8124
155-5619	Gasket	382-5054
157-6257	Collar	393-0912
159-8169	Gear-Planet	391-9870
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-9918	Retainer-Bearing	395-1321

AYT		
Original Part Number	Part Name	Classic Part Number
164-4891	Plate As.	391-1093
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
189-3041	Rod As	394-9811
191-4610	Pump Gp-Vane	422-8160
197-5510	Support As	419-0880
202-3572	Shaft As-Drive	426-0037
208-7534	Case As-Diff	388-6590
211-0592	Bearing - Main	419-6368
213-8621	Kit-Gasket-Wp	437-2003
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665

AYT		
Original Part Number	Part Name	Classic Part Number
217-8938	Tightening-Belt	419-4735
232-3679	Kit-Gasket (Rs)	437-2039
233-9748	Disc-Friction	417-9502
237-9849	Cage-Bearing	443-1201
243-0725	Kit-Dt Gasket	396-9953
243-0727	Kit-Dt Gasket	451-1506
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
319-5239	Wheel	396-9956
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

TLB		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9594	Bearing-Cup	377-7401
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916
1V-8852	Cap	308-9834
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163

TLB		
Original Part Number	Part Name	Classic Part Number
1W-9302	Gear-Crankshaft	386-3059
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2F-8509	Cone-Roller Brg	399-4434
2H-6489	Race-Brg Outer	374-8350
2L-5271	Bearing-Ball	371-4305
2P-5680	Turbine-Conv	308-9942
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3P-2414	Housing-Clutch	391-9831
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820

TLB		
Original Part Number	Part Name	Classic Part Number
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3246	Shaft-Planet	308-9925
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-9366	Piston-Clutch	391-9861
3R-8530	Boss	425-3454
4F-2041	Cup-Roller Brg	418-9609
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4P-2383	Adapter-Inlet	438-1812

Sales Model 980G (Cont'd.)

TLB		
Original Part Number	Part Name	Classic Part Number
4T-9311	Housing	396-0652
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
5P-9301	Bearing-Spl Ball	417-4496
5T-5682	Driver	418-9579
6I-2726	Bearing-Sleeve	419-4757
6I-8500	Plate-Clutch	377-7436
6K-5528	Cup-Roller Brg	447-8059
6N-1931	Plunger	379-0171
6P-0593	Bearing-Roller	386-4959
6P-6739	Shaft-Planet	308-9929
6P-7704	Carrier-Ring	314-8658
6V-1781	Bearing-Spl Ball	380-1508
6V-3831	Seal-O-Ring	436-2657
6Y-1603	Housing-Clutch	438-1818
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257

TLB		
Original Part Number	Part Name	Classic Part Number
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7M-5334	Cone-Roller Brg	420-2505
7N-2156	Bearing-Sleeve	380-7373
7T-3365	Carrier-Planet	388-6563
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-3145	Plate	422-7894
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-5639	Pin	425-6451
9L-5839	Coupling-Exhaust	374-7480
9M-1990	Dowel-Reaction	386-4963
9N-3167	Plate-Block Bot	430-4468
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446

TLB		
Original Part Number	Part Name	Classic Part Number
9P-8626	Gear-Sun	283-5219
9S-5279	Bearing-Inner	453-3661
9V-0247	Plate	417-4527
9W-2977	Hub As	423-6985
9W-4175	Shaft-Xmsn Input	394-8241
9W-4702	Stator-Converter	308-9939
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
102-8501	Manifold-Exhaust	377-5853
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929
107-5006	Joint Gp-Univ	416-2137
107-5007	Joint Gp-Slip	416-2145
107-5610	Yoke	398-8334
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
110-0551	Hub As	416-2146
112-5585	Shaft-Planet	308-9932

Sales Model 980G (Cont'd.)

TLB		
Original Part Number	Part Name	Classic Part Number
112-7309	Shaft-Planet	380-7521
112-8042	Carrier-Planet	390-0916
115-2958	Pin-Lower	393-0939
115-3184	Cap-Lower	395-1324
117-6675	Step As	419-0881
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3046	Carrier-Planet	393-1015
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
149-2914	Pinion-Dif Bevel	396-9950

TLB		
Original Part Number	Part Name	Classic Part Number
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-8169	Gear-Planet	391-9870
160-9874	Kit-Gasket-Scl	386-3048
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-9918	Retainer-Bearing	395-1321
164-4891	Plate As.	391-1093
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
197-5510	Support As	419-0880
202-3572	Shaft As-Drive	426-0037
208-7534	Case As-Diff	388-6590
211-0592	Bearing - Main	419-6368

TLB		
Original Part Number	Part Name	Classic Part Number
213-8621	Kit-Gasket-Wp	437-2003
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
217-8938	Tightening-Belt	419-4735
232-3679	Kit-Gasket (Rs)	437-2039
233-9748	Disc-Friction	417-9502
237-9849	Cage-Bearing	443-1201
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
319-5239	Wheel	396-9956
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
430-7619	Adapter-Cla	438-1812

Sales Model 980H

A8J		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916
1V-8240	Bearing-Sleeve	308-9807

A8J		
Original Part Number	Part Name	Classic Part Number
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8439	Pin As	308-9881
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944

A8J		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2F-8509	Cone-Roller Brg	399-4434
2H-6489	Race-Brg Outer	374-8350
2P-5680	Turbine-Conv	308-9942
3E-6772	Seal-Water	382-8017
3G-5285	Bearing-Sleeve	360-2312
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820

Sales Model 980H (Cont'd.)

A8J		
Original Part Number	**Part Name**	**Classic Part Number**
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3246	Shaft-Planet	308-9925
3P-3735	Housing As	391-9830
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-9366	Piston-Clutch	391-9861
3R-8530	Boss	425-3454
3V-6515	Link As	394-0186
4B-7255	Cone-Bearing	386-4951
4F-2041	Cup-Roller Brg	418-9609
4N-0685	Bearing-Sleeve	379-0191
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4T-9311	Housing	396-0652
4V-2057	Bearing-Spher	419-6019
4V-7099	Pin As	361-1698
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-2726	Bearing-Sleeve	419-4757
6I-3066	Gasket-Cyl Head	380-1518

A8J		
Original Part Number	**Part Name**	**Classic Part Number**
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6K-5528	Cup-Roller Brg	447-8059
6N-1931	Plunger	379-0171
6P-0593	Bearing-Roller	386-4959
6P-6739	Shaft-Planet	308-9929
6P-7704	Carrier-Ring	314-8658
6V-3831	Seal-O-Ring	436-2657
6Y-1603	Housing-Clutch	438-1818
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-7652	Cup-Rlr Brg	399-6067
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7M-5334	Cone-Roller Brg	420-2505
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-3145	Plate	422-7894
7W-5733	Gasket	421-7333
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212

A8J		
Original Part Number	**Part Name**	**Classic Part Number**
8R-3946	Collet	308-9841
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-5639	Pin	425-6451
9N-3167	Plate-Block Bot	430-4468
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-5279	Bearing-Inner	453-3661
9W-2977	Hub As	423-6985
9W-4702	Stator-Converter	308-9939
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9Y-2988	Breather As	361-1716
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929
107-5006	Joint Gp-Univ	416-2137

Sales Model 980H (Cont'd.)

A8J		
Original Part Number	Part Name	Classic Part Number
107-5007	Joint Gp-Slip	416-2145
107-5610	Yoke	398-8334
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
110-0551	Hub As	416-2146
111-8181	Cyl Gp-197 864 Y	390-0986
112-5003	Cyl Gp-159 582 Y	393-3654
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8042	Carrier-Planet	390-0916
115-2958	Pin-Lower	393-0939
115-3184	Cap-Lower	395-1324
115-7048	Pin	393-3684
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3046	Carrier-Planet	393-1015
129-9907	Impeller-Pump	383-1589
130-2621	Pin As	390-5273
131-7123	Bearing-Sleeve	422-6919

A8J		
Original Part Number	Part Name	Classic Part Number
133-3359	Manifold-Exhaust	419-4730
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
135-5553	Bearing	394-0203
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052
147-1900	Gasket Kit	447-0826
150-1916	Manifold-Exh	395-1322
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
157-6257	Collar	393-0912
159-8169	Gear-Planet	391-9870
160-9874	Kit-Gasket-Scl	386-3048
161-9918	Retainer-Bearing	395-1321
164-4891	Plate As.	391-1093
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898

A8J		
Original Part Number	Part Name	Classic Part Number
174-3405	Yoke As	398-2929
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
189-3041	Rod As	394-9811
208-7534	Case As-Diff	388-6590
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
233-9748	Disc-Friction	417-9502
237-9849	Cage-Bearing	443-1201
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
319-5239	Wheel	396-9956
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

JMS		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916
1V-8240	Bearing-Sleeve	308-9807

JMS		
Original Part Number	Part Name	Classic Part Number
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8439	Pin As	308-9881
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2D-5658	Bearing-Ball	301-4628

JMS		
Original Part Number	Part Name	Classic Part Number
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2F-8509	Cone-Roller Brg	399-4434
2H-6489	Race-Brg Outer	374-8350
2P-5680	Turbine-Conv	308-9942
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861

Sales Model 980H (Cont'd.)

JMS		
Original Part Number	Part Name	Classic Part Number
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3246	Shaft-Planet	308-9925
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-9366	Piston-Clutch	391-9861
3R-8530	Boss	425-3454
3S-1262	Retainer	308-9915
3V-6515	Link As	394-0186
3V-6648	Pin As	308-9884
4B-7255	Cone-Bearing	386-4951
4F-2041	Cup-Roller Brg	418-9609
4N-0685	Bearing-Sleeve	379-0191
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4T-9311	Housing	396-0652
4V-2057	Bearing-Spher	419-6019
4V-7099	Pin As	361-1698
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436

JMS		
Original Part Number	Part Name	Classic Part Number
6K-5528	Cup-Roller Brg	447-8059
6N-1931	Plunger	379-0171
6P-0593	Bearing-Roller	386-4959
6P-6739	Shaft-Planet	308-9929
6P-7704	Carrier-Ring	314-8658
6V-3831	Seal-O-Ring	436-2657
6Y-1603	Housing-Clutch	438-1818
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-7652	Cup-Rlr Brg	399-6067
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-5996	Rod As-Conn	379-8864
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7K-9639	Bearing-Sleeve	314-8643
7M-5334	Cone-Roller Brg	420-2505
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-3145	Plate	422-7894
7W-5733	Gasket	421-7333
8N-1726	Rod As-Conn	379-8866
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445

JMS		
Original Part Number	Part Name	Classic Part Number
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8R-3946	Collet	308-9841
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-5639	Pin	425-6451
9N-3167	Plate-Block Bot	430-4468
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-5279	Bearing-Inner	453-3661
9W-2977	Hub As	423-6985
9W-4702	Stator-Converter	308-9939
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9Y-2988	Breather As	361-1716
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929

Sales Model 980H (Cont'd.)

JMS		
Original Part Number	Part Name	Classic Part Number
107-5006	Joint Gp-Univ	416-2137
107-5007	Joint Gp-Slip	416-2145
107-5610	Yoke	398-8334
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
110-0551	Hub As	416-2146
111-8181	Cyl Gp-197 864 Y	390-0986
112-5003	Cyl Gp-159 582 Y	393-3654
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8042	Carrier-Planet	390-0916
114-0468	Pin-G.E.T.	443-1203
115-2958	Pin-Lower	393-0939
115-3184	Cap-Lower	395-1324
115-7048	Pin	393-3684
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3046	Carrier-Planet	393-1015
129-9907	Impeller-Pump	383-1589
130-2621	Pin As	390-5273

JMS		
Original Part Number	Part Name	Classic Part Number
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
135-5553	Bearing	394-0203
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052
147-1900	Gasket Kit	447-0826
150-1916	Manifold-Exh	395-1322
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
157-6257	Collar	393-0912
159-8169	Gear-Planet	391-9870
160-9874	Kit-Gasket-Scl	386-3048
161-9918	Retainer-Bearing	395-1321
164-4891	Plate As.	391-1093
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898

JMS		
Original Part Number	Part Name	Classic Part Number
174-3405	Yoke As	398-2929
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
189-3041	Rod As	394-9811
208-7534	Case As-Diff	388-6590
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
308-1845	Seal-Wiper	472-8032
319-5239	Wheel	396-9956
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

KZL		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916
1V-8240	Bearing-Sleeve	308-9807

KZL		
Original Part Number	Part Name	Classic Part Number
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8439	Pin As	308-9881
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944

KZL		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2F-8509	Cone-Roller Brg	399-4434
2H-6489	Race-Brg Outer	374-8350
2P-5680	Turbine-Conv	308-9942
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994

Sales Model 980H (Cont'd.)

KZL		
Original Part Number	Part Name	Classic Part Number
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3246	Shaft-Planet	308-9925
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-9366	Piston-Clutch	391-9861
3R-8530	Boss	425-3454
3S-1262	Retainer	308-9915
3V-6515	Link As	394-0186
3V-6648	Pin As	308-9884
4B-7255	Cone-Bearing	386-4951
4F-2041	Cup-Roller Brg	418-9609
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4T-9311	Housing	396-0652
4V-2057	Bearing-Spher	419-6019
4V-7099	Pin As	361-1698
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8500	Plate-Clutch	377-7436
6K-5528	Cup-Roller Brg	447-8059
6N-1931	Plunger	379-0171
6P-0593	Bearing-Roller	386-4959
6P-6739	Shaft-Planet	308-9929

KZL		
Original Part Number	Part Name	Classic Part Number
6P-7704	Carrier-Ring	314-8658
6V-3831	Seal-O-Ring	436-2657
6Y-1603	Housing-Clutch	438-1818
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-7652	Cup-Rlr Brg	399-6067
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7M-5334	Cone-Roller Brg	420-2505
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-3145	Plate	422-7894
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8R-3946	Collet	308-9841
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0280	Piston	283-5213

KZL		
Original Part Number	Part Name	Classic Part Number
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-5639	Pin	425-6451
9N-3167	Plate-Block Bot	430-4468
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-5279	Bearing-Inner	453-3661
9W-2977	Hub As	423-6985
9W-4702	Stator-Converter	308-9939
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9Y-2988	Breather As	361-1716
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929
107-5006	Joint Gp-Univ	416-2137
107-5007	Joint Gp-Slip	416-2145
107-5610	Yoke	398-8334
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
110-0551	Hub As	416-2146
111-8181	Cyl Gp-197 864 Y	390-0986

Sales Model 980H (Cont'd.)

KZL		
Original Part Number	Part Name	Classic Part Number
112-5003	Cyl Gp-159 582 Y	393-3654
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8042	Carrier-Planet	390-0916
115-2958	Pin-Lower	393-0939
115-3184	Cap-Lower	395-1324
115-7048	Pin	393-3684
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3046	Carrier-Planet	393-1015
129-9907	Impeller-Pump	383-1589
130-2621	Pin As	390-5273
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813

KZL		
Original Part Number	Part Name	Classic Part Number
135-5553	Bearing	394-0203
138-9381	Plate-Spacer	424-7052
150-1916	Manifold-Exh	395-1322
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
157-6257	Collar	393-0912
159-8169	Gear-Planet	391-9870
160-9874	Kit-Gasket-Scl	386-3048
161-9918	Retainer-Bearing	395-1321
164-4891	Plate As.	391-1093
167-8126	Damper As	382-8019
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656

KZL		
Original Part Number	Part Name	Classic Part Number
189-3041	Rod As	394-9811
208-7534	Case As-Diff	388-6590
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
319-5239	Wheel	396-9956
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

MHG		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809

MHG		
Original Part Number	Part Name	Classic Part Number
1V-8439	Pin As	308-9881
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2F-8509	Cone-Roller Brg	399-4434
2H-6489	Race-Brg Outer	374-8350

MHG		
Original Part Number	Part Name	Classic Part Number
2P-5680	Turbine-Conv	308-9942
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3246	Shaft-Planet	308-9925
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-9366	Piston-Clutch	391-9861
3R-8530	Boss	425-3454
3S-1262	Retainer	308-9915

Sales Model 980H (Cont'd.)

MHG		
Original Part Number	Part Name	Classic Part Number
3V-6515	Link As	394-0186
3V-6648	Pin As	308-9884
4B-7255	Cone-Bearing	386-4951
4F-2041	Cup-Roller Brg	418-9609
4N-0685	Bearing-Sleeve	379-0191
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4T-9311	Housing	396-0652
4V-2057	Bearing-Spher	419-6019
4V-7099	Pin As	361-1698
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-2726	Bearing-Sleeve	419-4757
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6I-8500	Plate-Clutch	377-7436
6K-5528	Cup-Roller Brg	447-8059
6N-1931	Plunger	379-0171
6P-0593	Bearing-Roller	386-4959
6P-6739	Shaft-Planet	308-9929
6P-7704	Carrier-Ring	314-8658
6V-3831	Seal-O-Ring	436-2657
6Y-1603	Housing-Clutch	438-1818

MHG		
Original Part Number	Part Name	Classic Part Number
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-7652	Cup-Rlr Brg	399-6067
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-5996	Rod As-Conn	379-8864
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7M-5334	Cone-Roller Brg	420-2505
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-3145	Plate	422-7894
7W-5733	Gasket	421-7333
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8R-3946	Collet	308-9841
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214

MHG		
Original Part Number	Part Name	Classic Part Number
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-5639	Pin	425-6451
9N-3167	Plate-Block Bot	430-4468
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-5279	Bearing-Inner	453-3661
9V-7710	Univ Joint As	394-8234
9W-2977	Hub As	423-6985
9W-4702	Stator-Converter	308-9939
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9Y-2988	Breather As	361-1716
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929
107-5006	Joint Gp-Univ	416-2137
107-5007	Joint Gp-Slip	416-2145
107-5610	Yoke	398-8334
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
110-0551	Hub As	416-2146
111-8181	Cyl Gp-197 864 Y	390-0986

Sales Model 980H (Cont'd.)

MHG		
Original Part Number	**Part Name**	**Classic Part Number**
112-5003	Cyl Gp-159 582 Y	393-3654
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8042	Carrier-Planet	390-0916
114-0468	Pin-G.E.T.	443-1203
115-2958	Pin-Lower	393-0939
115-3184	Cap-Lower	395-1324
115-7048	Pin	393-3684
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3046	Carrier-Planet	393-1015
129-9907	Impeller-Pump	383-1589
130-2621	Pin As	390-5273
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813

MHG		
Original Part Number	**Part Name**	**Classic Part Number**
135-5553	Bearing	394-0203
138-6744	Rebuild Kit-Pump	363-7457
138-9381	Plate-Spacer	424-7052
147-1900	Gasket Kit	447-0826
150-1916	Manifold-Exh	395-1322
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
157-6257	Collar	393-0912
159-8169	Gear-Planet	391-9870
160-9874	Kit-Gasket-Scl	386-3048
161-9918	Retainer-Bearing	395-1321
164-4891	Plate As.	391-1093
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
177-9024	Adapter-Damper	299-1956

MHG		
Original Part Number	**Part Name**	**Classic Part Number**
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
189-3041	Rod As	394-9811
208-7534	Case As-Diff	388-6590
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
319-5239	Wheel	396-9956
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

MKP		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809

MKP		
Original Part Number	**Part Name**	**Classic Part Number**
1V-8439	Pin As	308-9881
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2F-8509	Cone-Roller Brg	399-4434
2H-6489	Race-Brg Outer	374-8350

MKP		
Original Part Number	**Part Name**	**Classic Part Number**
2P-5680	Turbine-Conv	308-9942
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3246	Shaft-Planet	308-9925
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-3739	Carrier As	431-4032
3P-7489	Plate-Clutch	377-7423
3P-9366	Piston-Clutch	391-9861
3R-8530	Boss	425-3454

Sales Model 980H (Cont'd.)

MKP		
Original Part Number	Part Name	Classic Part Number
3S-1262	Retainer	308-9915
3V-6515	Link As	394-0186
4B-7255	Cone-Bearing	386-4951
4F-2041	Cup-Roller Brg	418-9609
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4T-9311	Housing	396-0652
4V-2057	Bearing-Spher	419-6019
4V-7099	Pin As	361-1698
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8500	Plate-Clutch	377-7436
6K-5528	Cup-Roller Brg	447-8059
6N-1931	Plunger	379-0171
6P-0593	Bearing-Roller	386-4959
6P-6739	Shaft-Planet	308-9929
6P-7704	Carrier-Ring	314-8658
6V-3831	Seal-O-Ring	436-2657
6Y-1603	Housing-Clutch	438-1818
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-7652	Cup-Rlr Brg	399-6067
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-5665	Elbow-90 Deg	399-8547

MKP		
Original Part Number	Part Name	Classic Part Number
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7K-9639	Bearing-Sleeve	314-8643
7M-5334	Cone-Roller Brg	420-2505
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7W-3145	Plate	422-7894
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8R-3946	Collet	308-9841
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-5639	Pin	425-6451
9N-3167	Plate-Block Bot	430-4468
9P-7757	Gear-Sun	283-5218

MKP		
Original Part Number	Part Name	Classic Part Number
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-5279	Bearing-Inner	453-3661
9W-2977	Hub As	423-6985
9W-4702	Stator-Converter	308-9939
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9Y-2988	Breather As	361-1716
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929
107-5006	Joint Gp-Univ	416-2137
107-5007	Joint Gp-Slip	416-2145
107-5610	Yoke	398-8334
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
110-0551	Hub As	416-2146
111-8181	Cyl Gp-197 864 Y	390-0986
112-5003	Cyl Gp-159 582 Y	393-3654
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8042	Carrier-Planet	390-0916
115-2958	Pin-Lower	393-0939
115-3184	Cap-Lower	395-1324
115-7048	Pin	393-3684
127-6356	Cover As.-Pump	420-8566

Sales Model 980H (Cont'd.)

MKP		
Original Part Number	Part Name	Classic Part Number
128-2922	Kit-Gasket (Wp)	386-3814
129-3046	Carrier-Planet	393-1015
129-9907	Impeller-Pump	383-1589
130-2621	Pin As	390-5273
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
135-5553	Bearing	394-0203
138-9381	Plate-Spacer	424-7052
150-1916	Manifold-Exh	395-1322
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107

MKP		
Original Part Number	Part Name	Classic Part Number
155-5619	Gasket	382-5054
157-6257	Collar	393-0912
159-8169	Gear-Planet	391-9870
160-9874	Kit-Gasket-Scl	386-3048
161-9918	Retainer-Bearing	395-1321
164-4891	Plate As.	391-1093
167-8126	Damper As	382-8019
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
189-3041	Rod As	394-9811
208-7534	Case As-Diff	388-6590

MKP		
Original Part Number	Part Name	Classic Part Number
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
217-8938	Tightening-Belt	419-4735
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
319-5239	Wheel	396-9956
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

PF8		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1534	Carrier-Ring	386-4916
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8439	Pin As	308-9881
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883

PF8		
Original Part Number	Part Name	Classic Part Number
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2F-8509	Cone-Roller Brg	399-4434
2H-6489	Race-Brg Outer	374-8350
2P-5680	Turbine-Conv	308-9942
3E-6772	Seal-Water	382-8017
3J-2903	Cover	422-6922
3K-2511	Dowel-Reaction	383-2126
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468

PF8		
Original Part Number	Part Name	Classic Part Number
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3246	Shaft-Planet	308-9925
3P-3735	Housing As	391-9830
3P-7489	Plate-Clutch	377-7423
3P-9366	Piston-Clutch	391-9861
3R-8530	Boss	425-3454
3V-6515	Link As	394-0186
4F-2041	Cup-Roller Brg	418-9609
4N-2514	Gear-Flywheel	421-7283
4N-4668	Breather-Engine	396-7271
4P-2383	Adapter-Inlet	438-1812
4T-9311	Housing	396-0652
4V-2057	Bearing-Spher	419-6019
4V-7099	Pin As	361-1698
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934

Sales Model 980H (Cont'd.)

PF8		
Original Part Number	Part Name	Classic Part Number
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8500	Plate-Clutch	377-7436
6K-5528	Cup-Roller Brg	447-8059
6N-1931	Plunger	379-0171
6P-6739	Shaft-Planet	308-9929
6P-7704	Carrier-Ring	314-8658
6V-3831	Seal-O-Ring	436-2657
6Y-1603	Housing-Clutch	438-1818
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-9960	Mount As.	376-3639
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-8893	Cone-Roller Brg	374-1846
7K-5448	Cup-Bearing	415-1922
7M-5334	Cone-Roller Brg	420-2505
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663

PF8		
Original Part Number	Part Name	Classic Part Number
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8P-9507	Piston-Clutch	283-5212
8R-3946	Collet	308-9841
8R-7425	Retainer	308-9917
8S-6511	Bearing-Sleeve	380-7372
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-5639	Pin	425-6451
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-5279	Bearing-Inner	453-3661
9W-2977	Hub As	423-6985
9W-4702	Stator-Converter	308-9939
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929
107-5006	Joint Gp-Univ	416-2137

PF8		
Original Part Number	Part Name	Classic Part Number
107-5007	Joint Gp-Slip	416-2145
107-5610	Yoke	398-8334
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
110-0551	Hub As	416-2146
111-8181	Cyl Gp-197 864 Y	390-0986
112-5003	Cyl Gp-159 582 Y	393-3654
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8042	Carrier-Planet	390-0916
115-2958	Pin-Lower	393-0939
115-3184	Cap-Lower	395-1324
115-7048	Pin	393-3684
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-3046	Carrier-Planet	393-1015
129-9907	Impeller-Pump	383-1589
130-2621	Pin As	390-5273
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-2151	Tensioner	419-4735
135-4928	Shaft-Water Pump	386-3813
135-5553	Bearing	394-0203
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
157-6257	Collar	393-0912
159-8169	Gear-Planet	391-9870
160-9874	Kit-Gasket-Scl	386-3048
161-9918	Retainer-Bearing	395-1321
164-4891	Plate As.	391-1093
167-8126	Damper As	382-8019
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055

Sales Model 980H (Cont'd.)

PF8		
Original Part Number	Part Name	Classic Part Number
187-8979	Gear As	393-3656
189-3041	Rod As	394-9811
208-7534	Case As-Diff	388-6590
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914

PF8		
Original Part Number	Part Name	Classic Part Number
217-8938	Tightening-Belt	419-4735
233-9748	Disc-Friction	417-9502
237-9849	Cage-Bearing	443-1201
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170

PF8		
Original Part Number	Part Name	Classic Part Number
278-1365	Arm As-Ui Rkr	433-7507
319-5239	Wheel	396-9956
328-4240	Arm As-V Rocker	433-0443
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model 980K

GTZ		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1534	Carrier-Ring	386-4916
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8439	Pin As	308-9881
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810

GTZ		
Original Part Number	Part Name	Classic Part Number
1V-9148	Bearing-Sleeve	308-9811
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2F-8509	Cone-Roller Brg	399-4434
2H-6489	Race-Brg Outer	374-8350
2P-5680	Turbine-Conv	308-9942
3K-2511	Dowel-Reaction	383-2126
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3246	Shaft-Planet	308-9925
3P-3735	Housing As	391-9830
3P-7489	Plate-Clutch	377-7423
3R-8530	Boss	425-3454
3T-6175	Gear-Transfer	398-8351
3V-6515	Link As	394-0186
4B-7255	Cone-Bearing	386-4951

GTZ		
Original Part Number	Part Name	Classic Part Number
4F-2041	Cup-Roller Brg	418-9609
4V-7099	Pin As	361-1698
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8500	Plate-Clutch	377-7436
6K-5528	Cup-Roller Brg	447-8059
6P-6739	Shaft-Planet	308-9929
6P-7704	Carrier-Ring	314-8658
6Y-1603	Housing-Clutch	438-1818
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-7652	Cup-Rlr Brg	399-6067
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857

Sales Model 980K (Cont'd.)

GTZ		
Original Part Number	**Part Name**	**Classic Part Number**
7G-5746	Housing-Clutch	392-4520
7G-7218	Carrier-Planet	283-5205
7M-5334	Cone-Roller Brg	420-2505
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8R-3946	Collet	308-9841
8R-7425	Retainer	308-9917
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0284	Housing-Clutch	283-5214
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-5639	Pin	425-6451
9P-5531	Gear-Sun	417-9499
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-5279	Bearing-Inner	453-3661
9S-7949	Cup-Roller Brg	420-6531

GTZ		
Original Part Number	**Part Name**	**Classic Part Number**
9W-1572	Shaft-Xmsn Input	419-1864
9W-2977	Hub As	423-6985
9W-4702	Stator-Converter	308-9939
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929
107-5006	Joint Gp-Univ	416-2137
107-5007	Joint Gp-Slip	416-2145
107-5610	Yoke	398-8334
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
110-0551	Hub As	416-2146

GTZ		
Original Part Number	**Part Name**	**Classic Part Number**
112-5585	Shaft-Planet	308-9932
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
112-8042	Carrier-Planet	390-0916
114-0468	Pin-G.E.T.	443-1203
115-2958	Pin-Lower	393-0939
115-3184	Cap-Lower	395-1324
115-7048	Pin	393-3684
124-0501	Cone-Spl Tapered	399-4441
124-0502	Cup-Spl Tapered	416-2161
124-0503	Cone-Spl Tapered	418-9604
129-3046	Carrier-Planet	393-1015
130-2621	Pin As	390-5273
159-8169	Gear-Planet	391-9870
161-9918	Retainer-Bearing	395-1321
164-4891	Plate As.	391-1093
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
208-7534	Case As-Diff	388-6590
213-8734	Cover-Transfer	420-3217
233-9748	Disc-Friction	417-9502
237-9849	Cage-Bearing	443-1201
319-5239	Wheel	396-9956
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

NEP		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797

NEP		
Original Part Number	**Part Name**	**Classic Part Number**
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1534	Carrier-Ring	386-4916
1V-8240	Bearing-Sleeve	308-9807

NEP		
Original Part Number	**Part Name**	**Classic Part Number**
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8439	Pin As	308-9881
1V-8852	Cap	308-9834
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944

Sales Model 980K (Cont'd.)

NEP		
Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2F-8509	Cone-Roller Brg	399-4434
2H-6489	Race-Brg Outer	374-8350
2P-5680	Turbine-Conv	308-9942
3K-2511	Dowel-Reaction	383-2126
3P-2415	Carrier-Planet	396-0653
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3246	Shaft-Planet	308-9925
3P-3735	Housing As	391-9830
3P-7489	Plate-Clutch	377-7423
3R-8530	Boss	425-3454
3V-6515	Link As	394-0186
4B-7255	Cone-Bearing	386-4951
4F-2041	Cup-Roller Brg	418-9609
4V-7099	Pin As	361-1698
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8500	Plate-Clutch	377-7436
6K-5528	Cup-Roller Brg	447-8059
6P-6739	Shaft-Planet	308-9929
6P-7704	Carrier-Ring	314-8658
6Y-1603	Housing-Clutch	438-1818

NEP		
Original Part Number	Part Name	Classic Part Number
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-7652	Cup-Rlr Brg	399-6067
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7M-5334	Cone-Roller Brg	420-2505
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8R-3946	Collet	308-9841
8R-7425	Retainer	308-9917
9G-0284	Housing-Clutch	283-5214
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-5639	Pin	425-6451
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-5279	Bearing-Inner	453-3661
9W-2977	Hub As	423-6985
9W-4702	Stator-Converter	308-9939
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
002-1212	Cup-Roller Brg	399-4446

NEP		
Original Part Number	Part Name	Classic Part Number
100-8010	Valve	423-5583
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929
107-5006	Joint Gp-Univ	416-2137
107-5007	Joint Gp-Slip	416-2145
107-5610	Yoke	398-8334
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
110-0551	Hub As	416-2146
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8042	Carrier-Planet	390-0916
115-2958	Pin-Lower	393-0939
115-3184	Cap-Lower	395-1324
115-7048	Pin	393-3684
129-3046	Carrier-Planet	393-1015
130-2621	Pin As	390-5273
159-8169	Gear-Planet	391-9870
161-9918	Retainer-Bearing	395-1321
164-4891	Plate As.	391-1093
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
208-7534	Case As-Diff	388-6590
213-8734	Cover-Transfer	420-3217
233-9748	Disc-Friction	417-9502
237-9849	Cage-Bearing	443-1201
319-5239	Wheel	396-9956
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model 980K (Cont'd.)

W7K		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1534	Carrier-Ring	386-4916
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8439	Pin As	308-9881
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2F-8509	Cone-Roller Brg	399-4434
2H-6489	Race-Brg Outer	374-8350
2P-5680	Turbine-Conv	308-9942
3K-2511	Dowel-Reaction	383-2126

W7K		
Original Part Number	**Part Name**	**Classic Part Number**
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3246	Shaft-Planet	308-9925
3P-3505	Shaft-Brake	384-3477
3P-3735	Housing As	391-9830
3P-7489	Plate-Clutch	377-7423
3R-8530	Boss	425-3454
3S-1262	Retainer	308-9915
3T-6175	Gear-Transfer	398-8351
3V-6515	Link As	394-0186
4B-7255	Cone-Bearing	386-4951
4F-2041	Cup-Roller Brg	418-9609
4V-2057	Bearing-Spher	419-6019
4V-7099	Pin As	361-1698
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8500	Plate-Clutch	377-7436
6K-5528	Cup-Roller Brg	447-8059
6P-6739	Shaft-Planet	308-9929
6P-7704	Carrier-Ring	314-8658
6Y-1603	Housing-Clutch	438-1818
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-7652	Cup-Rlr Brg	399-6067

W7K		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7G-7218	Carrier-Planet	283-5205
7K-9639	Bearing-Sleeve	314-8643
7M-5334	Cone-Roller Brg	420-2505
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2051	Plate-Clutch	385-6116
8R-3946	Collet	308-9841
8R-7425	Retainer	308-9917
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9G-0284	Housing-Clutch	283-5214
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-5639	Pin	425-6451
9P-5531	Gear-Sun	417-9499
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-5279	Bearing-Inner	453-3661
9S-7949	Cup-Roller Brg	420-6531
9W-1572	Shaft-Xmsn Input	419-1864
9W-2977	Hub As	423-6985
9W-4702	Stator-Converter	308-9939
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846

Sales Model 980K (Cont'd.)

W7K		
Original Part Number	Part Name	Classic Part Number
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
002-1212	Cup-Roller Brg	399-4446
100-8010	Valve	423-5583
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929
107-5006	Joint Gp-Univ	416-2137

W7K		
Original Part Number	Part Name	Classic Part Number
107-5007	Joint Gp-Slip	416-2145
107-5610	Yoke	398-8334
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
110-0551	Hub As	416-2146
112-5585	Shaft-Planet	308-9932
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
112-8042	Carrier-Planet	390-0916
114-0468	Pin-G.E.T.	443-1203
115-2958	Pin-Lower	393-0939
115-3184	Cap-Lower	395-1324
115-7048	Pin	393-3684
124-0501	Cone-Spl Tapered	399-4441
124-0502	Cup-Spl Tapered	416-2161
124-0503	Cone-Spl Tapered	418-9604

W7K		
Original Part Number	Part Name	Classic Part Number
129-3046	Carrier-Planet	393-1015
130-2621	Pin As	390-5273
159-8169	Gear-Planet	391-9870
161-9918	Retainer-Bearing	395-1321
164-4891	Plate As.	391-1093
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
208-7534	Case As-Diff	388-6590
213-8734	Cover-Transfer	420-3217
233-9748	Disc-Friction	417-9502
236-8675	Disc-Friction	428-7202
237-9849	Cage-Bearing	443-1201
319-5239	Wheel	396-9956
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model 980L

D8Z		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
2A-4429	Lock-Retainer	379-0174
2D-6511	Cup-Roller Brg	377-7417
5F-2465	Cup-Roller Brg	447-8060
5T-5682	Driver	418-9579
6K-5528	Cup-Roller Brg	447-8059
7M-5334	Cone-Roller Brg	420-2505

D8Z		
Original Part Number	Part Name	Classic Part Number
8H-9789	Bearing-Ball	374-8342
8R-7425	Retainer	308-9917
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154

D8Z		
Original Part Number	Part Name	Classic Part Number
110-0551	Hub As	416-2146
129-3046	Carrier-Planet	393-1015
159-8169	Gear-Planet	391-9870
319-5239	Wheel	396-9956

Sales Model 980M

KRS		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913

KRS		
Original Part Number	Part Name	Classic Part Number
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-3958	Bearing-Needle	434-6114

KRS		
Original Part Number	Part Name	Classic Part Number
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797

Sales Model 980M (Cont'd.)

KRS		
Original Part Number	Part Name	Classic Part Number
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8439	Pin As	308-9881
1V-8852	Cap	308-9834
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2H-6489	Race-Brg Outer	374-8350
2W-7213	Bearing-Sleeve	419-4667
2W-8494	Pulley-Alt	295-5692
3K-2511	Dowel-Reaction	383-2126
3P-2415	Carrier-Planet	396-0653
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3246	Shaft-Planet	308-9925
3P-3735	Housing As	391-9830
3R-8530	Boss	425-3454
3V-6515	Link As	394-0186
4B-7255	Cone-Bearing	386-4951
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4F-2041	Cup-Roller Brg	418-9609

KRS		
Original Part Number	Part Name	Classic Part Number
4N-2514	Gear-Flywheel	421-7283
4N-4577	Muffler As.	308-9877
4V-7099	Pin As	361-1698
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6K-5528	Cup-Roller Brg	447-8059
6P-6739	Shaft-Planet	308-9929
6P-7704	Carrier-Ring	314-8658
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-7652	Cup-Rlr Brg	399-6067
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7M-5334	Cone-Roller Brg	420-2505
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8R-7425	Retainer	308-9917
8S-9075	Bearing-Cone	418-9612

KRS		
Original Part Number	Part Name	Classic Part Number
8S-9076	Cup-Bearing	418-9613
9D-7924	Mount As	360-2356
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-5279	Bearing-Inner	453-3661
9S-7148	Cap As-Rain	378-3994
9W-2977	Hub As	423-6985
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
100-8010	Valve	423-5583
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5006	Joint Gp-Univ	416-2137
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
110-0551	Hub As	416-2146
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8042	Carrier-Planet	390-0916
115-2958	Pin-Lower	393-0939
115-3184	Cap-Lower	395-1324
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
124-0502	Cup-Spl Tapered	416-2161
129-3046	Carrier-Planet	393-1015
130-2621	Pin As	390-5273
159-8169	Gear-Planet	391-9870
161-3411	Gasket	394-0896
161-9918	Retainer-Bearing	395-1321

Sales Model 980M (Cont'd.)

KRS		
Original Part Number	Part Name	Classic Part Number
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929

KRS		
Original Part Number	Part Name	Classic Part Number
208-7534	Case As-Diff	388-6590
213-8734	Cover-Transfer	420-3217
233-9748	Disc-Friction	417-9502

KRS		
Original Part Number	Part Name	Classic Part Number
237-9849	Cage-Bearing	443-1201
319-5239	Wheel	396-9956

MGD		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8439	Pin As	308-9881
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418
2H-6489	Race-Brg Outer	374-8350
2W-7213	Bearing-Sleeve	419-4667

MGD		
Original Part Number	Part Name	Classic Part Number
2W-8494	Pulley-Alt	295-5692
3K-2511	Dowel-Reaction	383-2126
3P-3242	Shaft-Planet	308-9923
3R-8530	Boss	425-3454
3V-6515	Link As	394-0186
4B-7255	Cone-Bearing	386-4951
4F-2041	Cup-Roller Brg	418-9609
4N-2514	Gear-Flywheel	421-7283
4N-4577	Muffler As.	308-9877
4V-7099	Pin As	361-1698
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5K-3491	Spacer	308-9934
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6K-5528	Cup-Roller Brg	447-8059
6P-7704	Carrier-Ring	314-8658
6Y-3484	Bearing-Spl Ball	416-2166
6Y-7652	Cup-Rlr Brg	399-6067
6Y-9960	Mount As.	376-3639
7G-2830	Ring-Seal	295-6441
7G-7218	Carrier-Planet	283-5205
7M-5334	Cone-Roller Brg	420-2505
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209

MGD		
Original Part Number	Part Name	Classic Part Number
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8R-7425	Retainer	308-9917
9D-7924	Mount As	360-2356
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-5279	Bearing-Inner	453-3661
9S-7148	Cap As-Rain	378-3994
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
100-8010	Valve	423-5583
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
107-5002	Cage-Bearing	396-7261
107-5006	Joint Gp-Univ	416-2137
110-0551	Hub As	416-2146
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-2958	Pin-Lower	393-0939
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
124-0502	Cup-Spl Tapered	416-2161
129-3046	Carrier-Planet	393-1015
130-2621	Pin As	390-5273

Sales Model 980M (Cont'd.)

MGD		
Original Part Number	**Part Name**	**Classic Part Number**
159-8169	Gear-Planet	391-9870
161-3411	Gasket	394-0896
161-9918	Retainer-Bearing	395-1321

MGD		
Original Part Number	**Part Name**	**Classic Part Number**
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
213-8734	Cover-Transfer	420-3217

MGD		
Original Part Number	**Part Name**	**Classic Part Number**
233-9748	Disc-Friction	417-9502
237-9849	Cage-Bearing	443-1201
319-5239	Wheel	396-9956

MK3		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8439	Pin As	308-9881
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9457	Cone-Spl Tapered	377-7418

MK3		
Original Part Number	**Part Name**	**Classic Part Number**
2H-6489	Race-Brg Outer	374-8350
2W-7213	Bearing-Sleeve	419-4667
2W-8494	Pulley-Alt	295-5692
3K-2511	Dowel-Reaction	383-2126
3P-2415	Carrier-Planet	396-0653
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3246	Shaft-Planet	308-9925
3P-3735	Housing As	391-9830
3R-8530	Boss	425-3454
3V-6515	Link As	394-0186
4B-7255	Cone-Bearing	386-4951
4F-2041	Cup-Roller Brg	418-9609
4N-2514	Gear-Flywheel	421-7283
4N-4577	Muffler As.	308-9877
4V-7099	Pin As	361-1698
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5K-3491	Spacer	308-9934
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6K-5528	Cup-Roller Brg	447-8059
6P-6739	Shaft-Planet	308-9929
6P-7704	Carrier-Ring	314-8658

MK3		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-7652	Cup-Rlr Brg	399-6067
6Y-9960	Mount As.	376-3639
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7M-5334	Cone-Roller Brg	420-2505
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8R-7425	Retainer	308-9917
9D-7924	Mount As	360-2356
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9P-7757	Gear-Sun	283-5218
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9S-5279	Bearing-Inner	453-3661
9S-7148	Cap As-Rain	378-3994
9W-2977	Hub As	423-6985
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
100-8010	Valve	423-5583
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882

Sales Model 980M (Cont'd.)

MK3		
Original Part Number	**Part Name**	**Classic Part Number**
105-2487	Gear-Tfr Output	391-9881
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5006	Joint Gp-Univ	416-2137
108-2735	Ring-Lock	386-4935

MK3		
Original Part Number	**Part Name**	**Classic Part Number**
108-2736	Ring-Lock	384-3476
110-0551	Hub As	416-2146
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8042	Carrier-Planet	390-0916
115-2958	Pin-Lower	393-0939
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
124-0502	Cup-Spl Tapered	416-2161
129-3046	Carrier-Planet	393-1015
130-2621	Pin As	390-5273

MK3		
Original Part Number	**Part Name**	**Classic Part Number**
159-8169	Gear-Planet	391-9870
161-3411	Gasket	394-0896
161-9918	Retainer-Bearing	395-1321
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
213-8734	Cover-Transfer	420-3217
233-9748	Disc-Friction	417-9502
237-9849	Cage-Bearing	443-1201
319-5239	Wheel	396-9956

N8T		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3934	Cup-Roller Brg	392-4487
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1M-6573	Cup-Roller Brg	399-4438
1P-1367	Plunger-Valve	432-8913
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1T-0210	Bearing-Ball	417-4498
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808

N8T		
Original Part Number	**Part Name**	**Classic Part Number**
1V-8242	Bearing-Sleeve	308-9809
1V-8439	Pin As	308-9881
1V-8852	Cap	308-9834
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2B-0941	Spacer	418-1955
2D-5658	Bearing-Ball	301-4628
2D-6511	Cup-Roller Brg	377-7417
2D-9454	Cup-Roller Brg	415-1914
2D-9457	Cone-Spl Tapered	377-7418
2H-6489	Race-Brg Outer	374-8350
2K-5065	Cone-Roller Brg	416-2157
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
2W-8494	Pulley-Alt	295-5692
3K-2511	Dowel-Reaction	383-2126
3P-2415	Carrier-Planet	396-0653
3P-2983	Gear-Sun	417-9468

N8T		
Original Part Number	**Part Name**	**Classic Part Number**
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3246	Shaft-Planet	308-9925
3P-3735	Housing As	391-9830
3R-8530	Boss	425-3454
3V-6515	Link As	394-0186
4B-7255	Cone-Bearing	386-4951
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4F-2041	Cup-Roller Brg	418-9609
4N-2514	Gear-Flywheel	421-7283
4N-4577	Muffler As.	308-9877
4V-7099	Pin As	361-1698
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934

Sales Model 980M (Cont'd.)

N8T		
Original Part Number	**Part Name**	**Classic Part Number**
5K-8591	Bearing-Outer	380-7502
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-8194	Ring-Retaining	308-9920
5T-5682	Driver	418-9579
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6P-6739	Shaft-Planet	308-9929
6P-7704	Carrier-Ring	314-8658
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-4819	Carrier-Planet	296-1348
6Y-5793	Ring-Seal	451-9028
6Y-7652	Cup-Rlr Brg	399-6067
6Y-9960	Mount As.	376-3639
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2476	Gear-Planet	223-4816
7G-2830	Ring-Seal	295-6441
7G-3457	Gear-Planet	308-9857
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7M-5334	Cone-Roller Brg	420-2505
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822

N8T		
Original Part Number	**Part Name**	**Classic Part Number**
7V-0638	Spacer	425-3651
7V-6715	Pin As	361-1701
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8R-7425	Retainer	308-9917
9D-7924	Mount As	360-2356
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9M-2744	Cone-Spl Tapered	380-1480
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-5279	Bearing-Inner	453-3661
9S-7148	Cap As-Rain	378-3994
9W-2977	Hub As	423-6985
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
100-8010	Valve	423-5583
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881

N8T		
Original Part Number	**Part Name**	**Classic Part Number**
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-7798	Bearing-Ball	417-9494
107-5002	Cage-Bearing	396-7261
107-5006	Joint Gp-Univ	416-2137
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
110-0551	Hub As	416-2146
112-5585	Shaft-Planet	308-9932
112-7309	Shaft-Planet	380-7521
112-8041	Carrier-Planet	295-5681
112-8042	Carrier-Planet	390-0916
115-2958	Pin-Lower	393-0939
115-3184	Cap-Lower	395-1324
115-4072	Bearing	397-5069
115-4237	Pulley-Idler	374-4693
119-5727	Bearing-Spl Ball	417-9491
124-0502	Cup-Spl Tapered	416-2161
129-3046	Carrier-Planet	393-1015
130-2621	Pin As	390-5273
159-8169	Gear-Planet	391-9870
161-3411	Gasket	394-0896
161-9918	Retainer-Bearing	395-1321
171-3942	Yoke	398-2931
173-0888	Univ Jt As	394-0898
174-3405	Yoke As	398-2929
213-1365	Bearing-Sleeve	330-9256
213-8734	Cover-Transfer	420-3217
233-9748	Disc-Friction	417-9502
237-9849	Cage-Bearing	443-1201
319-5239	Wheel	396-9956
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model G910

3SD		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2K-8753	Pinion-Bevel	253-1432
2N-1599	Gear	378-3970
2S-0479	Bearing-Cone	380-7506
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3H-8726	Mount As	385-7208
4N-0432	Bearing-Ball	417-4499
4N-4161	Mount As	374-1448
4N-4539	Sleeve	314-8720
4P-7688	Valve As-Check	420-6216

3SD		
Original Part Number	Part Name	Classic Part Number
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5J-7010	Seal As	472-8011
5M-2054	Bearing	380-7510
5M-7936	Bearing-Outer	386-4953
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg	373-5386
5V-1168	Spider & Brg As	377-7435
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6K-8275	Cone-Roller Brg	399-6070
6S-3051	Cup-Rlr Brg	415-1928
6S-3158	Yoke	380-1478
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-3975	Trunnion	396-9940
6S-3976	Bearing	388-0589
6S-4074	Bearing	330-9249
6S-6009	Yoke-Univ Joint	446-3070
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-6896	Rebuild Kit	390-1006
6Y-7935	Disc-Friction	383-2121
7C-7955	Gasket-Cover	382-6899
7J-3351	Head	380-1515
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-3913	Rim As	398-2952

3SD		
Original Part Number	Part Name	Classic Part Number
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-5284	Bearing	388-0582
8J-5392	Ballstud	364-5264
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-2653	Pump Gp-Gr 1 Bsc	386-3057
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5211	Plate-Clutch	380-1493
9S-6917	Gear-Cplg Ring	446-3075
9S-7949	Cup-Roller Brg	420-6531
9Y-9431	Precleaner As	361-1718
100-8010	Valve	423-5583
119-6772	Valve-Exhaust	384-8699
154-5679	Kit-Dt Gasket	390-5277
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model G910 (Cont'd.)

8GD		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-5658	Bearing-Ball	301-4628
2K-8753	Pinion-Bevel	253-1432
2N-1599	Gear	378-3970
2S-0479	Bearing-Cone	380-7506
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3H-8726	Mount As	385-7208
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216

8GD		
Original Part Number	**Part Name**	**Classic Part Number**
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5J-7010	Seal As	472-8011
5M-2054	Bearing	380-7510
5M-7936	Bearing-Outer	386-4953
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg	373-5386
5V-1168	Spider & Brg As	377-7435
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6K-8275	Cone-Roller Brg	399-6070
6N-3256	Mount As	314-8688
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-3975	Trunnion	396-9940
6S-3976	Bearing	388-0589
6S-4074	Bearing	330-9249
6S-6009	Yoke-Univ Joint	446-3070
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-6896	Rebuild Kit	390-1006
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121

8GD		
Original Part Number	**Part Name**	**Classic Part Number**
7C-7955	Gasket-Cover	382-6899
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-3351	Head	380-1515
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-3913	Rim As	398-2952
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8J-5392	Ballstud	364-5264
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

Sales Model G910 (Cont'd.)

8GD		
Original Part Number	Part Name	Classic Part Number
9S-7949	Cup-Roller Brg	420-6531
9W-6390	Sleeve	385-3795
9Y-9431	Precleaner As	361-1718
100-8010	Valve	423-5583

8GD		
Original Part Number	Part Name	Classic Part Number
119-6772	Valve-Exhaust	384-8699
140-2382	Gasket Kit	390-5285
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024

8GD		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model G916

5GD		
Original Part Number	Part Name	Classic Part Number
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1219	Trunnion As	314-8724
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-2870	Shaft As-Balance	314-8715

5GD		
Original Part Number	Part Name	Classic Part Number
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2V-7990	Tube As	373-5382

5GD		
Original Part Number	Part Name	Classic Part Number
2W-1223	Pump Gp-Water	385-7197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8271	Arm As-Rocker	432-8912
2W-9978	Core As-Oclr	279-4983
3B-4124	Cup-Spl Tapered	422-6481
3K-3124	Muffler-Trap	247-2673
3T-2094	Bearing-Sleeve	388-0638
4B-7255	Cone-Bearing	386-4951
4E-3456	Lever As	367-6081
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710

Sales Model G916 (Cont'd.)

5GD		
Original Part Number	**Part Name**	**Classic Part Number**
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4T-3196	Cartridge Gp	422-8112
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4V-8629	Bearing-Sleeve	379-0194
4V-8643	Bearing-Sleeve	374-8354
4V-8661	Pin As	375-9968
4V-9577	Shaft-Planet	231-0001
4V-9901	Pin As	374-6508
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903

5GD		
Original Part Number	**Part Name**	**Classic Part Number**
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-2931	Pump Gp-Vn Bsc-B	422-8161
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2706	Cap-Lower	451-6443
6K-2707	Plate-Lock	319-3470
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-6721	Coupling	377-5830
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7C-2880	Bell As-Suction	380-1520

5GD		
Original Part Number	**Part Name**	**Classic Part Number**
7C-3862	Camshaft	458-0151
7C-7955	Gasket-Cover	382-6899
7E-9980	Camshaft	377-5851
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7K-2135	Bearing-Roller	417-4492
7K-7237	Gear-Planet	231-0009
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0691	Elbow-Water Rglt	378-3983
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7681	Pipe-Exh Ext	385-7213
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8E-4024	Carrier-Planet	398-8333

Sales Model G916 (Cont'd.)

5GD		
Original Part Number	Part Name	Classic Part Number
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6321	Gear-Sun	253-1441
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3753	Rod As-Conn	379-8867
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6308	Bearing-Conn Rod	419-7267
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081

5GD		
Original Part Number	Part Name	Classic Part Number
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-2470	Gasket Kit	393-5219
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8W-9587	Flange As	373-5394
9D-7924	Mount As	360-2356
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9M-5477	Bearing-Sleeve	374-6517
9N-5246	Bearing-Camshaft	384-4772
9N-5769	Cover-Housing	325-6050
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-2356	Manifold-Exhaust	261-0905
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9T-5096	Flexplate	455-3271
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-5168	Manifold-Exhaust	374-7483
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583

5GD		
Original Part Number	Part Name	Classic Part Number
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
140-2382	Gasket Kit	390-5285
140-2383	Gasket Kit	396-9927
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

1SD		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026

1SD		
Original Part Number	**Part Name**	**Classic Part Number**
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3G-2797	Bearing-Sleeve	360-2329
3K-3124	Muffler-Trap	247-2673
3T-2094	Bearing-Sleeve	388-0638
4E-3456	Lever As	367-6081
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-3603	Pin As	319-3441
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
4Y-1034	Pin As	396-0641
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537

1SD		
Original Part Number	**Part Name**	**Classic Part Number**
5S-9080	Pulley-Alt Drive	264-5883
5V-7574	Ring-Retaining	392-4483
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6H-3957	Bearing-Ball	311-9358
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7C-7955	Gasket-Cover	382-6899
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7I-4187	Yoke-1550	380-1510
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451

Sales Model G926 (Cont'd.)

1SD		
Original Part Number	**Part Name**	**Classic Part Number**
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7S-7681	Pipe-Exh Ext	385-7213
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518

1SD		
Original Part Number	**Part Name**	**Classic Part Number**
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8T-2470	Gasket Kit	393-5219
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
9G-5525	Shaft-Planet	419-8662
9G-8931	Yoke As	446-3074
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706

1SD		
Original Part Number	**Part Name**	**Classic Part Number**
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-5096	Flexplate	455-3271
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795
9Y-5168	Manifold-Exhaust	374-7483
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
140-2383	Gasket Kit	396-9927
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024

3TD		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476

3TD		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513

3TD		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3G-2797	Bearing-Sleeve	360-2329
3K-3124	Muffler-Trap	247-2673
3T-2094	Bearing-Sleeve	388-0638
4E-3456	Lever As	367-6081
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720

Sales Model G926 (Cont'd.)

3TD		
Original Part Number	Part Name	Classic Part Number
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-3603	Pin As	319-3441
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
4Y-1034	Pin As	396-0641
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5V-7574	Ring-Retaining	392-4483
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6H-3957	Bearing-Ball	311-9358
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281

3TD		
Original Part Number	Part Name	Classic Part Number
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7C-7955	Gasket-Cover	382-6899
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7I-4187	Yoke-1550	380-1510
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7S-7681	Pipe-Exh Ext	385-7213
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-2051	Compressor Gp -B	386-2063

3TD		
Original Part Number	Part Name	Classic Part Number
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8T-2470	Gasket Kit	393-5219
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
8W-9566	Flange As	376-9073
9G-5525	Shaft-Planet	419-8662
9G-8931	Yoke As	446-3074
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-5096	Flexplate	455-3271
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795
9Y-5168	Manifold-Exhaust	374-7483
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
140-2383	Gasket Kit	396-9927
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024

Sales Model G936

3HD		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1647	Impeller-Conv	377-7415
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1766	Muffler As.	298-2783
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223

3HD		
Original Part Number	Part Name	Classic Part Number
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-4611	Pipe-Exhaust	365-8821
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2P-8986	Cup-Rlr Bearing	415-1912
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055

3HD		
Original Part Number	Part Name	Classic Part Number
2W-5536	Core As-Radiator	380-7554
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2752	Cartridge Gp-Rr	422-8127
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3G-9891	Pump Gp-Gr A	399-8541
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4E-3456	Lever As	367-6081
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8344	Spider As-Fan	416-5520
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989

Sales Model G936 (Cont'd.)

3HD		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0092	Hub As	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-3680	Bellcrank	308-9802
4V-3842	Support-Trunnion	396-9935
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-6527	Disc	376-9050
4V-7543	Retainer	281-1699
4V-7545	Gear-Ring	394-9823
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
4Y-1034	Pin As	396-0641
5L-2031	Cup-Roller Brg	384-5927
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022

3HD		
Original Part Number	**Part Name**	**Classic Part Number**
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
5V-7574	Ring-Retaining	392-4483
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2932	Pump Gp-Vn Bsc-B	422-8155
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695

3HD		
Original Part Number	**Part Name**	**Classic Part Number**
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-2202	Bearing-Spl Ball	380-1574
6V-5413	Gasket Kit	390-5291
6V-5414	Gasket Kit	434-7289
6V-7459	Gasket Kit	391-1095
6W-2899	Shaft-Pinion	446-3057
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7I-4187	Yoke-1550	380-1510
7K-0686	Trunnion-Rear	297-7266
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496

Sales Model G936 (Cont'd.)

3HD		
Original Part Number	Part Name	Classic Part Number
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7V-0638	Spacer	425-3651
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623

3HD		
Original Part Number	Part Name	Classic Part Number
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3563	Cage-Bearing	451-0747
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-1606	Kit-Gskt-Sch	386-3046
8V-1537	Gear-Sun	446-3061
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9L-2685	Rod End	419-1866
9M-1853	Mount As.	376-3638
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923

3HD		
Original Part Number	Part Name	Classic Part Number
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9V-0247	Plate	417-4527
9V-8693	Actuator Gp-Bk	375-2629
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
138-2317	Wheel	396-9948
139-9177	Gasket Kit	377-7465
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111

Sales Model G936 (Cont'd.)

3HD		
Original Part Number	**Part Name**	**Classic Part Number**
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828

3HD		
Original Part Number	**Part Name**	**Classic Part Number**
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
252-5650	Rim As	397-5067
270-4353	Kit-Liner-Cla	270-4356

3HD		
Original Part Number	**Part Name**	**Classic Part Number**
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
275-0120	Pin As	419-7245
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-6872	Kit-Dt Gasket	394-8228
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

4ND		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1647	Impeller-Conv	377-7415
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356

4ND		
Original Part Number	**Part Name**	**Classic Part Number**
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2L-5271	Bearing-Ball	371-4305

4ND		
Original Part Number	**Part Name**	**Classic Part Number**
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2P-8986	Cup-Rlr Bearing	415-1912
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2752	Cartridge Gp-Rr	422-8127
3G-4704	Bearing-Sleeve	379-0185

Sales Model G936 (Cont'd.)

4ND		
Original Part Number	Part Name	Classic Part Number
3G-5285	Bearing-Sleeve	360-2312
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4E-3456	Lever As	367-6081
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8344	Spider As-Fan	416-5520
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0092	Hub As	396-9934

4ND		
Original Part Number	Part Name	Classic Part Number
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-3680	Bellcrank	308-9802
4V-3842	Support-Trunnion	396-9935
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-6527	Disc	376-9050
4V-7543	Retainer	281-1699
4V-7545	Gear-Ring	394-9823
4W-0452	Seal As -Cshaft	325-6191
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
4Y-1034	Pin As	396-0641
5L-2031	Cup-Roller Brg	384-5927
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883

4ND		
Original Part Number	Part Name	Classic Part Number
5V-1274	Spider	385-6110
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
5V-7574	Ring-Retaining	392-4483
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2932	Pump Gp-Vn Bsc-B	422-8155
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-2202	Bearing-Spl Ball	380-1574
6V-4785	Gasket Kit - Fs	388-0661
6V-5413	Gasket Kit	390-5291
6V-5414	Gasket Kit	434-7289
6V-5976	Kit-Gasket (Rs)	393-5200
6W-2899	Shaft-Pinion	446-3057
6Y-3484	Bearing-Spl Ball	416-2166

Sales Model G936 (Cont'd.)

4ND		
Original Part Number	**Part Name**	**Classic Part Number**
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7I-4187	Yoke-1550	380-1510
7K-0686	Trunnion-Rear	297-7266
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066

4ND		
Original Part Number	**Part Name**	**Classic Part Number**
7T-2036	Cap As-Fuel	361-1721
7V-0638	Spacer	425-3651
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377

4ND		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8T-1606	Kit-Gskt-Sch	386-3046
8T-9486	Gasket Kt	393-5197
8V-1537	Gear-Sun	446-3061
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9L-2685	Rod End	419-1866
9M-1853	Mount As.	376-3638
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9V-0247	Plate	417-4527
9V-8693	Actuator Gp-Bk	375-2629
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833

Sales Model G936 (Cont'd.)

4ND		
Original Part Number	Part Name	Classic Part Number
9Y-2992	Bearing-Sleeve	325-6032
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
138-2317	Wheel	396-9948
139-9177	Gasket Kit	377-7465
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126

4ND		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828

4ND		
Original Part Number	Part Name	Classic Part Number
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
252-5650	Rim As	397-5067
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
275-0120	Pin As	419-7245
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-6872	Kit-Dt Gasket	394-8228
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
391-8229	Kit-Gasket-Fs	398-2955

8ED		
Original Part Number	Part Name	Classic Part Number
1A-9252	Rod End-Yoke	377-5849
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-5480	Cover As.-End	299-1998
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862

8ED		
Original Part Number	Part Name	Classic Part Number
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0576	Bearing-Sleeve	379-0186
1T-1428	Retainer-Brg	300-2587
1T-1647	Impeller-Conv	377-7415
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006

8ED		
Original Part Number	Part Name	Classic Part Number
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2G-1034	Valve-Safety	380-7555

Sales Model G936 (Cont'd.)

8ED		
Original Part Number	**Part Name**	**Classic Part Number**
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2P-8986	Cup-Rlr Bearing	415-1912
2V-7990	Tube As	373-5382
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-2752	Cartridge Gp-Rr	422-8127
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3G-9891	Pump Gp-Gr A	399-8541
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638

8ED		
Original Part Number	**Part Name**	**Classic Part Number**
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4E-3456	Lever As	367-6081
4E-7608	Bearing-Sleeve	388-0639
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8344	Spider As-Fan	416-5520
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-0092	Hub As	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243

8ED		
Original Part Number	**Part Name**	**Classic Part Number**
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-3680	Bellcrank	308-9802
4V-3842	Support-Trunnion	396-9935
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-6527	Disc	376-9050
4V-7543	Retainer	281-1699
4V-7545	Gear-Ring	394-9823
4W-0452	Seal As -Cshaft	325-6191
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9655	Support	419-0882
4Y-1034	Pin As	396-0641
5L-2031	Cup-Roller Brg	384-5927
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110

Sales Model G936 (Cont'd.)

8ED		
Original Part Number	Part Name	Classic Part Number
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
5V-7574	Ring-Retaining	392-4483
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2932	Pump Gp-Vn Bsc-B	422-8155
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-2202	Bearing-Spl Ball	380-1574
6W-2899	Shaft-Pinion	446-3057
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7E-9918	Repair Kit-Major	388-0655

8ED		
Original Part Number	Part Name	Classic Part Number
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7H-4566	Cup-Roller Brg	399-6068
7I-4187	Yoke-1550	380-1510
7K-0686	Trunnion-Rear	297-7266
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-8443	Muffler	247-2675
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7V-0638	Spacer	425-3651
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935

8ED		
Original Part Number	Part Name	Classic Part Number
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082

Sales Model G936 (Cont'd.)

8ED		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
8V-1537	Gear-Sun	446-3061
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-8117	Housing As-Cl	302-2686
9L-2685	Rod End	419-1866
9M-1853	Mount As.	376-3638
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9V-0247	Plate	417-4527
9V-8693	Actuator Gp-Bk	375-2629
9W-4950	Gear-Sun	281-1688

8ED		
Original Part Number	**Part Name**	**Classic Part Number**
9W-4957	Carrier-Planet	390-0913
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
138-2317	Wheel	396-9948
139-9177	Gasket Kit	377-7465
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

8ED		
Original Part Number	**Part Name**	**Classic Part Number**
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
207-2015	Gasket Kit	447-0828
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
247-2670	Muffler-Classic	247-2675
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
275-0120	Pin As	419-7245
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-6872	Kit-Dt Gasket	394-8228
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model IT12

2YC		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3165	Plunger-Rlf V	373-1883

2YC		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398

2YC		
Original Part Number	**Part Name**	**Classic Part Number**
1P-7115	Mount As	418-1936
1T-0043	Bearing-Ball	390-5294
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078

Sales Model IT12 (Cont'd.)

2YC		
Original Part Number	Part Name	Classic Part Number
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-2566	Ring-Lock	416-2123
2D-5658	Bearing-Ball	301-4628
2K-8753	Pinion-Bevel	253-1432
2N-1599	Gear	378-3970
2S-0479	Bearing-Cone	380-7506
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3G-4704	Bearing-Sleeve	379-0185
3H-8726	Mount As	385-7208
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4N-0432	Bearing-Ball	417-4499
4N-4161	Mount As	374-1448
4N-4539	Sleeve	314-8720
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502
4T-8054	Seal As	472-8010
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5J-7010	Seal As	472-8011
5M-2054	Bearing	380-7510

2YC		
Original Part Number	Part Name	Classic Part Number
5M-7936	Bearing-Outer	386-4953
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg	373-5386
5V-1168	Spider & Brg As	377-7435
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6K-8088	Bearing-Roller	399-4428
6K-8275	Cone-Roller Brg	399-6070
6K-8314	Pin	252-6863
6S-3158	Yoke	380-1478
6S-3457	Pin	325-6147
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-3975	Trunnion	396-9940
6S-3976	Bearing	388-0589
6S-4074	Bearing	330-9249
6S-6009	Yoke-Univ Joint	446-3070
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-6896	Rebuild Kit	390-1006
6Y-7935	Disc-Friction	383-2121
7C-7955	Gasket-Cover	382-6899
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-0084	Bearing-Sleeve	453-6508
7K-0087	Bearing-Sleeve	374-6514
7K-3913	Rim As	398-2952
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816

2YC		
Original Part Number	Part Name	Classic Part Number
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8J-5392	Ballstud	364-5264
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8W-9587	Flange As	373-5394
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-2653	Pump Gp-Gr 1 Bsc	386-3057
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-5211	Plate-Clutch	380-1493
9S-6917	Gear-Cplg Ring	446-3075
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
9Y-9431	Precleaner As	361-1718
100-8010	Valve	423-5583
119-6772	Valve-Exhaust	384-8699
154-5679	Kit-Dt Gasket	390-5277
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model IT12 (Cont'd.)

4NC		
Original Part Number	**Part Name**	**Classic Part Number**
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1P-7115	Mount As	418-1936
1P-9594	Bearing-Cup	377-7401
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2D-2566	Ring-Lock	416-2123
2D-5658	Bearing-Ball	301-4628
2K-8753	Pinion-Bevel	253-1432
2N-1599	Gear	378-3970
2S-0479	Bearing-Cone	380-7506
2S-7931	Bearing-Sleeve	387-2904
2W-1223	Pump Gp-Water	385-7197
2W-7590	Cooler As-Oil	378-3971
2W-8271	Arm As-Rocker	432-8912
3G-4704	Bearing-Sleeve	379-0185
3G-8932	Pin	325-6143

4NC		
Original Part Number	**Part Name**	**Classic Part Number**
3H-8726	Mount As	385-7208
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-7688	Valve As-Check	420-6216
4S-8538	Bearing-Spl Ball	417-4502
4T-0231	Retainer	376-3641
4T-8054	Seal As	472-8010
4V-8675	Bearing-Sleeve	394-0187
4W-6869	Spacer-Fuel Pump	417-4534
5G-3612	Cap Gp-Protn	295-6419
5J-7010	Seal As	472-8011
5M-2054	Bearing	380-7510
5M-7936	Bearing-Outer	386-4953
5P-7807	Bearing-Ball	314-8502
5S-5917	Screw-Rocker Adj	380-7537
5T-8739	Spider Gp-Brg	373-5386
5V-1168	Spider & Brg As	377-7435
6H-3957	Bearing-Ball	311-9358
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6K-8275	Cone-Roller Brg	399-6070
6K-8314	Pin	252-6863
6N-3256	Mount As	314-8688
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6S-3158	Yoke	380-1478
6S-3457	Pin	325-6147
6S-3465	Bearing-Sleeve	382-6903

4NC		
Original Part Number	**Part Name**	**Classic Part Number**
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-3975	Trunnion	396-9940
6S-3976	Bearing	388-0589
6S-4074	Bearing	330-9249
6S-6009	Yoke-Univ Joint	446-3070
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6V-6896	Rebuild Kit	390-1006
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7C-7955	Gasket-Cover	382-6899
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9884	Bearing-Sleeve	325-6016
7K-0084	Bearing-Sleeve	453-6508
7K-0087	Bearing-Sleeve	374-6514
7K-2135	Bearing-Roller	417-4492
7K-3913	Rim As	398-2952
7K-5448	Cup-Bearing	415-1922
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7K-9642	Bearing-Sleeve	360-2340
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-4674	Muffler As.	373-1910
7N-7166	Race-Brg Thrust	417-4531
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582

Sales Model IT12 (Cont'd.)

4NC		
Original Part Number	**Part Name**	**Classic Part Number**
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-2810	Case As-Filter	314-8512
8J-5392	Ballstud	364-5264
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8R-1693	Pin As	415-1906
8R-6631	Hub	443-2057
8V-7176	Pin	241-2568
8W-9587	Flange As	373-5394

4NC		
Original Part Number	**Part Name**	**Classic Part Number**
9K-8757	Rod End-Special	311-9361
9L-7682	Valve-Inlet	385-9266
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

4NC		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
9W-6390	Sleeve	385-3795
9Y-9431	Precleaner As	361-1718
100-4529	Piston As	424-6368
100-8010	Valve	423-5583
119-6772	Valve-Exhaust	384-8699
140-2382	Gasket Kit	390-5285
174-6836	Gasket Kit - Tof	434-7280
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model IT12B

1KF		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1P-4693	Cup-Rlr Bearing	377-7398
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-9191	Cone-Roller Brg	374-1837
2K-8753	Pinion-Bevel	253-1432
2N-1599	Gear	378-3970
2S-0479	Bearing-Cone	380-7506
2W-7213	Bearing-Sleeve	419-4667
3E-7461	Gasket Kit-Sch	437-4575
3G-4704	Bearing-Sleeve	379-0185
3H-8726	Mount As	385-7208

1KF		
Original Part Number	**Part Name**	**Classic Part Number**
3T-2094	Bearing-Sleeve	388-0638
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5M-9644	Bearing-Outer	384-5929
5T-1362	Univ Joint As-5C	325-6011
5T-8739	Spider Gp-Brg	373-5386
5V-1168	Spider & Brg As	377-7435
6F-2956	Cup-Spl Tapered	420-6538

1KF		
Original Part Number	**Part Name**	**Classic Part Number**
6I-4689	Gasket-Cyl Head	377-5840
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8088	Bearing-Roller	399-4428
6K-8275	Cone-Roller Brg	399-6070
6K-8314	Pin	252-6863
6S-3158	Yoke	380-1478
6S-3457	Pin	325-6147
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-3975	Trunnion	396-9940
6S-3976	Bearing	388-0589
6S-4074	Bearing	330-9249
6V-4582	Bearing-Ball	380-1504
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317

Sales Model IT12B (Cont'd.)

1KF		
Original Part Number	**Part Name**	**Classic Part Number**
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-0084	Bearing-Sleeve	453-6508
7K-0087	Bearing-Sleeve	374-6514
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8J-5392	Ballstud	364-5264
8S-0248	Breather As	325-6033
8W-9587	Flange As	373-5394
8Y-0809	Spider Gp-Brg	417-4526
9C-5687	Separator	377-7456
9C-8772	Piston	376-9052

1KF		
Original Part Number	**Part Name**	**Classic Part Number**
9M-1853	Mount As.	376-3638
9P-8663	Spacer	422-9521
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
9X-2192	Gasket Kit-Sch	393-5189
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
121-7746	Pre-Cleaner As	360-2311
133-6597	Pipe-Extension	420-6220
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336

1KF		
Original Part Number	**Part Name**	**Classic Part Number**
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
154-5683	Kit-Dt Gasket	420-6528
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model IT12F

1KF		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1P-4693	Cup-Rlr Bearing	377-7398
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-1064	Gear-Flywheel	374-4703

1KF		
Original Part Number	**Part Name**	**Classic Part Number**
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-9191	Cone-Roller Brg	374-1837
2K-8753	Pinion-Bevel	253-1432
2N-1599	Gear	378-3970
2S-0479	Bearing-Cone	380-7506
2W-7213	Bearing-Sleeve	419-4667
3E-7461	Gasket Kit-Sch	437-4575
3G-4704	Bearing-Sleeve	379-0185

1KF		
Original Part Number	**Part Name**	**Classic Part Number**
3H-8726	Mount As	385-7208
3T-2094	Bearing-Sleeve	388-0638
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513

Sales Model IT12F (Cont'd.)

1KF		
Original Part Number	Part Name	Classic Part Number
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5M-2054	Bearing	380-7510
5M-5856	Pipe-Extension	373-1913
5M-9644	Bearing-Outer	384-5929
5T-1362	Univ Joint As-5C	325-6011
5T-8739	Spider Gp-Brg	373-5386
5V-1168	Spider & Brg As	377-7435
6F-2956	Cup-Spl Tapered	420-6538
6I-4689	Gasket-Cyl Head	377-5840
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8088	Bearing-Roller	399-4428
6K-8275	Cone-Roller Brg	399-6070
6K-8314	Pin	252-6863
6S-3158	Yoke	380-1478
6S-3457	Pin	325-6147
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-3975	Trunnion	396-9940
6S-3976	Bearing	388-0589
6S-4074	Bearing	330-9249
6V-4582	Bearing-Ball	380-1504
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316

1KF		
Original Part Number	Part Name	Classic Part Number
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7K-0084	Bearing-Sleeve	453-6508
7K-0087	Bearing-Sleeve	374-6514
7K-8877	Cone-Bearing	374-1847
7K-9360	Pin	319-3461
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8J-5392	Ballstud	364-5264
8S-0248	Breather As	325-6033
8W-9587	Flange As	373-5394
8Y-0809	Spider Gp-Brg	417-4526
9C-5687	Separator	377-7456
9C-8772	Piston	376-9052
9M-1853	Mount As.	376-3638
9P-8663	Spacer	422-9521
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
9X-2192	Gasket Kit-Sch	393-5189
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381

1KF		
Original Part Number	Part Name	Classic Part Number
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
121-7746	Pre-Cleaner As	360-2311
133-6597	Pipe-Extension	420-6220
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
154-5683	Kit-Dt Gasket	420-6528
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

6RS		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437

Sales Model IT12F (Cont'd.)

6RS		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3980	Cone-Roller Brg	399-4443
1H-5338	Cup-Roller Brg	374-8345
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2K-8753	Pinion-Bevel	253-1432
3T-2094	Bearing-Sleeve	388-0638
4M-6107	Bearing-Roller	380-7507
4T-8054	Seal As	472-8010
5J-7010	Seal As	472-8011
5L-6326	Bearing-Ball	420-3222
5M-5856	Pipe-Extension	373-1913
5V-1168	Spider & Brg As	377-7435

6RS		
Original Part Number	**Part Name**	**Classic Part Number**
6F-2956	Cup-Spl Tapered	420-6538
6K-8088	Bearing-Roller	399-4428
6S-3457	Pin	325-6147
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3975	Trunnion	396-9940
6S-3976	Bearing	388-0589
6V-4582	Bearing-Ball	380-1504
7K-0087	Bearing-Sleeve	374-6514
7K-9642	Bearing-Sleeve	360-2340
8D-0983	Mounting	384-3470
8J-5392	Ballstud	364-5264
9C-5687	Separator	377-7456

6RS		
Original Part Number	**Part Name**	**Classic Part Number**
9C-8772	Piston	376-9052
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
9V-0247	Plate	417-4527
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
114-1071	Piston	388-6583
115-4237	Pulley-Idler	374-4693
133-6597	Pipe-Extension	420-6220
151-5349	Head	383-1592
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024

Sales Model IT14B

3NJ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-1064	Gear-Flywheel	374-4703
2D-2566	Ring-Lock	416-2123
2D-9191	Cone-Roller Brg	374-1837
2K-8753	Pinion-Bevel	253-1432
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3G-4704	Bearing-Sleeve	379-0185
3H-8726	Mount As	385-7208
3T-2094	Bearing-Sleeve	388-0638

3NJ		
Original Part Number	**Part Name**	**Classic Part Number**
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5M-5856	Pipe-Extension	373-1913
5M-9644	Bearing-Outer	384-5929
5T-8739	Spider Gp-Brg	373-5386
5V-1168	Spider & Brg As	377-7435
6F-2956	Cup-Spl Tapered	420-6538
6I-4689	Gasket-Cyl Head	377-5840
6K-5746	Bearing-Roller	417-4503
6K-8088	Bearing-Roller	399-4428

3NJ		
Original Part Number	**Part Name**	**Classic Part Number**
6S-3457	Pin	325-6147
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-3975	Trunnion	396-9940
6S-3976	Bearing	388-0589
6V-4582	Bearing-Ball	380-1504
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7J-6461	Crown	325-6054
7K-0087	Bearing-Sleeve	374-6514

Sales Model IT14B (Cont'd.)

3NJ		
Original Part Number	Part Name	Classic Part Number
7K-9360	Pin	319-3461
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8J-5392	Ballstud	364-5264
8S-0248	Breather As	325-6033
8W-9587	Flange As	373-5394
8Y-0809	Spider Gp-Brg	417-4526
9C-5687	Separator	377-7456
9C-8772	Piston	376-9052
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
9V-0247	Plate	417-4527
9X-2192	Gasket Kit-Sch	393-5189
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610

3NJ		
Original Part Number	Part Name	Classic Part Number
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
121-7746	Pre-Cleaner As	360-2311
133-6597	Pipe-Extension	420-6220
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
154-5683	Kit-Dt Gasket	420-6528
176-3900	Accumulator	416-5513

3NJ		
Original Part Number	Part Name	Classic Part Number
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model IT14F

4EL		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-5338	Cup-Roller Brg	374-8345
1P-7115	Mount As	418-1936
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2K-8753	Pinion-Bevel	253-1432
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667

4EL		
Original Part Number	Part Name	Classic Part Number
3T-2094	Bearing-Sleeve	388-0638
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5M-5856	Pipe-Extension	373-1913
5V-1168	Spider & Brg As	377-7435
6F-2956	Cup-Spl Tapered	420-6538

4EL		
Original Part Number	Part Name	Classic Part Number
6I-4689	Gasket-Cyl Head	377-5840
6K-8088	Bearing-Roller	399-4428
6S-3457	Pin	325-6147
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-3975	Trunnion	396-9940
6S-3976	Bearing	388-0589
6V-4582	Bearing-Ball	380-1504
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6976	Bearing-Conn Rod	419-6317

Sales Model IT14F (Cont'd.)

4EL		
Original Part Number	**Part Name**	**Classic Part Number**
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7K-0087	Bearing-Sleeve	374-6514
7K-9360	Pin	319-3461
7T-2036	Cap As-Fuel	361-1721
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8J-5392	Ballstud	364-5264
8S-0248	Breather As	325-6033
9C-5687	Separator	377-7456
9C-8772	Piston	376-9052
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486

4EL		
Original Part Number	**Part Name**	**Classic Part Number**
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
133-6597	Pipe-Extension	420-6220
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376

4EL		
Original Part Number	**Part Name**	**Classic Part Number**
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
154-5683	Kit-Dt Gasket	420-6528
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model IT14G

1WN		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup-Roller Brg	374-8345
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
4T-8054	Seal As	472-8010
5M-5856	Pipe-Extension	373-1913
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6S-3465	Bearing-Sleeve	382-6903
7C-4349	Mount As	383-2117
7J-6250	Bearing-Sleeve	385-3803
7J-9884	Bearing-Sleeve	325-6016

1WN		
Original Part Number	**Part Name**	**Classic Part Number**
7K-0084	Bearing-Sleeve	453-6508
7K-0087	Bearing-Sleeve	374-6514
7K-9528	Bearing-Sleeve	308-9828
7M-7219	Bearing-Thrust	384-4816
8B-5972	Bearing-Ball	314-8503
9C-3848	Bearing	417-4493
9D-7924	Mount As	360-2356
9L-2685	Rod End	419-1866
9M-1328	Bearing-Aligning	325-6018
9S-7949	Cup-Roller Brg	420-6531

1WN		
Original Part Number	**Part Name**	**Classic Part Number**
9T-5729	Cyl Gp-0038 0158	422-2486
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
116-8539	Spider & Brg Kit	399-4399
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
223-3095	Gauge As	360-2295
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model IT14G (Cont'd.)

8ZM		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
1P-9594	Bearing-Cup	377-7401
1S-7057	Gasket	420-6384
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2S-6097	Tang	375-9979
2W-7213	Bearing-Sleeve	419-4667
3H-8726	Mount As	385-7208
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5M-5856	Pipe-Extension	373-1913
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-1211	Cover-Valve	314-8665
5S-9080	Pulley-Alt Drive	264-5883
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6S-3465	Bearing-Sleeve	382-6903
6V-2202	Bearing-Spl Ball	380-1574
6Y-7652	Cup-Rlr Brg	399-6067
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-3938	Pulley-Alt	433-2030
7C-4349	Mount As	383-2117
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

8ZM		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7J-6250	Bearing-Sleeve	385-3803
7J-9884	Bearing-Sleeve	325-6016
7K-0087	Bearing-Sleeve	374-6514
7K-2135	Bearing-Roller	417-4492
7K-9528	Bearing-Sleeve	308-9828
7M-7219	Bearing-Thrust	384-4816
7N-2957	Cover-Rad Cap	361-1722
7P-2372	Joint As	367-6072
7S-7809	Cap As-Radiator	295-6417
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8B-5972	Bearing-Ball	314-8503
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8H-2810	Case As-Filter	314-8512
8R-1693	Pin As	415-1906
8R-6631	Hub	443-2057
8S-0248	Breather As	325-6033
9C-3848	Bearing	417-4493
9D-7924	Mount As	360-2356
9L-2685	Rod End	419-1866
9M-1328	Bearing-Aligning	325-6018
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
9V-4975	Bearing-Sleeve	384-4784
9W-9930	Mount As	295-6437
9W-9940	Mount As.	360-2355

8ZM		
Original Part Number	Part Name	Classic Part Number
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-4594	Muffler As	360-7862
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
116-8539	Spider & Brg Kit	399-4399
117-5200	Spider As-Fan	428-8686
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
222-0458	Muffler As	393-0929
223-3095	Gauge As	360-2295
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

Sales Model IT14G (Cont'd.)

ERP		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup-Roller Brg	374-8345
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
4T-8054	Seal As	472-8010
5M-5856	Pipe-Extension	373-1913
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015

ERP		
Original Part Number	**Part Name**	**Classic Part Number**
6S-3465	Bearing-Sleeve	382-6903
7C-4349	Mount As	383-2117
7K-0087	Bearing-Sleeve	374-6514
8B-5972	Bearing-Ball	314-8503
9D-7924	Mount As	360-2356
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp	422-2486

ERP		
Original Part Number	**Part Name**	**Classic Part Number**
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
116-8539	Spider & Brg Kit	399-4399
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
223-3095	Gauge As	360-2295
226-8202	Seal-Wiper	472-8024

FWL		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup-Roller Brg	374-8345
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
4T-8054	Seal As	472-8010
5M-5856	Pipe-Extension	373-1913
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6S-3465	Bearing-Sleeve	382-6903
7C-4349	Mount As	383-2117
7K-0084	Bearing-Sleeve	453-6508

FWL		
Original Part Number	**Part Name**	**Classic Part Number**
7K-0087	Bearing-Sleeve	374-6514
7M-7219	Bearing-Thrust	384-4816
8B-5972	Bearing-Ball	314-8503
9D-7924	Mount As	360-2356
9M-1328	Bearing-Aligning	325-6018
9S-7949	Cup-Roller Brg	420-6531
9T-5729	Cyl Gp-0038 0158	422-2486
9V-4975	Bearing-Sleeve	384-4784

FWL		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9940	Mount As.	360-2355
116-8539	Spider & Brg Kit	399-4399
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
223-3095	Gauge As	360-2295
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

KZN		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup-Roller Brg	374-8345
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
4T-8054	Seal As	472-8010
5M-5856	Pipe-Extension	373-1913
6K-8088	Bearing-Roller	399-4428
6L-7751	Rod End-Spher	472-8015
6S-3465	Bearing-Sleeve	382-6903

KZN		
Original Part Number	**Part Name**	**Classic Part Number**
7C-4349	Mount As	383-2117
7K-0087	Bearing-Sleeve	374-6514
7M-7219	Bearing-Thrust	384-4816
8B-5972	Bearing-Ball	314-8503
9D-7924	Mount As	360-2356
9M-1328	Bearing-Aligning	325-6018
9S-7949	Cup-Roller Brg	420-6531

KZN		
Original Part Number	**Part Name**	**Classic Part Number**
9T-5729	Cyl Gp-0038 0158	422-2486
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
116-8539	Spider & Brg Kit	399-4399
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
226-8202	Seal-Wiper	472-8024

Sales Model IT18

7ZB		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1219	Trunnion As	314-8724
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221

7ZB		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8271	Arm As-Rocker	432-8912
2W-9978	Core As-Oclr	279-4983
3B-4124	Cup-Spl Tapered	422-6481
3K-3124	Muffler-Trap	247-2673
3T-2094	Bearing-Sleeve	388-0638
4B-7255	Cone-Bearing	386-4951

7ZB		
Original Part Number	**Part Name**	**Classic Part Number**
4E-3456	Lever As	367-6081
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4T-3196	Cartridge Gp	422-8112
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4V-8629	Bearing-Sleeve	379-0194
4V-9577	Shaft-Planet	231-0001
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261

Sales Model IT18 (Cont'd.)

7ZB		
Original Part Number	**Part Name**	**Classic Part Number**
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-2931	Pump Gp-Vn Bsc-B	422-8161
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2706	Cap-Lower	451-6443
6K-2707	Plate-Lock	319-3470
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-6721	Coupling	377-5830
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277

7ZB		
Original Part Number	**Part Name**	**Classic Part Number**
6P-3735	Shaft-Planet	368-0103
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-7955	Gasket-Cover	382-6899
7E-9980	Camshaft	377-5851
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-2135	Bearing-Roller	417-4492
7K-7237	Gear-Planet	231-0009
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0691	Elbow-Water Rglt	378-3983
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996

7ZB		
Original Part Number	**Part Name**	**Classic Part Number**
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7681	Pipe-Exh Ext	385-7213
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6321	Gear-Sun	253-1441
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3753	Rod As-Conn	379-8867
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349

Sales Model IT18 (Cont'd.)

7ZB		
Original Part Number	Part Name	Classic Part Number
8N-6308	Bearing-Conn Rod	419-7267
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9M-5477	Bearing-Sleeve	374-6517
9N-5246	Bearing-Camshaft	384-4772
9N-5769	Cover-Housing	325-6050
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108

7ZB		
Original Part Number	Part Name	Classic Part Number
9P-7101	Plate-Clutch	368-0122
9S-2356	Manifold-Exhaust	261-0905
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9T-5096	Flexplate	455-3271
9V-3289	Pin As	382-6904
9V-3363	Pin As	396-0663
9V-3405	Bearing-Sleeve	425-6453
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-5168	Manifold-Exhaust	374-7483
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
140-2382	Gasket Kit	390-5285
140-2383	Gasket Kit	396-9927
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125

7ZB		
Original Part Number	Part Name	Classic Part Number
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
289-2935	Seal As-Buffer	472-8028
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

9NB		
Original Part Number	Part Name	Classic Part Number
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437

9NB		
Original Part Number	Part Name	Classic Part Number
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883

9NB		
Original Part Number	Part Name	Classic Part Number
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3821	Bearing-Conn Rod	376-9076

Sales Model IT18 (Cont'd.)

9NB		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3822	Bearing-Conn Rod	376-9077
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1219	Trunnion As	314-8724
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2K-9295	Bearing-Cone	422-6480

9NB		
Original Part Number	**Part Name**	**Classic Part Number**
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8271	Arm As-Rocker	432-8912
2W-9978	Core As-Oclr	279-4983
3B-4124	Cup-Spl Tapered	422-6481
3K-3124	Muffler-Trap	247-2673
3T-2094	Bearing-Sleeve	388-0638
4B-7255	Cone-Bearing	386-4951
4E-3456	Lever As	367-6081
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710

9NB		
Original Part Number	**Part Name**	**Classic Part Number**
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4T-3196	Cartridge Gp	422-8112
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4V-8629	Bearing-Sleeve	379-0194
4V-9577	Shaft-Planet	231-0001
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535

Sales Model IT18 (Cont'd.)

9NB		
Original Part Number	Part Name	Classic Part Number
6E-2931	Pump Gp-Vn Bsc-B	422-8161
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2706	Cap-Lower	451-6443
6K-2707	Plate-Lock	319-3470
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-6721	Coupling	377-5830
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-7955	Gasket-Cover	382-6899
7E-9980	Camshaft	377-5851
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625

9NB		
Original Part Number	Part Name	Classic Part Number
7G-7611	Gear-Ring	398-2925
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-2135	Bearing-Roller	417-4492
7K-7237	Gear-Planet	231-0009
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0691	Elbow-Water Rglt	378-3983
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7681	Pipe-Exh Ext	385-7213
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582

9NB		
Original Part Number	Part Name	Classic Part Number
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6321	Gear-Sun	253-1441
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3753	Rod As-Conn	379-8867
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6308	Bearing-Conn Rod	419-7267
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083

Sales Model IT18 (Cont'd.)

9NB		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-2470	Gasket Kit	393-5219
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
9D-7924	Mount As	360-2356
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9M-5477	Bearing-Sleeve	374-6517
9N-5246	Bearing-Camshaft	384-4772
9N-5769	Cover-Housing	325-6050
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-2356	Manifold-Exhaust	261-0905
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042

9NB		
Original Part Number	**Part Name**	**Classic Part Number**
9T-5096	Flexplate	455-3271
9V-3289	Pin As	382-6904
9V-3363	Pin As	396-0663
9V-3405	Bearing-Sleeve	425-6453
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-5168	Manifold-Exhaust	374-7483
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
140-2382	Gasket Kit	390-5285
140-2383	Gasket Kit	396-9927
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

9NB		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
289-2935	Seal As-Buffer	472-8028
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model IT18B

1DF		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1A-9252	Rod End-Yoke	377-5849

1DF		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-3980	Cone-Roller Brg	399-4443

1DF		
Original Part Number	**Part Name**	**Classic Part Number**
1M-7250	Bowl	360-2296
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076

Sales Model IT18B (Cont'd.)

1DF		
Original Part Number	Part Name	Classic Part Number
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1T-1446	Impeller-Conv	377-7413
1U-2668	Cartridge Gp	422-8117
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6541	Plunger As	325-6173

1DF		
Original Part Number	Part Name	Classic Part Number
1W-6987	Valve As-Check	420-6221
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-2654	Ring-Lock	380-1488
2D-9191	Cone-Roller Brg	374-1837
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0535	Nut	299-2026
2K-9295	Bearing-Cone	422-6480
2K-9295	Bearing-Cone	422-6480
2S-0479	Bearing-Cone	380-7506
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
2W-8271	Arm As-Rocker	432-8912

1DF		
Original Part Number	Part Name	Classic Part Number
3B-4124	Cup-Spl Tapered	422-6481
3B-4124	Cup-Spl Tapered	422-6481
3K-3124	Muffler-Trap	247-2673
3K-3124	Muffler-Trap	247-2673
3T-2094	Bearing-Sleeve	388-0638
3T-2094	Bearing-Sleeve	388-0638
4B-7255	Cone-Bearing	386-4951
4B-7255	Cone-Bearing	386-4951
4E-3456	Lever As	367-6081
4E-3456	Lever As	367-6081
4M-3915	Bearing-Caged	377-7427
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-0660	Muffler As	298-2787
4P-4757	Muffler As	360-7877
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4T-0998	Lever	314-8687
4T-3196	Cartridge Gp	422-8112
4T-3196	Cartridge Gp	422-8112
4T-8054	Seal As	472-8010
4T-8054	Seal As	472-8010
4V-0094	Shaft-Planet	380-1486
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243

Sales Model IT18B (Cont'd.)

1DF		
Original Part Number	Part Name	Classic Part Number
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4V-6527	Disc	376-9050
4V-8629	Bearing-Sleeve	379-0194
4V-8629	Bearing-Sleeve	379-0194
4V-9577	Shaft-Planet	231-0001
4V-9577	Shaft-Planet	231-0001
4W-1203	Cup-Rlr Brg	418-9603
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
4W-9492	Repair Kt-Major	375-2261
5L-2031	Cup-Roller Brg	384-5927
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6B-7469	Spacer	417-4535
6E-2930	Pump Gp-Vn Bsc-B	422-8158

1DF		
Original Part Number	Part Name	Classic Part Number
6E-2930	Pump Gp-Vn Bsc-B	422-8158
6F-2956	Cup-Spl Tapered	420-6538
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6H-3957	Bearing-Ball	311-9358
6K-2706	Cap-Lower	451-6443
6K-2706	Cap-Lower	451-6443
6K-2707	Plate-Lock	319-3470
6K-2707	Plate-Lock	319-3470
6K-5744	Cage-Bearing	330-9266
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6K-8275	Cone-Roller Brg	399-6070
6K-9070	Washer-Thrust	330-9294
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6K-9151	Bearing-Sleeve	330-9265
6L-7751	Rod End-Spher	472-8015
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834

1DF		
Original Part Number	Part Name	Classic Part Number
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6P-3735	Shaft-Planet	368-0103
6V-0347	Cone-Spl Tapered	420-6537
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6V-6896	Rebuild Kit	390-1006
6Y-6832	Bearing-Rlr As	421-8181
6Y-6832	Bearing-Rlr As	421-8181
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7934	Disc-Friction	384-5937
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
6Y-7965	Disc-Friction	392-4518
7C-7955	Gasket-Cover	382-6899
7C-7955	Gasket-Cover	382-6899
7G-2480	Gear-Planet	226-6091
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7G-7611	Gear-Ring	398-2925
7I-4187	Yoke-1550	380-1510
7I-4187	Yoke-1550	380-1510
7J-6461	Crown	325-6054
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7J-9682	Bearing-Sleeve	360-2335
7K-2135	Bearing-Roller	417-4492
7K-2135	Bearing-Roller	417-4492
7K-7237	Gear-Planet	231-0009
7K-7237	Gear-Planet	231-0009
7M-7219	Bearing-Thrust	384-4816
7M-7219	Bearing-Thrust	384-4816

Sales Model IT18B (Cont'd.)

1DF		
Original Part Number	Part Name	Classic Part Number
7N-0691	Elbow-Water Rglt	378-3983
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7N-7166	Race-Brg Thrust	417-4531
7P-1577	Pin As	375-9969
7P-1577	Pin As	375-9969
7S-7681	Pipe-Exh Ext	385-7213
7S-7681	Pipe-Exh Ext	385-7213
7S-8576	Bearing As	435-4848
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7W-2059	Gasket-Cyl Hd	380-1548
8E-4589	Carrier As	416-2122
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8H-9789	Bearing-Ball	374-8342
8K-6321	Gear-Sun	253-1441
8K-6321	Gear-Sun	253-1441
8N-2051	Compressor Gp -B	386-2063
8N-2051	Compressor Gp -B	386-2063

1DF		
Original Part Number	Part Name	Classic Part Number
8N-2516	Bonnet-Valve	377-5858
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8S-9151	Cup-Spl Tapered	374-8348
8T-2470	Gasket Kit	393-5219
8V-1612	Shaft	425-6456
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6435	Spider & Brg Kit	377-7451
8W-9566	Flange As	376-9073
8W-9566	Flange As	376-9073
9D-7924	Mount As	360-2356
9D-7924	Mount As	360-2356
9G-5525	Shaft-Planet	419-8662
9G-5525	Shaft-Planet	419-8662
9G-8931	Yoke As	446-3074
9G-8931	Yoke As	446-3074
9L-2685	Rod End	419-1866
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9M-1853	Mount As.	376-3638
9N-5246	Bearing-Camshaft	384-4772
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-5786	Lifter-Valve	457-6607

1DF		
Original Part Number	Part Name	Classic Part Number
9N-6500	Rod-Valve Push	383-3706
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9S-7949	Cup-Roller Brg	420-6531
9T-5096	Flexplate	455-3271
9T-5096	Flexplate	455-3271
9V-3289	Pin As	382-6904
9V-3289	Pin As	382-6904
9V-3363	Pin As	396-0663
9V-3363	Pin As	396-0663
9V-3405	Bearing-Sleeve	425-6453
9V-3405	Bearing-Sleeve	425-6453
9V-3406	Bearing-Sleeve	425-6441
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784
9V-4975	Bearing-Sleeve	384-4784
9W-6044	Shaft-Planet	384-5957
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795
9W-6390	Sleeve	385-3795
9Y-5168	Manifold-Exhaust	374-7483
9Y-5168	Manifold-Exhaust	374-7483
100-8010	Valve	423-5583

Sales Model IT18B (Cont'd.)

1DF		
Original Part Number	**Part Name**	**Classic Part Number**
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311

1DF		
Original Part Number	**Part Name**	**Classic Part Number**
121-7746	Pre-Cleaner As	360-2311
140-2382	Gasket Kit	390-5285
140-2383	Gasket Kit	396-9927
226-8202	Seal-Wiper	472-8024
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028

1DF		
Original Part Number	**Part Name**	**Classic Part Number**
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
308-1845	Seal-Wiper	472-8032

2NJ		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913

2NJ		
Original Part Number	**Part Name**	**Classic Part Number**
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2D-2566	Ring-Lock	416-2123
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-9295	Bearing-Cone	422-6480
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3B-4124	Cup-Spl Tapered	422-6481
3G-4704	Bearing-Sleeve	379-0185
3K-3124	Muffler-Trap	247-2673
3T-2094	Bearing-Sleeve	388-0638
4B-7255	Cone-Bearing	386-4951
4E-3456	Lever As	367-6081
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216

2NJ		
Original Part Number	**Part Name**	**Classic Part Number**
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4T-3196	Cartridge Gp	422-8112
4T-8054	Seal As	472-8010
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4V-8629	Bearing-Sleeve	379-0194
4V-9577	Shaft-Planet	231-0001
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
6E-2930	Pump Gp-Vn Bsc-B	422-8158
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6K-2706	Cap-Lower	451-6443
6K-2707	Plate-Lock	319-3470

Sales Model IT18B (Cont'd.)

2NJ		
Original Part Number	Part Name	Classic Part Number
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7C-7955	Gasket-Cover	382-6899
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-2135	Bearing-Roller	417-4492

2NJ		
Original Part Number	Part Name	Classic Part Number
7K-7237	Gear-Planet	231-0009
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7P-1577	Pin As	375-9969
7S-7681	Pipe-Exh Ext	385-7213
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6321	Gear-Sun	253-1441
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8W-9587	Flange As	373-5394
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266

2NJ		
Original Part Number	Part Name	Classic Part Number
9M-1853	Mount As.	376-3638
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7949	Cup-Roller Brg	420-6531
9T-5096	Flexplate	455-3271
9V-3289	Pin As	382-6904
9V-3363	Pin As	396-0663
9V-3405	Bearing-Sleeve	425-6453
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784
9W-6390	Sleeve	385-3795
9Y-5168	Manifold-Exhaust	374-7483
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
140-2382	Gasket Kit	390-5285
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

4ZD		
Original Part Number	Part Name	Classic Part Number
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296

4ZD		
Original Part Number	Part Name	Classic Part Number
1N-3165	Plunger-Rlf V	373-1883
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077

4ZD		
Original Part Number	Part Name	Classic Part Number
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770

Sales Model IT18B (Cont'd.)

4ZD		
Original Part Number	**Part Name**	**Classic Part Number**
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1219	Trunnion As	314-8724
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-5300	Rotocoil As	443-2659
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2D-9191	Cone-Roller Brg	374-1837
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-9295	Bearing-Cone	422-6480
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367

4ZD		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8271	Arm As-Rocker	432-8912
2W-9978	Core As-Oclr	279-4983
3B-4124	Cup-Spl Tapered	422-6481
3K-3124	Muffler-Trap	247-2673
3T-2094	Bearing-Sleeve	388-0638
4B-7255	Cone-Bearing	386-4951
4E-3456	Lever As	367-6081
4M-3915	Bearing-Caged	377-7427
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-1767	Valve-Bypass	419-4716
4N-2954	Sleeve-Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710

4ZD		
Original Part Number	**Part Name**	**Classic Part Number**
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4T-3196	Cartridge Gp	422-8112
4T-8054	Seal As	472-8010
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4V-8629	Bearing-Sleeve	379-0194
4V-9577	Shaft-Planet	231-0001
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219

Sales Model IT18B (Cont'd.)

4ZD		
Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley-Alt Drive	264-5883
6B-7469	Spacer	417-4535
6E-2930	Pump Gp-Vn Bsc-B	422-8158
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6K-2706	Cap-Lower	451-6443
6K-2707	Plate-Lock	319-3470
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-5482	Plate-Friction	376-3637
6N-6721	Coupling	377-5830
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
7C-2880	Bell As-Suction	380-1520

4ZD		
Original Part Number	Part Name	Classic Part Number
7C-3862	Camshaft	458-0151
7C-7955	Gasket-Cover	382-6899
7E-9980	Camshaft	377-5851
7G-2480	Gear-Planet	226-6091
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7J-6461	Crown	325-6054
7J-9682	Bearing-Sleeve	360-2335
7K-2135	Bearing-Roller	417-4492
7K-7237	Gear-Planet	231-0009
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0691	Elbow-Water Rglt	378-3983
7N-2949	Pulley	264-5887
7N-3536	Gear-Fuel	279-4993
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9146	Gear-Fly Starter	279-4995
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-7070	Head As-Cylinder	325-6107
7S-7681	Pipe-Exh Ext	385-7213
7T-2036	Cap As-Fuel	361-1721
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548

4ZD		
Original Part Number	Part Name	Classic Part Number
7W-5687	Hub-Cshft	314-8684
7W-7546	Gasket-Plate	433-8187
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6321	Gear-Sun	253-1441
8N-0081	Trunnion	393-5196
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3753	Rod As-Conn	379-8867
8N-4110	Bearing-Sleeve	394-8207
8N-5929	Cover-Water Pump	296-1349
8N-6308	Bearing-Conn Rod	419-7267
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386

Sales Model IT18B (Cont'd.)

4ZD		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8T-2470	Gasket Kit	393-5219
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
9D-7924	Mount As	360-2356
9J-5875	Bearing-Sleeve	308-9830
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9M-5477	Bearing-Sleeve	374-6517
9N-5246	Bearing-Camshaft	384-4772
9N-5769	Cover-Housing	325-6050
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-2356	Manifold-Exhaust	261-0905
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

4ZD		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9T-5096	Flexplate	455-3271
9V-3289	Pin As	382-6904
9V-3363	Pin As	396-0663
9V-3405	Bearing-Sleeve	425-6453
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-5168	Manifold-Exhaust	374-7483
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
140-2382	Gasket Kit	390-5285
140-2383	Gasket Kit	396-9927
148-7455	Valve - Exhaust	270-4361
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353

4ZD		
Original Part Number	**Part Name**	**Classic Part Number**
165-4262	Body As-Piston	477-7126
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model IT18F

5EJ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3978	Cup-Roller Brg	399-4437

5EJ		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3980	Cone-Roller Brg	399-4443
1B-3980	Cone-Roller Brg	399-4443

5EJ		
Original Part Number	**Part Name**	**Classic Part Number**
1H-5338	Cup-Roller Brg	374-8345
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296

Sales Model IT18F (Cont'd.)

5EJ		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1P-3934	Cup-Roller Brg	420-6535
1P-3934	Cup-Roller Brg	420-6535
1S-7057	Gasket	420-6384
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1401	Ring-Seal	384-4799
1T-1804	Stator As-Conv	388-0572
1T-1804	Stator As-Conv	388-0572
1T-1805	Turbine-Conv	380-1490
1T-1805	Turbine-Conv	380-1490
1W-1064	Gear-Flywheel	374-4703
1W-1064	Gear-Flywheel	374-4703
2D-2654	Ring-Lock	380-1488
2K-9295	Bearing-Cone	422-6480
2K-9295	Bearing-Cone	422-6480
2N-1599	Gear	378-3970
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3B-4124	Cup-Spl Tapered	422-6481
3H-8726	Mount As	385-7208
3H-8726	Mount As	385-7208
3T-2094	Bearing-Sleeve	388-0638
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4E-4524	Pin As	380-7392
4M-6107	Bearing-Roller	380-7507
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-8577	Rod As-Injector	455-5513

5EJ		
Original Part Number	Part Name	Classic Part Number
4T-0998	Lever	314-8687
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019
4V-2057	Bearing-Spher	419-6019
4W-1203	Cup-Rlr Brg	418-9603
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
5L-2031	Cup-Roller Brg	384-5927
5M-6212	Tube	390-0996
5M-6212	Tube	390-0996
6E-0775	Head	425-9373
6E-0775	Head	425-9373
6E-6476	Pump Gp-Vn Bsc-A	422-8163
6E-6476	Pump Gp-Vn Bsc-A	422-8163
6F-2956	Cup-Spl Tapered	420-6538
6F-2956	Cup-Spl Tapered	420-6538
6I-4689	Gasket-Cyl Head	377-5840
6I-4689	Gasket-Cyl Head	377-5840
6K-2707	Plate-Lock	319-3470
6K-2707	Plate-Lock	319-3470
6K-5746	Bearing-Roller	417-4503
6K-5746	Bearing-Roller	417-4503
6K-9070	Washer-Thrust	330-9294
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6K-9151	Bearing-Sleeve	330-9265
6P-0593	Bearing-Roller	386-4959
6P-0593	Bearing-Roller	386-4959
6V-0347	Cone-Spl Tapered	420-6537

5EJ		
Original Part Number	Part Name	Classic Part Number
6V-0347	Cone-Spl Tapered	420-6537
6V-4582	Bearing-Ball	380-1504
6V-4582	Bearing-Ball	380-1504
6Y-5913	Disc-Friction	391-9836
6Y-5913	Disc-Friction	391-9836
6Y-9960	Mount As.	376-3639
6Y-9960	Mount As.	376-3639
7C-3729	Pulley	376-9066
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-3760	Tube As-O Drain	375-5443
7C-6450	Pipe Gp-Ext	377-5862
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8636	Cone-Bearing	418-9606
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-7302	Bracket	416-5497
7I-4187	Yoke-1550	380-1510
7I-4187	Yoke-1550	380-1510
7J-9682	Bearing-Sleeve	360-2335
7J-9682	Bearing-Sleeve	360-2335
7M-7219	Bearing-Thrust	384-4816
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7P-1577	Pin As	375-9969

Sales Model IT18F (Cont'd.)

5EJ		
Original Part Number	Part Name	Classic Part Number
7T-2036	Cap As-Fuel	361-1721
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8C-3111	Rod End-Spher	392-4523
8F-6058	Bearing-Sleeve	416-5494
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8H-2810	Case As-Filter	314-8512
8R-2193	Piston	376-9051
8R-2193	Piston	376-9051
8R-2196	Plate-Reaction	375-2626
8R-2196	Plate-Reaction	375-2626
8R-2199	Gear-Planet	421-7986
8R-2199	Gear-Planet	421-7986
8R-2533	Piston	377-7446
8R-2533	Piston	377-7446
8R-2535	Plate-Reaction	377-7447
8R-2535	Plate-Reaction	377-7447
8S-0248	Breather As	325-6033
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8S-9151	Cup-Spl Tapered	374-8348
8V-1612	Shaft	425-6456
8V-1612	Shaft	425-6456
8V-3134	Pinion-Bevel	260-0788
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6435	Spider & Brg Kit	377-7451
8W-9566	Flange As	376-9073
9C-3848	Bearing	417-4493
9C-3848	Bearing	417-4493
9C-3857	Pin	374-6503
9C-3857	Pin	374-6503

5EJ		
Original Part Number	Part Name	Classic Part Number
9C-6318	Bearing-Sleeve	374-6516
9C-6318	Bearing-Sleeve	374-6516
9S-7949	Cup-Roller Brg	420-6531
9S-7949	Cup-Roller Brg	420-6531
9V-0247	Plate	417-4527
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9V-3289	Pin As	382-6904
9V-3363	Pin As	396-0663
9V-3363	Pin As	396-0663
9V-3405	Bearing-Sleeve	425-6453
9V-3405	Bearing-Sleeve	425-6453
9V-3406	Bearing-Sleeve	425-6441
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
005-0471	Cone-Spl Tapered	415-1924
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-6267	Plate As-Idler	375-9983
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
101-1530	Bearing-Main	419-6382
105-2125	Joint Gp-Slip	398-2937
105-2125	Joint Gp-Slip	398-2937

5EJ		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
119-2950	Gasket	433-8195
121-7746	Pre-Cleaner As	360-2311
121-7746	Pre-Cleaner As	360-2311
128-7228	Pump Gp-Vn Bsc-A	422-8153
136-0819	Valve-Exhaust	384-8697
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
152-3952	Impeller-Pump	374-4696
154-5685	Kit-Dt Gasket	396-0649
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
226-8202	Seal-Wiper	472-8024
228-0416	Seal As	430-5356
228-0416	Seal As	430-5356
229-5153	Bearing-Thrust	419-6370

Sales Model IT18F (Cont'd.)

5EJ		
Original Part Number	Part Name	Classic Part Number
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578

5EJ		
Original Part Number	Part Name	Classic Part Number
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107

5EJ		
Original Part Number	Part Name	Classic Part Number
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703
441-9566	Gear-Flywheel	374-4703

6ZF		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1P-3934	Cup-Roller Brg	420-6535
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1804	Stator As-Conv	388-0572
1T-1805	Turbine-Conv	380-1490
1W-1064	Gear-Flywheel	374-4703
2K-9295	Bearing-Cone	422-6480
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3H-8726	Mount As	385-7208
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4M-6107	Bearing-Roller	380-7507
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

6ZF		
Original Part Number	Part Name	Classic Part Number
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
5M-6212	Tube	390-0996
6E-0775	Head	425-9373
6E-6476	Pump Gp-Vn Bsc-A	422-8163
6F-2956	Cup-Spl Tapered	420-6538
6I-4689	Gasket-Cyl Head	377-5840
6K-2707	Plate-Lock	319-3470
6K-5746	Bearing-Roller	417-4503
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6P-0593	Bearing-Roller	386-4959
6V-0347	Cone-Spl Tapered	420-6537
6V-4582	Bearing-Ball	380-1504
6Y-5913	Disc-Friction	391-9836
6Y-9960	Mount As.	376-3639
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8636	Cone-Bearing	418-9606

6ZF		
Original Part Number	Part Name	Classic Part Number
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7I-4187	Yoke-1550	380-1510
7J-9682	Bearing-Sleeve	360-2335
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8R-2193	Piston	376-9051
8R-2196	Plate-Reaction	375-2626
8R-2199	Gear-Planet	421-7986
8R-2533	Piston	377-7446
8R-2535	Plate-Reaction	377-7447
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8V-1612	Shaft	425-6456
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
9C-3848	Bearing	417-4493
9C-3857	Pin	374-6503
9C-6318	Bearing-Sleeve	374-6516

Sales Model IT18F (Cont'd.)

6ZF		
Original Part Number	**Part Name**	**Classic Part Number**
9S-7949	Cup-Roller Brg	420-6531
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9V-3363	Pin As	396-0663
9V-3405	Bearing-Sleeve	425-6453
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-2125	Joint Gp-Slip	398-2937

6ZF		
Original Part Number	**Part Name**	**Classic Part Number**
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-1337	Ring Kit-Pstn	377-5834
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2950	Gasket	433-8195
121-7746	Pre-Cleaner As	360-2311
128-7228	Pump Gp-Vn Bsc-A	422-8153
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
154-5685	Kit-Dt Gasket	396-0649
155-5619	Gasket	382-5054
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372

6ZF		
Original Part Number	**Part Name**	**Classic Part Number**
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
228-0416	Seal As	430-5356
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
232-3679	Kit-Gasket (Rs)	437-2039
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

4NN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1P-3934	Cup-Roller Brg	420-6535
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1804	Stator As-Conv	388-0572
1T-1805	Turbine-Conv	380-1490
1W-1064	Gear-Flywheel	374-4703
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3E-7461	Gasket Kit-Sch	437-4575
3H-8726	Mount As	385-7208
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4P-3683	Pump Gp-Water -B	374-7498

4NN		
Original Part Number	**Part Name**	**Classic Part Number**
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019
4V-8643	Bearing-Sleeve	374-8354
4V-8661	Pin As	375-9968
4V-9901	Pin As	374-6508
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
6E-0775	Head	425-9373
6I-4689	Gasket-Cyl Head	377-5840
6K-2707	Plate-Lock	319-3470
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264

4NN		
Original Part Number	**Part Name**	**Classic Part Number**
6K-9151	Bearing-Sleeve	330-9265
6P-0593	Bearing-Roller	386-4959
6V-4582	Bearing-Ball	380-1504
6W-9172	Bearing	389-6330
6W-9173	Bearing	374-1457
6Y-9960	Mount As.	376-3639
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449

Sales Model IT18F (Cont'd.)

4NN		
Original Part Number	Part Name	Classic Part Number
7E-7302	Bracket	416-5497
7J-6250	Bearing-Sleeve	385-3803
7J-9682	Bearing-Sleeve	360-2335
7J-9884	Bearing-Sleeve	325-6016
7K-9528	Bearing-Sleeve	308-9828
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-2036	Cap As-Fuel	361-1721
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8R-2533	Piston	377-7446
8R-2535	Plate-Reaction	377-7447
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8V-1612	Shaft	425-6456
8V-6435	Spider & Brg Kit	377-7451
9C-3848	Bearing	417-4493
9C-3857	Pin	374-6503
9S-7949	Cup-Roller Brg	420-6531
9V-3289	Pin As	382-6904
9V-3363	Pin As	396-0663

4NN		
Original Part Number	Part Name	Classic Part Number
9V-3405	Bearing-Sleeve	425-6453
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-2125	Joint Gp-Slip	398-2937
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
116-8539	Spider & Brg Kit	399-4399
119-2950	Gasket	433-8195
121-7746	Pre-Cleaner As	360-2311
128-7228	Pump Gp-Vn Bsc-A	422-8153

4NN		
Original Part Number	Part Name	Classic Part Number
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
154-5685	Kit-Dt Gasket	396-0649
165-9864	Gasket Kit-Sch	388-0659
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

6KN		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1P-3934	Cup-Roller Brg	420-6535
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1804	Stator As-Conv	388-0572
1T-1805	Turbine-Conv	380-1490
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488

6KN		
Original Part Number	Part Name	Classic Part Number
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3E-7461	Gasket Kit-Sch	437-4575
3H-8726	Mount As	385-7208
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010

6KN		
Original Part Number	Part Name	Classic Part Number
4V-2057	Bearing-Spher	419-6019
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5J-7010	Seal As	472-8011
5L-2031	Cup-Roller Brg	384-5927
6E-0775	Head	425-9373
6I-4689	Gasket-Cyl Head	377-5840
6K-2707	Plate-Lock	319-3470
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265

Wheel Loaders

Sales Model IT18F (Cont'd.)

6KN		
Original Part Number	**Part Name**	**Classic Part Number**
6P-0593	Bearing-Roller	386-4959
6V-4582	Bearing-Ball	380-1504
6Y-9960	Mount As.	376-3639
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7J-9682	Bearing-Sleeve	360-2335
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-2036	Cap As-Fuel	361-1721
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8R-2533	Piston	377-7446
8R-2535	Plate-Reaction	377-7447
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8V-1612	Shaft	425-6456

6KN		
Original Part Number	**Part Name**	**Classic Part Number**
8V-6435	Spider & Brg Kit	377-7451
8W-9566	Flange As	376-9073
9C-3848	Bearing	417-4493
9C-3857	Pin	374-6503
9S-7949	Cup-Roller Brg	420-6531
9V-3289	Pin As	382-6904
9V-3363	Pin As	396-0663
9V-3405	Bearing-Sleeve	425-6453
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-2125	Joint Gp-Slip	398-2937
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
116-8539	Spider & Brg Kit	399-4399

6KN		
Original Part Number	**Part Name**	**Classic Part Number**
119-2950	Gasket	433-8195
121-7746	Pre-Cleaner As	360-2311
128-7228	Pump Gp-Vn Bsc-A	422-8153
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
154-5685	Kit-Dt Gasket	396-0649
165-9864	Gasket Kit-Sch	388-0659
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703

Sales Model IT28

2KC		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443

2KC		
Original Part Number	**Part Name**	**Classic Part Number**
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076

2KC		
Original Part Number	**Part Name**	**Classic Part Number**
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147

Sales Model IT28 (Cont'd.)

2KC		
Original Part Number	Part Name	Classic Part Number
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3K-3124	Muffler-Trap	247-2673
3T-2094	Bearing-Sleeve	388-0638
4E-3456	Lever As	367-6081
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217

2KC		
Original Part Number	Part Name	Classic Part Number
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5V-7574	Ring-Retaining	392-4483
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6H-3957	Bearing-Ball	311-9358
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690

2KC		
Original Part Number	Part Name	Classic Part Number
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7C-7955	Gasket-Cover	382-6899
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7I-4187	Yoke-1550	380-1510
7J-9682	Bearing-Sleeve	360-2335
7K-0084	Bearing-Sleeve	453-6508
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7P-1577	Pin As	375-9969
7S-7681	Pipe-Exh Ext	385-7213
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867

Sales Model IT28 (Cont'd.)

2KC		
Original Part Number	**Part Name**	**Classic Part Number**
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
9G-5525	Shaft-Planet	419-8662
9G-8931	Yoke As	446-3074
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-5246	Bearing-Camshaft	384-4772

2KC		
Original Part Number	**Part Name**	**Classic Part Number**
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-5096	Flexplate	455-3271
9V-3289	Pin As	382-6904
9V-3363	Pin As	396-0663
9V-3405	Bearing-Sleeve	425-6453
9V-3406	Bearing-Sleeve	425-6441

2KC		
Original Part Number	**Part Name**	**Classic Part Number**
9V-4975	Bearing-Sleeve	384-4784
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795
9Y-5168	Manifold-Exhaust	374-7483
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
140-2383	Gasket Kit	396-9927
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024

8JB		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1P-7125	Governor As	383-3672
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117

8JB		
Original Part Number	**Part Name**	**Classic Part Number**
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554

8JB		
Original Part Number	**Part Name**	**Classic Part Number**
2W-8271	Arm As-Rocker	432-8912
3K-3124	Muffler-Trap	247-2673
3T-2094	Bearing-Sleeve	388-0638
4E-3456	Lever As	367-6081
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

Sales Model IT28 (Cont'd.)

8JB		
Original Part Number	Part Name	Classic Part Number
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5V-7574	Ring-Retaining	392-4483
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6H-3957	Bearing-Ball	311-9358
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937

8JB		
Original Part Number	Part Name	Classic Part Number
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7C-7955	Gasket-Cover	382-6899
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7I-4187	Yoke-1550	380-1510
7J-9682	Bearing-Sleeve	360-2335
7K-0084	Bearing-Sleeve	453-6508
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531
7P-1577	Pin As	375-9969
7S-7681	Pipe-Exh Ext	385-7213
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033
8S-9151	Cup-Spl Tapered	374-8348
8T-2470	Gasket Kit	393-5219
8V-1612	Shaft	425-6456

8JB		
Original Part Number	Part Name	Classic Part Number
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
9G-5525	Shaft-Planet	419-8662
9G-8931	Yoke As	446-3074
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9T-5096	Flexplate	455-3271
9V-3289	Pin As	382-6904
9V-3363	Pin As	396-0663
9V-3405	Bearing-Sleeve	425-6453
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795
9Y-5168	Manifold-Exhaust	374-7483
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
140-2383	Gasket Kit	396-9927
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024

1HF		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1H-5338	Cup-Roller Brg	374-8345
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-4693	Cup-Rlr Bearing	377-7398
1P-5480	Cover As.-End	299-1998
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-0576	Bearing-Sleeve	379-0186
1T-1401	Ring-Seal	384-4799
1T-1428	Retainer-Brg	300-2587
1T-1446	Impeller-Conv	377-7413
1T-1647	Impeller-Conv	377-7415

1HF		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-5920	Bearing-Camshaft	421-1558
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157

1HF		
Original Part Number	**Part Name**	**Classic Part Number**
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2P-8986	Cup-Rlr Bearing	415-1912
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8271	Arm As-Rocker	432-8912
3G-2752	Cartridge Gp-Rr	422-8127
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638

Sales Model IT28B (Cont'd.)

1HF		
Original Part Number	Part Name	Classic Part Number
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
4E-3456	Lever As	367-6081
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-8204	Mount As	374-1449
4N-8344	Spider As-Fan	416-5520
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010

1HF		
Original Part Number	Part Name	Classic Part Number
4V-0092	Hub As	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-3680	Bellcrank	308-9802
4V-3842	Support-Trunnion	396-9935
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-6527	Disc	376-9050
4V-7543	Retainer	281-1699
4V-7545	Gear-Ring	394-9823
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
4W-9655	Support	419-0882
4Y-1034	Pin As	396-0641
5L-2031	Cup-Roller Brg	384-5927
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247

1HF		
Original Part Number	Part Name	Classic Part Number
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
5V-7574	Ring-Retaining	392-4483
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2932	Pump Gp-Vn Bsc-B	422-8155
6H-3957	Bearing-Ball	311-9358
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6K-8895	Cap	374-6500
6L-7751	Rod End-Spher	472-8015
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-6721	Coupling	377-5830
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389

Sales Model IT28B (Cont'd.)

1HF		
Original Part Number	Part Name	Classic Part Number
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200
6V-6896	Rebuild Kit	390-1006
6W-2899	Shaft-Pinion	446-3057
6Y-3484	Bearing-Spl Ball	416-2166
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-7955	Gasket-Cover	382-6899
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7H-4566	Cup-Roller Brg	399-6068
7I-4187	Yoke-1550	380-1510

1HF		
Original Part Number	Part Name	Classic Part Number
7J-9682	Bearing-Sleeve	360-2335
7K-0084	Bearing-Sleeve	453-6508
7K-0686	Trunnion-Rear	297-7266
7K-2135	Bearing-Roller	417-4492
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0691	Elbow-Water Rglt	378-3983
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-7681	Pipe-Exh Ext	385-7213
7S-8443	Muffler	247-2675
7S-8576	Bearing As	435-4848
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-0638	Spacer	425-3651
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7W-7546	Gasket-Plate	433-8187

1HF		
Original Part Number	Part Name	Classic Part Number
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3753	Rod As-Conn	379-8867
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6308	Bearing-Conn Rod	419-7267
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

Sales Model IT28B (Cont'd.)

1HF		
Original Part Number	Part Name	Classic Part Number
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
8T-2470	Gasket Kit	393-5219
8V-1537	Gear-Sun	446-3061
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
8V-7659	Pin As	361-1702
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-5525	Shaft-Planet	419-8662
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9G-8931	Yoke As	446-3074
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-4460	Housing As-Cl	297-7203
9N-5246	Bearing-Camshaft	384-4772
9N-5769	Cover-Housing	325-6050
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122

1HF		
Original Part Number	Part Name	Classic Part Number
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9V-3363	Pin As	396-0663
9V-3405	Bearing-Sleeve	425-6453
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784
9V-8693	Actuator Gp-Bk	375-2629
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-5168	Manifold-Exhaust	374-7483
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
138-2317	Wheel	396-9948
140-2383	Gasket Kit	396-9927
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599

1HF		
Original Part Number	Part Name	Classic Part Number
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
247-2670	Muffler-Classic	247-2675
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
275-0120	Pin As	419-7245
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440

Sales Model IT28B (Cont'd.)

1JK		
Original Part Number	**Part Name**	**Classic Part Number**
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1P-4693	Cup-Rlr Bearing	377-7398
1S-1888	Bracket-Lamp	297-7147
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1446	Impeller-Conv	377-7413
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-4402	Gear-Camshaft	279-4981
1W-5920	Bearing-Camshaft	421-1558
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382

1JK		
Original Part Number	**Part Name**	**Classic Part Number**
2W-1223	Pump Gp-Water	385-7197
2W-5536	Core As-Radiator	380-7554
2W-8271	Arm As-Rocker	432-8912
3K-3124	Muffler-Trap	247-2673
3T-2094	Bearing-Sleeve	388-0638
4E-3456	Lever As	367-6081
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-8204	Mount As	374-1449
4P-0660	Muffler As	298-2787
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-4852	Piston	433-0452
4V-6527	Disc	376-9050
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5P-9514	Bearing-Ball	417-9467
5S-5917	Screw-Rocker Adj	380-7537
5S-9080	Pulley-Alt Drive	264-5883
5V-7574	Ring-Retaining	392-4483
6C-0570	Pump Gp-Mtrg Bsc	374-5380

1JK		
Original Part Number	**Part Name**	**Classic Part Number**
6H-3957	Bearing-Ball	311-9358
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6L-7751	Rod End-Spher	472-8015
6N-6721	Coupling	377-5830
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6V-2202	Bearing-Spl Ball	380-1574
6V-6896	Rebuild Kit	390-1006
6Y-6832	Bearing-Rlr As	421-8181
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
7C-7955	Gasket-Cover	382-6899
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7I-4187	Yoke-1550	380-1510
7J-9682	Bearing-Sleeve	360-2335
7K-0084	Bearing-Sleeve	453-6508
7K-2135	Bearing-Roller	417-4492
7M-7219	Bearing-Thrust	384-4816
7N-0691	Elbow-Water Rglt	378-3983
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-7166	Race-Brg Thrust	417-4531

Sales Model IT28B (Cont'd.)

1JK		
Original Part Number	Part Name	Classic Part Number
7P-1577	Pin As	375-9969
7S-7681	Pipe-Exh Ext	385-7213
7S-8576	Bearing As	435-4848
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-3753	Rod As-Conn	379-8867
8N-6308	Bearing-Conn Rod	419-7267
8S-0248	Breather As	325-6033

1JK		
Original Part Number	Part Name	Classic Part Number
8S-9151	Cup-Spl Tapered	374-8348
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
9G-5525	Shaft-Planet	419-8662
9G-8931	Yoke As	446-3074
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9N-5246	Bearing-Camshaft	384-4772
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144

1JK		
Original Part Number	Part Name	Classic Part Number
9T-5096	Flexplate	455-3271
9V-3289	Pin As	382-6904
9V-3363	Pin As	396-0663
9V-3405	Bearing-Sleeve	425-6453
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795
9Y-5168	Manifold-Exhaust	374-7483
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
140-2383	Gasket Kit	396-9927
213-1364	Bearing-Sleeve	330-9255
226-8202	Seal-Wiper	472-8024

5SD		
Original Part Number	Part Name	Classic Part Number
0R-8169	Compressor Gp	386-2063
0R-8169	Compressor Gp	386-2063
1A-9252	Rod End-Yoke	377-5849
1A-9252	Rod End-Yoke	377-5849
1B-3978	Cup-Roller Brg	399-4437
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-3980	Cone-Roller Brg	399-4443
1H-5338	Cup-Roller Brg	374-8345
1H-5338	Cup-Roller Brg	374-8345
1K-8041	Bearing-Sleeve	330-9257
1K-8041	Bearing-Sleeve	330-9257
1M-7250	Bowl	360-2296

5SD		
Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl	360-2296
1N-3165	Plunger-Rlf V	373-1883
1N-3165	Plunger-Rlf V	373-1883
1N-3574	Block Gp-Cyl	460-8298
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3576	Block Gp-Cyl	279-4978
1N-3821	Bearing-Conn Rod	376-9076
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1N-3822	Bearing-Conn Rod	376-9077
1N-3958	Elbow	325-6087
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761

5SD		
Original Part Number	Part Name	Classic Part Number
1N-4304	Head Gp-Cyl -A	269-8761
1P-1216	Manifold-Exhaust	261-0902
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-1722	Gear-Balance	298-2770
1P-4693	Cup-Rlr Bearing	377-7398
1P-4693	Cup-Rlr Bearing	377-7398
1P-5480	Cover As.-End	299-1998
1P-5480	Cover As.-End	299-1998
1P-7125	Governor As	383-3672

Sales Model IT28B (Cont'd.)

5SD		
Original Part Number	Part Name	Classic Part Number
1P-7125	Governor As	383-3672
1P-9945	Bracket As-Fan	296-1344
1P-9945	Bracket As-Fan	296-1344
1S-1888	Bracket-Lamp	297-7147
1S-1888	Bracket-Lamp	297-7147
1S-3062	Director-Water	418-9572
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-3743	Bearing-Ball	384-4786
1T-0020	Wheel-Turbine	297-4862
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0043	Bearing-Ball	390-5294
1T-0079	Wheel-Turbine	382-6894
1T-0079	Wheel-Turbine	382-6894
1T-0334	Bearing-Ball	380-1476
1T-0334	Bearing-Ball	380-1476
1T-0576	Bearing-Sleeve	379-0186
1T-0576	Bearing-Sleeve	379-0186
1T-1401	Ring-Seal	384-4799
1T-1401	Ring-Seal	384-4799
1T-1428	Retainer-Brg	300-2587
1T-1428	Retainer-Brg	300-2587
1T-1446	Impeller-Conv	377-7413
1T-1446	Impeller-Conv	377-7413
1T-1647	Impeller-Conv	377-7415
1T-1647	Impeller-Conv	377-7415
1T-1987	Housing-Rotating	297-4864
1T-1987	Housing-Rotating	297-4864
1T-1991	Stator As-Conv	380-1482
1T-1991	Stator As-Conv	380-1482
1U-2665	Cartridge Gp	422-8108
1U-2665	Cartridge Gp	422-8108
1U-2668	Cartridge Gp	422-8117
1U-2668	Cartridge Gp	422-8117
1V-6342	Gear As	308-9847

5SD		
Original Part Number	Part Name	Classic Part Number
1V-6342	Gear As	308-9847
1W-0311	Bearing-Main	376-9078
1W-0311	Bearing-Main	376-9078
1W-0312	Bearing-Main	376-9079
1W-0312	Bearing-Main	376-9079
1W-0568	Pump Gp-F Tfr	377-5859
1W-0568	Pump Gp-F Tfr	377-5859
1W-1661	Bearing-Main	376-9080
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-1662	Bearing-Main	382-6900
1W-1669	Piston	325-6158
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1698	Housing-Tfr Pump	296-1356
1W-2870	Shaft As-Balance	314-8715
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-2871	Shaft As-Balance	314-8716
1W-3900	Gasket	472-8006
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4407	Hub-Fan Pulley	296-1358
1W-5300	Rotocoil As	443-2659
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-5912	Tappet As-Guide&	325-6223
1W-5920	Bearing-Camshaft	421-1558
1W-5920	Bearing-Camshaft	421-1558
1W-6473	Compressor Gp -B	448-9150

5SD		
Original Part Number	Part Name	Classic Part Number
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6541	Plunger As	325-6173
1W-6987	Valve As-Check	420-6221
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9171	Bonnet-Valve	374-4707
1W-9771	Crankshaft As	368-5913
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2B-0941	Spacer	418-1955
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2D-2654	Ring-Lock	380-1488
2D-9191	Cone-Roller Brg	374-1837
2D-9454	Cup-Roller Brg	415-1914
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9455	Cone-Roller Brg	415-1915
2F-5721	Bearing-Ball	311-9354
2F-5721	Bearing-Ball	311-9354
2K-0535	Nut	299-2026
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-0714	Plate-Thrust	299-2040
2K-5065	Cone-Roller Brg	416-2157
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5066	Cone-Roller Brg	396-4142

Sales Model IT28B (Cont'd.)

5SD		
Original Part Number	Part Name	Classic Part Number
2K-5069	Cup-Roller Brg	374-8346
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5073	Bushing	299-1989
2K-9295	Bearing-Cone	422-6480
2L-5271	Bearing-Ball	371-4305
2L-5271	Bearing-Ball	371-4305
2P-0220	Gasket-Pump	398-2927
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1170	Shaft As-Gear	296-1367
2P-1757	Hub-Fan Pulley	296-1357
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2719	Pipe-Oil Filler	363-7454
2P-6245	Shaft As-Pump	325-6197
2P-6245	Shaft As-Pump	325-6197
2P-7828	Pan-Oil	314-8691
2P-7828	Pan-Oil	314-8691
2P-8912	Elbow-Exhaust	398-2957
2P-8912	Elbow-Exhaust	398-2957
2P-8986	Cup-Rlr Bearing	415-1912
2P-8986	Cup-Rlr Bearing	415-1912
2S-0479	Bearing-Cone	380-7506
2S-0479	Bearing-Cone	380-7506
2V-7990	Tube As	373-5382
2V-7990	Tube As	373-5382
2W-1223	Pump Gp-Water	385-7197
2W-1223	Pump Gp-Water	385-7197
2W-1707	Ring-Piston Top	270-4356
2W-1707	Ring-Piston Top	270-4356

5SD		
Original Part Number	Part Name	Classic Part Number
2W-1708	Ring-Piston	270-4357
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-2621	Valve-Inlet	247-6892
2W-5240	Pipe-Pump Outlet	376-9055
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-5536	Core As-Radiator	380-7554
2W-6757	Trunnion As	295-5678
2W-6757	Trunnion As	295-5678
2W-7255	Shaft-Water Pump	325-6203
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-7678	Gear-Water Pump	325-6088
2W-8271	Arm As-Rocker	432-8912
2W-8271	Arm As-Rocker	432-8912
3B-4124	Cup-Spl Tapered	422-6481
3G-2752	Cartridge Gp-Rr	422-8127
3G-2752	Cartridge Gp-Rr	422-8127
3G-4704	Bearing-Sleeve	379-0185
3G-4704	Bearing-Sleeve	379-0185
3G-5285	Bearing-Sleeve	360-2312
3G-5285	Bearing-Sleeve	360-2312
3K-3124	Muffler-Trap	247-2673
3K-3124	Muffler-Trap	247-2673
3L-1425	Bearing-Ball	311-9356
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-2094	Bearing-Sleeve	388-0638
3T-9496	Plate-Retainer	299-2042

5SD		
Original Part Number	Part Name	Classic Part Number
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487
3T-9960	Disc-Friction	417-9487
4B-7255	Cone-Bearing	386-4951
4E-3456	Lever As	367-6081
4E-3456	Lever As	367-6081
4K-7420	Retainer	297-7234
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4K-7463	Seal-Lip Type	472-8007
4M-3915	Bearing-Caged	377-7427
4M-3915	Bearing-Caged	377-7427
4N-0432	Bearing-Ball	417-4499
4N-0432	Bearing-Ball	417-4499
4N-4539	Sleeve	314-8720
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	269-8764
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-7978	Shaft As-Balance	314-8710
4N-8204	Mount As	374-1449
4N-8204	Mount As	374-1449
4N-8344	Spider As-Fan	416-5520
4N-8344	Spider As-Fan	416-5520
4P-0660	Muffler As	298-2787
4P-0660	Muffler As	298-2787
4P-3546	Valve As-Relief	325-6236
4P-3546	Valve As-Relief	325-6236
4P-4757	Muffler As	360-7877
4P-4757	Muffler As	360-7877
4P-7688	Valve As-Check	420-6216
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7827	Gear-Crankshaft	380-7533

Sales Model IT28B (Cont'd.)

5SD		
Original Part Number	**Part Name**	**Classic Part Number**
4P-8915	Gasket-Cyl Head	377-5838
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9384	Line As-Fuel Inj	279-4989
4P-9942	Seal-End Tank	385-7217
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4P-9964	Line As-Fuel Inj	298-2778
4S-8538	Bearing-Spl Ball	417-4502
4S-8538	Bearing-Spl Ball	417-4502
4T-0998	Lever	314-8687
4T-0998	Lever	314-8687
4T-3196	Cartridge Gp	422-8112
4T-8054	Seal As	472-8010
4T-8054	Seal As	472-8010

5SD		
Original Part Number	**Part Name**	**Classic Part Number**
4V-0092	Hub As	396-9934
4V-0092	Hub As	396-9934
4V-0093	Gear-Planet	394-9826
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-0094	Shaft-Planet	380-1486
4V-2518	Shaft	297-7243
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-2883	Bearing-Sleeve	379-0193
4V-3619	Pin As	380-7393
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-3625	Pin As	418-1944
4V-3680	Bellcrank	308-9802
4V-3680	Bellcrank	308-9802
4V-3842	Support-Trunnion	396-9935
4V-3842	Support-Trunnion	396-9935
4V-4852	Piston	433-0452
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-5099	Cover	418-1929
4V-6527	Disc	376-9050
4V-6527	Disc	376-9050
4V-7543	Retainer	281-1699
4V-7543	Retainer	281-1699
4V-7545	Gear-Ring	394-9823
4V-7545	Gear-Ring	394-9823
4V-8629	Bearing-Sleeve	379-0194

5SD		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8643	Bearing-Sleeve	374-8354
4V-8661	Pin As	375-9968
4V-9577	Shaft-Planet	231-0001
4V-9901	Pin As	374-6508
4W-0452	Seal As -Cshaft	325-6191
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
4W-2357	Mount As	386-4927
4W-6869	Spacer-Fuel Pump	417-4534
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-7188	Core As-Oclr	374-7501
4W-9480	Rod As-Pstn &	378-3976
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
4W-9492	Repair Kt-Major	375-2261
4W-9655	Support	419-0882
4W-9655	Support	419-0882
4Y-1034	Pin As	396-0641
4Y-1034	Pin As	396-0641
5L-2031	Cup-Roller Brg	384-5927
5L-2031	Cup-Roller Brg	384-5927
5M-9644	Bearing-Outer	384-5929
5M-9644	Bearing-Outer	384-5929
5P-2526	Cup-Rlr Bearing	380-7498
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8768	Kit-Gasket (Scl)	393-1024

Sales Model IT28B (Cont'd.)

5SD		
Original Part Number	**Part Name**	**Classic Part Number**
5P-9514	Bearing-Ball	417-9467
5P-9514	Bearing-Ball	417-9467
5S-5879	Bracket-Shaft	330-9247
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-7630	Bearing-Sleeve	394-0219
5S-9080	Pulley-Alt Drive	264-5883
5S-9080	Pulley-Alt Drive	264-5883
5V-1274	Spider	385-6110
5V-1274	Spider	385-6110
5V-6327	Yoke-Flange Bk	391-1086
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
5V-6328	Yoke As	451-9035
5V-7574	Ring-Retaining	392-4483
5V-7574	Ring-Retaining	392-4483
6B-7469	Spacer	417-4535
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6E-2931	Pump Gp-Vn Bsc-B	422-8161
6E-2932	Pump Gp-Vn Bsc-B	422-8155
6E-2932	Pump Gp-Vn Bsc-B	422-8155
6F-2956	Cup-Spl Tapered	420-6538
6H-3957	Bearing-Ball	311-9358
6H-3957	Bearing-Ball	311-9358

5SD		
Original Part Number	**Part Name**	**Classic Part Number**
6I-1345	Shaft As-O Pump	374-7475
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-8849	Cone-Rlr Bearing	415-1919
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6I-8860	Cup-Roller Brg	380-7495
6K-2706	Cap-Lower	451-6443
6K-2707	Plate-Lock	319-3470
6K-4189	Spacer	367-6075
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-5746	Bearing-Roller	417-4503
6K-8275	Cone-Roller Brg	399-6070
6K-8275	Cone-Roller Brg	399-6070
6K-8895	Cap	374-6500
6K-8895	Cap	374-6500
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6L-7751	Rod End-Spher	472-8015
6L-7751	Rod End-Spher	472-8015

5SD		
Original Part Number	**Part Name**	**Classic Part Number**
6N-1036	Gear-Oil Pump	279-4991
6N-1036	Gear-Oil Pump	279-4991
6N-1553	Coupling-Exhaust	295-6422
6N-1553	Coupling-Exhaust	295-6422
6N-6721	Coupling	377-5830
6N-6721	Coupling	377-5830
6N-7174	Shield-Oil	314-8544
6N-7174	Shield-Oil	314-8544
6P-0593	Bearing-Roller	386-4959
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-0748	Carrier-Planet	373-5389
6P-2233	Gear-Planet	281-1690
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2234	Gear-Planet	380-1479
6P-2473	Gear-Ring	449-9834
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-2474	Gear-Ring	480-8277
6P-3735	Shaft-Planet	368-0103
6P-3735	Shaft-Planet	368-0103
6P-7564	Carrier-Ring	384-3850
6P-7564	Carrier-Ring	384-3850
6P-7742	Shaft-Planet	281-1695
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6P-8005	Gear-Planet	281-1691
6T-5383	Gear-Ring	375-2624
6T-5383	Gear-Ring	375-2624
6V-0347	Cone-Spl Tapered	420-6537
6V-2202	Bearing-Spl Ball	380-1574
6V-2202	Bearing-Spl Ball	380-1574
6V-5976	Kit-Gasket (Rs)	393-5200
6V-5976	Kit-Gasket (Rs)	393-5200

Sales Model IT28B (Cont'd.)

5SD		
Original Part Number	Part Name	Classic Part Number
6V-6896	Rebuild Kit	390-1006
6V-6896	Rebuild Kit	390-1006
6W-2899	Shaft-Pinion	446-3057
6W-2899	Shaft-Pinion	446-3057
6Y-3484	Bearing-Spl Ball	416-2166
6Y-3484	Bearing-Spl Ball	416-2166
6Y-6832	Bearing-Rlr As	421-8181
6Y-6832	Bearing-Rlr As	421-8181
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7934	Disc-Friction	384-5937
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7935	Disc-Friction	383-2121
6Y-7965	Disc-Friction	392-4518
6Y-7965	Disc-Friction	392-4518
7B-7515	Bearing-Ball	399-6059
7B-7515	Bearing-Ball	399-6059
7C-2880	Bell As-Suction	380-1520
7C-2880	Bell As-Suction	380-1520
7C-3862	Camshaft	458-0151
7C-3862	Camshaft	458-0151
7C-7955	Gasket-Cover	382-6899
7C-7955	Gasket-Cover	382-6899
7E-9918	Repair Kit-Major	388-0655
7E-9918	Repair Kit-Major	388-0655
7E-9980	Camshaft	377-5851
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-0437	Plate-Clutch	417-9466
7G-2480	Gear-Planet	226-6091
7G-3707	Piston-Clutch	302-2691
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4306	Plate-Center	297-7229
7G-4990	Case-Xmsn	388-6561
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5444	Carrier-Planet	297-7165

5SD		
Original Part Number	Part Name	Classic Part Number
7G-5445	Carrier-Planet	469-4669
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-5614	Shaft-Planet	281-1697
7G-7610	Gear-Ring	375-2625
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7G-7611	Gear-Ring	398-2925
7H-4566	Cup-Roller Brg	399-6068
7H-4566	Cup-Roller Brg	399-6068
7I-4187	Yoke-1550	380-1510
7I-4187	Yoke-1550	380-1510
7J-9682	Bearing-Sleeve	360-2335
7J-9682	Bearing-Sleeve	360-2335
7K-0084	Bearing-Sleeve	453-6508
7K-0084	Bearing-Sleeve	453-6508
7K-0686	Trunnion-Rear	297-7266
7K-0686	Trunnion-Rear	297-7266
7K-2135	Bearing-Roller	417-4492
7K-2135	Bearing-Roller	417-4492
7K-7237	Gear-Planet	231-0009
7M-4046	Bearing-Sleeve	394-8206
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7M-7219	Bearing-Thrust	384-4816
7N-0165	Core As-O Clr	295-5670
7N-0165	Core As-O Clr	295-5670
7N-0691	Elbow-Water Rglt	378-3983
7N-0691	Elbow-Water Rglt	378-3983
7N-1164	Mount As	295-5451
7N-1164	Mount As	295-5451
7N-2834	Kit-Repair	374-4723
7N-2834	Kit-Repair	374-4723

5SD		
Original Part Number	Part Name	Classic Part Number
7N-5206	Mount As	374-1451
7N-5206	Mount As	374-1451
7N-5656	Sleeve	384-3848
7N-5656	Sleeve	384-3848
7N-5910	Impeller-Pump	314-8686
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7166	Race-Brg Thrust	417-4531
7N-7765	Governor As	377-5841
7N-7765	Governor As	377-5841
7N-7998	Plate-Block	374-7496
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-8022	Gasket-Cyl Head	378-3985
7N-9145	Gear-Flywheel	279-4994
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7N-9805	Pin-Piston	295-6438
7P-1577	Pin As	375-9969
7P-1577	Pin As	375-9969
7S-3161	Lifter-Valve	279-4996
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7S-4534	Bearing-Caged	417-9497
7S-7681	Pipe-Exh Ext	385-7213
7S-7681	Pipe-Exh Ext	385-7213
7S-8443	Muffler	247-2675
7S-8443	Muffler	247-2675
7S-8576	Bearing As	435-4848
7S-8576	Bearing As	435-4848
7S-8736	Pipe-Ext Exhaust	382-5066
7S-8736	Pipe-Ext Exhaust	382-5066
7T-2036	Cap As-Fuel	361-1721
7T-2036	Cap As-Fuel	361-1721
7T-8174	Gear-Planet	388-0583

Sales Model IT28B (Cont'd.)

5SD		
Original Part Number	Part Name	Classic Part Number
7T-8174	Gear-Planet	388-0583
7T-9989	Housing As-Cl	380-1509
7T-9989	Housing As-Cl	380-1509
7V-0638	Spacer	425-3651
7V-0638	Spacer	425-3651
7V-5645	Rod-Indicator	397-5061
7V-5645	Rod-Indicator	397-5061
7W-0508	Gear-Fp Drive	296-1351
7W-0508	Gear-Fp Drive	296-1351
7W-1058	Tube As-Supply	393-3613
7W-1058	Tube As-Supply	393-3613
7W-1927	Ring-Retainer	387-2935
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7W-2059	Gasket-Cyl Hd	380-1548
7W-7546	Gasket-Plate	433-8187
7W-7546	Gasket-Plate	433-8187
8A-2251	Liner-Cylinder	376-9068
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8A-2305	Repair Kt-Major	386-3042
8E-4024	Carrier-Planet	398-8333
8E-4589	Carrier As	416-2122
8E-4589	Carrier As	416-2122
8E-5284	Bearing	388-0582
8E-5284	Bearing	388-0582
8F-3170	Bearing-Roller	417-4504
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8H-9789	Bearing-Ball	374-8342
8K-6321	Gear-Sun	253-1441
8N-0703	Bearing-Sleeve	472-8037
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1187	Head Gp-Cyl -A	242-3435

5SD		
Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1721	Rod As-Conn	269-5291
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-1849	Bearing-Conn Rod	379-0196
8N-2051	Compressor Gp -B	386-2063
8N-2051	Compressor Gp -B	386-2063
8N-2516	Bonnet-Valve	377-5858
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3327	Arm Gp-V Rocker	314-8624
8N-3753	Rod As-Conn	379-8867
8N-3753	Rod As-Conn	379-8867
8N-4110	Bearing-Sleeve	394-8207
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5305	Spacer	363-7464

5SD		
Original Part Number	Part Name	Classic Part Number
8N-5929	Cover-Water Pump	296-1349
8N-5929	Cover-Water Pump	296-1349
8N-6308	Bearing-Conn Rod	419-7267
8N-6308	Bearing-Conn Rod	419-7267
8N-6796	Head Gp-Cyl -A	269-5290
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8229	Bearing-Main	376-9084
8P-3563	Cage-Bearing	451-0747
8P-3563	Cage-Bearing	451-0747
8S-0248	Breather As	325-6033
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3970	Chamber As	242-3438
8S-6511	Bearing-Sleeve	380-7372

Sales Model IT28B (Cont'd.)

5SD		
Original Part Number	Part Name	Classic Part Number
8S-6511	Bearing-Sleeve	380-7372
8S-9151	Cup-Spl Tapered	374-8348
8S-9151	Cup-Spl Tapered	374-8348
8T-0072	Cone-Rlr Brg	377-7448
8T-0072	Cone-Rlr Brg	377-7448
8T-2470	Gasket Kit	393-5219
8V-1537	Gear-Sun	446-3061
8V-1537	Gear-Sun	446-3061
8V-1612	Shaft	425-6456
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-1624	Lever	299-2019
8V-3134	Pinion-Bevel	260-0788
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
8V-6825	Joint Gp-Slip	453-0972
8V-7659	Pin As	361-1702
8V-7659	Pin As	361-1702
8W-9566	Flange As	376-9073
8W-9566	Flange As	376-9073
9D-7924	Mount As	360-2356
9G-1231	Plate	297-7232
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1488	Housing-Clutch	430-7620
9G-5525	Shaft-Planet	419-8662
9G-5525	Shaft-Planet	419-8662
9G-5842	Gear-Transfer	394-0913
9G-5842	Gear-Transfer	394-0913
9G-8117	Housing As-Cl	302-2686
9G-8117	Housing As-Cl	302-2686
9G-8931	Yoke As	446-3074
9G-8931	Yoke As	446-3074
9L-2685	Rod End	419-1866
9L-2685	Rod End	419-1866
9L-7682	Valve-Inlet	385-9266
9L-7682	Valve-Inlet	385-9266
9M-1853	Mount As.	376-3638
9M-1853	Mount As.	376-3638

5SD		
Original Part Number	Part Name	Classic Part Number
9N-4460	Housing As-Cl	297-7203
9N-4460	Housing As-Cl	297-7203
9N-5246	Bearing-Camshaft	384-4772
9N-5246	Bearing-Camshaft	384-4772
9N-5769	Cover-Housing	325-6050
9N-5769	Cover-Housing	325-6050
9N-5786	Lifter-Valve	457-6607
9N-5786	Lifter-Valve	457-6607
9N-6500	Rod-Valve Push	383-3706
9N-6500	Rod-Valve Push	383-3706
9P-6799	Piston-Clutch	469-4671
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-6903	Plate	368-0108
9P-7101	Plate-Clutch	368-0122
9P-7101	Plate-Clutch	368-0122
9S-3581	Cup-Roller Brg	415-1923
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3582	Cone-Roller Brg	396-4144
9S-7788	Ring-Piston	461-5124
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8679	Chamber As	325-6042
9S-8679	Chamber As	325-6042
9T-2200	Cartridgr Gp	422-8114
9T-2200	Cartridgr Gp	422-8114
9T-5096	Flexplate	455-3271
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9V-3289	Pin As	382-6904
9V-3363	Pin As	396-0663
9V-3363	Pin As	396-0663
9V-3405	Bearing-Sleeve	425-6453
9V-3405	Bearing-Sleeve	425-6453

5SD		
Original Part Number	Part Name	Classic Part Number
9V-3406	Bearing-Sleeve	425-6441
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784
9V-4975	Bearing-Sleeve	384-4784
9V-8693	Actuator Gp-Bk	375-2629
9V-8693	Actuator Gp-Bk	375-2629
9W-4950	Gear-Sun	281-1688
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
9W-4957	Carrier-Planet	390-0913
9W-6044	Shaft-Planet	384-5957
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-6046	Carrier As	388-0645
9W-6390	Sleeve	385-3795
9W-6390	Sleeve	385-3795
9Y-1798	Seal-Water	379-0165
9Y-1798	Seal-Water	379-0165
9Y-2991	Bearing-Sleeve	377-5833
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-2992	Bearing-Sleeve	325-6032
9Y-5168	Manifold-Exhaust	374-7483
9Y-5168	Manifold-Exhaust	374-7483
005-4834	Cone-Rlr Bearing	422-6490
005-4834	Cone-Rlr Bearing	422-6490
100-7860	Valve-Inlet	270-4360
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
100-8010	Valve	423-5583
110-1337	Ring Kit-Pstn	377-5834
110-1337	Ring Kit-Pstn	377-5834
111-8015	Gasket As-Head	279-4977
111-8015	Gasket As-Head	279-4977

Sales Model IT28B (Cont'd.)

5SD		
Original Part Number	Part Name	Classic Part Number
114-4680	Gear As-Pump	374-7485
114-4680	Gear As-Pump	374-7485
115-0637	Pump Gp-Gr 1	226-0160
115-0637	Pump Gp-Gr 1	226-0160
119-6772	Valve-Exhaust	384-8699
119-6772	Valve-Exhaust	384-8699
121-7746	Pre-Cleaner As	360-2311
121-7746	Pre-Cleaner As	360-2311
131-3815	Seal Gp-Basic	325-6193
131-3815	Seal Gp-Basic	325-6193
138-2317	Wheel	396-9948
138-2317	Wheel	396-9948
140-2383	Gasket Kit	396-9927
148-7455	Valve - Exhaust	270-4361
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
168-4531	Body As-Piston	477-7127

5SD		
Original Part Number	Part Name	Classic Part Number
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-1750	Seal Gp-Basic	472-8022
170-7502	Shaft-Dr Idler	374-7484
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-6712	Impeller-Pump	325-6112
172-7766	Pump Gp-Water -B	374-4698
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7771	Pump Gp-Water -B	419-4646
196-0028	Gear As-Idler	364-5259
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-0029	Gear As-Idler	374-4674
213-1364	Bearing-Sleeve	330-9255

5SD		
Original Part Number	Part Name	Classic Part Number
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
226-8202	Seal-Wiper	472-8024
232-3233	Bearing-Main	376-9085
232-3233	Bearing-Main	376-9085
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6893
241-3381	Valve Kit-Cla	247-6892
247-2670	Muffler-Classic	247-2675
247-2670	Muffler-Classic	247-2675
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
275-0120	Pin As	419-7245
275-0120	Pin As	419-7245
296-1359	Line As-Cla	279-4988
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
296-1360	Line As-Cla	279-4989
328-5572	Bearing-Rod	419-6349
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
334-8389	Crankshaft As	242-3439
337-0872	Crankshaft As	242-3440
337-0872	Crankshaft As	242-3440

Sales Model IT28F

1JL		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296

1JL		
Original Part Number	Part Name	Classic Part Number
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476

1JL		
Original Part Number	Part Name	Classic Part Number
1T-1401	Ring-Seal	384-4799
1T-1494	Impeller-Conv	388-6564

Sales Model IT28F (Cont'd.)

1JL		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1804	Stator As-Conv	388-0572
1T-1805	Turbine-Conv	380-1490
1T-2041	Carrier As	396-9893
2B-0941	Spacer	418-1955
2D-2654	Ring-Lock	380-1488
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4K-7463	Seal-Lip Type	472-8007
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
5J-7010	Seal As	472-8011
5M-6212	Tube	390-0996
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281

1JL		
Original Part Number	**Part Name**	**Classic Part Number**
6K-5746	Bearing-Roller	417-4503
6P-0593	Bearing-Roller	386-4959
6V-0347	Cone-Spl Tapered	420-6537
6V-4582	Bearing-Ball	380-1504
6Y-5913	Disc-Friction	391-9836
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7I-4187	Yoke-1550	380-1510
7J-8210	Cone-Roller Brg	423-6987
7J-9682	Bearing-Sleeve	360-2335
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512
8R-2193	Piston	376-9051
8R-2196	Plate-Reaction	375-2626
8R-2199	Gear-Planet	421-7986
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-3134	Pinion-Bevel	260-0788

1JL		
Original Part Number	**Part Name**	**Classic Part Number**
8V-6435	Spider & Brg Kit	377-7451
8W-9566	Flange As	376-9073
9C-6318	Bearing-Sleeve	374-6516
9U-3665	Joint Gp-Univ -A	398-8342
9U-3670	Yoke As	432-4221
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9V-3363	Pin As	396-0663
9V-3405	Bearing-Sleeve	425-6453
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784
9W-9931	Mount As.	360-2354
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-6267	Plate As-Idler	375-9983
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
126-5875	Flywheel As.	374-4694
128-7228	Pump Gp-Vn Bsc-A	422-8153
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592

Sales Model IT28F (Cont'd.)

1JL		
Original Part Number	Part Name	Classic Part Number
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371

1JL		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
228-0416	Seal As	430-5356
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912

1JL		
Original Part Number	Part Name	Classic Part Number
277-7089	Shaft As	380-7578
282-6648	Kit-Dt Gasket	396-9955
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

3CL		
Original Part Number	Part Name	Classic Part Number
1H-5338	Cup-Roller Brg	374-8345
1M-7250	Bowl	360-2296
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1494	Impeller-Conv	388-6564
1T-1804	Stator As-Conv	388-0572
1T-1805	Turbine-Conv	380-1490
1T-2041	Carrier As	396-9893
2B-0941	Spacer	418-1955
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4K-7463	Seal-Lip Type	472-8007
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-0998	Lever	314-8687
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927

3CL		
Original Part Number	Part Name	Classic Part Number
5J-7010	Seal As	472-8011
5M-6212	Tube	390-0996
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4189	Spacer	367-6075
6K-4191	Cap-Upper	300-2576
6K-4193	Plate-Lock	282-6566
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6P-0593	Bearing-Roller	386-4959
6V-0347	Cone-Spl Tapered	420-6537
6V-4582	Bearing-Ball	380-1504
6Y-5913	Disc-Friction	391-9836
6Y-9960	Mount As.	376-3639
7C-1371	Coupling-Exhaust	369-9490
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317

3CL		
Original Part Number	Part Name	Classic Part Number
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7I-4187	Yoke-1550	380-1510
7J-6250	Bearing-Sleeve	385-3803
7J-8210	Cone-Roller Brg	423-6987
7J-9344	Bearing-Sleeve	360-2334
7J-9682	Bearing-Sleeve	360-2335
7J-9884	Bearing-Sleeve	325-6016
7K-9528	Bearing-Sleeve	308-9828
7M-7219	Bearing-Thrust	384-4816
7P-1577	Pin As	375-9969
7T-2036	Cap As-Fuel	361-1721
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
7W-9027	Base-Oil Cooler	399-8545
8C-3111	Rod End-Spher	392-4523
8F-6058	Bearing-Sleeve	416-5494
8H-2810	Case As-Filter	314-8512

Wheel Loaders

Sales Model IT28F (Cont'd.)

3CL		
Original Part Number	Part Name	Classic Part Number
8J-5778	Bearing-Sleeve	374-8359
8R-2193	Piston	376-9051
8R-2196	Plate-Reaction	375-2626
8R-2199	Gear-Planet	421-7986
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-3134	Pinion-Bevel	260-0788
8V-6435	Spider & Brg Kit	377-7451
9C-6318	Bearing-Sleeve	374-6516
9M-1328	Bearing-Aligning	325-6018
9U-3665	Joint Gp-Univ -A	398-8342
9U-3670	Yoke As	432-4221
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9V-3363	Pin As	396-0663
9V-3405	Bearing-Sleeve	425-6453
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756

3CL		
Original Part Number	Part Name	Classic Part Number
9Y-8534	Support-Shft	463-7671
100-2941	Gasket Kit	393-1020
100-2953	Gasket Kit-Sch	393-1025
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-6267	Plate As-Idler	375-9983
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
121-7746	Pre-Cleaner As	360-2311
126-5875	Flywheel As.	374-4694
128-7228	Pump Gp-Vn Bsc-A	422-8153
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592

3CL		
Original Part Number	Part Name	Classic Part Number
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
176-3900	Accumulator	416-5513
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
228-0416	Seal As	430-5356
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
265-5287	Ring-Seal	472-8028
266-5907	Kit-Gasket-Cl	438-0155
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
282-6648	Kit-Dt Gasket	396-9955
286-2494	Kit-Gasket-Sch	387-2920
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

Sales Model IT28G

8CR		
Original Part Number	Part Name	Classic Part Number
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1494	Impeller-Conv	388-6564
1T-1804	Stator As-Conv	388-0572
1T-1805	Turbine-Conv	380-1490
1V-9148	Bearing-Sleeve	308-9811
1W-1064	Gear-Flywheel	374-4703

8CR		
Original Part Number	Part Name	Classic Part Number
2B-0941	Spacer	418-1955
2K-9295	Bearing-Cone	422-6480
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329
3G-5285	Bearing-Sleeve	360-2312
3T-2094	Bearing-Sleeve	388-0638

8CR		
Original Part Number	Part Name	Classic Part Number
4E-4524	Pin As	380-7392
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019
4V-2883	Bearing-Sleeve	379-0193
4V-8629	Bearing-Sleeve	379-0194

Sales Model IT28G (Cont'd.)

8CR		
Original Part Number	**Part Name**	**Classic Part Number**
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
5J-7010	Seal As	472-8011
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
6V-4582	Bearing-Ball	380-1504
6W-9172	Bearing	389-6330
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7J-6250	Bearing-Sleeve	385-3803
7J-9344	Bearing-Sleeve	360-2334
7J-9682	Bearing-Sleeve	360-2335
7J-9884	Bearing-Sleeve	325-6016
7K-9528	Bearing-Sleeve	308-9828
7M-7219	Bearing-Thrust	384-4816
7S-4411	Cap As-Rain	373-1912
7W-3773	Pulley-Cshaft	383-1583

8CR		
Original Part Number	**Part Name**	**Classic Part Number**
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8J-5778	Bearing-Sleeve	374-8359
8R-2193	Piston	376-9051
8R-2196	Plate-Reaction	375-2626
8S-0248	Breather As	325-6033
9D-7924	Mount As	360-2356
9J-5875	Bearing-Sleeve	308-9830
9M-1328	Bearing-Aligning	325-6018
9T-8944	Cyl Gp-102 356 Y	393-3665
9U-3670	Yoke As	432-4221
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
106-7799	Bearing-Ball	396-9947
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
116-8533	Yoke As	451-9031

9AR		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437

8CR		
Original Part Number	**Part Name**	**Classic Part Number**
116-8537	Shaft Gp-Drive-D	418-9570
116-8539	Spider & Brg Kit	399-4399
119-1852	Cyl Gp 0102 0755	430-5960
119-2940	Gasket	378-4002
122-6381	Pin As	419-6073
122-6387	Pin As	425-6448
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
176-3900	Accumulator	416-5513
177-4132	Kit-Dt Gasket	394-8227
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
228-0416	Seal As	430-5356
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
441-9566	Gear-Flywheel	374-4703
460-5395	Kit-Gasket (Sch)	436-8395

Sales Model IT28G (Cont'd.)

9AR		
Original Part Number	Part Name	Classic Part Number
1B-3980	Cone-Roller Brg	399-4443
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1494	Impeller-Conv	388-6564
1T-1804	Stator As-Conv	388-0572
1T-1805	Turbine-Conv	380-1490
1V-9148	Bearing-Sleeve	308-9811
1W-1064	Gear-Flywheel	374-4703
2B-0941	Spacer	418-1955
2K-9295	Bearing-Cone	422-6480
2N-1599	Gear	378-3970
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019
4V-8629	Bearing-Sleeve	379-0194
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
5J-7010	Seal As	472-8011
5P-7807	Bearing-Ball	314-8502
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537

9AR		
Original Part Number	Part Name	Classic Part Number
6V-4582	Bearing-Ball	380-1504
6W-9172	Bearing	389-6330
7C-1371	Coupling-Exhaust	369-9490
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7J-9344	Bearing-Sleeve	360-2334
7J-9682	Bearing-Sleeve	360-2335
7M-7219	Bearing-Thrust	384-4816
7S-4411	Cap As-Rain	373-1912
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8R-2193	Piston	376-9051
8R-2196	Plate-Reaction	375-2626
8S-0248	Breather As	325-6033
9D-7924	Mount As	360-2356
9U-3670	Yoke As	432-4221
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
106-7799	Bearing-Ball	396-9947

9AR		
Original Part Number	Part Name	Classic Part Number
107-7708	Bearing-Main	419-6381
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
116-8533	Yoke As	451-9031
116-8537	Shaft Gp-Drive-D	418-9570
116-8539	Spider & Brg Kit	399-4399
119-1852	Cyl Gp 0102 0755	430-5960
119-2940	Gasket	378-4002
122-6381	Pin As	419-6073
122-6387	Pin As	425-6448
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
151-5349	Head	383-1592
152-3952	Impeller-Pump	374-4696
163-1387	Gear-Flywheel	374-4697
176-3900	Accumulator	416-5513
177-4132	Kit-Dt Gasket	394-8227
212-4893	Bearing-Thrust	419-6372
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
226-8202	Seal-Wiper	472-8024
228-0416	Seal As	430-5356
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
233-9204	Kit-Seal-H.Cyl-1	472-8025
271-5658	Crankshaft As.	368-5912
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789

Sales Model IT28G (Cont'd.)

9AR		
Original Part Number	**Part Name**	**Classic Part Number**
441-9566	Gear-Flywheel	374-4703

9AR		
Original Part Number	**Part Name**	**Classic Part Number**
460-5395	Kit-Gasket (Sch)	436-8395

DBT		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1V-9148	Bearing-Sleeve	308-9811
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019
4V-8629	Bearing-Sleeve	379-0194
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011
5T-5682	Driver	418-9579
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919

DBT		
Original Part Number	**Part Name**	**Classic Part Number**
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
6W-9172	Bearing	389-6330
7J-6250	Bearing-Sleeve	385-3803
7J-9344	Bearing-Sleeve	360-2334
7J-9682	Bearing-Sleeve	360-2335
7J-9884	Bearing-Sleeve	325-6016
7K-9528	Bearing-Sleeve	308-9828
7M-7219	Bearing-Thrust	384-4816
9D-7924	Mount As	360-2356
9J-5875	Bearing-Sleeve	308-9830
9M-1328	Bearing-Aligning	325-6018
9T-8944	Cyl Gp-102 356 Y	393-3665
9V-3406	Bearing-Sleeve	425-6441

DBT		
Original Part Number	**Part Name**	**Classic Part Number**
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
119-1852	Cyl Gp 0102 0755	430-5960
121-7746	Pre-Cleaner As	360-2311
122-6381	Pin As	419-6073
122-6387	Pin As	425-6448
151-5349	Head	383-1592
176-3900	Accumulator	416-5513
199-5067	Muffler As	360-7894
213-1370	Bearing-Sleeve	380-7370
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

EWF		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3S-3875	Screen-Suction	435-4849

EWF		
Original Part Number	**Part Name**	**Classic Part Number**
3T-2094	Bearing-Sleeve	388-0638
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-4524	Pin As	380-7392
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019
4V-8629	Bearing-Sleeve	379-0194
4V-8674	Bearing-Sleeve	307-1529

EWF		
Original Part Number	**Part Name**	**Classic Part Number**
5J-7010	Seal As	472-8011
5M-7925	Bearing-Roller	419-7774
5V-1274	Spider	385-6110
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428

Sales Model IT28G (Cont'd.)

EWF		
Original Part Number	**Part Name**	**Classic Part Number**
6T-2293	Piston-Load	426-0040
6T-5611	Spacer	435-8520
6V-0347	Cone-Spl Tapered	420-6537
6Y-3484	Bearing-Spl Ball	416-2166
7G-7431	Piston-Selector	432-8911
7J-6250	Bearing-Sleeve	385-3803
7J-9344	Bearing-Sleeve	360-2334
7J-9682	Bearing-Sleeve	360-2335
7J-9884	Bearing-Sleeve	325-6016
7K-0078	Bearing-Sleeve	308-9825

EWF		
Original Part Number	**Part Name**	**Classic Part Number**
7K-9528	Bearing-Sleeve	308-9828
7M-7219	Bearing-Thrust	384-4816
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
9D-7924	Mount As	360-2356
9J-5875	Bearing-Sleeve	308-9830
9K-1171	Cup-Rlr Bearing	430-3339
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924

EWF		
Original Part Number	**Part Name**	**Classic Part Number**
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
122-6381	Pin As	419-6073
122-6387	Pin As	425-6448
128-3935	Bearing-Race	396-9897
151-5349	Head	383-1592
176-3900	Accumulator	416-5513
199-5067	Muffler As	360-7894
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

WAC		
Original Part Number	**Part Name**	**Classic Part Number**
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1M-7250	Bowl	360-2296
1V-9148	Bearing-Sleeve	308-9811
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329
3T-2094	Bearing-Sleeve	388-0638
4E-4524	Pin As	380-7392
4T-8054	Seal As	472-8010
4V-2057	Bearing-Spher	419-6019
4V-8629	Bearing-Sleeve	379-0194
4V-8674	Bearing-Sleeve	307-1529
5J-7010	Seal As	472-8011
5T-5682	Driver	418-9579

WAC		
Original Part Number	**Part Name**	**Classic Part Number**
6E-0775	Head	425-9373
6F-2956	Cup-Spl Tapered	420-6538
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-0347	Cone-Spl Tapered	420-6537
6W-9172	Bearing	389-6330
7J-9682	Bearing-Sleeve	360-2335
7M-7219	Bearing-Thrust	384-4816
9D-7924	Mount As	360-2356
9V-3406	Bearing-Sleeve	425-6441
9V-4975	Bearing-Sleeve	384-4784
9W-9940	Mount As.	360-2355
9Y-7215	Sleeve-Isolator	425-3646

WAC		
Original Part Number	**Part Name**	**Classic Part Number**
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
106-7799	Bearing-Ball	396-9947
114-1071	Piston	388-6583
119-1852	Cyl Gp 0102 0755	430-5960
121-7746	Pre-Cleaner As	360-2311
122-6381	Pin As	419-6073
122-6387	Pin As	425-6448
151-5349	Head	383-1592
176-3900	Accumulator	416-5513
199-5067	Muffler As	360-7894
226-8202	Seal-Wiper	472-8024
233-9204	Kit-Seal-H.Cyl-1	472-8025
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032

Sales Model IT38F

5DR		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
1T-2041	Carrier As	396-9893
2B-0941	Spacer	418-1955
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
3T-2094	Bearing-Sleeve	388-0638
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383
4E-2168	Piston	375-2623
4E-2250	Housing	399-6043
4E-3997	Housing-Pinion	374-6498
4J-0121	Cap-Bearing	360-2344
4K-7463	Seal-Lip Type	472-8007
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2883	Bearing-Sleeve	379-0193
4V-5099	Cover	418-1929
4V-7105	Pin As	361-1699

5DR		
Original Part Number	Part Name	Classic Part Number
4V-8674	Bearing-Sleeve	307-1529
4V-9901	Pin As	374-6508
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2357	Mount As	386-4927
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5V-1274	Spider	385-6110
5V-7574	Ring-Retaining	392-4483
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6P-0593	Bearing-Roller	386-4959
6V-4582	Bearing-Ball	380-1504
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
7C-1371	Coupling-Exhaust	369-9490
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7H-4566	Cup-Roller Brg	399-6068
7J-5131	Trunnion	296-1371
7J-8210	Cone-Roller Brg	423-6987
7W-3773	Pulley-Cshaft	383-1583

5DR		
Original Part Number	Part Name	Classic Part Number
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8J-5778	Bearing-Sleeve	374-8359
8R-1891	Gear-Ring	450-7547
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9R-4067	Joint Gp-Univ	373-5399
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-3650	Support-Trunnion	394-2580
100-3651	Support-Trunnion	445-7699
100-5927	Joint Gp-Univ -A	390-5260
100-6267	Plate As-Idler	375-9983
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
103-1713	Yoke-Bk-Flange	382-6892
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381

Sales Model IT38F (Cont'd.)

5DR		
Original Part Number	**Part Name**	**Classic Part Number**
107-7750	Pulley	382-6896
110-6167	Pin As	375-9972
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694
136-0819	Valve-Exhaust	384-8697
138-1840	Retainer-Seal	374-6511
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388

5DR		
Original Part Number	**Part Name**	**Classic Part Number**
152-3952	Impeller-Pump	374-4696
159-1845	Yoke As (1480)	380-1494
163-1387	Gear-Flywheel	374-4697
179-1970	Yoke As.	376-9053
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369

5DR		
Original Part Number	**Part Name**	**Classic Part Number**
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578
282-6648	Kit-Dt Gasket	396-9955
286-2494	Kit-Gasket-Sch	387-2920
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
334-1033	Disc-Friction	394-8242
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
460-5395	Kit-Gasket (Sch)	436-8395

6FN		
Original Part Number	**Part Name**	**Classic Part Number**
1B-4038	Cup-Roller Brg	423-6988
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
1T-2041	Carrier As	396-9893
2B-0941	Spacer	418-1955
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
3T-2094	Bearing-Sleeve	388-0638
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383

6FN		
Original Part Number	**Part Name**	**Classic Part Number**
4E-2168	Piston	375-2623
4E-2250	Housing	399-6043
4E-3997	Housing-Pinion	374-6498
4J-0121	Cap-Bearing	360-2344
4K-7463	Seal-Lip Type	472-8007
4P-3683	Pump Gp-Water -B	374-7498
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2883	Bearing-Sleeve	379-0193
4V-5099	Cover	418-1929
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4V-9901	Pin As	374-6508
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

6FN		
Original Part Number	**Part Name**	**Classic Part Number**
4W-2357	Mount As	386-4927
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5V-1274	Spider	385-6110
5V-7574	Ring-Retaining	392-4483
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6P-0593	Bearing-Roller	386-4959
6V-4582	Bearing-Ball	380-1504
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
7C-1371	Coupling-Exhaust	369-9490
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-5403	Tube As	374-4673

Sales Model IT38F (Cont'd.)

6FN		
Original Part Number	Part Name	Classic Part Number
7C-6450	Pipe Gp-Ext	377-5862
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7H-4566	Cup-Roller Brg	399-6068
7J-5131	Trunnion	296-1371
7J-6250	Bearing-Sleeve	385-3803
7J-8210	Cone-Roller Brg	423-6987
7J-9884	Bearing-Sleeve	325-6016
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
7W-5426	Camshaft As.	378-3987
7W-8064	Valve-Inlet	384-8705
8C-3111	Rod End-Spher	392-4523
8H-2810	Case As-Filter	314-8512
8J-5778	Bearing-Sleeve	374-8359
8R-1891	Gear-Ring	450-7547
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439

6FN		
Original Part Number	Part Name	Classic Part Number
9J-5875	Bearing-Sleeve	308-9830
9R-4067	Joint Gp-Univ	373-5399
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9W-9940	Mount As.	360-2355
9Y-4668	Muffler As	373-1911
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-3650	Support-Trunnion	394-2580
100-3651	Support-Trunnion	445-7699
100-5927	Joint Gp-Univ -A	390-5260
100-6267	Plate As-Idler	375-9983
101-1530	Bearing-Main	419-6382
103-1713	Yoke-Bk-Flange	382-6892
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
110-6167	Pin As	375-9972
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
126-5875	Flywheel As.	374-4694

6FN		
Original Part Number	Part Name	Classic Part Number
136-0819	Valve-Exhaust	384-8697
138-1840	Retainer-Seal	374-6511
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
152-3952	Impeller-Pump	374-4696
159-1845	Yoke As (1480)	380-1494
163-1387	Gear-Flywheel	374-4697
179-1970	Yoke As.	376-9053
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578
282-6648	Kit-Dt Gasket	396-9955
286-2494	Kit-Gasket-Sch	387-2920
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
334-1033	Disc-Friction	394-8242
352-2151	Pump Gp-Water -B	434-6107
352-2160	Pump Gp-Water -B	433-0789
460-5395	Kit-Gasket (Sch)	436-8395

Sales Model IT38G

1CW		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988

Sales Model IT38G (Cont'd.)

1CW		
Original Part Number	**Part Name**	**Classic Part Number**
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
1T-2041	Carrier As	396-9893
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383
4E-2168	Piston	375-2623
4E-2250	Housing	399-6043
4E-3997	Housing-Pinion	374-6498
4J-0121	Cap-Bearing	360-2344
4K-7463	Seal-Lip Type	472-8007
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2883	Bearing-Sleeve	379-0193
4V-5099	Cover	418-1929

1CW		
Original Part Number	**Part Name**	**Classic Part Number**
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4V-9901	Pin As	374-6508
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-7574	Ring-Retaining	392-4483
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-4582	Bearing-Ball	380-1504
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
7C-1371	Coupling-Exhaust	369-9490
7C-3729	Pulley	376-9066
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7H-4566	Cup-Roller Brg	399-6068
7J-5131	Trunnion	296-1371
7J-8210	Cone-Roller Brg	423-6987
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551

1CW		
Original Part Number	**Part Name**	**Classic Part Number**
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8J-5778	Bearing-Sleeve	374-8359
8R-1891	Gear-Ring	450-7547
8S-0248	Breather As	325-6033
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9D-7924	Mount As	360-2356
9R-4067	Joint Gp-Univ	373-5399
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-3650	Support-Trunnion	394-2580
100-3651	Support-Trunnion	445-7699
100-5927	Joint Gp-Univ -A	390-5260
100-6267	Plate As-Idler	375-9983
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
103-0887	Pulley-Idler	449-9546
103-1713	Yoke-Bk-Flange	382-6892
105-1738	Manifold-Exhaust	374-4692
105-7535	Bearing-Dbl Row	417-9496
107-7708	Bearing-Main	419-6381
110-6167	Pin As	375-9972
113-6200	Gasket	438-2020
114-1071	Piston	388-6583

Sales Model IT38G (Cont'd.)

1CW		
Original Part Number	Part Name	Classic Part Number
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
125-2873	Core As-Ac Cond	436-2254
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
137-6995	Muffler As	360-7868
138-1840	Retainer-Seal	374-6511
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376

1CW		
Original Part Number	Part Name	Classic Part Number
152-3952	Impeller-Pump	374-4696
159-1845	Yoke As (1480)	380-1494
166-6757	Yoke	446-3078
176-3900	Accumulator	416-5513
179-1970	Yoke As.	376-9053
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
239-4290	Kit-Gasket-Sch	435-2574

1CW		
Original Part Number	Part Name	Classic Part Number
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578
282-6648	Kit-Dt Gasket	396-9955
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
334-1033	Disc-Friction	394-8242
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

7BS		
Original Part Number	Part Name	Classic Part Number
1B-4038	Cup-Roller Brg	423-6988
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1S-7057	Gasket	420-6384
1T-0334	Bearing-Ball	380-1476
1T-1401	Ring-Seal	384-4799
1T-1805	Turbine-Conv	380-1490
1T-2041	Carrier As	396-9893
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
3T-2094	Bearing-Sleeve	388-0638
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383

7BS		
Original Part Number	Part Name	Classic Part Number
4E-2168	Piston	375-2623
4E-2250	Housing	399-6043
4E-3997	Housing-Pinion	374-6498
4K-7463	Seal-Lip Type	472-8007
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2883	Bearing-Sleeve	379-0193
4V-5099	Cover	418-1929
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4V-9901	Pin As	374-6508
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217

7BS		
Original Part Number	Part Name	Classic Part Number
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5V-1274	Spider	385-6110
5V-7574	Ring-Retaining	392-4483
6I-1099	Manifold-Exh	424-6366
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6K-8088	Bearing-Roller	399-4428
6V-4582	Bearing-Ball	380-1504
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
7C-1371	Coupling-Exhaust	369-9490
7C-3729	Pulley	376-9066
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317

Sales Model IT38G (Cont'd.)

7BS		
Original Part Number	**Part Name**	**Classic Part Number**
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7H-4566	Cup-Roller Brg	399-6068
7J-6250	Bearing-Sleeve	385-3803
7J-8210	Cone-Roller Brg	423-6987
7J-9344	Bearing-Sleeve	360-2334
7J-9884	Bearing-Sleeve	325-6016
7K-9528	Bearing-Sleeve	308-9828
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8R-1891	Gear-Ring	450-7547
8S-0248	Breather As	325-6033
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9D-7924	Mount As	360-2356
9J-5875	Bearing-Sleeve	308-9830
9M-1328	Bearing-Aligning	325-6018
9R-4067	Joint Gp-Univ	373-5399

7BS		
Original Part Number	**Part Name**	**Classic Part Number**
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9W-9940	Mount As.	360-2355
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-3650	Support-Trunnion	394-2580
100-3651	Support-Trunnion	445-7699
100-5927	Joint Gp-Univ -A	390-5260
100-6267	Plate As-Idler	375-9983
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
103-1713	Yoke-Bk-Flange	382-6892
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
110-6167	Pin As	375-9972
113-6200	Gasket	438-2020
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
125-2873	Core As-Ac Cond	436-2254
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445

7BS		
Original Part Number	**Part Name**	**Classic Part Number**
136-0819	Valve-Exhaust	384-8697
137-6995	Muffler As	360-7868
138-1840	Retainer-Seal	374-6511
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
159-1845	Yoke As (1480)	380-1494
166-6757	Yoke	446-3078
176-3900	Accumulator	416-5513
179-1970	Yoke As.	376-9053
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
239-4290	Kit-Gasket-Sch	435-2574
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578
282-6648	Kit-Dt Gasket	396-9955
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
334-1033	Disc-Friction	394-8242
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

CSX		
Original Part Number	**Part Name**	**Classic Part Number**
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
2A-4429	Lock-Retainer	379-0174
2K-9295	Bearing-Cone	422-6480

CSX		
Original Part Number	**Part Name**	**Classic Part Number**
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328

CSX		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481

Sales Model IT38G (Cont'd.)

CSX		
Original Part Number	Part Name	Classic Part Number
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383
4E-2168	Piston	375-2623
4E-3997	Housing-Pinion	374-6498
4T-8054	Seal As	472-8010
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2883	Bearing-Sleeve	379-0193
4V-5099	Cover	418-1929
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4V-9901	Pin As	374-6508
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5V-1274	Spider	385-6110
5V-7574	Ring-Retaining	392-4483
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7C-1371	Coupling-Exhaust	369-9490

CSX		
Original Part Number	Part Name	Classic Part Number
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7H-4566	Cup-Roller Brg	399-6068
7J-6250	Bearing-Sleeve	385-3803
7J-8210	Cone-Roller Brg	423-6987
7J-9344	Bearing-Sleeve	360-2334
7J-9884	Bearing-Sleeve	325-6016
7K-9528	Bearing-Sleeve	308-9828
7K-9639	Bearing-Sleeve	314-8643
7W-5095	Gear-Flywheel	425-9190
8R-1891	Gear-Ring	450-7547
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9D-7924	Mount As	360-2356
9J-5875	Bearing-Sleeve	308-9830
9M-1328	Bearing-Aligning	325-6018
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9W-9940	Mount As.	360-2355
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3414	Pump Gp-Vn Bsc-A	422-8149

CSX		
Original Part Number	Part Name	Classic Part Number
100-3650	Support-Trunnion	394-2580
100-3651	Support-Trunnion	445-7699
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
110-6167	Pin As	375-9972
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
124-3237	Precleaner As	432-4220
125-2873	Core As-Ac Cond	436-2254
133-4995	Gasket-Cyl Head	434-2445
138-1840	Retainer-Seal	374-6511
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
164-4413	Mount	419-0876
166-6757	Yoke	446-3078
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526
334-1033	Disc-Friction	394-8242

Sales Model IT38G (Cont'd.)

JAN		
Original Part Number	**Part Name**	**Classic Part Number**
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
2A-4429	Lock-Retainer	379-0174
2K-9295	Bearing-Cone	422-6480
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3B-4124	Cup-Spl Tapered	422-6481
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383
4E-2168	Piston	375-2623
4E-3997	Housing-Pinion	374-6498
4T-8054	Seal As	472-8010
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2883	Bearing-Sleeve	379-0193
4V-5099	Cover	418-1929
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4V-9901	Pin As	374-6508
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5P-7807	Bearing-Ball	314-8502
5V-1274	Spider	385-6110
5V-7574	Ring-Retaining	392-4483
6E-4892	Cyl Gp-089 478 Y	394-9828
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495

JAN		
Original Part Number	**Part Name**	**Classic Part Number**
6K-4191	Cap-Upper	300-2576
6K-5528	Cup-Roller Brg	447-8059
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7H-4566	Cup-Roller Brg	399-6068
7J-8210	Cone-Roller Brg	423-6987
7W-5095	Gear-Flywheel	425-9190
8R-1891	Gear-Ring	450-7547
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9D-7924	Mount As	360-2356
9M-1328	Bearing-Aligning	325-6018
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9W-9940	Mount As.	360-2355
005-4834	Cone-Rlr Bearing	422-6490
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605

JAN		
Original Part Number	**Part Name**	**Classic Part Number**
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-3650	Support-Trunnion	394-2580
100-3651	Support-Trunnion	445-7699
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
110-6167	Pin As	375-9972
114-1071	Piston	388-6583
115-4072	Bearing	397-5069
124-3237	Precleaner As	432-4220
125-2873	Core As-Ac Cond	436-2254
132-6597	Cone-Spl	422-6477
133-4995	Gasket-Cyl Head	434-2445
138-1840	Retainer-Seal	374-6511
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
164-4413	Mount	419-0876
166-6757	Yoke	446-3078
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
212-4893	Bearing-Thrust	419-6372
213-1364	Bearing-Sleeve	330-9255
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
265-5287	Ring-Seal	472-8028
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
275-0120	Pin As	419-7245
310-8658	Pin As	425-1526
334-1033	Disc-Friction	394-8242

Sales Model IT38H

JNJ		
Original Part Number	Part Name	Classic Part Number
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
2D-5658	Bearing-Ball	301-4628
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4J-0121	Cap-Bearing	360-2344
4T-8054	Seal As	472-8010
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192

JNJ		
Original Part Number	Part Name	Classic Part Number
4V-2883	Bearing-Sleeve	379-0193
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4V-9901	Pin As	374-6508
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
6E-4892	Cyl Gp-089 478 Y	394-9828
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6Y-3151	Stator-Converter	388-6562
7H-4566	Cup-Roller Brg	399-6068
7J-5131	Trunnion	296-1371
7J-8210	Cone-Roller Brg	423-6987
7J-9344	Bearing-Sleeve	360-2334

JNJ		
Original Part Number	Part Name	Classic Part Number
8C-3111	Rod End-Spher	392-4523
8J-5778	Bearing-Sleeve	374-8359
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9D-7924	Mount As	360-2356
9V-3289	Pin As	382-6904
9W-9940	Mount As.	360-2355
005-4834	Cone-Rlr Bearing	422-6490
114-1071	Piston	388-6583
176-3900	Accumulator	416-5513
184-9843	Head	347-0461
265-5287	Ring-Seal	472-8028
275-0120	Pin As	419-7245
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526

MCJ		
Original Part Number	Part Name	Classic Part Number
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
2D-5658	Bearing-Ball	301-4628
2K-4502	Bearing-Sleeve	299-1986
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328
3G-2797	Bearing-Sleeve	360-2329
3G-4704	Bearing-Sleeve	379-0185
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4V-2588	Pin As	435-6050
4V-2872	Bearing-Sleeve	380-7558

MCJ		
Original Part Number	Part Name	Classic Part Number
4V-2873	Bearing-Sleeve	379-0192
4V-2883	Bearing-Sleeve	379-0193
4V-7105	Pin As	361-1699
4V-8674	Bearing-Sleeve	307-1529
4V-9901	Pin As	374-6508
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6K-4191	Cap-Upper	300-2576
6Y-3151	Stator-Converter	388-6562
7H-4566	Cup-Roller Brg	399-6068
7J-8210	Cone-Roller Brg	423-6987

MCJ		
Original Part Number	Part Name	Classic Part Number
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
8C-3111	Rod End-Spher	392-4523
8J-5778	Bearing-Sleeve	374-8359
8V-6435	Spider & Brg Kit	377-7451
8V-7659	Pin As	361-1702
9D-7924	Mount As	360-2356
9J-5875	Bearing-Sleeve	308-9830
9M-1328	Bearing-Aligning	325-6018
9V-3289	Pin As	382-6904
9W-9940	Mount As.	360-2355
005-4834	Cone-Rlr Bearing	422-6490
114-1071	Piston	388-6583
176-3900	Accumulator	416-5513

Wheel Loaders

Sales Model IT38H (Cont'd.)

MCJ		
Original Part Number	Part Name	Classic Part Number
184-9843	Head	347-0461
265-5287	Ring-Seal	472-8028
275-0120	Pin As	419-7245

MCJ		
Original Part Number	Part Name	Classic Part Number
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030

MCJ		
Original Part Number	Part Name	Classic Part Number
308-1845	Seal-Wiper	472-8032
310-8658	Pin As	425-1526

Sales Model IT62G

6PS		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-4502	Bearing-Sleeve	299-1986
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4J-0121	Cap-Bearing	360-2344
4K-7270	Support-Trunnion	373-5384
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217

6PS		
Original Part Number	Part Name	Classic Part Number
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-2883	Bearing-Sleeve	379-0193
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9538	Bearing-Roller	421-8183
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1511	Pin As	418-1945
6I-1099	Manifold-Exh	424-6366
6J-6043	Bearing-Sleeve	374-1456
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639

6PS		
Original Part Number	Part Name	Classic Part Number
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-3509	Pipe As-Ex Ext	373-1907
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-5131	Trunnion	296-1371
7J-9344	Bearing-Sleeve	360-2334
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523

Sales Model IT62G (Cont'd.)

6PS		
Original Part Number	Part Name	Classic Part Number
8J-5778	Bearing-Sleeve	374-8359
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-4568	Piston	385-6108
8R-9306	Pinion-Diff Bev	388-0569
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-5875	Bearing-Sleeve	308-9830
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756

6PS		
Original Part Number	Part Name	Classic Part Number
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-6675	Step As	419-0881
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
128-1009	Muffler As	435-6047
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445

6PS		
Original Part Number	Part Name	Classic Part Number
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

AKP		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912

AKP		
Original Part Number	Part Name	Classic Part Number
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4P-3683	Pump Gp-Water -B	374-7498
4P-7051	Pulley-Alt	376-9064
4P-7790	Shaft As-Arm	457-4596

AKP		
Original Part Number	Part Name	Classic Part Number
4P-8577	Rod As-Injector	455-5513
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-2883	Bearing-Sleeve	379-0193
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5K-0983	Seal-Lip Type	472-8012

Sales Model IT62G (Cont'd.)

AKP		
Original Part Number	**Part Name**	**Classic Part Number**
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5P-9538	Bearing-Roller	421-8183
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1511	Pin As	418-1945
6I-1099	Manifold-Exh	424-6366
6J-6043	Bearing-Sleeve	374-1456
6P-0593	Bearing-Roller	386-4959
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-9960	Mount As.	376-3639
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-3938	Pulley-Alt	433-2030
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-8365	Drive Gp-Fan Bsc	433-2025
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581

AKP		
Original Part Number	**Part Name**	**Classic Part Number**
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7K-9639	Bearing-Sleeve	314-8643
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-5095	Gear-Flywheel	425-9190
8C-3111	Rod End-Spher	392-4523
8J-5778	Bearing-Sleeve	374-8359
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8S-0248	Breather As	325-6033
8V-1612	Shaft	425-6456
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9V-0247	Plate	417-4527
9V-3289	Pin As	382-6904
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-5295	Tube-Gov Conn	419-4756
9Y-8534	Support-Shft	463-7671
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
105-1738	Manifold-Exhaust	374-4692

AKP		
Original Part Number	**Part Name**	**Classic Part Number**
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
113-6200	Gasket	438-2020
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
117-6675	Step As	419-0881
119-2940	Gasket	378-4002
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
128-1009	Muffler As	435-6047
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
133-4995	Gasket-Cyl Head	434-2445
136-0819	Valve-Exhaust	384-8697
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
275-0120	Pin As	419-7245
277-7089	Shaft As	380-7578
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2160	Pump Gp-Water -B	433-0789

Sales Model IT62G (Cont'd.)

AYA		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3L-1425	Bearing-Ball	311-9356
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-2883	Bearing-Sleeve	379-0193
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1511	Pin As	418-1945
6J-6043	Bearing-Sleeve	374-1456
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691

AYA		
Original Part Number	Part Name	Classic Part Number
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-1371	Coupling-Exhaust	369-9490
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9T-5096	Flexplate	455-3271
9V-0247	Plate	417-4527

AYA		
Original Part Number	Part Name	Classic Part Number
9V-3289	Pin As	382-6904
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
117-6675	Step As	419-0881
124-3237	Precleaner As	432-4220
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-2873	Core As-Ac Cond	436-2254
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
152-3952	Impeller-Pump	374-4696
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
164-4413	Mount	419-0876
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
236-4413	Pump Gp-Water -B	434-6110
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
275-0120	Pin As	419-7245

Sales Model IT62H

M5G		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2A-4429	Lock-Retainer	379-0174
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328
2W-7213	Bearing-Sleeve	419-4667
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-2883	Bearing-Sleeve	379-0193
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
5D-7449	Cup-Spl Tapered	416-2161
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5P-7807	Bearing-Ball	314-8502
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1511	Pin As	418-1945
6J-6043	Bearing-Sleeve	374-1456

M5G		
Original Part Number	**Part Name**	**Classic Part Number**
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6V-3831	Seal-O-Ring	436-2657
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7C-5403	Tube As	374-4673
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7E-6794	Arm As-Injector	433-0449
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7W-5095	Gear-Flywheel	425-9190
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
8V-7659	Pin As	361-1702
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232

M5G		
Original Part Number	**Part Name**	**Classic Part Number**
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9V-3289	Pin As	382-6904
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
101-1530	Bearing-Main	419-6382
107-7708	Bearing-Main	419-6381
115-4072	Bearing	397-5069
133-4995	Gasket-Cyl Head	434-2445
145-0162	Bearing-Main	419-6380
145-0164	Bearing-Main	419-6376
154-8030	Gasket	394-0894
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
212-4893	Bearing-Thrust	419-6372
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
224-6638	Bearing-Rod	419-6371
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
275-0120	Pin As	419-7245

Sales Model IT62K

S8X		
Original Part Number	Part Name	Classic Part Number
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2P-1373	Cup-Rlr Brg	382-5075
2P-8986	Cup-Rlr Bearing	415-1912
2V-0707	Bearing-Sleeve	360-2328
3R-8530	Boss	425-3454
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-3196	Pin As	361-1697
4E-8534	Retainer-Seal	300-2588
4V-2883	Bearing-Sleeve	379-0193
4V-5099	Cover	418-1929
4V-8674	Bearing-Sleeve	307-1529
5K-0983	Seal-Lip Type	472-8012
5P-3930	Bearing As-Rlr	419-6022
5T-5682	Driver	418-9579
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703

S8X		
Original Part Number	Part Name	Classic Part Number
5V-1511	Pin As	418-1945
5V-1882	Pin As	361-1700
6J-6043	Bearing-Sleeve	374-1456
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6Y-1084	Impeller-Conv	380-1477
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
7B-7515	Bearing-Ball	399-6059
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7G-0437	Plate-Clutch	417-9466
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7V-0638	Spacer	425-3651

S8X		
Original Part Number	Part Name	Classic Part Number
8R-1088	Bearing-Sleeve	419-0885
8R-4568	Piston	385-6108
9C-8418	Plate-Reaction	385-6129
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9J-7099	Bearing-Sleeve	391-9818
9M-1328	Bearing-Aligning	325-6018
9N-4460	Housing As-Cl	297-7203
9V-3289	Pin As	382-6904
9W-0517	Carrier-Planet	281-1686
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-8010	Valve	423-5583
155-6648	Cone Spl Rol Brg	418-9599
176-9273	Piston	297-4860
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
275-0120	Pin As	419-7245
310-1899	Pin As	393-0932

Sales Model M6

MDM		
Original Part Number	Part Name	Classic Part Number
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114

MDM		
Original Part Number	Part Name	Classic Part Number
2H-6489	Race-Brg Outer	374-8350
2K-9295	Bearing-Cone	422-6480
3B-4124	Cup-Spl Tapered	422-6481

MDM		
Original Part Number	Part Name	Classic Part Number
5M-6126	Bearing	377-7433
136-7813	Bearing-Race	460-8296
171-3942	Yoke	398-2931

6QW		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-7057	Gasket	420-6384
1V-8242	Bearing-Sleeve	308-9809
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
1V-8953	Pin	308-9892
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229

6QW		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
3G-9891	Pump Gp-Gr A	399-8541
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-2250	Housing	399-6043
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4K-7270	Support-Trunnion	373-5384
4N-0432	Bearing-Ball	417-4499
4N-2514	Gear-Flywheel	421-7283
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-3754	Core As-Oclr	438-2016
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8279	Manifold-Exhaust	430-8041

6QW		
Original Part Number	**Part Name**	**Classic Part Number**
4P-8280	Manifold-Exhaust	430-7236
4T-9311	Housing	396-0652
4V-3044	Plate-Lock	308-9911
4V-5099	Cover	418-1929
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4V-8673	Bearing-Sleeve	307-1528
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
4W-9822	Core Gp-O Clr	374-4711
4W-9989	Gear As-Idler	302-2677
5K-0609	Cover	308-9843
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-8591	Bearing-Outer	380-7502
5M-0578	Bearing	419-7775
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5V-1274	Spider	385-6110
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358

Sales Model R1300 (Cont'd.)

6QW		
Original Part Number	**Part Name**	**Classic Part Number**
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-7751	Rod End-Spher	472-8015
6M-1592	Bearing-Sleeve	374-1462
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-1705	Shaft-Pump Drive	283-5201
6V-3831	Seal-O-Ring	436-2657
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-5816	Shaft-Fan	399-8552
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9346	Bearing-Sleeve	374-8357
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816

6QW		
Original Part Number	**Part Name**	**Classic Part Number**
7N-0110	Core As-Oil Clr	319-3435
7N-1164	Mount As	295-5451
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-5082	Pin As	374-8367
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7V-8640	Spindle	424-4945
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5164	Gasket	420-8568
7W-5692	Pulley-Cshaft	386-3041
7W-5844	Bearing-Conn Rod	419-4650
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-4954	Housing As-Cl	391-9823
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349

6QW		
Original Part Number	**Part Name**	**Classic Part Number**
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8R-3946	Collet	308-9841
8R-4568	Piston	385-6108
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-8117	Housing As-Cl	302-2686
9J-7099	Bearing-Sleeve	391-9818
9K-5639	Pin	425-6451
9L-5908	Gasket	433-8196
9N-3668	Base As.-Coolant	419-4718
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9Y-1798	Seal-Water	379-0165
9Y-7215	Sleeve-Isolator	425-3646
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605

Sales Model R1300 (Cont'd.)

6QW		
Original Part Number	**Part Name**	**Classic Part Number**
100-7860	Valve-Inlet	270-4360
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
111-8015	Gasket As-Head	279-4977
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
119-5727	Bearing-Spl Ball	417-9491
124-2726	Head	377-5855
126-5984	Ring-Backup	419-4654
131-3815	Seal Gp-Basic	325-6193
134-3038	Gasket Kit	437-3228
147-1740	Gear-Planet	377-7466
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154

6QW		
Original Part Number	**Part Name**	**Classic Part Number**
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-0570	Rebuild Kit-Pump	380-7577
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835

6QW		
Original Part Number	**Part Name**	**Classic Part Number**
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
176-9273	Piston	297-4860
187-0605	Gasket Kit - Cl	382-5055
187-3307	Gasket As-Cyl	438-2022
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
197-9251	Pin As.-Piston	454-6110
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
216-4781	Gasket Kit	437-8144
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
321-5714	Piston-Clutch	281-1693
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439
352-2077	Pump Gp-Water -B	434-6108

Sales Model R1300G

LJB		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1V-8242	Bearing-Sleeve	308-9809

LJB		
Original Part Number	**Part Name**	**Classic Part Number**
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
1V-8953	Pin	308-9892
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981

LJB		
Original Part Number	**Part Name**	**Classic Part Number**
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

Sales Model R1300G (Cont'd.)

LJB		
Original Part Number	Part Name	Classic Part Number
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-9891	Pump Gp-Gr A	399-8541
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-2250	Housing	399-6043
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008

LJB		
Original Part Number	Part Name	Classic Part Number
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4T-9311	Housing	396-0652
4V-3044	Plate-Lock	308-9911
4V-5099	Cover	418-1929
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4V-8673	Bearing-Sleeve	307-1528
4W-0452	Seal As -Cshaft	325-6191
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
4W-9989	Gear As-Idler	302-2677
5K-0609	Cover	308-9843
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-8591	Bearing-Outer	380-7502
5M-0578	Bearing	419-7775
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5V-1274	Spider	385-6110
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674

LJB		
Original Part Number	Part Name	Classic Part Number
6L-7751	Rod End-Spher	472-8015
6M-1592	Bearing-Sleeve	374-1462
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-1705	Shaft-Pump Drive	283-5201
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9346	Bearing-Sleeve	374-8357
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994

Sales Model R1300G (Cont'd.)

LJB		
Original Part Number	**Part Name**	**Classic Part Number**
7N-9805	Pin-Piston	295-6438
7P-5082	Pin As	374-8367
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7V-8640	Spindle	424-4945
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-4954	Housing As-Cl	391-9823
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322

LJB		
Original Part Number	**Part Name**	**Classic Part Number**
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8R-3946	Collet	308-9841
8R-4568	Piston	385-6108
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-8117	Housing As-Cl	302-2686
9J-7099	Bearing-Sleeve	391-9818
9K-5639	Pin	425-6451
9L-5908	Gasket	433-8196
9N-3668	Base As.-Coolant	419-4718
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
119-5727	Bearing-Spl Ball	417-9491
124-2726	Head	377-5855

LJB		
Original Part Number	**Part Name**	**Classic Part Number**
131-3815	Seal Gp-Basic	325-6193
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
176-9273	Piston	297-4860
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
321-5714	Piston-Clutch	281-1693
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

Sales Model R1300G (Cont'd.)

NJB		
Original Part Number	Part Name	Classic Part Number
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1V-8242	Bearing-Sleeve	308-9809
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
1V-8953	Pin	308-9892
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624

NJB		
Original Part Number	Part Name	Classic Part Number
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-9891	Pump Gp-Gr A	399-8541
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4E-2250	Housing	399-6043
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4V-8673	Bearing-Sleeve	307-1528
4W-0452	Seal As -Cshaft	325-6191

NJB		
Original Part Number	Part Name	Classic Part Number
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
4W-9989	Gear As-Idler	302-2677
5K-0609	Cover	308-9843
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-8591	Bearing-Outer	380-7502
5M-0578	Bearing	419-7775
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5V-1274	Spider	385-6110
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-7751	Rod End-Spher	472-8015
6M-1592	Bearing-Sleeve	374-1462
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-1705	Shaft-Pump Drive	283-5201
6V-4350	Race-Spl Rlr Brg	384-5933

Sales Model R1300G (Cont'd.)

NJB		
Original Part Number	**Part Name**	**Classic Part Number**
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9346	Bearing-Sleeve	374-8357
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-5082	Pin As	374-8367
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7V-8640	Spindle	424-4945
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-4954	Housing As-Cl	391-9823
8F-3170	Bearing-Roller	417-4504

NJB		
Original Part Number	**Part Name**	**Classic Part Number**
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8R-3946	Collet	308-9841
8R-4568	Piston	385-6108
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
9C-9191	Trunnion	302-2701

NJB		
Original Part Number	**Part Name**	**Classic Part Number**
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-8117	Housing As-Cl	302-2686
9J-7099	Bearing-Sleeve	391-9818
9K-5639	Pin	425-6451
9L-5908	Gasket	433-8196
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
119-5727	Bearing-Spl Ball	417-9491
124-2726	Head	377-5855
131-3815	Seal Gp-Basic	325-6193
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-4262	Body As-Piston	270-4351
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201

Sales Model R1300G (Cont'd.)

NJB		
Original Part Number	Part Name	Classic Part Number
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
176-9273	Piston	297-4860
190-3832	Core As-Oclr	438-3251

NJB		
Original Part Number	Part Name	Classic Part Number
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	270-4357

NJB		
Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4351
321-5714	Piston-Clutch	281-1693
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

Sales Model R1300GII

RSL		
Original Part Number	Part Name	Classic Part Number
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1N-3576	Block Gp-Cyl	279-4978
1P-1367	Plunger-Valve	432-8913
1P-9945	Bracket As-Fan	296-1344
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1T-0043	Bearing-Ball	390-5294
1V-8242	Bearing-Sleeve	308-9809
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
1V-8953	Pin	308-9892
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-3900	Gasket	472-8006
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-5300	Rotocoil As	443-2659
1W-5912	Tappet As-Guide&	325-6223
1W-6987	Valve As-Check	420-6221
1W-9171	Bonnet-Valve	374-4707

RSL		
Original Part Number	Part Name	Classic Part Number
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2P-0220	Gasket-Pump	398-2927
2P-1170	Shaft As-Gear	296-1367
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2519	Tube As-Inlet	325-6230
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-3767	Tube-Disposal	377-5850
2P-6245	Shaft As-Pump	325-6197
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357

RSL		
Original Part Number	Part Name	Classic Part Number
2W-2621	Valve-Inlet	247-6892
2W-7255	Shaft-Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear-Water Pump	325-6088
3G-9891	Pump Gp-Gr A	399-8541
3L-1425	Bearing-Ball	311-9356
3T-2094	Bearing-Sleeve	388-0638
3T-9960	Disc-Friction	417-9487
4D-0487	Valve As-Check	375-4334
4E-2250	Housing	399-6043
4E-8534	Retainer-Seal	300-2588
4F-2041	Cup-Roller Brg	418-9609
4N-0432	Bearing-Ball	417-4499
4N-7693	Crankshaft As	269-8763
4P-3546	Valve As-Relief	325-6236
4P-7688	Valve As-Check	420-6216
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-7543	Retainer	281-1699
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4V-8673	Bearing-Sleeve	307-1528

Sales Model R1300GII (Cont'd.)

RSL		
Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As -Cshaft	325-6191
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-5363	Core Gp-O Clr	380-7531
4W-6869	Spacer-Fuel Pump	417-4534
4W-9989	Gear As-Idler	302-2677
5K-0609	Cover	308-9843
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-8591	Bearing-Outer	380-7502
5M-0578	Bearing	419-7775
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6795	Chamber As	242-3437
5S-7630	Bearing-Sleeve	394-0219
5S-8543	Bearing-Sleeve	376-3635
5V-1274	Spider	385-6110
6B-7469	Spacer	417-4535
6H-3957	Bearing-Ball	311-9358
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6L-7751	Rod End-Spher	472-8015
6M-1592	Bearing-Sleeve	374-1462
6N-1036	Gear-Oil Pump	279-4991
6N-7174	Shield-Oil	314-8544
6P-2233	Gear-Planet	281-1690
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133

RSL		
Original Part Number	Part Name	Classic Part Number
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6T-1705	Shaft-Pump Drive	283-5201
6V-4350	Race-Spl Rlr Brg	384-5933
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
7B-7515	Bearing-Ball	399-6059
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-9980	Camshaft	377-5851
7G-0437	Plate-Clutch	417-9466
7G-3707	Piston-Clutch	302-2691
7G-4281	Housing As-Spt	297-7201
7G-5444	Carrier-Planet	297-7165
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-6062	Gear-Ring	302-2678
7J-9346	Bearing-Sleeve	374-8357
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-0110	Core As-Oil Clr	319-3435
7N-5910	Impeller-Pump	314-8686
7N-7166	Race-Brg Thrust	417-4531
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-9145	Gear-Flywheel	279-4994
7N-9805	Pin-Piston	295-6438
7P-5082	Pin As	374-8367
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4534	Bearing-Caged	417-9497
7T-1285	Gear-Planet	297-7190
7T-3343	Plate-Clutch	297-7231
7V-8640	Spindle	424-4945

RSL		
Original Part Number	Part Name	Classic Part Number
7W-0508	Gear-Fp Drive	296-1351
7W-1927	Ring-Retainer	387-2935
7W-5692	Pulley-Cshaft	386-3041
7W-7546	Gasket-Plate	433-8187
7W-9020	Bell As-Pump Suc	378-3989
8E-4954	Housing As-Cl	391-9823
8F-3170	Bearing-Roller	417-4504
8H-2810	Case As-Filter	314-8512
8H-9789	Bearing-Ball	374-8342
8K-6282	Gear-Sun	281-1698
8N-0703	Bearing-Sleeve	472-8037
8N-0875	Valve-Exhaust	247-6893
8N-1187	Head Gp-Cyl -A	242-3435
8N-1721	Rod As-Conn	269-5291
8N-1849	Bearing-Conn Rod	379-0196
8N-2641	Sleeve	325-6210
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5929	Cover-Water Pump	296-1349
8N-6796	Head Gp-Cyl -A	269-5290
8N-7315	Tube As-Outlet	325-6232
8N-7782	Rotocoil As	383-1585
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8R-3946	Collet	308-9841
8R-4568	Piston	385-6108

Sales Model R1300GII (Cont'd.)

RSL		
Original Part Number	Part Name	Classic Part Number
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-6511	Bearing-Sleeve	380-7372
8T-0072	Cone-Rlr Brg	377-7448
9C-9191	Trunnion	302-2701
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620
9G-1491	Carrier-Planet	281-1685
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9G-8117	Housing As-Cl	302-2686
9J-7099	Bearing-Sleeve	391-9818
9K-5639	Pin	425-6451
9L-5908	Gasket	433-8196
9N-4460	Housing As-Cl	297-7203
9N-5769	Cover-Housing	325-6050
9S-7788	Ring-Piston	461-5124
9S-8679	Chamber As	325-6042
9W-0517	Carrier-Planet	281-1686
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688

RSL		
Original Part Number	Part Name	Classic Part Number
9W-9930	Mount As	295-6437
9Y-1798	Seal-Water	379-0165
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-7860	Valve-Inlet	270-4360
111-8015	Gasket As-Head	279-4977
119-5727	Bearing-Spl Ball	417-9491
124-2726	Head	377-5855
131-3815	Seal Gp-Basic	325-6193
147-1740	Gear-Planet	377-7466
148-7455	Valve - Exhaust	270-4361
155-6648	Cone Spl Rol Brg	418-9599
164-6560	Body As-Piston	477-7125
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	477-7126
167-8123	Damper As	299-2006
168-4531	Body As-Piston	477-7127
169-1750	Seal Gp-Basic	472-8022

RSL		
Original Part Number	Part Name	Classic Part Number
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
170-7502	Shaft-Dr Idler	374-7484
172-5185	Shaft-Water Pump	325-6201
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-7760	Pump Gp-Water -B	380-7574
172-7765	Pump Gp-Water -B	394-9835
176-9273	Piston	297-4860
190-3832	Core As-Oclr	438-3251
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
206-6405	Bearing-Spl Ball	420-2503
213-1370	Bearing-Sleeve	380-7370
232-3233	Bearing-Main	376-9085
270-4353	Kit-Liner-Cla	295-6438
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4351
321-5714	Piston-Clutch	281-1693
328-5572	Bearing-Rod	419-6349
334-8389	Crankshaft As	242-3439

Sales Model R1600

9EW		
Original Part Number	Part Name	Classic Part Number
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755

9EW		
Original Part Number	Part Name	Classic Part Number
1U-2667	Cartridge Gp	422-8116
1V-6934	Bearing-Sleeve	364-5265
1V-8241	Bearing-Sleeve	308-9808
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5065	Cone-Roller Brg	416-2157

9EW		
Original Part Number	Part Name	Classic Part Number
2K-5103	Cone-Roller Brg	380-7505
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5715	Bushing	299-1987
2V-7092	Plate-Retainer	374-6510
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
3G-2665	Cover	308-9842
3G-5492	Rod As	377-5836
3K-2511	Dowel-Reaction	383-2126

Sales Model R1600 (Cont'd.)

9EW		
Original Part Number	**Part Name**	**Classic Part Number**
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
3T-4384	Housing As-Cl	435-2573
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-2250	Housing	399-6043
4E-8535	Retainer-Seal	300-2589
4F-2041	Cup-Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-5392	Spider	377-7430
4V-7543	Retainer	281-1699
4V-8673	Bearing-Sleeve	307-1528
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511
5K-0609	Cover	308-9843
5K-3490	Spacer	308-9933
5K-3502	Cap-Lower	308-9835
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
6E-0775	Head	425-9373
6E-5028	Rod As	425-9372
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387

9EW		
Original Part Number	**Part Name**	**Classic Part Number**
6N-2687	Spider As.-Fan	385-7199
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-3831	Seal-O-Ring	436-2657
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-5816	Shaft-Fan	399-8552
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9682	Bearing-Sleeve	360-2335
7N-1164	Mount As	295-5451
7P-5082	Pin As	374-8367
7T-3365	Carrier-Planet	388-6563
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8D-0983	Mounting	384-3470
8E-7569	Case-Xmsn	394-0899
8F-3170	Bearing-Roller	417-4504
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212

9EW		
Original Part Number	**Part Name**	**Classic Part Number**
8R-0931	Housing-Pinion	302-4300
8R-1088	Bearing-Sleeve	419-0885
8R-4268	Collet	384-3461
9C-5852	Hub As	297-7208
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-5639	Pin	425-6451
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9V-2410	Housing-Bearing	302-2679
9V-7710	Univ Joint As	394-8234
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3597	Plate-Reaction	380-1501
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024

Sales Model R1600 (Cont'd.)

9EW		
Original Part Number	Part Name	Classic Part Number
118-2800	Housing As.-Rglt	419-4719
124-2726	Head	377-5855
126-5984	Ring-Backup	419-4654
136-7813	Bearing-Race	460-8296
147-1206	Gear Planet	418-9597
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-9288	Case As-Diff	380-1496
151-4836	Diff Gp -A	416-2120
160-1400	Yoke (1710)	319-3479

9EW		
Original Part Number	Part Name	Classic Part Number
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
213-1370	Bearing-Sleeve	380-7370
216-4781	Gasket Kit	437-8144

9EW		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
334-1032	Disc-Friction	440-3116
352-2077	Pump Gp-Water -B	434-6108

9XP		
Original Part Number	Part Name	Classic Part Number
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1V-6934	Bearing-Sleeve	364-5265
1V-8241	Bearing-Sleeve	308-9808
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5065	Cone-Roller Brg	416-2157
2K-5103	Cone-Roller Brg	380-7505
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454

9XP		
Original Part Number	Part Name	Classic Part Number
2V-5715	Bushing	299-1987
2W-8494	Pulley-Alt	295-5692
2W-9978	Core As-Oclr	279-4983
3G-2665	Cover	308-9842
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
3T-4384	Housing As-Cl	435-2573
4E-2250	Housing	399-6043
4E-8535	Retainer-Seal	300-2589
4F-2041	Cup-Roller Brg	418-9609
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-5392	Spider	377-7430
4V-7543	Retainer	281-1699
4V-8673	Bearing-Sleeve	307-1528
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511
5K-0609	Cover	308-9843
5K-3490	Spacer	308-9933

9XP		
Original Part Number	Part Name	Classic Part Number
5K-3502	Cap-Lower	308-9835
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
6E-0775	Head	425-9373
6E-5028	Rod As	425-9372
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-2687	Spider As.-Fan	385-7199
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-3831	Seal-O-Ring	436-2657
6Y-1690	Carrier-Ring	384-3849
6Y-4819	Carrier-Planet	296-1348
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-5816	Shaft-Fan	399-8552
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205

Wheel Loaders

Sales Model R1600 (Cont'd.)

9XP		
Original Part Number	**Part Name**	**Classic Part Number**
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9682	Bearing-Sleeve	360-2335
7N-1164	Mount As	295-5451
7P-5082	Pin As	374-8367
7T-3365	Carrier-Planet	388-6563
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8E-7569	Case-Xmsn	394-0899
8F-3170	Bearing-Roller	417-4504
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-0931	Housing-Pinion	302-4300
8R-4268	Collet	384-3461
9C-5852	Hub As	297-7208
9G-0280	Piston	283-5213

9XP		
Original Part Number	**Part Name**	**Classic Part Number**
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-5639	Pin	425-6451
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9V-2410	Housing-Bearing	302-2679
9V-7710	Univ Joint As	394-8234
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3597	Plate-Reaction	380-1501
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447

9XP		
Original Part Number	**Part Name**	**Classic Part Number**
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
126-5984	Ring-Backup	419-4654
136-7813	Bearing-Race	460-8296
147-1206	Gear Planet	418-9597
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-9288	Case As-Diff	380-1496
151-4836	Diff Gp -A	416-2120
160-1400	Yoke (1710)	319-3479
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
213-1370	Bearing-Sleeve	380-7370
216-4781	Gasket Kit	437-8144
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
334-1032	Disc-Friction	440-3116
352-2077	Pump Gp-Water -B	434-6108

Sales Model R1600G

9PP		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347

9PP		
Original Part Number	**Part Name**	**Classic Part Number**
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913

Sales Model R1600G (Cont'd.)

9PP		
Original Part Number	Part Name	Classic Part Number
1P-3958	Bearing-Needle	434-6114
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1S-9670	Univ Jt As	443-2017
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1V-6934	Bearing-Sleeve	364-5265
1V-8241	Bearing-Sleeve	308-9808
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5065	Cone-Roller Brg	416-2157
2K-5103	Cone-Roller Brg	380-7505
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5715	Bushing	299-1987
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
3T-4384	Housing As-Cl	435-2573
4E-2250	Housing	399-6043
4E-8535	Retainer-Seal	300-2589
4F-2041	Cup-Roller Brg	418-9609
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-5392	Spider	377-7430

9PP		
Original Part Number	Part Name	Classic Part Number
4V-7543	Retainer	281-1699
4V-8673	Bearing-Sleeve	307-1528
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511
5K-0609	Cover	308-9843
5K-3490	Spacer	308-9933
5K-3502	Cap-Lower	308-9835
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
6E-0775	Head	425-9373
6E-5028	Rod As	425-9372
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-2687	Spider As.-Fan	385-7199
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-3831	Seal-O-Ring	436-2657
6Y-1690	Carrier-Ring	384-3849
6Y-2065	Mount As-650 Cup	377-5844
6Y-4819	Carrier-Planet	296-1348
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-5816	Shaft-Fan	399-8552
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846

9PP		
Original Part Number	Part Name	Classic Part Number
7J-9682	Bearing-Sleeve	360-2335
7P-5082	Pin As	374-8367
7T-3365	Carrier-Planet	388-6563
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8E-7569	Case-Xmsn	394-0899
8F-3170	Bearing-Roller	417-4504
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-0931	Housing-Pinion	302-4300
8R-4268	Collet	384-3461
9C-5852	Hub As	297-7208
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-5639	Pin	425-6451
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9V-2410	Housing-Bearing	302-2679
9V-7710	Univ Joint As	394-8234

Sales Model R1600G (Cont'd.)

9PP		
Original Part Number	**Part Name**	**Classic Part Number**
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3597	Plate-Reaction	380-1501
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448

9PP		
Original Part Number	**Part Name**	**Classic Part Number**
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
126-5984	Ring-Backup	419-4654
136-7813	Bearing-Race	460-8296
147-1206	Gear Planet	418-9597
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-9288	Case As-Diff	380-1496
151-4836	Diff Gp -A	416-2120
160-1400	Yoke (1710)	319-3479
176-4168	Bridge As-Valve	419-4727

9PP		
Original Part Number	**Part Name**	**Classic Part Number**
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
213-1370	Bearing-Sleeve	380-7370
216-4781	Gasket Kit	437-8144
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
319-0848	Kit-Gasket(T)	438-0138
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
334-1032	Disc-Friction	440-3116
352-2077	Pump Gp-Water -B	434-6108

9YZ		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1S-3743	Bearing-Ball	384-4786
1S-7057	Gasket	420-6384
1S-9670	Univ Jt As	443-2017
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1V-6934	Bearing-Sleeve	364-5265
1V-8241	Bearing-Sleeve	308-9808
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834

9YZ		
Original Part Number	**Part Name**	**Classic Part Number**
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5065	Cone-Roller Brg	416-2157
2K-5103	Cone-Roller Brg	380-7505
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5715	Bushing	299-1987
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
3T-4384	Housing As-Cl	435-2573
4E-2250	Housing	399-6043
4E-8535	Retainer-Seal	300-2589
4F-2041	Cup-Roller Brg	418-9609
4N-2514	Gear-Flywheel	421-7283
4P-8279	Manifold-Exhaust	430-8041

9YZ		
Original Part Number	**Part Name**	**Classic Part Number**
4P-8280	Manifold-Exhaust	430-7236
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652
4V-5099	Cover	418-1929
4V-5392	Spider	377-7430
4V-7543	Retainer	281-1699
4V-8673	Bearing-Sleeve	307-1528
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511
5K-0609	Cover	308-9843
5K-3490	Spacer	308-9933
5K-3502	Cap-Lower	308-9835
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917

Sales Model R1600G (Cont'd.)

9YZ		
Original Part Number	Part Name	Classic Part Number
5P-5167	Race-Brg Outer	417-4529
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
6E-0775	Head	425-9373
6E-5028	Rod As	425-9372
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-2687	Spider As.-Fan	385-7199
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-3831	Seal-O-Ring	436-2657
6Y-1690	Carrier-Ring	384-3849
6Y-2065	Mount As-650 Cup	377-5844
6Y-4819	Carrier-Planet	296-1348
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-5816	Shaft-Fan	399-8552
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9682	Bearing-Sleeve	360-2335
7P-5082	Pin As	374-8367
7T-3365	Carrier-Planet	388-6563
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8E-7569	Case-Xmsn	394-0899
8F-3170	Bearing-Roller	417-4504
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-0953	Turbine-Conv	297-7269

9YZ		
Original Part Number	Part Name	Classic Part Number
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-0931	Housing-Pinion	302-4300
8R-4268	Collet	384-3461
9C-5852	Hub As	297-7208
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-5639	Pin	425-6451
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9V-2410	Housing-Bearing	302-2679
9V-7710	Univ Joint As	394-8234
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3597	Plate-Reaction	380-1501
100-8010	Valve	423-5583
101-3125	Gasket	420-8567
111-2645	Valve-Pump Byp	441-1561

9YZ		
Original Part Number	Part Name	Classic Part Number
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
126-5984	Ring-Backup	419-4654
136-7813	Bearing-Race	460-8296
147-1206	Gear Planet	418-9597
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
148-9288	Case As-Diff	380-1496
151-4836	Diff Gp -A	416-2120
160-1400	Yoke (1710)	319-3479
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
213-1370	Bearing-Sleeve	380-7370
216-4781	Gasket Kit	437-8144
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
319-0848	Kit-Gasket(T)	438-0138
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
334-1032	Disc-Friction	440-3116
352-2077	Pump Gp-Water -B	434-6108

9SD		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1S-3743	Bearing-Ball	384-4786
1S-9670	Univ Jt As	443-2017
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1U-2667	Cartridge Gp	422-8116
1V-6934	Bearing-Sleeve	364-5265
1V-8241	Bearing-Sleeve	308-9808
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2K-5065	Cone-Roller Brg	416-2157
2K-5103	Cone-Roller Brg	380-7505
2P-8986	Cup-Rlr Bearing	415-1912
2V-5656	Ring-Snap	374-1454
2V-5715	Bushing	299-1987
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3K-2511	Dowel-Reaction	383-2126
3L-1425	Bearing-Ball	311-9356
3P-3208	Flange-Joint	301-4647
3T-4384	Housing As-Cl	435-2573
4E-2250	Housing	399-6043
4E-8535	Retainer-Seal	300-2589
4F-2041	Cup-Roller Brg	418-9609
4N-2514	Gear-Flywheel	421-7283
4T-8054	Seal As	472-8010
4T-9311	Housing	396-0652

9SD		
Original Part Number	**Part Name**	**Classic Part Number**
4V-5099	Cover	418-1929
4V-5392	Spider	377-7430
4V-7543	Retainer	281-1699
4V-8673	Bearing-Sleeve	307-1528
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511
5K-0609	Cover	308-9843
5K-3490	Spacer	308-9933
5K-3502	Cap-Lower	308-9835
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-5045	Bearing-Spl Ball	415-1917
5P-5167	Race-Brg Outer	417-4529
5P-5411	Race-Brg Outer	417-9481
5P-8194	Ring-Retaining	308-9920
6E-0775	Head	425-9373
6E-5028	Rod As	425-9372
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6N-2687	Spider As.-Fan	385-7199
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6Y-1690	Carrier-Ring	384-3849
6Y-2065	Mount As-650 Cup	377-5844
6Y-4819	Carrier-Planet	296-1348
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-6461	Crown	325-6054
7J-8893	Cone-Roller Brg	374-1846
7J-9682	Bearing-Sleeve	360-2335

9SD		
Original Part Number	**Part Name**	**Classic Part Number**
7P-5082	Pin As	374-8367
7T-3365	Carrier-Planet	388-6563
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
8E-7569	Case-Xmsn	394-0899
8F-3170	Bearing-Roller	417-4504
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-0953	Turbine-Conv	297-7269
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-0931	Housing-Pinion	302-4300
8R-4268	Collet	384-3461
9C-5852	Hub As	297-7208
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-5639	Pin	425-6451
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9V-2410	Housing-Bearing	302-2679
9V-7710	Univ Joint As	394-8234
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550

Sales Model R1600H (Cont'd.)

9SD		
Original Part Number	Part Name	Classic Part Number
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
100-3597	Plate-Reaction	380-1501
100-8010	Valve	423-5583
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916

9SD		
Original Part Number	Part Name	Classic Part Number
136-7813	Bearing-Race	460-8296
147-1206	Gear Planet	418-9597
148-9288	Case As-Diff	380-1496
151-4836	Diff Gp -A	416-2120
160-1400	Yoke (1710)	319-3479
213-1370	Bearing-Sleeve	380-7370

9SD		
Original Part Number	Part Name	Classic Part Number
226-8202	Seal-Wiper	472-8024
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
334-1032	Disc-Friction	440-3116

Sales Model R1700

4LZ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1T-0043	Bearing-Ball	390-5294
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1333	Carrier As	445-9250
1T-1534	Carrier-Ring	386-4916
1T-1607	Spider As	434-9637
2A-4429	Lock-Retainer	379-0174
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
2W-8494	Pulley-Alt	295-5692
3K-2511	Dowel-Reaction	383-2126
3P-3208	Flange-Joint	301-4647
3T-2094	Bearing-Sleeve	388-0638
3T-4384	Housing As-Cl	435-2573
4K-7463	Seal-Lip Type	472-8007
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236

4LZ		
Original Part Number	Part Name	Classic Part Number
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
5D-2989	Bearing	380-7511
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-3831	Seal-O-Ring	436-2657
6Y-4819	Carrier-Planet	296-1348
6Y-5793	Ring-Seal	451-9028
7E-5816	Shaft-Fan	399-8552
7E-8926	Head Kt-Cyl	377-5847
7F-2742	Bearing-Ball	422-6488
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-8893	Cone-Roller Brg	374-1846

4LZ		
Original Part Number	Part Name	Classic Part Number
7K-5448	Cup-Bearing	415-1922
7T-3365	Carrier-Planet	388-6563
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8E-7569	Case-Xmsn	394-0899
8H-5352	Bearing-Ball	453-3658
8N-3666	Repair Kt-Major	377-5842
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-9507	Piston-Clutch	283-5212
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719

Wheel Loaders

Sales Model R1700 (Cont'd.)

4LZ		
Original Part Number	**Part Name**	**Classic Part Number**
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-5279	Bearing-Inner	453-3661
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9Y-7215	Sleeve-Isolator	425-3646
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567

4LZ		
Original Part Number	**Part Name**	**Classic Part Number**
104-1706	Valve-Regulating	432-8281
110-1337	Ring Kit-Pstn	377-5834
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
116-1102	Sleeve-Injector	451-9024
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154

4LZ		
Original Part Number	**Part Name**	**Classic Part Number**
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

Sales Model R1700G

8XZ		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1S-7057	Gasket	420-6384
1S-9670	Univ Jt As	443-2017
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1333	Carrier As	445-9250
1T-1534	Carrier-Ring	386-4916
1T-1607	Spider As	434-9637
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6511	Cup-Roller Brg	377-7417
2K-5065	Cone-Roller Brg	416-2157

8XZ		
Original Part Number	**Part Name**	**Classic Part Number**
2P-8986	Cup-Rlr Bearing	415-1912
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3G-6856	Pump Gp-Gr A	421-1556
3K-2511	Dowel-Reaction	383-2126
3P-3208	Flange-Joint	301-4647
3T-2094	Bearing-Sleeve	388-0638
3T-4384	Housing As-Cl	435-2573
4E-2250	Housing	399-6043
4K-7463	Seal-Lip Type	472-8007
4N-2514	Gear-Flywheel	421-7283
4P-3754	Core As-Oclr	438-2016
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4T-9311	Housing	396-0652
4V-8673	Bearing-Sleeve	307-1528
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5K-0609	Cover	308-9843

8XZ		
Original Part Number	**Part Name**	**Classic Part Number**
5K-3490	Spacer	308-9933
5K-3502	Cap-Lower	308-9835
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6N-2687	Spider As.-Fan	385-7199
6P-7357	Gear As-Pump	388-0561
6P-7358	Pump Gp-Gr 1 Bsc	308-9913
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6V-3831	Seal-O-Ring	436-2657
6W-4789	Shaft Gp-Drive-D	452-0444
6Y-2065	Mount As-650 Cup	377-5844

Sales Model R1700G (Cont'd.)

8XZ		
Original Part Number	Part Name	Classic Part Number
6Y-4819	Carrier-Planet	296-1348
6Y-5793	Ring-Seal	451-9028
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-3557	Spider As-Fan	430-4471
7E-5816	Shaft-Fan	399-8552
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7G-9555	Univ Joint As	314-8721
7J-8893	Cone-Roller Brg	374-1846
7J-9346	Bearing-Sleeve	374-8357
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-5334	Cone-Roller Brg	420-2505
7N-1164	Mount As	295-5451
7P-5082	Pin As	374-8367
7T-3365	Carrier-Planet	388-6563
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
7W-5164	Gasket	420-8568
7W-5844	Bearing-Conn Rod	419-4650
8E-7569	Case-Xmsn	394-0899
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-9507	Piston-Clutch	283-5212

8XZ		
Original Part Number	Part Name	Classic Part Number
8R-7425	Retainer	308-9917
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8V-1540	Univ Jt As	388-6574
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-5639	Pin	425-6451
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-5279	Bearing-Inner	453-3661
9T-5360	Plate-Pressure	424-4941
9V-7710	Univ Joint As	394-8234
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9W-9930	Mount As	295-6437
9Y-7215	Sleeve-Isolator	425-3646
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
104-1706	Valve-Regulating	432-8281
105-8704	Support-Trunnion	416-5510
105-8735	Gear-Diff Bevel	416-2154
107-5002	Cage-Bearing	396-7261
110-0551	Hub As	416-2146
111-2645	Valve-Pump Byp	441-1561
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916

8XZ		
Original Part Number	Part Name	Classic Part Number
114-0468	Pin-G.E.T.	443-1203
115-2989	Manifold-Exhaust	434-9635
115-4517	Core As-Oclr	421-7281
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
118-2800	Housing As.-Rglt	419-4719
129-3046	Carrier-Planet	393-1015
147-3781	Kit-Gasket(Wp)	422-2484
148-2125	Liner-Cylinder	458-0154
149-2914	Pinion-Dif Bevel	396-9950
159-8169	Gear-Planet	391-9870
161-9918	Retainer-Bearing	395-1321
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
187-3307	Gasket As-Cyl	438-2022
197-9251	Pin As.-Piston	454-6110
208-7534	Case As-Diff	388-6590
216-4781	Gasket Kit	437-8144
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
319-5239	Wheel	396-9956
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
352-2077	Pump Gp-Water -B	434-6108

SBR		
Original Part Number	Part Name	Classic Part Number
1H-4478	Pin	330-9272

Sales Model R1700G (Cont'd.)

SBR		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1S-9670	Univ Jt As	443-2017
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1333	Carrier As	445-9250
1T-1534	Carrier-Ring	386-4916
1T-1607	Spider As	434-9637
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6511	Cup-Roller Brg	377-7417
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3G-6856	Pump Gp-Gr A	421-1556
3K-2511	Dowel-Reaction	383-2126
3P-3208	Flange-Joint	301-4647
3T-2094	Bearing-Sleeve	388-0638
3T-4384	Housing As-Cl	435-2573
4E-2250	Housing	399-6043
4K-7463	Seal-Lip Type	472-8007
4N-2514	Gear-Flywheel	421-7283
4T-9311	Housing	396-0652
4V-8673	Bearing-Sleeve	307-1528
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511

SBR		
Original Part Number	**Part Name**	**Classic Part Number**
5F-2465	Cup-Roller Brg	447-8060
5K-0609	Cover	308-9843
5K-3490	Spacer	308-9933
5K-3502	Cap-Lower	308-9835
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6P-7357	Gear As-Pump	388-0561
6P-7358	Pump Gp-Gr 1 Bsc	308-9913
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935
6W-4789	Shaft Gp-Drive-D	452-0444
6Y-2065	Mount As-650 Cup	377-5844
6Y-4819	Carrier-Planet	296-1348
6Y-5793	Ring-Seal	451-9028
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7E-3557	Spider As-Fan	430-4471
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-8893	Cone-Roller Brg	374-1846
7J-9346	Bearing-Sleeve	374-8357
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-5334	Cone-Roller Brg	420-2505

SBR		
Original Part Number	**Part Name**	**Classic Part Number**
7P-5082	Pin As	374-8367
7T-3365	Carrier-Planet	388-6563
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
8E-7569	Case-Xmsn	394-0899
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-9507	Piston-Clutch	283-5212
8R-7425	Retainer	308-9917
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-2500	Kit-Gasket	393-1028
8V-1540	Univ Jt As	388-6574
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-0723	Pin	396-7283
9K-0724	Collar	392-4524
9K-0725	Cap	444-0575
9K-0726	Cap	393-3680
9K-5639	Pin	425-6451
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-5279	Bearing-Inner	453-3661
9T-5360	Plate-Pressure	424-4941
9V-7710	Univ Joint As	394-8234
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859

Sales Model R1700G (Cont'd.)

SBR		
Original Part Number	Part Name	Classic Part Number
9W-8437	Gear-Sun	450-7550
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-8704	Support-Trunnion	416-5510
105-8735	Gear-Diff Bevel	416-2154
107-5002	Cage-Bearing	396-7261

SBR		
Original Part Number	Part Name	Classic Part Number
110-0551	Hub As	416-2146
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
129-3046	Carrier-Planet	393-1015
149-2914	Pinion-Dif Bevel	396-9950
159-8169	Gear-Planet	391-9870
161-9918	Retainer-Bearing	395-1321

SBR		
Original Part Number	Part Name	Classic Part Number
176-4168	Bridge As-Valve	419-4727
208-7534	Case As-Diff	388-6590
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
319-5239	Wheel	396-9956
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

XBR		
Original Part Number	Part Name	Classic Part Number
1H-4478	Pin	330-9272
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1P-1367	Plunger-Valve	432-8913
1S-9670	Univ Jt As	443-2017
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0861	Impeller-Conv	421-1715
1T-1078	Bearing-Thrust	384-4802
1T-1333	Carrier As	445-9250
1T-1534	Carrier-Ring	386-4916
1T-1607	Spider As	434-9637
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-6511	Cup-Roller Brg	377-7417
2K-5065	Cone-Roller Brg	416-2157
2P-8986	Cup-Rlr Bearing	415-1912
2W-8494	Pulley-Alt	295-5692
3G-2665	Cover	308-9842
3G-6856	Pump Gp-Gr A	421-1556
3K-2511	Dowel-Reaction	383-2126
3P-3208	Flange-Joint	301-4647
3T-2094	Bearing-Sleeve	388-0638
3T-4384	Housing As-Cl	435-2573

XBR		
Original Part Number	Part Name	Classic Part Number
4E-2250	Housing	399-6043
4K-7463	Seal-Lip Type	472-8007
4N-2514	Gear-Flywheel	421-7283
4T-9311	Housing	396-0652
4V-8673	Bearing-Sleeve	307-1528
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-9822	Core Gp-O Clr	374-4711
5D-2989	Bearing	380-7511
5F-2465	Cup-Roller Brg	447-8060
5K-3490	Spacer	308-9933
5K-3502	Cap-Lower	308-9835
5M-6126	Bearing	377-7433
5P-2526	Cup-Rlr Bearing	380-7498
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5045	Bearing-Spl Ball	415-1917
5P-5411	Race-Brg Outer	417-9481
5P-7807	Bearing-Ball	314-8502
5P-8194	Ring-Retaining	308-9920
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6K-5528	Cup-Roller Brg	447-8059
6P-7357	Gear As-Pump	388-0561
6P-7358	Pump Gp-Gr 1 Bsc	308-9913
6P-7704	Carrier-Ring	314-8658
6V-0538	Bearing-Spl Ball	398-2935

XBR		
Original Part Number	Part Name	Classic Part Number
6W-4789	Shaft Gp-Drive-D	452-0444
6Y-2065	Mount As-650 Cup	377-5844
6Y-4819	Carrier-Planet	296-1348
6Y-5793	Ring-Seal	451-9028
7E-3557	Spider As-Fan	430-4471
7G-2830	Ring-Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier-Planet	283-5205
7G-7724	Piston-Clutch	283-5206
7J-8893	Cone-Roller Brg	374-1846
7J-9346	Bearing-Sleeve	374-8357
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-5334	Cone-Roller Brg	420-2505
7P-5082	Pin As	374-8367
7T-3365	Carrier-Planet	388-6563
7T-8816	Bearing-Spl Ball	420-2491
7T-9370	Gear-Sun	283-5207
8E-7569	Case-Xmsn	394-0899
8H-5352	Bearing-Ball	453-3658
8H-9789	Bearing-Ball	374-8342
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445

Sales Model R1700G (Cont'd.)

XBR		
Original Part Number	**Part Name**	**Classic Part Number**
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-8559	Yoke-6C	443-2016
8P-9507	Piston-Clutch	283-5212
8R-7425	Retainer	308-9917
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8T-2500	Kit-Gasket	393-1028
8V-1540	Univ Jt As	388-6574
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-6744	Bearing-Sleeve	418-1931
9K-0723	Pin	396-7283
9K-0724	Collar	392-4524
9K-0725	Cap	444-0575

XBR		
Original Part Number	**Part Name**	**Classic Part Number**
9K-0726	Cap	393-3680
9K-5639	Pin	425-6451
9P-7757	Gear-Sun	283-5218
9P-8516	Gear-Ring	373-5398
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-9031	Gear-Sun	283-5220
9S-5279	Bearing-Inner	453-3661
9T-5360	Plate-Pressure	424-4941
9V-7710	Univ Joint As	394-8234
9W-3605	Carrier-Ring	314-8662
9W-8270	Gear-Ring	308-9859
9W-8437	Gear-Sun	450-7550
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
105-8704	Support-Trunnion	416-5510

XBR		
Original Part Number	**Part Name**	**Classic Part Number**
105-8735	Gear-Diff Bevel	416-2154
107-5002	Cage-Bearing	396-7261
110-0551	Hub As	416-2146
112-5585	Shaft-Planet	308-9932
112-8042	Carrier-Planet	390-0916
129-3046	Carrier-Planet	393-1015
149-2914	Pinion-Dif Bevel	396-9950
159-8169	Gear-Planet	391-9870
161-9918	Retainer-Bearing	395-1321
208-7534	Case As-Diff	388-6590
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
319-5239	Wheel	396-9956
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922

Sales Model R2900

5TW		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4478	Pin	330-9272
1P-1367	Plunger-Valve	432-8913
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-1078	Bearing-Thrust	384-4802
1T-1333	Carrier As	445-9250
1T-1386	Yoke-Univ Joint	325-6239
1T-1534	Carrier-Ring	386-4916

5TW		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1607	Spider As	434-9637
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-9302	Gear-Crankshaft	386-3059
1W-9812	Gear-Crankshaft	380-1513
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2D-9457	Cone-Spl Tapered	377-7418
2H-6489	Race-Brg Outer	374-8350
2K-5065	Cone-Roller Brg	416-2157
2L-5271	Bearing-Ball	371-4305
2P-1757	Hub-Fan Pulley	296-1357
2S-6150	Cover-Pulley	428-8817
2V-6129	Cover	390-5295

5TW		
Original Part Number	**Part Name**	**Classic Part Number**
2W-7458	Crankshaft As	242-3439
3E-6772	Seal-Water	382-8017
3G-2665	Cover	308-9842
3G-6856	Pump Gp-Gr A	421-1556
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-7489	Plate-Clutch	377-7423
3T-2094	Bearing-Sleeve	388-0638
3T-2139	Housing As-Cl	394-2583
3T-6175	Gear-Transfer	398-8351

Sales Model R2900 (Cont'd.)

5TW		
Original Part Number	Part Name	Classic Part Number
3T-6176	Gear-Transfer	398-8350
4E-0752	Joint Gp-Univ	435-0197
4E-2250	Housing	399-6043
4E-3751	Yoke As	451-0750
4F-2041	Cup-Roller Brg	418-9609
4K-7463	Seal-Lip Type	472-8007
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0913	Screen As-Bell	374-7489
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-2954	Sleeve-Camshaft	299-2059
4N-4668	Breather-Engine	396-7271
4N-5857	Cap-Bearing	376-9086
4N-6257	Adapter	415-1904
4N-7693	Crankshaft As	269-8763
4P-2383	Adapter-Inlet	438-1812
4P-7827	Gear-Crankshaft	380-7533
4S-5367	Mount As	375-9986
4T-9311	Housing	396-0652
4V-4483	Plate-Lock	396-9933
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219
5K-3968	Cage-Bearing	308-9804
5K-4079	Cage-Bearing	308-9805
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-2526	Cup-Rlr Bearing	380-7498
5P-4992	Bearing-Ball	380-1507
5P-6254	Bearing	420-2495

5TW		
Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing-Ball	314-8502
5P-8768	Kit-Gasket (Scl)	393-1024
5P-9769	Cone-Rlr Bearing	422-6486
6H-2577	Spider Gp-Brg	333-4954
6I-1453	Crankshaft As	368-5916
6I-2726	Bearing-Sleeve	419-4757
6M-1592	Bearing-Sleeve	374-1462
6N-1931	Plunger	379-0171
6N-2687	Spider As.-Fan	385-7199
6N-5482	Plate-Friction	376-3637
6P-6739	Shaft-Planet	308-9929
6T-3726	Carrier As	390-5269
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-9885	Bearing-Rlr As	396-9906
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7J-8893	Cone-Roller Brg	374-1846
7J-9346	Bearing-Sleeve	374-8357
7K-5448	Cup-Bearing	415-1922
7M-4046	Bearing-Sleeve	394-8206
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7N-7998	Plate-Block	374-7496
7N-9805	Pin-Piston	295-6438
7W-3145	Plate	422-7894
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342

5TW		
Original Part Number	Part Name	Classic Part Number
8N-1849	Bearing-Conn Rod	379-0196
8N-2104	Bell As-Suction	380-1521
8N-4110	Bearing-Sleeve	394-8207
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-9622	Bracket As-Fan	433-2024
8P-4047	Shaft-Planet	373-5390
8S-6511	Bearing-Sleeve	380-7372
8V-1540	Univ Jt As	388-6574
9B-1320	Valve-Check	377-5832
9C-4202	Ring	424-0127
9G-1919	Gear-Planet	371-4307
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9K-0723	Pin	396-7283
9K-0724	Collar	392-4524
9K-0725	Cap	444-0575
9K-0726	Cap	393-3680
9K-0802	Spacer	419-0892
9K-0804	Pin	367-6092
9K-0805	Cap	415-1910
9K-0806	Cap	430-4469
9K-5639	Pin	425-6451
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9P-5531	Gear-Sun	417-9499
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-5279	Bearing-Inner	453-3661

Wheel Loaders

Sales Model R2900 (Cont'd.)

5TW		
Original Part Number	Part Name	Classic Part Number
9S-8597	Spring	399-8561
9V-3052	Plate	434-1401
9V-7710	Univ Joint As	394-8234
9W-2977	Hub As	423-6985
9W-5768	Gear-Ring	380-7474
9W-7040	Piston-Clutch	377-7462
9Y-2988	Breather As	361-1716
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-4563	Gear-Transfer	399-4430
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
106-7798	Bearing-Ball	417-9494
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
114-0468	Pin-G.E.T.	443-1203
124-0501	Cone-Spl Tapered	399-4441

5TW		
Original Part Number	Part Name	Classic Part Number
124-0502	Cup-Spl Tapered	416-2161
124-0503	Cone-Spl Tapered	418-9604
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-3815	Seal Gp-Basic	325-6193
131-7123	Bearing-Sleeve	422-6919
132-0985	Bearing-Sleeve	399-6056
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
149-5985	Stator-Converter	419-1865
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
159-3021	Gasket	377-5845
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
164-4891	Plate As.	391-1093
166-9142	Gasket	420-8546

5TW		
Original Part Number	Part Name	Classic Part Number
167-8126	Damper As	382-8019
169-5804	Yoke As	444-0574
170-4860	Bonnet-Oil Clr	430-5359
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
196-6845	Yoke As	451-9034
202-3572	Shaft As-Drive	426-0037
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
232-3233	Bearing-Main	376-9085
233-9748	Disc-Friction	417-9502
237-9849	Cage-Bearing	443-1201
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
334-8389	Crankshaft As	242-3439
430-7619	Adapter-Cla	438-1812

Sales Model R2900G

GLK		
Original Part Number	Part Name	Classic Part Number
1H-4478	Pin	330-9272
1P-1367	Plunger-Valve	432-8913
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107

GLK		
Original Part Number	Part Name	Classic Part Number
1T-1078	Bearing-Thrust	384-4802
1T-1333	Carrier As	445-9250
1T-1386	Yoke-Univ Joint	325-6239
1T-1534	Carrier-Ring	386-4916
1T-1607	Spider As	434-9637
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955

GLK		
Original Part Number	Part Name	Classic Part Number
2H-6489	Race-Brg Outer	374-8350
2P-1757	Hub-Fan Pulley	296-1357
2S-6150	Cover-Pulley	428-8817
2V-6129	Cover	390-5295
3E-6772	Seal-Water	382-8017
3G-2665	Cover	308-9842
3G-6856	Pump Gp-Gr A	421-1556
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3P-2415	Carrier-Planet	396-0653

Sales Model R2900G (Cont'd.)

GLK		
Original Part Number	Part Name	Classic Part Number
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-7489	Plate-Clutch	377-7423
3T-2094	Bearing-Sleeve	388-0638
3T-2139	Housing As-Cl	394-2583
3T-6175	Gear-Transfer	398-8351
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4E-0752	Joint Gp-Univ	435-0197
4E-2250	Housing	399-6043
4E-3751	Yoke As	451-0750
4K-7463	Seal-Lip Type	472-8007
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0685	Bearing-Sleeve	379-0191
4N-0913	Screen As-Bell	374-7489
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-2954	Sleeve-Camshaft	299-2059
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4T-9311	Housing	396-0652
4V-4483	Plate-Lock	396-9933
4W-2474	Rotocoil As	388-6571
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219

GLK		
Original Part Number	Part Name	Classic Part Number
5K-3968	Cage-Bearing	308-9804
5K-4079	Cage-Bearing	308-9805
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-4992	Bearing-Ball	380-1507
5P-6254	Bearing	420-2495
5P-7807	Bearing-Ball	314-8502
5P-9769	Cone-Rlr Bearing	422-6486
6H-2577	Spider Gp-Brg	333-4954
6I-2726	Bearing-Sleeve	419-4757
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6M-1592	Bearing-Sleeve	374-1462
6N-1931	Plunger	379-0171
6N-2687	Spider As.-Fan	385-7199
6N-5482	Plate-Friction	376-3637
6P-6739	Shaft-Planet	308-9929
6T-3726	Carrier As	390-5269
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-9885	Bearing-Rlr As	396-9906
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7C-5665	Elbow-90 Deg	399-8547
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-3557	Spider As-Fan	430-4471
7E-5996	Rod As-Conn	379-8864
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7J-8893	Cone-Roller Brg	374-1846
7J-9346	Bearing-Sleeve	374-8357

GLK		
Original Part Number	Part Name	Classic Part Number
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7W-3145	Plate	422-7894
7W-5733	Gasket	421-7333
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-2104	Bell As-Suction	380-1521
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-9622	Bracket As-Fan	433-2024
8P-4047	Shaft-Planet	373-5390
8S-6511	Bearing-Sleeve	380-7372
8V-1540	Univ Jt As	388-6574
9B-1320	Valve-Check	377-5832
9G-1919	Gear-Planet	371-4307
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9K-0723	Pin	396-7283
9K-0724	Collar	392-4524
9K-0725	Cap	444-0575
9K-0726	Cap	393-3680
9K-0802	Spacer	419-0892
9K-0804	Pin	367-6092
9K-0805	Cap	415-1910
9K-0806	Cap	430-4469
9N-3167	Plate-Block Bot	430-4468
9N-3668	Base As.-Coolant	419-4718
9P-5531	Gear-Sun	417-9499
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-5279	Bearing-Inner	453-3661
9S-8597	Spring	399-8561
9V-3052	Plate	434-1401
9V-7710	Univ Joint As	394-8234
9W-2977	Hub As	423-6985
9W-5768	Gear-Ring	380-7474

Sales Model R2900G (Cont'd.)

GLK		
Original Part Number	**Part Name**	**Classic Part Number**
9W-7040	Piston-Clutch	377-7462
9W-9930	Mount As	295-6437
9Y-6054	Rod As-Conn	379-8868
9Y-7735	Bearing-Rod	419-4665
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8608	Manifold-Exhaust	376-9062
104-8583	Manifold-Hsg	399-6058
104-8584	Housing-Rgltr	419-4725
106-7798	Bearing-Ball	417-9494
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
124-0501	Cone-Spl Tapered	399-4441
124-0502	Cup-Spl Tapered	416-2161

GLK		
Original Part Number	**Part Name**	**Classic Part Number**
124-0503	Cone-Spl Tapered	418-9604
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
149-5985	Stator-Converter	419-1865
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
161-7128	Spring As.	419-4726
164-4891	Plate As.	391-1093
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
169-5804	Yoke As	444-0574

GLK		
Original Part Number	**Part Name**	**Classic Part Number**
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
196-6845	Yoke As	451-9034
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
217-0578	Bearing-Rod	419-4665
233-9748	Disc-Friction	417-9502
237-9849	Cage-Bearing	443-1201
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
321-5746	Bearing-Main	419-6367
328-4240	Arm As-V Rocker	433-0443
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387

JLK		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4478	Pin	330-9272
1P-1367	Plunger-Valve	432-8913
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-1078	Bearing-Thrust	384-4802
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1333	Carrier As	445-9250

JLK		
Original Part Number	**Part Name**	**Classic Part Number**
1T-1386	Yoke-Univ Joint	325-6239
1T-1534	Carrier-Ring	386-4916
1T-1607	Spider As	434-9637
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-6489	Race-Brg Outer	374-8350
2P-1757	Hub-Fan Pulley	296-1357
2S-6150	Cover-Pulley	428-8817
2V-6129	Cover	390-5295
3E-6772	Seal-Water	382-8017
3G-2665	Cover	308-9842
3G-6856	Pump Gp-Gr A	421-1556
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356

JLK		
Original Part Number	**Part Name**	**Classic Part Number**
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-7489	Plate-Clutch	377-7423
3T-2094	Bearing-Sleeve	388-0638
3T-2139	Housing As-Cl	394-2583
3T-6175	Gear-Transfer	398-8351
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4D-0487	Valve As-Check	375-4334
4E-0752	Joint Gp-Univ	435-0197

Sales Model R2900G (Cont'd.)

JLK		
Original Part Number	Part Name	Classic Part Number
4E-2250	Housing	399-6043
4E-3751	Yoke As	451-0750
4K-7463	Seal-Lip Type	472-8007
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0685	Bearing-Sleeve	379-0191
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-2954	Sleeve-Camshaft	299-2059
4N-6658	Bearing-Sleeve	373-1885
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4T-9311	Housing	396-0652
4V-4483	Plate-Lock	396-9933
4V-8673	Bearing-Sleeve	307-1528
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-6150	Adapter-Support	432-4219
5K-3968	Cage-Bearing	308-9804
5K-4079	Cage-Bearing	308-9805
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-4992	Bearing-Ball	380-1507
5P-6254	Bearing	420-2495
5P-9769	Cone-Rlr Bearing	422-6486
6H-2577	Spider Gp-Brg	333-4954
6I-3066	Gasket-Cyl Head	380-1518
6I-4024	Gasket-Plate	377-5839
6M-1592	Bearing-Sleeve	374-1462
6N-1931	Plunger	379-0171

JLK		
Original Part Number	Part Name	Classic Part Number
6N-5482	Plate-Friction	376-3637
6P-6739	Shaft-Planet	308-9929
6T-3726	Carrier As	390-5269
6V-3831	Seal-O-Ring	436-2657
6Y-2065	Mount As-650 Cup	377-5844
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-9885	Bearing-Rlr As	396-9906
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7E-3557	Spider As-Fan	430-4471
7E-5996	Rod As-Conn	379-8864
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7J-8893	Cone-Roller Brg	374-1846
7J-9346	Bearing-Sleeve	374-8357
7J-9682	Bearing-Sleeve	360-2335
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401
7P-5082	Pin As	374-8367
7W-5733	Gasket	421-7333
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8N-1726	Rod As-Conn	379-8866
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-9622	Bracket As-Fan	433-2024
8P-4047	Shaft-Planet	373-5390
8S-6511	Bearing-Sleeve	380-7372
8V-1540	Univ Jt As	388-6574
9B-1320	Valve-Check	377-5832
9G-1919	Gear-Planet	371-4307
9G-6744	Bearing-Sleeve	418-1931

JLK		
Original Part Number	Part Name	Classic Part Number
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9K-0723	Pin	396-7283
9K-0724	Collar	392-4524
9K-0725	Cap	444-0575
9K-0726	Cap	393-3680
9K-0802	Spacer	419-0892
9K-0804	Pin	367-6092
9K-0805	Cap	415-1910
9K-0806	Cap	430-4469
9L-6371	Rod-Eye	363-7459
9N-3668	Base As.-Coolant	419-4718
9P-5531	Gear-Sun	417-9499
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-5279	Bearing-Inner	453-3661
9S-8597	Spring	399-8561
9V-3052	Plate	434-1401
9V-7710	Univ Joint As	394-8234
9W-2977	Hub As	423-6985
9W-5768	Gear-Ring	380-7474
9W-7040	Piston-Clutch	377-7462
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
101-7354	Manifold-Exhaust	386-3060
102-8608	Manifold-Exhaust	376-9062
106-7798	Bearing-Ball	417-9494
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
124-0501	Cone-Spl Tapered	399-4441
124-0502	Cup-Spl Tapered	416-2161
124-0503	Cone-Spl Tapered	418-9604
127-6356	Cover As.-Pump	420-8566

Wheel Loaders

Sales Model R2900G (Cont'd.)

JLK		
Original Part Number	**Part Name**	**Classic Part Number**
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
149-5985	Stator-Converter	419-1865
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048

JLK		
Original Part Number	**Part Name**	**Classic Part Number**
161-7128	Spring As.	419-4726
164-4891	Plate As.	391-1093
166-9142	Gasket	420-8546
167-8126	Damper As	382-8019
169-5804	Yoke As	444-0574
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
196-6845	Yoke As	451-9034
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914

JLK		
Original Part Number	**Part Name**	**Classic Part Number**
233-9748	Disc-Friction	417-9502
237-9849	Cage-Bearing	443-1201
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
308-1845	Seal-Wiper	472-8032
328-4240	Arm As-V Rocker	433-0443

Sales Model R3000H

RCM		
Original Part Number	**Part Name**	**Classic Part Number**
1H-4478	Pin	330-9272
1P-1367	Plunger-Valve	432-8913
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1S-9209	Shaft-Tightener	374-6499
1T-0655	Bearing-Thrust	377-7409
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0762	Race-Thrust	384-4803
1T-1078	Bearing-Thrust	384-4802
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1386	Yoke-Univ Joint	325-6239
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2B-0941	Spacer	418-1955
2H-6489	Race-Brg Outer	374-8350

RCM		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1757	Hub-Fan Pulley	296-1357
2S-6150	Cover-Pulley	428-8817
2V-6129	Cover	390-5295
3E-6772	Seal-Water	382-8017
3G-2665	Cover	308-9842
3G-6856	Pump Gp-Gr A	421-1556
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3P-2415	Carrier-Planet	396-0653
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-7489	Plate-Clutch	377-7423
3T-2094	Bearing-Sleeve	388-0638
3T-2139	Housing As-Cl	394-2583
3T-6175	Gear-Transfer	398-8351
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494

RCM		
Original Part Number	**Part Name**	**Classic Part Number**
4D-0487	Valve As-Check	375-4334
4E-0752	Joint Gp-Univ	435-0197
4E-2250	Housing	399-6043
4E-3751	Yoke As	451-0750
4K-7463	Seal-Lip Type	472-8007
4N-0209	Bonnet-Valve	378-3973
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-1767	Valve-Bypass	419-4716
4N-2514	Gear-Flywheel	421-7283
4N-2690	Shaft As	386-3053
4N-2697	Pulley-Tightener	376-9056
4N-2954	Sleeve-Camshaft	299-2059
4P-2383	Adapter-Inlet	438-1812
4S-5367	Mount As	375-9986
4T-9311	Housing	396-0652
4V-4483	Plate-Lock	396-9933
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333

Sales Model R3000H (Cont'd.)

RCM		
Original Part Number	Part Name	Classic Part Number
4W-6150	Adapter-Support	432-4219
5K-3968	Cage-Bearing	308-9804
5K-4079	Cage-Bearing	308-9805
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
5P-4992	Bearing-Ball	380-1507
5P-6254	Bearing	420-2495
5P-9769	Cone-Rlr Bearing	422-6486
6H-2577	Spider Gp-Brg	333-4954
6M-1592	Bearing-Sleeve	374-1462
6N-1931	Plunger	379-0171
6N-5482	Plate-Friction	376-3637
6P-6739	Shaft-Planet	308-9929
6T-3726	Carrier As	390-5269
6Y-2065	Mount As-650 Cup	377-5844
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-9885	Bearing-Rlr As	396-9906
7C-0307	Gasket	399-8571
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7J-8893	Cone-Roller Brg	374-1846
7J-9346	Bearing-Sleeve	374-8357
7K-5448	Cup-Bearing	415-1922
7M-7219	Bearing-Thrust	384-4816
7N-2156	Bearing-Sleeve	380-7373
7N-7628	Gasket	419-1811
7N-7878	Cover-Plate	434-2401

RCM		
Original Part Number	Part Name	Classic Part Number
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8N-5305	Spacer	363-7464
8N-5579	Retainer	425-3451
8N-9622	Bracket As-Fan	433-2024
8P-4047	Shaft-Planet	373-5390
8S-6511	Bearing-Sleeve	380-7372
8V-1540	Univ Jt As	388-6574
9B-1320	Valve-Check	377-5832
9G-1919	Gear-Planet	371-4307
9G-6744	Bearing-Sleeve	418-1931
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9K-0723	Pin	396-7283
9K-0724	Collar	392-4524
9K-0725	Cap	444-0575
9K-0726	Cap	393-3680
9K-0802	Spacer	419-0892
9K-0804	Pin	367-6092
9K-0805	Cap	415-1910
9K-0806	Cap	430-4469
9L-6371	Rod-Eye	363-7459
9P-5531	Gear-Sun	417-9499
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9S-5279	Bearing-Inner	453-3661
9S-8597	Spring	399-8561
9V-3052	Plate	434-1401
9V-7710	Univ Joint As	394-8234
9W-2977	Hub As	423-6985
9W-5768	Gear-Ring	380-7474
9W-7040	Piston-Clutch	377-7462
9W-9930	Mount As	295-6437
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
101-3125	Gasket	420-8567
102-8608	Manifold-Exhaust	376-9062

RCM		
Original Part Number	Part Name	Classic Part Number
106-7798	Bearing-Ball	417-9494
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
124-0501	Cone-Spl Tapered	399-4441
124-0502	Cup-Spl Tapered	416-2161
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
164-4891	Plate As.	391-1093
167-8126	Damper As	382-8019
177-9024	Adapter-Damper	299-1956
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
196-6845	Yoke As	451-9034
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
233-9748	Disc-Friction	417-9502
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443

Wheel Loaders

Sales Model R3200G

MAZ		
Original Part Number	Part Name	Classic Part Number
1P-1367	Plunger-Valve	432-8913
1P-3958	Bearing-Needle	434-6114
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
2A-4429	Lock-Retainer	379-0174
2H-6489	Race-Brg Outer	374-8350
3E-6772	Seal-Water	382-8017
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3P-2685	Piston-Clutch	308-9908
3P-2761	Housing-Clutch	430-8994
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3242	Shaft-Planet	308-9923
3P-3246	Shaft-Planet	308-9925
3P-3735	Housing As	391-9830
3P-7489	Plate-Clutch	377-7423
3P-8186	Housing-Screen	390-5261
3T-6175	Gear-Transfer	398-8351
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4N-0913	Screen As-Bell	374-7489
4N-2514	Gear-Flywheel	421-7283
4P-2383	Adapter-Inlet	438-1812
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
5D-6298	Cup-Spl Tapered	399-6063
5M-2054	Bearing	380-7510
5M-6126	Bearing	377-7433

MAZ		
Original Part Number	Part Name	Classic Part Number
5M-7925	Bearing-Roller	419-7774
5P-0403	Bearing-Roller	420-6542
6N-1931	Plunger	379-0171
6P-6739	Shaft-Planet	308-9929
6Y-3484	Bearing-Spl Ball	416-2166
6Y-5793	Ring-Seal	451-9028
6Y-9885	Bearing-Rlr As	396-9906
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7G-2476	Gear-Planet	223-4816
7G-3457	Gear-Planet	308-9857
7G-5746	Housing-Clutch	392-4520
7N-2156	Bearing-Sleeve	380-7373
7N-7878	Cover-Plate	434-2401
8K-0067	Spacer	396-1569
8N-2104	Bell As-Suction	380-1521
8S-6511	Bearing-Sleeve	380-7372
8V-1540	Univ Jt As	388-6574
9N-3167	Plate-Block Bot	430-4468
9P-5531	Gear-Sun	417-9499
9S-7949	Cup-Roller Brg	420-6531
9W-1572	Shaft-Xmsn Input	419-1864
9W-2977	Hub As	423-6985
9W-7040	Piston-Clutch	377-7462
9W-9930	Mount As	295-6437
101-3125	Gasket	420-8567
106-7798	Bearing-Ball	417-9494
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-7930	Bearing As	377-7463

MAZ		
Original Part Number	Part Name	Classic Part Number
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
124-0501	Cone-Spl Tapered	399-4441
124-0502	Cup-Spl Tapered	416-2161
124-0503	Cone-Spl Tapered	418-9604
127-6356	Cover As.-Pump	420-8566
128-2922	Kit-Gasket (Wp)	386-3814
129-9907	Impeller-Pump	383-1589
131-7123	Bearing-Sleeve	422-6919
133-3359	Manifold-Exhaust	419-4730
135-4928	Shaft-Water Pump	386-3813
138-9381	Plate-Spacer	424-7052
150-1916	Manifold-Exh	395-1322
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
155-5619	Gasket	382-5054
160-9874	Kit-Gasket-Scl	386-3048
164-4891	Plate As.	391-1093
186-2001	Rotocoil As	397-5055
187-8979	Gear As	393-3656
211-0592	Bearing - Main	419-6368
213-8734	Cover-Transfer	420-3217
216-5582	Bearing-Sleeve	390-0914
233-9748	Disc-Friction	417-9502
237-9849	Cage-Bearing	443-1201
246-3130	Shaft-Water Pump	392-4508
253-1752	Plate-Thrust	379-0170
278-1365	Arm As-Ui Rkr	433-7507
328-4240	Arm As-V Rocker	433-0443

Sales Model SEM657C

S57		
Original Part Number	**Part Name**	**Classic Part Number**
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915

S57		
Original Part Number	**Part Name**	**Classic Part Number**
2P-1373	Cup-Rlr Brg	382-5075
4T-9311	Housing	396-0652
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985

S57		
Original Part Number	**Part Name**	**Classic Part Number**
9W-9931	Mount As.	360-2354
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605

Cornerstone Brochure

Media Number	Description	Languages Available
PEDP9129	Cat® Classic Parts - Another Option for Older Cat Machines	English
PFDP9129	Cat Classic Parts - Another Option for Older Cat Machines	French
PPDP9129	Cat Classic Parts - Another Option for Older Cat Machines	Portuguese
PSDP9129	Cat Classic Parts - Another Option for Older Cat Machines	Spanish

Datasheets

Media Number	Description	Languages Available
PEHP9565	Cat Classic Parts	English
PEHJ0188	Cat Classic Parts for Commercial Engines	English
PFHJ0188	Cat Classic Parts for Commercial Engines	French
PPHJ0188	Cat Classic Parts for Commercial Engines	Portuguese
PSHJ0188	Cat Classic Parts for Commercial Engines	Spanish

Tri-folds

Media Number	Description	Languages Available
PECJ0011	D300/3300 PC Engine Quick Reference Card	English
PECJ0034	Customer Quick Reference Guide	English
PECJ0015	3300 DI Engine Quick Reference Guide	English
PECJ0037	Commercial Engines Quick Reference Guide	English
PFCJ0037	Commercial Engines Quick Reference Guide	French
PPCJ0037	Commercial Engines Quick Reference Guide	Portuguese
PSCJ0037	Commercial Engines Quick Reference Guide	Spanish

Literature References

Counter Cards

Media Number	Description	Languages Available
PEKJ0008	Cat Classic Parts 3300 DI Engine Parts	English
PEKJ0013	Cat Classic Parts for High-Hour Commercial Engines	English
PFKJ0013	Cat Classic Parts for High-Hour Commercial Engines	French
PPKJ0013	Cat Classic Parts for High-Hour Commercial Engines	Portuguese
PSKJ0013	Cat Classic Parts for High-Hour Commercial Engines	Spanish

Posters/Banners

Media Number	Description	Languages Available
PEPJ0094	Dealer Services Campaign - Cat Classic Parts	English
PEPJ0141	It's Time for Cat Classic Parts	English
PEPJ0142	Power Up Cost Down	English

CDs

Media Number	Description	Languages Available
PEWJ0124	Cat Classic Parts 3300 DI Engine Parts Promo Kit	English
PERJ0074	Cat Classic Parts for Commercial Engines Promo Kit	English

Sales Aid - DEALER USE ONLY

Media Number	Description	Languages Available
PEWJ0050	What Are Cat Classic Parts?	English
PEWJ0143	Cat Classic Parts Cutaway Engine	English

DLMS Course - DEALER USE ONLY

Course Number	Description	Languages Available
20269	Parts Pro - Cat® Classic Parts	English

Part Numbers Beginning with 0

Original Part Number	Part Name	Classic Part Number
002-1212	Cup-Roller Brg	399-4446
005-0469	Cup-Rlr Bearing	418-9610
005-0471	Cone-Spl Tapered	415-1924
005-4834	Cone-Rlr Bearing	422-6490
005-8639	Bearing-Aligning	415-1925
030-0060	Bearing-Cup	415-1926
030-0061	Bearing-Cone	418-9605
030-1957	Cone-Bearing	420-2502
054-2213	Spider & Brg As	347-0464
054-6549	Pinion-Planetary	347-0478
054-7091	Bearing-Rlr As	384-5959
055-1260	Housing Bk-Outer	347-0479
055-1986	Seal-Lip Type	347-0465
064-3274	Mount	391-9834
086-0414	Flange	392-4522
086-0523	Pin	314-8696
087-5533	Bearing-Sleeve	314-8628
087-5548	Bearing-Sleeve	396-1568
087-5802	Link-Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing-Sleeve	314-8629
087-5978	Flange	374-3496
087-6372	Pin	396-7284
094-1509	Shaft-Planet	360-2273
094-1850	Bearing-Trunnion	419-4747
096-4002	Bearing	420-3221
096-7911	Bearing-Sleeve	314-8653
096-7912	Bearing-Sleeve	314-8654
096-7913	Bearing-Sleeve	314-8655
099-0166	Spring	399-4400
099-0718	Bearing-Sleeve	360-2313
099-0721	Bearing-Sleeve	314-8641
099-0722	Link As	415-1909

Part Numbers Beginning with 1

Original Part Number	Part Name	Classic Part Number
100-2848	Ring-Guide	399-6057
100-2930	Gasket Kit - F	393-1026
100-2937	Kit-Gasket (Ocl)	436-8417
100-2941	Gasket Kit	393-1020
100-2951	Gasket-Kit Sch	447-8649
100-2953	Gasket Kit-Sch	393-1025
100-3414	Pump Gp-Vn Bsc-A	422-8149
100-3596	Piston	380-1511
100-3597	Plate-Reaction	380-1501
100-3650	Support-Trunnion	394-2580
100-3651	Support-Trunnion	445-7699
100-4529	Piston As	424-6368
100-4594	Muffler As	360-7862
100-5927	Joint Gp-Univ -A	390-5260
100-5953	Gasket Kit - F	437-4573
100-6174	Cyl Gp-0089 0421	425-9368
100-6267	Plate As-Idler	375-9983
100-6298	Camshaft As	398-2958
100-6920	Adapter-Nozzle	380-1552
100-7408	Camshaft As	378-4000
100-7860	Valve-Inlet	270-4360
100-8010	Valve	423-5583
101-0155	Pipe As-Exhaust	399-4427
101-1503	Shaft	394-9199
101-1504	Shaft	373-5379
101-1530	Bearing-Main	419-6382
101-1816	Bridge As-Intake	374-4689
101-1817	Bridge As.-Exh	374-4690
101-1818	Bridge As-Exh	374-4691
101-2749	Adaptr-Water Pmp	375-9984
101-3125	Gasket	420-8567
101-3374	Gear-Camshaft Dr	376-9069
101-4020	Pin As	396-7285
101-5141	Disc-Friction	380-7473
101-5144	Disc-Friction	380-7516
101-7354	Manifold-Exhaust	386-3060
101-7517	Housing	391-1094
101-7689	Yoke As	422-7245
101-8644	Kit-Gasket (Ocl)	436-8416
101-8740	Muffler As	360-7878
101-9640	Gear-Air Compr	398-2966
102-1561	Lifter As-Valve	311-9402
102-3167	Pin As	418-9575
102-3927	Muffler As	420-6219
102-4560	Bearing-Sleeve	347-0469
102-4563	Gear-Transfer	399-4430
102-8112	Cylinder	360-2276
102-8139	Spring	392-4526
102-8501	Manifold-Exhaust	377-5853
102-8503	Manifold-Exhaust	392-4513
102-8608	Manifold-Exhaust	376-9062
102-8636	Gear-Drive	472-8035
103-0887	Pulley-Idler	449-9546
103-1713	Yoke-Bk-Flange	382-6892
103-5345	Bearing-Sleeve	393-3640
103-5961	Wheel	398-2963
104-1706	Valve-Regulating	432-8281
104-3014	Gasket Kit	388-0656
104-3133	Carrier-Planet	435-2897
104-4747	Pin	392-4527
104-5283	Manifold-Exhaust	394-9831
104-6374	Piston	393-1052
104-7238	Plate	380-7404
104-8583	Manifold-Hsg	399-6058

Part Cross-Reference

Part Numbers Beginning with 1 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
104-8584	Housing-Rgltr	419-4725
104-8655	Bearing-Sleeve	391-9892
104-9635	Kit-Gasket-Sch	436-8415
105-0017	Cylinder	416-2130
105-1738	Manifold-Exhaust	374-4692
105-2070	Bushing	394-0221
105-2094	Cyl Gp-0076 1194	423-7868
105-2095	Rod As	421-1565
105-2125	Joint Gp-Slip	398-2937
105-2155	Pump Gp-Vn Bsc-A	422-8151
105-2485	Gear-Tfr Output	398-2932
105-2486	Gear-Transfer	391-9882
105-2487	Gear-Tfr Output	391-9881
105-2659	Bearing-Sleeve	419-2304
105-3196	Motor Gp-Grtr	282-6547
105-7535	Bearing-Dbl Row	417-9496
105-8586	Pinion As	375-2630
105-8651	Core As-Oclr	434-9521
105-8704	Support-Trunnion	416-5510
105-8724	Hub	418-9598
105-8727	Shaft-Axle	423-6986
105-8735	Gear-Diff Bevel	416-2154
106-0714	Shaft	364-5260
106-2822	Gasket Kit	436-8376
106-6540	Retainer	418-1941
106-6878	Pin	372-7510
106-7098	Flange Assm	390-5271
106-7099	Carrier-Planet	388-6585
106-7131	Shaft	288-8714
106-7798	Bearing-Ball	417-9494
106-7799	Bearing-Ball	396-9947
106-8711	Elbow-Exhaust	383-3709
107-0621	Kit-Gskt-Sch	436-8414
107-2139	Pin As.	360-2352
107-3950	Head	383-1588
107-5002	Cage-Bearing	396-7261
107-5005	Joint Gp-Univ	396-9929
107-5006	Joint Gp-Univ	416-2137
107-5007	Joint Gp-Slip	416-2145
107-5610	Yoke	398-8334
107-7473	Muffler As.	385-7223
107-7708	Bearing-Main	419-6381
107-7750	Pulley	382-6896
107-8106	Manifold-Exh	374-7487
107-8107	Manifold-Exh	398-2926
107-8108	Manifold-Exh	385-6141
107-8109	Manifold-Exh	374-7488
107-8112	Manifold-Exh	376-9063
107-8375	Shaft As	439-1134
107-9172	Piston	375-2622
107-9739	Pin As	393-3689
108-1760	Bearing-Ball	417-9493
108-2102	Bonnet-Valve	455-3274
108-2735	Ring-Lock	386-4935
108-2736	Ring-Lock	384-3476
108-5603	Screw-Adj Arm	379-0166
108-5680	Gage-Oil Level	378-4001
108-6630	Pump Gp-F Inj -B	432-8276
108-6631	Plunger & Bbl As	419-4744
108-6633	Pump Gp-Fuel Inj	420-6215
108-7754	Housing As.	433-9856
108-7930	Bearing As	377-7463
108-8250	Carrier-Seal	421-7830
108-9191	Pin As	424-3515
109-0367	Pin	421-1566
109-0377	Pin As	399-8543
109-0380	Pin As	396-7276
109-0958	Pin	394-0208
109-1231	Strip	393-3683
109-4848	Pulley-Cshaft	416-5507
109-5562	Shaft-Pin (Bev)	275-5272
109-6928	Gasket Kit	436-8413
109-6938	Bracket	451-9033
109-7687	Bearing-Ball	420-3220
109-9323	Muffler As	369-9491
109-9349	Mount-Rubber	384-3469
109-9350	Mount-Rubber	393-1046
109-9368	Mount-Rubber	384-3471
109-9369	Mount-Rubber	393-1047
109-9445	Mount-Rubber	393-1048
109-9446	Mount-Rubber	393-1049
109-9463	Muffler As	360-7864
110-0013	Cup-Rlr Brg	384-5960
110-0551	Hub As	416-2146
110-0840	Track Rod As.	391-1097
110-1337	Ring Kit-Pstn	377-5834
110-1488	Gear-Ring	394-0882
110-2665	Shaft-Planet	391-9871
110-4652	Housing	302-2683
110-5096	Head As-Cyl	394-0915
110-6167	Pin As	375-9972
110-7056	Gear-Planet	374-3497
110-7059	Carrier-Planet	301-4636
110-7209	Carrier As	301-5237
110-7216	Gear-Sun	391-9877
110-7228	Carrier-Planet	390-0918
110-7232	Gear-Sun	417-9472
110-7243	Carrier As	384-5961
110-8368	Bearing-Cup	416-2172
111-1757	Gasket Kit - Sch	436-8395
111-2645	Valve-Pump Byp	441-1561
111-3895	Yoke	421-3080
111-4332	Plate	396-7290
111-4340	Pin	451-1512
111-4343	Pin	390-5272
111-8015	Gasket As-Head	279-4977
111-8181	Cyl Gp-197 864 Y	390-0986
112-1665	Muffler As.	435-4847
112-1773	Piston	347-0462
112-2255	Gear-Bevel	446-3076
112-3249	Muffler As	247-2661
112-4296	Cylinder As	443-5197
112-4297	Cylinder As	443-5199
112-5003	Cyl Gp-159 582 Y	393-3654
112-5060	Bracket As	364-5270
112-5061	Bracket As	364-5271
112-5088	Muffler As.	396-9943
112-5089	Muffler As-Na	390-0982
112-5495	Joint Gp-Univ	297-4858
112-5538	Kit-Gasket-Sch	436-8412
112-5585	Shaft-Planet	308-9932
112-7308	Carrier-Planet	419-8803
112-7309	Shaft-Planet	380-7521
112-7750	Manifold-Exhaust	390-0919
112-7751	Manifold-Exhaust	390-0917
112-7993	Gasket Kit	437-3231
112-8041	Carrier-Planet	295-5681
112-8042	Carrier-Planet	390-0916
113-1149	Shaft As-Awd	418-9574
113-1150	Shaft As-Main	433-6670
113-2966	Pin As	380-7398
113-4610	Gasket Kit	436-8410
113-6200	Gasket	438-2020
113-9098	Pin	425-6447
113-9099	Pin	425-3449
114-0468	Pin-G.E.T.	443-1203

Part Numbers Beginning with 1 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
114-0915	Shield As.	394-0887
114-1071	Piston	388-6583
114-1383	Shaft-Planet	398-8349
114-1398	Gauge-Oil Level	394-9815
114-4680	Gear As-Pump	374-7485
114-4787	Kit-Gasket (Ocl)	388-0657
115-0637	Pump Gp-Gr 1	226-0160
115-2367	Valve-Exhaust	384-8700
115-2368	Valve-Inlet	384-8704
115-2775	Pin As	418-1967
115-2958	Pin-Lower	393-0939
115-2989	Manifold-Exhaust	434-9635
115-3184	Cap-Lower	395-1324
115-3657	Kit-Gasket-Ocl	437-4572
115-4072	Bearing	397-5069
115-4204	Pulley As-Idler	301-5219
115-4237	Pulley-Idler	374-4693
115-4517	Core As-Oclr	421-7281
115-6400	Spring	399-8564
115-6427	Spring	301-4776
115-6428	Piston As	394-0188
115-6429	Cylinder	301-4679
115-6469	Spacer	425-3645
115-7048	Pin	393-3684
115-9398	Arm-Valve Rocker	433-0448
115-9399	Arm-Valve Rocker	433-0447
115-9400	Arm As-Ui Rocker	433-0446
115-9403	Shaft As	434-7259
116-1102	Sleeve-Injector	451-9024
116-7885	Pan-Oil (Front)	379-0173
116-8533	Yoke As	451-9031
116-8537	Shaft Gp-Drive-D	418-9570
116-8539	Spider & Brg Kit	399-4399
117-0019	Disc-Friction	417-9492
117-0023	Kit-Bearing-Tc	464-9061
117-0456	Crankshaft As	394-2587
117-5200	Spider As-Fan	428-8686
117-5435	Pin As	393-0934
117-5553	Guard As-Tck Gde	419-4729
117-5612	Pipe	398-2965
117-6270	Support As	434-1400
117-6675	Step As	419-0881
117-7899	Gasket Kit - Sch	436-8409
117-7901	Kit-Gasket (F)	436-8397
117-9712	Shaft-Dr Idler	425-7754
118-2089	Pulley	434-2449
118-2800	Housing As.-Rglt	419-4719
118-5196	Pin	380-7397
118-5839	Seal-Lip Type	435-8517
118-6335	Pin	436-3042
118-7805	Pinion-Bevel	394-9197
118-8458	Spider As-Fan	395-1306
118-9906	Muffler As	360-7865
119-1852	Cyl Gp 0102 0755	430-5960
119-2863	Pin	314-8698
119-2940	Gasket	378-4002
119-2950	Gasket	433-8195
119-5727	Bearing-Spl Ball	417-9491
119-6772	Valve-Exhaust	384-8699
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
119-7053	Flange	417-9471
120-0300	Fan As-Radiator	419-4648
120-3861	Bracket As	415-1897
121-5455	Tube As-Exhaust	449-4735
121-5457	Tube As-Exhaust	419-4670
121-5459	Tube As.-Exhaust	420-6397
121-5461	Tube As-Exhaust	419-4666
121-7583	Gear-Planet	364-5257
121-7627	Bearing-Roller	453-3653
121-7632	Disc-Clutch	394-9195
121-7746	Pre-Cleaner As	360-2311
122-0321	Valve-Exhaust	384-8698
122-0322	Valve-Inlet	384-8703
122-1881	Plate-Clutch	347-0475
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
122-6381	Pin As	419-6073
122-6387	Pin As	425-6448
122-6787	Yoke As	416-2139
122-8900	Kit-Gasket(F)	437-3230
123-2111	Piston	462-5714
123-3472	Pump Gp-Gr 1 Bsc	345-1978
123-6592	Gasket Kit	437-4571
123-6597	Gasket Kit	436-8421
123-8509	Pump Gp-Vn Bsc	422-8152
124-0501	Cone-Spl Tapered	399-4441
124-0502	Cup-Spl Tapered	416-2161
124-0503	Cone-Spl Tapered	418-9604
124-2726	Head	377-5855
124-3012	Gasket Kit	437-3229
124-3237	Precleaner As	432-4220
124-3240	Pin	282-6548
124-3684	Gasket Kit-Sch	437-8646
124-5233	Pin	443-2664
124-5741	Pin	394-0204
124-7566	Kit-Gasket-Acl	437-4570
124-7569	Gasket Kit	393-1041
124-7570	Kit-Gasket-Acl	437-4569
124-7609	Gear-Pump Idler	428-8504
125-0024	Cyl Gp 0152 0800	399-8566
125-0025	Rod As	394-8208
125-1037	Pin As	375-9985
125-2728	Core As	395-1302
125-2873	Core As-Ac Cond	436-2254
125-2950	Gear As	301-4762
126-0734	Muffler As	397-5052
126-2522	Cone-Spl Tapered	377-7397
126-5056	Shield As-Man Lh	369-9492
126-5057	Shield As-Man Lh	369-9493
126-5875	Flywheel As.	374-4694
126-5984	Ring-Backup	419-4654
126-7130	Shaft As	275-5300
126-7134	Pipe As-Exhaust	451-9032
126-8181	Cone-Spl Tapered	434-3295
126-8557	Pulley	433-2027
126-9461	Pin	392-4528
127-1517	Gasket Kit - F	437-4568
127-1518	Gasket Kit - F	437-4567
127-2194	Gasket Kit-Sch	437-8645
127-3365	Joint Gp-Slip	367-6067
127-3467	Manifold-Exhaust	394-9827
127-4525	Gage As	386-3043
127-4953	Gasket Kit-Sch	437-8676
127-5022	Gasket Kit-Sch	437-8643
127-5537	Core As-Oclr	325-6045
127-5970	Gear-Planet	301-3398

Part Cross-Reference

Part Numbers Beginning with 1 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
127-6356	Cover As.-Pump	420-8566
127-6974	Gasket Kit	393-3638
127-8592	Muffler As	347-0463
127-8594	Muffler As-Turbo	390-0981
127-8932	Cylinder As	422-4937
128-1009	Muffler As	435-6047
128-2922	Kit-Gasket (Wp)	386-3814
128-3132	Gasket Kit	437-4566
128-3935	Bearing-Race	396-9897
128-4128	Rod Gp-Tie	385-6136
128-7228	Pump Gp-Vn Bsc-A	422-8153
128-9863	Bearing-Sleeve	314-8630
128-9864	Bearing-Sleeve	425-6437
128-9882	Bearing-Sleeve	314-8642
128-9883	Bearing-Sleeve	360-2314
128-9884	Bearing-Sleeve	360-2315
129-2381	Gear-Planet	275-5274
129-3046	Carrier-Planet	393-1015
129-3068	Rebuild Kit-Pump	363-7455
129-3069	Rebuild Kit-Pump	363-7456
129-4259	Cyl Gp 0102 1437	393-3655
129-4299	Gear-Planet	446-3077
129-7768	Bearing-Sleeve	360-2316
129-9907	Impeller-Pump	383-1589
130-0479	Pin As	415-1907
130-0485	Pin	396-7286
130-1455	Gasket Kit	437-4604
130-1521	Gasket Kit - Sch	393-1030
130-1637	Shaft	347-0471
130-1918	Pin As	393-0933
130-2533	Pin	396-7265
130-2621	Pin As	390-5273
130-3013	Shaft As	391-9865
130-3014	Shaft As	391-9864
130-3139	Bearing-Sleeve	391-9875
130-4778	Housing As	419-4659
130-4779	Housing As	441-1562
130-5451	Pin	394-9816
130-6856	Pre-Cleaner As	361-1717
130-6879	Seal	347-0482
130-8412	Piston-Clutch	394-0910
130-9293	Rod	314-8708
131-3736	Socket Gp-Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp-Basic	325-6193
131-6001	Pin As	376-3646
131-6091	Gear-Sliding	385-7201
131-7123	Bearing-Sleeve	422-6919
131-8246	Yoke As (8.5C)	430-5362
131-8248	Yoke As	434-6113
131-8674	Gear As-Drive	394-0911
132-0985	Bearing-Sleeve	399-6056
132-2463	Joint Gp-Slip	432-6605
132-6597	Cone-Spl	422-6477
132-7923	Gasket Kit-Sch	437-8642
133-2437	Link	377-6199
133-3359	Manifold-Exhaust	419-4730
133-3545	Tightener-Belt	434-1407
133-3565	Tube As-Exhaust	374-4695
133-3566	Tube As-Exhaust	378-4003
133-3919	Gasket Kit-Sch	393-1031
133-4995	Gasket-Cyl Head	434-2445
133-6597	Pipe- Extension	420-6220
133-8890	Race	399-4423
133-8991	Line As-Fuel Inj	378-4004
133-8992	Line As-Fuel Inj	378-4005
133-8993	Line As-Fuel Inj	378-4006
133-8994	Line As-Fuel Inj	378-4007
133-8995	Line As-Fuel Inj	378-4008
133-8996	Line As-Fuel Inj	378-4009
133-9016	Pulley	421-7191
134-0039	Housing-Piston	432-4217
134-2659	Rod As	388-6568
134-3036	Gasket Kit	393-3629
134-3038	Gasket Kit	437-3228
134-3056	Guard-Duo-Cone	421-7831
134-3068	Kit-Gasket(F)	393-3636
134-4200	Manifold-Exhaust	443-2060
134-8948	Plate	399-8588
134-8949	Plate	383-2110
134-8950	Plate	399-8587
134-8951	Plate	382-5061
134-9807	Gasket Kit	437-3214
135-0239	Gasket Kit	437-4606
135-0524	Piston-Clutch	380-7402
135-2151	Tensioner	419-4735
135-2376	Gasket Kit-Lower	393-3634
135-2707	Kit-Gasket(Bsc)	392-4506
135-3225	Shaft As	399-8582
135-4928	Shaft-Water Pump	386-3813
135-5553	Bearing	394-0203
135-6160	Shaft-Sun Gear	394-8239
135-7393	Head	382-6895
135-7989	Gasket Kit	393-3633
135-8167	Pipe-Extension	395-1305
136-0819	Valve-Exhaust	384-8697
136-7813	Bearing-Race	460-8296
137-1339	Pump Gp-Water -B	434-6112
137-1970	Impeller-Pump	380-1553
137-2817	Bearing-Sleeve	434-2399
137-2818	Bearing-Sleeve	380-7381
137-2819	Bearing-Sleeve	360-2317
137-2820	Bearing-Sleeve	360-2318
137-2821	Bearing-Sleeve	419-4717
137-2822	Bearing-Sleeve	453-0971
137-2919	Bearing-Sleeve	360-2319
137-3060	Bearing-Sleeve	360-2320
137-4097	Muffler As.	360-7866
137-6500	Rotocoil As.	397-5053
137-6995	Muffler As	360-7868
137-8479	Spacer	395-1323
138-1840	Retainer-Seal	374-6511
138-1987	Gasket Kit - F	437-3238
138-2317	Wheel	396-9948
138-4037	Kit-Gasket (Acl)	438-1797
138-4039	Kit-Gasket(F)	437-3224
138-4338	Kit-Gasket-T	393-1032
138-6743	Gasket Kit	437-3223
138-6744	Rebuild Kit-Pump	363-7457
138-7025	Kit-Gasket(F)	437-3222
138-9381	Plate-Spacer	424-7052
139-0683	Gasket Kit	390-5290
139-4750	Kit-Gasket-F	437-3221
139-4758	Gasket Kit	436-8405
139-6849	Gasket Kit	388-6586
139-6850	Gasket Kit	384-4809
139-8963	Kit-Gasket-Mch	436-8404
139-9170	Gasket Kit	447-0825
139-9172	Gasket Kit	384-5964
139-9173	Gasket Kit	434-7261
139-9175	Gasket Kit	377-7464
139-9176	Gasket Kit	390-5283

Part Numbers Beginning with 1 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
139-9177	Gasket Kit	377-7465
139-9178	Gasket Kit	434-7262
139-9179	Gasket Kit	390-5289
140-1093	Gasket Kit-Sch	436-8394
140-2246	Gasket Kit	383-3710
140-2382	Gasket Kit	390-5285
140-2383	Gasket Kit	396-9927
140-2731	Kit-Gasket (Cl)	436-8403
140-2739	Kit-Gasket-Acl	437-3220
140-2746	Kit-Gasket-Mch	437-3219
140-2749	Gasket Kit	393-1033
140-2859	Kit-Gasket-Mch	437-3218
140-8435	Flange	451-9015
140-9631	Kit-Gasket(F)	437-3217
140-9902	Gasket Kit	393-0916
141-0338	Kit-Gasket(Acl)	437-3215
141-0340	Kit-Gasket(F)	436-8402
141-0345	Gasket Kit	437-3227
141-0348	Gasket Kit	437-4579
141-1021	Gasket Kit	437-4615
141-1028	Kit-Gasket(Sch)	435-2576
141-1936	Kit-Gasket(F)	437-4614
141-1939	Gasket Kit	437-4613
141-1942	Gasket Kit	437-4612
141-2919	Rod As	399-8567
141-4109	Core As-Oclr	416-5518
141-4617	Kit-Gasket(Acl)	393-0917
141-4689	Bar Gp-Equalizer	443-3570
141-4974	Gasket Kit	388-0658
141-5787	Kit-Gasket(Ocl)	437-4611
141-6136	Socket Gp	333-4953
141-6137	Socket Gp	325-6212
141-6138	Socket Gp	325-6213
141-7274	Gasket Kit	418-1951
141-7277	Kit-Gasket-Fs	437-4610
141-7955	Gasket Kit	437-4609
141-9792	Gasket Kit - Ocl	393-3632
142-0226	Kit-Gasket-Fs	393-1034
142-0227	Gasket Kit	437-4608
142-0228	Gasket Kit - Sch	393-1035
142-0404	Kit-Gasket-Fs	437-4607
142-1662	Kit-Gasket(F)	392-4511
142-1699	Gasket Kit	392-4507
142-2221	Gasket Kit - Sch	437-8127
142-2303	Pin As	423-3537
142-2535	Gasket Kit	437-4593
142-3035	Kit-Gasket (Wlg)	393-0926
142-5093	Kit-Gasket (Acl)	437-4605
142-7526	Gasket Kit	393-0918
142-8811	Muffler As	360-2297
142-8845	Muffler As	360-9619
143-0905	Gasket Kit	437-4617
143-1314	Kit-Gasket-T	437-4603
143-2605	Kit-Gasket-Mch	393-0915
143-3321	Bearing-Sleeve	425-3583
143-5428	Gasket Kit	437-8115
143-5430	Gasket Kit	437-4602
143-5447	Gasket Kit - F	393-1036
143-5448	Gasket Kit - Sch	447-8652
143-7356	Bearing As	380-1483
144-0482	Gasket	420-8547
144-0502	Ring Kit-Piston	395-1312
144-0503	Piston & Ring Kt	380-1554
144-0744	Compressor Gp -B	435-6046
144-1150	Gasket Kit	391-9879
144-7289	Roller As	434-1862
144-7293	Roller As	434-1992
144-7299	Roller As	434-1991
144-7314	Roller As	434-8984
144-9072	Cylinder As	394-8209
145-0162	Bearing-Main	419-6380
145-0163	Bearing-Main	419-6336
145-0164	Bearing-Main	419-6376
145-0165	Bearing-Main	419-6388
145-0803	Pin	393-0936
145-0804	Sleeve	391-9905
145-2867	Kit-Gasket (Wp)	449-9830
145-3030	Cylinder	360-2260
145-3036	Spring	375-5445
145-3037	Support	480-8271
145-4585	Muffler As	360-9627
145-6726	Gasket Kit	437-4600
145-6749	Shaft As-Input	433-9211
145-8503	Shaft As-Idler	426-0035
146-2601	Cover	399-6054
146-4229	Gasket Kit - Sch	437-4599
146-9733	Muffler As	435-6045
147-1007	Kit-Dt Gasket	388-6587
147-1010	Gasket Kit	390-5278
147-1012	Gasket Kit	434-7263
147-1206	Gear Planet	418-9597
147-1740	Gear-Planet	377-7466
147-1900	Gasket Kit	447-0826
147-3309	Spindle	282-6628
147-3310	Spindle-Wheel	383-2111
147-3311	Spindle-Wheel	469-8102
147-3400	Spindle	282-6549
147-3781	Kit-Gasket(Wp)	422-2484
147-4358	Pin	419-6030
147-4359	Pin	393-0937
147-6170	Gasket Kit	437-4598
147-9670	Fan As-Rev	435-9912
148-0885	Stator-Converter	379-0161
148-2125	Liner-Cylinder	458-0154
148-2593	Head	383-1591
148-3091	Bearing-Sleeve	365-8825
148-3465	Pin	383-2112
148-4634	Shaft-Planet	360-2274
148-7455	Valve - Exhaust	270-4361
148-8269	Gasket Kit - Cl	437-4597
148-8861	Gasket Kit	437-4596
148-9288	Case As-Diff	380-1496
148-9810	Gasket Kit	393-3631
149-0625	Kit-Gasket(F)	437-4595
149-0629	Gasket Kit - Sch	437-4594
149-2752	Muffler	360-9628
149-2914	Pinion-Dif Bevel	396-9950
149-4912	Kit-Gasket (Sch)	437-4616
149-5985	Stator-Converter	419-1865
150-0351	Spacer	396-7291
150-1914	Manifold-Exh	434-6111
150-1916	Manifold-Exh	395-1322
150-3416	Muffler	360-9620
150-4637	Pan-Oil	377-5843
150-8459	Kit-Gasket(F)	438-1798
150-8685	Gasket Kit	392-4503
151-4836	Diff Gp -A	416-2120
151-5349	Head	383-1592
151-5911	Manifold As.-Exh	441-5604
152-3952	Impeller-Pump	374-4696
152-5705	Gasket	447-0830
152-6485	Cyl Gp-102 472 Y	390-0985
153-3580	Shaft	299-2055
153-7023	Valve-Inlet	391-1106
153-7024	Valve-Exhaust	391-1107
154-1642	Gasket Kit - Scl	437-8117
154-2689	Spider	463-7670
154-5278	Pin	393-3685

Part Cross-Reference

Part Numbers Beginning with 1 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
154-5279	Pin	392-4529
154-5280	Pin	391-9868
154-5676	Gasket Kit	447-0827
154-5679	Kit-Dt Gasket	390-5277
154-5682	Gasket Kit	434-7264
154-5683	Kit-Dt Gasket	420-6528
154-5685	Kit-Dt Gasket	396-0649
154-8030	Gasket	394-0894
155-1378	Gasket Kit - Sch	437-8152
155-1379	Gasket Kit - Sch	386-3815
155-2819	Ejector As-Exh	325-6078
155-5091	Cartridge Gp	422-8124
155-5619	Gasket	382-5054
155-6048	Kit-Dt Gasket	434-7272
155-6057	Kit-Gasket-Trans	388-6588
155-6637	Gear-Oil Drive	425-9189
155-6648	Cone Spl Rol Brg	418-9599
155-8688	Gasket Kit	434-7273
155-8690	Gasket Kit	434-7274
155-8691	Kit-Dt Gasket	396-0650
155-8694	Gasket Kit	451-1503
155-8696	Kit-Dt Gasket	396-9944
155-8698	Gasket Kit	394-0914
156-0140	Kit-Bearing	464-9063
156-0738	Rod As	394-8210
156-6237	Elbow As	396-1567
156-8206	Kit-Dt Gasket	451-3112
156-8208	Kit-Gasket-Trans	434-7275
156-8578	Shaft	417-9490
157-0956	Pump Gp-Vn Bsc-B	422-8154
157-2828	Muffler As	360-9621
157-5075	Gear-Planet	394-9821
157-6257	Collar	393-0912
158-1433	Gasket Kit	393-1003
158-1438	Kit-Dt Gasket	434-7276
158-1439	Kit-Dt Gasket	434-7290
158-1441	Kit-Dt Gasket	394-9207
159-0959	Pin As	418-9578
159-0961	Pin	396-7287
159-1845	Yoke As (1480)	380-1494
159-1847	Yoke As (1610)	373-5381
159-3021	Gasket	377-5845
159-3263	Muffler As	430-7623
159-8169	Gear-Planet	391-9870
159-9742	Kit-Gasket(F)	437-1996
160-0305	Bearing-Aligning	396-9945
160-1014	Pin As	347-0473
160-1400	Yoke (1710)	319-3479
160-5691	Pin	393-0931
160-6305	Cap-Bearing	295-5686
160-6306	Cap-Bearing	325-6038
160-8178	Rod As-Conn	379-8869
160-9874	Kit-Gasket-Scl	386-3048
161-3411	Gasket	394-0896
161-4111	Pump Gp-Xx 1 Gr	374-7502
161-7128	Spring As.	419-4726
161-9082	Gasket Kit	434-7277
161-9918	Retainer-Bearing	395-1321
162-0152	Bearing-Sleeve	422-9519
162-0191	Gear-Planet	418-9593
162-0195	Carrier-Planet	435-4784
162-0268	Hub As	426-3475
162-0270	Carrier-Planet	394-9819
162-3904	Pump As-F Prm	391-1102
162-4012	Gasket Kit - F	437-8126
163-1387	Gear-Flywheel	374-4697
163-3103	Manifold-Exh	430-8992
163-3127	Sleeve	419-4668
163-3749	Bearing-Sleeve	433-7505
163-4063	Core As-Rdtr	391-9826
163-4109	Manifold-Exhaust	433-9857
163-5316	Kit-Gasket(F)	437-2018
163-5636	Kit-Gasket(Ocl)	437-2017
163-5723	Gasket Kit - Sch	437-8641
163-7280	Gasket Kit	434-7260
164-2138	Gasket Kit - Sch	437-2016
164-4413	Mount	419-0876
164-4891	Plate As.	391-1093
164-6560	Body As-Piston	477-7125
164-6574	Kit-Gasket-Acl	437-2015
164-7174	Cyl Gp-0076-1067	423-7865
165-2495	Cyl Gp-0064-0292	399-8562
165-2496	Cyl Gp-0064-0292	399-8568
165-4262	Body As-Piston	270-4351
165-4262	Body As-Piston	270-4353
165-4262	Body As-Piston	477-7126
165-5255	Pin As	425-6449
165-5634	Shaft As.-Output	421-7067
165-7211	Strip	325-6219
165-7573	Kit-Gasket (Fs)	438-0141
165-9864	Gasket Kit-Sch	388-0659
166-2142	Hub Gp-Shaft	394-8238
166-6352	Tube As.	432-4223
166-6757	Yoke	446-3078
166-6930	Cone-Spl Tapered	399-4443
166-7870	Pad As-Street	416-5515
166-9142	Gasket	420-8546
167-0622	Gasket Kit	434-7279
167-8123	Damper As	299-2006
167-8126	Damper As	382-8019
168-0444	Pin	393-3687
168-4531	Body As-Piston	477-7127
168-8453	Bearing-Spl Ball	417-4497
169-1750	Seal Gp-Basic	472-8022
169-4199	Gasket-Oil Pan	433-8194
169-4200	Gasket	472-8023
169-5804	Yoke As	444-0574
169-9527	Cyl Gp-0076-0352	430-5959
170-0556	Kit-Rebuild-Pump	383-3712
170-0558	Kit-Rebuild-Pump	390-1001
170-0560	Rebuild Kit-Pump	363-7458
170-0564	Rebuild Kit-Pump	380-7576
170-0566	Kit-Rebuild-Pump	377-5835
170-0570	Rebuild Kit-Pump	380-7577
170-4860	Bonnet-Oil Clr	430-5359
170-5212	Rod As	399-8575
170-7501	Kit-Gasket(Ocl)	437-2014
170-7502	Shaft-Dr Idler	374-7484
170-8541	Core As-Rdtr	379-0180
170-8714	Disc-Friction	456-9193
171-3942	Yoke	398-2931
171-6696	Diaphragm	384-4811
171-8780	Kit-Gasket (Ocl)	437-2013
172-2349	Cylinder As (Lh)	430-5958
172-5185	Shaft-Water Pump	325-6201
172-5188	Shaft-Water Pump	325-6202
172-5189	Impeller-Pump	295-5687
172-5190	Impeller-Pump	325-6111
172-6712	Impeller-Pump	325-6112
172-7760	Pump Gp-Water -B	380-7574
172-7763	Pump Gp-Water -B	374-7499
172-7765	Pump Gp-Water -B	394-9835

Part Numbers Beginning with 1 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
172-7766	Pump Gp-Water -B	374-4698
172-7767	Pump Gp-Water -B	296-1365
172-7771	Pump Gp-Water -B	419-4646
172-7772	Pump Gp-Water -B	438-2009
172-7775	Pump Gp-Water -B	398-2942
172-7776	Pump Gp-Water -B	395-1314
173-0888	Univ Jt As	394-0898
173-1926	Cyl Gp-0102-0541	399-8576
173-1927	Cyl Gp-0102-0541	426-0036
174-0739	Gasket Kit - F	437-2012
174-3405	Yoke As	398-2929
174-5385	Gasket Kit - Ocl	393-1037
174-6820	Bearing-Sleeve	387-2903
174-6822	Bearing-Sleeve	387-2901
174-6829	Gasket Kit	394-8237
174-6836	Gasket Kit - Tof	434-7280
174-7432	Head	388-0660
176-1402	Pin	425-2562
176-3900	Accumulator	416-5513
176-4168	Bridge As-Valve	419-4727
176-4172	Bridge As-Valve	457-4600
176-6997	Shaft	399-8573
176-6998	Impeller-Wtr Pmp	425-9367
176-8167	Kit-Gasket-Acl	437-2011
176-8182	Kit-Gasket(Scl)	437-2010
176-9273	Piston	297-4860
177-4132	Kit-Dt Gasket	394-8227
177-7886	Cone	418-9605
177-9024	Adapter-Damper	299-1956
178-3086	Ballstud	374-1453
178-8608	Cone	422-6479
179-1970	Yoke As.	376-9053
179-3008	Cylinder	480-8272
179-3044	Cylinder	385-6138
179-6152	Bearing	361-1704
180-6645	Shaft As.	396-1566
183-2358	Bearing	425-3588
184-1413	Pin As	393-1050
184-4395	Guide	393-1042
184-9843	Head	347-0461
185-2831	Line As	380-1516
186-2001	Rotocoil As	397-5055
186-4117	Carrier As	394-8235
186-4118	Gear-Planet	347-0483
186-4439	Gear-Planet	380-1485
186-4440	Shaft-Planet	364-5261
186-5652	Pin	392-4532
186-5662	Pin	421-1560
186-5730	Pin	393-3688
187-0605	Gasket Kit - Cl	382-5055
187-3307	Gasket As-Cyl	438-2022
187-3825	Pad As.	397-5054
187-3827	Pad As.	397-5057
187-8979	Gear As	393-3656
188-2886	Gasket Kit	434-7281
188-2887	Kit-Dt Gasket	394-8244
188-4211	Cylinder As	425-9366
189-1814	Kit-Gasket(Ocl)	437-2009
189-3041	Rod As	394-9811
189-3878	Link As	438-1813
189-3922	Pin	393-0938
189-3923	Pin	393-0935
189-4148	Pin As	423-3536
189-4150	Pin As	423-3535
189-6062	Pin As	425-2561
190-0649	Tightener-Belt	434-1407
190-3832	Core As-Oclr	438-3251
190-9861	Kit-Gskt-Acl	386-3812
191-3118	Cyl Gp-0170 1680	399-8560
191-3235	Housing-Sprocket	394-0200
191-3240	Housing-Motor	418-1962
191-3243	Housing-Motor	418-1963
191-4610	Pump Gp-Vane	422-8160
191-7725	Cyl Gp-0076-1067	423-7867
191-7727	Cylinder As.	430-5957
191-7941	Line As-Fuel Inj	378-4011
191-7942	Line As-Fuel Inj	374-4699
191-7943	Line As-Fuel Inj	374-4700
191-7944	Line As-Fuel Inj	374-4701
191-7945	Line As-Fuel Inj	378-4012
191-7946	Line As-Fuel Inj	378-4013
191-9323	Kit-Bearing	464-9064
192-0478	Kit-Gasket (Sch)	437-1995
192-6445	Cyl Gp-235 535 Y	393-3651
192-6446	Cyl Gp-235 535 Y	393-3657
192-6447	Head	425-9365
192-6448	Rod As	428-7630
192-8318	Bearing-Sleeve	360-2321
193-0646	Spacer	419-2310
193-1683	Pad	416-5496
193-1684	Pad	396-0645
193-1688	Pad	416-5495
193-3322	Gasket Kit - Ocl	437-2007
193-5016	Flange	425-3644
196-0028	Gear As-Idler	364-5259
196-0029	Gear As-Idler	374-4674
196-3986	Gasket Kit	390-5275
196-6845	Yoke As	451-9034
196-7078	Strip Wear Front	418-1968
196-9534	Bearing Kt-Main	468-8667
197-5510	Support As	419-0880
197-9251	Pin As.-Piston	454-6110
199-0760	Bearing-Roller	465-8981
199-4582	Bearing-Needle	388-6589
199-5067	Muffler As	360-7894
1A-0744	Screw-Rocker Adj	379-0167
1A-2846	Cap As-Filler	311-9368
1A-3987	Disc-Ster Cl Dr	230-7119
1A-9252	Rod End-Yoke	377-5849
1B-3922	Cup-Roller Brg	416-2158
1B-3924	Cone-Roller Brg	422-6482
1B-3934	Cup-Roller Brg	392-4487
1B-3937	Cup-Roller Brg	377-7394
1B-3941	Cone-Roller Brg	422-6486
1B-3978	Cup-Roller Brg	399-4437
1B-3980	Cone-Roller Brg	399-4443
1B-4038	Cup-Roller Brg	423-6988
1B-4043	Cone-Roller Brg	377-7395
1B-4102	Bearing-Ball	399-4426
1B-5675	Bearing	377-7396
1B-6577	Cone-Spl Tapered	374-1839
1H-4106	Pin As-Drawbar	325-6126
1H-4478	Pin	330-9272
1H-4493	Cone-Spl Tapered	386-4939
1H-5338	Cup-Roller Brg	374-8345
1H-8382	Gear-Oil Pump Dr	226-6103
1H-8937	Drum-Cl Brake	226-7993
1J-0774	Bracket	369-9485

Part Cross-Reference

Part Numbers Beginning with 1 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
1J-2087	Bushing	421-9041
1J-2860	Cup-Spl Tapered	374-8347
1J-4757	Cone-Bearing	374-1840
1J-6744	Bearing	361-1705
1J-6746	Pin	256-4817
1J-6747	Pin	367-6078
1J-6749	Screw-Adj	256-4824
1K-8041	Bearing-Sleeve	330-9257
1L-7205	Bearing-Ball	416-2167
1L-7319	Cup-Roller Brg	380-7499
1M-0090	Gasket-Manifold	445-7701
1M-0176	Flange-Drum	223-4810
1M-1930	Cage-Pinion Brg	217-7727
1M-1947	Support As	226-6096
1M-1994	Bearing As-Rlr	399-6066
1M-3917	Shaft	386-4915
1M-4095	Bearing-Inner	417-9486
1M-4167	Shaft-Planet	219-9700
1M-5270	Pipe-Extension	367-6065
1M-6573	Cup-Roller Brg	399-4438
1M-7250	Bowl	360-2296
1M-7912	Cone-Roller Brg	380-7503
1M-8736	Cup-Roller Brg	423-7759
1M-8776	Bearing-Roller	417-4516
1M-8923	Race-Brg Outer	440-3117
1M-9029	Guard	226-0219
1M-9177	Plate-Cl Press	226-6112
1M-9444	Retainer-Spring	299-2046
1N-2936	Muffler As	298-2782
1N-2946	Extension-Exh	367-6064
1N-3113	Support-Elbow	433-8185
1N-3165	Plunger-Rlf V	373-1883
1N-3300	Shield As	374-4702
1N-3574	Block Gp-Cyl	460-8298
1N-3576	Block Gp-Cyl	279-4978
1N-3706	Pipe-Extension	434-6497
1N-3821	Bearing-Conn Rod	376-9076
1N-3822	Bearing-Conn Rod	376-9077
1N-3958	Elbow	325-6087
1N-4304	Head Gp-Cyl -A	269-8761
1N-4317	Bearing-Main	419-7253
1N-4336	Bearing-Conn Rod	419-6329
1N-4337	Bearing-Conn Rod	419-6328
1P-0005	Pump Gp-Fuel Tfr	256-4756
1P-0009	Rod As-Conn	311-9450
1P-0579	Housing As	219-9678
1P-0623	Bearing	420-3224
1P-0963	Guard As-Roller	226-0179
1P-1006	Strip-Guard	226-0245
1P-1216	Manifold-Exhaust	261-0902
1P-1367	Plunger-Valve	432-8913
1P-1721	Gear-Balance	298-2769
1P-1722	Gear-Balance	298-2770
1P-1897	Gear-Final Drive	215-1670
1P-1943	Gear-Idler & First	446-3067
1P-2187	Pump Gp-Gr 1 Bsc	299-2044
1P-2636	Cup-Roller Brg	396-4147
1P-2662	Cone-Roller Brg	374-1851
1P-2694	Cone-Rlr Brg	374-1841
1P-2695	Cup-Rlr Brg	374-8344
1P-2696	Cone-Bearing	374-1834
1P-3318	Strip	385-7206
1P-3934	Cup-Roller Brg	420-6535
1P-3935	Cone-Roller Brg	377-7397
1P-3958	Bearing-Needle	434-6114
1P-4110	Disc-Friction	433-9858
1P-4145	Valve Gp-Press	247-4436
1P-4147	Bearing-Needle	417-4507
1P-4231	Pump Gp-Gear	226-0156
1P-4303	Head As-Cylinder	242-3434
1P-4693	Cup-Rlr Bearing	377-7398
1P-4694	Cone-Roller Brg	380-7504
1P-4695	Cup-Rlr Bearing	374-1842
1P-4696	Cone-Rlr Bearing	374-1843
1P-5480	Cover As.-End	299-1998
1P-6400	Plunger As-Pump	383-1568
1P-6752	Pump Gp-Gr 1 Bsc	226-0161
1P-7115	Mount As	418-1936
1P-7125	Governor As	383-3672
1P-7295	Shaft-Acc Drive	431-5261
1P-7522	Yoke As	382-6893
1P-7590	Support As-Fr	213-4400
1P-7834	Cup-Bearing	380-7500
1P-7835	Cone-Bearing	377-7399
1P-7895	Cone-Roller Brg	396-4145
1P-7936	Spider As-Fan	383-3673
1P-8554	Coupling-Exhaust	325-6052
1P-8835	Shaft As	215-1672
1P-9593	Cone-Rlr Brg	377-7400
1P-9594	Bearing-Cup	377-7401
1P-9945	Bracket As-Fan	296-1344
1P-9989	Pipe-Head Outlet	363-7453
1R-6322	Cylinder	384-3463
1S-0057	Plate-Clutch	377-7404
1S-0876	Bolt-Spring	226-0224
1S-1888	Bracket-Lamp	297-7147
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
1S-2233	Bearing-Sleeve	379-0188
1S-2269	Sleeve	226-2720
1S-3062	Director-Water	418-9572
1S-3743	Bearing-Ball	384-4786
1S-3926	Manifold-Exhaust	430-7622
1S-5315	Cap As-Brace Brg	226-4848
1S-5331	Cylinder-Adj	226-0214
1S-6422	Pilot As-Spring	226-4849
1S-7056	Bearing-Ball	422-6483
1S-7057	Gasket	420-6384
1S-8607	Baffle	380-7540
1S-8734	Bracket-Roller	226-0212
1S-8754	Joint Gp-Univ	308-9873
1S-8764	Ring-Fly Clu Adj	226-8014
1S-9110	Bearing-Needle	420-2497
1S-9209	Shaft-Tightener	374-6499
1S-9670	Univ Jt As	443-2017
1T-0020	Wheel-Turbine	297-4862
1T-0022	Wheel-Impeller	430-8040
1T-0043	Bearing-Ball	390-5294
1T-0051	Wheel-Impeller	388-6582
1T-0079	Wheel-Turbine	382-6894
1T-0210	Bearing-Ball	417-4498
1T-0221	Wheel-Turbine	390-5268
1T-0224	Carrier-Ring	239-7928
1T-0231	Retainer-Bearing	319-3471
1T-0237	Flange As-Output	239-7929
1T-0256	Gear-Pump Drive	239-7930

Part Numbers Beginning with 1 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
1T-0278	Bearing-Sleeve	394-0213
1T-0299	Cup-Roller Brg	422-6494
1T-0334	Bearing-Ball	380-1476
1T-0364	Flange-Joint	388-6567
1T-0365	Flange-Joint	434-1861
1T-0406	Wheel-Impeller	384-3854
1T-0421	Flange As-Output	295-5442
1T-0436	Gear-Pump Drive	247-3367
1T-0437	Housing-Rotating	295-5685
1T-0438	Retainer-Bearing	295-0410
1T-0441	Bearing-Ball	449-4738
1T-0443	Carrier As-Guide	247-3368
1T-0447	Carrier-Ring	295-0409
1T-0521	Retainer-Bearing	325-6180
1T-0555	Carrier-Gde Whl	384-3853
1T-0576	Bearing-Sleeve	379-0186
1T-0589	Cup-Roller Brg	386-4942
1T-0595	Carrier-Wheel	239-7939
1T-0610	Bearing-Ball	396-4136
1T-0611	Converter As-Tor	235-1804
1T-0633	Impeller-Conv	390-5266
1T-0655	Bearing-Thrust	377-7409
1T-0660	Impeller-Conv	388-6595
1T-0679	Roller-Freewheel	384-4797
1T-0686	Race-Brg Thrust	380-7464
1T-0699	Impeller-Conv	235-1808
1T-0737	Race-Spl Thrust	384-4798
1T-0762	Race-Thrust	384-4803
1T-0766	Bearing-Sleeve	383-2107
1T-0767	Bearing-Sleeve	383-2108
1T-0781	Impeller	380-7488
1T-0782	Turbine-Conv	377-7410
1T-0787	Plate-Freewheel	430-8131
1T-0807	Race-Thrust Brg	453-3651
1T-0861	Impeller-Conv	421-1715
1T-0876	Hub-Turbine	397-5058
1T-0902	Bearing-Sleeve	389-6326
1T-0930	Tc Gp-Basic	388-6566
1T-0969	Bearing-Sleeve	453-6497
1T-1016	Carrier-Guide	388-6584
1T-1033	Plate-Cl Backing	431-4136
1T-1051	Impeller-Conv	388-6598
1T-1053	Turbine As-Conv	377-7412
1T-1078	Bearing-Thrust	384-4802
1T-1079	Hub-Impeller	416-2152
1T-1278	Bearing-Thrust	370-8370
1T-1281	Retainer-Brg	390-0924
1T-1282	Race-Brg Thrust	373-1755
1T-1331	Stator-Converter	229-8237
1T-1333	Carrier As	445-9250
1T-1348	Support As-Carr	419-4049
1T-1386	Yoke-Univ Joint	325-6239
1T-1389	Carrier-Bearing	247-4124
1T-1399	Impeller-Conv	391-9829
1T-1401	Ring-Seal	384-4799
1T-1428	Retainer-Brg	300-2587
1T-1446	Impeller-Conv	377-7413
1T-1494	Impeller-Conv	388-6564
1T-1534	Carrier-Ring	386-4916
1T-1562	Wheel As-Guide	388-6580
1T-1607	Spider As	434-9637
1T-1647	Impeller-Conv	377-7415
1T-1691	Impeller-Conv	297-4863
1T-1701	Carrier-Stator	384-3853
1T-1790	Carrier As	296-1347
1T-1804	Stator As-Conv	388-0572
1T-1805	Turbine-Conv	380-1490
1T-1880	Carrier-Ring	295-0408
1T-1940	Housing As	396-0646
1T-1981	Stator As-Conv	377-7416
1T-1987	Housing-Rotating	297-4864
1T-1988	Shaft-Output	428-6656
1T-1991	Stator As-Conv	380-1482
1T-1993	Wheel-Turbine	235-0920
1T-2041	Carrier As	396-9893
1T-2048	Carrier As-Stat	472-8038
1T-2050	Carrier As-Stat	325-6040
1T-2052	Stator As.	295-5683
1T-2069	Carrier-Bearing	439-4543
1T-2077	Retainer-Bearing	380-7408
1U-0145	Bearing-Thrust	417-9482
1U-0408	Cyl Gp-0165 1549	415-1898
1U-0725	Retainer	314-8707
1U-0738	Bearing-Sleeve	333-4942
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1U-1625	Pump Gp-Gr A	421-1555
1U-1997	Rod As	419-4652
1U-2135	Cyl Gp-0121 0955	395-1304
1U-2665	Cartridge Gp	422-8108
1U-2666	Cartridge Gp	422-8115
1U-2667	Cartridge Gp	422-8116
1U-2668	Cartridge Gp	422-8117
1U-2669	Cartridge Gp	422-8118
1U-2738	Piston Assembly	367-6074
1U-3522	Rod As	390-5281
1U-3953	Cartridge Gp	426-0024
1U-3969	Pump Gp-Vn Bsc-B	422-8150
1U-3998	Seal As	472-8005
1U-4103	Trunnion	295-5680
1U-4661	Lever Gp	396-7267
1U-4851	Cyl Gp-0102 1360	422-4560
1V-0188	Disc	386-4943
1V-1080	Housing-Brg Spt	260-0775
1V-3995	Pin	319-3449
1V-4838	Link As-Spring	308-9874
1V-5724	Diff Gp -A	260-0776
1V-5736	Bearing-Sleeve	379-0187
1V-6342	Gear As	308-9847
1V-6913	Tube As	435-4793
1V-6934	Bearing-Sleeve	364-5265
1V-8240	Bearing-Sleeve	308-9807
1V-8241	Bearing-Sleeve	308-9808
1V-8242	Bearing-Sleeve	308-9809
1V-8280	Plate	382-6889
1V-8439	Pin As	308-9881
1V-8604	Gear-Ring	308-9853
1V-8606	Gear-Sun	308-9860
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8953	Pin	308-9892
1V-8954	Pin As	361-1696
1V-9143	Bearing-Sleeve	308-9810
1V-9148	Bearing-Sleeve	308-9811
1V-9208	Link As-Rear	299-2020
1W-0156	Core As-Oclr	416-5525
1W-0311	Bearing-Main	376-9078

Part Cross-Reference

Part Numbers Beginning with 1 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
1W-0312	Bearing-Main	376-9079
1W-0370	Muffler As.	360-7869
1W-0458	Shield As-Turbo	367-6082
1W-0466	Shield As-Turbo	369-9495
1W-0568	Pump Gp-F Tfr	377-5859
1W-0777	Muffler As	247-2662
1W-1064	Gear-Flywheel	374-4703
1W-1219	Trunnion As	314-8724
1W-1661	Bearing-Main	376-9080
1W-1662	Bearing-Main	382-6900
1W-1669	Piston	325-6158
1W-1695	Pump Gp-F Tfr	279-4980
1W-1698	Housing-Tfr Pump	296-1356
1W-1700	Pump Gp-F Tfr	377-5846
1W-1766	Muffler As.	298-2783
1W-1822	Valve-Exhaust	443-1205
1W-1877	Gear As-Idler	426-0027
1W-2489	Muffler As	360-7870
1W-2491	Muffler As-Eject	360-7871
1W-2572	Muffler As.	247-2663
1W-2870	Shaft As-Balance	314-8715
1W-2871	Shaft As-Balance	314-8716
1W-3062	Retainer As	311-9445
1W-3397	Plate	391-9810
1W-3900	Gasket	472-8006
1W-4369	Pulley-Alt	296-1340
1W-4402	Gear-Camshaft	279-4981
1W-4407	Hub-Fan Pulley	296-1358
1W-4506	Adapter-Seal	372-7515
1W-4623	Muffler As	360-9622
1W-4737	Gear-Cshft	295-5688
1W-4738	Bearing-Sleeve	325-6020
1W-4740	Gear As.-Drive	295-5689
1W-4746	Retainer-Gear	295-5690
1W-5009	Crankshaft As	398-2969
1W-5036	Bracket As-Fan	425-1210
1W-5105	Ring Gp-Piston	311-9446
1W-5300	Rotocoil As	443-2659
1W-5910	Tappet As-Guide&	383-1569
1W-5912	Tappet As-Guide&	325-6223
1W-5920	Bearing-Camshaft	421-1558
1W-6005	Bearing-Sleeve	417-4521
1W-6183	Shield As-Manf	367-6083
1W-6184	Shield As	416-5524
1W-6185	Shield As	374-4704
1W-6186	Shield As	374-4705
1W-6356	Gasket	438-1795
1W-6440	Gasket-Cyl Head	449-9548
1W-6473	Compressor Gp -B	448-9150
1W-6541	Plunger As	325-6173
1W-6810	Pipe-Outlet	472-8036
1W-6987	Valve As-Check	420-6221
1W-7035	Kit-Pump (Rbd)	421-1553
1W-7072	Rebuild Kt-Pump	428-6657
1W-7073	Rebuild Kt-Pump	383-3677
1W-7074	Kit-Rebuild-Pump	419-4712
1W-7080	Kit-Pump (Rbd)	392-4515
1W-7082	Rebuild Kt-Pump	383-3681
1W-7238	Shaft As-Pump Dr	379-0164
1W-7239	Shaft As-Idler	379-0163
1W-7940	Spider As-Fan	295-5443
1W-8539	Bearing-Conn Rod	419-7251
1W-8606	Valve-Inlet	443-1204
1W-9171	Bonnet-Valve	374-4707
1W-9191	Line As-Fuel Inj	311-9403
1W-9201	Line As-Fuel Inj	311-9411
1W-9202	Line As-Fuel Inj	311-9412
1W-9203	Line As-Fuel Inj	311-9413
1W-9204	Line As-Fuel Inj	311-9414
1W-9205	Line As-Fuel Inj	311-9415
1W-9206	Line As-Fuel Inj	311-9416
1W-9207	Line As-Fuel Inj	311-9417
1W-9208	Line As-Fuel Inj	311-9418
1W-9209	Line As-Fuel Inj	311-9419
1W-9210	Line As-Fuel Inj	311-9420
1W-9211	Line As-Fuel Inj	311-9421
1W-9212	Line As-Fuel Inj	311-9422
1W-9229	Muffler As	302-4282
1W-9302	Gear-Crankshaft	386-3059
1W-9490	Pulley-Alt	394-0885
1W-9519	Muffler As	397-5043
1W-9771	Crankshaft As	368-5913
1W-9812	Gear-Crankshaft	380-1513
1W-9832	Muffler As	416-5493

Part Numbers Beginning with 2

Original Part Number	Part Name	Classic Part Number
200-3199	Muffler As-Eject	396-1565
200-3200	Muffler As-Eject	418-9586
200-7929	Housing	416-5489
201-2078	Bar As-Equalizer	418-1946
201-4802	Sleeve	419-2309
201-5243	Kit-Gasket(F)	437-2019
202-2380	Shaft As.-Input	399-4432
202-3572	Shaft As-Drive	426-0037
203-9726	Gasket Kit	434-7282
204-4458	Gasket Kit - Acl	437-8151
204-4462	Gasket Kit - Sch	437-2005
205-1098	Gasket Kit	434-7283
205-6642	Muffler As	480-8273
206-0502	Cylinder As.	423-7866
206-0503	Cyl Gp-0114-0695	426-0038
206-5794	Gear-Sun	394-8233
206-6405	Bearing-Spl Ball	420-2503
207-1332	Bellows As	444-0569
207-2015	Gasket Kit	447-0828
207-2016	Gasket Kit	434-7284
207-8176	Cover-Xmsn	420-3218
208-0421	Muffler As	360-9624
208-5026	Pin	325-6133

Part Numbers Beginning with 2 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
208-6161	Gasket Kit - F	437-8150
208-6163	Kit-Gasket-Sch	437-2004
208-6165	Kit-Gasket-Mch	437-8149
208-7534	Case As-Diff	388-6590
208-8795	Retainer	430-5355
208-8796	Retainer	417-9489
208-8797	Retainer	432-8908
209-6188	Plate	393-1053
209-9886	Tie Rod As	396-9901
210-2154	Kit-Gasket-Trans	394-8232
210-2155	Kit-Gasket-Trans	434-7285
210-7305	Shaft	396-9952
210-7443	Gasket Kit - Sch	437-8125
211-0592	Bearing - Main	419-6368
212-4893	Bearing-Thrust	419-6372
213-1304	Kit-Dt Gasket	394-8231
213-1305	Kit-Dt Gasket	394-8230
213-1364	Bearing-Sleeve	330-9255
213-1365	Bearing-Sleeve	330-9256
213-1370	Bearing-Sleeve	380-7370
213-3193	Rod As-Conn	379-8870
213-3294	Gage As-O Level	398-2930
213-6732	Muffler As-Lh	363-7099
213-6733	Muffler As-Rh	363-7098
213-8467	Kit-Gasket(Wlg)	438-0143
213-8621	Kit-Gasket-Wp	437-2003
213-8734	Cover-Transfer	420-3217
214-6045	Bellows As	435-4846
215-7140	Kit-Gasket(Mch)	437-2002
215-7144	Kit-Gasket(Sch)	437-8148
215-9365	Bearing	422-6917
216-4499	Kit-Gasket-Sch	437-8147
216-4530	Kit-Gasket-Mch	437-8146
216-4592	Gasket Kit - Ocl	437-8145
216-4781	Gasket Kit	437-8144
216-5359	Kit-Dt Gasket	451-1504
216-5361	Kit - Gasket	383-2109
216-5582	Bearing-Sleeve	390-0914
216-7957	U-Joint	367-6069
217-0578	Bearing-Rod	419-4665
217-0586	Bearing-Rod	419-7266
217-7884	Gasket Kit - Wp	437-8143
217-8938	Tightening-Belt	419-4735
218-4389	Kit-Gasket(Sch)	437-8124
219-3501	Kit - Gasket	437-8129
219-6544	Kit-Gasket-Acl	437-2001
219-6556	Kit-Gasket(F)	437-8141
219-6560	Kit-Gasket(F)	437-8153
219-6578	Kit-Gasket-Mch	437-8139
219-6610	Kit - Gasket	437-8138
219-7628	Kit-Gasket-Mch	437-8137
219-7629	Kit-Gasket-Sch	437-8136
219-7630	Kit - Gasket	437-2000
219-7975	Kit-Gasket(Sch)	437-1999
219-9693	Shaft-Classic	216-7876
219-9693	Shaft-Classic	217-7738
220-3779	Kit-Gasket(F)	437-1998
220-4554	Kit-Dt Gasket	417-9469
220-4556	Kit - Gasket	391-9878
221-0859	Kit-Gasket-T	437-8135
221-3371	Kit-Gasket-Mch	437-2031
221-3372	Kit-Gasket-Sch	437-2006
221-6946	Kit-Dt Gasket	394-9208
221-6947	Kit - Gasket	394-9209
221-6949	Kit-Dt Gasket	419-8663
221-6985	Retainer	399-4406
221-9356	Flywheel As	435-2575
221-9755	Gear-Planet	390-5293
222-0458	Muffler As	393-0929
222-0862	Housing	419-1860
222-1177	Kit-Gasket-Sch	437-2008
222-7974	Kit - Gasket	437-2044
222-7987	Kit - Gasket	437-2043
222-8662	Kit-Gasket(F)	437-8134
222-9154	Kit - Gasket	437-8133
223-1101	Kit-Dt Gasket	451-1505
223-1102	Kit-Gasket-F	437-8132
223-3095	Gauge As	360-2295
223-3343	Kit-Gasket-Acl	437-8131
223-3344	Kit-Gasket(Ocl)	437-2040
223-3345	Kit-Gasket-Sch	437-8130
223-7811	Kit-Gasket(Sch)	437-8636
223-8228	Kit-Gasket(Sch)	437-8142
224-3973	Kit-Gasket-Rs	437-8123
224-4323	Kit-Gasket-Rs	393-3627
224-6638	Bearing-Rod	419-6371
225-4529	Cyl Gp-0160 1356	393-3658
226-0930	Gear-Transfer	394-0888
226-2018	Kit-Gasket-Acl	393-0921
226-8202	Seal-Wiper	472-8024
227-6228	Cage	360-2343
227-6789	Bearing-Sleeve	360-2322
228-0416	Seal As	430-5356
228-0419	Seal As	443-3571
228-5621	Bearing-Sleeve	360-2323
228-7325	Ster Cl Kit-Cla	230-7119
229-1490	Sleeve-Injector	393-3659
229-2949	Rod As.- Track	347-0486
229-2950	Rod As.- Track	347-0487
229-5153	Bearing-Thrust	419-6370
229-5154	Bearing-Thrust	419-6369
230-7112	Ster Cl Kit-Cla	216-7840
230-7114	Ster Cl Kit-Cla	219-9690
230-7116	Ster Cl Kit-Cla	229-8227
230-7117	Ster Cl Kit-Cla	219-9696
231-0649	Kit-Gasket (Sch)	437-8673
231-1591	Muffler As.	360-9625
231-1937	Kit-Strg Cl-Cla	226-6101
232-1841	Kit-Gasket (Fs)	387-2922
232-2600	Kit-Gasket-Fs	437-8672
232-2672	Kit-Gasket-Fs	393-0922
232-2922	Kit-Gasket-Rs	437-8671
232-3233	Bearing-Main	376-9085
232-3675	Kit-Gasket-Rs	437-8670
232-3679	Kit-Gasket (Rs)	437-2039
232-4504	Kit-Gasket-Fs	437-2038
232-4649	Kit-Gasket-Rs	437-8669
232-4658	Kit-Gasket-Fs	437-2037
232-6148	Kit-Gasket(Rs)	437-2036
232-6167	Kit-Gasket(Fs)	437-2035
232-6173	Kit-Gasket-Fs	393-0923
232-6574	Kit-Gasket-Rs	437-2034
232-6599	Kit-Gasket (Mch)	437-2033
232-6642	Kit-Gasket (Sch)	437-2020
233-5001	Strip	393-3683
233-6728	Kit-Gasket-Fs	437-2032
233-6984	Kit-Gasket(Fs)	437-2045
233-7083	Kit-Gasket-Fs	387-2919
233-8668	Kit-Gasket-Mch	437-2030
233-8669	Kit-Gasket-Mch	393-1038
233-8681	Kit-Gasket-Mch	393-0920
233-8683	Kit-Gasket-Mch	393-1039
233-9198	Kit-Gasket-Sch	437-2029
233-9200	Kit-Gasket-Sch	393-0927
233-9203	Kit-Gasket-Sch	437-2028
233-9204	Kit-Seal-H.Cyl-1	472-8025
233-9245	Kit-Gasket-Sch	437-2027
233-9456	Kit-Gasket-Sch	422-7510

Part Cross-Reference

Part Numbers Beginning with 2 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
233-9464	Kit-Gasket(Sch)	393-0925
233-9466	Kit-Gasket-Sch	437-2026
233-9473	Kit-Gasket-Sch	437-2025
233-9474	Kit-Gasket (Sch)	437-2024
233-9480	Kit-Gasket-Sch	437-2023
233-9748	Disc-Friction	417-9502
234-1628	Kit-Gasket-Rs	437-2022
234-1630	Kit-Gasket(Rs)	393-1040
234-1874	Kit-Gasket-Fs	437-8668
234-1900	Kit-Gasket(Fs)	437-8667
234-1914	Kit-Gasket(Fs)	437-2021
234-1929	Kit-Gasket-Rs	393-1022
234-1983	Kit-Gasket-Fs	393-0924
234-1985	Kit-Gasket-Fs	437-8666
234-7988	Kit-Gasket-Sch	387-2925
234-7989	Kit-Gasket-Sch	437-8122
234-7991	Kit-Gasket-Mch	437-8121
234-7994	Kit-Gasket-Sch	437-8120
234-7996	Kit-Gasket-Sch	437-8665
234-7998	Kit-Gasket-Mch	437-8640
234-7999	Kit-Gasket-Sch	437-8119
234-8001	Kit-Gasket-Mch	437-8118
234-8002	Kit-Gasket-Sch	386-3817
234-8009	Kit-Gasket-Sch	382-5056
234-8011	Kit-Gasket-Sch	437-8664
234-8013	Kit-Gasket-Sch	437-8650
234-8014	Kit-Gasket-Sch	437-8662
234-8015	Kit-Gasket-Sch	437-8674
234-8016	Kit-Gasket-Sch	393-0919
234-8019	Kit-Gasket-Sch	437-8639
234-8020	Kit-Gasket-Sch	437-8660
235-0912	Tc Kit-Cla	235-0920
235-0913	Tc Kit-Cla	235-0920
235-1802	Tc Kit-Cla	235-0920
235-1802	Tc Kit-Cla	235-1808
235-1803	Tc Kit-Cla	235-0920
235-1806	Tc Kit-Cla	229-8237
235-9832	Head	419-4658
236-4413	Pump Gp-Water -B	434-6110
236-6268	Bearing-Sleeve	453-6499
236-6269	Bearing-Sleeve	453-6500
236-6270	Bearing-Sleeve	425-6436
236-6271	Bearing-Sleeve	360-2324
236-6277	Bearing-Sleeve	419-0884
236-7724	Retainer	299-2048
236-8183	Bearing-Sleeve	453-6501
236-8675	Disc-Friction	428-7202
236-8883	Kit-Gasket-Ocl	437-8659
237-0944	Bearing-Sleeve	394-0194
237-2252	Bearing-Sleeve	347-0474
237-2859	Bearing-Rlr	368-0125
237-6367	Kit - Gasket-Sch	437-8625
237-9849	Cage-Bearing	443-1201
238-0293	Adapter-Jacket	424-0742
239-1497	Trunnion	394-0197
239-4290	Kit-Gasket-Sch	435-2574
239-4378	Support	480-8274
239-4390	Recoil Gp-Adj&-A	480-8275
239-9956	Brake Disc	347-0485
240-2912	Bearing-Sleeve	418-1969
240-2913	Bearing-Sleeve	360-2325
240-2915	Bearing-Sleeve	360-2326
240-2916	Bearing-Sleeve	360-2327
241-1397	Kit-Dt Gasket	434-7286
241-1399	Kit-Dt Gasket	394-9211
241-3381	Valve Kit-Cla	247-6892
241-3381	Valve Kit-Cla	247-6893
242-9834	Kit-Gasket-Mch	387-2923
242-9847	Kit-Gasket-Mch	438-0129
242-9857	Kit-Gasket-Mch	437-8637
243-0723	Kit-Dt Gasket	391-9886
243-0725	Kit-Dt Gasket	396-9953
243-0726	Kit-Dt Gasket	394-9210
243-0727	Kit-Dt Gasket	451-1506
243-0728	Kit-Dt Gasket	394-9206
243-0729	Kit-Dt Gasket	434-7287
243-0731	Kit-Dt Gasket	451-1507
243-4690	Kit-Gasket (Ocl)	437-8658
243-4780	Kit-Gasket(Cl)	437-8657
243-6718	Kit-Brg(Main)	469-1690
244-1400	Kit-Gasket-Sch	437-8656
244-8504	Pin As	426-0032
246-3130	Shaft-Water Pump	392-4508
246-5916	Kit-Seal-H.Cyl-1	472-8026
246-8883	Rod As	425-9364
247-2670	Muffler-Classic	247-2675
247-7143	Yoke	451-9025
247-8853	Cyl Gp-0150 1156	399-8583
247-8856	Rod As	395-1317
248-2987	Guide	419-4709
250-1984	Trunnion	319-3476
250-2398	Pin As	382-8047
250-2402	Pin As	360-2351
250-6555	Kit-Liner-Cla	250-6563
250-6556	Kit-Liner-Cla	250-6564
250-6557	Liner Kit-Cla	295-6438
250-6558	Liner Kit-Cla	295-6438
251-1224	Kit-Gasket-Mch	437-8655
251-7319	Bearing-Sleeve	425-6450
252-0168	Link Assembly	433-9210
252-1152	Muffler As.	395-1307
252-5650	Rim As	397-5067
252-7038	Kit-Dt Bearing	464-9065
252-7955	Kit-Gasket(Cl)	437-8654
253-1752	Plate-Thrust	379-0170
254-5676	Kit-Gasket-Sch	437-8649
255-2899	Pipe As-Tail	301-5246
255-6863	Gasket	450-5024
256-9653	Flywheel As.	425-3444
257-0424	Shaft	421-8170
258-0768	Bearing Sleeve	394-0201
258-2303	Bearing-Sleeve	307-1524
258-2305	Bearing-Sleeve	325-6029
258-2308	Bearing-Sleeve	325-6019
260-7799	Pinion-Circ Dr	367-6094
262-4335	Kit - Dt Gasket	434-7288
262-4338	Kit - Dt Gasket	451-1508
262-4339	Kit-Dt Gasket	451-1509
262-5009	Kit-Gasket(Sch)	437-8635
262-5080	Kit-Gasket-Sch	437-8634
262-7044	Bearing	418-1948
262-7133	Kit-Gasket(Sch)	437-8633
264-2769	Bearing As.-Spl	419-8664
264-6898	Kit-Gasket-Sch	382-5069
265-5287	Ring-Seal	472-8028
265-9183	Kit-Gasket(Sch)	437-8632
265-9185	Kit-Gasket(Ocl)	437-8631
265-9186	Kit-Gasket(Sch)	437-8630
266-2540	Kit-Gasket(Sch)	437-8629
266-4561	Kit-Gasket-Cl	437-8628
266-5907	Kit-Gasket-Cl	438-0155
266-6621	Kit-Gasket(Cl)	438-0154
268-2932	Kit-Gasket-Sch	438-0153
268-5569	Pin As	415-1905
269-0381	Cyl Gp-100 254 X	393-3660
269-6989	Pin	425-2559

Part Numbers Beginning with 2 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
270-4353	Kit-Liner-Cla	270-4351
270-4353	Kit-Liner-Cla	270-4356
270-4353	Kit-Liner-Cla	270-4357
270-4353	Kit-Liner-Cla	295-6438
271-5658	Crankshaft As.	368-5912
272-1956	Gasket	419-4710
272-4673	Muffler	301-7974
273-3160	Ballstud	396-9954
274-4274	Bearing-Sleeve	391-9896
274-4553	Disc-Clutch	416-2153
275-0120	Pin As	419-7245
275-2316	Kit-Dt Bearing	464-9066
277-7089	Shaft As	380-7578
278-0223	Housing-Brake	456-0554
278-1365	Arm As-Ui Rkr	433-7507
278-1972	Cylinder As.	394-9813
278-8781	Kit-Gasket(Sch)	437-8653
281-2813	Kit-Gasket-Sch	387-2921
282-2065	Kit-Gasket-T	438-0184
282-4348	Kit-Dt Gasket	419-8665
282-6648	Kit-Dt Gasket	396-9955
283-5666	Gasket-Cyl Head	388-6565
283-6443	Kit-Gasket-T	437-8652
286-2494	Kit-Gasket-Sch	387-2920
286-8903	Cyl Gp-Basic	425-9363
287-8465	Kit-Gasket-Fs	437-8627
288-2551	Kit-Dt Gasket	396-9958
288-2552	Kit-Gasket-Txg	391-9884
288-6375	Kit-Gasket(Fs)	437-8104
289-2935	Seal As-Buffer	472-8028
289-2946	Seal-U-Cup	472-8030
289-4093	Kit-Gasket-Sch	438-0152
289-4884	Kit-Gasket-Mch	437-8651
289-5160	Kit-Gasket-Sch	437-8663
289-5181	Kit-Gasket-Mch	438-0151
289-6232	Kit-Gasket(Sch)	437-8661
289-7886	Rod As	422-7246
289-9183	Kit-Gasket-Sch	438-0150
290-0187	Kit-Gasket-Sch	437-8116
290-2060	Kit-Gasket-Sch	438-0149
291-9117	Kit-Gasket (Sch)	438-0148
292-2500	Kit-Gasket-Mch	438-0147
292-5516	Kit-Dt Gasket	391-9885
293-1009	Kit-Gasket(Mch)	438-0146
293-3018	Kit-Gasket(Sch)	438-0145
293-3041	Kit-Gasket-Mch	438-0144
293-6012	Kit-Gasket-Mch	438-0128
293-6013	Kit-Gasket-Sch	438-0142
296-1359	Line As-Cla	279-4988
296-1360	Line As-Cla	279-4989
297-1742	Kit-Gasket-Sch	438-0156
297-6870	Kit-Dt Gasket	451-1510
297-6872	Kit-Dt Gasket	394-8228
297-7222	Pin As.-Cla	361-1699
297-7245	Shaft-Cla	215-1694
2A-4429	Lock-Retainer	379-0174
2A-4576	Cup-Roller Brg	386-4944
2A-4577	Cone-Roller Brg	374-1836
2A-7089	Bearing-Sleeve	380-7382
2B-0941	Spacer	418-1955
2B-8824	Drum	216-7817
2D-1345	Drum-Brake	228-9430
2D-2566	Ring-Lock	416-2123
2D-2654	Ring-Lock	380-1488
2D-2978	Spider & Brg As	399-4424
2D-3188	Yoke	365-8822
2D-5383	Gasket	445-7709
2D-5658	Bearing-Ball	301-4628
2D-5961	Pin-Axle Pivot	228-9438
2D-6341	Pin	330-9273
2D-6421	Bearing-Outer	417-4510
2D-6511	Cup-Roller Brg	377-7417
2D-6516	Bearing As-Rlr	435-2572
2D-9130	Washer-Thrust	308-9943
2D-9191	Cone-Roller Brg	374-1837
2D-9453	Cone-Roller Brg	380-7508
2D-9454	Cup-Roller Brg	415-1914
2D-9455	Cone-Roller Brg	415-1915
2D-9457	Cone-Spl Tapered	377-7418
2D-9459	Cage-Bearing	431-5257
2F-0025	Tube	325-6233
2F-5721	Bearing-Ball	311-9354
2F-7576	Shaft-Sprocket	226-6071
2F-8509	Cone-Roller Brg	399-4434
2G-1034	Valve-Safety	380-7555
2G-1085	Housing As-Diff	393-0928
2G-2411	Ballstud As	387-2899
2G-2858	Cap-Pivot	243-0345
2G-4011	Collar	330-9269
2G-5768	Gear-Bevel	388-0646
2G-5838	Shaft	425-6452
2G-6157	Pin	282-6550
2G-6285	Valve Kt	383-1570
2G-6336	Hub-Brake	282-6551
2G-6339	Hub-Brake	430-7621
2G-6375	Shaft-Drive	275-5282
2G-6377	Sprocket	275-5286
2G-7309	Shaft	393-3682
2G-7387	Bearing-Sleeve	330-9258
2G-7388	Bearing-Sleeve	330-9259
2G-7464	Insert-Bolt	386-4918
2G-7759	Cage As	399-8574
2G-8083	Pin	393-3666
2G-8084	Pin	392-4531
2G-8238	Yoke As	282-6631
2G-8608	Bearing-Sleeve	385-3783
2G-8609	Pin	319-3450
2G-8610	Pin	389-6316
2G-8613	Pin	282-6553
2G-8616	Pin	282-6554
2G-8617	Pin	282-6555
2G-8620	Pin	282-6556
2G-8621	Pin	282-6557
2G-8623	Pin	393-3675
2G-8625	Pin	282-6558
2G-8628	Pin	282-6559
2G-8629	Pin	282-6560
2G-8630	Pin	389-6304
2G-8631	Bearing-Sleeve	391-9811
2G-8633	Pin	282-6561
2G-8639	Bearing-Sleeve	380-7560
2G-8735	Pin	391-1105
2G-8736	Bearing-Sleeve	299-1959
2G-8739	Retainer	389-6314
2G-8769	Pin	282-6562
2G-9097	Cap	418-1926
2G-9098	Cap	300-2573
2H-2330	Bearing-Sleeve	452-9554
2H-3069	Lifter As-Valve	387-2927
2H-3517	Bearing-Inner	417-4505
2H-3712	Bearing-Ball	392-4488
2H-4338	Plate-Pressure	226-8010
2H-4386	Plate-Ring Lock	431-5259
2H-4438	Stud-Cl Spring	431-5260
2H-4482	Collar	229-8218
2H-5046	Link-Fly Cl Cam	299-2024

Part Cross-Reference

Part Numbers Beginning with 2 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
2H-5047	Roller	385-7204
2H-5048	Link	389-6334
2H-5080	Gasket Kt-V Gr	438-0180
2H-6489	Race-Brg Outer	374-8350
2H-6936	Disc-Steer Cl Dr	380-7471
2H-9192	Bearing-Ball	394-8236
2J-1227	Retainer	440-0850
2J-1424	Rod As	469-4665
2J-2152	Cup-Roller Brg	374-1852
2J-5233	Bearing-Thrust	388-0578
2J-5596	Pin-Pivot	297-7211
2J-5649	Pin-Cylinder	256-4782
2J-8489	Bearing-Sleeve	295-5691
2K-0227	Bearing-Sleeve	384-4780
2K-0535	Nut	299-2026
2K-0714	Plate-Thrust	299-2040
2K-1386	Bearing	423-6991
2K-3632	Yoke As	297-4866
2K-4442	Bearing-Sleeve	308-9812
2K-4502	Bearing-Sleeve	299-1986
2K-4507	Bearing-Sleeve	325-6021
2K-4513	Bearing-Sleeve	308-9814
2K-5065	Cone-Roller Brg	416-2157
2K-5066	Cone-Roller Brg	396-4142
2K-5069	Cup-Roller Brg	374-8346
2K-5073	Bushing	299-1989
2K-5103	Cone-Roller Brg	380-7505
2K-5254	Bearing-Outer	377-7419
2K-5804	Rod End-Spher	416-2151
2K-6413	Pin	360-2270
2K-8753	Pinion-Bevel	253-1432
2K-9295	Bearing-Cone	422-6480
2L-4238	Mount-Flexible	385-7222
2L-4444	Bearing	419-6029
2L-5271	Bearing-Ball	371-4305
2L-6744	Plunger	426-0030
2M-0125	Cylinder-Adj	226-0215
2M-0369	Pilot-Spring R	226-0226
2M-0398	Sleeve-Bolt	226-0235
2M-1086	Plate As-Press	226-8023
2M-1149	Race-Brg Outer	418-9615
2M-1163	Plate As-Spring	383-2123
2M-2416	Guard-Idler-Lh	226-4933
2M-4208	Spacer-Timing	417-4533
2M-4209	Spacer-Timing	417-4532
2M-4668	Retainer-Guard	297-4867
2M-5685	Bearing-Needle	380-7469
2M-6960	Cage-Gear Brg	239-7971
2M-6984	Drum-Cl Driven	239-7946
2M-7116	Strip-Tapping	384-3480
2M-8340	Rod End-Yoke	374-4678
2M-8714	Cone-Roller Brg	420-2492
2M-8912	Disc-Ster Cl Dr	393-3649
2N-1572	Muffler As-Exh	361-6575
2N-1599	Gear	378-3970
2N-2139	Cone-Roller Brg	415-1911
2N-3236	Gasket-Man Exh	415-1900
2N-3253	Cup-Roller Brg	420-2493
2N-3254	Cone-Roller Brg	380-7501
2N-3386	Support-Shield	419-1863
2N-5693	Gasket-Aftclr	438-2019
2N-5842	Screw-Bridge Adj	418-1934
2N-7242	Tube As	444-5677
2P-0220	Gasket-Pump	398-2927
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2P-1005	Bearing-Sleeve	296-1342
2P-1126	Pulley-Cshft	264-5868
2P-1129	Pulley-Tightener	264-5869
2P-1131	Arm As-Tightener	430-8132
2P-1170	Shaft As-Gear	296-1367
2P-1370	Cup-Rlr Brg	384-5921
2P-1373	Cup-Rlr Brg	382-5075
2P-1374	Cone-Rlr Brg	374-1844
2P-1438	Pipe-Exh Ext	325-6157
2P-1503	Gear-First	213-8637
2P-1604	Piston-Ster Cl	219-9694
2P-1605	Pilot-Cl Piston	219-9695
2P-1738	Plate As-Oil Pan	325-6164
2P-1739	Tube As-Pump	325-6229
2P-1751	Bell As-Suction	430-7624
2P-1757	Hub-Fan Pulley	296-1357
2P-1781	Spacer-Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2407	Pulley	383-3684
2P-2519	Tube As-Inlet	325-6230
2P-2656	Line As-Fuel Inj	430-9650
2P-2697	Tube As-Air Vent	382-6901
2P-2719	Pipe-Oil Filler	363-7454
2P-2744	Muffler As.	247-2664
2P-2784	Ejector As-Exh	367-6063
2P-2788	Adapter-Fan	390-0984
2P-2811	Race-Spl Rlr Brg	417-4528
2P-2922	Gear-Transfer	219-9679
2P-2923	Gear-Transfer	219-9680
2P-3422	Gear-First Red	213-8451
2P-3423	Pinion-Sec Redc	216-3553
2P-3424	Gear-First Red	215-1675
2P-3425	Pinion-Sec Red	217-7697
2P-3598	Shaft-Output	215-1676
2P-3645	Pump Gp-Gr 2 Bsc	450-2389
2P-3669	Pinion-Bevel	215-1677
2P-3767	Tube-Disposal	377-5850
2P-3839	Crankshaft As	398-2968
2P-4363	Housing-Clutch	391-9833
2P-4364	Housing As-Cl	396-9928
2P-4370	Plate-Clutch	325-6166
2P-4404	Housing As-Cl	226-8027
2P-4426	Shaft As-Planet	384-3478
2P-4429	Shaft As-Planet	384-4828
2P-4431	Gear-Ring	394-9832
2P-4432	Gear-Ring	418-9583
2P-4433	Gear-Ring	384-4787
2P-4440	Gear	434-4386
2P-4470	Turbine-Conv	390-0910
2P-4510	Piston-Clutch	275-5293
2P-4611	Pipe-Exhaust	365-8821
2P-4698	Bearing-Sleeve	389-6318
2P-4701	Shaft As-Gear	297-7257
2P-5081	Muffler As	360-7872
2P-5608	Pipe-Extension	367-6066
2P-5609	Muffler As.	247-2665
2P-5680	Turbine-Conv	308-9942
2P-5769	Coupling	394-9812
2P-5774	Gear As-Oil Pump	428-6659
2P-5861	Housing As-Rot	430-8128
2P-6128	Pulley	264-5872
2P-6245	Shaft As-Pump	325-6197
2P-7032	Spacer-Bearing	396-4138
2P-7622	Bolt-Spring	226-4850
2P-7828	Pan-Oil	314-8691
2P-7830	Pump Gp	314-8533

Part Numbers Beginning with 2 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
2P-7984	Yoke As-Idler	226-0220
2P-8907	Spider As-Fan	330-9289
2P-8912	Elbow-Exhaust	398-2957
2P-8986	Cup-Rlr Bearing	415-1912
2P-9037	Drum-Ster Clutch	219-9696
2P-9038	Drum-Cl Driven	216-7821
2P-9313	Pump Gp-Gr 1 Bsc	418-1966
2P-9314	Disc As-Clutch	384-4791
2P-9632	Damper As	299-2004
2P-9660	Gear	226-5995
2P-9672	Cage-Pinion Brg	226-7972
2R-0524	Cone-Bearing	422-6484
2S-0479	Bearing-Cone	380-7506
2S-1273	Chamber As	319-3434
2S-1477	Holder As-Cage	226-7985
2S-2430	Thrower-Chsft O	380-7543
2S-3188	Plate	299-2041
2S-3486	Gasket Kt-V G	438-0179
2S-3803	Gear	226-6106
2S-3804	Gear-Sliding	226-6107
2S-3913	Cage-Gear Brg	217-7722
2S-3946	Gear-Final Drive	215-1678
2S-3966	Ring-Seal	297-7237
2S-4015	Plunger As-Valve	311-9438
2S-4357	Pinion-Fdr	217-7706
2S-4365	Retainer As	216-3554
2S-4900	Shaft As	384-4792
2S-5100	Valve-Ball	386-3049
2S-5551	Coupling-Exhaust	398-2934
2S-5735	Plate-Clutch	398-2964
2S-6097	Tang	375-9979
2S-6150	Cover-Pulley	428-8817
2S-6196	Shaft-Pulley	438-9541
2S-6263	Guard Gp-Spring	226-0192
2S-6264	Guard Gp-Spring	226-0193
2S-6265	Rod Gp-Recoil	226-0197
2S-6344	Gear-Final Drive	297-7173
2S-6401	Cup-Roller Brg	380-7497
2S-6739	Pulley-Tightener	298-2794
2S-7062	Shaft-Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7264	Pump As-Fuel Inj	395-1318
2S-7527	Flange-Drum	213-8163
2S-7596	Retainer	215-1679
2S-7603	Drum-Steer Cl Dr	213-6951
2S-7873	Pump Gp	226-0162
2S-7917	Gear-Pump Dr	247-4119
2S-7931	Bearing-Sleeve	387-2904
2S-8884	Ring-Piston	465-8995
2S-8961	Pulley-Tightener	264-5875
2T-0374	Pin	418-1952
2T-1581	Bearing-Sleeve	399-6051
2T-3885	Housing	448-4967
2T-3890	Shaft As-Stub	425-9376
2V-0447	Bearing-Sleeve	380-7559
2V-0705	Pin As	241-2524
2V-0706	Bearing-Sleeve	388-0637
2V-0707	Bearing-Sleeve	360-2328
2V-1074	Shaft-Planet	364-5262
2V-1256	Bearing-Sleeve	422-9529
2V-1722	Pin As	241-2525
2V-3687	Gear-Diff Bevel	308-9849
2V-4148	Shaft-Planet	388-6579
2V-4331	Collar	387-2910
2V-4374	Joint Gp-Slip	308-9872
2V-4405	Housing-Brg Spt	396-0648
2V-4700	Pin	308-9894
2V-4734	Gear-Diff Ring	417-9474
2V-5608	Shaft-Pin(Bevel)	446-3056
2V-5656	Ring-Snap	374-1454
2V-5709	Shaft-Axle	299-2056
2V-5714	Gear-Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier-Planet	297-7164
2V-6129	Cover	390-5295
2V-6220	Shaft-Planet	221-9073
2V-6221	Shaft-Planet	221-9108
2V-6327	Support As-Front	391-9832
2V-6371	Cover As	398-8338
2V-7092	Plate-Retainer	374-6510
2V-7170	Yoke	308-9948
2V-7198	Pilot As-Rec Spg	302-2709
2V-7990	Tube As	373-5382
2W-0994	Body As-Preclnr	367-6084
2W-1223	Pump Gp-Water	385-7197
2W-1225	Pump Gp-Water	380-7532
2W-1707	Ring-Piston Top	270-4356
2W-1708	Ring-Piston	270-4357
2W-1748	Elbow-Exhaust	447-0821
2W-2621	Valve-Inlet	247-6892
2W-3391	Body As-F Inj V	383-3687
2W-3428	Muffler As	298-2784
2W-3597	Muffler As	397-5044
2W-3875	Gear-Oil Pump Dr	399-8548
2W-4087	Gear As-Idler	418-9582
2W-4437	Gear As-Idler	388-0556
2W-5240	Pipe-Pump Outlet	376-9055
2W-5536	Core As-Radiator	380-7554
2W-5539	Core As-Rad	374-7492
2W-5540	Core As-Radiator	363-7452
2W-6030	Tube	314-8729
2W-6250	Support	422-7897
2W-6280	Bracket As-Fan	431-5271
2W-6632	Core As-Rad	391-1096
2W-6757	Trunnion As	295-5678
2W-6965	Coupling	416-5490
2W-6967	Elbow As	420-6385
2W-7176	Shaft-Fp & Gov Dr	432-8906
2W-7177	Shaft-Fp & Gov Dr	433-9215
2W-7213	Bearing-Sleeve	419-4667
2W-7255	Shaft-Water Pump	325-6203
2W-7455	Gear As	396-9957
2W-7458	Crankshaft As	242-3439
2W-7590	Cooler As-Oil	378-3971
2W-7610	Gear-Hyd Pump Dr	418-1940
2W-7614	Gear-Crankshaft	425-7752
2W-7678	Gear-Water Pump	325-6088
2W-7774	Ejector As-Exh	393-0914
2W-7933	Core As-O Clr	374-4708
2W-7980	Camshaft As	378-3972
2W-8038	Gear-Camshaft	425-7751
2W-8271	Arm As-Rocker	432-8912
2W-8437	Muffler As	385-7198
2W-8493	Pulley-Fan	430-5361
2W-8494	Pulley-Alt	295-5692
2W-9094	Adapter-Exhaust	299-2534
2W-9978	Core As-Oclr	279-4983

Part Cross-Reference

Part Numbers Beginning with 3

Original Part Number	Part Name	Classic Part Number
300-9500	Kit-Gasket-Sch	387-2914
305-2669	Kit-Gasket (Cl)	438-0183
307-1303	Muffler As.	361-6574
307-1961	Plate	472-8031
308-1845	Seal-Wiper	472-8032
310-1899	Pin As	393-0932
310-3510	Roller As.	434-1919
310-8658	Pin As	425-1526
312-0782	Worm-Circ Drv	282-6623
312-5931	Kit-Gasket(Sch)	438-0140
313-4914	Kit-Gasket(T)	438-0182
314-8717	Shaft-Cla	360-2273
315-6671	Kit-Gasket(Op)	438-0139
316-4396	Kit-Gasket(Sch)	393-3661
318-9013	Kit-Gasket(Sch)	437-8128
319-0848	Kit-Gasket(T)	438-0138
319-2228	Shoe-Circle Gde	419-4706
319-2229	Shoe-Circle Gde	396-7288
319-3607	Kit-Gasket(Rs)	438-0137
319-5239	Wheel	396-9956
319-8126	Kit-Gasket(Sch)	438-0136
321-5714	Piston-Clutch	281-1693
321-5746	Bearing-Main	419-6367
322-2929	Kit-Gasket(Sch)	438-0135
323-4174	Kit-Gasket(Sch)	438-0134
325-2721	Kit-Gasket(T)	393-3662
325-3291	Roller As	434-1918
325-6012	Brg-Cla	325-6019
328-4240	Arm As-V Rocker	433-0443
328-4266	Cylinder As.	393-3664
328-4267	Cyl Gp-140 114 Y	393-3653
328-4374	Disc-Friction	384-5966
328-4375	Disc-Friction	443-1922
328-5572	Bearing-Rod	419-6349
328-5573	Bearing-Conn Rod	419-4665
328-5573	Bearing-Conn Rod	419-6387
328-5574	Bearing-Rod	419-7266
331-8538	Seal-Wheel	391-9874
333-9877	Pin As	394-0217
334-1032	Disc-Friction	440-3116
334-1033	Disc-Friction	394-8242
334-8389	Crankshaft As	242-3439
336-4979	Kit-Gasket(Dt)	451-1511
337-0872	Crankshaft As	242-3440
341-2430	Damper As-Cshft	299-2005
343-4836	Mount As	424-6369
345-1976	Pump-Gr-Cla	345-1978
347-6081	Gauge As	360-2348
347-8681	Kit-Gasket(Fs)	438-0133
347-8682	Kit-Gasket(Ocl)	438-0132
347-8683	Kit-Gasket(Rs)	438-0131
347-8684	Kit-Gasket(Sch)	438-0130
347-8688	Kit-Gasket(Sch)	438-0170
352-0200	Pump Gp-Water -B	434-6109
352-0209	Pump Gp-Water -B	375-4336
352-1053	Kit-Dt Gasket	447-0829
352-2077	Pump Gp-Water -B	434-6108
352-2151	Pump Gp-Water -B	434-6107
352-2153	Pump As-Water	433-0444
352-2157	Pump Gp-Water -B	433-0441
352-2160	Pump Gp-Water -B	433-0789
352-2163	Pump As-Water	434-6106
355-0763	Kit-Gasket(Sch)	438-0181
357-7540	Valve-Fill	360-2292
358-9117	Gear-Planet	380-7490
360-7863	Muffler-Cla	360-7878
368-0297	Plate-Clutch	377-7420
374-1849	Brg-Rlr-Cla	399-4442
391-8229	Kit-Gasket-Fs	398-2955
391-8256	Kit-Gasket (Sch)	447-8653
392-6301	Kit-Spider & Brg	390-0915
3B-1142	Retainer-Spring	391-1099
3B-3967	Race-Roller Brg	386-4947
3B-4124	Cup-Spl Tapered	422-6481
3B-6217	Muffler As	247-2671
3B-6218	Muffler As	247-2672
3B-8845	Bearing-Inner	417-4509
3D-4343	Chain-Tandem Dr	394-0214
3D-4718	Bearing-Sleeve	245-5795
3D-5315	Pinion-Dif Bevel	308-9856
3D-9126	Cup-Roller Brg	399-4435
3D-9132	Cone-Roller Brg	453-3652
3D-9133	Cup-Roller Brg	418-9601
3E-3322	Gasket Kit - F	437-8114
3E-3332	Kit-Gasket(Ocl)	437-8113
3E-3339	Gasket Kit	393-3614
3E-4325	Kit-Gasket (F)	437-8112
3E-4326	Gasket Kit	437-8111
3E-4329	Kit-Gasket(Ocl)	437-8110
3E-4880	Coupling As	417-9465
3E-4903	Mount As	396-7274
3E-4924	Mounting As	391-9812
3E-6772	Seal-Water	382-8017
3E-7461	Gasket Kit-Sch	437-4575
3E-7466	Gasket Kit	393-3615
3E-7473	Gasket Kit	393-3616
3E-7496	Gasket Kit - Sch	437-8105
3E-8905	Gasket Kit	393-3617
3F-1972	Retainer As	226-7988
3F-3049	Cone-Roller Brg	418-9600
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6492	Ballstud	388-0588
3F-6523	Pin-Clevis	256-4818
3F-6612	Cap-Ball Joint	297-7155
3G-0027	Pin As	388-6601
3G-0034	Trunnion	361-1712
3G-0222	Bearing-Sleeve	374-6512
3G-0910	Cap-Bearing	325-6037
3G-1239	Pump Gp-Vn Bsc-B	439-1135
3G-1305	Cyl Gp-159 586 Y	430-5966
3G-1853	Cyl Gp-076 406 Y	415-1895
3G-2580	Bearing-Sleeve	422-9526
3G-2665	Cover	308-9842
3G-2717	Cartridge Gp	439-1132
3G-2720	Cartridge Gp-Rr	448-5051
3G-2749	Cartridge Gp-Rr	422-8125
3G-2751	Cartridge Gp-Rr	422-8126
3G-2752	Cartridge Gp-Rr	422-8127
3G-2797	Bearing-Sleeve	360-2329
3G-2806	Cartridge Gp	422-8128
3G-2834	Cartridge Gp-Rr	426-0025
3G-2835	Cartridge Gp-Rr	422-8106
3G-2837	Cartridge Gp-Rr	422-8123
3G-2858	Pump Gp-Gr A	424-7054

Part Numbers Beginning with 3 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
3G-3346	Bushing	385-3786
3G-3347	Bushing	385-3792
3G-3521	Bearing	380-7513
3G-4292	Bearing	425-6439
3G-4601	Pump Gp-Vn-Bsc-B	422-8139
3G-4602	Pump Gp-Vn-Bsc-B	439-1131
3G-4704	Bearing-Sleeve	379-0185
3G-4752	Cyl Gp-035-060-Y	390-0987
3G-5192	Cyl Gp-0126 1128	399-8577
3G-5223	Cyl Gp-0083-1016	399-8557
3G-5224	Cyl Gp-0083-0459	425-9375
3G-5264	Cylinder As.	393-1018
3G-5285	Bearing-Sleeve	360-2312
3G-5337	Bearing-Spher	418-9602
3G-5492	Rod As	377-5836
3G-5497	Cyl Gp-0210 0535	394-9822
3G-5502	Cylinder As	390-0988
3G-5707	Cyl Gp-0210 0188	399-8556
3G-5750	Bearing-Plate	419-4734
3G-5999	Bearing-Sleeve	391-9813
3G-6058	Pin As	389-6306
3G-6098	Pin As	383-2124
3G-6313	Bearing	325-6007
3G-6846	Pump Gp-Vn Bsc-A	422-8165
3G-6856	Pump Gp-Gr A	421-1556
3G-6910	Bearing-Plate	419-4733
3G-7412	Pump Gp-Vn Bsc-B	422-8167
3G-7482	Sleeve	425-3455
3G-7600	Cyl Gp-076 314 U	422-4936
3G-7637	Pump Gp-Vn Bsc-A	422-8148
3G-7638	Pump Gp-Vn Bsc-B	422-8174
3G-7639	Pump Gp-Vn Bsc-B	422-8173
3G-7640	Pump Gp-Vn Bsc-B	422-8172
3G-7651	Cartridge Gp	422-8121
3G-7652	Cartridge Gp	426-0026
3G-7653	Cartridge Gp	422-8099
3G-7654	Cartridge Gp	422-8100
3G-7655	Cartridge Gp	422-8119
3G-7657	Cartridge Gp	422-8101
3G-7658	Cartridge Gp	426-0427
3G-7659	Cartridge Gp	422-8102
3G-7660	Cartridge Gp	422-8103
3G-7661	Cartridge Gp	422-8113
3G-7662	Cartridge Gp	422-8105
3G-7663	Cartridge Gp	422-8120
3G-7664	Cartridge Gp	422-8130
3G-7666	Cartridge Gp	422-8098
3G-7667	Cartridge Gp	422-8107
3G-7752	Pin As	384-4779
3G-8136	Retainer	425-3585
3G-8245	Bearing-Sleeve	399-8586
3G-8621	Cyl Gp-092 299 Y	399-8554
3G-8746	Rod As	394-8217
3G-8792	Cylinder As	469-4666
3G-8900	Pin	325-6140
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3G-9303	Pin	367-6079
3G-9891	Pump Gp-Gr A	399-8541
3H-0881	Ring-Piston	465-8998
3H-1996	Bearing-Ball	380-1498
3H-5867	Retainer-Spring	390-0992
3H-7161	Pin	256-4819
3H-7164	Pin-Pivot	256-4820
3H-8726	Mount As	385-7208
3J-1943	Collar	468-5015
3J-2333	Bearing-Sleeve	422-9525
3J-2373	Bearing-Sleeve	380-7562
3J-2443	Bearing	383-2125
3J-2682	Bracket	296-1345
3J-2903	Cover	422-6922
3J-3493	Ballstud	256-4832
3J-3953	Bearing-Sleeve	384-4778
3J-4284	Cap-Brg	314-8656
3J-4778	Roller As	394-2582
3J-5190	Cap-Brg	256-4837
3J-5432	Pin-Pivot	361-1711
3J-6043	Trunnion	319-3477
3J-6167	Bearing-Sleeve	299-1960
3J-6412	Bearing-Sleeve	386-4920
3J-6442	Bearing-Sleeve	299-1961
3J-6484	Bearing-Sleeve	380-7383
3J-6502	Pin	319-3453
3J-6558	Brace As	416-5522
3J-6559	Cap-Bearing	296-1346
3J-6560	Screw-Adj	297-7240
3J-6561	Screw-Adj	297-7241
3J-6570	Support-Bearing	299-2069
3J-6573	Screw-Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6577	Pin-Brace	367-6077
3J-7798	Bracket	385-3791
3J-8688	Bearing-Sleeve	380-1561
3J-9097	Retainer	397-5045
3J-9133	Bearing-Sleeve	361-1691
3J-9325	Piston	390-0993
3J-9511	Bearing-Sleeve	385-3782
3K-0526	Bearing-Ball	386-4949
3K-0963	Pin-Lock	308-9895
3K-2511	Dowel-Reaction	383-2126
3K-3124	Muffler-Trap	247-2673
3K-4290	Rod End	374-1823
3K-7020	Gear-Planet	221-9074
3K-7110	Gear-Planet	253-1435
3K-9604	Cage-Bearing	396-0654
3K-9608	Guard-Dirt	374-1447
3L-1425	Bearing-Ball	311-9356
3L-9409	Cup-Roller Brg	399-4436
3L-9410	Cone-Spl Tapered	391-9899
3N-1968	Mount-Shock	397-5046
3N-2078	Pump Gp-Fuel Tfr	311-9444
3N-3017	Adapter As	433-2031
3N-3368	Pipe-Exhaust	311-9434
3N-3786	Rod-Thrt Cont	397-5051
3N-4892	Lever-Gov Cont	439-4542
3N-5869	Support-Elbow	375-9973
3N-6411	Cup-Rlr Bearing	423-7759
3N-6841	Tube As-Inlet Rh	311-9464
3N-7326	Thrower-Cshft O	311-9458
3N-7327	Thrower-Cshft O	311-9459
3N-7702	Shaft-Pump Idler	428-7201
3N-8463	Bearing-Roller	394-9193
3N-9160	Ring-Cshft Seal	311-9447
3P-0114	Elbow-Exhaust	314-8516
3P-0165	Pulley-Fan Drive	298-2775
3P-0203	Pump Gp-Gr Basic	418-1965

Part Cross-Reference

Part Numbers Beginning with 3 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
3P-0204	Pump Gp-Gr Basic	421-2550
3P-0296	Gear	416-2149
3P-0297	Shaft As	275-5297
3P-0298	Carrier-Input	384-5922
3P-0329	Drum As-Gear	380-7484
3P-0395	Cage-Carrier Brg	217-7723
3P-0726	Shaft As	275-5298
3P-0786	Coupling	433-0440
3P-0801	Plate-Clutch	383-2119
3P-0894	Shaft As-Planet	302-3446
3P-0895	Bearing-Spl Ball	394-9184
3P-0951	Bearing-Spl Ball	416-2159
3P-1210	Cone-Roller Brg	399-4433
3P-1459	Spring-Recoil	375-5448
3P-1465	Spring-Recoil	384-3479
3P-1609	Carrier-Planet	302-4292
3P-1619	Gear-Transfer	468-5017
3P-1624	Flange As	468-5018
3P-1651	Piston As	302-4296
3P-1686	Plate-Clutch	388-0586
3P-1686	Plate-Clutch	388-0586
3P-1687	Plate-Clutch	428-6658
3P-1691	Housing As	432-5219
3P-1697	Coupling	390-0911
3P-1885	Spring-Recoil	375-5449
3P-2414	Housing-Clutch	391-9831
3P-2415	Carrier-Planet	396-0653
3P-2564	Race-Brg Outer	417-9480
3P-2582	Bearing-Spl Ball	417-9478
3P-2685	Piston-Clutch	308-9908
3P-2759	Carrier-Planet	394-9820
3P-2761	Housing-Clutch	430-8994
3P-2822	Retainer	422-3509
3P-2852	Clutch-Hub	301-4902
3P-2854	Shaft As-Clutch	416-2127
3P-2855	Plate-Clutch	377-7422
3P-2863	Gear-Idler	399-6044
3P-2865	Shaft As-Idler	393-1056
3P-2871	Case-Final Drive	398-2939
3P-2872	Case-Final Drive	390-5296
3P-2983	Gear-Sun	417-9468
3P-3059	Gear-Sun	308-9861
3P-3103	Carrier-Ring	385-7203
3P-3208	Flange-Joint	301-4647
3P-3241	Plate-Pressure	325-6167
3P-3242	Shaft-Planet	308-9923
3P-3245	Shaft-Planet	308-9924
3P-3246	Shaft-Planet	308-9925
3P-3424	Shaft	416-5526
3P-3429	Cage-Bearing	452-0430
3P-3505	Shaft-Brake	384-3477
3P-3623	Lock-Adj Nut	226-7989
3P-3735	Housing As	391-9830
3P-3738	Housing As	385-7196
3P-3739	Carrier As	431-4032
3P-4135	Support As	396-7266
3P-4142	Plate As	299-2039
3P-4143	Suspension As	393-3644
3P-4157	Yoke As-Idler	226-0221
3P-4197	Guard As-Idler	226-0189
3P-4265	Piston-Clutch	397-5063
3P-5349	Piston As	275-5292
3P-5672	Yoke	223-6313
3P-5736	Hub-Gear	219-2975
3P-5736	Hub-Gear	219-2975
3P-5737	Shaft As-Clutch	275-5273
3P-5754	Hub-Gear	219-2976
3P-5754	Hub-Gear	219-2976
3P-5955	Disc-Friction	428-7205
3P-6318	Flange-Drum	213-8165
3P-6560	Stop-Rec Spring	226-0232
3P-6561	Stop-Rec Spring	226-0233
3P-6814	Pump Gp-Gr 1	226-0163
3P-6816	Pump Gp-Gr 1	226-0164
3P-7042	Housing-Clutch	390-0912
3P-7489	Plate-Clutch	377-7423
3P-7640	Gear-Ctrshft	325-6093
3P-7641	Gear-Ctrshft	325-6094
3P-7643	Gear-Pinion Shft	302-2669
3P-8186	Housing-Screen	390-5261
3P-8393	Plate-Clutch	388-0592
3P-8845	Bearing-Inner	416-5491
3P-9366	Piston-Clutch	391-9861
3P-9394	Shaft-Planet	215-1680
3R-5327	Pipe-Extension	383-1571
3R-8530	Boss	425-3454
3S-0040	Plate-Clutch	384-4796
3S-0044	Plate-Clutch	377-7424
3S-1262	Retainer	308-9915
3S-1292	Bearing-Sleeve	425-8226
3S-1404	Bearing-Outer	417-4508
3S-1467	Pump Gp-F Inj -B	452-9555
3S-1691	Disc-Steer Cl Dr	302-2705
3S-1723	Kit-Gasket (Wp)	438-0178
3S-2252	Manifold-Exhaust	261-0887
3S-2616	Pump Gp-Trans	226-0165
3S-3875	Screen-Suction	435-4849
3S-3917	Guard As-Sprkt	226-0188
3S-3918	Guard As-Sprkt	226-4950
3S-4646	Bearing-Roller	419-2302
3S-5017	Elbow-Exhaust	369-9498
3S-6989	Nut-Spanner	219-9701
3S-7153	Gear-Sliding	227-0024
3S-7308	Cage-Pinion Brg	219-9702
3S-7504	Gear-Idler	226-6084
3S-7517	Pulley-Belt Adj	264-5876
3S-7987	Shaft-Planet	226-6074
3S-8055	Bearing-Inner	433-7506
3S-8634	Hub-Gear	219-2977
3S-8634	Hub-Gear	219-2977
3S-9466	Bearing-Sleeve	314-8509
3S-9669	Bearing	416-2168
3S-9919	Shaft As	239-7959
3T-0300	Pump Gp-Gr 2Bsc	421-1557
3T-0996	Bearing-Sleeve	295-5695
3T-0997	Bearing-Sleeve	307-1524
3T-1162	Sleeve-Wear	325-6209
3T-1407	Disc-Friction	392-4516
3T-1445	Pump Gp-Gr 3	386-3051
3T-1446	Pump Gp-Gr 3 Bsc	325-6178
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690
3T-1921	Drum-Cl Inner	229-8227
3T-2094	Bearing-Sleeve	388-0638
3T-2095	Bearing-Sleeve	384-3459
3T-2139	Housing As-Cl	394-2583
3T-2145	Carrier As	325-6041
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-3150	Guide-Frt Idler	394-0191
3T-4008	Gear-Planet	295-5444
3T-4011	Shaft As-Planet	295-5698
3T-4308	Bearing-Sleeve	296-1341
3T-4384	Housing As-Cl	435-2573

Part Numbers Beginning with 3 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
3T-4482	Guide-Frt Idler	226-0248
3T-4568	Shaft-Planet	314-8712
3T-4824	Gear-Planet	295-5699
3T-5021	Carrier-Planet	295-5700
3T-5100	Hub-Impeller	451-9022
3T-5102	Impeller-Conv	416-2125
3T-5200	Carrier-Planet	295-5701
3T-5294	Spacer	325-6216
3T-5355	Flange	386-3052
3T-5419	Impeller-Conv	416-2144
3T-5672	Gear As-Pump	295-5447
3T-5674	Gear As-Pump	295-5449
3T-5929	Gear	288-8718
3T-6175	Gear-Transfer	398-8351
3T-6176	Gear-Transfer	398-8350
3T-7192	Guard As	325-6100
3T-7195	Guard As	325-6101
3T-7398	Guide As	419-4647
3T-7701	Cylinder As	325-6058
3T-7710	Guide	325-6102
3T-7711	Guide	325-6103
3T-8359	Pump Gp-Gr 1 Bsc	295-5445
3T-8904	Yoke As	443-2056
3T-9496	Plate-Retainer	299-2042
3T-9960	Disc-Friction	417-9487

Original Part Number	Part Name	Classic Part Number
3V-0593	Rim As	418-9568
3V-2281	Link As	299-2023
3V-2337	Pin As	319-3440
3V-3855	Housing-Brg Spt	375-9980
3V-4046	Plate-Pressure	380-7470
3V-4643	Rod As	389-6333
3V-5148	Pinion-Swing Gr	231-0251
3V-5257	Bracket-Carr Rlr	297-7149
3V-5317	Gear	231-0010
3V-5762	Support As	389-6310
3V-6515	Link As	394-0186
3V-6648	Pin As	308-9884
3V-6697	Housing	424-4944
3V-7065	Plate	380-1487
3V-7427	Housing As	297-7197
3V-8976	Cylinder As	433-7508
3W-0241	Pin As	393-3676
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
3W-2196	Housing As	396-0661
3W-2197	Plate As	416-5511
3W-2214	Housing As	418-1947
3W-2215	Plate As	396-0655
3W-2420	Bearing	417-4517
3W-4363	Pin As	375-2634

Original Part Number	Part Name	Classic Part Number
3W-5159	Plate-Parking Bk	391-9904
3W-5501	Gear-Planet	288-8719
3W-6144	Hub-Sprocket	396-7277
3W-6551	Shaft	295-5702
3W-6555	Shaft	295-5703
3W-7559	Pin As	419-4731
3W-7770	Tube As	385-7227
3W-8160	Piston As	393-1051
3W-8177	Retainer	428-7634
3W-8238	Cap	425-3448
3W-8239	Sleeve-Wear	360-2342
3W-8240	Bearing-Sleeve	425-6438
3W-8339	Plate	397-5047
3W-8355	Pin As	425-2565
3W-8398	Bearing-Sleeve	379-0189
3W-8403	Sleeve	393-3673
3W-8406	Cap	416-5534
3W-8409	Bearing	398-8336
3W-8570	Bearing	416-2136
3W-8572	Pin As	393-3672
3W-8679	Yoke As	425-1384
3Y-2768	Ring	439-4544
3Y-9984	Manifold-Exhaust	325-6123

Part Numbers Beginning with 4

Original Part Number	Part Name	Classic Part Number
430-7619	Adapter-Cla	438-1812
441-9566	Gear-Flywheel	374-4703
443-1200	Brg-Rlr-Cla	377-7397
448-7015	Kit-Ovhl-Cla	311-9356
448-7015	Kit-Ovhl-Cla	361-1716
448-7015	Kit-Ovhl-Cla	363-7455
448-7015	Kit-Ovhl-Cla	374-8342
448-7015	Kit-Ovhl-Cla	379-0166
448-7015	Kit-Ovhl-Cla	379-0171
448-7015	Kit-Ovhl-Cla	379-0174
448-7015	Kit-Ovhl-Cla	384-8700
448-7015	Kit-Ovhl-Cla	384-8704
448-7015	Kit-Ovhl-Cla	386-3048

Original Part Number	Part Name	Classic Part Number
448-7015	Kit-Ovhl-Cla	386-3812
448-7015	Kit-Ovhl-Cla	386-3814
448-7015	Kit-Ovhl-Cla	388-6571
448-7017	Kit-Ovhl-Cla	311-9356
448-7017	Kit-Ovhl-Cla	361-1716
448-7017	Kit-Ovhl-Cla	363-7455
448-7017	Kit-Ovhl-Cla	373-1885
448-7017	Kit-Ovhl-Cla	374-8342
448-7017	Kit-Ovhl-Cla	375-9974
448-7017	Kit-Ovhl-Cla	379-0166
448-7017	Kit-Ovhl-Cla	379-0170
448-7017	Kit-Ovhl-Cla	379-0171
448-7017	Kit-Ovhl-Cla	379-0174

Original Part Number	Part Name	Classic Part Number
448-7017	Kit-Ovhl-Cla	379-0177
448-7017	Kit-Ovhl-Cla	379-0191
448-7017	Kit-Ovhl-Cla	384-8700
448-7017	Kit-Ovhl-Cla	384-8704
448-7017	Kit-Ovhl-Cla	386-3048
448-7017	Kit-Ovhl-Cla	386-3812
448-7017	Kit-Ovhl-Cla	386-3814
448-7017	Kit-Ovhl-Cla	388-6571
448-7017	Kit-Ovhl-Cla	419-6367
448-7017	Kit-Ovhl-Cla	422-6919
448-7018	Kit-Gasket-F-Cla	325-6158
448-7018	Kit-Gasket-F-Cla	325-6210
448-7018	Kit-Gasket-F-Cla	383-1569

Part Cross-Reference

Part Numbers Beginning with 4 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
448-7018	Kit-Gasket-F-Cla	384-4816
448-7018	Kit-Gasket-F-Cla	399-4423
448-7018	Kit-Gasket-F-Cla	417-4499
456-2503	Kit-Ovhl-Cla	270-4360
456-2503	Kit-Ovhl-Cla	270-4361
456-2503	Kit-Ovhl-Cla	311-9356
456-2503	Kit-Ovhl-Cla	325-6236
456-2503	Kit-Ovhl-Cla	374-8342
456-2503	Kit-Ovhl-Cla	379-0174
456-2503	Kit-Ovhl-Cla	380-7537
456-2503	Kit-Ovhl-Cla	383-1575
456-2503	Kit-Ovhl-Cla	398-2927
456-2503	Kit-Ovhl-Cla	419-6349
456-2504	Kit-Ovhl-Cla	311-9356
456-2504	Kit-Ovhl-Cla	361-1716
456-2504	Kit-Ovhl-Cla	363-7455
456-2504	Kit-Ovhl-Cla	374-8342
456-2504	Kit-Ovhl-Cla	379-0166
456-2504	Kit-Ovhl-Cla	379-0174
456-2504	Kit-Ovhl-Cla	382-8042
456-2504	Kit-Ovhl-Cla	386-3048
456-2504	Kit-Ovhl-Cla	393-1021
456-2504	Kit-Ovhl-Cla	419-7266
456-2505	Kit-Ovhl-Cla	270-4360
456-2505	Kit-Ovhl-Cla	270-4361
456-2505	Kit-Ovhl-Cla	311-9356
456-2505	Kit-Ovhl-Cla	325-6236
456-2505	Kit-Ovhl-Cla	374-8342
456-2505	Kit-Ovhl-Cla	376-9085
456-2505	Kit-Ovhl-Cla	379-0174
456-2505	Kit-Ovhl-Cla	380-7372
456-2505	Kit-Ovhl-Cla	380-7537
456-2505	Kit-Ovhl-Cla	383-1575
456-2505	Kit-Ovhl-Cla	394-8206
456-2505	Kit-Ovhl-Cla	394-8207
456-2505	Kit-Ovhl-Cla	398-2927
456-2505	Kit-Ovhl-Cla	419-6349
456-2506	Kit-Ovhl-Cla	311-9356
456-2506	Kit-Ovhl-Cla	361-1716
456-2506	Kit-Ovhl-Cla	363-7455
456-2506	Kit-Ovhl-Cla	373-1885
456-2506	Kit-Ovhl-Cla	374-8342
456-2506	Kit-Ovhl-Cla	375-9974
456-2506	Kit-Ovhl-Cla	379-0166
456-2506	Kit-Ovhl-Cla	379-0170
456-2506	Kit-Ovhl-Cla	379-0174
456-2506	Kit-Ovhl-Cla	379-0191
456-2506	Kit-Ovhl-Cla	380-7372

Original Part Number	Part Name	Classic Part Number
456-2506	Kit-Ovhl-Cla	380-7373
456-2506	Kit-Ovhl-Cla	382-8042
456-2506	Kit-Ovhl-Cla	386-3048
456-2506	Kit-Ovhl-Cla	393-1021
456-2506	Kit-Ovhl-Cla	393-1040
456-2506	Kit-Ovhl-Cla	417-4524
456-2506	Kit-Ovhl-Cla	419-6368
456-2506	Kit-Ovhl-Cla	419-7266
456-2506	Kit-Ovhl-Cla	422-6919
456-2506	Kit-Ovhl-Cla	437-8672
456-2507	Kit-Ovhl-Cla	311-9356
456-2507	Kit-Ovhl-Cla	361-1716
456-2507	Kit-Ovhl-Cla	363-7455
456-2507	Kit-Ovhl-Cla	373-1885
456-2507	Kit-Ovhl-Cla	374-8342
456-2507	Kit-Ovhl-Cla	379-0166
456-2507	Kit-Ovhl-Cla	379-0170
456-2507	Kit-Ovhl-Cla	379-0171
456-2507	Kit-Ovhl-Cla	379-0174
456-2507	Kit-Ovhl-Cla	379-0191
456-2507	Kit-Ovhl-Cla	380-7372
456-2507	Kit-Ovhl-Cla	380-7373
456-2507	Kit-Ovhl-Cla	382-8042
456-2507	Kit-Ovhl-Cla	384-8698
456-2507	Kit-Ovhl-Cla	384-8703
456-2507	Kit-Ovhl-Cla	386-3048
456-2507	Kit-Ovhl-Cla	393-1021
456-2507	Kit-Ovhl-Cla	393-1040
456-2507	Kit-Ovhl-Cla	399-8571
456-2507	Kit-Ovhl-Cla	417-4524
456-2507	Kit-Ovhl-Cla	419-6368
456-2507	Kit-Ovhl-Cla	419-7266
456-2507	Kit-Ovhl-Cla	437-8672
456-2508	Kit-Gasket-Cla	325-6158
456-2508	Kit-Gasket-Cla	325-6210
456-2508	Kit-Gasket-Cla	325-6223
456-2508	Kit-Gasket-Cla	384-4816
456-2508	Kit-Gasket-Cla	417-4499
456-2508	Kit-Gasket-Cla	417-4531
456-2510	Kit-Gasket-Cla	419-4716
460-5395	Kit-Gasket (Sch)	436-8395
464-9063	Kit-Dt Brg-Cla	374-1839
464-9063	Kit-Dt Brg-Cla	374-1852
464-9063	Kit-Dt Brg-Cla	377-7418
464-9063	Kit-Dt Brg-Cla	399-4438
464-9063	Kit-Dt Brg-Cla	416-2161
464-9063	Kit-Dt Brg-Cla	418-9609

Original Part Number	Part Name	Classic Part Number
464-9064	Kit-Dt Brg-Cla	376-3636
464-9064	Kit-Dt Brg-Cla	377-7397
464-9064	Kit-Dt Brg-Cla	377-7433
464-9064	Kit-Dt Brg-Cla	384-5932
464-9064	Kit-Dt Brg-Cla	415-1917
464-9064	Kit-Dt Brg-Cla	418-1931
464-9064	Kit-Dt Brg-Cla	419-6022
464-9064	Kit-Dt Brg-Cla	420-2491
464-9064	Kit-Dt Brg-Cla	420-6535
464-9064	Kit-Dt Brg-Cla	434-3296
4B-1455	Cap As-Filler	361-1719
4B-7064	Shaft-Worm	245-5803
4B-7255	Cone-Bearing	386-4951
4B-7270	Cone-Bearing	399-4439
4B-9373	Cone-Roller Brg	399-4440
4B-9374	Bearing-Cup	380-7494
4C-1335	Washer-Thrust	399-4425
4D-0487	Valve As-Check	375-4334
4D-2156	Bearing As-Rlr	422-6485
4D-2229	Cage-Bearing	229-1598
4D-2619	Bearing	417-4494
4D-3882	Cone-Roller Brg	399-6060
4D-4065	Rod End-Spher	374-1824
4D-4324	Cone-Spl Tapered	420-6534
4D-4325	Cup-Spl Tapered	420-6533
4D-4661	Pump Gp-Vn Bsc-A	422-8162
4D-6664	Coupling-Shaft	243-0338
4D-6698	Bearing-Td Hsg	228-9405
4D-6926	Segment-Control	228-9455
4D-7534	Bearing As-Rlr	441-5602
4E-0079	Cage-Bearing	434-4387
4E-0403	Gear-Planet	260-0781
4E-0752	Joint Gp-Univ	435-0197
4E-1011	Pin As	430-9676
4E-1035	Pin	241-2553
4E-1065	Pin As	241-2538
4E-2138	Gear-Sun	399-4401
4E-2165	Gear-Sun	376-9070
4E-2166	Carrier-Planet	373-5383
4E-2168	Piston	375-2623
4E-2250	Housing	399-6043
4E-3196	Pin As	361-1697
4E-3197	Pin As	374-6507

Part Numbers Beginning with 4 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
4E-3456	Lever As	367-6081
4E-3604	Joint Gp-Univ	421-5542
4E-3751	Yoke As	451-0750
4E-3997	Housing-Pinion	374-6498
4E-4524	Pin As	380-7392
4E-5213	Cover As	299-2000
4E-7608	Bearing-Sleeve	388-0639
4E-7717	Shaft-Sprocket	432-6606
4E-8534	Retainer-Seal	300-2588
4E-8535	Retainer-Seal	300-2589
4E-9426	Collar	231-0000
4E-9658	Joint Gp-Slip	452-9553
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-2041	Cup-Roller Brg	418-9609
4F-2393	Bearing-Ball	380-1499
4F-5003	Spring As-Arm	383-2127
4F-5004	Spring As-Arm	383-2128
4H-4021	Plate As-Loading	229-8219
4H-7496	Plate-Pump Seal	420-6217
4H-9040	Nut	226-7996
4H-9640	Bearing-Sleeve	386-4921
4I-0453	Bearing-Sleeve	360-2331
4I-0465	Pin	372-7511
4I-0704	Bearing-Sleeve	360-2332
4I-1524	Cylinder As	394-8216
4I-3954	Tube As	301-4779
4I-3957	Tube As	301-4801
4I-4617	Pin As	424-6367
4I-4619	Pin As	425-2564
4I-4665	Bearing-Sleeve	364-5267
4I-4666	Bearing-Sleeve	388-0640
4I-4805	Pin	365-8828
4I-4806	Pin	364-5268
4I-4807	Pin	383-2139
4I-4811	Pin As	480-8268
4I-4812	Pin As	480-8269
4I-5015	Pin	365-8829
4I-5016	Pin	396-7272
4I-7401	Spring	380-7414
4J-0121	Cap-Bearing	360-2344
4J-1612	Pin	308-9896
4J-1614	Pin-Pivot	297-7214
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-1999	Ballstud	314-8625
4J-2379	Bearing-Sleeve	393-1014
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2592	Brace As	418-1928
4J-2847	Trunnion As	297-7267
4J-3583	Screw-Adjusting	297-7242
4J-3589	Cap-Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-4497	Cylinder Gp-Rh	399-8585
4J-4498	Cylinder Gp-Lh	425-9374
4J-5241	Retainer	434-1415
4J-5693	Bearing-Sleeve	385-3790
4J-5694	Bearing-Sleeve	379-0190
4J-5695	Bearing-Sleeve	386-4922
4J-6167	Bearing-Sleeve	325-6009
4J-6326	Bearing-Half	376-3630
4J-6374	Bearing-Sleeve	295-6407
4J-7650	Retainer As	440-0851
4K-0255	Retainer As	226-6102
4K-0299	Bearing-Sleeve	308-9816
4K-0300	Bearing-Sleeve	308-9817
4K-1102	Bearing-Sleeve	325-6010
4K-1328	Drum-Ster Cl Dr	216-7840
4K-3004	Bearing-Trun Sup	314-8632
4K-3128	Bearing-Sleeve	314-8633
4K-3150	Pin	385-3788
4K-4780	Strip As-Wear	299-2063
4K-4894	Cage-Bearing	453-0968
4K-6212	Shaft-Bev Pinion	223-4806
4K-6558	Pin-Lower	302-2710
4K-6736	Drum-Brake	223-6320
4K-6760	Cap-Lower	300-2574
4K-6761	Cap-Upper	300-2575
4K-7269	Support-Trun-Frt	299-2067
4K-7270	Support-Trunnion	373-5384
4K-7287	Support As-Rear	383-2116
4K-7420	Retainer	297-7234
4K-7463	Seal-Lip Type	472-8007
4K-7467	Bearing As-Rlr	380-1500
4K-7556	Yoke	385-6118
4K-8225	Pin-Cylinder	297-7215
4K-8561	Pin	299-2036
4K-8734	Bearing-Sleeve	299-1962
4K-9598	Retainer	297-7235
4L-3437	Gasket	420-8572
4L-3756	Bearing-Thrust	311-9366
4L-4653	Plate-Thrust	311-9440
4L-6706	Gasket	421-1028
4L-8473	Plate-Wear	419-0883
4M-0410	Gear-Oil Pump Dr	428-6660
4M-1001	Pump Gp-Fd Oil	226-0166
4M-1641	Dowel-Reaction	386-4952
4M-3915	Bearing-Caged	377-7427
4M-4431	Shaft-Pump Dr	390-0994
4M-5226	Bearing-Ball	399-6061
4M-5858	Bearing-Spl Ball	417-4495
4M-6107	Bearing-Roller	380-7507
4M-9183	Bearing-Sleeve	386-4924
4M-9214	Shaft-Pump Drive	314-8543
4M-9215	Gear-Pump Idler	311-9391
4M-9216	Gear-Pump Drive	311-9390
4N-0209	Bonnet-Valve	378-3973
4N-0342	Plate-Cam Thrust	375-9974
4N-0362	Cover As-Rgltr	419-4722
4N-0406	Gear-Tfr Pump	373-1903
4N-0429	Gear-Tfr Pump	373-1915
4N-0432	Bearing-Ball	417-4499
4N-0614	Cap-Crankshaft	448-9156
4N-0685	Bearing-Sleeve	379-0191
4N-0733	Pump Gp-Xx 1 Gr	374-7502
4N-0913	Screen As-Bell	374-7489
4N-1010	Support-Elbow	416-5509
4N-1015	Bearing-Sleeve	417-4525
4N-1098	Shaft As	374-1455
4N-1106	Shaft As-Rocker	377-5837
4N-1116	Shaft As-Pump	374-7473
4N-1119	Gear-Tfr Pump	373-1884
4N-1157	Coupling-Exhaust	379-0177
4N-1186	Bearing-Sleeve	417-4519
4N-1320	Gasket-Adapter	398-2928
4N-1675	Manifold-Exhaust	443-2015
4N-1767	Valve-Bypass	419-4716
4N-1849	Pipe-Air	421-7143
4N-2484	Bonnet-Valve	455-3272
4N-2514	Gear-Flywheel	421-7283
4N-2572	Spider As-Fan	451-9027
4N-2690	Shaft As	386-3053

Part Cross-Reference

Part Numbers Beginning with 4 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
4N-2697	Pulley-Tightener	376-9056
4N-2954	Sleeve-Camshaft	299-2059
4N-3092	Spider As-Fan	363-7465
4N-3281	Line As-Fuel Inj	247-3362
4N-3282	Line As-Fuel Inj	247-3363
4N-3283	Line As-Fuel Inj	247-3364
4N-3284	Line As-Fuel Inj	247-3365
4N-3339	Spider As.	419-0891
4N-3664	Guide-Valve	314-8524
4N-3714	Chamber As	363-7450
4N-3875	Ring-Piston	465-8997
4N-3927	Compressor As	435-6051
4N-4161	Mount As	374-1448
4N-4519	Quadrant-Control	444-0572
4N-4520	Guide	388-6600
4N-4534	Pulley-Crkshft	374-4709
4N-4539	Sleeve	314-8720
4N-4577	Muffler As.	308-9877
4N-4668	Breather-Engine	396-7271
4N-4679	Pulley-Fan	394-9837
4N-4782	Pulley	325-6176
4N-4864	Pump Gp-F Tfr	242-3442
4N-4878	Pump Gp-F Tfr	390-0995
4N-4880	Pump Gp-F Tfr	256-4758
4N-4942	Rod-Eye	421-8919
4N-5184	Muffler As	360-7874
4N-5390	Pulley-Alt Drive	264-5879
4N-5572	Gasket	433-8192
4N-5614	Arm As-Rocker	374-4710
4N-5857	Cap-Bearing	376-9086
4N-5858	Cap-Cshft Brg	448-9157
4N-5958	Tube-Exhaust Ext	385-3811
4N-6257	Adapter	415-1904
4N-6302	Belt Set-Vee	314-8495
4N-6413	Support-Alt	433-9855
4N-6658	Bearing-Sleeve	373-1885
4N-7692	Crankshaft As	269-8764
4N-7693	Crankshaft As	269-8763
4N-7977	Shaft As-Balance	314-8709
4N-7978	Shaft As-Balance	314-8710
4N-7982	Pulley	264-5880
4N-8204	Mount As	374-1449
4N-8344	Spider As-Fan	416-5520
4N-8434	Spider As-Fan	451-9030
4N-8472	Housing-Aftclr	419-0887
4N-8591	Coupling-Exhaust	325-6053
4N-8809	Chamber As	247-3297
4N-8814	Line As-F Inj	247-3366
4N-8942	Muffler As	298-2786
4N-9213	Elbow-Exhaust	330-9270
4N-9325	Pulley-Alt Drive	419-4657
4N-9941	Line As-Fuel Inj	380-1562
4N-9942	Line As-Fuel Inj	380-1563
4N-9943	Line As-Fuel Inj	380-1572
4N-9944	Line As-Fuel Inj	380-1565
4P-0660	Muffler As	298-2787
4P-0854	Core As-Oil Clr	419-0890
4P-0893	Core As-Radiator	376-9057
4P-0897	Core As-Radiator	376-9058
4P-1463	Muffler As	360-7876
4P-2383	Adapter-Inlet	438-1812
4P-3546	Valve As-Relief	325-6236
4P-3683	Pump Gp-Water -B	374-7498
4P-3754	Core As-Oclr	438-2016
4P-4010	Muffler As	298-2788
4P-4757	Muffler As	360-7877
4P-5433	Compressor As	419-4728
4P-5435	Compressor As	396-9942
4P-5884	Core As-Oclr	435-0196
4P-6548	Muffler As	360-7878
4P-6589	Pipe As	382-6898
4P-6649	Muffler As	416-5527
4P-7051	Pulley-Alt	376-9064
4P-7688	Valve As-Check	420-6216
4P-7731	Core Gp-O Clr	385-7228
4P-7790	Shaft As-Arm	457-4596
4P-7801	Line As-Fuel Inj	373-1888
4P-7802	Line As-Fuel Inj	373-1889
4P-7803	Line As-Fuel Inj	373-1890
4P-7804	Line As-Fuel Inj	373-1891
4P-7805	Line As-Fuel Inj	373-1892
4P-7806	Line As-Fuel Inj	373-1893
4P-7807	Line As-Fuel Inj	373-1894
4P-7808	Line As-Fuel Inj	373-1895
4P-7809	Line As-Fuel Inj	373-1896
4P-7810	Line As-Fuel Inj	373-1897
4P-7811	Line As-Fuel Inj	373-1898
4P-7812	Line As-Fuel Inj	373-1899
4P-7826	Gear-Camshaft	472-8008
4P-7827	Gear-Crankshaft	380-7533
4P-7830	Gear-Oil Drive	472-8009
4P-8279	Manifold-Exhaust	430-8041
4P-8280	Manifold-Exhaust	430-7236
4P-8577	Rod As-Injector	455-5513
4P-8915	Gasket-Cyl Head	377-5838
4P-9381	Line As-Fuel Inj	279-4984
4P-9382	Line As-Fuel Inj	279-4985
4P-9383	Line As-Fuel Inj	279-4988
4P-9384	Line As-Fuel Inj	279-4989
4P-9385	Line As-Fuel Inj	279-4986
4P-9386	Line As-Fuel Inj	279-4987
4P-9395	Line As-Fuel Inj	383-3690
4P-9396	Line As-Fuel Inj	383-3691
4P-9942	Seal-End Tank	385-7217
4P-9943	Seal-End Tank	385-7216
4P-9961	Line As-Fuel Inj	325-6115
4P-9962	Line As-Fuel Inj	325-6116
4P-9963	Line As-Fuel Inj	298-2777
4P-9964	Line As-Fuel Inj	298-2778
4Q-1346	Link As-Bearing&	425-3649
4S-5049	Guard As-Rh	226-0183
4S-5050	Guard As-Lh	226-0184
4S-5367	Mount As	375-9986
4S-5891	Plate-Clutch	388-0575
4S-5943	Piston-Clutch	221-9112
4S-6189	Pinion-Reverse	226-6077
4S-6256	Nut-Brg Adj	235-8008
4S-6559	Tube	325-6234
4S-6707	Piston-Clutch	215-1686
4S-7793	Thrower-Cshft O	367-6085
4S-8005	Pinion-Fdr	226-6076
4S-8472	Hood As-Preclnr	296-1355
4S-8530	Shaft-Planet	221-9111
4S-8534	Shaft As-Planet	221-9116
4S-8538	Bearing-Spl Ball	417-4502
4S-8660	Pump Gp-Trans	226-0167
4S-8670	Shaft-Planet	300-2590
4S-8687	Piston-Clutch	226-8008
4S-8708	Housing-Clutch	216-3557
4S-8718	Cage-Carrier Brg	217-7724

Part Numbers Beginning with 4 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
4S-8855	Coupling-Exhaust	369-9488
4S-9062	Cap-Fd Bearing	226-0204
4S-9325	Race-Spl Rlr Brg	418-9590
4S-9326	Bearing	417-4506
4S-9782	Race & Roller As	385-3779
4S-9783	Race-Rlr Bearing	418-9589
4T-0202	Pin As	325-6130
4T-0231	Retainer	376-3641
4T-0406	Rod As	394-8215
4T-0416	Cartridge Gp	422-8138
4T-0417	Cartridge Gp	422-8109
4T-0422	Cartridge Gp	422-8129
4T-0509	Pump Gp-Vn Bsc-B	422-8159
4T-0589	Slider	434-1411
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-1684	Bearing	377-7428
4T-1893	Cartridge Gp	422-8110
4T-3196	Cartridge Gp	422-8112
4T-4073	Valve Gp-Shtl -B	439-1138
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4T-6869	Cartridge Gp	422-8104
4T-7534	Pin	433-9209
4T-7640	Shaft As	393-3643
4T-7819	Cyl Gp-051 127 Y	426-0028
4T-8054	Seal As	472-8010
4T-9290	Cyl Gp-0152 0495	399-8579
4T-9311	Housing	396-0652
4V-0015	Plate-Lock	282-6563
4V-0092	Hub As	396-9934
4V-0093	Gear-Planet	394-9826
4V-0094	Shaft-Planet	380-1486
4V-0189	Pin	374-6504
4V-0381	Bearing-Sleeve	299-1963
4V-2057	Bearing-Spher	419-6019
4V-2120	Pin	365-8830
4V-2518	Shaft	297-7243
4V-2588	Pin As	435-6050
4V-2723	Pin	419-6016
4V-2744	Gear	224-1303
4V-2872	Bearing-Sleeve	380-7558
4V-2873	Bearing-Sleeve	379-0192
4V-2881	Link As-Bearing&	384-3464
4V-2883	Bearing-Sleeve	379-0193
4V-3044	Plate-Lock	308-9911
4V-3396	Hub-Gear	222-1763
4V-3396	Hub-Gear	222-1763
4V-3603	Pin As	319-3441
4V-3619	Pin As	380-7393
4V-3623	Pin As	375-9967
4V-3625	Pin As	418-1944
4V-3680	Bellcrank	308-9802
4V-3842	Support-Trunnion	396-9935
4V-4483	Plate-Lock	396-9933
4V-4852	Piston	433-0452
4V-5099	Cover	418-1929
4V-5100	Support-Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-5388	Shaft-Bev Pinion	297-7244
4V-5392	Spider	377-7430
4V-5393	Gear-Bevel	297-7189
4V-5394	Gear-Diff	297-7177
4V-5400	Housing-Brg Spt	385-7202
4V-5454	Link	299-2025
4V-6421	Pin As	319-3442
4V-6527	Disc	376-9050
4V-7082	Joint Gp-Slip	367-6068
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-7543	Retainer	281-1699
4V-7545	Gear-Ring	394-9823
4V-7725	Piston	394-2581
4V-8518	Link As-Brg&	374-1450
4V-8519	Bearing-Sleeve	307-1526
4V-8520	Bearing-Sleeve	307-1527
4V-8534	Shaft-Planet	281-1700
4V-8535	Hub As	423-9669
4V-8538	Gear-Ring	288-8720
4V-8611	Yoke As	418-9567
4V-8629	Bearing-Sleeve	379-0194
4V-8643	Bearing-Sleeve	374-8354
4V-8661	Pin As	375-9968
4V-8673	Bearing-Sleeve	307-1528
4V-8674	Bearing-Sleeve	307-1529
4V-8675	Bearing-Sleeve	394-0187
4V-9577	Shaft-Planet	231-0001
4V-9901	Pin As	374-6508
4W-0255	Spider As-Fan	382-5052
4W-0419	Core As-Oclr	379-0182
4W-0452	Seal As -Cshaft	325-6191
4W-0456	Muffler As-Eject	360-7879
4W-1203	Cup-Rlr Brg	418-9603
4W-2042	Spacer	325-6217
4W-2061	Pan As-Oil Sump	416-5519
4W-2357	Mount As	386-4927
4W-2446	Damper As	279-4990
4W-2472	Spring-Valve	380-7550
4W-2474	Rotocoil As	388-6571
4W-2541	Shaft-Gov Cont	399-8580
4W-2566	Adapter-Seal	383-1573
4W-2567	Adapter-Seal	383-1574
4W-2606	Seal Gp-Cshft -A	311-9452
4W-2607	Seal Gp-Cshft -A	311-9453
4W-3632	Muffler As	385-7224
4W-4588	Sleeve	394-0218
4W-5053	Muffler As	360-7881
4W-5363	Core Gp-O Clr	380-7531
4W-5477	Pump Gp-F Tfr	380-1512
4W-5549	Core As-Oclr	311-9376
4W-5550	Core As-Oclr	311-9377
4W-5693	Bearing-Con Rod	419-6324
4W-5698	Bearing-Main	419-6323
4W-5699	Bearing-Main	419-6307
4W-5700	Bearing-Main	419-6320
4W-5701	Bearing-Main	419-6333
4W-5702	Bearing-Con Rod	419-6318
4W-5703	Bearing-Con Rod	419-7255
4W-5719	Adapter As	373-1906
4W-5733	Adapter As-Valve	378-3975
4W-5998	Rod-Valve Push	379-0168
4W-6150	Adapter-Support	432-4219
4W-6805	Flywheel As	421-3325
4W-6869	Spacer-Fuel Pump	417-4534
4W-7188	Core As-Oclr	374-7501
4W-7382	Core As-Oclr	380-1514
4W-8485	Muffler As	430-4472
4W-9480	Rod As-Pstn &	378-3976
4W-9492	Repair Kt-Major	375-2261
4W-9655	Support	419-0882
4W-9771	Gear-Crankshaft	302-2674

Part Cross-Reference

Part Numbers Beginning with 4 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
4W-9773	Gear-Hyd Pump Dr	380-7549
4W-9822	Core Gp-O Clr	374-4711
4W-9989	Gear As-Idler	302-2677
4Y-0709	Disc-Friction	377-7431
4Y-1034	Pin As	396-0641
4Y-2817	Ejector As	295-6423
4Y-4340	Pin As	319-3442
4Y-4905	Washer-Soft	416-5535
4Y-4951	Muffler As	419-0889
4Y-5711	Pin As	425-6442
4Y-7089	Pin As-Rmte Lub	397-5042

Part Numbers Beginning with 5

Original Part Number	Part Name	Classic Part Number
5A-4003	Shaft-Sprocket	229-8228
5A-5740	Gear-Sliding	229-8229
5A-7840	Shaft-Tr Sprkt	215-1687
5A-9551	Gear-Finaldrive	226-7979
5B-9169	Plug-Drain	419-4736
5C-0857	Plate-Mating	376-3624
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer-Pin	299-2047
5C-6739	Bearing-Sleeve	445-7704
5C-8273	Adapter	415-1902
5C-8584	Gear-Planet	231-0006
5D-0470	Valve Gp-Qrel	314-8549
5D-2989	Bearing	380-7511
5D-4799	Bearing-Roller	416-2160
5D-6201	Shoe-Yoke	243-0356
5D-6296	Cone-Spl Tapered	399-6062
5D-6298	Cup-Spl Tapered	399-6063
5D-6657	Race-Spl	417-4530
5D-6659	Bearing	417-4511
5D-7449	Cup-Spl Tapered	416-2161
5D-8153	Shaft-Drive	421-8180
5D-9675	Spider	394-9203
5D-9745	Shoe-Guide	330-9285
5D-9906	Shaft-Axle	228-9413
5F-0736	Pin-Pivot	256-4823
5F-1248	Cone-Roller Brg	399-4441
5F-2256	Cage-Bearing	226-7973
5F-2465	Cup-Roller Brg	447-8060
5F-2830	Bearing-Needle	384-5925
5F-7404	Nut-Bearing Lock	308-9878
5F-7958	Shaft-Roller	434-1865
5F-7993	Pin	319-3454
5F-8651	Bearing-Ball	420-3223
5G-3612	Cap Gp-Protn	295-6419
5G-4381	Yoke As	469-4662
5G-5846	Pinion	418-9585
5G-8708	Drum	384-4794
5G-9075	Strip	295-0412
5G-9076	Strip	295-0413
5H-0047	Disc-Cl Drive	388-0576
5H-1719	Pump Gp-Fd Oil	226-0168
5H-5500	Collar-Fly Cl	302-2704
5H-5553	Screw-Tappet Adj	311-9451
5H-7071	Director-Water	388-0555
5I-3301	Pin As	387-2929
5I-3371	Pin As	393-3668
5I-7619	Pulley	301-4772
5I-7707	Pipe	438-2011
5I-7708	Pipe	438-2014
5I-7710	Pipe	438-2013
5I-7711	Pipe	438-2012
5I-7914	Muffler	435-4791
5I-7959	Pulley As	301-5256
5I-8628	Plate-Valve	301-4771
5J-0778	Cyl Gp-184 597 Y	399-8544
5J-1192	Bearing-Sleeve	374-8355
5J-1193	Bearing-Sleeve	382-8046
5J-1449	Pin As	393-3671
5J-1806	Pin	396-0662
5J-1825	Pin	367-6080
5J-1968	Shaft-Roller	386-4928
5J-1980	Pin	385-3805
5J-2245	Bearing	422-6916
5J-2246	Bearing	418-1927
5J-2445	Bearing-Sleeve	380-7563
5J-2449	Cylinder Gp-Bowl	419-8800
5J-2450	Cylinder Gp-Bowl	430-5965
5J-2453	Rod As.	394-8214
5J-2528	Plunger	391-1318
5J-3506	Retainer	399-8551
5J-4321	Trunnion	302-2700
5J-4929	Bearing	256-4796
5J-5365	Pin	380-7553
5J-5643	Connector	325-6043
5J-6424	Bearing-Aligning	416-2135
5J-6430	Bearing-Sleeve	379-0195
5J-6611	Bearing-Sleeve	383-2140
5J-7010	Seal As	472-8011
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-8103	Bearing-Sleeve	389-6309
5J-8118	Bearing-Sleeve	451-9018
5J-8361	Bearing-Sleeve	384-4775
5J-8363	Bearing-Sleeve	394-0209
5J-9348	Bearing As	416-2162
5J-9451	Bearing	374-8338
5K-0609	Cover	308-9843
5K-0871	Pin-Lower	282-6630
5K-0983	Seal-Lip Type	472-8012
5K-0984	Bearing-Sleeve	330-9262
5K-0989	Cap-Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap-Lower	319-3433
5K-1068	Retainer-Seal	260-0786

Part Numbers Beginning with 5 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
5K-2294	Bearing	396-9912
5K-2432	Pin-Cylinder	384-3473
5K-2754	Spring-Recoil	418-1956
5K-3171	Plate-Coupling	417-9475
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3493	Cover	391-9814
5K-3495	Collar	383-2129
5K-3499	Pin-Lower	308-9898
5K-3502	Cap-Lower	308-9835
5K-3929	Bearing As-Rlr	416-2163
5K-3967	Yoke As	308-9946
5K-3968	Cage-Bearing	308-9804
5K-4079	Cage-Bearing	308-9805
5K-4268	Retainer-Bearing	308-9916
5K-4273	Bearing-Sleeve	374-1461
5K-4787	Bearing-Sleeve	308-9819
5K-5927	Boss	299-1973
5K-5933	Cover As	247-4125
5K-6377	Pin	241-2610
5K-6383	Pin	241-2612
5K-7995	Bearing-Sleeve	308-9820
5K-8265	Pin	241-2590
5K-8591	Bearing-Outer	380-7502
5K-8628	Cage	449-4732
5L-2030	Cone-Roller Brg	418-9614
5L-2031	Cup-Roller Brg	384-5927
5L-2093	Gasket	393-3619
5L-2648	Bearing-Sleeve	311-9362
5L-2660	Bearing-Sleeve	311-9363
5L-5772	Race & Roller As	394-9200
5L-6326	Bearing-Ball	420-3222
5L-7520	Elbow-Exhaust	419-4711
5L-7632	Support-Elbow	433-9854
5L-7634	Elbow-Turbo Exh	380-1555
5L-8856	Coupling-Exhaust	311-9379
5L-9370	Elbow-Man Inlet	311-9388
5L-9371	Connector-Inlet	311-9375
5L-9656	Cone-Bearing	399-4448
5L-9738	Coupling-Exhaust	311-9380
5M-0549	Gear-Trans	215-1689
5M-0578	Bearing	419-7775
5M-1988	Piston-Steer Cl	219-9691
5M-1990	Pilot-Cl Piston	229-8233
5M-2051	Bearing-Caged	380-7467
5M-2054	Bearing	380-7510
5M-2824	Coupling-Exhaust	431-5270
5M-2971	Guard As-F Idler	226-0190
5M-3499	Shaft-Planet	319-3475
5M-3560	Bearing-Sleeve	392-4521
5M-3941	Shaft-Planet	215-1691
5M-3942	Shaft-Planet	215-1692
5M-3996	Gear-Ring	214-0527
5M-4427	Gear-Sun	214-0529
5M-5018	Bearing-Roller	380-7509
5M-5073	Joint Gp-Univ	325-6113
5M-5822	Gear-Pump Drive	247-4120
5M-5856	Pipe-Extension	373-1913
5M-5894	Cover-Bearing	448-2438
5M-6120	Gear-Sun	213-8740
5M-6126	Bearing	377-7433
5M-6198	Shaft-Planet	215-1694
5M-6199	Shaft As-Planet	215-1694
5M-6208	Gear-Ring	247-4121
5M-6210	Shaft-Planet	219-9683
5M-6211	Shaft-Planet	219-9684
5M-6212	Tube	390-0996
5M-6636	Support-Frame	235-8007
5M-6637	Bearing-Sleeve	380-7376
5M-6651	Hub-Gear	211-2135
5M-6651	Hub-Gear	211-2135
5M-6670	Shaft-Sprocket	216-7847
5M-6674	Guard-F Idler Lh	226-2736
5M-6709	Check As-Ball	380-7542
5M-7290	Cage-Bearing	216-7848
5M-7306	Cylinder	226-2737
5M-7340	Cage-Bearing	325-6034
5M-7341	Cover-Bearing	452-0443
5M-7342	Flange-Shaft	215-1696
5M-7344	Gear-Fifth	213-8741
5M-7701	Cylinder	385-7229
5M-7841	Gear-Ring	214-0525
5M-7864	Pump Gp-Scavenge	226-0169
5M-7869	Gear-Ring	214-0530
5M-7875	Carrier-Front	213-4495
5M-7882	Joint Gp-Univ	297-7210
5M-7923	Shaft-Output	215-1697
5M-7925	Bearing-Roller	419-7774
5M-7936	Bearing-Outer	386-4953
5M-7955	Shaft As-Planet	364-5273
5M-9644	Bearing-Outer	384-5929
5N-1841	Flange-Pipe	426-0029
5N-1932	Shaft-Clutch	425-0216
5N-2902	Seal-Oil	314-8540
5N-3274	Plate	425-3648
5N-4378	Shaft As-Pump	311-9456
5N-4504	Plate-Port	397-5048
5N-6165	Bearing	425-3587
5N-8501	Head As-Cyl	256-4762
5N-8657	Manifold-Exhaust	261-0886
5N-8879	Manifold-Exhaust	261-0898
5N-9055	Manifold-Exhaust	261-0890
5P-0403	Bearing-Roller	420-6542
5P-1370	Bearing As-Rlr	416-2164
5P-1949	Cup-Rlr Bearing	415-1916
5P-2448	Bearing-Ball	399-6064
5P-2503	Cup-Rlr Bearing	384-5930
5P-2504	Cone-Rlr Bearing	420-6541
5P-2526	Cup-Rlr Bearing	380-7498
5P-3489	Race-Brg Outer	396-9905
5P-3490	Cone-Rlr Bearing	380-7518
5P-3930	Bearing As-Rlr	419-6022
5P-4992	Bearing-Ball	380-1507
5P-5044	Race-Brg Outer	417-9479
5P-5045	Bearing-Spl Ball	415-1917
5P-5066	Bearing-Outer	416-2165
5P-5067	Race-Spl Rlr Brg	396-4137
5P-5167	Race-Brg Outer	417-4529
5P-5354	Cup-Rlr Bearing	399-4445
5P-5410	Bearing-Spl Ball	396-4134
5P-5411	Race-Brg Outer	417-9481
5P-6254	Bearing	420-2495
5P-7487	Bearing-Aligning	434-3300
5P-7802	Bearing-Aligning	420-2496
5P-7807	Bearing-Ball	314-8502
5P-8043	Bearing-Cone	423-6989
5P-8053	Kit-Gasket (Sch)	415-1901
5P-8054	Gasket Kit	437-8109
5P-8194	Ring-Retaining	308-9920
5P-8366	Gasket Kit - Sch	387-2911
5P-8545	Gasket Kit	437-8626

Part Cross-Reference

Part Numbers Beginning with 5 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
5P-8768	Kit-Gasket (Scl)	393-1024
5P-8772	Gasket Kit	383-1575
5P-8789	Gasket Kt	393-3620
5P-8876	Cup-Rlr Bearing	416-2170
5P-8950	Gasket Kit	393-3621
5P-8970	Gasket Kt-Liner	383-1576
5P-8974	Gasket Kit - Wp	387-2912
5P-9176	Bearing	396-4141
5P-9177	Race-Brg Inner	396-4139
5P-9237	Gasket Kit	438-0174
5P-9301	Bearing-Spl Ball	417-4496
5P-9439	Bearing-Spl Ball	371-4306
5P-9505	Cone-Roller Brg	420-6540
5P-9514	Bearing-Ball	417-9467
5P-9531	Cone-Rlr Bearing	386-4956
5P-9538	Bearing-Roller	421-8183
5P-9552	Gasket Kt	393-3623
5P-9553	Gasket Kit - Wp	393-3624
5P-9561	Gasket Kt-V G	437-8106
5P-9568	Gasket Kit	393-3625
5P-9769	Cone-Rlr Bearing	422-6486
5P-9814	Gasket Kt-Vg	393-3635
5P-9840	Kit-Gasket-Sch	437-8140
5P-9841	Gasket Kit - Vg	393-3626
5P-9962	Bearing-Aligning	399-4397
5P-9972	Gasket Kit	393-5207
5S-0160	Strip-Guard	226-2738
5S-0161	Strip-Guard	226-2739
5S-0192	Pinion-Fdr	215-1698
5S-0464	Gear-First Red	216-7852
5S-0927	Sleeve-Wear	425-3453
5S-0928	Carrier-Ring	443-2969
5S-1211	Cover-Valve	314-8665
5S-1220	Lifter As-Valve	387-2926
5S-1601	Pump Gp-Gr 2 Bsc	386-3054
5S-1684	Gasket Kt-V Gr	393-5224
5S-1757	Insert-Seat	311-9401
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4326	Housing-Screen	435-4790
5S-4442	Bearing-Spl Ball	419-6025
5S-4557	Bearing	311-9360
5S-4863	Holder As-Cage	215-1732
5S-5879	Bracket-Shaft	330-9247
5S-5917	Screw-Rocker Adj	380-7537
5S-5918	Rod-Valve Push	394-0903
5S-6531	Holder As-Cage	214-2078
5S-6795	Chamber As	242-3437
5S-6978	Shaft-Planet	221-9103
5S-7010	Shaft-Planet	221-9104
5S-7630	Bearing-Sleeve	394-0219
5S-7877	Bearing-Spl Ball	392-4491
5S-7893	Joint-Drive	380-7387
5S-7894	Flange As	216-7854
5S-8543	Bearing-Sleeve	376-3635
5S-8767	Gear-First	226-6085
5S-9080	Pulley-Alt Drive	264-5883
5T-0735	Chain Gp	390-5262
5T-0906	Cover	282-6625
5T-0925	Actuator Gp-Bk	379-0198
5T-0975	Camshaft-Brake	422-4935
5T-0999	Camshaft-Brake	422-4934
5T-1362	Univ Joint As-5C	325-6011
5T-2925	Strip-Wear	282-6564
5T-2926	Shoe-Circle Gde	302-2699
5T-3030	Pin As	389-6308
5T-3288	Yoke	424-0743
5T-3323	Pin As	380-7394
5T-3327	Pin As	383-2130
5T-3329	Pin As	380-7395
5T-5157	Camshaft-Lh	394-9189
5T-5158	Camshaft-Rh	394-9190
5T-5222	Shoe-Circle Gde	297-7261
5T-5682	Driver	418-9579
5T-6619	Shoe-Circle Gde	468-9792
5T-6620	Shoe-Circle Gde	424-4943
5T-6819	Pin	425-2563
5T-6820	Bearing	425-3447
5T-7129	Housing	472-8013
5T-7130	Housing	396-0656
5T-8365	Strip-Wear	380-7418
5T-8367	Strip-Wear	297-7263
5T-8500	Shoe-Circle Dr	243-0359
5T-8501	Shoe-Circle Dr	243-0358
5T-8525	Plate	389-6307
5T-8526	Pin As.	396-7270
5T-8528	Pin As.	396-7269
5T-8652	Pin As	383-2131
5T-8654	Pin As	396-0668
5T-8687	Pin As	423-3542
5T-8739	Spider Gp-Brg&	373-5386
5T-9430	Race-Seal Ring	398-8347
5T-9536	Roller-Ejector	399-8559
5T-9594	Pin As	419-6069
5U-0557	Pump Gp-Vn Bsc-B	422-8175
5V-1168	Spider & Brg As	377-7435
5V-1274	Spider	385-6110
5V-1508	Pin As.	361-1703
5V-1509	Pin As	319-3443
5V-1511	Pin As	418-1945
5V-1530	Link As	374-1463
5V-1882	Pin As	361-1700
5V-4573	Disc	388-0591
5V-5279	Bearing-Sleeve	299-1966
5V-5661	Bearing-Sleeve	299-1965
5V-5866	Pin As.	361-1707
5V-5917	Pinion-Diff	297-7224
5V-6125	Diaphragm	384-5931
5V-6327	Yoke-Flange Bk	391-1086
5V-6328	Yoke As	451-9035
5V-7222	Gear-Final Drive	231-0237
5V-7574	Ring-Retaining	392-4483

Part Numbers Beginning with 6

Original Part Number	Part Name	Classic Part Number
6A-7099	Bearing-Sleeve	388-0644
6A-7129	Bearing-Sleeve	301-3130
6A-7196	Pilot-Front	385-7200
6B-3158	Shoe-Yoke Lh	243-0357
6B-3223	Cup-Bearing	399-6065
6B-5163	Bearing	417-4514
6B-6224	Ferrule	419-4738
6B-7178	Fork-Band Adj	299-2009
6B-7469	Spacer	417-4535
6C-0570	Pump Gp-Mtrg Bsc	374-5380
6C-0739	Carrier As	231-0012
6C-1573	Rod	297-7238
6C-3500	Shaft-Bev Pinion	384-4788
6C-3617	Support-Trunnion	374-4712
6C-5062	Pinion	231-0016
6D-0217	Bearing-Sleeve	325-6022
6D-0738	Pinion-Dif Bevel	394-9840
6D-1734	Cup-Roller Brg	416-2171
6D-2348	Disc-Friction	380-7489
6D-4671	Ballstud	420-6530
6D-4909	Cap-Pivot	297-7159
6D-5415	Plate	382-8043
6D-6859	Bearing	330-9248
6D-7788	Joint	380-7388
6D-8671	Bolt-Draft	243-0333
6E-0775	Head	425-9373
6E-0787	Bearing-Sleeve	425-6443
6E-1108	Bearing-Sleeve	325-6023
6E-2190	Rod As	394-8213
6E-2387	Cartridge Gp	422-8132
6E-2396	Cartridge Gp	422-8122
6E-2928	Pump Gp-Vn Bsc-A	426-1701
6E-2929	Pump Gp-Vn Bsc-A	422-8157
6E-2930	Pump Gp-Vn Bsc-B	422-8158
6E-2931	Pump Gp-Vn Bsc-B	422-8161
6E-2932	Pump Gp-Vn Bsc-B	422-8155
6E-4258	Cartridge	422-8133
6E-4730	Pump Gp-Vn Bsc-B	426-1925
6E-4892	Cyl Gp-089 478 Y	394-9828
6E-4985	Cover-Filter	424-2015
6E-5028	Rod As	425-9372
6E-5449	Bearing-Sleeve	464-4048
6E-5831	Pump Gp-Vn Bsc-A	426-1699
6E-6153	Plate-Port	346-5678
6E-6163	Shaft	346-5679
6E-6416	Cylinder As	425-9371
6E-6474	Cartridge Gp	422-8135
6E-6476	Pump Gp-Vn Bsc-A	422-8163
6E-6482	Pump Gp-Vn Bsc-B	422-8164
6E-6483	Pump Gp-Vn Bsc-B	422-8176
6F-2904	Bearing	295-5673
6F-2956	Cup-Spl Tapered	420-6538
6F-6992	Cap-Ballsocket	297-7160
6F-7523	Cap-Bearing	325-6039
6G-0078	Breather	435-4789
6G-0387	Disc	394-2579
6G-0389	Spider	384-4800
6G-0400	Shaft-Drive	399-4403
6G-1633	Chain Gp	282-6565
6G-1908	Housing As-Drive	297-7198
6G-1914	Shim	434-1864
6G-1919	Cap-Pivot	243-0337
6G-2707	Shaft-Axle	422-2650
6G-2749	Camshaft	422-4933
6G-2750	Camshaft	422-4927
6G-2947	Shaft	243-0346
6G-3784	Bearing-Sleeve	425-6455
6G-3785	Bearing-Sleeve	425-6454
6G-4372	Strip-Wear	380-7416
6G-4524	Strip-Wear	380-7417
6G-4525	Strip-Wear	282-6624
6G-4642	Shim	434-1863
6G-4680	Adapter	302-2633
6G-4831	Shaft	391-9809
6G-5155	Bearing-Thrust	394-0220
6G-5343	Bearing-Sleeve	450-9169
6G-5704	Piston	394-9838
6G-6844	Bearing-Sleeve	419-6070
6G-6847	Bearing-Sleeve	419-4723
6G-7213	Carrier-Planet	396-9936
6G-8425	Valve Gp-Cont -K	367-6086
6G-9428	Bracket-Rail	396-7264
6G-9429	Bracket-Rail	396-7263
6G-9430	Bracket	418-1938
6H-2577	Spider Gp-Brg&	333-4954
6H-3566	Cone-Bearing	415-1918
6H-3957	Bearing-Ball	311-9358
6H-5843	Thrower-Chsft O	393-3612
6H-5845	Baffle-Oil	390-0926
6I-0031	Line As-Fuel Inj	374-4713
6I-0032	Line As-Fuel Inj	374-4714
6I-0033	Line As-Fuel Inj	374-4715
6I-0034	Line As-Fuel Inj	375-2262
6I-0035	Line As-Fuel Inj	374-4716
6I-0036	Line As-Fuel Inj	374-4717
6I-0037	Line As-Fuel Inj	374-4718
6I-0038	Line As-Fuel Inj	374-4719
6I-1032	Line As-Fuel Inj	390-0931
6I-1035	Line As-Fuel Inj	390-0921
6I-1036	Line As-Fuel Inj	390-0922
6I-1038	Line As-Fuel Inj	390-0923
6I-1099	Manifold-Exh	424-6366
6I-1240	Governor As	380-7538
6I-1327	Bonnet-Valve	455-3273
6I-1345	Shaft As-O Pump	374-7475
6I-1346	Pump Gp-Beo 2 Gr	295-5674
6I-1363	Spider As	380-1517
6I-1364	Spider As	391-9824
6I-1453	Crankshaft As	368-5916
6I-1647	Arm Gp-V Rocker	433-0451
6I-1650	Arm Gp-V Rocker	433-0450
6I-2408	Muffler As.	378-3978
6I-2409	Pipe	383-3693
6I-2726	Bearing-Sleeve	419-4757
6I-2981	Plate-Block	374-7495
6I-3066	Gasket-Cyl Head	380-1518
6I-3662	Muffler As	360-7882
6I-3907	Adapter-Pilot	398-8348
6I-4024	Gasket-Plate	377-5839
6I-4613	Plate-Spacer	380-7405
6I-4689	Gasket-Cyl Head	377-5840
6I-6425	Muffler As	386-3045
6I-6457	Rod	421-8920

Part Cross-Reference

Part Numbers Beginning with 6 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
6I-8132	Pinion	226-6080
6I-8500	Plate-Clutch	377-7436
6I-8510	Housing As - Clu	373-5387
6I-8642	Race-Brg Outer	396-9898
6I-8849	Cone-Rlr Bearing	415-1919
6I-8860	Cup-Roller Brg	380-7495
6I-9103	Bearing-Outer	421-8182
6I-9507	Piston-Clutch	417-9470
6I-9508	Piston-Clutch	390-5274
6I-9509	Plate	398-2960
6I-9808	Bearing-Ball	417-9484
6J-0774	Trunnion	256-4844
6J-2326	Pin	319-3458
6J-3999	Connector	428-7631
6J-5179	Retainer	380-7406
6J-5342	Retainer	325-6182
6J-6043	Bearing-Sleeve	374-1456
6J-6229	Pin	299-2030
6J-6604	Pin	419-6071
6J-7500	Retainer	383-2104
6J-7563	Pin	319-3459
6J-8183	Bracket	394-0195
6J-9258	Trunnion As	256-4846
6J-9480	Pin As	384-4774
6J-9482	Pin As	380-7400
6K-2034	Shaft	297-7249
6K-2694	Bearing-Sleeve	453-6504
6K-2697	Bearing-Sleeve	330-9263
6K-2703	Pin-Lower	252-6853
6K-2704	Pin-Upper	252-6873
6K-2706	Cap-Lower	451-6443
6K-2707	Plate-Lock	319-3470
6K-2899	Bearing-Sleeve	453-6505
6K-3674	Shaft-Bev Pinion	253-1427
6K-3937	Pin	241-2557
6K-4148	Bearing-Sleeve	393-3670
6K-4180	Pin-Upper	252-6854
6K-4189	Spacer	367-6075
6K-4190	Cap-Lower	297-7161
6K-4191	Cap-Upper	300-2576
6K-4192	Pin-Lower	252-6855
6K-4193	Plate-Lock	282-6566
6K-4442	Rod End-Special	373-5388
6K-4597	Yoke As	446-3069
6K-4599	Yoke As	385-6111
6K-4600	Yoke	226-5993
6K-4617	Shaft-Sprocket	221-7951
6K-5513	Pin	241-2558
6K-5528	Cup-Roller Brg	447-8059
6K-5619	Shaft	253-1429
6K-5625	Gear-Bevel	253-1438
6K-5744	Cage-Bearing	330-9266
6K-5745	Retainer-Bearing	330-9281
6K-5746	Bearing-Roller	417-4503
6K-6001	Pin	308-9902
6K-6046	Pin	241-2602
6K-6047	Pin	241-2603
6K-6053	Pin	241-2604
6K-6054	Pin	241-2605
6K-6175	Pin	241-2606
6K-6185	Pin-Cylinder	252-6859
6K-6349	Pin	252-6860
6K-6350	Bearing-Sleeve	451-6444
6K-7161	Pin	241-2559
6K-7162	Pin	241-2560
6K-7164	Pin	241-2561
6K-7165	Pin	241-2562
6K-7166	Pin-Arm Pivot	241-2563
6K-7167	Pin	241-2569
6K-7284	Pin	241-2591
6K-7287	Pin	241-2564
6K-7288	Pin	252-6862
6K-7356	Yoke As	330-9296
6K-8088	Bearing-Roller	399-4428
6K-8275	Cone-Roller Brg	399-6070
6K-8307	Pin	241-2593
6K-8308	Pin	241-2594
6K-8309	Pin	241-2595
6K-8311	Pin	241-2599
6K-8314	Pin	252-6863
6K-8316	Pin	252-6865
6K-8542	Pin	252-6867
6K-8544	Pin	252-6874
6K-8546	Pin	252-6868
6K-8895	Cap	374-6500
6K-8897	Bracket As	299-1977
6K-9070	Washer-Thrust	330-9294
6K-9150	Bearing-Sleeve	330-9264
6K-9151	Bearing-Sleeve	330-9265
6L-2279	Plug-Ptf	419-4739
6L-3353	Rod End-Special	416-2134
6L-4714	Panel-Acl Filter	314-8532
6L-4716	Gasket-Exhaust	398-2951
6L-6481	Elbow-Air Inlet	311-9385
6L-6490	Sleeve-O-Ring	398-8346
6L-7751	Rod End-Spher	472-8015
6L-7816	Seal-O-Ring	314-8542
6L-8761	Sleeve-O-Ring	396-7268
6L-8968	Coupling-Exhaust	311-9381
6M-1592	Bearing-Sleeve	374-1462
6N-0425	Coupling-Exhaust	394-9836
6N-0597	Pulley-Fan	420-6391
6N-0622	Elbow-Exhaust	380-7534
6N-0714	Pulley-Alt	264-5884
6N-0731	Muffler As-Exh	382-8018
6N-0957	Core As-Radiator	398-2938
6N-0977	Bearing-Sleeve	417-4524
6N-1036	Gear-Oil Pump	279-4991
6N-1186	Pulley-Belt	448-2424
6N-1218	Core As-Radiator	379-0181
6N-1553	Coupling-Exhaust	295-6422
6N-1572	Mount As	308-9876
6N-1813	Pump Gp-Bft 1 Gr	330-9279
6N-1878	Muffler As	360-7883
6N-1931	Plunger	379-0171
6N-1965	Line As-F Inj	250-7535
6N-1966	Line As-F Inj	250-7536
6N-2460	Pump Gp-Eng Oil	395-1316
6N-2549	Mount As	384-3467
6N-2687	Spider As.-Fan	385-7199
6N-2789	Pulley	264-5886
6N-2820	Pump Gp-Eng Oil	415-1903
6N-3025	Tube As	419-4656
6N-3256	Mount As	314-8688
6N-3641	Pulley-Tightener	380-7536
6N-3964	Muffler As	360-7884
6N-4184	Muffler As	385-7226
6N-4597	Coupling-Exhaust	369-9489
6N-5300	Pulley-Cshaft	378-3979
6N-5354	Pipe-Extension	430-8130
6N-5392	Manifold-Exhaust	394-0905
6N-5435	Ejector As-Exh	443-2663
6N-5437	Muffler As.	247-2674
6N-5482	Plate-Friction	376-3637
6N-5967	Elbow	394-9825
6N-5978	Coupling-Exhaust	369-9487

Part Numbers Beginning with 6 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
6N-5987	Shaft-Water Pump	390-0998
6N-6015	Pump Gp-Water	453-6502
6N-6490	Bracket As-Fan	420-8569
6N-6721	Coupling	377-5830
6N-6969	Chamber As	247-3299
6N-7154	Rotocoil As	380-7556
6N-7174	Shield-Oil	314-8544
6N-7175	Rotocoil As	382-8042
6N-7263	Gasket-Cyl Head	380-7386
6N-7295	Manifold-Exhaust	261-0903
6N-7653	Gage As-O Level	428-7206
6N-7695	Cover-Oil Pump	441-1564
6N-8441	Bearing-Sleeve	380-7371
6N-8645	Ejector As	388-0560
6N-8992	Adapter-Fan	394-9810
6N-9133	Gasket-Plate	398-2959
6N-9211	Core As-O Clr	435-6049
6N-9653	Core As-Oil Clr	386-3056
6N-9654	Core As-Oil Clr	435-4787
6N-9743	Support-Muffler	308-9940
6N-9752	Core As-Oil Clr	468-5016
6P-0169	Hub-Fly Clutch	297-7204
6P-0236	Guide-Lever	422-6475
6P-0549	Guard-Fdr Wear	223-4812
6P-0593	Bearing-Roller	386-4959
6P-0748	Carrier-Planet	373-5389
6P-2090	Base-Xmsn O Fil	397-5049
6P-2233	Gear-Planet	281-1690
6P-2234	Gear-Planet	380-1479
6P-2322	Plate	389-6311
6P-2473	Gear-Ring	449-9834
6P-2474	Gear-Ring	480-8277
6P-2776	Gear-Final Drive	217-7718
6P-2923	Yoke As	382-6891
6P-3593	Support	229-8231
6P-3597	Retainer	222-1770
6P-3735	Shaft-Planet	368-0103
6P-3904	Retainer-Bearing	396-0644
6P-4327	Pad	384-3472
6P-5172	Guard Gp-Rec -A	226-0196
6P-5173	Guard Gp-Rec -A	229-8617
6P-5343	Rod Gp-Tck Adj	226-0200
6P-5404	Plate-Cl & Brake	325-6168
6P-6653	Plate-Guide	226-0208
6P-6739	Shaft-Planet	308-9929
6P-7357	Gear As-Pump	388-0561
6P-7358	Pump Gp-Gr 1 Bsc	308-9913
6P-7564	Carrier-Ring	384-3850
6P-7704	Carrier-Ring	314-8658
6P-7706	Carrier-Ring	388-6603
6P-7742	Shaft-Planet	281-1695
6P-7743	Shaft-Planet	281-1696
6P-7968	Plate-Clutch	416-2133
6P-8003	Gear-Planet	281-1689
6P-8005	Gear-Planet	281-1691
6P-8340	Sleeve	422-7895
6P-8829	Retainer	380-7407
6S-2828	Cup-Roller Brg	384-5932
6S-3051	Cup-Rlr Brg	415-1928
6S-3158	Yoke	380-1478
6S-3203	Drum-Ster Cl	388-0590
6S-3397	Shaft-Ster Cl	388-6593
6S-3398	Drum-Cl Driving	390-5279
6S-3442	Strip-Wear	386-4929
6S-3457	Pin	325-6147
6S-3463	Bearing-Sleeve	374-6513
6S-3465	Bearing-Sleeve	382-6903
6S-3472	Pin As.	421-9629
6S-3474	Pin As	375-9981
6S-3975	Trunnion	396-9940
6S-3976	Bearing	388-0589
6S-4074	Bearing	330-9249
6S-6009	Yoke-Univ Joint	446-3070
6S-6031	Cup-Rlr Brg	415-1920
6S-6032	Cone-Rlr Brg	415-1921
6S-6902	Spider & Brg As	390-5280
6S-7220	Plate As	396-0657
6T-0016	Pump Gp-Gr 4 Bsc	418-1957
6T-0064	Shaft-Planet	295-6442
6T-0239	Piston	418-9591
6T-0243	Plate-Thrust	325-6169
6T-0248	Ring-Seal	295-6440
6T-0952	Pad As	367-6087
6T-0956	Pad As	367-6088
6T-0960	Pad As	367-6089
6T-1235	Gasket	433-8190
6T-1261	Insert	418-1937
6T-1702	Support As	299-2065
6T-1705	Shaft-Pump Drive	283-5201
6T-1711	Plate	389-6324
6T-1724	Bar As-Equalizer	283-5223
6T-1933	Collar-Idler End	226-2746
6T-1935	Guide-Frt Idler	440-3257
6T-1980	Collar-Idler End	226-0210
6T-1996	Plate-Clutch	368-0117
6T-2293	Piston-Load	426-0040
6T-2975	Retainer	420-3219
6T-3080	Plate-Cl & Brake	325-6170
6T-3324	Housing As-Cl	391-9827
6T-3651	Pump Gp-Gr 1 Bsc	345-1978
6T-3726	Carrier As	390-5269
6T-4481	Shaft-Planet	221-7946
6T-5383	Gear-Ring	375-2624
6T-5611	Spacer	435-8520
6T-6779	Housing As-Clu	398-2962
6T-7407	Shaft-Pivot	432-8910
6T-7882	Gear-Planet	296-1352
6T-8249	Pin	399-8542
6T-8250	Retainer	319-3473
6T-8801	Guide As	396-0640
6T-8886	Disc-Ster Cl	380-7517
6T-8907	Pad As	380-7391
6T-9564	Guide As	416-5530
6V-0214	Kit-Gasket-Mch	437-4590
6V-0216	Kit-Gasket-Sch	437-4589
6V-0220	Kit-Gasket(Cl)	437-4588
6V-0229	Gasket Kit	437-4587
6V-0233	Kit-Gasket-T	437-4586
6V-0235	Gasket Kit	437-4585
6V-0237	Kit-Gasket-Exp	437-4584
6V-0241	Gasket Kit - F	393-3628
6V-0327	Cup-Rlr Brg	399-4444
6V-0328	Cone-Rlr Brg	399-4442
6V-0329	Cone-Rlr Brg	396-4142
6V-0330	Cup-Rlr Brg	422-6487
6V-0347	Cone-Spl Tapered	420-6537
6V-0456	Bearing As-Rlr	435-4041
6V-0538	Bearing-Spl Ball	398-2935
6V-0600	Gasket Kit	437-4583
6V-0611	Kit-Gasket-Fs	437-4581
6V-0662	Cup-Rlr Brg	420-6539
6V-0664	Cone-Rlr Brg	423-6990

Part Cross-Reference

Part Numbers Beginning with 6 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
6V-0832	Cone-Rlr Bearing	453-3654
6V-1013	Bearing	396-4140
6V-1014	Race-Spl Rlr Brg	416-2173
6V-1033	Rod End-Spher	375-5444
6V-1168	Gasket Kit	437-4565
6V-1181	Gasket Kit	437-4578
6V-1339	Gasket Kit	388-0651
6V-1395	Gasket Kt-Vg	438-0173
6V-1781	Bearing-Spl Ball	380-1508
6V-1785	Kit-Gasket-Mch	437-3190
6V-2202	Bearing-Spl Ball	380-1574
6V-2209	Gasket Kit	419-4732
6V-2237	Gasket Kit	437-3212
6V-2246	Gasket Kit	391-1091
6V-2466	Kit-Gasket-Fs	437-3211
6V-2502	Gasket Kit	437-3210
6V-2523	Gasket Kit	437-3209
6V-2527	Gasket Kit	387-2918
6V-2529	Gasket Kit	437-3208
6V-2539	Gasket Kit	437-3207
6V-2543	Gasket Kit	437-3206
6V-2544	Gasket Kit	437-3205
6V-2545	Gasket Kit - F	437-3204
6V-2546	Gasket Kit - F	437-3203
6V-2547	Gasket Kit - F	437-3189
6V-2580	Gasket Kt-V G	393-3637
6V-2909	Gasket Kit - F	388-0652
6V-2936	Gasket Kt-V G	387-2915
6V-2981	Gasket Kit - Vg	437-3201
6V-2983	Gasket Kt	437-3213
6V-2998	Gasket Kit	437-3199
6V-3709	Gasket Kit	393-5223
6V-3710	Gasket Kit	447-8646
6V-3736	Gasket Kt-Instl	438-0157
6V-3737	Gasket Kt-Lines	438-0171
6V-3743	Kit-Gasket Pump	438-0169
6V-3749	Gasket Kt	387-2916
6V-3751	Gasket Kt-V G	393-5222
6V-3831	Seal-O-Ring	436-2657
6V-4350	Race-Spl Rlr Brg	384-5933
6V-4540	Gasket Kit - Wp	393-1021
6V-4582	Bearing-Ball	380-1504
6V-4714	Kit-Gasket (Cl)	437-3197
6V-4785	Gasket Kit - Fs	388-0661
6V-5003	Bearing-Aligning	420-2498
6V-5413	Gasket Kit	390-5291
6V-5414	Gasket Kit	434-7289
6V-5426	Kit-Gasket-Wp	438-0167
6V-5428	Kit-Gasket-Ocl	386-3044
6V-5465	Gasket Kt	438-0166
6V-5467	Gasket Kt-F Sys	387-2924
6V-5468	Kit-Gasket	438-0165
6V-5495	Gasket Kt-Exp Tk	393-5211
6V-5905	Gasket Kit	437-3195
6V-5918	Gasket Kit	437-3194
6V-5919	Gasket Kit	437-3193
6V-5920	Gasket Kit - F	388-0653
6V-5976	Kit-Gasket (Rs)	393-5200
6V-6371	Gasket Kit	438-0164
6V-6375	Gasket Kt-Lines	438-0162
6V-6384	Kit-Gasket-Wp	387-2917
6V-6385	Kit-Gasket (Wp)	438-0161
6V-6894	Rebuild Kt-Pump	383-3696
6V-6896	Rebuild Kit	390-1006
6V-7266	Gasket Kt-Head	393-5212
6V-7459	Gasket Kit	391-1095
6V-7476	Kit-Dt Gasket	390-5282
6V-7479	Gasket Kt-Cyl Hd	438-0160
6V-8041	Gasket Kit	437-3191
6V-9221	Gasket Kit	391-1092
6V-9228	Gasket Kt-Cyl Hd	438-0159
6V-9255	Gasket Kt	387-2913
6V-9259	Gasket Kt	393-5213
6V-9698	Gasket Kt-Pump	388-0647
6V-9725	Kit-Gasket (F)	437-3200
6V-9729	Gasket Kit - F	393-5195
6V-9736	Kit-Gasket (F)	437-3202
6V-9921	Gasket Kit	437-3236
6W-0240	Bearing-Brace	297-7143
6W-1958	Element	390-5284
6W-2899	Shaft-Pinion	446-3057
6W-3662	Ring-Drive	446-3079
6W-4281	Yoke-Flange	308-9949
6W-4284	Cage-Bearing	308-9832
6W-4733	Retainer-Bearing	391-1089
6W-4751	Yoke As	398-8337
6W-4755	Joint Gp-Univ	396-9924
6W-4789	Shaft Gp-Drive-D	452-0444
6W-5119	Housing-Support	450-8051
6W-7290	Shaft-Planet	308-9930
6W-7352	Retainer	424-0741
6W-9172	Bearing	389-6330
6W-9173	Bearing	374-1457
6W-9677	Tube As-Rh	388-6569
6W-9678	Tube As-Lh	388-6570
6Y-0145	Plate-Locking	419-8801
6Y-0210	Bearing-Sleeve	453-6506
6Y-0305	Cage As-Bearing	297-7150
6Y-0306	Bearing-Sleeve	391-1104
6Y-0576	Support As	416-5531
6Y-0579	Coupling	434-9636
6Y-0926	Gear-Planet	295-6427
6Y-0984	Gear-Ring	295-6428
6Y-1031	Cone-Rlr Bearing	434-5098
6Y-1032	Cup-Rlr Bearing	434-5097
6Y-1084	Impeller-Conv	380-1477
6Y-1089	Turbine-Conv	385-6112
6Y-1090	Stator-Converter	385-6113
6Y-1320	Plate-Clutch	384-5935
6Y-1603	Housing-Clutch	438-1818
6Y-1604	Carrier As	468-9790
6Y-1690	Carrier-Ring	384-3849
6Y-2027	Disc-Friction	377-7441
6Y-2065	Mount As-650 Cup	377-5844
6Y-2539	Cone-Roller Brg	464-4050
6Y-2540	Cup-Roller Brg	434-8985
6Y-2689	Coupler	422-3508
6Y-2878	Retainer	424-0740
6Y-3151	Stator-Converter	388-6562
6Y-3484	Bearing-Spl Ball	416-2166
6Y-3545	Pin	391-9815
6Y-3896	Pin As	325-6132
6Y-3955	Bearing-Ball	417-9485
6Y-4027	Pin	325-6148
6Y-4457	Bearing-Aligning	420-2504
6Y-4573	Carrier As	421-7243
6Y-4689	Bearing-Aligning	420-6532
6Y-4819	Carrier-Planet	296-1348
6Y-5348	Disc-Friction	384-4827
6Y-5692	Plate-Brake	380-7492
6Y-5793	Ring-Seal	451-9028
6Y-5812	Bearing-Sleeve	325-6019
6Y-5814	Pin	389-6305
6Y-5913	Disc-Friction	391-9836
6Y-5914	Disc-Friction	390-5265
6Y-5915	Disc-Friction	384-5936

Part Numbers Beginning with 6 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
6Y-5916	Disc-Friction	377-7442
6Y-6126	Plate-Wear	325-6174
6Y-6127	Plate-Wear	325-6175
6Y-6134	Bearing-Sleeve	325-6013
6Y-6234	Bearing-Sleeve	325-6014
6Y-6236	Bearing-Sleeve	325-6024
6Y-6382	Strip	419-0888
6Y-6582	Plate-Wear	419-2307
6Y-6751	Pin	325-6149
6Y-6752	Pin	325-6150
6Y-6775	Pin	325-6151
6Y-6832	Bearing-Rlr As	421-8181
6Y-7471	Pin-Pivot	325-6152
6Y-7474	Pin-Pivot	325-6153
6Y-7652	Cup-Rlr Brg	399-6067
6Y-7795	Pad As	391-9816
6Y-7796	Pad As	391-9817
6Y-7909	Disc-Friction	374-4676
6Y-7914	Disc-Friction	390-5264
6Y-7916	Disc-Friction	428-7204
6Y-7920	Disc-Friction	388-0587
6Y-7929	Disc-Friction	456-0555
6Y-7934	Disc-Friction	384-5937
6Y-7935	Disc-Friction	383-2121
6Y-7946	Disc-Friction	384-4801
6Y-7956	Disc-Friction	374-4677
6Y-7965	Disc-Friction	392-4518
6Y-8037	Guide As	435-9915
6Y-8248	Pin	325-6154
6Y-8675	Housing As	418-9584
6Y-8842	Block-Rubber	432-8274
6Y-9885	Bearing-Rlr As	396-9906
6Y-9930	Mount As	360-2353
6Y-9960	Mount As.	376-3639

Part Numbers Beginning with 7

Original Part Number	Part Name	Classic Part Number
7B-5088	Drum-Steer Cl Dr	223-4813
7B-7515	Bearing-Ball	399-6059
7C-0145	Core As-Oclr	374-4720
7C-0307	Gasket	399-8571
7C-1067	Impeller-Pump	378-3980
7C-1068	Impeller-Pump	378-3981
7C-1371	Coupling-Exhaust	369-9490
7C-2880	Bell As-Suction	380-1520
7C-3039	Core As-Oclr	363-7451
7C-3567	Mount As	314-8689
7C-3729	Pulley	376-9066
7C-3760	Tube As-O Drain	375-5443
7C-3862	Camshaft	458-0151
7C-3938	Pulley-Alt	433-2030
7C-4297	Seal As-Cshaft	325-6192
7C-4349	Mount As	383-2117
7C-5403	Tube As	374-4673
7C-5665	Elbow-90 Deg	399-8547
7C-5851	Muffler As	298-2790
7C-6398	Muffler As	360-7885
7C-6450	Pipe Gp-Ext	377-5862
7C-6628	Pulley-Alt	396-9894
7C-6697	Shaft - Idler	425-9370
7C-6976	Bearing-Conn Rod	419-6317
7C-6977	Bearing-Conn Rod	419-6316
7C-7344	Muffler As	360-7886
7C-7955	Gasket-Cover	382-6899
7C-8365	Drive Gp-Fan Bsc	433-2025
7C-9198	Block	419-2303
7D-1945	Gear-Worm	469-4668
7D-4519	Shaft	245-5807
7D-4523	Coupling	245-5817
7D-5859	Adapter	297-7136
7D-5861	Adapter	243-0364
7D-6524	Shaft-Axle	228-8917
7D-7259	Bearing-Roller	394-9201
7D-7442	Hub-Fd Gear	228-8918
7D-7607	Gear-Dif Bevel	388-0595
7D-7889	Gear-Ring	275-5276
7D-8225	Seal-Ring	472-8016
7D-8226	Seal-Ring	472-8017
7D-8348	Cup-Rlr Brg	384-5939
7D-8349	Cone-Rlr Brg	419-6074
7D-8354	Sprocket	398-8335
7D-8362	Cover	396-0658
7D-8434	Disc	377-7443
7D-8437	Cone-Roller Brg	380-1502
7D-8636	Cone-Bearing	418-9606
7D-8637	Cup-Bearing	418-9607
7D-9267	Yoke	330-9297
7E-0558	Bearing-Rod	419-7256
7E-0559	Bearing-Rod	419-7257
7E-0853	Muffler As	360-7887
7E-2888	Gear-Fuel Pump	397-5062
7E-2944	Muffler As	360-7888
7E-3205	Manifold-Inlet	376-9060
7E-3455	Tube As	374-4721
7E-3509	Pipe As-Ex Ext	373-1907
7E-3557	Spider As-Fan	430-4471
7E-3909	Tube-Exhaust	398-8339
7E-4728	Rod As-Conn	379-8863
7E-5085	Bushing	377-5829
7E-5287	Elbow As-Ex	430-4470
7E-5663	Muffler As	247-2667
7E-5816	Shaft-Fan	399-8552
7E-5996	Rod As-Conn	379-8864
7E-6002	Bearing-Sleeve	417-4523
7E-6003	Bearing-Sleeve	417-4522
7E-6004	Bearing-Sleeve	417-4520
7E-6794	Arm As-Injector	433-0449
7E-7302	Bracket	416-5497
7E-7894	Bearing-Rod	419-7260
7E-8830	Bracket As-Fan	383-3697
7E-8926	Head Kt-Cyl	377-5847
7E-9595	Core As-Radiator	396-9926
7E-9907	Spacer-Fp Timing	394-0222
7E-9918	Repair Kit-Major	388-0655

Part Cross-Reference

Part Numbers Beginning with 7 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
7E-9980	Camshaft	377-5851
7F-2742	Bearing-Ball	422-6488
7F-7780	Pin-Anchor	384-4825
7F-9541	Pin As-Drawbar	296-1361
7F-9547	Pin As.-Drawbar	295-0414
7G-0437	Plate-Clutch	417-9466
7G-2037	Joint Gp-Univ	226-8017
7G-2262	Pump Gp-Gr 2 Bsc	421-1552
7G-2474	Gear-Planet	300-2577
7G-2475	Gear-Planet	223-4815
7G-2476	Gear-Planet	223-4816
7G-2480	Gear-Planet	226-6091
7G-2481	Gear-Planet	226-6092
7G-2487	Gear-Planet	221-9092
7G-2492	Gear-Planet	239-7933
7G-2494	Gear-Planet	422-2490
7G-2496	Gear-Planet	446-3071
7G-2500	Gear-Planet	296-1350
7G-2517	Gear-Planet	213-8747
7G-2521	Gear-Planet	213-8749
7G-2824	Piston	295-6439
7G-2828	Plate-Clutch	325-6171
7G-2830	Ring-Seal	295-6441
7G-3451	Gear-Planet	297-7188
7G-3452	Gear-Planet	275-5290
7G-3453	Gear-Planet	377-7444
7G-3454	Gear-Planet	300-2578
7G-3455	Gear-Planet	300-2582
7G-3456	Gear-Planet	300-2583
7G-3457	Gear-Planet	308-9857
7G-3461	Gear-Planet	275-5291
7G-3707	Piston-Clutch	302-2691
7G-3815	Pump Gp-Gr 2 Bsc	226-0171
7G-4281	Housing As-Spt	297-7201
7G-4306	Plate-Center	297-7229
7G-4605	Support As	387-2938
7G-4758	Gear-Planet	288-8723
7G-4990	Case-Xmsn	388-6561
7G-5444	Carrier-Planet	297-7165
7G-5445	Carrier-Planet	469-4669
7G-5572	Gear-Sun	300-2580
7G-5589	Gear-Ring	281-1692
7G-5593	Gear-Sun	300-2581
7G-5614	Shaft-Planet	281-1697
7G-5618	Manifold As	283-5204
7G-5746	Housing-Clutch	392-4520
7G-5749	Piston-Clutch	416-2132
7G-5780	Shaft-Planet	325-6196
7G-5783	Gear-Planet	288-8724
7G-5784	Gear-Planet	288-8725
7G-5972	Plate-Thrust	393-1055
7G-6042	Cage As	216-7856
7G-6044	Cage As	216-7857
7G-6059	Carrier-Ring	393-0911
7G-6062	Gear-Ring	302-2678
7G-6576	Cage As	216-7859
7G-6681	Cage As	216-7860
7G-7013	Coupling-Pump Dr	295-5450
7G-7014	Flange-Stub	396-9925
7G-7218	Carrier-Planet	283-5205
7G-7431	Piston-Selector	432-8911
7G-7610	Gear-Ring	375-2625
7G-7611	Gear-Ring	398-2925
7G-7681	Shaft As	307-1530
7G-7724	Piston-Clutch	283-5206
7G-8389	Guard	226-0202
7G-9555	Univ Joint As	314-8721
7G-9708	Plate-Thrust	393-1054
7H-1318	Coupling-Ster Cl	226-8002
7H-2424	Sleeve-Spring	226-4852
7H-4566	Cup-Roller Brg	399-6068
7H-4710	Bushing-Sleeve	299-1990
7H-6967	Bearing-Ball	422-6489
7H-7628	Bearing	453-3655
7I-4187	Yoke-1550	380-1510
7I-5399	Shaft	421-8178
7I-7180	Piston	421-7142
7I-7181	Piston	393-5217
7I-7712	Cylinder	393-1019
7I-7713	Rod	391-9873
7I-7714	Piston As	422-9530
7I-7717	Spring	392-4525
7J-0086	Bearing As	256-4842
7J-0373	Shaft As	399-8578
7J-0583	Pump Gp-Vn Bsc-A	426-1698
7J-1309	Bearing-Aligning	360-2275
7J-1333	Bearing-Sleeve	295-6408
7J-1334	Bearing-Sleeve	325-6015
7J-1335	Bearing-Sleeve	380-7567
7J-1336	Bearing-Sleeve	384-4776
7J-1337	Bearing	380-7367
7J-1770	Cap-Bearing	396-0664
7J-2604	Bearing-Sleeve	380-7369
7J-3216	Bearing	368-0104
7J-3338	Rod As	394-0906
7J-3351	Head	380-1515
7J-4083	Piston	396-9907
7J-4888	Bearing-Sleeve	385-3789
7J-4981	Trunnion	394-0210
7J-4982	Bearing	383-2132
7J-4983	Cap-Bearing	384-3460
7J-5131	Trunnion	296-1371
7J-5242	Spider & Brg As	450-7548
7J-5356	Guide Lh	416-5503
7J-6250	Bearing-Sleeve	385-3803
7J-6461	Crown	325-6054
7J-6869	Ring	389-6329
7J-6884	Shaft	387-2937
7J-7488	Bearing	256-4836
7J-8210	Cone-Roller Brg	423-6987
7J-8295	Head	388-0566
7J-8301	Cylinder As	473-8931
7J-8302	Cyl Gp-040-334 X	473-8932
7J-8458	Bearing-Sleeve	380-7374
7J-8893	Cone-Roller Brg	374-1846
7J-9344	Bearing-Sleeve	360-2334
7J-9346	Bearing-Sleeve	374-8357
7J-9365	Bearing-Sleeve	453-6507
7J-9366	Bearing-Sleeve	299-1985
7J-9367	Rod As	469-4660
7J-9434	Shaft	380-7557
7J-9682	Bearing-Sleeve	360-2335
7J-9694	Bearing-Sleeve	385-3794
7J-9707	Bearing-Sleeve	308-9821
7J-9708	Bearing-Sleeve	299-1964
7J-9731	Bearing-Sleeve	308-9822
7J-9814	Bearing-Sleeve	308-9824
7J-9842	Bearing-Sleeve	299-1968
7J-9843	Rod As	469-4667
7J-9884	Bearing-Sleeve	325-6016
7K-0078	Bearing-Sleeve	308-9825
7K-0084	Bearing-Sleeve	453-6508
7K-0085	Bearing-Sleeve	393-3646

Part Numbers Beginning with 7 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
7K-0087	Bearing-Sleeve	374-6514
7K-0449	Yoke As	297-7271
7K-0450	Yoke As	297-7272
7K-0686	Trunnion-Rear	297-7266
7K-1127	Nut-Adjusting	451-0744
7K-1510	Washer-Thrust	330-9295
7K-1512	Cover	469-8101
7K-2135	Bearing-Roller	417-4492
7K-3527	Shaft As-Joint	448-9153
7K-3913	Rim As	398-2952
7K-4458	Gear-Final Drive	226-6093
7K-4512	Pinion-Fdr	226-6081
7K-4770	Pinion	226-6082
7K-5213	Pin	252-6869
7K-5448	Cup-Bearing	415-1922
7K-6432	Retainer-Bearing	398-2933
7K-6497	Pin	252-6870
7K-7176	Pin	241-2570
7K-7200	Pin	241-2600
7K-7237	Gear-Planet	231-0009
7K-7431	Hub As	470-3783
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-8877	Cone-Bearing	374-1847
7K-8890	Tube As	391-1098
7K-9343	Pin	241-2571
7K-9344	Pin	241-2607
7K-9345	Pin	241-2608
7K-9346	Pin	252-6871
7K-9347	Pin	252-6875
7K-9348	Pin	252-6872
7K-9360	Pin	319-3461
7K-9506	Pin	241-2584
7K-9513	Pin	241-2596
7K-9514	Pin	241-2597
7K-9515	Pin	241-2589
7K-9528	Bearing-Sleeve	308-9828
7K-9589	Bearing-Sleeve	453-6509
7K-9591	Bearing-Sleeve	365-8826
7K-9592	Bearing-Sleeve	360-2336
7K-9593	Bearing-Sleeve	360-2337
7K-9601	Bearing-Sleeve	360-2338
7K-9602	Bearing-Sleeve	360-2339
7K-9604	Bearing-Sleeve	308-9829
7K-9638	Bearing-Sleeve	365-8827
7K-9639	Bearing-Sleeve	314-8643
7K-9640	Bearing-Sleeve	389-6328
7K-9642	Bearing-Sleeve	360-2340
7K-9643	Bearing-Sleeve	445-7707
7K-9644	Bearing-Sleeve	360-2341
7K-9717	Link As-Rear	434-2447
7K-9794	Link As-Rear	431-5262
7K-9981	Pin As	308-9887
7K-9988	Pin	308-9904
7K-9989	Pin	308-9905
7K-9990	Pin	308-9906
7L-0103	Impeller-Pump	398-2967
7L-0104	Impeller-Pump	311-9395
7L-2041	Shaft-Water Pump	428-7200
7L-4302	Gasket	420-8570
7L-7508	Bearing-Ball	420-6536
7L-8240	Bellows	419-4741
7M-0457	Guard-Frame	226-0217
7M-0665	Bar As-Equalizer	231-3312
7M-0680	Housing As-Susp	444-1841
7M-0699	Cap-Brace Brg	247-4123
7M-0859	Fork As-Shift	297-7172
7M-1154	Bearing-Spl	417-4515
7M-1296	Valve-Relief	390-0990
7M-1776	Plate-Idler Gde	226-0222
7M-1845	Plate As-Spring	384-3474
7M-1850	Strip-Wear	389-6327
7M-1851	Bolt-Spring	226-0223
7M-1856	Pilot-Rec Spg	226-0225
7M-1859	Pilot As-Spring	226-0207
7M-1861	Stop-Spring Rh	226-0228
7M-1862	Stop-Spring Lh	226-0229
7M-1889	Guard As	213-9108
7M-1890	Guard As-Fd Wear	213-9109
7M-2167	Ring-Gov Cont	308-9919
7M-2531	Rod-Tie	297-7239
7M-4046	Bearing-Sleeve	394-8206
7M-4204	Manifold-Exhaust	261-0901
7M-4358	Manifold-Exhaust	261-0907
7M-4603	Body-Fuel Valve	311-9348
7M-4926	Retainer-Piston	314-8538
7M-5334	Cone-Roller Brg	420-2505
7M-5692	Impeller-Pump	433-0791
7M-7219	Bearing-Thrust	384-4816
7M-7226	Gasket-Cam Cover	433-8189
7M-7358	Valve-Inlet	298-2774
7M-7817	Valve-Inlet	311-9474
7M-9398	Plate-Guide	297-7230
7N-0061	Muffler As	360-7889
7N-0110	Core As-Oil Clr	319-3435
7N-0113	Core As-Oclr	388-0564
7N-0128	Core As-Oil Clr	299-1994
7N-0165	Core As-O Clr	295-5670
7N-0619	Pulley-Fan	383-1581
7N-0691	Elbow-Water Rglt	378-3983
7N-1152	Pulley-Fan	333-4951
7N-1164	Mount As	295-5451
7N-1183	Plunger As-Fuel	419-4742
7N-1220	Plunger As-Pump	419-4743
7N-1275	Pulley-Fan	380-7535
7N-1393	Muffler As	374-7477
7N-1572	Cover-Water Pump	377-5854
7N-1760	Ejector As	373-1914
7N-2063	Shaft As-Pump	386-3055
7N-2155	Bearing	383-2133
7N-2156	Bearing-Sleeve	380-7373
7N-2213	Bearing-Sleeve	394-0190
7N-2834	Kit-Repair	374-4723
7N-2871	Line As-Fuel Inj	319-8172
7N-2872	Line As-Fuel Inj	319-8173
7N-2874	Line As-Fuel Inj	298-2779
7N-2875	Line As-Fuel Inj	298-2780
7N-2876	Line As-Fuel Inj	298-2781
7N-2949	Pulley	264-5887
7N-2957	Cover-Rad Cap	361-1722
7N-3349	Shaft As-Drive	394-0889
7N-3350	Gear As-Pump Dr	319-3437
7N-3352	Plate-Spacer	386-3062
7N-3486	Manifold-Exhaust	261-0899
7N-3521	Core As-O Clr	383-3699
7N-3536	Gear-Fuel	279-4993
7N-4170	Pump Gp-Eng Oil	379-0169
7N-4407	Gasket-Rod Comp	433-9853

Part Cross-Reference

Part Numbers Beginning with 7 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
7N-4515	Body As-Piston	311-9346
7N-4618	Ejector As-Exh	397-5060
7N-4674	Muffler As.	373-1910
7N-5089	Gasket	394-0890
7N-5206	Mount As	374-1451
7N-5218	Manifold-Exhaust	435-4786
7N-5219	Manifold-Exhaust	425-2362
7N-5449	Spool-Press Rlf	434-2450
7N-5503	Gear-Cshft Rr	233-2182
7N-5511	Gear As-Idler	233-2180
7N-5539	Muffler As	360-7891
7N-5645	Tube As-Outlet	378-3984
7N-5656	Sleeve	384-3848
7N-5810	Gear As-Idler	233-2179
7N-5815	Gear-Cshft Rr	233-2181
7N-5819	Gear-Hyd Pump Dr	215-1758
7N-5825	Gear-Pto Drive	215-1759
7N-5910	Impeller-Pump	314-8686
7N-6677	Core As-O Clr	299-1995
7N-7091	Line As-Fuel Inj	396-9938
7N-7092	Line As-Fuel Inj	396-9937
7N-7166	Race-Brg Thrust	417-4531
7N-7386	Gasket-Cyl Head	392-4519
7N-7435	Kit-Major Repair	374-4724
7N-7628	Gasket	419-1811
7N-7639	Rotator-Valve	383-1582
7N-7765	Governor As	377-5841
7N-7878	Cover-Plate	434-2401
7N-7998	Plate-Block	374-7496
7N-8018	Seal-Water	418-1964
7N-8021	Plate-Block	374-7497
7N-8022	Gasket-Cyl Head	378-3985
7N-8117	Muffler As	247-2668
7N-8371	Line As-Fuel Inj	373-1901
7N-8629	Coupling-Elbow	419-4664
7N-8828	Pulley	420-6395
7N-8876	Head Gp-Cyl -A	269-5290
7N-8923	Muffler As	416-5499
7N-8957	Gear-Crankshaft	422-2652
7N-9145	Gear-Flywheel	279-4994
7N-9146	Gear-Fly Starter	279-4995
7N-9352	Gasket	433-8188
7N-9647	Muffler As	386-3050
7N-9674	Muffler As	360-7892
7N-9805	Pin-Piston	295-6438
7N-9810	Pin-Piston	311-9432
7P-1577	Pin As	375-9969
7P-2285	Pin As	393-3669
7P-2372	Joint As	367-6072
7P-3214	Pin	425-3452
7P-3466	Bearing-Sleeve	422-9523
7P-3472	Pin	374-8366
7P-4695	Tube	424-0860
7P-4777	Pin	416-5488
7P-5082	Pin As	374-8367
7P-6348	Bearing	399-6042
7P-6531	Shaft-Sun Gear	430-5352
7P-6596	Bearing-Sleeve	295-6409
7P-6768	Rod As	469-4670
7P-6770	Support As	389-6299
7P-6773	Pilot	470-3785
7P-6984	Pin	393-3674
7P-7245	Valve	386-3811
7P-7734	Rod As	376-3643
7P-7858	Bearing-Sleeve	374-8362
7P-8076	Gear-Planet	390-5263
7P-8370	Bearing	295-6410
7P-9568	Gear-Planet	446-3072
7P-9578	Shaft	470-3787
7S-1234	Bushing As-Spt	394-0192
7S-2983	Pump Gp	450-2390
7S-3002	Bearing-Spl Ball	386-4961
7S-3161	Lifter-Valve	279-4996
7S-3206	Seal-O-Ring	436-2656
7S-4000	Piston	416-2143
7S-4097	Adapter-Exh Man	383-3700
7S-4411	Cap As-Rain	373-1912
7S-4497	Gear-Cplg & Sun	444-1842
7S-4523	Gear-Ring	419-8799
7S-4534	Bearing-Caged	417-9497
7S-4629	Pump Gp-Trans	226-0158
7S-5003	Cap As-Rain	379-0184
7S-5787	Chamber As	247-3300
7S-6839	Hub-Clutch	399-4407
7S-6964	Gear-Ring	214-0532
7S-6976	Body As-Pump	419-4649
7S-7043	Mount As	389-6332
7S-7070	Head As-Cylinder	325-6107
7S-7400	Pump Gp	226-0173
7S-7602	Pump Gp-Cl Oil	226-0174
7S-7625	Support As	226-6095
7S-7681	Pipe-Exh Ext	385-7213
7S-7809	Cap As-Radiator	295-6417
7S-7973	Guard-Fd Wear	213-9110
7S-7975	Guard-Fd Wear	239-7966
7S-8443	Muffler	247-2675
7S-8576	Bearing As	435-4848
7S-8577	Shaft-Planet	420-6529
7S-8631	Shaft As	275-5296
7S-8660	Pump Gp-Trans	226-0175
7S-8736	Pipe-Ext Exhaust	382-5066
7T-0119	Support As	299-2066
7T-0204	Bearing-Brace	247-4126
7T-0205	Bearing-Brace	247-4127
7T-0206	Bearing-Brace	297-7144
7T-0341	Support	425-9191
7T-1285	Gear-Planet	297-7190
7T-1776	Slide	396-0659
7T-2036	Cap As-Fuel	361-1721
7T-2336	Disc-Friction	433-7096
7T-2879	Trunnion As	396-7262
7T-3038	Gear-Reverse	445-1097
7T-3039	Gear	445-1095
7T-3173	Piston-Clutch	346-5680
7T-3194	Yoke	346-5681
7T-3343	Plate-Clutch	297-7231
7T-3365	Carrier-Planet	388-6563
7T-3370	Yoke As	302-2702
7T-3566	Piston	394-9191
7T-3676	Hub-Reaction	388-6578
7T-4053	Shaft As-Output	398-2940
7T-4752	Turbine-Conv	416-2148
7T-4753	Stator-Converter	384-5945
7T-4754	Impeller-Conv	385-7231
7T-4971	Cap-Bearing	428-8816
7T-5216	Sleeve-Wear	422-9522
7T-5426	Cone-Roller Brg	453-3657
7T-5510	Pad As-Resilient	367-6090
7T-6427	Pin	319-3462
7T-6652	Cone-Rlr Bearing	416-2124
7T-7621	Bearing As-Rlr	384-4823
7T-8136	Shaft-Planet	314-8714
7T-8174	Gear-Planet	388-0583
7T-8336	Hub	418-9580
7T-8337	Shaft	416-2138

Part Numbers Beginning with 7 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
7T-8816	Bearing-Spl Ball	420-2491
7T-9272	Gear-Sun	296-1354
7T-9370	Gear-Sun	283-5207
7T-9542	Gear-Ring	384-4822
7T-9647	Piston-Clutch	275-5294
7T-9931	Countershaft	215-1760
7T-9989	Housing As-Cl	380-1509
7V-0638	Spacer	425-3651
7V-3719	Collet As	376-3644
7V-5645	Rod-Indicator	397-5061
7V-5979	Gear	231-0238
7V-5981	Driver	231-0256
7V-6715	Pin As	361-1701
7V-6716	Pin As	396-7273
7V-6790	Shaft-Bev Pinion	308-9922
7V-6898	Pin As	241-2539
7V-8640	Spindle	424-4945
7W-0140	Gear-Drive	399-8546
7W-0182	Plunger & Bbl As	391-9893
7W-0205	Core As-Oclr	379-0183
7W-0508	Gear-Fp Drive	296-1351
7W-0561	Pump Gp-F Inj -B	432-8278
7W-0675	Core As-Oclr	434-4016
7W-1058	Tube As-Supply	393-3613
7W-1713	Core Gp-O Clr	438-2010
7W-1927	Ring-Retainer	387-2935
7W-2059	Gasket-Cyl Hd	380-1548
7W-2136	Bearing-Conn Rod	419-7281
7W-2138	Bearing-Main	419-7250
7W-2164	Core As-Oclr	299-1996
7W-2315	Retainer	384-3475
7W-2731	Retainer	423-3541
7W-3145	Plate	422-7894
7W-3580	Bracket-Mtg	418-1939
7W-3773	Pulley-Cshaft	383-1583
7W-4070	Gear-Camshaft	380-1551
7W-4137	Shaft As.	378-3986
7W-4473	Manifold-Ex	443-2095
7W-5095	Gear-Flywheel	425-9190
7W-5164	Gasket	420-8568
7W-5194	Muffler As.	346-5682
7W-5426	Camshaft As.	378-3987
7W-5435	Adapter-Nozzle	374-7493
7W-5524	Ejector As-Exh	397-5056
7W-5687	Hub-Cshft	314-8684
7W-5692	Pulley-Cshaft	386-3041
7W-5696	Hub-Cshft	424-5887
7W-5698	Pulley-Cshaft	295-5679
7W-5699	Pulley-Cshaft	378-3988
7W-5733	Gasket	421-7333
7W-5838	Ejector As-Ex	443-2660
7W-5844	Bearing-Conn Rod	419-4650
7W-5928	Pump Gp-F Inj -B	432-8277
7W-5929	Plunger & Bbl As	391-9895
7W-6459	Core As-Oclr	395-1313
7W-7181	Muffler As-Rh	360-7906
7W-7182	Muffler As-Lh	360-7907
7W-7546	Gasket-Plate	433-8187
7W-8064	Valve-Inlet	384-8705
7W-8584	Manifold-Exhaust	396-9932
7W-9020	Bell As-Pump Suc	378-3989
7W-9027	Base-Oil Cooler	399-8545
7W-9707	Muffler As-Eject	360-9626
7X-2396	Gasket Kit	393-5194
7X-2397	Gasket Kit	393-5193
7X-2522	Gasket Kit	437-8648
7X-2754	Gasket Kit - F	437-3235
7X-2846	Gasket Kit	437-8647
7X-7954	Gasket Kit	393-5204
7X-7975	Gasket Kit	437-3233
7Y-0207	Cylinder	383-1584
7Y-0213	Gear-Planet	301-4760
7Y-0219	Gear-Coupling	376-7652
7Y-0221	Gear-Planet	301-4758
7Y-0223	Shaft-Planet	301-4625
7Y-0224	Gear-Planet	301-4759
7Y-0225	Shaft-Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear-Sun	301-4689
7Y-0242	Carrier	301-4637
7Y-0249	Gear-Sun	301-4694
7Y-0631	Spring	375-5446
7Y-0680	Piston	360-2262
7Y-0896	Cover	424-0128
7Y-0912	Bearing-Rlr As	417-4513
7Y-1035	Mount	383-2118
7Y-1100	Bearing-Roller	394-8226
7Y-1215	Coupling	422-3512
7Y-1258	Piston	367-6091
7Y-1315	Pipe As-Tail	385-7209
7Y-1427	Gear-Sun	288-8727
7Y-1428	Gear-Planet	288-8728
7Y-1430	Gear-Sun	314-8671
7Y-1431	Gear-Planet	288-8729
7Y-1432	Carrier-Planet	314-8659
7Y-1461	Coupling	301-4649
7Y-1508	Muffler As	395-1303
7Y-1513	Pipe As-Exhaust	301-5249
7Y-1563	Gear Gp-Brg & Bsc	385-3776
7Y-1606	Spring	375-5447
7Y-1644	Gear-Planet	301-3406
7Y-1646	Shaft-Planet	301-4624
7Y-1685	Rod	333-4952
7Y-1687	Piston As	360-2266
7Y-1738	Support	443-5198
7Y-1768	Gear-Ring	450-9167
7Y-1772	Cage	374-3500
7Y-1774	Carrier-Planet	376-7654
7Y-1775	Shaft-Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-1978	Muffler As	360-7893
7Y-2040	Muffler As	301-7975
7Y-2345	Pin	394-0211
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2392	Link-Rh	301-4765
7Y-2395	Bearing-Sleeve	314-8646
7Y-2396	Bearing-Sleeve	314-8634
7Y-2581	Guard As-Trk Gde	480-8270
7Y-3427	Bearing-Sleeve	314-8635
7Y-3428	Bearing-Sleeve	314-8647
7Y-3546	Link	438-1817
7Y-3547	Pin	396-7278
7Y-3548	Pin	396-7289
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3551	Bearing-Sleeve	380-7375
7Y-3552	Bearing-Sleeve	364-5266
7Y-3553	Bearing-Sleeve	301-0433
7Y-4269	Bearing As-Rlr	419-2308
7Y-4270	Bearing As-Rlr	388-6577
7Y-4666	Bearing-Sleeve	314-8636

Part Cross-Reference

Part Numbers Beginning with 7 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
7Y-5102	Bearing-Sleeve	380-7368
7Y-5108	Rod As	394-0912
7Y-5128	Bearing-Sleeve	314-8648
7Y-5131	Bearing-Sleeve	301-4626
7Y-6389	Bearing	372-7507
7Y-6607	Bearing	372-7508
7Y-6608	Bearing	314-8649
7Y-6626	Bearing	314-8650

Part Numbers Beginning with 8

Original Part Number	Part Name	Classic Part Number
8A-2251	Liner-Cylinder	376-9068
8A-2305	Repair Kt-Major	386-3042
8B-5965	Race & Roller As	417-4512
8B-5972	Bearing-Ball	314-8503
8B-8439	Bearing-Ball	399-6069
8C-0580	Gasket Kit - T	393-1023
8C-3111	Rod End-Spher	392-4523
8C-3467	Gasket Kit - F	437-4574
8C-4402	Gasket Kit - F	436-8393
8C-4455	Gasket Kit	436-8392
8C-4456	Gasket Kit - Sch	393-1029
8C-5704	Gasket Kit - Sch	393-1027
8C-6553	Gasket Kit	436-8390
8C-8555	Gasket Kit	434-7278
8C-8714	Kit-Gasket-Cl	436-8389
8C-8741	Kit-Gasket-(Rs)	438-0172
8D-0983	Mounting	384-3470
8D-1634	Retainer	416-5533
8D-1648	Disc	367-6070
8D-1651	Cover	396-7279
8D-1669	Gear-Sun	418-9596
8D-1671	Gear-Planet	416-2155
8D-1784	Pin	282-6567
8D-1817	Cup-Roller Brg	434-3296
8D-1833	Pin	364-5269
8D-2256	Cone-Roller Brg	374-1848
8D-2277	Gear	399-4431
8D-2351	Pin	297-7217
8D-2423	Shaft-Drive	394-8221
8D-2429	Pin As	319-3445
8D-2452	Gear-Sun	394-8233
8D-2459	Gear-Planet	390-5293
8D-2469	Shaft-Drive	275-5280
8D-2519	Shaft-Planet	300-2591
8D-2528	Shaft-Drive	394-9829
8D-2878	Ring-Wear	330-9282
8D-3442	Gear-Bevel	433-2026
8D-3591	Carrier-Planet	301-4769
8D-3669	Gear-Diff Ring	418-9581
8D-3743	Sprocket	391-9876
8D-3744	Shaft-Drive	275-5283
8D-3877	Gear-Sun	275-5278
8D-3949	Ring-Wear	330-9283
8D-3997	Pin As	389-6302
8D-4009	Tube As	392-4496
8D-4027	Housing-Diff	380-7522
8D-4278	Spacer	435-6048
8D-4402	Yoke	365-8823
8D-4673	Pin-Cylinder	302-2711
8D-4675	Pin-Cylinder	391-9863
8D-4766	Pin-Cylinder	365-8832
8D-4942	Housing As	392-4514
8D-5048	Yoke As	415-1899
8D-5059	Diff Gp -A	388-6572
8D-5344	Gear-Worm	243-0341
8D-5949	Stud	416-5492
8D-6138	Camshaft	394-9187
8D-6139	Camshaft	394-9188
8D-6629	Bearing	418-1953
8D-7083	Bearing	386-4930
8D-7086	Bearing	330-9251
8D-7096	Pin-Axle Leaning	297-7219
8D-7167	Pin	389-6319
8D-7284	Bearing	330-9252
8D-7427	Shaft-Dr Pinion	282-6568
8D-7693	Housing	384-4830
8D-7719	Spider & Brg As	384-5946
8D-7996	Bearing-Sleeve	472-8018
8D-8159	Retainer	419-8661
8D-8168	Bearing	453-6511
8D-8233	Retainer	399-4429
8D-8572	Bearing-Sleeve	380-7384
8D-8587	Gear-Transfer	398-8352
8D-8633	Shaft-Drive	275-5281
8D-8634	Gear-Planet	275-5275
8D-8639	Gear-Ring	275-5277
8D-8805	Cover	299-2002
8D-8829	Bearing-Sleeve	361-1692
8D-9159	Bearing-Sleeve	472-8019
8D-9296	Bearing	330-9253
8D-9457	Gear-Diff	430-9000
8D-9804	Housing-Drive	302-2682
8D-9815	Pin-Cylinder	297-7220
8D-9973	Housing	391-9825
8E-2043	Yoke As	385-6115
8E-2058	Bearing	384-5949
8E-2890	Gear	422-2489
8E-3525	Hub-Sprocket	393-1043
8E-3726	Stator-Converter	394-0907
8E-4024	Carrier-Planet	398-8333
8E-4026	Pin As	394-0902
8E-4164	Bar As-Equalizer	469-4661
8E-4526	Disc-Friction	417-9495
8E-4589	Carrier As	416-2122
8E-4954	Housing As-Cl	391-9823
8E-5001	Shaft As.	434-2400
8E-5284	Bearing	388-0582
8E-5450	Seal-Ebar	325-6190
8E-5993	Gear As-Idler	215-1903
8E-6220	Pin As	422-4559
8E-6221	Pin	325-6155
8E-6752	Bearing-Sleeve	388-6576
8E-6754	Connector As	325-6044
8E-6755	Bearing-Sleeve	325-6026
8E-6756	Bearing-Sleeve	325-6027
8E-6758	Connector As	396-0639

Part Numbers Beginning with 8 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
8E-7455	Gear-Planet	221-7947
8E-7456	Gear-Planet	221-7948
8E-7569	Case-Xmsn	394-0899
8E-9740	Gear-Output Tfr	432-8905
8E-9741	Gear-Output Tfr	391-1088
8F-3170	Bearing-Roller	417-4504
8F-5104	Screen As-Se Pan	314-8539
8F-6058	Bearing-Sleeve	416-5494
8F-7278	Diaphragm	392-4485
8F-8523	Bearing-Sleeve	383-3701
8F-9365	Pin	319-3463
8G-0890	Bearing-Align	374-8340
8G-0935	Cap	425-3584
8G-1682	Pin	241-2585
8G-3102	Piston	325-6162
8G-3733	Pin As	419-7636
8G-3965	Hub-Sprocket	424-4942
8G-4022	Bearing	422-6920
8G-4027	Pin As	393-3677
8G-4187	Pin As	295-5676
8G-4189	Bearing-Aligning	295-6411
8G-4190	Seal-Ebar	296-1366
8G-4259	Bearing-Aligning	374-8341
8G-4372	Support As	376-3645
8G-4510	Plate-Clutch	383-2113
8G-8311	Bearin - Sleeve	295-6412
8G-8331	Pin As	443-2971
8G-8944	Sleeve-Wear	418-1954
8H-0901	Cup-Spl Tap Roll	399-4444
8H-0902	Cone-Roller Brg	399-4442
8H-1174	Drum-Ster Cl Dr	226-6101
8H-1383	Rod-Tie	299-2051
8H-1994	Valve-Exhaust	443-1206
8H-2434	Drum-Ster Cl Dr	216-7862
8H-2810	Case As-Filter	314-8512
8H-4320	Bearing-Ball	419-2301
8H-5026	Cover-Adj Pulley	445-7698
8H-5352	Bearing-Ball	453-3658
8H-7577	Plate-Locking	392-4486
8H-7980	Piston	226-0249
8H-8175	Bearing-Sleeve	376-3636
8H-8898	Pin	385-3801
8H-9789	Bearing-Ball	374-8342
8I-1098	Shaft	396-7275
8J-0201	Bearing-Sleeve	384-4781
8J-0278	Bearing-Sleeve	385-3808
8J-0546	Cyl Gp-076 276 Y	430-8116
8J-0632	Pin	396-7280
8J-1616	Lever	330-9271
8J-1624	Valve As	390-0997
8J-2022	Piston As-Pump	367-6073
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-2880	Cap-Bearing	295-6420
8J-3443	Bearing	396-7281
8J-4411	Bearing-Aligning	384-4815
8J-4492	Stem	383-3702
8J-5014	Pin	384-4773
8J-5392	Ballstud	364-5264
8J-5654	Bearing-Sleeve	325-6028
8J-5778	Bearing-Sleeve	374-8359
8J-6296	Shaft	419-6072
8J-6322	Cup-Roller Brg	399-4447
8J-6384	Bearing-Sleeve	472-8034
8J-6536	Bearing	425-6444
8J-6552	Carrier-Bearing	399-6055
8J-6861	Bearing As	384-5950
8J-6868	Cyl Gp-040 405 X	430-5964
8J-7211	Guide-Lh	428-8815
8J-7466	Seat	385-3787
8J-7596	Bearing-Sleeve	361-1693
8J-7694	Bearing	431-5264
8J-7727	Pin	380-7552
8J-7978	Bearing-Spher	388-0581
8J-8590	Cyl Gp-076 274 Y	430-5963
8J-8809	Pump Gp-Gr -A	419-4653
8J-9926	Bearing-Sleeve	383-2115
8K-0067	Spacer	396-1569
8K-0455	Pin	241-2547
8K-0509	Plate-Mating	382-5053
8K-0533	Bearing-Sleeve	314-8637
8K-1754	Spacer	231-0247
8K-2082	Spring-Recoil	388-6560
8K-2198	Cylinder	382-5062
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8K-4392	Bearing-Sleeve	389-6325
8K-4850	Cage-Bearing	451-0745
8K-5283	Plate	299-2043
8K-5334	Pin	241-2598
8K-5587	Rod Gp-Recoil	226-4954
8K-5757	Bearing-Sleeve	367-6076
8K-5758	Pin	241-2566
8K-5999	Gear-Sun	253-1440
8K-6282	Gear-Sun	281-1698
8K-6283	Gear-Sun	221-9077
8K-6321	Gear-Sun	253-1441
8K-9661	Gear-Bevel	213-8218
8L-3972	Baffle	311-9345
8L-4282	Hub	444-0573
8L-4529	Pulley-Alt	264-5889
8L-4889	Shaft-Aux Drive	433-9212
8L-5769	Shaft-Fan	439-1137
8L-8867	Pulley	434-1409
8M-0874	Plunger As-Valve	311-9439
8M-3368	Valve-Check	388-6599
8M-6191	Sleeve-Bolt	226-0234
8M-6676	Cylinder-Adj	226-4960
8M-7166	Housing-Screen	297-7192
8M-7207	Guard As-Fr R Rh	226-0236
8M-7208	Guard As-Frame	226-0237
8M-8068	Bearing-Spl Ball	417-4500
8M-8623	Gear-Sun	213-8755
8M-8628	Flange-Joint	217-9776
8M-8644	Housing-Clutch	215-1782
8M-8646	Plate As-Center	216-3583
8M-8650	Piston-Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier-Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0081	Trunnion	393-5196
8N-0111	Mount As	374-1452
8N-0560	Gear-O Pump Dr	378-3990
8N-0561	Gear-Pump Idler	373-1886
8N-0701	Bearing-Sleeve	419-4745
8N-0703	Bearing-Sleeve	472-8037
8N-0784	Manifold-Mount	393-1044
8N-0788	Cover	440-0849
8N-0875	Valve-Exhaust	247-6893
8N-0935	Gear-Pump Drive	399-8569
8N-1184	Elbow-Exhaust	392-4497
8N-1187	Head Gp-Cyl -A	242-3435
8N-1188	Head Gp-Cyl -A	241-3381
8N-1188	Head Gp-Cyl -A	242-3436
8N-1214	Mount As	325-6125

Part Cross-Reference

Part Numbers Beginning with 8 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
8N-1300	Bushing As-Spt	394-0193
8N-1365	Gear-Drive	394-8222
8N-1594	Shield As	378-3991
8N-1616	Shield As	377-5856
8N-1619	Shield As	377-5857
8N-1620	Shield As-Manf	374-4725
8N-1622	Shield As-Manf	374-4726
8N-1628	Shaft As-F Pump	383-3703
8N-1721	Rod As-Conn	269-5291
8N-1726	Rod As-Conn	379-8866
8N-1849	Bearing-Conn Rod	379-0196
8N-1984	Rod As-Conn	242-3441
8N-2051	Compressor Gp	386-2063
8N-2051	Compressor Gp -B	386-2063
8N-2104	Bell As-Suction	380-1521
8N-2258	Shield As-Bottom	421-1562
8N-2275	Bearing-Sleeve	311-9365
8N-2368	Shield As	449-9547
8N-2516	Bonnet-Valve	377-5858
8N-2518	Bearing-Sleeve	417-4518
8N-2641	Sleeve	325-6210
8N-3180	Body As-Piston	250-6563
8N-3181	Piston Gp-Basic	250-6555
8N-3182	Body As-Piston	250-6564
8N-3183	Piston Gp-Basic	250-6556
8N-3248	Gasket As	415-1893
8N-3251	Shaft As-Rkr Arm	314-8711
8N-3304	Pulley-Tightener	419-4708
8N-3312	Shaft As-Rkr Arm	325-6200
8N-3325	Arm Gp-V Rocker	314-8623
8N-3327	Arm Gp-V Rocker	314-8624
8N-3451	Line As-Fuel Inj	390-0927
8N-3452	Line As-Fuel Inj	390-0928
8N-3453	Line As-Fuel Inj	390-0940
8N-3454	Line As-Fuel Inj	390-0930
8N-3455	Line As-Fuel Inj	390-0920
8N-3539	Plunger As-Pump	377-5861
8N-3666	Repair Kt-Major	377-5842
8N-3723	Valve-Exhaust	311-9472
8N-3753	Rod As-Conn	379-8867
8N-4110	Bearing-Sleeve	394-8207
8N-4445	Pipe-Exhaust Ext	386-3061
8N-4550	Shaft-Pulley	445-9247
8N-4810	Gasket-Cyl Head	437-2046
8N-4975	Muffler As.	443-2661
8N-5305	Spacer	363-7464
8N-5385	Manifold-Exhaust	391-9835
8N-5387	Elbow-Exh Ext	373-1908
8N-5388	Muffler As	360-7895
8N-5579	Retainer	425-3451
8N-5779	Coupling-Exhaust	325-6047
8N-5884	Pulley-Fan Drive	416-5500
8N-5929	Cover-Water Pump	296-1349
8N-6004	Head As-Cyl	247-3369
8N-6308	Bearing-Conn Rod	419-7267
8N-6796	Head Gp-Cyl -A	269-5290
8N-7257	Mount As	396-0660
8N-7315	Tube As-Outlet	325-6232
8N-7486	Condenser As	436-2263
8N-7764	Bearing-Main	419-6310
8N-7765	Bearing-Main	419-7269
8N-7766	Bearing-Main	419-7270
8N-7771	Bearing-Conn Rod	419-7272
8N-7773	Bearing-Conn Rod	419-7274
8N-7782	Rotocoil As	383-1585
8N-7923	Bearing-Main	419-7275
8N-7924	Bearing-Main	419-7276
8N-7933	Bearing-Conn Rod	419-7280
8N-7934	Bearing-Conn Rod	419-6308
8N-8110	Gasket-Cam Hsg	433-8186
8N-8196	Adapter-Exh Manf	377-5852
8N-8220	Bearing-Conn Rod	377-5860
8N-8221	Bearing-Conn Rod	419-6377
8N-8222	Bearing-Conn Rod	419-6322
8N-8223	Bearing-Conn Rod	419-6386
8N-8225	Bearing-Main	419-6385
8N-8226	Bearing-Main	376-9081
8N-8227	Bearing-Main	376-9082
8N-8228	Bearing-Main	376-9083
8N-8229	Bearing-Main	376-9084
8N-8258	Bearing-Sleeve	452-1077
8N-8983	Hub-Fan Pulley	421-7227
8N-9402	Coupling	325-6048
8N-9489	Chamber As	247-3301
8N-9523	Elbow	425-2566
8N-9622	Bracket As-Fan	433-2024
8N-9733	Line As-F Inj	319-8174
8P-0187	Nut-Adjusting	219-9676
8P-0514	Yoke As	308-9947
8P-0605	Gear-First Red	213-8453
8P-0606	Pinion-Sec Red	215-1783
8P-0621	Nut-Adjusting	451-0746
8P-0953	Turbine-Conv	297-7269
8P-0961	Impeller-Conv	433-9204
8P-1182	Shaft	227-4771
8P-1183	Gear-Bevel	226-7980
8P-1324	Cage-Gr Shft Brg	229-8239
8P-1325	Hub-Ster Cl Dr	226-8005
8P-1326	Pilot-Cl Piston	226-6097
8P-1327	Pinion-Fdr	226-8000
8P-1653	Nut-Sprocket Adj	449-4734
8P-1656	Plate-Clutch	367-6071
8P-1774	Pinion-Fdr	226-8001
8P-1851	Hub As-Sprocket	224-1314
8P-1853	Nut-Adjusting	226-7997
8P-1855	Hub As-Sprocket	227-4770
8P-1865	Bar As-Equalizer	231-3313
8P-1892	Piston	283-5208
8P-1916	Gear-Planet	283-5209
8P-1918	Gear-Planet	283-5210
8P-1919	Gear-Planet	300-2579
8P-1948	Gear-Ring	469-4663
8P-1964	Plate-Clutch	377-7445
8P-2042	Shaft-Planet	283-5211
8P-2051	Plate-Clutch	385-6116
8P-2430	Shaft As	297-7258
8P-3377	Tube As	392-4498
8P-3512	Piston-Clutch	416-2131
8P-3563	Cage-Bearing	451-0747
8P-3595	Mount	418-1950
8P-4047	Shaft-Planet	373-5390
8P-4520	Piston-Clutch	394-0908
8P-4537	Pinion-Reduction	216-7867
8P-5117	Rod Gp-Tck Adj	226-2747
8P-5229	Carrier-Stator	395-1309
8P-5961	Gear-Ring	385-6137

Part Numbers Beginning with 8 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
8P-6083	Yoke-U Joint	446-3073
8P-6274	Guard As-Lh	226-4949
8P-6275	Guard As-Rh	226-0191
8P-6803	Shaft As	215-1842
8P-7396	Hub-Planet Gear	239-7967
8P-7788	Retainer-Cl Pstn	417-9476
8P-7790	Valve Gp-Press	247-4437
8P-8221	Plate-Guide	226-2748
8P-8559	Yoke-6C	443-2016
8P-8567	Carrier-Stator	450-5586
8P-8570	Pilot As-Cl Pstn	226-6097
8P-8677	Hub-Impeller	297-7205
8P-9507	Piston-Clutch	283-5212
8R-0931	Housing-Pinion	302-4300
8R-0942	Plate-Reaction	380-1484
8R-1015	Support-Trunnion	374-4712
8R-1088	Bearing-Sleeve	419-0885
8R-1465	Rim As	417-9501
8R-1693	Pin As	415-1906
8R-1891	Gear-Ring	450-7547
8R-2193	Piston	376-9051
8R-2196	Plate-Reaction	375-2626
8R-2199	Gear-Planet	421-7986
8R-2533	Piston	377-7446
8R-2535	Plate-Reaction	377-7447
8R-3252	Shaft-Planet	297-7259
8R-3921	Collet	308-9839
8R-3941	Collet	393-1016
8R-3943	Collet	308-9840
8R-3946	Collet	308-9841
8R-4184	Bearing-Sleeve	374-6515
8R-4265	Collet	384-3462
8R-4268	Collet	384-3461
8R-4568	Piston	385-6108
8R-4821	Carrier-Planet	308-9837
8R-6213	Mount As	389-6301
8R-6631	Hub	443-2057
8R-6830	Joint Gp-Slip	388-0567
8R-7336	Bearing	301-3394
8R-7425	Retainer	308-9917
8R-8335	Gear-Bevel	368-0105
8R-9306	Pinion-Diff Bev	388-0569
8R-9750	Gear-Planet	391-9869
8S-0248	Breather As	325-6033
8S-0493	Shaft As-Pump	325-6198
8S-0611	Cage-Bearing	451-0748
8S-0905	Muffler As	302-2690
8S-1061	Pilot As-Spring	226-0227
8S-1522	Chamber As	390-1004
8S-1523	Chamber As	388-0565
8S-1831	Guard As-Sprkt	226-4947
8S-1892	Gasket Kt-Wp	436-8398
8S-2123	Cage-Fdr Bearing	217-7726
8S-2126	Spacer-Hub Brg	222-1767
8S-2140	Trunnion-Gear	226-8020
8S-2389	Body-Fuel Valve	377-5831
8S-2809	Muffler	247-2677
8S-3487	Gear As-Ring	221-7949
8S-3517	Bearing-Spl Ball	417-4501
8S-3554	Yoke	448-9154
8S-3617	Chamber As	247-3302
8S-3653	Bonnet-Valve	374-4728
8S-3656	Plunger As-Pump	419-4750
8S-3970	Chamber As	242-3438
8S-3995	Gage As-Level	430-8042
8S-4996	Muffler	390-0909
8S-5438	Muffler As	360-7896
8S-6370	Yoke	431-2155
8S-6380	Tube As	452-0446
8S-6511	Bearing-Sleeve	380-7372
8S-6782	Adapter-Exhaust	383-1586
8S-7716	Manifold-Exhaust	295-0415
8S-7717	Manifold-Exhaust	261-0894
8S-7718	Manifold-Exhaust	295-0416
8S-7818	Bracket	226-0211
8S-9075	Bearing-Cone	418-9612
8S-9076	Cup-Bearing	418-9613
8S-9151	Cup-Spl Tapered	374-8348
8S-9686	Gasket Kit	393-5215
8S-9698	Gasket Kit	393-5221
8T-0072	Cone-Rlr Brg	377-7448
8T-0209	Race-Spl Rlr Brg	384-5951
8T-1177	Bearing-Rlr	419-1862
8T-1606	Kit-Gskt-Sch	386-3046
8T-1622	Gasket Kit - Sch	436-8388
8T-1630	Kit-Gasket-F	436-8387
8T-1631	Kit-Gasket-Mch	436-8375
8T-1643	Kit-Dt Gasket	388-6575
8T-2455	Gasket Kit	436-8396
8T-2466	Gasket Kit	393-5199
8T-2470	Gasket Kit	393-5219
8T-2489	Gasket Kit - Sch	436-8408
8T-2499	Kit-Gasket-Sch	436-8383
8T-2500	Kit-Gasket	393-1028
8T-3383	Kit-Gasket-Mch	447-8648
8T-4870	Gasket Kit	436-8378
8T-6479	Gasket Kit	436-8377
8T-6485	Gasket Kit	436-8406
8T-6487	Kit-Gasket-Sch	436-8384
8T-7047	Gasket Kit	384-5952
8T-9486	Gasket Kt	393-5197
8V-1537	Gear-Sun	446-3061
8V-1540	Univ Jt As	388-6574
8V-1612	Shaft	425-6456
8V-1624	Lever	299-2019
8V-2632	Pin As	241-2523
8V-2634	Pin As	241-2518
8V-2639	Pin As	241-2542
8V-3134	Pinion-Bevel	260-0788
8V-3550	Rim As	417-9477
8V-5439	Pin As	241-2531
8V-6382	Hub As	308-9868
8V-6384	Spacer As	308-9935
8V-6390	Drum-Brake	377-7449
8V-6435	Spider & Brg Kit	377-7451
8V-6825	Joint Gp-Slip	453-0972
8V-7175	Pin	241-2567
8V-7176	Pin	241-2568
8V-7659	Pin As	361-1702
8V-7885	Housing-Support	297-7193
8W-0328	Cylinder-Damper	419-4715
8W-0376	Shaft	394-9194
8W-1708	Pin	388-0643
8W-1749	Plate	380-7403
8W-1751	Bracket As	288-8732
8W-1752	Bracket-Rail	288-8733
8W-1753	Bracket-Rail	288-8734
8W-2307	Shaft-Planet	275-5284
8W-2308	Shaft-Planet	275-5285
8W-2309	Shaft-Planet	392-4504
8W-3589	Link As-Spring	380-7389
8W-3613	Bearing	418-1960
8W-3881	Bearing	394-8224
8W-4066	Bracket-Rail	288-8735
8W-4067	Bracket-Rail	288-8736
8W-4167	Bearing-Sleeve	361-1694

Part Cross-Reference

Part Numbers Beginning with 8 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
8W-4523	Bearing-Sleeve	385-3798
8W-4652	Housing-Spindle	385-7215
8W-4653	Housing-Spindle	385-7214
8W-5092	Pinion-Circle Dr	282-6569
8W-5293	Pin	282-6570
8W-5296	Pin	438-2017
8W-6324	Kit-Wear Strip	424-0739
8W-6476	Pin	418-1935
8W-6493	Pin	395-1320
8W-6494	Pin	391-9902
8W-6497	Pin	319-3465
8W-7452	Housing	416-2141
8W-8124	Housing	472-8021
8W-8138	Shaft	377-7453
8W-8286	Sprocket	299-2061
8W-8289	Sprocket	282-6629
8W-8317	Sprocket	275-5287
8W-8319	Sprocket	380-7482
8W-8462	Joint Gp-Univ	421-7829
8W-8512	Pin As	385-7220
8W-8628	Spindle-Fr Axle	282-6571
8W-9566	Flange As	376-9073
8W-9587	Flange As	373-5394
8W-9728	Gear	399-6045
8X-0576	Kit-Wear Strip	383-2105
8X-0962	Pin	423-3539
8X-0967	Pin As	425-6445
8X-3434	Arm As-Leaning	438-1816
8X-3435	Arm As-Leaning	438-1814
8X-4741	Insert	375-4335
8X-5425	Guide As-Hose	432-4222
8X-6738	Shaft-Planet	394-8225
8X-8067	Mounting	394-0205
8Y-0035	Yoke As	393-1057
8Y-0395	Pin As	393-3678
8Y-0809	Spider Gp-Brg&	417-4526
8Y-0978	Plate As	434-1402
8Y-1198	Strip	325-6220
8Y-1199	Strip	325-6221
8Y-1853	Strip	428-7633
8Y-2735	Spring	383-2134
8Y-6559	Hub	416-5501
8Y-6659	Spring-Recoil	422-7893
8Y-7186	Link As	399-8584

Part Numbers Beginning with 9

Original Part Number	Part Name	Classic Part Number
9B-0399	Link As-Cl Drive	431-5268
9B-1320	Valve-Check	377-5832
9C-0624	Pin As.	361-1709
9C-0625	Pin As	308-9888
9C-1484	Pin As	319-3446
9C-2249	Yoke As	382-6890
9C-3095	Spider Gp-Brg&	394-8219
9C-3530	Joint Gp-Univ	449-9832
9C-3848	Bearing	417-4493
9C-3857	Pin	374-6503
9C-4007	Bearing-Sleeve	374-1459
9C-4080	Yoke-Brake	302-2703
9C-4096	Yoke-Bk Flange	369-9496
9C-4202	Ring	424-0127
9C-4737	Pin As	241-2520
9C-4912	Pin As	241-2517
9C-4978	Pin-Lower	319-3466
9C-5687	Separator	377-7456
9C-5852	Hub As	297-7208
9C-6015	Pinion-Diff Bev	297-7225
9C-6029	Bearing-Planet	375-9982
9C-6187	Pin As	241-2521
9C-6281	Tube As	398-2953
9C-6317	Shaft-Planet	373-5397
9C-6318	Bearing-Sleeve	374-6516
9C-6329	Plate-Reaction	377-7457
9C-6335	Gear-Planet	319-3439
9C-8074	Gear-Planet	308-9858
9C-8075	Gear-Sun	308-9864
9C-8205	Gear-Bevel	319-8175
9C-8218	Shaft-Bev Pinion	302-2697
9C-8278	Case As-Diff	423-6984
9C-8418	Plate-Reaction	385-6129
9C-8669	Shaft-Bev Pinion	368-0107
9C-8772	Piston	376-9052
9C-8986	Collet As	374-6502
9C-9191	Trunnion	302-2701
9D-0120	Gear-Planet	288-8737
9D-1491	Coupling	416-2121
9D-1511	Bearing-Sleeve	333-4943
9D-1512	Bearing-Sleeve	333-4944
9D-1589	Mounting	387-2928
9D-2252	Insert	385-6139
9D-2716	Spindle-Wheel	228-9463
9D-2754	Insert	333-4948
9D-2756	Insert	333-4949
9D-3242	Cone-Roller Brg	453-3659
9D-3288	Bolt-Draft	333-4941
9D-4094	Bearing-Sleeve	418-1933
9D-4413	Shaft-Axle	421-7983
9D-5444	Pin	380-7396
9D-5741	Worm-Circle Dr	297-7270
9D-5746	Gear-Worm	299-2011
9D-5921	Shaft-Dr Pinion	297-7254
9D-6889	Plate As	394-9818
9D-7924	Mount As	360-2356
9D-8285	Cap	391-9822
9D-9665	Bracket-Cyl Mtg	299-1980
9D-9967	Washer-Thrust	389-6323
9D-9968	Washer-Thrust	391-9890
9F-3212	Bearing-Ball	384-5953
9F-3358	Link As-Cl Drive	394-0207
9F-7101	Bushing-Collar	299-1988
9F-8074	Bearing-Outer	452-3180
9G-0007	Hub	224-1311
9G-0280	Piston	283-5213
9G-0284	Housing-Clutch	283-5214
9G-0285	Piston	283-5215
9G-0289	Shaft-Planet	283-5216
9G-0290	Hub-Clutch	283-5217
9G-1231	Plate	297-7232
9G-1488	Housing-Clutch	430-7620

Part Numbers Beginning with 9 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
9G-1491	Carrier-Planet	281-1685
9G-1499	Gear-Pump (Oil)	295-6424
9G-1696	Pad As	391-9820
9G-1697	Pad As	391-9821
9G-1919	Gear-Planet	371-4307
9G-2413	Shaft-Output	297-7255
9G-3056	Pump Gp-Gr 4A	421-1563
9G-5525	Shaft-Planet	419-8662
9G-5842	Gear-Transfer	394-0913
9G-6476	Rod Gp-Idler Rec	226-0198
9G-6744	Bearing-Sleeve	418-1931
9G-6774	Gear-Transfer	398-8343
9G-7038	Pin	396-0665
9G-7411	Gear-Pump (Oil)	297-7182
9G-7412	Gear As-Pump	297-7183
9G-7993	Cage-Gr Brg Rh	239-7973
9G-8117	Housing As-Cl	302-2686
9G-8302	Guide	226-4853
9G-8303	Collar-Idler End	226-0242
9G-8638	Gear-Planet	295-6425
9G-8931	Yoke As	446-3074
9G-9078	Sleeve	431-6618
9G-9086	Bearing-Sleeve	416-5528
9G-9174	Gear-Sun	295-6430
9G-9180	Hub-Sprocket	295-6436
9G-9182	Spindle	468-9791
9G-9183	Shaft	295-0417
9G-9543	Gear-Pump (Oil)	295-6426
9G-9764	Yoke As	319-3478
9H-2256	Pump Gp-F Prm	311-9443
9H-5233	Piston-Clutch	219-9708
9H-5797	Plunger As-Pump	391-9891
9H-6236	Rod As	390-0999
9H-7670	Piston	226-4961
9J-0105	Hub	415-1894
9J-0123	Trunnion	325-6227
9J-0940	Pin	319-3467
9J-0944	Pin	380-7399
9J-0945	Bearing-Sleeve	383-2135
9J-0946	Bearing	421-9759
9J-0950	Bearing-Sleeve	396-0667
9J-0951	Bearing-Sleeve	396-0666
9J-1140	Bushing	384-4782
9J-1141	Bushing	384-4783
9J-1187	Bearing-Sleeve	384-4785
9J-1379	Pin As	389-6303
9J-1676	Bearing-Sleeve	380-7378
9J-1679	Bearing-Sleeve	380-7566
9J-2007	Piston As	419-4714
9J-2290	Pin As	423-3538
9J-2332	Bearing-Pivot	299-1969
9J-2365	Retainer	325-6186
9J-2433	Cylinder As	480-8276
9J-2759	Trunnion	394-0216
9J-3206	Bearing-Spher	360-2275
9J-3466	Cyl Gp-028 121 Y	393-0913
9J-3741	Shaft	386-4933
9J-5048	Pump Gp-Vn Bsc-A	422-8166
9J-5049	Pump Gp-Vn Bsc-B	422-8156
9J-5050	Pump Gp-Vn Bsc-B	422-8168
9J-5053	Pump Gp-Vn Bsc-B	422-8169
9J-5058	Pump Gp-Vn Bsc-B	422-8170
9J-5061	Pump Gp-Vn Bsc-B	422-8171
9J-5070	Pump Gp-Vn Bsc-B	422-8140
9J-5080	Pump Gp-Vn Bsc-A	422-8141
9J-5082	Pump Gp-Vn Bsc-A	422-8142
9J-5083	Pump Gp-Vn Bsc-A	422-8143
9J-5284	Bearing-Sleeve	380-7379
9J-5875	Bearing-Sleeve	308-9830
9J-5942	Bearing-Sleeve	380-7380
9J-6001	Cap As	444-0570
9J-6260	Trunnion	426-0031
9J-6549	Bearing-Sleeve	453-6514
9J-6556	Rod As	394-8212
9J-7099	Bearing-Sleeve	391-9818
9J-7891	Cartridge Gp-Rr	422-8134
9J-8006	Piston	449-4736
9J-8165	Cyl Gp-050 288 Y	398-2941
9J-8166	Cylinder As	394-9834
9J-8323	Trunnion	361-1713
9J-9427	Bearing-Sleeve	361-1695
9J-9487	Bearing-Sleeve	447-0822
9J-9598	Pin	296-1362
9J-9812	Bearing	434-7258
9K-0723	Pin	396-7283
9K-0724	Collar	392-4524
9K-0725	Cap	444-0575
9K-0726	Cap	393-3680
9K-0802	Spacer	419-0892
9K-0804	Pin	367-6092
9K-0805	Cap	415-1910
9K-0806	Cap	430-4469
9K-1171	Cup-Rlr Bearing	430-3339
9K-1193	Gear-Sun	221-9099
9K-1773	Gear-Ring	221-9100
9K-3413	Gear-Bevel	223-4807
9K-3969	Spider & Brg As	432-8275
9K-3970	Spider & Brg As	453-3660
9K-5639	Pin	425-6451
9K-5780	Rim As	388-6597
9K-8423	Bearing-Sleeve	421-9043
9K-8425	Bearing-Sleeve	314-8638
9K-8428	Pin As	241-2533
9K-8435	Pin	241-2552
9K-8757	Rod End-Special	311-9361
9K-9156	Retainer As	297-7236
9K-9158	Bearing-Sleeve	299-1970
9K-9271	Holder As-Cage	217-7730
9K-9273	Nut-Adjusting	226-7998
9L-2685	Rod End	419-1866
9L-5519	Manifold-Exhaust	392-4500
9L-5520	Manifold-Exhaust	383-1587
9L-5521	Manifold-Exhaust	396-9895
9L-5836	Coupling-Exhaust	385-7212
9L-5839	Coupling-Exhaust	374-7480
9L-5908	Gasket	433-8196
9L-5961	Adapter-Compr Dr	416-5508
9L-6371	Rod-Eye	363-7459
9L-7682	Valve-Inlet	385-9266
9M-0701	Piston-Steer Cl	219-9692
9M-1328	Bearing-Aligning	325-6018
9M-1500	Shaft-Planet	219-9685
9M-1853	Mount As.	376-3638
9M-1990	Dowel-Reaction	386-4963

Part Cross-Reference

Part Numbers Beginning with 9 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
9M-1995	Gear-Sun	213-8756
9M-1996	Shaft-Planet	215-1875
9M-1997	Bearing-Ball	384-5954
9M-2038	Gear-Tfr Driven	215-1876
9M-2039	Gear-Tfr Driving	219-9672
9M-2042	Race-Roller Brg	417-9500
9M-2045	Pinion-Bevel	215-1878
9M-2049	Gear-Ring	214-0533
9M-2417	Retainer-Gear	380-7409
9M-2744	Cone-Spl Tapered	380-1480
9M-3025	Cover As	299-2001
9M-3914	Bearing-Aligning	420-2501
9M-4370	Bearing-Sleeve	453-6515
9M-4789	Shaft-Gov Cont	297-7256
9M-4955	Pump Gp-F Tfr	242-3443
9M-5045	Guard As-Wear	213-9111
9M-5350	Spring-Valve	380-7573
9M-5477	Bearing-Sleeve	374-6517
9M-6692	Strip	386-4934
9M-8117	Shaft-Fly Clutch	226-6073
9M-8119	Retainer-Inlet	226-8022
9M-8281	Gear As-Pump	325-6089
9M-8395	Bearing-Sleeve	391-1103
9N-0316	Bracket-Pulley	434-1993
9N-1161	Line As-Fuel Inj	383-3705
9N-1545	Race-Thrust	394-9205
9N-3167	Plate-Block Bot	430-4468
9N-3345	Pulley As-Idler	398-8341
9N-3668	Base As.-Coolant	419-4718
9N-3970	Line As-Fuel Inj	390-1005
9N-4460	Housing As-Cl	297-7203
9N-4622	Pin	319-3468
9N-5246	Bearing-Camshaft	384-4772
9N-5251	Piston Gp-Bsc	250-6557
9N-5403	Body As-Piston	250-6558
9N-5529	Body-F Inj Valve	378-3993
9N-5769	Cover-Housing	325-6050
9N-5786	Lifter-Valve	457-6607
9N-5920	Bearing-Conn Rod	419-6383
9N-6221	Crankshaft As	368-5914
9N-6500	Rod-Valve Push	383-3706
9P-0566	Case-Fdr	419-1861
9P-0620	Cage-Pinion Brg	221-1052
9P-0863	Pin	389-6321
9P-2201	Valve Gp-Rlf -A	386-3816
9P-2653	Pump Gp-Gr 1 Bsc	386-3057
9P-3436	Holder As-Cage	216-7875
9P-3663	Carrier-Planet	213-6939
9P-3731	Carrier-Planet	301-4767
9P-3757	Gear	394-9196
9P-3758	Gear-Planet	419-8805
9P-3803	Carrier-Planet	468-5013
9P-5363	Piston-Clutch	219-9687
9P-5379	Housing-Clutch	215-1904
9P-5531	Gear-Sun	417-9499
9P-6592	Gear-Planet	215-1915
9P-6799	Piston-Clutch	469-4671
9P-6800	Piston-Clutch	380-1505
9P-6903	Plate	368-0108
9P-6912	Pin	394-0189
9P-7101	Plate-Clutch	368-0122
9P-7757	Gear-Sun	283-5218
9P-7917	Valve Gp-Cont -C	385-3810
9P-8283	Plate-Clutch	296-1364
9P-8516	Gear-Ring	373-5398
9P-8517	Case-Xmsn	394-0909
9P-8521	Gear-Ring	296-1353
9P-8623	Shaft-Planet	314-8719
9P-8624	Shaft-Planet	295-5446
9P-8626	Gear-Sun	283-5219
9P-8663	Spacer	422-9521
9P-9000	Shaft-Ster Cl	217-7738
9P-9031	Gear-Sun	283-5220
9P-9360	Gear-First Red	213-8454
9P-9361	Gear-Final Drive	223-4809
9P-9362	Pinion-Fdr	215-1944
9P-9363	Pinion-Reduction	219-9677
9P-9507	Race-Thrust	371-4309
9P-9517	Stator-Converter	297-7262
9P-9575	Cage-Bev Gr Brg	216-7876
9P-9610	Pump Gp-Gr 1 Bsc	283-5221
9R-0080	Coupling	346-5683
9R-0097	Pin	346-5684
9R-0313	Hub As	388-6591
9R-0424	Pin	346-5686
9R-0437	Pin	389-6320
9R-1572	Wheel As-Front	388-6604
9R-1725	Bearing-Sleeve	425-6446
9R-1917	Bearing-Sleeve	418-1958
9R-2410	Retainer As.	346-5688
9R-2419	Kit-Bearing	383-2137
9R-2421	Shaft	346-5689
9R-2424	Gear-Planet Sun	346-5690
9R-2476	Disc-Bk Rear	346-5691
9R-2477	Disc As	346-5692
9R-2480	Case As	394-0881
9R-2487	Gear	394-9186
9R-2491	Spider	346-5693
9R-2601	Rod Gp-Tie	385-6133
9R-2842	Rod-Tie	385-6134
9R-2843	Rod-Tie	385-6135
9R-2846	Pin	346-5694
9R-2857	Rod-Piston	418-9588
9R-3527	Carrier-Planet	396-9892
9R-4067	Joint Gp-Univ	373-5399
9R-4208	Pin	425-3450
9R-6070	Pin As	393-3681
9R-6161	Pin	374-6505
9R-6162	Pin	418-1943
9R-6163	Pin	346-5701
9R-6475	Pad As	346-5702
9R-6545	Pin	346-5703
9R-6950	Pinion-Planetary	391-9872
9R-7092	Bar	364-5272
9R-7696	Pin	346-5705
9R-8199	Joint-Double	384-4813
9R-8231	Pad As	397-5066
9R-8235	Pad As	383-2106
9R-8579	Pin	346-5711
9R-8580	Pin As	418-1932
9R-8663	Pin	365-8831
9R-8709	Pin	346-5715
9R-8714	Fork	390-0929
9R-8715	Spider As-Brg&	346-5716
9R-8718	Yoke As	364-5258
9R-9190	Rod Gp-Tie	346-5718
9R-9400	Case As	346-5719
9R-9402	Seal-Rax	347-0476
9R-9403	Pinion	347-0477
9R-9475	Bearing-Sleeve	380-7377
9R-9505	Bearing-Sleeve	453-6516
9R-9812	Pin	347-0468
9S-0440	Tube As	392-4499
9S-1026	Cage-Gear Brg	216-7873

Part Numbers Beginning with 9 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
9S-1043	Guard As-Guiding	226-0240
9S-1044	Guard As-Guiding	226-0241
9S-1045	Strip-Guard	226-0246
9S-1046	Strip-Guard	226-0247
9S-1195	Pump As-Oil	390-1000
9S-1267	Ejector As-Exh	397-5059
9S-1768	Pipe-Ext Exhaust	380-7544
9S-2354	Manifold-Exhaust	261-0888
9S-2355	Manifold-Exhaust	261-0891
9S-2356	Manifold-Exhaust	261-0905
9S-3321	Cage-Pinion Brg	226-7974
9S-3581	Cup-Roller Brg	415-1923
9S-3582	Cone-Roller Brg	396-4144
9S-3955	Cage-Gear Brg	216-7874
9S-4829	Race-Brg Inner	423-9668
9S-5211	Plate-Clutch	380-1493
9S-5265	Shaft As	215-1945
9S-5267	Carrier As	392-4512
9S-5279	Bearing-Inner	453-3661
9S-5746	Ferrule-Seal	392-4493
9S-5771	Bushing As	385-7219
9S-6129	Pulley-Alt Drive	264-5891
9S-6147	Body As	369-9499
9S-6590	Pump Gp-Cl Oil	226-0176
9S-6743	Chamber As	247-3303
9S-6875	Pinion-Final Dr	217-7705
9S-6917	Gear-Cplg Ring	446-3075
9S-7079	Muffler As	247-2669
9S-7148	Cap As-Rain	378-3994
9S-7534	Pipe-Exh Ext	398-2950
9S-7788	Ring-Piston	461-5124
9S-7949	Cup-Roller Brg	420-6531
9S-8184	Pin-Drawbar	398-8345
9S-8217	Bolt-Spring	469-4672
9S-8245	Strip-Tck Gde Gd	226-0243
9S-8246	Strip-Tck Gde Gd	226-0244
9S-8257	Guard As-Guiding	226-0238
9S-8258	Guard As-Guiding	226-0239
9S-8353	Strip-Tck Gde Gd	226-4854
9S-8354	Strip-Tck Gde Gd	226-4855
9S-8358	Guard As-Guiding	226-4856
9S-8597	Spring	399-8561
9S-8679	Chamber As	325-6042
9S-8789	Plate-Clutch	302-2712
9S-9328	Muffler	395-1308
9S-9696	Spider As-Fan	383-3707
9T-0142	Cyl Gp-0184-0281	394-9830
9T-0486	Pump Gp-Vn Bsc-A	422-8144
9T-1697	Cartridge Gp-	422-8137
9T-2200	Cartridgr Gp	422-8114
9T-2387	Rod As	393-5218
9T-2472	Cyl Gp-76 1017 U	396-9930
9T-2852	Cylinder As-Lh	423-7869
9T-2860	Cyl Gp-0133-1535	395-1310
9T-3055	Cylinder As	430-5962
9T-3866	Pump Gp-Vn Bsc-A	422-8145
9T-3884	Piston As	393-3639
9T-3948	Rod As	393-0940
9T-4761	Head	325-6108
9T-4762	Head	325-6109
9T-5096	Flexplate	455-3271
9T-5336	Cartridge Gp	422-8131
9T-5360	Plate-Pressure	424-4941
9T-5729	Cyl Gp-0038 0158	422-2486
9T-6123	Pump Gp-Vn Bsc-B	422-8147
9T-6577	Pump Gp-Gr B	419-0873
9T-6906	Gear-Idler	419-4662
9T-7414	Pump Gp-Gr B	421-1564
9T-7676	Cartridge Gp	422-8136
9T-7916	Pump Gp-Vn Bsc-B	426-1697
9T-8944	Cyl Gp-102 356 Y	393-3665
9U-0465	Shaft-Pinion	394-0904
9U-0466	Gear-Bevel	418-9587
9U-0654	Coupling	297-7167
9U-0971	Gear-Sun	368-0124
9U-0974	Bushing-Sleeve	374-1460
9U-0975	Hub As	390-5259
9U-1179	Joint Gp-Univ	421-7828
9U-2400	Housing As	231-0249
9U-2787	Gear-Planet	367-6093
9U-3124	Gear-Planet	288-8806
9U-3125	Gear-Sun	288-8807
9U-3665	Joint Gp-Univ -A	398-8342
9U-3670	Yoke As	432-4221
9U-8481	Pin As.	295-5675
9U-9162	Tube As	451-9023
9U-9198	Strip	388-0641
9U-9657	Bearing-Spl Ball	371-4308
9V-0247	Plate	417-4527
9V-1290	Wheel	396-9946
9V-2410	Housing-Bearing	302-2679
9V-3052	Plate	434-1401
9V-3289	Pin As	382-6904
9V-3363	Pin As	396-0663
9V-3405	Bearing-Sleeve	425-6453
9V-3406	Bearing-Sleeve	425-6441
9V-3829	Collar	382-6905
9V-3852	Bearing-Sleeve	450-9166
9V-3853	Pin	319-3469
9V-4333	Gear-Oil Pump Ip	226-6105
9V-4975	Bearing-Sleeve	384-4784
9V-5160	Plunger Kt-Adj	385-7218
9V-5173	Joint Gp-Univ	451-9019
9V-5174	Joint Gp-Univ	375-2628
9V-6165	Plate-Outer	377-7460
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9V-6526	Ring-Retaining	422-2485
9V-7710	Univ Joint As	394-8234
9V-7860	Support As-Front	308-9938
9V-8693	Actuator Gp-Bk	375-2629
9V-9408	Spring	425-9369
9V-9833	Gear-Bevel	394-8243
9V-9840	Spider	417-9498
9W-0099	Bearing-Sleeve	314-8639
9W-0517	Carrier-Planet	281-1686
9W-0550	Shaft-Xmsn Upper	226-6000
9W-0551	Shaft-Pinion	388-6592
9W-0552	Shaft-Pinion	226-6001
9W-0876	Bearing-Sleeve	325-6031
9W-1566	Impeller-Conv	390-5270
9W-1567	Impeller-Conv	391-9880
9W-1572	Shaft-Xmsn Input	419-1864
9W-1677	Bearing	297-7145

Part Cross-Reference

Part Numbers Beginning with 9 (Cont'd.)

Original Part Number	Part Name	Classic Part Number
9W-1683	Pin	391-9819
9W-2344	Coupling-Pump Dr	314-8666
9W-2579	Plate	314-8701
9W-2977	Hub As	423-6985
9W-3120	Pin As	393-3641
9W-3271	Body As-Oil Pump	430-4553
9W-3605	Carrier-Ring	314-8662
9W-3607	Shaft As-Input	440-3115
9W-4162	Bearing	396-9899
9W-4163	Race-Rlr Bearing	394-9202
9W-4175	Shaft-Xmsn Input	394-8241
9W-4662	Disc-Friction	428-7203
9W-4702	Stator-Converter	308-9939
9W-4897	Bracket As	295-6414
9W-4949	Carrier-Planet	281-1687
9W-4950	Gear-Sun	281-1688
9W-4957	Carrier-Planet	390-0913
9W-5768	Gear-Ring	380-7474
9W-5936	Hub	430-7617
9W-6044	Shaft-Planet	384-5957
9W-6046	Carrier As	388-0645
9W-6099	Piston-Clutch	391-9828
9W-6390	Sleeve	385-3795
9W-6433	Impeller-Conv	308-9871
9W-6434	Hub-Impeller	443-2018
9W-6435	Flange-Drive	308-9846
9W-7019	Disc-Friction	377-7461
9W-7040	Piston-Clutch	377-7462
9W-7458	Piston-Clutch	391-9862
9W-7481	Gear-Planet	295-6431
9W-7919	Bearing-Sleeve	425-3647
9W-7925	Cone-Roller Brg	422-6491
9W-7926	Cup-Roller Brg	421-2554
9W-8270	Gear-Ring	308-9859
9W-8384	Hub-Turbine	297-7207
9W-8437	Gear-Sun	450-7550
9W-9027	Plate	419-2306
9W-9930	Mount As	295-6437
9W-9931	Mount As.	360-2354
9W-9940	Mount As.	360-2355
9X-2192	Gasket Kit-Sch	393-5189
9X-6560	Gasket Kit	382-5073
9Y-0231	Line As-F Inj	390-0932
9Y-0232	Line As-F Inj	390-0933
9Y-0233	Line As-F Inj	390-0934
9Y-0234	Line As-F Inj	390-0935
9Y-0235	Line As-F Inj	390-0936
9Y-0236	Line As-F Inj	390-0937
9Y-0237	Line As-F Inj	390-0938
9Y-0238	Line As-F Inj	390-0939
9Y-0635	Spacer	435-8519
9Y-1403	Muffler As	393-0930
9Y-1798	Seal-Water	379-0165
9Y-1917	Pulley-Fan	395-1311
9Y-2148	Tube As-Exhaust	378-3995
9Y-2149	Tube As-Exh	374-7481
9Y-2150	Tube As-Exhaust	374-4729
9Y-2151	Tube As-Exhaust	374-7482
9Y-2988	Breather As	361-1716
9Y-2991	Bearing-Sleeve	377-5833
9Y-2992	Bearing-Sleeve	325-6032
9Y-3317	Core As-Radiator	378-3996
9Y-3318	Core As-Radiator	374-7491
9Y-3969	Line As-Fuel Inj	378-3998
9Y-4668	Muffler As	373-1911
9Y-5168	Manifold-Exhaust	374-7483
9Y-5295	Tube-Gov Conn	419-4756
9Y-6054	Rod As-Conn	379-8868
9Y-7215	Sleeve-Isolator	425-3646
9Y-7735	Bearing-Rod	419-4665
9Y-8534	Support-Shft	463-7671
9Y-9431	Precleaner As	361-1718
9Y-9497	Bearing-Conn Rod	441-1563

BUILT FOR IT.™

PECJ0051-06
www.cat.com

© 2016 Caterpillar • All Rights Reserved

CAT, CATERPILLAR, BUILT FOR IT, their respective logos, “Caterpillar Yellow” and the “Power Edge” trade dress, as well as corporate and product identity used herein, are trademarks of Caterpillar and may not be used without permission.

CAT®